

# Indicator Light Status Interpretation

## Indicator Light Status Interpretation

The USB expansion board has two indicator lights. The one closer to the outside is the PWR indicator light, and the one closer to the inside is the STATE indicator light.

PWR Indicator Light: Lights up when powered, indicating power status.

STATE Indicator Light:

| STATE Indicator Status | Function                     |
|------------------------|------------------------------|
| Off                    | Detecting module             |
| Steady On              | Connecting signal            |
| Blinking               | Signal connection successful |

