Button control

Button control

Hardware connection

Control principle

Software configuration

Pin definition

Software code


Control function

Experimental phenomenon

The tutorial demonstrates that the button controls the buzzer to sound, and the LED keeps flashing.

The tutorial only introduces the standard library project code

Hardware connection



Peripherals	Development board	Description
KEY1	PA8	One end of KEY is connected to the PA8 pin, and the other end is connected to GND

Control principle

Trigger an external interrupt through a button, and switch the buzzer sound state according to the triggered button.

Control pin	Read level	LED effect
PA8	Read low level	Switch buzzer sound state
PA8	Read high level	Do not switch buzzer sound state

• NVIC (Nested Vector Interrupt Controller)

NVIC controls the interrupt-related functions of the entire chip and provides a reliable interrupt processing mechanism for the system.

• Interrupt priority

Preemption priority: Preemption priority is used to determine the relative priority between interrupts. When an interrupt with a high preemption priority occurs, it can interrupt the interrupt with a low preemption priority being executed;


Response priority: When multiple interrupt sources have the same preemption priority, the interrupt with a high response priority will be processed first, and will not be interrupted by the interrupt with the same preemption priority but a low response priority.

• EXTI (External Interrupt)

The external interrupt/event controller consists of 19 edge detectors that generate event/interrupt requests.

Each input line can be independently configured with input type (pulse or hang-up) and corresponding trigger event (rising edge or falling edge or both edges), and each input line can be independently masked.

External interrupt/event line image



EXTIO~EXIT4 have independent interrupt channels
EXTI5~EXIT9 share the same interrupt channel: EXTI9_5_IRQ
EXTI10~EXIT15 share the same interrupt channel: EXTI15_10_IRQ

Software configuration

Pin definition

Main control chip	Pin	Main function (after reset)	Default multiplexing function	Redefine function
STM32F103RCT6	PA8	PA8	USART1_CK/TIM1_CH1/MCO	

Software code

The default function of the PA8 pin is a normal IO pin function.

```
Product supporting data source code path: Attachment \rightarrow Source code summary \rightarrow 1.Base_Course \rightarrow 4.KEY
```

Control function

The tutorial only briefly introduces the code, and you can open the project source code to read it in detail.

Key1_GPIO_Init

```
void Key1_GPIO_Init(void)
    GPIO_InitTypeDef GPIO_InitStructure;
    EXTI_InitTypeDef EXTI_InitStructure;
    NVIC_InitTypeDef NVIC_InitStructure;
    RCC_APB2PeriphClockCmd(KEY1_GPIO_CLK, ENABLE);
    GPIO_InitStructure.GPIO_Pin = KEY1_GPIO_PIN;
    GPIO_InitStructure.GPIO_Mode = GPIO_Mode_IPU;
    GPIO_Init(KEY1_GPIO_PORT, &GPIO_InitStructure);
    EXTI_InitStructure.EXTI_Line=EXTI_Line8;
    EXTI_InitStructure.EXTI_Mode = EXTI_Mode_Interrupt;
    EXTI_InitStructure.EXTI_Trigger = EXTI_Trigger_Falling;
    EXTI_InitStructure.EXTI_LineCmd = ENABLE;
    EXTI_Init(&EXTI_InitStructure);
    NVIC_InitStructure.NVIC_IRQChannel = EXTI9_5_IRQn;
    NVIC_InitStructure.NVIC_IRQChannelPreemptionPriority = 0x02;
    NVIC_InitStructure.NVIC_IRQChannelSubPriority = 0x01;
    NVIC_InitStructure.NVIC_IRQChannelCmd = ENABLE;
    NVIC_Init(&NVIC_InitStructure);
}
```

```
void EXTI9_5_IRQHandler(void)
{
    if(KEY_INT==0)
    {
        EXTI->PR=1<<8; // Clear interrupt flag
        BEEP_BEEP = !BEEP_BEEP;
    }
}</pre>
```

Experimental phenomenon

The KEY.hex file generated by the project compilation is located in the OBJ folder of the KEY project. Find the KEY.hex file corresponding to the project and use the FlyMcu software to download the program into the development board.

After the program is successfully downloaded: the LED switches on and off every 500ms; each time the KEY1 button is pressed, the sound state will be switched.