
PC serial communication

1. Device connection




2. Slide the module to STC8 serial mode




3. Open the serial debugging assistant


 Open Uart Assistant, select the corresponding serial port number, and the baud rate is 115200,



• Open the Command Word Broadcast Word Protocol List V3_EN file in the attachment




 When we say "Go ahead", the serial port debugging assistant will print out the corresponding protocol



According to the Command Word Broadcast Word Protocol List V3_EN file, enter the
corresponding command, and the voice module broadcasts the text of the corresponding
protocol





You can hear the normal broadcast of the voice module.