# **Button control skip car**

#### **Button control skip car**

- 1. Learning objectives
- 2. Building blocks
- 3. Motor wiring
- 4. Code analysis
- 5. Write and download the program
- 6. Experimental phenomenon

# 1. Learning objectives

In this course, we mainly learn how to use Python programming to achieve that when the A button on the micro:bit motherboard is pressed, the loading platform is laid flat; when the B button on the micro:bit motherboard is pressed, the loading platform is unloaded.

## 2. Building blocks

For detailed steps of building blocks, please refer to the installation drawings of [Assembly course]-[Skip car] in the materials or the building blocks installation album.


### 3. Motor wiring

The motor wiring on the left side of the car is inserted into the M1 interface of the Super:bit expansion board, and the black wire is close to the battery side;

The motor wiring on the right side of the car is inserted into the M3 interface of the Super:bit expansion board, and the black wire is close to the battery side;


The building block servo wiring is inserted into the S1 interface of the Super:bit expansion board, and the orange servo wiring is inserted into the yellow pin of S1.

As shown below:



### ! Notes:

When conducting a course related to the building block servo for the first time, we need to remove the gear on the servo first and upload the program of this course to the micro:bit; then turn on the power switch of the Super:bit expansion board and wait for the building block servo to turn to the initial position; then, we can turn off the power, adjust the angle of the car loading platform to be parallel to the ground, and then install the servo gear. (If you have used the dump truck and servo-related programs before, you can skip this step)



# 4. Code analysis

For the program of this course, please see the **Button control skip car.py** file.

from microbit import \*
import superbit

First, import the libraries needed for this lesson from microbit: the superbit library is compatible with the superbit expansion board;

```
display.show(Image.HAPPY)
superbit.servo270(superbit.S1, 240)
```

display.show(Image.HAPPY): Display a smiley face pattern on the microbit dot matrix; superbit.servo270(superbit.S1, 0): Initialize the building block servo to rotate to about 0°;

```
while True:
if button_a.is_pressed():
superbit.servo270(superbit.S1, 240)
elif button_b.is_pressed():
superbit.servo270(superbit.S1, 60)
```

In an infinite loop, determine whether the A and B buttons on the microbit mainboard are pressed. If the A button is pressed, the servo rotates to 240° (loading platform is flat); if the B button is pressed, the servo rotates to 60° (loading platform is unloading).

# 5. Write and download the program


- 1. Open the Mu software and enter the code in the editing window. **Note! All English and** symbols should be entered in English mode, use the Tab key (tab key) for indentation, and the last line ends with a blank program.
- 2. Click the thumb 'Check' button to check whether our code has errors. If a cursor or underline appears in a line, it means a syntax error. Please check and modify it. If there is no error, the lower left corner will prompt that there is no problem with the detection.

```
Mu 1.2.0 - Button control skip car.py
                                    (-1
      +)(土)(土)
                                            ⊕
                                                   Q
                                                         0
                                                                              ψ
                    ?
      New Load Save Flash Files REPL Plotter Zoom-in Zoom-out
Button control skip car.py 🗶
  1 from microbit import *
  2 import superbit
  4 display.show(Image.HAPPY)
  superbit.servo270(superbit.S1, 240)
  7 while True:
        if button_a.is_pressed():
             superbit.servo270(superbit.S1, 240)
  10
         elif button_b.is_pressed():
        superbit.servo270(superbit.S1, 60)
  11
  12
                                                                                        BBC micro:bit 🗰 🚓
Awesome! Zero problems found.
```

3. Click the 'REPL' button to check whether the Superbit library has been downloaded. If not, please refer to [Preparation before class] --> [2.4 Python Programming Guide].

```
Mu 1.2.0 - Button control skip car.pv
                                      -4-
                    (Q)
                                                   (Q)
                                                                                (h)
                Save Flash Files
Button control skip car.py 🗶
  1 from microbit import *
  2 import superbit
  4 display.show(Image.HAPPY)
  superbit.servo270(superbit.S1, 240)
  7 while True:
         if button_a.is_pressed():
             superbit.servo270(superbit.S1, 240)
  9
         elif button_b.is_pressed():
        superbit.servo270(superbit.S1, 60)
  11
  12
BBC micro:bit REPL
MicroPython v1.15-64-g1e2f0d280 on 2025-06-26; SuperbitV2 and Sensor v3.0.0 with modified by Yahboom
Type "help()" for more information.
                                                                                         BBC micro:bit 🗰 🤹
```


4. After the program is written, connect the computer and microbit mainboard with a microUSB data cable, click the 'Flash' button to download the program to the micro:bit mainboard. (You need to click the 'REPL' button again to turn off the import library file function before you can download the program normally).



5. If the download fails, please confirm whether the microbit is connected to the computer normally via the microUSB data cable and the Superbit Python library has been imported.

## 6. Experimental phenomenon

After the program is downloaded successfully, the micro:bit dot matrix will display a smiley face, as shown in the figure below. When the A button on the micro:bit motherboard is pressed, the loading platform is laid flat; when the B button on the micro:bit motherboard is pressed, the loading platform is unloaded.



If you need to restart, press the reset button on the back of the micro:bit motherboard.