

Regarding inverse kinematics, we have packaged the library file, and the user can directly adjust the library and use it.

## Code path:

dofbot\_kinematics\_fk.cpp and dofbot\_kinematics\_ik.cpp file in the dofbot\_ws/src/dofbot\_moveit/src/ directory.