

Use of adaptive grippers

C# API Usage Instructions

1. **SetGripperMode(byte mode)** Function: Set the crawl mode Return value: None Parameter description: Parameter 1: Mode: 1-transparent mode, 0-IO mode
2. **setGripperValue(byte angle, byte speed)** Function: Controlling the adaptive gripper Return value: None Parameter description: Parameter 1: Gripper opening and closing angle (0-100, 0--closed, 100-open maximum angle), Parameter 2: Gripper opening and closing speed (0-100)
3. **getGripperValue()** Function: Get the adaptive gripper angle Return value: int type, returns the gripper angle (0--closed, 100-open maximum angle) Parameter Description: None

Use Cases

setGripperValue()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SetGripperMode(0);//Transparent transmission
            Thread.Sleep(1000);
            mc.setGripperValue(0,10)
            mc.Close();
        }
    }
}
```

getGripperValue()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
```

```
static void Main(string[] args)
{
    MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
    mc.Open();
    Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
    mc.SetGripperMode(0);//Transparent transmission
    Thread.Sleep(1000);
    int num = mc.getGripperValue();
    mc.Close();
}
}
```