Button	Function	Press Jog Dial Button	Shift
1		Assignment Mode Inputs/Outputs	
2		Assignment Mode Sends	
3		Assignment Mode Volume/Pan	
4		Assignment Mode Plug-ins	
5		Previous Page	
6		Next Page	
7		Toggle Returns	
8		Toggle Track View/Time View (Position and SMPTE)	
I<	Previous Channel	Punch In	Goto first Channel
>1	Next Channel	Punch Out	Goto last Channel
<<8	Previous Bank	Set left Loop Point	Goto first Bank
8>>	Next Bank	Set right Loop Point	Goto last Bank
«	Previous Marker	Marker Home	
»	Next Marker	Marker End	
>	Play	Continue Play	Play Selection
	Stop	Show Assignment Mode and Master Fader Assignment	
ے	Loop	Set/Delete Marker	
MIX	Arrangement/Session View	View Browser	Focus
R	Return To Arrangement	View Detail	Focus
W	Zoom (see table below)	View Detail Subview	Focus
SEL		Metronome	
SEL 2		Follow Song	
SEL 3		Draw	
SEL 4		Shift	
SEL 5		Control	
SEL 6		Alt	
SEL 7		Redo	
SEL 8		Undo	
Touch M	aster Fader	Toggle Fader: Master Volume/Cue Volume	

Zoom button and Jog Dial behaviour

Zoom	Cursor	Jog Dial	Session View
		Left/Right	Select Clip: 1 Turn = 1 Step (Cursor up/down)
	(=)	Left/Right	Select Track (Cursor left/right)
	(Left/Right	Select Clip: 1 Turn = 1 Step (Cursor up/down)
W			Trigger clip + Shift: Stop clip + Ctrl: Add/remove Stop button + Alt: Trigger scene + Alt + Shift: Stop all clips
Zoom	Cursor	Jog Dial	Arrangement View
		Left/Right	Play Position: Movement in 1/4 Press Jog Dial Button: Adjust Tempo Press Jog Dial Button + Shift: Adjust Tempo in small steps
	(=)	Left/Right	Play Position: Movement in 1/16 Press Jog Dial Button: Select time section
	(‡)	Left/Right	Select Track (Cursor up/down)
W	(=)	Left/Right	Zoom Arrangement
W	(1)	Left/Right	Zoom Track Press Jog Dial Button: Zoom all Tracks

Additional functions:

Pressing the two buttons and simultaneously flips Fader and Pots.

Pressing the Jog Dial Button you can exclusive Arm and Solo tracks.

Bug:

Pressing the two buttons and simultaneously stops sending MIDI messages for these two buttons.