

CNC Bravo-2 — Operation & Maintenance Manual

Overview

CNC Bravo-2 is a horizontal machining center for batch production. Currently under scheduled maintenance for spindle bearing replacement.

Safety

Two-hand start required for automatic cycle. Interlock doors must be closed. Hearing protection recommended above 85 dB.

Maintenance Mode

Machine is in MAINTENANCE status. Do not attempt production runs until maintenance lead clears the unit.

Spindle Bearing Replacement

Order part SKF-7014. Torque spindle nut to 180 Nm. Run break-in program at 50% RPM for 30 minutes.

Calibration

After bearing replacement, perform spindle warm-up (15 min), then tool length probe calibration on all active tools.

Emergency Contacts

- 1 Maintenance Lead: ext. 204
- 2 Plant Manager: ext. 101
- 3 Safety Officer: ext. 999