

TC ID	Test Scenario	Preconditions	Test Steps	Test Data	Expected Result	Actual Result	Status
PEN_01	Check cap opening	Pen available	Open cap	Pen	Cap opens smoothly	TBD	Pass/Fail
PEN_02	Check cap closing	Cap opened	Close cap	Pen	Cap closes properly	TBD	Pass/Fail
PEN_03	Verify ink flow	Pen with ink	Write on paper	A4 paper	Continuous ink flow	TBD	Pass/Fail
PEN_04	Check writing quality	Ink available	Write sentence	"Hello"	Clear writing	TBD	Pass/Fail
PEN_05	Check pen grip	Pen available	Hold pen	Hand	Comfortable grip	TBD	Pass/Fail
PEN_06	Verify pen tip	Pen available	Inspect tip	Visual	Tip not damaged	TBD	Pass/Fail
PEN_07	Check refill	Pen available	Open body	Refill	Refill fitted properly	TBD	Pass/Fail
PEN_08	Replace refill	New refill available	Replace refill	New refill	Replaced successfully	TBD	Pass/Fail
PEN_09	Leakage test	Pen filled	Keep upside down	1 hour	No leakage	TBD	Pass/Fail
PEN_10	Drop test	Pen available	Drop from table	Height 3 ft	No damage	TBD	Pass/Fail
PEN_11	Pocket clip test	Pen available	Attach to pocket	Shirt pocket	Clip works	TBD	Pass/Fail
PEN_12	Ink color check	Pen available	Write on paper	White paper	Correct color	TBD	Pass/Fail
PEN_13	Long writing test	Pen ready	Write for 10 mins	Notebook	Smooth writing	TBD	Pass/Fail
PEN_14	Body strength	Pen available	Press body	Manual	No crack	TBD	Pass/Fail
PEN_15	Ink dry test	Written text	Wait 10 sec	Paper	Ink dries	TBD	Pass/Fail
PEN_16	Start after idle	Pen unused	Write after 1 day	Notebook	Starts immediately	TBD	Pass/Fail
PEN_17	Temperature test	Pen available	Store hot/cold	40°C / 5°C	Works properly	TBD	Pass/Fail

PEN_18	Brand label check	New pen	Inspect body	Visual	Correct label	TBD	Pass/Fail
PEN_19	End ink test	Low ink pen	Write	Notebook	Fades properly	TBD	Pass/Fail
PEN_20	Packaging test	New packed pen	Open pack	Package	No damage	TBD	Pass/Fail

TC ID	Test Scenario	Preconditions	Test Steps	Test Data	Expected Result	Actual Result	Status
TV_01	Power ON	TV plugged in	Press power button	Button	TV turns ON	TBD	Pass/Fail
TV_02	Power OFF	TV ON	Press power	Button	TV turns OFF	TBD	Pass/Fail
TV_03	Remote power	Remote ready	Press power on remote	Remote	TV turns ON/OFF	TBD	Pass/Fail
TV_04	Volume up	TV ON	Press Vol+	Remote	Volume increases	TBD	Pass/Fail
TV_05	Volume down	TV ON	Press Vol-	Remote	Volume decreases	TBD	Pass/Fail
TV_06	Mute function	TV ON	Press mute	Remote	Sound muted	TBD	Pass/Fail
TV_07	Channel up	Channels available	Press CH+	Remote	Next channel	TBD	Pass/Fail
TV_08	Channel down	Channels available	Press CH-	Remote	Previous channel	TBD	Pass/Fail
TV_09	Numeric channel	TV ON	Enter channel no.	101	Channel opens	TBD	Pass/Fail
TV_10	Display quality	Video source connected	Play video	HD video	Clear display	TBD	Pass/Fail
TV_11	Sound quality	Speaker ON	Play audio	Audio file	Clear sound	TBD	Pass/Fail
TV_12	Brightness setting	TV ON	Adjust brightness	Settings	Brightness changes	TBD	Pass/Fail
TV_13	Contrast setting	TV ON	Adjust contrast	Settings	Contrast changes	TBD	Pass/Fail

TV_14	HDMI connection	HDMI cable ready	Connect laptop	HDMI	Screen mirrored	TBD	Pass/Fail
TV_15	USB detection	USB ready	Insert USB	USB drive	Files visible	TBD	Pass/Fail
TV_16	Wi-Fi connection	Router ON	Connect Wi-Fi	SSID/Password	Connected	TBD	Pass/Fail
TV_17	Open app	Internet ON	Launch app	YouTube	App opens	TBD	Pass/Fail
TV_18	Standby mode	TV idle	Wait	10 min	Enters standby	TBD	Pass/Fail
TV_19	Remote battery	Batteries inserted	Press buttons	AAA battery	Remote works	TBD	Pass/Fail
TV_20	Factory reset	TV configured	Reset settings	Settings menu	Defaults restored	TBD	Pass/Fail