

STCS-evo500TS – Remote Configuration

Menu 'Configuration' >> 'M1' >> 'Remote Mode':

The "Remote Mode" parameter defines how the machine connects to external devices. If this parameter is equal to:

OFF: the system cannot be configured externally;

ON-TON: both the shrinking time and the process temperature can be configured;

ON-TOFF: only the shrinking time can be configured externally.

Menu 'Configuration' >> 'M1' >> 'Blockage Mode':

The "Remote Mode Blockage" parameter defines if the machine blocks after receiving data from the ultrasonic welding machine and after performing a valid shrinking operation. If this parameter is equal to:

OFF: the system does not block, i.e. it is possible to perform several operations without receiving new data from the welding machine;

ON: only makes one shrinking operation after receiving data from USW machine. After a successfully shrinking operation, the STCS-evo500TS blocks, waiting for new information from the USW machine i.e. one welding one shrinking, the machine blocks too if receive 00s (zero seconds) to shrinking time from the USW machine that means that a bad weld occurs;

ON-BOX (*):

1) After the welding process, the ultrasonic welding machine sends via serial port (RS232) the shrinking parameters to the Mecalbi machine and automatically locks waiting for the feedback;

2) Once the operator presses the start buttons on the Mecalbi machine, the ultrasonic welding machine receives the feedback (a signal with the character DC2 - ASCII 18) and unlocks, waiting for a new cycle;

3) All shrinking parameters with more than 00s (zero seconds) shrinking time will be considered valid by the Mecalbi machine;

4) If the shrinking time sent by the ultrasonic welding machine is equal to 00s (zero seconds), the Mecalbi machine locks preventing any operation and will only unlock again when receiving valid shrinking parameters. In this case, it is considered that either there was an error during the welding process or the splice is for taping.

ON-BOX-ON (*):

ON + ON-BOX – enables both functionalities. The machine will behave as described on **ON-BOX** and will lock after each operation (as described on **ON** function) until new valid data from USW machine.

(*)Requirements:

- STCS-evo500TS with firmware version 077715-33-000-R41 or higher;
- Schunk machine with software version 3.4.118 or higher.