SmartX ■■■■ - User Manual

1. Product Overview

The SmartX lock supports fingerprint, password, and NFC unlocking.
It is powered by 4 AA batteries which can last up to 12 months.

2. How to Reset the Lock

If you forget the admin password, press and hold the reset button located inside the battery compartment for 5 seconds.
Wait for a long beep sound, then the lock will restore factory settings.

3. Troubleshooting

Problem: The lock says 'Low Battery' but the batteries are new.
Solution: Ensure you are using 1.5V alkaline batteries, not 1.2V rechargeable batteries.

Problem: Fingerprint not recognized.
Solution: Clean the fingerprint sensor with a dry cloth and ensure your finger is dry.