

# ACOPOS D1 伺服固件升级说明

关键词: ACOPOS D1、固件升级

Date: March 8, 2024

Project Number: AT-xx-xxxxx

We reserve the right to change the content of this manual without prior notice. The information contained herein is believed to be accurate as of the date of publication, however, B&R makes no warranty, expressed or implied, with regards to the products or the documentation contained within this document. B&R shall not be liable in the event if incidental or consequential damages in connection with or arising from the furnishing, performance or use of these products. The software names, hardware names and trademarks used in this document are registered by the respective companies.

### I Versions

Version	Date	Comment	Edited by
1.0	Feb 6, 2024	初版整理	Zhou Shenyang

Table 1: Versions

## **II** Distribution

Name	Company, Department	Amount	Remarks

Table 2: Distribution

# **III** Safety Notices

Safety notices in this document are organized as follows:

Safety notice	Description
Danger!	Disregarding the safety regulations and guidelines can be life-threatening.
Warning!	Disregarding the safety regulations and guidelines can result in severe injury or heavy damage to material.
Caution!	Disregarding the safety regulations and guidelines can result in injury or damage to material.
Information:	Important information used to prevent errors.

Table 3: Safety notices

## **IV** Table of Contents

1. 适用范围	4
2. 原理概述	4
3. 调试环境	
4. 技术实现	4
5 参考资料	8

#### 1. 适用范围

伺服常规升级、功能添加、BUG 修复等可使用该方法进行固件升级。

#### 2. 原理概述

ACOPOS D1 支持固件在线升级,升级列表放有最近 3 次上传的固件程序,一般情况客户不需要升级。


每一个伺服都有一个唯一的序列号,使用 ACOPOS D1 Studio 软件查询到驱动对应的序号,将序号和需求一起交给贝加莱的工作人员,可对该伺服单独上传程序,待升级程序上传至服务器后,客户可在现场在线升级到最新版本。

#### 1. 调试环境


- -ACOPOS D1 伺服驱动器。
- -PC
- -ACOPOS D1 Studio 上位机软件 V1.0。

#### 2. 技术实现


1. 打开 ACOPOS D1 Studio 软件, 界面如下:




2. 电脑连接网络后,点击"固件升级"按钮,弹出升级界面,然后点击右侧的"检测"按钮,弹出连接设置,然后点击"打开串口",最后点击"完成"。




3. 弹出升级对话框,复制序号栏中的序号,将序号与需求一起递交给贝加莱工作人员,待新的固件程序上传后可在线升级,如果列表中有需要的固件程序可直接升级。



4. 新版本发布后重复 1-3 步, 弹出升级对话框, 选择需要升级的固件版本, 点击右下角的 "更新"按钮, 等待提示"成功"。



5. 更新成功后, 伺服会自动重启到普通模式, 至此升级完成。



注: 1.固件升级过程中请勿断电!

2.固件升级<mark>有可能</mark>会根据版本不同会缺省参数至出厂值,建议用户升级前备份一下伺服 参数。

#### 3. 参考资料

《ACOPOS D1 Studio V1.0 使用手册》