AVIATESAIR

OM-B

Operations Manual Part B

Aircraft operating matters: limitations, configuration policy and handling notes for each fleet.

REVISION	EFFECTIVE	DOCUMENTS	ISSUED BY
0	24 SEP 2026	8	AviatesAir Flight Operations

This copy is uncontrolled once printed or saved. The current revision is always in the AviatesAir EFB (Manuals).
For flight simulation use only. Not for real-world aviation.

List of effective documents

DOCUMENT	TITLE	REV	EFFECTIVE
OM-B 0	Fleet Overview & Configuration Policy	0	24 SEP 2026
OM-B A320	Airbus A319 / A320neo	0	24 SEP 2026
OM-B A350	Airbus A350-900	0	24 SEP 2026
OM-B A380	Airbus A380-800	0	24 SEP 2026
OM-B 737	Boeing 737-600 / -800 / -900ER / MAX 8	0	24 SEP 2026
OM-B 777F	Boeing 777F (Skycargo)	0	24 SEP 2026
OM-B 747-8	Boeing 747-8	0	24 SEP 2026
OM-B ATR	ATR 72-600 / ATR 42-600	0	24 SEP 2026

Contents

OM-B 0 Fleet Overview & Configuration Policy
- The fleet
- Company configuration policy
- Normal checklists

OM-B A320 Airbus A319 / A320neo
- Fleet
- Speed limitations
- Configuration policy
- Handling notes
- Checklist

OM-B A350 Airbus A350-900
- Fleet
- Configuration policy
- Handling notes
- Checklist

OM-B A380 Airbus A380-800
- Fleet
- Airport and ground requirements
- Wake turbulence
- Configuration policy
- Handling notes
- Checklist

OM-B 737 Boeing 737-600 / -800 / -900ER / MAX 8
- Fleet
- Flap placard speeds (737-800)
- Configuration policy
- Handling notes
- Checklists

OM-B 777F Boeing 777F (Skycargo)
- Fleet
- Cargo operations
- Configuration policy
- Handling notes
- Checklist

OM-B 747-8 Boeing 747-8
- Fleet
- Configuration policy
- Handling notes
- Checklist

OM-B ATR ATR 72-600 / ATR 42-600
- Fleet
- Hotel mode and propeller brake
- Icing
- Configuration policy
- Handling notes
- Checklists

Fleet Overview & Configuration Policy

The AviatesAir fleet at a glance: types, brands, roles, typical weights and the company takeoff/landing configuration policy for every type.

> **NOTE** Figures in OM-B are **typical** for the type and variant. Your add-on's own documentation takes precedence where it differs.

The fleet

TYPE	ICAO	BRAND	ROLE	TYPICAL MTOW	CHAPTER
Airbus A319	A319	CityHopper	Short haul	75.5 t	OM-B A320
Airbus A320neo	A20N	Mainline	Short / medium haul	79.0 t	OM-B A320
Airbus A350-900	A359	Mainline	Long haul	283 t	OM-B A350
Airbus A380-800	A388	Mainline	Long haul, trunk routes	575 t	OM-B A380
Boeing 737-600	B736	CityHopper	Short haul	65.5 t	OM-B 737
Boeing 737-800	B738	Mainline	Short / medium haul	79.0 t	OM-B 737
Boeing 737-900ER	B739	Mainline	Medium haul, high density	85.1 t	OM-B 737
Boeing 737 MAX 8	B38M	Mainline	Short / medium haul	82.2 t	OM-B 737
Boeing 777F	B77F	Skycargo	Long-haul freighter	347.8 t	OM-B 777F
Boeing 747-8	B748	Mainline	Long haul	447.7 t	OM-B 747-8
ATR 72-600	AT76	CityHopper	Regional	23.0 t	OM-B ATR
ATR 42-600	AT46	CityHopper	Regional, short fields	18.6 t	OM-B ATR

Company configuration policy

TYPE	TAKEOFF FLAP	LANDING FLAP: STANDARD	LANDING FLAP: MINIMUM
A319 / A320neo	CONF 1+F, 2 or 3 (OPT)	**CONF FULL**	**CONF 3** (CN-003)
A350	CONF 1+F, 2 or 3	CONF FULL	CONF 3
A380	CONF 1+F, 2 or 3	CONF FULL	CONF 3
737 NG / MAX	**FLAPS 5 minimum** (CN-002); 10, 15, 25 as required	**FLAPS 30**	**FLAPS 25** (CN-003)

TYPE	TAKEOFF FLAP	LANDING FLAP: STANDARD	LANDING FLAP: MINIMUM
777F	FLAPS 5, 15 or 20	FLAPS 30	FLAPS 25
747-8	FLAPS 10 or 20	FLAPS 30	FLAPS 25
ATR 72-600	FLAPS 15	FLAPS 30	FLAPS 15 in icing / as required
ATR 42-600	FLAPS 15	FLAPS 35	FLAPS 25 as required

> **NOTE** Only the 737 and A320-family entries are company **restrictions** (Company NOTAMs). The others describe normal practice.

Normal checklists

Every type has its own normal checklist in the QRH and in the EFB **Checklists** app.

Airbus A319 / A320neo

Key data, speed limitations, configuration policy (CONF 3 minimum for landing) and handling notes for the AviatesAir A319 (CityHopper) and A320neo (Mainline).

Fleet

	A319	A320NEO
Brand	CityHopper (VAH)	Mainline (VAV)
Engines	CFM56-5B / IAE V2500	CFM LEAP-1A / PW1100G
Typical MTOW	75,500 kg	79,000 kg
Typical MLW	62,500 kg	67,400 kg
Typical MZFW	58,500 kg	64,300 kg
Max operating altitude	39,800 ft	39,800 ft
VMO / MMO	350 kt / M0.82	350 kt / M0.82

Speed limitations

CONFIGURATION	VFE
CONF 1	230 kt
CONF 1+F	215 kt
CONF 2	200 kt
CONF 3	185 kt
CONF FULL	177 kt

LANDING GEAR	SPEED
VLO extension	250 kt
VLO retraction	220 kt
VLE	280 kt / M0.67

Configuration policy

- **Takeoff:** CONF 1+F, 2 or 3 from EFB Departure Perf (OPT recommended). FLEX when performance allows.
- **Landing: CONF FULL standard; CONF 3 minimum** (CN-003). Choose CONF 3 for a reason (windshear expected, go-around performance) and brief it.

- **Autobrake:** LO for normal landings on long dry runways, MED for short or wet runways.

Handling notes

- **Managed** speed and descent are normal. Monitor the energy circle and the descent profile, and use speedbrakes early rather than late.
- **Approach speed:** VAPP = VLS + the greater of 5 kt (A/THR ON) and ⅓ of the headwind component, 15 kt maximum. EFB Arrival Perf computes it.
- **Flare:** at about 30 ft. "RETARD" is called at 20 ft: bring the thrust levers to idle. Avoid holding the aircraft off; the A320 family floats readily.
- **Tail-strike awareness:** don't over-rotate. Target about 15° after lift-off at 3° per second.
- **neo:** allow for the longer engine warm-up before takeoff thrust and the cool-down before shutdown that the add-on's procedures call for.

Checklist

QRH normal checklist: A319 / A320neo

Airbus A350-900

Key data, configuration policy and long-haul handling notes for the AviatesAir A350-900.

Fleet

	A350-900
Brand	Mainline (VAV)
Engines	Rolls-Royce Trent XWB-84
Typical MTOW	283,000 kg
Typical MLW	207,000 kg
Typical MZFW	195,700 kg
Max operating altitude	43,100 ft
VMO / MMO	340 kt / M0.89

Configuration policy

- **Takeoff:** CONF 1+F, 2 or 3 per performance. FLEX is normal on long-haul departures. Heavy departures commonly need CONF 2 or 3.
- **Landing: CONF FULL standard**; CONF 3 when briefed (windshear, go-around performance).
- **Braking: BTV** (brake-to-vacate) is preferred where the runway exit is known: select the exit in the approach briefing. Otherwise use autobrake LO/2/3 as the runway requires.

Handling notes

- **Pitch trim** is set automatically on the ground, so there's no trim setting in the checklist. Check the takeoff data instead.
- **Long haul:** plan crew rest and fuel checks at every ETOPS entry point and waypoint. Keep the step-climb plan from the OFP.
- **Descent planning:** allow for a long, shallow deceleration. Start the descent on the managed profile and use speedbrakes early rather than late.
- **Flare** at about 30 ft, idle by touchdown. The A350 is stable in the flare, so avoid the tendency to hold it off.

Checklist

QRH normal checklist: A350

Airbus A380-800

Key data, wake turbulence, airport and gate requirements, configuration policy and handling notes for the AviatesAir A380.

Fleet

	A380-800
Brand	Mainline (VAV)
Engines	Rolls-Royce Trent 900 / Engine Alliance GP7200
Typical MTOW	575,000 kg
Typical MLW	394,000 kg
Typical MZFW	369,000 kg
Max operating altitude	43,100 ft
VMO / MMO	340 kt / M0.89
Wake category	**Super (J)**, RECAT-EU category A

Airport and ground requirements

- The A380 needs **Code F** taxiways, stands and runways. Plan only to airports with A380 routes; they're approved for it.
- Expect **longer pushback and taxi times** and follow-me vehicles at some airports.
- Use the gate the airport scenery designates for the A380. Upper-deck boarding bridges are needed for a realistic turnaround.

Wake turbulence

- File and fly as **"Super"** on the network. Aircraft behind you need enlarged separation: up to 8 NM for a light aircraft on approach.
- Departing behind another A380, allow at least **3 minutes** unless ATC applies radar separation.

Configuration policy

- **Takeoff:** CONF 1+F, 2 or 3 per performance, with FLEX.
- **Landing: CONF FULL standard**. **BTV** is preferred where the exit is known; otherwise autobrake per the runway state.

Handling notes

- **Inertia:** plan speed and altitude changes well ahead. The aircraft decelerates slowly in level flight.

- **Flare** at about 40–50 ft with a small pitch change and progressive thrust reduction. Touch down on the main gear and lower the nose promptly.
- **Taxi** with the external taxi camera system. Keep the nose wheel on the centreline in turns and watch for wingtip clearance.

Checklist

QRH normal checklist: A380

Boeing 737-600 / -800 / -900ER / MAX 8

Key data, flap placards, company flap restrictions (FLAPS 5 minimum for takeoff, FLAPS 25 minimum for landing) and handling notes for the 737 NG and MAX fleet.

WARNING Company restrictions apply to this fleet: **FLAPS 5 minimum for takeoff** (CN-002) and **FLAPS 25 minimum for landing** (CN-003).

Fleet

	737-600	737-800	737-900ER	737 MAX 8
Brand	CityHopper	Mainline	Mainline	Mainline
Engines	CFM56-7B	CFM56-7B	CFM56-7B	CFM LEAP-1B
Typical MTOW	65,500 kg	79,000 kg	85,100 kg	82,200 kg
Typical MLW	55,100 kg	66,400 kg	71,400 kg	69,300 kg
Typical MZFW	51,700 kg	62,700 kg	67,700 kg	65,900 kg
Max operating altitude	41,000 ft	41,000 ft	41,000 ft	41,000 ft
VMO / MMO	340 kt / M0.82	340 kt / M0.82	340 kt / M0.82	340 kt / M0.82

Flap placard speeds (737-800)

FLAPS	1	2	5	10	15	25	30	40
Max speed (kt)	250	250	250	210	200	190	175	162

LANDING GEAR	SPEED
Extension (VLO)	270 kt / M0.82
Retraction (VLO)	235 kt
Extended (VLE)	320 kt / M0.82

Configuration policy

- **Takeoff: FLAPS 5 standard and minimum.** FLAPS 10, 15 or 25 for limiting runways. **FLAPS 1 is not permitted** (CN-002).
- **Landing: FLAPS 30 standard; FLAPS 25 minimum**; FLAPS 40 for short, wet or contaminated runways (CN-003).
- **Autobrake:** RTO for takeoff; 2 for normal landings, 3 for wet or shorter runways, MAX for contaminated runways.
- **Speedbrake:** ARMED for landing; check that it deploys on touchdown.

Handling notes

- **Rotation:** a smooth 2–3° per second towards about 15° nose-up. The longer the fuselage, the smaller the **tail-strike margin**: the 737-800, MAX 8 and especially the -900ER have far less than the -600. Never rotate before VR, and never rotate rapidly.
- **Approach speed:** VREF + ½ the steady headwind + the full gust increment, minimum +5 kt, maximum +20 kt.
- **Flare:** begin at about 20 ft, raise the nose 2–3° and retard the thrust to idle. **Don't hold it off.** The 737 lands best firmly and on speed, and floating risks a tail strike on the -900ER.
- **Pitch at touchdown:** keep the normal landing attitude; don't push the nose down in the flare (a flat or nose-low touchdown risks a nose-gear-first landing), and never raise it to stretch the float.
- **MAX 8:** probe heat stays in **AUTO** (see the checklist). The LEAP-1B needs a longer warm-up before takeoff thrust.

Checklists

QRH normal checklist: 737-600/-800/-900ER · QRH normal checklist: 737 MAX 8

Boeing 777F (Skycargo)

Key data, cargo loading and dangerous goods, configuration policy and handling notes for the AviatesAir Skycargo 777 Freighter.

Fleet

	777F
Brand	Skycargo (VAC)
Engines	GE90-110B1
Typical MTOW	347,800 kg
Typical MLW	260,800 kg
Typical MZFW	248,100 kg
Max payload	about 102,000 kg
Max operating altitude	43,100 ft
VMO / MMO	330 kt / M0.89

Cargo operations

- **Loadsheet:** check the OFP's zero-fuel weight and the loadsheet MACZFW / MACTOW against the EFB (Pilot Brief → Loadsheet) before computing takeoff performance. Late changes of more than 1,000 kg need a new performance calculation.
- **Payload** is in kilograms on the loadsheet. Enter takeoff weight in tonnes in Departure Perf.
- **Supernumeraries:** couriers and animal handlers travel in the upper-deck area and receive a safety briefing.
- Only dangerous goods listed on the **NOTOC** (notice to captain) are carried. Brief their location and the fire drill for the main deck.

Configuration policy

- **Takeoff:** FLAPS 5, 15 or 20 per performance. Heavy freighter departures often need 15 or 20. Use derate or assumed temperature where performance allows.
- **Landing: FLAPS 30 standard**; FLAPS 25 when briefed.
- **Autobrake:** RTO for takeoff; 2 or 3 for landing as the runway requires.

Handling notes

- **Rotation:** a steady 2–2.5° per second. The long fuselage has a limited tail-strike margin, and the tail skid gives an early warning.
- **Approach:** the 777 is stable but slow to decelerate. Be configured and on speed by the 1,000 ft gate at heavy weights.

- **Flare** at about 30 ft, retard at about 25 ft, and don't float.

Checklist

QRH normal checklist: 777F

Boeing 747-8

Key data, configuration policy and handling notes for the AviatesAir 747-8 (Intercontinental data, freighter variant noted).

Fleet

	747-8 INTERCONTINENTAL	747-8F (IF FLOWN)
Brand	Mainline (VAV)	Mainline (VAV)
Engines	GEnx-2B67	GEnx-2B67
Typical MTOW	447,700 kg	447,700 kg
Typical MLW	312,100 kg	346,100 kg
Typical MZFW	295,300 kg	329,800 kg
Max operating altitude	43,100 ft	43,100 ft
VMO / MMO	365 kt / M0.90	365 kt / M0.90

Configuration policy

- **Takeoff:** FLAPS 10 or 20 per performance, with assumed temperature or derate where available.
- **Landing: FLAPS 30 standard**; FLAPS 25 when briefed (for example for go-around performance at high weights).
- **Autobrake:** RTO for takeoff; 2, 3 or 4 for landing as the runway requires.

Handling notes

- **Four engines:** set takeoff thrust symmetrically and monitor all four through the takeoff roll. An engine failure after V1 needs less rudder than on a twin, but still needs prompt, accurate rudder.
- **Rotation:** about 2–3° per second to the target attitude. Mind the tail on the long-bodied -8.
- **Flare:** begin at about 30 ft, and reduce thrust to idle during the flare. Keep the wings level. The outboard engine pods sit low in a crosswind.
- **Taxi:** judge turns from the main-gear position, which is well behind you, and use oversteer at narrow taxiway junctions.

Checklist

QRH normal checklist: 747-8

ATR 72-600 / ATR 42-600

Key data, hotel mode and propeller brake, icing, configuration policy and turboprop handling notes for the AviatesAir CityHopper ATR fleet.

Fleet

	ATR 72-600	ATR 42-600
Brand	CityHopper (VAH)	CityHopper (VAH)
Engines	2 × PW127M	2 × PW127M
Typical MTOW	23,000 kg	18,600 kg
Typical MLW	22,350 kg	18,300 kg
Typical MZFW	21,000 kg	17,000 kg
Max operating altitude	25,000 ft	25,000 ft
VMO	250 kt	250 kt

Hotel mode and propeller brake

- **Engine 2** can run with the **propeller brake ON** (hotel mode) to provide electrical power and air conditioning on the ground, like an APU.
- Never approach the right-hand propeller while engine 2 is running in hotel mode. Treat it as a running engine.
- **Before taxi:** propeller brake **OFF** (the "unfeather" sequence), condition levers **AUTO**.
- **After landing:** taxi in on engine 2. Shut down engine 1 (CL FTR then FUEL SO) after at least **one minute** at idle.

Icing

- The ATR operates at levels where icing is common. When the **ICING AOA** light is on, the icing speeds apply (the red bugs) and the **minimum manoeuvring speeds increase**.
- Engage the airframe de-icing boots at the first sign of ice accretion and keep them on until clear of icing conditions.
- In **severe icing** (ice on the side windows, unexpected roll or heavy vibration): leave the icing conditions immediately and disengage the autopilot while holding the controls firmly.

Configuration policy

	ATR 72-600	ATR 42-600
Takeoff	**FLAPS 15**	**FLAPS 15**
Landing: standard	**FLAPS 30**	**FLAPS 35**

	ATR 72-600	ATR 42-600
Landing: alternative	FLAPS 15 (icing or as required)	FLAPS 25 (as required)

- Power management selector: **TO** for takeoff, **MCT** after an engine failure, **CLB** and **CRZ** as the phases require.
- TLU **LO SPD** for landing (check it has moved).

Handling notes

- **Rotation** at VR to about 6–8°. The ATR 72 has a long fuselage, so don't over-rotate.
- **Approach:** a stable 3° path at VAPP, with power (not pitch) controlling speed. Keep a little power in the flare.
- **Flare** is small: reduce power progressively from about 20 ft and let the aircraft settle. Avoid pulling the power to flight idle high up, as the sink rate builds quickly.
- **Crosswind:** the ATR has a relatively low wing loading and a high wing. Hold aileron into wind during the takeoff and landing roll, and engage the gust lock only when parked.
- **Tail prop:** fit the **tail stand** on the ATR 72 whenever it is parked (it isn't needed on the ATR 42).

Checklists

QRH normal checklist: ATR 72-600 · QRH normal checklist: ATR 42-600