AVIATESAIR

LIBRARY

Operations Manual Library

Company NOTAMs, Operations Manual Parts A and B, Quick Reference Handbook and Pilot Guides

REVISION	EFFECTIVE	DOCUMENTS	ISSUED BY
0	24 SEP 2026	33	AviatesAir Flight Operations

This copy is uncontrolled once printed or saved. The current revision is always in the AviatesAir EFB (Manuals).
For flight simulation use only. Not for real-world aviation.

List of effective documents

DOCUMENT	TITLE	REV	EFFECTIVE
CN-001	Aircraft Registrations: Fleet-Wide Use	0	24 SEP 2026
CN-002	Boeing 737 NG / MAX Takeoff Flap Restriction	0	24 SEP 2026
CN-003	Minimum Landing Flap for the Boeing 737 and Airbus A320 Family	0	24 SEP 2026
OM-A 0	Introduction & Manual Control	0	24 SEP 2026
OM-A 1	Operational Policy & Flight Planning	0	24 SEP 2026
OM-A 2	Fuel Policy	0	24 SEP 2026
OM-A 3	Weather, Minima & Runway Condition	0	24 SEP 2026
OM-A 4	Standard Operating Procedures	0	24 SEP 2026
OM-A 5	Approach & Landing Policy	0	24 SEP 2026
OM-A 6	Flight Data Monitoring & Landing Assessment	0	24 SEP 2026
OM-A 7	Online Network Operations	0	24 SEP 2026
OM-A 8	Abnormal & Emergency Policy	0	24 SEP 2026
OM-B 0	Fleet Overview & Configuration Policy	0	24 SEP 2026
OM-B A320	Airbus A319 / A320neo	0	24 SEP 2026
OM-B A350	Airbus A350-900	0	24 SEP 2026
OM-B A380	Airbus A380-800	0	24 SEP 2026
OM-B 737	Boeing 737-600 / -800 / -900ER / MAX 8	0	24 SEP 2026
OM-B 777F	Boeing 777F (Skycargo)	0	24 SEP 2026
OM-B 747-8	Boeing 747-8	0	24 SEP 2026
OM-B ATR	ATR 72-600 / ATR 42-600	0	24 SEP 2026
QRH 0	Immediate Actions (Memory Items)	0	24 SEP 2026
QRH NC 1	Normal Checklist: Airbus A319 / A320neo	0	24 SEP 2026
QRH NC 2	Normal Checklist: Airbus A350	0	24 SEP 2026
QRH NC 3	Normal Checklist: Airbus A380	0	24 SEP 2026
QRH NC 4	Normal Checklist: Boeing 737-600/-800/-900ER	0	24 SEP 2026
QRH NC 5	Normal Checklist: Boeing 737 MAX 8	0	24 SEP 2026
QRH NC 6	Normal Checklist: Boeing 777F	0	24 SEP 2026
QRH NC 7	Normal Checklist: Boeing 747-8	0	24 SEP 2026
QRH NC 8	Normal Checklist: ATR 72-600	0	24 SEP 2026
QRH NC 9	Normal Checklist: ATR 42-600	0	24 SEP 2026

DOCUMENT	TITLE	REV	EFFECTIVE
GUIDE 1	The AviatesAir Tracker & ACARS	0	24 SEP 2026
GUIDE 2	Using the AviatesAir EFB	0	24 SEP 2026
GUIDE 3	Weather & Performance Know-How	0	24 SEP 2026

Contents

CN-001 Aircraft Registrations: Fleet-Wide Use
- Notice
- The one condition: routes for your type
- What does not change

CN-002 Boeing 737 NG / MAX Takeoff Flap Restriction
- Restriction
- Why
- How the tools apply it

CN-003 Minimum Landing Flap for the Boeing 737 and Airbus A320 Family
- Restriction
- Why
- How the tools apply it

OM-A 0 Introduction & Manual Control
- The document library
- Order of precedence
- Terminology
- Revisions

OM-A 1 Operational Policy & Flight Planning
- The operation
- Callsigns and flight numbers
- Bookings
- Routes and aircraft types
- Repositioning
- The life of a flight
- Pilot responsibilities

OM-A 2 Fuel Policy
- Planned fuel
- In-flight fuel management
- Fuel declarations

OM-A 3 Weather, Minima & Runway Condition
- Planning minima
- Takeoff and approach minima
- Crosswind and tailwind
- Runway condition and the Global Reporting Format (GRF)
- Low-visibility operations
- Thunderstorms, icing and windshear

OM-A 4 Standard Operating Procedures
- Philosophy
- PF and PM duties
- Flows and checklists
- Briefings
- Sterile flight deck
- Automation
- Altimeter setting
- Speed limits
- Ground operations
- Noise abatement departure

OM-A 5 Approach & Landing Policy
- Stabilised approach criteria
- Go-around policy
- Landing technique
- Deceleration
- Landing flap policy

OM-A 6 Flight Data Monitoring & Landing Assessment
- What is recorded
- Landing score
- FDM events
- Held for review
- Just culture

OM-A 7 Online Network Operations
- Before you connect
- On the frequency
- When there's no ATC
- Datalink
- Events
- Non-normals online

OM-A 8 Abnormal & Emergency Policy
- Handling a non-normal
- Declaring an emergency
- Squawk codes
- Diversion
- Overweight landing
- Rejected takeoff
- Tail strike and hard landing
- Reporting occurrences

OM-B 0 Fleet Overview & Configuration Policy
- The fleet
- Company configuration policy
- Normal checklists

OM-B A320 Airbus A319 / A320neo

- Fleet
- Speed limitations
- Configuration policy
- Handling notes
- Checklist

OM-B A350 Airbus A350-900

- Fleet
- Configuration policy
- Handling notes
- Checklist

OM-B A380 Airbus A380-800

- Fleet
- Airport and ground requirements
- Wake turbulence
- Configuration policy
- Handling notes
- Checklist

OM-B 737 Boeing 737-600 / -800 / -900ER / MAX 8

- Fleet
- Flap placard speeds (737-800)
- Configuration policy
- Handling notes
- Checklists

OM-B 777F Boeing 777F (Skycargo)

- Fleet
- Cargo operations
- Configuration policy
- Handling notes
- Checklist

OM-B 747-8 Boeing 747-8

- Fleet
- Configuration policy
- Handling notes
- Checklist

OM-B ATR ATR 72-600 / ATR 42-600

- Fleet
- Hotel mode and propeller brake
- Icing
- Configuration policy
- Handling notes
- Checklists

QRH 0 Immediate Actions (Memory Items)

- Rejected takeoff
- Engine fire or severe damage
- Emergency descent
- TCAS resolution advisory
- Terrain warning: "PULL UP" / "TERRAIN AHEAD PULL UP"
- Windshear
- Unreliable airspeed
- Stall recovery

QRH NC 1 Normal Checklist: Airbus A319 / A320neo

- BEFORE START
- AFTER START
- BEFORE TAKEOFF
- AFTER TAKEOFF / CLIMB
- APPROACH
- LANDING
- PARKING
- SECURING THE AIRCRAFT

QRH NC 2 Normal Checklist: Airbus A350

- BEFORE START
- AFTER START
- BEFORE TAKEOFF
- AFTER TAKEOFF / CLIMB
- APPROACH
- LANDING
- PARKING
- SECURING THE AIRCRAFT

QRH NC 3 Normal Checklist: Airbus A380

- BEFORE START
- AFTER START
- BEFORE TAKEOFF
- AFTER TAKEOFF / CLIMB
- APPROACH
- LANDING
- PARKING
- SECURING THE AIRCRAFT

QRH NC 4 Normal Checklist: Boeing 737-600/-800/-900ER

- PREFLIGHT
- BEFORE START
- BEFORE TAXI
- BEFORE TAKEOFF
- AFTER TAKEOFF
- DESCENT
- APPROACH
- LANDING
- SHUTDOWN
- SECURE

QRH NC 5 Normal Checklist: Boeing 737 MAX 8

- PREFLIGHT
- BEFORE START
- BEFORE TAXI
- BEFORE TAKEOFF
- AFTER TAKEOFF
- DESCENT
- APPROACH
- LANDING
- SHUTDOWN
- SECURE

QRH NC 6 Normal Checklist: Boeing 777F

- PREFLIGHT
- BEFORE START
- BEFORE TAXI
- BEFORE TAKEOFF
- AFTER TAKEOFF
- DESCENT
- APPROACH
- LANDING
- SHUTDOWN
- SECURE

QRH NC 7 Normal Checklist: Boeing 747-8
PREFLIGHT
BEFORE START
BEFORE TAXI
BEFORE TAKEOFF
AFTER TAKEOFF
DESCENT
APPROACH
LANDING
SHUTDOWN
SECURE

QRH NC 8 Normal Checklist: ATR 72-600
FINAL COCKPIT PREPARATION
BEFORE PROPELLER ROTATION
BEFORE TAXI
TAXI
BEFORE TAKEOFF
AFTER TAKEOFF
CRUISE
DESCENT
APPROACH
BEFORE LANDING
AFTER LANDING
PARKING
LEAVING THE AIRCRAFT

QRH NC 9 Normal Checklist: ATR 42-600
FINAL COCKPIT PREPARATION
BEFORE PROPELLER ROTATION
BEFORE TAXI
TAXI
BEFORE TAKEOFF
AFTER TAKEOFF
CRUISE
DESCENT
APPROACH
BEFORE LANDING
AFTER LANDING
PARKING
LEAVING THE AIRCRAFT

GUIDE 1 The AviatesAir Tracker & ACARS
First-time setup
The pages
Flying a recorded flight
After the flight

GUIDE 2 Using the AviatesAir EFB
Pairing
The apps
Flight mode
Manuals app tips

GUIDE 3 Weather & Performance Know-How
Reading a METAR
Flight categories
Reading a TAF
What drives takeoff performance
What drives landing performance

Aircraft Registrations: Fleet-Wide Use

Any AviatesAir registration may be used from any airport, as often as you like and even while another pilot is flying it. The only condition is that your departure airport has routes for the type.

> NOTE Status: **ACTIVE** until cancelled. Applies to every AviatesAir, CityHopper and Skycargo type.

Notice

AviatesAir does not assign airframes to individual pilots or stations. You may fly **any registration in the AviatesAir fleet**:

- from **any airport** in the network,
- **as many times as you like**, and
- **even if another pilot is flying the same registration at the same time.**

Maintaining a unique registration for every position in a shared virtual fleet would add administration without adding anything to the operation, so the whole fleet is pooled.

The one condition: routes for your type

Your departure airport must have AviatesAir **routes for the aircraft type you intend to fly**. Before booking, check the route list in the Tracker (**Routes**) for your departure airport and filter by type.

> NOTE Example: East Midlands (EGNX) has Boeing 737-800 routes, so a B738 departure from EGNX with any B738 registration is valid.

If the departure airport has no routes for your type, choose another type that is served there, or reposition to an airport that has routes for the type you want (see OM-A 1, Repositioning).

What does not change

- Your **booking** still defines the flight: route, flight number, aircraft **type** and schedule. The registration you pick must be of the booked type.
- File the registration you are actually flying in your SimBrief OFP and your network flight plan so ATC, the OFP and the Tracker agree.
- Company callsigns are unaffected. See OM-A 1, Callsigns.

Boeing 737 NG / MAX Takeoff Flap Restriction

FLAPS 5 is the minimum takeoff flap setting for every 737 in the fleet, even where performance would allow FLAPS 1. Purpose: tail-strike prevention.

WARNING Status: **ACTIVE** until cancelled. Applies to the **B736, B738, B739ER and B38M**.

Restriction

FLAPS 5 is the minimum flap setting for takeoff. FLAPS 1 is **not permitted**, even when the runway, weight and weather would make it performance-legal.

Use FLAPS 5 as the normal setting and FLAPS 10, 15 or 25 when performance requires more flap (short or limiting runways, obstacles, high density altitude).

Why

A lower flap setting means higher rotation and lift-off speeds and a **higher body attitude at lift-off**, which reduces tail clearance. The 737-800, -900ER and MAX 8 are long-bodied and particularly sensitive to this.

A tail strike is never a small event: the aircraft must **return to the departure airport** for inspection. That means a long delay to your flight, disruption to the rest of the rotation and the risk of further problems with the airframe later.

How the tools apply it

- **EFB Departure Perf** only offers FLAPS 5 and above for 737 types, and **OPT** only chooses between permitted settings. If a restricted setting is ever requested, the result is flagged with this notice.
- Rotate at the normal rate (about 2–3° per second) towards the target pitch attitude. Don't rotate early or aggressively. See OM-B 737, Handling notes.
- A tail strike, or a takeoff flown with a prohibited setting, is a reportable occurrence. Tell staff via the PIREP review comment (see OM-A 6).

Minimum Landing Flap for the Boeing 737 and Airbus A320 Family

737 NG/MAX land with FLAPS 25 minimum (FLAPS 30 standard). A319/A320neo land with CONF 3 minimum (CONF FULL standard). Using the minimum is fully permitted and never counts against a PIREP.

WARNING Status: **ACTIVE** until cancelled. Applies to the **B736, B738, B739ER, B38M, A319 and A320neo**.

Restriction

FLEET	MINIMUM LANDING FLAP	STANDARD LANDING FLAP	ALSO PERMITTED
Boeing 737 NG / MAX	**FLAPS 25**	**FLAPS 30**	FLAPS 40 (short, wet or contaminated runways)
Airbus A319 / A320neo	**CONF 3**	**CONF FULL**	None

Landing with **less** than the minimum (for example a 737 at FLAPS 15, or an A320 at CONF 2) is not permitted except when a non-normal procedure in the QRH/ECAM requires it.

NOTE Using the **minimum** configuration (FLAPS 25 / CONF 3) is a normal, fully accepted choice. It **never** results in a deduction or any action against your PIREP. The Tracker's landing review treats both as the landing configuration.

Why

Less landing flap means a **higher approach speed** (VREF / VLS). The consequences:

- more energy to dissipate: a **longer landing distance** and more braking,
- a **longer runway occupancy** before you can vacate, which disrupts traffic on busy online events, and
- a greater tendency towards a **firm touchdown**, which puts stress on the airframe and may call for an inspection.

The standard settings (FLAPS 30 / CONF FULL) give the lowest approach speed and the most margin. Choose the minimum only for a reason, such as expected windshear, a go-around performance limit or noise, and brief it.

How the tools apply it

- **EFB Arrival Perf** offers only permitted settings and defaults to the standard one.
- The **landing review** in the Tracker judges "landing configuration by 1,000 ft" against the company minimum for your type (see OM-A 6).
- Fly the approach speed for the flap you have selected. The stabilised-approach criteria are in OM-A 5.

Introduction & Manual Control

How the AviatesAir document library is organised, how to read it (shall / should / may), revision control and which document takes precedence.

Welcome to AviatesAir. This Operations Manual sets out how we fly: the policies, procedures and standards every AviatesAir, CityHopper and Skycargo pilot follows. It is written the way a real airline writes its manuals, so that flying with us feels like flying for an airline, while staying practical for a virtual operation.

> CAUTION AviatesAir is a **virtual airline** for flight simulation. Nothing in this library is approved or certified data, and none of it may be used for real-world aviation.

The document library

MANUAL	CONTENTS
Company NOTAMs (CN)	Current operational notices. Read and **acknowledge** every active notice before your next flight.
OM-A: General / Basic	Operating policy, flight planning, fuel, weather and minima, SOPs, approach and landing policy, flight data monitoring, online operations, abnormal and emergency policy.
OM-B: Aircraft Operating Matters	One chapter per fleet: key data and limitations, company configuration policy, handling notes.
QRH: Quick Reference Handbook	Normal checklists for every type (identical to the EFB **Checklists** app) and immediate-action items.
Pilot Guides	The AviatesAir Tracker, ACARS and EFB, plus weather and performance know-how.

Order of precedence

When two documents disagree, apply the **first** in this list:

1. **ATC instructions** and the safety of the flight (in the simulator)
2. **Company NOTAMs**: they amend the manuals until the manuals are revised
3. **OM-B** for your aircraft type
4. **OM-A**
5. The aircraft add-on's own documentation (FCOM/QRH/FCTM supplied with it)
6. Pilot Guides

> NOTE Aircraft data in OM-B are typical figures for the type. Where your add-on's own limitations differ (engine option, weight variant, software standard), **the add-on's figures apply**.

Terminology

WORD	MEANING
shall / must	Mandatory. Deviations may lead to a PIREP being held for review.
should	Recommended practice. Deviate only with good reason, and brief it.
may	Optional; at the pilot's discretion.
PF / PM	Pilot Flying / Pilot Monitoring. Flying alone you do both, but think in both roles.
AAL / AGL	Above aerodrome level / above ground level.

Revisions

Every document shows its **revision number** and **effective date**. When a document is revised, its revision number increases. A revised Company NOTAM must be acknowledged again. Suggestions and corrections are welcome: raise them with AviatesAir staff on Discord.

Operational Policy & Flight Planning

The AviatesAir operation: subsidiaries and callsigns, bookings, routes, registrations, repositioning, the OFP and the life of a flight from booking to PIREP.

The operation

AviatesAir flies scheduled passenger and cargo services under three operating brands. Each has its own ICAO designator used for ATC callsigns and SimBrief dispatch:

OPERATING BRAND	ICAO DESIGNATOR	FLEET
AviatesAir Mainline	**VAV**	A320neo · A350 · A380 · 737-800 · 737-900ER · 737 MAX 8 · 747-8
AviatesAir CityHopper	**VAH**	A319 · 737-600 · ATR 72-600 · ATR 42-600
AviatesAir Skycargo	**VAC**	777F

Callsigns and flight numbers

- **Route flight numbers** always use the **AV** prefix (e.g. *AV150*). This is the number shown on the booking and in the logbook.
- The **ATC callsign** uses the operating brand's designator plus 1–4 characters: up to four digits, optionally ending in up to two letters (e.g. *VAV34NE*, *VAH64E*, *VAC023F*). The Tracker generates it when you book.
- File exactly the callsign shown on your booking in SimBrief and on your network flight plan. The radiotelephony callsign is spoken as designator plus suffix (for example "*VAV three four november echo*").

Bookings

- You hold **one booking at a time**. Complete or cancel it before booking another.
- A booking defines the **route, flight number, aircraft type and scheduled departure time**.
- Once a booking is **activated** (the flight has started), it is locked and can no longer be cancelled.
- **Charter** bookings are available for flying outside the published schedule.
- **Event flights** earn the event's hours multiplier when you confirm attendance at the event reminder before departure.

Punctuality

Plan to be off blocks at the scheduled time. A departure **more than 20 minutes after the scheduled departure time** is recorded and the PIREP is held for review. If you are running late, cancel and rebook rather than departing an hour late on an old booking.

Routes and aircraft types

Only fly a type from an airport that has **AviatesAir routes for that type**; the Routes page lists them. Registrations are pooled fleet-wide; see CN-001.

Repositioning

Your position is the destination of your last completed flight. If you need to be somewhere else to fly the route you want, the **Reposition** action on the Routes page may be used **once every 7 days**. Otherwise, fly there.

The life of a flight

1. **Book** the flight in the Tracker.
2. **Plan**: generate the SimBrief OFP with the booked flight number, callsign, type and your registration, then import it in the Tracker **ACARS** page. The OFP flows automatically into the EFB (Pilot Brief, Departure Perf, Dashboard).
3. **Brief**: read the Company NOTAMs and the OFP, check weather and NOTAMs for departure, destination and alternates, and compute takeoff performance.
4. **Fly**: keep the **Tracker running and connected to the simulator for the whole flight**, from the gate to the gate. Flight phases, the route, fuel and the landing are recorded automatically.
5. **Arrive**: park, set the parking brake and shut down. The Tracker completes the flight and submits the **PIREP** automatically.
6. **Review**: read your landing report in the EFB **Landing** app. If the PIREP is held for review, add your comment (see OM-A 6).

> **NOTE** If the simulator or the Tracker crashes mid-flight, restart the Tracker: flight recovery resumes the recorded flight. A PIREP that fails to send is retried automatically at the next start.

Pilot responsibilities

You shall:

- fly the **booked** route and type, with a realistic OFP,
- follow ATC and published procedures when flying online,
- operate within the aircraft's limitations and the company restrictions in the Company NOTAMs,
- avoid using simulation "cheats" (slew, time acceleration, unrealistic fuel or weight edits, pausing mid-approach) on a recorded flight.

Fuel Policy

How AviatesAir plans fuel (taxi, trip, contingency, alternate, final reserve, additional, extra), in-flight fuel management and the MINIMUM FUEL / MAYDAY FUEL declarations.

AviatesAir follows an ICAO/EASA-style fuel scheme. SimBrief calculates it for you; this chapter explains what each figure is for, so you can judge whether the OFP makes sense.

Planned fuel

COMPONENT	AVIATESAIR POLICY
Taxi	Expected taxi-out burn, including APU use. Use the OFP figure; add more at congested hubs.
Trip	Takeoff to landing at destination, including the expected departure and arrival procedures.
Contingency	**5 % of trip fuel**, never less than **5 minutes** of holding at 1,500 ft above destination.
Alternate	Missed approach at destination, climb, cruise and approach to the **destination alternate**.
Final reserve	**30 minutes** holding at 1,500 ft above the alternate, for jets and turboprops alike.
Additional	Only when needed so that fuel never falls below final reserve (e.g. an isolated destination with no alternate).
Extra	Commander's discretion: weather, expected holding, ATC delays, online event congestion.

Minimum takeoff fuel = trip + contingency + alternate + final reserve + additional. **Block fuel** = minimum takeoff fuel + taxi + extra.

> **NOTE** Busy online events regularly add 10–20 minutes of holding or vectoring. Carry extra fuel accordingly and note it in your briefing.

Destination alternate

A destination alternate is required unless the flight is very short and the destination weather is well above minima. Choose one that has suitable runways and weather above the planning minima in OM-A 3. Our long-haul fleet (A350, A380, 777F, 747-8) should always carry one.

Tankering

Carrying fuel for the next sector is permitted when the OFP shows a saving and the landing weight stays within limits. Never tanker if it would push the landing weight above MLW or erode landing performance on a limiting runway.

In-flight fuel management

- Check **fuel on board against the OFP** at every waypoint or at least every 30 minutes. The EFB Dashboard shows the predicted arrival fuel against the planned figure.
- Investigate any trend of more than **5 %** or an **imbalance**: fuel leak, wrong cruise level, headwinds.

- Plan to land with **at least final reserve plus alternate fuel** at destination. If that is no longer possible, re-plan early: a lower level, a closer alternate, or a diversion.

Fuel declarations

CALL	WHEN
"MINIMUM FUEL"	You are committed to landing at a specific aerodrome, and any further delay may result in landing with **less than final reserve**. This is not an emergency. It tells ATC that further delay is not acceptable.
"MAYDAY MAYDAY MAYDAY FUEL"	The fuel you are calculated to have on landing at the nearest suitable aerodrome is **less than final reserve**. This is an emergency.

> **CAUTION** Final reserve is there to be protected, not used. A landing below final reserve is a reportable occurrence. Mention it in your PIREP comment.

Weather, Minima & Runway Condition

Planning minima for destinations and alternates, takeoff and landing minima, crosswind and tailwind policy by runway condition code (RWYCC), low-visibility operations and the Global Reporting Format.

Planning minima

An aerodrome may be planned as a **destination** or **destination alternate** only if the forecast (TAF, including TEMPO/PROB groups) for **one hour before to one hour after** the expected arrival time is at or above:

APPROACH AVAILABLE	DESTINATION	DESTINATION ALTERNATE
Precision approach (ILS CAT I / GLS / LPV)	Published minima	DA/H **+ 200 ft** and RVR/VIS **+ 800 m**
Non-precision (RNP LNAV / LNAV/VNAV, VOR, NDB)	Published minima	MDA/H **+ 400 ft** and RVR/VIS **+ 1,500 m**
Circling	Published circling minima	Circling minima **+ 400 ft / + 1,500 m**

A **takeoff alternate** within one hour's flying time (one engine inoperative, still air; two hours for the A350, 777F, 747-8 and A380) is required when departure weather is below the landing minima for the departure runway.

Takeoff and approach minima

- **Takeoff:** minimum RVR/visibility **400 m** with centreline lighting; **550 m** without. Lower values need low-visibility procedures (LVP) in force at the airport, where the simulator scenery and network ATC support them.
- **Approach:** fly to the minima published on the chart. Set the DA/MDA on the minimums selector during the approach briefing.
- **Approach ban:** do not continue an approach below **1,000 ft AAL** if the reported RVR/visibility is below the required minimum.

Crosswind and tailwind

Company crosswind guidance is based on the **runway condition code (RWYCC)** and matches the EFB Arrival Perf warnings. Never exceed the aircraft's demonstrated crosswind (your add-on's FCOM).

RWYCC	RUNWAY DESCRIPTION	MAX CROSSWIND (INCL. GUSTS)
6	Dry	**33 kt**
5	Wet (≤ 3 mm water), frost	**33 kt**
4	Compacted snow (≤ −15 °C OAT)	**25 kt**
3	Wet "slippery", dry snow or wet snow over compacted snow	**25 kt**
2	Standing water or slush (> 3 mm)	**15 kt**
1	Ice	**15 kt**

RWYCC	RUNWAY DESCRIPTION	MAX CROSSWIND (INCL. GUSTS)
0	Wet ice, water on compacted snow	**Operations not permitted**

- **Tailwind:** maximum **10 kt** for takeoff and landing unless the add-on's AFM allows more; never on a contaminated runway (RWYCC ≤ 4).
- Gust factor: add the full gust to the crosswind when comparing with the limit.

Runway condition and the Global Reporting Format (GRF)

Runway state is reported as a **runway condition report (RCR)**: a RWYCC for each third of the runway (e.g. *RWYCC 5/5/3*), plus contaminant type, depth and coverage. Use the **lowest** code of the thirds you will use, and select it in EFB Arrival/Departure Perf. Pilots report braking action as **GOOD** (5), **GOOD TO MEDIUM** (4), **MEDIUM** (3), **MEDIUM TO POOR** (2), **POOR** (1) or **LESS THAN POOR** (0).

> CAUTION On contaminated runways, performance calculations must assume **no reverse thrust credit** for dispatch, and you should plan the **longest available runway**.

Low-visibility operations

CAT II/III approaches are permitted only when:

- the aircraft and add-on support autoland to the required category,
- the airport publishes the approach and ATC declares LVP in force (online), and
- you brief the automatic callouts, minima (DH or alert height) and go-around.

Thunderstorms, icing and windshear

- **Thunderstorms:** avoid active cells by at least **20 NM** laterally in cruise (10 NM below FL200). Never take off or land with a storm over the airport or on the approach path.
- **Icing:** use engine and wing anti-ice as the aircraft procedures require. Airframe de-icing is required before takeoff with frost, snow or ice on critical surfaces.
- **Windshear:** reported moderate or severe windshear, or a predictive windshear alert: **delay** the takeoff or approach. See the QRH immediate actions if you encounter it.

Standard Operating Procedures

Flight-deck philosophy, PF/PM duties, flows and checklists, briefings, sterile flight deck, automation, altimeter setting, speed limits, taxi, APU use and noise abatement.

Philosophy

Fly the aircraft first: **aviate, navigate, communicate**. Every AviatesAir flight is flown to the same standard whether it is recorded, online or offline, so that good habits become automatic.

PF and PM duties

PILOT FLYING (PF)	PILOT MONITORING (PM)
Flight path and speed control	Radio communication
Aircraft configuration (calls for flap, gear)	Selects flap/gear on the PF's call and confirms
Navigation and automation mode selection	Monitors the flight path, calls deviations
Calls for checklists	Reads checklists

Flying single-pilot in the simulator, you do both. Keep the discipline anyway: make the calls, then verify them.

Flows and checklists

1. **Flows** configure the aircraft from memory, panel by panel.
2. **Checklists** then *verify* that the critical items were done. They are **read–verify**, not read–do.
3. Read the challenge, check the item, state the response. Stop at the **line** on Airbus checklists until the clearance is received.
4. Use the checklist for **your type**. The EFB **Checklists** app selects it from your booking automatically; the QRH has the same checklists in print.

Briefings

Departure briefing (before start): runway and intersection, takeoff performance (flap, thrust, V-speeds), the SID and initial altitude, transition altitude, engine-failure and emergency turn procedure, return plan, taxi route and hot spots, weather and anything unusual.

Approach briefing (before top of descent): the ATIS, STAR and transition, approach type and minima, landing flap and autobrake, landing distance and runway exit, missed approach and go-around altitude, diversion fuel and the alternate, taxi to stand.

> **NOTE** A briefing is a plan you can fly, not a recital. Brief the threats first ("*what could catch us out today?*"), then the plan.

Sterile flight deck

Below **10,000 ft**, and whenever on the ground with engines running, only operationally relevant activity takes place: no cabin PAs except safety-related ones, no chat, no photos, no reading the news. On a stream or voice channel, go quiet.

Automation

- Use the **appropriate level** of automation. Hand-flying practice is encouraged in good weather and light traffic; **engage the autopilot** in busy airspace, in IMC, in RVSM airspace and when workload is high.
- **Know what the FMA says.** Read every mode change aloud.
- If the automation does something unexpected, **take it one level down** (managed → selected → manual) before troubleshooting.

Altimeter setting

- **Departure:** set QNH before start. Set **STD (1013 / 29.92)** when passing the **transition altitude** in the climb.
- **Arrival:** set destination QNH when cleared to an altitude, or at the **transition level** in the descent.
- **Cross-check** both altimeters and the standby after every change. The EFB shows the planned transition altitude in Pilot Brief and Departure Perf.

Speed limits

CONDITION	MAXIMUM
Below **FL100** (unless ATC or a published procedure says otherwise)	**250 kt IAS**
Holding (ICAO, up to FL140)	**230 kt**
Flap and gear extension	Placard speeds, see OM-B
Taxi, straight line	**30 kt** GS (20 kt on wet or contaminated surfaces)
Taxi, turns more than 30° and ramp areas	**10 kt** GS

Ground operations

- **Pushback:** only with the parking brake released on the tug's instruction, beacon **ON**, doors closed.
- **Engine start:** after pushback clearance. Heavies start the second engine(s) after the tug is disconnected, if the ground crew permit.
- **Taxi:** follow the cleared route with the airport chart displayed. Stop and ask when in doubt. Use taxi lights at night and runway turnoff lights as needed.
- **Single-engine taxi** is permitted for fuel saving where the add-on supports it: after landing when the engine has cooled (typically three minutes), and never on contaminated surfaces.
- **APU:** use ground power where available. Start the APU no earlier than necessary before pushback, and shut it down after arrival once ground power is connected.

Noise abatement departure

Unless the airport or ATC specifies otherwise, fly **NADP 2**:

1. Takeoff thrust and V2 + 10–20 kt to **1,000 ft AAL**.
2. At 1,000 ft AAL: lower the nose, reduce to climb thrust, accelerate and retract flaps on schedule.
3. Climb at clean speed to 3,000 ft AAL, then accelerate to 250 kt.

Where the SID requires **NADP 1**, reduce to climb thrust at 800–1,500 ft but keep takeoff flap and V2 + 10–20 kt until **3,000 ft AAL**.

Approach & Landing Policy

Stabilised-approach criteria and gates, the no-fault go-around policy, landing technique, touchdown zone, autobrake and reverse use, landing flap policy and runway vacating.

Stabilised approach criteria

An approach is **stabilised** when **all** of the following are true:

1. The aircraft is on the correct **lateral and vertical flight path**, needing only small changes of heading and pitch.
2. It is in the **landing configuration**: gear down, landing flap set (at or above the company minimum for the type; see CN-003).
3. The speed is between **VREF (VLS on Airbus) and VAPP + 10 kt**, and not decreasing below the target.
4. The **rate of descent is no greater than 1,000 fpm**. If a higher rate is expected (a steep approach or a high groundspeed), it must be briefed.
5. **Thrust** is stabilised, spooled up and appropriate for the configuration.
6. **Bank angle** is no more than 10° below 500 ft; wings level by 50 ft except for crosswind correction.
7. All **briefings and checklists** are complete. The LANDING checklist is done by 1,000 ft.

Gates

GATE	HEIGHT	REQUIREMENT
IMC gate	**1,000 ft AAL**	Stabilised, in IMC and on every instrument approach.
VMC gate	**500 ft AAL**	Stabilised, in visual conditions on a visual approach. Configuration must be complete by 1,000 ft.

> **WARNING** If the approach is **not stabilised at the gate**, or becomes unstable below it, a **GO-AROUND is mandatory**. There is no "just this once".

The EFB Landing report shows your 1,000 ft and 500 ft gate states from the recorded approach, and the Tracker holds a PIREP for review when gear, flap or speed were not stabilised by 1,000 ft (see OM-A 6).

Go-around policy

AviatesAir has a **no-fault go-around policy**. Nobody is ever criticised for going around. A go-around is a normal manoeuvre, and a well-flown one is a sign of good airmanship. Go around when:

- the approach is not stabilised at the gate,
- the required visual reference is not established at the minima,
- there is a runway incursion, an obstacle, or an ATC instruction to go around,
- windshear, a long flare or a bounce means you can't touch down safely in the touchdown zone,
- you have any doubt.

After a go-around, fly the published missed approach unless ATC instructs otherwise. Re-brief before a second attempt. After **two** unsuccessful approaches, divert unless the reason has clearly gone away.

Landing technique

- **Aim** for the touchdown aiming point (the large markings about 1,000 ft / 300–400 m past the threshold). Cross the threshold at about **50 ft**.
- **Touchdown zone:** touch down within the **touchdown zone**, the first **3,000 ft (900 m)** past the threshold (or the first third of a shorter runway), ideally close to the aiming point. A touchdown beyond it is a **long landing**, and one less than 200 ft past the threshold is a **short landing**. If the touchdown point is running long, go around rather than chase it.
- **Flare** at the type's normal height (roughly 20–30 ft on narrow-bodies, higher on heavies), reduce thrust smoothly and **don't float**. A firm, on-speed touchdown in the zone beats a long "butter".
- **Crosswind:** use the type's recommended technique. Crab to the flare, then de-crab with rudder, cross-controlling with aileron as needed so the aircraft touches down aligned with the centreline.
- Lower the nose wheel promptly and smoothly. **Stay on the centreline.**

Deceleration

- **Autobrake:** select to match the runway: LOW/2 for long dry runways, MED/3 for normal or wet runways, MAX only for short or contaminated runways (BTV on the A350/A380 where available).
- **Reverse thrust:** idle reverse at least on every landing where available. Full reverse on short, wet or contaminated runways, cancelled by about 60 kt (per type).
- Plan the **runway exit** in the approach briefing and aim to vacate without delay, especially at busy online events.

Landing flap policy

Use the **standard landing flap** for your type unless there is a reason not to. The **company minimum** in CN-003 applies to the 737 and A320 family.

Flight Data Monitoring & Landing Assessment

What the Tracker records, how landings are scored and graded, the FDM event limits, which exceedances hold a PIREP for review, and the just culture behind it.

Real airlines run a **Flight Data Monitoring (FDM)** programme: every flight's data is recorded and analysed to find trends and improve safety. AviatesAir does the same with the Tracker. The aim is **learning, not punishment**.

What is recorded

For every flight: the flight phases, route and altitude profile, block and air times, fuel, and every landing. For every landing: the full approach from about 2½ minutes before touchdown through the rollout (altitude, speeds, vertical speed, pitch, bank, flap and gear), plus the touchdown values. You can review any of your last 25 landings in the EFB **Landing** app.

Landing score

Each landing is scored out of **100** on six factors:

FACTOR	POINTS	FULL MARKS
Vertical speed at touchdown	**30**	≤ 250 fpm (25 pts to 400, 15 to 600, 8 to 800, 3 to 1,000)
Pitch attitude at touchdown	**20**	1.5–3.5° nose-up (15 pts 0.5–5°, 8 pts 0–7°)
Bank angle at touchdown	**15**	< 1° (12 < 2°, 8 < 3°, 4 < 5°)
Speed at touchdown	**15**	100–145 kt IAS (10 pts 80–160 kt, 5 pts 60–180 kt)
Crosswind component	**10**	< 2 kt, scaling down to 1 pt at 15 kt or more
Approach stability	**10**	Stabilised approach (2 pts if not)

> **NOTE** The speed band suits the narrow-body fleet. Heavies (A380, 747-8, 777F) naturally touch down faster and lose a few points there. Compare your heavy landings with each other, not with the A320.

SCORE	GRADE
90–100	**EXCELLENT**
75–89	**GOOD**
60–74	**FAIR**
40–59	**HARD**
0–39	**VERY HARD**

The **butter rating** (PURE BUTTER · BUTTER · SMOOTH · SOLID · FIRM · HARD) is the fun part: it's based on vertical speed alone and has no bearing on review.

> **NOTE** A *SOLID* 200–300 fpm touchdown in the touchdown zone is exactly what airlines want, especially on a wet or short runway. Don't float the aircraft down the runway chasing a butter landing.

FDM events

The landing report lists exceedances as **WARNING** (red), **CAUTION** (amber) or **NOTE**. These are AviatesAir's event limits, not aircraft limitations:

EVENT	CAUTION	WARNING
Vertical speed at touchdown	≥ 600 fpm	≥ 800 fpm
Pitch at touchdown (tail-strike margin)	≥ 7.5° (or nose-low < 0°)	≥ 9.0°
Bank at touchdown	≥ 3°	≥ 5°
Bounce	1 bounce	2 or more
Touchdown past the threshold	> 2,500 ft	> 3,000 ft (long landing)
Touchdown short	n/a	< 200 ft past the threshold
Centreline deviation	≥ 30 ft	≥ 60 ft
Rate of descent below 1,000 ft AAL	≥ 1,000 fpm	≥ 1,500 fpm
Bank below 500 ft	≥ 10°	≥ 15°
Unstabilised at a gate	1,000 ft gate	500 ft gate
Tailwind at touchdown	n/a	≥ 10 kt
Crosswind component	≥ 25 kt	n/a
Crab angle at touchdown	≥ 5°	n/a
No flare detected	note	n/a

Held for review

A PIREP is **held for review** by staff, not rejected, when any of the following occurred:

- **Hard landing:** touchdown vertical speed above **800 fpm**,
- a **bounced** landing,
- **gear, landing flap or approach speed not stabilised by 1,000 ft AGL** (landing flap at or above the company minimum counts; see CN-003),
- touchdown more than **60 ft** from the centreline, or outside **200–3,000 ft** past the threshold (where the runway is in the Tracker's database),
- a climb or descent rate above **8,000 fpm** at any point,

- cruise airspeed outside a safe band (jets 250–530 kt IAS, turboprops 150–300 kt),
- off blocks more than **20 minutes** after the scheduled departure.

When a flight is held, the Tracker asks for your comment. **Explain what happened** (for example "gusting 25 kt, bounced and went around", or "ATC kept us high, descent rate 1,400 fpm to regain the path"). Honest context is all that's needed.

Just culture

- Honest mistakes and honest reports are **never** punished. We learn from them.
- **Recklessness** is not acceptable: deliberate, repeated disregard of SOPs, limits or ATC, or manipulating the simulator to fake a flight.
- Trends matter more than single events. Staff may offer tips or a check flight if the same event keeps recurring.

Online Network Operations

Flying AviatesAir on VATSIM and IVAO: flight plans, callsigns and remarks, radio discipline, UNICOM, CPDLC/Hoppies, events and simulating non-normals online.

Flying online is encouraged, and it's what makes our events come alive. On a network you share the sky with real people, so **the network's rules come first**: the VATSIM Code of Conduct or the IVAO rules, and the controller's instructions.

Before you connect

- File a **flight plan** that matches your OFP: route, cruise level, aircraft type with equipment and wake category, and your alternate. SimBrief can prefile it for you.
- **Callsign:** your booking callsign (VAV / VAH / VAC + suffix; see OM-A 1).
- **Remarks:** include `/V/` (voice) and `RMK/AVIATESAIR VIRTUAL`, plus anything ATC should know (e.g. `RMK/NEW TO THE AREA`). If ATC asks how to say your callsign, spell out the designator and suffix.
- Connect **at the gate**, never on a runway or taxiway. Set your transponder to standby or as the network requires.

On the frequency

- **Listen before you talk.** Plan the call, then make it in one go.
- Use standard **ICAO phraseology** and read back clearances, runway, altitude, heading, speed and squawk.
- If you don't understand, say so: "*Say again*". Nobody minds.
- Check in with **callsign, level and anything asked for** (the ATIS letter, SID or STAR).

When there's no ATC

Monitor and self-announce on **UNICOM 122.800** (VATSIM) or the network's published unicom. Give position and intentions at key points: pushback, taxi, lining up, departing, established on final, vacating.

Datalink

- Where the controller provides it, request **departure clearance (PDC/DCL)** and use **CPDLC** logon via Hoppie's ACARS.
- AviatesAir's own ACARS messages (loadsheet, timings) come through Hoppies when it is enabled in the Tracker; they're company messages, not ATC clearances.

Events

- For events, **book early**, arrive at the gate in good time and **carry extra fuel** for holding.
- Keep speeds as assigned. On a busy frequency, keep transmissions short and vacate promptly after landing.
- Confirm attendance at the event reminder so the event's hours multiplier is applied (see OM-A 1).

Non-normals online

- You may simulate a non-normal only if you can **fly it realistically without disrupting other traffic**. On a busy event, don't.
- Tell ATC early and plainly what you need ("*…request return to the field, engine failure, VAV12 heavy*"). Don't surprise them with a squawk change.
- **Never squawk 7500** (unlawful interference) on any network.
- If the simulator misbehaves (a crash, or a freeze on final), leave the frequency and **disconnect** rather than stay connected as a hazard.

Abnormal & Emergency Policy

Declaring an emergency, squawk codes, diversion decisions, overweight landings, rejected takeoffs, tail strikes and hard landings, and reporting occurrences.

Handling a non-normal

1. **Fly the aircraft.** Maintain control and a safe flight path, then use the automation.
2. **Identify** the problem: ECAM/EICAS messages, warnings and indications.
3. Carry out the **immediate actions** (memory items) where they apply. See the QRH.
4. Work through the **ECAM or QRH checklist** for the type in your add-on.
5. **Decide:** continue, return or divert. Use a structured model such as **T-DODAR** (Time, Diagnose, Options, Decide, Assign, Review).
6. **Communicate** with ATC, and brief the cabin in the simulator.

Declaring an emergency

CALL	USE FOR
MAYDAY MAYDAY MAYDAY	Grave and imminent danger requiring immediate assistance: engine fire, loss of all engines, depressurisation, smoke, MAYDAY FUEL.
PAN PAN, PAN PAN, PAN PAN	Urgency, where the safety of the aircraft or a person is at risk: engine failure after it's secured, medical emergency, a significant system failure.

Squawk codes

CODE	MEANING
7700	Emergency, unless ATC has already assigned another code.
7600	Radio failure. Follow the published loss-of-communications procedure.
7500	Unlawful interference. **Never used** at AviatesAir (see OM-A 7).

Diversion

Divert when continuing to destination is no longer safe or sensible:

- weather below minima with no improvement expected within your fuel,
- a non-normal requiring a **landing at the nearest suitable airport** (fire not confirmed out, smoke, a single remaining power source, the ECAM/QRH says so),
- a medical emergency,
- fuel below what is needed for destination plus reserves.

A diverted flight is a normal outcome. Land, park, and let the Tracker complete the flight. Explain the diversion in the PIREP comment.

Overweight landing

Landing above MLW is permitted **only** when a delay to reduce weight would compromise safety (fire, smoke, medical). Fly a stabilised approach at the correct VAPP with the maximum landing flap, and land smoothly: aim for **less than 360 fpm** at touchdown. An overweight landing always requires an inspection, so report it.

Rejected takeoff

- **Below 80 kt** (100 kt on the Airbus fleet): reject for any significant failure or warning.
- **80 kt / 100 kt to V1:** reject only for engine failure or fire, a predictive windshear warning, unsafe configuration warnings or if the aircraft is unsafe or unable to fly.
- **After V1:** continue the takeoff. The problem is dealt with in the air.

The PF calls "**STOP**" and performs the RTO actions (see QRH).

Tail strike and hard landing

- **Suspected tail strike:** don't pressurise the aircraft further than needed. Return to the departure airport for inspection (see CN-002).
- **Hard landing** above 800 fpm, or a heavy bounce: the aircraft needs an inspection before the next flight. The PIREP is held for review automatically; add your comment.

Reporting occurrences

Report in your PIREP comment (or to staff on Discord) any of: a tail strike, a hard or overweight landing, a landing below final reserve fuel, a runway excursion, a TCAS RA, a GPWS warning, a windshear encounter, a level bust, or any event you think others could learn from. Reports are handled under our **just culture** policy (OM-A 6).

Fleet Overview & Configuration Policy

The AviatesAir fleet at a glance: types, brands, roles, typical weights and the company takeoff/landing configuration policy for every type.

> **NOTE** Figures in OM-B are **typical** for the type and variant. Your add-on's own documentation takes precedence where it differs.

The fleet

TYPE	ICAO	BRAND	ROLE	TYPICAL MTOW	CHAPTER
Airbus A319	A319	CityHopper	Short haul	75.5 t	OM-B A320
Airbus A320neo	A20N	Mainline	Short / medium haul	79.0 t	OM-B A320
Airbus A350-900	A359	Mainline	Long haul	283 t	OM-B A350
Airbus A380-800	A388	Mainline	Long haul, trunk routes	575 t	OM-B A380
Boeing 737-600	B736	CityHopper	Short haul	65.5 t	OM-B 737
Boeing 737-800	B738	Mainline	Short / medium haul	79.0 t	OM-B 737
Boeing 737-900ER	B739	Mainline	Medium haul, high density	85.1 t	OM-B 737
Boeing 737 MAX 8	B38M	Mainline	Short / medium haul	82.2 t	OM-B 737
Boeing 777F	B77F	Skycargo	Long-haul freighter	347.8 t	OM-B 777F
Boeing 747-8	B748	Mainline	Long haul	447.7 t	OM-B 747-8
ATR 72-600	AT76	CityHopper	Regional	23.0 t	OM-B ATR
ATR 42-600	AT46	CityHopper	Regional, short fields	18.6 t	OM-B ATR

Company configuration policy

TYPE	TAKEOFF FLAP	LANDING FLAP: STANDARD	LANDING FLAP: MINIMUM
A319 / A320neo	CONF 1+F, 2 or 3 (OPT)	**CONF FULL**	**CONF 3** (CN-003)
A350	CONF 1+F, 2 or 3	CONF FULL	CONF 3
A380	CONF 1+F, 2 or 3	CONF FULL	CONF 3
737 NG / MAX	**FLAPS 5 minimum** (CN-002); 10, 15, 25 as required	**FLAPS 30**	**FLAPS 25** (CN-003)

TYPE	TAKEOFF FLAP	LANDING FLAP: STANDARD	LANDING FLAP: MINIMUM
777F	FLAPS 5, 15 or 20	FLAPS 30	FLAPS 25
747-8	FLAPS 10 or 20	FLAPS 30	FLAPS 25
ATR 72-600	FLAPS 15	FLAPS 30	FLAPS 15 in icing / as required
ATR 42-600	FLAPS 15	FLAPS 35	FLAPS 25 as required

> **NOTE** Only the 737 and A320-family entries are company **restrictions** (Company NOTAMs). The others describe normal practice.

Normal checklists

Every type has its own normal checklist in the QRH and in the EFB **Checklists** app.

Airbus A319 / A320neo

Key data, speed limitations, configuration policy (CONF 3 minimum for landing) and handling notes for the AviatesAir A319 (CityHopper) and A320neo (Mainline).

Fleet

	A319	A320NEO
Brand	CityHopper (VAH)	Mainline (VAV)
Engines	CFM56-5B / IAE V2500	CFM LEAP-1A / PW1100G
Typical MTOW	75,500 kg	79,000 kg
Typical MLW	62,500 kg	67,400 kg
Typical MZFW	58,500 kg	64,300 kg
Max operating altitude	39,800 ft	39,800 ft
VMO / MMO	350 kt / M0.82	350 kt / M0.82

Speed limitations

CONFIGURATION	VFE
CONF 1	230 kt
CONF 1+F	215 kt
CONF 2	200 kt
CONF 3	185 kt
CONF FULL	177 kt

LANDING GEAR	SPEED
VLO extension	250 kt
VLO retraction	220 kt
VLE	280 kt / M0.67

Configuration policy

- **Takeoff:** CONF 1+F, 2 or 3 from EFB Departure Perf (OPT recommended). FLEX when performance allows.
- **Landing: CONF FULL standard; CONF 3 minimum** (CN-003). Choose CONF 3 for a reason (windshear expected, go-around performance) and brief it.

- **Autobrake:** LO for normal landings on long dry runways, MED for short or wet runways.

Handling notes

- **Managed** speed and descent are normal. Monitor the energy circle and the descent profile, and use speedbrakes early rather than late.
- **Approach speed:** VAPP = VLS + the greater of 5 kt (A/THR ON) and ⅓ of the headwind component, 15 kt maximum. EFB Arrival Perf computes it.
- **Flare:** at about 30 ft. "RETARD" is called at 20 ft: bring the thrust levers to idle. Avoid holding the aircraft off; the A320 family floats readily.
- **Tail-strike awareness:** don't over-rotate. Target about 15° after lift-off at 3° per second.
- **neo:** allow for the longer engine warm-up before takeoff thrust and the cool-down before shutdown that the add-on's procedures call for.

Checklist

QRH normal checklist: A319 / A320neo

Airbus A350-900

Key data, configuration policy and long-haul handling notes for the AviatesAir A350-900.

Fleet

	A350-900
Brand	Mainline (VAV)
Engines	Rolls-Royce Trent XWB-84
Typical MTOW	283,000 kg
Typical MLW	207,000 kg
Typical MZFW	195,700 kg
Max operating altitude	43,100 ft
VMO / MMO	340 kt / M0.89

Configuration policy

- **Takeoff:** CONF 1+F, 2 or 3 per performance. FLEX is normal on long-haul departures. Heavy departures commonly need CONF 2 or 3.
- **Landing: CONF FULL standard**; CONF 3 when briefed (windshear, go-around performance).
- **Braking: BTV** (brake-to-vacate) is preferred where the runway exit is known: select the exit in the approach briefing. Otherwise use autobrake LO/2/3 as the runway requires.

Handling notes

- **Pitch trim** is set automatically on the ground, so there's no trim setting in the checklist. Check the takeoff data instead.
- **Long haul:** plan crew rest and fuel checks at every ETOPS entry point and waypoint. Keep the step-climb plan from the OFP.
- **Descent planning:** allow for a long, shallow deceleration. Start the descent on the managed profile and use speedbrakes early rather than late.
- **Flare** at about 30 ft, idle by touchdown. The A350 is stable in the flare, so avoid the tendency to hold it off.

Checklist

QRH normal checklist: A350

Airbus A380-800

Key data, wake turbulence, airport and gate requirements, configuration policy and handling notes for the AviatesAir A380.

Fleet

	A380-800
Brand	Mainline (VAV)
Engines	Rolls-Royce Trent 900 / Engine Alliance GP7200
Typical MTOW	575,000 kg
Typical MLW	394,000 kg
Typical MZFW	369,000 kg
Max operating altitude	43,100 ft
VMO / MMO	340 kt / M0.89
Wake category	**Super (J)**, RECAT-EU category A

Airport and ground requirements

- The A380 needs **Code F** taxiways, stands and runways. Plan only to airports with A380 routes; they're approved for it.
- Expect **longer pushback and taxi times** and follow-me vehicles at some airports.
- Use the gate the airport scenery designates for the A380. Upper-deck boarding bridges are needed for a realistic turnaround.

Wake turbulence

- File and fly as **"Super"** on the network. Aircraft behind you need enlarged separation: up to 8 NM for a light aircraft on approach.
- Departing behind another A380, allow at least **3 minutes** unless ATC applies radar separation.

Configuration policy

- **Takeoff:** CONF 1+F, 2 or 3 per performance, with FLEX.
- **Landing: CONF FULL standard**. **BTV** is preferred where the exit is known; otherwise autobrake per the runway state.

Handling notes

- **Inertia:** plan speed and altitude changes well ahead. The aircraft decelerates slowly in level flight.

- **Flare** at about 40–50 ft with a small pitch change and progressive thrust reduction. Touch down on the main gear and lower the nose promptly.
- **Taxi** with the external taxi camera system. Keep the nose wheel on the centreline in turns and watch for wingtip clearance.

Checklist

QRH normal checklist: A380

Boeing 737-600 / -800 / -900ER / MAX 8

Key data, flap placards, company flap restrictions (FLAPS 5 minimum for takeoff, FLAPS 25 minimum for landing) and handling notes for the 737 NG and MAX fleet.

WARNING Company restrictions apply to this fleet: **FLAPS 5 minimum for takeoff** (CN-002) and **FLAPS 25 minimum for landing** (CN-003).

Fleet

	737-600	737-800	737-900ER	737 MAX 8
Brand	CityHopper	Mainline	Mainline	Mainline
Engines	CFM56-7B	CFM56-7B	CFM56-7B	CFM LEAP-1B
Typical MTOW	65,500 kg	79,000 kg	85,100 kg	82,200 kg
Typical MLW	55,100 kg	66,400 kg	71,400 kg	69,300 kg
Typical MZFW	51,700 kg	62,700 kg	67,700 kg	65,900 kg
Max operating altitude	41,000 ft	41,000 ft	41,000 ft	41,000 ft
VMO / MMO	340 kt / M0.82	340 kt / M0.82	340 kt / M0.82	340 kt / M0.82

Flap placard speeds (737-800)

FLAPS	1	2	5	10	15	25	30	40
Max speed (kt)	250	250	250	210	200	190	175	162

LANDING GEAR	SPEED
Extension (VLO)	270 kt / M0.82
Retraction (VLO)	235 kt
Extended (VLE)	320 kt / M0.82

Configuration policy

- **Takeoff: FLAPS 5 standard and minimum.** FLAPS 10, 15 or 25 for limiting runways. **FLAPS 1 is not permitted** (CN-002).
- **Landing: FLAPS 30 standard; FLAPS 25 minimum**; FLAPS 40 for short, wet or contaminated runways (CN-003).
- **Autobrake:** RTO for takeoff; 2 for normal landings, 3 for wet or shorter runways, MAX for contaminated runways.
- **Speedbrake:** ARMED for landing; check that it deploys on touchdown.

Handling notes

- **Rotation:** a smooth 2–3° per second towards about 15° nose-up. The longer the fuselage, the smaller the **tail-strike margin**: the 737-800, MAX 8 and especially the -900ER have far less than the -600. Never rotate before VR, and never rotate rapidly.
- **Approach speed:** VREF + ½ the steady headwind + the full gust increment, minimum +5 kt, maximum +20 kt.
- **Flare:** begin at about 20 ft, raise the nose 2–3° and retard the thrust to idle. **Don't hold it off.** The 737 lands best firmly and on speed, and floating risks a tail strike on the -900ER.
- **Pitch at touchdown:** keep the normal landing attitude; don't push the nose down in the flare (a flat or nose-low touchdown risks a nose-gear-first landing), and never raise it to stretch the float.
- **MAX 8:** probe heat stays in **AUTO** (see the checklist). The LEAP-1B needs a longer warm-up before takeoff thrust.

Checklists

QRH normal checklist: 737-600/-800/-900ER · QRH normal checklist: 737 MAX 8

Boeing 777F (Skycargo)

Key data, cargo loading and dangerous goods, configuration policy and handling notes for the AviatesAir Skycargo 777 Freighter.

Fleet

	777F
Brand	Skycargo (VAC)
Engines	GE90-110B1
Typical MTOW	347,800 kg
Typical MLW	260,800 kg
Typical MZFW	248,100 kg
Max payload	about 102,000 kg
Max operating altitude	43,100 ft
VMO / MMO	330 kt / M0.89

Cargo operations

- **Loadsheet:** check the OFP's zero-fuel weight and the loadsheet MACZFW / MACTOW against the EFB (Pilot Brief → Loadsheet) before computing takeoff performance. Late changes of more than 1,000 kg need a new performance calculation.
- **Payload** is in kilograms on the loadsheet. Enter takeoff weight in tonnes in Departure Perf.
- **Supernumeraries:** couriers and animal handlers travel in the upper-deck area and receive a safety briefing.
- Only dangerous goods listed on the **NOTOC** (notice to captain) are carried. Brief their location and the fire drill for the main deck.

Configuration policy

- **Takeoff:** FLAPS 5, 15 or 20 per performance. Heavy freighter departures often need 15 or 20. Use derate or assumed temperature where performance allows.
- **Landing: FLAPS 30 standard**; FLAPS 25 when briefed.
- **Autobrake:** RTO for takeoff; 2 or 3 for landing as the runway requires.

Handling notes

- **Rotation:** a steady 2–2.5° per second. The long fuselage has a limited tail-strike margin, and the tail skid gives an early warning.
- **Approach:** the 777 is stable but slow to decelerate. Be configured and on speed by the 1,000 ft gate at heavy weights.

- **Flare** at about 30 ft, retard at about 25 ft, and don't float.

Checklist

QRH normal checklist: 777F

Boeing 747-8

Key data, configuration policy and handling notes for the AviatesAir 747-8 (Intercontinental data, freighter variant noted).

Fleet

	747-8 INTERCONTINENTAL	747-8F (IF FLOWN)
Brand	Mainline (VAV)	Mainline (VAV)
Engines	GEnx-2B67	GEnx-2B67
Typical MTOW	447,700 kg	447,700 kg
Typical MLW	312,100 kg	346,100 kg
Typical MZFW	295,300 kg	329,800 kg
Max operating altitude	43,100 ft	43,100 ft
VMO / MMO	365 kt / M0.90	365 kt / M0.90

Configuration policy

- **Takeoff:** FLAPS 10 or 20 per performance, with assumed temperature or derate where available.
- **Landing: FLAPS 30 standard**; FLAPS 25 when briefed (for example for go-around performance at high weights).
- **Autobrake:** RTO for takeoff; 2, 3 or 4 for landing as the runway requires.

Handling notes

- **Four engines:** set takeoff thrust symmetrically and monitor all four through the takeoff roll. An engine failure after V1 needs less rudder than on a twin, but still needs prompt, accurate rudder.
- **Rotation:** about 2–3° per second to the target attitude. Mind the tail on the long-bodied -8.
- **Flare:** begin at about 30 ft, and reduce thrust to idle during the flare. Keep the wings level. The outboard engine pods sit low in a crosswind.
- **Taxi:** judge turns from the main-gear position, which is well behind you, and use oversteer at narrow taxiway junctions.

Checklist

QRH normal checklist: 747-8

ATR 72-600 / ATR 42-600

Key data, hotel mode and propeller brake, icing, configuration policy and turboprop handling notes for the AviatesAir CityHopper ATR fleet.

Fleet

	ATR 72-600	ATR 42-600
Brand	CityHopper (VAH)	CityHopper (VAH)
Engines	2 × PW127M	2 × PW127M
Typical MTOW	23,000 kg	18,600 kg
Typical MLW	22,350 kg	18,300 kg
Typical MZFW	21,000 kg	17,000 kg
Max operating altitude	25,000 ft	25,000 ft
VMO	250 kt	250 kt

Hotel mode and propeller brake

- **Engine 2** can run with the **propeller brake ON** (hotel mode) to provide electrical power and air conditioning on the ground, like an APU.
- Never approach the right-hand propeller while engine 2 is running in hotel mode. Treat it as a running engine.
- **Before taxi:** propeller brake **OFF** (the "unfeather" sequence), condition levers **AUTO**.
- **After landing:** taxi in on engine 2. Shut down engine 1 (CL FTR then FUEL SO) after at least **one minute** at idle.

Icing

- The ATR operates at levels where icing is common. When the **ICING AOA** light is on, the icing speeds apply (the red bugs) and the **minimum manoeuvring speeds increase**.
- Engage the airframe de-icing boots at the first sign of ice accretion and keep them on until clear of icing conditions.
- In **severe icing** (ice on the side windows, unexpected roll or heavy vibration): leave the icing conditions immediately and disengage the autopilot while holding the controls firmly.

Configuration policy

	ATR 72-600	ATR 42-600
Takeoff	**FLAPS 15**	**FLAPS 15**
Landing: standard	**FLAPS 30**	**FLAPS 35**

	ATR 72-600	ATR 42-600
Landing: alternative	FLAPS 15 (icing or as required)	FLAPS 25 (as required)

- Power management selector: **TO** for takeoff, **MCT** after an engine failure, **CLB** and **CRZ** as the phases require.
- TLU **LO SPD** for landing (check it has moved).

Handling notes

- **Rotation** at VR to about 6–8°. The ATR 72 has a long fuselage, so don't over-rotate.
- **Approach:** a stable 3° path at VAPP, with power (not pitch) controlling speed. Keep a little power in the flare.
- **Flare** is small: reduce power progressively from about 20 ft and let the aircraft settle. Avoid pulling the power to flight idle high up, as the sink rate builds quickly.
- **Crosswind:** the ATR has a relatively low wing loading and a high wing. Hold aileron into wind during the takeoff and landing roll, and engage the gust lock only when parked.
- **Tail prop:** fit the **tail stand** on the ATR 72 whenever it is parked (it isn't needed on the ATR 42).

Checklists

QRH normal checklist: ATR 72-600 · QRH normal checklist: ATR 42-600

Immediate Actions (Memory Items)

The recall actions every AviatesAir pilot knows by heart (rejected takeoff, engine fire, emergency descent, TCAS RA, terrain, windshear, unreliable airspeed and stall recovery) in Airbus and Boeing form.

WARNING Reference only. The **ECAM / QRH of your aircraft add-on** is the authority for your type. Fly the aircraft first; do the memory items from memory, then complete the checklist.

Rejected takeoff

	ACTION
PF calls	**"STOP"**
Thrust levers	**IDLE / CLOSE** (autothrottle disconnects)
Reverse thrust	**MAX** as required
Brakes	**RTO autobrake**, or maximum manual braking
Speedbrake / ground spoilers	Check **deployed**
Direction	Maintain the **centreline**
After stopping	Parking brake **SET**. Notify ATC and the cabin, then assess (fire? evacuation?)

Engine fire or severe damage

Airbus (ECAM ENG FIRE): thrust lever (affected) **IDLE**; engine master (affected) **OFF**; fire push-button **PUSH**; agent 1 **DISCH** after 10 s; agent 2 if the fire persists after 30 s.

Boeing (ENG FIRE): autothrottle **DISENGAGE**; thrust lever (affected) **CLOSE**; engine start lever / fuel control switch (affected) **CUTOFF**; engine fire switch **PULL, then ROTATE** to the stop to discharge; if the fire warning persists after 30 seconds, rotate it to the other bottle.

Emergency descent

1. Crew oxygen masks **ON, 100 %**. Establish communication.
2. Signs **ON**; passenger oxygen **ON** if the cabin altitude exceeds 14,000 ft.
3. Descent **INITIATE**: altitude selector to the lowest safe altitude (MEA/MORA, typically FL100), heading as required, speed **MAX / appropriate**, speedbrakes **FULL**.
4. Transponder **7700** unless ATC has assigned another code. Declare **MAYDAY**.

TCAS resolution advisory

- **Follow the RA** promptly and smoothly: disconnect the autopilot and flight directors and fly the green band. On Airbus types with the AP/FD TCAS mode, the autopilot may fly the RA; monitor it.

- **Never** manoeuvre against the RA, even if ATC has given a conflicting instruction.
- Report "**TCAS RA**" to ATC as soon as possible. When clear of conflict, return to the clearance and report "**clear of conflict, returning to…**".

Terrain warning: "PULL UP" / "TERRAIN AHEAD PULL UP"

- **Airbus:** AP **OFF**; pitch **pull to full back stick**; thrust **TOGA**; speedbrakes **RETRACT**; wings **LEVEL**.
- **Boeing:** AP and A/T **DISENGAGE**; thrust **MAX**; pitch to **20°** and roll wings level; speedbrakes **RETRACT**. Stay at the pitch limit indication if needed.
- Climb until the warning stops **and** you are safe. Do not change configuration until then.

Windshear

- **Takeoff roll** (before V1): reject if there's enough runway, otherwise continue.
- **Airborne / on approach** ("WINDSHEAR"): thrust **TOGA / MAX**; follow the flight director or pitch to about 15° (Boeing: up to the pitch limit indicator); **do not change the configuration** (gear or flaps) until out of the shear; speedbrakes **RETRACT**.
- **Predictive "WINDSHEAR AHEAD"** on approach: **go around**.

Unreliable airspeed

If a flight path is in danger (Airbus memory items): AP / FD / A/THR **OFF**, then set pitch and thrust, keep the flaps where they are, retract the speedbrakes, and raise the gear after takeoff.

PHASE	PITCH	THRUST
Below the thrust-reduction altitude	**15°**	**TOGA**
Above the thrust-reduction altitude, below FL100	**10°**	**CLB**
Above FL100	**5°**	**CLB**

Boeing: A/T and AP **DISENGAGE**, flight director switches **OFF**, then set the attitude and thrust for the flight phase from the QRH table.

Stall recovery

1. **Nose down:** reduce the angle of attack, push to unload (trim nose-down as needed).
2. **Bank:** roll **wings level**.
3. **Thrust:** as needed; mind the pitch-up couple of underwing engines.
4. **Speedbrakes:** retract.
5. Return to the desired flight path when out of the stall, without triggering a secondary stall.

Normal Checklist: Airbus A319 / A320neo

8 normal checklists, 57 items: BEFORE START · AFTER START · BEFORE TAKEOFF · AFTER TAKEOFF / CLIMB…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

BEFORE START

CHALLENGE	RESPONSE
COCKPIT PREP	**COMPLETED** *(BOTH)*
GEAR PINS and COVERS	**REMOVED**
SIGNS	**ON/AUTO**
ADIRS	**NAV**
FUEL QUANTITY	**___ KG / BALANCED**
TO DATA	**SET**
BARO REF	**___ SET** *(BOTH)*
WINDOWS/DOORS	**CLOSED/ARMED** *(BOTH)*
BEACON	**ON**
MOBILE PHONE	**OFF** *(BOTH)*
THR LEVERS	**IDLE**
PARKING BRAKE	**SET**

AFTER START

CHALLENGE	RESPONSE
ANTI ICE	**AS RQRD**
ECAM STATUS	**CHECKED**
PITCH TRIM	**___ % SET**
RUDDER TRIM	**ZERO**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
FLT CTL	**CHECKED** *(BOTH)*
FLT INSTRUMENTS	**CHECKED** *(BOTH)*
BRIEFING	**CONFIRMED**
FLAP SETTING	**CONF** ___ *(BOTH)*
FMA & TO DATA (*PF reads the FMA and takeoff data, PM checks*)	**READ / CHECKED** *(PF/PM)*
TRANSPONDER	___ **SET**
ECAM MEMO (*AUTO BRK MAX · SIGNS ON · SPLRS ARM · FLAPS TO · TO CONFIG NORM*)	**TO NO BLUE**
CABIN	**SECURED**
ENG MODE SEL	**AS RQRD**
TCAS	**TA OR TA/RA**
PACKS	**AS RQRD**

AFTER TAKEOFF / CLIMB

CHALLENGE	RESPONSE
LDG GEAR	**UP**
FLAPS	**RETRACTED**
PACKS	**ON**
BARO REF (*At the transition altitude*)	**STD SET** *(BOTH)*

APPROACH

CHALLENGE	RESPONSE
BRIEFING	**CONFIRMED**
ECAM STATUS	**CHECKED**
SEAT BELTS	**ON**
BARO REF	___ **SET** *(BOTH)*
MINIMUM	___ **SET** *(BOTH)*
ENG MODE SEL	**AS RQRD**

LANDING

CHALLENGE	RESPONSE
CABIN	**SECURED**
A/THR	**SPEED / OFF**
GO-AROUND ALT	**___ SET**
ECAM MEMO (*LDG GEAR DN · SIGNS ON · SPLRS ARM · FLAPS SET*)	**LDG NO BLUE**

PARKING

CHALLENGE	RESPONSE
APU BLEED	**ON**
Y ELEC PUMP	**OFF**
ENGINES	**OFF**
SEAT BELTS	**OFF**
EXT LT	**AS RQRD**
FUEL PUMPS	**OFF**
PARK BRK and CHOCKS	**AS RQRD**
MOBILE PHONE	**ON**
TRANSPONDER	**STBY 2000**
RADAR / PWS	**OFF**

SECURING THE AIRCRAFT

CHALLENGE	RESPONSE
ADIRS	**OFF**
OXYGEN	**OFF**
APU BLEED	**OFF**
EMER EXIT LT	**OFF**
NO SMOKING	**OFF**
APU and BAT	**OFF**

Source: Airbus A319/A320 Normal Checklist (Airbus, Nov 2017 simulation release). ENG MODE SEL / neo items as per the A320neo cockpit. For simulation use only.

Normal Checklist: Airbus A350

8 normal checklists, 50 items: BEFORE START · AFTER START · BEFORE TAKEOFF · AFTER TAKEOFF / CLIMB…

> **NOTE** These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

BEFORE START

CHALLENGE	RESPONSE
COCKPIT PREP	**COMPLETED** *(BOTH)*
GEAR PINS & COVERS	**REMOVED**
SIGNS	**ON/AUTO**
ADIRS	**NAV**
FUEL QUANTITY	___ **KG**
T.O DATA	**SET**
BARO REF	___ **SET** *(BOTH)*
WINDOWS / DOORS	**CLOSED** *(BOTH)*
BEACON	**ON**
MOBILE PHONE	**OFF** *(BOTH)*
THR LEVERS	**IDLE**
PARKING BRAKE	**SET**

AFTER START

CHALLENGE	RESPONSE
ANTI ICE	**AS RQRD**
ECAM STATUS (*Pitch trim is set automatically on the A350*)	**CHECKED**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
FLT CTL	**CHECKED** *(BOTH)*

CHALLENGE	RESPONSE
FLT INSTRUMENTS	**CHECKED** *(BOTH)*
BRIEFING	**CONFIRMED**
FLAPS SETTING	**CONF** ___ *(BOTH)*
FMA & T.O DATA	**READ / CHECKED** *(PF/PM)*
TRANSPONDER	___ **SET**
ECAM MEMO (*AUTO BRK RTO · SIGNS ON · SPLRS ARM · FLAPS T.O · T.O CONFIG NORM*)	**T.O NO BLUE** *(BOTH)*
CABIN	**SECURED**
TCAS	**TA OR TA/RA**
PACKS	**AS RQRD**

AFTER TAKEOFF / CLIMB

CHALLENGE	RESPONSE
LDG GEAR	**UP**
FLAPS	**RETRACTED**
PACKS	**ON**
BARO REF (*At the transition altitude*)	**STD SET** *(BOTH)*

APPROACH

CHALLENGE	RESPONSE
BRIEFING	**CONFIRMED**
ECAM STATUS	**CHECKED**
SEAT BELTS	**ON**
BARO REF	___ **SET** *(BOTH)*
MINIMUM	___ **SET** *(BOTH)*
AUTO BRK / BTV	**AS RQRD**

LANDING

CHALLENGE	RESPONSE
CABIN	**SECURED**

CHALLENGE	RESPONSE
A/THR	**SPEED / OFF**
ECAM MEMO (*LDG GEAR DN · SIGNS ON · SPLRS ARM · FLAPS SET*)	**LDG NO BLUE**

PARKING

CHALLENGE	RESPONSE
APU BLEED	**ON**
ELEC PUMPS	**OFF**
ENGINES	**OFF**
SEAT BELTS	**OFF**
EXT LT	**AS RQRD**
FUEL PUMPS	**OFF**
PARK BRK and CHOCKS	**AS RQRD**

SECURING THE AIRCRAFT

CHALLENGE	RESPONSE
ADIRS	**OFF**
OXYGEN	**OFF**
APU BLEED	**OFF**
EMER EXIT LT	**OFF**
SIGNS	**OFF**
APU and BAT	**OFF**

Source: Airbus A350 FCOM normal checklist (ECL) excerpts, aligned to the A320 C/L layout for items common to the family. For simulation use only.

Normal Checklist: Airbus A380

8 normal checklists, 54 items: BEFORE START · AFTER START · BEFORE TAKEOFF · AFTER TAKEOFF / CLIMB…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

BEFORE START

CHALLENGE	RESPONSE
COCKPIT PREP	**COMPLETED** *(BOTH)*
GEAR PINS & COVERS	**REMOVED**
OXYGEN	**CHECKED**
SIGNS	**ON/AUTO**
ADIRS	**NAV**
FUEL QUANTITY	___ **KG**
T.O DATA	**SET**
BARO REF	___ **SET** *(BOTH)*
WINDOWS / DOORS	**CLOSED** *(BOTH)*
BEACON	**ON**
THR LEVERS	**IDLE**
PARKING BRAKE	**SET**

AFTER START

CHALLENGE	RESPONSE
ANTI ICE	**AS RQRD**
ECAM STATUS	**CHECKED**
PITCH TRIM	___ **CHECKED**
RUDDER TRIM	**NEUTRAL**
GROUND EQUIPMENT	**CLEAR**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
FLT CTL	**CHECKED** *(BOTH)*
FLT INSTRUMENTS	**CHECKED** *(BOTH)*
BRIEFING	**CONFIRMED**
FLAPS SETTING	**CONF** ___ *(BOTH)*
FMA & T.O DATA (*V1 · VR · V2 · FLEX TEMP*)	**READ / CHECKED** *(PF/PM)*
AUTO BRK	**RTO**
TRANSPONDER	___ **SET**
ECAM MEMO (*SIGNS ON · SPLRS ARM · FLAPS T.O · T.O CONFIG NORM*)	**T.O NO BLUE** *(BOTH)*
CABIN	**SECURED**
TCAS	**TA OR TA/RA**
PACKS	**AS RQRD**

AFTER TAKEOFF / CLIMB

CHALLENGE	RESPONSE
LDG GEAR	**UP**
FLAPS	**RETRACTED**
PACKS	**ON**
APU MASTER	**OFF**
BARO REF (*At the transition altitude*)	**STD SET** *(BOTH)*

APPROACH

CHALLENGE	RESPONSE
BRIEFING	**CONFIRMED**
ECAM STATUS	**CHECKED**
SEAT BELTS	**ON**
BARO REF	___ **SET** *(BOTH)*
MINIMUM	___ **SET** *(BOTH)*

CHALLENGE	RESPONSE
AUTO BRK / BTV	**AS RQRD**

LANDING

CHALLENGE	RESPONSE
CABIN	**SECURED**
A/THR	**SPEED / OFF**
ECAM MEMO (*LDG GEAR DN · SIGNS ON · SPLRS ARM · FLAPS SET*)	**LDG NO BLUE**

PARKING

CHALLENGE	RESPONSE
APU BLEED	**ON**
ENGINES (ALL 4)	**OFF**
SEAT BELTS	**OFF**
EXT LT	**AS RQRD**
FUEL PUMPS	**OFF**
PARK BRK and CHOCKS	**AS RQRD**

SECURING THE AIRCRAFT

CHALLENGE	RESPONSE
ADIRS	**OFF**
OXYGEN	**OFF**
APU BLEED	**OFF**
EMER EXIT LT	**OFF**
SIGNS	**OFF**
APU and BATTERIES	**OFF**

Source: FlyByWire A380X simulation checklist (29 Nov 2021) arranged in the Airbus ECL normal-checklist layout. For simulation use only.

Normal Checklist: Boeing 737-600/-800/-900ER

10 normal checklists, 54 items: PREFLIGHT · BEFORE START · BEFORE TAXI · BEFORE TAKEOFF…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

PREFLIGHT

CHALLENGE	RESPONSE
Oxygen	**Tested, 100%**
Navigation transfer and display switches	**NORMAL, AUTO**
Window heat	**ON**
Pressurization mode selector	**AUTO**
Flight instruments	**Heading ___, Altimeter ___**
Parking brake	**Set**
Engine start levers	**CUTOFF**

BEFORE START

CHALLENGE	RESPONSE
Flight deck door	**Closed and locked**
Fuel	**___ KGS, Pumps ON**
Passenger signs	___
Windows	**Locked**
MCP	**V2 ___, HDG ___, ALT ___**
Takeoff speeds	**V1 ___, VR ___, V2 ___**
CDU preflight	**Completed**
Rudder and aileron trim	**Free and 0**
Taxi and takeoff briefing	**Completed**
Anti collision light	**ON**

BEFORE TAXI

CHALLENGE	RESPONSE
Generators	**ON**
Probe heat	**ON**
Anti-ice	___
Isolation valve	**AUTO**
Engine start switches	**CONT**
Recall	**Checked**
Autobrake	**RTO**
Engine start levers	**IDLE detent**
Flight controls	**Checked**
Ground equipment	**Clear**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
Flaps	**___, Green light**
Stabilizer trim	**___ Units**

AFTER TAKEOFF

CHALLENGE	RESPONSE
Engine bleeds	**ON**
Packs	**AUTO**
Landing gear	**UP and OFF**
Flaps	**UP, No lights**

DESCENT

CHALLENGE	RESPONSE
Pressurization	**LAND ALT ___**
Recall	**Checked**
Autobrake	___

CHALLENGE	RESPONSE
Landing data	**VREF ___, Minimums ___**
Approach briefing	**Completed**

APPROACH

CHALLENGE	RESPONSE
Altimeters	___

LANDING

CHALLENGE	RESPONSE
Engine start switches	**CONT**
Speedbrake	**ARMED**
Landing gear	**Down**
Flaps	**___, Green light**

SHUTDOWN

CHALLENGE	RESPONSE
Fuel pumps	**OFF**
Probe heat	**OFF**
Hydraulic panel	**Set**
Flaps	**UP**
Parking brake	___
Engine start levers	**CUTOFF**
Weather radar	**OFF**

SECURE

CHALLENGE	RESPONSE
IRSs	**OFF**
Emergency exit lights	**OFF**
Window heat	**OFF**

CHALLENGE	RESPONSE
Packs	**OFF**

Source: Boeing 737NG QRH Normal Checklists (as published in training references, e.g. aviationhunt.com). For simulation use only.

Normal Checklist: Boeing 737 MAX 8

10 normal checklists, 54 items: PREFLIGHT · BEFORE START · BEFORE TAXI · BEFORE TAKEOFF…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

PREFLIGHT

CHALLENGE	RESPONSE
Oxygen	**Tested, 100%**
Navigation transfer and display switches	**NORMAL, AUTO**
Window heat	**ON**
Pressurization mode selector	**AUTO**
Flight instruments	**Heading ___, Altimeter ___**
Parking brake	**Set**
Engine start levers	**CUTOFF**

BEFORE START

CHALLENGE	RESPONSE
Flight deck door	**Closed and locked**
Fuel	**___ KGS, Pumps ON**
Passenger signs	___
Windows	**Locked**
MCP	**V2 ___, HDG ___, ALT ___**
Takeoff speeds	**V1 ___, VR ___, V2 ___**
CDU preflight	**Completed**
Rudder and aileron trim	**Free and 0**
Taxi and takeoff briefing	**Completed**
Anti collision light	**ON**

BEFORE TAXI

CHALLENGE	RESPONSE
Generators	**ON**
Probe heat	**AUTO**
Anti-ice	___
Isolation valve	**AUTO**
Engine start switches	**CONT**
Recall	**Checked**
Autobrake	**RTO**
Engine start levers	**IDLE detent**
Flight controls	**Checked**
Ground equipment	**Clear**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
Flaps	**___, Green light**
Stabilizer trim	**___ Units**

AFTER TAKEOFF

CHALLENGE	RESPONSE
Engine bleeds	**ON**
Packs	**AUTO**
Landing gear	**UP and OFF**
Flaps	**UP, No lights**

DESCENT

CHALLENGE	RESPONSE
Pressurization	**LAND ALT ___**
Recall	**Checked**
Autobrake	___

CHALLENGE	RESPONSE
Landing data	**VREF ___, Minimums ___**
Approach briefing	**Completed**

APPROACH

CHALLENGE	RESPONSE
Altimeters	___

LANDING

CHALLENGE	RESPONSE
Engine start switches	**CONT**
Speedbrake	**ARMED**
Landing gear	**Down**
Flaps	**___, Green light**

SHUTDOWN

CHALLENGE	RESPONSE
Fuel pumps	**OFF**
Probe heat	**AUTO**
Hydraulic panel	**Set**
Flaps	**UP**
Parking brake	___
Engine start levers	**CUTOFF**
Weather radar	**OFF**

SECURE

CHALLENGE	RESPONSE
IRSs	**OFF**
Emergency exit lights	**OFF**
Window heat	**OFF**

CHALLENGE	RESPONSE
Packs	**OFF**

Source: Boeing 737NG QRH Normal Checklists with the 737 MAX differences (probe heat AUTO). For simulation use only.

Normal Checklist: Boeing 777F

10 normal checklists, 38 items: PREFLIGHT · BEFORE START · BEFORE TAXI · BEFORE TAKEOFF…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

PREFLIGHT

CHALLENGE	RESPONSE
Oxygen	**Tested, 100%**
Flight instruments	**Heading ___, Altimeter ___**
Parking brake	**Set**
Fuel control switches	**CUTOFF**

BEFORE START

CHALLENGE	RESPONSE
Flight deck door	**Closed and locked**
Passenger signs	___
MCP	**V2 ___, HDG/TRK ___, ALT ___**
Takeoff speeds	**V1 ___, VR ___, V2 ___**
CDU preflight	**Completed**
Trim	___ **Units, 0, 0**
Taxi and takeoff briefing	**Completed**
Beacon	**ON**

BEFORE TAXI

CHALLENGE	RESPONSE
Anti-ice	___
Recall	**Checked**
Autobrake	**RTO**

CHALLENGE	RESPONSE
Flight controls	**Checked**
Ground equipment	**Clear**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
Flaps	___

AFTER TAKEOFF

CHALLENGE	RESPONSE
Landing gear	**UP**
Flaps	**UP**

DESCENT

CHALLENGE	RESPONSE
Recall	**Checked**
Notes	**Checked**
Autobrake	___
Landing data	**VREF ___, Minimums ___**
Approach briefing	**Completed**

APPROACH

CHALLENGE	RESPONSE
Altimeters	___

LANDING

CHALLENGE	RESPONSE
Speedbrake	**ARMED**
Landing gear	**Down**
Flaps	___

SHUTDOWN

CHALLENGE	RESPONSE
Hydraulic panel	**Set**
Fuel pumps	**Off**
Flaps	**Up**
Parking brake	—
Fuel control switches	**CUTOFF**
Weather radar	**Off**

SECURE

CHALLENGE	RESPONSE
ADIRU	**Off**
Emergency lights	**OFF**
Packs	**Off**

Source: Boeing 777 QRH Normal Checklists (common to the 777-200LR/-300ER/777F electronic checklist). For simulation use only.

Normal Checklist: Boeing 747-8

10 normal checklists, 38 items: PREFLIGHT · BEFORE START · BEFORE TAXI · BEFORE TAKEOFF…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

PREFLIGHT

CHALLENGE	RESPONSE
Oxygen	**Tested, 100%**
Flight instruments	**Heading ___, Altimeter ___**
Parking brake	**Set**
Fuel control switches	**CUTOFF**

BEFORE START

CHALLENGE	RESPONSE
Flight deck door	**Closed and locked**
Passenger signs	___
MCP	**V2 ___, HDG/TRK ___, ALT ___**
Takeoff speeds	**V1 ___, VR ___, V2 ___**
CDU preflight	**Completed**
Trim	___ **Units, 0, 0**
Taxi and takeoff briefing	**Completed**
Beacon	**BOTH**

BEFORE TAXI

CHALLENGE	RESPONSE
Anti-ice	___
Recall	**Checked**
Autobrake	**RTO**

CHALLENGE	RESPONSE
Flight controls	**Checked**
Ground equipment	**Clear**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
Flaps	___

AFTER TAKEOFF

CHALLENGE	RESPONSE
Landing gear	**UP**
Flaps	**UP**

DESCENT

CHALLENGE	RESPONSE
Recall	**Checked**
Notes	**Checked**
Autobrake	___
Landing data	**VREF ___, Minimums ___**
Approach briefing	**Completed**

APPROACH

CHALLENGE	RESPONSE
Altimeters	___

LANDING

CHALLENGE	RESPONSE
Speedbrake	**ARMED**
Landing gear	**Down**
Flaps	___

SHUTDOWN

CHALLENGE	RESPONSE
Hydraulic demand pumps	**OFF**
Fuel pumps	**Off**
Flaps	**Up**
Parking brake	—
Fuel control switches	**CUTOFF**
Weather radar	**Off**

SECURE

CHALLENGE	RESPONSE
IRSs	**OFF**
Emergency lights	**OFF**
Packs	**Off**

Source: Boeing 747-8 QRH Normal Checklists (747-400 lineage: beacon BOTH, hydraulic demand pumps, IRSs). For simulation use only.

Normal Checklist: ATR 72-600

13 normal checklists, 93 items: FINAL COCKPIT PREPARATION · BEFORE PROPELLER ROTATION · BEFORE TAXI · TAXI…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

FINAL COCKPIT PREPARATION

CHALLENGE	RESPONSE
PARKING BRAKE	**ON / PRESS CHECKED**
ALTIMETERS	**SET**
LANDING ELEVATION	**SET**
FMS / COM / NAV	**SET / CHECKED**
FUEL QUANTITY / FOB	**CHECKED**
ENG FUEL USED	**RESET**
MEMO PANEL	**CHECKED**
PWR MGT	**TO**
PROP BRAKE	**AS RQD**

BEFORE PROPELLER ROTATION

CHALLENGE	RESPONSE
TAIL PROP	**ON BOARD**
DOORS	**CLOSED**
FMS & T/O DATA	**CONFIRMED / SET**
TRIMS	**SET**
CDLS	**CHECKED**
SEAT BELTS	**ON**
BEACON	**ON**

BEFORE TAXI

CHALLENGE	RESPONSE
FWS	**RCL**
PROP BRAKE	**OFF**
COCKPIT COM HATCH	**CLOSED**
NOSE WHEEL STEERING	**ON**
CL 1 + 2	**AUTO**
ANTI-ICING	**AS RQD**
ANTI-SKID	**TESTED**
FLAPS	**15 SET**

TAXI

CHALLENGE	RESPONSE
TAXI & T/O LIGHTS	**ON**
BRAKES	**CHECKED**
FGCP / FMA	**SET / CHECKED**
TO CONFIG	**TESTED**
TAKEOFF BRIEFING	**COMPLETE**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
APM	**SET**
BLEED VALVES (*OFF for bleeds-off takeoff performance*)	**AS RQD**
AIR FLOW	**NORM**
GUST LOCK	**RELEASED**
FLIGHT CONTROLS	**CHECKED**
XPDR / TCAS	**TA/RA**
EXT LIGHTS	**ON**
FD BAR (*When lined up*)	**CENTRED**

CHALLENGE	RESPONSE
RUDDER CAM	**CENTRED**
FLIGHT ATTENDANTS	**NOTIFIED**

AFTER TAKEOFF

CHALLENGE	RESPONSE
LDG GEAR	**UP**
FLAPS	**0°**
PWR MGT / NP	**CLB / CHECKED**
BLEED VALVES	**ON**
TAXI & T/O LIGHTS	**OFF**
ALTIMETERS	**SET & CHECKED**
SEAT BELTS	**AS RQD**

CRUISE

CHALLENGE	RESPONSE
CRUISE SPEED	**SET**
PWR MGT	**CRZ**
STBY ALTIMETER	**SET**
PRESSURIZATION	**CHECKED**
TCAS	**ABOVE / BELOW**

DESCENT

CHALLENGE	RESPONSE
FWS	**RCL**
LDG ELEVATION	**SET / CHECKED**
FMS (NAV / PERF)	**SET / CHECKED**
DH / MDA	**SET**
ARRIVAL BRIEFING	**COMPLETE**

APPROACH

CHALLENGE	RESPONSE
SEAT BELTS	**ON**
LANDING LIGHTS	**ON**
ALTIMETERS	**QNH SET & CHECKED**
CABIN ALTITUDE	**CHECKED**
CROSSFEED	**CHECKED**

BEFORE LANDING

CHALLENGE	RESPONSE
LDG GEAR	**DOWN, 3 GREEN**
FLAPS (*FLAPS 30 normal landing*)	**30 SET**
PWR MGT	**TO**
TLU	**LO SPD**
ICING AOA LIGHT	**CHECKED**
EXT LIGHTS	**CHECKED**
FLIGHT ATTENDANTS	**ADVISED**

AFTER LANDING

CHALLENGE	RESPONSE
XPDR / TCAS / RADAR	**STBY**
FLIGHT CONTROLS	**LOCKED**
FLAPS	**0°**
TRIMS	**SET**
LANDING LIGHTS / STROBES	**OFF**
ANTI / DE-ICING	**OFF**
ENG START ROTARY	**OFF**
CL 1 (*After at least one minute at idle; taxi in on ENG 2*)	**FTR THEN FUEL SO**

PARKING

CHALLENGE	RESPONSE
PARKING BRAKE	**ON**
TAXI & T/O LIGHTS	**OFF**
CL 2	**FTR**
PROP BRAKE (*ON for hotel mode*)	**AS RQD**
BEACON	**OFF**
TAIL PROP	**IN POSITION**
SEAT BELTS	**OFF**
FWD CARGO DOOR	**OPEN**

LEAVING THE AIRCRAFT

CHALLENGE	RESPONSE
OXYGEN MAIN SUPPLY	**OFF**
ICE & RAIN PROTECTION	**OFF**
EXT LIGHTS	**OFF**
EMER LIGHTS	**DISARMED**
RADAR	**OFF**
CL 2	**FUEL SO**
FUEL PUMPS 1 + 2	**OFF**
CDLS	**OFF**
BAT	**OFF**

Source: ATR 72-600 operator normal checklist WA-OPS-02-08B (May 2016), reordered into ATR FCOM phase order. For simulation use only.

Normal Checklist: ATR 42-600

13 normal checklists, 93 items: FINAL COCKPIT PREPARATION · BEFORE PROPELLER ROTATION · BEFORE TAXI · TAXI…

NOTE These are the same checklists as the EFB **Checklists** app, which follows your booked aircraft automatically. Complete the flows first, then read the checklist as challenge and response.

FINAL COCKPIT PREPARATION

CHALLENGE	RESPONSE
PARKING BRAKE	**ON / PRESS CHECKED**
ALTIMETERS	**SET**
LANDING ELEVATION	**SET**
FMS / COM / NAV	**SET / CHECKED**
FUEL QUANTITY / FOB	**CHECKED**
ENG FUEL USED	**RESET**
MEMO PANEL	**CHECKED**
PWR MGT	**TO**
PROP BRAKE	**AS RQD**

BEFORE PROPELLER ROTATION

CHALLENGE	RESPONSE
CARGO DOORS	**CLOSED**
DOORS	**CLOSED**
FMS & T/O DATA	**CONFIRMED / SET**
TRIMS	**SET**
CDLS	**CHECKED**
SEAT BELTS	**ON**
BEACON	**ON**

BEFORE TAXI

CHALLENGE	RESPONSE
FWS	**RCL**
PROP BRAKE	**OFF**
COCKPIT COM HATCH	**CLOSED**
NOSE WHEEL STEERING	**ON**
CL 1 + 2	**AUTO**
ANTI-ICING	**AS RQD**
ANTI-SKID	**TESTED**
FLAPS	**15 SET**

TAXI

CHALLENGE	RESPONSE
TAXI & T/O LIGHTS	**ON**
BRAKES	**CHECKED**
FGCP / FMA	**SET / CHECKED**
TO CONFIG	**TESTED**
TAKEOFF BRIEFING	**COMPLETE**

BEFORE TAKEOFF

CHALLENGE	RESPONSE
APM	**SET**
BLEED VALVES (*OFF for bleeds-off takeoff performance*)	**AS RQD**
AIR FLOW	**NORM**
GUST LOCK	**RELEASED**
FLIGHT CONTROLS	**CHECKED**
XPDR / TCAS	**TA/RA**
EXT LIGHTS	**ON**
FD BAR (*When lined up*)	**CENTRED**

CHALLENGE	RESPONSE
RUDDER CAM	**CENTRED**
FLIGHT ATTENDANTS	**NOTIFIED**

AFTER TAKEOFF

CHALLENGE	RESPONSE
LDG GEAR	**UP**
FLAPS	**0°**
PWR MGT / NP	**CLB / CHECKED**
BLEED VALVES	**ON**
TAXI & T/O LIGHTS	**OFF**
ALTIMETERS	**SET & CHECKED**
SEAT BELTS	**AS RQD**

CRUISE

CHALLENGE	RESPONSE
CRUISE SPEED	**SET**
PWR MGT	**CRZ**
STBY ALTIMETER	**SET**
PRESSURIZATION	**CHECKED**
TCAS	**ABOVE / BELOW**

DESCENT

CHALLENGE	RESPONSE
FWS	**RCL**
LDG ELEVATION	**SET / CHECKED**
FMS (NAV / PERF)	**SET / CHECKED**
DH / MDA	**SET**
ARRIVAL BRIEFING	**COMPLETE**

APPROACH

CHALLENGE	RESPONSE
SEAT BELTS	**ON**
LANDING LIGHTS	**ON**
ALTIMETERS	**QNH SET & CHECKED**
CABIN ALTITUDE	**CHECKED**
CROSSFEED	**CHECKED**

BEFORE LANDING

CHALLENGE	RESPONSE
LDG GEAR	**DOWN, 3 GREEN**
FLAPS (*FLAPS 35 normal landing (FLAPS 25 as required)*)	**35 SET**
PWR MGT	**TO**
TLU	**LO SPD**
ICING AOA LIGHT	**CHECKED**
EXT LIGHTS	**CHECKED**
FLIGHT ATTENDANTS	**ADVISED**

AFTER LANDING

CHALLENGE	RESPONSE
XPDR / TCAS / RADAR	**STBY**
FLIGHT CONTROLS	**LOCKED**
FLAPS	**0°**
TRIMS	**SET**
LANDING LIGHTS / STROBES	**OFF**
ANTI / DE-ICING	**OFF**
ENG START ROTARY	**OFF**
CL 1 (*After at least one minute at idle; taxi in on ENG 2*)	**FTR THEN FUEL SO**

PARKING

CHALLENGE	RESPONSE
PARKING BRAKE	**ON**
TAXI & T/O LIGHTS	**OFF**
CL 2	**FTR**
PROP BRAKE (*ON for hotel mode*)	**AS RQD**
BEACON	**OFF**
CHOCKS	**IN PLACE**
SEAT BELTS	**OFF**
FWD CARGO DOOR	**OPEN**

LEAVING THE AIRCRAFT

CHALLENGE	RESPONSE
OXYGEN MAIN SUPPLY	**OFF**
ICE & RAIN PROTECTION	**OFF**
EXT LIGHTS	**OFF**
EMER LIGHTS	**DISARMED**
RADAR	**OFF**
CL 2	**FUEL SO**
FUEL PUMPS 1 + 2	**OFF**
CDLS	**OFF**
BAT	**OFF**

Source: Derived from the ATR 72-600 operator normal checklist (common ATR 42/72 type rating): no tail prop, FLAPS 35 landing. For simulation use only.

The AviatesAir Tracker & ACARS

Setting up the Tracker (ACARS key, SimBrief, Hoppies), what each page is for, and how a flight is recorded and reported from gate to gate.

The **AviatesAir Tracker** is the desktop app that connects to Microsoft Flight Simulator, records your flights and files your PIREPs. It also hosts the EFB.

First-time setup

1. **Sign in** with your **ACARS key**, the 28-character key you receive when you register at *flyaviatesair.uk*. It identifies you on every PIREP and message.
2. **Settings → SimBrief Integration:** enter your SimBrief username or ID so the Tracker can fetch your OFP.
3. **Settings → Hoppies ACARS:** enable company ACARS messages if you want loadsheets and timing messages in the simulator's datalink. Company messages use AviatesAir's own Hoppies connection, so no personal logon code is needed for them.
4. **Settings → EFB Companion:** enable it to use the tablet (see Guide 2).

The pages

PAGE	USE IT FOR
Dashboard	Today at a glance: your position, booking, recent flights and stats.
Flights	Your logbook: every recorded flight with its landing grade.
Routes	The route network: find routes from your position by type, book, or reposition.
Fleet	The AviatesAir fleet and registrations.
Pilot Hub	Your booking, career statistics and landing history.
ACARS	The live flight: connection state, booking, SimBrief OFP, live flight data, and the Hoppies log.
Map	Live map of your flight and other AviatesAir pilots.
Messages	Direct messages with other pilots (friend codes) and company broadcasts.
News / Events / Support	Company news, events to join, and help.

Flying a recorded flight

1. **Book** on the Routes page. The booking gives you the flight number (**AV…**) and your ATC callsign.
2. Open **ACARS**, generate the plan in SimBrief (the Tracker can open it for you), then **fetch the OFP**.
3. Start the simulator at the gate. The Tracker connects automatically and shows **LIVE**.
4. Fly. The Tracker detects each phase (taxi, takeoff, climb, cruise, descent, approach, landing) and records the route, fuel and your landing.
5. After parking and shutting down, the flight **completes** and the **PIREP is submitted** automatically.

> **CAUTION** Keep the Tracker running from gate to gate. If something crashes, restart the Tracker and simulator. Flight recovery resumes the flight, and a PIREP that failed to send is retried at the next start.

After the flight

- The **touchdown report** pops up after landing, and every landing stays available in the EFB **Landing** app.
- A PIREP flagged by the checks in OM-A 6 is **held for review**. Add a short explanation when you're asked.
- **Discord presence** shows your flight on your Discord profile while you fly (if enabled).

Using the AviatesAir EFB

Pairing a tablet, phone or second screen, and what every EFB app does: dashboard, performance, Pilot Brief, map, checklists, landing report, manuals and more.

The EFB is the AviatesAir tablet. It runs on any device on your home network (iPad, Android tablet, phone or a second monitor) and is fed live by the Tracker.

Pairing

1. In the Tracker, open **Settings** → **EFB Companion** and start the EFB server. Tick "Launch the EFB server when the app starts" to keep it on.
2. On your device (same Wi-Fi network), open the address shown, or scan the QR code.
3. Enter the **6-digit pairing code** if asked. The device stays paired.

> NOTE Add the EFB to your tablet's home screen for a full-screen, app-like experience. On the tablet, swipe up on the home bar or press **Esc** to return to the home screen.

The apps

APP	WHAT IT DOES
AviatesAir	The flight dashboard: route and progress, OOOI times against the schedule, next waypoint and ETA, the vertical profile, live data, fuel and descent advisor, weather, current checklists, last landing.
Departure Perf	Takeoff performance: runway data, FLEX/TOGA, V-speeds, trim and flap (company flap restrictions applied), with the FMS takeoff page to copy.
Arrival Perf	Landing performance: runway condition (RWYCC), autobrake, reversers, failures, VAPP and landing distance.
Map	Moving map with your route, weather radar, SIGMETs, METARs, and VATSIM/IVAO traffic and ATC.
Pilot Brief	Your OFP: flight summary, fuel, weather, NOTAMs, loadsheet and the full plan.
Weather	Weather for your departure, arrival and alternate (or any ICAO you search). Shows the live VATSIM or IVAO ATIS with its letter and frequency, warns you when a new ATIS letter comes out, and lists the controllers online. Below that: the decoded METAR with a wind dial over the runways, the crosswind on every runway, the cloud layers, a TAF timeline with your ETA marked and any SIGMETs over the field. If no ATIS is online, one is built from the METAR.
Checklists	The electronic normal checklist for your booked aircraft (Airbus, Boeing or ATR style).
Landing	Your touchdown report: score, FDM events, approach profile, touchdown zone and stabilised-approach gates.
Manuals	This library: Company NOTAMs, OM-A, OM-B, QRH and guides, with search, bookmarks and PDF export.

APP	WHAT IT DOES
Messages	Chat with other AviatesAir pilots, the same messages as the desktop app. The **Crew Room** goes to every pilot; everything else is one to one. Start a conversation from your pilots, from anyone **flying now**, or with a friend code (yours is at the bottom of the list). **Share my flight** drops your callsign, route, level and ETA into a message. A clock next to your message means it is queued and will go out when the desktop app next reaches the server.
ACARS	Datalink on the Hoppie network, under your own Hoppie logon code. Message company dispatch (VAOPS) or any station, request a pre-departure clearance, get a METAR, TAF or ATIS, and log on to a controller's CPDLC to send requests. Answer uplinks with **WILCO**, **UNABLE** or **STANDBY** on the message screen. Messages still reach your in-sim ACARS too. The **Ops log** shows the automatic company messages.
Settings	Theme, light or dark, **interface size** (Auto makes the EFB bigger on a large monitor), wallpaper, and **Units**: one weight setting, KG or LB, used by every app on every device. **Flight mode** turns alerts, sterile cockpit and keep screen on on or off for this device. Also the EFB-only SimBrief import, ending the flight, your datalink status, the devices connected and the pairing code for adding another.
Scratchpad	Your notepad: pages for the CRAFT clearance, ATIS, takeoff and approach briefs, holding, frequencies and taxi route, plus blank, lined, grid and typed pages. Write with a pen, highlighter or text stamps; values the EFB already knows appear as faint hints. **New flight** starts a fresh set of pages.

Flight mode

The EFB follows your flight by itself:

- **Passing 1,000 ft** on the climb it switches to flight mode. Below **1,000 ft** on the way down it switches to approach mode, and after touchdown it shows **Landed** with a link to your landing report.
- The **dock** at the bottom of the home screen changes with the phase: performance and the brief before departure, the map and weather in flight, checklists and arrival performance on the approach, the landing report after landing.
- **Sterile cockpit**: chat messages are held while you taxi, below 10,000 ft and on the approach. **STERILE** shows in the status bar with the number held, and they appear together once you're clear. ACARS and CPDLC always come through straight away.
- New messages and ACARS uplinks show as a banner at the top when you're in another app. Tap it to open the message.
- The screen stays on during a flight. On a tablet this starts after your next tap.

Manuals app tips

- **Company NOTAMs** marked **READ & ACKNOWLEDGE** show a badge on the home screen until you acknowledge them.
- **Search** covers every manual; tap a result to jump straight to the section.
- Documents for **your aircraft** are pinned at the top of the library automatically.
- **Export PDF** prints the document, or a whole manual, to a PDF you can share.

Weather & Performance Know-How

Reading METARs and TAFs, flight categories, runway condition codes, and what really drives takeoff and landing performance.

Reading a METAR

`EGLL 241150Z 24012G22KT 9999 FEW035 BKN080 12/06 Q1014 TEMPO 4000 SHRA`

GROUP	MEANING
`EGLL 241150Z`	London Heathrow, 24th at 11:50 UTC
`24012G22KT`	Wind from 240° at 12 kt, gusting 22 kt
`9999`	Visibility 10 km or more
`FEW035 BKN080`	Few cloud at 3,500 ft, broken at 8,000 ft (the **ceiling** is the lowest BKN or OVC layer)
`12/06`	Temperature 12 °C, dew point 6 °C
`Q1014`	QNH 1014 hPa (`A2992` = 29.92 inHg)
`TEMPO 4000 SHRA`	Temporarily 4,000 m in rain showers

Flight categories

CATEGORY	CEILING	VISIBILITY
VFR	above 3,000 ft	more than 5 SM (8 km)
MVFR	1,000–3,000 ft	3–5 SM
IFR	500–999 ft	1–3 SM
LIFR	below 500 ft	less than 1 SM

The EFB colours METARs by these categories, and highlights gusts, low ceilings and significant weather.

Reading a TAF

TAFs forecast the weather for 24–30 hours. `BECMG` means a gradual change, `TEMPO` temporary fluctuations (under an hour at a time), `PROB30/40` a 30 or 40 % probability. For planning, the **worst** condition in the arrival window counts (see OM-A 3).

What drives takeoff performance

FACTOR	EFFECT
Weight	Heavier: higher V-speeds and a longer runway needed.

FACTOR	EFFECT
Density altitude (elevation + temperature)	Hot and high: less thrust and lift, a longer takeoff and a lower FLEX temperature.
Wind	Headwind shortens the takeoff, tailwind lengthens it considerably.
Runway condition	Wet or contaminated: longer accelerate-stop distance, lower V1.
Flap	More flap: lower speeds and a shorter run, but worse climb gradient.
Slope	Uphill lengthens the takeoff run.

FLEX / assumed temperature: the aircraft uses less than full thrust, as if it were hotter than it is, when the runway allows. That saves engine wear. EFB Departure Perf finds the highest FLEX temperature that still meets the runway requirement.

What drives landing performance

The landing distance grows with **weight**, **approach speed** (which is why less flap means a longer landing; see CN-003), **tailwind**, **density altitude**, and above all **runway condition**. Braking on a POOR (RWYCC 1) runway can more than double the stopping distance of a dry one. EFB Arrival Perf shows the landing distance for every autobrake setting and warns when the margin is thin. Pick a setting with a comfortable margin, not the one that just fits.