# Workstation Cradle



**User Guide** 

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. © 2021 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

Information in this document is subject to change without notice. The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used or copied only in accordance with the terms of those agreements.

For further information regarding legal and proprietary statements, please go to:

SOFTWARE: <u>zebra.com/linkoslegal</u> COPYRIGHTS: <u>zebra.com/copyright</u> WARRANTY: <u>zebra.com/warranty</u>

END USER LICENSE AGREEMENT: zebra.com/eula

## **Terms of Use**

## **Proprietary Statement**

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

## **Product Improvements**

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

## **Liability Disclaimer**

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

## **Limitation of Liability**

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

## **About This Document**

## Introduction

This guide provides information about developing applications for Zebra Workstation Connect.



**IMPORTANT:** If you have a problem with your equipment, contact Zebra Global Customer Support for your region. Contact information is available at: <u>zebra.com/support</u>.

## **Configurations**

This guide covers the following configurations:

Configuration	Description	Device Compatibility
CRD-TC5X-1SWS-01	TC5X Workstation Docking Cradle Kit with Std Cup, HDMI, Ethernet and multiple USB Ports. Included in kit:	All TC5X Mobile Computers including the TC51, TC56, TC52 and TC57.
	Cradle (CRD-TC5X-1SWS1-01),	
	Power Supply (i.e. PWRBGA12V50W0WW)	
	• DC Cable (i.e. CBL-DC-388A1-01).	
	Country specific AC line cord sold separately.	

## **Service Information**

If you have a problem with your equipment, contact Zebra Global Customer Support for your region. Contact information is available at <u>zebra.com/support</u>.

When contacting support, please have the following information available:

- · Serial number of the unit
- Model number or product name
- Software/firmware type or version number

## **About This Document**

Zebra responds to calls by email, telephone or fax within the time limits set forth in support agreements.

If your problem cannot be solved by Zebra Customer Support, you may need to return your equipment for servicing and will be given specific directions. Zebra is not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty.


If you purchased your Zebra business product from a Zebra business partner, contact that business partner for support.

This section describes the default features of Zebra Workstation Connect, these interactions can be performed by the user on the external monitor while connected to peripherals including keyboard, mouse, and headsets. These features are also available via mobile device.

 When the mobile device is docked in the Zebra Workstation Cradle, the following screen appears on an external monitor. Users are able to see the taskbar at the bottom of the screen with the All Applications button at the left side.




2. The All Applications button allows the user to access all of the applications that are available on the device. Once an application icon is clicked (a single mouse click or a single tap if using a touch monitor), the application launches on the desktop and the application icon indicates that the application is running. Users are required to click on the All Applications button to dismiss the All Applications panel if it is currently being displayed.



All Applications Icon

3. All running applications that are open on the external monitor or on the mobile device are displayed on the taskbar. Users can switch between open applications by clicking on one of the taskbar icons. When an icon is clicked, the corresponding application is presented in the foreground. A subsequent click restores or minimizes the application if it is not currently minimized.



**4.** All desktop and mobile applications shown on the taskbar are separated by a vertical line. Desktop applications are shown on left side of the line and mobile applications display on the right side with a blue mobile badge on the application icon as shown below.



Blue Mobile Badge

- 5. A right click using the mouse (or a tap and hold on mobile computers) on the taskbar icons brings up a contextual menu for the corresponding application icon. Using the contextual menu functions, close the application represented by the icon or move an application between the mobile device screen and desktop without losing the state of the application.
- 6. The Back and Home navigation buttons are available on the left side of the taskbar. The Home button allows users to bring the desktop home screen to the foreground and the Back button allows users to go back to the previously running application. When using Chrome, the Back button also brings the previous page accessed by the user.




Back Home


7. When an application is launched, it is displayed on an independent and resizable window. The top icons on the right side of the window allow the user to see the application in full screen or close the application.

By selecting any of the side or bottom edges of the application window, the user is able to resize the window.


If an application is viewed on Chrome, the three dots on the top right side of the browser window open a menu that presents the **Desktop Site** option. This option presents the webpage or web-based application with a Desktop UI.



- **8.** By right clicking on the **Desktop Home Screen** (or by tap and if using a mobile computer), users are presented with a contextual menu that allows them to:
  - Add an app shortcut to the Home Screen for guick access
  - Sort shortcuts (by alphabetical order or by added date)
  - Set / Modify




To add a shortcut the desktop, select Add a Shortcut from the menu and select the applications to be added to the desktop. Once a specific application is selected, it creates the shortcut on the Home Screen.



**10.** By default, the following app shortcuts are presented on the Desktop Home Screen:


- · Google Chrome
- Device Settings
- Google Playstore
- · Device Files




11. To change the Home Screen wallpaper, select the option from the menu and navigate to the image gallery or any image folder available in the device to select the Wallpaper for the Desktop Home Screen. This action does not have any impact on mobile device Home Screen.



12. When docking a device into the Workstation Cradle, the default behavior is that an application running on the mobile device remains running on the mobile device and presents a corresponding taskbar icon. In the section below, all of the applications presented on the taskbar were previously running on the device prior to docking. This behavior can be overridden via configuration. For more information, see Administrator Configurable Features on page 14.



13. The default behavior of the Zebra Workstation Connect applications while undocking the device from the cradle dictates than an application running on the desktop transitions to the mobile device and runs in the background. The figure below provides an example of how applications transition to the device and run in the background when the device is undocked.



**14.** The notification panel is presented on the far right corner of the taskbar and displays when the user clicks the icon. The notification panel is dismissed when the user clicks on the icon again. A red notification badge displays if there are any unread notifications.




**15.** When selected, this panel displays all of the unread notifications for both mobile and desktop applications. Read specific notifications by clicking on the notification or click the dismiss button to dismiss it.




**16.** Status icons are displayed on the right section of the taskbar and displays additional information when hovering over the icons.

The default icons are:

- Battery
- VPN
- Connectivity
- Bluetooth displays its connection state and number of connected devices.



- 17. The Status Icons on the taskbar show additional information when the mouse is hovering over the icons.
  - Battery Icon
  - VPN Icon
  - Connectivity Icons (Wi-Fi, Cellular, Ethernet)
  - Bluetooth Icon



- **18.** The volume control panel is located on the left side of the status area. When the icon is clicked, the following options are available:
  - Control the sliders for adjusting the current volume of all available audio streams.
  - Present the currently selected audio output path for media streams.
  - Present all of the available alternative audio output paths for media streams.
  - Select a new audio output path for a media steam to replace the current path.
  - See more accesses Sound and Vibration in Settings.

• Done dismisses the volume control menu.

