Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 1: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

TELEMETRY SPECTRUM ANALYSIS & FIELD DISPATCH SIGN-OFF RECORD

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 2: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

TELEMETRY SPECTRUM ANALYSIS & FIELD DISPATCH SIGN-OFF RECORD

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress...

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 3: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 4: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 5: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 6: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress...

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 7: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

TELEMETRY SPECTRUM ANALYSIS & FIELD DISPATCH SIGN-OFF RECORD

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 8: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

TELEMETRY SPECTRUM ANALYSIS & FIELD DISPATCH SIGN-OFF RECORD

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 9: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 10: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 11: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.

Phase 1: Power Indicator

Solid Green: System OK.

Solid Red: Adapter failure.

OFF: Verify power outlet.

Phase 2: DSL Indicator

Solid Green: Copper synced.

Blinking: Sync in progress..

OFF: Check line cable/splitter.

Phase 3: Internet Indicator

Blinking Green: Traffic OK.

Solid Red: Auth error.

OFF: No WAN connection.

Phase 4: Optical LOS Indicator

OFF: Optical signal normal.

Blinking Red: Fiber cut

or signal < -27 dBm.

Phase 5: Wi-Fi Indicator

Solid Green: Wireless active.

OFF: WLAN disabled via

physical button.

Phase 6: Factory Reset Protocol

Hold pin in reset hole

for 10 seconds to restore

default 192.168.1.1 settings.

SECTION 12: HARDWARE DIAGNOSTICS FOR DN8245V, DG8045 & ZXHN H168N ROUTERS

1. VDSL LINE QUALITY VERIFICATION (192.168.1.1):

- Login using username 'admin' and printed serial password on router rear sticker.

- Check Signal-to-Noise Ratio (SNR Margin): Must remain above 8 dB for stability.

- Check Line Attenuation: Values below 20 dB indicate excellent copper distance.

2. RED INTERNET LED RESOLUTION:

- Verify PPPoE username ending in '@tedata.net.eg' and customer password.

- Trigger automated TR-069 WAN reconfiguration push from CSR Technical Support portal.

3. WI-FI FREQUENCY INTERFERENCE MANAGEMENT:

- Configure 2.4 GHz channels manually to 1, 6, or 11 to avoid adjacent channel bleed.

- Split 5 GHz and 2.4 GHz SSIDs to dedicate high bandwidth to streaming and gaming devices.

4. STORE HARDWARE REPLACEMENT CRITERIA:

- Faulty routers within active warranty are swapped instantly at any official WE Branch free of charge.