

Candelabra Lighting — Control Key

White keys pick the preset. Octave picks the colour. Black keys unused. Master is CC 14 × note velocity × the palette's own ceiling. Notes are gated: held is active, released falls to blackout.

Presets — white keys, any octave

Note	P	Preset	CC	Serial	Controls
C	0	blackout	14	M	master fader
D	1	steady	2	S	speed
E	2	flicker	3	D	depth
F	3	gust	4	W	warmth
G	4	ember	5	T	crossfade time
A	5	pulse	12	H	hue OFFSET — 64 = no change
B	6	strobe	13	C	sat OFFSET — 64 = no change
			15	B	white boost — 0 flame, 127 max

Colour palettes — octave

Octave	Colour	hue	sat	warmth	notes
C -2	deep ember	20	234	255	capped at M27
C-1	candle flame — HOME	0	0	0	
C0	red	255	255	0	
C1	orange	17	255	0	
C2	yellow	34	255	0	
C3	green	73	242	0	
C4	cyan	125	236	0	
C5	blue	160	255	0	
C6	violet	186	252	0	
C7	magenta	223	255	0	
C8	full white	0	0	0	boost 255

MIDI channel — what it addresses

Ch	Target	Serial	Value	Colour
1	both fixtures	F0	0	red
2	antler A	F1	43	yellow
3	antler B	F2	85	green
4 / 5 / 6	antler A, candles 1 / 2 / 3	F11 F12 F13	128	cyan
7 / 8 / 9	antler B, candles 1 / 2 / 3	F21 F22 F23	170	blue
			213	magenta

Hue wheel

Hue and saturation are offsets, not absolutes. CC 12 at 64 leaves the note's palette colour alone; below and above push either way round the wheel, half a turn at each extreme. CC 13 does the same for saturation, clamped rather than wrapped. Set an envelope's resting value to 64, not 0 — 0 means "shift half a wheel", not "no change". Offsets persist across notes like any CC.

White boost. Nothing in the normal colour path lights all four dies at once — RGB is held down when saturation is low, and the white die switches off as saturation rises. CC 15 blends toward all four at full. C8 is the same thing on a key.

Serial, into the transmitter's monitor at 115200, newline: F<fix> P<preset> M<master> S<speed> D<depth> W<warmth> T<fade> H<hue> C<sat> B<boost>. Omitted fields keep their value. Default flicker: F0 P2 M255 S170 D220 W0 C0 T0

CC numbers to avoid: 0 and 32 bank select · 1 mod wheel, DAWs reset it · 6 and 38 data entry · 7 volume · 10 and 11 pan and expression · 96-101 RPN/NRPN · 120-127 channel mode. Safe: 14, 15, 20-31.