

4.2 Auto operation start



(1) Turn on the [MAIN SWITCH].




- (2) Turn on the (a).
- (3) Turn on the (b).
- (4) Turn on the (c).
- (5) Turn on the (d).
- * Turn on the UV power when UV function is in use.



(6) MAIN SCREEN is displayed, and buzzer sounds. Press [BUZZER STOP] key to stop the sound.

MAIN SCREEN



(7) Press [MAN.] key on the MAIN SCREEN to display 1st page of the setting screen.

1st page of the setting screen

	J		
WAFER Size	CASS. Mode	T/DATA	START
VIZE	INDL		STOP
WAFER Type	LAMP Time	TOTAL Timer	AUTO
ITPE	1116	TIPEK	MAN.
UV, N2 Select	T3 ALI. SELECT		RESET
OLLLOT	OLLLOT		ESC
		FWD	BUZZER
		PAGE	STOP

Pressing [FWD PAGE] / [REV PAGE] switches the display of "1st page of the setting screen" and "2nd page of the setting screen".

2nd page of the setting screen

	2 page of the setting screen						
	ALIGNER	3-TIMES	APPLY	START			
	HETUNER	APPLY	DOWN	ST0P			
	T/1, 2 SELECT	T/3 SELECT	REPEEL	AUTO			
	SELEGI	SELECT.	SELECT	MAN.			
	PAD UP Timer	IRRA., N2 Timer		RESET			
l				ESC			
	REV Page			BUZZER STOP			
•				3101			

Confirm each setting on the screen shown on the next page or later.


To enter each screen, press each key on the "1st/2nd page of the setting screen".


(8) Confirm whether the setting conditions for wafers to process are correct with each screen shown below. Select appropriate items if the setting condition is inappropriate. Confirm the settings on the screen framed by broken lines to the maintenance engineers.

- [ESC] key: Pressing the key displays "1st / 2nd of the setting screen".

- [AUTO] key: Pressing the key displays MAIN SCREEN.








(9) Press [INIT. RESET] key to enable the machine auto operation. The each unit moves to auto operation starting position (Initial reset).



(10) After the initial reset has completed, place the cassettes on the cassette table. Close the front cover.



(11) Press [START] key to start auto operation.