

CSI API ETABS v1

cAreaObj Interface

Namespace: [ETABSV1](#)**Assembly:** ETABSV1 (in ETABSV1.dll) Version: 1.0.0.0 (1.24.0.0)

▲Syntax

C# **VB** **C++** **F#**[Copy](#)

```
Public Interface cAreaObj  
  
Dim instance As cAreaObj
```

The [cAreaObj](#) type exposes the following members.

▲Methods

	Name	Description
	AddByCoord	Adds a new area object, defining points at the specified coordinates.
	AddByPoint	Adds a new area object whose defining points are specified by name.
	ChangeName	
	Count	
	Delete	Deletes area objects.
	DeleteLoadTemperature	
	DeleteLoadUniform	Deletes the uniform load assignments to the specified area objects for the specified load pattern.
	DeleteLoadUniformToFrame	
	DeleteLoadWindPressure	
	DeleteMass	

	DeleteModifiers	
	DeleteSpring	
	GetAllAreas	Retrieves select data for all area objects in the model
	GetCurvedEdges	Retrieves curve data for all edges of an area object
	GetDesignOrientation	Retrieves the design orientation of an area object.
	GetDiaphragm	Retrieves the diaphragm assignment to the specified area object
	GetEdgeConstraint	
	GetElm	
	GetGroupAssign	Retrieves the groups to which an area object is assigned.
	GetGUID	
	GetLabelFromName	Retrieves the label and story for a unique area object name
	GetLabelNameList	Retrieves the names and labels of all defined area objects.
	GetLoadTemperature	Retrieves the temperature load assignments to area objects.
	GetLoadUniform	Retrieves the uniform load assignments to area objects.
	GetLoadUniformToFrame	Retrieves the uniform to frame load assignments to area objects.
	GetLoadWindPressure	Retrieves the wind pressure load assignments to area objects.
	GetLocalAxes	
	GetMass	
	GetMaterialOverwrite	

	GetModifiers	
	GetNameFromLabel	Retrieves the unique name of an area object, given the label and story level
	GetNameList	Retrieves the names of all defined area objects.
	GetNameListOnStory	Retrieves the names of the defined area objects on a given story.
	GetOffsets3	
	GetOpening	Retrieves whether the specified area object is an opening.
	GetPier	Retrieves the pier label assignments of an area object
	GetPoints	Retrieves the names of the point objects that define an area object.
	GetProperty	Retrieves the area property assigned to an area object.
	GetRebarDataPier	Retrieves rebar data for an area pier object
	GetRebarDataSpandrel	Retrieves rebar data for an area spandrel object
	GetSelected	
	GetSelectedEdge	
	GetSpandrel	Retrieves the Spandrel label assignments of an area object
	GetSpringAssignment	Retrieves the named area spring property assignment for an area object
	GetTransformationMatrix	
	SetDiaphragm	Assigns a diaphragm to a specified area object
	SetEdgeConstraint	Makes generated edge constraint assignments to area objects.

	SetGroupAssign	
	SetGUID	
	SetLoadTemperature	
	SetLoadUniform	Assigns uniform loads to area objects.
	SetLoadUniformToFrame	
	SetLoadWindPressure	
	SetLocalAxes	Assigns a local axis angle to area objects.
	SetMass	
	SetMaterialOverwrite	
	SetModifiers	
	SetOpening	Designates an area object(s) as an opening.
	SetPier	Sets the pier label assignment of one or more area objects
	SetProperty	Assigns an area property to area objects.
	SetSelected	
	SetSelectedEdge	
	SetSpandrel	Sets the Spandrel label assignment of one or more area objects
	SetSpringAssignment	Assigns an existing named area spring property to area objects

[Top](#)

See Also

Reference

[ETABSv1 Namespace](#)

ETABS®, SAP2000® and CSiBridge® are registered trademarks of Computers and Structures, Inc.
 Copyright © Computers and Structures, Inc. 2022. All rights reserved.

Send comments on this topic to support@csiamerica.com

