

CSI API ETABS v1

cFrameObj Interface

Namespace: [ETABSV1](#)**Assembly:** ETABSV1 (in ETABSV1.dll) Version: 1.0.0.0 (1.24.0.0)

▲Syntax

C# **VB** **C++** **F#**[Copy](#)

```
Public Interface cFrameObj  
  
Dim instance As cFrameObj
```

The [cFrameObj](#) type exposes the following members.

▲Methods

	Name	Description
	AddByCoord	Adds a new frame object whose end points are at the specified coordinates.
	AddByPoint	Adds a new frame object whose end points are specified by name.
	ChangeName	
	Count	
	Delete	Deletes frame objects.
	DeleteLateralBracing	
	DeleteLoadDistributed	Deletes the distributed load assignments to the specified frame objects for the specified load pattern.
	DeleteLoadPoint	Deletes the point load assignments to the specified frame objects for the specified load pattern.
	DeleteLoadTemperature	

	DeleteMass	
	DeleteModifiers	
	DeleteSpring	
	GetAllFrames	Retrieves select data for all frame objects in the model
	GetColumnSpliceOverwrite	Retrieves the frame object column splice overwrite assignment.
	GetCurved_2	Retrieves frame object curve data
	GetDesignOrientation	Retrieves the design orientation for a given frame object
	GetDesignProcedure	Retrieves the design procedure for a frame object
	GetElm	
	GetEndLengthOffset	Retrieves the frame object end offsets along the 1-axis of the object.
	GetGroupAssign	Retrieves the groups to which a frame object is assigned.
	GetGUID	Retrieves the GUID for the specified frame object.
	GetHingeAssigns	DEPRECATED Retrieves frame object hinge assignments.
	GetHingeAssigns_1	Retrieves frame object hinge assignments. The assignments include the hinge property, type, and location
	GetInsertionPoint	Retrieves frame object insertion point assignments. The assignments include the cardinal point and end joint offsets.
	GetLabelFromName	Retrieves the label and story for a unique frame object name
	GetLabelNameList	Retrieves the names and labels of all defined frame objects.

	GetLateralBracing	
	GetLoadDistributed	Retrieves the distributed load assignments to frame objects.
	GetLoadPoint	Retrieves the point load assignments to frame objects.
	GetLoadTemperature	Retrieves the temperature load assignments to frame objects.
	GetLocalAxes	Retrieves the frame local axis angle assignment for frame objects.
	GetMass	
	GetMaterialOverwrite	
	GetModifiers	Retrieves the frame modifier assignment for frame objects. The default value for all modifiers is one.
	GetNameFromLabel	Retrieves the unique name of a frame object, given the label and story level
	GetNameList	Retrieves the names of all defined frame objects.
	GetNameListOnStory	Retrieves the names of the defined frame objects on a given story.
	GetOutputStations	Retrieves frame object output station data
	GetPier	Retrieves the pier label assignments of a frame object
	GetPoints	Retrieves the names of the point objects at each end of a specified frame object.
	GetReleases	
	GetSection	Retrieves the frame section property assigned to a frame object.
	GetSectionNonPrismatic	
	GetSelected	

	GetSpandrel	Retrieves the Spandrel label assignments of a frame object
	GetSpringAssignment	Retrieves the named line spring property assignment for a frame object
	GetSupports	Retrieves support data for a given frame beam object
	GetTCLimits	
	GetTransformationMatrix	
	GetTypeOAPI	Retrieves the type of frame object (straight or curved)
	SetColumnSpliceOverwrite	Sets the frame object column splice overwrite assignment.
	SetDesignProcedure	Sets the design procedure for frame objects.
	SetEndLengthOffset	Assigns frame object end offsets along the 1-axis of the object.
	SetGroupAssign	Adds or removes frame objects from a specified group.
	SetGUID	Sets the GUID for the specified frame object. If the GUID is passed in as a blank string, the program automatically creates a GUID for the object.
	SetInsertionPoint	Assigns frame object insertion point data. The assignments include the cardinal point and end joint offsets.
	SetLateralBracing	
	SetLoadDistributed	Assigns distributed loads to frame objects.
	SetLoadPoint	Assigns point loads to frame objects.
	SetLoadTemperature	
	SetLocalAxes	Assigns a local axis angle to frame objects.
	SetMass	

	SetMaterialOverwrite	
	SetModifiers	Sets the frame modifier assignment for frame objects. The default value for all modifiers is one
	SetOutputStations	Assigns frame object output station data.
	SetPier	Sets the pier label assignment of one or more frame objects
	SetReleases	Makes end release and partial fixity assignments to frame objects.
	SetSection	Assigns a frame section property to a frame object.
	SetSelected	Sets the selected status for a frame object.
	SetSpandrel	Sets the Spandrel label assignment of one or more frame objects
	SetSpringAssignment	Assigns an existing named line spring property to frame objects
	SetTCLimits	Makes tension/compression force limit assignments to frame objects.

[Top](#)

See Also

Reference

[ETABSv1 Namespace](#)

ETABS®, SAP2000® and CSiBridge® are registered trademarks of Computers and Structures, Inc. Copyright © Computers and Structures, Inc. 2022. All rights reserved.

Send comments on this topic to support@csiamerica.com