

MATLAB R2026a

HOME PLOTS APPS EDITOR PUBLISH VIEW Search (Ctrl+Shift+Space)

Save Section Section with Title Bold Italic Monospaced Hyperlink Inline LaTeX Bulleted List Numbered List Image Preformatted Text Code Display LaTeX Publish Publish as HTML Publish as PDF

FILE INSERT SECTION INSERT INLINE MARKUP INSERT BLOCK MARKUP PUBLISH

C: > Users > aabdu > OneDrive > Desktop > IT WORKBOOK > 10

Files

- 1.m
- 1.pdf
- 1a.png
- 1b.png
- 1c.png
- 2.m
- 2.pdf
- EX#1.m.txt
- EX#2.m.txt

Workspace

Name	Value	Size	Class
ans	2	1×1	double
load_co...	'high'	1×4	char
phi	0.8000	1×1	double
Tamb	30	1×1	double
Top	156	1×1	double
Tref	20	1×1	double
type	'type-a'	1×6	char

```
26 if strcmp(type,'type-a')
27     Top = ((220 - Tamb) - Tref)*phi + Tref;
28 elseif strcmp(type,'type-b')
29     Top = ((206 - 0.88*Tamb) - Tref)*phi + Tref;
30 else
31     disp('Wrong chamber type entered');
32     return;
33 end
34
35 % displaying result
36 fprintf('Operating temperature = %.2f °C\n', Top);
```

Command Window

```
Enter type of mixing chamber (Type-A or Type-B): Type-A
Enter ambient temperature (°C): 30
Enter reference temperature (°C): 20
Enter load condition (low, medium, or high): high
Operating temperature = 156.00 °C

ans =

    2

>>
```

Editor: 100% UTF-8 CRLF Script Ln 36 Col 51