

Cisco Router Boot Sequence Tutorial

December 16th, 2011 Go to comments

In this article we will learn about the main components of a Cisco router and how the boot process takes place.

Types of memory

Generally Cisco routers (and switches) contain four types of memory:

Read-Only Memory (ROM): ROM stores the router's bootstrap startup program, operating system software, and power-on diagnostic test programs (POST).

Flash Memory: Generally referred to simply as "flash", the IOS images are held here. Flash is erasable and reprogrammable ROM. Flash memory content is retained by the router on reload.

Random-Access Memory (RAM): Stores operational information such as routing tables and the running configuration file. RAM contents are lost when the router is powered down or reloaded.

Non-volatile RAM (NVRAM): NVRAM holds the router's startup configuration file. NVRAM contents are not lost when the router is powered down or reloaded.


Some comparisons to help you remember easier:

- + RAM is a volatile memory so contents are lost on reload, where NVRAM and Flash contents are not.
- + NVRAM holds the startup configuration file, where RAM holds the running configuration file.
- + ROM contains a bootstrap program called ROM Monitor (or ROMmon). When a router is powered on, the bootstrap runs a hardware diagnostic called POST (Power-On Self Test).

Router boot process

The following details the router boot process:

- 1. The router is powered on.
- 2. The router first runs Power-On Self Test (POST)
- 3. The bootstrap checks the Configuration Register value to specify where to load the IOS. By default (the default value of Configuration Register is 2102, in hexadecimal), the router first looks for "boot system" commands in startup-config file. If it finds these commands, it will run boot system commands in order they appear in startup-config to locate the IOS. If not, the IOS image is loaded from Flash. If the IOS is not found in Flash, the bootstrap can try to load the IOS from TFTP server or from ROM (mini-IOS).
- 4. After the IOS is found, it is loaded into RAM.
- 5. The IOS attempts to load the configuration file (startup-config) from NVRAM to RAM. If the startup-config is not found in NVRAM, the IOS attempts to load a configuration file from TFTP. If no TFTP server responds, the router enters Setup Mode (Initial Configuration Mode).



And this is the process we can see on our screen when the router is turned on:

System Bootstrap, Version 12.1(3r)T2, RELEASE SOFTWARE (fc1)

Copyright (c) 2000 by cisco Systems, Inc.

cisco 2811 (MPC860) processor (revision 0x200) with 60416K/5120K bytes of memory

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

Load IOS & start running router

cisco Systems, Inc. 170 West Tasman Drive San Jose, California 95134-1706

Cisco IOS Software, 2800 Software (C2800NM-ADVIPSERVICESK9-M), Version 12.4(15)T 1, RELEASE SOFTWARE (fc2)

Technical Support: http://www.cisco.com/techsupport Copyright (c) 1986-2007 by Cisco Systems, Inc. Compiled Wed 18-Jul-07 06:21 by pt_rel_team Image text-base: 0x400A925C, data-base: 0x4372CE20

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at: http://www.cisco.com/wwl/export/crypto/tool/stqrg.html

If you require further assistance please contact us by sending email to export@cisco.com.

cisco 2811 (MPC860) processor (revision 0x200) with 60416K/5120K bytes of memory

Processor board ID JAD05190MTZ (4292891495) M860 processor: part number 0, mask 49 2 FastEthernet/IEEE 802.3 interface(s)

239K bytes of non-volatile configuration memory.

62720K bytes of ATA CompactFlash (Read/Write)

Cisco IOS Software, 2800 Software (C2800NM-ADVIPSERVICESK9-M), Version 12.4(15)T 1. RELEASE SOFTWARE (fc2)

Technical Support: http://www.cisco.com/techsupport Copyright (c) 1986-2007 by Cisco Systems, Inc. Compiled Wed 18-Jul-07 06:21 by pt_rel_team

--- System Configuration Dialog ---

Continue with configuration dialog? [yes/no]:

Setup mode (no configuration file found)

In short, when powered on the router needs to do:

- 1. Run **POST** to check hardware
- 2. Search for a <u>valid IOS</u> (the Operating System of the router)
- 3. Search for a <u>configuration file</u> (all the configurations applied to this router)

Specify how much RAM, NVRAM and Flash of a router

Also, from the information shown above, we can learn some information about router's model, RAM, Flash, NVRAM memories as shown below:

cisco 2811 (MPC860) processor (revision 0x200) with 60416K/5120K bytes of memory
Router model RAM
Processor board ID JAD05190MTZ (4292891495)
M860 processor: part number 0, mask 49
2 FastEthernet/IEEE 802.3 interface(s) NVRAM
239K bytes of non-volatile configuration memory.
62720K bytes of ATA CompactFlash (Read/Write)
Cisco IOS Software, 2800 Software (C2800NM-ADVIPSERVICESK9-M), Version 12.4(15)T
1, RELEASE SOFTWARE (fc2) IOS version
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2007 by Cisco Systems, Inc.
Compiled Wed 18-Jul-07 06:21 by pt_rel_team

Note: The "show version" command also gives us this information.

All the above information is straight-forwarding except the information of RAM. In some series of routers, the RAM information is displayed by 2 parameters (in this case 60416K/5120K). The first parameter indicates how much RAM is in the router while the second parameter (5120K) indicates how much DRAM is being used for Packet memory. Packet memory is used for buffering packets.

So, from the output above we can learn:

Amount of RAM: 60416 + 5120 = 65536KB / 1024 = 64MB

Amount of NVRAM: 239KB Amount of Flash: 62720KB

Comments (0) Comments

1. No comments yet.

Add a Comment		
	Name	
		11

Submit Comment

Subscribe to comments feed

<u>Cisco Command Line Interface CLI CCNA – Basic Questions</u>

Premium Member Zone

Welcome **Gurjeet singh!**

- Welcome Premium Member
- CCNA New Questions Part 5
- CCNA New Questions Part 6
- CCNA New Questions Part 7

- CCNA New Questions Part 8
- CCNA New Questions Part 9
- Composite Quizzes
- <u>Logout</u>

CCNA 200-301

- Basic Questions
- <u>Topology Architecture Questions</u>
- Cloud & Virtualization Questions
- CDP & LLDP Questions
- Switch Questions
- VLAN & Trunking Questions
- VLAN & Trunking Questions 2
- STP & VTP Questions
- EtherChannel Questions
- TCP & UDP Questions
- IP Address & Subnetting Questions
- IP Routing Questions
- IP Routing Questions 2
- OSPF Questions
- OSPF Questions 2
- EIGRP Questions
- NAT Questions
- NTP Questions
- Syslog Questions
- HSRP Questions
- Access-list Questions
- AAA Questions
- Security Questions
- Security Questions 2
- DAI Questions
- IPv6 Questions
- DNS Questions
- QoS Questions
- Port Security Questions
- Wireless Questions
- Wireless Questions 2
- SDN Questions
- DNA Center Questions
- <u>Drag Drop Questions</u>
- <u>Drag Drop Questions 2</u>
- <u>Drag Drop Questions 3</u>
- VPN Questions
- DHCP Questions
- Automation Questions
- Miscellaneous Questions
- CCNA FAQs & Tips
- Share your new CCNA Experience

CCNA Self-Study

- Practice CCNA GNS3 Labs
- CCNA Knowledge
- CCNA Lab Challenges

- Puppet Tutorial
- Chef Tutorial
- Ansible Tutorial
- JSON Tutorial
- Layer 2 Threats and Security Features
- AAA TACACS+ and RADIUS Tutorial
- STP Root Port Election Tutorial
- GRE Tunnel Tutorial
- Basic MPLS Tutorial
- TCP and UDP Tutorial
- Border Gateway Protocol BGP Tutorial
- Point to Point Protocol (PPP) Tutorial
- WAN Tutorial
- DHCP Tutorial
- Simple Network Management Protocol SNMP Tutorial
- Syslog Tutorial
- Gateway Load Balancing Protocol GLBP Tutorial
- EtherChannel Tutorial
- Hot Standby Router Protocol HSRP Tutorial
- InterVLAN Routing Tutorial
- Cisco Command Line Interface CLI
- Cisco Router Boot Sequence Tutorial
- OSI Model Tutorial
- <u>Subnetting Tutorial Subnetting Made Easy</u>
- Frame Relay Tutorial
- Wireless Tutorial
- Virtual Local Area Network VLAN Tutorial
- VLAN Trunking Protocol VTP Tutorial
- IPv6 Tutorial
- Rapid Spanning Tree Protocol RSTP Tutorial
- Spanning Tree Protocol STP Tutorial
- Network Address Translation NAT Tutorial
- Access List Tutorial
- RIP Tutorial
- EIGRP Tutorial
- OSPF Tutorial

Network Resources

- Free Router Simulators
 - o CCNA Website
 - ENCOR Website
 - ENSDWI Website
 - ENARSI Website
 - DevNet Website
 - CCIE R&S Website
 - Security Website
 - Wireless Website
 - o <u>Design Website</u>
 - o Data Center Website
 - Service Provider Website
 - Collaboration Website



Copyright © 2021 CCNA Training Site Privacy Policy. Valid XHTML 1.1 and CSS 3.H