

Day -3 Troubleshooting Theory

Task -1 : issue on using USB keyboard and mouse

1. The mouse or keyboard stops working completely

- **Why it happens: The connection is loose, or the port lost connection.**
- **Simple Solution: Unplug the cable or USB receiver, wait 5 seconds, and plug it back into a different USB port on your laptop.**

2. The pointer jumps around or the mouse doesn't track smoothly

- **Why it happens: The optical sensor at the bottom of the mouse is blocked by dust, or the surface underneath it is shiny/reflective (like glass).**
- **Simple Solution: Flip the mouse over and gently wipe the sensor lens with a clean cloth, and always use a flat, non-reflective mousepad instead of a glossy table.**

3. Keys type double letters or the mouse double-clicks by itself

- **Why it happens:** Dust and dirt are stuck under the buttons, or the software settings are too sensitive.
- **Simple Solution:** Blow out the dirt using compressed air. If that doesn't work, go to your laptop's Settings > Accessibility (or Keyboard settings) and slow down the key repeat speed.

4. Wireless mouse or keyboard keeps disconnecting or lagging

- **Why it happens:** The tiny USB receiver (dongle) is getting interference from Wi-Fi routers or other metal devices.
- **Simple Solution:** Move the USB receiver closer to your mouse/keyboard (use a USB extension cable if needed) and make sure the batteries in your mouse or keyboard are fully charged.

5. Media keys or shortcut keys (like volume, brightness, or mute) aren't working

- **Why it happens:** The Function Lock (Fn Lock) key is turned on, or the special media hotkeys are disabled on your laptop keyboard.
- **Simple Solution:** Look for a key with a small lock icon on it (usually the Fn key or Esc key)

and press Fn + Esc (or Fn + Lock) together to unlock your shortcut keys.

Task -2 : Troubleshooting in Bluetooth and Phone

Step 1: Check Power & Battery Indicators

- **Action: Check the LED status light on your headphones or charging case.**
- **What to check: Look for a solid light or color indicating battery level (e.g., green or blue).**
- **Fix: If the light is blinking red, amber, or completely dark, your headphones are out of battery. Plug them into power for 10–15 minutes before trying again.**

Step 2: Toggle Bluetooth On Your Phone

- **Action: Refresh your phone's wireless connection.**
- **What to check: Swipe down (Android) or swipe down from the top-right (iPhone) to open your Quick Settings / Control Center.**

- **Fix:** Tap the Bluetooth icon to turn it OFF. Wait about 5 seconds, then tap it again to turn it ON.

Step 3: Put Headphones into "Pairing Mode"

- **Action:** Make sure your headphones are actively looking for your phone.
- **What to check:** If your headphones are already connected to another nearby device (like a laptop or tablet), they won't connect to your phone. Disconnect them from other devices first.
- **Fix:** Press and hold the power/Bluetooth button on the headphones for 3 to 5 seconds until the LED light rapidly flashes (usually blue or white). This signal shows they are in discovery mode.

Step 4: "Forget" and Re-Pair the Device

- **Action:** Remove the saved connection memory on your phone and set it up fresh.
- **What to check:** Go to Settings > Bluetooth on your phone and look under Paired Devices or My Devices.
- **Fix:**

- 1. Tap the gear icon or (i) next to your headphones' name.**
- 2. Select Forget This Device (or Unpair).**
- 3. Look under Available Devices at the bottom, select your headphones, and tap Pair.**

Step 5: Restart Your Phone

- Action: Clear out minor software glitches on your phone.**
- Fix: Power off your phone completely, wait 10 seconds, turn it back on, and try connecting one more time.**

Task -3 Webcam is not detected in zoom meeting

1. Check the USB Cable & Port

- What to do: Unplug the webcam and plug it directly into a different USB port on your computer.**

- **Tip: Avoid using USB hubs or extensions—plug it straight into the back or side of your PC.**

2. Check the Physical Privacy Switch or Cover

- **What to do: Make sure the small plastic cover on the camera lens is slid open.**
- **Tip: Some webcams also have a physical switch or toggle on the side that turns the power on/off. Ensure it is switched ON.**

3. Allow Camera Access in Windows Settings

- **What to do:**
 - 1. Open your Windows Settings (press Win + I).**
 - 2. Click Privacy, then click Camera on the left.**
 - 3. Make sure "Allow access to the camera on this device" is ON.**
 - 4. Scroll down and make sure "Allow desktop apps to access your camera" is toggled ON (this lets Zoom use your camera).**

4. Select the Right Camera Inside Zoom

- **What to do:**
 - 1. Open Zoom and click your Profile Picture / Settings gear icon in the top right.**

2. Go to the Video tab.

3. Click the Camera dropdown menu and select your external webcam instead of the built-in laptop camera.

5. Close Other Apps Using the Camera

- **What to do: Close any other programs that might be using your camera in the background (like Skype, Microsoft Teams, Discord, or a web browser).**
- **Tip: Only one app can use your webcam at a time!**

Task -4 : When Printer Shows Offline

Steps:

1. Open Settings.

2. Go to Troubleshoot.

3. Select Other troubleshooters.

4. Click Run next to Printer.

5. Choose the offline printer and follow the instructions.

What the troubleshooter does:

- Checks if the printer is connected.**
- Checks if the printer is turned on.**
- Checks the printer driver.**
- Checks the print queue for stuck jobs.**
- Tries to fix any problems automatically.**

What information it shows:

- The problems it finds.**
- Whether the problem was fixed.**
- If it cannot fix the problem, it suggests what to do next.**