MP-200 Pump Station Troubleshooting Extract

This extract is for indexing tests. Procedures are invented for demonstration only.

4.1 Motor does not start

Check the supply voltage at the panel input. Expected 400 V between phases.

If one phase is missing, inform the electrical supervisor and do not restart the pump.

4.2 Low discharge pressure

Confirm the suction strainer is clean and below the minimum water level.

Prime the pump by opening the vent until water flows steadily, then close the vent.

Look for air leaks on the suction pipe. Bubbles in the sight glass indicate air entry.

4.3 Bearing noise

Listen at each bearing housing. A grinding sound means the bearing needs grease or replacement.

Check shaft alignment at the coupling with a dial gauge against the maintenance sheet limit.

4.4 Seal leakage

A slow drip of a few drops per minute is normal for gland packing.

A steady leak from the mechanical seal face requires replacement of the seal kit. Do not over-tighten.