#### TELEGRAM LISTING CMS

# S3000 Expert/Anti Collision S300 Expert





de

en



Dieses Werk ist urheberrechtlich geschützt. Die dadurch begründeten Rechte bleiben bei der Firma SICK AG. Eine Vervielfältigung des Werks oder von Teilen dieses Werks ist nur in den Grenzen der gesetzlichen Bestimmungen des Urheberrechtsgesetzes zulässig. Eine Abänderung oder Kürzung des Werks ist ohne ausdrückliche schriftliche Zustimmung der Firma SICK AG untersagt.

# Inhalt

1	Zu die	esem Doku	ument	5	
	1.1	Funktion	n dieses Dokuments	5	
	1.2	Zielgrup	pe	5	
	1.3	Informat	tionstiefe	5	
	1.4	Geltungs	sbereich	5	
2	Syste	mbeschrei	ibung	6	
_	2.1		usgabe		
		2.1.1	Kompatibilitätsmodus		
	2.2	Systema	aufbau		
	2.3	-	che Schnittstelle		
		2.3.1	Übertragungs- und Datenformat		
3	Konfi	guration d	er Messdatenausgabe	a	
3	3.1		dienoberfläche		
	3.2		nstellungen		
	5.2	3.2.1	Baudrate		
		3.2.2	Silentzeit individuell		
		3.2.3	Sendemodus		
		3.2.4	Trigger-Ereignis (nur im Sendemodus Internes Ereignis)		
	3.3	_	I von I/O-Daten		
	5.5	3.3.1	Ausgabe I/O-Daten		
	3.4		che Messdatenausgabe		
	5.4	3.4.1	Messdatenausgabe		
		3.4.2	Messbereiche		
	3.5		I des Telegrammaufbaus		
	0.0	3.5.1	Telegrammaufbau		
4	Kamm	milkatiam	sarten		
4	<b>Ko</b> mn 4.1		Adressen		
	4.1		Token		
	4.2 4.3	-			
	4.3 4.4	Telegrammstruktur			
5			atenausgabe nur auf Anfrage		
			nd-Telegramm		
	5.2		elegramm		
		5.2.1	Fehlercodes des Reply-Telegramms		
	5.3		d-Kommunikation	19	
		5.3.1	Beispiel für ein Send-Telegramm "Schreiben des Token in		
			Block 25"	19	
		5.3.2	Beispiel für ein Fetch-Telegramm "Lesen des Operating Data		
	- 4		Block 11"	20	
	5.4		rung von Daten im Sendemodus <i>Datenausgabe nur auf</i>	•	
				20	
		5.4.1	Beispiel für Kommunikation im Sendemodus Datenausgabe		
		<b>=</b> 1	nur auf Anfrage		
	5.5		Telegramme (nur S3000)		
		5.5.1	Beispiel: Ausgabe Reflektor Block 52/Block 114	22	
6	Sende	emodus <i>Ko</i>	ontinuierliche Datenausgabe	24	
	6.1	Aufbau d	der kontinuierlichen Datenausgabe	25	
		6.1.1	Telegrammkopf, Verwaltungsdaten, allgemeine Daten	25	

		6.1.2	I/O-Daten	25
		6.1.3	Messdaten (Distanz)	26
		6.1.4	Reflektordaten	
		6.1.5	CRC	
	6.2		II-Versionsnummer	
	6.3	Format	der I/O-Daten	
		6.3.1	Überwachungsfalldaten	
		6.3.2	Statische Eingangsdaten	
		6.3.3	Geschwindigkeitsdaten	
		6.3.4	Ausgangsparameterdaten	
		6.3.5	Roh-Geschwindigkeitsdaten 1/2	29
	6.4		nd Reflektordatenformate	
		6.4.1	Datenformat der Messdaten für S3000 (2 Byte)	30
		6.4.2	Datenformat der Messdaten für S300 (2 Byte)	30
		6.4.3	Datenformat der Messdaten bei Konfiguration "Minimale	
			Entfernung je Messbereich" für S3000 (4 Byte)	31
		6.4.4	Datenformat der Messdaten bei Konfiguration "Minimale	
			Entfernung je Messbereich" für S300 (4 Byte)	31
		6.4.5	Datenformat der Reflektordaten für S3000 (4 Byte)	32
		6.4.6	Datenformat der Reflektordaten für S300 (4 Byte)	32
	6.5	Beispiel	für kontinuierliche Datenausgabe mit S3000	32
		6.5.1	Konfiguration 1: Messdaten	32
		6.5.2	Konfiguration 2: Reflektordaten	36
	6.6	Anhalte	n der Datenausgabe	38
	6.7	Fest ko	nfigurierte Modi der kontinuierlichen Datenausgabe	38
	6.8	Online u	umkonfigurierbare Modi der kontinuierlichen Datenausgabe	39
		6.8.1	Block 103	39
		6.8.2	Block 104	39
		6.8.3	Block 105	39
7	Sandai	modue In	ternes Ereignis	40
•	7.1		n der Datenausgabe	
		Amilaico	Ti dei Buteriausguse	
8			ationen zu den Messdaten	
	8.1		che Zeitstempel und Telegrammnummern	
	8.2		nale Abhängigkeit vom verwendeten Gerätetyp	
	8.3	Benenn	ung der Schutz- und Warnfelder	42
9	Reflek	tormarke	enerkennung	43
_	9.1		ormarken	
	9.2		änkungen	_
40			•	
10		_	<u> </u>	
11				
12				
	12.1		tion of the data blocks used in the \$3000	
	12.2	Descrip	tion of the data blocks used in the S300	121

### 1 Zu diesem Dokument

Bitte lesen Sie dieses Kapitel sorgfältig, bevor Sie mit der Dokumentation und der CMS-Funktion des S3000 oder S300 arbeiten.

#### 1.1 Funktion dieses Dokuments

Das vorliegende Telegrammlisting CMS beschreibt die messdatenspezifische Funktionserweiterung des S3000 Expert, des S3000 Anti Collision und des S300 Expert (zusätzlicher Geltungsbereich siehe Abschnitt 1.4 "Geltungsbereich" auf S. 5). Es ist als Ergänzung zur Betriebsanleitung S3000 bzw. S300 zu verstehen.



Für allgemeine Informationen, wie beispielsweise zum Anbau, zur Installation und Inbetriebnahme des Sicherheits-Laserscanners, verwenden Sie bitte die Betriebsanleitung S3000 bzw. S300. Beachten Sie bitte die darin beschriebenen Sicherheitshinweise in Kapitel 2 und 8, bevor Sie die Anlage in Betrieb nehmen.

Die vom Laserscanner zur Verfügung gestellten Telegrammdaten dürfen nicht für Sicherheitsanwendungen verwendet werden!

#### 1.2 Zielgruppe

Das Telegrammlisting CMS richtet sich an Systemspezialisten im Bereich der Hard- und Softwareentwicklung, die die scannereigenen Messwertdaten in ihre Hostapplikation einbinden und auswerten wollen.

#### 1.3 Informationstiefe

Das vorliegende Telegrammlisting CMS enthält Informationen zu folgenden Themen:

- Beschreibung der RS-422-Schnittstelle
- Beschreibung des verwendeten RK512-Protokolls
- Beschreibung der scannerspezifischen Sonderfunktionen
- Hinweise zum Einsatz
- Fehlerdiagnose

#### 1.4 Geltungsbereich

Das vorliegende Telegrammlisting ist anwendbar für die Sicherheits-Laserscanner S3000 Expert, S3000 Anti Collision und S300 Expert mit folgenden Typenbezeichnungen:

S3000: S30A-XXXX GB und S30A-XXXX EK

S300: S30**B**-XXXX **GB** 

Der Laserscanner S3000 Professional CMS und der Laserscanner S300 Professional CMS arbeiten ausschließlich im Kompatibilitätsmodus. Mit dieser Einschränkung ist das vorliegende Telegrammlisting auch anwendbar für die genannten Laserscanner mit folgenden Typenbezeichnungen:

\$3000: \$30**A**-XXXX **DB** \$300: \$30**B**-XXXX **DB** 

# 2 Systembeschreibung

#### 2.1 Datenausgabe

Die Sicherheits-Laserscanner S3000 Expert, S3000 Anti Collision und S300 Expert können über die RS-422-Schnittstelle Messdaten und I/O-Daten ausgeben. Zu den Messdaten gehören Distanzdaten und Reflektorerkennungsdaten, zu den I/O-Daten gehören z. B. die von einem Inkrementalgeber ermittelte Geschwindigkeit und die Schaltzustände der OSSDs.

Diese Daten können für allgemeine Überwachungs- und Steuerungsaufgaben verwendet werden. Sie dienen insbesondere der Navigationsunterstützung bei fahrerlosen Transportfahrzeugen (FTF).



Die vom Laserscanner zur Verfügung gestellten Telegrammdaten dürfen nicht für Sicherheitsanwendungen verwendet werden!

#### **Hinweis**

Wenn Sie die erweiterten CMS-Funktionen verwenden, dann sollten Sie im Fall eines Geräteaustauschs als Ersatz für ein CMS-Gerät immer ein CMS-Gerät verwenden.

Die Konfiguration der Messdatenausgabe erfolgt zusammen mit der Konfiguration des Scanners über eine der Kommunikationsschnittstellen (RS-232, RS-422, EFI).

Die Daten werden während des Betriebs von einem Hostrechner über die RS-422-Schnittstelle empfangen und verarbeitet. Die Datenübertragung erfolgt in der Form von Telegrammen nach dem RK512-Protokoll.

Die Datenausgabe erfolgt je nach Konfiguration auf unterschiedliche Weise:

- Die Datentelegramme werden vom Hostrechner einzeln angefordert (Sendemodus Datenausgabe nur auf Anfrage).
- Die Datentelegramme werden vom Sicherheits-Laserscanner kontinuierlich ausgegeben (Sendemodus Kontinuierliche Datenausgabe).
- Die Datentelegramme werden nach einem internen Ereignis (Trigger) vom Sicherheits-Laserscanner ausgegeben (Sendemodus Internes Ereignis).

#### 2.1.1 Kompatibilitätsmodus

Um die Kompatibilität mit älteren Geräten zu gewährleisten, können die Sicherheits-Laserscanner S3000 mit Firmware ≥ B02.40 und die Sicherheits-Laserscanner S300 mit Firmware ≥ 02.10 im Kompatibilitätsmodus betrieben werden. Den Kompatibilitätsmodus aktivieren Sie im Geräteauswahlassistenten der CDS (SICK Configuration & Diagnostic Software).


Die Messdatenausgabe des S3000 Expert im Kompatibilitätsmodus ist identisch mit der des S3000 Professional CMS; die Messdatenausgabe des S300 Expert im Kompatibilitätsmodus ist identisch mit der des S300 Professional CMS und des S300 Expert CMS.

Der S3000 Anti Collision kann nicht im Kompatibilitätsmodus betrieben werden.

Weitere Informationen zum Kompatibilitätsmodus finden Sie in der Betriebsanleitung zum S3000/S300 (Art.-Nr. 8009937/8010947).

Sofern für den Kompatibilitätsmodus abweichende Einstellungen oder Ausgaben gelten, wird in diesem Dokument darauf hingewiesen.

# 2.2 Systemaufbau



#### 2.3 Elektrische Schnittstelle

Die elektrische Schnittstelle ist nach dem Standard EIA RS-422-A implementiert. Die elektrische Anschlussmöglichkeit finden Sie in der Betriebsanleitung S3000/S300 im Kapitel "Elektroinstallation".

Der Anschluss über die RS-422-Schnittstelle darf im laufenden Betrieb bestehen. Die RS-232-Schnittstelle (Konfigurationsschnitstelle) ist dagegen ausschließlich für den temporären Anschluss während der Konfiguration vorgesehen.

#### 2.3.1 Übertragungs- und Datenformat

Ein Datenbyte setzt sich zusammen aus 1 Startbit, 8 Datenbits, 1 Stopbit, kein Paritybit.

Die Baudrate an der RS-422-Schnittstelle ist mit Hilfe der CDS einstellbar auf folgende Baudraten:

- 9600 Baud
- 19200 Baud
- 38400 Baud
- 115,2 kBaud (nur S300)
- 125 kBaud
- 230,4 kBaud (nur S300)
- 250 kBaud
- 460,8 kBaud (nur S300)
- 500 kBaud


Im Auslieferungszustand ist die Schnittstelle mit einer Baudrate von 38400 Baud vorkonfiguriert.

Beim S3000 Expert/Anti Collision können alle Messdaten in (Beinahe-)Echtzeit (mit einer Verzögerung von ca. einer Spiegelumdrehung, d. h. je nach Modus 30 ms oder 60 ms) übertragen werden, wenn die Schnittstelle auf 500 kBaud eingestellt ist. Bei niedrigeren Baudraten oder hoher Netzauslastung kann nicht jeder Scan ausgewertet werden, so dass die Daten einzelner oder mehrerer Messungen entfallen und nur die Daten jeder zweiten, dritten etc. Messung ausgegeben werden. Auch durch die zusätzliche Ausgabe von I/O-Daten kann sich die Anzahl der ausgegebenen Messungen reduzieren.

Beim S300 Expert können alle Messdaten in Echtzeit übertragen werden, wenn die Schnittstelle auf 500 kBaud eingestellt und kein Filter gesetzt ist. Sobald Messbereiche gesetzt sind oder Reflektordaten übertragen werden, können nur noch die Daten jeder zweiten Messung übertragen werden. Bei niedrigeren Baudraten oder hoher Netzauslastung kann nicht jeder Scan ausgewertet werden, so dass die Daten einzelner oder mehrerer Messungen entfallen und nur die Daten jeder zweiten, dritten etc. Messung ausgegeben werden. Auch durch die zusätzliche Ausgabe von I/O-Daten kann sich die Anzahl der ausgegebenen Messungen reduzieren.

# 3 Konfiguration der Messdatenausgabe

#### 3.1 CDS-Bedienoberfläche



#### Hinweis

Die Abbildungen der Bedienoberfläche in diesem Kapitel sind beispielhaft. Das tatsächliche Aussehen der Bedienoberfläche kann je nach Softwareversion, Gerät und Feldmodus abweichen.

Die Konfiguration der Messdatenausgabe erfolgt in der CDS über das Gerätesymbol S3000 bzw. S300 im Bereich *Messdatenausgabe*.

Damit Sie in der CDS auf die erweiterten CMS-Funktionen des S3000 Expert/Anti Collision / S300 Expert zugreifen können, müssen Sie den korrekten Scannertyp auswählen. Verwenden Sie dazu bei angeschlossenem Scanner die Funktion *Erkennen*. Falls Sie ein neues Projekt erstellen, muss im Geräteauswahlassistenten für Softwarepaket I/O-Modul die Option CMS Modul ausgewählt sein.

#### 3.2 Grundeinstellungen




Abbildung beispielhaft. Die angezeigten Optionen können abweichen.

#### 3.2.1 Baudrate

Die Baudrate der RS-422-Schnittstelle lässt sich entsprechend der Menüauswahl einstellen (weitere Informationen siehe Abschnitt 2.3.1 "Übertragungs- und Datenformat" auf Seite 8).

#### 3.2.2 Silentzeit individuell

Die Silentzeit dient dazu, in den Sendemodi Kontinuierliche Datenausgabe und Internes Ereignis die Schnittstelle freizugeben. Dazu kann der Hostrechner die Datenausgabe für die eingestellte Silentzeit unterbrechen (siehe Abschnitt 6.6 "Anhalten der Datenausgabe" auf Seite 38). Anschließend ist der Zugriff auf die Schnittstelle möglich. Nach Ablauf der Silentzeit wird die Datenausgabe automatisch fortgesetzt

Im Auslieferungszustand ist die Silentzeit auf 5000 ms eingestellt.

#### 3.2.3 Sendemodus

Datenausgabe nur auf Anfrage: Daten werden nur auf Anfrage ausgegeben (siehe

Kapitel 5 "Sendemodus Datenausgabe nur auf Anfrage"

auf S. 17).

Kontinuierliche Datenausgabe: Daten werden permanent ausgegeben (siehe Kapitel 6

"Sendemodus Kontinuierliche Datenausgabe" auf S. 24).

Internes Ereignis: Daten werden nur bei Eintreffen eines internen

Ereignisses (siehe unten) ausgegeben (siehe Kapitel 7

"Sendemodus Internes Ereignis" auf S. 40).

#### 3.2.4 Trigger-Ereignis (nur im Sendemodus Internes Ereignis)

Reflektor: Die Detektion eines Reflektors löst die Datenausgabe aus.

Ausgewähltes Feld: Ein Eingriff in eines der ausgewählten Felder löst die Datenausgabe

aus.

#### Abweichend davon gibt es im Kompatibilitätsmodus folgende Optionen:

Objekt im zugeordneten Schutzfeld: Ein Eingriff in das aktive Schutz- oder Warnfeld löst

die Datenausgabe aus.

Objekt im simultanen Schutzfeld: S3000: Ein Eingriff in das aktive simultane Schutz-

oder Warnfeld löst die Datenausgabe aus.


S300: Funktion nicht verfügbar.

Reflektor erkannt: Die Detektion eines Reflektors löst die Datenausgabe

aus.

#### 3.3 Auswahl von I/O-Daten

Durch Auswahl der folgenden Optionen können so genannte I/O-Daten an den Hostrechner ausgegeben werden. Diese Einstellung ist nur möglich, wenn der Sendemodus Kontinuierliche Datenausgabe oder Internes Ereignis gewählt ist.



#### 3.3.1 Ausgabe I/O-Daten

Aktueller Überwachungsfall: Der aktive Überwachungsfall wird ausgegeben

Statische Eingänge: Die Status der statischen Eingänge werden ausgegeben.

Geschwindigkeit: Die ermittelte Geschwindigkeit der aktiven Inkrementalgeber

wird ausgegeben.

OSSDs: Die aktiven Schaltzustände der OSSDs werden ausgegeben.

Inkrementalgeberwerte: Die ermittelten Rohdaten jedes einzelnen Inkrementalgebers

werden ausgegeben.

Weitere Informationen zu den ausgegeben Daten und zum Format finden Sie in Abschnitt 6.1.2 "I/O-Daten" auf Seite 25.

#### 3.4 Spezifische Messdatenausgabe



Hier legen Sie fest, welche Messdaten übertragen werden. Diese Einstellung ist nur möglich, wenn der Sendemodus *Kontinuierliche Datenausgabe* oder *Internes Ereignis* gewählt ist.

#### 3.4.1 Messdatenausgabe

Inaktiv: Es werden keine Messdaten ausgegeben.

Distanz: Messdaten der Raumkontur sowie detektierte Reflektoren werden

entsprechend den aktiven Messbereichen ausgegeben (das Reflektor-

Bit ist in Bit 13 des Distanzwerts enthalten).

Reflektor, alle: Es werden nur Positionsdaten detektierter Reflektoren ausgegeben. Es

werden die Daten sämtlicher Pulse ausgegeben, die auf einen

Reflektor treffen.

Reflektorzentrum: Es werden nur Positionsdaten detektierter Reflektoren ausgegeben.

Benachbarte Positionsdaten von Reflektoren werden

zusammengefasst und als gemittelter Wert ausgegeben, d. h. wenn mehrere Pulse auf einen Reflektor treffen, dann wird der mittlere

Winkel der Pulse ausgegeben.

Weitere Informationen zu den ausgegeben Daten und zum Format finden Sie in den Abschnitten 6.1.3 "Messdaten (Distanz)" auf Seite 26 und 6.1.4 "Reflektordaten" auf Seite 27.

#### 3.4.2 Messbereiche

Es lassen sich bis zu 4 Messbereiche beim S3000 bzw. 5 Messbereiche beim S300 definieren. Jeder Messbereich wird durch seinen Start- und Endwinkel bestimmt. Eine Überlappung der Messbereiche ist nicht möglich. Diese Einstellung ist nur möglich, wenn der Sendemodus *Kontinuierliche Datenausgabe* oder *Internes Ereignis* gewählt ist und als Messdatenausgabe die Option *Distanz* gewählt ist.

Für jeden aktiven Messbereich kann mit der Option Art eine Auswahl getroffen werden:

Minimum: Nur der kleinste Messwert wird ausgegeben.

Jeder Wert: Alle Messwerte werden ausgegeben.

Jeder n-te Wert: Es werden jeweils nur die Daten jedes 2. ... 15. Messwerts

ausgegeben.

**\$3000:** Wenn kein Messbereich konfiguriert ist, werden keine Messdaten ausgegeben. Damit alle Messdaten ausgegeben werden, muss ein Messbereich von –5° bis 185° konfiguriert sein.

**\$300:** Wenn kein Messbereich koniguriert ist, werden alle Messdaten ausgegeben.

**Hinweis** Es werden immer die Messwerte von Startwinkel bis Endwinkel zuzüglich der Messwerte bis unter den nächsten vollen Winkelgrad ausgegeben.

Ausnahme: Bei  $185\,^\circ$  (S3000) bzw.  $225\,^\circ$  (S300) gibt es keine darüber hinaus gehenden

Messwerte.

#### 3.5 Auswahl des Telegrammaufbaus

 Telegrammaufbau

 ⊚ 1 Telegramm (I/O + Messdaten)
 © 2 Telegramme (1. I/O, 2. Messdaten)

Hier legen Sie fest, ob I/O-Daten und Messdaten in einem gemeinsamen Telegramm übertragen werden oder ob zwei getrennte Telegramme übertragen werden. Diese Einstellung ist nur möglich, wenn die Ausgabe von I/O-Daten aktiv ist und wenn der Sendemodus *Kontinuierliche Datenausgabe* oder *Internes Ereignis* gewählt ist.

#### 3.5.1 Telegrammaufbau

1 Telegramm (I/O + Messdaten): I/O-Daten und Messdaten werden in einem

kombinierten Telegramm ausgegeben.

2 Telegramme (1. I/O, 2. Messdaten): I/O-Daten und Messdaten werden in getrennten

Telegrammen abwechselnd ausgegeben.

## 4 Kommunikationsarten

#### 4.1 Geräte-Adressen

Für eine Kommunikation der Geräte im Remote-Betrieb sind die Kommunikationsadressen (Device Address) für Host und Guest notwendig.

Für einzelne Scanner ist die Geräteadresse 0x07.

Wenn zwei Scanner im Verbund betrieben werden, sind die Adressen wie folgt aufgeteilt:

Host: 0x07Guest: 0x08

Diese Adresse wird im RK512-Telegrammkopf als Device Address angegeben (siehe Abschnitt 5.1 "Command-Telegramm" auf Seite 17).

#### 4.2 System-Token

Das Token verwaltet die unterschiedlichen Kommunikationsportale (RS-232, RS-422, EFI). Ein Gerät erlaubt keinen zeitgleichen Zugriff von verschiedenen Schnittstellen. In einem EFI-Verbund gilt dies für alle Schnittstellen der beteiligten Geräte: Der Zugriff kann immer nur über eine einzelne Schnittstelle erfolgen. Dies wird dadurch sichergestellt, dass vor dem Lesen oder Schreiben der Daten das Token angefordert und erfolgreich zugewiesen werden muss.

Falls auf der Messdatenschnittstelle (RS-422) kontinuierliche Datenausgabe erfolgt, kann gleichzeitig über die Konfigurationsschnittstelle (RS-232) oder EFI eine Kommunikation durchgeführt werden. Die kontinuierliche Datenausgabe wird dadurch nicht beeinflusst.

#### Ausnahme:

In den Sendemodi Kontinuierliche Datenausgabe und Internes Ereignis kann nicht direkt ein Request-Telegramm vom Hostrechner gesendet werden. Der Hostrechner muss zuerst die kontinuierliche Datenausgabe bzw. den Sendemodus Internes Ereignis unterbrechen (siehe Abschnitt 6.6 "Anhalten der Datenausgabe" auf S. 38).

Von einer seriellen Schnittstelle muss immer das angeschlossene Gerät adressiert werden, um das Token zu erhalten. Ohne vorherige Zuweisung des Token ist es nicht möglich, auf Daten eines Geräts zuzugreifen. Das Token wird beim Ausschalten nicht gespeichert und muss nach dem Einschalten neu angefordert werden.

Sie fordern das Token an, indem Sie mit einem Send-Telegramm z. B. für den Zugriff auf einen einzelnen Scanner (ohne EFI-Verbund) über die RS-232-Schnittstelle den Wert 0x0F07 in Block 25 schreiben.

Sie geben das Token frei, indem Sie mit einem Send-Telegramm den Wert 0x0000 in Block 25 schreiben.

Ein Beispiel für die Kommunikation inklusive Schreiben und Freigeben des Token finden Sie in Abschnitt 5.4.1 "Beispiel für Kommunikation im Sendemodus *Datenausgabe nur auf Anfrage*" auf S. 21.

Detaillierte Informationen zum Datenformat finden Sie im Appendix in Abschnitt 12.1.3 "Config master block (block no. 25)" auf S. 101 für den S3000 und in Abschnitt 12.2.3 "Config master block (block no. 25)" auf S. 126 für den S300.

#### 4.3 Telegrammstruktur

Die Kommunikation nach dem RK512-Standard basiert auf Command- und Reply-Telegrammen. Ein Command-Telegramm ist entweder ein Send- oder ein Fetch-Telegramm. Auf dieser Kommunikationsstruktur beruht der Sendemodus *Datenausgabe nur auf Anfrage*: Der Hostrechner sendet ein Fetch-Telegramm an den Scanner, um die Messdaten abzurufen. Der Scanner sendet die angeforderten Daten in einem Reply-Telegramm. Detaillierte Informationen zur Struktur der Command- und Reply-Telegramme finden Sie in Kapitel 5 "Sendemodus *Datenausgabe nur auf Anfrage*" auf Seite 17.

In den Sendemodi Kontinuierliche Datenausgabe und Internes Ereignis werden die Daten vom Scanner ebenfalls in Telegrammen übertragen. Es erfolgt keine Anforderung durch den Hostrechner (detaillierte Informationen in Kapitel 6 "Sendemodus Kontinuierliche Datenausgabe" auf Seite 24). Bei Bedarf kann die kontinuierliche Datenausgabe unterbrochen werden, um Command-Telegramme an den Scanner zu senden (siehe Abschnitt 6.6 "Anhalten der Datenausgabe" auf Seite 38).

Im Telegrammkopf werden Werte, die 2 Byte umfassen, mit dem High Byte (HB) zuerst übertragen. Bei den Datenbytes werden die 16- und 32-bit-Wörter mit dem Low Byte (LB) zuerst übertragen.

Der Wert im Size-Feld bezeichnet immer die Anzahl von 16-bit-Datenwörtern, es kann nicht auf einzelne Bytes zugegriffen werden.

#### 4.4 Datenintegrität

Da der RK512-Standard keinen Mechanismus zur Überprüfung der Integrität der empfangenen Daten zur Verfügung stellt, ist ein solcher Mechanismus in den Daten des RK512-Telegramms ergänzt. Dieser umfasst die exakte Wiederholung der Bytes 5 bis 10 vom Kopf eines Command-Telegramms in den ersten sechs Datenbytes sowie einen CRC-Wert, der über die Datenbytes gebildet wird und an diese angehängt wird. Demnach muss die Anzahl der Datenwörter, die im Size-Feld des Telegrammkopfs eines Command-Telegramms angegeben wird, um vier Wörter erhöht werden.

Der CRC-Wert umfasst 16 Bit und wird nach dem Polynom  $x^{16} + x^{12} + x^5 + x^0$  (0x1021) gebildet. Dieser CCITT-CRC wird im gesamten Kommunikationsstack angewandt, wo ein CRC zur Absicherung der übertragenen Daten benötigt wird.

Nachfolgend eine einfache Routine in C zur CRC-Berechnung als Beispiel:

```
static const unsigned short crc table[256] = {
0x0000, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
0x1231, 0x0210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
0x2462, 0x3443, 0x0420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
0x3653, 0x2672, 0x1611, 0x0630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
0x48c4, 0x58e5, 0x6886, 0x78a7, 0x0840, 0x1861, 0x2802, 0x3823,
Oxc9cc, Oxd9ed, Oxe98e, Oxf9af, Ox8948, Ox9969, Oxa90a, Oxb92b,
0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0x0a50, 0x3a33, 0x2a12,
Oxdbfd, Oxcbdc, Oxfbbf, Oxeb9e, Ox9b79, Ox8b58, Oxbb3b, Oxab1a,
0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0x0c60, 0x1c41,
0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0x0e70,
0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
0x1080, 0x00a1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
0x02b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
0x34e2, 0x24c3, 0x14a0, 0x0481, 0x7466, 0x6447, 0x5424, 0x4405,
0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
0x26d3, 0x36f2, 0x0691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
0x5844, 0x4865, 0x7806, 0x6827, 0x18c0, 0x08e1, 0x3882, 0x28a3,
0xcb7d, 0xdb5c, 0xeb3f, 0xfb1e, 0x8bf9, 0x9bd8, 0xabbb, 0xbb9a,
0x4a75, 0x5a54, 0x6a37, 0x7a16, 0x0af1, 0x1ad0, 0x2ab3, 0x3a92,
0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0x0cc1,
0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0x0ed1, 0x1ef0
} ;
WORD CRC16 (BYTE *Data, WORD length)
   WORD CRC 16 = 0xFFFF;
    WORD i;
    for (i = 0; i < length; i++)
        CRC 16 = (CRC 16 << 8) ^ (crc table[(CRC 16 >> 8) ^
(Data[i])]);
    }
    return CRC 16;
}
```

# Sendemodus Datenausgabe nur auf Anfrage

Im Sendemodus Datenausgabe nur auf Anfrage werden die Messdaten durch den Hostrechner angefordert (z. B. Block 12: Scan Data). Es werden Send- und Fetch-Telegramme verwendet.

Bei Send-Telegrammen schickt der Hostrechner nach dem Telegrammkopf die zu übertragenden Daten, der Empfänger antwortet mit einem Reply-Telegramm, das nur aus einem Kopf ohne weitere Daten besteht. Bei Fetch-Telegrammen schickt der Hostrechner den Kopf eines Fetch-Telegramms ohne nachfolgende Daten, und der Sensor antwortet mit einem Reply-Telegramm, welches nach dem Telegrammkopf die angeforderten Daten enthält.

Auch im EFI-Verbund ist der Hostrechner immer der aktive Teilnehmer. Die Sensoren senden von sich aus keine RK512-Telegramme. Damit entfällt auch ein möglicher Initialisierungskonflikt bei gleichzeitiger Kommunikationsaufnahme.

#### 5.1 **Command-Telegramm**

Der Telegrammkopf des Command-Telegramms (Befehlstelegramm) besteht aus 10 Bytes, welche folgende Bedeutungen haben:

Byte	Telegrammfelder	Inhalt	Bedeutung
1	Telegram Identifier	0x00	
2		0x00	
3	Command Telegram Type	,A' (0x41) oder	Send-Telegramm oder
		,E' (0x45)	Fetch-Telegramm
4	Command Data Type	,D' (0x44)	Zugriff auf Datenblock
5	Destination Address/	0 bis 255	Blocknummer
	Source Address	(0x00 bis 0xFF)	
6		0 bis 255	Blockindex
		(0x00 bis 0xFF)	
7	Size	0 bis 65535	Blockgröße in Datenwörtern
8			
9	Coordination Flag	OxFF	
10	Device Address	0x07 oder	Host
		0x08	Guest

Tabelle: Aufbau Command-Telegramm

#### 5.2 Reply-Telegramm

Der Telegrammkopf des Reply-Telegramms (Reaktionstelegramm) besteht aus 4 Bytes, welche folgende Bedeutung haben:

Byte	Telegrammfelder	Inhalt	Bedeutung
1	Telegram Identifier	0x00 (immer)	
2		0x00 (immer)	
3	Reply Telegram Type	0x00 (immer)	Reply-Telegramm
4	Reply Error Number	0x00	Kein Fehler
		0x01 bis 0xFF	Fehlercode siehe Fehlertabelle

Tabelle: Aufbau Reply-Telegramm

#### 5.2.1 Fehlercodes des Reply-Telegramms

Das Reply-Telegramm ist die Antwort des S3000/S300 auf ein Send- oder Fetch-Telegramm.

Stellt der S3000/S300 einen Fehler fest, zeigt er dies im Fehlercode des Reply-Telegramms an, und es werden keine Daten nach dem Reply-Telegrammkopf geschickt.

Fehlercode im Reply-Telegramm	Kommunikationsfehler nach dem RK512-Protokoll	
0x00	Kein Fehler.	
0x01	Der aktuelle Status des Geräts erlaubt keinen Schreibzugriff auf den Datenblock.	
0x02	Der Zugriff auf den Datenblock ist der aktuellen Benutzergruppe nicht erlaubt.	
0x03	Das Passwort ist nicht korrekt.	
0x04	Das System-Token ist belegt.	
0x05	Parameter nicht korrekt.	
	Der Blockindex der Zieladresse oder Quelladresse im Command- Telegramm (Byte 6) ist unzulässig (nicht im Register Interface definiert).	
0x06	Gerät ist aufgrund interner Prozesse ausgelastet. Für Zugriff auf den Datenblock Vorgang wiederholen.	
0.07	Interner Fehler des Gerätes.	
0x07	Zugriff auf Datenblock im aktuellen Gerätezustand nicht unterstützt.	
OxOA	Eine der Überwachungen der Kommunikation ist fehlgeschlagen (u. a. Timeout des EFI-RK512-Pakets/EFI-RK512 Acknowledge oder fehlerhafte Übertragung des EFI-RK512-Pakets/EFI-RK512 Acknowledge).	
0x0C	Das Coordination Flag (Byte Number) im Command-Telegramm (Byte 9) ist ungleich 0xFF.	
	Die Device Address im Command-Telegramm (Byte 10, Bit 0 bis 3) ist ungültig (d. h. ist gleich 0).	
	Die CPU Number im Command-Telegramm (Byte 10, Bit 5 bis 7) ist unzulässig.	
0x10	Der Telegram Identifier im Command-Telegramm (Byte 1) ist ungleich 0x00 oder 0xFF oder wird nicht gefolgt von einem weiteren Byte 0x00 (Byte 2).	
	Der Command Data Type im Command-Telegramm (Byte 4) ist unzulässig.	
0x14	Die Datenblocknummer der Destination Address bzw. Source Address im Command-Telegramm (Byte 5) ist unzulässig (nicht im Register Interface definiert).	
0x16	Der Command Telegram Type im Command-Telegramm (Byte 3) ist unzulässig.	

Fehlercode im Reply-Telegramm	Kommunikationsfehler nach dem RK512-Protokoll
0x34	<ul> <li>Telegramm-Format-Fehler.</li> <li>Mögliche Ursachen:</li> <li>Die im Size-Feld des Command-Telegramms angegebene Länge (Byte 7 und 8) übersteigt die im Datenblock ab der angegebenen Adresse verfügbaren Einträge.</li> <li>Die Länge der Daten des Send-Telegramms war größer als im Size-Feld angegeben.</li> <li>Die Länge der Daten des Send-Telegrammms war kleiner als im Size-Feld angegeben.</li> <li>Es wurde ein Fetch-Telegramm mit Nutzdaten empfangen.</li> <li>Das Send-Telegramm wurde korrekt empfangen, aber der CRC-Wert über die Daten ist falsch oder die ersten sechs Datenbytes stimmen nicht mit den Bytes 5 bis 10 aus dem Telegrammkopf überein.</li> </ul>
0x36	Es wurde ein Command-Telegramm empfangen, obwohl noch kein Reply-Telegramm für das vorherige Command-Telegramm versendet wurde.

Tabelle: Fehlercodes Reply-Telegramm

#### 5.3 Standard-Kommunikation

#### 5.3.1 Beispiel für ein Send-Telegramm "Schreiben des Token in Block 25"


# Hostrechner Send: 00 00 41 44 19 00 00 05 FF 07 19 00 00 05 FF 07 07 0F 9F D0 CRC Daten für CRC Gesendete Daten Telegrammkopf-Wiederholung Device Address Coordination Flag Size = Blockgröße + Telegrammkopf-Wiederholung + CRC Destination Address: Blocknummer 25 Data Type: Blockzugriff Telegram Type: Send Telegram ID

S3000 Reply:

00 00 00 00


#### 5.3.2 Beispiel für ein Fetch-Telegramm "Lesen des Operating Data Block 11"

#### **Hostrechner Send:**



#### S3000 Reply

00 00 00 00 00 00 0B 00 00 56 FF 07 08 38 FD FD 00 02 00 55 00 00 00 00 00 08 7D 00 CO 02 00 00 35 01 00 00 52 00 61 04 00 00 9F 02 39 02 18 02 6A 00 0C 00 02 00 32 02 1B 00 1A 00 0A 00 49 02 02 00 28 00 14 00 23 02 01 00 04 00 0F 00 00 02 20 00 06 00 04 00 2A 02 1F 00 21 00 05 00 31 02 09 00 17 00 10 00 02 00 19 00 94 00 00 00 00 00 00 0A 00 0E 49 87 47 F6 4A 18 44 65 4E A7 00 9C 14 31 02 64 00 5A 00 A5 02 DE 02 07 01 69 01 6D 02 E8 02 A3 13 C3 00 F1 00 07 01 53 01 A6 01 34 02 03 03 3D 04 54 06 05 0A 98 00 C7 08 AC 08 2D 2C



# 5.4 Anforderung von Daten im Sendemodus *Datenausgabe* nur auf Anfrage

Beim S3000 und beim S300 können Messdatenblöcke mit statischer Länge (Block 12, beim S3000 auch Block 52), für den S3000 optional auch Messdatenblöcke mit flexibler Länge (Block 112, Block 114) angefordert werden.

Beim S3000 mit Firmware des Sensorkopfes ≥ B02.40 kann je nach eingestellter Auflösung Block 58 (bei 0,5° Scanauflösung) oder Block 59 (bei 0,25° Scanauflösung) angefordert werden. Diese Blöcke haben eine statische Länge.

Beim S300 mit Firmware ≥ 2.10 kann Block 58 mit statischer Länge angefordert werden.

Beispiel 1: Es existiert nur ein S3000 und es sollen Messdaten empfangen werden.

- 1. Power On
- 2. Get Token (Send-Telegramm mit Device Address 0x07)
- 3. Read Scandatensatz 1 (Fetch-Telegramm mit Device Address 0x07)

- 4. Read Scandatensatz 2 (Fetch-Telegramm mit Device Address 0x07)
- 5. Read Scandatensatz n (Fetch-Telegramm mit Device Address 0x07)
- 6. Release Token (Send-Telegramm mit Device Address 0x07)

Beispiel 2: Es existiert ein EFI-Verbund aus zwei S3000 und es sollen abwechselnd Messdaten von beiden Scannern empfangen werden. Es werden 2 getrennte RS-422-Verbindungen vorausgesetzt.

- 1. Power On
- 2. Get Token S3000 (Host) (Send-Telegramm mit Device Address 0x07)
- 3. Read Scandatensatz von S3000 (Host) (Fetch-Telegramm mit Device Address 0x07)
- 4. Release Token S3000 (Host) (Send-Telegramm mit Device Address 0x07)
- 5. Get Token S3000 (Guest) (Send-Telegramm mit Device Address 0x08)
- 6. Read Scandatensatz von S3000 (Guest) (Fetch-Telegramm mit Device Address 0x08)
- 7. Release Token S3000 (Guest) (Send-Telegramm mit Device Address 0x08)

#### 5.4.1 Beispiel für Kommunikation im Sendemodus Datenausgabe nur auf Anfrage

#### **Get Token**

Hostrechner Send: 00 00 41 44 19 00 00 05 FF 07 19 00 00 05 FF 07 07 0F 9F D0

S3000 Reply: 00 00 00 00

#### Read Scan Data (Block 12)

Hostrechner Send: 00 00 45 44 0C 00 02 FE FF 07

S3000 Reply: 00 00 00 00 00 00 02 FE FF 07 00 08 3B 00 3D 00 ... 00 00 FE E9

#### Read Reflector Data (Block 52)

Hostrechner Send: 00 00 45 44 34 00 01 04 FF 07

S3000 Reply: 00 00 00 00 <mark>34 00 01 04 FF 07</mark> 02 00 00 00 34 01 ... 00 00 DE EA

#### Read Extended Scan Data (Block 112)

Hostrechner Send: 00 00 45 44 70 00 03 02 FF 07

S3000 Reply: 00 00 00 00 <mark>70 00 03 02 FF 07</mark> 01 00 00 00 14 4B ... 29 00 <mark>26 8B</mark>

#### Read Extended Reflector Data (Block 114)

Hostrechner Send: 00 00 45 44 72 00 01 04 FF 07

S3000 Reply: 00 00 00 00 <mark>72 00 00 18 FF 07</mark> 01 00 00 00 35 01 ... E8 23 F4 D1

#### Read Scan Data 05 Block (Block 58)

Hostrechner Send: 00 00 45 44 3A 00 01 8F FF 07

S3000 Reply: 00 00 00 00 <mark>70 00 03 02 FF 07 01 00 00 07 00 ... 00 00 E1 C3</mark>

#### Read Scan Data 025 Block (Block 59)

Hostrechner Send: 00 00 45 44 3B 00 03 0B FF 07

S3000 Reply: 00 00 00 00 <mark>3B 00 03 0B FF 07</mark> 01 00 00 00 07 00 ... 00 00 <mark>C5 12</mark>

#### **Release Token**

Hostrechner Send: 00 00 41 44 19 00 00 05 FF 07 19 00 00 05 FF 07 00 00 E7 B8

S3000 Reply: 00 00 00 00

#### 5.5 Flexible Telegramme (nur S3000)

Bei einigen Hostrechnern besteht die Forderung, die Interrupt-Belastung für den UART so gering wie möglich zu halten. In solchen Fällen kann (im Sendemodus *Datenausgabe nur auf Anfrage*) ein Datenblock mit flexibler Länge im Reply-Telegramm verwendet werden (Block 112 statt Block 12 und Block 114 statt Block 52).

#### 5.5.1 Beispiel: Ausgabe Reflektor Block 52/Block 114

Annahme: Der S3000 erkennt 8 Reflektoren in je 10 Metern Entfernung auf Puls 1, 2, 3, 6, 7, 9, 10, 761.

Fordert man vom Hostrechner den Block 52 an, sieht das Reply-Telegramm folgendermaßen aus:

#### S3000 Reply für Block 52

00 00 00 00 <mark>34 00 01 04 FF 07</mark> 02 00 00 00 34 01 00 00 02 00 E8 23 04 00 E8 23 06 00 E8 23 0C 00 E8 23 0E 00 E8 23 12 00 E8 23 14 

Fordert man vom Hostrechner den Block 114 an, sieht das Reply-Telegramm folgendermaßen aus:

#### S3000 Reply für Block 114

00 00 00 00 <mark>72 00 00 18 FF 07</mark> 01 00 00 00 35 01 00 00 02 00 E8 23 04 00 E8 23 06 00 E8 23 0C 00 E8 23 0E 00 E8 23 12 00 E8 23 14 00 E8 23 F2 05 E8 23 <mark>F4 D1</mark>

Block 114 enthält nur die relevanten Nutzdaten, im Block 52 werden dagegen immer 256 Datenwörter ausgegeben. Falls nur in 8 Messwerten Reflektoren erkannt wurden, werden in Block 52 also 236 Datenwörter ohne Information übertragen.

Der Hostrechner fordert einen Datenblock mit flexibler Länge immer mit maximal angegebener Blocklänge (+ 3 Wörter Telegrammkopf-Wiederholung + 1 Wort CRC) an.

Im Reply-Telegramm des S3000 wird in der Telegrammkopf-Wiederholung die tatsächliche Blocklänge (+ 3 Wörter Telegrammkopf-Wiederholung + 1 Wort CRC) an den Hostrechner übergeben.

#### Hinweis

Die Blöcke 112 und 114 sind nur von einem direkt angeschlossenen (lokalen) Scanner verfügbar. Die Ausgabe der Blöcke eines zweiten Scanners, der über EFI am lokalen Scanner angeschlossen ist, ist nicht möglich.

23

# Sendemodus Kontinuierliche Datenausgabe

Um einen möglichst effizienten Telegrammverkehr aufbauen zu können, kann der S3000 bzw. S300 in der CDS so konfiguriert werden, dass er die Messwerte und einige Zusatzinformationen permanent an der RS-422-Schnittstelle aussendet. Die kontinuierliche Datenausgabe wird nicht durch den Telegrammverkehr über die anderen zur Verfügung stehenden Schnittstellen beeinträchtigt. Für die kontinuierliche Datenausgabe ist es nicht erforderlich, dass das Token für die RS-422-Schnittstelle reserviert wird (im Sendemodus *Datenausgabe nur auf Anfrage* kann immer nur eine Schnittstelle das Token besitzen, siehe Abschnitt 4.2 "System-Token" auf S. 14).

Bei der kontinuierlichen Datenausgabe erfolgt die Ausgabe der Messdaten automatisch, die Telegramme müssen nur gelesen werden.

In den Sendemodi Kontinuierliche Datenausgabe und Internes Ereignis kann nicht direkt ein Request-Telegramm vom Hostrechner gesendet werden. Der Hostrechner muss zuerst die kontinuierliche Datenausgabe bzw. den Sendemodus Internes Ereignis unterbrechen (siehe Abschnitt 6.6 "Anhalten der Datenausgabe" auf Seite 38).


Die Daten im Datenblock des Telegramms sind konfigurierbar.

Es existieren folgende Ausgabeoptionen:

- Messdaten über 4 konfigurierbare Winkelbereiche beim S3000 bzw.
   5 Winkelbereiche beim S300
- Minimum der Messdaten pro Winkelbereich
- Alle reflektierten Pulse oder nur Reflektorzentren
- Alternierende Ausgabe Messdaten/Reflektordaten und I/O-Daten

#### Beispiel: Telegrammaufbau kontinuierliche Datenausgabe

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 17 01 00 00 02 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 <mark>10 07</mark>



Abhängig von der Konfiguration hat der Configurable Contour and Measurement Block eine dynamische Länge, die sich von Telegramm zu Telegramm verändern kann.

Ebenfalls abhängig von der Konfiguration können im Configurable Contour and Measurement Block alternierend I/O-Daten und Messdaten ausgegeben werden (siehe Abschnitt 3.5.1 "Telegrammaufbau" auf S. 13).

#### Hinweis

Im Sendemodus *Kontinuierliche Datenausgabe* können an der RS-422-Schnittstelle nur Daten des direkt angeschlossenen (lokalen) Scanners ausgegeben werden. Die Ausgabe von Daten eines zweiten Scanners, der über EFI am lokalen Scanner angeschlossen ist, ist nicht möglich.

#### 6.1 Aufbau der kontinuierlichen Datenausgabe

#### 6.1.1 Telegrammkopf, Verwaltungsdaten, allgemeine Daten

Die Datenausgabe beginnt immer wie folgt:

00 00 00 00 4 Byte RK512-Telegrammkopf: Reply-Telegramm

Datenblocknummer 0x0000 für kontinuierliche Datenausgabe oder

Datenausgabe nach Triggerereignis

xx xx Größe des Telegramms in 16-bit-Datenwörtern

S3000

Die Telegrammlänge wird aus den Daten hinter dem Telegrammkopf (vom ersten Byte der Verwaltungsdaten, 5. Byte des Telegramms) bis zum letzen Byte des Telegramms (inkl. CRC) berechnet. Das Längenfeld enthält also den Wert: (Gesamtlänge in Bytes – 4)/2

#### S300: Wenn keine IO-Daten und keine Sektoren konfiguriert sind

Die Telegrammlänge wird aus den Daten hinter dem Längenfeld (vom 5. Byte der Verwaltungsdaten, 9. Byte des Telegramms) bis zum letzen Byte des Telegramms (inkl. CRC) berechnet. Das Längenfeld enthält also den Wert: (Gesamtlänge in Bytes – 8)/2

#### S300: Wenn IO-Daten oder mindestens ein Sektor konfiguriert sind

Die Telegrammlänge wird aus den Daten hinter der Protokoll-Version in den Nutzdaten (vom 3. Byte der Nutzdaten, 13. Byte des Telegramms) bis zum letzen Byte des Nutzdatenblocks (letztes Byte vor dem CRC-Wert) berechnet. Das Längenfeld enthält also den Wert:

(Gesamtlänge in Bytes - 14)/2

#### S300: Im Kompatibilitätsmodus

Die Telegrammlänge wird aus den Daten hinter dem Telegrammkopf (vom ersten Byte der Verwaltungsdaten, 5. Byte des Telegramms) bis zum letzen Byte des Telegramms (inkl. CRC) berechnet. Das Längenfeld enthält also den Wert: (Gesamtlänge in Bytes – 4)/2

Coordination Flag und Device Address, hier 0x07 (Host oder Standalone-Gerät)

03 01 Protokoll-Versionsnummer: 0x0103

**Im Kompatibiltätsmodus abweichend:** 02 01 Protokoll-Versionsnummer: 0x0102 Detaillierte Informationen siehe Abschnitt 6.2 "Protokoll-Versionsnummer" auf S. 28.

00 00 oder 01 00 Status Normal 0x0000 oder Lockout 0x0001

17 01 00 00 Scannummer (Zeitstempel), hier 0x00000117 (siehe Abschnitt 8.1, S. 41)

02 00 Telegrammnummer, hier 0x0002

#### 6.1.2 I/O-Daten

Der folgende Block mit der Kennung AAAA wird ausgegeben, wenn I/O-Datenausgabe konfiguriert wurde. Wenn nicht alternierende Ausgabe konfiguriert wurde, wird er in jedem

25

Telegramm ausgegeben. Wenn alternierende Ausgabe konfiguriert wurde, wird er nur ausgegeben, wenn die Telegrammnummer **ungerade** ist.


# AA AA ID für I/O-Daten xx xx Überwachungsfalldaten (nur wenn konfiguriert) xx xx Statische Eingangsdaten (nur wenn konfiguriert) xx xx Geschwindigkeitsdaten (nur wenn konfiguriert) xx xx Ausgangsparameterdaten (nur wenn konfiguriert) xx xx Roh-Geschwindigkeitsdaten: Data1 (nur wenn konfiguriert) xx xx Roh-Geschwindigkeitsdaten: Data2 (nur wenn konfiguriert)

Detaillierte Informationen zu den Datenformaten siehe Abschnitt 6.3 "Format der I/O-Daten" auf S. 28.

#### 6.1.3 Messdaten (Distanz)

Der folgende Block mit der Kennung BBBB wird ausgegeben, wenn Messdatenausgabe (Distanz) konfiguriert wurde. Wenn nicht alternierende Ausgabe konfiguriert wurde, wird er in jedem Telegramm ausgegeben. Wenn alternierende Ausgabe konfiguriert wurde, wird er nur ausgegeben, wenn die Telegrammnummer **gerade** ist.

Es kann nur einer der beiden Blöcke BBBB und CCCC ausgegeben werden. Welcher dieser beiden Blöcke ausgegeben wird, ist von der Konfiguration in der CDS abhängig.




Detaillierte Informationen zu den Datenformaten siehe Abschnitt 6.4 "Mess- und Reflektordatenformate" auf S. 30.

#### 6.1.4 Reflektordaten

Der folgende Block mit der Kennung CCCC wird ausgegeben, wenn Messdatenausgabe (Reflektor) konfiguriert wurde. Wenn nicht alternierende Ausgabe konfiguriert wurde, wird er in jedem Telegramm ausgegeben. Wenn alternierende Ausgabe gewählt wurde, wird er nur ausgegeben, wenn die Telegrammnummer gerade ist.

Es kann nur einer der beiden Blöcke BBBB und CCCC ausgegeben werden. Welcher dieser beiden Blöcke ausgegeben wird, ist von der Konfiguration in der CDS abhängig.



Detaillierte Informationen zu den Datenformaten siehe Abschnitt 6.4 "Mess- und Reflektordatenformate" auf S. 30.

#### 6.1.5 **CRC**

Abschließend wird der CRC-Wert ausgegeben:



xx xx 16 Bit CRC

Der CRC-Wert wird über die Daten hinter dem Telegrammkopf (vom ersten Byte der Verwaltungsdaten, 5. Byte des Telegramms) bis zum letzen Byte des Nutzdatenblocks gebildet (letztes Byte vor dem CRC-Wert).

#### 6.2 Protokoll-Versionsnummer

S3000/S300: 0x0103

Im Kompatibilitätsmodus: S3000/S300: 0x0102

Die Protokoll-Versionsnummer sollte vom Hostrechner geprüft werden. Sie ist abhängig von der Firmwareversion im verwendeten Sensor und davon, ob der Kompatibilitätsmodus aktiviert ist

Bei einer anderen Versionsnummer kann der Aufbau der kontinuierlichen Datenausgabe abweichen.

#### 6.3 Format der I/O-Daten

#### 6.3.1 Überwachungsfalldaten

#### S3000

- OO O2 Überwachungsfall/Standby
  Referenz: Appendix, Abschnitt 12.1.5/12.1.6, Block 58/59 Scan Data,
  Register Processing, Wort 0
- O4 00 Auswertung Feld A (Feldnummer, Feldart, Mehrfachauswertung)
  Referenz: Appendix, Abschnitt 12.1.5/12.1.6, Block 58/59 Scan Data,
  Register Field Evaluation A, Wort 10
- O6 41 Auswertung Feld B (Feldnummer, Feldart, Mehrfachauswertung),
  Referenz: Appendix, Abschnitt 12.1.5/12.1.6, Block 58/59 Scan Data,
  Register Field Evaluation B, Wort 11
- O8 O2 Auswertung Feld C (Feldnummer, Feldart, Mehrfachauswertung)
  Referenz: Appendix, Abschnitt 12.1.5/12.1.6, Block 58/59 Scan Data,
  Register Field Evaluation C, Wort 12
- OA 43 Auswertung Feld D (Feldnummer, Feldart, Mehrfachauswertung)
  Referenz: Appendix, Abschnitt 12.1.5/12.1.6, Block 58/59 Scan Data,
  Register Field Evaluation D, Wort 13

#### Abweichend davon bestehen die Überwachungsfalldaten im Kompatibiltätsmodus aus:

OB O2 Überwachungsfall/Standby/Feldsatz A/Feldsatz A aktiv/Feldsatz B/Feldsatz B aktiv.

Referenz: Appendix, Abschnitt 12.1.1, Block 11 Operating Data, Register Monitoring Data, Wort 6

#### **S300**

Die Überwachungsfalldaten sind beim S300 die gleichen wie beim S3000. Da es beim S300 jedoch keine simultanen Schutzfelder gibt, sind die Überwachungsfalldaten für die Feld 3 Evaluation Data (simultane Schutzfelder) auf die Standardwerte gesetzt: Die Datenfelder ControlAreaB, ControlAreaBActive und ControlAreaAActive werden nicht genutzt, diese Bits sind immer 0.

OO O2 Überwachungsfall/Standby, hier 0x02/0x00
Referenz: Appendix, Abschnitt 12.2.4, Block 58 Scan Data,
Register Processing, Wort 0

- O4 00 Auswertung Feld A (Feldnummer, Feldart, Mehrfachauswertung),
   Referenz: Appendix, Abschnitt 12.2.4, Block 58 Scan Data,
   Register Field Evaluation A, Wort 10
- O6 41 Auswertung Feld B (Feldnummer, Feldart, Mehrfachauswertung)
  Referenz: Appendix, Abschnitt 12.2.4, Block 58 Scan Data,
  Register Field Evaluation B, Wort 11
- CO 01 Auswertung Feld C ist auf 0x1C0 gesetzt, da das dritte Feld im S300 immer inaktiv ist.
  - Referenz: Appendix, Abschnitt 12.2.4, Block 58 Scan Data, Register Field Evaluation C, Wort 12
- O8 12 Auswertung Feld D (Feldnummer, Feldart, Mehrfachauswertung) Referenz: Appendix, Abschnitt 12.2.4, Block 58 Scan Data, Register Field Evaluation D, Wort 13

#### Abweichend davon bestehen die Überwachungsfalldaten im Kompatibiltätsmodus aus:

O3 82 Überwachungsfall/Standby Referenz: Appendix, Abschnitt 12.2.4, Block 58 Scan Data, Register Processing, Wort 0

#### 6.3.2 Statische Eingangsdaten

xx xx Statische Eingangsdaten: nicht sichere Eingänge/Sicherheitseingänge Referenz: Appendix, Abschnitt 12.1.1 (S3000)/12.2.1 (S300), Block 11 Operating Data, Register Input data, Wort 3

#### 6.3.3 Geschwindigkeitsdaten

xx xx Geschwindigkeitsdaten: gemessene Geschwindigkeit
 Referenz: Appendix, Abschnitt 12.1.1 (S3000)/12.2.1 (S300), Block 11
 Operating Data, Register InputData, Wort 4

#### 6.3.4 Ausgangsparameterdaten

Ausgangsparameterdaten: OSSD-Status, Warnausgang etc., Referenz: Appendix, Abschnitt 12.1.1 (S3000)/12.2.1 (S300), Block 11 Operating Data, Register OutputStates, Wort 5

#### 6.3.5 Roh-Geschwindigkeitsdaten 1/2

#### S3000

Roh-Geschwindigkeitsdaten 1/2: Rohgeschwindigkeit der Inkrementalgeber 1 und 2 in Pulsen pro 12,52 ms (2 Pulse pro Inkrement, d. h. pro Umdrehung des Inkrementalgebers). Dieser Wert ist vorzeichenbehaftet (Zweierkomplement): Positive Werte stehen für Vorwärtsbewegung, negative Werte stehen für Rückwärtsbewegung. Dieser Wert wird von der Schaltung zur Evaluation des Geschwindigkeitsgebers im S3000 generiert.

#### **S300**

Roh-Geschwindigkeitsdaten 1/2: Rohgeschwindigkeit der Inkrementalgeber 1 und 2 in cm/s). Dieser Wert ist vorzeichenbehaftet (Zweierkomplement): Positive Werte stehen für Vorwärtsbewegung, negative Werte stehen für Rückwärtsbewegung.

#### 6.4 Mess- und Reflektordatenformate

Eine Erläuterung der in den folgenden Tabellen verwendeten Benennung der Felder finden Sie in Abschnitt 8.3 "Benennung der Schutz-, Warn- und Kollisionsschutzfelder" auf Seite 42.

#### 6.4.1 Datenformat der Messdaten für S3000 (2 Byte)

Bit 15 13	Bit 12 0
Status-Bits	Gemessene
Bit 15: Eingriff innerhalb Feld C oder D erkannt (wenn das Feld als Schutzfeld/Kollisionsschutzfeld aktiviert ist)	Entfernung in Zentimetern
Bit 14: Eingriff innerhalb Feld A oder B erkannt (wenn das Feld als Schutzfeld/Kollisionsschutzfeld aktiviert ist)	
Bit 13: CMS-Modelle: Reflektor erkannt	
Nicht-CMS-Modelle: Scanner geblendet	
Abweichend davon gilt im Kompatibilitätsmodus:	
Bit 15: Messwert innerhalb simultanem Schutzfeld erkannt	
Bit 14: Messwert innerhalb Schutzfeld erkannt	

#### 6.4.2 Datenformat der Messdaten für S300 (2 Byte)

Bit 15 13	Bit 12 0
Status-Bits	Gemessene
Bit 15: Firmware < 2.10: Messwert innerhalb Warnfeld erkannt	Entfernung in
Firmware ≥ 2.10: 0 (fixer Wert des Bits)	Zentimetern
Bit 14: Messwert innerhalb Schutzfeld erkannt	
Bit 13: CMS-Modelle: Reflektor erkannt	
Nicht-CMS-Modelle: Scanner geblendet	

# 6.4.3 Datenformat der Messdaten bei Konfiguration "Minimale Entfernung je Messbereich" für S3000 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status-Bits	Gemessene	Winkel von 0° 190°
Bit 31: Eingriff innerhalb Feld C oder D erkannt (wenn das Feld als Schutzfeld/Kollisionsschutzfeld aktiviert ist)	Entfernung in Zentimetern	(Angabe in 0,01°)
Bit 30: Eingriff innerhalb Feld A oder B erkannt (wenn das Feld als		
Schutzfeld/Kollisionsschutzfeld aktiviert ist)		
Bit 29: CMS-Modelle: Reflektor erkannt		
Nicht-CMS-Modelle: Scanner geblendet		
Abweichend davon gilt im		
Kompatibilitätsmodus:		
Bit 31: Messwert innerhalb simultanem Schutzfeld erkannt		
Bit 30: Messwert innerhalb Schutzfeld erkannt		

# 6.4.4 Datenformat der Messdaten bei Konfiguration "Minimale Entfernung je Messbereich" für S300 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status-Bits	Gemessene	Winkel von 0° 270°
Bit 31: Firmware < 2.10: Messwert innerhalb Warnfeld erkannt	Entfernung in Zentimetern	(Angabe in 0,01°)
Firmware ≥ 2.10: 0 (fixer Wert des Bits)		
Bit 30: Messwert innerhalb Schutzfeld erkannt		
Bit 29: Reflektor erkannt		

31

#### 6.4.5 Datenformat der Reflektordaten für S3000 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status-Bits	Gemessene	Winkel von 0° 190°
Bit 31: Eingriff innerhalb Feld C oder D erkannt (wenn das Feld als Schutzfeld/Kollisionsschutzfeld aktiviert ist)	Entfernung in Zentimetern	(Angabe in 0,01°)
Bit 30: Eingriff innerhalb Feld A oder B erkannt (wenn das Feld als Schutzfeld/Kollisionsschutzfeld aktiviert ist)		
Bit 29: CMS-Modelle: Reflektor erkannt		
Nicht-CMS-Modelle: Scanner geblendet		
Abweichend davon gilt im		
Kompatibilitätsmodus:		
Bit 31: Messwert innerhalb simultanem Schutzfeld erkannt		
Bit 30: Messwert innerhalb Schutzfeld erkannt		

#### 6.4.6 Datenformat der Reflektordaten für S300 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status-Bits	Gemessene	Winkel von 0° 270°
Bit 31: Firmware < 2.10: Messwert innerhalb Warnfeld erkannt	Entfernung in Zentimetern	(Angabe in 0,01°)
Firmware ≥ 2.10: 0 (fixer Wert des Bits)		
Bit 30: Messwert innerhalb Schutzfeld erkannt		
Bit 29: Reflektor erkannt		

#### 6.5 Beispiel für kontinuierliche Datenausgabe mit S3000

#### 6.5.1 Konfiguration 1: Messdaten

Ausgabe aller Messwerte aus den vier Bereichen 0° ... 1°, 32° ... 33°, 128° ... 129° und 189° ... 190°, keine Ausgabe von I/O-Daten (daher Ausgabe in einem Telegramm/nicht alternierend), kontinuierliche Datenausgabe, 0,25° Winkelauflösung (120 ms Basisansprechzeit)

#### Empfang von 3 Messdatensätzen

...

00 00 00 00 <mark>00 00 00 2B FF 07</mark> 03 01 00 00 17 01 00 00 00 00 BB BB 11 11 E8 23 E8 23 E8 23 E8 03 E8 03 E8 23 E8 23 E8 03 22 22 E8 03 E8 0

00 00 00 00 <mark>00 00 00 2B FF 07</mark> 03 01 00 00 18 01 00 00 01 00 BB BB 11 11 E8 23 E8 23 E8 23 E8 03 E8 03 E8 23 E8 23 E8 03 22 22 E8 03 E8 03 E8 03 E8 03 E8 03 E8 03

E8 03 E8 03 33 33 E8 03 44 44 E8 03 E8 03 E8 03 E8 03 E8 23 <mark>DB 8E</mark>

00 00 00 00 00 00 00 28 FF 07 03 01 00 00 19 01 00 00 02 00 BB BB 11 11 E8 23 E8 23 E8 23 E8 03 E8 03 E8 23 E8 23 E8 03 E8 03

...

#### Erläuterung des ersten Messdatensatzes

00 00 00 00 4 Byte RK512-Telegrammkopf: Reply-Telegramm

Datenblocknummer 0x0000 für kontinuierliche Datenausgabe oder Datenausgabe nach Triggerereignis

<mark>00 2B</mark> Größe des Telegramms in 16-bit-Datenwörtern: 43 Datenwörter

FF 07 Coordination Flag und Device Address, hier 0x07 (Host oder Standalone-Gerät)

03 01 Protokoll-Versionsnummer: 01.03

00 00 Status: normal

17 01 00 00 Scannummer (Zeitstempel): hier 0x00000117 = 279

00 00 Telegrammnummer: 0

BB BB ID für Messdaten

11 11 ID für Messdaten aus Messbereich 1 (eingestellt in CDS, hier: 0° ... 1°)

E8 23 Messwert 1 im aktuellen Messbereich (hier: bei 0°): 0x23E8,

in Bit-Schreibweise: 0010 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 1: Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

(512 cm + 256 cm + 128 cm + 64 cm + 32 cm + 8 cm = 1000 cm)

E8 23 Messwert 2 im aktuellen Messbereich (hier: bei 0,25°): 0x23E8,

in Bit-Schreibweise: 0010 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 1: Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 23 Messwert 3 im aktuellen Messbereich (hier: bei 0,5°): 0x23E8,

in Bit-Schreibweise: 0010 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 1: Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 03 Messwert 4 im aktuellen Messbereich (hier: bei 0,75°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 03 Messwert 5 im aktuellen Messbereich (hier: bei 1°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 23 Messwert 6 im aktuellen Messbereich (hier: bei 1,25°): 0x23E8,

in Bit-Schreibweise: 0010 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 1: Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 23 Messwert 7 im aktuellen Messbereich (hier: bei 1,5°): 0x23E8,

in Bit-Schreibweise: 0010 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 1: Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 03 Messwert 8 im aktuellen Messbereich (hier: bei 1,75°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

22 22 ID für Messdaten aus Messbereich 2 (eingestellt in CDS, hier: 32° ... 33°)

E8 03 Messwert 1 im aktuellen Messbereich (hier: bei 32°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

---

33 33 ID für Messdaten aus Messbereich 3 (eingestellt in CDS, hier: 128° ... 129°)

E8 03 Messwert 1 im aktuellen Messbereich (hier: bei 128°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

...

<mark>44 44</mark> ID für Messdaten aus Messbereich 4 (eingestellt in CDS, hier: 189° ... 190°)

E8 03 Messwert 1 im aktuellen Messbereich (hier: bei 189°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 03 Messwert 2 im aktuellen Messbereich (hier: bei 189,25°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 03 Messwert 3 im aktuellen Messbereich (hier: bei 189,5°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 03 Messwert 4 im aktuellen Messbereich (hier: bei 189,75°): 0x03E8,

in Bit-Schreibweise: 0000 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 13: 0: kein Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

E8 23 Messwert 5 im aktuellen Messbereich (hier: bei 190°): 0x23E8,

in Bit-Schreibweise: 0010 0011 1110 1000

Bit 15: 0: kein Eingriff in Feld C und D (sofern als Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 14: 0: kein Eingriff in Feld A und B (sofern als Schutzfeld/Kollisionsschutzfeld

aktiviert)

Bit 13: 1: Reflektor erkannt

Bits 12 ... 0: Distanz in cm: 0x03E8 = 1000 [cm]

9C F4 16 Bit CRC

#### 6.5.2 Konfiguration 2: Reflektordaten

Ausgabe aller Reflektoren, keine Ausgabe von I/O-Daten (daher Ausgabe in einem Telegramm/nicht alternierend), kontinuierliche Datenausgabe, 0,25° Winkelauflösung (120 ms Basisansprechzeit)

#### Empfang von 3 Messdatensätzen

...

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 17 01 00 00 00 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 <mark>07 DE</mark>

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 18 01 00 00 01 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 B9 1C

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 19 01 00 00 02 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 E6 E7

...

#### **Hinweis**

In den Reflektordaten wird zuerst die Anzahl der erkannten Reflektoren ausgegeben, da diese nicht über die Konfiguration festgelegt ist.

#### Erläuterung des ersten Messdatensatzes

00 00 00 00 4 Byte RK512-Telegrammkopf: Reply-Telegramm

00 00 Datenblocknummer 0x0000 für kontinuierliche Datenausgabe oder Datenausgabe nach Triggerereignis

00 1B Größe des Telegramms in 16-bit-Datenwörtern

FF 07 Coordination Flag und Device Address, hier 0x07 (Host oder Standalone-Gerät)

03 01 Protokoll-Versionsnummer: 01.03

00 00 Status: normal

17 01 00 00 Scannummer (Zeitstempel): hier 0x00000117

<mark>00 00</mark> Telegrammnummer: 0

CC CC ID für Reflektordaten

<mark>08 00</mark> Anzahl der erkannten Reflektoren: hier 0x0008 = 8

00 00 E8 23 Reflektor 1: 0x23E80000

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

(512 cm + 256 cm + 128 cm + 64 cm + 32 cm + 8 cm = 1000 cm)

Bits 15 ... 0: Winkel in 0,01°: 0x0000 = 0 (=> 0°)

(entspricht -5° im Koordinatensystem des S3000)

19 00 E8 23 Reflektor 2: 0x23E80019

in Bit-Schreibweise: 0010 0011 1110 1000 0000 0000 0001 1001

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in 0,01°: 0x0019 = 25 (=> 0,25°)

(entspricht -4,75° im Koordinatensystem des S3000)

32 00 E8 23 Reflektor 3: 0x23E80032

in Bit-Schreibweise: 0010 0011 1110 1000 0000 0000 0011 0010

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in  $0.01^{\circ}$ :  $0x0032 = 50 (=> 0.5^{\circ})$ 

(entspricht -4,5° im Koordinatensystem des S3000)

7D 00 E8 23 Reflektor 4: 0x23E8007D

in Bit-Schreibweise: 0010 0011 1110 1000 0000 0000 0111 1101

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in  $0.01^{\circ}$ :  $0x007D = 125 (=> 1.25^{\circ})$ 

(entspricht -3,75° im Koordinatensystem des S3000)

96 00 E8 23 Reflektor 5: 0x23E80096

in Bit-Schreibweise: 0010 0011 1110 1000 0000 0000 1001 0110

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in 0,01°: 0x0096 = 150 (=> 1,5°)

(entspricht -3,5° im Koordinatensystem des S3000)

C8 00 E8 23 Reflektor 5: 0x23E800C8

in Bit-Schreibweise: 0010 0011 1110 1000 0000 0000 1100 1000

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in 0,01°: 0x00C8 = 200 (=> 2,0°)

(entspricht -3° im Koordinatensystem des S3000)

E1 00 E8 23 Reflektor 5: 0x23E800E1

in Bit-Schreibweise: 0010 0011 1110 1000 0000 0000 1110 0001

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in  $0.01^{\circ}$ :  $0x00E1 = 225 (=> 2.25^{\circ})$ 

(entspricht -2,75° im Koordinatensystem des S3000)

38 4A E8 23 Reflektor 5: 0x23E84A38

in Bit-Schreibweise: 0010 0011 1110 1000 0100 1010 0011 1000

Bit 31: 0: kein Eingriff in Feld C und D (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 30: 0: kein Eingriff in Feld A und B (sofern als

Schutzfeld/Kollisionsschutzfeld aktiviert)

Bit 29: 1: Reflektor erkannt

Bits 28 ... 16: Distanz in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: Winkel in 0,01°: 0x4A38 = 19000 (=> 190,0°)

(entspricht 185° im Koordinatensystem des S3000)

07 DE 16 Bit CRC

#### 6.6 Anhalten der Datenausgabe

In den Sendemodi Kontinuierliche Datenausgabe und Internes Ereignis kann nicht direkt ein Request-Telegramm vom Hostrechner gesendet werden.

Der Hostrechner muss zuerst die kontinuierliche Datenausgabe bzw. den Sendemodus Internes Ereignis unterbrechen. Dies erfolgt durch das Senden eines Zeichens 0x41. Jetzt kann der Hostrechner wie im Sendemodus Datenausgabe nur auf Anfrage kommunizieren, solange die konfigurierbare Silentzeit noch nicht verstrichen ist. Danach setzt die Ausgabe der Messdaten automatisch wieder ein.

Dieses Zeichen muss im Sendemodus Internes Ereignis auch dann gesendet werden, wenn gerade kein internes Ereignis vorliegt, wenn also gerade keine Daten ausgegeben werden.

**Hinweis** 

Die kontinuierliche Datenausgabe erfolgt nur in den Systemzuständen Normal und Lockout. In allen anderen Systemzuständen wird die kontinuierliche Datenausgabe (bzw. der Sendemodus Internes Ereignis) automatisch deaktiviert.

### 6.7 Fest konfigurierte Modi der kontinuierlichen **Datenausgabe**

Mit der CDS wird die Messdatenausgabe zunächst fest konfiguriert.

Diese Konfiguration bleibt permanent im Gerät erhalten, solange keine neue Konfiguration an das Gerät übertragen wird.

Bei jedem Einschalten wird diese Konfiguration aus dem Speicher des Systemsteckers geladen.

# 6.8 Online umkonfigurierbare Modi der kontinuierlichen Datenausgabe

Für einige Einstellungen der Messdatenkonfiguration gibt es die Möglichkeit, im laufenden Betrieb Parameter zu ändern.

Diese Einstellungen sind jedoch flüchtig und werden nach dem Einschalten mit den ursprünglich konfigurierten Einstellungen überschrieben.

Allgemeine Informationen zum Telegrammformat für die verwendeten Command-Telegramme finden Sie in Abschnitt 5.1 "Command-Telegramm" auf Seite 17.

### 6.8.1 Block 103

Hier kann online auf Reflektor- oder Messdatenausgabe umgeschaltet werden. Details zu Block 103 finden Sie im Appendix auf Seite 104 und auf Seite 132.

### **Beispiel**

Hostrechner Send: 00 00 41 44 67 00 00 05 FF 07 67 00 00 05 FF 07 00 00 FA 96

S3000 Reply: 00 00 00 00

### 6.8.2 Block 104

Hier können die 4 Winkelbereiche beim S3000 bzw. 5 Winkelbereiche beim S300 neu festgelegt werden, wobei alle Bereiche auf einmal neu gesetzt werden (siehe Beispiel Block 103).

Details zu Block 104 finden Sie im Appendix auf Seite 115 und auf Seite 133.

### 6.8.3 Block 105

Hier können die Output-Trigger-Bedingungen neu festgelegt werden (siehe Beispiel Block 103).

Details zu Block 105 finden Sie im Appendix auf Seite 116 und auf Seite 134.

# 7 Sendemodus Internes Ereignis

Im Sendemodus *Internes Ereignis* erfolgt die Datenausgabe nur dann, wenn ein Triggerereignis eintritt. Die Triggerereignisse werden in der CDS konfiguriert (siehe Abschnitt 3.2.4 "Trigger-Ereignis (nur im Sendemodus *Internes Ereignis*)" auf S. 10). Die Datenausgabe erfolgt so lange, wie eines der in der CDS definierten Triggerereignisse vorliegt. Sie endet automatisch, sobald kein Triggerereignis mehr vorliegt.

Die ausgegebenen Daten und das Datenformat sind identisch mit der kontinuierlichen Datenausgabe.

## 7.1 Anhalten der Datenausgabe

In den Sendemodi *Kontinuierliche Datenausgabe* und *Internes Ereigni*s kann nicht direkt ein Request-Telegramm vom Hostrechner gesendet werden.

Der Hostrechner muss zuerst die kontinuierliche Datenausgabe bzw. den Sendemodus *Internes Ereignis* unterbrechen. Dies erfolgt durch das Senden eines Zeichens 0x41. Jetzt kann der Hostrechner wie im Sendemodus *Datenausgabe nur auf Anfrage* kommunizieren, solange die konfigurierbare Silentzeit noch nicht verstrichen ist. Danach setzt die Ausgabe der Messdaten automatisch wieder ein.

Dieses Zeichen muss im Sendemodus *Internes Ereignis* auch dann gesendet werden, wenn gerade kein internes Ereignis vorliegt, wenn also gerade keine Daten ausgegeben werden.

### Hinweis

Die kontinuierliche Datenausgabe erfolgt nur in den Systemzuständen *Normal* und *Lockout*. In allen anderen Systemzuständen wird die kontinuierliche Datenausgabe (bzw. der Sendemodus *Internes Ereignis*) automatisch deaktiviert.

# Weitere Informationen zu den Messdaten

# 8.1 Zusätzliche Zeitstempel und Telegrammnummern

In einem bewegten Transportfahrzeug ist die Zuordnung eines Messwertsatzes oder des Reflektordatensatzes mit einer Zeitmarke für den Hostrechner notwendig, damit der Messwertsatz mit der richtigen Position und der richtigen Orientierung des Fahrzeugs ausgewertet wird. Deshalb ist im Sensor ein globaler Zähler (32 Bit) realisiert, der bei den Blöcken 52, 112 und 114 in den Sendemodi *Datenausgabe nur auf Anfrage* (nur S3000) und *Kontinuierliche Datenausgabe* mit ausgegeben wird. Dieser Zähler wird bei jedem Scan, also alle 40 ms (beim S300) bzw. je nach Modus alle 30 ms oder 60 ms (beim S3000) intern inkrementiert.

Zusätzlich besitzen diese Blöcke je eine eigene Telegrammnummer, die nur bei Ausgabe des Blocks inkrementiert wird.

# 8.2 Funktionale Abhängigkeit vom verwendeten Gerätetyp

Die Funktionalität der Messwertausgabe ist abhängig vom verwendeten Gerätetyp:

	Funktionalität	S3000 Expert/Anti Collision	S300 Expert
Sendemodus	Block 11	Ja	Ja
Datenausgabe	Operating Data		
nur auf Anfrage	(Betriebsdaten)		
	Block 25	Ja	Ja
	Config Master Block (Token)		
	Block 12	Ja	Ja
	Scan Data		
	(Messwerte)		
	Block 112	Ja	Nein
	Extended Scan Data		
	(Messwerte)		
	Block 52	Ja	Nein
	Reflector Detection		
	(Reflektordaten)		
	Block 114	Ja	Nein
	Extended Reflector Detection		
	(Reflektordaten)		
	Block 58	Ja, falls Scanauflösung	Ja, falls Firmware
	Scan Data 05	0,5° und Firmware des	≥ 2.10
	(Messwerte, Auflösung 0,5°)	Sensorkopfes ≥ B02.40	
	Block 59	Ja, falls Scanauflösung	Nein
	Scan Data 025	0,25° Firmware des	
	(Messwerte, Auflösung 0,25°)	Sensorkopfes ≥ B02.40	
Sendemodus	I/O-Daten	Ja	Ja
Kontinuierliche	Messwerte	Ja	Ja
Datenausgabe	Reflektordaten	Ja	Ja
oder Internes	Block 103	Ja	Ja
Ereignis	Online Measurement Config		
	(Online-Umschaltung auf		
	Messwerte oder		
	Reflektordaten)		

Funktionalität	S3000 Expert/Anti Collision	S300 Expert
Block 104 Online Output Range Config (Online-Konfiguration Messbereiche)	Ja	Ja
Block 105 Online Output Trigger (Online-Konfiguration Triggerereignis)	Ja	Ja

# 8.3 Benennung der Schutz-, Warn- und Kollisionsschutzfelder

In den Erläuterungen zu den Telegrammen werden die Schutz-, Warn- und Kollisionsschutzfelder mit den Buchstaben A bis D bezeichnet. Die Zuordnung dieser Buchstaben zu den Schutz-, Warn- und Kollisionsschutzfeldern wird in der folgenden Tabelle erläutert:

Feld	S3000 Expert Dual-Feldmodus	S3000 Expert Triple-Feldmodus	S3000 Expert Vier simultane Schutzfelder	S3000 Anti Collision Dual (Kollisions- schutz)	S3000 Anti Collision Triple (Kollisions- schutz)	S300 Expert
Α	Schutzfeld	Schutzfeld	Schutzfeld 1	Schutzfeld	Schutzfeld	Schutzfeld
В	Warnfeld	Warnfeld 1	Schutzfeld 2	Kollisionsschutzfeld	Kollisionsschutzfeld 1	Warnfeld 1
С	Simultanes	_	Simultanes	Simultanes	-	-
	Schutzfeld		Schutzfeld 1	Schutzfeld		
D	Simultanes	Warnfeld 2	Simultanes	Simultanes	Kollisionsschutzfeld 2	Warnfeld 2
	Warnfeld		Schutzfeld 2	Kollisionsschutzfeld		

### Im Kompatibilitätsmodus:

Feld	\$3000	S300
Α	Schutzfeld	Schutzfeld
В	Warnfeld	Warnfeld
С	Simultanes Schutzfeld	_
D	Simultanes Warnfeld	_

# 9 Reflektormarkenerkennung


### 9.1 Reflektormarken

Für die Reflektormarkenerkennung wird die Verwendung von Cube 3000x empfohlen.


Die Reflektormarken können als Reflektorstreifen (Reflektortafeln) oder als zylindrische Reflektoren ausgeführt werden. Reflektorstreifen werden auf ortsfesten Flächen angebracht, z. B. auf Wänden oder Anlagen. Zylindrische Reflektoren werden dort eingesetzt, wo die Reflektormarke von mehr als einer Seite detektiert werden muss. Sie müssen vom Parcours aus immer vollständig zu sehen sein.

Die Höhe und vertikale Anordnung der Reflektoren ist so zu wählen, dass der Messstrahl auch bei unebenem Boden auf den Reflektor trifft. Empfohlen wird eine detektierbare Reflektorhöhe von mindestens 500 mm.

Die Reichweite des S3000 beträgt max. 49 Meter. Daraus ergibt sich die Mindestgröße der Reflektoren bei einer empfohlenen Messauflösung von 0,25°:



Die Reichweite des S300 beträgt max. 30 Meter . Daraus ergibt sich die Mindestgröße der Reflektoren bei einer empfohlenen Messauflösung von 0,5°:




# 9.2 Einschränkungen


Hochglänzende Gegenstände, z. B. aus Edelstahl, können fälschlicherweise als Reflektoren erkannt werden, wenn sie sich im Scan-Bereich befinden. Dies muss bei der Navigation berücksichtigt werden, damit fehlerhafte Positionsberechnungen vermieden werden.

Aus technischen Gründen ist eine zuverlässige Reflektorerkennung erst ab einem Mindestabstand von 40 cm zum Scanner möglich.

Reflektorfolien reflektieren nur noch einen geringen Teil des Lichtpulses zurück, wenn sie aus Winkeln größer 50° zur Senkrechten angeleuchtet werden. Dieser Effekt ist abhängig von der verwendeten Folie, in jedem Fall muss aber damit gerechnet werden, dass ein entsprechend schräg getroffener Reflektor nicht mehr erkannt wird. Der Reflektor sollte vorzugsweise so montiert werden, dass die Messstrahlen vertikal zur Reflektorfläche gerichtet sind. Wo die Reflektormarke von mehr als einer Seite detektiert werden muss, sollten zylindrische Reflektoren bevorzugt werden,

Falls ungenaue Treffer (z. B. aufgrund von Bodenunebenheiten oder Vibrationen des Fahrzeugs) anderweitig vermieden werden, ein einzelner Volltreffer im Fahrbetrieb zur Reflektorerkennung ausreicht und die Positionsbestimmung des Hostrechners ausreichend tolerant ist, genügt auch eine erheblich geringere Reflektorbreite:





# 10 Fehlerdiagnose

Für die Diagnose der Einstellungen an Ihrem Sensor stehen Ihnen folgende Möglichkeiten zur Verfügung:

Sie können die Blöcke, die Sie online ändern, jederzeit wieder aus dem Sensor zurücklesen, um sicherzustellen, dass die Einstellungen im Gerät korrekt sind.

Mit Hilfe der CDS stehen Ihnen folgende Diagnose-Möglichkeiten zur Verfügung:

- Anzeige der im Gerät abgespeicherten Konfiguration.
- Darstellung der aktuellen Einstellung des Sensors im Betriebszustandsbericht.

# 11 Glossar

CDS SICK Configuration & Diagnostic Software

CMS Contour Measurement & Safety

Device Address Geräteadresse für Kommunikation

Diamond Grade Reflektorfolie mit entsprechenden optischen

Eigenschaften

EFI siehe Enhanced Function Interface

Enhanced Function Interface sichere SICK-Gerätekommunikation

Kontinuierliche Datenausgabe permanenter Sende-Modus der Messdaten

Messbereich Segment im Scanfeld

Messdaten vom Sensor gemessene Entfernungswerte

Output Trigger Definition des Auslösers für Datenausgabe

Protokoll-Versionsnummer Firmware-/Gerätekennung für den Hostrechner

Reflektordaten Entfernungswerte, bei denen ein Reflektor erkannt wurde

Remote-Betrieb zwei S3000/S300 im EFI-Verbund

RK512 Telegram Header Protokoll-Definition für Datenkommunikation

Roh-Geschwindigkeitsdaten aktuell gemessene Inkrementalgeberwerte

Scandatensatz Entfernungswerte eines Messumlaufs (0...190°/0...270°)

Silentzeit Pausezeit bei kontinuierlicher Datenausgabe

Volltreffer komplette Fläche des Laserstrahls trifft auf ein Objekt

Zeitstempel Zeitmarke, die bei der Datengenerierung ermittelt wird

This document is protected by the law of copyright, whereby all rights established therein remain with the company SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Alteration or abridgement of the document is not permitted without the explicit written approval of the company SICK AG.

# **Contents**

1	About this document							
	1.1	Purpose	e of this document	51				
	1.2	Target group						
	1.3	Information depth						
	1.4	Scope						
2	Syster	ystem description						
	2.1	Data output						
		2.1.1	Compatibility mode					
	2.2	System	construction	53				
	2.3	Electrica	al interface	54				
		2.3.1	Transfer and data formats	54				
3	Config	guration f	or measured data output	55				
	3.1	CDS user interface						
	3.2	Basic se	ettings	56				
		3.2.1	Baud rate					
		3.2.2	Individual silent time	56				
		3.2.3	Send mode	56				
		3.2.4	Trigger event (only in send mode Internal event)	56				
	3.3	Selectio	n of I/O data	57				
		3.3.1	I/O data output	57				
	3.4	Specific	measured data output	57				
		3.4.1	Measured data output	58				
		3.4.2	Measuring ranges	58				
	3.5	Selectio	n of telegram structure					
		3.5.1	Telegram structure	59				
4	Comm	unication	ı types	60				
	4.1	Device a	addresses	60				
	4.2	System token						
	4.3	Telegra	m structure	61				
	4.4	Data integrity						
5	Send i	mode <i>Dat</i>	a output on request	63				
		Command telegram						
	5.2		legram					
		5.2.1	Reply telegram error codes	64				
	5.3	Standar	d communication	65				
		5.3.1	Example for a send telegram "Write token in block 25"	65				
		5.3.2	Example for a fetch telegram "Read operating data					
			block 11"	65				
	5.4	Request	ting data in send mode Data output on request	66				
		5.4.1	Example for communication in send mode Data output on					
			request	67				
	5.5	Flexible	telegram (S3000 only)					
		5.5.1	Example: Output reflector block 52 / block 114	68				
6	Send :	Send mode Continuous data output7						
	6.1		re of continuous data output					
		6.1.1	Telegram header, administration data, general data	71				
		6.1.2	I/O data	71				
		6.1.3	Measured data (distance)	72				

	12.1 12.2		tion of the data blocks used in the S3000tion of the data blocks used in the S300	
12				
11	Glossa	ry		93
10	Fault d	liagnosis		92
9	9.1 9.2	Reflecto	detection or marksions	89
8	Furthe 8.1 8.2 8.3	Addition Function	nal time stamps and telegram numbers	87 87
7	7.1	Stoppin	g data outputg	86
		6.8.2 6.8.3	Block 104Block 105	
	6.8		econfigurable modes for continuous data output Block 103	85
	6.6 6.7		g data outputonfigured modes for continuous data output	84
	0.0	6.5.1 6.5.2	Configuration 1: measured data  Configuration 2: reflector data	78
	6.5	6.4.5 6.4.6 Example	Reflector data format for S300 (4 Byte)	78 78
		6.4.2 6.4.3 6.4.4	Data format of measured data for S300 (2 Byte)	77
	6.4	6.3.2 6.3.3 6.3.4 6.3.5	Static input data	75 75 75 75
	6.2 6.3		Reflector data	73 74 74

# About this document

Please read this chapter carefully before you begin working with this documentation and the CMS function of the S3000 or S300.

# 1.1 Purpose of this document

This CMS telegram listing describes the measuring-data-specific functional extension of the S3000 Expert, S3000 Anti Collision and the S300 Expert (additional scope see section 1.4 "Scope" on page 51).

This document is to be considered a supplement to the S3000 and S300 operating instructions.



Please refer to the operating instructions for the S3000 and S300 for general information, such as mounting, installation and commissioning of the safety laser scanner. Please observe the safety notes detailed in chapters 2 and 8 of the above mentioned document before commissioning the system.

The telegram data made available by the laser scanner may not be used for safety applications.

## 1.2 Target group

The CMS telegram listing is written for system specialists working in the field of hardware and software development intending to integrate and evaluate the scanner's internal measured data into host applications.

# 1.3 Information depth

This CMS telegram listing contains information about the following topics:

- Description of the RS-422 interface
- Description of the RK512 protocol used
- Description of the scanner-related special functions
- Notes on use
- Fault diagnosis

## 1.4 Scope

This telegram listing is applicable to the safety laser scanners S3000 Expert, S3000 Anti Collision and S300 Expert with the following type codes:

S3000: S30A-XXXX GB and S30A-XXXX EK

S300: S30**B**-XXXX **GB** 

The laser scanner S3000 Professional CMS and laser scanner S300 Professional CMS work exclusively in compatibility mode. With this restriction, the telegram listing is also applicable for the named laser scanner types with the following type codes:

\$3000: \$30**A**-XXXX **DB** \$300: \$30**B**-XXXX **DB** 

# 2 System description

## 2.1 Data output

The safety laser scanners S3000 Expert, S3000 Anti Collision and S300 Expert can output measured data and I/O data via the RS-422 interface. The measured data includes distance data and reflector detection data. The I/O data includes, for example, speeds detected by an incremental encoder or output states for OSSDs.

This data can be used for general monitoring and control tasks. They are particularly applicable for purposes of navigation support for automated guided vehicles (AGVs).



The telegram data made available by the laser scanner may not be used for safety applications.

Note

If you use the extended CMS functions you should always use a CMS device as a replacement for a CMS device whenever a device needs to be replaced.

Configuration of the measured data output is realized in combination with scanner configuration via one of the communications interfaces (RS-232, RS-422, EFI).

During operation the data is received and processed by a host computer via the RS-422 interface. The data transfer is undertaken in the form of telegrams in accordance with the RK512 protocol.

The data output is realized in various ways depending on the configuration:

- The data telegrams are requested individually by the host computer (send mode Data output on request).
- The data telegrams are output continuously by the safety laser scanner (send mode *Continuous data output*).
- The data telegrams are output by the safety laser scanner after an internal event (trigger) (send mode *Internal event*).

### 2.1.1 Compatibility mode

In order to ensure compatibility with older models, safety laser scanner S3000 with firmware  $\geq$  B02.40 and safety laser scanner S300 with firmware  $\geq$  02.10 can be operated in compatibility mode. You can activate compatibility mode via the device selection wizard on the CDS (SICK Configuration & Diagnostic Software).


The measured data output for the S3000 Expert in compatibility mode is identical to that of the S3000 Professional CMS; measured data output for the S300 Expert in compatibility mode is identical to that of the S300 Professional CMS and S300 Expert CMS.

The S3000 Anti Collision can not be operated in compatibility mode.

Further information regarding compatibility mode can be found in the operating instructions for the S3000/S300 (item no. 8009942/8010948).

This document highlights any deviating settings or outputs which apply to compatibility mode.

# 2.2 System construction



### 2.3 Electrical interface

The electrical interface is implemented in accordance with the EIA RS-422-A standard.

The options for electrical connection are detailed in the operating instructions for the \$3000/\$300 in the "Electrical Installation" chapter.

Connection via the RS-422 interface may be maintained in operation. However, the RS-232 interface (configuration interface) is designed solely for temporary connection during the configuration process.

### 2.3.1 Transfer and data formats

A data byte is composed of 1 start bit, 8 data bits, 1 stop bit and no parity bit.

The baud rate on the RS-422 interface can be configured to the following baud rates with the help of CDS:

- 9600 Baud
- 19200 Baud
- 38400 Baud
- 115.2 kBaud (S300 only)
- 125 kBaud
- 230.4 kBaud (S300 only)
- 250 kBaud
- 460.8 kBaud (S300 only)
- 500 kBaud


The interface is preconfigured ex factory to a default baud rate of 38400 baud.

S3000 Expert/Anti Collision is able to transfer all measured data in (near) real-time (with a delay of approx one mirror rotation, i.e. 30 ms or 60 ms, depending on mode), if the interface is set to 500 kBaud. Lower baud rates or higher network loads will mean that the system cannot evaluate every scan, so that data from individual or multiple measurements will be dropped and only data from every second or third, etc. measurement will be output. In addition, the additional output of I/O data can lead to a reduction in output measurements.

S300 Expert can transfer all measured data in real-time, if the interface is set to 500 kBaud and no filter is set. As soon as measuring ranges are set or reflector data is transferred, only the data from every second measurement can be transferred. Lower baud rates or higher network loads will mean that the system cannot evaluate every scan, so that data from individual or multiple measurements will be dropped and only data from every second or third, etc. measurement will be output. In addition, the additional output of I/O data can lead to a reduction in output measurements.

# 3 Configuration for measured data output

### 3.1 CDS user interface



**Note** The figures for the user interface in this chapter are intended as examples only. The actual appearance of the user interface can vary depending on the software version, device and field mode.

Configuration of measured data output is realized in the CDS using the device symbol S3000 or S300 in the *Measured data output* area.

You need to select the correct scanner type in order to be able to access the extended CMS functions of the S3000 Expert/Anti Collision / S300 Expert in CDS. In order to do so, hook up the scanner and use the *Identify* function. If you are creating a new project, the CMS module option must be selected in the device selection wizard for I/O module software package.

# 3.2 Basic settings



Illustration is an example. The available options may differ.

### 3.2.1 Baud rate

The baud rate of the RS-422 interface can be configured via the corresponding menu item (see section 2.3.1 "Transfer and data formats" on page 54 for further information).

### 3.2.2 Individual silent time

The silent time feature serves to free up the interface in send modes *Continuous data output* and *Internal event*. In order to do so, the host computer is able to interrupt data output for the duration of the configured silent time (see section 6.6 "Stopping data output" on page 84 for further information). Access to the interface is subsequently possible. Data output is automatically resumed once the silent time has elapsed. A silent time of 5000 ms is preconfigured ex factory.

### 3.2.3 Send mode

Data output on request: Data is only output when requested (see chapter 5 "Send

mode Data output on request" on page 63).

Continuous data output: Data is output permanently (see chapter 6 "Send mode

Continuous data output" on page 70).

Internal event: Data is only output after an internal event (see chapter 7

"Send mode Internal event" on page 86).

### 3.2.4 Trigger event (only in send mode Internal event)

Reflector: Detection of a reflector triggers data output.

Selected field: Interruption of one the selected fields triggers data output.

### The following deviating options are available in compatibility mode:

Object in the allocated protective field: Interruption of the active protective or warning

field triggers data output.

Object in the simultaneous protective field: S3000: Interruption of the activated

simultaneous protective or warning field


triggers data output.

S300: Function not available.

Reflector detected: Detection of a reflector triggers data output.

## 3.3 Selection of I/O data

Selection of the following options enables the designated I/O data to be output to the host computer. These settings are only possible if send mode *Continuous data output* or *Internal event* are selected.



### 3.3.1 I/O data output

Current monitoring case: The active monitoring case is output.

Static inputs: The status of the static inputs is output.

Velocity: The determined speed of the active incremental encoder is

output.


OSSDs: The active states of the OSSDs are output.

Incremental encoder values: The determined raw data of each individual incremental

encoder is output.

Further information about output data and format can be found in section 6.1.2 "I/O data" on page 71.

# 3.4 Specific measured data output



Here you are able to specify which measured data should be transferred. These settings are only possible if send mode *Continuous data output* or *Internal event* are selected.

#### 3.4.1 Measured data output

Inactivate: No measured data is output.

Distance: Measured data of the spatial contours as well as detected reflectors

are output in accordance with the active measuring ranges (the

reflector bit is contained in bit 13 of the distance value).

Reflector, all: Only positional data for detected reflectors is output. Data is output for

all pulses which hit a reflector.

Reflector center: Only positional data for detected reflectors is output. Neighboring

> positional data from reflectors will be compiled and output as an average value, i.e. if numerous pulses hit a reflector, then the average

pulse angle will be output.

Further information about output data and format can be found in sections 6.1.3 "Measured data (distance)" on page 72 and 6.1.4 "Reflector data" on page 72.

#### 3.4.2 Measuring ranges

Up to 4 measuring ranges can be defined for the S3000 and 5 measuring ranges for the S300. Each measuring range is defined by its start and end angle. Overlapping of the measuring ranges is not possible. These settings are only possible if send mode Continuous data output or Internal event are selected and the Distance option is selected for measured data output.

The option *Type* can be used to make a selection for each active measuring range.

Minimum: Only the lowest measured value is output.

Every value: All measured values will be output.

Every n-th value: Only data for every 2nd to every 15th measured value is output.

S3000: If no measuring range is defined, no measured data will be output. In order to

output all measured data, a measuring range from -5° to 185° must be

configured.

S300: If no measuring range is defined, all measured data will be output.

Note The measured data output always includes the measured values from start angle to end angle pus the measured values up until the next complete angular degree.

Exception: at 185° (S3000) or 225° (S300) there are no measured values in excess of

this figure.

# 3.5 Selection of telegram structure



Here you can specify if I/O data and measured data are transmitted together in a combined telegram, or whether two separate telegrams are transmitted. These settings are only possible if I/O data output is active and send mode *Continuous data output* or *Internal event* are selected.

### 3.5.1 Telegram structure

1 message (I/O + measured data): I/O data and measured data are output in a

combined telegram.

2 messages (1st I/O, 2nd measured data): I/O data and measured data are output

alternately in separate telegrams.

# 4 Communication types

### 4.1 Device addresses

For communication of the devices in remote operation, the communications addresses (device address) for host and guest are required.

The device address is 0x07 for individual scanners.

If two scanners are used in a system, then the addresses are assigned as follows:

Host: 0x07Guest: 0x08

The address is specified in the RK512 telegram header (see section 5.1 "Command telegram" on page 63).

# 4.2 System token

The token serves to manage the various communications portals (RS-232, RS-422, EFI). A device does not permit simultaneous access to various interfaces. This applies to all interfaces for the participating devices in an EFI system. Access can only be realized via one of the individual interfaces. This is ensured by requesting and successfully assigning the token prior to reading or writing data.

If the measured data interface (RS-422) is in continuous data output mode, then communication can be simultaneously transferred via the configuration interface (RS-232) or EFI. The continuous data output is not affected by this.

### **Exception:**

In send modes *Continuous data output* and *Internal Event* it is not possible to directly send a request telegram from the host computer. The host computer must first interrupt continuous data output or send mode *Internal Event* (see section 6.6 "Stopping data output" on page 84).

A serial interface must always address the connected device to obtain the token. It is not possible to access device data without prior assignment of the token. The token is not stored when the system is shut down and must be re-requested when re-started.

You can request the token by sending a send telegram, e.g. for access to an individual scanner (without EFI system) writing the value 0x0F07 to Block 25, via the RS-232 interface.

You can release the token by sending a send telegram to write value 0x0000 to block 25. An example for communication including writing and releasing the token is given in section 5.4.1 "Example for communication in send mode *Data output on request*" on page 67. Detailed information relating to data formats can be found in the appendix in section 12.1.3 "Config master block (block no. 25)" on page 101 for the S3000 and in section

12.2.3 "Config master block (block no. 25)" on page 126 for the S300.

## 4.3 Telegram structure

Communication according to the RK512 standard is based on command and reply telegrams. A command telegram is either a send or fetch telegram. The Send mode *Data output on request* is based on this communications structure: The host computer sends a fetch telegram to the scanner in order to query measured data. The scanner sends the requested data in a reply telegram. Detailed information about the structure of command and reply telegrams can be found in chapter 5 "Send mode *Data output on request*" on page 63.

The data from scanners is also transferred via telegrams in send modes *Continuous data output* and *Internal event*. A request is sent by the host computer (detailed information in chapter 6 "Send mode *Continuous data output*" on page 70). If necessary, continuous data output can be interrupted in order to send command telegrams to the scanner (see section 6.6 "Stopping data output" on page 84).

The high byte (HB) is transferred first for values comprised of 2 bytes in the telegram header. The low byte (LB) is transferred first for data bytes of 16 and 32 bit words.

The value of the size field always designates the number of 16 bit data words. It is not possible to access individual bytes.

# 4.4 Data integrity

As the RK512 standard does not contain a mechanism for checking the integrity of the received data, a mechanism for this purpose is provided by the data in the RK512 telegram. This comprises precise repeating of bytes 5 to 10 in the header of the command telegram in the first six data bytes as well as a CRC value which is formed from the data bytes and which is appended to the telegram. Therefore, the number of data words specified in the size field of the command telegram header must be increased by four words.

The CRC value is comprised of 16 bits and is formed according to the following polynomial  $x^{16} + x^{12} + x^5 + x^0$  (0x1021). This CCITT-CRC is applied in the communication stack wherever a CRC is required to protect the transferred data.

The following is a straightforward sample routine in C for CRC calculation:

```
static const unsigned short crc table[256] = {
0x0000, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
0x1231, 0x0210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
0x2462, 0x3443, 0x0420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
0x3653, 0x2672, 0x1611, 0x0630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
0x48c4, 0x58e5, 0x6886, 0x78a7, 0x0840, 0x1861, 0x2802, 0x3823,
Oxc9cc, Oxd9ed, Oxe98e, Oxf9af, Ox8948, Ox9969, Oxa90a, Oxb92b,
0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0x0a50, 0x3a33, 0x2a12,
Oxdbfd, Oxcbdc, Oxfbbf, Oxeb9e, Ox9b79, Ox8b58, Oxbb3b, Oxab1a,
0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0x0c60, 0x1c41,
0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0x0e70,
0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
0x1080, 0x00a1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
0x02b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
0x34e2, 0x24c3, 0x14a0, 0x0481, 0x7466, 0x6447, 0x5424, 0x4405,
0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
0x26d3, 0x36f2, 0x0691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
0x5844, 0x4865, 0x7806, 0x6827, 0x18c0, 0x08e1, 0x3882, 0x28a3,
Oxcb7d, Oxdb5c, Oxeb3f, Oxfb1e, Ox8bf9, Ox9bd8, Oxabbb, Oxbb9a,
0x4a75, 0x5a54, 0x6a37, 0x7a16, 0x0af1, 0x1ad0, 0x2ab3, 0x3a92,
0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0x0cc1,
0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0x0ed1, 0x1ef0
} ;
WORD CRC16 (BYTE *Data, WORD length)
   WORD CRC 16 = 0xFFFF;
   WORD i;
    for (i = 0; i < length; i++)
        CRC 16 = (CRC 16 << 8) ^ (crc table[(CRC 16 >> 8) ^
(Data[i])]);
    }
    return CRC 16;
}
```

# Send mode Data output on request

In send mode *Data output on request*, the measured data are requested by the host computer (e.g. block 12: Scan data). Send and fetch telegrams are used.

For send telegrams, the host computer sends the data to be transferred after the telegram header, the receiver answers with a reply telegram, which consists of a header only, without any additional data. For fetch telegrams, the host computer sends the header of a fetch telegram only, without additional data, the sensor answers with a reply telegram which contains the requested data after the telegram header.

The host computer is always the active node, even in an EFI system. The sensors themselves do not send RK512 telegrams. This means that there is no risk of possible initialization conflicts in the event of simultaneous communications.

# 5.1 Command telegram

The telegram head of the command telegram is comprised of 10 bytes, which have the following meaning:

Byte	Telegram fields	Contents	Meaning
1	Telegram identifier	0x00	
2		0x00	
3	Command telegram type	'A' (0x41) or	Send telegram or
		'E (0x45)	Fetch telegram
4	Command data type	'D' (0x44)	Access to data sheet
5	Destination address/	0 to 255	Block number
	Source address	(0x00 to 0xFF)	
6		0 to 255	Block index
		(0x00 to 0xFF)	
7	Size	0 to 65535	Block size in data words
8			
9	Coordination flag	OxFF	
10	Device address	0x07 or	Host
		0x08	Guest

Table: Command telegram structure

# 5.2 Reply telegram

The telegram header of the reply telegram (reaction telegram) is comprised of 4 bytes, which have the following meaning:

Byte	Telegram fields	Contents	Meaning
1	Telegram identifier	0x00 (always)	
2		0x00 (always)	
3	Reply telegram type	0x00 (always)	Reply telegram
4	Reply error number	0x00	No error
		0x01 to 0xFF	See error table for error codes

Table: Reply telegram structure

### 5.2.1 Reply telegram error codes

The reply telegram is the reply to a send or fetch telegram given by the S3000/S300. If the S3000/S300 detects a fault, it displays this by way of an error code in the reply telegram and no data will be sent after the reply telegram header.


ications error in accordance with the RK512 protocol
ent status of the device allows no write access to the data
o data block not allowed for the current user group.
sword is incorrect.
em token is occupied.
ter not correct.
et address block index or source address in the command (byte 6) is impermissible (not defined in register interface).
ce is busy due to internal processes. Repeat the process for o the data block.
device fault.
o data block not supported in current device mode.
he communication monitors has failed (among other things of EFI RK512 packets / EFI RK512 acknowledge or faulty of EFI RK512 packets / EFI RK512 acknowledge).
rdination flag (byte Number) in command telegram (byte 9) is al OxFF.
ce address in command telegram (byte 10, bit 0 to 3) is .e. equals 0).
number in command telegram (byte 10, bit 5 to 7) is ssible.
gram identifier in command telegram (byte 1) is not equal
OxFF or is not followed by an additional byte 0x00 (byte 2).
mand data type in command telegram (byte 4) is
ssible.
a block number of the destination address or source address nand telegram (byte 5) is impermissible (not defined in interface).
nmand telegram type in command telegram (byte 3) is ssible.
n format error. causes: length specified in the command telegram size field gth (byte 7 and 8) exceeds the available space in the a block for the specified address. length of send telegram data was greater than the gth specified in the size field. length of send telegram data was less than the gth specified in the size field. tch telegram was received with user data. send telegram was correctly received, but the CRC te of the data is incorrect or the first six data bytes do
t

Table: Reply telegram error codes

Error code in reply telegram	Communications error in accordance with the RK512 protocol
0x36	A command telegram was received although no reply telegram was
	sent for the previous command telegram.

### 5.3 Standard communication

### 5.3.1 Example for a send telegram "Write token in block 25"




Telegram ID

### **S3000** reply:

00 00 00 00


### 5.3.2 Example for a fetch telegram "Read operating data block 11"

# Host computer send:



### S3000 reply

00 00 00 00 <mark>0B 00 00 56 FF 07</mark> 08 38 FD FD 00 02 00 55 00 00 00 00 00 08 7D 00 C0 02 00 00 35 01 00 00 52 00 61 04 00 00 9F 02 39 02 18 02 6A 00 0C 00 02 00 32 02 1B 00 1A 00 0A 00 49 02 02 00 28 00 14 00 23 02 01 00 04 00 0F 00 00 02 20 00 06 00 04 00 2A 02 1F 00 21 00 05 00 31 02 09 00 17 00 10 00 02 00 19 00 94 00 00 00 00 00 00 00 0A 00 0E 49 87 47 F6 4A 18 44 65 4E A7 00 9C 14 31 02 64 00 5A 00 A5 02 DE 02 07 01 69 01 6D 02 E8 02 A3 13 C3 00 F1 00 07 01 53 01 A6 01 34 02 03 03 3D 04 54 06 05 0A 98 00 C7 08 AC 08 <mark>2D 2C</mark>



#### 5.4 Requesting data in send mode Data output on request

The S3000 and S300 support measured data blocks of static lengths (block 12, for S3000 also block 52), whereas the S3000 optionally supports flexible measured data block lengths (block 112, block 114).

For the S3000 with sensor head firmware ≥ B02.40 it is possible to request block 58 (for 0.5° scan resolution) or block 59 (for 0.25° scan resolution), once the resolution is configured. These blocks have a fixed length.

For the S300 with firmware ≥ 2.10 it is possible to request block 58 with static length.

Example 1: Only one S3000 is in use and measured data should be received.

- 1. Power on
- 2. Get token (send telegram with device address 0x07)
- Read scan data record 1 (fetch telegram with device address 0x07)
- Read scan data record 2 (fetch telegram with device address 0x07)
- Read scan data record n (fetch telegram with device address 0x07) 5.
- Release token (send telegram with device address 0x07)

Example 2: There is an EFI system comprised of two S3000s and the system should alternately receive measured data from both scanners. There must be 2 separate RS-422 connections available.

- 1. Power on
- Get token S3000 (host) (send telegram with device address 0x07)
- Read scan data record from \$3000 (host) (fetch telegram with device address 0x07)
- Release token S3000 (host) (send telegram with device address 0x07)
- Get token S3000 (guest) (send telegram with device address 0x08)
- 6. Read scan data record from \$3000 (guest) (fetch telegram with device address 0x08)
- Release token S3000 (guest) (send telegram with device address 0x08)

© SICK AG • Industrial Safety Systems • Germany • All rights reserved

### 5.4.1 Example for communication in send mode Data output on request

### **Get token**

Host computer send: 00 00 41 44 19 00 00 05 FF 07 19 00 00 05 FF 07 07 0F 9F D0

S3000 reply: 00 00 00 00

### Read scan data (block 12)

Host computer send: 00 00 45 44 0C 00 02 FE FF 07

S3000 reply: 00 00 00 00 <mark>0C 00 02 FE FF 07</mark> 00 08 3B 00 3D 00 ... 00 00 FE E9

### Read reflector data (block 52)

Host computer send: 00 00 45 44 34 00 01 04 FF 07

S3000 reply: 00 00 00 00 <mark>34 00 01 04 FF 07</mark> 02 00 00 00 34 01 ... 00 00 DE EA

### Read extended scan data (block 112)

Host computer send: 00 00 45 44 70 00 03 02 FF 07

S3000 reply: 00 00 00 00 <mark>70 00 03 02 FF 07</mark> 01 00 00 00 14 4B ... 29 00 26 8B

### Read extended reflector data (block 114)

Host computer send: 00 00 45 44 72 00 01 04 FF 07

S3000 reply: 00 00 00 00 <mark>72 00 00 18 FF 07</mark> 01 00 00 00 35 01 ... E8 23 F4 D1

### Read scan data 05 block (block 58)

Host computer send: 00 00 45 44 3A 00 01 8F FF 07

S3000 reply: 00 00 00 00 <mark>70 00 03 02 FF 07 01 00 00 00 07 00 ... 00 00 E1 C3</mark>

### Read scan data 025 block (block 59)

Host computer send: 00 00 45 44 3B 00 03 0B FF 07

S3000 reply: 00 00 00 00 <mark>3B 00 03 0B FF 07</mark> 01 00 00 00 07 00 ... 00 00 <mark>C5 12</mark>

### Release token

Host computer send: 00 00 41 44 19 00 00 05 FF 07 19 00 00 05 FF 07 00 00 E7 B8

S3000 reply: 00 00 00 00

# 5.5 Flexible telegram (S3000 only)

For some host computers, it is necessary to keep the interrupt load for the UART as low as possible. In such cases (in send mode *Data output on request*) it is possible to use a data block with flexible length in the reply telegram (block 112 instead of block 12 and block 114 instead of block 52).

### 5.5.1 Example: Output reflector block 52 / block 114

Assumption: the S3000 detects 8 reflectors at 10 meters distance each on pulses 1, 2, 3, 6, 7, 9, 10, 761.

If block 52 is requested by the host computer, the reply telegram will be composed as follows:

### S3000 reply for block 52

If block 114 is requested by the host computer, the reply telegram will be composed as follows:

### \$3000 reply for block 114

00 00 00 00 <mark>72 00 00 18 FF 07</mark> 01 00 00 00 35 01 00 00 02 00 E8 23 04 00 E8 23 06 00 E8 23 0C 00 E8 23 0E 00 E8 23 12 00 E8 23 14 00 E8 23 F2 05 E8 23 F4 D1

Block 114 only contains the relevant user data, whereas in block 52 there is always 256 data words output. If reflectors are only detected in 8 measured values, then block 52 contains 236 data words without information.

A data block with flexible length is requested by the host computer always with the maximum specified block length (+ 3 word telegram header repeat + 1 word CRC).

The reply telegram from the S3000 transfers the actual block length in the telegram header (+ 3 word telegram header repeat + 1 word CRC) to the host computer.

**Note** Blocks 112 and 114 are only available from a directly connected (local) scanner. The output of blocks from a second scanner, connected to a local scanner via EFI, is not possible.

69

# 6 Send mode Continuous data output

In order to create efficient telegram traffic, the S3000 and S300 can be configured in the CDS so that the measured values and certain additional information is permanently sent to the RS-422 interface. Continuous data output is not influenced by the telegram traffic via the other available interfaces. It is not necessary for continuous data output that the token is reserved for the RS-422 interface (in send mode *Data output on request*, only one interface at a time can own the token, see section 4.2 "System token" on page 60).

The measured data is output automatically in continuous data output mode, so that the telegrams only need to be read.

In send modes *Continuous data output* and *Internal Event* it is not possible to directly send a request telegram from the host computer. The host computer must first interrupt continuous data output or send mode *Internal Event* (see section 6.6 "Stopping data output" on page 84).


The data in the telegram's data block is configurable.

The following output options are available:

- Measured data from 4 configurable angular ranges for S3000 and 5 angular ranges for S300
- Minimum measured data per angular range
- All reflector pulses or only reflector centers
- Alternating output measured data / reflector data and I/O data

### Example: telegram structure for continuous data output

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 17 01 00 00 02 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 <mark>10 07</mark>



Dependent on the configuration, the Configurable contour and measurement block can have a dynamic length, which can vary from telegram to telegram.

Likewise depending on configuration, the Configurable contour and measurement block can also output alternating I/O data and measured data (see section 3.5.1 "Telegram structure" on page 59).

Note In send mode *Continuous data output* the RS 422 interface can only output data from directly connected (local) scanners. The output of data from a second scanner, connected to a local scanner via EFI, is not possible.

## 6.1 Structure of continuous data output

### 6.1.1 Telegram header, administration data, general data

Data output always begins as follows:

00 00 00 00 4 Byte RK512 telegram header: Reply telegram

Data block number 0x0000 for continuous data output or data output after trigger event

xx xx Size of telegram in 16-bit data words

### **S3000**

The telegram size is calculated based on the data after the telegram header (starting with the first byte of the administration data, 5. byte of the telegram) up to and including the last byte of the telegram (incl. CRC). The length field thus shows the value: (total telegram length in bytes -4)/2

### \$300: If I/O data and measuring ranges are not configured

The telegram size is calculated based on the data after the length field (starting with the 5. byte of the administration data, 9. byte of the telegram) up to and including the last byte of the telegram (incl. CRC). The length field thus shows the value: (total telegram length in bytes – 8)/2

### \$300: If I/O data or at least one measuring range is configured

The telegram size is calculated based on the data after the protocol version within in the user data (starting with the 3. byte of the user data, 13. byte of the telegram) ) up to and including the last byte of the user data (last byte bevore the CRC). The length field thus shows the value:

(total telegram length in bytes - 14)/2

### S300: In compatibility mode

The telegram size is calculated based on the data after the telegram header (starting with the first byte of the administration data, 5. byte of the telegram) up to and including the last byte of the telegram (incl. CRC). The length field thus shows the value: (total telegram length in bytes -4)/2

FF 07 Coordination flag and device address, here 0x07 (host or standalone device)

03 01 Protocol version number: 0x0103

**Deviation in compatibility mode: 02 01** Protocol version number: 0x0102

See section 6.2 "Protocol version number" on page 74 for detailed information.

00 00 or 01 00 Status normal 0x0000 or lockout 0x0001

17 01 00 00 Scan number (time stamp), here 0x00000117 (see section 8.1, page 87)

02 00 Telegram number, here 0x0002

### 6.1.2 I/O data

The following block with code AAAA is output, if I/O data output is configured. If non-alternating output has been configured, then this is output in every telegram. If alternating output has been configured, then this is only output for every **odd** numbered telegram.

# AA AA ID for I/O data

- xx xx monitoring case data (only if configured)
- xx xx static input data (only if configured)
- xx xx speed data (only if configured)
- xx xx output parameter data (only if configured)
- xx xx raw speed data: Data1 (only if configured)
- xx xx raw speed data: Data2 (only if configured)

Detailed information about data formats can be found under section 6.3 "I/O data format" on page 74.

### 6.1.3 Measured data (distance)

The following block with code BBBB is output, if measured data output (distance) is configured. If non-alternating output has been configured, then this is output in every telegram. If alternating output has been configured, then this is only output for every **even** numbered telegram.

Only one of the two blocks BBBB or CCCC can be output. Which of these two blocks is output depends on the configuration in CDS.

### **BB BB** ID for measured data

- **11 11** ID for measured data from measuring range 1
  - xx xx Measured values from measuring range 1
- 22 22 ID for measured data from measuring range 2
  - xx xx Measured values from measuring range 2
- 33 33 ID for measured data from measuring range 3
  - xx xx Measured values from measuring range 3
- 44 44 ID for measured data from measuring range 4
  - xx xx Measured values from measuring range 4
- 55 55 ID for measured data from measuring range 5 (S300 only)
  - xx xx Measured values from measuring range 5 (S300 only)

Detailed information about data formats can be found under section 6.4 "Measured and reflector data formats" on page 76.

### 6.1.4 Reflector data

© SICK AG • Industrial Safety Systems • Germany • All rights reserved

The following block with code CCCC is output, if measured data output (reflector) is configured. If non-alternating output has been configured, then this is output in every telegram. If alternating output has been configured, then this is only output for every **even** numbered telegram.

Only one of the two blocks BBBB or CCCC can be output. Which of these two blocks is output depends on the configuration in CDS.

# CC CC ID for reflector data xx xx Number of detected reflectors xx xx Reflectors (all or only centers, depending on configuration)

Detailed information about data formats can be found under section 6.4 "Measured and reflector data formats" on page 76.

### 6.1.5 CRC

Subsequently the CRC value is output:



### 16 Bit CRC

The CRC value is calculated based on the data after the telegram header (starting with the first byte of the administration data, 5. byte of the telegram) up to and including the last byte of the user data block (last byte before the CRC value).

# 6.2 Protocol version number

S3000/S300: 0x0103

In compatibility mode: S3000/S300: 0x0102

The protocol version number should be checked by the host computer. It is dependent on the firmware version on the sensor used and on whether compatibility mode is activated.

For other version numbers, the structure of continuous data output can vary.

# 6.3 I/O data format

### 6.3.1 Monitoring case data

### **S3000**

- 00 02 Monitoring case/standby
  Reference: Appendix, section 12.1.5/12.1.6, block 58/59 Scan data, register processing, word 0
- O4 00 Field evaluation A (field number, field type, multiple sampling)
  Reference: Appendix, section 12.1.5/12.1.6, block 58/59 scan data, register field evaluation A, word 10
- O6 41 Field evaluation B (field number, field type, multiple sampling)
  Reference: Appendix, section 12.1.5/12.1.6, block 58/59 scan data, register field evaluation B, word 11
- O8 02 Field evaluation C (field number, field type, multiple sampling)
  Reference: Appendix, section 12.1.5/12.1.6, block 58/59 scan data, register field evaluation C, word 12
- OA 43 Field evaluation D (field number, field type, multiple sampling)
  Reference: Appendix, section 12.1.5/12.1.6, block 58/59 scan data, register field evaluation D, word 13

### In compatibility mode the monitoring case data is comprised of:

OB 02 Monitoring case/standby/field set A/field set A active/field set B/field set B active.

Reference: Appendix, section 12.1.1, block 11 operating data, register monitoring data, word 6

### **S300**

The monitoring case data is identical for S300 as well as S3000. However, as there are no simultaneous protective fields for the S300, the monitoring case data for field 3 evaluation data (simultaneous protective fields) are set to default values. The data fields ControlAreaB, ControlAreaBActive and ControlAreaAActive are not used, these bits are always 0.

- OO O2 Monitoring case/standby, here 0x02/0x00

  Reference: Appendix, section 12.2.4, block 58 scan data, register processing, word 0
- O4 00 Field evaluation A (field number, field type, multiple sampling) Reference: Appendix, section 12.2.4, block 58 scan data, register field evaluation A, word 10

O6 41 Field evaluation B (field number, field type, multiple sampling)
Reference: Appendix, section 12.2.4, block 58 scan data,
register field evaluation B, word 11

CO 01 Field evaluation C is set to 0x1CO, as the third field in S300 is always deactivated.

Reference: Appendix, section 12.2.4, block 58 scan data, register field evaluation C, word 12

O8 12 Field evaluation D (field number, field type, multiple sampling) Reference: Appendix, section 12.2.4, block 58 scan data, register field evaluation D, word 13

### In compatibility mode the monitoring case data is comprised of:

03 82 Monitoring case/standby Reference: Appendix, section 12.2.4, block 58 scan data, register processing, word 0

### 6.3.2 Static input data

xx xx Static input data: non-safe inputs/safety capable inputs Reference: Appendix, section 12.1.1 (S3000)/12.2.1 (S300), block 11 operating data, register input data, word 3

### 6.3.3 Speed data

X XX Speed data: measured speed
Reference: Appendix, section 12.1.1 (S3000)/12.2.1 (S300), block 11
operating data, register input data, word 4

# 6.3.4 Output parameter data

Output parameter data: OSSD status, warning output, etc., Reference: Appendix, section 12.1.1 (S3000)/12.2.1 (S300), block 11 operating data, register output states, word 5

### 6.3.5 Raw speeds 1/2

### S3000

Raw speed data 1/2: raw speed of incremental encoders 1 and 2 in pulses per 12.52 ms (2 pulses per increment, i.e. per revolution of the incremental encoder). This value is signed (two's complement): positive values represent a forward movement and negative values represent reverse movement. This value is generated by the speed encoder evaluation circuitry in the S3000.

# **S300**

Raw speed data 1/2: raw speed of incremental encoders 1 and 2 in cm/s).

This value is signed (two's complement): positive values represent a forward movement and negative values represent reverse movement.

# 6.4 Measured and reflector data formats

An explanation of the designations used in the fields can be found in section 8.3 "Designation of protective, warning and collision protection fields" on page 88.

# 6.4.1 Data format of measured data for \$3000 (2 Byte)

Bit 15 13	Bit 12 0
Status bits	Measured
Bit 15: Interruption of field C or D detected (if the field is activated as a protective field/collision protection field)	distance in centimeters
Bit 14: Interruption of field A or B detected (if the field is activated as a protective field/collision protection field)	
Bit 13: CMS models: Reflector detected	
Non-CMS models: Scanner dazzled	
Deviations from this applicable to compatibility mode:	
Bit 15: Measured value detected within simultaneous protective field	
Bit 14: Measured value detected within protective field	

# 6.4.2 Data format of measured data for \$300 (2 Byte)

Bit 15 13	Bit 12 0
Status bits	Measured
Bit 15: Firmware < 2.10: Measured value detected within warning field	distance in centimeters
Firmware ≥ 2.10: 0 (fixed bit value)	
Bit 14: Measured value detected within protective field	
Bit 13: CMS models: Reflector detected	
Non-CMS models: Scanner dazzled	

# 6.4.3 Data format of measured data for configuration "Minimum distance per measuring range" for \$3000 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status bits	Measured	Angle from 0° to 190°
Bit 31: Interruption of field C or D detected (if the field is activated as a protective field/collision protection field)	distance in centimeters	(given in 0.01°)
Bit 30: Interruption of field A or B detected (if the field is activated as a protective field/collision protection field)		
Bit 29: CMS models: Reflector detected		
Non-CMS models: Scanner dazzled		
Deviations from this applicable to compatibility mode:		
Bit 31: Measured value detected within simultaneous protective field		
Bit 30: Measured value detected within protective field		

# 6.4.4 Data format of measured data for configuration "Minimum distance per measuring range" for \$300 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status bits	Measured	Angle from 0° to 270°
Bit 31: Firmware < 2.10: Measured value detected within warning field	distance in centimeters	(given in 0.01°)
Firmware ≥ 2.10: 0 (fixed bit value)		
Bit 30: Measured value detected within protective field		
Bit 29: Reflector detected		

### 6.4.5 Reflector data format for \$3000 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status bits	Measured	Angle from 0° to 190°
Bit 31: Interruption of field C or D detected (if the field is activated as a protective field/collision protection field)	distance in centimeters	(given in 0.01°)
Bit 30: Interruption of field A or B detected (if the field is activated as a protective field/collision protection field)		
Bit 29: CMS models: Reflector detected		
Non-CMS models: Scanner dazzled		
Deviations from this applicable to compatibility mode:		
Bit 31: Measured value detected within simultaneous protective field		
Bit 30: Measured value detected within protective field		

# 6.4.6 Reflector data format for \$300 (4 Byte)

Bit 31 29	Bit 28 16	Bit 15 0
Status bits	Measured	Angle from 0° to 270°
Bit 31: Firmware < 2.10: Measured value detected within warning field	distance in centimeters	(given in 0.01°)
Firmware ≥ 2.10: 0 (fixed bit value)		
Bit 30: Measured value detected within protective field		
Bit 29: Reflector detected		

# 6.5 Example for continuous data output with S3000

# 6.5.1 Configuration 1: measured data

Output of all measured values from the four ranges  $0^{\circ}$  to  $1^{\circ}$ ,  $32^{\circ}$  to  $33^{\circ}$ ,  $128^{\circ}$  to  $129^{\circ}$  and  $189^{\circ}$  to  $190^{\circ}$ , no output of I/O data (for this reason, output in one telegram/non-alternating), continuous data output,  $0.25^{\circ}$  angular resolution ( $120^{\circ}$  ms basic response time)

### Reception of 3 measured data records

...

00 00 00 00 <mark>00 00 00 2B FF 07</mark> 03 01 00 00 17 01 00 00 00 00 BB BB 11 11 E8 23 E8 23 E8 23 E8 03 E8 03 E8 23 E8 23 E8 03 E8 0

00 00 00 00 <mark>00 00 00 2B FF 07</mark> 03 01 00 00 18 01 00 00 01 00 BB BB 11 11 E8 23 E8 23 E8 23 E8 03 E8 03 E8 23 E8 23 E8 03 22 22 E8 03 33 33 E8 03 44 44 E8 03 E8 03 E8 03 E8 03 E8 23 <mark>DB 8E</mark>

00 00 00 00 <mark>00 00 00 2B FF 07</mark> 03 01 00 00 19 01 00 00 02 00 BB BB 11 11 E8 23 E8 23 E8 23 E8 03 E8 03 E8 23 E8 23 E8 03 22 22 E8 03 33 33 E8 03 44 44 E8 03 E8 03 E8 03 E8 03 E8 23 <mark>3DE1</mark>

### Explanation of the first measured data record

00 00 00 00 4 Byte RK512 tTelegram header: Reply telegram

00 00 Data block number 0x0000 for continuous data output or data output after trigger event

00 2B Size of telegram in 16-bit data words: 43 data words

FF 07 Coordination flag and device address, here 0x07 (host or standalone device)

03 01 Protocol version number: 01.03

00 00 Status: normal

17 01 00 00 Scan number (time stamp): in this case 0x00000117 = 279

00 00 Telegram number: 0

BB BB ID for measured data

ID for measured data from measuring range 1 (set in CDS, in this case: 0° to 1°)

E8 23 Measured value 1 in current measuring range (in this case: at 0°): 0x23E8, in bit notation: 0010 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 1: reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

(512 cm + 256 cm + 128 cm + 64 cm + 32 cm + 8 cm = 1000 cm)

E8 23 Measured value 2 in current measuring range (in this case: at 0.25°): 0x23E8, in bit notation: 0010 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 1: reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 23 Measured value 3 in current measuring range (in this case: at 0.5°): 0x23E8, in bit notation: 0010 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 1: reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 03 Measured value 4 in current measuring range (in this case: at 0.75°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 03 Measured value 5 in current measuring range (in this case: at 1°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 23 Measured value 6 in current measuring range (in this case: at 1.25°): 0x23E8, in bit notation: 0010 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 1: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 23 Measured value 7 in current measuring range (in this case: at 1.5°): 0x03E8, in bit notation: 0010 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 1: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 03 Measured value 8 in current measuring range (in this case: at 1.75°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

<mark>22 22</mark> ID for measured data in measuring range 2 (set in CDS, here: 32° to 33°)

E8 03 Measured value 1 in current measuring range (in this case: at 32°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

...

- 33 33 ID for measured data in measuring range 3 (set in CDS, here: 128° to 129°)
- E8 03 Measured value 1 in current measuring range (in this case: at 128°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

...

- 44~44 ID for measured data in measuring range 4 (set in CDS, here:  $189\degree$  to  $190\degree$ )
- E8 03 Measured value 1 in current measuring range (in this case: at 189°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

- E8 03 Measured value 2 in current measuring range (in this case: at 189.25°): 0x03E8, in bit notation: 0000 0011 1110 1000
  - Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 03 Measured value 3 in current measuring range (in this case: at 189.5°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 03 Measured value 4 in current measuring range (in this case: at 189.75°): 0x03E8, in bit notation: 0000 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 0: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

E8 23 Measured value 5 in current measuring range (in this case: at 190°): 0x23E8, in bit notation: 0010 0011 1110 1000

Bit 15: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 14: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 13: 1: no reflector detected

Bits 12 ... 0: distance in cm: 0x03E8 = 1000 [cm]

9C F4 16 Bit CRC

### 6.5.2 Configuration 2: reflector data

Output of all reflectors, no output of I/O data (therefore output in one telegram/non-alternating), continuous data output,  $0.25\,^{\circ}$  angular resolution (120 ms basic response time)

### Reception of 3 measured data records

...

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 17 01 00 00 00 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 07 DE

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 18 01 00 00 01 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 <mark>B9 1C</mark>

00 00 00 00 <mark>00 00 00 1B FF 07</mark> 03 01 00 00 19 01 00 00 02 00 CC CC 08 00 00 00 E8 23 19 00 E8 23 32 00 E8 23 7D 00 E8 23 96 00 E8 23 C8 00 E8 23 E1 00 E8 23 38 4A E8 23 E6 E7

•••

Note

The reflector data first outputs the number of detected reflectors, as this is not determined by the configuration.

### Explanation of the first measured data record

00 00 00 00 4 Byte RK512 telegram header: Reply telegram

Data block number 0x0000 for continuous data output or data output after trigger event

00 1B Size of telegram in 16 bit data words

FF 07 Coordination flag and device address, here 0x07 (host or standalone device)

03 01 Protocol version number: 01.03

00 00 Status: normal

17 01 00 00 Scan number (time stamp): here 0x00000117

00 00 Telegram number: 0

CC CC ID for reflector data

08 00 Number of detected reflectors: here 0x0008 = 8

00 00 E8 23 Reflector 1: 0x23E80000

Bit 31: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

(512 cm + 256 cm + 128 cm + 64 cm + 32 cm + 8 cm = 1000 cm)

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x0000 = 0 (=> 0^{\circ})$ 

(corresponds to -5° in S3000 coordinates system)

#### 19 00 E8 23 Reflector 2: 0x23E80019

in bit notation: 0010 0011 1110 1000 0000 0000 0001 1001

Bit 31: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x0019 = 25 (=> 0.25^{\circ})$ 

(corresponds to -4.75° in S3000 coordinates system)

#### 32 00 E8 23 Reflector 3: 0x23E80032

in bit notation: 0010 0011 1110 1000 0000 0000 0011 0010

Bit 31: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x0032 = 50 (=> 0.5^{\circ})$ 

(corresponds to -4.5° in S3000 coordinates system)

#### 7D 00 E8 23 Reflector 4: 0x23E8007D

in bit notation: 0010 0011 1110 1000 0000 0000 0111 1101

Bit 31: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in 0.01°: 0x007D = 125 (=> 1.25°)

(corresponds to -3.75° in S3000 coordinates system)

#### 96 00 E8 23 Reflector 5: 0x23E80096

in bit notation: 0010 0011 1110 1000 0000 0000 1001 0110

Bit 31: 0: no interruption of field C and D (if activated as protective field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated as protective field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x0096 = 150 (=> 1.5^{\circ})$ 

(corresponds to -3.5° in S3000 coordinates system)

#### C8 00 E8 23 Reflector 5: 0x23E800C8

in bit notation: 0010 0011 1110 1000 0000 0000 1100 1000

Bit 31: 0: no interruption of field C and D (if activated as protective  $\,$ 

field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated as protective

field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x00008 = 200 (=> 2.0^{\circ})$ 

(corresponds to -3° in S3000 coordinates system)

### E1 00 E8 23 Reflector 5: 0x23E800E1

in bit notation: 0010 0011 1110 1000 0000 0000 1110 0001

Bit 31: 0: no interruption of field C and D (if activated as protective

field/collision protection field)

Bit 30: 0:no interruption of field A and B (if activated as protective

field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x00E1 = 225 (=> 2.25^{\circ})$ 

(corresponds to -2.75° in S3000 coordinates system)

### 38 4A E8 23 Reflector 5: 0x23E84A38

in bit notation: 0010 0011 1110 1000 0100 1010 0011 1000

Bit 31: 0: no interruption of field C and D (if activated as protective

field/collision protection field)

Bit 30: 0: no interruption of field A and B (if activated s protective

field/collision protection field)

Bit 29: 1: reflector detected

Bits 28 ... 16: distance in cm: 0x03E8 = 1000 [cm]

Bits 15 ... 0: angle in  $0.01^{\circ}$ :  $0x4A38 = 19000 (=> 190.0^{\circ})$ 

(corresponds to 185° in S3000 coordinates system)

07 DE 16 Bit CRC

# 6.6 Stopping data output

In send modes *Continuous data output* and *Internal event* it is not possible to directly send a request telegram from the host computer.

The host computer must first interrupt continuous data output or send mode *Internal* event. This is realized by sending code 0x41. Now the host computer can communicate in the same way as in *Data output on request* mode, as long as the configurable silent time has not elapsed. Subsequently the measured data output is automatically resumed.

This code must also be sent in *Internal* event send mode if no internal event is currently pending, in other words, if no data is being output.

**Note** Continuous data output is only undertaken in *Normal* and *Lockout system status*. In all other system states, the continuous data output (or send mode *Internal event*) is automatically deactivated.

# 6.7 Fixed configured modes for continuous data output

The CDS initially configures the measured data output so that it is fixed.

This configuration is retained permanently by the device until such time as a new configuration is transferred to the device.

Each switching-on operation causes this configuration to be loaded from the system plug memory.

# 6.8 Online reconfigurable modes for continuous data output

There is the option to change parameters during active operations for certain measuring data configuration settings.

These settings are however volatile and are overwritten by the originally configured settings when switching on.

General information about the telegram formats for the command telegrams used can be found in section 5.1 "Command telegram" on page 63.

### 6.8.1 Block 103

Here it is possible to switch over to reflector or measured data output in online mode. Details about block 103 can be found in the Appendix on page 104 and page 132.

### **Example**

Host computer send: 00 00 41 44 67 00 00 05 FF 07 67 00 00 05 FF 07 00 00 FA 96 S3000 reply: 00 00 00 00

### 6.8.2 Block 104

Here it is possible to reconfigure 4 angular ranges for S3000 or 5 angular ranges for S300, whereby all ranges will be restarted at once (see example Block 103).

Details about block 104 can be found in the Appendix on page 115 and page 133.

### 6.8.3 Block 105

Here it is possible to redetermine the Output trigger conditions (see example Block 103). Details about block 105 can be found in the Appendix on page 116 and page 134.

# 7 Send mode Internal event

In *Internal event* send mode, data output is only undertaken when a trigger event occurs. The trigger events are configured in CDS (see section 3.2.4 "Trigger event (only in send mode *Internal event*)" on page 56). Data output is undertaken for as long as the trigger event defined in CDS is pending. This ends automatically as soon as the trigger event is no longer current.

The output data and the data formats are identical to those of continuous data output mode.

# 7.1 Stopping data output

© SICK AG • Industrial Safety Systems • Germany • All rights reserved

In send modes *Continuous data output* and *Internal event* it is not possible to directly send a request telegram from the host computer.

The host computer must first interrupt continuous data output or send mode *Internal* event. This is realized by sending code 0x41. Now the host computer can communicate in the same was as in *Data output on request* mode, as long as the configurable silent time has not elapsed. Subsequently the measured data output is automatically resumed.

This code must also be sent in *Internal* event send mode if no internal event is currently pending, in other words, if no data is being output.

**Note** Continuous data output is only undertaken in *Normal* and *Lockout system status*. In all other system states, the continuous data output (or send mode *Internal event*) is automatically deactivated.

# S Further information about measured data

# 8.1 Additional time stamps and telegram numbers

For moving vehicles, assignment of measured value records or reflector data records with a timestamp is necessary for the host computer in order that the measured value record can be evaluated with the right position and the right orientation of the vehicle. For this reason, in the sensor a global counter (32 bit) is realized, which is output with blocks 52, 112 and 114 in send modes *Data output on request* (only S3000) and *Continuous data output*. This counter is internally incremented on each scan, in other words, every 40 ms (for S300) and depending on mode, every 30 ms or 60 ms (for S3000).

In addition, these blocks contain a unique telegram number, which is only incremented when the blocks are output.

# 8.2 Functional dependence on device type used

The functionality of the measured value output is dependent on the device type used:

	Functionality	S3000 Expert/Anti Collision	S300 Expert
Send mode Block 11		Yes	Yes
Data output on Operating Data			
request	Block 25	Yes	
	Config Master Block (Token)		
	Block 12	Yes	Yes
	Scan Data		
	(measured values)		
	Block 112	Yes	No
	Extended Scan Data		
	(measured values)		
	Block 52	Yes	No
	Reflector Detection		
	(reflector data)		
	Block 114	Yes	No
	Extended Reflector Detection		
	(reflector data)		
Block 58		Yes, if scan resolution 0.5°	Yes, if firmware ≥
Scan Data 05		and sensor head firmware	2.10
(measured values,		≥ B02.40	
	resolution 0.5°)		
	Block 59	Yes, if scan resolution	No
	Scan Data 025 (measured	0.25° and sensor head	
	values, resolution 0.25°)	firmware ≥ B02.40	
Send mode	I/O data	Yes	Yes
Continuous	Measured values	Yes	Yes
data output or Reflector data		Yes	Yes
Internal event	Block 103	Yes	Yes
	Online Measurement Config		
	(online switchover to		
	measured values or reflector		
	data)		

Functionality	S3000 Expert/Anti Collision	S300 Expert
Block 104 Online Output Range Config (online configuration measuring ranges)	Yes	Yes
Block 105 Online Output Trigger (online configuration trigger event)	Yes	Yes

# 8.3 Designation of protective, warning and collision protection fields

The protective, warning and collision protection fields are coded with letters A to D in the explanations to the telegrams. The assignment of these letters for protective, warning and collision protection fields is explained in the following table:

Field	S3000 Expert	S3000 Expert	S3000 Expert	S3000 Anti Collision	S3000 Anti Collision	S300 Expert
	Dual Field mode	Triple Field mode	Four simultaneous	Dual (collision	Triple (collision	
			protective fields	protection)	protection)	
Α	Protective field	Protective field	Protective field 1	Protective field	Protective field	Protective field
В	Warning field	Warning field 1	Protective field 2	Collision protection	Collision protection	Warning field 1
				field	field 1	
С	Simultaneous	-	Simultaneous	Simultaneous	-	-
	protective field		protective field 1	protective field		
D	Simultaneous	Warning field 2	Simultaneous	Simultaneous	Collision protection	Warning field 2
	warning field		protective field 2	collision protection	field 2	
				field		

# In compatibility mode:

Field	\$3000	S300
Α	Protective field	Protective field
В	Warning field	Warning field
С	Simultaneous protective field	_
D	Simultaneous warning field	_

# 9 Reflector mark detection


# 9.1 Reflector marks

The use of Cube 3000x is recommended for reflector mark detection.


The reflector marks can be implemented as reflector strips (reflector plates) or cylindrical reflectors. Reflector strips are attached to fixed surfaces, e.g. walls or systems. Cylindrical reflectors are used in situations where the reflector marks must be detected from more than one side. They must be fully visible from the course at all times.

The height and vertical alignment of the reflectors is to be selected such that the measuring beam hits the reflectors even if the floor is uneven. A detectable reflector height of at least 500 mm is recommended.

The scanning range of the S3000 amounts to max. 49 meters. This gives the minimum size of the reflectors at a recommended measuring resolution of  $0.25^{\circ}$ :



The scanning range of the S300 amounts to max. 30 meters. This gives the minimum size of the reflectors at a recommended measuring resolution of 0.5°:




# 9.2 Restrictions


Highly reflective objects, e.g. stainless steel surfaces can be incorrectly detected as reflectors, if they are placed within the scanned area. This must be taken into consideration for the navigation system, in order that incorrect position calculations are avoided.

For technical reasons, reliable reflector detection is only possible from a minimum distance of 40 cm to the scanner.

Reflector foils only reflect a small amount of the light pulse when they are illuminated at angles greater than 50° from vertical. This effect is dependent on the foil used. In any case, it must be taken into consideration that the obliquely illuminated reflectors may not be detected. The reflector should preferably be mounted so that the measuring beam is aligned vertically to the reflector surface. Cylindrical reflectors should be used where the reflector marks have to be detected from more than one side.

If imprecise hits (for example, due to uneven floors or vehicle vibrations) can be avoided otherwise, a single direct hit in driving mode is sufficient for reflector detection and positional determination of the host computer is tolerant enough, then a significantly lower reflector width may suffice if.





# 10 Fault diagnosis

The following options are available for diagnosing faults in the configuration of your sensor:

Blocks that have been changed online can be read back from the sensor at any time to check that the device settings are correct.

The following diagnostic options are available for use with the CDS:

• Display of configuration stored on device.

 $\ensuremath{\texttt{@}}$  SICK AG • Industrial Safety Systems • Germany • All rights reserved

• Depiction of current sensor settings in operational status report.

# 11 Glossary

CDS SICK Configuration & Diagnostic Software

CMS Contour Measurement & Safety

Continuous data output Permanent measured data send mode

Device address Device address for communication

Diamond Grade Reflector foil with respective optical characteristics

Direct hit The complete area of a laser beam hits an object

EFI see Enhanced Function Interface

Enhanced Function Interface Safe SICK device communication

Measured data Distance values measured by the sensor

Output trigger Definition of trigger for data output

Measuring range Segment in scan field

Protocol version number Firmware/device code for host computer

Reflector data Distance data where a reflector has been detected

Remote operation Two S3000/S300 in EFI system

RK512 telegram header Protocol definition for data communication

Scan data record Distance values of a measuring cycle (0 to 190°/0 to

270°)

Silent time Pause time for continuous data output

Time stamp determined at the time of data generation

# 12 Appendix

This appendix lists the data blocks that are relevant for using the measurement data of the S3000 Expert/Anti Collision (section 12.1) and S300 Expert (section 12.2).

All data listed in this appendix are volatile, i. e. they are not maintained through power down.

Note

Only for Compatibility mode: In this appendix, the term Control Area A refers to the active field set, while Control Area B refers to the active simultaneous field set. The term Monitoring Area refers to the configured field sets 0 ... (n - 1). Each field set may consist of one protective field and one or two warning fields. For details on field sets, see the operating instructions of the \$3000/\$300.

### 12.1 Description of the data blocks used in the S3000

#### 12.1.1 Operating data block (block no. 11)

### **Block description**

Data b	olock name	Block no.	Block size	External access
Opera	ting data block	11	164 Byte	Read only
	Block registers	Block words	Register size	Register description
	Operating mode	0	2 Byte	Operating mode of device
	Display data	1 2	4 Byte	Actual display contents
	Input data	3 4	4 Byte	Input data
	Output data	5	2 Byte	Output data
	Monitoring data	6	2 Byte	Monitoring data
	Configuration counter	7	2 Byte	Configuration counter info
	Device time-on	8 9	4 Byte	Device time-on since last power-up
	Reserved for internal use	10 81	132 Byte	Reserved

# **Register description**

Register name	Block word	Field bits	Field name	Field description
Operating mode	0	0 3	Device state	0: Normal 1: Configuration 2: Lockout 3: System initialization 4: Wait for valid inputs 5: Front screen calibration 6: Boot 7: Production 8: Wait for reset 9: Teach-in Other: n/u
		4	Device mode	0: Device is in regular mode 1: n/u
		5 7	n/u	n/u

Register name	Block word	Field bits	Field name	Field description
		8 10	Access level	Access level successfully set by external device.  0: Level 0  1: Level 1A  2: Level 1B  3: Level 2  4: Level 3A  5: Level 3B  6: Level 4  7: n/u
		11 12	Configuration state	O: Device not in configuration mode.  1: Configuration tool required.  2: Configuration in progress.  3: Configuration completed.  Other: n/u
		13 15	Active service interface	O: No interface active.  1: External serial interface. 2: Navigation data interface. 3: Enhanced Function Interface. Other: n/u
Display data	1	0	Displayed character 1 7-segment display: Segment a	0: Segment LED off 1: Segment LED on
		1	Displayed character 1 7-segment display: Segment b	0: Segment LED off 1: Segment LED on
		2	Displayed character 1 7-segment display: Segment c	0: Segment LED off 1: Segment LED on
		3	Displayed character 1 7-segment display: Segment d	0: Segment LED off 1: Segment LED on
		4	Displayed character 1 7-segment display: Segment e	0: Segment LED off 1: Segment LED on
		5	Displayed character 1 7-segment display: Segment f	0: Segment LED off 1: Segment LED on
		6	Displayed character 1 7-segment display: Segment g	0: Segment LED off 1: Segment LED on

95

Register name	Block word	Field bits	Field name	Field description
		7	Displayed character 1 7-segment display: Dot	0: Segment LED off 1: Segment LED on
		8 15	Displayed character 2 <sup>1</sup>	See displayed character 1.
	2	0 7	n/u	n/u
		8 9	State of OSSD LEDs	O: Both LEDs off (Green OSSD LED off and Red OSSD LED off)  1: Green OSSD LED on (Red OSSD LED off)  2: Red OSSD LED on (Green OSSD LED off)  3: n/u
		10 11	State of reset LED	0: LED off 1: LED blinking (1 Hz) 2: LED flashing (4 Hz) 3: LED on
		12 13	State of weak LED	See state of reset LED.
		14 15	State of warning field LED	See state of reset LED.
Input data	3	0	Reset of field A	0: Low 1: High
		1	Reset of field B	0: Low 1: High
		2	Reset of field C	0: Low 1: High
		3	Reset of field D	0: Low 1: High
		4	Standby	0: Low 1: High
		5	Operator acknowledge	0: Low 1: High
		6	EDM input	0: Low 1: High
		7	RES input	0: Low 1: High
		8	Input D2	0: Low 1: High
		9	Input D1	0: Low 1: High
		10	Input C2	0: Low 1: High
		11	Input C1	0: Low 1: High
		12	Input B2	0: Low 1: High
		13	Input B1	0: Low 1: High

On the device, there is only one 7-segment display. Therefore the representation of the two digits is as follows: Constant indication of a character represents a single character. Flashing indication of a character represents two identical characters. Alternating indication of two characters represents two different characters.

Register name	Block word	Field bits	Field name	Field description
		14	Input A2	0: Low 1: High
		15	Input A1	0: Low 1: High
	4	0 15	Speed	-2000 2000 [cm/s] 0x7FFF: Speed is not evaluated. Other: n/u
Output data	5	0	State of OSSDs	0: Deactivated 1: Activated
		1	State of auxiliary output 3	O: Output voltage level high (24 V). 1: Output voltage level low (0 V).
		2 3	State of auxiliary output 2	0: Output voltage level high (24 V). 1: Toggling slowly (1 Hz). 2: n/u 3: Output voltage level low (0 V).
		4 5	State of auxiliary output 1	0: Output voltage level high (24 V). 1: Toggling slowly (1 Hz). 2: Toggling fast (4 Hz). 3: Output voltage level low (0 V).
		6 7	n/u	n/u
		8	Field A	Intrusion detected by field evaluation A. 0: Intrusion detected. 1: No intrusion detected.
		9	Field B	Intrusion detected by field evaluation B. 0: Intrusion detected. 1: No intrusion detected.
		10	Field C	Intrusion detected by field evaluation C. 0: Intrusion detected. 1: No intrusion detected.
		11	Field D	Intrusion detected by field evaluation D. 0: Intrusion detected. 1: No intrusion detected.
		12	Reset required field A	Reset required by field evaluation A. 0: No reset required. 1: Reset required.
		13	Reset required field B	Reset required by field evaluation B. 0: No reset required. 1: Reset required.
		14	Reset required field C	Reset required by field evaluation C. 0: No reset required. 1: Reset required.
		15	Reset required field D	Reset required by field evaluation D. 0: No reset required. 1: Reset required.

97

Register name	Block word	Field bits	Field name	Field description
Monitoring data	6	0 4	Monitoring case	0 31: Active monitoring case
		5	Standby	Standby mode flag 0: No standby 1: Standby
		6 7	n/u	n/u
		8 10	Control area A	0 7: Monitoring area of control area A Only used in compatibility mode, otherwise control area A is always O (no support of monitoring of control areas).
		11	Control area A activated	0: Control area A inactive 1: Control area A active Only used in compatibility mode, otherwise the flag is always false (no support of monitoring of control areas).
		12 14	Control area B	0 7: Monitoring area of control area B Only used in compatibility mode, otherwise control area B is always O (no support of monitoring of control areas).
		15	Control area B activated	O: Control area B inactive 1: Control area B active Only used in compatibility mode, otherwise the flag is always false (no support of monitoring of control areas).
Configuration counter	7	0 15	Configuration counter	O: Initial state of connector plug Other: Number of configurations stored in connector plug so far
Device time-on	89	0 31	Device time-on	Time-on of the device since power-up [s]
Reserved for internal use	10 81			

# 12.1.2 Scan data block (block no. 12)

# **Block description**

Data k	olock name	Block no.	Block size	External access
Scan	data block	12	1524 Byte	Read only
	Block registers	Block words	Register size	Register description
	Monitoring data	0	2 Byte	Monitoring data
	Scan data pulse 0 760	1 761	1522 Byte	Measurement data per pulse

# **Register description**

Register name	Block word	Field bits	Field name	Field description				
Monitoring data	0	0 4	Monitoring case	0 31: Active monitoring case				
		5	Standby	Standby mode flag 0: No standby 1: Standby				
		6 7	n/u	n/u				
						8 10	Control area A	O 7: Monitoring area of control area A Only used in compatibility mode, otherwise control area A is always O (no support of monitoring of control areas).
			11	Control area A activated	O: Control area A inactive 1: Control area A active Only used in compatibility mode, otherwise the flag is always false (no support of monitoring of control areas).			
			12 14	Control area B	O 7: Monitoring area of control area B Only used in compatibility mode, otherwise control area B is always O (no support of monitoring of control areas).			
				15	Control area B activated	O: Control area B inactive 1: Control area B active Only used in compatibility mode, otherwise the flag is always false (no support of monitoring of control areas).		

99

Register name	Block word	Field bits	Field name	Field description
Scan data pulse 0	1	0 12	Distance	Distance [cm]
		13	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		14	Status flag 2	Intrusion detected in field evaluation A or B (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within protective field
		15	Status flag 3	Intrusion detected in field evaluation C or D (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within simultaneous protective field
Scan data pulse 1 760	2 761	See scan data pulse 0.		

© SICK AG • Industrial Safety Systems • Germany • All rights reserved

# 12.1.3 Config master block (block no. 25)

# **Block description**

Data b	olock name	Block no.	Block size	External access
Config	g master block	25	2 Byte	Read Write
	Block registers	Block words	Register size	Register description
	Master ID	0	2 Byte	Master identification

# **Register description**

Register name	Block word	Field bits	Field name	Field description
Master ID	0	0 15	Token	0x0000:Token not assigned. Other: Token assigned to some interface.

# Remark:

In order to request the token, write some number > 0 to the Master ID register.

In order to return the token, write 0x0000 to the Master ID register.

# 12.1.4 Reflector detection block (block no. 52)

# **Block description**

Data b	olock name	Block no.	Block size	External access
Reflec	ctor detection block	52	512 Byte	Read only
	Block registers	Block words	Register size	Register description
	Telegram number	0 1	4 Byte	Telegram number
	Scan number	2 3	4 Byte	Scan number
	Reflector data 0 125	4 255	504 Byte	Reflector data per reflector

# **Register description**

@ SICK AG • Industrial Safety Systems • Germany • All rights reserved

Register name	Block word	Field bits	Field name	Field description
Telegram number	0 1	0 31	Telegram number	Current telegram number
Scan number	2 3	0 31	Scan number	Scan number since power- on
Reflector data 0	4 5	0	Half pulse	Only relevant for reflector center output.  O: Reflector center is on pulse (see bits 1 10).  1: Reflector center is between two pulses (add 0.5 to pulse number according to bits 1 10).
		1 10	Pulse number	0: No reflector detected.  1 381/761 (depending on scan resolution): Number of pulse within the scan. Note: Pulses are numbered starting with 1 (different from other fields).
		11	Center pulse	0: No 1: Yes (this is the center of a detected reflector)
		12 15	n/u	n/u
		16 28	Distance	Distance [cm]
		29	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		30	Status flag 2	Intrusion detected in field evaluation A or B (if activated for evaluation of protective field/collision protection field).  In compatibility mode: Measured value detected within protective field.
		31	Status flag 3	Intrusion detected in field evaluation C or D (if activated for evaluation of protective field/ collision protection

			field).  In compatibility mode:  Measured value detected  within simultaneous  protective field.
Reflector data 1 125	6 255	See reflector data 0.	

**Note** Pulses that detect a reflector are ignored if 126 pulses have already detected a reflector or if the central pulses of 126 sections with consecutive pulses that detected a reflector have already been output.

# 12.1.5 Scan data 05 block (block no. 58)

The scan data can be accessed if the device is operating with a resolution of  $0.5\,^{\circ}$ .

# **Block description**

Data block name		Block no.	Block size	External access
Scan d	lata 05 block	58	790 Byte	Read only
	Block registers	Block words	Register size	Register description
	Processing	0	2 Byte	Information about the current processing status
	Display	1 2	4 Byte	Display setting
	Input data	3 4	4 Byte	Input data
	Output data	5	2 Byte	Output data
	Speed data	68	6 Byte	Speed data
	Error info	9	2 Byte	Error or info
	Field evaluation A	10	2 Byte	Status of field evaluation A
	Field evaluation B D	11 13	6 Byte	Status of field evaluation B D
	Pulse 0	14	2 Byte	Information about the measurement of pulse 0
	Pulse 1 380	15 394	760 Byte	Information about the measurement of pulses 1 380

# **Register description**

Register name	Block word	Field bits	Field name	Field description
Processing	0	0 4	Active Case	0 31: Active monitoring case
		5	StandBy	0: No standby 1: Device in standby
		6 15	n/u	n/u
Display	1 2	0	Displayed character 1 7-segment display: Segment a	0: Segment LED off 1: Segment LED on
		1	Displayed character 1 7-segment display: Segment b	0: Segment LED off 1: Segment LED on
		2	Displayed character 1 7-segment display: Segment c	0: Segment LED off 1: Segment LED on
		3	Displayed character 1 7-segment display: Segment d	0: Segment LED off 1: Segment LED on
		4	Displayed character 1 7-segment display: Segment e	0: Segment LED off 1: Segment LED on

Register name	Block word	Field bits	Field name	Field description
		5	Displayed character 1 7-segment display: Segment f	0: Segment LED off 1: Segment LED on
		6	Displayed character 1 7-segment display: Segment g	0: Segment LED off 1: Segment LED on
		7	Displayed character 1 7-segment display: Dot	0: Segment LED off 1: Segment LED on
		8 15	Displayed character 2 <sup>2</sup>	See displayed character 1.
		16 23	n/u	n/u
		24 25	State of OSSD LEDs	0: Both LEDs off (Green OSSD LED off and Red OSSD LED off) 1: Green OSSD LED on (Red OSSD LED off) 2: Red OSSD LED on (Green OSSD LED off) 3: n/u
		26 27	State of reset LED	0: LED off 1: LED blinking (1 Hz) 2: LED flashing (4 Hz) 3: LED on
		28 29	State of weak LED	See state of reset LED
		30 31	State of warning field LED	See state of reset LED
Input data	3 4	0	Reset of field A	0: Low 1: High
		1	Reset of field B	0: Low 1: High
		2	Reset of field C	0: Low 1: High
		3	Reset of field D	0: Low 1: High
		4	Standby	0: Low 1: High
		5	Operator acknowledge	0: Low 1: High
		6	EDM input	0: Low 1: High
		7	RES input	0: Low 1: High
		8	Input D2	0: Low 1: High
		9	Input D1	0: Low 1: High

On the device, there is only one 7-segment display. Therefore the representation of the two digits is as follows: Constant indication of a character represents a single character. Flashing indication of a character represents two identical characters. Alternating indication of two characters represents two different characters.

Register name	Block word	Field bits	Field name	Field description
		10	Input C2	0: Low 1: High
		11	Input C1	0: Low 1: High
		12	Input B2	0: Low 1: High
		13	Input B1	0: Low 1: High
		14	Input A2	0: Low 1: High
		15	Input A1	0: Low 1: High
		16 31	Speed	-2000 2000 [cm/s] (two's-complement representation) 0x7FFF: Speed is not evaluated. Other: n/u
Output data	5	0	State of OSSDs	0: Deactivated 1: Activated
		1	State of auxiliary output 3	O: Output voltage level high (24 V) 1: Output voltage level low (0 V)
		2 3	State of auxiliary output 2	0: Output voltage level high (24 V) 1: Toggling slowly (1 Hz) 2: n/u 3: Output voltage level low (0 V)
		4 5	State of auxiliary output 1	0: Output voltage level high (24 V) 1: Toggling slowly (1 Hz) 2: Toggling fast (4 Hz) 3: Output voltage level low (0 V)
		6 7	n/u	n/u
		8	Field A	Intrusion detected by field evaluation A. 0: Intrusion detected. 1: No intrusion detected.
		9	Field B	Intrusion detected by field evaluation B. 0: Intrusion detected. 1: No intrusion detected.
		10	Field C	Intrusion detected by field evaluation C. 0: Intrusion detected. 1: No intrusion detected.
		11	Field D	Intrusion detected by field evaluation D. 0: Intrusion detected. 1: No intrusion detected.
		12	Reset required field A	Reset required by field evaluation A. 0: No reset required. 1: Reset required.

Register name	Block word	Field bits	Field name	Field description
		13	Reset required field B	Reset required by field evaluation B. 0: No reset required. 1: Reset required.
		14	Reset required field C	Reset required by field evaluation C. 0: No reset required. 1: Reset required.
		15	Reset required field D	Reset required by field evaluation D. 0: No reset required. 1: Reset required.
Speed data	6 8	0 15	Speed inc 1	Speed of incremental encoder 1: -2000 2000 [cm/s] (two's-complement representation)
		16 31	Speed inc 2	Speed of incremental encoder 2: -2000 2000 [cm/s] (two's-complement representation)
		32	Input E2	0: Low 1: High
		33	Input E1	0: Low 1: High
		34 46	n/u	n/u
		47	Speed status	Status of speed information: 0: The speed information is invalid. 1: The speed information is valid.
Error info	9	0 15	Error code	Lockout error or info code
Field evaluation A	n A 10	0 5	Monitoring field number	0 63: Monitoring field number of field assigned to field evaluation A
		6 7	Monitoring field type	0: Protective field 1: Warning field 2: Collision protection field 3: Inactive field
		8 15	Multiple scan evaluation	0 255: Number of scans that an object has to be detected as intrusion to set the status of the field to "intruded".
Field evaluation B D	11 13	See field eval	uation A.	

Register name	Block word	Field bits	Field name	Field description
Pulse 0	14	0 12	Distance	Distance [cm]
		13	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		14	Status flag 2	Intrusion detected in field evaluation A or B (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within protective field.
		15	Status flag 3	Intrusion detected in field evaluation C or D (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within simultaneous protective field.
Pulse 1 380	15 394	See pulse 0.		

# 12.1.6 Scan data 025 block (block no. 59)

The scan data can be accessed if the device is operating with a resolution of 0.25°.

#### **Block description**

Data b	lock name	Block no.	Block size	External access
Scan d	lata 025 block	59	1550 Byte	Read only
	Block registers	Block words	Register size	Register description
	Processing	0	2 Byte	Information about the current processing status
	Display	12	4 Byte	Display setting
	Input data	3 4	4 Byte	Input data
	Output data	5	2 Byte	Output data
	Speed data	68	6 Byte	Speed data
	Error info	9	2 Byte	Error or info
	Field evaluation A	10	2 Byte	Status of field evaluation A
	Field evaluation B D	11 13	6 Byte	Status of field evaluation B D
	Pulse 0	14	2 Byte	Information about the measurement of pulse 0
	Pulse 1 760	15 774	1520 Byte	Information about the measurement of pulses 1 760

Register name	Block word	Field bits	Field name	Field description
Processing	0	0 4	Active case	0 31: Active monitoring case
		5	Standby	0: No standby 1: Device in standby
		6 15	n/u	n/u
Display	1 2	0	Displayed character 1 7-segment display: Segment a	0: Segment LED off 1: Segment LED on
		1	Displayed character 1 7-segment display: Segment b	0: Segment LED off 1: Segment LED on
		2	Displayed character 1 7-segment display: Segment c	0: Segment LED off 1: Segment LED on
		3	Displayed character 1 7-segment display: Segment d	0: Segment LED off 1: Segment LED on
		4	Displayed character 1 7-segment display: Segment e	0: Segment LED off 1: Segment LED on

Register name	Block word	Field bits	Field name	Field description
		5	Displayed character 1 7-segment display: Segment f	0: Segment LED off 1: Segment LED on
		6	Displayed character 1 7-segment display: Segment g	0: Segment LED off 1: Segment LED on
		7	Displayed character 1 7-segment display: Dot	0: Segment LED off 1: Segment LED on
		8 15	Displayed character 2 <sup>3</sup>	See displayed character 1.
		16 23	n/u	n/u
		24 25	State of OSSD LEDs	0: Both LEDs off (Green OSSD LED off and red OSSD LED off). 1: Green OSSD LED on (Red OSSD LED off). 2: Red OSSD LED on (Green OSSD LED off). 3: n/u
		26 27	State of reset LED	0: LED off. 1: LED blinking (1 Hz). 2: LED flashing (4 Hz). 3: LED on.
		28 29	State of weak LED	See state of reset LED.
		30 31	State of warning field LED	See state of reset led.
Input data	3 4	0	Reset of field A	0: Low 1: High
		1	Reset of field B	0: Low 1: High
		2	Reset of field C	0: Low 1: High
		3	Reset of field D	0: Low 1: High
		4	Standby	0: Low 1: High
		5	Operator acknowledge	0: Low 1: High
		6	EDM input	0: Low 1: High
		7	RES input	0: Low 1: High
		8	Input D2	0: Low 1: High
		9	Input D1	0: Low 1: High

On the device, there is only one 7-segment display. Therefore the representation of the two digits is as follows: Constant indication of a character represents a single character. Flashing indication of a character represents two identical characters. Alternating indication of two characters represents two different characters.

Register name	Block word	Field bits	Field name	Field description							
		10	Input C2	0: Low 1: High							
		11	Input C1	0: Low 1: High							
		12	Input B2	0: Low 1: High							
		13	Input B1	0: Low 1: High							
		14	Input A2	0: Low 1: High							
		15	Input A1	0: Low 1: High							
		16 31	Speed	-2000 2000 [cm/s] (two's-complement representation) 0x7FFF: Speed is not evaluated. Other: n/u							
Output data	5	0	State of OSSDs	0: Deactivated 1: Activated							
		1	State of auxiliary output 3	0: Output voltage level high (24 V) 1: Output voltage level low (0 V)							
			2 3	State of auxiliary output 2	0: Output voltage level high (24 V) 1: Toggling slowly (1 Hz) 2: n/u 3: Output voltage level low (0 V)						
		4 5	State of auxiliary output 1	O: Output voltage level high (24 V) 1: Toggling slowly (1 Hz) 2: Toggling fast (4 Hz) 3: Output voltage level low (0 V)							
		6 7	n/u	n/u							
				8	Field A	Intrusion detected by field evaluation A. 0: Intrusion detected. 1: No intrusion detected.					
									9	Field B	Intrusion detected by field evaluation B. 0: Intrusion detected. 1: No intrusion detected.
				10	Field C	Intrusion detected by field evaluation C. 0: Intrusion detected. 1: No intrusion detected.					
		11	Field D	Intrusion detected by field evaluation D. 0: Intrusion detected. 1: No intrusion detected.							
		12	Reset required field A	Reset required by field evaluation A. 0: No reset required. 1: Reset required.							

Register name	Block word	Field bits	Field name	Field description
		13	Reset required field B	Reset required by field evaluation B. 0: No reset required. 1: Reset required.
		14	Reset required field C	Reset required by field evaluation C. 0: No reset required. 1: Reset required.
		15	Reset required field D	Reset required by field evaluation D. 0: No reset required. 1: Reset required.
Speed data	6 8	0 15	Speed inc 1	Speed of incremental encoder 1: -2000 2000 [cm/s] (two's-complement representation)
		16 31	Speed inc 2	Speed of incremental encoder 2: -2000 2000 [cm/s] (two's-complement representation)
		32	Input E2	0: Low 1: High
		33	Input E1	0: Low 1: High
		34 46	n/u	n/u
		47	Speed status	Status of speed information: 0: The speed information is invalid. 1: The speed information is valid.
Error info	9	0 15	Error code	Lockout error or info code
Field evaluation A	10	0 5	Monitoring field number	0 63: Monitoring field number of field assigned to field evaluation A
		6 7	Monitoring field type	0: Protective field 1: Warning field 2: Collision protection field 3: Inactive field
		8 15	Multiple scan evaluation	0 255: Number of scans that an object has to be detected as intrusion to set the status of the field to "intruded".
Field evaluation B D	11 13	See field eval	uation A.	

Register name	Block word	Field bits	Field name	Field description
Pulse 0	14	0 12	Distance	Distance [cm]
		13	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		14	Status flag 2	Intrusion detected in field evaluation A or B (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within protective field.
		15	Status flag 3	Intrusion detected in field evaluation C or D (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within simultaneous protective field.
Pulse 1 760	15 774	See pulse 0.	•	

#### 12.1.7 Online measurement config block (block no. 103)

This block is used to change the content of the CMS telegram online.

Changes are volatile, i. e. they are not maintained through power down.

#### **Block description**

Data k	olock name	Block no.	Block size	External access
Online measurement config block		103	2 Byte	Read Write
	Block registers	Block words	Register size	Register description
	Measurement data	0	2 Byte	Selection of measurement data to be transmitted.

Register name	Block word	Field bits	Field name	Field description
Measurement data 0	0	Distance data or reflector data	0: Distance data 1: Reflector data	
			Reflector data	O: All pulses that detected a reflector are output.  1: If several consecutive pulses detect a reflector, only data of the central of these pulses is output.
		2 15	n/u	n/u

#### 12.1.8 Online output range config block (block no. 104)

This block is relevant only if distance data is configured (either in CDS or in block 103).

This block is used to change the content of the CMS telegram online.

Changes are volatile, i. e. they are not maintained through power down.

#### **Block description**

Data b	lock name	Block no.	Block size	External access
Online block	output range config	104	16 Byte	Read Write
	Block registers	Block words	Register size	Register description
	Output range 0 configuration	0 1	4 Byte	Configuration of sector 0 to be transmitted.
	Output range 1 configuration	2 3	4 Byte	Configuration of sector 1 to be transmitted.
	Output range 2 configuration	4 5	4 Byte	Configuration of sector 2 to be transmitted.
	Output range 3 configuration	6 7	4 Byte	Configuration of sector 3 to be transmitted.

Register name	Block word	Field bits	Field name	Field description	
Output range 0 configuration	0 1	0 7	Begin of output range	0 190: Angle –5° 185° in steps of 1° Other: No pulse data output. Shall not be larger than end of output range of previous output range.	
		8 15	End of output range	Begin 190: Angle –5° 185° in steps of 1° Other: prohibited. Shall not be smaller than begin of output range.	
		16 19	Output pulse count	O: Min. distance of range  1: Distance data of all pulses  2 15: Output of distance data every n <sup>th</sup> pulse	
		20 31	n/u	n/u	
Output range 1 configuration	2 3	See output range 0 configuration.			
Output range 2 configuration	4 5	See output range 0 configuration.			
Output range 3 configuration	6 7	See output ra	nge 0 configuratio	n.	

# 12.1.9 Online output trigger config block (block no. 105)

This block is used to change the content of the CMS telegram online.

Changes are volatile, i. e. they are not maintained through power down.

# **Block description**

Data b	olock name	Block no.	Block size	External access
Online output trigger config block		105	2 Byte	Read Write
	Block registers	Block words	Register size	Register description
	Output trigger configuration	0	2 Byte	Configuration of output triggers.

Register name	Block word	Field bits	Field name	Field description							
Output trigger configuration	0	0 1	Trigger condition	0: No data output 1: Continuous output 2: Internal event (Shall only be different to "0" if allowed by device capabilities.)							
									2	Control area A	Triggers on detected objects within protective or warning field evaluated by control area A.
		3	Control area B	Triggers on detected objects within protective or warning field evaluated by control area B.							
		4	Reflector detected	Triggers on detected reflector.							
			5	Glare	Triggers on detected glare in distance measurement.						
			6	Field evaluation A	Triggers on detected object in monitoring field processed by field evaluation A.						
					7	Field evaluation B	Triggers on detected object in monitoring field processed by field evaluation B.				
		8	Field evaluation C	Triggers on detected object in monitoring field processed by field evaluation C.							
			9	Field evaluation D	Triggers on detected object in monitoring field processed by field evaluation D.						
		10 15	n/u	n/u							

# 12.1.10 Extended scan data block (block no. 112)

# **Block description**

Data I	block name	Block no.	Block size	External access
Exten	ded scan data block	112	772 or 1532 Byte	Read only
	Block registers	Block words	Register size	Register description
	Telegram number	0 1	4 Byte	Telegram number
	Scan number	2 3	4 Byte	Scan number
	Monitoring data	4	2 Byte	Monitoring data
	Scan data pulse 0 380 or 0 760	5 765	762 or 1522 Byte	Scan data per pulse

Register name	Block word	Field bits	Field name	Field description
Telegram number	0 1	0 31	Telegram number	Current telegram number
Scan number	2 3	0 31	Scan number	Scan number since power-up
Monitoring data	4	0 4	Monitoring case	0 31: Active monitoring case
		5	Standby	0: No standby 1: Standby operation
		6 7	n/u	n/u
		8 10	Control area A	0 7: Monitoring area of control area A Only used in compatibility mode, otherwise control area A is always 0 (no support of monitoring of control areas).
		11	Control area A activated	O: Control area A inactive 1: Control area A active Only used in compatibility mode, otherwise the flag is always false (no support of monitoring of control areas).
		12 14	Control area B	7: Monitoring area of control area B     Only used in compatibility mode, otherwise control area B is always 0 (no support of monitoring of control areas).
		15	Control area B activated	O: Control area B inactive 1: Control area B active Only used in compatibility mode, otherwise the flag is always false (no support of monitoring of control areas).

Register name	Block word	Field bits	Field name	Field description
Scan data pulse 0	5	0 12	Distance	Distance [cm]
		13	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		14	Status flag 2	Intrusion detected in field evaluation A or B (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within protective field.
		15	Status flag 3	Intrusion detected in field evaluation C or D (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within simultaneous protective field.
Scan data pulse 1 380 or 1 760	6 385 or 6 765	See scan data pulse 0.		

 $\textbf{Note} \hspace{0.5cm} \textbf{The actual size of the telegram depends on the scan resolution.} \\$ 

@ SICK AG • Industrial Safety Systems • Germany • All rights reserved

# 12.1.11 Extended reflector detection block (block no. 114)

# **Block description**

Data b	lock name	Block no.	Block size	External access
	led reflector ion block	114	512 Byte	Read only
	Block registers	Block words	Register size	Register description
	Telegram number	0 1	4 Byte	Telegram number
	Scan number	2 3	4 Byte	Scan number
	Reflector data 0 125	4 255	504 Byte	Reflector data per reflector

Register name	Block word	Field bits	Field name	Field description
Telegram number	0 1	0 31	Telegram number	Current telegram number
Scan number	2 3	0 31	Scan number	Scan number since power-up
Reflector data 0	4 5	0	Half pulse	Only relevant for reflector center output.  0: Reflector center is on pulse (see bits 1 10).  1: Reflector center is between two pulses (add 0.5 to pulse number according to bits 1 10).
		1 10	Pulse number	O: No reflector detected.  1 381/761 (depending on scan resolution): Number of pulse within the scan.  Note: Pulses are numbered starting with 1 (different from other fields).
		11	Center pulse	0: No 1: Yes (this is the center of a detected reflector)
		12 15	n/u	n/u
		16 28	Distance	Distance [cm]
		29	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		30	Status flag 2	Intrusion detected in field evaluation A or B (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within protective field.
		31	Status flag 3	Intrusion detected in field evaluation C or D (if activated for evaluation of protective field/ collision protection field). In compatibility mode: Measured value detected within simultaneous

Register name	Block word	Field bits	Field name	Field description
				protective field.
Reflector data 1 125	6 255	See reflector data 0.		

**Note** Pulses that detect a reflector are ignored if 126 pulses have already detected a reflector or if the central pulses of 126 sections with consecutive pulses that detected a reflector have already been output.

**Note** The actual size of the telegram depends on the number of detected reflectors.

# 12.2 Description of the data blocks used in the S300

# 12.2.1 Operating data block (block no. 11)

# **Block description**

Data block name	Block no.	Block size	External access
Operating data block	11	238 Byte	Read only

Register name	Block word	Field bits	Field name	Field description
Operating mode	0	0 3	Device state	0: Normal 1: Configuration 2: Lockout 3: System initialization 4: Wait for valid inputs 5: Front screen calibration 7: Production 8: Wait for reset
		4 5	Measurement state	Actual state of measurement kernel 0: Initialization state 1: Testgate measurement state 2: Reference measurement state 3: Measurement kernel ready
		6	Device mode	Device is in standard mode     ScannerlQ mode is active.
		7	n/u	n/u
		8 10	Access level	Access level successfully set by external device. 0: Level 0 1: Level 1A 2: Level 1B 3: Level 2 4: Level 3A 5: Level 4
		11 12	Configuration state	O: Device not in configuration mode.  1: Configuration tool required.  2: Configuration in progress.  3: Configuration completed.
		13 15	Active service interface	O: No interface active. 1: External serial interface. 2: Navigation data interface. 3: Enhanced Function Interface.
Display data	1	0 7	Displayed character 1	Bit 0:Segment LED a Bit 1: Segment LED b Bit 6: Segment LED g Bit 7: Segment dot LED

Register name	Block word	Field bits	Field name	Field description
		8 15	Displayed character 2 4	See displayed character 1.
	2	0 7	Displayed character 3	Always 0 (empty character)
		8 9	State of OSSD LEDs	0: n/u 1: Green OSSD LED on (Red OSSD LED off) 2: Red OSSD LED on (Green OSSD LED off) 3: n/u
		10 11	State of reset LED	0: LED off 1: LED blinking (1 Hz) 2: LED flashing (4 Hz) 3: LED on
		12 13	State of weak LED	See state of reset LED
		14 15	State of warning field LED	See state of reset LED
Input data	3	0	Input aux 1	Auxiliary input 1 0: Low state 1: High state
		1	Input aux 2	Auxiliary input 2 0: Low state 1: High state
		2	Input aux 3	Auxiliary input 3 0: Low state 1: High state
		3 4	n/u	n/u
		5	Parkmode input	0: Low 1: High
		6	EDM input	0: Low 1: High
		7	RES input	0: Low 1: High
		8	Input D2	0: Low 1: High
		9	Input D1	0: Low 1: High
		10	Input C2	0: Low 1: High
		11	Input C1	0: Low 1: High
		12	Input B2	0: Low 1: High
		13	Input B1	0: Low 1: High
		14	Input A2	0: Low 1: High
		15	Input A1	0: Low 1: High

On the device, there is only one 7-segment display. Therefore the representation of the two digits is as follows: Constant indication of a character represents a single character. Flashing indication of a character represents two identical characters. Alternating indication of two characters represents two different characters.

Register name	Block word	Field bits	Field name	Field description
	4	0 15	Speed	-2000 2000 [cm/s]   (two's-complement   representation)  0x0000: Speed is not   evaluated.  In compatibility mode:  0x7FFF: Speed is not   evaluated.  Other: n/u
Output data	5	0	State of OSSDs	(Consider speed valid flag!)  0: Deactivated (red)
Output data	3	O .	State of OSSDS	1: Activated (green)
		1	State of warning output or aux 3	0: Deactivated (red) 1: Activated (green)
		2 3	State of reset required output or aux 2	0: Deactivated (off) 1: Toggling slowly (1 Hz) 2: Toggling fast (4 Hz 3: Activated (on)
		4 5	State of error/weak output or aux 1	O: Deactivated (off), not configured or contamination error.  1: Toggling slowly (1 Hz), contamination warning.  2: Toggling fast (4 Hz), lockout.  3: Activated (on), configured and no lockout or contamination error.
		6 7	n/u	n/u
		8	Field A	Intrusion detected by field evaluation A. 0: Intrusion detected. 1: No intrusion detected.
		9	Field B	Intrusion detected by field evaluation B. 0: Intrusion detected. 1: No intrusion detected.
		10	Field C	Intrusion detected by field evaluation C. 0: Intrusion detected. 1: No intrusion detected.
		11	Field D	Intrusion detected by field evaluation D. 0: Intrusion detected. 1: No intrusion detected.
		12	Reset required field A	Reset required by field evaluation A. 0: No reset required. 1: Reset required.
		13	Reset required field B	Reset required by field evaluation B. 0: No reset required. 1: Reset required.
		14	Reset required field C	Reset required by field evaluation C. 0: No reset required. 1: Reset required.

Register name	Block word	Field bits	Field name	Field description
		15	Reset required field D	Reset required by field evaluation D. 0: No reset required. 1: Reset required.
Monitoring data	6	0 4	Monitoring case	0 31: Active monitoring Case
		5 6	n/u	n/u
		7	Standby	Device is in standby mode.
		8 12	Control area A	0 31: Standard: Active control area Enhanced <sup>5</sup> : Active protective field
		13 15	n/u	n/u
Configuration counter	7	0 15	Configuration counter	O: Initial state of connector plug Other: Number of configurations stored in connector plug so far
Device time-on	8 9	0 31	Device time-on	Time-on of the device since power-up [s]
Reserved for internal use	10 118			

 $<sup>^{\</sup>rm 5}$   $\,$  Only with S300 Expert in Compatibility mode with resolution configured to 1°.

# 12.2.2 Scan data block (block no. 12)

#### **Block description**

Data block name	Block no.	Block size	External access
Scan data block	12	1084 Byte	Read only

Register name	Block word	Field bits	Field name	Field description	
Monitoring data	oring data 0	0 3	Monitoring case	0 15: Active monitoring case	
		4 7	n/u	n/u	
			8 12	Control area	0 19: Standard: active control area Enhanced <sup>6</sup> : active protective field
		13 15	n/u	n/u	
Scan data pulse 0	1	0 12	Distance	Distance [cm]	
		13	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.	
		14	Status flag 2	Intrusion detected in protective field (field evaluation A).	
		15	Status flag 3	Firmware < 2.10: Intrusion detected in warning field. Firmware ≥ 2.10: n/u	
Scan data pulse 1 540	1 540	See scan data pulse 0.			

 $<sup>^{\</sup>rm 6}$   $\,$  Only with S300 Expert in Compatibility mode with resolution configured to 1°.

# 12.2.3 Config master block (block no. 25)

# **Block description**

Data block name	Block no.	Block size	External access
Config master block	25	2 Byte	Read Write

# **Register description**

Register name	Block word	Field bits	Field name	Field description
Master ID register	0	0 15	Token	0x0000: Token not assigned. Other: Token assigned to some interface.

#### Remark:

In order to request the token, write some number > 0 to the Master ID register.

In order to return the token, write 0x0000 to the Master ID register.

# 12.2.4 Scan data 05 block (block no. 58)

# **Block description**

Data b	lock name	Block no.	Block size	External access
Scan d	lata 05 block	58	1110 Byte	Read only
	Block registers	Block words	Register size	Register description
	Processing	0	2 Byte	Information about the current processing status
	Display	12	4 Byte	Display content
	Input data	3 4	4 Byte	Input data
	Output states	5	2 Byte	Output data
	Speed data	6 8	6 Byte	Speed data
	Error info	9	2 Byte	Error or info
	Field evaluation A	10	2 Byte	Status of field evaluation A
	Field evaluation B D	11 13	6 Byte	Status of field evaluation B D
	Pulse 0	14	2 Byte	Information about the measurement of pulse 0
	Pulse 1 540	15 554	1080 Byte	Information about the measurement of pulses 1 540

Register name	Block word	Field bits	Field name	Field description
Processing	0	0 4	Active case	0 31: Active monitoring case
		5	Standby	0: No standby 1: Device in standby
		6 15	n/u	n/u
Display	12	0	Displayed character 1 7-segment display: Segment a	0: Segment LED off 1: Segment LED on
		1	Displayed character 1 7-segment display: Segment b	0: Segment LED off 1: Segment LED on
		2	Displayed character 1 7-segment display: Segment c	0: Segment LED off 1: Segment LED on
		3	Displayed character 1 7-segment display: Segment d	0: Segment LED off 1: Segment LED on
		4	Displayed character 1 7-segment display: Segment e	0: Segment LED off 1: Segment LED on

Register name	Block word	Field bits	Field name	Field description
		5	Displayed character 1 7-segment display: Segment f	0: Segment LED off 1: Segment LED on
		6	Displayed character 1 7-segment display: Segment g	0: Segment LED off 1: Segment LED on
		7	Displayed character 1 7-segment display: Dot	0: Segment LED off 1: Segment LED on
		8 15	Displayed character 2 7	See displayed character 1.
		16 23	Displayed character 3	Always 0 (empty character)
		24 25	State of OSSD LEDs	0: n/u 1: Green OSSD LED on (Red OSSD LED off) 2: Red OSSD LED on (Green OSSD LED off) 3: n/u
		26 27	Reset Required LED	State of reset required LED: 0: LED off 1: LED blinking (1 Hz) 2: LED flashing (4 Hz) 3: LED on
		28 29	Weak LED	State of weak LED: See state of reset LED.
		30 31	Warn LED	State of Warn LED: See state of reset LED.
Input data	3 4	0	Input aux 1	Auxiliary Input 1: 0: Low 1: High
		1	Input aux 2	Auxiliary Input 2: 0: Low 1: High
		2	Input aux 3	Auxiliary Input 3: 0: Low 1: High
		3 4	n/u	n/u
		5	Input park mode	Park mode input 0: Low 1: High
		6	Input EDM	EDM input: 0: Low 1: High
		7	Input reset	Reset input: 0: Low 1: High
		8	Input D2	0: Low 1: High

On the device, there is only one 7-segment display. Therefore the representation of the two digits is as follows: Constant indication of a character represents a single character. Flashing indication of a character represents two identical characters. Alternating indication of two characters represents two different characters.

Register name	Block word	Field bits	Field name	Field description
		9	Input D1	0: Low 1: High
		10	Input C2	0: Low 1: High
		11	Input C1	0: Low 1: High
		12	Input B2	0: Low 1: High
		13	Input B1	0: Low 1: High
		14	Input A2	0: Low 1: High
		15	Input A1	0: Low 1: High
		16 31	Speed	-2000 2000 [cm/s] (two's-complement representation) 0x0000: Speed is not evaluated.  In compatibility mode: 0x7FFF: Speed is not evaluated.
				Other: n/u (Consider speed valid flag!)
Output states	5	0	State of OSSDs	0: Deactivated (red) 1: Activated (green)
		1	State of warning output or aux 3	0: Deactivated (red) 1: Activated (green)
		2 3	State of reset required output or aux 2	0: Deactivated (off) 1: Toggling slowly (1 Hz) 2: Toggling fast (4 Hz) 3: Activated (on)
		4 5	State of error/weak output or aux 1	O: Deactivated (off), not configured or contamination error  1: Toggling slowly (1 Hz), contamination warning  2: Toggling fast (4 Hz), lockout  3: Activated (on), configured and no lockout or contamination error
		6 7	n/u	n/u
		8	Field A	Intrusion detected by field evaluation A. 0: Intrusion detected. 1: No intrusion detected.
		9	Field B	Intrusion detected by field evaluation B. 0: Intrusion detected. 1: No intrusion detected.
		10	Field C	Intrusion detected by field evaluation C. 0: Intrusion detected. 1: No intrusion detected.

Register name	Block word	Field bits	Field name	Field description
		11	Field D	Intrusion detected by field evaluation D. 0: Intrusion detected. 1: No intrusion detected.
		12	Reset required field A	Reset required by field evaluation A.  0: No reset required.  1: Reset required.
		13	Reset required field B	Reset required by field evaluation B. 0: No reset required. 1: Reset required.
		14	Reset required field C	Reset required by field evaluation C. 0: No reset required. 1: Reset required.
		15	Reset required field D	Reset required by field evaluation D. 0: No reset required. 1: Reset required.
Speed data 6	6 7	0 15	Speed inc 1	Speed of Incremental Encoder 1: -2000 2000 [cm/s] (two's-complement representation)
		16 31	Speed inc 2	Speed of Incremental Encoder 2: -2000 2000 [cm/s] (two's-complement representation)
	8	0	Input E2	0: Low 1: High
		1	Input E1	0: Low 1: High
		2 14	n/u	n/u
		15	Speed status	Status of speed 0: The speed information is invalid. 1: The speed information is valid.
Error info	9	0 15	Error code	Lockout error or info code
Field evaluation A	10	0 5	Monitoring field number	0 63: Monitoring field number of field assigned to field evaluation A
		6 7	Monitoring field type	O: Protective field 1: Warning field 2: Contour field 3: Inactive field. With the inactive field selected no monitoring field is evaluated and the field status is set as configure with Expert application configuration block to free (MutingField) or intrusion (BlockingField)

@ SICK AG • Industrial Safety Systems • Germany • All rights reserved

Register name	Block word	Field bits	Field name	Field description
		8 15	Multiple scan evaluation	0 255: Number of scans that an object has to be detected as intrusion to set the status of the field to "intruded".
Field evaluation B D	11 13	See field eval	uation A.	
Pulse 0	14	0 12	Distance	Distance [cm]
		13	Status flag 1	CMS variants: Reflector detected. Non-CMS variants: Measurement was glared.
		14	Status flag 2	Intrusion detected in protective field (field evaluation A).
		15	Status flag 3	Firmware < 2.10: Intrusion detected in warning field. Firmware ≥ 2.10: n/u
Pulse 1 540	15 554	See pulse 0.	•	

#### 12.2.5 Online measurement config block (block no. 103)

This block is used to change the content of the CMS telegram online.

Changes are volatile, i. e. they are not maintained through power down.

#### **Block description**

Data block name	Block no.	Block size	External access
Online measurement config block	103	2 Byte	Read Write

Register name	Block word	Field bits	Field name	Field description
Measurement data	0	0	Distance data or reflector data	0: Distance data 1: Reflector data
		1	Reflector data	O: All pulses that detected a reflector are output.  1: If several consecutive pulses detect a reflector, only data of the central of these pulses is output.
		2 15	n/u	n/u

#### 12.2.6 Online output range config block (block no. 104)

This block is relevant only if distance data is configured (either in CDS or in block 103).

This block is used to change the content of the CMS telegram online.

Changes are volatile, i. e. they are not maintained through power down.

#### **Block description**

Data block name	Block no.	Block size	External access
Online output range config block	104	20 Byte	Read Write

Register name	Block word	Field bits	Field name	Field description	
Output range 0 configuration	0	0 8	Begin of output range	0 270: Angle -45° 225° in steps of 1° Other: No pulse data output. Shall not be larger than end of output range of previous output range.	
		9 15	n/u	n/u	
	1	0 8	End of output range	Begin 270: Angle –45° 225° in steps of 1° Other: Prohibited. Shall not be smaller than begin of output range.	
		9 11	n/u	n/u	
		12 15	Output pulse count	O: Min. distance of range  1: Distance data of all pulses  2 15: Output of distance data every n <sup>th</sup> pulse	
Output range 1 configuration	2 3	See output range 0 configuration.			
Output range 2 configuration	4 5	See output range 0 configuration.			
Output range 3 configuration	6 7	See output range 0 configuration.			
Output range 4 configuration	8 9	See output range 0 configuration.			

# 12.2.7 Online output trigger config block (block no. 105)

This block is used to change the content of the CMS telegram online.

Changes are volatile, i. e. they are not maintained through power down.

### **Block description**

Data block name	Block no.	Block size	External access
Online output trigger config block	105	2 Byte	Read Write

Register name	Block word	Field bits	Field name	Field description
Output trigger configuration	0	0 1	Trigger condition	0: No data output 1: Continuous output 2: Internal event (Shall only be different to "0" if allowed by device capabilities.)
		2	Control area A	Triggers on detected objects within protective or warning field.
		3	n/u	n/u
		4	Reflector detected	Triggers on detected reflector.
		5	Device glared	Triggers on detected glare in distance measurement.
		6	Field evaluation A	Triggers on detected object in field A.
		7	Field evaluation B	Triggers on detected object in field B.
		8	Field evaluation C	Triggers on detected object in field C.
		9	Field evaluation D	Triggers on detected object in field D.
		10 15	n/u	n/u

Telegram	Listing	CMS

Australia

Phone +61 3 9457 0600 1800 33 48 02 - tollfree

E-Mail sales@sick.com.au

Belgium/Luxembourg

Phone +32 (0)2 466 55 66 E-Mail info@sick.be

Phone +55 11 3215-4900 E-Mail marketing@sick.com.br

Phone +1 905 771 14 44 E-Mail information@sick.com

Česká republika

Phone +420 2 57 91 18 50

E-Mail sick@sick.cz

China

Phone +86 4000 121 000 E-Mail info.china@sick.net.cn Phone +852-2153 6300

E-Mail ghk@sick.com.hk

Danmark

Phone +45 45 82 64 00

E-Mail sick@sick.dk

Phone +49 211 5301-301

E-Mail info@sick.de

España

Phone +34 93 480 31 00

E-Mail info@sick.es

France

Phone +33 1 64 62 35 00

E-Mail info@sick.fr

Phone +44 (0)1727 831121

E-Mail info@sick.co.uk

India

Phone +91-22-4033 8333

E-Mail info@sick-india.com

Israel

Phone +972-4-6881000

E-Mail info@sick-sensors.com

Phone +39 02 27 43 41

E-Mail info@sick.it

Phone +81 (0)3 5309 2112

E-Mail support@sick.jp Magyarország

Phone +36 1 371 2680

E-Mail office@sick.hu

Nederland

Phone +31 (0)30 229 25 44

E-Mail info@sick.nl

Norge

Phone +47 67 81 50 00

E-Mail sick@sick.no

Österreich

Phone +43 (0)22 36 62 28 8-0

E-Mail office@sick.at

Phone +48 22 837 40 50

E-Mail info@sick.pl

Phone +40 356 171 120

E-Mail office@sick.ro

Russia

Phone +7-495-775-05-30

E-Mail info@sick.ru

Phone +41 41 619 29 39

E-Mail contact@sick.ch

Singapore

Phone +65 6744 3732

E-Mail sales.gsg@sick.com

Sloveniia

Phone +386 (0)1-47 69 990

E-Mail office@sick.si

South Africa

Phone +27 11 472 3733

E-Mail info@sickautomation.co.za

Phone +82 2 786 6321/4

E-Mail info@sickkorea.net

Suomi

Phone +358-9-25 15 800

E-Mail sick@sick.fi

Sverige

Phone +46 10 110 10 00

E-Mail info@sick.se

Phone +886-2-2375-6288

E-Mail sales@sick.com.tw

Türkive

Phone +90 (216) 528 50 00 E-Mail info@sick.com.tr

**United Arab Emirates** 

Phone +971 (0) 4 8865 878

E-Mail info@sick.ae

USA/México

Phone +1(952) 941-6780

1 800 325-7425 - tollfree E-Mail info@sickusa.com

More representatives and agencies

at www.sick.com

