

LX12-R operating instructions

Mounting, alignment, teach-in and maintenance

Safety

The sensor is not a safety component according to the Machinery Directive and must not be used for personnel protection. Observe the national regulations for the installation of electrical equipment.

Mounting and alignment

Mount the sensor and the reflector on opposite sides of the conveyor at the same height. Align the light spot to the centre of the reflector until the yellow LED is on (light received) and the stability indicator is lit.

Maintenance

Clean the front screen and the reflector at regular intervals with a soft cloth. Contamination reduces the function reserve; the sensor reports contamination via IO-Link.