

Linked Lamp Setup & Usage Manual



www.linkedlamp.com
www.github.com/aarushmagic/Linked-Lamp

Thank you for building and using the Linked Lamp! We hope this device brings you closer to your loved ones, no matter the distance between you. As an open-source, community-driven project, Linked Lamp relies on the creativity and collaboration of makers like you. You can find the full source code, 3D design files, and community updates on our GitHub repository. Please note that because this is a DIY electronics project, assembly and operation are done at your own risk. The software and hardware designs are provided "as-is" without any warranties. If you have questions, want to report a bug, or would like to share your own custom builds, join us on GitHub or visit www.linkedlamp.com.

First Time Setup

1. Plug in the lamp using a USB-C cable and a 5V power adapter
2. Connect your phone to the "Linked Lamp Setup" WiFi network.
3. A configuration page will open automatically. If not, go to <http://192.168.4.1> in a browser.
4. Select your home Wi-Fi network, enter the password, and tap Save. The lamp will restart and blink twice to indicate it is connected to WiFi.
 - a. Note: Only 2.4GHz Wi-Fi networks are supported
5. Open the Linked Lamp Dashboard (www.linkedlamp.com/my) and enter your Unique ID (UID) found at the end of this manual
6. If prompted, follow the on-screen steps to install the dashboard as a Progressive Web App (PWA) for ease of use.

Using the Lamp

1. **Single Tap:** Sends your color to your partner's lamp (your lamp will flash briefly to confirm).
2. **Tap & Hold:** Cycles through colors. Release at any color to save it as your new default.
3. **Double Tap:** Turns the lamp off (does not affect ambient mode light).
4. **Quickly Tap 5+ Times:** Resets Wi-Fi settings (confirmed by two red flashes). Then repeat setup steps 2-4.

LED Indicators

- **Double green flash:** WiFi connected successfully.
- **Double red flash:** WiFi credentials are being reset (triggered by 5+ taps). The lamp restarts with the setup hotspot.
- **1-second color flash:** Send confirmation. After a single tap, the lamp briefly shows the color you sent
- **3-second color flash:** Color pick confirmation. After holding to select a new default color, the lamp shows your selection for 3 seconds.
- **20-second breathing pulse:** Signal received. The lamp gently pulses for 20 seconds, then holds a steady glow until the timer expires.

Firmware Updates

Check for updates manually in the dashboard under Settings > Check for Update. The lamp does not check for or install updates automatically.

Updates are downloaded over Wi-Fi and applied automatically, after which the lamp will reboot.

While automatic crash-recovery is built-in, updates are not guaranteed to be bug-free. Review the source code at www.github.com/aarushmagic/Linked-Lamp before updating.

Remember, your ID and QR code are a secret. Never share them with anyone else.

Or simply scan the QR code below:



Visit the Linked Lamp dashboard at www.linkedlamp.com/my and type:

My Unique ID

My Dashboard

The Web App dashboard is your remote control. Open it in any browser at www.linkedlamp.com/my. Once you enter your Unique ID (UID), your lamp is linked!

Send Tab

- View online/offline status in the top-right corner. Click the icon for details on each individual lamp.
- Press "Send Signal" to send your default color to your partner.
 - "Signal Sending" means the signal has left your device.
 - "Signal Sent" means the partner's lamp has received the signal and turned on.
- Create "Quick Signals" (presets) using a single color or a custom color cycle of up to 10 colors.
- View the timestamp of the last signal received from your partner.

Settings Tab

- **My Default Color:** Pick the color sent to your partner when you physically tap the lamp or send tap using the dashboard.
- **Daytime:** Customize the lamp's behavior during normal hours.
 - **Lamp On Time:** Adjust how long your lamp stays lit upon receiving a tap
 - **Max Brightness:** Set the daytime light intensity

Troubleshooting

- **Ambient Mode:** Toggle a low-power background glow in your choice of color when the lamp is idle.
- **Nighttime Mode:** Enable a customized schedule to change the lamp's behavior during quiet hours.
 - **Schedule & Timezone:** Choose your timezone and set the night start/end times.
 - **Night Behavior:** Adjust the lamp-on duration and lower the brightness (set to 0% to keep the lamp completely off).
 - **Note:** Ambient lighting automatically turns off when Nighttime mode is active.
- **Check for Update:** Manually check for and install the latest wireless firmware updates.
- **Switch Accounts:** Link and switch between multiple lamp profiles on the same device.
 - Available only when installed as an app/PWA
 - To add multiple accounts, select "Switch Accounts" in the dashboard and type in the UID of the new lamp.

Secondary Lamp

Each user is allowed to add one secondary lamp to their account. Visit www.linkedlamp.com/setup-software and simply flash a new lamp using the exact same configurations as your original. The new lamp will automatically detect the primary device and register itself as secondary. Once linked, both lamps will receive incoming signals in sync, and tapping either lamp will send a signal to your partner.

Q. Lamp keeps restarting
Ans: Check that your Wi-Fi is online and the MQTT broker is working. The lamp reboots every 5 minutes if disconnected.

Q. Lamp isn't responding to taps
Ans: Tap the circle on the front of the lamp's base. If still unresponsive, check your Wi-Fi connection.

Q. Lamp won't connect to Wi-Fi
Ans: Ensure you are using a 2.4GHz network. For USB-C debugging, visit: www.linkedlamp.com/wifi-tool

Q. Other lamp doesn't light up
Ans: Ensure both lamps are powered and connected. Check the Linked Lamp Dashboard to verify connection status.

Q. Lamp shows config portal unexpectedly
Ans: This happens after power cycling, a Wi-Fi reset (5+ taps), or connection failure. Connect to the "Linked Lamp Setup" network to reconfigure.

Q. Lamp turns off on its own
Ans: This is normal behavior. The lamp has a default 5 minute auto-off timer to save power. You can change this duration in your dashboard settings.

For other issues, visit: www.linkedlamp.com/faq

Advanced users may also use the web-based serial monitor to fix any issues:
www.linkedlamp.com/serial