

Module 2: A+ Peripherals and Power Supply

DAY 3:-

Task 1:

5 Common Issues faced with USB keyboards or mice on laptops:

1. Device not detected

- The laptop doesn't recognize the keyboard or mouse when plugged in.
- **Solution:** Try a different USB port on the laptop or Unplug and replug the device.

2. Cursor or keys lagging/unresponsive

- Input feels delayed or intermittently stops working.
- **Solution:** Update or reinstall the USB driver from Device manager.

3. Driver conflicts after Windows update.

- A recent OS update breaks previously working input devices.
- **Solution:** Roll back or update the driver via Device Manager.

4. Loose or damaged USB port

- The connector doesn't stay seated, causing on/off disconnects
- **Solution:** Gently clean the port with compressed air to remove dust or use different USB port or get it repaired.

5. Insufficient power from USB port

- Device disconnects randomly, especially with USB hubs or power-saving settings.
- **Solution:** Disable 'USB selective suspend' in Windows power settings.

Task 2:

Check the headphones are powered on.

- Press the power button.
- Confirm the power LED turns on.
-

Ensure the headphones are in pairing mode.

- Press and hold the Bluetooth/power button until the LED flashes (usually blue and white or blue and red, depending on the model).
- This flashing light indicates the headphones are ready to pair.

Check Bluetooth on the phone.

- Open **Settings** → **Bluetooth**.
- Verify that **Bluetooth** is turned **On**.

Look for the headphones in the Bluetooth device list.

- If they appear under **Available devices**, tap the headphone name to pair.
- If they connect successfully, verify they show as **Connected**.

If the headphones don't appear, refresh the device search.

- Turn Bluetooth **Off**, wait 10 seconds, then turn it **On** again.
- Scan for nearby devices.

Remove any previous pairing.

- If the headphones are listed under **Paired devices** but won't connect:
 - Tap the settings icon next to the device.
 - Select **Forget** or **Unpair**.
 - Put the headphones back into pairing mode and pair them again.

Check if the headphones are connected to another device.

- Turn off Bluetooth on nearby phones, tablets, or laptops that were previously paired.
- Some Bluetooth headphones can connect to only one device at a time.

Restart both devices.

- Turn the headphones off and back on.
- Restart the phone.
- Try pairing again.

Test the connection.

- Play music or a video.
- Verify the audio comes through the headphones instead of the phone speaker.

If the issue persists, reset the headphones.

- Follow the manufacturer's instructions to perform a factory reset.
- Pair the headphones with the phone again.

Task 3:

External Webcam Not Detected in Zoom (Windows 10) – Troubleshooting Checklist

1. Check the Physical Connection

- Ensure the webcam is securely connected to the USB port.
 - Try a different USB port if it isn't detected.
 - Verify that any webcam power or activity LED is on (if applicable).
2. **Verify the Webcam in Device Manager**
 - Press **Win + X** → **Device Manager**.
 - Expand **Cameras** or **Imaging devices**.
 - Check if the webcam is listed and whether it has a yellow warning icon.
 - If necessary, right-click the device and select **Update driver** or **Enable device**.
 3. **Test the Webcam in the Camera App**
 - Open the **Camera** app in Windows.
 - If the webcam works here, the issue is likely with Zoom settings rather than the hardware or driver.
 4. **Check Windows Camera Privacy Settings**
 - Go to **Settings** → **Privacy** → **Camera** (or **Privacy & Security** → **Camera** on newer Windows versions).
 - Make sure **Camera access** is turned **On**.
 - Enable **Let apps access your camera**.
 - Ensure desktop apps (including Zoom) are allowed to access the camera.
 5. **Verify Zoom Camera Settings**
 - Open **Zoom** → **Settings** → **Video**.
 - Select the correct webcam from the **Camera** drop-down menu.
 - If multiple cameras are connected, ensure Zoom isn't using the wrong one.
 6. **Close Other Applications Using the Webcam**
 - Close apps such as **Camera**, **Microsoft Teams**, **Skype**, **Google Meet**, or **OBS Studio**.
 - Restart Zoom and check if the webcam is detected, as only one application may be able to access the webcam at a time in some cases.

Task 4:

Steps to Use the Windows Printer Troubleshooter

1. Press **Windows + I** to open **Settings**.
2. Go to **System** → **Troubleshoot** → **Other troubleshooters** → **Printer**
3. Find **Printer** and click **Run** (or **Run the troubleshooter**).
4. Select the printer that is showing **Offline** when prompted.
5. Allow Windows to scan for problems. The troubleshooter will automatically check for common issues such as:
 - Printer connectivity problems (USB or network)
 - Incorrect printer settings

- Print Spooler service issues
 - Missing or outdated printer drivers
 - Whether the printer is set as the default printer
6. If Windows finds a problem, choose **Apply this fix** if prompted.
 7. After the troubleshooter finishes, try printing a test page to verify that the printer is back online.

Information the Troubleshooter Provides

During the troubleshooting process, Windows displays:

- The checks it is performing (for example, checking the Print Spooler service or printer status).
- Whether any problems were detected.
- A description of each issue found.
- Any fixes it applied automatically.
- Recommended actions if it cannot fix the problem automatically (such as reconnecting the printer, restarting the Print Spooler, or reinstalling the printer driver).
- A final summary indicating whether the issue was resolved or if further troubleshooting is required.

