ZONE No. 1
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
ZONE No. 2
GORGE
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
OFF
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
DANGER
DANGER

ZONE No. 1
GORGE
DANGER 960 VOLTS FROM SUPPLY
E-1 Z1
DANGER
Hazardous voltage. Will cause severe injury or death.
Do not enter compartment until you have:
Turned off main power
Disconnected voltage.
Grounded all terminals
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
PULL KNOB BEFORE →
OPERATING MAIN ← HANDLE
S
OFF
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
ZONE No. 2
GORGE
DANGER 960 VOLTS FROM SUPPLY
E-1 Z2
ZONE No. 3
GORGE
DANGER 960 VOLTS FROM SUPPLY
E-1 Z3
P

·ZONE No. 1·

GORGE

·DANGER 960 VOLTS·
FROM SUPPLY

CONTROL MODE
LOCAL REMOTE

DANGER

Hazardous voltage.
Will cause severe
injury or death.
Do not enter compartment
until you have:
Turned off main power.
Disconnected voltage.
Grounded all terminals.

DANGER

·ZONE No. 2·

GORGE

·DANGER 960 VO
FROM SUPP

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

FULL KNOB BEFORE →S

OPERATING BAR ← HANDLE

S

OFF

·DISCONNECT BOTH PRIMARY AND
SECONDARY FOR ISOLATION·

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

·DISCONNECT BOTH PRIMARY AND
SECONDARY FOR ISOLATION·

DANGER

DANGER

DANGER 960 VOLTS
FROM SUPPLY

DANGER
Hazardous voltage.
Will cause severe
injury or death.
Do not enter compartment
until you have:
Turned off main power.
Disconnected voltages.
Grounded all terminals.

DANGER

ZONE No. 3
GORGE

DANGER 960 VOLTS
FROM SUPPLY

DANGER

Spang

GORG

ECT BOTH PRIMARY AND
DARY FOR ISOLATION

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

DISCONNECT BOTH PRIMARY AND
SECONDARY FOR ISOLATION

DANGER

DANGER

-ZONE No. 2-

GORGE

-DANGER 960 VOLTS-
FROM SUPPLY

DANGER

SWITCH SETTINGS

POSITION	VOLTS	AMPS.
SERIES	960	200
PARALLEL	480	400

DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

DANGER

-ZONE No. 3-

GORGE

-DANGER 960 VOLTS-
FROM SUPPLY

Spang

DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

DANGER

ZONE No. 2
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
Hazardous voltage
Will cause severe
injury or death.
Do not enter compartment
until you have:
Turned off main power.
Disconnected voltage
Grounded all terminals
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
ZONE No. 3
GORGE
DANGER 960 VOLTS FROM SUPPLY
Spang
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

ZONE No. 2
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
S
OFF
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
ZONE No. 3
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
SWITCH SETTINGS
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
Spang
GORGE
DANGER
DANGER

DANGER 960 VOLTS FROM SUPPLY

E-121

DANGER

Hazardous voltage.
Will cause severe injury or death.
Do not enter compartment until you have:
Turned-off main power
Disconnected voltage.
Grounded all terminals.

DANGER

ZONE No. 2
GORGE

DANGER 960 VOLTS FROM SUPPLY

DANGER

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

S OFF

DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

CONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

ZONE No. 3
GORGE

DANGER 960 VOLTS FROM SUPPLY

DANGER

Spang

GORGE

DANGER

DANGER

ZONE No. 1
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
Hazardous voltage. Will cause severe injury or death. Do not enter compartment until you have: Turned off main power. Disconnected voltage. Grounded all terminals.
DANGER
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
OFF
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
DANGER
DANGER
ZONE No. 2
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
OFF
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
DANGER
DANGER

-ZONE No. 1-

GORGE

-DANGER 960 VOLTS-
FROM SUPPLY

DANGER

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

PULL HANDLE BEFORE →

OPERATING BAR ← HANDLE

S OFF

-DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

-ZONE No. 2-

GORGE

-DANGER 960 VOLTS-
FROM SUPPLY

DANGER

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

-DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

GORGE
ZONE No. 1
GORGE

-ZONE No. 1-
GORGE
.DANGER 960 VOLTS.
FROM SUPPLY
-ZONE No. 2-
GORGE
GORGE
GROUPE SPANB
ARRET
ARRET
MARCHE
MARCHE
Schneider
Electric
SM6

DANGER 960 VOLTS FROM SUPPLY

ZONE No. 2

GORGE

DANGER

DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION

ZONE No. 2
GORGE
DANGER 960 VOLTS FROM SUPPLY
DANGER
ZONE No. 3
GORGE
DANGER 960 VOLTS FROM SUPPLY
Spang
GORGE
SWITCH SETTINGS
POSITION VOLTS AMPS
SERIES 960 200
PARALLEL 480 400
PULL KNOB BEFORE
S
OF
DISCONNECT BOTH PRIMARY AND SECONDARY FOR ISOLATION
DANGER

No. 2

ORGE

DANGER 960 VOLTS
FROM SUPPLY

DANGER

Hazardous voltage
Will cause severe
injury or death.
Do not enter compartment
until you have
Turned off main power
Disconnected voltage
Grounded all terminals

DANGER

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

OFF

DISCONNECT BOTH PRIMARY AND
SECONDARY FOR ISOLATION

DANGER

ZONE No. 3

GORGE

SWITCH SETTINGS

POSITION	VOLTS	AMPS
SERIES	960	200
PARALLEL	480	400

DISCONNECT BOTH PRIMARY AND
SECONDARY FOR ISOLATION

DANGER 960 VOLTS
FROM SUPPLY

DANGER

DANGER

DANGER

Spang