Embedded Software Essentials

Other Useful GNU Tools

C1 M2 V9

Copyright

 Copyright (C) 2017 by Alex Fosdick. Redistribution, modification or use of this presentation is permitted as long as the files maintain this copyright. Users are permitted to modify this and use it to learn about the field of embedded software. Alex Fosdick and the University of Colorado are not liable for any misuse of this material.

GNU Binary Utilities

- Extra programs to help with the process of building
- These include
 - The Assembler (ar)
 - The Linker (Id)
 - Conversion of executables
 - Sizing compiled images
 - Library/Archive creation
 - Symbol Listing
 - Debugging
 - Many more!

```
alex@ubuntu14: ~/repos/ese-coursera/demos/c1/m2/v9
alex@ubuntu14:v9$ (test) ls -la /usr/bin/arm-none-eabi*
-rwxr-xr-x 1 root root 902876 Jun 28 08:48 /usr/bin/arm-none-eabi-addr2line
-rwxr-xr-x 1 root root 935648 Jun 28 08:48 /usr/bin/arm-none-eabi-ar
-rwxr-xr-x 1 root root 1508736 Jun 28 08:48 /usr/bin/arm-none-eabi-as
-rwxr-xr-x 1 root root 781840 Jun 28 08:48 /usr/bin/arm-none-eabi-c++
-rwxr-xr-x 1 root root 902652 Jun 28 08:48 /usr/bin/arm-none-eabi-c++filt
-rwxr-xr-x 1 root root 781840 Jun 28 08:48 /usr/bin/arm-none-eabi-cpp
                        30520 Jun 28 08:48 /usr/bin/arm-none-eabi-elfedit
-rwxr-xr-x 1 root root
-rwxr-xr-x 1 root root 781840 Jun 28 08:48 /usr/bin/arm-none-eabi-g++
-rwxr-xr-x 1 root root 777744 Jun 28 08:48 /usr/bin/arm-none-eabi-gcc
-rwxr-xr-x 1 root root 777744 Jun 28 08:48 /usr/bin/arm-none-eabi-gcc-5.4.1
                        26208 Jun 28 08:48 /usr/bin/arm-none-eabi-gcc-ar
-rwxr-xr-x 1 root root
                        26208 Jun 28 08:48 /usr/bin/arm-none-eabi-gcc-nm
-rwxr-xr-x 1 root root
                        26208 Jun 28 08:48 /usr/bin/arm-none-eabi-gcc-ranlib
-rwxr-xr-x 1 root root
-rwxr-xr-x 1 root root 452760 Jun 28 08:48 /usr/bin/arm-none-eabi-gcov
-rwxr-xr-x 1 root root 424080 Jun 28 08:48 /usr/bin/arm-none-eabi-gcov-tool
-rwxr-xr-x 1 root root 5530912 Jun 28 08:48 /usr/bin/arm-none-eabi-gdb
-rwxr-xr-x 1 root root 977340 Jun 28 08:48 /usr/bin/arm-none-eabi-gprof
-rwxr-xr-x 1 root root 1255520 Jun 28 08:48 /usr/bin/arm-none-eabi-ld
-rwxr-xr-x 1 root root 1255520 Jun 28 08:48 /usr/bin/arm-none-eabi-ld.bfd
-rwxr-xr-x 1 root root 915548 Jun 28 08:48 /usr/bin/arm-none-eabi-nm
-rwxr-xr-x 1 root root 1117788 Jun 28 08:48 /usr/bin/arm-none-eabi-objcopy
-rwxr-xr-x 1 root root 1372668 Jun 28 08:48 /usr/bin/arm-none-eabi-objdump
-rwxr-xr-x 1 root root 935648 Jun 28 08:48 /usr/bin/arm-none-eabi-ranlib
-rwxr-xr-x 1 root root 550876 Jun 28 08:48 /usr/bin/arm-none-eabi-readelf
-rwxr-xr-x 1 root root 902844 Jun 28 08:48 /usr/bin/arm-none-eabi-size
-rwxr-xr-x 1 root root 902908 Jun 28 08:48 /usr/bin/arm-none-eabi-strings
-rwxr-xr-x 1 root root 1117788 Jun 28 08:48 /usr/bin/arm-none-eabi-strip
alex@ubuntu14:v9$ (test)
```

Useful GNU Tools

Name	Purpose	ARM Executable
size	Lists the section sizes for object and executable files	arm-none-eabi-size
nm	Lists the symbols from object files	arm-none-eabi-nm
objcopy	Copies and translates object files	arm-none-eabi-objcopy
objdump	Displays information from object files	arm-none-eabi-objdump
readelf	Displays information from elf files	arm-none-eabi-readelf
gdb	GNU Project Debugger	gdb

GNU Size Utility

 Use GCC's size to display the sizes of the compiled sections inside your object files and executable file outputs

- Gives you an idea of your memory footprint is for you executable
 - Code Memory
 - Data Memory

```
alex@ubuntu14:v9$ (test) arm-none-eabi-size -Atd demo.out
demo.out :
section
                    size
                             addr
.init
                      12
                            32768
.text
                   34600
                            32780
.fini
                            67380
                      12
                    1312
                            67392
.rodata
                                           All Memory
.ARM.exidx
                            68704
.eh frame
                            68712
                                             sections
                           134252
.init array
                                           compiled in
.fini_array
                           134260
.jcr
                           134264
                                              output
.data
                           134272
                    2244
.bss
                                            executable
                     112
                           136516
                     156
.stab
.stabstr
                     333
                     110
.comment
.debug_frame
                    4700
.ARM.attributes
Total
                   43659
```

```
alex@ubuntu14:v9$ (test) arm-none-eabi-size -Bx demo.out
                                                            HEX
   text
           data
                    bss
                            dec
                                    hex filename
          0x8d4
                   0x70
                          38320
                                   95b0 demo.out
 0x8c6c
alex@ubuntu14:v9$ (test) arm-none-eabi-size -Bd demo.out
                                                          Decimal
   text
           data
                    bss
                            dec
                                     hex filename
  35948
           2260
                    112
                          38320
                                    95b0 demo.out
```

```
alex@ubuntu14:v9$ (test) arm-none-eabi-size -Btd demo.out main.o my_file.o
                    bss
                             dec
                                     hex filename
           data
   text
  35948
           2260
                    112
                           38320
                                    95b0 demo.out
                                                               Each File
                                      1e main.o
     30
                                                             Section size
    192
                             192
                                      c0 my file.o
              0
                           38542
  36170
           2260
                    112
                                    968e (TOTALS)
```

NM Utility

- The symbol utility allows us to investigate the size of all the possible symbols that are defined in a given executable or object file
- Symbols are identifiers in your source code that can be referenced
 - Variables
 - Functions
 - Debug

Symbol Descriptions

- **T**: Code
- **R**: Read Only
- D: Initialized Data
- **B**: Uninitialized Data (BSS)

```
alex@ubuntu14:v9$ (test) arm-none-eabi-nm -S --defined --size-sort -s demo.out
000084f8 00000002 T exit
0000850c 00000004 R _global_impure_ptr
00018960 00000004 D _impure_ptr
00018980 0000000a B memory
000083e0 00000010 T atexit
0000802c 00000018 t register fini
                                                   All defined
00008194 0000001a T get value
000081f0 0000001e T clear_all
                                              symbols (variables
00008174 0000001e T clear value
0000800c 00000020 T exit
                                                and code) in the
00008150 00000022 T set_value
000083f0 00000034 T __libc_fini_array
                                               output executable
0000811c 00000034 T main
000081b0 0000003e T set all
00008210 00000048 T __libc_init_array
00008258 0000008c T memset
00008424 000000d4 T __register_exitproc
000082e4 000000fc T call exitprocs
00018538 00000428 d impure data
```

NM example

- my_file.c contains 5 function definitions, no global variables
- Ending Code Address: 0xBE
 - ~190 Bytes of code Memory
- Biggest Function: set_all
- Smallest Function: clear_value, set_value

my_file.c Symbol Table

Name	Starting Address	Code Size [Bytes]
clear_all	0x00	0x22
clear_value	0x24	Oz1E
get_value	0x44	0x1A
set_all	0x60	0x3E
set_value	0xA0	0x1E


```
alex@ubuntu14:v9$ (test) arm-none-eabi-nm -S --defined -s my_file.o
000000a0 0000001e T clear_all
00000024 0000001e T clear_value
00000044 0000001a T get_value
00000060 0000003e T set_all
00000000 00000022 T set_value
```

Objcopy Utility

- The object copy utility is used to:
 - Convert objects files from one format to another
 - Make a copy of an object file
- Executables are a type of object file
 - Many different object file formats

Object Format Types:

- Binary
- srec (Motorola S-record)
- intel Hex Record (ihex)
- elf32-littlearm
- elf32-bigarm



Objdump Utility

- Dumps information about an object file
 - Section Headers
 - Symbols
 - Debugging
- Can take object files and dump assembly from the machine code
 - Regular object files
 - Output Executables

```
file format elf32-littlearm
demo:
Disassembly of section .init:
00008000 < init>:
                                         {r3, r4, r5, r6, r7, lr}
    8000:
                b5f8
                                 push
    8002:
                46c0
                                                          ; (mov r8, r8)
                                 nop
                                         {r3, r4, r5, r6, r7}
    8004:
                bcf8
                                 pop
    8006:
                                         {r3}
                bc08
                                 pop
    8008:
                469e
                                         lr, r3
                                 mov
                4770
                                 bx
    800a:
Disassembly of section .text:
0000800c <exit>:
    800c:
                b510
                                         {r4, lr}
                                 push
                2100
                                         r1, #0
    800e:
                                 movs
    8010:
                0004
                                         г4. г0
                                 MOVS
    8012:
                                         82e4 < call exitprocs>
                f000 f967
    8016:
                4b04
                                 ldr
                                         r3, [pc, #16]
                                                          ; (8028 <exit+0x1c>)
    8018:
                6818
                                         r0, [r3, #0]
                                         r3, [r0, #60]
    801a:
                6bc3
                                                          ; 0x3c
    801c:
                2b00
                                 CMP
                                         r3, #0
                                         8022 <exit+0x16>
    801e:
                d000
                                 bea.n
    8020:
                4798
                                 blx
                                         г3
    8022:
                0020
                                 MOVS
                                         r0, r4
                                 ы
                                         84f8 < exit>
    8024:
                f000 fa68
    8028:
                0000850c
                                         0x0000850c
                Machine
                                   Assembly Instructions
Address
                  code
```

Objdump Utility

 Debug symbols allow your C-program and assembly to intermix

C-programming Statements

Debugger uses this debug software

```
main.o:
            file format elf32-littlearm
Disassembly of section .text:
         <main>:
extern char memory[MAX_LENGTH];
 .nt main(void){
                                  {r7, lr}
        b580
                         push
                         add
                                  г7, sp, #
        af00
  clear_all(memory, MAX_LENGTH);
                                  r3, [рс, #4
        4b0a
        210a
                         movs
                                  r1, #
        0018
                         movs
                                  г0, г3
        f7ff fffe
                                   <clear_all>
  set_value(memory,
                                  r3, [pc, #32]
        4b08
                         ldr
                                                  : (30 <main+
                                 r2, #
                         MOVS
                                  r1, #
        21aa
                         MOVS
        0018
                         movs
                                  г0, г3
        f7ff fffe
                                   <set value>
  set value(memory,
        4b05
                                  r3, [pc, #
                         ldr
  1c:
                                  r2, #
  1e:
                         movs
                                  r1, #
        0018
                         movs
                                  г0, г3
                                   <set_value>
        f7ff fffe
  return 0;
                         movs
                                  r3, #
```

Address Machine code

Assembly Instructions

Readelf Utility

- Displays information about a ELF formatted file
 - Compiled Sections
 - Memory Sections
 - Symbol Tables
 - Architecture Specifics

ELF Files are not human readable they contain lots of hidden information in binary data

```
alex@ubuntu14:v9$ (test) arm-none-eabi-readelf demo.out --all
ELF Header:
 Magic:
          7f 45 4c 46 01 01 01 00 00 00 00 00 00 00 00 00
 Class:
                                      ELF32
                                      2's complement, little endian
 Data:
  Version:
                                      1 (current)
 OS/ABI:
                                      UNIX - System V
  ABI Version:
                                      EXEC (Executable file)
  Type:
  Machine:
  Version:
                                      0x1
  Entry point address:
                                      0x80a5
  Start of program headers:
                                      52 (bytes into file)
 Start of section headers:
                                      39140 (bytes into file)
                                      0x5000200, Version5 EABI, soft-float ABI
  Flags:
 Size of this header:
                                      52 (bytes)
 Size of program headers:
                                      32 (bytes)
 Number of program headers:
 Size of section headers:
                                      40 (bytes)
 Number of section headers:
 Section header string table index: 15
Section Headers:
  [Nr] Name
                         Type
                         NULL
  [ 0]
                                          00000000 000000 000000 00
                         PROGBITS
   1]
       .init
                         PROGBITS
   2]
       .text
   3]
       .fini
                         PROGBITS
                                          000084fc 0084fc 00000c 00
       .rodata
                         PROGBITS
                                          00008508 008508 000008 00
       .ARM.exidx
                         ARM EXIDX
                                          00008510 008510 000008 00
       .eh frame
                         PROGBITS
                                          00008518 008518 000004 00
       .init_array
                         INIT ARRAY
                                          0001851c 00851c 000008 00
       .fini array
                         FINI ARRAY
                                          00018524 008524 000004 00
                         PROGBITS
   9]
       .jcr
                                          00018528 008528 000004 00
       .data
                         PROGBITS
                                          00018530 008530 000434 00
  [10]
  [11]
       .bss
                         NOBITS
                                          00018964 008964 000028 00
                         PROGBITS
  [12]
       .comment
                                          00000000 008964 00006e 01
       .debug frame
                         PROGBITS
                                          00000000 0089d4 000184 00
       .ARM.attributes
                         ARM_ATTRIBUTES 00000000 008b58 000028 00
       .shstrtab
                         STRTAB
                                                                              0
  [16]
       .symtab
                         SYMTAB
                                          00000000 008b80 0008b0 10
  [17] .strtab
                         STRTAB
                                          00000000 009430 000419 00
Key to Flags:
 W (write), A (alloc), X (execute), M (merge), S (strings)
 I (info), L (link order), G (group), T (TLS), E (exclude), x (unknown)
 O (extra OS processing required) o (OS specific), p (processor specific)
```