Ai Overclock Tuner

Allows you to select the memory overclocking profile.

Configuration options: [Auto] [Manual] [XMP]

DRAM Frequency

Sets the operating frequency of the installed memory.

Configuration options: [Auto] [DDR5-4800] [DDR5-5600]

CPU Core Ratio

Adjusts the multiplier applied to the base clock.

Precision Boost Overdrive

Extends the processor boost limits beyond stock values.

Use with adequate cooling installed.

Secure Boot Control

Enables or disables secure boot validation for the operating system.

Configuration options: [Enabled] [Disabled]