

|                                                                      |                         |                         |
|----------------------------------------------------------------------|-------------------------|-------------------------|
| <b>Document Name: Universal Gateway Ethernet Setting User Manual</b> |                         |                         |
| <b>Document No: ESP-21-22-002</b>                                    | <b>Revision: R00</b>    | <b>Date: 02/08/2021</b> |
| <b>Prepared By: CGH</b>                                              | <b>Approved By: RDT</b> | <b>Sheet: 1</b>         |

# Universal Gateway Ethernet Setting User Manual

**Document Name: Universal Gateway Ethernet Setting User Manual****Document No: ESP-21-22-002****Revision: R00****Date: 02/08/2021****Prepared By: CGH****Approved By: RDT****Sheet: 2****1 Configure network parameter**

Set the PC to static IP mode and then connect it with the module via Ethernet or Wi-Fi. The PC IP address is set to 192.168.18.10/255.255.255.0, gateway 192.168.18.254. The (Wi-Fi default ssid and the default password, see this document.) open the browser <http://192.168.18.2>, enter the web configuration page, default user name and password is admin / admin. Modify the network Parameters through the web. Now, the IP address is 192.168.18.2.

**1.1 Configure serial network parameter**

Opens the browser <http://192.168.18.2/ser2net.asp>, enter the serial-to-network web configuration page. Configure the serial-to-network parameters as needed through a web page.

**2 WEB configuration**

## WEB configuration page

The screenshot displays a web configuration interface for serial-to-network parameters. At the top, there is a 'NetMode:' dropdown menu set to 'Default'. Below this is a table with two columns: 'Current' and 'Updated'. The table contains the following parameters:

|                            | Current         | Updated                                                                |
|----------------------------|-----------------|------------------------------------------------------------------------|
| Serial Configure:          | 115200,8,n,1    | <input type="text" value="115200,8,n,1"/>                              |
| Serial Framing Lenth:      | 64              | <input type="text" value="64"/>                                        |
| Serial Framing Timeout:    | 10 milliseconds | <input type="text" value="10"/> milliseconds (< 256, 0 for no timeout) |
| Network Mode:              | none            | <input type="text" value="None"/>                                      |
| Remote Server Domain/IP:   | 192.168.11.245  | <input type="text" value="192.168.11.245"/>                            |
| Locale/Remote Port Number: | 8080            | <input type="text" value="8080"/>                                      |
| Network Protocol:          | tcp             | <input type="text" value="TCP"/>                                       |
| Network Timeout:           | 0 seconds       | <input type="text" value="0"/> seconds (< 256, 0 for no timeout)       |

At the bottom of the form, there are two buttons: 'Apply' and 'Cancel'.

Through the correct module address ([default address:http://192.168.18.2/ser2net.asp](http://192.168.18.2/ser2net.asp)), you can access to the WEB configuration page.

**2.1 The page can be divided into 3 areas :**

- 1 Network configuration area
- 2 Serial function configuration areas
- 3 Configuration submit area

|                                                                      |                         |                         |
|----------------------------------------------------------------------|-------------------------|-------------------------|
| <b>Document Name: Universal Gateway Ethernet Setting User Manual</b> |                         |                         |
| <b>Document No: ESP-21-22-002</b>                                    | <b>Revision: R00</b>    | <b>Date: 02/08/2021</b> |
| <b>Prepared By: CGH</b>                                              | <b>Approved By: RDT</b> | <b>Sheet: 3</b>         |

WEB network configuration

**Net mode selection :**

- Default – default work mode
- ETH-SERIAL – Serial to Ethernet

Choose different work mode the web will show you different page. Mode configuration page is as follows:

Set Network details  
Of Client Network  
At this page

NetMode: ETH-SERIAL

IP Type: STATIC

IP Address: 192.168.11.254

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.11.1

Primary DNS Server: 192.168.11.1

Secondary DNS Server: 8.8.8.8

Serial to Ethernet-static IP