

INTRO

Config and / or firmware upload can be triggered via USB pen-drive method.

Required Hardware

The **USB pen-drive** device is required to flash the config/firmware via USB method.



The unit has the following 3 connectors:

9 pin MNG connector (must be connected towards the management interface of switch you want to program).

USB female connector (USB plug to insert the USB memory stick that contains the config or the firmware).

USB male connector (USB plug to insert into your computer to access the switch console via the SERIAL to USB application on you PC).

Format the USB-Sticks

The USB stick capacity must be minimum 4 GB.

The unit needs to be formatted as > **FAT 32**

And the label must be: **VDS_KACTION** (*config will not load if the label is different*)

Prepare USB stick for Firmware upload

The latest Firmware will be provided by your contact partner: NOMAD.

Current latest version (Jan-11-2024) is **sw-std-ng-fw-7.4.0.zip**

md5sum = 7afb11db61d2e8e9debb48d5d30526d9

When the zip file is extracted, you will find 3 files:

Name	Size	Type	Modified
 bigbang-a-ng.ksi	39.7 MB	unknown	24 April 2022, 17:37
 ipart-ng.kad	23.6 MB	unknown	10 October 2023, 14:48
 u-boot-ng.kad	235.5 kB	unknown	27 July 2023, 15:41

Copy the files onto the USB stick.

-Procedure to install Firmware from USB

Insert the pen-drive with the “Firmware” USB onto the new switch.

Power up the new switch and watch the 6 LEDs marked as POWER.

They will start to flash one by one from LED 1 to LED 6.

When they stop flashing and all 6 LEDs are ON at once the firmware upgrade succeeded.

You may unplug USB stick 1 (the unit will auto reboot once the USB stick is removed).

Prepare USB stick for Config upload

The required files will be provided by your contact Partner: NOMAD.

Copy the following required files onto the USB stick.

1. Required Switch Config file

Name
 CFG-197001010001.kad

- a.
 2. *K_ACTION.1.17.generic_kad_load*
 - a. md5sum = 921574152ddbf87703adcdd924584efc

The USB key should now have two files - a Config file “.kad” and a “K_ACTION” file.

Procedure to upload your config from USB

Do not Insert the pen-drive with the “Config” USB onto the new switch, yet!!!

If your switch is not in factory default mode, you need to factory reset it, see procedure below.

Power up the new switch and watch POWER LED 1 and 2.

When the POWER LED 1 is ON and POWER LED 2 is flashing the switch is booted and ready.

Insert the USB key into the pen-drive tool and insert pen-drive console connector into the switch console.

Now watch the LEDs, LED#6 will flash > when LED#6 is solid, remove USB drive (switch will reboot)

How to factory reset the switch

Log on to the switch and execute the command “*sysadmin delete startup-config*”.

Switch will respond with “**Press Y to confirm, N otherwise**” *Confirm with Y*

The system will reboot.

Now the switch is ready to be configured again.