

microplay



KEY GUIDE

Function	Buttons	Submenu	Note				
Hotkey	Select	-	Activation key for various actions in the game				
IN THE GAME							
Funktion	Buttons	Submenu	Note				
Exit Game	Hotkey + Start	_	Close the Current emulation				
Insert Coin	Select	_	Coin for arcade games				
Console Settings	Hotkey + X	Configuration Menu	caution! Many settings (everything preconfigured)				
	Hotkey + X	Quick Menu -> Save State	Saves current game (for games without memory function)				
	Hotkey + X	Quick Menu -> Load State	Loads last game (for games without memory function)				
	Hotkey + X	Quick Menu -> Take Screenshot	take a screenshot				
	Hotkey + X	Quick Menu -> Controls	Controller settings for current emulation				
PSP Menu	Button	_					
♥Xbox Controller	Xbox-Taste	Game Menu	Menu with settings, Saveslots, Quit				
♥PS3/PS4 Controller	PS-Taste	Game Menu	Menu with settings, Saveslots, Quit				
♥8Bitdo Controller	L2 or R2	Game Menu	Menu with settings, Saveslots, Quit				
Retro USB Controller	Select	Game Menu	Menu with settings, Saveslots, Quit				
♥USB Univ.Controller	Select	Game Menu	Menu with settings, Saveslots, Quit				
Nintendo DS Menu	Button	_					
	Select	Game Menu	Menu with settings, Saveslots, Quit				
Famicom	Button	_					
Change disk	L1	_	Switches between Disc-A and B				

IN THE GAME SELECTION					
Function	Buttons	Submenu	Note		
Change Console	Left, Right	-	to navigate through the consoles		
Change Game	UP, DOWN	_	to navigate through the game list		
Gamesearch	Select	_	Menu for searching, filtering and delete games		
Menu	Start	_	Starts the system menu		
Launch	A	_	Launch the Game		
Back	В	_	back to the system selection		
Random	Х	_	Launch a random game		
Favorites	Υ	_	add Game to the Favorites		

IN THE MENU					
Function	Buttons	Submenu	Note		
Startmenu	Start	_	Starts the system menu		
	Start	QUIT -> GO TO COMMAND LINE	Command Line (for experienced users)		
	Start	QUIT -> Shutdown System	Shutdown the System		
	Start	QUIT -> Restart Emulationstation	fast reboot		
	Start	QUIT -> Restart System	Full System reboot		
	Start	CONFIGURE CONTROLLERS	Controller key assignment		
	Start	SOUND SETTINGS	Sound settings for outputs (jack, HDMI,)		
	Start	UI SETTINGS	System settings (Screensaver, Designs,)		
	Start	GAME COLLECTION SETTINGS	Set a own game collection		
	Start	OTHER SETTINGS	Other Settings (VRAM, Powersave)		

MPCORE NXT (c)opyright by microplay