

Application Program Interface (API)

PSS®E 35.3.2

December 2021

Siemens Industry, Inc.
Siemens Power Technologies International
400 State Street
Schenectady, NY 12301-1058 USA
+1 518-395-5000
www.siemens.com/power-technologies

Copyright © 1990, 2020 Siemens Power Technologies International

Information in this manual and any software described herein is confidential and subject to change without notice and does not represent a commitment on the part of Siemens Industry, Inc., Siemens Power Technologies International. The software described in this manual is furnished under a license agreement or nondisclosure agreement and may be used or copied only in accordance with the terms of the agreement. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, for any purpose other than the purchaser's personal use, without the express written permission of Siemens Industry, Inc., Siemens Power Technologies International. PSS®E high-performance transmission planning software is a registered trademark of Siemens Industry, Inc., Siemens Power Technologies International in the United States and other countries. The Windows 7® and Windows 10® operating systems, the Visual C++® development system, Microsoft Office Excel® and Microsoft Visual Studio® are registered trademarks of Microsoft Corporation in the United States and other countries. The Python programming language is a trademark of the Python Software Foundation. Other names may be trademarks of their respective owners.

Table of Contents

Preface	liii
Power Flow	1
Power Flow Operation	2
ACCC	2
ACCC_2	4
ACCC_MULTIPLE_MERGE	6
ACCC_MULTIPLE_RUN_REPORT	8
ACCC_MULTIPLE_RUN_REPORT_2	11
ACCC_PARALLEL	15
ACCC_PARALLEL_2	18
ACCC_SINGLE_RUN_REPORT	21
ACCC_SINGLE_RUN_REPORT_2	24
ACCC_SINGLE_RUN_REPORT_3	27
ACCC_SINGLE_RUN_REPORT_4	30
ACCC_SINGLE_RUN_REPORT_5	33
ACCC_TRIP_COR	37
ACCC_TRIP_COR_2	41
ACCC_TRIP_COR_3	45
ACCC_WITH_COR	50
ACCC_WITH_COR_2	54
ACCC_WITH_COR_3	58
ACCC_WITH_DSP	62
ACCC_WITH_DSP_2	65
ACCC_WITH_DSP_3	68
ACCC_WITH_TRIP	71
ACCC_WITH_TRIP_2	74
ACCC_WITH_TRIP_PARALLEL	77
ACCOR	80
ACCOR_2	83
ACCOR_3	86
ALERT_OUTPUT	89
ALLOW_PSSUSERPF	91
ALPH	92
APPEND_ACCC	93
APPLY_VAR_LIMITS	95
AREA	96
AREA_2	97
AREA_ZONE	98
ARNM	99
ARNM_2	101
BASE_FREQUENCY	103
BGEN	104
BRCH	105
BRCH_2	107
BSNM	109
BUSN	112
BUS_INPUT	113
BUS_OUTPUT	114

BUS_SIZE_LEVEL	115
CASE	116
CA_ITERATIONS	117
CHECKVOLTAGELIMITS	118
CHECK_POWERFLOW_DATA	119
CHKCNTDUPLICON	121
CHKCNTDUPLIDFX	122
CLOSE_POWERFLOW	123
CLOSE_REPORT	124
CMPR	125
CNTB	127
CONG	129
CONL	130
CONNECTIVITY_CHECK	132
CONTROL_AREA_INTERCHANGE	133
CSV_TO_RAWX	134
DCCC	135
DCCC_2	137
DCCOR	139
DCCOR_2	141
DCLF	144
DCLF_2	146
DCPSCOPF	148
DC_TAP_ADJUSTMENT	151
DELTMPFILES	152
DFAX	153
DFAX_2	155
DFAX_CONTINGENCY	157
DFTI	158
DIFF	161
DSCN	165
DUPLICATE_CNTLABEL_CHECK	166
ECDI	167
ECHO	169
EEQV	170
EQRD	172
EXAM	174
FACT	175
FDNS	176
FILE_OVERWRITE	178
FIND	179
FLAT_START	180
FNSL	181
GCAP	183
GCAP_2	184
GDIF	185
GENDSP	187
GENDSP_2	189
GENS	191
GEOL	192
GETCONTINGENCYSAVEDCASE	193

GIC_PF	194
GNESTATUS	196
GNET	197
IMNET	198
IMOUTAGE	199
IMPC	200
IMPLEMENT_TRANSFER	201
IMPLEMENT_TRANSFER_2	204
INLF	207
INLF_2	209
INTA	211
INTZ	212
ISOLATE_LEVELS	213
JOIN	214
LAMP	215
LINES_PER_PAGE	216
LINES_PER_PAGE_ONE_DEVICE	217
LINE_SHUNT_REPORTING	218
LIST	219
LISTCONTINGENCYSAVEDCASES	221
LLRF	222
LOAD_REDUCTION	224
LOUT	225
LTAP	226
MACCC	227
MACCC_2	232
MACCC_3	237
MACCC_PARALLEL	242
MACCC_PARALLEL_2	247
MACCC_TRIP_COR	252
MACCC_TRIP_COR_2	258
MACCC_TRIP_COR_3	264
MACCC_TRIP_COR_4	271
MACCC_WITH_COR	277
MACCC_WITH_COR_2	282
MACCC_WITH_COR_3	288
MACCC_WITH_COR_4	294
MACCC_WITH_TRIP	300
MACCC_WITH_TRIP_2	305
MACCC_WITH_TRIP_3	310
MACCC_WITH_TRIP_PARALLEL	315
MACCC_WITH_TRIP_PARALLEL_2	320
MATRIX_GROWTH_FACTOR	325
MCRE	326
MODR	327
MOVE3WND	329
MOVEBRN	330
MOVEINDMAC	331
MOVEINDMACS	332
MOVELOAD	333
MOVELOADS	334

MOVEMAC	335
MOVEPLNT	336
MOVESHUNT	337
MOVESHUNTS	338
MOVESWS	339
MOVESWSHUNT	340
MOVESWSHUNTS	341
MOV_ALPHA	342
MOV_ITERATIONS	343
MOV_TOLERANCE	344
MSLV	345
MSUM	347
MTDC	348
MULTISECTION_REPORTING	349
MWMI	350
MWOMWMSF	352
MWOMWOSF	353
N11_ACCC	354
N11_ACCC_2	358
N11_ACCC_3	362
N11_ACCC_PARALLEL	366
N11_ACCC_PARALLEL_2	370
N11_ACCC_PSCOPF	374
N11_ACCC_PSCOPF_2	381
N11_ACCC_PSCOPF_3	388
NETG	394
NEWCAS	395
NEWCASE_2	396
NEWTON_TOLERANCE	397
NEW_DIMENSION	398
NON_DIVERGENT	399
NON_TRANS_PERCENT_UNITS	400
NSOL	401
NUMBER_THREADS	403
ORDR	404
OTDF	405
OUTPUT_Y_MATRIX	406
OUTS	407
OWNM	408
OWNM_2	410
OWNM_3	412
OWNR	414
PATH	415
PHASE_SHIFT_ADJUSTMENT	416
POLY	417
POUT	420
POWER_OUTPUT	421
PP_ACCC	422
PP_ACCC_MULTI_CASE	424
PRINT_OUTAGED_BRANCHES	427
PRINT_WINDING_BUSES	428

PROGRESS_OUTPUT	429
PROMPT_OUTPUT	430
PRTI	431
PSCOPF	432
PSCOPF_2	438
PSEB	444
PSSEHALT	445
PSSEHALT_2	446
PV_ENGINE	447
PV_ENGINE_1A	452
PV_ENGINE_2	457
PV_ENGINE_3	463
PV_ENGINE_4	469
PV_ENGINE_5	475
PV_ENGINE_6	481
QV_ENGINE	487
QV_ENGINE_2	490
QV_ENGINE_3	493
QV_ENGINE_4	496
RANK	500
RANK_BRN_AND_MAC	502
RATE	504
RATE_2	506
RATING_SET	508
RAWD	509
RAWDX	511
RAWD_2	513
RAWX_TO_CSV	515
RDCH	516
RDCHRAWVERSION	517
RDEQ	518
READ	520
READCAPCURVES	521
READRAWVERSION	522
READSUB	523
READSUBRAWVERSION	525
READVDFFROMRAWX	527
READX	528
RECN	529
REGB	530
RELIND	531
RELIND_2	534
REMM	537
REPORT_OUTPUT	538
RESQ	539
RESQVERSION	540
RESULT_TABLE_OUTPUT	541
RETI	542
RETRY_PSSUSERPF	543
REV29_NAMES	544
RNFI	545

RSOL	547
RUNLASTSOLUTION	549
RWCM	550
RWMA	551
RWMM	553
RWSQ	554
RWSQ_2	556
SAVE	558
SCAL	559
SCAL_2	562
SCAL_3	565
SCAL_4	568
SENSITIVITY_FLOW	571
SENSITIVITY_FLOWS	575
SENSITIVITY_INTERFACE	578
SENSITIVITY_VOLTAGE	581
SENSITIVITY_VOLTAGES	584
SET_INPUT_DEV	587
SET_PROGRESS_VERBOSE	588
SHNT	589
SHORT_CIRCUIT_COORDINATES	590
SHORT_CIRCUIT_MODELING	591
SHORT_CIRCUIT_UNITS	592
SHORT_CIRCUIT_WARNING	593
SHORT_CIRCUIT_Z_COORDINATES	594
SHORT_CIRCUIT_Z_UNITS	595
SHOW	596
SHOWTABLE	597
SHOWTABLEBYINDEX	598
SIZE	599
SOLV	600
SPCB	602
SPIL	604
SPLT	608
SQLI	609
SRAIND	611
STOP	613
STOP_2	614
SUBS	615
SWITCHED_SHUNT_ADJUSTMENT	616
TAP_ADJUSTMENT	617
TEXT	618
TFLG	619
TIES	620
TIEZ	621
TIME	622
TLST	623
TLTG	624
TPCH	628
TRANSFORMER_PERCENT_UNITS	631
TRANSMISSION_LINE_UNITS	632

TREE	633
TYSL	634
USER	635
VAMM	636
VAMO	637
VCHK	638
VOLTAGE_INPUT	639
VOLTAGE_OUTPUT	640
VSMO	641
WRITECAPCURVES	642
WRITERAWVERSION	644
WRITESEQVERSION	645
WRITESEQVERSION_2	646
WRITE_OPTIONS_FILE	647
XEQV	648
ZONE	650
ZONE_2	651
ZONE_AREA	652
ZONM	653
ZONM_2	655
Power Flow Data	658
AREA_DATA	658
BRANCH_CHNG	660
BRANCH_CHNG_3	662
BRANCH_DATA	665
BRANCH_DATA_3	667
BUS_CHNG_3	670
BUS_CHNG_4	672
BUS_DATA	674
BUS_DATA_2	676
BUS_DATA_3	678
BUS_DATA_4	680
BUS_NUMBER	682
CASE_TITLE_DATA	683
CASOLUTION_PARAMETERS	684
CASOLUTION_PARAMETERS_2	685
EXTR	687
FACTS_CHNG_2	688
FACTS_CHNG_3	691
FACTS_DATA	694
FACTS_DATA_2	697
FACTS_DATA_3	700
GNE_CHNG	703
GNE_DATA	705
IMPEDANCE_CORRECTION_DATA	707
IMPEDANCE_CORRECTION_DATA_3	708
INDUCTION_MACHINE_CHNG	709
INDUCTION_MACHINE_DATA	712
LOAD_CHNG_4	715
LOAD_CHNG_5	717
LOAD_CHNG_6	719

LOAD_DATA	721
LOAD_DATA_3	723
LOAD_DATA_4	725
LOAD_DATA_5	727
LOAD_DATA_6	729
LONG_TITLE_DATA	731
MACHINE_CAP_CURVE_CHNG	732
MACHINE_CAP_CURVE_DATA	734
MACHINE_CHNG_2	736
MACHINE_CHNG_3	738
MACHINE_CHNG_4	740
MACHINE_DATA	742
MACHINE_DATA_2	744
MACHINE_DATA_3	746
MACHINE_DATA_4	749
MBID2DC	752
MBID3WND	753
MBIDATRN	754
MBIDBRN	755
MBIDFACTS	756
MBIDGNE	757
MBIDINDMAC	758
MBIDLOAD	759
MBIDMAC	760
MBIDMDC	761
MBIDMSL	762
MBIDSHUNT	763
MBIDSWSHUNT	764
MBIDVD	765
MBIDVSC	766
MULTI_SECTION_LINE_DATA	767
MULTI_SECTION_LINE_EDIT	769
MULTI_TERM_DC_BUS_DATA	770
MULTI_TERM_DC_CONVR_DATA	772
MULTI_TERM_DC_LINE_CHNG	775
MULTI_TERM_DC_LINE_DATA	777
MULTI_TERM_DC_LINK_DATA	779
OWNER_DATA	781
PBUS_ADD_MOD	782
PBUS_DELETE	783
PLANT_CHNG	784
PLANT_CHNG_3	785
PLANT_CHNG_4	786
PLANT_DATA	788
PLANT_DATA_3	789
PLANT_DATA_4	790
PURG	792
PURG2DC	794
PURG3WND	795
PURGAREA	796
PURGATRN	797

PURGBRN	798
PURGCAPCURVE	799
PURGE_MULTI_TERM_DC_BUS	800
PURGE_MULTI_TERM_DC_CONVR	801
PURGE_MULTI_TERM_DC_LINK	803
PURGFACTS	804
PURGGNE	805
PURGINDMAC	806
PURGINDMACS	807
PURGLOAD	808
PURGLOADS	809
PURGMAC	810
PURGMDC	811
PURGMSL	812
PURGMUT	813
PURGOWNER	814
PURGPLNT	815
PURGSHUNT	816
PURGSHUNTS	817
PURGSWS	818
PURGSWSHUNT	819
PURGVSC	820
PURGZONE	821
PURG_VOLTAGE_DROOP	822
RATINGSETTEXTDATA	823
SHUNT_CHNG	824
SHUNT_DATA	825
SOLUTION_PARAMETERS	826
SOLUTION_PARAMETERS_2	828
SOLUTION_PARAMETERS_3	830
SOLUTION_PARAMETERS_4	832
SOLUTION_PARAMETERS_5	834
SWITCHED_SHUNT_CHNG_3	837
SWITCHED_SHUNT_CHNG_4	840
SWITCHED_SHUNT_CHNG_5	843
SWITCHED_SHUNT_DATA	846
SWITCHED_SHUNT_DATA_3	849
SWITCHED_SHUNT_DATA_4	852
SWITCHED_SHUNT_DATA_5	855
THREE_WINDING_DATA	858
THREE_WND_IMPEDANCE_DATA	862
THREE_WND_IMPED_CHNG_3	865
THREE_WND_IMPED_CHNG_4	868
THREE_WND_IMPED_DATA_3	871
THREE_WND_IMPED_DATA_4	874
THREE_WND_WINDING_DATA	877
THREE_WND_WINDING_DATA_3	879
THREE_WND_WINDING_DATA_4	881
THREE_WND_WINDING_DATA_5	884
TRANSACTION_ADD_MOD	887
TRANSACTION_DELETE	888

TRANSFER_CHNG	889
TRANSFER_DATA	890
TWO_TERMINAL_DC_LINE_CHNG	892
TWO_TERMINAL_DC_LINE_DATA	894
TWO_TERM_DC_CONVERTER_DATA_3	896
TWO_TERM_DC_CONVR_DATA	899
TWO_WINDING_CHNG_4	902
TWO_WINDING_CHNG_5	906
TWO_WINDING_CHNG_6	910
TWO_WINDING_DATA	915
TWO_WINDING_DATA_3	919
TWO_WINDING_DATA_4	923
TWO_WINDING_DATA_5	927
TWO_WINDING_DATA_6	931
VOLTAGE_DROOP_CHNG	936
VOLTAGE_DROOP_DATA	938
VSC_DC_CONVERTER_DATA	940
VSC_DC_CONVERTER_DATA_3	942
VSC_DC_LINE_CHNG	944
VSC_DC_LINE_DATA	945
ZONE_DATA	946
Node Breaker	948
Node Breaker Operation	949
CONVERT_SECTION_TO_BUS	949
ISOLATE2DCLINEBYBREAKER	950
ISOLATE3WTBYBREAKER	951
ISOLATEBUSBYBREAKER	952
ISOLATEFACTSBYBREAKER	953
ISOLATEINDMACHINEBYBREAKER	954
ISOLATELINEBYBREAKER	955
ISOLATELOADBYBREAKER	956
ISOLATEMACHINEBYBREAKER	957
ISOLATEMSLINEBYBREAKER	958
ISOLATEMTDCLINEBYBREAKER	959
ISOLATENODEBYBREAKER	960
ISOLATESHUNTBYBREAKER	961
ISOLATESWDBYBREAKER	962
ISOLATESWSHUNTBYBREAKER	963
ISOLATESWSHUNTBYBREAKER_2	964
ISOLATEVSCDCLINEBYBREAKER	965
RESTORESTATESFROMISOLATE	966
STATION_BUILD_CONFIG	967
STATION_LIST	968
STATION_POUT	969
STATION_POUT_2	970
STATION_TREE	971
Node Breaker Data	974
FETCH_ADJVAR_TERM_NODE	974
FETCH_INDMACHINE_TERM_NODE	975
FETCH_LOAD_TERM_NODE	976
FETCH_MACHINE_TERM_NODE	977

FETCH_SHUNT_TERM_NODE	978
FETCH_SWS_SHUNT_TERM_NODE	979
FETCH_SWS_SHUNT_TERM_NODE_2	980
PLANT_BUS_SECTION_CHNG	981
STATION_2DC_CONV_TERM_CHNG	982
STATION_ADJVAR_TERM_CHNG	983
STATION_BRANCH_TERM_CHNG	984
STATION_BRANCH_TERM_MOVE	985
STATION_BUS_PURG	986
STATION_CHNG	987
STATION_DATA	988
STATION_FACTS_TERM_CHNG	989
STATION_INDMACHINE_TERM_CHNG	990
STATION_LOAD_TERM_CHNG	991
STATION_MACHINE_TERM_CHNG	992
STATION_MTDC_TERM_CHNG	993
STATION_NODE_CHNG	994
STATION_NODE_DATA	995
STATION_NODE_NUMBER	996
STATION_NODE_PURG	997
STATION_NUMBER	998
STATION_PURG	999
STATION_SHUNT_TERM_CHNG	1000
STATION_SWDC_CHNG	1001
STATION_SWDC_DATA	1003
STATION_SWDC_MCID	1005
STATION_SWDC_MOVE	1006
STATION_SWDC_PURG	1007
STATION_SWS_SHUNT_TERM_CHNG	1008
STATION_SWS_SHUNT_TERM_CHNG_2	1009
STATION_THREE_WND_TERM_CHNG	1010
STATION_THREE_WND_TERM_MOVE	1011
STATION_VSCDC_CONV_TERM_CHNG	1012
SYSTEM_SWDC_CHNG	1013
SYSTEM_SWDC_DATA	1015
Optimal Power Flow	1019
Optimal Power Flow Operation	1020
ADD_DETAILS_TO_OPF_LOG	1020
APPLY_ALTERNATE_STEP_SIZE	1021
APPLY_AUTOMATIC_SCALING	1022
BAD_ITER_COARSE_LIMIT	1023
BAD_ITER_FINE_LIMIT	1024
CLAMP_NONOPTIMIZED_GENS	1025
CONSTRAIN_INTERFACE_FLOWS	1026
FINAL_OPF_BARRIER_COEFF	1027
IMPORT_ECDI	1028
INITIAL_OPF_BARRIER_COEFF	1029
INTERFACE_FLOW_COST_COEFF	1030
LSTO	1031
MINIMIZE_ADJ_BUS_SHUNTS	1033
MINIMIZE_FUEL_COST	1034

MINIMIZE_INTERFACE_FLOWS	1035
MINIMIZE_LOAD_ADJUSTMENTS	1036
MINIMIZE_P_LOSSES	1037
MINIMIZE_P_SLACK	1038
MINIMIZE_Q_LOSSES	1039
MINIMIZE_Q_SLACK	1040
MINIMIZE_REACTIVE_RESERVE	1041
MINIMIZE_SERIES_COMP	1042
NOPF	1043
OPEN_BUS_VOLTAGE_LIMITS	1044
OPF_BARRIER_STEP_LENGTH	1045
OPF_CLAMP_DECAY_FACTOR	1046
OPF_FINAL_CLAMP_TOL	1047
OPF_FIXED_VOLTAGE_PENALTY	1048
OPF_FIX_ALL_GENERATORS	1049
OPF_FIX_PHASE_SHIFTERS	1050
OPF_FIX_SWITCHED_SHUNTS	1051
OPF_FIX_TAP_RATIOS	1052
OPF_INITIAL_CLAMP_TOL	1053
OPF_INTERIOR_SHIFT_FACTOR	1054
OPF_LAMBDA_TOLERANCE	1055
OPF_LF_CONTROL_PENALTY	1056
OPF_MAX_TAP_RATIO_STEP	1057
OPF_MIN_TAP_RATIO_STEP	1058
OPF_REGULATE_AREA_INT	1059
OPF_ROUND_SWITCHED_SHUNTS	1060
OPF_ROUND_TAP_RATIOS	1061
OPF_SCALE_QGEN_LIMITS	1062
OPF_STEP_LENGTH_TOLERANCE	1063
OPF_USE_GENERATOR_VSCHED	1064
OPTO	1065
PRODUCE_OPF_LOG_FILE	1071
P_LOSSES_COST_COEFF	1072
Q_LOSSES_COST_COEFF	1073
REACTIVE_RESV_COST_COEFF	1074
ROPF	1075
RWOP	1076
SET_OPF_REPORT_SUBSYSTEM	1077
USE_DUAL_CRITERIA	1078
USE_EMERGENCY_FLOW_LIMITS	1079
USE_EMERGENCY_VOLT_LIMITS	1080
WRITE_OPF_OPTIONS_FILE	1081
Optimal Power Flow Data	1084
NEWOPF	1084
OPF_ADJBRX_INDV	1085
OPF_ADJBRX_SUBSYS	1087
OPF_ADJLOAD_TBL	1090
OPF_ADJVAR_INDV	1092
OPF_ADJVAR_INDV_2	1094
OPF_ADJVAR_SUBSYS	1096
OPF_APDSP_TBL	1099

OPF_BRFLW_3WT_INDV	1101
OPF_BRFLW_BRN_INDV	1103
OPF_BRFLW_SUBSYS	1105
OPF_BUS_INDV	1108
OPF_BUS_INDV_2	1110
OPF_BUS_SUBSYS	1112
OPF_CHANGE_3WT_FLOW_ID	1115
OPF_CHANGE_ADJVAR_ID	1116
OPF_CHANGE_BRN_FLOW_ID	1117
OPF_CSTTBL_LIN	1118
OPF_CSTTBL_POLY	1119
OPF_CSTTBL_QUAD	1120
OPF_GENDSP_INDV	1121
OPF_GENDSP_SUBSYS	1122
OPF_GENRSV_INDV	1123
OPF_GENRSV_SUBSYS	1124
OPF_GEN_RCAP_INDV	1126
OPF_GEN_RCAP_SUBSYS	1128
OPF_INTFLW_3WT	1131
OPF_INTFLW_BRN	1132
OPF_INTFLW_MAIN	1133
OPF_INTFLW_RESET	1135
OPF_LNCEQN_ADJLOAD	1136
OPF_LNCEQN_ADJVAR	1137
OPF_LNCEQN_BRFLOW	1138
OPF_LNCEQN_INTFLOW	1139
OPF_LNCEQN_MAIN	1140
OPF_LNCEQN_PGEN	1141
OPF_LNCEQN_QGEN	1142
OPF_LNCEQN_RESET	1143
OPF_LNCEQN_SWSHUNT	1144
OPF_LNCEQN_SWSHUNT_2	1145
OPF_LNCEQN_TRAN	1146
OPF_LNCEQN_VANG	1147
OPF_LNCEQN_VANG_2	1148
OPF_LNCEQN_VMAG	1149
OPF_LNCEQN_VMAG_2	1150
OPF_LOAD_INDV	1151
OPF_LOAD_SUBSYS	1152
OPF_PERRSV_GEN	1153
OPF_PERRSV_MAIN	1154
OPF_PERRSV_RESET	1155
PURGE_ALL_OPF_DATA	1156
PURGE_OPF_ADJBRX_INDV	1157
PURGE_OPF_ADJBRX_SUBSYS	1158
PURGE_OPF_ADJLOAD_TBL	1159
PURGE_OPF_ADJVAR_INDV	1160
PURGE_OPF_ADJVAR_INDV_3	1161
PURGE_OPF_ADJVAR_SUBSYS	1162
PURGE_OPF_APDSP_TBL	1163
PURGE_OPF_BRFLW_3WT	1164

PURGE_OPF_BRFLW_BRN	1165
PURGE_OPF_BRFLW_SUBSYS	1166
PURGE_OPF_BUS_INDV	1167
PURGE_OPF_BUS_INDV_3	1168
PURGE_OPF_BUS_SUBSYS	1169
PURGE_OPF_CSTTBL_LIN	1170
PURGE_OPF_CSTTBL_POLY	1171
PURGE_OPF_CSTTBL_QUAD	1172
PURGE_OPF_GENDSP_INDV	1173
PURGE_OPF_GENDSP_SUBSYS	1174
PURGE_OPF_GENRSV_INDV	1175
PURGE_OPF_GENRSV_SUBSYS	1176
PURGE_OPF_GEN_RCAP_INDV	1177
PURGE_OPF_GEN_RCAP_SUBSYS	1178
PURGE_OPF_INTFLW	1179
PURGE_OPF_INTFLW_3WT	1180
PURGE_OPF_INTFLW_BRN	1181
PURGE_OPF_LNCEQN	1182
PURGE_OPF_LNCEQN_ADJLOAD	1183
PURGE_OPF_LNCEQN_ADJVAR	1184
PURGE_OPF_LNCEQN_BRFLOW	1185
PURGE_OPF_LNCEQN_INTFLOW	1186
PURGE_OPF_LNCEQN_PGEN	1187
PURGE_OPF_LNCEQN_QGEN	1188
PURGE_OPF_LNCEQN_SWSHUNT	1189
PURGE_OPF_LNCEQN_SWSHUNT_2	1190
PURGE_OPF_LNCEQN_TRAN	1191
PURGE_OPF_LNCEQN_VANG	1192
PURGE_OPF_LNCEQN_VANG_2	1193
PURGE_OPF_LNCEQN_VMAG	1194
PURGE_OPF_LNCEQN_VMAG_2	1195
PURGE_OPF_LOAD_INDV	1196
PURGE_OPF_LOAD_SUBSYS	1197
PURGE_OPF_PERRSV	1198
PURGE_OPF_PERRSV_GEN	1199
Fault Analysis	1202
Fault Analysis Operation	1203
ANSI	1203
ANSI_2	1205
ANSI_3	1207
ASCC	1210
ASCC_1A	1212
ASCC_2	1214
ASCC_3	1216
ASCC_SCFILE	1220
BKDY	1221
CHECK_SEQUENCE_DATA	1223
FLAT	1224
FLAT_2	1226
IECS	1229
IECS_2	1231

IECS_3	1234
IECS_4	1237
IECS_SCFILE	1241
NEWSEQ	1242
SCEQ	1243
SCGR	1245
SCMU	1247
SCMU_2	1254
SCOP	1261
SEQD	1263
SEQD_2	1264
SEQUENCE_NETWORK_SETUP	1265
SQEX	1266
Fault Analysis Data	1269
MBIDNCS	1269
SEQ_3_WIND_GROUNDING_DATA	1270
SEQ_3_WIND_WINDING_DATA	1271
SEQ_BRANCH_DATA	1272
SEQ_BRANCH_DATA_3	1274
SEQ_BUS_DATA	1276
SEQ_FIXED_SHUNT_DATA	1277
SEQ_INDUCTION_MACH_DATA	1278
SEQ_INDUCTION_MACH_DATA_2	1280
SEQ_LOAD_DATA	1282
SEQ_MACHINE_DATA	1284
SEQ_MACHINE_DATA_3	1286
SEQ_MACHINE_DATA_4	1288
SEQ_MACHINE_NCS_DATA	1290
SEQ_MACHINE_NCS_DATA_PURG	1292
SEQ_MUTUAL_DATA	1293
SEQ_NCS_FLT_CNTRB_CHNG	1295
SEQ_NCS_FLT_CNTRB_DATA	1296
SEQ_NCS_FLT_CNTRB_PURG	1297
SEQ_NCS_TABLE_DATA	1298
SEQ_NCS_TABLE_PURG	1299
SEQ_SWITCHED_SHUNT_DATA	1300
SEQ_SWITCHED_SHUNT_DATA_3	1302
SEQ_THREE_WINDING_DATA	1304
SEQ_THREE_WINDING_DATA_3	1306
SEQ_TWO_WINDING_DATA	1308
SEQ_TWO_WINDING_DATA_3	1310
Harmonics	1313
Harmonics Operation	1314
HARMONICS	1314
HAR_NEW	1316
HAR_PURG	1317
HAR_READ	1318
HAR_READX	1319
HAR_WRITE	1320
HAR_WRITEX	1321
Harmonics Data	1324

HAR_2TDC	1324
HAR_2TDC_CHNG	1325
HAR_2TDC_PURG	1326
HAR_BRN	1327
HAR_BRN_CHNG	1328
HAR_BRN_PURG	1329
HAR_CURSRC	1330
HAR_CURSRC_CHNG	1331
HAR_CURSRC_CHNG_NAME	1332
HAR_CURSRC_CHNG_ONEPT	1333
HAR_CURSRC_NAME	1334
HAR_CURSRC_ONEPT	1335
HAR_CURSRC_PURG	1336
HAR_CURSRC_PURG_ONEPT	1337
HAR_FACTS	1338
HAR_FACTS_CHNG	1339
HAR_FACTS_PURG	1340
HAR_IMPCHAR	1341
HAR_IMPCHAR_CHNG	1342
HAR_IMPCHAR_CHNG_NAME	1343
HAR_IMPCHAR_CHNG_ONEPT	1344
HAR_IMPCHAR_NAME	1345
HAR_IMPCHAR_ONEPT	1346
HAR_IMPCHAR_PURG	1347
HAR_IMPCHAR_PURG_ONEPT	1348
HAR_INDMC	1349
HAR_INDMC_CHNG	1350
HAR_INDMC_PURG	1351
HAR_LOAD	1352
HAR_LOAD_CHNG	1353
HAR_LOAD_PURG	1354
HAR_MACH	1355
HAR_MACH_CHNG	1356
HAR_MACH_PURG	1357
HAR_MTDC	1358
HAR_MTDC_CHNG	1359
HAR_MTDC_PURG	1360
HAR_TRN	1361
HAR_TRN_CHNG	1362
HAR_TRN_PURG	1363
HAR_VLTSRC	1364
HAR_VLTSRC_CHNG	1365
HAR_VLTSRC_CHNG_NAME	1366
HAR_VLTSRC_CHNG_ONEPT	1367
HAR_VLTSRC_NAME	1368
HAR_VLTSRC_ONEPT	1369
HAR_VLTSRC_PURG	1370
HAR_VLTSRC_PURG_ONEPT	1371
HAR_VSCDC	1372
HAR_VSCDC_CHNG	1373
HAR_VSCDC_PURG	1374

GIC	1377
GIC Operation	1378
GIC	1378
GIC_2	1381
GIC_3	1387
GIC_4	1393
GIC_5	1400
GIC_6	1407
GIC_7	1416
GIC_8	1425
GIC_BRANCH_EFIELD_NN	1436
GIC_EARTH1D_USR_PURG	1438
GIC_EFIELD_WAVESHAPE	1439
GIC_EFIELD_WAVESHAPE_REF	1440
GIC_EFIELD_WAVESHAPE_SUPP	1441
GIC_MVARLOSS_SCALING_FACTORS	1442
GIC_NEW	1443
GIC_PF_OPTIONS	1444
GIC_PURG	1446
GIC_READ	1447
GIC_READ_EFIELD_GRID	1448
GIC_THERMAL_IMPACT	1449
GIC_THERMAL_IMPACT_1	1450
GIC_WRITE	1451
GIC_WRITE_STN	1452
GIC Data	1455
GIC_2TDC	1455
GIC_2TDC_CHNG	1456
GIC_2TDC_PURG	1457
GIC_BRN	1458
GIC_BRN_CHNG	1460
GIC_BRN_PURG	1462
GIC_EARTH1D_USR	1463
GIC_EARTH1D_USR_CHNG	1464
GIC_FACTS	1465
GIC_FACTS_CHNG	1466
GIC_FACTS_PURG	1467
GIC_FXSH	1468
GIC_FXSH_CHNG	1469
GIC_FXSH_PURG	1470
GIC_LOAD	1471
GIC_LOAD_CHNG	1472
GIC_LOAD_PURG	1473
GIC_MTDC	1474
GIC_MTDC_CHNG	1475
GIC_MTDC_PURG	1476
GIC_SUBSTN	1477
GIC_SUBSTN_CHNG	1478
GIC_SUBSTN_PURG	1479
GIC_SWSH	1480
GIC_SWSH_CHNG	1481

GIC_SWSH_PURG	1482
GIC_TRN	1483
GIC_TRN_CHNG	1486
GIC_TRN_PURG	1489
GIC_VSCDC	1490
GIC_VSCDC_CHNG	1491
GIC_VSCDC_PURG	1492
Dynamics Simulation	1495
Dynamic Simulation Operation	1496
ADDMODELLIBRARY	1496
ASTR	1497
AULIST	1500
CHANGE_CHANNEL_OUT_FILE	1501
CHANGE_CHRICN	1502
CHANGE_CON	1503
CHANGE_GREF	1504
CHANGE_ICON	1505
CHANGE_STATE	1506
CHANGE_SWSREF	1507
CHANGE_SWSREF_2	1508
CHANGE_VAR	1509
CHANGE_VREF	1510
DCLIST	1511
DLST	1512
DOCU	1513
DROPMODELLIBRARY	1516
DROPMODELPROGRAM	1517
DYDA	1518
DYNAMICSMODE	1521
DYNAMICS_SOLUTION_PARAMS	1522
DYNAMICS_SOLUTION_PARAM_2	1524
DYNEXPORTCSV	1526
DYRE_ADD	1527
DYRE_NEW	1528
ERUN	1529
ESTR_OPEN_CIRCUIT_TEST	1530
ESTR_RESPONSE_RATIO_TEST	1531
FCLIST	1533
GRUN	1534
GSTR	1535
INCREMENT_GREF	1536
INCREMENT_SWSREF	1537
INCREMENT_SWSREF_2	1538
INCREMENT_VREF	1539
LDLIST	1540
LOAD_ARRAY_CHANNEL	1541
MLST	1542
MRUN	1544
MSTR	1545
POWERFLOWMODE	1546
PSAS	1547

RLLIST	1548
RSTR	1549
RUN	1550
RWDY	1551
SET_CHNFIL_TYPE	1552
SET_DISABLE_RUN	1553
SET_FREQ_RELAY_V_THRESH	1554
SET_GENANG	1555
SET_GENANG_2	1556
SET_GENANG_3	1558
SET_GENANG_SUBSYS_FLAG	1560
SET_GENPWR	1561
SET_GENSPDEV	1562
SET_GENSPDEV_SUBSYS_FLAG	1563
SET_LOAD_MODEL_THRESH	1564
SET_MODEL_DEBUG_OUTPUT_FLAG	1565
SET_NETFRQ	1566
SET_NEXT_CHANNEL	1567
SET_NEXT_ICON	1568
SET_NEXT_VAR	1569
SET_OSSCAN	1570
SET_OSSCAN_2	1571
SET_OSSCAN_SUBSYS_FLAG	1572
SET_RELANG	1573
SET_RELSCN	1575
SET_RELSCN_SUBSYS_FLAG	1576
SET_VLTSCN	1577
SET_VLTSCN_SUBSYS_FLAG	1578
SET_VOLTAGE_DIP_CHECK	1579
SET_VOLTAGE_REC_CHECK	1580
SET_VOLT_VIOL_SUBSYS_FLAG	1582
SET_ZSORCE_RECONCILE_FLAG	1583
SIZE_DS	1584
SNAP	1585
STRT	1586
STRT_2	1587
SWSLIST	1588
TRIG_VOLT_VIOLATION_CHECK	1589
WNLIST	1590
Output Channel Operations	1593
Dynamic Simulation Output Channel Operation	1593
CHANGE_CHANNEL	1593
CHSB	1594
CRT_PLOT_CHANNEL	1597
DELETE_ALL_PLOT_CHANNELS	1598
DMPC	1599
LIST_CHANNEL_MODELS	1601
REMOVE_UNUSED_CHAN_MODELS	1602
Assign Machine Quantities to Output Channels	1604
MACHINE_APP_R_X_CHANNEL	1604
MACHINE_ARRAY_CHANNEL	1606

MACHINE_ITERM_CHANNEL	1608
Assign Branch Quantities to Output Channels	1611
BRANCH_APP_R_X_CHANNEL	1611
BRANCH_MVA_CHANNEL	1613
BRANCH_P_AND_Q_CHANNEL	1615
BRANCH_P_CHANNEL	1617
THREE_WND_APP_R_X_CHANNEL	1619
THREE_WND_MVA_CHANNEL	1621
THREE_WND_P_AND_Q_CHANNEL	1623
THREE_WND_P_CHANNEL	1625
Assign Other Quantities to Output Channels	1628
BUS_FREQUENCY_CHANNEL	1628
STATE_CHANNEL	1629
VAR_CHANNEL	1630
VOLTAGE_AND_ANGLE_CHANNEL	1631
VOLTAGE_CHANNEL	1633
Plant Related Models	1636
ADD_PLANT_MODEL	1636
CHANGE_PLMOD_CHRICN	1638
CHANGE_PLMOD_CON	1639
CHANGE_PLMOD_DATA	1640
CHANGE_PLMOD_ICON	1642
CHANGE_PLMOD_VAR	1643
GMB_ADD_PLANT_MODEL	1644
PLMOD_CONSISTENCY	1646
PLMOD_PACK	1647
PLMOD_REMOVE	1648
PLMOD_STATUS	1649
PLMOD_UNCONNECTED	1650
PLMOD_USER	1651
Wind Related Models	1653
ADD_WIND_MODEL	1653
CHANGE_WNMOD_CHRICN	1655
CHANGE_WNMOD_CON	1656
CHANGE_WNMOD_ICON	1657
CHANGE_WNMOD_VAR	1658
WNMOD_CONSISTENCY	1659
WNMOD_PACK	1660
WNMOD_REMOVE	1661
WNMOD_STATUS	1662
WNMOD_UNCONNECTED	1663
WNMOD_USER	1664
Load Related Models	1666
ADD_LOAD_MODEL	1666
CHANGE_LDMOD_CHRICN	1668
CHANGE_LDMOD_CON	1669
CHANGE_LDMOD_DATA	1670
CHANGE_LDMOD_ICON	1672
CHANGE_LDMOD_VAR	1673
LDMOD_PACK	1674
LDMOD_REMOVE	1675

LDMOD_STATUS	1676
LDMOD_STATUS2	1677
LDMOD_UNCONNECTED	1678
LDMOD_USER	1679
Line Relay Models	1681
ADD_RELAY_MODEL	1681
CHANGE_RLMOD_CHRICN	1683
CHANGE_RLMOD_CON	1684
CHANGE_RLMOD_DATA	1685
CHANGE_RLMOD_ICON	1687
CHANGE_RLMOD_VAR	1688
RLMOD_PACK	1689
RLMOD_REMOVE	1690
RLMOD_STATUS	1691
RLMOD_UNCONNECTED	1692
RLMOD_USER	1693
DC Line Related Models	1695
ADD_MTDCLINE_MODEL	1695
ADD_TTDCLINE_MODEL	1697
ADD_VSDCLINE_MODEL	1699
CHANGE_MTDCLMOD_CHRICN	1700
CHANGE_MTDCLMOD_CON	1701
CHANGE_MTDCLMOD_DATA	1702
CHANGE_MTDCLMOD_ICON	1704
CHANGE_MTDCLMOD_VAR	1705
CHANGE_TTDCLMOD_CHRICN	1706
CHANGE_TTDCLMOD_CON	1707
CHANGE_TTDCLMOD_DATA	1708
CHANGE_TTDCLMOD_ICON	1710
CHANGE_TTDCLMOD_VAR	1711
CHANGE_VSDCLMOD_CHRICN	1712
CHANGE_VSDCLMOD_CON	1713
CHANGE_VSDCLMOD_DATA	1714
CHANGE_VSDCLMOD_ICON	1716
CHANGE_VSDCLMOD_VAR	1717
DCLMOD_PACK	1718
DCLMOD_UNCONNECTED	1719
DCLMOD_USER	1720
MTDCLMOD_REMOVE	1721
MTDCLMOD_STATUS	1722
TTDCLMOD_REMOVE	1723
TTDCLMOD_STATUS	1724
VSDCLMOD_REMOVE	1725
VSDCLMOD_STATUS	1726
FACTS Device Models	1728
ADD_FACTS_DEVICE_MODEL	1728
CHANGE_FCTMOD_CHRICN	1730
CHANGE_FCTMOD_CON	1731
CHANGE_FCTMOD_DATA	1732
CHANGE_FCTMOD_ICON	1734
CHANGE_FCTMOD_VAR	1735

FCTMOD_PACK	1736
FCTMOD_REMOVE	1737
FCTMOD_STATUS	1738
FCTMOD_UNCONNECTED	1739
FCTMOD_USER	1740
GMB_ADD_FACTS_DEV_MODEL	1741
Switched Shunt Models	1744
ADD_SWSHUNT_MODEL	1744
ADD_SWSHUNT_MODEL_2	1746
CHANGE_SWSMOD_CHRICN	1748
CHANGE_SWSMOD_CHRICN_2	1749
CHANGE_SWSMOD_CON	1750
CHANGE_SWSMOD_CON_2	1751
CHANGE_SWSMOD_ICON	1752
CHANGE_SWSMOD_ICON_2	1753
CHANGE_SWSMOD_VAR	1754
CHANGE_SWSMOD_VAR_2	1755
GMB_ADD_SWSHUNT_MODEL	1756
GMB_ADD_SWSHUNT_MODEL_2	1758
SWSMOD_PACK	1760
SWSMOD_REMOVE	1761
SWSMOD_REMOVE_2	1762
SWSMOD_STATUS	1763
SWSMOD_STATUS_2	1764
SWSMOD_UNCONNECTED	1765
SWSMOD_USER	1766
Induction Machine Models	1768
ADD_INDMAC_MODEL	1768
CHANGE_IMMOD_CHRICN	1770
CHANGE_IMMOD_CON	1771
CHANGE_IMMOD_ICON	1772
CHANGE_IMMOD_VAR	1773
IMMOD_PACK	1774
IMMOD_REMOVE	1775
IMMOD_STATUS	1776
IMMOD_UNCONNECTED	1777
IMMOD_USER	1778
CCT Models	1780
ADD_CCT2DCO_MODEL	1780
ADD_CCT2WTD_MODEL	1782
ADD_CCT3WTD_MODEL	1784
ADD_CCTBRND_MODEL	1786
ADD_CCTBRNO_MODEL	1788
ADD_CCTBUSO_MODEL	1790
ADD_CCTMCNO_MODEL	1791
ADD_CCTMCNP_MODEL	1793
ADD_CCTMSCO_MODEL	1795
ADD_CCTSWSO_MODEL	1796
ADD_CCTSWSO_MODEL_2	1798
CCT2DCOMOD_REMOVE	1800
CCT2DCOMOD_STATUS	1801

CCT2DCO_LIST	1802
CCT2WTDMOD_REMOVE	1803
CCT2WTDMOD_STATUS	1804
CCT2WTD_LIST	1805
CCT3WTDMOD_REMOVE	1806
CCT3WTDMOD_STATUS	1807
CCT3WTD_LIST	1808
CCTBRNDMOD_REMOVE	1809
CCTBRNDMOD_STATUS	1810
CCTBRND_LIST	1811
CCTBRNOMOD_REMOVE	1812
CCTBRNOMOD_STATUS	1813
CCTBRNO_LIST	1814
CCTBUSOMOD_REMOVE	1815
CCTBUSOMOD_STATUS	1816
CCTBUSO_LIST	1817
CCTMCNOMOD_REMOVE	1818
CCTMCNOMOD_STATUS	1819
CCTMCNO_LIST	1820
CCTMCNPMOD_REMOVE	1821
CCTMCNPMOD_STATUS	1822
CCTMCNP_LIST	1823
CCTMOD_PACK	1824
CCTMOD_USER	1825
CCTMSCOMOD_REMOVE	1826
CCTMSCOMOD_STATUS	1827
CCTMSCO_LIST	1828
CCTSWSOMOD_REMOVE	1829
CCTSWSOMOD_REMOVE_2	1830
CCTSWSOMOD_STATUS	1831
CCTSWSOMOD_STATUS_2	1832
CCTSWSO_LIST	1833
CHANGE_CCT2DCOMOD_CHRICN	1834
CHANGE_CCT2DCOMOD_CON	1835
CHANGE_CCT2DCOMOD_ICON	1836
CHANGE_CCT2DCOMOD_VAR	1837
CHANGE_CCT2WTDMOD_CHRICN	1838
CHANGE_CCT2WTDMOD_CON	1839
CHANGE_CCT2WTDMOD_ICON	1840
CHANGE_CCT2WTDMOD_VAR	1841
CHANGE_CCT3WTDMOD_CHRICN	1842
CHANGE_CCT3WTDMOD_CON	1843
CHANGE_CCT3WTDMOD_ICON	1844
CHANGE_CCT3WTDMOD_VAR	1845
CHANGE_CCTBRNDMOD_CHRICN	1846
CHANGE_CCTBRNDMOD_CON	1847
CHANGE_CCTBRNDMOD_ICON	1848
CHANGE_CCTBRNDMOD_VAR	1849
CHANGE_CCTBRNOMOD_CHRICN	1850
CHANGE_CCTBRNOMOD_CON	1851
CHANGE_CCTBRNOMOD_ICON	1852

CHANGE_CCTBRNOMOD_VAR	1853
CHANGE_CCTBUSOMOD_CHRICN	1854
CHANGE_CCTBUSOMOD_CON	1855
CHANGE_CCTBUSOMOD_ICON	1856
CHANGE_CCTBUSOMOD_VAR	1857
CHANGE_CCTMCNOMOD_CHRICN	1858
CHANGE_CCTMCNOMOD_CON	1859
CHANGE_CCTMCNOMOD_ICON	1860
CHANGE_CCTMCNOMOD_VAR	1861
CHANGE_CCTMCNPMOD_CHRICN	1862
CHANGE_CCTMCNPMOD_CON	1863
CHANGE_CCTMCNPMOD_ICON	1864
CHANGE_CCTMCNPMOD_VAR	1865
CHANGE_CCTMSCOMOD_CHRICN	1866
CHANGE_CCTMSCOMOD_CON	1867
CHANGE_CCTMSCOMOD_ICON	1868
CHANGE_CCTMSCOMOD_VAR	1869
CHANGE_CCTSWSOMOD_CHRICN	1870
CHANGE_CCTSWSOMOD_CHRICN_2	1871
CHANGE_CCTSWSOMOD_CON	1872
CHANGE_CCTSWSOMOD_CON_2	1873
CHANGE_CCTSWSOMOD_ICON	1874
CHANGE_CCTSWSOMOD_ICON_2	1875
CHANGE_CCTSWSOMOD_VAR	1876
CHANGE_CCTSWSOMOD_VAR_2	1877
Auxiliary Signal Models	1879
ADD_FCTSAUXSIGNAL_MODEL	1879
ADD_MTDCAUXSIGNAL_MODEL	1881
ADD_TTDCAUXSIGNAL_MODEL	1883
ADD_VSDCAUXSIGNAL_MODEL	1885
AUXMOD_PACK	1887
AUXMOD_UNCONNECTED	1888
AUXMOD_USER	1889
CHANGE_FCTSAUXMOD_CHRICN	1890
CHANGE_FCTSAUXMOD_CON	1892
CHANGE_FCTSAUXMOD_DATA	1894
CHANGE_FCTSAUXMOD_ICON	1896
CHANGE_FCTSAUXMOD_VAR	1898
CHANGE_MTDCAUXMOD_CHRICN	1900
CHANGE_MTDCAUXMOD_CON	1902
CHANGE_MTDCAUXMOD_DATA	1904
CHANGE_MTDCAUXMOD_ICON	1906
CHANGE_MTDCAUXMOD_VAR	1908
CHANGE_TTDCAUXMOD_CHRICN	1910
CHANGE_TTDCAUXMOD_CON	1912
CHANGE_TTDCAUXMOD_DATA	1914
CHANGE_TTDCAUXMOD_ICON	1916
CHANGE_TTDCAUXMOD_VAR	1918
CHANGE_VSDCAUXMOD_CHRICN	1920
CHANGE_VSDCAUXMOD_CON	1921
CHANGE_VSDCAUXMOD_DATA	1922

CHANGE_VSDCAUXMOD_ICON	1924
CHANGE_VSDCAUXMOD_VAR	1925
FCTSAUXMOD_REMOVE	1926
FCTSAUXMOD_STATUS	1927
MTDCAUXMOD_REMOVE	1928
MTDCAUXMOD_STATUS	1929
TTDCAUXMOD_REMOVE	1930
TTDCAUXMOD_STATUS	1931
VSDCAUXMOD_REMOVE	1932
VSDCAUXMOD_STATUS	1933
Set Disturbance	1935
DIST_3PHASE_BUS_FAULT	1935
DIST_3WIND_CLOSE	1937
DIST_3WIND_FAULT	1938
DIST_3WIND_TRIP	1940
DIST_BRANCH_CLOSE	1941
DIST_BRANCH_FAULT	1942
DIST_BRANCH_TRIP	1944
DIST_BUS_FAULT	1945
DIST_BUS_FAULT_2	1946
DIST_BUS_FAULT_3	1948
DIST_BUS_TRIP	1950
DIST_CLEAR_FAULT	1951
DIST_MACHINE_TRIP	1953
DIST_SCMU_FAULT	1954
DIST_SCMU_FAULT_2	1956
DIST_SCMU_FAULT_3	1958
DIST_SPCB_FAULT	1960
DIST_SPCB_FAULT_2	1962
Subsystem Definition	1965
Area Subsystems	1966
ASYS	1966
ASYSDEF	1967
ASYSINIT	1968
Bus Subsystems	1970
BSYS	1970
BSYSADD	1972
BSYSDEF	1974
BSYSDELO	1975
BSYSINIT	1976
BSYSMEM	1977
BSYSO	1978
BSYSRCL	1979
Owner Subsystems	1981
OSYS	1981
OSYSDEF	1982
OSYSINIT	1983
Zone Subsystems	1985
ZSYS	1985
ZSYSDEF	1986
ZSYSINIT	1987

Diagram View	1989
CHANGEDIAGCONTOUR	1990
CHECKDIAGFILE	1992
CLOSEDIAGFILE	1993
DELETEDIAGCONTOUR	1994
ENABLEDIAGCONTOUR	1995
EXPORTBUSLOCFILE	1997
EXPORTBUSLOCFILE_2	1998
EXPORTIMAGEFILE	1999
EXPORTIMAGEFILE_2	2000
GEXMBUS	2001
GROWBUS	2002
GROWBUSLEVELS	2003
GROWDIAGRAM	2004
GROWDIAGRAM_2	2005
GROWSTATION	2007
GRPG	2008
IMPORTDRAWFILE	2009
IMPORTIMAGEFILE	2010
NEWDIAGFILE	2011
NEXTDIAGFILEDATASET	2012
OPENACCFILE	2013
OPENACCFILE_2	2014
OPENBUSLOCFILE	2015
OPENDIAGFILE	2016
PREVDIAGFILEDATASET	2017
PRINTDIAGFILE	2018
PRINTDIAGFILE_2	2019
REFRESHDIAGCONTOUR	2020
REFRESHDIAGFILE	2021
RENUMDIAGFILE	2022
SAVEDIAGFILE	2023
SETDIAGAUTOFILE	2024
SETDIAGFONT	2025
SETDIAGPREC	2026
SETDIAGPREC_2	2027
SETDIAGPROP	2028
SETDIAGPROP_2	2031
SETDIAGPROP_3	2034
SETDIAGPROP_4	2037
SETDIAGPROP_5	2040
SETDIAGRESACCC	2043
SETDIAGRESACCC_2	2044
SETDIAGRESACCC_3	2045
SETDIAGRESASCC	2046
SETDIAGRESASCC_2	2048
SETDIAGRESASCC_3	2050
SETDIAGRESDATA	2052
SETDIAGRESDATA_2	2055
SETDIAGRESDATA_3	2056
SETDIAGRESDYN	2057

SETDIAGRESDYN_2	2058
SETDIAGRESGDIF	2059
SETDIAGRESIEC	2062
SETDIAGRESIEC_2	2064
SETDIAGRESIEC_3	2066
SETDIAGRESMUST	2068
SETDIAGRESOPF	2069
SETDIAGRESOPF_2	2070
SETDIAGRESOPF_3	2071
SETDIAGRESPFLOWCHECK	2072
SETDIAGRESPFLOWCHECK_2	2076
SETDIAGRESPFLOWCHECK_3	2079
SETDIAGRESPFLOWOPTIONS	2082
SETDIAGRESPFLOWOPTIONS_2	2084
SETDIAGRESPFLOWOPTIONS_3	2086
SETDIAGRESREL	2088
SETDIAGRESREL_2	2090
SETDIAGRESREL_3	2092
SETDIAGRESSCGR	2094
SETDIAGRESTYPEACC	2097
SETDIAGRESTYPEASCC	2098
SETDIAGRESTYPEDATA	2099
SETDIAGRESTYPEDYN	2100
SETDIAGRESTYPEGDIF	2101
SETDIAGRESTYPEGIC	2102
SETDIAGRESTYPEHARM	2103
SETDIAGRESTYPEIEC	2104
SETDIAGRESTYPEMUST	2105
SETDIAGRESTYPEOPF	2106
SETDIAGRESTYPEPFLOW	2107
SETDIAGRESTYPEPEREL	2108
SETDIAGRESTYPESCGR	2109
SETDIAGRESVRCS	2110
SETDIAGRESVRCS_2	2113
SETDIAGTITLE	2116
SWITCHDIAGFILEDATASET	2117
UPDATEBUSLOCDIAGFILE	2118
Single Element Data	2119
APIERRSTR	2120
AR DAT	2121
ARE DAT	2123
AREINT	2124
ARENAM	2125
ARENUM	2126
AREUSE	2127
ARIT OJ	2128
BRNCUR	2129
BRNDAT	2130
BRNDT2	2132
BRNFLO	2134
BRNINT	2135

BRNMSC	2137
BRNMVA	2139
BRNNAM	2140
BRNSTT	2141
BSYSISDEF	2142
BUSDAT	2143
BUSDT1	2144
BUSDT2	2146
BUSEXS	2148
BUSINT	2149
BUSMSM	2150
BUSORDPOS	2151
BUSSECTDAT	2152
BUSSECTDT1	2153
BUSSECTDT2	2155
BUSSECTEXS	2157
BUSSECTINT	2158
CCTMDLNAM_2DCO	2159
CCTMDLNAM_2WTD	2160
CCTMDLNAM_3WTD	2161
CCTMDLNAM_BRND	2162
CCTMDLNAM_BRNO	2163
CCTMDLNAM_BUSO	2164
CCTMDLNAM_MCNO	2165
CCTMDLNAM_MCNP	2166
CCTMDLNAM_MSCO	2167
CCTMDLNAM_SWSO_2	2168
CCTMIND_2DCO	2169
CCTMIND_2WTD	2170
CCTMIND_3WTD	2172
CCTMIND_BRND	2174
CCTMIND_BRNO	2176
CCTMIND_BUSO	2178
CCTMIND_MCNO	2179
CCTMIND_MCNP	2180
CCTMIND_MSCO	2181
CCTMIND_SWSO	2182
CCTMIND_SWSO_2	2184
CHKTRE	2186
CHNVAL	2187
DC2AUXMIND	2188
DC2AUXMNAM	2190
DC2DAT	2191
DC2DAT_2	2193
DC2INT	2195
DC2INT_2	2196
DC2MIND	2197
DC2MNAM	2199
DCNAUXMIND	2200
DCNAUXMNAM	2202
DCNCIN	2203

DCNCIN_2	2204
DCNDAT	2205
DCNDAT_2	2207
DCNINT	2209
DCNINT_2	2210
DCNMIND	2211
DCNMNAM	2213
DSCVAL	2214
DSIVAL	2215
DSRVAL	2216
FCDAUXMIND	2217
FCDAUXMNAM	2219
FCDDAT	2220
FCDDAT_2	2223
FCDINT	2226
FCDINT_2	2227
FCDMIND	2228
FCDMNAM	2229
FXSDT1	2230
FXSDT2	2232
FXSINT	2234
GENCNV	2235
GENDAT	2236
GENDT1	2237
GENSECTDAT	2238
GENSECTDT1	2239
GETHOMEPATH	2240
GET_MSTATE	2241
GNECHR	2242
GNEDAT	2243
GNEINT	2244
INDDT1	2246
INDDT2	2248
INDINT	2250
INI2DC	2252
INIBRN	2253
INIBRN_2	2254
INIBRX	2255
INIBRX_2	2256
INIBUS	2257
INIBUS_2	2258
INIBUX	2259
INIFAX	2260
INIFXS	2261
INIIND	2262
INILOD	2263
INIMAC	2264
INIMDC	2265
INIMSL	2266
ININAM	2267
ININAM_2	2268

ININAX	2269
INISTABUSSECT	2270
INISTANODE	2271
INISTASWDEV	2272
INISWS	2273
INITIE	2274
INITIX	2275
INIVSC	2276
ISLAND	2277
ITERAT	2278
LMODIND	2279
LMODNAM	2281
LODCNV	2282
LODDT1	2283
LODDT2	2285
LODIND	2287
LODINT	2288
LODTYPE	2289
MACCHR	2290
MACDAT	2291
MACDT2	2293
MACIND	2295
MACINT	2296
MACSTT	2298
MAXMSM	2299
MDLIND	2300
MDLLIBCNT	2302
MDLNAM	2303
MDLPGMCNT	2304
NATONO	2305
NOTONA	2306
NOTONASECT	2307
NXT2DC	2308
NXTBRN	2309
NXTBRN3	2310
NXTBRN3_2	2311
NXTBRN_2	2312
NXTBUS	2313
NXTBUS_2	2314
NXTFAX	2315
NXTFXS	2316
NXTIND	2317
NXTLOD	2318
NXTMAC	2319
NXTMDC	2320
NXTMSL	2321
NXTSTABUSSECT	2322
NXTSTANODE	2323
NXTSTASWDEV	2324
NXTSWS	2325
NXTTIE	2326

NXTTIE3	2327
NXTVSC	2328
OKSTRT	2329
OPENUN	2330
ORDBUS	2331
ORDBUSSECT	2332
OWNDAT	2333
OWNNAM	2335
OWNNUM	2336
OWNUSE	2337
PRMDAT	2338
PRMINT	2340
RATCHR	2341
RMODIND	2342
RMODNAM	2344
SBSGTBKV	2345
SC3WND	2346
SCBRN2	2348
SCBUS2	2349
SCDONE	2351
SCINIT	2352
SCMAC2	2353
SELCTR	2354
SETHOMEPATH	2355
SFILES	2356
SLMODIND	2357
SLMODNAM	2359
SOLSTR	2360
SOLVED	2361
SOLVED_CA	2362
STADAT	2363
STAINTE	2364
STANAME	2365
STANODEINT	2366
STANODENAME	2367
STAREA	2368
STASWDEV DAT	2369
STASWDEVINT	2371
STASWDEVNAME	2372
STBSKV	2373
STZONE	2374
SWSBLK	2375
SWSBLK_2	2376
SWSBLZ	2378
SWSBLZ2	2379
SWS DAT	2380
SWS DAT_2	2381
SWS DT1	2382
SWSINT	2383
SWSINT_2	2384
SWSMIND	2385

SWSMIND_2	2387
SWSMNAM	2389
SWSMNAM_2	2390
SYSMSM	2391
SYSMVA	2392
SYSTOT	2393
TITLDT	2394
TOTBUS	2395
TR3DAT	2396
TR3DT2	2397
TR3INT	2399
TR3NAM	2401
TRNDAT	2402
TRXDAT	2403
VOLTAGEDROOPDATA	2404
VOLTAGEDROOPINT	2405
VSCAUXMIND	2406
VSCAUXMNAM	2408
VSCCDT	2409
VSCCIN	2411
VSCINT	2412
VSCMIND	2413
VSCMNAM	2414
WINDMIND	2415
WINDMNAM	2417
WNDDAT	2418
WNDDT2	2420
WNDINT	2422
XFRDAT	2424
XFRINT	2426
XFRNAM	2428
ZNDAT	2429
ZNITOI	2431
ZONNAM	2432
ZONNUM	2433
ZONUSE	2434
Extension Data Access	2435
GET_EXT_ACLINE_CHAR	2436
GET_EXT_ACLINE_INT	2437
GET_EXT_ACLINE_LOGICAL	2438
GET_EXT_ACLINE_REAL	2439
GET_EXT_AREA_CHAR	2440
GET_EXT_AREA_INT	2441
GET_EXT_AREA_LOGICAL	2442
GET_EXT_AREA_REAL	2443
GET_EXT_BUS_CHAR	2444
GET_EXT_BUS_INT	2445
GET_EXT_BUS_LOGICAL	2446
GET_EXT_BUS_REAL	2447
GET_EXT_CHAR	2448
GET_EXT_FACTS_CHAR	2449

GET_EXT_FACTS_INT	2450
GET_EXT_FACTS_LOGICAL	2451
GET_EXT_FACTS_REAL	2452
GET_EXT_FIXSHUNT_CHAR	2453
GET_EXT_FIXSHUNT_INT	2454
GET_EXT_FIXSHUNT_LOGICAL	2455
GET_EXT_FIXSHUNT_REAL	2456
GET_EXT_GENERATOR_CHAR	2457
GET_EXT_GENERATOR_INT	2458
GET_EXT_GENERATOR_LOGICAL	2459
GET_EXT_GENERATOR_REAL	2460
GET_EXT_GNE_CHAR	2461
GET_EXT_GNE_INT	2462
GET_EXT_GNE_LOGICAL	2463
GET_EXT_GNE_REAL	2464
GET_EXT_IATRANS_CHAR	2465
GET_EXT_IATRANS_INT	2466
GET_EXT_IATRANS_LOGICAL	2467
GET_EXT_IATRANS_REAL	2468
GET_EXT_INDMACH_CHAR	2469
GET_EXT_INDMACH_INT	2470
GET_EXT_INDMACH_LOGICAL	2471
GET_EXT_INDMACH_REAL	2472
GET_EXT_INT	2473
GET_EXT_LOAD_CHAR	2474
GET_EXT_LOAD_INT	2475
GET_EXT_LOAD_LOGICAL	2476
GET_EXT_LOAD_REAL	2477
GET_EXT_LOGICAL	2478
GET_EXT_MSLINE_CHAR	2479
GET_EXT_MSLINE_INT	2480
GET_EXT_MSLINE_LOGICAL	2481
GET_EXT_MSLINE_REAL	2482
GET_EXT_NTERMDC_CHAR	2483
GET_EXT_NTERMDC_INT	2484
GET_EXT_NTERMDC_LOGICAL	2485
GET_EXT_NTERMDC_REAL	2486
GET_EXT_OWNER_CHAR	2487
GET_EXT_OWNER_INT	2488
GET_EXT_OWNER_LOGICAL	2489
GET_EXT_OWNER_REAL	2490
GET_EXT_RATING_CHAR	2491
GET_EXT_RATING_INT	2492
GET_EXT_RATING_LOGICAL	2493
GET_EXT_RATING_REAL	2494
GET_EXT_REAL	2495
GET_EXT_ROWCOUNT	2496
GET_EXT_SUBNODE_CHAR	2497
GET_EXT_SUBNODE_INT	2498
GET_EXT_SUBNODE_LOGICAL	2499
GET_EXT_SUBNODE_REAL	2500

GET_EXT_SUBSWD_CHAR	2501
GET_EXT_SUBSWD_INT	2502
GET_EXT_SUBSWD_LOGICAL	2503
GET_EXT_SUBSWD_REAL	2504
GET_EXT_SUB_CHAR	2505
GET_EXT_SUB_INT	2506
GET_EXT_SUB_LOGICAL	2507
GET_EXT_SUB_REAL	2508
GET_EXT_SWSHUNT_CHAR	2509
GET_EXT_SWSHUNT_INT	2510
GET_EXT_SWSHUNT_LOGICAL	2511
GET_EXT_SWSHUNT_REAL	2512
GET_EXT_SYSSWD_CHAR	2513
GET_EXT_SYSSWD_INT	2514
GET_EXT_SYSSWD_LOGICAL	2515
GET_EXT_SYSSWD_REAL	2516
GET_EXT_TRANSFORMER_CHAR	2517
GET_EXT_TRANSFORMER_INT	2518
GET_EXT_TRANSFORMER_LOGICAL	2519
GET_EXT_TRANSFORMER_REAL	2520
GET_EXT_TWOTERMDC_CHAR	2521
GET_EXT_TWOTERMDC_INT	2522
GET_EXT_TWOTERMDC_LOGICAL	2523
GET_EXT_TWOTERMDC_REAL	2524
GET_EXT_VSCDC_CHAR	2525
GET_EXT_VSCDC_INT	2526
GET_EXT_VSCDC_LOGICAL	2527
GET_EXT_VSCDC_REAL	2528
GET_EXT_ZONE_CHAR	2529
GET_EXT_ZONE_INT	2530
GET_EXT_ZONE_LOGICAL	2531
GET_EXT_ZONE_REAL	2532
SET_EXT_ACLINE_CHAR	2533
SET_EXT_ACLINE_INT	2534
SET_EXT_ACLINE_LOGICAL	2535
SET_EXT_ACLINE_REAL	2536
SET_EXT_AREA_CHAR	2537
SET_EXT_AREA_INT	2538
SET_EXT_AREA_LOGICAL	2539
SET_EXT_AREA_REAL	2540
SET_EXT_BUS_CHAR	2541
SET_EXT_BUS_INT	2542
SET_EXT_BUS_LOGICAL	2543
SET_EXT_BUS_REAL	2544
SET_EXT_CHAR	2545
SET_EXT_FACTS_CHAR	2546
SET_EXT_FACTS_INT	2547
SET_EXT_FACTS_LOGICAL	2548
SET_EXT_FACTS_REAL	2549
SET_EXT_FIXSHUNT_CHAR	2550
SET_EXT_FIXSHUNT_INT	2551

SET_EXT_FIXSHUNT_LOGICAL	2552
SET_EXT_FIXSHUNT_REAL	2553
SET_EXT_GENERATOR_CHAR	2554
SET_EXT_GENERATOR_INT	2555
SET_EXT_GENERATOR_LOGICAL	2556
SET_EXT_GENERATOR_REAL	2557
SET_EXT_GNE_CHAR	2558
SET_EXT_GNE_INT	2559
SET_EXT_GNE_LOGICAL	2560
SET_EXT_GNE_REAL	2561
SET_EXT_IATRANS_CHAR	2562
SET_EXT_IATRANS_INT	2563
SET_EXT_IATRANS_LOGICAL	2564
SET_EXT_IATRANS_REAL	2565
SET_EXT_INDMACH_CHAR	2566
SET_EXT_INDMACH_INT	2567
SET_EXT_INDMACH_LOGICAL	2568
SET_EXT_INDMACH_REAL	2569
SET_EXT_INT	2570
SET_EXT_LOAD_CHAR	2571
SET_EXT_LOAD_INT	2572
SET_EXT_LOAD_LOGICAL	2573
SET_EXT_LOAD_REAL	2574
SET_EXT_LOGICAL	2575
SET_EXT_MSLINE_CHAR	2576
SET_EXT_MSLINE_INT	2577
SET_EXT_MSLINE_LOGICAL	2578
SET_EXT_MSLINE_REAL	2579
SET_EXT_NTERMDC_CHAR	2580
SET_EXT_NTERMDC_INT	2581
SET_EXT_NTERMDC_LOGICAL	2582
SET_EXT_NTERMDC_REAL	2583
SET_EXT_OWNER_CHAR	2584
SET_EXT_OWNER_INT	2585
SET_EXT_OWNER_LOGICAL	2586
SET_EXT_OWNER_REAL	2587
SET_EXT_RATING_CHAR	2588
SET_EXT_RATING_INT	2589
SET_EXT_RATING_LOGICAL	2590
SET_EXT_RATING_REAL	2591
SET_EXT_REAL	2592
SET_EXT_SUBNODE_CHAR	2593
SET_EXT_SUBNODE_INT	2594
SET_EXT_SUBNODE_LOGICAL	2595
SET_EXT_SUBNODE_REAL	2596
SET_EXT_SUBSWD_CHAR	2597
SET_EXT_SUBSWD_INT	2598
SET_EXT_SUBSWD_LOGICAL	2599
SET_EXT_SUBSWD_REAL	2600
SET_EXT_SUB_CHAR	2601
SET_EXT_SUB_INT	2602

SET_EXT_SUB_LOGICAL	2603
SET_EXT_SUB_REAL	2604
SET_EXT_SWSHUNT_CHAR	2605
SET_EXT_SWSHUNT_INT	2606
SET_EXT_SWSHUNT_LOGICAL	2607
SET_EXT_SWSHUNT_REAL	2608
SET_EXT_SYSSWD_CHAR	2609
SET_EXT_SYSSWD_INT	2610
SET_EXT_SYSSWD_LOGICAL	2611
SET_EXT_SYSSWD_REAL	2612
SET_EXT_TRANSFORMER_CHAR	2613
SET_EXT_TRANSFORMER_INT	2614
SET_EXT_TRANSFORMER_LOGICAL	2615
SET_EXT_TRANSFORMER_REAL	2616
SET_EXT_TWOTERMDC_CHAR	2617
SET_EXT_TWOTERMDC_INT	2618
SET_EXT_TWOTERMDC_LOGICAL	2619
SET_EXT_TWOTERMDC_REAL	2620
SET_EXT_VSCDC_CHAR	2621
SET_EXT_VSCDC_INT	2622
SET_EXT_VSCDC_LOGICAL	2623
SET_EXT_VSCDC_REAL	2624
SET_EXT_ZONE_CHAR	2625
SET_EXT_ZONE_INT	2626
SET_EXT_ZONE_LOGICAL	2627
SET_EXT_ZONE_REAL	2628
Subsystem Data Retrieval	2629
Character Data	2630
GET_CHAR_LENGTH	2630
Bus Data	2632
ABUSCHAR	2632
ABUSCOUNT	2634
ABUSCPLX	2635
ABUSINT	2637
ABUSREAL	2639
ABUSTYPES	2641
Plant Bus Data	2643
AGENBUSCHAR	2643
AGENBUSCOUNT	2645
AGENBUSCPLX	2646
AGENBUSINT	2648
AGENBUSREAL	2650
AGENBUSTYPES	2653
Machine Data	2655
AMACHCHAR	2655
AMACHCOUNT	2657
AMACHCPLX	2658
AMACHINT	2660
AMACHREAL	2662
AMACHTYPES	2665
Load Bus Data	2667

ALODBUSCHAR	2667
ALODBUSCOUNT	2669
ALODBUSCPLX	2671
ALODBUSINT	2674
ALODBUSREAL	2676
ALODBUSTYPES	2679
Load Data	2681
ALOADCHAR	2681
ALOADCOUNT	2683
ALOADCPLX	2684
ALOADINT	2687
ALOADREAL	2689
ALOADTYPES	2692
Fixed Shunt Bus Data	2694
AFXSHNTBUSCHAR	2694
AFXSHNTBUSCOUNT	2696
AFXSHNTBUSCPLX	2697
AFXSHNTBUSINT	2699
AFXSHNTBUSREAL	2701
AFXSHNTBUSTYPES	2703
Fixed Shunt Data	2705
AFXSHUNTCHAR	2705
AFXSHUNTCOUNT	2707
AFXSHUNTCPLX	2708
AFXSHUNTINT	2710
AFXSHUNTREAL	2712
AFXSHUNTTYPES	2714
Switched Shunt Bus Data	2716
ASWSHUNTBUSCHAR	2716
ASWSHUNTBUSCOUNT	2718
ASWSHUNTBUSCPLX	2719
ASWSHUNTBUSINT	2721
ASWSHUNTBUSREAL	2723
ASWSHUNTBUSTYPES	2725
Switched Shunt Data	2727
ASWSHCHAR	2727
ASWSHCOUNT	2729
ASWSHCPLX	2730
ASWSHINT	2732
ASWSHREAL	2734
ASWSHTYPES	2738
Branch Flow Data	2740
AFLOWCHAR	2740
AFLOWCOUNT	2743
AFLOWCPLX	2745
AFLOWINT	2747
AFLOWREAL	2749
AFLOWTYPES	2752
Branch Data	2754
ABRNCHAR	2754
ABRNCOUNT	2757

ABRNCPLX	2759
ABRNINT	2761
ABRNREAL	2764
ABRNTYPES	2772
Two-Winding Transformer Data	2774
ATRNCCHAR	2774
ATRNCOUNT	2777
ATRNCPLX	2779
ATRNINT	2782
ATRNREAL	2785
ATRNTYPES	2793
Three-Winding Transformer Data	2795
ATR3CHAR	2795
ATR3COUNT	2798
ATR3CPLX	2800
ATR3INT	2803
ATR3REAL	2806
ATR3TYPES	2808
Three-Winding Transformer Winding Data	2810
AWNDCHAR	2810
AWNDCOUNT	2813
AWNDCPLX	2815
AWNDINT	2817
AWNDREAL	2820
AWNDTYPES	2828
Two-Terminal dc Line Data	2830
A2TRMDCCCHAR	2830
A2TRMDCCCOUNT	2832
A2TRMDCCPLX	2833
A2TRMDCCINT	2835
A2TRMDCCREAL	2837
A2TRMDCCTYPES	2841
Two-Terminal dc Line Converter Data	2843
A2TRMDCCONVCHAR	2843
A2TRMDCCONVCOUNT	2846
A2TRMDCCONVCPLX	2848
A2TRMDCCONVINT	2850
A2TRMDCCONVREAL	2852
A2TRMDCCONVTYPES	2855
Multi-Terminal dc Line Data	2857
AMULTITRMDCCCHAR	2857
AMULTITRMDCCCOUNT	2859
AMULTITRMDCCPLX	2860
AMULTITRMDCCINT	2862
AMULTITRMDCCREAL	2864
AMULTITRMDCCTYPES	2866
Multi-Terminal dc Line Converter Data	2868
AMULTITRMDCCONVCHAR	2868
AMULTITRMDCCONVCOUNT	2871
AMULTITRMDCCONVCPLX	2873
AMULTITRMDCCONVINT	2875

AMULTITRMDCCONVREAL	2877
AMULTITRMDCCONVTYPES	2880
VSC dc Line Data	2882
AVSCDCCHAR	2882
AVSCDCCOUNT	2884
AVSCDCCPLX	2885
AVSCDCINT	2887
AVSCDCREAL	2889
AVSCDCTYPES	2891
VSC dc Line Converter Data	2893
AVSCDCCONVCHAR	2893
AVSCDCCONVCOUNT	2896
AVSCDCCONVCPLX	2898
AVSCDCCONVINT	2900
AVSCDCCONVREAL	2902
AVSCDCCONVTYPES	2905
FACTS Device Data	2907
AFACTSCHAR	2907
AFACTSCOUNT	2909
AFACTSCPLX	2911
AFACTSINT	2913
AFACTSREAL	2915
AFACTSTYPES	2919
FACTS Device Bus Data	2921
AFACTSBUSCHAR	2921
AFACTSBUSCOUNT	2924
AFACTSBUSCPLX	2926
AFACTSBUSINT	2928
AFACTSBUSREAL	2931
AFACTSBUSTYPES	2934
Area Data	2936
AAREACHAR	2936
AAREACOUNT	2938
AAREACPLX	2939
AAREAINT	2941
AAREAREAL	2943
AAREATYPES	2946
Owner Data	2948
AOWNERCHAR	2948
AOWNERCOUNT	2950
AOWNERCPLX	2951
AOWNERINT	2953
AOWNERREAL	2955
AOWNERTYPES	2958
Zone Data	2960
AZONECHAR	2960
AZONECOUNT	2962
AZONECPLX	2963
AZONEINT	2965
AZONEREAL	2967
AZONETYPES	2970

Induction Machine Bus Data	2972
AINDMACBUSCHAR	2972
AINDMACBUSCOUNT	2974
AINDMACBUSCPLX	2976
AINDMACBUSINT	2978
AINDMACBUSREAL	2980
AINDMACBUSTYPES	2983
Induction Machine Data	2985
AINDMACCHAR	2985
AINDMACCOUNT	2987
AINDMACCPLX	2989
AINDMACINT	2991
AINDMACREAL	2994
AINDMACTYPES	2997
Substation Data	2999
ASTATIONCHAR	2999
ASTATIONCOUNT	3001
ASTATIONINT	3002
ASTATIONREAL	3004
ASTATIONTYPES	3005
Substation Node Data	3007
ANODECHAR	3007
ANODECOUNT	3009
ANODEINT	3010
ANODEREAL	3012
ANODETYPES	3013
Substation Switching Device Data	3015
ASTASWDEVCHAR	3015
ASTASWDEVCOUNT	3017
ASTASWDEVCPLEX	3018
ASTASWDEVINT	3020
ASTASWDEVREAL	3022
ASTASWDEVTYPES	3024
Substation Terminal Data	3026
ATERMINALCHAR	3026
ATERMINALCOUNT	3028
ATERMINALINT	3029
ATERMINALTYPES	3031
Zero Sequence Mutuals Data	3033
AZMUTCHAR	3033
AZMUTCOUNT	3035
AZMUTCPLX	3037
AZMUTINT	3039
AZMUTREAL	3041
AZMUTTYPES	3043
Graphical Analysis Output	3045
POLY_PRINT	3046
PV_PRINT	3047
QV_PRINT	3049
SETFULLVIEWGRAPHAREA	3050
SETFULLVIEWSCALE	3053

Scenarios	3055
CLOSESCENARIOFILE	3056
NEWSCENARIOFILE	3057
OPENSCENARIOFILE	3058
SAVESCENARIOFILE	3059
SCENARIOCLOSE	3060
SCENARIOCOPYFILE	3061
SCENARIOFILEADD	3062
SCENARIOFILECOUNT	3063
SCENARIOFILEGETATTRS	3064
SCENARIOFILEGETCOMMENTS	3065
SCENARIOFILELENGTHCOMMENTS	3066
SCENARIOFILELIST	3067
SCENARIOFILEREMOVE	3068
SCENARIOFILERENAME	3069
SCENARIOFILESETATTRS	3070
SCENARIOFILESETCOMMENTS	3071
SCENARIOGETATTRS	3072
SCENARIOGETCOMMENTS	3073
SCENARIOGETOPT	3074
SCENARIOGROUPADD	3076
SCENARIOGROUPCOUNT	3077
SCENARIOGROUPGETCOMMENTS	3078
SCENARIOGROUPLengthComments	3079
SCENARIOGROUPLIST	3080
SCENARIOGROUPOPEN	3081
SCENARIOGROUPREMOVE	3082
SCENARIOGROUPRENAME	3083
SCENARIOGROUPSETCOMMENTS	3084
SCENARIOISDIRTY	3085
SCENARIOISVALID	3086
SCENARIOLENGTHCOMMENTS	3087
SCENARIOMODELGROUP	3088
SCENARIOMOVEFILE	3089
SCENARIONEW	3090
SCENARIOOPEN	3091
SCENARIOSAVE	3092
SCENARIOSETATTRS	3093
SCENARIOSETCOMMENTS	3094
SCENARIOSETOPT	3095
SCENARIOTRACKFILEADD	3097
SCENARIOTRACKFILELIST	3098
SCENARIOTRACKFILEENUM	3099
SCENARIOUNZIP	3100
SCENARIOUNZIPPROBLEMS	3101
SCENARIOUNZIP SOLUTIONS	3102
SCENARIOZIP	3103
SCENARIOZIPACTIVE	3104
SCENARIOZIPOPEN	3105
SCENARIOZIPSAVE	3106
Event Studies	3107

CLOSEEVENTSTUDYFILE	3108
OPENEVENTSTUDYFILE	3109
RUNDYNAMICEVENTSTUDY	3110
RUNPOWERFLOWEVENTSTUDY	3111
SAVEEVENTSTUDYFILE	3112
SETACTIVEEVENTSTUDY	3113
Measurement Interface	3114
HDAIMPORTDATA	3115
Multiple Element Data	3116
AVOLTAGEDROOPCHAR	3117
AVOLTAGEDROOPCOUNT	3118
AVOLTAGEDROOPINT	3119
AVOLTAGEDROOPREAL	3120
GETMODELLIBRARIES	3122
GETMODELPROGRAMS	3123
LAST_PF	3124
RXPATH	3125
TREEDAT	3126
Using the Vendor Neutral Contingency and RAS Auxiliary File	3128
ACCC_RAS	3129
ACCC_RAS_2	3130
ADD2WINDINGCONTINGENCYELEMENT	3132
ADD2WINDINGREMEDIALACTIONELEMENT	3134
ADD3WINDINGCONTINGENCYELEMENT	3137
ADD3WINDINGREMEDIALACTIONELEMENT	3140
ADDACLINECONTINGENCYELEMENT	3143
ADDACLINEREMEDIALACTIONELEMENT	3145
ADDBUSCONTINGENCYELEMENT	3148
ADDBUSREMEDIALACTIONELEMENT	3150
ADDCONTINGENCY	3153
ADDCONTINGENCYELEMENT	3154
ADDDCCONVCONTINGENCYELEMENT	3156
ADDDCCONVREMEDIALACTIONELEMENT	3158
ADDDCLINECONTINGENCYELEMENT	3161
ADDDCLINEREMEDIALACTIONELEMENT	3163
ADDFIXSHUNTCONTINGENCYELEMENT	3166
ADDFIXSHUNTREMEDIALACTIONELEMENT	3168
ADDGENERATORCONTINGENCYELEMENT	3171
ADDGENERATORREMEDIALACTIONELEMENT	3173
ADDLOADCONTINGENCYELEMENT	3176
ADDLOADREMEDIALACTIONELEMENT	3178
ADDPYTHONCONTINGENCYELEMENT	3181
ADDPYTHONREMEDIALACTIONELEMENT	3183
ADDREMEDIALACTION	3185
ADDREMEDIALACTIONELEMENT	3186
ADDSUBCONTINGENCYELEMENT	3189
ADDSUBREMEDIALACTIONELEMENT	3191
ADDVSCDCCONTINGENCYELEMENT	3194
ADDVSCDCREMEDIALACTIONELEMENT	3196
APPEND_RAS	3199
READ_RAS	3200

VALIDATE_RAS	3201
WRITE_RAS	3202
Non-Engineering	3204
ALERT	3205
BEGINREPORT	3206
CLEARALERTOUTPUT	3207
CLEARPROGRESSOUTPUT	3208
FILEIN	3209
GETBATDEFAULTS	3210
GETDEFAULTCHAR	3211
GETDEFAULTINT	3212
GETDEFAULTREAL	3213
GETLOADEDMODULES	3214
GETMODFUNCLIST	3215
IOFLUSH	3216
LAUNCH_PROGRAM	3217
PAGEREPORT	3218
PROGRESS	3219
PROMPT	3220
PSSEINIT	3221
PSSEVERSION	3222
REFRESHGUI	3223
REPORT	3224
RUNIPLANFILE	3225
RUNRSPNSFILE	3226
SHOWLOADEDLIBRARIES	3227
SHOWLOADEDMODULES	3228
STARTRECORDING	3229
STOPRECORDING	3230
T_ALERT_OUTPUT	3231
T_PROGRESS_OUTPUT	3233
T_PROMPT_OUTPUT	3235
T_REPORT_OUTPUT	3237
USERIN	3239
PSSPLOT Module	3240
ADDFUNCTION	3241
CHANNELFILEEXCELEXPORT	3242
DELETESELPLOT	3243
DRAGDROPLOTDATA	3244
EXPORTPLOT	3245
INSERTPAGE	3246
INSERTPLOT	3247
MULTICHANNEXCELEXPORT	3248
NEWPLOTBOOK	3249
OPENCHANDATAFILE	3250
PLOTPAGEPRINTSETUP	3251
PRINTACTIVEPAGE	3252
PRINTSELPLOT	3253
SETSELECTEDPAGE	3254
SETSELECTEDPLOT	3255
SHOWPLOTEDITOR	3256

XYPLOT	3257
PSSRDB Module	3258
MUSTPY Module	3259
MUST Analysis Functions	3260
ACCDEFAULTS	3260
ACCONTBYCONT	3262
ACCONTBYMONEL	3264
ACCSOLVE	3266
ACLFDC	3268
ACLFNS	3270
ACSOLVE_LFD	3272
ACSOLVE_LFN	3273
ACTIVITYACCONT	3274
ACTIVITYMUST	3275
ACTTRANSFERLIMITSTUDY	3276
ADDTRANSACTION	3277
APPLYSINGLECONT	3278
AREABUBBLE	3279
AREAIMPACT	3280
AREASINZONES	3282
AREASLACKS	3283
AREASUMMARY	3284
BRANCHSENSITIVITY	3285
CDETAILBRANCHES	3287
CDETAILINTERFACES	3288
CDETAILVOLTAGEBUSES	3289
CHANGEPARAMS	3290
CLEARMULTISTUDY	3297
CNALLTRANSELBRANCHES	3298
CNALLTRANSELFLOWGATES	3299
CNALLTRANSELINTERFACES	3300
CNALLVIOLATED	3301
CNALLVIOLFREQ	3302
CNBASEVIOLATED	3303
CNCINITSELBRANCHES	3304
CNCINITSELINTERFACES	3305
CNCOMPSELBRANCHES	3306
CNCOMPSELINTERFACES	3307
CNCOMPSELVOLTAGEBUSES	3308
CNCRESULTSELBRANCHES	3309
CNCRESULTSELINTERFACES	3310
CNDETAILSELFLOWGATES	3311
CNDETAILSELINTERFACES	3312
CNFACTORSELFLOWGATES	3313
CNFREQSELBRANCHES	3314
CNFREQSELBRANCHES_TBL	3315
CNFREQSELINTERFACES	3316
CNFREQSELINTERFACES_TBL	3317
CNFREQSELVOLTAGEBUSES	3318
CNGAPSELBRANCHES	3319
CNGAPSELFLOWGATES	3320

CNGAPPSELINTERFACES	3321
CNIMPACTSELBRANCHES	3322
CNIMPACTSELFLOWGATES	3323
CNIMPACTSELINTERFACES	3324
CNLISTSELBRANCHES	3325
CNLISTSELBRANCHES_TBL	3326
CNLISTSELFLOWGATES	3327
CNLISTSELFLOWGATES_TBL	3328
CNLISTSELINTERFACES	3329
CNLISTSELINTERFACES_TBL	3330
CNLISTSELVOLTAGEBUSES	3331
CNOTDFSELBRANCHES	3332
CNOTDFSELINTERFACES	3333
CNSELECTBRANCHBYALL	3334
CNSELECTBRANCHBYAREAS	3335
CNSELECTBRANCHBYBRANCHES	3336
CNSELECTBRANCHBYBUSES	3337
CNSELECTBRANCHBYIMPACT	3338
CNSELECTBRANCHBYTIES	3339
CNSELECTBRANCHBYVIOL	3340
CNSELECTBRANCHBYZONES	3341
CNSELECTFGATEBYALL	3342
CNSELECTFGATEBYCONT	3343
CNSELECTFGATEBYID	3344
CNSELECTFGATEBYIMPACT	3345
CNSELECTFGATEBYVIOL	3346
CNSELECTINTERBYALL	3347
CNSELECTINTERBYIMPACT	3348
CNSELECTINTERBYNAME	3349
CNSELECTINTERBYNUMBER	3350
CNSELECTINTERBYVIOL	3351
CNSELECTVOLTAGEBUSESBYVIOL	3352
CNSELECTVOLTBUSBYALL	3353
CNSELECTVOLTBUSBYAREAS	3354
CNSELECTVOLTBUSBYBUSES	3355
CNSELECTVOLTBUSBYZONES	3356
CNSELECTVOLTBUSESBYDEVIATION	3357
CNSENSUBSELBRANCHES	3358
CNSENSUBSELFLOWGATES	3359
CNSENSUBSELINTERFACES	3360
CNSTUDYSELBRANCHES	3361
CNSTUDYSELFLOWGATES	3362
CNSTUDYSELINTERFACES	3363
CNSUBSELBRANCHES	3364
CNSUBSELFLOWGATES	3365
CNSUBSELINTERFACES	3366
CNSUMMARYVIOLATIONS	3367
CNTRANSACTSELBRANCHES	3368
CNTRANSACTSELFLOWGATES	3369
CNTRANSACTSELINTERFACES	3370
CNVARSELBRANCHES	3371

CNVARSELINTERFACES	3372
CNVARSELVOLTAGEBUSES	3373
CNVIOLSELBRANCHES	3374
CNVIOLSELBRANCHES_TBL	3375
CNVIOLSELFLOWGATES	3376
CNVIOLSELFLOWGATES_TBL	3377
CNVIOLSELINTERFACES	3378
CNVIOLSELINTERFACES_TBL	3379
CNVIOLSELVOLTAGEBUSES	3380
COMPAREFCITC	3381
CONSTRDEFS	3382
DCCONTBYCONT	3384
DCCONTBYMONEL	3386
DCSOLVE	3388
DCTransferLimitStudy	3389
DETAILSELCONTINGENCIES	3390
DETAILSELCONTINGENCIESSP	3391
DIRECT	3392
EXCLUDESELECTEDCONTS	3393
EXECUTEACCONT	3394
EXITACTIVITYACCONT	3395
EXITACTIVITYMUST	3396
FCITC2LINE	3397
FCITCAC	3398
FCITCACMULT	3399
FCITCACSINGLE	3400
FCITCBASE	3401
FCITCBASEMULT	3402
FCITCBASESINGLE	3403
FCITCMULT	3404
FCITCSINGLE	3405
FCITCSUBS	3406
FCITCTLTG	3407
FCITCWISE	3408
FLOWGATESSENSITIVITY	3409
FORGETSTUDYTRANSFER	3411
GENDETAILS	3412
GENSENDETAIL	3413
GENSENSUMMARY	3414
ILFDEFAULTS	3415
IMPACTINTRFACEPARTFACT	3417
IMPACTSETBASECASE	3419
IMPACTSETCONTINGENCY	3420
IMPACTTIESPARTFACT	3421
IMPACTTOTALPARTFACT	3423
INCLUDESELECTEDCONTS	3424
INTERFACESENSITIVITY	3425
LISTACCONTDETAILS	3427
LISTACCONTSUMMARY	3428
LISTAREAS	3429
LISTBUSES	3430

LISTEXCLUDES	3431
LISTGENERATORS	3432
LISTPHASESHIFTERS	3433
LISTSELCONTINGENCIES	3434
LISTSELCONTINGENCIES_TBL	3435
LISTZONES	3436
LIST_BFLOW	3437
LIST_BIMPACT	3438
LIST_CFLOW	3439
LIST_CIMPACT	3440
LIST_CONTINS	3441
LIST_CONTINS_WISL	3442
LIST_LODF	3443
LIST_LODF_WISL	3444
LIST_MONELS	3445
LIST_PTDF	3446
LIST_PTDFC	3447
LIST_SYSTEMS	3448
MDETAILBRANCHES	3449
MDETAILINTERFACES	3450
MDETAILVOLTAGEBUSES	3451
MODIFYDISPATCH	3452
MONELIMPACT	3453
MONSENSALLSUBBRANCHES	3455
MONSENSALLSUBFLOWGATES	3456
MONSENSALLSUBINTERFACES	3457
MONSENSALLTRANBRANCHES	3458
MONSENSALLTRANFLOWGATES	3459
MONSENSALLTRANINTERFACES	3460
MONSENSSINGLESUBBRANCHES	3461
MONSENSSINGLESUBFLOWGATES	3462
MONSENSSINGLESUBINTERFACES	3463
MONSENSSUBSPARTBRANCHES	3464
MONSENSSUBSPARTFLOWGATES	3465
MONSENSSUBSPARTINTERFACES	3466
MONSENSTRANBRANCHES	3467
MONSENSTRANFLOWGATES	3468
MONSENSTRANINTERFACES	3469
MULTACFCITC	3470
MULTDCFCITC	3472
MULTIPLEPARALLELTRANSFERS	3473
MULTIPLESTUDYTRANSFERS	3475
MUSTOPTDEFS	3477
MUSTSTART	3479
MUSTSTOP	3480
PARALLELDETAILTRANSFER	3481
PARALLELFCITCSUMMARY	3482
PRINTRPT	3483
PSCASE	3484
RDEXCHGFILE	3485
RDMONCONFILE	3486

RDMUSTFILES	3487
RDSUBFILE	3489
READACCONTFILE	3490
READRAWDATA	3491
REAREABUS	3492
REMOVEEXCLUDES	3493
REZONEBUS	3494
SAVEACCONTFILE	3495
SAVEFLOWGATES	3496
SAVESELECTEDCONTS	3497
SAVESUBSYSTEMS	3498
SAVEXCHGFILE	3499
SCEDANALYSIS	3500
SELECTACTIVECONTS	3502
SELECTALLCONTS	3503
SELECTCOMPLEXCONTS	3504
SELECTCONVERGECONTS	3505
SELECTDISABLEDCONTS	3506
SELECTEXCLUDEDCONTS	3507
SELECTGENCONTS	3508
SELECTHISEVCONTS	3509
SELECTIMBALANCECONTS	3510
SELECTISLANDCONTS	3511
SELECTLOADCONTS	3512
SELECTLOSEVCONTS	3513
SELECTNOTCONVERGECONTS	3514
SELECTNOVIOLCONTS	3515
SELECTSINGLEBRANCHCONTS	3516
SELECTSPECIFICCONTS	3517
SELECTVIOLCONTS	3518
SETEXCLUDEDBRANCHES	3519
SETEXCLUDEDCONTINGENCIES	3520
SETEXCLUDEDFLOWGATES	3521
SETEXCLUDEDINTERFACES	3522
SETEXCLUDEDVOLTAGEBUSES	3523
SGLACFCITC	3524
SGLDCFCITC	3526
SHOWPARAMS	3528
SUBSYSTEMS	3530
SUMMARYCONTINGENCIES	3531
SWINGBUSES	3532
VIOLSELCONTINGENCIES	3533
VIOLSELCONTINGENCIES_TBL	3534
WRITEEXCLUDES	3535
WRITERAWDATA	3536
ZONEBUBBLE	3537
ZONESINAREAS	3538
ZONESUMMARY	3539
MUST Data Retrieval	3541
GETEXCLUDEDBRANCHES	3541
GETEXCLUDEDCONTINGENCIES	3542

GETEXCLUDEDFLOWGATES	3543
GETEXCLUDEDINTERFACES	3544
GETEXCLUDEDVOLTAGEBUSES	3545
GETFINALBALANCE	3546
GETFINALFLOW	3547
GETIDOFCONTINGENCYBYNAME	3548
GETIDOFFLOWGATEBYNAME	3549
GETIDOFINTERFACEBYNAME	3550
GETIDOFVOLTAGEBUSBYNAME	3551
GETINITBALANCE	3552
GETINITIALFLOW	3553
GETIPFFACTOR	3554
GETNAMEOFCONTINGENCYBYID	3555
GETNAMEOFFLOWGATEBYID	3556
GETNAMEOFINTERFACEBYID	3557
GETNAMEOFVOLTAGEBUSBYID	3558
GETNUMOFEXCLUDEDBRANCHES	3559
GETNUMOFEXCLUDEDCONTINGENCIES	3560
GETNUMOFEXCLUDEDFLOWGATES	3561
GETNUMOFEXCLUDEDINTERFACES	3562
GETNUMOFEXCLUDEDVOLTAGEBUSES	3563
GETTPFBALANCE	3564
PSSARRAYS Module	3566
ACCC_SUMMARY	3567
ACCC_SOLUTION	3570
ACCC_SUMMARY_REPORT	3572
SENSITIVITY_FLOW_TO_MW	3573
ACCC_SOLUTION_REPORT	3574
ACCC_VIOLATIONS_REPORT	3575
ASCC_CURRENTS	3576
IECS_CURRENTS	3581
OTDF_FACTORS	3587
PV_SUMMARY	3589
PV_SUMMARY_REPORT	3591
PV_SOLUTION	3592
PV_SOLUTION_REPORT	3594
QV_SOLUTION	3595
QV_SOLUTION_REPORT	3596
QV_SUMMARY	3597
QV_SUMMARY_REPORT	3599
PSSEXCEL Module	3600
ACCC	3601
iec_data_file	3605
pv	3607
qv	3610
EXCELPY Module	3612
Methods	3616
Workbook Functions	3622
GICDATA Module	3623
PSSPIHIST Module	3626
PFCONTROL Module	3628

PFDSCNBUS	3629
PFCNCTBUS	3630
PFBRCHINT	3631
PFSUBSWDINT	3632
PFFXSINT	3633
PFFXSREAL	3634
PFSWSINT	3635
PFSWSREAL	3636
PFSWSINT_2	3637
PFSWSREAL_2	3638
PFLODINT	3639
PFLODREAL	3640
PFMACINT	3641
PFMACREAL	3642
PFPLNTRREAL	3643
PFCNTLVSC	3645
PSSACCSS Module	3647
ACCC_FILE_INIT	3648
ACCC_FILE_SIZE	3650
ACCC_FILE_GET_SUM_VOLT	3652
ACCC_FILE_CLOSE	3655
ACCC_FILE_SUMMARY	3656
ACCC_FILE_SUMMARY_2	3660
ACCC_FILE_SUMMARY_3	3664
ACCC_FILE_SUM_AREAS	3669
ACCC_FILE_CNTG_VOLT	3672
ACCC_FILE_CNTG_FLOW	3675
ACCC_FILE_CNTG_FLOW_2	3678
ACCC_FILE_CNTG_VOLT_FLOW	3681
ACCC_FILE_CNTG_VOLT_FLOW_2	3684
ACCC_FILE_CNTG_DSCR	3687
ACCC_FILE_CNTG_LOAD	3690
ACCC_FILE_SOLUTION	3693
ACCC_FILE_SOLUTION_2	3697
Other Python Modules	3701
Modules Supplied with a GUI	3702
Modules that Define Functions	3703
Index	3704

Preface

Structure of Manual

This document defines the PSS®E Application Program Interface (API) to the various engineering functions in PSS®E.

How API Routines are Described

The description for each API routine starts with a brief explanation of its function, followed by one or more language specific syntaxes for calling the routine, followed by a detailed description of the arguments used in those calling sequences. The nomenclature used in the argument descriptions is most consistent with the Fortran programming language.

The syntaxes for calling the API routines will include at least one of the PSS®E automation file languages, and will usually include a syntax for use from a Fortran program. The set of syntaxes will include all the PSS®E automation file languages where the API routine can be used. Some general comments about those syntaxes may be helpful, as follows:

PSS®E Automation File Languages

Batch commands: this is a free-format input syntax. Items can be separated by a comma or spaces, strings need only be quoted if they contain spaces or commas, omitted items can be indicated by consecutive commas, arrays are entered as a sequence of scalar values, and a semi-colon can be used to terminate the command and return the remaining items to default values (it must be a separate data item, i.e., it must be separated from the previous data item by a space or comma). Except for unquoted filenames, a forward slash will terminate a line. Commands may be continued over multiple lines. The sequence @! at the beginning of the line will cause that line to be ignored.

Python commands: Python is an open source language; its syntax is well documented. Some of the arguments are defined as arrays (in keeping with Fortran nomenclature, as mentioned above). Python does not have arrays, and in general you should interpret arrays to mean lists (although tuples will usually work on input). Arrays that have some elements as input and some as output in the Fortran syntax are represented in the Python syntax as two separate arrays (i.e. lists). Keywords can be used for arguments, and any argument can be omitted. Additionally, any element of an input array can be specified as a keyword, e.g. myarray6=2 specifies that the 6th element of the array myarray has the value 2. If an alias is documented for a specific array element, it can also be used as a keyword for that element.

Fortran call statements: Fortran is a well-documented language (where it matters, we will use the Fortran 2008 standard). We will not use features that require explicit interfaces without stating so clearly in the description. Unless specifically stated, arguments cannot be omitted.

IPLAN commands: the IPLAN language is described in the IPLAN manual. For purposes of the CALL statement it resembles Fortran. Unless specifically stated, arguments cannot be omitted.

Return Codes / Error Codes

Most API routines return a integer return code, where zero indicates success. In Python, where multiple values are returned (a tuple), the return code will always be the first value. When non-successful (usually non-zero)

error codes are returned, other returned values are set to None in Python, and are either uninitialized or unchanged (for input/output values) in other syntaxes.

The Python interface can be made to throw exceptions instead of returning error codes values (the default). Enter:

```
psspy.setThrowPsseExceptions(True)
```

or

```
psspy.param.throwPsseExceptions = True
```

To see if the Python interface is set to throw exceptions instead of returning error code values:

```
val = psspy.getThrowPsseExceptions()
```

Default Values

When values are omitted, special “no input” values are supplied. These special values – for each variable type – are meant to indicate that “no input” was supplied. Many of the API routines permit this and will use documented default values when “no input” values are supplied.

The actual “no input” values can be retrieved from the API routines GETDEFAULTINT, GETDEFAULTREAL, and GETDEFAULTCHAR (capitalization depends on syntax). Users should never depend on the actual values returned, by these functions. They should be used only for supplying values to the PSS®E API routines.

When automation files are recorded, items that have the default value are omitted in batch commands (i.e. recorded as “,”) and recorded as `_i`, `_f`, `_s`, or `_o` (for integer, real/float, character/string, and filename, respectively). In the PSS®E embedded Python environment there will be local variables `_i`, `_f`, and `_s` set to the values returned from GETDEFAULTxxx routines mentioned above (`_o` will be treated as blanks). Outside of PSS®E it is the user’s responsibility to set those variables.

Recording

Two recording formats are available: batch commands and Python.

Not all API routines are recordable. Routines that only retrieve data do not record, for example. If an API routine is recordable, it will have a batch command format specified; routines without a batch command format specified are not recordable.

Python Modules

Most of the PSS®E API is defined in the module `psspy`. Later chapters discuss routines defined in other modules. In those cases the Chapter name will include the name of the module.

In keeping with normal Python documentation the namespace is not included as part of the syntax for the individual routines. This may seem confusing to newcomers to Python. For those whose first exposure to Python is inside of PSS®E, be aware that, normally, you will use the, say, case API routine by entering:

```
psspy.case(filename)
```

not

case(filename)

Chapter 1

Power Flow

This chapter describes the API routines corresponding to the operational and data changing functions of the PSS®E Power Flow.

1.1. Power Flow Operation

This section describes the API routines corresponding to the operational functions of the PSS®E Power Flow. Also included are those routines that control basic program operations and the Open Access option.

1.1.1. ACCC

This API routine is obsolete. It has been replaced by the API routine [accc_with_dsp_2](#).

Use this API to apply the AC contingency calculation function (activity ACCC).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ACCC  TOL  OPTIONS(1)..OPTIONS(7)  DFXFILE  ACCFILE  THRFILE
```

Python command syntax:

```
ierr = accc(tol, options, dfxfile, accfile, thrfile)
```

Fortran command syntax:

```
CALL ACCCAPI(TOL, OPTIONS, DFXFILE, ACCFILE, THRFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTIONS (7)	array of 7 elements specifying solution options(input).
	OPTIONS(1) tap adjustment flag (tap adjustment option setting by default)
	OPTIONS(1) = 0 disable
	OPTIONS(1) = 1 enable stepping adjustment
	OPTIONS(1) = 2 enable direct adjustment
	OPTIONS(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTIONS(2) = 0 disable
	OPTIONS(2) = 1 enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTIONS(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTIONS(3) = 0 disable
	OPTIONS(3) = 1 enable
	OPTIONS(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTIONS(4) = 0 disable

	OPTIONS(4) = 1	enable
	OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	solution method flag (0 by default)
	OPTIONS(6) = 0	FDNS
	OPTIONS(6) = 1	FNSL
	OPTIONS(6) = 2	optimized FDNS
	OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(7) = 0	disable
	OPTIONS(7) = 1	enable
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output file (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	no Distribution Factor Data File specified
	IERR = 7	no Contingency Solution Output File specified
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	bus type code and series element status inconsistencies
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for API are not met

1.1.2. ACCC_2

This API routine is obsolete. It has been replaced by the API routine [accc_with_dsp_3](#).

Use this API to apply the AC contingency calculation function (activity ACCC).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ACCC_2  TOL  OPTIONS(1)..OPTIONS(7)  DFXFILE  ACCFILE  THRFILE
```

Python command syntax:

```
ierr = accc_2(tol, options, dfxfile, accfile, thrfile)
```

Fortran command syntax:

```
CALL ACCC_2(TOL, OPTIONS, DFXFILE, ACCFILE, THRFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).	
Integer OPTIONS (9)	OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTIONS(6)	solution method flag (0 by default)
	OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(8)	induction motor treatment flag (0 by default)
	OPTIONS(9)	induction machine failure flag (0 by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output file (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred.
	IERR > 0	as for ACCC_WITH_DSP_3.

1.1.3. ACCC_MULTIPLE_MERGE

Use this API to merge a number of AC contingency solution files (acc files) into one acc file. The acc files must be based on the same base case and MON file.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_ACCC_MULTIPLE_MERGE  OPTION NFILES ACFILES(1)..ACFILES(NFILES) ACCFILE
```

Python command syntax:

```
ierr = accc_multiple_merge(option, nfiles, acfiles, accfile)
```

Fortran command syntax:

```
CALL ACCC_MULTIPLE_MERGE(OPTION, NFILES, ACFILES, ACCFILE, IERR)
```

Where:

Integer OPTION	Options for merging acc files. (input).
OPTION = 0	Do not merge .acc files if some .acc files have different solving options, sub files or .mon files.
OPTION = 1	Merge the .acc files even if some .acc files have different solving options, sub files or .mon files.
Integer NFILES	The number of contingency acc files to be merged. (input).
Character*260 ACFILES	An array of names of acc files. (input).
Character*260 ACCFILE	The name of the merged contingency acc file. (input).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid OPTION value
IERR = 2	invalid NFILES value
IERR = 3	error opening a Contingency Solution Output File
IERR = 4	file is not in the form of a current Contingency Solution Output File
IERR = 5	some input .acc files have different information (.sav, .sub, .mon, PSSE version, solution options)
IERR = 6	error reading or writing Contingency Solution Output file
IERR = 7	error reading a Contingency Solution Output File
IERR = 8	error closing a Contingency Solution Output file
IERR = 9	Prerequisite requirements for function not met

1.1.4. ACCC_MULTIPLE_RUN_REPORT

This API routine is obsolete. It has been replaced by the API routine [accc_multiple_run_report_2](#).

Use this API to report the results of up to nine executions of the AC Contingency Calculation function.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ACCC_MULTIPLE_RUN_REPORT  OPTIONS(1)..OPTIONS(14)
                               VALUES(1)..VALUES(7)  NFILES  ACFILES(1)..ACFILES(NFILES)
```

Python command syntax:

```
ierr = accc_multiple_run_report(options, values, nfiles, acfiles)
```

Fortran command syntax:

```
CALL ACCC_MULTIPLE_RUN_REPORT(OPTIONS, VALUES, NFILES, ACFILES, IERR)
```

Where:

Integer OPTIONS (14)	array of 14 elements specifying defining reporting options(input).
OPTIONS(1)	column headings code (1 by default)
OPTIONS(1) = 1	Contingency Solution Output File names
OPTIONS(1) = 2	Saved Case File names as contained in the Contingency Solution Output Files
OPTIONS(2)	base case rating set (rating set program option setting by default)
OPTIONS(2) = 1	rate A
OPTIONS(2) = 2	rate B
OPTIONS(2) = 3	rate C
OPTIONS(3)	contingency case rating set (rating set program option setting by default)
OPTIONS(3) = 1	rate A
OPTIONS(3) = 2	rate B
OPTIONS(3) = 3	rate C
OPTIONS(4)	print monitored elements summary report (0 by default)
OPTIONS(4) = 0	no
OPTIONS(4) = 1	yes
OPTIONS(5)	print missing monitored elements report (0 by default)
OPTIONS(5) = 0	no
OPTIONS(5) = 1	yes
OPTIONS(6)	print missing monitored voltage buses report (0 by default)
OPTIONS(6) = 0	no
OPTIONS(6) = 1	yes

OPTIONS(7)	print contingency legend (2 by default)
OPTIONS(7) = 0	no
OPTIONS(7) = 1	complete master legend report only
OPTIONS(7) = 2	reduced legend with each table
OPTIONS(7) = 3	both master legend report and legend with each table
OPTIONS(8)	print missing contingencies report (0 by default)
OPTIONS(8) = 0	no
OPTIONS(8) = 1	yes
OPTIONS(9)	print non-converged contingencies report (0 by default)
OPTIONS(9) = 0	no
OPTIONS(9) = 1	yes
OPTIONS(10)	print loading violation reports (0 by default)
OPTIONS(10) = 0	no
OPTIONS(10) = 1	base case and worst case contingency violations only
OPTIONS(10) = 2	base case and all contingency violations only
OPTIONS(10) = 3	base case, worst case contingency, and all contingency violations
OPTIONS(11)	print voltage violation reports (0 by default)
OPTIONS(11) = 0	no
OPTIONS(11) = 1	base case and worst case contingency violations only
OPTIONS(11) = 2	base case and all contingency violations only
OPTIONS(11) = 3	base case, worst case contingency, and all contingency violations
OPTIONS(12)	option for processing interfaces in loading violation reports (1 by default)
OPTIONS(12) = 0	exclude interfaces from loading violation checking and reporting
OPTIONS(12) = 1	check and report interface loading violations
OPTIONS(13)	in loading violation reports, exclude monitored branches and interfaces that show loading violations in the base case from being checked and reported in contingency case reports (0 by default)
OPTIONS(13) = 0	no
OPTIONS(13) = 1	yes
OPTIONS(14)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports (0 by default)
OPTIONS(14) = 0	no

	OPTIONS(14) = 1	yes
Real VALUES (7)	array of 7 elements specifying reporting parameters(input).	
	VALUES(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	VALUES(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	VALUES(3)	in loading violation reports, percent of flow rating for reporting (100.0 by default)
	VALUES(4)	in the worst case contingency loading violation reports, percent of flow rating for counting (> VALUES(3)) (100.0 by default)
	VALUES(5)	in loading violation reports, minimum contingency case flow change from base case value for reporting and counting (0.0 by default)
	VALUES(6)	in loading violation reports, minimum contingency case percent loading increase from base case value for reporting and counting (0.0 by default)
	VALUES(7)	minimum contingency case voltage change for reporting and counting in voltage range violations (0.0 by default)
Integer NFILES	number of Contingency Solution Output Files to be processed (1 through 22) (input; no default allowed).	
Character*260 ACFILES (NFILES)	NFILES names of Contingency Solution Output Files (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	invalid NFILES value
	IERR = 4	the percent for counting is less than the percent for reporting
	IERR = 5	file is not in the form of a current Contingency Solution Output File
	IERR = 6	error opening a Contingency Solution Output File
	IERR = 7	error reading a Contingency Solution Output File
	IERR = 8	error opening a temporary file
	IERR = 9	error opening a subfile in the temporary file
	IERR = 10	error reading or writing the temporary file
	IERR = 11	error closing a subfile in the temporary file
	IERR = 12	prerequisite requirements for API are not met

1.1.5. ACCC_MULTIPLE_RUN_REPORT_2

Use this API to report the results of up to twenty two executions of the AC Contingency Calculation function.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_ACCC_MULTIPLE_RUN_REPORT_2  OPTIONS(1)..OPTIONS(16)
                                VALUES(1)..VALUES(7)  NFILES  ACFILES(1)..ACFILES(NFILES)
```

Python command syntax:

```
ierr = accc_multiple_run_report_2(options, values, nfiles, acfiles)
```

Fortran command syntax:

```
CALL ACCC_MULTIPLE_RUN_REPORT_2(OPTIONS, VALUES, NFILES, ACFILES, IERR)
```

Where:

Integer OPTIONS (16)	array of 16 elements specifying defining reporting options(input).
OPTIONS(1)	column headings code (1 by default)
OPTIONS(1) = 1	Contingency Solution Output File names
OPTIONS(1) = 2	Saved Case File names as contained in the Contingency Solution Output Files
OPTIONS(2)	base case rating set (rating set program option setting by default)
OPTIONS(2) = 1	rate A
OPTIONS(2) = 2	rate B
OPTIONS(2) = 3	rate C
OPTIONS(3)	contingency case rating set (rating set program option setting by default)
OPTIONS(3) = 1	rate A
OPTIONS(3) = 2	rate B
OPTIONS(3) = 3	rate C
OPTIONS(4)	base case voltage limit when STATUS(1) is 0, 1, 3 or 4
OPTIONS(4) = 1	normal limit
OPTIONS(4) = 2	emergency limit
OPTIONS(5)	contingency case voltage limit when STATUS(1) is 0, 1, 3 or 4
OPTIONS(5) = 1	normal limit
OPTIONS(5) = 2	emergency limit
OPTIONS(6)	print monitored elements summary report (0 by default)
OPTIONS(6) = 0	no
OPTIONS(6) = 1	yes

OPTIONS(7)	print missing monitored elements report (0 by default)
OPTIONS(7) = 0	no
OPTIONS(7) = 1	yes
OPTIONS(8)	print missing monitored voltage buses report (0 by default)
OPTIONS(8) = 0	no
OPTIONS(8) = 1	yes
OPTIONS(9)	print contingency legend (2 by default)
OPTIONS(9) = 0	no
OPTIONS(9) = 1	complete master legend report only
OPTIONS(9) = 2	reduced legend with each table
OPTIONS(9) = 3	both master legend report and legend with each table
OPTIONS(10)	print missing contingencies report (0 by default)
OPTIONS(10) = 0	no
OPTIONS(10) = 1	yes
OPTIONS(11)	print non-converged contingencies report (0 by default)
OPTIONS(11) = 0	no
OPTIONS(11) = 1	yes
OPTIONS(12)	print loading violation reports (0 by default)
OPTIONS(12) = 0	no
OPTIONS(12) = 1	base case and worst case contingency violations only
OPTIONS(12) = 2	base case and all contingency violations only
OPTIONS(12) = 3	base case, worst case contingency, and all contingency violations
OPTIONS(13)	print voltage violation reports (0 by default)
OPTIONS(13) = 0	no
OPTIONS(13) = 1	base case and worst case contingency violations only
OPTIONS(13) = 2	base case and all contingency violations only
OPTIONS(13) = 3	base case, worst case contingency, and all contingency violations
OPTIONS(14)	option for processing interfaces in loading violation reports (1 by default)
OPTIONS(14) = 0	exclude interfaces from loading violation checking and reporting
OPTIONS(14) = 1	check and report interface loading violations
OPTIONS(15)	in loading violation reports, exclude monitored branches and interfaces that show loading violations in the base case from be-

		ing checked and reported in contingency case reports (0 by default)
	OPTIONS(15) = 0	no
	OPTIONS(15) = 1	yes
	OPTIONS(16)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports (0 by default)
	OPTIONS(16) = 0	no
	OPTIONS(16) = 1	yes
Real VALUES (7)	array of 7 elements specifying reporting parameters(input).	
	VALUES(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	VALUES(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	VALUES(3)	in loading violation reports, percent of flow rating for reporting (100.0 by default)
	VALUES(4)	in the worst case contingency loading violation reports, percent of flow rating for counting (> VALUES(3)) (100.0 by default)
	VALUES(5)	in loading violation reports, minimum contingency case flow change from base case value for reporting and counting (0.0 by default)
	VALUES(6)	in loading violation reports, minimum contingency case percent loading increase from base case value for reporting and counting (0.0 by default)
	VALUES(7)	minimum contingency case voltage change for reporting and counting in voltage range violations (0.0 by default)
Integer NFILES	number of Contingency Solution Output Files to be processed (1 through 9) (input; no default allowed).	
Character*260 ACFILES (NFILES)	NFILES names of Contingency Solution Output Files (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	invalid NFILES value
	IERR = 4	the percent for counting is less than the percent for reporting
	IERR = 5	file is not in the form of a current Contingency Solution Output File

IERR = 6	error opening a Contingency Solution Output File
IERR = 7	error reading a Contingency Solution Output File
IERR = 8	error opening a temporary file
IERR = 9	error opening a subfile in the temporary file
IERR = 10	error reading or writing the temporary file
IERR = 11	error closing a subfile in the temporary file
IERR = 12	prerequisite requirements for API are not met

1.1.6. ACCC_PARALLEL

This API routine is obsolete. It has been replaced by the API routine [accc_parallel_2](#).

Use this API routine to run the initial release of the parallel implementation of the AC contingency calculation function (use ACCC_WITH_DSP_3 to run AC contingency calculation function serially). The API routine distributes contingency cases among multiple processors evenly, and tests the contingency cases assigned to each processor in parallel.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_ACCC_PARALLEL  TOL OPTACC(1)..OPTACC(10) LABEL DFXFILE ACCFILE THRFILE
INLFILE
```

Python command syntax:

```
ierr = accc_parallel(tol, optacc, label, dfxfile, accfile, thrfile,
inlfile)
```

Fortran command syntax:

```
CALL ACCC_PARALLEL(TOL, OPTACC, LABEL, DFXFILE, ACCFILE, THRFILE, INLFILE,
IERR)
```

Where:

Real TOL	Is the mismatch tolerance (input; Newton solution convergence tolerance, TOLN, by default).	
Integer OPTACC (10)	array of elements specifying solution options. The values are as follows:(input).	
	OPTACC(1)	tap adjustment flag. (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag. (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag. (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable
	OPTACC(4)	dc tap adjustment flag. (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag. (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag. (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag. (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage) (0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the stalled or tripped state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the stalled or tripped state.
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Character*32 LABEL	Is the name of the generation dispatch subsystem (blank by default, no default allowed if OPTIONS(10) is not 0). (input).	
Character*260 DFXFILE	Is the name of the Distribution Factor Data file. (input; no default allowed).	
Character*260 ACCFILE	Is the name of the Contingency Solution Output file. (input; no default allowed).	
Character*260 THRFILE	Is the name of the Load Throwover Data file. (input; blank by default).	
Character*260 INLFILE	Is the name of the Unit Inertia and Governor Data File. (input; blank by default).	

Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid TOL value
IERR = 2	invalid OPTIONS value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation dispatch subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	no Distribution Factor Data File specified
IERR = 9	no Contingency Solution Output File specified
IERR = 10	in-service induction machines are in the "stalled" or "tripped" state
IERR = 11	buses with bus type code and series element status inconsistencies
IERR = 12	no ZIP Archive Output File specified
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	error opening Unit Inertia and Governor Data File
IERR = 55	error opening ZIP Archive Output File
IERR = 56	prerequisite requirements for API are not met

1.1.7. ACCC_PARALLEL_2

Use this API routine to run the second release of the parallel implementation of the AC contingency calculation function (use ACCC_WITH_DSP_3 to run AC contingency calculation function serially). The API routine distributes contingency cases among multiple processors evenly, and tests the contingency cases assigned to each processor in parallel.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_ACCC_PARALLEL_2  TOL OPTACC(1)..OPTACC(11) LABEL DFXFILE ACCFILE
  THRFILE INLFILE ZIPFILE
```

Python command syntax:

```
ierr = accc_parallel_2(tol, optacc, label, dfxfile, accfile, thrfile,
  inlfile, zipfile)
```

Fortran command syntax:

```
CALL ACCC_PARALLEL_2(TOL, OPTACC, LABEL, DFXFILE, ACCFILE, THRFILE,
  INLFILE, ZIPFILE, IERR)
```

Where:

Real TOL	Is the mismatch tolerance (input; Newton solution convergence tolerance, TOLN, by default).	
Integer OPTACC (11)	array of elements specifying solution options. The values are as follows:(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable
	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable

	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage) (0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
	OPTACC(11)	ZIP archive flag (0 by default)
	OPTACC(11) = 0	do not write a ZIP archive file
	OPTACC(11) = 1	write a ZIP archive using the file specified as ZIPFILE
Character*32 LABEL		Is the name of the generation dispatch subsystem (blank by default, no default allowed if OPTIONS(10) is not 0) (input).
Character*260 DFXFILE		Is the name of the Distribution Factor Data file (input; no default allowed).
Character*260 ACCFILE		Is the name of the Contingency Solution Output file (input; no default allowed).
Character*260 THRFILE		Is the name of the Load Throwover Data file (input; blank by default).

Character*260 INLFILE	Is the name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 ZIPFILE	Is the name of the ZIP Archive Output File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	no Distribution Factor Data File specified
	IERR = 9	no Contingency Solution Output File specified
	IERR = 10	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 11	buses with bus type code and series element status inconsistencies
	IERR = 12	no ZIP Archive Output File specified
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	error opening Unit Inertia and Governor Data File
	IERR = 55	error opening ZIP Archive Output File
	IERR = 56	prerequisite requirements for API are not met.

1.1.8. ACCC_SINGLE_RUN_REPORT

This API routine is obsolete. It has been replaced by the API routine [accc_single_run_report_2](#).

Use this API, the AC Contingency Report function, to report the results of the AC Contingency Calculation function.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ACCC_SINGLE_RUN_REPORT STATUS(1)..STATUS(8) INTVAL(1)..INTVAL(5)
REALVAL(1)..REALVAL(7) RFILE
```

Python command syntax:

```
ierr = accc_single_run_report(status, intval, realval, rfile)
```

Fortran command syntax:

```
CALL ACCC_SINGLE_RUN_REPORT(STATUS, INTVAL, REALVAL, RFILE, IERR)
```

Where:

Integer STATUS (8)	array of 8 elements specifying (input).
STATUS(1)	report format (3 by default)
STATUS(1) = 0	spreadsheet overload report
STATUS(1) = 1	spreadsheet loading table
STATUS(1) = 2	available capacity table
STATUS(1) = 3	non-spreadsheet overload report
STATUS(1) = 4	non-spreadsheet loading table
STATUS(1) = 5	non-converged networks report
STATUS(2)	base case rating set; used only when STATUS(1) is 0, 1, 3 or 4 (rating set program option setting by default)
STATUS(2) = 1	rate A
STATUS(2) = 2	rate B
STATUS(2) = 3	rate C
STATUS(3)	contingency case rating set when STATUS(1) is 0, 1, 3 or 4; base case and contingency case rating set when STATUS(1) is 2 (rating set program option setting by default)
STATUS(3) = 1	rate A
STATUS(3) = 2	rate B
STATUS(3) = 3	rate C
STATUS(4)	exclude interfaces from report; used only when STATUS(1) is 0, 1, 2, 3 or 4 (0 by default)
STATUS(4) = 0	no
STATUS(4) = 1	yes

	STATUS(5)	run voltage limit check; used only when STATUS(1) is 0, 1, 3 or 4 (0 by default)
	STATUS(5) = 0	no
	STATUS(5) = 1	yes
	STATUS(6)	in overload reports, exclude monitored branches and interfaces that show load-ing violations in the base case from being checked and reported in contingency cases; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(6) = 0	no
	STATUS(6) = 1	yes
	STATUS(7)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(7) = 0	no
	STATUS(7) = 1	yes
	STATUS(8)	exclude cases with no overloads from non-spreadsheet overload report; used only when STATUS(1) is 3 (0 by default)
	STATUS(8) = 0	no
	STATUS(8) = 1	yes
Integer INTVAL (5)	array of 5 elements specifying (input).	
	INTVAL(1)	number of low voltage range violations filtering criterion (0 by default)
	INTVAL(2)	number of high voltage range violations filtering criterion (0 by default)
	INTVAL(3)	number of voltage deviation violations filtering criterion; not applied to base case (0 by default)
	INTVAL(4)	number of buses in the largest disconnected island filtering criterion; not applied to base case (0 by default)
	INTVAL(5)	maximum number of elements in the available capacity table (no limit by default)
Real REALVAL (7)	array of 7 elements specifying (input).	
	REALVAL(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	REALVAL(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	REALVAL(3)	percent of flow rating; used only when STATUS(1) is 0, 3 or 4 (100.0 by default)

	REALVAL(4)	in overload reports, minimum contingency case flow change from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(5)	in overload reports, minimum contingency case percent loading increase from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(6)	in voltage range violation reports, minimum contingency case voltage change from base case value; used only when STATUS(1) is 0, 1, 3 or 4 (0.0 by default)
	REALVAL(7)	cutoff threshold for available capacity table; used only when STATUS(1) is 2 (99999.0 by default)
Character* 260 RFILE	Contingency Solution Output File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATUS value
	IERR = 2	invalid INTVAL value
	IERR = 3	invalid REALVAL value
	IERR = 4	error opening RFILE
	IERR = 5	error reading RFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.9. ACCC_SINGLE_RUN_REPORT_2

This API routine is obsolete. It has been replaced by the API routine [accc_single_run_report_3](#).

This API is the second release of the AC Contingency Report function. Use this API to report the results of the AC Contingency Calculation function.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_ACCC_SINGLE_RUN_REPORT_2 STATUS(1)..STATUS(9) INTVAL(1)..INTVAL(5)
REALVAL(1)..REALVAL(7) RFILE
```

Python command syntax:

```
ierr = accc_single_run_report_2(status, intval, realval, rfile)
```

Fortran command syntax:

```
CALL ACCC_SINGLE_RUN_REPORT_2(STATUS, INTVAL, REALVAL, RFILE, IERR)
```

Where:

Integer STATUS (9)	array of 9 elements specifying (input).
STATUS(1)	report format (3 by default)
STATUS(1) = 0	spreadsheet overload report
STATUS(1) = 1	spreadsheet loading table
STATUS(1) = 2	available capacity table
STATUS(1) = 3	non-spreadsheet overload report
STATUS(1) = 4	non-spreadsheet loading table
STATUS(1) = 5	non-converged networks report
STATUS(1) = 6	non-spreadsheet corrective actions report
STATUS(2)	base case rating set; used only when STATUS(1) is 0, 1, 3 or 4 (rating set program option setting by default)
STATUS(2) = 1	rate A
STATUS(2) = 2	rate B
STATUS(2) = 3	rate C
STATUS(3)	contingency case rating set when STATUS(1) is 0, 1, 3 or 4; base case and contingency case rating set when STATUS(1) is 2 (rating set program option setting by default)
STATUS(3) = 1	rate A
STATUS(3) = 2	rate B
STATUS(3) = 3	rate C
STATUS(4)	exclude interfaces from report; used only when STATUS(1) is 0, 1, 2, 3, 4 (0 by default)
STATUS(4) = 0	no
STATUS(4) = 1	yes

	STATUS(5)	run voltage limit check; used only when STATUS(1) is 0, 1, 3, 4 (0 by default)
	STATUS(5) = 0	no
	STATUS(5) = 1	yes
	STATUS(6)	in overload reports, exclude monitored branches and interfaces that show load-ing violations in the base case from being checked and reported in contingency cases; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(6) = 0	no
	STATUS(6) = 1	yes
	STATUS(7)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(7) = 0	no
	STATUS(7) = 1	yes
	STATUS(8)	exclude cases with no overloads from non-spreadsheet overload report or non-spreadsheet corrective actions report; used only when STATUS(1) is 3 (0 by default)
	STATUS(8) = 0	no
	STATUS(8) = 1	yes
	STATUS(9)	report post-tripping action solutions (0 by default)
	STATUS(9) = 0	no
	STATUS(9) = 1	yes
Integer INTVAL (5)	array of 5 elements specifying (input).	
	INTVAL(1)	number of low voltage range violations filtering criterion (0 by default)
	INTVAL(2)	number of high voltage range violations filtering criterion (0 by default)
	INTVAL(3)	number of voltage deviation violations filtering criterion; not applied to base case (0 by default)
	INTVAL(4)	number of buses in the largest disconnected island filtering criterion; not applied to base case (0 by default)
	INTVAL(5)	maximum number of elements in the available capacity table (no limit by default)
Real REALVAL (7)	array of 7 elements specifying (input).	
	REALVAL(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)

	REALVAL(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	REALVAL(3)	percent of flow rating; used only when STATUS(1) is 0, 3 or 4 (100.0 by default)
	REALVAL(4)	in overload reports, minimum contingency case flow change from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(5)	in overload reports, minimum contingency case percent loading increase from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(6)	in voltage range violation reports, minimum contingency case voltage change from base case value; used only when STATUS(1) is 0, 1, 3 or 4 (0.0 by default)
	REALVAL(7)	cutoff threshold for available capacity table; used only when STATUS(1) is 2 (99999.0 by default)
Character*260 RFILE	Contingency Solution Output File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATUS value
	IERR = 2	invalid INTVAL value
	IERR = 3	invalid REALVAL value
	IERR = 4	error opening RFILE
	IERR = 5	error reading RFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.10. ACCC_SINGLE_RUN_REPORT_3

This API routine is obsolete. It has been replaced by the API routine [accc_single_run_report_4](#).

This API is the third release of the AC Contingency Report function. Use this API to report the results of the AC Contingency Calculation function.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ACCC_SINGLE_RUN_REPORT_3 STATUS(1)..STATUS(10) INTVAL(1)..INTVAL(5)
REALVAL(1)..REALVAL(7) RFILE
```

Python command syntax:

```
ierr = accc_single_run_report_3(status, intval, realval, rfile)
```

Fortran command syntax:

```
CALL ACCC_SINGLE_RUN_REPORT_3(STATUS, INTVAL, REALVAL, RFILE, IERR)
```

Where:

Integer STATUS (10)	array of 10 elements specifying (input).
STATUS(1)	report format (3 by default)
STATUS(1) = 0	spreadsheet overload report
STATUS(1) = 1	spreadsheet loading table
STATUS(1) = 2	available capacity table
STATUS(1) = 3	non-spreadsheet overload report
STATUS(1) = 4	non-spreadsheet loading table
STATUS(1) = 5	non-converged networks report
STATUS(1) = 6	non-spreadsheet corrective actions report
STATUS(2)	base case rating set; used only when STATUS(1) is 0, 1, 3 or 4 (rating set program option setting by default)
STATUS(2) = 1	rate A
STATUS(2) = 2	rate B
STATUS(2) = 3	rate C
STATUS(3)	contingency case rating set when STATUS(1) is 0, 1, 3 or 4; base case and contingency case rating set when STATUS(1) is 2 (rating set program option setting by default)
STATUS(3) = 1	rate A
STATUS(3) = 2	rate B
STATUS(3) = 3	rate C
STATUS(4)	exclude interfaces from report; used only when STATUS(1) is 0, 1, 2, 3, 4 (0 by default)
STATUS(4) = 0	no
STATUS(4) = 1	yes

STATUS(5)	run voltage limit check; used only when STATUS(1) is 0, 1, 3, 4 (0 by default)
STATUS(5) = 0	no
STATUS(5) = 1	yes
STATUS(6)	in overload reports, exclude monitored branches and interfaces that show load-ing violations in the base case from being checked and reported in contingency cases; used only when STATUS(1) is 0 or 3 (0 by default)
STATUS(6) = 0	no
STATUS(6) = 1	yes
STATUS(7)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports; used only when STATUS(1) is 0 or 3 (0 by default)
STATUS(7) = 0	no
STATUS(7) = 1	yes
STATUS(8)	exclude cases with no overloads from non-spreadsheet overload report or non-spreadsheet corrective actions report; used only when STATUS(1) is 3 (0 by default)
STATUS(8) = 0	no
STATUS(8) = 1	yes
STATUS(9)	report post-tripping action solutions (0 by default)
STATUS(9) = 0	no
STATUS(9) = 1	yes
STATUS(10)	report loss of loads (0 by default)
STATUS(10) = 0	no
STATUS(10) = 1	yes
Integer INTVAL (5)	array of 5 elements specifying (input).
INTVAL(1)	number of low voltage range violations filtering criterion (0 by default)
INTVAL(2)	number of high voltage range violations filtering criterion (0 by default)
INTVAL(3)	number of voltage deviation violations filtering criterion; not applied to base case (0 by default)
INTVAL(4)	number of buses in the largest disconnected island filtering criterion; not applied to base case (0 by default)
INTVAL(5)	maximum number of elements in the available capacity table (no limit by default)

Real REALVAL (7)	array of 7 elements specifying (input).	
	REALVAL(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	REALVAL(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	REALVAL(3)	percent of flow rating; used only when STATUS(1) is 0, 3 or 4 (100.0 by default)
	REALVAL(4)	in overload reports, minimum contingency case flow change from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(5)	in overload reports, minimum contingency case percent loading increase from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(6)	in voltage range violation reports, minimum contingency case voltage change from base case value; used only when STATUS(1) is 0, 1, 3 or 4 (0.0 by default)
	REALVAL(7)	cutoff threshold for available capacity table; used only when STATUS(1) is 2 (99999.0 by default)
Character*260 RFILE	Contingency Solution Output File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATUS value
	IERR = 2	invalid INTVAL value
	IERR = 3	invalid REALVAL value
	IERR = 4	error opening RFILE
	IERR = 5	error reading RFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.11. ACCC_SINGLE_RUN_REPORT_4

This API is the fourth release of the AC Contingency Report function. Use this API to report the results of the AC Contingency Calculation function.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_ACCC_SINGLE_RUN_REPORT_4 STATUS(1)..STATUS(12) INTVAL(1)..INTVAL(5)
REALVAL(1)..REALVAL(7) RFILE
```

Python command syntax:

```
ierr = accc_single_run_report_4(status, intval, realval, rfile)
```

Fortran command syntax:

```
CALL ACCC_SINGLE_RUN_REPORT_4(STATUS, INTVAL, REALVAL, RFILE, IERR)
```

Where:

Integer STATUS (12)	array of 12 elements specifying (input).
STATUS(1)	report format (3 by default)
STATUS(1) = 0	spreadsheet overload report
STATUS(1) = 1	spreadsheet loading table
STATUS(1) = 2	available capacity table
STATUS(1) = 3	non-spreadsheet overload report
STATUS(1) = 4	non-spreadsheet loading table
STATUS(1) = 5	non-converged networks report
STATUS(1) = 6	non-spreadsheet corrective actions report
STATUS(2)	base case rating set; used only when STATUS(1) is 0, 1, 3 or 4 (rating set program option setting by default)
STATUS(2) = 1	rate A
STATUS(2) = 2	rate B
STATUS(2) = 3	rate C
STATUS(3)	contingency case rating set when STATUS(1) is 0, 1, 3 or 4; base case and contingency case rating set when STATUS(1) is 2 (rating set program option setting by default)
STATUS(3) = 1	rate A
STATUS(3) = 2	rate B
STATUS(3) = 3	rate C
STATUS(4)	base case voltage limit when STATUS(1) is 0, 1, 3 or 4
STATUS(4) = 1	normal limit
STATUS(4) = 2	emergency limit
STATUS(5)	contingency case voltage limit when STATUS(1) is 0, 1, 3 or 4

	STATUS(5) = 1	normal limit
	STATUS(5) = 2	emergency limit
	STATUS(6)	exclude interfaces from report; used only when STATUS(1) is 0, 1, 2, 3, 4 (0 by default)
	STATUS(6) = 0	no
	STATUS(6) = 1	yes
	STATUS(7)	run voltage limit check; used only when STATUS(1) is 0, 1, 3, 4 (0 by default)
	STATUS(7) = 0	no
	STATUS(7) = 1	yes
	STATUS(8)	in overload reports, exclude monitored branches and interfaces that show loading violations in the base case from being checked and reported in contingency cases; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(8) = 0	no
	STATUS(8) = 1	yes
	STATUS(9)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(9) = 0	no
	STATUS(9) = 1	yes
	STATUS(10)	exclude cases with no overloads from non-spreadsheet overload report or non-spreadsheet corrective actions report; used only when STATUS(1) is 3 (0 by default)
	STATUS(10) = 0	no
	STATUS(10) = 1	yes
	STATUS(11)	report post-tripping action solutions (0 by default)
	STATUS(11) = 0	no
	STATUS(11) = 1	yes
	STATUS(12)	report loss of loads (0 by default)
	STATUS(12) = 0	no
	STATUS(12) = 1	yes
Integer INTVAL (5)	array of 5 elements specifying (input).	
	INTVAL(1)	number of low voltage range violations filtering criterion (0 by default)
	INTVAL(2)	number of high voltage range violations filtering criterion (0 by default)

	INTVAL(3)	number of voltage deviation violations filtering criterion; not applied to base case (0 by default)
	INTVAL(4)	number of buses in the largest disconnected island filtering criterion; not applied to base case (0 by default)
	INTVAL(5)	maximum number of elements in the available capacity table (no limit by default)
Real REALVAL (7)	array of 7 elements specifying (input).	
	REALVAL(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	REALVAL(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	REALVAL(3)	percent of flow rating; used only when STATUS(1) is 0, 3 or 4 (100.0 by default)
	REALVAL(4)	in overload reports, minimum contingency case flow change from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(5)	in overload reports, minimum contingency case percent loading increase from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(6)	in voltage range violation reports, minimum contingency case voltage change from base case value; used only when STATUS(1) is 0, 1, 3 or 4 (0.0 by default)
	REALVAL(7)	cutoff threshold for available capacity table; used only when STATUS(1) is 2 (99999.0 by default)
Character* 260 RFILE	Contingency Solution Output File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATUS value
	IERR = 2	invalid INTVAL value
	IERR = 3	invalid REALVAL value
	IERR = 4	error opening RFILE
	IERR = 5	error reading RFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.12. ACCC_SINGLE_RUN_REPORT_5

This API is the fourth release of the AC Contingency Report function. Use this API to report the results of the AC Contingency Calculation function.

This API routine was first introduced in release 34.5.0.

Batch command syntax:

```
BAT_ACCC_SINGLE_RUN_REPORT_5 STATUS(1)..STATUS(14) INTVAL(1)..INTVAL(5)
REALVAL(1)..REALVAL(7) RFILE
```

Python command syntax:

```
ierr = accc_single_run_report_5(status, intval, realval, rfile)
```

Fortran command syntax:

```
CALL ACCC_SINGLE_RUN_REPORT_5(STATUS, INTVAL, REALVAL, RFILE, IERR)
```

Where:

Integer STATUS (14)	array of 14 elements specifying (input).
STATUS(1)	report format (3 by default)
STATUS(1) = 0	spreadsheet overload report
STATUS(1) = 1	spreadsheet loading table
STATUS(1) = 2	available capacity table
STATUS(1) = 3	non-spreadsheet overload report
STATUS(1) = 4	non-spreadsheet loading table
STATUS(1) = 5	non-converged networks report
STATUS(1) = 6	non-spreadsheet corrective actions report
STATUS(2)	base case branch rating set; used only when STATUS(1) is 0, 1, 3 or 4 (rating set program option setting by default)
STATUS(2) = 1	rate 1
STATUS(2) = 2	rate 2
STATUS(2) = 3	rate 3
STATUS(2) = 4	rate 4
STATUS(2) = 5	rate 5
STATUS(2) = 6	rate 6
STATUS(2) = 7	rate 7
STATUS(2) = 8	rate 8
STATUS(2) = 9	rate 9
STATUS(2) = 10	rate 10
STATUS(2) = 11	rate 11
STATUS(2) = 12	rate 12
STATUS(3)	contingency case branch rating set when STATUS(1) is 0, 1, 3 or 4; base case and contingency case rating set when STATUS(1) is 2 (rating set program option setting by default)

STATUS(3) = 1	rate 1
STATUS(3) = 2	rate 2
STATUS(3) = 3	rate 3
STATUS(3) = 4	rate 4
STATUS(3) = 5	rate 5
STATUS(3) = 6	rate 6
STATUS(3) = 7	rate 7
STATUS(3) = 8	rate 8
STATUS(3) = 9	rate 9
STATUS(3) = 10	rate 10
STATUS(3) = 11	rate 11
STATUS(3) = 12	rate 12
STATUS(4)	base case SWD rating set; used only when STATUS(1) is 0, 1, 3 or 4 (rating set program option setting by default)
STATUS(4) = 1	rate 1
STATUS(4) = 2	rate 2
STATUS(4) = 3	rate 3
STATUS(5)	contingency case SWD rating set when STATUS(1) is 0, 1, 3 or 4; base case and contingency case rating set when STATUS(1) is 2 (rating set program option setting by default)
STATUS(5) = 1	rate 1
STATUS(5) = 2	rate 2
STATUS(5) = 3	rate 3
STATUS(6)	base case voltage limit when STATUS(1) is 0, 1, 3 or 4
STATUS(6) = 1	normal limit
STATUS(6) = 2	emergency limit
STATUS(7)	contingency case voltage limit when STATUS(1) is 0, 1, 3 or 4
STATUS(7) = 1	normal limit
STATUS(7) = 2	emergency limit
STATUS(8)	exclude interfaces from report; used only when STATUS(1) is 0, 1, 2, 3, 4 (0 by default)
STATUS(8) = 0	no
STATUS(8) = 1	yes
STATUS(9)	run voltage limit check; used only when STATUS(1) is 0, 1, 3, 4 (0 by default)
STATUS(9) = 0	no
STATUS(9) = 1	yes
STATUS(10)	in overload reports, exclude monitored branches and interfaces that show loading violations in the base case from being checked and reported in contingency cases;

		used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(10) = 0	no
	STATUS(10) = 1	yes
	STATUS(11)	in voltage range violation reports, exclude monitored buses that show voltage range violations in the base case from the corresponding check in contingency case reports; used only when STATUS(1) is 0 or 3 (0 by default)
	STATUS(11) = 0	no
	STATUS(11) = 1	yes
	STATUS(12)	exclude cases with no overloads from non-spreadsheet overload report or non-spreadsheet corrective actions report; used only when STATUS(1) is 3 (0 by default)
	STATUS(12) = 0	no
	STATUS(12) = 1	yes
	STATUS(13)	report post-tripping action solutions (0 by default)
	STATUS(13) = 0	no
	STATUS(13) = 1	yes
	STATUS(14)	report loss of loads (0 by default)
	STATUS(14) = 0	no
	STATUS(14) = 1	yes
Integer INTVAL (5)	array of 5 elements specifying (input).	
	INTVAL(1)	number of low voltage range violations filtering criterion (0 by default)
	INTVAL(2)	number of high voltage range violations filtering criterion (0 by default)
	INTVAL(3)	number of voltage deviation violations filtering criterion; not applied to base case (0 by default)
	INTVAL(4)	number of buses in the largest disconnected island filtering criterion; not applied to base case (0 by default)
	INTVAL(5)	maximum number of elements in the available capacity table (no limit by default)
Real REALVAL (7)	array of 7 elements specifying (input).	
	REALVAL(1)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	REALVAL(2)	system mismatch converged tolerance (MVA) (5.0 by default)
	REALVAL(3)	percent of flow rating; used only when STATUS(1) is 0, 3 or 4 (100.0 by default)

	REALVAL(4)	in overload reports, minimum contingency case flow change from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(5)	in overload reports, minimum contingency case percent loading increase from base case value; used only when STATUS(1) is 0 or 3 (0.0 by default)
	REALVAL(6)	in voltage range violation reports, minimum contingency case voltage change from base case value; used only when STATUS(1) is 0, 1, 3 or 4 (0.0 by default)
	REALVAL(7)	cutoff threshold for available capacity table; used only when STATUS(1) is 2 (99999.0 by default)
Character* 260 RFILE	Contingency Solution Output File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATUS value
	IERR = 2	invalid INTVAL value
	IERR = 3	invalid REALVAL value
	IERR = 4	error opening RFILE
	IERR = 5	error reading RFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.13. ACCC_TRIP_COR

This API routine is obsolete. It has been replaced by the API routine [accs_trip_cor_2](#).

Use this API to apply the AC contingency calculation with tripping simulations and corrective actions. When there are violations in the post-tripping simulation solutions, the corrections actions analysis is launched to eliminate the violations, with the objective of minimizing the controls adjustments, including load shedding, MW generation dispatch and phase shifter angle adjustments. Rating set program option setting and 100.0 percent of rating set are used to check branch and interface flow overload violations.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_ACCC_TRIP_COR  TOL  OPTACC(1)..OPTACC(8) OPTTRP(1)..OPTTRP(3)
  OPTCOR(1)..OPTCOR(5)  VALUES(1)..VALUES(5)  LABELS(1)..LABELS(4)  DFXFILE
  ACCFILE  THRFILE  INLFILE  TRPFILE
```

Python command syntax:

```
ierr = accc_trip_cor(tol, optacc, opttrp, optcor, values, labels, dfxfile,
  accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL ACCC_TRIP_COR(TOL, OPTACC, OPTTRP, OPTCOR, VALUES, LABELS, DFXFILE,
  ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (5)	array of 5 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective actions (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flow solutions (from 0 to 10, 1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable

	OPTCOR(5) = 1	enable
Real VALUES (5)	array of 5 elements specifying corrective actions parameters(input).	
	VALUES(1)	bus voltage violation tolerance (0.1 by default)
	VALUES(2)	branch flow overload tolerance (0.1 by default)
	VALUES(3)	generator control weighting factor (1.0 by default)
	VALUES(4)	load control weighting factor (1.0 by default)
	VALUES(5)	phase shifter control weighting factor (1.0 by default)
Character*32 LABELS (4)	array of 4 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(3)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(4)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTTRP value
	IERR = 9	invalid OPTCOR value

IERR = 10	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 49	error opening Tripping Element Data File
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for API are not met

1.1.14. ACCC_TRIP_COR_2

This API routine is obsolete. It has been replaced by the API routine [acc_trip_cor_3](#).

This API is the second release of the function to run AC contingency analysis with tripping simulation and corrective actions. Following a post contingency solution, trip events are simulated if their tripping conditions are satisfied. Corrective actions are then specified automatically to eliminate the violations in each post tripping solution with the objective of minimizing the control adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls. Please note that flows are checked against rating set program option setting and 100.0 percent of the rating to determine flow overload violations.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_ACCC_TRIP_COR_2  TOL OPTACC(1)..OPTACC(8) OPTTRP(1)..OPTTRP(3)
  OPTCOR(1)..OPTCOR(8) VALUES(1)..VALUES(8) LABELS(1)..LABELS(7) DFXFILE
  ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = accc_trip_cor_2(tol, optacc, opttrp, optcor, values, labels,
  dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL ACCC_TRIP_COR_2(TOL, OPTACC, OPTTRP, OPTCOR, VALUES, LABELS, DFXFILE,
  ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).	
Integer OPTACC (8)	array of 8 elements specifying power flow solution(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable

	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (RESERVE)
	OPTACC(8) = 2	subsystem machines (PMAX)
	OPTACC(8) = 3	subsystem machines (INERTIA)
	OPTACC(8) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flow solutions (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)

	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (8)	array of 8 elements specifying corrective actions parameters(input).	
	VALUES(1)	bus voltage violation tolerance (0.1 by default)
	VALUES(2)	branch overload violation tolerance (0.1 by default)
	VALUES(3)	generator control weighting factor (1.0 by default)
	VALUES(4)	load control weighting factor (1.0 by default)
	VALUES(5)	phase shifter control weighting factor (1.0 by default)
	VALUES(6)	off-line generator control weighting factor (1.0 by default)
	VALUES(7)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(8)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (7)	array of 7 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(3)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(4)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
	LABELS(5)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(6)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)

	LABELS(7)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE		name of Distribution Factor Data File (input; no default allowed).
Character*260 ACCFILE		name of Contingency Solution Output File (input; no default allowed).
Character*260 THRFILE		name of Load Throwover Data File (input; blank for none).
Character*260 INLFILE		name of Unit Inertia Data File (input; blank for none).
Character*260 TRPFILE		name of Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTTRP value
	IERR = 9	invalid OPTCOR value
	IERR = 10	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.15. ACCC_TRIP_COR_3

This API is the third release of the function to run AC contingency analysis with tripping simulation and corrective actions. Following a post contingency solution, trip events are simulated if their tripping conditions are satisfied. Corrective actions are then specified automatically to eliminate the violations in each post tripping solution with the objective of minimizing the control adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls. Please note that flows are checked against rating set program option setting and 100.0 percent of the rating to determine flow overload violations.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ACCC_TRIP_COR_3  TOL OPTACC(1)..OPTACC(10) OPTTRP(1)..OPTTRP(3)
  OPTCOR(1)..OPTCOR(8) VALUES(1)..VALUES(8) LABELS(1)..LABELS(7) DFXFILE
  ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = accc_trip_cor_3(tol, optacc, opttrp, optcor, values, labels,
  dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL ACCC_TRIP_COR_3(TOL, OPTACC, OPTTRP, OPTCOR, VALUES, LABELS, DFXFILE,
  ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (RESERVE)
	OPTACC(10) = 2	subsystem machines (PMAX)
	OPTACC(10) = 3	subsystem machines (INERTIA)
	OPTACC(10) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable

	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flow solutions (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (8)	array of 8 elements specifying corrective actions parameters(input).	
	VALUES(1)	bus voltage violation tolerance (0.1 by default)
	VALUES(2)	branch overload violation tolerance (0.1 by default)
	VALUES(3)	generator control weighting factor (1.0 by default)
	VALUES(4)	load control weighting factor (1.0 by default)
	VALUES(5)	phase shifter control weighting factor (1.0 by default)
	VALUES(6)	off-line generator control weighting factor (1.0 by default)
	VALUES(7)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(8)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (7)	array of 7 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)

	LABELS(3)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(4)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
	LABELS(5)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(6)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(7)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE		name of Distribution Factor Data File (input; no default allowed).
Character*260 ACCFILE		name of Contingency Solution Output File (input; no default allowed).
Character*260 THRFILE		name of Load Throwover Data File (input; blank for none).
Character*260 INLFILE		name of Unit Inertia Data File (input; blank for none).
Character*260 TRPFILE		name of Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTTRP value
	IERR = 11	invalid OPTCOR value
	IERR = 12	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia Data File
	IERR = 51	error opening Contingency Solution Output File

IERR = 52

error opening Distribution Factor Data File

IERR = 53

error opening Load Throwover Data File

IERR = 54

prerequisite requirements for function not met

1.1.16. ACCC_WITH_COR

This API routine is obsolete. It has been replaced by the API routine [accc_with_cor_2](#).

Use this API to apply the AC contingency calculation with corrective actions. When there are violations in the post-contingency solutions, the corrections actions analysis is launched to eliminate the violations, with the objective of minimizing the controls adjustments, including load shedding, MW generation dispatch, and phase shifter angle adjustments. Rating set program option setting and 100.0 percent of the rating set are used to check branch and interface flow overload violations.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_ACCC_WITH_COR  TOL  OPTACC(1)..OPTACC(8)  OPTCOR(1)..OPTCOR(5)
VALUES(1)..VALUES(5)  LABELS(1)..LABELS(4)  DFXFILE  ACCFILE  THRFILE
INLFILE
```

Python command syntax:

```
ierr = accc_with_cor(tol, optacc, optcor, values, labels, dfxfile,
accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_COR(TOL, OPTACC, OPTCOR, VALUES, LABELS, DFXFILE, ACCFILE,
THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTCOR (5)	array of 5 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective actions (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flow solutions (from 0 to 10, 1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load curtailment flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
Real VALUES (5)	array of 5 elements specifying corrective actions parameters(input).	
	VALUES(1)	bus voltage violation tolerance (0.1 by default)
	VALUES(2)	branch flow overload tolerance (0.1 by default)
	VALUES(3)	generator control weighting factor (1.0 by default)

	VALUES(4)	load control weighting factor (1.0 by default)
	VALUES(5)	phase shifter control weighting factor (1.0 by default)
Character*32 LABELS (4)	array of 4 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(3)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(4)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTCOR value
	IERR = 9	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File

IERR = 54

prerequisite requirements for API are not met

1.1.17. ACCC_WITH_COR_2

This API routine is obsolete. It has been replaced by the API routine [accc_with_cor_3](#).

This API is the second release of function to run AC contingency analysis with corrective actions. Corrective actions are specified automatically to eliminate the violations in each post contingency solution with the objective of minimizing the controls adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls. Please note that flows are checked against rating set program option setting and 100.0 percent of the rating to determine flow overload violations.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_ACCC_WITH_COR_2  TOL OPTACC(1)..OPTACC(8) OPTCOR(1)..OPTCOR(8)
VALUES(1)..VALUES(8) LABELS(1)..LABELS(7)  DFXFILE ACCFILE THRFILE
INLFILE
```

Python command syntax:

```
ierr = accc_with_cor_2(tol, optacc, optcor, values, labels, dfxfile,
accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_COR_2(TOL, OPTACC, OPTCOR, VALUES, LABELS, DFXFILE,
ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).	
Integer OPTACC (8)	array of 8 elements specifying power flow solution(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable

	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (RESERVE)
	OPTACC(8) = 2	subsystem machines (PMAX)
	OPTACC(8) = 3	subsystem machines (INERTIA)
	OPTACC(8) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective actions (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable

	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (8)	array of 8 elements specifying corrective actions parameters(input).	
	VALUES(1)	bus voltage violation tolerance (0.1 by default)
	VALUES(2)	branch overload violation tolerance (0.1 by default)
	VALUES(3)	generator control weighting factor (1.0 by default)
	VALUES(4)	load control weighting factor (1.0 by default)
	VALUES(5)	phase shifter control weighting factor (1.0 by default)
	VALUES(6)	off-line generator control weighting factor (1.0 by default)
	VALUES(7)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(8)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (7)	array of 7 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(3)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(4)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
	LABELS(5)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(6)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(7)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred

IERR = 1	invalid TOL value
IERR = 2	invalid OPTACC value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	invalid OPTCOR value
IERR = 9	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multisection line members
IERR = 50	error opening Unit Inertia Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.18. ACCC_WITH_COR_3

This API is the third release of function to run AC contingency analysis with corrective actions. Corrective actions are specified automatically to eliminate the violations in each post contingency solution with the objective of minimizing the controls adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls. Please note that flows are checked against rating set program option setting and 100.0 percent of the rating to determine flow overload violations.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ACCC_WITH_COR_3  TOL OPTACC(1)..OPTACC(10) OPTCOR(1)..OPTCOR(8)
VALUES(1)..VALUES(8) LABELS(1)..LABELS(7)  DFXFILE ACCFILE THRFILE
INLFILE
```

Python command syntax:

```
ierr = accc_with_cor_3(tol, optacc, optcor, values, labels, dfxfile,
accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_COR_3(TOL, OPTACC, OPTCOR, VALUES, LABELS, DFXFILE,
ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN, by default).
Integer OPTACC (10)	array of 10 elements specifying power flow solution(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable
OPTACC(1) = 1	enable stepping adjustment
OPTACC(1) = 2	enable direct adjustment
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable
OPTACC(3) = 1	enable
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable

	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (RESERVE)
	OPTACC(10) = 2	subsystem machines (PMAX)
	OPTACC(10) = 3	subsystem machines (INERTIA)
	OPTACC(10) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective actions (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)

	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (8)	array of 8 elements specifying corrective actions parameters(input).	
	VALUES(1)	bus voltage violation tolerance (0.1 by default)
	VALUES(2)	branch overload violation tolerance (0.1 by default)
	VALUES(3)	generator control weighting factor (1.0 by default)
	VALUES(4)	load control weighting factor (1.0 by default)
	VALUES(5)	phase shifter control weighting factor (1.0 by default)
	VALUES(6)	off-line generator control weighting factor (1.0 by default)
	VALUES(7)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(8)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (7)	array of 7 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(3)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(4)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
	LABELS(5)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(6)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)

	LABELS(7)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of Unit Inertia Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTCOR value
	IERR = 11	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 50	error opening Unit Inertia Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.19. ACCC_WITH_DSP

This API routine is obsolete. It has been replaced by the API routine [accc_with_dsp_2](#).

Use this API to apply the AC contingency calculation function with a generation dispatch function to handle imbalances in power resources and demand due to contingencies.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ACCC_WITH_DSP  TOL  OPTACC(1)..OPTACC(8)  LABEL  DFXFILE  ACCFILE
  THRFILE  INLFILE
```

Python command syntax:

```
ierr = accc_with_dsp(tol, optacc, label, dfxfile, accfile, thrfile,
  inlfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_DSP(TOL, OPTACC, LABEL, DFXFILE, ACCFILE, THRFILE, INLFILE,
  IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable

	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Character*32 LABEL	name of the generation dispatch subsystem (input; blank by default, no default allowed if OPTACC(8) is not 0).	
Character*260 DFXFILE	name of the Distribution Factor Data file (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output file (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data file (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	no Distribution Factor Data File specified
	IERR = 9	no Contingency Solution Output File specified
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX

IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	error opening Unit Inertia and Governor Data File
IERR = 55	prerequisite requirements for API are not met

1.1.20. ACCC_WITH_DSP_2

This API routine is obsolete. It has been replaced by the API routine [accc_with_dsp_3](#).

Use this API to run the second release of AC contingency calculation function (ACCC, ACCC_WITH_DSP). The API provides the options to handle induction machines in a contingency analysis.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ACCC_WITH_DSP_2  TOL  OPTIONS(1)..OPTIONS(10)  LABEL  DFXFILE  ACCFILE
  THRFILE  INLFILE
```

Python command syntax:

```
ierr = accc_with_dsp_2(tol, options, label, dfxfile, accfile, thrfile,
  inlfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_DSP_2(TOL, OPTIONS, LABEL, DFXFILE, ACCFILE, THRFILE,
  INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTIONS (10)	array of 10 elements specifying solution options(input).
	OPTIONS(1) tap adjustment flag (tap adjustment option setting by default)
	OPTIONS(1) = 0 disable
	OPTIONS(1) = 1 enable stepping adjustment
	OPTIONS(1) = 2 enable direct adjustment
	OPTIONS(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTIONS(2) = 0 disable
	OPTIONS(2) = 1 enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTIONS(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTIONS(3) = 0 disable
	OPTIONS(3) = 1 enable
	OPTIONS(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTIONS(4) = 0 disable
	OPTIONS(4) = 1 enable
	OPTIONS(5) switched shunt adjustment flag (switched shunt adjustment option setting by default)

	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	solution method flag (0 by default)
	OPTIONS(6) = 0	FDNS
	OPTIONS(6) = 1	FNSL
	OPTIONS(6) = 2	optimized FDNS
	OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(7) = 0	disable
	OPTIONS(7) = 1	enable
	OPTIONS(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(8) = 0	stall
	OPTIONS(8) = 1	trip
	OPTIONS(9)	induction machine failure flag (0 by default)
	OPTIONS(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTIONS(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTIONS(10)	dispatch mode (0 by default)
	OPTIONS(10) = 0	disable
	OPTIONS(10) = 1	subsystem machines (reserve)
	OPTIONS(10) = 2	subsystem machines (pmax)
	OPTIONS(10) = 3	subsystem machines (inertia)
	OPTIONS(10) = 4	subsystem machines (governor droop)
Character*32 LABEL	name of the generation dispatch subsystem (input; blank by default, no default allowed if OPTIONS(10) is not 0).	
Character*260 DFXFILE	name of the Distribution Factor Data file (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output file (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data file (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted

IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation dispatch subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	no Distribution Factor Data File specified
IERR = 9	no Contingency Solution Output File specified
IERR = 10	in-service induction machines are in the "stalled" or "tripped" state
IERR = 11	buses with bus type code and series element status inconsistencies
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	error opening Unit Inertia and Governor Data File
IERR = 55	prerequisite requirements for API are not met

1.1.21. ACCC_WITH_DSP_3

Use this API to run the second release of AC contingency calculation function (ACCC, ACCC_WITH_DSP). The API provides the options to handle induction machines in a contingency analysis.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_ACCC_WITH_DSP_3  TOL OPTACC(1)..OPTACC(11) LABEL DFXFILE ACCFILE
  THRFILE INLFILE ZIPFILE
```

Python command syntax:

```
ierr = accc_with_dsp_3(tol, optacc, label, dfxfile, accfile, thrfile,
  inlfile, zipfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_DSP_3(TOL, OPTACC, LABEL, DFXFILE, ACCFILE, THRFILE,
  INLFILE, ZIPFILE, IERR)
```

Where:

Real TOL	Is the mismatch tolerance. (input; Newton solution convergence tolerance, TOLN, by default).	
Integer OPTACC (11)	array of elements specifying solution options. The values are as follows:(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable
	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable

	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
	OPTACC(11)	ZIP archive flag (0 by default)
	OPTACC(11) = 0	do not write a ZIP archive file
	OPTACC(11) = 1	write a ZIP archive using the file specified as ZIPFILE
Character*32 LABEL	Is the name of the generation dispatch subsystem (blank by default, no default allowed if OPTIONS(10) is not 0). (input).	
Character*260 DFXFILE	Is the name of the Distribution Factor Data file (input; no default allowed).	
Character*260 ACCFILE	Is the name of the Contingency Solution Output file (input; no default allowed).	
Character*260 THRFILE	Is the name of the Load Throwover Data file (input; blank by default).	
Character*260 INLFILE	Is the name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 ZIPFILE	Is the name of the ZIP Archive Output File (input; blank by default).	
Integer IERR	error code (output).	

IERR = 0	no error occurred
IERR = 1	invalid TOL value
IERR = 2	invalid OPTIONS value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation dispatch subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	no Distribution Factor Data File specified
IERR = 9	no AC Contingency Solution Output File specified
IERR = 10	in-service induction machines are in the "stalled" or "tripped" state
IERR = 11	buses with bus type code and series element status inconsistencies
IERR = 12	no ZIP Archive Output File specified
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	error opening Unit Inertia and Governor Data File
IERR = 55	error opening ZIP Archive Output File
IERR = 56	prerequisite requirements for API are not met.

1.1.22. ACCC_WITH_TRIP

This API routine is obsolete. It has been replaced by the API routine [accc_with_trip_2](#).

Use this API to apply the AC contingency calculation function with a post-contingency tripping function. This may be used, for example, to simulate switchings that occur when specified monitored quantities are beyond threshold values.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ACCC_WITH_TRIP  TOL  OPTACC(1)..OPTACC(8)  OPTTRP(1)..OPTTRP(3)  LABEL
                    DFXFILE  ACCFILE  THRFILE  INLFILE  TRPFILE
```

Python command syntax:

```
ierr = accc_with_trip(tol, optacc, opttrp, label, dfxfile, accfile,
                    thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_TRIP(TOL, OPTACC, OPTTRP, LABEL, DFXFILE, ACCFILE, THRFILE,
                    INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable
	OPTACC(4) = 1 enable

	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Character*32 LABEL	name of the generation dispatch subsystem (input; blank by default; no default allowed if OPTACC(8) is not 0).	
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted

IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	Invalid OPTTRP value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 49	error opening Tripping Element Data File
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.23. ACCC_WITH_TRIP_2

Use this API to run the second version of AC contingency calculation function with a post-contingency tripping function. This may be used, for example, to simulate switchings that occur when specified monitored quantities are beyond threshold values.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ACCC_WITH_TRIP_2 TOL OPTACC(1)..OPTACC(10) OPTTRP(1)..OPTTRP(3)
  LABEL DFXFILE ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = accc_with_trip_2(tol, optacc, opttrp, label, dfxfile, accfile,
  thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_TRIP_2(TOL, OPTACC, OPTTRP, LABEL, DFXFILE, ACCFILE,
  THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable
	OPTACC(4) = 1 enable
	OPTACC(5) switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0 disable

	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Character*32 LABEL	name of the generation dispatch subsystem (input; blank by default; no default allowed if OPTACC(8) is not 0).	
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	

Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	Invalid OPTTRP value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.24. ACCC_WITH_TRIP_PARALLEL

Use this API to run the parallel version of AC contingency calculation function with a post-contingency tripping function (use ACCC_WITH_TRIP_2 to run the function sequentially). The API distributes contingency cases among multiple processors evenly, and tests the contingency cases and following tripping actions assigned to each processor in parallel.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_ACCC_WITH_TRIP_PARALLEL  TOL OPTACC(1)..OPTACC(10)
    OPTTRP(1)..OPTTRP(3) LABEL DFXFILE ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = accc_with_trip_parallel(tol, optacc, opttrp, label, dfxfile,
    accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL ACCC_WITH_TRIP_PARALLEL(TOL, OPTACC, OPTTRP, LABEL, DFXFILE, ACCFILE,
    THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	Is the mismatch tolerance (input; Newton solution convergence tolerance, TOLN, by default).
Integer OPTACC (10)	array of elements specifying power flow solution options. The values are as follows:(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable.
OPTACC(1) = 1	enable stepping adjustment.
OPTACC(1) = 2	enable direct adjustment.
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable.
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange.
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange.
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable.
OPTACC(3) = 1	enable.
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable.
OPTACC(4) = 1	enable.

	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable.
	OPTACC(5) = 1	enable.
	OPTACC(5) = 2	enable continuous mode, disable discrete mode.
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS.
	OPTACC(6) = 1	FNSL.
	OPTACC(6) = 2	optimized FDNS.
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable.
	OPTACC(7) = 1	enable.
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage). (0 by default)
	OPTACC(8) = 0	stall.
	OPTACC(8) = 1	trip.
	OPTACC(9)	induction machine failure flag. (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state.
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state.
	OPTACC(10)	dispatch mode. (0 by default)
	OPTACC(10) = 0	disable.
	OPTACC(10) = 1	subsystem machines (reserve).
	OPTACC(10) = 2	subsystem machines (pmax).
	OPTACC(10) = 3	subsystem machines (inertia).
	OPTACC(10) = 4	subsystem machines (governor droop).
Integer OPTTRP (3)		array of elements specifying tripping simulation options. The values are as follows:(input).
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable.
	OPTTRP(1) = 1	enable tripping simulation.
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Character*32 LABEL		Is the name of the generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0). (input).

Character*260 DFXFILE	Is the name of the Distribution Factor Data File. (input; no default allowed).
Character*260 ACCFILE	Is the name of the Contingency Solution Output File. (input; no default allowed).
Character*260 THRFILE	Is the name of the Load Throwover Data File. (input; blank by default).
Character*260 INLFILE	Is the name of the Unit Inertia and Governor Data File. (input; blank by default).
Character*260 TRPFILE	Is the name of the Tripping Element Data File (input, blank for none; no default allowed if OPTTRP(1) is 1). (input).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid TOL value
IERR = 2	invalid OPTACC value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation dispatch subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	Invalid OPTTRP value.
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 49	error opening Tripping Element Data File.
IERR = 50	error opening Unit Inertia and Governor Data File.
IERR = 51	error opening Contingency Solution Output File.
IERR = 52	error opening Distribution Factor Data File.
IERR = 53	error opening Load Throwover Data File.
IERR = 54	prerequisite requirements for API are not met.

1.1.25. ACCOR

This API routine is obsolete. It has been replaced by the API routine [accor_2](#).

Use this API to apply corrective actions to the base case using successive linear programming methods. The corrective actions are to eliminate flow overloads and voltage violations with the objective of minimizing the control adjustments, including load shedding, MW generations dispatch, and phase shifter angle adjustments.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_ACCOR  OPTIONS(1) .. OPTIONS(10)  VALUES(1) .. VALUES(7)
          LABELS(1) .. LABELS(3)  DFXFILE
```

Python command syntax:

```
ierr = accor(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL ACCORAPI(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (10)	array of 10 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable

	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	rating set (rating set program option setting by default)
	OPTIONS(6) = 1	rating A
	OPTIONS(6) = 2	rating B
	OPTIONS(6) = 3	rating C
	OPTIONS(7)	number of power flow solutions (from 1 to 10; 1 by default)
	OPTIONS(8)	generator control flag (1 by default)
	OPTIONS(8) = 0	disable
	OPTIONS(8) = 1	enable
	OPTIONS(9)	load control flag (0 by default)
	OPTIONS(9) = 0	disable
	OPTIONS(9) = 1	enable
	OPTIONS(10)	phase shifter control flag (1 by default)
	OPTIONS(10) = 0	disable
	OPTIONS(10) = 1	enable
Real VALUES (7)	array of 7 elements specifying AC corrective actions parameters(input).	
	VALUES(1)	MW mismatch tolerance (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating set (100.0 by default)
	VALUES(3)	bus voltage violation tolerance (0.1 by default)
	VALUES(4)	branch flow overload tolerance (0.1 by default)
	VALUES(5)	generator control weighting factor (1.0 by default)
	VALUES(6)	load control weighting factor (1.0 by default)
	VALUES(7)	phase shifter control weighting factor (1.0 by default)
Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).	
	LABELS(1)	label of generator control subsystem (blank by default; no default allowed if OPTIONS(8) is 1)
	LABELS(2)	label of load control subsystem (blank by default; no default allowed if OPTIONS(9) is 1)
	LABELS(3)	label of phase shifter control subsystem (blank by default; no default allowed if OPTIONS(10) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred

IERR = 1	invalid OPTIONS value
IERR = 2	invalid VALUES value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	No controls
IERR = 6	control subsystem not defined
IERR = 7	Distribution Factor Data File not specified
IERR = 8	largest mismatch exceeds tolerance
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Distribution Factor Data File
IERR = 52	prerequisite requirements for function not met

1.1.26. ACCOR_2

This API routine is obsolete. It has been replaced by the API routine [accor_3](#).

This API is the second release of corrective action function. Use this API to augment control strategies with off-line generator control, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_ACCOR_2  OPTIONS(1)..OPTIONS(13)  VALUES(1)..VALUES(10)
             LABELS(1)..LABELS(6)  DFXFILE
```

Python command syntax:

```
ierr = accor_2(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL ACCORAPI_2(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (13)	array of 13 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable

	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	rating set (rating set program option setting by default)
	OPTIONS(6) = 1	rating A
	OPTIONS(6) = 2	rating B
	OPTIONS(6) = 3	rating C
	OPTIONS(7)	number of power flow solutions (from 1 to 10; 1 by default)
	OPTIONS(8)	generator control flag (1 by default)
	OPTIONS(8) = 0	disable
	OPTIONS(8) = 1	enable
	OPTIONS(9)	load control flag (0 by default)
	OPTIONS(9) = 0	disable
	OPTIONS(9) = 1	enable
	OPTIONS(10)	phase shifter control flag (1 by default)
	OPTIONS(10) = 0	disable
	OPTIONS(10) = 1	enable
	OPTIONS(11)	off-line generator control flag (0 by default)
	OPTIONS(11) = 0	disable
	OPTIONS(11) = 1	enable
	OPTIONS(12)	tap setting adjustment flag (0 by default)
	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	enable
	OPTIONS(13)	switched shunt control flag (0 by default)
	OPTIONS(13) = 0	disable
	OPTIONS(13) = 1	enable
Real VALUES (10)	array of 10 elements specifying AC corrective actions parameters(input).	
	VALUES(1)	MW mismatch tolerance (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating set (100.0 by default)
	VALUES(3)	bus voltage violation tolerance (0.1 by default)
	VALUES(4)	branch flow overload tolerance (0.1 by default)
	VALUES(5)	generator control weighting factor (1.0 by default)
	VALUES(6)	load control weighting factor (1.0 by default)
	VALUES(7)	phase shifter control weighting factor (1.0 by default)
	VALUES(8)	off-line generator control weighting factor (1.0 by default)
	VALUES(9)	tap setting adjustment weighting factor (1.0 by default)

	VALUES(10)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (6)	array of 6 elements specifying subsystem labels(input).	
	LABELS(1)	label of generator control subsystem (blank by default; no default allowed if OPTIONS(8) is 1)
	LABELS(2)	label of load control subsystem (blank by default; no default allowed if OPTIONS(9) is 1)
	LABELS(3)	label of phase shifter control subsystem (blank by default; no default allowed if OPTIONS(10) is 1)
	LABELS(4)	off-line generator control subsystem (blank by default; no default allowed if OPTIONS(11) is 1)
	LABELS(5)	tap setting adjustment subsystem (blank by default; no default allowed if OPTIONS(12) is 1)
	LABELS(6)	switched shunt control subsystem (blank by default; no default allowed if OPTIONS(13) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus, use activity TREE
	IERR = 5	No controls
	IERR = 6	control subsystem not defined
	IERR = 7	Distribution Factor Data File not specified
	IERR = 8	largest mismatch exceeds tolerance
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file, run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	prerequisite requirements for function not met

1.1.27. ACCOR_3

This API is the third release of corrective action function. Use this API to specify voltage limits in determining voltage violations.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_ACCOR_3  OPTIONS(1)..OPTIONS(14) VALUES(1)..VALUES(10)
             LABELS(1)..LABELS(6) DFXFILE
```

Python command syntax:

```
ierr = accor_3(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL ACCORAPI_3(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (14)	array of elements specifying solution options. The values are as follows:(input).	
	OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable.
	OPTIONS(1) = 1	enable stepping adjustment.
	OPTIONS(1) = 2	enable direct adjustment.
	OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable.
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange.
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange.
	OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable.
	OPTIONS(3) = 1	enable.
	OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTIONS(4) = 0	disable.
	OPTIONS(4) = 1	enable.
	OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTIONS(5) = 0	disable.
	OPTIONS(5) = 1	enable.
	OPTIONS(5) = 2	enable continuous mode, disable discrete mode.

	OPTIONS(6)	rating set (rating set program option setting by default)
	OPTIONS(6) = 1	rating A
	OPTIONS(6) = 2	rating B
	OPTIONS(6) = 3	rating C
	OPTIONS(7)	voltage limit
	OPTIONS(7) = 1	normal
	OPTIONS(7) = 2	emergency
	OPTIONS(8)	number of power flow solutions (from 1 to 10; 1 by default)
	OPTIONS(9)	generator control flag (1 by default)
	OPTIONS(9) = 0	disable.
	OPTIONS(9) = 1	enable.
	OPTIONS(10)	load control flag. (0 by default)
	OPTIONS(10) = 0	disable.
	OPTIONS(10) = 1	enable.
	OPTIONS(11)	phase shifter control flag (1 by default)
	OPTIONS(11) = 0	disable.
	OPTIONS(11) = 1	enable.
	OPTIONS(12)	off-line generator control flag (0 by default)
	OPTIONS(12) = 0	disable.
	OPTIONS(12) = 1	enable.
	OPTIONS(13)	tap setting adjustment flag (0 by default)
	OPTIONS(13) = 0	disable.
	OPTIONS(13) = 1	enable.
	OPTIONS(14)	switched shunt control flag (0 by default)
	OPTIONS(14) = 0	disable.
	OPTIONS(14) = 1	enable.
Real VALUES (10)	array of elements specifying AC corrective actions parameters. The values are as follows:(input).	
	VALUES(1)	MW mismatch tolerance (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating set (100.0 by default)
	VALUES(3)	bus voltage violation tolerance (0.1 by default)
	VALUES(4)	branch flow overload tolerance (0.1 by default)
	VALUES(5)	generator control weighting factor (1.0 by default)
	VALUES(6)	load control weighting factor (1.0 by default)
	VALUES(7)	phase shifter control weighting factor (1.0 by default)
	VALUES(8)	off-line generator control weighting factor (1.0 by default)

	VALUES(9)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(10)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (6)	array of elements specifying subsystem labels (input). The values are as follows:(input).	
	LABELS(1)	label of generator control subsystem (blank by default; no default allowed if OPTIONS(9) is 1).
	LABELS(2)	label of load control subsystem (blank by default; no default allowed if OPTIONS(10) is 1).
	LABELS(3)	label of phase shifter control subsystem (blank by default; no default allowed if OPTIONS(11) is 1).
	LABELS(4)	off-line generator control subsystem (blank by default; no default allowed if OPTIONS(12) is 1).
	LABELS(5)	tap setting adjustment subsystem (blank by default; no default allowed if OPTIONS(13) is 1).
	LABELS(6)	switched shunt control subsystem (blank by default; no default allowed if OPTIONS(14) is 1).
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	No controls.
	IERR = 6	control subsystem not defined.
	IERR = 7	Distribution Factor Data File not specified.
	IERR = 8	largest mismatch exceeds tolerance.
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX.
	IERR = 22	monitored elements exceed limit when adding multi-section line members.
	IERR = 51	error opening Distribution Factor Data File.
	IERR = 52	prerequisite requirements for API are not met.

1.1.28. ALERT_OUTPUT

Use this API to specify the alert device.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_ALERT_OUTPUT ISLCT FILARG OPTIONS(1) OPTIONS(2)
```

Python command syntax:

```
ierr = alert_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL OPENALERTDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
	ISLCT = 1 standard destination. In the PSSE GUI standard output for alerts is a message box and a copy to the Alerts/Warnings tab of the output bar.
	ISLCT = 2 direct output to a file.
	ISLCT = 3 direct output to a printer.
	ISLCT = 4 direct output to progress device.
	ISLCT = 5 direct output to report device.
	ISLCT = 6 no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
	OPTIONS(1) file and printer open options: The OPTIONS(1) values may be summed to select multiple options
	OPTIONS(1) = 0 open with carriage control format and, for files, for overwrite of existing files
	OPTIONS(1) = 1 open with list format
	OPTIONS(1) = 2 open file for append (file output only)
	OPTIONS(1) = 2 set printer orientation to portrait mode (printer output only)
	OPTIONS(1) = 4 open printer in immediate print mode (printer output only)
	OPTIONS(2) number of copies to print (printer only)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met
	IERR = 2 failed to open device

1.1.29. ALLOW_PSSUSERPF

Use this API to specify or return the option to allow or disallow the loading or use of the Powerflow Customization Interface (PCI) implementation module (pssuserpf).

This API routine was first introduced in release 33.6.0 and 34.0.1.

Batch command syntax:

```
BAT_ALLOW_PSSUSERPF IVAL
```

Python command syntax:

```
ierr = allow_pssuserpf(ival)
ierr,ival = allow_pssuserpf()
```

Fortran command syntax:

```
CALL ALLOW_PSSUSERPF(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
	IVAL = 0 PCI disabled.
	IVAL = 1 PCI enabled.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.30. ALPH

Use this API to print an alphabetically sorted table of all buses in a specified subsystem of the working case (activity ALPH).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ALPH  SID  ALL
```

Python command syntax:

```
ierr = alph(sid, all)
```

Fortran command syntax:

```
CALL ALPHNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.31. APPEND_ACCC

Use this API to replicate system conditions of a contingency case solution, as contained in a designated Saved Case File, in the form of a Contingency Solution Output File. Results may be appended to an existing Contingency Solution Output File, or an new Contingency Solution Output File may be created.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_APPEND_ACCC  OPTION  DFXFILE  BASFILE  CNTFILE  ACCFILE  LABEL
                  NUMDESC  DESCRIPT(1)..DESCRIPT(NUMDESC)
```

Python command syntax:

```
ierr = append_accc(option, dfxfile, basfile, cntfile, accfile, label,
                  numdesc, descrpt)
```

Fortran command syntax:

```
CALL APPEND_ACCC(OPTION, DFXFILE, BASFILE, CNTFILE, ACCFILE, LABEL,
                  NUMDESC, DESCRIPT, IERR)
```

Where:

Integer OPTION	append flag (input; 1 by default). OPTION = 0 create a new Contingency Solution Output File in the file specified in ACCFILE. OPTION = 1 append results to the existing Contingency Solution Output File specified in ACCFILE
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).
Character*260 BASFILE	name of the Saved Case File containing the pre-contingency power flow working case. This is the case that was present when the Distribution Factor Data File specified in DFXFILE was constructed; it is also the case from which the contingency case was formed. Its solution is in the Saved Case File specified in CNTFILE (input; no default allowed).
Character*260 CNTFILE	name of the Saved Case File containing the contingency case solution for which results are to be placed in the Contingency Solution Output File specified in ACCFILE. This case must be formed by imposing status and/or boundary condition changes on the pre-contingency case specified in BASFILE, and then solving using one or more of the power flow solution activities (input; no default allowed).
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).
Character*32 LABEL	12 character contingency label (input; blank by default).
Integer NUMDESC	number of lines of text used to describe the contingency case; must be between 1 and 16 (input; no default allowed).
Character*160 DESCRIPT (NUMDESC)	Are NUMDESC lines of text describing the contingency case (input; blank by default).

Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid OPTION value
IERR = 2	invalid NUMDESC value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	no base case Saved Case File specified
IERR = 6	no contingency case Saved Case File specified
IERR = 7	Contingency Solution Output File not found
IERR = 8	DFAX File and Contingency Solution Output File are not compatible
IERR = 9	no Distribution Factor Data File specified
IERR = 10	no Contingency Solution Output File specified
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening pre-contingency Saved Case File
IERR = 54	error opening contingency case Saved Case File
IERR = 55	error reading Contingency Solution Output File
IERR = 56	prerequisite requirements for API are not met

1.1.32. APPLY_VAR_LIMITS

Use this API to specify or return the option for the default VAR limits setting; either apply automatically, apply immediately, ignore, or apply on a specific iteration

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_APPLY_VAR_LIMITS IVAL
```

Python command syntax:

```
ierr = apply_var_limits(ival)
ierr, ival = apply_var_limits()
```

Fortran command syntax:

```
CALL APPLY_VAR_LIMITS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = -1	ignore
	IVAL = 0	apply immediately
	IVAL = >0	apply on the specified iteration or when the largest reactive power mismatch is less than a pre-programmed tolerance
Integer IOCODE	IVAL = 99	apply automatically
	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.33. AREA

This API routine is obsolete. It has been replaced by the API routine [area_2](#).

Use this API to tabulate area totals by area, as well as the desired area net interchange (activity AREA).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_AREA  SID  ALL
```

Python command syntax:

```
ierr = area(sid, all)
```

Fortran command syntax:

```
CALL AREANW(SID, ALL, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all areas.
Integer IERR	ALL = 0	process only areas in area subsystem SID.
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 4	prerequisite requirements for API are not met

1.1.34. AREA_2

Use this API to tabulate area totals by area, as well as the desired area net interchange (activity AREA).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_AREA_2  SID  ALL  OPT
```

Python command syntax:

```
ierr = area_2(sid, all, opt)
```

Fortran command syntax:

```
CALL AREA_2(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all areas.
Integer OPT	ALL = 0	process only areas in area subsystem SID.
	load and induction machine reporting option (input; 2 by default).	
	OPT = 1	tabulate loads, induction generators and induction motors connected to area buses
	OPT = 2	tabulate loads, induction generators and induction motors assigned to the area
Integer IERR	OPT = 3	tabulate three load and induction machine subtotals for each area: -area load and induction machines connected to area buses -area load and induction machines connected to non-area buses -non-area load and induction machines connected to area buses
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	Invalid OPT value
	IERR = 4	prerequisite requirements for API are not met

1.1.35. AREA_ZONE

Use this API to tabulate area totals by area, along with subtotals by zone. The desired net interchange of each area reported is also tabulated.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_AREA_ZONE  SID  ALL
```

Python command syntax:

```
ierr = area_zone(sid, all)
```

Fortran command syntax:

```
CALL AREA_ZONE(SID, ALL, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all areas.
	ALL = 0	process only areas in area subsystem SID.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.36. ARNM

This API routine is obsolete. It has been replaced by the API routine [arnm_2](#).

Use this API to reassign the buses and loads in a specified subsystem of the working case from their original area to a designated area (activity ARNM).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ARNM  SID  ALL  STATUS(1)  STATUS(2)  IANEW
```

Python command syntax:

```
ierr = arnm(sid, all, status, ianew)
```

Fortran command syntax:

```
CALL ARNMW(SID, ALL, STATUS, IANEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS (2)	array of 2 elements specifying (input).	
	STATUS(1)	Area assignments of buses to IANEW; (0 by default)
	STATUS(1) = 1	Change area assignments of buses to IANEW
	STATUS(1) = 0	Leave area assignments of buses unchanged
	STATUS(2)	Area assignments of loads to IANEW; (0 by default)
	STATUS(2) = 1	Change area assignments of loads to IANEW
Integer IANEW	new area to be assigned to specified buses and/or loads. IANEW must be between 1 and 9999 (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid new area number
	IERR = 5	area table is full; cannot add area to the working case

IERR = 6

prerequisite requirements for API are not met

1.1.37. ARNM_2

This API routine is the second release of the area renumbering function. Use this API routine to reassign the buses, loads and/or induction machines in a specified subsystem of the working case from their original area to a designated area (activity ARNM).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ARNM_2 SID ALL STATUS(1) STATUS(2) STATUS(3) IANEW
```

Python command syntax:

```
ierr = arnm_2(sid, all, status, ianew)
```

Fortran command syntax:

```
CALL ARNM_2(SID, ALL, STATUS, IANEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS (3)	array of 3 elements specifying (input).	
	STATUS(1)	Area assignments of buses to IANEW; (0 by default)
	STATUS(1) = 1	Change area assignments of buses to IANEW
	STATUS(1) = 0	Leave area assignments of buses unchanged
	STATUS(2)	Area assignments of loads to IANEW; (0 by default)
	STATUS(2) = 1	Change area assignments of loads to IANEW
	STATUS(2) = 0	Leave area assignments of loads unchanged
	STATUS(3)	Area assignments of induction machines to IANEW; (0 by default)
	STATUS(3) = 1	Change area assignments of induction machines to IANEW
	STATUS(3) = 0	Leave area assignments of induction machines unchanged
Integer IANEW	new area to be assigned to specified buses, load, and/or induction machines. IANEW must be between 1 and 9999 (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined

IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	invalid new area number
IERR = 5	area table is full; cannot add area to the working case
IERR = 6	prerequisite requirements for API are not met

1.1.38. BASE_FREQUENCY

Use this API to specify or return the value of the base frequency option setting.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_BASE_FREQUENCY RVAL
```

Python command syntax:

```
ierr = base_frequency(rval)
ierr, rval = base_frequency()
```

Fortran command syntax:

```
CALL BASE_FREQUENCY_API(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	base frequency (usually 50 or 60) (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 60.0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to the value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

1.1.39. BGEN

Use this API to convert the mismatch at boundary buses to equivalent load and/or generation (activity BGEN). It is intended to be used following the removal of a subsystem from a solved working case, with the flows to the deleted subsystem replaced by load and/or generation at those retained buses that were directly connected to the removed subsystem.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BGEN  SID  ALL  STATUS
```

Python command syntax:

```
ierr = bgen(sid, all, status)
```

Fortran command syntax:

```
CALL BGENNW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS	type of boundary condition modification to be used (input; 0 by default).	
	STATUS = 0	generator for inflow; load for outflow.
	STATUS = 1	all equivalent generators.
	STATUS = 2	all equivalent loads.
	error code (output).	
Integer IERR	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	prerequisite requirements for API are not met

1.1.40. BRCH

This API routine is obsolete. It has been replaced by the API routine [brch_2](#).

Use this API to tabulate those branches where impedances or other characteristics are such that they may be detrimental to the rate of convergence of one or more of the power flow solution activities.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BRCH  SID  ALL  DTEST(1)..DTEST(10)  TOLVAL(1)..TOLVAL(7)
```

Python command syntax:

```
ierr = brch(sid, all, dotest, tolval)
```

Fortran command syntax:

```
CALL BRCHNW(SID, ALL, DTEST, TOLVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer DTEST (10)	array of 10 elements specifying options. Each element determines whether a specific branch check should be applied. For DTEST(I) = 1, the corresponding branch check is applied; for DTEST(I) = 0, the check is bypassed(input). DTEST(1) check for small reactances DTEST(2) check for large reactances DTEST(3) check for large resistance to reactance ratios (R/X) DTEST(4) check for negative reactances DTEST(5) check for large ratio of largest to smallest reactance at each bus DTEST(6) check for high or negative charging DTEST(7) check data of parallel transformers DTEST(8) check for high tap ratios DTEST(9) check for low tap ratios DTEST(10) check for zero sequence non-transformer branch impedances of 0.0
Real TOLVAL (7)	array of 7 elements specifying options. Each element contains a limit or threshold value used in one of the branch checks(input).

	TOLVAL(1)	>0.0 reactance lower limit (0.0005 by default)
	TOLVAL(2)	>0.0 reactance upper limit (1.0 by default)
	TOLVAL(3)	>0.0 R/X threshold (0.66667 by default)
	TOLVAL(4)	>=10.0 Xmax/Xmin threshold (500.0 by default)
	TOLVAL(5)	>=0.0 charging upper limit (5.0 by default)
	TOLVAL(6)	>0.8 high tap ratio limit (1.1 by default)
	TOLVAL(7)	>0.0 and < 1.2 low tap ratio limit (0.9 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid DOTEST value
	IERR = 4	invalid TOLVAL value
	IERR = 5	prerequisite requirements for API are not met

1.1.41. BRCH_2

Use this API to tabulate those branches where impedances or other characteristics are such that they may be detrimental to the rate of convergence of one or more of the power flow solution activities.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_BRCH_2  SID ALL DOTEST(1)..DOTEST(11) TOLVAL(1)..TOLVAL(7)
```

Python command syntax:

```
ierr = brch_2(sid, all, dotest, tolval)
```

Fortran command syntax:

```
CALL BRCH_2(SID, ALL, DOTEST, TOLVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer DOTEST (11)	array of elements specifying options. Each element determines whether a specific branch check should be applied. For DOTEST(I) = 1, the corresponding branch check is applied; for DOTEST(I) = 0, the check is bypassed(input). DOTEST(1) check for small reactances. DOTEST(2) check for large reactances. DOTEST(3) check for large resistance to reactance ratios (R/X). DOTEST(4) check for negative reactances. DOTEST(5) check for large ratio of largest to smallest reactance at each bus. DOTEST(6) check for high or negative charging. DOTEST(7) check data of parallel transformers. DOTEST(8) check for high tap ratios. DOTEST(9) check for low tap ratios. DOTEST(10) check for inconsistent transformer loss data values (copper loss and no-load loss). DOTEST(11) check for zero sequence non-transformer branch impedances of 0.0.
Real TOLVAL (7)	array of elements specifying options. Each element contains a limit or threshold value used in one of the branch checks (input). TOLVAL(1) >0.0. reactance lower limit (0.0005 by default).

	TOLVAL(2)	>0.0. reactance upper limit (1.0 by default).
	TOLVAL(3)	>0.0. R/X threshold (0.66667 by default).
	TOLVAL(4)	>=10.0. Xmax/Xmin threshold (500.0 by default).
	TOLVAL(5)	>=0.0. charging upper limit (5.0 by default).
	TOLVAL(6)	>0.8. high tap ratio limit (1.1 by default).
	TOLVAL(7)	> 0.0 and < 1.2. low tap ratio limit (0.9 by default).
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid DOTEST value
	IERR = 4	invalid TOLVAL value
	IERR = 5	prerequisite requirements for API are not met

1.1.42. BSNM

Use this API to change the bus numbers of specified network buses in the working case and retain a tabulation, in file form, of bus number changes made (activity BSNM). This API must be referenced with one OPT 0 reference followed by one of the following:

- one OPT 5, 11 or 12 reference.
- one or more OPT 1 references, followed by one OPT 7 reference.
- one or more OPT 2 references, followed by one OPT 7 reference.
- one or more OPT 3 references, followed by one OPT 7 reference.
- one or more OPT 4 references, followed by one OPT 7 reference.
- one OPT 15 reference for each area in the case containing at least one bus, in ascending area number order, followed by one OPT 25 reference.
- zero or more OPT 15 references in the same order as above, followed by one OPT 35 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BSNM  SID  ALL  OPT  STATUS  BUSRNG(1)  BUSRNG(2)  OLDNAM  TFILE  OUT
          OFILE
```

Python command syntax:

```
ierr = bsnm(sid, all, opt, status, busrng, oldnam, tfile, out, ofile)
```

Fortran command syntax:

```
CALL BSNMNW(SID, ALL, OPT, STATUS, BUSRNG, OLDNAM, TFILE, OUT, OFILE,
            IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer OPT	method used to renumber the buses (input; no default allowed). OPT = 0 initialize for renumbering. OPT = 1 renumber buses based on name/new number pairs. OPT = 11 renumber using name translation file. OPT = 2 renumber buses based on old number/new number pairs. OPT = 12 renumber buses using number translation file. OPT = 3 pack all buses in specified low/high pairs. OPT = 4 renumber buses based on the subsystem specified in the OPT 0 reference. OPT = 5 renumber all buses.

	OPT = 15	renumber all buses blocking by area.
	OPT = 25	apply blocking by area changes.
	OPT = 35	cancel blocking by area changes.
	OPT = 7	cleanup from renumbering.
Integer STATUS	If OPT=15, is the number of the area where the bus number range is specified in BUSRNG. STATUS must be between 1 and AREAS (the highest area number allowed at the present size level of PSSE). If OPT=4: STATUS = 0 indicates a new bus number range is provided. STATUS = 1 indicates a bus number offset is provided. Otherwise STATUS is ignored (input).	
Integer BUSRNG (2)	If OPT = 1: BUSRNG(1) is the new bus number. If OPT = 2: BUSRNG(1) is the old bus number. BUSRNG(2) is the new bus number. If OPT = 3: BUSRNG(1) is the bus number at which to start packing sequentially. BUSRNG(2) is the bus number at which to end packing sequentially. If OPT = 4 and STATUS = 0: BUSRNG(1) is the starting bus number for the range into which the subsystem is to be renumbered. BUSRNG(2) is the ending bus number for the range into which the subsystem is to be renumbered. If OPT = 4 and STATUS = 1: BUSRNG(1) is amount by which all buses in the specified subsystem are offset. If OPT = 5: BUSRNG(1) bus number at which to start renumbering all buses in the working case. Buses are re-sequenced in increments of 1. If OPT = 15: BUSRNG(1) is the starting bus number for the range into which the area is to be renumbered. BUSRNG(2) is the ending bus number for the range into which the area is to be renumbered (input).	
Character*18 OLDNAM	extended bus name of the bus to be renumbered when OPT is 1 (when OPT is 1) (input; no default allowed).	
Character*260 TFILE	bus name/number translation file. This file is only used if OPT = 11 or 12. Data in the translation file must be in the form specified in the PSSE Program Operation Manual. (when OPT is 11 or 12) (input; no default allowed).	
Integer OUT	option selection when OPT is 0 (input; 1 by default).	
	OUT = 0	direct output to a data file specified by OFILE.
	OUT = 1	direct output to the current report device.
	OUT = 2	no output.
Character*260 OFILE	Bus Renumbering Translation file for the records of activity BSNM (when OPT is 0 and OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OUT value
	IERR = 4	invalid OPT 0 call; bus renumbering already initialized
	IERR = 5	prior OPT is not 0 (OPT=1,2,11,12,5,25)
	IERR = 6	bus not found (OPT=1,2,11,12)

IERR = 7	invalid new bus number (OPT=1,2,11,12,4)
IERR = 8	bus number is already assigned to another bus (OPT=1,2,11,12,4)
IERR = 9	prior OPT not 0 or 3 (OPT=3,4,15,35)
IERR = 10	invalid starting bus number (OPT=3,4,5,15)
IERR = 11	invalid ending bus number (OPT=3,4,15)
IERR = 12	starting bus number is greater than ending bus number (OPT=3,4,15)
IERR = 13	invalid STATUS value (OPT=4)
IERR = 14	invalid offset value (OPT=4)
IERR = 15	not enough unused bus numbers in specified bus number range (OPT=4)
IERR = 16	not enough numbers between BUSRNG(1) and 999997 (OPT=5)
IERR = 17	area specified but no more areas left to process (OPT=15)
IERR = 18	area out of sequence (OPT=15)
IERR = 19	bus number range of an area overlaps that of another area (OPT=15)
IERR = 20	bus number range of an area is not large enough (OPT=15)
IERR = 21	not enough OPT 15 calls (OPT=25)
IERR = 22	invalid OPT 7 call; bus renumbering is not initialized (OPT=7)
IERR = 23	invalid OPT value
IERR = 24	error opening TFILE (OPT=11,12)
IERR = 25	error opening OFILE
IERR = 26	prerequisite requirements for API are not met

1.1.43. BUSN

Use this API to tabulate unused bus numbers within a specified bus number range (activity BUSN).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BUSN  BUSLO  BUSHI
```

Python command syntax:

```
ierr = busn(buslo, bushi)
```

Fortran command syntax:

```
CALL BUSNAPI(BUSLO, BUSHI, IERR)
```

Where:

Integer BUSLO	low limit of bus number range (input; 1 by default).	
Integer BUSHI	high limit of bus number range (input; 999,997).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid starting bus number
	IERR = 2	starting bus number is greater than ending bus number
	IERR = 3	prerequisite requirements for API are not met

1.1.44. BUS_INPUT

Use this API to specify or return the bus input option setting, for either numbers or names.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_BUS_INPUT IVAL
```

Python command syntax:

```
ierr = bus_input(ival)
ierr, ival = bus_input()
```

Fortran command syntax:

```
CALL BUS_INPUT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = 0	bus numbers.
	IVAL = 1	extended bus names.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.45. BUS_OUTPUT

Use this API to specify or return the bus output option setting, for either numbers or names.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_BUS_OUTPUT IVAL
```

Python command syntax:

```
ierr = bus_output(ival)
ierr, ival = bus_output()
```

Fortran command syntax:

```
CALL BUS_OUTPUT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 bus numbers.
	IVAL = 1 extended bus names.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.46. BUS_SIZE_LEVEL

Use this API to specify or return the value of the PSSE size level option setting to a multiple of 1,000 between 1,000 and 200,000.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_BUS_SIZE_LEVEL IVAL
```

Python command syntax:

```
ierr = bus_size_level(ival)
ierr, ival = bus_size_level()
```

Fortran command syntax:

```
CALL BUS_SIZE_LEVEL_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1000 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to the value specified in IVAL. IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid IVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met IERR = 4 unable to change bus size. PSSE Xplore is limited to 50 buses.

1.1.47. CASE

Use this API to open a PSSE Saved Case file and transfers its data into the PSSE working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CASE  SFILE
```

Python command syntax:

```
ierr = case(sfile)
```

Fortran command syntax:

```
CALL CASENW(SFILE, IERR)
```

Where:

Character*260 SFILE	name of the PSSE saved case file If SFILE is "*", CASENW attempts to reopen the most recently accessed Saved Case File. If no Saved Case File was accessed in the current execution of PSSE, CASENW returns an error code (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SFILE is blank
	IERR = 2	error reading from SFILE
	IERR = 3	error opening SFILE
	IERR = 4	prerequisite requirements for API are not met

1.1.48. CA_ITERATIONS

Use this API to specify or return the contingency iterations limit setting.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_CA_ITERATIONS IVAL
```

Python command syntax:

```
ierr = ca_iterations(ival)
ierr, ival = ca_iterations()
```

Fortran command syntax:

```
CALL CA_ITERATIONS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 20 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to the value specified in IVAL. IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid IVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

1.1.49. CHECKVOLTAGELIMITS

Use this API to tabulate those buses where voltage magnitude is beyond their normal or emergency voltage limits. This check may be performed for all buses in the working case or for all buses in a specified subsystem.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_CHECKVOLTAGELIMITS  SID ALL OPT THRSH
```

Python command syntax:

```
ierr = checkvoltageLimits(sid, all, opt, thrsh)
```

Fortran command syntax:

```
CALL CHECKVOLTAGELIMITS(SID, ALL, OPT, THRSH, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer OPT	set of voltage limits to be used (input; 1 by default). OPT = 1 normal limits OPT = 2 emergency limits
Real THRSH	voltage limit threshold ($-0.05 < \text{THRSH} < 0.05$) (input 0.0). THRSH = 0.0 log voltages above upper limit or below lower limit THRSH > 0.0 log voltages beyond or within THRSH of a limit THRSH < 0.0 log voltage outside a limit by more than (-THRSH)
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid OPT value IERR = 4 invalid THRSH value IERR = 5 prerequisite requirements for API are not met

1.1.50. CHECK_POWERFLOW_DATA

Use this API routine to perform data checks on the selected categories of powerflow data for all buses in the working case or for all buses in a specified subsystem.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_CHECK_POWERFLOW_DATA SID ALL OPT
```

Python command syntax:

```
ierr = check_powerflow_data(sid, all, opt)
```

Fortran command syntax:

```
CALL CHECK_POWERFLOW_DATA(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer OPT	powerflow data category to be checked (input; 0 by default). OPT = 0 all data categories OPT = 1 bus data OPT = 2 load data OPT = 3 plant data OPT = 4 generator unit data OPT = 5 induction machine data OPT = 6 fixed bus shunt data OPT = 7 switched shunt data OPT = 8 non-transformer branch data OPT = 9 two-winding transformer data OPT = 10 three-winding transformer data OPT = 11 transformer impedance table correction data OPT = 12 multi-section line data OPT = 13 two-terminal dc line data OPT = 14 multi-terminal dc line data OPT = 15 VSC dc line data OPT = 16 FACTS device data OPT = 17 GNE device data OPT = 18 area interchange data OPT = 19 owner data

Integer IERR	OPT = 20	zone data
	OPT = 21	capability curve data
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 4	capability curve data is not in the working case
	IERR = 5	prerequisite requirements for API are not met

1.1.51. CHKCNTDUPLICON

Check duplicate labels in Contingency (CON) file.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_CHKCNTDUPLICON CONFILE
```

Python command syntax:

```
ierr, dnum = chkcntduplicon(confile)
```

Fortran command syntax:

```
CALL CHKCNTDUPLICON(CONFILE, DNUM, IERR)
```

Where:

Character*260 CONFILE	contingency file name (input).
integer DNUM	total number of duplicated contingency labels in the contingency file (output; 0 by default).
Integer IERR	error code (output).
	IERR = 1 no CON file specified
	IERR = 2 error opening CON file
	IERR = 3 prerequisite requirements for function not met

1.1.52. CHKCNTDUPLIDFX

Check duplicate labels in DFAX file.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_CHKCNTDUPLIDFX DFXFILE
```

Python command syntax:

```
ierr, dnum = chkcntduplidx(dfxfilename)
```

Fortran command syntax:

```
CALL CHKCNTDUPLIDFX(DFXFILE, DNUM, IERR)
```

Where:

Character*260 DFXFILE	contingency file name (input).
integer DNUM	total number of duplicated contingency labels in the dfax file (output; 0 by default).
Integer IERR	error code (output).
	IERR = 1 no DFAX file specified
	IERR = 2 error opening DFAX file
	IERR = 3 prerequisite requirements for function not met

1.1.53. CLOSE_POWERFLOW

Removes the current powerflow working case from PSSE's working memory. Thus, the PSSE powerflow arrays are in the same state as they are immediately following PSSE startup. The default PSSE program option settings are unchanged.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CLOSE_POWERFLOW
```

Python command syntax:

```
ierr = close_powerflow()
```

Fortran command syntax:

```
CALL CLOSE_POWERFLOW(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.54. CLOSE_REPORT

Sets the report output device to the standard output and sets the command line to request device selection for individual reporting activities (Activity CLOS).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_CLOSE_REPORT
```

Python command syntax:

```
ierr = close_report()
```

Fortran command syntax:

```
CALL CLOSEREPORTDEVICE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.55. CMPR

Use this API to tabulate certain case totals, as contained in the working case, with those of a designated Saved Case (activity CMPR). Either system totals, area totals, owner totals, or zone totals may be compared. It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by any number of references with APIOPT=2, followed by one reference with APIOPT=3.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference, followed by one APIOPT 3 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CMPR  SID  APIOPT  STATUS(1)..STATUS(4)  THRSH  CFILE
```

Python command syntax:

```
ierr = cmpr(sid, apiopt, status, thrsh, cfile)
```

Fortran command syntax:

```
CALL CMPRNW(SID, APIOPT, STATUS, THRSH, CFILE, IERR)
```

Where:

Integer SID	a valid area, zone or owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 0 or 1; 0).	
Integer APIOPT	mode of operation in the API (input; 0 by default).	
	APIOPT = 0	initialize for case totals comparison, run the comparison specified by STATUS(3), and run post-processing clean up.
	APIOPT = 1	initialize system for system, area, owner, zone totals.
	APIOPT = 2	calculate and report system, area, owner, zone totals.
	APIOPT = 3	postprocessing housekeeping.
Integer STATUS (4)	array of 4 elements specifying The value of each element is as follows(input).	
	STATUS(1)	tabulation method (used only when APIOPT is 0 or 1; 0 by default)
	STATUS(1) = 0	tabulate system totals
	STATUS(1) = 1	tabulate area totals for area subsystem SID
	STATUS(1) = 2	tabulate owner totals for owner subsystem SID
	STATUS(1) = 3	tabulate zone totals for zone subsystem SID
	STATUS(2)	units for the difference threshold (used only when APIOPT is 0 or 2; 0 by default)
	STATUS(2) = 0	threshold in engineering units

	STATUS(2) = 1	threshold in percent
	STATUS(3)	quantity to be compared (used only when APIOPT is 0 or 2; 1 by default)
	STATUS(3) = 1	compare generation
	STATUS(3) = 2	compare load
	STATUS(3) = 3	compare losses
	STATUS(3) = 4	compare mismatch
	STATUS(3) = 5	compare interchange; not valid for STATUS(1) = 2
	STATUS(4)	file to restore into the working case upon completion (used only when APIOPT is 0 or 3; 0 by default)
	STATUS(4) = 0	restore the working case
	STATUS(4) = 1	restore the comparison file to the working case
Real THRSH		difference threshold, in either engineering units or a percent, based on the value of STATUS(2) (input; used only when APIOPT is 0 or 2; 0.0).
Character*260 CFILE		Saved Case file to be compared against the working case (when APIOPT is 0 or 1) (input; no default allowed).
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid APIOPT value
	IERR = 3	invalid STATUS value
	IERR = 4	owner (STATUS(1)=2) interchange (STATUS(3)=5) combination is invalid
	IERR = 5	invalid THRSH value
	IERR = 6	CFILE is blank
	IERR = 7	error writing the working case to a temporary file
	IERR = 8	unexpected APIOPT value
	IERR = 9	error reading the comparison case
	IERR = 10	error opening the temporary file
	IERR = 11	prerequisite requirements for API are not met

1.1.56. CNTB

Use this API to tabulate the voltage setpoints and desired voltage bands of voltage-controlling equipment in the working case (activity CNTB). Optionally, new scheduled voltages may be specified.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CNTB  SID  ALL  APIOPT  STATUS(1)..STATUS(3)  V(1)  V(2)
```

Python command syntax:

```
ierr, next, bus, ckt, v = cntb(sid, all, apiopt, status, v)
```

Fortran command syntax:

```
CALL CNTBNW(SID, ALL, APIOPT, STATUS, NEXT, BUS, CKT, V, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (used only when APIOPT is 2) (input; 0 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer APIOPT	mode of operation in the API (input).	
	APIOPT = 1	initialize.
	APIOPT = 2	specify voltage setpoint for controlled bus.
	APIOPT = 3	specify voltage band for load drop compensating transformer.
Integer STATUS (3)	array of 3 elements specifying used to control reporting and processing options(input).	
	STATUS(1)	varies by APIOPT
	STATUS(1) = 0	For APIOPT=1, list subsystem controlled buses with conflicts. For APIOPT=2 or 3, no change
	STATUS(1) = 1	For APIOPT=1, list all subsystem controlled buses. For APIOPT=2, change voltage setpoints to new setpoint in V(1). For APIOPT=3, change voltage band to new voltage band in V(1) and V(2)
	STATUS(2)	varies by APIOPT
	STATUS(2) = 0	For APIOPT=1, report at OPENed output device. For APIOPT=2 or 3, not used
	STATUS(2) = 1	For APIOPT=1, list in progress area and allow voltage schedule change. For APIOPT=2 or 3, not used

	STATUS(3)	varies by APIOPT
	STATUS(3) = 0	For APIOPT=1, process all controlling elements and controlled buses. For APIOPT=2 or 3, not used
	STATUS(3) = 1	For APIOPT=1, process active controlling elements and controlled buses. For APIOPT=2 or 3, not used
Integer NEXT	returned as the next APIOPT value expected by the API (output).	
	NEXT = 1	done with this execution of CNTBNW.
	NEXT = 2	change voltage setpoint/schedule.
	NEXT = 3	change VMIN, VMAX of load drop compensating transformer.
Integer BUS (3)	array of 3 elements specifying a returned three bus values(output).	
	BUS(1)	Returned as controlled bus for which voltage schedule may be changed when Next=2. Returned as controlled bus for which voltage schedule may be changed when Next=3
	BUS(2)	Returned as the from bus of the transformer when Next=3
	BUS(3)	Returned as the to bus of the transformer when Next=3
Character*2 CKT	returned as the circuit ID of the transformer returned in BUS(2) and BUS(3) when NEXT returned as 3 (output).	
Real V (2)	array of 2 elements specifying Voltage values(input).	
	V(1)	New setpoint when APIOPT=2, new VMIN when APIOPT=3. Returned as present setpoint when NEXT=2, returned as present VMIN when NEXT=3
	V(2)	New VMAX when APIOPT=3. Returned as present VMAX when NEXT=3
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid new voltage setpoint value (V(1) <= 0.5 or V(1) >= 1.5)
	IERR = 5	VMIN is not less than VMAX
	IERR = 6	invalid APIOPT value
	IERR = 7	unexpected APIOPT value
	IERR = 8	prerequisite requirements for API are not met

1.1.57. CONG

Use this API to convert generators from their power flow representation in preparation for switching studies and dynamic simulations (activity CONG).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CONG  OPT
```

Python command syntax:

```
ierr = cong(opt)
```

Fortran command syntax:

```
CALL CONGAPI(OPT, IERR)
```

Where:

Integer OPT	machine impedance option (input; 0 by default).	
	OPT = 0	use ZSORCE and IMZSRC.
	OPT = 1	use fault analysis subtransient impedance and IMZPOS.
	OPT = 2	use fault analysis transient impedance and IMZPOS.
	OPT = 3	use fault analysis synchronous impedance and IMZPOS.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	generators are already converted
	IERR = 3	generator conversion failed due to a machine impedance of zero
	IERR = 4	generator conversion failed due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 5	prerequisite requirements for API are not met

1.1.58. CONL

Use this API to convert the constant MVA load for a specified grouping of network loads to a specified mixture of the constant MVA, constant current, and constant admittance load characteristics (activity CONL).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CONL  SID  ALL  APIOPT  STATUS(1)  STATUS(2)  LOADIN(1) . .  LOADIN(2)
          LOADIN(3)  LOADIN(4)
```

Python command syntax:

```
ierr, rloads = conl(sid, all, apiopt, status, loadin)
```

Fortran command syntax:

```
CALL CONLW(SID, ALL, APIOPT, STATUS, LOADIN, RLOADS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 2; 0).	
Integer ALL	all buses or specified subsystem flag (input; used only when APIOPT is 2; 0).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer APIOPT	mode of operation in the API (input; no default allowed).	
	APIOPT = 1	initialize for load conversion.
	APIOPT = 2	convert loads.
	APIOPT = 3	postprocessing housekeeping.
Integer STATUS (2)	array of 2 elements specifying The value of each element is as follows(input).	
	STATUS(1)	method of conversion (used only when APIOPT is 1; 0 by default)
	STATUS(1) = 0	convert existing constant MVA load
	STATUS(1) = 1	reconstruct loads using present voltage, then convert
	STATUS(1) = 2	reconstruct loads using unity voltage, then convert
	STATUS(2)	a special OPF bus type code flag (used only when APIOPT is 2; 0 by default)
	STATUS(2) = 0	all buses in subsystem
	STATUS(2) = 1	only Type 1 buses in subsystem
	STATUS(2) = 2	only Type 2 and 3 buses in subsystem
Real LOADIN (4)	array of 4 elements specifying (input).	

	LOADIN(1)	percent of active power load to be converted to the constant current characteristic
	LOADIN(2)	percent of active power load to be converted to the constant admittance characteristic
	LOADIN(3)	percent of reactive power load to be converted to the constant current characteristic
	LOADIN(4)	percent of reactive power load to be converted to the constant admittance characteristic
Integer RLODS	returned as the number of unconverted loads remaining in the working case. If the value is nonzero after a call with APIOPT = 2, and the remaining loads are to be converted, the API is called again with ALL = 1 and APIOPT = 2 (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid APIOPT value
	IERR = 4	invalid STATUS value
	IERR = 5	unexpected APIOPT value
	IERR = 6	prerequisite requirements for API are not met

1.1.59. CONNECTIVITY_CHECK

Use this API to specify or return the option to enable or disable the solution connectivity checking option setting.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_CONNECTIVITY_CHECK IVAL
```

Python command syntax:

```
ierr = connectivity_check(ival)
ierr, ival = connectivity_check()
```

Fortran command syntax:

```
CALL CONNECTIVITY_CHECK_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).	
	IVAL = 0	no solution connectivity check before power flow solutions.
	IVAL = 1	run solution connectivity check before each power flow solution.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.60. CONTROL_AREA_INTERCHANGE

Use this API to to specify or return the area interchange control option setting to disabled, or enabled with tie lines only, or enabled with tie lines and loads.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_CONTROL_AREA_INTERCHANGE IVAL
```

Python command syntax:

```
ierr = control_area_interchange(ival)
ierr, ival = control_area_interchange()
```

Fortran command syntax:

```
CALL CONTROL_AREA_INTERCHANGE_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 disabled.
	IVAL = 1 enabled with interchange determined from tie lines only.
	IVAL = 2 enabled with interchange determined from tie lines and loads.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.61. CSV_TO_RAWX

Use this API to import a rawx (extended raw data) data table from a CSV (comma-separated values) file.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_CSV_TO_RAWX
```

Python command syntax:

```
ierr = csv_to_rawx(tblname, sfile)
```

Fortran command syntax:

```
CALL CSV_TO_RAWX(TBLNAME, SFILE, IERR)
```

Where:

Character*100 TBLNAME	name of the data table to import into (not case sensitive) (input; no default allowed).	
Character*260 SFILE	file path of the CSV input file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid tblname
	IERR = 2	error opening SFILE
	IERR = 3	error generating RAWX data
	IERR = 4	error reading RAWX data
	IERR = 10	prerequisite requirements for API are not met

1.1.62. DCCC

This API routine is obsolete. It has been replaced by the API routine [dccc_2](#).

Use this API to run contingency case solutions using a linear network (dc) model (activity DCCC).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DCCC  OPTIONS(1)..OPTIONS(6)  VALUES(1)..VALUES(3)  DFXFILE
```

Python command syntax:

```
ierr = dccc(options, values, dfxfile)
```

Fortran command syntax:

```
CALL DCCCAPI(OPTIONS, VALUES, DFXFILE, IERR)
```

Where:

Integer OPTIONS (6)	array of 6 elements specifying calculation and reporting options. The value of each element is as follows(input).
OPTIONS(1)	contingency case rating set (rating set program option setting by default)
OPTIONS(1) = 1	RATEA
OPTIONS(1) = 2	RATEB
OPTIONS(1) = 3	RATEC
OPTIONS(2)	base case line flow code (0 by default)
OPTIONS(2) = 0	dc base case
OPTIONS(2) = 1	ac base case
OPTIONS(3)	format code (0 by default)
OPTIONS(3) = 0	overload output
OPTIONS(3) = 1	full output
OPTIONS(4)	exclude cases with no overloads from the overload report (0 by default)
OPTIONS(4) = 0	no
OPTIONS(4) = 1	yes
OPTIONS(5)	convert MVA ratings to estimated MW ratings (0 by default)
OPTIONS(5) = 0	no
OPTIONS(5) = 1	yes
OPTIONS(6)	code to discontinue activity if MW mismatch exceeds TOLS(1) (0 by default)
OPTIONS(6) = 0	discontinue
OPTIONS(6) = 1	continue
Real VALUES (3)	array of 3 elements specifying tolerances and thresholds. The value of each element is as follows(input).

	VALUES(1)	required MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating for reporting an element as overloaded (100.0 by default)
	VALUES(3)	minimum contingency case flow change for including an element in the overload report (0.0 by default)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	no Distribution Factor Data File specified
	IERR = 4	generators are converted
	IERR = 5	buses in island(s) without a swing bus; use activity TREE
	IERR = 6	largest mismatch exceeds mismatch tolerance
	IERR = 7	error opening file DFXFILE
	IERR = 8	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 9	file DFXFILE does not contain distribution factors; run DFAX with distribution factor option enabled
	IERR = 10	no monitored branches or interfaces defined
	IERR = 11	prerequisite requirements for API are not met

1.1.63. DCCC_2

Use this API to run contingency case solutions using a linear network (dc) model (activity DCCC).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_DCCC_2  OPTIONS(1)..OPTIONS(8)  VALUES(1)..VALUES(3)  DFXFILE
```

Python command syntax:

```
ierr = dccc_2(options, values, dfxfile)
```

Fortran command syntax:

```
CALL DCCC_2 (OPTIONS, VALUES, DFXFILE, IERR)
```

Where:

Integer OPTIONS (8)	array of elements specifying calculation and reporting options. The value of each element is as follows.(input).
OPTIONS(1)	is the loss estimate option (1 by default)
OPTIONS(1) = 0	exclude loss estimate
OPTIONS(1) = 1	use the present voltage vector to estimate losses and apply them as "hidden loads".
OPTIONS(2)	is the regulating phase shifter code. (0 by default)
OPTIONS(2) = 0	fixed phase shift angles in the base case and the contingency cases.
OPTIONS(2) = 1	fixed MW in the base case, fixed phase shift angles in the contingency cases.
OPTIONS(2) = 2	fixed MW in the base case and the contingency cases.
OPTIONS(3)	contingency case rating set; 1 through 12 (rating set program option setting by default)
OPTIONS(4)	base case line flow code (0 by default)
OPTIONS(4) = 0	dc base case.
OPTIONS(4) = 1	ac base case.
OPTIONS(5)	output format code (0 by default)
OPTIONS(5) = 0	overload output.
OPTIONS(5) = 1	full output.
OPTIONS(6)	exclude cases with no overloads from the overload report (0 by default)
OPTIONS(6) = 0	no.
OPTIONS(6) = 1	yes.
OPTIONS(7)	convert MVA ratings to estimated MW ratings. (0 by default)
OPTIONS(7) = 0	no.

	OPTIONS(7) = 1	yes.
	OPTIONS(8)	code to discontinue activity if MW mismatch exceeds VALUES(1). (0 by default)
	OPTIONS(8) = 0	discontinue.
	OPTIONS(8) = 1	continue.
Real VALUES (3)	array of elements specifying tolerances and thresholds. The value of each element is as follows.(input).	
	VALUES(1)	required MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN, by default)
	VALUES(2)	percent of rating for reporting an element as overloaded. (100 by default)
	VALUES(3)	minimum contingency case flow change for including an element in the overload report. (0.0 by default)
Character* 260 DFXFILE	Is the name of Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	no Distribution Factor Data File specified
	IERR = 4	generators are converted
	IERR = 5	buses in island(s) without a swing bus; use activity TREE
	IERR = 6	largest mismatch exceeds mismatch tolerance
	IERR = 7	error opening DFXFILE
	IERR = 8	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 9	file DFXFILE does not contain distribution factors; run DFAX with distribution factor option enabled.
	IERR = 10	no monitored branches or interfaces defined.
	IERR = 11	prerequisite requirements for API are not met.

1.1.64. DCCOR

Use this API to apply corrective actions to the base case using linear programming methods. The corrective actions are to eliminate flow overloads with the objective of minimizing the control adjustments, including load shedding, MW generations dispatch, and phase shifter angle adjustments.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_DCCOR  OPTIONS(1)..OPTIONS(7)  VALUES(1)..VALUES(6)
          LABELS(1)..LABELS(3)  DFXFILE
```

Python command syntax:

```
ierr = dccor(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL DCCORAPI(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (7)	array of 7 elements specifying DC corrective actions solution options(input).	
	OPTIONS(1)	rating set (rating set program option setting by default)
	OPTIONS(1) = 1	rating A
	OPTIONS(1) = 2	rating B
	OPTIONS(1) = 3	rating C
	OPTIONS(2)	generator control flag (1 by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable
	OPTIONS(3)	load control flag (0 by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	phase shifter control flag (1 by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable
	OPTIONS(5)	convert MVA ratings to estimated MW ratings (0 by default)
	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(6)	code to discontinue activity if MW mismatch exceeds tolerance (VALUES(1) (0 by default)
	OPTIONS(6) = 0	disable (i.e. continue, do not discontinue activity)
	OPTIONS(6) = 1	enable (i.e. discontinue)
	OPTIONS(7)	modify network data with corrective actions solutions (1 by default)

	OPTIONS(7) = 0	disable (i.e. do not modify network data)
	OPTIONS(7) = 1	enable (i.e. allow network data to be modified)
Real VALUES (6)	array of 6 elements specifying DC corrective actions parameters(input).	
	VALUES(1)	MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating set (100.0 by default)
	VALUES(3)	branch flow overload tolerance (0.1 by default)
	VALUES(4)	generator control weighting factor (1.0 by default)
	VALUES(5)	load control weighting factor (1.0 by default)
	VALUES(6)	phase shifter control weighting factor (1.0 by default)
Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).	
	LABELS(1)	label of generator control subsystem (blank by default; no default allowed if OPTIONS(2) is 1)
	LABELS(2)	label of load control subsystem (blank by default; no default allowed if OPTIONS(3) is 1)
	LABELS(3)	label of phase shifter control subsystem (blank by default; no default allowed if OPTIONS(4) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	No controls
	IERR = 6	control subsystem not defined
	IERR = 7	Distribution Factor Data File not specified
	IERR = 8	largest mismatch exceeds tolerance
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	prerequisite requirements for function not met

1.1.65. DCCOR_2

Use this API to apply corrective actions to the base case using linear programming methods. The corrective actions are to eliminate flow overloads with the objective of minimizing the control adjustments, including load shedding, MW generations dispatch, and phase shifter angle adjustments.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_DCCOR_2  OPTIONS(1)..OPTIONS(7)  VALUES(1)..VALUES(6)
             LABELS(1)..LABELS(3)  DFXFILE
```

Python command syntax:

```
ierr = dccor_2(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL DCCORAPI_2(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying DC corrective actions solution options(input).
OPTIONS(1)	rating set (rating set program option setting by default)
OPTIONS(1) = 1	rating A
OPTIONS(1) = 2	rating B
OPTIONS(1) = 3	rating C
OPTIONS(2)	generator control flag (1 by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable
OPTIONS(3)	load control flag (0 by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	phase shifter control flag (1 by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	off-line generator control flag (1 by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(6)	convert MVA ratings to estimated MW ratings (0 by default)
OPTIONS(6) = 0	disable
OPTIONS(6) = 1	enable
OPTIONS(7)	code to discontinue activity if MW mismatch exceeds tolerance (VALUES(1) (0 by default)
OPTIONS(7) = 0	disable (i.e. continue, do not discontinue activity)

	OPTIONS(7) = 1	enable (i.e. discontinue)
	OPTIONS(8)	modify network data with corrective actions solutions (1 by default)
	OPTIONS(8) = 0	disable (i.e. do not modify network data)
	OPTIONS(8) = 1	enable (i.e. allow network data to be modified)
Real VALUES (7)	array of 7 elements specifying DC corrective actions parameters(input).	
	VALUES(1)	MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating set (100.0 by default)
	VALUES(3)	branch flow overload tolerance (0.1 by default)
	VALUES(4)	generator control weighting factor (1.0 by default)
	VALUES(5)	load control weighting factor (1.0 by default)
	VALUES(6)	phase shifter control weighting factor (1.0 by default)
	VALUES(7)	off-line generator control weighting factor (1.0 by default)
Character*32 LABELS (4)	array of 4 elements specifying subsystem labels(input).	
	LABELS(1)	label of generator control subsystem (blank by default; no default allowed if OPTIONS(2) is 1)
	LABELS(2)	label of load control subsystem (blank by default; no default allowed if OPTIONS(3) is 1)
	LABELS(3)	label of phase shifter control subsystem (blank by default; no default allowed if OPTIONS(4) is 1)
	LABELS(4)	label of off-line generator control subsystem (blank by default; no default allowed if OPTIONS(5) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	No controls
	IERR = 6	control subsystem not defined
	IERR = 7	Distribution Factor Data File not specified
	IERR = 8	largest mismatch exceeds tolerance

IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Distribution Factor Data File
IERR = 52	prerequisite requirements for function not met

1.1.66. DCLF

This API routine is obsolete. It has been replaced by the API routine [dclf_2](#).

Use this API to apply the dc analogy network solution algorithm to the network modeled in the working case (activity DCLF).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DCLF  SID  ALL  STATUS(1)..STATUS(4)  BRNCH(1)..BRNCH(3)  CKT
```

Python command syntax:

```
ierr = dclf(sid, all, status, brnch, ckt)
```

Fortran command syntax:

```
CALL DCLFAPI(SID, ALL, STATUS, BRNCH, CKT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS (4)	array of 4 elements specifying The value of each element is as follows(input).	
	STATUS(1)	rating used in tabulating the report (default rating set program option setting)
	STATUS(1) = 1	RATEA
	STATUS(1) = 2	RATEB
	STATUS(1) = 3	RATEC
	STATUS(2)	voltage that should be saved (0 by default)
	STATUS(2) = 0	original voltages
	STATUS(2) = 1	base case dc power flow voltages
	STATUS(2) = 2	change case dc power flow voltages
	STATUS(3)	status of the changed branch upon completion (0 by default)
	STATUS(3) = 0	leave unchanged
	STATUS(3) = 1	save changed status
	STATUS(4)	action code if the MW mismatch exceeds 0.5 MW (1 by default)
	STATUS(4) = 0	discontinue
	STATUS(4) = 1	continue

Integer BRNCH (3)	array of 3 elements specifying The use of each element is as follows. The values can all be zero or defaulted if no branch is to be changed for the solution(input).
BRNCH(1)	from bus of the branch for which status is to be changed for the solution (0 by default)
BRNCH(2)	to bus of the branch for which status is to be changed for the solution (0 by default)
BRNCH(3)	third bus connected by a three-winding transformer, or zero for a nontransformer branch or a two-winding transformer (0 by default)
Character*2 CKT	circuit ID of the branch for which status is to be changed for the solution (input; '1' by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	bus not found
IERR = 5	branch not found
IERR = 6	three-winding transformer not found
IERR = 7	multi-section line specified but multi-section line reporting option is disabled
IERR = 8	closing a multi-section line is invalid in DCLF
IERR = 9	returning a Type 4 bus to service is not allowed in DCLF
IERR = 10	closing a three-winding transformer is not allowed in DCLF
IERR = 11	generators are converted
IERR = 12	buses in island(s) without a swing bus; use activity TREE
IERR = 13	largest mismatch exceeds 0.5 MW
IERR = 14	prerequisite requirements for API are not met

1.1.67. DCLF_2

Use this API routine to apply the dc analogy network solution algorithm to the network modeled in the working case (activity DCLF).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_DCLF_2  SID ALL STATUS(1)..STATUS(6) BRNCH(1)..BRNCH(3) CKT
```

Python command syntax:

```
ierr = dclf_2(sid, all, status, brnch, ckt)
```

Fortran command syntax:

```
CALL DCLF_2(SID, ALL, STATUS, BRNCH, CKT, IERR)
```

Where:

Integer SID	Is a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined. (input; 1 by default).
Integer ALL	Is the all buses or specified subsystem flag. (input; 1 by default).
Integer STATUS (6)	array of elements specifying calculation options. The value of each element is as follows.(input).
	STATUS(1) is the loss estimate option. (1 by default)
	STATUS(1) = 0 exclude loss estimate.
	STATUS(1) = 1 use the present voltage vector to estimate losses and apply them as "hidden loads".
	STATUS(2) is the regulating phase shifter code (0 by default)
	STATUS(2) = 0 fixed phase shift angles in the base case and the change case.
	STATUS(2) = 1 fixed MW in the base case, fixed phase shift angles in the change case.
	STATUS(2) = 2 fixed MW in the base case and the change case.
	STATUS(3) is rating used in tabulating the report; 1 through 12 (default rating set program option setting by default).
	STATUS(4) is the voltage that should be saved. (0 by default)
	STATUS(4) = 0 original voltages.
	STATUS(4) = 1 base case dc power flow voltages.
	STATUS(4) = 2 change case dc power flow voltages.
	STATUS(5) is status of the changed branch upon completion (0 by default)
	STATUS(5) = 0 leave unchanged.

	STATUS(5) = 1	save changed status.
	STATUS(6)	is action code if the MW mismatch exceeds 0.5 MW. (1 by default)
	STATUS(6) = 0	discontinue.
	STATUS(6) = 1	continue.
Integer BRNCH (3)	array of elements specifying calculation options. The use of each element is as follows. The values can all be zero or defaulted if no branch is to be changed for the solution.(input).	
	BRNCH(1)	is the from bus of the branch for which status is to be changed for the solution (0 by default)
	BRNCH(2)	is the to bus of the branch for which status is to be changed for the solution (0 by default)
	BRNCH(3)	is the third bus connected by a three-winding transformer, or zero for a nontransformer branch or a two-winding transformer (0 by default)
Character*2 CKT	Is the circuit ID of the branch for which status is to be changed for the solution (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined.
	IERR = 2	invalid ALL value.
	IERR = 3	invalid STATUS value.
	IERR = 4	bus not found.
	IERR = 5	branch not found.
	IERR = 6	three-winding transformer not found.
	IERR = 7	multi-section line specified but multi-section line reporting option is disabled.
	IERR = 8	closing a multi-section line is invalid in DCLF.
	IERR = 9	returning a Type 4 bus to service is not allowed in DCLF.
	IERR = 10	closing a three-winding transformer is not allowed in DCLF.
	IERR = 11	generators are converted.
	IERR = 12	buses in island(s) without a swing bus; use activity TREE
	IERR = 13	largest mismatch exceeds 0.5 MW.
	IERR = 14	prerequisite requirements for API are not met.

1.1.68. DCPSCOPF

This API is the DC based Preventive Security Constrained Optimal Power Flow solution (DCPSCOPF). This API is used to find the settings of controls for a system to comply with base case and contingency case operation limits. The API is implemented with DC preventive security constrained optimal power flow method (DCPSCOPF). The objective of the DCPSCOPF is to minimize control adjustments subject to operation limits constraints. The available controls are generation MW outputs of on-line and off-line generators, loads, phase shifters.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_DCPSCOPF  OPTIONS(1)..OPTIONS(7) VALUES(1)..VALUES(6)
              LABELS(1)..LABELS(5) DFXFILE INLFILE THRFILE
```

Python command syntax:

```
ierr = dcpscopf(options, values, labels, dfxfile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL DCPSCOPFAPI(OPTIONS, VALUES, LABELS, DFXFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (7)	array of elements specifying power flow options(input).
OPTIONS(1)	dispatch mode (0 by default)
OPTIONS(1) = 0	disable.
OPTIONS(1) = 1	subsystem machines (RESERVE).
OPTIONS(1) = 2	subsystem machines (PMAX).
OPTIONS(1) = 3	subsystem machines (INERTIA).
OPTIONS(1) = 4	subsystem machines (GOVERNOR DROOP).
OPTIONS(2)	Ignore initial violations in the base case (1 by default)
OPTIONS(2) = 0	No
OPTIONS(2) = 1	Yes
OPTIONS(3)	Abort if MW mismatch exceeds tolerance (0 by default)
OPTIONS(3) = 0	No
OPTIONS(3) = 1	Yes
OPTIONS(4)	generator control flag (1 by default)
OPTIONS(4) = 0	disable generation MW dispatch
OPTIONS(4) = 1	enable
OPTIONS(5)	load control flag (0 by default)
OPTIONS(5) = 0	disable load shedding control
OPTIONS(5) = 1	enable
OPTIONS(6)	phase shifter control flag (1 by default)
OPTIONS(6) = 0	disable phase shifter control
OPTIONS(6) = 1	enable

	OPTIONS(7)	off-line generator control flag (0 by default)
	OPTIONS(7) = 0	disable generation MW dispatch of off-line generators
	OPTIONS(7) = 1	enable
Real VALUES (6)	array of elements specifying power flow options(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Flow tolerance in linear programming
	VALUES(3)	Weighting factor of generation MW dispatch (1.0 by default)
	VALUES(4)	Weighting factor of load control (1.0 by default)
	VALUES(5)	Weighting factor of phase shifter control (1.0 by default)
	VALUES(6)	Weighting factor of generation MW dispatch of off-line generators (1.0 by default)
Character*32 LABELS (5)	array of elements specifying labels(input).	
	LABELS(1)	The label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation output (blank for none).
	LABELS(2)	The label of generation dispatch control system. MW injections of the generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(3)	The label of load control system. Loads in the load control system are available for curtailment in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(4)	The label of phase shifter adjustment system. The phase angles of phase shifters in the system are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(5)	The label of generation MW control of off-line generator control system. MW injections of the off-line generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	

Character*260 INLFILE	Is the name of Load Throwover Data File (input, blank for none). (input).	
Character*260 THRFILE	Is the name of Unit Inertia Data File (input, blank for none). (input).	
Integer IERR	error code (output).	
IERR = -1	PSCOPF terminates with active constraints	
IERR = 0	No error	
IERR = 1	invalid OPTIONS value	
IERR = 2	invalid VALUES value	
IERR = 3	generators are converted	
IERR = 4	buses in island(s) without a swing bus; use activity TREE	
IERR = 5	largest mismatch exceeds mismatch tolerance	
IERR = 6	Generation subsystem not specified	
IERR = 7	too many islands in base case	
IERR = 8	buses with bus type code and series element status inconsistencies	
IERR = 9	no Distribution Factor Data File specified	
IERR = 10	No controls are specified	
IERR = 11	No constraints are specified	
IERR = 12	Simulation STOP. Duplicated contingency labels in DFAX file	
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX	
IERR = 22	monitored elements exceed limit when adding multi-section line members	
IERR = 51	error opening Distribution Factor Data File	
IERR = 52	error opening Load Throwover Data File	
IERR = 53	error opening Unit Inertia and Governor Data File	
IERR = 54	prerequisite requirements for API are not met	

1.1.69. DC_TAP_ADJUSTMENT

Use this API to specify or return the option to enable or disable the dc tap adjustment option setting.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_DC_TAP_ADJUSTMENT IVAL
```

Python command syntax:

```
ierr = dc_tap_adjustment(ival)
ierr, ival = dc_tap_adjustment()
```

Fortran command syntax:

```
CALL DC_TAP_ADJUSTMENT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 disabled.
	IVAL = 1 enabled.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.70. DELTMPFILES

Delete closed temporary files. PSSE creates a subdirectory within the user's "temporary" directory; only files there are removed.

This API routine was first introduced in release 32.2.0.

Batch command syntax:

```
BAT_DELTMPFILES
```

Python command syntax:

```
ierr = deltmpfiles()
```

Fortran command syntax:

```
CALL DELTMPFILES(IERR)
```

Where:

Integer IERR	error code (output).
IERR = 1	prerequisite requirements for API are not met.

1.1.71. DFAX

This API routine is obsolete. It has been replaced by the API routine [dfax_2](#).

Use this API to construct a Distribution Factor Data File (activity DFAX).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_DFAX  OPTIONS(1)  OPTIONS(2)  SUBFILE  MONFILE  CONFILE  DFXFILE
```

Python command syntax:

```
ierr = dfax(options, subfile, monfile, confile, dfxfile)
```

Fortran command syntax:

```
CALL DFAXAPI(OPTIONS, SUBFILE, MONFILE, CONFILE, DFXFILE, IERR)
```

Where:

Integer OPTIONS (2)	array of 2 elements specifying calculation options. The value of each element is as follows(input).	
	OPTIONS(1)	distribution factor option flag (1 by default)
	OPTIONS(1) = 0	do not calculate distribution factors (i.e., DFAX,AC)
	OPTIONS(1) = 1	calculate distribution factors
	OPTIONS(2)	monitored element sorting flag (0 by default)
	OPTIONS(2) = 0	do not sort (i.e., leave in Monitored Element Description File order)
	OPTIONS(2) = 1	sort
Character*260 SUBFILE	name of the Subsystem Description File; blank for none (input; blank by default).	
Character*260 MONFILE	name of Monitored Element Description File (input; no default allowed).	
Character*260 CONFILE	name of Contingency Description Data File (input; no default allowed).	
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	no Distribution Factor Data File specified
	IERR = 5	no Monitored Element Data input file specified

IERR = 6	no Contingency Description Data file specified
IERR = 7	fatal error reading input file
IERR = 8	error opening output file DFXFILE
IERR = 9	error opening input file SUBFILE
IERR = 10	error opening input file MONFILE
IERR = 11	error opening input file CONFILE
IERR = 12	prerequisite requirements for API are not met

1.1.72. DFAX_2

Use this API to construct a Distribution Factor Data File (activity DFAX).

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_DFAX_2  OPTIONS(1)..OPTIONS(3) SUBFILE MONFILE CONFILE DFXFILE
```

Python command syntax:

```
ierr = dfax_2(options, subfile, monfile, confile, dfxfile)
```

Fortran command syntax:

```
CALL DFAXAPI_2(OPTIONS, SUBFILE, MONFILE, CONFILE, DFXFILE, IERR)
```

Where:

Integer OPTIONS (3)	array of elements specifying calculation options. The value of each element is as follows.(input).
OPTIONS(1)	distribution factor option flag. (1 by default)
OPTIONS(1) = 0	do not calculate distribution factors (i.e., DFAX,AC).
OPTIONS(1) = 1	calculate distribution factors.
OPTIONS(2)	monitored element sorting flag (0 by default)
OPTIONS(2) = 0	do not sort (i.e., leave in Monitored Element Description File order).
OPTIONS(2) = 1	sort.
OPTIONS(3)	out-of-service monitored branch flag (0 by default)
OPTIONS(3) = 0	eliminate out-of-service branch from monitored branches.
OPTIONS(3) = 1	keep out-of-service branch in monitored branches.
Character*260 SUBFILE	Is the name of the Subsystem Description File (input; blank by default).
Character*260 MONFILE	Is the name of Monitored Element Description File (input; no default allowed).
Character*260 CONFILE	Is the name of Contingency Description Data File (input; no default allowed).
Character*260 DFXFILE	Is the name of Distribution Factor Data File (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred.
IERR = 1	invalid OPTIONS value
IERR = 2	generators are converted.

IERR = 3	buses in island(s) without a swing bus; use activity TREE
IERR = 4	no Distribution Factor Data File specified
IERR = 5	no Monitored Element Data input file specified.
IERR = 6	no Contingency Description Data file specified.
IERR = 7	fatal error reading input file.
IERR = 8	error opening output file DFXFILE.
IERR = 9	error opening input file SUBFILE.
IERR = 10	error opening input file MONFILE.
IERR = 11	error opening input file CONFILE.
IERR = 12	prerequisite requirements for API are not met.

1.1.73. DFAX_CONTINGENCY

Use this API to combine one contingency in the first Distribution Factor file with one contingency in the second Distribution Factor file and so on, till specified contingency level is reached, to create multiple event contingencies and then export resulting contingencies to user defined report device.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr = dfax_contingency(option, confile, dfxfile)
```

Fortran command syntax:

```
CALL DFAX_CONTINGENCY(OPTION, CONFILE, DFXFILE, IERR)
```

Where:

Integer OPTION	level of multiple contingencies (input; from 1 to 3; 1).
Character*260 CONFILE	name of Contingency Description Data File (input; blank by default).
Character*260 DFXFILE (OPTION)	OPTION names of Distribution Factor Data Files where contingencies are combined each other to build OPTION level contingencies (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid OPTION value
	IERR = 2 Input file is not a Distribution Factor Data File
	IERR = 3 error reading Distribution Factor Data File
	IERR = 51 error opening Contingency Description Data File
	IERR = 52 error opening Distribution Factor Data File

1.1.74. DFTI

Use this API to compare tie lines, as contained in the working case, with those of a designated Saved Case (activity DFTI). It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by any number of references with APIOPT=2, followed by one reference with APIOPT=3.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference, followed by one APIOPT 3 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DFTI  SID  APIOPT  STATUS(1)..STATUS(5)  THRSH  CFILE
```

Python command syntax:

```
ierr, seqflg = dfti(sid, apiopt, status, thrsh, cfile)
```

Fortran command syntax:

```
CALL DFTIAPI(SID, APIOPT, STATUS, THRSH, CFILE, SEQFLG, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 0 or 1; 0).
Integer APIOPT	mode of operation of DFTIAPI (input; 0 by default). APIOPT = 0 initialize for case comparison, run the comparison specified by STATUS(4), and run post-processing clean up. APIOPT = 1 initialize for case comparison. APIOPT = 2 run a comparison. APIOPT = 3 post-processing clean up.
Integer STATUS (5)	array of 5 elements specifying comparison options(input). STATUS(1) defines the working case content following an APIOPT=0 or 3 reference (used only when APIOPT is 0, 1 or 3; 0 by default) STATUS(1) = 0 original working case STATUS(1) = 1 Saved Case specified in CFILE STATUS(2) flag for method of considering buses in the two cases to be the same bus (used only when APIOPT is 0 or 1; 0 by default) STATUS(2) = 0 same bus numbers STATUS(2) = 1 same extended bus names STATUS(2) = 2 same bus numbers and extended bus names STATUS(3) flag for specifying THRESH (used only when APIOPT is 0 or 2; 0 by default) STATUS(3) = 0 engineering units

	STATUS(3) = 1	percent
	STATUS(4)	code for the comparison to be run (used only when APIOPT is 0 or 2; 1 by default)
	STATUS(4) = 1	branch status
	STATUS(4) = 2	line R, X, B
	STATUS(4) = 3	line shunts
	STATUS(4) = 4	line ratings
	STATUS(4) = 5	metered end
	STATUS(4) = 6	line length
	STATUS(4) = 7	transformers
	STATUS(4) = 8	flow MW or MVAR (from bus)
	STATUS(4) = 9	flow MW or MVAR (from & to)
	STATUS(4) = 10	line MW or MVAR losses
	STATUS(4) = 11	zero sequence R, X, B
	STATUS(4) = 12	zero sequence line shunts
	STATUS(4) = 13	transformer connection codes
	STATUS(4) = 14	flow MW (from bus)
	STATUS(4) = 15	flow MVAR (from bus)
	STATUS(4) = 16	flow MW (from and to buses)
	STATUS(4) = 17	flow MVAR (from and to buses)
	STATUS(4) = 18	line MW losses
	STATUS(4) = 19	line MVAR losses
	STATUS(5)	line rating to be compared when STATUS(4) is 4 (used only when APIOPT is 0 or 2; 0 by default)
	STATUS(5) = 0	all ratings
	STATUS(5) = 1	RATEA
	STATUS(5) = 2	RATEB
	STATUS(5) = 3	RATEC
Real THRSH		difference threshold (input; used only when APIOPT is 0 or 2; 0.0).
Character*260 CFILE		name of Saved Case File in which tie lines are to be compared to those of the working case (when APIOPT is 0 or 1) (input; no default allowed).
Logical SEQFLG (2)		array of 2 elements specifying returned when APIOPT=0 or 1(output).
	SEQFLG(1)	true if there is sequence data in the working case
	SEQFLG(2)	true if there is sequence data in the Saved Case in file CFILE
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid STATUS value
	IERR = 3	CFILE is blank

IERR = 4	no ties to compare
IERR = 5	invalid APIOPT value
IERR = 6	unexpected APIOPT value
IERR = 7	invalid THRSH value
IERR = 8	error reading the comparison case
IERR = 9	prerequisite requirements for API are not met

1.1.75. DIFF

Use this API to compare specified power flow data and solution results, as contained in the working case, with those of a designated Saved Case (activity DIFF). It must be referenced first with APIOPT=1, followed by any number of references with APIOPT=2, followed by one reference with APIOPT=3:

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DIFF  SID  ALL  APIOPT  STATUS(1)..STATUS(4)  THRSH(1)..THRSH(3)
          CFILE
```

Python command syntax:

```
ierr, seqflg = diff(sid, all, apiopt, status, thrsh, cfile)
```

Fortran command syntax:

```
CALL DIFFNW(SID, ALL, APIOPT, STATUS, THRSH, CFILE, SEQFLG, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer APIOPT	mode of operation in the API (input; no default allowed).	
	APIOPT = 1	initialize for case comparison.
	APIOPT = 2	run case comparison for specified data category.
	APIOPT = 3	postprocessing housekeeping.
Integer STATUS (4)	array of elements specifying STATUS contains various processing options and has different values or meanings depending on the value of APIOPT(input).	
	STATUS(1)	working case or threshold option (0 by default)
	STATUS(1) = 0	If APIOPT=1 or 3, leave original case as working case. If APIOPT=2, thresholds are in engineering units.
	STATUS(1) = 1	If APIOPT=1 or 3, leave comparison case (CFILE) as working case. If APIOPT=2, thresholds are percentages.
	STATUS(2)	comparison options
	STATUS(2) = 0	If APIOPT=1, bus numbers must be the same to match (default for APIOPT=1 or 3).
	STATUS(2) = 1	If APIOPT=1, bus names must be the same to match. If APIOPT=2, compare bus identifiers (default for APIOPT=2).

STATUS(2) = 2	If APIOPT=1, bus numbers and names must be the same to match. If APIOPT=2, compare bus type codes.
STATUS(2) = 3	(If APIOPT=2) compare machine statuses.
STATUS(2) = 4	(If APIOPT=2) compare generator MW.
STATUS(2) = 5	(If APIOPT=2) compare generator MW or MVAR.
STATUS(2) = 6	(If APIOPT=2) compare bus loads.
STATUS(2) = 7	(If APIOPT=2) compare bus shunts.
STATUS(2) = 8	(If APIOPT=2) compare switched shunts.
STATUS(2) = 9	(If APIOPT=2) compare voltage.
STATUS(2) = 10	(If APIOPT=2) compare bus voltage & angle.
STATUS(2) = 11	(If APIOPT=2) compare MBASE & ZSORCE.
STATUS(2) = 12	(If APIOPT=2) compare MBASE & RPOS+jX.
STATUS(2) = 13	(If APIOPT=2) compare MBASE & ZNEG.
STATUS(2) = 14	(If APIOPT=2) compare MBASE & ZZERO.
STATUS(2) = 15	(If APIOPT=2) compare negative sequence loads.
STATUS(2) = 16	(If APIOPT=2) compare zero sequence loads.
STATUS(2) = 17	(If APIOPT=2) compare branch status.
STATUS(2) = 18	(If APIOPT=2) compare line R, X, & B.
STATUS(2) = 19	(If APIOPT=2) compare line shunts.
STATUS(2) = 20	(If APIOPT=2) compare line ratings.
STATUS(2) = 21	(If APIOPT=2) compare metered end.
STATUS(2) = 22	(If APIOPT=2) compare transformers.
STATUS(2) = 23	(If APIOPT=2) compare from P or Q flow.
STATUS(2) = 24	(If APIOPT=2) compare from and to P or Q flow.
STATUS(2) = 25	(If APIOPT=2) compare P or Q losses.
STATUS(2) = 26	(If APIOPT=2) compare zero sequence R, X, & B.
STATUS(2) = 27	(If APIOPT=2) compare zero sequence line shunts.
STATUS(2) = 28	(If APIOPT=2) compare connection codes.
STATUS(2) = 29	(If APIOPT=2) compare zero sequence mutuals.
STATUS(2) = 30	(If APIOPT=2) compare multisection lines.
STATUS(2) = 31	(If APIOPT=2) compare multisection line metered end.
STATUS(2) = 32	(If APIOPT=2) compare load status.
STATUS(2) = 33	(If APIOPT=2) compare line lengths.
STATUS(2) = 34	(If APIOPT=2) compare generator Q.
STATUS(2) = 35	(If APIOPT=2) compare from P flow.
STATUS(2) = 36	(If APIOPT=2) compare from Q flow.
STATUS(2) = 37	(If APIOPT=2) compare from and to P flow.

	STATUS(2) = 38	(If APIOPT=2) compare from and to Q flow.
	STATUS(2) = 39	(If APIOPT=2) compare line P losses.
	STATUS(2) = 40	(If APIOPT=2) compare line Q losses.
	STATUS(2) = 41	(If APIOPT=2) compare shunt status.
	STATUS(2) = 42	(If APIOPT=2) compare switched shunt status.
	STATUS(2) = 43	(If APIOPT=2) compare load scalable flag.
	STATUS(2) = 44	(If APIOPT=2) compare MBASE & RPOS+jX'.
	STATUS(2) = 45	(If APIOPT=2) compare MBASE & RPOS+jXs.
	STATUS(2) = 46	(If APIOPT=2) compare bus substation.
	STATUS(2) = 47	(If APIOPT=2) compare node status.
	STATUS(2) = 48	(If APIOPT=2) compare switching device status.
	STATUS(2) = 49	(If APIOPT=2) compare switching device P or Q flow.
	STATUS(2) = 50	(If APIOPT=2) compare switching device P flow.
	STATUS(2) = 51	(If APIOPT=2) compare switching device Q flow.
	STATUS(3)	load characteric comparison option (0 by default)
	STATUS(3) = 0	use total nominal load (only used if APIOPT=2)
	STATUS(3) = 1	use constant MVA (only used if APIOPT=2)
	STATUS(3) = 2	use constant current (only used if APIOPT=2)
	STATUS(3) = 3	use constant admittance (only used if APIOPT=2)
	STATUS(4)	line rating to use. (1 by default)
	STATUS(4) = 0	use all ratings (only used if APIOPT=2)
	STATUS(4) = 1-12	use rating specified (only used if APIOPT=2)
Real THRSH (3)	array of 3 elements specifying thresholds (only used when APIOPT is 2)(input).	
	THRSH(1)	difference threshold (0.0 by default)
	THRSH(2)	voltage or tap ratio threshold (0.0 by default)
	THRSH(3)	angle threshold (0.0 by default)
Character*260 CFILE	saved case to be compared against the data currently in the working case (only used when APIOPT is 1) (input; no default allowed).	
Logical SEQFLG (2)	array of 2 elements specifying returned when APIOPT = 1(output).	
	SEQFLG(1)	true if there is sequence data in the working case
	SEQFLG(2)	true if there is sequence data in the Saved Case in file CFILE
Integer IERR	error code (output).	
	IERR = 0	no error occurred

IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	invalid APIOPT value
IERR = 4	invalid STATUS value
IERR = 5	invalid THRSH value
IERR = 6	CFILE is blank
IERR = 7	unexpected APIOPT value
IERR = 8	error building the case to case translation files
IERR = 9	error reading the comparison case
IERR = 10	prerequisite requirements for API are not met

1.1.76. DSCN

Use this API to electrically disconnect a bus (activity DSCN).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DSCN  BUS
```

Python command syntax:

```
ierr = dscn(bus)
```

Fortran command syntax:

```
CALL DSCNAPI(BUS, IERR)
```

Where:

Integer BUS	number of the bus to be disconnected (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus BUS not found
	IERR = 2	prerequisite requirements for API are not met

1.1.77. DUPLICATE_CNTLABEL_CHECK

Use this API to specify or return the option to enable or disable the duplicated contingency labels check when Distribution Factor Data File (*.dfx) or Contingency Description Data File (*.con) files are used.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_DUPLICATE_CNTLABEL_CHECK STATUS
```

Python command syntax:

```
ierr = duplicate_cntlabel_check(status)
ierr, status = duplicate_cntlabel_check()
```

Fortran command syntax:

```
CALL DUPLICATE_CNTLABEL_CHECK(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if ICODE is 0, no default allowed; else output).	
	STATUS = 0	disable checking duplicated contingency labels in DFAX or CON file.
	STATUS = 1	enable checking duplicated contingency labels in DFAX or CON file.
Integer ICODE	Indicates the operation mode of the API (no default allowed).	
	ICODE = 0	set the option setting to the value specified in STATUS.
	ICODE = 1	return the current value of the option setting in STATUS.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	Invalid STATUS value
	IERR = 2	Invalid ICODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.78. ECDI

Use this API to place machines in a specified subsystem on- or off-line to satisfy a given subsystem minimum capacity; the in-service machines in the subsystem are then dispatched on the basis of incremental cost to meet a specified total subsystem generation (activity ECDI).

This API must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by one reference with APIOPT=2, followed by one or more references with APIOPT=3, followed by one reference with APIOPT=4.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference, followed by one APIOPT 3 reference, followed by one APIOPT 4 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ECDI  SID  ALL  APIOPT  CFILE  STATUS  VALUES(1)  VALUES(2)
```

Python command syntax:

```
ierr = ecdi(sid, all, apiopt, cfile, status, values)
```

Fortran command syntax:

```
CALL ECDIAPI(SID, ALL, APIOPT, CFILE, STATUS, VALUES, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 0 or 2; 0).
Integer ALL	all buses or specified subsystem flag (input; used only when APIOPT is 0 or 2; 1). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer APIOPT	mode of operation of the API (input; 0 by default). APIOPT = 0 initialize, specify subsystem, process, and clean up. APIOPT = 1 initialize for dispatch. APIOPT = 2 specify subsystem. APIOPT = 3 apply calculation. APIOPT = 4 postprocessing housekeeping.
Character*260 CFILE	name of the Economic Dispatch Data File (when APIOPT is 0 or 1) (input; no default allowed).
Integer STATUS	unit commitment option (input; used only when APIOPT is 0 or 2; 0). STATUS = 0 start from current commitment profile. STATUS = 1 new commitment profile (start with all units off-line). STATUS = 2 unit commitment disabled.

Real VALUES (2)	array of 2 elements specifying (used only when APIOPT is 0 or 3)(input).	
	VALUES(1)	desired loading (present loading by default)
	VALUES(2)	desired minimum capacity of units being dispatched (0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid APIOPT value
	IERR = 3	invalid ALL value
	IERR = 4	invalid STATUS value
	IERR = 5	dispatch unable to meet desired power and capacity
	IERR = 6	no dispatch data for any subsystem machines
	IERR = 7	negative VALUES value
	IERR = 8	unexpected APIOPT value
	IERR = 9	error opening CFILE
	IERR = 10	prerequisite requirements for API are not met

1.1.79. ECHO

Use this API to enable or disable response echoing (activity ECHO).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_ECHO IDVFIL
```

Python command syntax:

```
ierr = echo(idvfil)
```

Fortran command syntax:

```
CALL ECHOAPI(IDVFIL, IERR)
```

Where:

Character*260 IDVFIL	name of Response File to be constructed (blank to disable) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening IDVFIL
	IERR = 2	prerequisite requirements for API are not met

1.1.80. EEQV

Use this API to construct an electrical equivalent of a specified subsystem of the working case (activity EE-QV).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_EEQV SID ALL STATUS(1)..STATUS(6) DVAL(1) DVAL(2)
```

Python command syntax:

```
ierr = eeqv(sid, all, status, dval)
```

Fortran command syntax:

```
CALL EEQVNW(SID, ALL, STATUS, DVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer STATUS (6)	array of 6 elements specifying They are used to control equivalencing options. A value of 0 means the option is not enabled. A value of 1 means the option is enabled. They are as follows(input). STATUS(1) retain area boundary buses (0 by default) STATUS(2) retain zone boundary buses (0 by default) STATUS(3) suppress the equivalencing option for phase shifters (0 by default) STATUS(4) retain controlled buses (0 by default) STATUS(5) retain existing branches between retained buses (0 by default) STATUS(6) net load and shunt at retained buses (0 by default)
Real DVAL (2)	array of 2 elements specifying They are as follows(input). DVAL(1) minimum active or reactive power generation for retaining generator buses (0.0 by default) DVAL(2) branch threshold tolerance (10.0 by default)
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value

IERR = 3

invalid STATUS value

IERR = 4

invalid DVAL value

IERR = 5

prerequisite requirements for API are not met

1.1.81. EQRD

Use this API to build an electrical equivalent of radial and, optionally, two-point Type 1 buses in a specified subsystem of the working case (activity EQRD).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_EQRD  SID  ALL  STATUS(1)..STATUS(8)
```

Python command syntax:

```
ierr = eqrd(sid, all, status)
```

Fortran command syntax:

```
CALL EQRDW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS (8)	array of 8 elements specifying They are used to control equivalencing options. A value of 0 means the option is not enabled. A value of 1 means the option is enabled. They are as follows(input).	
	STATUS(1)	build an electrical equivalent of radial buses only (0 by default)
	STATUS(2)	suppress the equivalencing option for transformers (0 by default)
	STATUS(3)	suppress the equivalencing option for zero impedance lines (0 by default)
	STATUS(4)	suppress the equivalencing option for controlled buses (0 by default)
	STATUS(5)	suppress the equivalencing option for mutually coupled branches (0 by default)
	STATUS(6)	suppress the equivalencing option for area boundary buses (0 by default)
	STATUS(7)	suppress the equivalencing option for zone boundary buses (0 by default)
	STATUS(8)	apply transformer impedance correction to zero sequence network (1 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined

IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	error writing the working case to a temporary file
IERR = 5	load table is full; restoring original working case
IERR = 6	fixed bus shunt table is full; restoring original working case
IERR = 7	error opening temporary file
IERR = 8	prerequisite requirements for API are not met

1.1.82. EXAM

Use this API to tabulate all power flow data pertaining to a specified bus (activity EXAM).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_EXAM  SID  ALL
```

Python command syntax:

```
ierr = exam(sid, all)
```

Fortran command syntax:

```
CALL EXAMNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.83. FACT

Use this API to factorize the network admittance matrix in preparation for switching studies and dynamic simulations (activity FACT).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_FACT
```

Python command syntax:

```
ierr = fact()
```

Fortran command syntax:

```
CALL FACTAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	generators are not converted
	IERR = 2	prerequisite requirements for API are not met

1.1.84. FDNS

Use this API to apply the fixed slope decoupled Newton-Raphson power flow calculation (activity FDNS).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_FDNS  OPTIONS(1) .. OPTIONS(8)
```

Python command syntax:

```
ierr = fdns(options)
```

Fortran command syntax:

```
CALL FDNSAPI(OPTIONS, IERR)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (use tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (use area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (use phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (use dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (use switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	flat start flag (0 by default)
	OPTIONS(6) = 0	do not flat start
	OPTIONS(6) = 1	flat start
	OPTIONS(6) = 2	flat start, then estimate voltage magnitudes
	OPTIONS(6) = 3	flat start, then estimate voltage phase angles
	OPTIONS(6) = 4	flat start, then estimate voltage magnitudes and phase angles
	OPTIONS(7)	var limit flag (99 by default)
	OPTIONS(7) = 0	apply var limits immediately
	OPTIONS(7) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(7) = -1	ignore var limits
	OPTIONS(8)	non-divergent solution flag (use non-divergent solution option setting by default)
	OPTIONS(8) = 0	disable
	OPTIONS(8) = 1	enable
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	bus type code and series element status inconsistencies
	IERR = 5	prerequisite requirements for API are not met

1.1.85. FILE_OVERWRITE

Use this API to specify or return the option to set the file overwrite option setting to either ask first or overwrite.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_FILE_OVERWRITE IVAL
```

Python command syntax:

```
ierr = file_overwrite(ival)
ierr, ival = file_overwrite()
```

Fortran command syntax:

```
CALL FILE_OVERWRITE_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
	IVAL = 0 ask first.
	IVAL = 1 overwrite.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.86. FIND

Use this API to tabulate a list of buses matching a partial extended bus name (activity FIND).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_FIND  NAME BSKV
```

Python command syntax:

```
ierr = find(name, bskv)
```

Fortran command syntax:

```
CALL FINDAPI(NAME, BSKV, IERR)
```

Where:

Character*24 NAME	bus name, including imbedded asterisks that are treated as wildcard characters (input; blank by default).	
Character*12 BSKV	bus base voltage (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error decoding BSKV
	IERR = 2	prerequisite requirements for API are not met

1.1.87. FLAT_START

Use this API to specify or return the option to enable or disable the voltage flat start option setting.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FLAT_START IVAL
```

Python command syntax:

```
ierr = flat_start(ival)
ierr, ival = flat_start()
```

Fortran command syntax:

```
CALL FLAT_START_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).	
	IVAL = 0	use present voltages as the starting point in power flow solutions.
	IVAL = 1	flat start voltages before power flow solutions.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.88. FNSL

Use this API to apply the Newton-Raphson power flow calculation (activity FNSL).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_FNSL  OPTIONS(1) .. OPTIONS(8)
```

Python command syntax:

```
ierr = fnsL(options)
```

Fortran command syntax:

```
CALL FNSLAPI(OPTIONS, IERR)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (use tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (use area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (use phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (use dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (use switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	flat start flag (0 by default)
	OPTIONS(6) = 0	do not flat start
	OPTIONS(6) = 1	flat start
	OPTIONS(6) = 2	flat start, then estimate voltage magnitudes
	OPTIONS(6) = 3	flat start, then estimate voltage phase angles
	OPTIONS(6) = 4	flat start, then estimate voltage magnitudes and phase angles
	OPTIONS(7)	var limit flag (99 by default)
	OPTIONS(7) = 0	apply var limits immediately
	OPTIONS(7) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(7) = -1	ignore var limits
	OPTIONS(8)	non-divergent solution flag (use non-divergent solution option setting by default)
	OPTIONS(8) = 0	disable
	OPTIONS(8) = 1	enable
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	bus type code and series element status inconsistencies
	IERR = 5	prerequisite requirements for API are not met

1.1.89. GCAP

This API routine is obsolete. It has been replaced by the API routines [ReadCapCurves](#) and [GCAP_2](#).

Use this API to read a data file containing capability curve data and print a report of machine loading and limit data (activity GCAP). Optionally, machine reactive power limits in the working case may be updated.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_GCAP SID ALL OPT GFILE
```

Python command syntax:

```
ierr = gcap(sid, all, opt, gfile)
```

Fortran command syntax:

```
CALL GCAPNW(SID, ALL, OPT, GFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer OPT	update var limits option (input; 0 by default).	
	OPT = 0	leave var limits unchanged.
	OPT = 1	update var limits in the working case.
Character*260 GFILE	Machine Capability Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 4	error opening GFILE
	IERR = 5	prerequisite requirements for API are not met

1.1.90. GCAP_2

Use this API to print a report of machine loading and reactive power limit data (activity GCAP). Optionally, machine reactive power limits in the working case may be updated.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_GCAP_2  SID  ALL  OPT
```

Python command syntax:

```
ierr = gcap_2(sid, all, opt)
```

Fortran command syntax:

```
CALL GCAP_2(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer OPT	update var limits option (input; 0 by default). OPT = 0 leave var limits unchanged. OPT = 1 update var limits in the working case.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 capability curve data has not been read into this case IERR = 2 invalid SID value or subsystem SID is not defined IERR = 3 invalid ALL value IERR = 4 invalid OPT value IERR = 5 prerequisite requirements for API are not met

1.1.91. GDIF

Use this API to calculate differences between the working case and a designated Saved Case (activity GDIF). Results may be programmatically accessed via the internally accessible fetch routines DIFTXT, DIFBUS, DIFBRN, DIF3WN, DIF2DC, DIFMDC and DIFCT.

Usage is: call to GDIFAPI with APIOPT = 0;

multiple calls to fetch routines;

optionally, repeat of above steps for different Saved Case and/or subsystem;

final call to GDIFAPI with APIOPT = 1.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_GDIF  SID  ALL  APIOPT  NAMARG  FILARG
```

Python command syntax:

```
ierr = gdif(sid, all, apiopt, namarg, filarg)
```

Fortran command syntax:

```
CALL GDIFAPI(SID, ALL, APIOPT, NAMARG, FILARG, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 0; 0).	
Integer ALL	all buses or specified subsystem flag (input; used only when APIOPT is 0; 1).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer APIOPT	mode of operation of GDIFAPI (input; no default allowed).	
	APIOPT = 0	apply difference calculations and fill arrays used by fetch routines.
	APIOPT = 1	deallocate arrays used by fetch routines.
Integer NAMARG	flag indicating how to match up buses in the two cases (input; used only when APIOPT is 0; 0).	
	NAMARG = 0	by bus number only.
	NAMARG = 1	by extended bus name only.
	NAMARG = 2	by both number and name.
Character*260 FILARG	name of Saved Case File to be compared to the working case (when APIOPT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value

IERR = 3	invalid APIOPT value
IERR = 4	invalid NAMARG value
IERR = 5	FILARG is blank
IERR = 6	error reading the comparison case
IERR = 7	prerequisite requirements for API are not met

1.1.92. GENDSP

Use this API to impose a contingency specified in the Distribution Factor Data file and apply the generation dispatch algorithm used in contingency analysis on the working case. The network can then be solved by power flow solutions.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_GENDSP  OPTIONS(1)  OPTIONS(2)  LABELS(1)  LABELS(2)  DFXFILE  THRFILE
            INLFILE
```

Python command syntax:

```
ierr = gendsp(options, labels, dfxfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL GENDSPAPI(OPTIONS, LABELS, DFXFILE, THRFILE, INLFILE, IERR)
```

Where:

Integer OPTIONS (2)	array of 2 elements specifying options(input).
OPTIONS(1)	dispatch mode (1 by default)
OPTIONS(1) = 0	disable dispatch
OPTIONS(1) = 1	subsystem machines (RESERVE)
OPTIONS(1) = 2	subsystem machines (PMAX)
OPTIONS(1) = 3	subsystem machines (INERTIA)
OPTIONS(1) = 4	subsystem machines (GOVERNOR DROOP)
OPTIONS(2)	study case (1 by default)
OPTIONS(2) = 0	impose a contingency case on the working case
OPTIONS(2) = 1	working case
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).
LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTIONS(1) is from 1 to 4)
LABELS(2)	contingency label (blank by default, no default allowed if OPTIONS(2) is 0)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid OPTIONS value
IERR = 2	no dispatch subsystem specified

IERR = 3	no contingency specified
IERR = 4	no Distribution Factor Data File specified
IERR = 5	generators are converted
IERR = 6	too many islands in base case
IERR = 7	contingency not found in Distribution Factor Data File
IERR = 21	file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 23	no subsystem defined in Distribution Factor Data file
IERR = 24	subsystem not found
IERR = 51	error opening Distribution Factor Data File
IERR = 52	error opening Load Throwover Data File
IERR = 53	error opening Unit Inertia and Governor Data File
IERR = 54	error opening or writing temporary Saved Case File
IERR = 55	prerequisite requirements for function not met

1.1.93. GENDSP_2

Use this API to impose a contingency specified in the Distribution Factor Data file and apply the generation dispatch algorithm used in contingency analysis on the working case. The network can then be solved by power flow solutions.

This API routine was first introduced in release 35.3.3.

Batch command syntax:

```
BAT_GENDSP_2  OPTIONS(1)  OPTIONS(2)  SYSLABEL  CNTLABEL  DFXFILE  THRFILE
              INLFILE
```

Python command syntax:

```
ierr = gendsp_2(options, syslabel, cntlabel, dfxfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL GENDSPAPI_2(OPTIONS, SYSLABEL, CNTLABEL, DFXFILE, THRFILE, INLFILE,
                 IERR)
```

Where:

Integer OPTIONS (2)	array of 2 elements specifying options(input).
OPTIONS(1)	dispatch mode (1 by default)
OPTIONS(1) = 0	disable dispatch
OPTIONS(1) = 1	subsystem machines (RESERVE)
OPTIONS(1) = 2	subsystem machines (PMAX)
OPTIONS(1) = 3	subsystem machines (INERTIA)
OPTIONS(1) = 4	subsystem machines (GOVERNOR DROOP)
OPTIONS(2)	study case (1 by default)
OPTIONS(2) = 0	impose a contingency case on the working case
OPTIONS(2) = 1	working case
Character*32 SYSLABEL	subsystem label (input).
Character*160 CNTLABEL	contingency label (input).
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid OPTIONS value
IERR = 2	no dispatch subsystem specified
IERR = 3	no contingency specified
IERR = 4	no Distribution Factor Data File specified
IERR = 5	generators are converted

IERR = 6	too many islands in base case
IERR = 7	contingency not found in Distribution Factor Data File
IERR = 21	file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 23	no subsystem defined in Distribution Factor Data file
IERR = 24	subsystem not found
IERR = 51	error opening Distribution Factor Data File
IERR = 52	error opening Load Throwover Data File
IERR = 53	error opening Unit Inertia and Governor Data File
IERR = 54	error opening or writing temporary Saved Case File
IERR = 55	prerequisite requirements for function not met

1.1.94. GENS

Use this API to tabulate the loading and voltage conditions at plant buses (activity GENS).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_GENs  SID  ALL  OPT  VREV
```

Python command syntax:

```
ierr = gens(sid, all, opt, vrev)
```

Fortran command syntax:

```
CALL GENSNW(SID, ALL, OPT, VREV, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer OPT	option (input; 4 by default). OPT = 1 tabulate var limited plants with unequal var limits. OPT = 2 tabulate all var limited plants. OPT = 3 tabulate on-line plants. OPT = 4 tabulate all plants.
Integer VREV	option to select the units in which voltages are tabulated (input; 0 by default). VREV = 0 use default voltage units. VREV = 1 use alternate voltage units.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid OPT value IERR = 4 invalid VREV value IERR = 5 prerequisite requirements for API are not met

1.1.95. GEOL

Use this API to tabulate the loading and voltage conditions at the generator terminals for online machines at Type 2 and 3 buses in the working case (activity GEOL).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_GEOL  SID  ALL  OPT
```

Python command syntax:

```
ierr = geol(sid, all, opt)
```

Fortran command syntax:

```
CALL GEOLNW(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer OPT	option (input; 1 by default). OPT = 1 tabulate overloaded machines only. OPT = 2 tabulate all machines.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid OPT value IERR = 4 prerequisite requirements for API are not met

1.1.96. GETCONTINGENCYSAVEDCASE

Use this API routine to place the working case in the form of a specified system condition as calculated during a previous run of one of the members of the the AC contingency calculation family. This function retrieves data from a ZIP Archive Ouptut File that was created during the contingency calculation.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_GETCONTINGENCYSAVEDCASE  PATHZIP ISVFILE
```

Python command syntax:

```
ierr = getcontingencysavedcase(pathzip, isvfile)
```

Fortran command syntax:

```
CALL GETCONTINGENCYSAVEDCASE(PATHZIP, ISVFILE, IERR)
```

Where:

Character*260 PATHZIP	Is the name of the ZIP Archive Output File (input; no default allowed).
Character*260 ISVFILE	Is the name of an Incremental Saved Case File (.isv file) contained in PATHZIP (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred.
	IERR = 1 unable to pick up the base Saved Case File from the ZIP Archive File.
	IERR = 2 error opening the Incremental Saved Case File.
	IERR = 3 error closing the Incremental Saved Case File.
	IERR = 4 prerequisite requirements for API are not met.

1.1.97. GIC_PF

Add activity GIC calculated Mvar Qloss in scaled manner to the working case to arrive at the converged power flow solution.

This API routine was first introduced in release 34.5.0.

Python command syntax:

```
ierr = gic_pf(addfile, qpct, method, tap, area, phshift, dctap, swsh,
             flat, varlimit, nondiv, pfprogress)
```

Where:

Character ADDFILE	RDCH raw file created by GIC activity that represents Constant Current Mvar losses due to GMD corresponding to the working case (input; no default allowed).
real QPCT	Percent Mvar loss step size that will be incrementally added to the working case (input; 100 by default [add all (100%) Mvar losses in one step]).
character METHOD	Power flow solution method (input; last by default). method = last last power flow method used by working case method = fnsl full Newton-Raphson method = fdns fixed slope decoupled Newton-Raphson method = nsol decoupled Newton-Raphson
integer TAP	power flow tap adjustment flag (input; use last solution tap option by default). tap = 0 disable tap = 1 enable stepping adjustment tap = 2 enable direct adjustment
integer AREA	power flow area interchange adjustment flag (input; use last solution area option by default). area = 0 disable area = 1 enable using tie line flows only in calculating area interchange area = 2 enable using tie line flows and loads in calculating area interchange
integer PHSHIFT	power flow phase shift adjustment flag (input; use last solution phshift option by default). phshift = 0 disable phshift = 1 enable
integer DCTAP	power flow dc tap adjustment flag (input; use last solution dctap option by default). dctap = 0 disable dctap = 1 enable
integer SWSH	power flow switched shunt adjustment flag (input; use last solution swsh option by default).

	swsh = 0	disable
	swsh = 1	enable
	swsh = 2	enable continuous mode, disable discrete mode
integer FLAT	power flow flat start flag (input; use last solution flat option by default).	
	flat = 0	do not flat start
	flat = 1	flat start
	flat = 2	flat start, then estimate voltage magnitudes
	flat = 3	flat start, then estimate voltage phase angles
	flat = 4	flat start, then estimate voltage magnitudes and phase angles
integer VARLIMIT	power flow var limit flag (input; use last solution varlimit option by default).	
	varlimit = 0	apply var limits immediately
	varlimit > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	varlimit = -1	ignore var limits
integer NONDIV	power flow non-divergent solution flag (not used in NSOL) (input; use last solution nondiv option by default).	
	nondiv = 0	disable
	nondiv = 1	enable
integer PFPROGRESS	flag to show or suppress data change and power flow solution progress messages (input; 0 by default).	
	pfprogress = 0	suppress progress
	pfprogress = 1	show progress
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	Data change or PF solution error, check progress for details

1.1.98. GNESTATUS

Use this API to specify or return the status of a GNE device.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_GNESTATUS  'NAME'  IVAL
```

Python command syntax:

```
ierr = gnestatus(name, ival)
ierr, ival = gnestatus(name)
```

Fortran command syntax:

```
CALL GNESTATUS(NAME, IVAL, IOCODE, IERR)
```

Where:

Character*12 NAME	name of the GNE device for which the status is to be changed (input; no default allowed).
Integer IVAL	value of the status of the specified GNE device (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, no default allowed; else output). IVAL = 0 out-of-service. IVAL = 1 in-service.
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the status to the value specified in IVAL. IOCODE = 1 return the current value of the status in IVAL.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 GNE device not found IERR = 2 invalid GNE status value IERR = 3 invalid IOCODE value IERR = 4 prerequisite requirements for API are not met

1.1.99. GNET

Use this API to change in-service generation to negative MVA load at all Type 2 and 3 buses in the subsystem specified by the user.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_GNET  SID  ALL
```

Python command syntax:

```
ierr = gnet(sid, all)
```

Fortran command syntax:

```
CALL GNETNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.100. IMNET

Use this API routine to change the status of induction machines that are in-service to out-of-service, and to replace the power flowing from the network into the machine with constant power load. The routine can be directed to process either all in-service induction machines, all in-service induction machines within a specified subsystem, or all in-service induction machines outside of a specified subsystem.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMNET  SID  ALL  INOUT
```

Python command syntax:

```
ierr = imnet(sid, all, inout)
```

Fortran command syntax:

```
CALL IMNET(SID, ALL, INOUT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only induction machines within, or outside of, subsystem SID
	ALL = 1	process all induction machines
Integer INOUT	include or exclude induction machines in subsystem SID (input; 0 by default).	
	INOUT = 0	process only machines inside of subsystem SID
	INOUT = 1	process only machines outside of subsystem SID
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid INOUT value
	IERR = 4	prerequisite requirements for API are not met

1.1.101. IMOUTAGE

Use this API routine to change the status of induction machines that are in-service, but that have been set to the "stalled" (for motors) or "tripped" (for generators) state by the power flow solution, to out-of-service.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMOUTAGE SID ALL MOTOPT GENOPT
```

Python command syntax:

```
ierr = imoutage(sid, all, motopt, genopt)
```

Fortran command syntax:

```
CALL IMOUTAGE(SID, ALL, MOTOPT, GENOPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only induction machines in subsystem SID ALL = 1 process all induction machines
Integer MOTOPT	"stalled" induction motor option (input; 0 by default). MOTOPT = 0 set to out-of-service MOTOPT = 1 leave in-service
Integer GENOPT	"tripped" induction generator option (input; 0 by default). GENOPT = 0 set to out-of-service GENOPT = 1 leave in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid MOTOPT value IERR = 4 invalid GENOPT value IERR = 5 prerequisite requirements for API are not met

1.1.102. IMPC

Use this API to calculate the impact of transaction events on MW flows using a linear network (dc) model.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_IMPC  EVENT DFXFILE ATCFILE
```

Python command syntax:

```
ierr = impc(event, dfxfile, atcfile)
```

Fortran command syntax:

```
CALL IMPCAPI(EVENT, DFXFILE, ATCFILE, IERR)
```

Where:

Integer EVENT	transaction event number (input; no default allowed).
Character*260 DFXFILE	name of DFAX data file (input; no default allowed).
Character*260 ATCFILE	name of ATC updates file; blank for none (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	no transactions defined
IERR = 2	transaction event not defined
IERR = 3	no name of DFAX data file specified
IERR = 4	error opening ATC updates file
IERR = 5	error opening file DFXFILE
IERR = 6	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 8	no monitored branches or interfaces defined
IERR = 9	prerequisite requirements for API are not met

1.1.103. IMPLEMENT_TRANSFER

This API routine is obsolete. It has been replaced by the API routine [implement_transfer_2](#).

Use this API to apply a specified transfer using the same transfer dispatch methods that are available in the PV analysis calculation engine.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_IMPLEMENT_TRANSFER  OPTIONS(1)..OPTIONS(4)  RVAL  LABELS(1)  LABELS(2)
                        DFXFILE  ECDFILE
```

Python command syntax:

```
ierr = implement_transfer(options, rval, labels, dfxfile, ecdfile)
```

Fortran command syntax:

```
CALL IMPLEMENT_TRANSFER(OPTIONS, RVAL, LABELS, DFXFILE, ECDFILE, IERR)
```

Where:

Integer OPTIONS (4)	array of 4 elements specifying transfer implementation options(input).	
	OPTIONS(1)	study (source) system transfer dispatch method (1 by default)
	OPTIONS(1) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
	OPTIONS(1) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(1) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(1) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(1) = 5	subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(1) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
	OPTIONS(1) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
	OPTIONS(1) = 8	subsystem buses with positive MW machines via ECDI
	OPTIONS(2)	opposing (sink) system transfer dispatch method (1 by default)
	OPTIONS(2) = 1	buses and distribution factors from DFAX file for buses with positive MW machines

	OPTIONS(2) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(2) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(2) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(2) = 5	subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(2) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
	OPTIONS(2) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
	OPTIONS(2) = 8	subsystem buses with positive MW machines via ECDI
	OPTIONS(3)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
	OPTIONS(3) = 0	no limits
	OPTIONS(3) = 1	honor machine active power limits
	OPTIONS(4)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
	OPTIONS(4) = 0	no limits
	OPTIONS(4) = 1	enforce non-negative net active power constant MVA load
Real RVAL	transfer increment in MW (input; no default allowed).	
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which load is to be increased (no default allowed)
Character*260 DFAXFILE	name of the DFAX data file (input; no default allowed).	
Character*260 ECDFILE	name of the Economic Dispatch Data file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid RVAL value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted

IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	no DFAX data file specified
IERR = 6	no economic dispatch data file specified
IERR = 7	no participating dispatch buses in study system
IERR = 8	no participating dispatch buses in opposing system
IERR = 9	subsystem engine error
IERR = 10	unable to implement transfer in study system
IERR = 11	unable to implement transfer in opposing system
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 52	error opening DFAX data file
IERR = 54	prerequisite requirements for API are not met

1.1.104. IMPLEMENT_TRANSFER_2

Use this API routine to apply a specified transfer using the same transfer dispatch methods that are available in the PV analysis calculation engine.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_IMPLEMENT_TRANSFER_2  OPTIONS(1)..OPTIONS(4)  RVAL(1)..RVAL(2)
                           LABELS(1)..LABELS(2) DFXFILE  ECDFILE
```

Python command syntax:

```
ierr = implement_transfer_2(options, rval, labels, dfxfile, ecdfile)
```

Fortran command syntax:

```
CALL IMPLEMENT_TRANSFER_2(OPTIONS, RVAL, LABELS, DFXFILE, ECDFILE, IERR)
```

Where:

Integer OPTIONS (4)	array of elements specifying transfer implementation options (input). The values are as follows:(input).
OPTIONS(1)	study (source) system transfer dispatch method (1 by default)
OPTIONS(1) = 1	buses and distribution factors from DFAX file for buses with positive MW machines.
OPTIONS(1) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(1) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(1) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(1) = 5	subsystem buses with positive MW machines in proportion to their MW output.
OPTIONS(1) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(1) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC).
OPTIONS(1) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(1) = 9	subsystem buses with positive MW machines via ECDI with unit commitment enabled
OPTIONS(2)	opposing (sink) system transfer dispatch method (1 by default)
OPTIONS(2) = 1	buses and distribution factors from DFAX file for buses with positive MW machines.

	OPTIONS(2) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(2) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(2) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(2) = 5	subsystem buses with positive MW machines in proportion to their MW output.
	OPTIONS(2) = 6	subsystem buses with positive MW machines in proportion to their MBASEs.
	OPTIONS(2) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC).
	OPTIONS(2) = 8	subsystem buses with positive MW machines via ECDI. with unit commitment disabled
	OPTIONS(2) = 9	subsystem buses with positive MW machines via ECDI with unit commitment enabled
	OPTIONS(3)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
	OPTIONS(3) = 0	no limits.
	OPTIONS(3) = 1	honor machine active power limits.
	OPTIONS(4)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
	OPTIONS(4) = 0	no limits.
	OPTIONS(4) = 1	enforce non-negative net active power constant MVA load.
Real RVAL (2)	array of elements specifying transfer implementation options. The values are as follows:(input).	
	RVAL(1)	the transfer increment in MW
	RVAL(2)	power factor for load increases in dispatch methods 2, 3 and 4 (0.0 by default). Specify RVAL(2) as < 0.0 to retain the original power factor at each load that is changed.
Character*32 LABELS (2)	array of elements specifying subsystem labels (input). The values are as follows:(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which load is to be decreased
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which load is to be increased
Character*260 DFXFILE	Is the name of the Distribution Factor Data file (input; no default allowed).	

Character* 260 ECDFILE	Is the name of the Economic Dispatch Data file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred.
	IERR = 1	invalid RVAL value.
	IERR = 2	invalid OPTIONS value.
	IERR = 3	generators are converted.
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	no Distribution Factor Data File specified.
	IERR = 6	no Economic Dispatch Data File specified.
	IERR = 7	no participating dispatch buses in study system.
	IERR = 8	no participating dispatch buses in opposing system
	IERR = 9	subsystem engine error.
	IERR = 10	Unable to implement transfer in study system.
	IERR = 11	Unable to implement transfer in opposing system
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 23	no subsystems defined.
	IERR = 24	subsystem not found.
	IERR = 25	specified subsystems overlap.
	IERR = 26	no in-service buses in subsystem WORLD.
	IERR = 50	error opening Economic Dispatch Data File.
	IERR = 52	error opening Distribution Factor Data File.
	IERR = 54	prerequisite requirements for API are not met.

1.1.105. INLF

This API routine is obsolete. It has been replaced by the API routine [inlf_2](#).

Use this API to apply an inertial or governor response power flow calculation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_INLF  OPTIONS(1)..OPTIONS(7)  IFILE
```

Python command syntax:

```
ierr = inlf(options, ifile)
```

Fortran command syntax:

```
CALL INLFAPI(OPTIONS, IFILE, IERR)
```

Where:

Integer OPTIONS (7)	array of 7 elements specifying solution options(input).
OPTIONS(1)	solution type (0 by default)
OPTIONS(1) = 0	inertial
OPTIONS(1) = 1	governor response
OPTIONS(2)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(2) = -1	solution type default (inertial => disable; governor => stepping)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable stepping adjustment
OPTIONS(2) = 2	enable direct adjustment
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = -1	solution type default (inertial => disable; governor => enable)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = -1	solution type default (inertial => disable; governor => enable)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = -1	solution type default (inertial => enable; governor => enable)

	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	generator var limit flag (-1 (inertial) or 99 (governor) by default)
	OPTIONS(6) = 0	apply var limits immediately
	OPTIONS(6) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(6) = -1	ignore var limits
	OPTIONS(7)	missing active power limits flag (only used in governor response power flow) (0 by default)
	OPTIONS(7) = 0	pre-PSSE-29 approach (0.0 to 1.0 pu for machines with no Unit Inertia and Governor Data File record read; working case values for machines with PMAX defaulted on ECDI data record)
	OPTIONS(7) = 1	0.0 to 1.0 pu for both categories of machines
	OPTIONS(7) = 2	working case values for both categories of machines
Character*260 IFILE	name of unit inertia and governor data file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	bus type code and series element status inconsistencies
	IERR = 4	error opening IFILE
	IERR = 5	prerequisite requirements for API are not met

1.1.106. INLF_2

Use this API routine to run the second release of the inertial and governor response power flow calculation.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_INLF_2  OPTIONS(1)..OPTIONS(8)  IFILE
```

Python command syntax:

```
ierr = inlf_2(options, ifile)
```

Fortran command syntax:

```
CALL INLF_2(OPTIONS, IFILE, IERR)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying solution options(input).
OPTIONS(1)	solution type (0 by default)
OPTIONS(1) = 0	inertial
OPTIONS(1) = 1	governor response
OPTIONS(2)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(2) = -1	solution type default (inertial => disable; governor => stepping)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable stepping adjustment
OPTIONS(2) = 2	enable direct adjustment
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = -1	solution type default (inertial => disable; governor => enable)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = -1	solution type default (inertial => disable; governor => enable)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = -1	solution type default (inertial => enable; governor => enable)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable

	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	generator var limit flag (-1 (inertial) or 99 (governor) by default)
	OPTIONS(6) = 0	apply var limits immediately
	OPTIONS(6) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(6) = -1	ignore var limits
	OPTIONS(7)	induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
	OPTIONS(7) = 0	stall
	OPTIONS(7) = 1	trip
	OPTIONS(8)	missing active power limits flag (only used in governor response power flow) (0 by default)
	OPTIONS(8) = 0	pre-PSSE-29 approach (0.0 to 1.0 pu for machines with no Unit Inertia and Governor Data File record read; working case values for machines with PMAX defaulted on ECDI data record)
	OPTIONS(8) = 1	0.0 to 1.0 pu for both categories of machines
	OPTIONS(8) = 2	working case values for both categories of machines
Character*260 IFILE	name of unit inertia and governor data file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	bus type code and series element status inconsistencies
	IERR = 4	error opening IFILE
	IERR = 5	prerequisite requirements for API are not met

1.1.107. INTA

Use this API to summarize tie flows between an interchange area and all other areas in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_INTA SID ALL
```

Python command syntax:

```
ierr = inta(sid, all)
```

Fortran command syntax:

```
CALL INTANW(SID, ALL, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only areas in area subsystem SID
	ALL = 1	process all areas
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.108. INTZ

Use this API to summarize tie flows between each zone and all other zones in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_INTZ  SID  ALL
```

Python command syntax:

```
ierr = intz(sid, all)
```

Fortran command syntax:

```
CALL INTZNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Zone subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all zones or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only zones in zone subsystem SID
Integer IERR	ALL = 1	process all zones
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.109. ISOLATE_LEVELS

Use this API to specify or return the maximum number of levels to go outward when isolating an element by breaker.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATE_LEVELS IVAL IOCODE
```

Python command syntax:

```
ierr = isolate_levels(ival, iocode)
```

Fortran command syntax:

```
CALL ISOLATE_LEVELS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 4 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.110. JOIN

The API combines two buses into a single bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_JOIN  IBUS  JBUS  STATUS
```

Python command syntax:

```
ierr = join(ibus, jbus, status)
ierr, idtrns = join(ibus, jbus, status, nid)
```

Fortran command syntax:

```
CALL JOINAPI(IBUS, JBUS, STATUS, NID, IDTRNS, IERR)
```

Where:

Integer IBUS	retained bus number (input).
Integer JBUS	eliminated bus number (input).
Integer STATUS	line shunt option (input; 1 by default). STATUS = 0 ignore line shunts of deleted branches STATUS = 1 add line shunts of deleted branches to shunt of retained bus
Integer NID	number of elements in the IDTRNS array; 0 to suppress setting IDTRNS; 0 by default
Character*18 IDTRNS (NID)	returned as the ID translation originally connected to bus JBUS. IDTRNS contents: Columns Content 1-2 LD for load. BR for non-trans- former branch. IM for induction machine MC for machine. SH for fixed bus shunt T2 for two-winding transformer. T3 for three-wind- ing transformer. 3-8 For BR and T2 records, bus number at the oth- er end of the branch. For T3 records, bus number of one of the other buses connected by the transformer. 9-14 For T3 records, bus num- ber of the other bus connected by the transformer. 15-16 Old identi- fier. 17-18 New identifier (output).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid STATUS value IERR = 2 bus not found IERR = 3 invalid NID value IERR = 4 IDTRNS is not big enough IERR = 5 JOIN processing error IERR = 6 bus is part of a substation IERR = 7 prerequisite requirements for API are not met

1.1.111. LAMP

Use this API to print power flow solution output, including loadings in amps, in a traditional power flow report format. Bus related information is on the left side of the report and branch related information on the right side.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LAMP SID ALL
```

Python command syntax:

```
ierr = lamp(sid, all)
```

Fortran command syntax:

```
CALL LAMPNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.112. LINES_PER_PAGE

Use this API to specify or return the page length limits for the four output devices; also retrieve device names.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_LINES_PER_PAGE IVAL(1) IVAL(2) IVAL(3) IVAL(4)
```

Python command syntax:

```
ierr = lines_per_page(ival)
ierr, ival, devnam = lines_per_page()
```

Fortran command syntax:

```
CALL LINES_PER_PAGE_API(IVAL, DEVNAM, IOCODE, IERR)
```

Where:

Integer IVAL (4)	array of 4 elements specifying the page length limits(input).
IVAL(1)	lines per page for disk files (no change by default)
IVAL(2)	lines per page for the report window (no change by default)
IVAL(3)	lines per page for the first primary hard copy device (no change by default)
IVAL(4)	lines per page for the second primary hard copy device (no change by default)
Character*40 DEVNAM (4)	array of 4 elements specifying the four devices (when IVAL is output)(output).
DEVNAM(1)	'FILE'
DEVNAM(2)	'REPORT WINDOW'
DEVNAM(3)	name of first primary hard copy device
DEVNAM(4)	name of second primary hard copy device
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
IOCODE = 0	set the option settings to the values specified in IVAL.
IOCODE = 1	return the current values of the option settings in IVAL.
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	negative IVAL value
IERR = 2	invalid IOCODE value
IERR = 3	prerequisite requirements for API are not met

1.1.113. LINES_PER_PAGE_ONE_DEVICE

Use this API to specify or return the page length limit and device name for one of the four output devices.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_LINES_PER_PAGE_ONE_DEVICE  DEVICE  IVAL
```

Python command syntax:

```
ierr = lines_per_page_one_device(device, ival)

ierr, ival, devnam = lines_per_page_one_device(device)
```

Fortran command syntax:

```
CALL LINES_PER_PAGE_ONE_DEVICE_API(DEVICE, IVAL, DEVNAM, IOCODE, IERR)
```

Where:

Integer DEVICE	Indicates which of the four devices is to be processed (input; no default allowed).
	DEVICE = 1 for disk files.
	DEVICE = 2 for the report window.
	DEVICE = 3 for the first primary hard copy output device.
	DEVICE = 4 for the second primary hard copy output device.
Integer IVAL	value of the lines per page option setting of the device corresponding to DEVICE (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, no change by default; else output).
Character*40 DEVNAM	returned as the device name of the device corresponding to DEVICE (when IVAL is output) (output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 negative IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 invalid DEVICE value
	IERR = 4 prerequisite requirements for API are not met

1.1.114. LINE_SHUNT_REPORTING

Use this API to specify or return the option to enable or disable the line shunt reporting.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_LINE_SHUNT_REPORTING IVAL
```

Python command syntax:

```
ierr = line_shunt_reporting(ival)
ierr, ival = line_shunt_reporting()
```

Fortran command syntax:

```
CALL LINE_SHUNT_REPORTING_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = 0	no special reporting of line shunts in POUT, LOUT and LAMP.
	IVAL = 1	include special reporting of line shunts in POUT, LOUT and LAMP.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.115. LIST

Use this API routine to tabulate the power flow working case in a form suitable for problem data documentation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LIST SID ALL OPT VREV
```

Python command syntax:

```
ierr = list(sid, all, opt, vrev)
```

Fortran command syntax:

```
CALL LISTNW(SID, ALL, OPT, VREV, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer OPT	power flow data category to be tabulated (input; 1 by default). OPT = 1 case summary OPT = 2 bus data OPT = 3 switched shunt data OPT = 4 plant data OPT = 5 generator unit data OPT = 6 branch data (single entry) OPT = 7 branch data (double entry) OPT = 8 two-winding transformer impedance data OPT = 9 line shunt data OPT = 10 dc line data OPT = 11 area interchange data OPT = 12 full listing (single entry) OPT = 13 full listing (double entry) OPT = 14 impedance table correction data OPT = 15 multi-section line data OPT = 16 zone data OPT = 17 inter-area transfer data OPT = 18 load data OPT = 19 owner data OPT = 20 FACTS device sending end data

	OPT = 21	two-winding transformer winding data
	OPT = 22	three-winding transformer impedance data
	OPT = 23	three-winding transformer winding data
	OPT = 24	three-winding transformer control data
	OPT = 25	three-winding transformer general data
	OPT = 26	two-winding transformer control data
	OPT = 27	FACTS device terminal end data
	OPT = 28	fixed bus shunt data
	OPT = 29	GNE device data
	OPT = 30	induction machine circuit data
	OPT = 31	induction machine miscellaneous data
	OPT = 32	capability curve data
Integer VREV	units used for displaying voltages (input; 0 by default).	
	VREV = 0	use default voltage units
	VREV = 1	use alternate voltage units
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 4	invalid VREV value
	IERR = 5	prerequisite requirements for API are not met

1.1.116. LISTCONTINGENCYSAVEDCASES

Use this API routine to obtain a report listing some or all of the system conditions preserved in a ZIP Archive Output File that was created during a previous run of one of the members of the the AC contingency calculation family.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_LISTCONTINGENCYSAVEDCASES  PATHZIP LABEL
```

Python command syntax:

```
ierr = listcontingencysavedcases(pathzip, label)
```

Fortran command syntax:

```
CALL LISTCONTINGENCYSAVEDCASES(PATHZIP, LABEL, IERR)
```

Where:

Character*260 PATHZIP	Is the name of the ZIP Archive Output File (input; no default allowed).
Character*32 LABEL	Is a label indicating the system condition(s) that are to be tabulated. blank: list all system conditions. contingency label: list all system conditions for the specified contingency label. Base Case: list all system conditions for the base case; use only for ZIP Archive Output Files written by the P-V and Q-V analysis functions. (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred.
	IERR = 1 error opening the file Names.phy in the ZIP Archive Output File.
	IERR = 2 error reading the file Names.phy in the ZIP Archive Output File.
	IERR = 3 error closing the file Names.phy in the ZIP Archive Output File.
	IERR = 4 internal error.
	IERR = 5 internal error.
	IERR = 6 prerequisite requirements for API are not met.

1.1.117. LLRF

Use this API to apply the line loading relief calculation using a linear network (dc) model. It must first be called once with APIOPT set to 1, then once for each priority level for which the adjustment method is to be changed with APIOPT set to 2, and finally once with APIOPT set to 3.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_LLRF  APIOPT  OPTIONS(1)  OPTIONS(2)  RVAL  DFXFILE
```

Python command syntax:

```
ierr = llrf(apiopt, options, rval, dfxfile)
```

Fortran command syntax:

```
CALL LLRFAP1(APIOPT, OPTIONS, RVAL, DFXFILE, IERR)
```

Where:

Integer APIOPT	mode of operation (input).
APIOPT = 1	initialize
APIOPT = 2	specify a priority level and the adjustment method to be applied; must be called once for each priority level, adjustment method pair to be specified
APIOPT = 3	specify a line loading relief function, apply the required calculations, report results, and terminate
Integer OPTIONS (2)	array of 2 elements specifying options and values to be used in the current calculation phase of LLRFAP1; ignored when APIOPT is 1. When APIOPT is 2, the elements of OPTIONS define a priority level and the adjustment method to be used in curtailing or restoring transactions. When APIOPT is 3, the first element of OPTIONS defines the line loading relief function to be applied. For the curtail transactions and restore transactions functions, the second element of OPTIONS defines the monitored element to be used as the transaction adjustment target(input).
OPTIONS(1)	When APIOPT is 2, priority level When APIOPT is 3 (no default allowed)
OPTIONS(1) = 0	curtail transactions
OPTIONS(1) = 1	restore transactions
OPTIONS(1) = 2	report distribution factor matrix
OPTIONS(2)	When APIOPT is 3, monitored element list index (1 by default when OPTIONS(1) is 0 or 1).. When APIOPT is 2)
OPTIONS(2) = 0	first in, last out (FILO)
OPTIONS(2) = 1	decreasing order of distribution factor magnitude (DF-ORDER)

	OPTIONS(2) = 2	distribution factor pro rata (DF-PRO RATA)
	OPTIONS(2) = 3	pro rata based on the product of distribution factor and transaction schedule (DF-SCHED-PRO RATA)
Real RVAL	used in the current calculation phase of LLRFAP; ignored when APIOPT is 2. When APIOPT is 1, RVAL is the distribution factor tolerance used to preclude those transactions with negligible effect on the target monitored element from the transaction adjustment functions (input; 0.05 by default). When APIOPT is 3, RVAL is the target element adjustment MW (10.0 by default).	
Character*260 DFXFILE	name of DFAX data file when APIOPT is 1 (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no transactions defined
	IERR = 2	no DFAX data file specified
	IERR = 3	invalid OPTIONS value
	IERR = 4	invalid RVAL value
	IERR = 5	unexpected APIOPT value
	IERR = 6	invalid APIOPT value
	IERR = 7	error opening file DFXFILE
	IERR = 8	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 10	no monitored branches or interfaces defined
	IERR = 11	prerequisite requirements for API are not met

1.1.118. LOAD_REDUCTION

Use this API to tabulate the amount of load reduction in a specified subsystem due to the voltage at the bus to which the load is connected being below PQBRAK (for constant MVA load) or 0.5 (for constant current load).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_LOAD_REDUCTION SID ALL AOZOPT
```

Python command syntax:

```
ierr = load_reduction(sid, all, aozopt)
```

Fortran command syntax:

```
CALL LOAD_REDUCTION(SID, ALL, AOZOPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only loads in subsystem SID
	ALL = 1	process all loads
Integer AOZOPT	subsystem selection option when area, owner and/or zone are included in the subsystem selection criteria (input; 1 by default).	
	AOZOPT = 1	use the area, owner and/or zone assignments of the bus to which the load is connected
	AOZOPT = 2	use the area, owner and/or zone assignments of the load
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid AOZOPT value
	IERR = 4	prerequisite requirements for API are not met

1.1.119. LOUT

Use this API to print the power flow solution results in a traditional power flow report format. Bus related information is on the left side of the report and branch related information on the right side.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LOUT  SID  ALL
```

Python command syntax:

```
ierr = lout(sid, all)
```

Fortran command syntax:

```
CALL LOUTNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.120. LTAP

Use this API to insert a bus at a designated location along a line.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LTAP FRMBUS TOBUS 'CKT' FRACTION NEWNUM 'NEWNAM' NEWKV
```

Python command syntax:

```
ierr = ltap(frmbus, tobus, ckt, fraction, newnum, newnam, newkv)
```

Fortran command syntax:

```
CALL LTAPAPI(FRMBUS, TOBUS, CKT, FRACTION, NEWNUM, NEWNAM, NEWKV, IERR)
```

Where:

Integer FRMBUS	one of the buses connected by the branch to be tapped (input; no default allowed).
Integer TOBUS	other bus connected by the branch to be tapped (input; no default allowed).
Character*2 CKT	circuit identifier of the branch to be tapped (input; '1' by default).
Real FRACTION	new bus location relative to bus FRMBUS in per unit of total line length (input; 0.5).
Integer NEWNUM	number to be assigned to the new bus (input; no default allowed).
Character*12 NEWNAM	name to be assigned to the new bus (input; blank by default).
Real NEWKV	base voltage to be assigned to the new bus (input; base voltage of bus FRMBUS).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 branch not found
	IERR = 3 branch is a transformer
	IERR = 4 invalid FRACTION value
	IERR = 5 invalid NEWNUM value
	IERR = 6 bus number is already assigned to another bus
	IERR = 7 invalid NEWKV value
	IERR = 8 bus, branch, or branch ownership tables full
	IERR = 9 prerequisite requirements for API are not met

1.1.121. MACCC

This API routine is obsolete. It has been replaced by the API routine [maccc_2](#).

Use this API to run multiple level contingency analysis. User-specified and automatically-selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MACCC  TOL  OPTACC(1)..OPTACC(8)  OPTMAC(1)..OPTMAC(41)
            OPTRNK(1)..OPTRNK(17)  VALUES(1)..VALUES(3)  LABELS(1)  LABELS(2)  DFXFILE
            ACCFILE  THRFILE  INLFILE
```

Python command syntax:

```
ierr = maccc(tol, optacc, optmac, optrnk, values, labels, dfxfile,
            accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCCAPI(TOL, OPTACC, OPTMAC, OPTRNK, VALUES, LABELS, DFXFILE,
            ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable
	OPTACC(4) = 1 enable

	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1<=OPTMAC(2)<=3; 1 by default)
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations, otherwise
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable

OPTRNK(2)	contingency rating (rating set program option setting by default)
OPTRNK(2) = 1	rate A
OPTRNK(2) = 2	rate B
OPTRNK(2) = 3	rate C
OPTRNK(3)	convert ratings to MW (0 by default)
OPTRNK(3) = 0	disable
OPTRNK(3) = 1	enable
OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
OPTRNK(4) = 0	disable
OPTRNK(4) = 1	enable
OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
OPTRNK(8) = 0	disable
OPTRNK(8) = 1	enable
OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
OPTRNK(12) = 0	disable
OPTRNK(12) = 1	enable
OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
OPTRNK(16) = 0	include only with non-zero rating

	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Real VALUES (3)	array of 3 elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating set ($0 \leq \text{VALUES}(1) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies ($\text{VALUES}(3) \geq 0.0$; 0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTMAC value
	IERR = 9	invalid OPTRNK value
	IERR = 10	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 50	error opening Unit Inertia and Governor Data File

IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.122. MACCC_2

Use this API to run the second release of multiple level contingency analysis. User-specified and automatically-selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MACCC_2  TOL  OPTACC(1)..OPTACC(10)  OPTMAC(1)..OPTMAC(41)
              OPTRNK(1)..OPTRNK(17)  VALUES(1)..VALUES(3)  LABELS(1)  LABELS(2)  DFXFILE
              ACCFILE  THRFILE  INLFILE
```

Python command syntax:

```
ierr = maccc_2(tol, optacc, optmac, optrnk, values, labels, dfxfile,
               accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCCAPI_2(TOL, OPTACC, OPTMAC, OPTRNK, VALUES, LABELS, DFXFILE,
               ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable
	OPTACC(4) = 1 enable
	OPTACC(5) switched shunt adjustment flag (switched shunt adjustment option setting by default)

	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels)
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis

	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(2) = -3	N-3 contingency analysis
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations, otherwise
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	contingency rating (rating set program option setting by default)
	OPTRNK(2) = 1	rate A
	OPTRNK(2) = 2	rate B
	OPTRNK(2) = 3	rate C
	OPTRNK(3)	convert ratings to MW (0 by default)
	OPTRNK(3) = 0	disable
	OPTRNK(3) = 1	enable
	OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(4) = 0	disable
	OPTRNK(4) = 1	enable
	OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(8) = 0	disable
	OPTRNK(8) = 1	enable
	OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)

	OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(12) = 0	disable
	OPTRNK(12) = 1	enable
	OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Real VALUES (3)	array of 3 elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating set ($0 \leq \text{VALUES}(1) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (≥ 0.0 ; 0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	

Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid TOL value
IERR = 2	invalid OPTACC value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	invalid OPTMAC value
IERR = 11	invalid OPTRNK value
IERR = 12	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.123. MACCC_3

Use this API to run the third release of multiple level contingency analysis. User-specified and automatically-selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MACCC_2  TOL  OPTACC(1)..OPTACC(10)  OPTMAC(1)..OPTMAC(41)
              OPTRNK(1)..OPTRNK(17)  VALUES(1)..VALUES(2)  LABELS(1)  LABELS(2)  DFXFILE
              ACCFILE  THRFILE  INLFILE
```

Python command syntax:

```
ierr = maccc_3(tol, optacc, optmac, optrnk, values, labels, dfxfile,
               accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCCAPI_3(TOL, OPTACC, OPTMAC, OPTRNK, VALUES, LABELS, DFXFILE,
               ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable
	OPTACC(4) = 1 enable
	OPTACC(5) switched shunt adjustment flag (switched shunt adjustment option setting by default)

	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels)
	OPTMAC(2) = -3	N-3 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 1	N-1 contingency analysis

	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	Each element from 3 to 41 of OPTMAC array represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit (machine) and single branch outages respectively
	OPTMAC(3) = 0	(0 by default)
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (15)	array of 15 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(2) = 0	disable
	OPTRNK(2) = 1	enable
	OPTRNK(3)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(4)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(5)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(6)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(6) = 0	disable
	OPTRNK(6) = 1	enable
	OPTRNK(7)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(8)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(9)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(10)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(10) = 0	disable
	OPTRNK(10) = 1	enable

	OPTRNK(11)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(12)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(13)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(14)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(14) = 0	include only with non-zero rating
	OPTRNK(14) = 1	all
	OPTRNK(15)	include contingencies that create swingless island (0 by default)
	OPTRNK(15) = 0	disable
	OPTRNK(15) = 1	enable
Real VALUES (2)	array of 2 elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	MW threshold for islanding contingencies (≥ 0.0 ; 0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined

IERR = 7	too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	invalid OPTMAC value
IERR = 11	invalid OPTRNK value
IERR = 12	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.124. MACCC_PARALLEL

Use this API to run the multiple level contingency analysis in parallel when the number of contingency processors in Program Settings is greater than 1. User-specified and automatically selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 33.3.0.

Batch command syntax:

```
BAT_MACCC_PARALLEL  TOL OPTACC(1)..OPTACC(10) OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) VALUES(1)..VALUES(3) LABELS(1)..LABELS(2) DFXFILE
  ACCFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = maccc_parallel(tol, optacc, optmac, optrnk, values, labels,
  dfxfile, accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCC_PARALLEL(TOL, OPTACC, OPTMAC, OPTRNK, VALUES, LABELS, DFXFILE,
  ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	Is the mismatch tolerance (input; Newton solution convergence tolerance, TOLN, by default).
Integer OPTACC (10)	array of elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable.
	OPTACC(1) = 1 enable stepping adjustment.
	OPTACC(1) = 2 enable direct adjustment.
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable.
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange.
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange.
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable.
	OPTACC(3) = 1 enable.
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable.
	OPTACC(4) = 1 enable.

OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTACC(5) = 0	disable.
OPTACC(5) = 1	enable.
OPTACC(5) = 2	enable continuous mode, disable discrete mode.
OPTACC(6)	solution method flag (0 by default)
OPTACC(6) = 0	FDNS.
OPTACC(6) = 1	FNSL.
OPTACC(6) = 2	optimized FDNS.
OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
OPTACC(7) = 0	disable.
OPTACC(7) = 1	enable.
OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default) (applied when an induction motor fails to solve due to low by default)
OPTACC(8) = 0	stall.
OPTACC(8) = 1	trip.
OPTACC(9)	induction machine failure flag (0 by default)
OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state.
OPTACC(10)	dispatch mode (0 by default)
OPTACC(10) = 0	disable.
OPTACC(10) = 1	subsystem machines (reserve).
OPTACC(10) = 2	subsystem machines (pmax).
OPTACC(10) = 3	subsystem machines (inertia).
OPTACC(10) = 4	subsystem machines (governor droop).
Integer OPTMAC (41)	array of elements specifying contingency evaluation level and combinations (input). The values are as follows:(input).
OPTMAC(1)	run multiple contingency analysis (1 by default)
OPTMAC(1) = 0	disable.
OPTMAC(1) = 1	enable.
OPTMAC(2)	contingency evaluation level.
OPTMAC(2) = -3	N-3 contingency analysis
OPTMAC(2) = -2	N-2 contingency analysis
OPTMAC(2) = 1	N-1 contingency analysis

	OPTMAC(3)	each element represents a type of contingency combinations in the following order. (0 by default)
	OPTMAC(3) = 0	do not include the contingency combination
	OPTMAC(3) = 1	include the "S" contingency combination. This and the remaining elements of the array (i.e. 3-41) individually indicate whether particular contingency combinations are to be included. In the following S, U and B refer to user specified cases, single machine and single branch outages, respectively: {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}
Integer OPTRNK (17)	array of elements specifying ranking options. The values are as follows:(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable.
	OPTRNK(1) = 1	enable.
	OPTRNK(2)	contingency rating (rating set program option setting by default)
	OPTRNK(2) = 1	rate A.
	OPTRNK(2) = 2	rate B.
	OPTRNK(2) = 3	rate C.
	OPTRNK(3)	convert ratings to MW (0 by default)
	OPTRNK(3) = 0	disable.
	OPTRNK(3) = 1	enable.
	OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(4) = 0	disable.
	OPTRNK(4) = 1	enable.
	OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(8) = 0	disable.
	OPTRNK(8) = 1	enable.
	OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)

	OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(12) = 0	disable.
	OPTRNK(12) = 1	enable.
	OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating.
	OPTRNK(16) = 1	all.
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable.
	OPTRNK(17) = 1	enable.
Real VALUES (3)	array of elements specifying ranking parameters. The values are as follows: (input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default).
	VALUES(2)	percent of rating set ($0 \leq \text{VALUES}(2) \leq 200.0$; 100.0 by default).
	VALUES(3)	MW threshold for islanding contingencies (≥ 0.0 ; 0.0 by default).
Character*32 LABELS (2)	array of elements specifying subsystem labels. The values are as follows: (input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0).
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	Is the name of the Contingency Solution Output File (input; no default allowed).	

Character*260 THRFILE	Is the name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	Is the name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred.
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted.
	IERR = 4	buses in island(s) without a swing bus; use activity TREE.
	IERR = 5	largest mismatch exceeds mismatch tolerance.
	IERR = 6	generation subsystem is not defined.
	IERR = 7	too many islands in base case.
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value.
	IERR = 11	invalid OPTRNK value.
	IERR = 12	invalid VALUES value.
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for API are not met

1.1.125. MACCC_PARALLEL_2

Use this API to run the multiple level contingency analysis in parallel when the number of contingency processors in Program Settings is greater than 1. User-specified and automatically selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MACCC_PARALLEL_2  TOL OPTACC(1)..OPTACC(10) OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) VALUES(1)..VALUES(3) LABELS(1)..LABELS(2) DFXFILE
  ACCFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = maccc_parallel_2(tol, optacc, optmac, optrnk, values, labels,
  dfxfile, accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCC_PARALLEL_2(TOL, OPTACC, OPTMAC, OPTRNK, VALUES, LABELS,
  DFXFILE, ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	Is the mismatch tolerance (input; Newton solution convergence tolerance, TOLN, by default).
Integer OPTACC (10)	array of elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable.
	OPTACC(1) = 1 enable stepping adjustment.
	OPTACC(1) = 2 enable direct adjustment.
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable.
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange.
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange.
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable.
	OPTACC(3) = 1 enable.
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0 disable.
	OPTACC(4) = 1 enable.

OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTACC(5) = 0	disable.
OPTACC(5) = 1	enable.
OPTACC(5) = 2	enable continuous mode, disable discrete mode.
OPTACC(6)	solution method flag (0 by default)
OPTACC(6) = 0	FDNS.
OPTACC(6) = 1	FNSL.
OPTACC(6) = 2	optimized FDNS.
OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
OPTACC(7) = 0	disable.
OPTACC(7) = 1	enable.
OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default) (applied when an induction motor fails to solve due to low by default)
OPTACC(8) = 0	stall.
OPTACC(8) = 1	trip.
OPTACC(9)	induction machine failure flag (0 by default)
OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state.
OPTACC(10)	dispatch mode (0 by default)
OPTACC(10) = 0	disable.
OPTACC(10) = 1	subsystem machines (reserve).
OPTACC(10) = 2	subsystem machines (pmax).
OPTACC(10) = 3	subsystem machines (inertia).
OPTACC(10) = 4	subsystem machines (governor droop).
Integer OPTMAC (41)	array of elements specifying contingency evaluation level and combinations (input). The values are as follows:(input).
OPTMAC(1)	run multiple contingency analysis (1 by default)
OPTMAC(1) = 0	disable.
OPTMAC(1) = 1	enable.
OPTMAC(2)	contingency evaluation level.
OPTMAC(2) = -3	N-3 contingency analysis
OPTMAC(2) = -2	N-2 contingency analysis
OPTMAC(2) = 1	N-1 contingency analysis

	OPTMAC(3)	Each element from 3 to 41 of OPTMAC array represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit (machine) and single branch outages respectively
	OPTMAC(3) = 0	(0 by default)
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (15)		array of elements specifying ranking options. The values are as follows:(input).
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable.
	OPTRNK(1) = 1	enable.
	OPTRNK(2)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(2) = 0	disable.
	OPTRNK(2) = 1	enable.
	OPTRNK(3)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(4)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(5)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(6)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(6) = 0	disable.
	OPTRNK(6) = 1	enable.
	OPTRNK(7)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(8)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(9)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(10)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(10) = 0	disable.
	OPTRNK(10) = 1	enable.

	OPTRNK(11)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(12)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(13)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(14)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(14) = 0	include only with non-zero rating.
	OPTRNK(14) = 1	all.
	OPTRNK(15)	include contingencies that create swingless island (0 by default)
	OPTRNK(15) = 0	disable.
	OPTRNK(15) = 1	enable.
Real VALUES (2)	array of elements specifying ranking parameters. The values are as follows: (input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default).
	VALUES(2)	MW threshold for islanding contingencies (≥ 0.0 ; 0.0 by default).
Character*32 LABELS (2)	array of elements specifying subsystem labels. The values are as follows: (input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0).
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	Is the name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	Is the name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	Is the name of the Unit Inertia and Governor Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred.
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted.
	IERR = 4	buses in island(s) without a swing bus; use activity TREE.

IERR = 5	largest mismatch exceeds mismatch tolerance.
IERR = 6	generation subsystem is not defined.
IERR = 7	too many islands in base case.
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	invalid OPTMAC value.
IERR = 11	invalid OPTRNK value.
IERR = 12	invalid VALUES value.
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for API are not met

1.1.126. MACCC_TRIP_COR

This API routine is obsolete. It has been replaced by the API routine [maccc_trip_cor_2](#).

Use this API to run multiple AC contingency analysis with tripping simulations and corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination with each other as overlapping contingencies. When there are violations in post-tripping simulation solutions, the corrective actions analysis will be launched to eliminate the violations, with the objective of minimizing the controls adjustments, including load shedding, MW generation dispatch and phase shifter angle adjustments.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_MACCC_TRIP_COR  TOL  OPTACC(1)..OPTACC(8)  OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17)  OPTTRP(1)..OPTTRP(3)  OPTCOR(1)..OPTCOR(5)
  VALUES(1)..VALUES(8)  LABELS(1)..LABELS(5)  DFXFILE  ACCFILE  THRFILE
  INLFILE  TRPFILE
```

Python command syntax:

```
ierr = maccc_trip_cor(tol, optacc, optmac, optrnk, opttrp, optcor, values,
  labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_TRIP_COR(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable

	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)		array of 41 elements specifying contingency evaluation level and combinations(input).
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1<=OPTMAC(2)<=3; 1 by default)
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations, otherwise
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)		array of 17 elements specifying ranking options(input).

OPTRNK(1)	include ties from contingency subsystem (0 by default)
OPTRNK(1) = 0	disable
OPTRNK(1) = 1	enable
OPTRNK(2)	contingency rating (rating set program option setting by default)
OPTRNK(2) = 1	rate A
OPTRNK(2) = 2	rate B
OPTRNK(2) = 3	rate C
OPTRNK(3)	convert ratings to MW (0 by default)
OPTRNK(3) = 0	disable
OPTRNK(3) = 1	enable
OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
OPTRNK(4) = 0	disable
OPTRNK(4) = 1	enable
OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
OPTRNK(8) = 0	disable
OPTRNK(8) = 1	enable
OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
OPTRNK(12) = 0	disable
OPTRNK(12) = 1	enable
OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)

	OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (5)	array of 5 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective actions (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flow solutions (from 0 to 10; 1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
Real VALUES (8)	array of 8 elements specifying ranking and corrective action parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating ($0 \leq \text{VALUES}(1) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (≥ 0.0 ; 0.0 by default)
	VALUES(4)	bus voltage violation tolerance (0.1 by default)

	VALUES(5)	branch flow overload tolerance (0.1 by default)
	VALUES(6)	generator control weighting factor (1.0 by default)
	VALUES(7)	load control weighting factor (1.0 by default)
	VALUES(8)	phase shifter control weighting factor (1.0 by default)
Character*32 LABELS (5)	array of 5 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
	LABELS(3)	label of generator control subsystem (blank by default; no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default; no default allowed if OPTCOR(4) is 1)
	LABELS(5)	label of phase shifter control subsystem (blank by default; no default allowed if OPTCOR(5) is 1)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTMAC value
	IERR = 9	invalid OPTRNK value
	IERR = 10	invalid OPTTRP value
	IERR = 11	invalid OPTCOR value

IERR = 12	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 49	error opening Tripping Element Data File
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for API are not met

1.1.127. MACCC_TRIP_COR_2

This API routine is obsolete. It has been replaced by the API routine [maccc_trip_cor_3](#).

This API is the second release of function to run multiple AC contingency analysis with tripping simulations and corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination each other as overlapping contingencies. Following a post contingency solution, trip events are simulated if their tripping conditions are satisfied. Corrective actions are then specified automatically to eliminate the violations in each post tripping solution with the objective of minimizing the control adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_MACCC_TRIP_COR_2  TOL  OPTACC(1)..OPTACC(8) OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) OPTTRP(1)..OPTTRP(3) OPTCOR(1)..OPTCOR(8)
  VALUES(1)..VALUES(11) LABELS(1)..LABELS(8) DFXFILE ACCFILE THRFILE
  INLFILE TRPFILE
```

Python command syntax:

```
ierr = maccc_trip_cor_2(tol, optacc, optmac, optrnk, opttrp, optcor,
  values, labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_TRIP_COR_2(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable

	OPTACC(3) = 1	enable
	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (RESERVE)
	OPTACC(8) = 2	subsystem machines (PMAX)
	OPTACC(8) = 3	subsystem machines (INERTIA)
	OPTACC(8) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	allow multiple contingency analysis (0 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(1) = 2	enabled with failure cutoff disabled
	OPTMAC(2)	contingency evaluation level (1 by default)
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations

	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	contingency rating (rating set program option setting by default)
	OPTRNK(2) = 1	rate A
	OPTRNK(2) = 2	rate B
	OPTRNK(2) = 3	rate C
	OPTRNK(3)	convert ratings to MW (0 by default)
	OPTRNK(3) = 0	disable
	OPTRNK(3) = 1	enable
	OPTRNK(4)	machine overload contingencies (0 by default)
	OPTRNK(4) = 0	disable
	OPTRNK(4) = 1	enable
	OPTRNK(5)	minimum of machine overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(6)	maximum of machine overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(7)	cutoff of machine overload contingencies to evaluate (≥ 0 , 5 by default)
	OPTRNK(8)	line overload contingencies (0 by default)
	OPTRNK(8) = 0	disable
	OPTRNK(8) = 1	enable
	OPTRNK(9)	minimum of line overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(10)	maximum of line overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(11)	cutoff of line overload contingencies (≥ 0 , 5 by default)
	OPTRNK(12)	voltage collapse line contingencies (0 by default)
	OPTRNK(12) = 0	disable
	OPTRNK(12) = 1	enable
	OPTRNK(13)	minimum of voltage collapse line contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(14)	maximum of voltage collapse line contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(15)	cutoff of voltage collapse line contingencies (≥ 0 , 5 by default)
	OPTRNK(16)	include all branches in voltage collapse ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating

	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (11)	array of 11 elements specifying ranking parameters and corrective actions parameters(input).	
	VALUES(1)	small reactance threshold, (0<= VALUES (1)<=0.005, 0.0005 by default)
	VALUES(2)	percent of flow rating, (0<= VALUES (2)<=200.0, 100.0 by default)

	VALUES(3)	MW threshold for islanding contingencies (≥ 0 , 0.0 by default)
	VALUES(4)	bus voltage violation tolerance (0.1 by default)
	VALUES(5)	branch overload violation tolerance (0.1 by default)
	VALUES(6)	generator control weighting factor (1.0 by default)
	VALUES(7)	load control weighting factor (1.0 by default)
	VALUES(8)	phase shifter control weighting factor (1.0 by default)
	VALUES(9)	off-line generator control weighting factor (1.0 by default)
	VALUES(10)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(11)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
	LABELS(3)	label of generator control subsystem (blank by default for none, no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(5)	label of phase shifter control subsystem (blank by default for none, no default allowed if OPTCOR(5) is 1)
	LABELS(6)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(7)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(8)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank for none).	

Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTMAC value
	IERR = 9	invalid OPTRNK value
	IERR = 10	invalid OPTTRP value
	IERR = 11	invalid OPTCOR value
	IERR = 12	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.128. MACCC_TRIP_COR_3

This API is the third release of function to run multiple AC contingency analysis with tripping simulations and corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination each other as overlapping contingencies. Following a post contingency solution, trip events are simulated if their tripping conditions are satisfied. Corrective actions are then specified automatically to eliminate the violations in each post tripping solution with the objective of minimizing the control adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MACCC_TRIP_COR_3  TOL  OPTACC(1)..OPTACC(10) OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) OPTTRP(1)..OPTTRP(3) OPTCOR(1)..OPTCOR(8)
  VALUES(1)..VALUES(11) LABELS(1)..LABELS(8) DFXFILE ACCFILE THRFILE
  INLFILE TRPFILE
```

Python command syntax:

```
ierr = maccc_trip_cor_3(tol, optacc, optmac, optrnk, opttrp, optcor,
  values, labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_TRIP_COR_3(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (RESERVE)
	OPTACC(10) = 2	subsystem machines (PMAX)
	OPTACC(10) = 3	subsystem machines (INERTIA)
	OPTACC(10) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	allow multiple contingency analysis (0 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(1) = 2	enabled with failure cutoff disabled
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3,

	the event list at the first level is used for any higher levels)
OPTMAC(2) = 1	N-1 contingency analysis
OPTMAC(2) = 2	N-2 contingency analysis
OPTMAC(2) = -2	N-2 contingency analysis
OPTMAC(2) = 3	N-3 contingency analysis
OPTMAC(2) = -3	N-3 contingency analysis
OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit and single branch outages respectively
OPTMAC(3) = 1	include the contingency combinations
OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).
OPTRNK(1)	include ties from subsystem (0 by default)
OPTRNK(1) = 0	disable
OPTRNK(1) = 1	enable
OPTRNK(2)	contingency rating (rating set program option setting by default)
OPTRNK(2) = 1	rate A
OPTRNK(2) = 2	rate B
OPTRNK(2) = 3	rate C
OPTRNK(3)	convert ratings to MW (0 by default)
OPTRNK(3) = 0	disable
OPTRNK(3) = 1	enable
OPTRNK(4)	machine overload contingencies (0 by default)
OPTRNK(4) = 0	disable
OPTRNK(4) = 1	enable
OPTRNK(5)	minimum of machine overload contingencies to evaluate (≥ 0 , 1 by default)
OPTRNK(6)	maximum of machine overload contingencies to evaluate (≥ 0 , 10 by default)
OPTRNK(7)	cutoff of machine overload contingencies to evaluate (≥ 0 , 5 by default)
OPTRNK(8)	line overload contingencies (0 by default)
OPTRNK(8) = 0	disable
OPTRNK(8) = 1	enable
OPTRNK(9)	minimum of line overload contingencies to evaluate (≥ 0 , 1 by default)

	OPTRNK(10)	maximum of line overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(11)	cutoff of line overload contingencies (≥ 0 , 5 by default)
	OPTRNK(12)	voltage collapse line contingencies (0 by default)
	OPTRNK(12) = 0	disable
	OPTRNK(12) = 1	enable
	OPTRNK(13)	minimum of voltage collapse line contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(14)	maximum of voltage collapse line contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(15)	cutoff of voltage collapse line contingencies (≥ 0 , 5 by default)
	OPTRNK(16)	include all branches in voltage collapse ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable

	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (11)	array of 11 elements specifying ranking parameters and corrective actions parameters(input).	
	VALUES(1)	small reactance threshold, (0<= VALUES (1)<=0.005, 0.0005 by default)
	VALUES(2)	percent of flow rating, (0<= VALUES (2)<=200.0, 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (>=0, 0.0 by default)
	VALUES(4)	bus voltage violation tolerance (0.1 by default)
	VALUES(5)	branch overload violation tolerance (0.1 by default)
	VALUES(6)	generator control weighting factor (1.0 by default)
	VALUES(7)	load control weighting factor (1.0 by default)
	VALUES(8)	phase shifter control weighting factor (1.0 by default)
	VALUES(9)	off-line generator control weighting factor (1.0 by default)
	VALUES(10)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(11)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
	LABELS(3)	label of generator control subsystem (blank by default for none, no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)

	LABELS(5)	label of phase shifter control subsystem (blank by default for none, no default allowed if OPTCOR(5) is 1)
	LABELS(6)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(7)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(8)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE		name of Distribution Factor Data File (input; no default allowed).
Character*260 ACCFILE		name of Contingency Solution Output File (input; no default allowed).
Character*260 THRFILE		name of Load Throwover Data File (input; blank for none).
Character*260 INLFILE		name of the Unit Inertia and Governor Data File (input; blank for none).
Character*260 TRPFILE		name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value
	IERR = 11	invalid OPTRNK value
	IERR = 12	invalid OPTTRP value
	IERR = 13	invalid OPTCOR value
	IERR = 14	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia Data File

IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.129. MACCC_TRIP_COR_4

This API is the third release of function to run multiple AC contingency analysis with tripping simulations and corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination each other as overlapping contingencies. Following a post contingency solution, trip events are simulated if their tripping conditions are satisfied. Corrective actions are then specified automatically to eliminate the violations in each post tripping solution with the objective of minimizing the control adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MACCC_TRIP_COR_4  TOL  OPTACC(1)..OPTACC(10) OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) OPTTRP(1)..OPTTRP(3) OPTCOR(1)..OPTCOR(8)
  VALUES(1)..VALUES(11) LABELS(1)..LABELS(8) DFXFILE ACCFILE THRFILE
  INLFILE TRPFILE
```

Python command syntax:

```
ierr = maccc_trip_cor_4(tol, optacc, optmac, optrnk, opttrp, optcor,
  values, labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_TRIP_COR_4(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (RESERVE)
	OPTACC(10) = 2	subsystem machines (PMAX)
	OPTACC(10) = 3	subsystem machines (INERTIA)
	OPTACC(10) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	allow multiple contingency analysis (0 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(1) = 2	enabled with failure cutoff disabled
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3,

		the event list at the first level is used for any higher levels)
	OPTMAC(2) = -3	N-3 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	Each element from 3 to 41 of OPTMAC array represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit (machine) and single branch outages respectively
	OPTMAC(3) = 0	(0 by default)
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (15)	array of 15 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	machine overload contingencies (0 by default)
	OPTRNK(2) = 0	disable
	OPTRNK(2) = 1	enable
	OPTRNK(3)	minimum of machine overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(4)	maximum of machine overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(5)	cutoff of machine overload contingencies to evaluate (≥ 0 , 5 by default)
	OPTRNK(6)	line overload contingencies (0 by default)
	OPTRNK(6) = 0	disable
	OPTRNK(6) = 1	enable
	OPTRNK(7)	minimum of line overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(8)	maximum of line overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(9)	cutoff of line overload contingencies (≥ 0 , 5 by default)
	OPTRNK(10)	voltage collapse line contingencies (0 by default)
	OPTRNK(10) = 0	disable
	OPTRNK(10) = 1	enable

	OPTRNK(11)	minimum of voltage collapse line contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(12)	maximum of voltage collapse line contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(13)	cutoff of voltage collapse line contingencies (≥ 0 , 5 by default)
	OPTRNK(14)	include all branches in voltage collapse ranking (0 by default)
	OPTRNK(14) = 0	include only with non-zero rating
	OPTRNK(14) = 1	all
	OPTRNK(15)	include contingencies that create swingless island (0 by default)
	OPTRNK(15) = 0	disable
	OPTRNK(15) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable tripping simulation
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable

	OPTCOR(8) = 1	enable
Real VALUES (10)	array of 10 elements specifying ranking parameters and corrective actions parameters(input).	
	VALUES(1)	small reactance threshold, (0<= VALUES (1)<=0.005, 0.0005 by default)
	VALUES(2)	MW threshold for islanding contingencies (>=0, 0.0 by default)
	VALUES(3)	bus voltage violation tolerance (0.1 by default)
	VALUES(4)	branch overload violation tolerance (0.1 by default)
	VALUES(5)	generator control weighting factor (1.0 by default)
	VALUES(6)	load control weighting factor (1.0 by default)
	VALUES(7)	phase shifter control weighting factor (1.0 by default)
	VALUES(8)	off-line generator control weighting factor (1.0 by default)
	VALUES(9)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(10)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
	LABELS(3)	label of generator control subsystem (blank by default for none, no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(5)	label of phase shifter control subsystem (blank by default for none, no default allowed if OPTCOR(5) is 1)
	LABELS(6)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(7)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(8)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	

Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank for none).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value
	IERR = 11	invalid OPTRNK value
	IERR = 12	invalid OPTTRP value
	IERR = 13	invalid OPTCOR value
	IERR = 14	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.130. MACCC_WITH_COR

This API routine is obsolete. It has been replaced by the API routine [maccc_with_cor_2](#).

Use this API to run multiple AC contingency analysis with corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination with each other as overlapping contingencies. The corrective actions analysis will be launched for the contingencies with flow and voltage violations to eliminate the violations with the objective of minimizing the controls adjustments including load shedding, MW generation dispatch and phase shifter angle adjustments.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_MACCC_WITH_COR  TOL  OPTACC(1)..OPTACC(8) OPTMAC(1)..OPTMAC(41)
  OPTRNK(1)..OPTRNK(17)  OPTCOR(1)..OPTCOR(5) VALUES(1)..VALUES(8)
  LABELS(1)..LABELS(5)  DFXFILE  ACCFILE  THRFILE  INLFILE
```

Python command syntax:

```
ierr = maccc_with_cor(tol, optacc, optmac, optrnk, optcor, values, labels,
  dfxfile, accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_COR(TOL, OPTACC, OPTMAC, OPTRNK, OPTCOR, VALUES, LABELS,
  DFXFILE, ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution options(input).
	OPTACC(1) tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0 disable
	OPTACC(1) = 1 enable stepping adjustment
	OPTACC(1) = 2 enable direct adjustment
	OPTACC(2) area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0 disable
	OPTACC(2) = 1 enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2 enable using tie line flows and loads in calculating area interchange
	OPTACC(3) phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0 disable
	OPTACC(3) = 1 enable
	OPTACC(4) dc tap adjustment flag (dc tap adjustment option setting by default)

	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1<=OPTMAC(2)<=3; 1 by default)
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying contingency ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable

OPTRNK(1) = 1	enable
OPTRNK(2)	contingency rating (rating set program option setting by default)
OPTRNK(2) = 1	rate A
OPTRNK(2) = 2	rate B
OPTRNK(2) = 3	rate C
OPTRNK(3)	convert ratings to MW (0 by default)
OPTRNK(3) = 0	disable
OPTRNK(3) = 1	enable
OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
OPTRNK(4) = 0	disable
OPTRNK(4) = 1	enable
OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0)
OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
OPTRNK(8) = 0	disable
OPTRNK(8) = 1	enable
OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
OPTRNK(12) = 0	disable
OPTRNK(12) = 1	enable
OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
OPTRNK(16)	include all branches in voltage depression ranking (0 by default)

	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTCOR (5)	array of 5 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective actions (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number of power flow solutions (from 0 to 10; 1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
Real VALUES (8)	array of 8 elements specifying ranking and corrective actions parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating set ($0 \leq \text{VALUES}(1) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (≥ 0.0 ; 0.0 by default)
	VALUES(4)	bus voltage violation tolerance (0.1 by default)
	VALUES(5)	branch flow overload tolerance (0.1 by default)
	VALUES(6)	generator control weighting factor (1.0 by default)
	VALUES(7)	load control weighting factor (1.0 by default)
	VALUES(8)	phase shifter control weighting factor (1.0 by default)
Character*32 LABELS (5)	array of 5 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)

	LABELS(3)	label of generator control subsystem (blank by default; no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default; no default allowed if OPTCOR(4) is 1)
	LABELS(5)	label of phase shifter control subsystem (blank by default; no default allowed if OPTCOR(5) is 1)
Character*260 DFXFILE		name of the Distribution Factor Data File (input; no default allowed).
Character*260 ACCFILE		name of the Contingency Solution Output File (input; no default allowed).
Character*260 THRFILE		name of the Load Throwover Data File (input; blank by default).
Character*260 INLFILE		name of the Unit Inertia and Governor Data File (input; blank by default).
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTMAC value
	IERR = 9	invalid OPTRNK value
	IERR = 10	invalid OPTCOR value
	IERR = 11	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for API are not met

1.1.131. MACCC_WITH_COR_2

This API routine is obsolete. It has been replaced by the API routine [maccc_with_cor_3](#).

This API is the second release of function to run multiple AC contingency analysis with corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination each other as overlapping contingencies. Corrective actions are specified automatically to eliminate the violations in each post contingency solution with the objective of minimizing the controls adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_MACCC_WITH_COR_2  TOL  OPTACC(1)..OPTACC(8) OPTMAC(1).. OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) OPTCOR(1)..OPTCOR(8) VALUES(1)..VALUES(11)
  LABELS(1)..LABELS(8) DFXFILE ACCFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = maccc_with_cor_2(tol, optacc, optmac, optrnk, optcor, values,
  labels, dfxfile, accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_COR_2(TOL, OPTACC, OPTMAC, OPTRNK, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).	
Integer OPTACC (8)	array of 8 elements specifying power flow solution(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable

	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (RESERVE)
	OPTACC(8) = 2	subsystem machines (PMAX)
	OPTACC(8) = 3	subsystem machines (INERTIA)
	OPTACC(8) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTMAC (41)		array of 41 elements specifying contingency evaluation level and combinations(input).
	OPTMAC(1)	allow multiple contingency analysis (0 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(1) = 2	enabled with failure cutoff disabled
	OPTMAC(2)	contingency evaluation level (1 by default)
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations
	OPTMAC(3) = 0	(0 by default)

Integer OPTRNK (17)

	array of 17 elements specifying ranking options(input).
OPTRNK(1)	include ties from subsystem (0 by default)
OPTRNK(1) = 0	disable
OPTRNK(1) = 1	enable
OPTRNK(2)	contingency rating (rating set program option setting by default)
OPTRNK(2) = 1	rate A
OPTRNK(2) = 2	rate B
OPTRNK(2) = 3	rate C
OPTRNK(3)	convert ratings to MW (0 by default)
OPTRNK(3) = 0	disable
OPTRNK(3) = 1	enable
OPTRNK(4)	machine overload contingencies (0 by default)
OPTRNK(4) = 0	disable
OPTRNK(4) = 1	enable
OPTRNK(5)	minimum of machine overload contingencies to evaluate (≥ 0 , 1 by default)
OPTRNK(6)	maximum of machine overload contingencies to evaluate (≥ 0 , 10 by default)
OPTRNK(7)	cutoff of machine overload contingencies to evaluate (≥ 0 , 5 by default)
OPTRNK(8)	line overload contingencies (0 by default)
OPTRNK(8) = 0	disable
OPTRNK(8) = 1	enable
OPTRNK(9)	minimum of line overload contingencies to evaluate (≥ 0 , 1 by default)
OPTRNK(10)	maximum of line overload contingencies to evaluate (≥ 0 , 10 by default)
OPTRNK(11)	cutoff of line overload contingencies (≥ 0 , 5 by default)
OPTRNK(12)	voltage collapse line contingencies (0 by default)
OPTRNK(12) = 0	disable
OPTRNK(12) = 1	enable
OPTRNK(13)	minimum of voltage collapse line contingencies to evaluate (≥ 0 , 1 by default)
OPTRNK(14)	maximum of voltage collapse line contingencies to evaluate (≥ 0 , 10 by default)
OPTRNK(15)	cutoff of voltage collapse line contingencies (≥ 0 , 5 by default)
OPTRNK(16)	include all branches in voltage collapse ranking (0 by default)
OPTRNK(16) = 0	include only with non-zero rating
OPTRNK(16) = 1	all

	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (11)	array of 11 elements specifying ranking parameters and corrective actions parameters(input).	
	VALUES(1)	small reactance threshold, (0<= VALUES (1)<=0.005, 0.0005 by default)
	VALUES(2)	percent of flow rating, (0<= VALUES (2)<=200.0, 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (>=0, 0.0 by default)
	VALUES(4)	bus voltage violation tolerance (0.1 by default)
	VALUES(5)	branch overload violation tolerance (0.1 by default)
	VALUES(6)	generator control weighting factor (1.0 by default)
	VALUES(7)	load control weighting factor (1.0 by default)
	VALUES(8)	phase shifter control weighting factor (1.0 by default)

	VALUES(9)	off-line generator control weighting factor (1.0 by default)
	VALUES(10)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(11)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is 1)
	LABELS(2)	label of contingency subsystem (blank by default)
	LABELS(3)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(5)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
	LABELS(6)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(7)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(8)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia and Governor Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	invalid OPTMAC value
	IERR = 9	invalid OPTRNK value

IERR = 10	invalid OPTCOR value
IERR = 11	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multisection line members
IERR = 50	error opening Unit Inertia Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.132. MACCC_WITH_COR_3

This API is the third release of function to run multiple AC contingency analysis with corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination each other as overlapping contingencies. Corrective actions are specified automatically to eliminate the violations in each post contingency solution with the objective of minimizing the controls adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MACCC_WITH_COR_3  TOL  OPTACC(1)..OPTACC(10) OPTMAC(1).. OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) OPTCOR(1)..OPTCOR(8) VALUES(1)..VALUES(11)
  LABELS(1)..LABELS(8) DFXFILE ACCFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = maccc_with_cor_3(tol, optacc, optmac, optrnk, optcor, values,
  labels, dfxfile, accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_COR_3(TOL, OPTACC, OPTMAC, OPTRNK, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable
OPTACC(1) = 1	enable stepping adjustment
OPTACC(1) = 2	enable direct adjustment
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable
OPTACC(3) = 1	enable
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable

	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (RESERVE)
	OPTACC(10) = 2	subsystem machines (PMAX)
	OPTACC(10) = 3	subsystem machines (INERTIA)
	OPTACC(10) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	allow multiple contingency analysis (0 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(1) = 2	enabled with failure cutoff disabled
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels)

	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(2) = -3	N-3 contingency analysis
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	contingency rating (rating set program option setting by default)
	OPTRNK(2) = 1	rate A
	OPTRNK(2) = 2	rate B
	OPTRNK(2) = 3	rate C
	OPTRNK(3)	convert ratings to MW (0 by default)
	OPTRNK(3) = 0	disable
	OPTRNK(3) = 1	enable
	OPTRNK(4)	machine overload contingencies (0 by default)
	OPTRNK(4) = 0	disable
	OPTRNK(4) = 1	enable
	OPTRNK(5)	minimum of machine overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(6)	maximum of machine overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(7)	cutoff of machine overload contingencies to evaluate (≥ 0 , 5 by default)
	OPTRNK(8)	line overload contingencies (0 by default)
	OPTRNK(8) = 0	disable
	OPTRNK(8) = 1	enable
	OPTRNK(9)	minimum of line overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(10)	maximum of line overload contingencies to evaluate (≥ 0 , 10 by default)

	OPTRNK(11)	cutoff of line overload contingencies (≥ 0 , 5 by default)
	OPTRNK(12)	voltage collapse line contingencies (0 by default)
	OPTRNK(12) = 0	disable
	OPTRNK(12) = 1	enable
	OPTRNK(13)	minimum of voltage collapse line contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(14)	maximum of voltage collapse line contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(15)	cutoff of voltage collapse line contingencies (≥ 0 , 5 by default)
	OPTRNK(16)	include all branches in voltage collapse ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable

Real VALUES (11)	array of 11 elements specifying ranking parameters and corrective actions parameters(input).
VALUES(1)	small reactance threshold, ($0 \leq \text{VALUES}(1) \leq 0.005$, 0.0005 by default)
VALUES(2)	percent of flow rating, ($0 \leq \text{VALUES}(2) \leq 200.0$, 100.0 by default)
VALUES(3)	MW threshold for islanding contingencies (≥ 0 , 0.0 by default)
VALUES(4)	bus voltage violation tolerance (0.1 by default)
VALUES(5)	branch overload violation tolerance (0.1 by default)
VALUES(6)	generator control weighting factor (1.0 by default)
VALUES(7)	load control weighting factor (1.0 by default)
VALUES(8)	phase shifter control weighting factor (1.0 by default)
VALUES(9)	off-line generator control weighting factor (1.0 by default)
VALUES(10)	tap setting adjustment weighting factor (1.0 by default)
VALUES(11)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem labels(input).
LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is 1)
LABELS(2)	label of contingency subsystem (blank by default)
LABELS(3)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
LABELS(4)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
LABELS(5)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
LABELS(6)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
LABELS(7)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
LABELS(8)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).

Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia and Governor Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value
	IERR = 11	invalid OPTRNK value
	IERR = 12	invalid OPTCOR value
	IERR = 13	invalid VALUES value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multisection line members
	IERR = 50	error opening Unit Inertia Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.133. MACCC_WITH_COR_4

This API is the third release of function to run multiple AC contingency analysis with corrective actions. The user-specified and automatically-selected contingencies are evaluated individually and in combination each other as overlapping contingencies. Corrective actions are specified automatically to eliminate the violations in each post contingency solution with the objective of minimizing the controls adjustments including load shedding, MW generation dispatch, phase shifter angle adjustments, off-line generator controls, tap setting adjustments and switched shunt controls.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MACCC_WITH_COR_4  TOL  OPTACC(1)..OPTACC(10) OPTMAC(1).. OPTMAC(41)
  OPTRNK(1)..OPTRNK(17) OPTCOR(1)..OPTCOR(8) VALUES(1)..VALUES(11)
  LABELS(1)..LABELS(8) DFXFILE ACCFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = maccc_with_cor_4(tol, optacc, optmac, optrnk, optcor, values,
  labels, dfxfile, accfile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_COR_4(TOL, OPTACC, OPTMAC, OPTRNK, OPTCOR, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (10)	array of 10 elements specifying power flow solution(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable
OPTACC(1) = 1	enable stepping adjustment
OPTACC(1) = 2	enable direct adjustment
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable
OPTACC(3) = 1	enable
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable

	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous, disable discrete
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (RESERVE)
	OPTACC(10) = 2	subsystem machines (PMAX)
	OPTACC(10) = 3	subsystem machines (INERTIA)
	OPTACC(10) = 4	subsystem machines (GOVERNOR DROOP)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	allow multiple contingency analysis (0 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(1) = 2	enabled with failure cutoff disabled
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels)

	OPTMAC(2) = -3	N-3 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	Each element from 3 to 41 of OPTMAC array represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit (machine) and single branch outages respectively
	OPTMAC(3) = 0	(0 by default)
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (15)	array of 15 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	machine overload contingencies (0 by default)
	OPTRNK(2) = 0	disable
	OPTRNK(2) = 1	enable
	OPTRNK(3)	minimum of machine overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(4)	maximum of machine overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(5)	cutoff of machine overload contingencies to evaluate (≥ 0 , 5 by default)
	OPTRNK(6)	line overload contingencies (0 by default)
	OPTRNK(6) = 0	disable
	OPTRNK(6) = 1	enable
	OPTRNK(7)	minimum of line overload contingencies to evaluate (≥ 0 , 1 by default)
	OPTRNK(8)	maximum of line overload contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(9)	cutoff of line overload contingencies (≥ 0 , 5 by default)
	OPTRNK(10)	voltage collapse line contingencies (0 by default)
	OPTRNK(10) = 0	disable
	OPTRNK(10) = 1	enable
	OPTRNK(11)	minimum of voltage collapse line contingencies to evaluate (≥ 0 , 1 by default)

	OPTRNK(12)	maximum of voltage collapse line contingencies to evaluate (≥ 0 , 10 by default)
	OPTRNK(13)	cutoff of voltage collapse line contingencies (≥ 0 , 5 by default)
	OPTRNK(14)	include all branches in voltage collapse ranking (0 by default)
	OPTRNK(14) = 0	include only with non-zero rating
	OPTRNK(14) = 1	all
	OPTRNK(15)	include contingencies that create swingless island (0 by default)
	OPTRNK(15) = 0	disable
	OPTRNK(15) = 1	enable
Integer OPTCOR (8)	array of 8 elements specifying corrective actions options(input).	
	OPTCOR(1)	run corrective action (0 by default)
	OPTCOR(1) = 0	disable
	OPTCOR(1) = 1	enable
	OPTCOR(2)	number power flows (1 by default)
	OPTCOR(3)	generator control flag (1 by default)
	OPTCOR(3) = 0	disable
	OPTCOR(3) = 1	enable
	OPTCOR(4)	load control flag (0 by default)
	OPTCOR(4) = 0	disable
	OPTCOR(4) = 1	enable
	OPTCOR(5)	phase shifter control flag (1 by default)
	OPTCOR(5) = 0	disable
	OPTCOR(5) = 1	enable
	OPTCOR(6)	off-line generator control flag (0 by default)
	OPTCOR(6) = 0	disable
	OPTCOR(6) = 1	enable
	OPTCOR(7)	tap setting adjustment flag (0 by default)
	OPTCOR(7) = 0	disable
	OPTCOR(7) = 1	enable
	OPTCOR(8)	switched shunt control flag (0 by default)
	OPTCOR(8) = 0	disable
	OPTCOR(8) = 1	enable
Real VALUES (10)	array of 10 elements specifying ranking parameters and corrective actions parameters(input).	
	VALUES(1)	small reactance threshold, ($0 \leq \text{VALUES}(1) \leq 0.005$, 0.0005 by default)
	VALUES(2)	MW threshold for islanding contingencies (≥ 0 , 0.0 by default)
	VALUES(3)	bus voltage violation tolerance (0.1 by default)

	VALUES(4)	branch overload violation tolerance (0.1 by default)
	VALUES(5)	generator control weighting factor (1.0 by default)
	VALUES(6)	load control weighting factor (1.0 by default)
	VALUES(7)	phase shifter control weighting factor (1.0 by default)
	VALUES(8)	off-line generator control weighting factor (1.0 by default)
	VALUES(9)	tap setting adjustment weighting factor (1.0 by default)
	VALUES(10)	switched shunt control weighting factor (1.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default, no default allowed if OPTACC(8) is 1)
	LABELS(2)	label of contingency subsystem (blank by default)
	LABELS(3)	label of generator control subsystem (blank by default, no default allowed if OPTCOR(3) is 1)
	LABELS(4)	label of load control subsystem (blank by default, no default allowed if OPTCOR(4) is 1)
	LABELS(5)	label of phase shifter control subsystem (blank by default, no default allowed if OPTCOR(5) is 1)
	LABELS(6)	off-line generator control subsystem (blank by default; no default allowed if OPTCOR(6) is 1)
	LABELS(7)	tap setting adjustment subsystem (blank by default; no default allowed if OPTCOR(7) is 1)
	LABELS(8)	switched shunt control subsystem (blank by default; no default allowed if OPTCOR(8) is 1)
Character*260 DFXFILE	name of Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia and Governor Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted

IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	invalid OPTMAC value
IERR = 11	invalid OPTRNK value
IERR = 12	invalid OPTCOR value
IERR = 13	invalid VALUES value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multisection line members
IERR = 50	error opening Unit Inertia Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.134. MACCC_WITH_TRIP

This API routine is obsolete. It has been replaced by the API routine [maccc_with_trip_2](#).

Use this API to run multiple level contingency analysis with tripping simulation.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MACCC_WITH_TRIP  TOL OPTACC(1)..OPTACC(8) OPTMAC(1).. OPTMAC(41)
  OPTRNK(1).. OPTRNK(17) OPTTRP(1)..OPTTRP(3) VALUES(1).. VALUES(3)
  LABELS(1) LABELS(2) DFXFILE ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = maccc_with_trip(tol, optacc, optmac, optrnk, opttrp, values,
  labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_TRIP(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, VALUES, LABELS,
  DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).
Integer OPTACC (8)	array of 8 elements specifying power flow solution options(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable
OPTACC(1) = 1	enable stepping adjustment
OPTACC(1) = 2	enable direct adjustment
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable
OPTACC(3) = 1	enable
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable
OPTACC(4) = 1	enable
OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)

	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	dispatch mode (0 by default)
	OPTACC(8) = 0	disable
	OPTACC(8) = 1	subsystem machines (reserve)
	OPTACC(8) = 2	subsystem machines (pmax)
	OPTACC(8) = 3	subsystem machines (inertia)
	OPTACC(8) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1<=OPTMAC(2)<=3; 1 by default)
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations, otherwise
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	contingency rating (rating set program option setting by default)

OPTRNK(2) = 1	rate A
OPTRNK(2) = 2	rate B
OPTRNK(2) = 3	rate C
OPTRNK(3)	convert ratings to MW (0 by default)
OPTRNK(3) = 0	disable
OPTRNK(3) = 1	enable
OPTRNK(4)	include machine contingencies from over- load ranking (0 by default)
OPTRNK(4) = 0	disable
OPTRNK(4) = 1	enable
OPTRNK(5)	minimum of machine contingencies to evalu- ate (≥ 0 ; 1 by default)
OPTRNK(6)	maximum of machine contingencies to eval- uate (≥ 0 ; 10 by default)
OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
OPTRNK(8) = 0	disable
OPTRNK(8) = 1	enable
OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by de- fault)
OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by de- fault)
OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
OPTRNK(12) = 0	disable
OPTRNK(12) = 1	enable
OPTRNK(13)	minimum of branch contingencies from volt- age depression ranking to evaluate (≥ 0 ; 1 by default)
OPTRNK(14)	maximum of branch contingencies from volt- age depression ranking to evaluate (≥ 0 ; 10 by default)
OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
OPTRNK(16) = 0	include only with non-zero rating
OPTRNK(16) = 1	all

	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Real VALUES (3)	array of 3 elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating ($0 \leq \text{VALUES}(2) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (≥ 0 ; 0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined

IERR = 7	too many islands in base case
IERR = 8	invalid OPTMAC value
IERR = 9	invalid OPTRNK value
IERR = 10	invalid VALUES value
IERR = 11	invalid OPTTRP value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 49	error opening Tripping Element Data File
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.135. MACCC_WITH_TRIP_2

Use this API to run the second version of multiple level contingency analysis with tripping simulation.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MACCC_WITH_TRIP_2  TOL OPTACC(1)..OPTACC(10) OPTMAC(1).. OPTMAC(41)
  OPTRNK(1).. OPTRNK(17) OPTTRP(1)..OPTTRP(3) VALUES(1).. VALUES(3)
  LABELS(1) LABELS(2) DFXFILE ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = maccc_with_trip_2(tol, optacc, optmac, optrnk, opttrp, values,
  labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_TRIP_2(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).	
Integer OPTACC (10)	array of 10 elements specifying power flow solution options(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable
	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable

	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)		array of 41 elements specifying contingency evaluation level and combinations(input).
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels)
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(2) = -3	N-3 contingency analysis

	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively
	OPTMAC(3) = 1	include the contingency combinations, otherwise
	OPTMAC(3) = 0	(0 by default)
Integer OPTRNK (17)	array of 17 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	contingency rating (rating set program option setting by default)
	OPTRNK(2) = 1	rate A
	OPTRNK(2) = 2	rate B
	OPTRNK(2) = 3	rate C
	OPTRNK(3)	convert ratings to MW (0 by default)
	OPTRNK(3) = 0	disable
	OPTRNK(3) = 1	enable
	OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(4) = 0	disable
	OPTRNK(4) = 1	enable
	OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(8) = 0	disable
	OPTRNK(8) = 1	enable
	OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)

	OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(12) = 0	disable
	OPTRNK(12) = 1	enable
	OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Real VALUES (3)	array of 3 elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating ($0 \leq \text{VALUES}(1) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (≥ 0 ; 0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	

Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value
	IERR = 11	invalid OPTRNK value
	IERR = 12	invalid VALUES value
	IERR = 13	invalid OPTTRP value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met

1.1.136. MACCC_WITH_TRIP_3

Use this API to run the second version of multiple level contingency analysis with tripping simulation.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MACCC_WITH_TRIP_3  TOL OPTACC(1)..OPTACC(10) OPTMAC(1).. OPTMAC(41)
  OPTRNK(1).. OPTRNK(15) OPTTRP(1)..OPTTRP(3) VALUES(1).. VALUES(2)
  LABELS(1) LABELS(2) DFXFILE ACCFILE THRFILE INLFILE TRPFILE
```

Python command syntax:

```
ierr = maccc_with_trip_3(tol, optacc, optmac, optrnk, opttrp, values,
  labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_TRIP_3(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, TOLN).	
Integer OPTACC (10)	array of 10 elements specifying power flow solution options(input).	
	OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTACC(1) = 0	disable
	OPTACC(1) = 1	enable stepping adjustment
	OPTACC(1) = 2	enable direct adjustment
	OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTACC(2) = 0	disable
	OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
	OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTACC(3) = 0	disable
	OPTACC(3) = 1	enable
	OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTACC(4) = 0	disable
	OPTACC(4) = 1	enable
	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable

	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)	array of 41 elements specifying contingency evaluation level and combinations(input).	
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels)
	OPTMAC(2) = -3	N-3 contingency analysis
	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis

	OPTMAC(3)	Each element from 3 to 41 of OPTMAC array represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit (machine) and single branch outages respectively
	OPTMAC(3) = 0	(0 by default)
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (15)	array of 15 elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(2) = 0	disable
	OPTRNK(2) = 1	enable
	OPTRNK(3)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(4)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(5)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(6)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(6) = 0	disable
	OPTRNK(6) = 1	enable
	OPTRNK(7)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(8)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(9)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(10)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(10) = 0	disable
	OPTRNK(10) = 1	enable
	OPTRNK(11)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)

	OPTRNK(12)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(13)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(14)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(14) = 0	include only with non-zero rating
	OPTRNK(14) = 1	all
	OPTRNK(15)	include contingencies that create swingless island (0 by default)
	OPTRNK(15) = 0	disable
	OPTRNK(15) = 1	enable
Integer OPTTRP (3)	array of 3 elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Real VALUES (2)	array of 2 elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	MW threshold for islanding contingencies (≥ 0 ; 0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0)
	LABELS(2)	label of contingency subsystem (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value

IERR = 2	invalid OPTACC value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	generation subsystem is not defined
IERR = 7	too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	invalid OPTMAC value
IERR = 11	invalid OPTRNK value
IERR = 12	invalid VALUES value
IERR = 13	invalid OPTTRP value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 49	error opening Tripping Element Data File
IERR = 50	error opening Unit Inertia and Governor Data File
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 54	prerequisite requirements for function not met

1.1.137. MACCC_WITH_TRIP_PARALLEL

Use this API to run the multiple level contingency analysis with tripping simulation in parallel when the number of contingency processors in Program Settings is greater than 1. User-specified and automatically selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_MACCC_WITH_TRIP_PARALLEL  TOL  OPTACC(1)..OPTACC(10)
  OPTMAC(1)..OPTMAC(41)  OPTRNK(1)..OPTRNK(17)  OPTTRP(1)..OPTTRP(3)
  VALUES(1)..VALUES(3)  LABELS(1)..LABELS(2)  DFXFILE  ACCFILE  THRFILE  INLFILE
  TRPFILE
```

Python command syntax:

```
ierr = maccc_with_trip_parallel(tol, optacc, optmac, optrnk, opttrp,
  values, labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_TRIP_PARALLEL(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP, VALUES,
  LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, by default).
Integer OPTACC (10)	array of elements specifying power flow solution options(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable
OPTACC(1) = 1	enable stepping adjustment
OPTACC(1) = 2	enable direct adjustment
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable
OPTACC(3) = 1	enable
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable
OPTACC(4) = 1	enable

	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)		array of elements specifying contingency evaluation level and combinations. (input).
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels by default)
	OPTMAC(2) = -3	N-3 contingency analysis

	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	each element represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single machine and single branch outages respectively. (0 by default)
	OPTMAC(3) = 0	not include the contingency combinations
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (17)	array of elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	contingency rating (rating set program option setting by default)
	OPTRNK(2) = 1	rate A
	OPTRNK(2) = 2	rate B
	OPTRNK(2) = 3	rate C
	OPTRNK(3)	convert ratings to MW (0 by default)
	OPTRNK(3) = 0	disable
	OPTRNK(3) = 1	enable
	OPTRNK(4)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(4) = 0	disable
	OPTRNK(4) = 1	enable
	OPTRNK(5)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(6)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(7)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(8)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(8) = 0	disable
	OPTRNK(8) = 1	enable
	OPTRNK(9)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)

	OPTRNK(10)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(11)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(12)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(12) = 0	disable
	OPTRNK(12) = 1	enable
	OPTRNK(13)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(14)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(15)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(16)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(16) = 0	include only with non-zero rating
	OPTRNK(16) = 1	all
	OPTRNK(17)	include contingencies that create swingless island (0 by default)
	OPTRNK(17) = 0	disable
	OPTRNK(17) = 1	enable
Integer OPTTRP (3)	array of elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Real VALUES (3)	array of elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	percent of rating ($0 \leq \text{VALUES}(2) \leq 200.0$; 100.0 by default)
	VALUES(3)	MW threshold for islanding contingencies (≥ 0 ; 0.0 by default)
Character*32 LABELS (2)	array of elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0 by default)

	LABELS(2)	label of contingency subsystem (blank by default) (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	
Character*260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1). (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value
	IERR = 11	invalid OPTRNK value
	IERR = 12	invalid VALUES value
	IERR = 13	invalid OPTTRP value
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met.

1.1.138. MACCC_WITH_TRIP_PARALLEL_2

Use this API to run the multiple level contingency analysis with tripping simulation in parallel when the number of contingency processors in Program Settings is greater than 1. User-specified and automatically selected contingencies from built-in contingency ranking functions are evaluated individually and in combination with each other as overlapping outages up to the specified evaluation level.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MACCC_WITH_TRIP_PARALLEL_2  TOL  OPTACC(1)..OPTACC(10)
  OPTMAC(1)..OPTMAC(41)  OPTRNK(1)..OPTRNK(17)  OPTTRP(1)..OPTTRP(3)
  VALUES(1)..VALUES(3)  LABELS(1)..LABELS(2)  DFXFILE  ACCFILE  THRFILE  INLFILE
  TRPFILE
```

Python command syntax:

```
ierr = maccc_with_trip_parallel_2(tol, optacc, optmac, optrnk, opttrp,
  values, labels, dfxfile, accfile, thrfile, inlfile, trpfile)
```

Fortran command syntax:

```
CALL MACCC_WITH_TRIP_PARALLEL_2(TOL, OPTACC, OPTMAC, OPTRNK, OPTTRP,
  VALUES, LABELS, DFXFILE, ACCFILE, THRFILE, INLFILE, TRPFILE, IERR)
```

Where:

Real TOL	mismatch tolerance (input; Newton solution convergence tolerance, by default).
Integer OPTACC (10)	array of elements specifying power flow solution options(input).
OPTACC(1)	tap adjustment flag (tap adjustment option setting by default)
OPTACC(1) = 0	disable
OPTACC(1) = 1	enable stepping adjustment
OPTACC(1) = 2	enable direct adjustment
OPTACC(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTACC(2) = 0	disable
OPTACC(2) = 1	enable using tie line flows only in calculating area interchange
OPTACC(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTACC(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTACC(3) = 0	disable
OPTACC(3) = 1	enable
OPTACC(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTACC(4) = 0	disable
OPTACC(4) = 1	enable

	OPTACC(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTACC(5) = 0	disable
	OPTACC(5) = 1	enable
	OPTACC(5) = 2	enable continuous mode, disable discrete mode
	OPTACC(6)	solution method flag (0 by default)
	OPTACC(6) = 0	FDNS
	OPTACC(6) = 1	FNSL
	OPTACC(6) = 2	optimized FDNS
	OPTACC(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTACC(7) = 0	disable
	OPTACC(7) = 1	enable
	OPTACC(8)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTACC(8) = 0	stall
	OPTACC(8) = 1	trip
	OPTACC(9)	induction machine failure flag (0 by default)
	OPTACC(9) = 0	treat contingency as non-converged if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(9) = 1	treat contingency as solved if it converges, even if any induction machines are placed in the "stalled" or "tripped" state
	OPTACC(10)	dispatch mode (0 by default)
	OPTACC(10) = 0	disable
	OPTACC(10) = 1	subsystem machines (reserve)
	OPTACC(10) = 2	subsystem machines (pmax)
	OPTACC(10) = 3	subsystem machines (inertia)
	OPTACC(10) = 4	subsystem machines (governor droop)
Integer OPTMAC (41)		array of elements specifying contingency evaluation level and combinations. (input).
	OPTMAC(1)	run multiple contingency analysis (1 by default)
	OPTMAC(1) = 0	disable
	OPTMAC(1) = 1	enable
	OPTMAC(2)	contingency evaluation level (1 by default). If it is 2 or 3, a newly ordered event list is built for the next level after solving AC power flow each case at current level; if it is -2 or -3, the event list at the first level is used for any higher levels by default)
	OPTMAC(2) = -3	N-3 contingency analysis

	OPTMAC(2) = -2	N-2 contingency analysis
	OPTMAC(2) = 1	N-1 contingency analysis
	OPTMAC(2) = 2	N-2 contingency analysis
	OPTMAC(2) = 3	N-3 contingency analysis
	OPTMAC(3)	Each element from 3 to 41 of OPTMAC array represents a type of contingency combinations in the following order. {S, U, B, SS, SU, SB, US, UU, UB, BS, BU, BB, SSS, SSB, SSU, SBS, SBB, SBU, SUS, SUB, SUU, USS, USU, USB, UUS, UUB, UUU, UBS, UBU, UBB, BSS, BSU, BSB, SUS, SUB, SUU, BBS, BBU, BBB}, where S, U and B are user specified cases, single unit (machine) and single branch outages respectively
	OPTMAC(3) = 0	(0 by default)
	OPTMAC(3) = 1	include the contingency combinations
Integer OPTRNK (15)	array of elements specifying ranking options(input).	
	OPTRNK(1)	include ties from contingency subsystem (0 by default)
	OPTRNK(1) = 0	disable
	OPTRNK(1) = 1	enable
	OPTRNK(2)	include machine contingencies from overload ranking (0 by default)
	OPTRNK(2) = 0	disable
	OPTRNK(2) = 1	enable
	OPTRNK(3)	minimum of machine contingencies to evaluate (≥ 0 ; 1 by default)
	OPTRNK(4)	maximum of machine contingencies to evaluate (≥ 0 ; 10 by default)
	OPTRNK(5)	non-failure cutoff of machine contingencies (≥ 0 ; 5 by default)
	OPTRNK(6)	include branch contingencies from overload ranking (0 by default)
	OPTRNK(6) = 0	disable
	OPTRNK(6) = 1	enable
	OPTRNK(7)	minimum of branch contingencies from overload ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(8)	maximum of branch contingencies from overload ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(9)	non-failure cutoff of branch contingencies from overload ranking (≥ 0 ; 5 by default)
	OPTRNK(10)	include branch contingencies from voltage depression ranking (0 by default)
	OPTRNK(10) = 0	disable

	OPTRNK(10) = 1	enable
	OPTRNK(11)	minimum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 1 by default)
	OPTRNK(12)	maximum of branch contingencies from voltage depression ranking to evaluate (≥ 0 ; 10 by default)
	OPTRNK(13)	non-failure cutoff of branch contingencies from voltage depression ranking (≥ 0 ; 5 by default)
	OPTRNK(14)	include all branches in voltage depression ranking (0 by default)
	OPTRNK(14) = 0	include only with non-zero rating
	OPTRNK(14) = 1	all
	OPTRNK(15)	include contingencies that create swingless island (0 by default)
	OPTRNK(15) = 0	disable
	OPTRNK(15) = 1	enable
Integer OPTTRP (3)	array of elements specifying tripping simulation options(input).	
	OPTTRP(1)	tripping simulation flag (0 by default)
	OPTTRP(1) = 0	disable
	OPTTRP(1) = 1	enable
	OPTTRP(2)	number of tripping events per power flow (1 by default)
	OPTTRP(3)	number of power flows per contingency (1 by default)
Real VALUES (2)	array of elements specifying ranking parameters(input).	
	VALUES(1)	small reactance threshold ($0 \leq \text{VALUES}(1) \leq 0.005$; 0.0005 by default)
	VALUES(2)	MW threshold for islanding contingencies (≥ 0 ; 0.0 by default)
Character*32 LABELS (2)	array of elements specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch subsystem (blank by default; no default allowed if OPTACC(8) is not 0 by default)
	LABELS(2)	label of contingency subsystem (blank by default) (blank by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of the Contingency Solution Output File (input; no default allowed).	
Character*260 THRFILE	name of the Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	name of the Unit Inertia and Governor Data File (input; blank by default).	

Character* 260 TRPFILE	name of the Tripping Element Data File (input; blank for none; no default allowed if OPTTRP(1) is 1). (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid TOL value
	IERR = 2	invalid OPTACC value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	invalid OPTMAC value
	IERR = 11	invalid OPTRNK value
	IERR = 12	invalid VALUES value
	IERR = 13	invalid OPTTRP value
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 49	error opening Tripping Element Data File
	IERR = 50	error opening Unit Inertia and Governor Data File
	IERR = 51	error opening Contingency Solution Output File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 54	prerequisite requirements for function not met.

1.1.139. MATRIX_GROWTH_FACTOR

Use this API to specify or return the value of the matrix growth factor option setting.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_MATRIX_GROWTH_FACTOR  RVAL
```

Python command syntax:

```
ierr = matrix_growth_factor(rval)

ierr, rval = matrix_growth_factor()
```

Fortran command syntax:

```
CALL MATRIX_GROWTH_FACTOR_API(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 2.0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to the value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

1.1.140. MCRE

Use this API to read a Machine Impedance Data File and add the data specified in it to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MCRE STATUS(1) STATUS(2) IFILE
```

Python command syntax:

```
ierr = mcre(status, ifile)
```

Fortran command syntax:

```
CALL MCREAPI(STATUS, IFILE, IERR)
```

Where:

Integer STATUS (2)	array of 2 elements specifying options(input).
STATUS(1)	new machine status option (0 by default)
STATUS(1) = 0	set from STAT field on input record
STATUS(1) = 1	set from status of other machines at the bus
STATUS(2)	option for treatment of machines with no data record specified and other machines at the bus with record specified (0 by default)
STATUS(2) = 0	place out-of-service
STATUS(2) = 1	delete
Character*260 IFILE	name of machine impedance data file (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid STATUS value
IERR = 2	generators are converted
IERR = 3	error opening IFILE
IERR = 4	prerequisite requirements for API are not met

1.1.141. MODR

Use this API to uniformly increase or decrease the line resistances of in-service nontransformer branches. It must first be called once with APIOPT set to 1, then once for each subsystem to be processed with APIOPT set to 2, and finally once with APIOPT set to 3.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MODR  SID  ALL  APIOPT  IRAT  RLOAD  FMAX
```

Python command syntax:

```
ierr, nchng = modr(sid, all, apiopt, irat, rload, fmax)
```

Fortran command syntax:

```
CALL MODRNW(SID, ALL, APIOPT, IRAT, RLOAD, FMAX, NCHNG, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 2; 0).	
Integer ALL	all buses or specified subsystem flag (input; used only when APIOPT is 2; 1).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer APIOPT	mode of operation of the API (input; no default allowed).	
	APIOPT = 1	initialize system for line resistance modification
	APIOPT = 2	modify line resistances
	APIOPT = 3	postprocessing housekeeping
Integer IRAT	rating set on which the present values of branch resistances are based (input; used only when APIOPT is 1; default rating set program option setting).	
	IRAT = 1	RATEA
	IRAT = 2	RATEB
	IRAT = 3	RATEC
Real RLOAD	base line loading in percent. $0.0001 < \text{RLOAD} < 2000.0$ (input; used only when APIOPT is 1; 100.0).	
Real FMAX	line resistance scaling factor in pu $0.0 < \text{FMAX} < 0.1$ (input; used only when APIOPT is 1; 0.01).	
Integer NCHNG	returned as the number of branch resistances changed (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined

IERR = 2	invalid ALL value
IERR = 3	invalid APIOPT value
IERR = 4	invalid IRAT value
IERR = 5	invalid RLOAD value
IERR = 6	invalid FMAX value
IERR = 7	unexpected APIOPT value
IERR = 8	prerequisite requirements for API are not met

1.1.142. MOVE3WND

Use this API to disconnect the third bus of a specified three-winding transformer from the bus to which it is currently connected, and reconnect it to a designated bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVE3WND IBUS JBUS1 JBUS2 'CKT' NEWTOBUS2 'NEWCKT'
```

Python command syntax:

```
ierr = move3wnd(ibus, jbus1, jbus2, ckt, newtobus2, newckt)
```

Fortran command syntax:

```
CALL MOVE3WND(IBUS, JBUS1, JBUS2, CKT, NEWTOBUS2, NEWCKT, IERR)
```

Where:

Integer IBUS	one of the buses connected by the three-winding transformer; the transformer will remain connected to this bus (input; no default allowed).
Integer JBUS1	other bus connected by the three-winding transformer; the transformer will remain connected to this bus (input; no default allowed).
Integer JBUS2	third bus connected by the three-winding transformer; this connection will be severed and the transformer connected to bus NEWTOBUS2 (input; no default allowed).
Character*2 CKT	circuit identifier of the three-winding transformer to be rerouted (input; '1' by default).
Integer NEWTOBUS2	number of the bus to which the three-winding transformer is to be connected (input; no default allowed).
Character*2 NEWCKT	new circuit identifier to be assigned to the rerouted three-winding transformer (input; CKT).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 three-winding transformer not found
	IERR = 3 new connection bus must not be the present from or to buses
	IERR = 4 circuit NEWCKT from IBUS to JBUS1 to NEWTOBUS2 already exists
	IERR = 5 invalid new identifier; cannot start with &, * or @
	IERR = 6 invalid new identifier; must not be blank
	IERR = 7 node-breaker terminal connection table is full
	IERR = 8 prerequisite requirements for API are not met

1.1.143. MOVEBRN

Use this API to disconnect the to bus of a specified non-transformer branch or two-winding transformer from the bus to which it is currently connected, and reconnect it to a designated bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVEBRN IBUS JBUS 'CKT' NEWTOBUS 'NEWCKT'
```

Python command syntax:

```
ierr = movebrn(ibus, jbus, ckt, newtobus, newckt)
```

Fortran command syntax:

```
CALL MOVEBRN(IBUS, JBUS, CKT, NEWTOBUS, NEWCKT, IERR)
```

Where:

Integer IBUS	one of the buses connected by the branch; the branch will remain connected to this bus (input; no default allowed).
Integer JBUS	other bus connected by the branch; this connection will be severed and the branch connected to bus NEWTOBUS (input; no default allowed).
Character*2 CKT	circuit identifier of the branch to be rerouted (input; '1' by default).
Integer NEWTOBUS	number of the bus to which the branch is to be connected (input; no default allowed).
Character*2 NEWCKT	new circuit identifier to be assigned to the rerouted branch (input; CKT).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 circuit CKT from IBUS to JBUS not found
	IERR = 3 new connection bus must not be the present from or to bus
	IERR = 4 circuit NEWCKT from IBUS to NEWTOBUS already exists
	IERR = 5 invalid new identifier; cannot start with &, * or @
	IERR = 6 invalid new identifier; must not be blank
	IERR = 7 node-breaker terminal connection table is full
	IERR = 8 prerequisite requirements for API are not met

1.1.144. MOVEINDMAC

Use this API routine to disconnect the specified induction machine from the bus to which it is currently connected, and reconnect it to a designated bus.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MOVEINDMAC IBUS 'ID' NEWBUS 'NEWID'
```

Python command syntax:

```
ierr = moveindmac(ibus, id, newbus, newid)
```

Fortran command syntax:

```
CALL MOVEINDMAC(IBUS, ID, NEWBUS, NEWID, IERR)
```

Where:

Integer IBUS	bus to which induction machine ID is connected (input; no default allowed).
Character*2 ID	machine identifier of the induction machine to be moved (input; '1' by default).
Integer NEWBUS	number of the bus to which the induction machine is to be moved (input; ID).
Character*2 NEWID	new induction machine identifier to be assigned to the relocated induction machine (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 induction machine not found
	IERR = 3 IBUS and NEWBUS are the same bus
	IERR = 4 induction machine NEWID at bus NEWBUS already exists
	IERR = 5 invalid new identifier; must not be blank
	IERR = 6 node-breaker terminal connection table is full
	IERR = 7 prerequisite requirements for API are not met

1.1.145. MOVEINDMACS

Use this API routine to disconnect all of the induction machines at the specified bus, and reconnect them to a designated bus. Bus TOBUS must not have any induction machines connected to it at the time this API routine is called.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MOVEINDMACS  IBUS  NEWBUS
```

Python command syntax:

```
ierr = moveindmacs(ibus, newbus)
```

Fortran command syntax:

```
CALL MOVEINDMACS(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	bus at which one or more induction machines currently exist (input; no default allowed).	
Integer NEWBUS	bus to which the induction machines on bus IBUS are to be moved (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no induction machines at bus IBUS
	IERR = 3	IBUS and NEWBUS are the same bus
	IERR = 4	NEWBUS already has induction machines (move individual machines)
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

1.1.146. MOVELOAD

Use this API to disconnect the specified load from the bus to which it is currently connected, and reconnect it to a designated bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVELOAD IBUS 'ID' NEWBUS 'NEWID'
```

Python command syntax:

```
ierr = moveload(ibus, id, newbus, newid)
```

Fortran command syntax:

```
CALL MOVELOAD(IBUS, ID, NEWBUS, NEWID, IERR)
```

Where:

Integer IBUS	bus to which the load ID is connected (input; no default allowed).
Character*2 ID	load identifier of the load to be moved (input; '1' by default).
Integer NEWBUS	number of the bus to which the load is to be moved (input; no default allowed).
Character*2 NEWID	new load identifier to be assigned to the relocated load (input; ID).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 load not found
	IERR = 3 IBUS and NEWBUS are the same bus
	IERR = 4 load NEWID at bus NEWBUS already exists
	IERR = 5 invalid new identifier; must not be blank
	IERR = 6 node-breaker terminal connection table is full
	IERR = 7 prerequisite requirements for API are not met

1.1.147. MOVELOADS

Use this API to disconnect all of the load from the specified bus, and reconnect it to a designated bus. Bus TOBUS must not have any load connected to it at the time this API is called.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVELOADS IBUS NEWBUS
```

Python command syntax:

```
ierr = moveloads(ibus, newbus)
```

Fortran command syntax:

```
CALL MOVELOADS(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	bus on which one or more loads currently exist (input; no default allowed).	
Integer NEWBUS	bus to which the loads on bus IBUS are to be moved (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no loads at bus IBUS
	IERR = 3	IBUS and NEWBUS are the same bus
	IERR = 4	NEWBUS already has loads (move individual loads)
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

1.1.148. MOVEMAC

Use this API to disconnect the specified machine from the bus to which it is currently connected, and re-connect it to a designated bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVEMAC  IBUS  'ID'  NEWBUS  'NEWID'
```

Python command syntax:

```
ierr = movemac(ibus, id, newbus, newid)
```

Fortran command syntax:

```
CALL MOVEMAC(IBUS, ID, NEWBUS, NEWID, IERR)
```

Where:

Integer IBUS	bus to which the machine ID is connected (input; no default allowed).
Character*2 ID	machine identifier of the machine to be moved (input; '1' by default).
Integer NEWBUS	number of the bus to which the machine is to be moved (input; ID).
Character*2 NEWID	new machine identifier to be assigned to the relocated machine (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 machine not found
	IERR = 3 IBUS and NEWBUS are the same bus
	IERR = 4 machine NEWID at bus NEWBUS already exists
	IERR = 5 plant table full (move machine to an existing plant)
	IERR = 6 invalid new identifier; must not be blank
	IERR = 7 node-breaker terminal connection table is full
	IERR = 8 prerequisite requirements for API are not met

1.1.149. MOVEPLNT

Use this API to disconnect all of the machines from the specified bus, and reconnect it to a designated bus. Bus TOBUS must not have any plant data associated with it at the time this API is called.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVEPLNT  IBUS  NEWBUS
```

Python command syntax:

```
ierr = moveplnt(ibus, newbus)
```

Fortran command syntax:

```
CALL MOVEPLNT(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	bus on which plant data currently exists (input; no default allowed).	
Integer NEWBUS	bus to which the plant on bus IBUS is to be moved (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no plant at bus IBUS
	IERR = 3	IBUS and NEWBUS are the same bus
	IERR = 4	NEWBUS already has plant data (move individual machines)
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

1.1.150. MOVESHUNT

Use this API to disconnect the specified fixed shunt from the bus to which it is currently connected, and re-connect it to a designated bus.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_MOVESHUNT IBUS 'ID' NEWBUS 'NEWID'
```

Python command syntax:

```
ierr = moveshunt(ibus, id, newbus, newid)
```

Fortran command syntax:

```
CALL MOVESHUNT(IBUS, ID, NEWBUS, NEWID, IERR)
```

Where:

Integer IBUS	bus to which the shunt ID is connected (input; no default allowed).
Character*2 ID	shunt identifier of the fixed shunt to be moved (input; '1' by default).
Integer NEWBUS	number of the bus to which the shunt is to be moved (input; no default allowed).
Character*2 NEWID	new shunt identifier to be assigned to the relocated fixed shunt (input; ID).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 fixed shunt not found
	IERR = 3 IBUS and NEWBUS are the same bus
	IERR = 4 shunt NEWID at bus NEWBUS already exists
	IERR = 5 invalid new identifier; must not be blank
	IERR = 6 node-breaker terminal connection table is full
	IERR = 7 prerequisite requirements for API are not met

1.1.151. MOVESHUNTS

Use this API to disconnect all of the fixed shunts from the specified bus and reconnect them to a designated bus. Bus TOBUS must not have any fixed shunt connected to it at the time this API is called.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_MOVESHUNTS IBUS NEWBUS
```

Python command syntax:

```
ierr = moveshunts(ibus, newbus)
```

Fortran command syntax:

```
CALL MOVESHUNTS(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	bus on which one or more fixed shunts currently exist (input; no default allowed).	
Integer NEWBUS	bus to which the fixed shunts on bus IBUS are to be moved (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no fixed shunts at bus IBUS
	IERR = 3	IBUS and NEWBUS are the same bus
	IERR = 4	NEWBUS already has fixed shunts (move individual shunts)
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

1.1.152. MOVESWS

This API routine is obsolete. It has been replaced by the API routine [MoveSwShunt](#).

Use this API to disconnect the switched shunt load from the specified bus and reconnect it to a designated bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MOVESWS  IBUS  NEWBUS
```

Python command syntax:

```
ierr = movesws(ibus, newbus)
```

Fortran command syntax:

```
CALL MOVESWS(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	bus on which a switched shunt currently exists (input; no default allowed).	
Integer NEWBUS	bus to which the switched shunt on bus IBUS is to be moved (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no switched shunt at bus IBUS
	IERR = 3	IBUS and NEWBUS are the same bus
	IERR = 4	prerequisite requirements for API are not met

1.1.153. MOVESWSHUNT

Use this API to disconnect the specified switched shunt from the bus to which it is currently connected, and reconnect it to a designated bus.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MOVESWSHUNT IBUS 'ID' NEWBUS 'NEWID'
```

Python command syntax:

```
ierr = moveswshunt(ibus, id, newbus, newid)
```

Fortran command syntax:

```
CALL MOVESWSHUNT(IBUS, ID, NEWBUS, NEWID, IERR)
```

Where:

Integer IBUS	bus to which switched shunt ID is connected (input; no default allowed).
Character*2 ID	shunt identifier of the switched shunt to be moved (input; '1' by default).
Integer NEWBUS	number of the bus to which the shunt is to be moved (input; no default allowed).
Character*2 NEWID	new shunt identifier to be assigned to the relocated switched shunt (input; ID).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 switched shunt not found
	IERR = 3 IBUS and NEWBUS are the same bus
	IERR = 4 switched shunt NEWID at bus NEWBUS already exists
	IERR = 5 invalid new identifier; must not be blank
	IERR = 6 node-breaker terminal connection table is full
	IERR = 7 prerequisite requirements for API are not met

1.1.154. MOVESWSHUNTS

Use this API to disconnect all of the switched shunts from the specified bus and reconnect them to a designated bus. Bus TOBUS must not have any switched shunt connected to it at the time this API is called.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MOVESWSHUNTS  IBUS  NEWBUS
```

Python command syntax:

```
ierr = moveswshunts(ibus, newbus)
```

Fortran command syntax:

```
CALL MOVESWSHUNTS(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	bus on which one or more switched shunts currently exist (input; no default allowed).	
Integer NEWBUS	bus to which the switched shunts on bus IBUS are to be moved (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no switched shunts at bus IBUS
	IERR = 3	IBUS and NEWBUS are the same bus
	IERR = 4	NEWBUS already has switched shunts (move individual switched shunts)
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

1.1.155. MOV_ALPHA

Use this API to specify or return the value of the MOV iteration ALPHA option setting.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_MOV_ALPHA RVAL IOCODE
```

Python command syntax:

```
ierr = mov_alpha(rval, iocode)
```

Fortran command syntax:

```
CALL MOV_ALPHA(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	MOV iteration ALPHA option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0.3 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in RVAL.
	IOCODE = 1	return the current value of the option setting in RVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid RVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.156. MOV_ITERATIONS

Use this API to specify or return the value of the maximum MOV iterations option setting.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_MOV_ITERATIONS IVAL IOCODE
```

Python command syntax:

```
ierr = mov_iterations(ival, iocode)
```

Fortran command syntax:

```
CALL MOV_ITERATIONS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 20 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.157. MOV_TOLERANCE

Use this API to specify or return the value of the MOV iteration tolerance option setting.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_MOV_TOLERANCE  RVAL  IOCODE
```

Python command syntax:

```
ierr = mov_tolerance(rval, iocode)
```

Fortran command syntax:

```
CALL MOV_TOLERANCE(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	MOV iteration tolerance (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0.01 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in RVAL.
	IOCODE = 1	return the current value of the option setting in RVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid RVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.158. MSLV

Use this API to apply the modified Gauss-Seidel power flow calculation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MSLV  OPTIONS(1) .. OPTIONS(6)
```

Python command syntax:

```
ierr = mslv(options)
```

Fortran command syntax:

```
CALL MSLVAPI(OPTIONS, IERR)
```

Where:

Integer OPTIONS (6)	array of 6 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (use tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable
OPTIONS(2)	area interchange adjustment flag (use area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	flat start flag (0 by default)
OPTIONS(3) = 0	do not flat start
OPTIONS(3) = 1	flat start
OPTIONS(3) = 2	flat start, then estimate voltage magnitudes
OPTIONS(3) = 3	flat start, then estimate voltage phase angles
OPTIONS(3) = 4	flat start, then estimate voltage magnitudes and phase angles
OPTIONS(4)	dc tap adjustment flag (use dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (use switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable

Integer IERR	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	var limit flag (0 by default)
	OPTIONS(6) = 0	apply var limits
	OPTIONS(6) = 1	ignore var limits
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	bus type code and series element status inconsistencies
	IERR = 5	prerequisite requirements for API are not met

1.1.159. MSUM

Use this API to print a summary of mileage by owner.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MSUM
```

Python command syntax:

```
ierr = msum()
```

Fortran command syntax:

```
CALL MSUMAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 4	prerequisite requirements for API are not met

1.1.160. MTDC

Use this API to produce a report of bus voltages and flows for each in-service multi-terminal dc line.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MTDC
```

Python command syntax:

```
ierr = mtdc()
```

Fortran command syntax:

```
CALL MTDCAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no unblocked multi-terminal dc lines in this case
	IERR = 2	prerequisite requirements for API are not met

1.1.161. MULTISECTION_REPORTING

Use this API to specify or return the option to enable or disable multi-section line reporting.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MULTISECTION_REPORTING IVAL
```

Python command syntax:

```
ierr = multisection_reporting(ival)
ierr, ival = multisection_reporting()
```

Fortran command syntax:

```
CALL MULTISECTION_LINE_REPORTING_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
	IVAL = 0 off.
	IVAL = 1 on.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.162. MWMI

Use this API to apply the MAPP MW-mile calculation

.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MWMI  SID  ALL  STATUS(1)..STATUS(4)  VALUES(1)..VALUES(3)  INPFILE
          TRNFILE  OUTFILE
```

Python command syntax:

```
ierr = mwmi(sid, all, status, values, inpfile, trnfile, outfile)
```

Fortran command syntax:

```
CALL MWMIAPI(SID, ALL, STATUS, VALUES, INPFILE, TRNFILE, OUTFILE, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 0	only areas in area subsystem SID are in the pool
	ALL = 1	all areas are in the pool
Integer STATUS (4)	array of 4 elements specifying solution options(input).	
	STATUS(1)	rating used (default rating set program option setting)
	STATUS(1) = 1	RATEA
	STATUS(1) = 2	RATEB
	STATUS(1) = 3	RATEC
	STATUS(2)	option to list data (0 by default)
	STATUS(2) = 0	no
	STATUS(2) = 1	yes
	STATUS(3)	option to include buyer and seller branches in the detailed branch output file (0 by default)
	STATUS(3) = 0	no
	STATUS(3) = 1	yes
	STATUS(4)	action code if the MW mismatch exceeds 0.5 MW (0 by default)
Real VALUES (3)	STATUS(4) = 0	discontinue
	STATUS(4) = 1	continue
array of 3 elements specifying solution parameters(input).		

	VALUES(1)	percent load reduction for calculating capacity for serving load (10.0 by default)
	VALUES(2)	MW for each transaction; used when no transactions data file is specified (10.0 by default)
	VALUES(3)	distribution factor threshold for detailed branch (0.0 by default)
Character*260 INPFILE	name of MWMI data file (input; no default allowed).	
Character*260 TRNFILE	name of the transactions raw data file; blank for none (input; blank by default).	
Character*260 OUTFILE	name of the detailed branch output file; blank for none (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid VALUES value
	IERR = 5	INPFILE is blank
	IERR = 6	generators are converted
	IERR = 7	buses in island(s) without a swing bus; use activity TREE
	IERR = 8	largest mismatch exceeds 0.5 MW
	IERR = 9	error opening INPFILE
	IERR = 10	error opening OUTFILE
	IERR = 11	error opening TRNFILE
	IERR = 12	prerequisite requirements for API are not met

1.1.163. MWOMWMSF

Use this API to tabulate generation (MW) on MW-mile shift factors for a specified transaction event.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MWOMWMSF  EVENT
```

Python command syntax:

```
ierr = mwomwmsf(event)
```

Fortran command syntax:

```
CALL MWOMWMSFAPI(EVENT, IERR)
```

Where:

Integer EVENT	transaction event number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no transactions defined
	IERR = 2	invalid transaction event number
	IERR = 3	transaction event not defined
	IERR = 4	prerequisite requirements for API are not met

1.1.164. MWOMWOSF

Use this API to tabulate generation (MW) on MW-ohm shift factors for a specified transaction event.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MWOMWOSF  EVENT
```

Python command syntax:

```
ierr = mwomwosf(event)
```

Fortran command syntax:

```
CALL MWOMWOSFAPI(EVENT, IERR)
```

Where:

Integer EVENT	transaction event number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no transactions defined
	IERR = 2	invalid transaction event number
	IERR = 3	transaction event not defined
	IERR = 4	prerequisite requirements for API are not met

1.1.165. N11_ACCC

This API routine is obsolete. It has been replaced by the API routine [n11_acc2](#).

This API is used to perform N-1-1 contingency analysis. Each pair of N-1-1 contingencies is simulated in the way that the first N-1 contingency is simulated by a full AC load flow solution with the power flow options for the first N-1 contingency; the post solution of the first N-1 contingency is used as the base case for the second N-1 contingency, the second N-1 contingency is imposed and solved by a full AC load flow solution with power flow options for the second N-1 contingency.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_N11_ACCC  OPTIONS(1)..OPTIONS(18) VALUES(1) VALUES(2) LABEL DFXFILE
              ACCFILE CONFILE INLFILE THRFILE
```

Python command syntax:

```
ierr = n11_acc2(options, values, label, dfxfile, accfile, confile, inlfile,
               thrfile)
```

Fortran command syntax:

```
CALL N11_ACCC(OPTIONS, VALUES, LABEL, DFXFILE, ACCFILE, CONFILE, INLFILE,
              THRFILE, IERR)
```

Where:

Integer OPTIONS (18)	array of 18 elements specifying integer specifying power flow options(input).	
	OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable

OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable
OPTIONS(9) = 1	enable stepping adjustment
OPTIONS(9) = 2	enable direct adjustment
OPTIONS(10)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(11)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable
OPTIONS(11) = 1	enable

	OPTIONS(12)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	enable
Real VALUES (2)	array of 2 elements specifying a real(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Percent of rating for the first N-1 contingency and second N-1 contingency case (100.0 by default)
Character*32 LABEL	label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation (input).	
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of contingency analysis output file (input; no default allowed).	
Character*260 CONFILE	name of Contingency Description Data File for the second N-1 contingencies (input; blank for none).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Generators are converted
	IERR = 4	Buses in island(s) without a swing bus--use activity TREE
	IERR = 5	Largest mismatch exceeds tolerance
	IERR = 6	Generation subsystem not specified
	IERR = 7	Too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	No Distribution Factor Data input file specified
	IERR = 11	No Contingency Analysis Output File specified
	IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
	IERR = 13	No second N-1 contingencies are specified
	IERR = 14	Invalid base/contingency case flag combination
	IERR = 21	File is not in the form of a PSSE-25 or later DFAX file--run DFAX

IERR = 22	Monitored elements exceed limit when adding multi-section line members
IERR = 51	Error opening distribution factor data file
IERR = 52	Error opening load throwover data file
IERR = 53	Error opening inertia data file
IERR = 54	Prerequisite requirements for function not met

1.1.166. N11_ACCC_2

This API is the second release of N-1-1 contingency analysis solution. This API is used to perform N-1-1 contingency analysis. Each pair of N-1-1 contingencies is simulated in the way that the first N-1 contingency is simulated by a full AC load flow solution with the power flow options for the first N-1 contingency; the post solution of the first N-1 contingency is used as the base case for the second N-1 contingency, the second N-1 contingency is imposed and solved by a full AC load flow solution with power flow options for the second N-1 contingency.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_N11_ACCC_2  OPTIONS(1) . . OPTIONS(20)  VALUES(1)  VALUES(2)  LABEL  DFXFILE
                ACCFILE  CONFILE  INLFILE  THRFILE
```

Python command syntax:

```
ierr =
    n11_accc_2(options, values, label, dfxfile, accfile, confile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL
    N11_ACCC_2( OPTIONS, VALUES, LABEL, DFXFILE, ACCFILE, CONFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (20)	array of 20 elements specifying integer specifying power flow options(input).	
	OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)

OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable
OPTIONS(9) = 1	enable stepping adjustment
OPTIONS(9) = 2	enable direct adjustment
OPTIONS(10)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(11)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable
OPTIONS(11) = 1	enable
OPTIONS(12)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)

	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	enable
	OPTIONS(13)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
	OPTIONS(13) = 0	disable
	OPTIONS(13) = 1	enable
	OPTIONS(13) = 2	enable continuous, disable discrete
	OPTIONS(14)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(14) = 0	stall
	OPTIONS(14) = 1	trip
	OPTIONS(15)	generation dispatch method
	OPTIONS(15) = 1	subsystem machines (PMAX)
	OPTIONS(15) = 2	subsystem machines (PMAX)
	OPTIONS(15) = 3	subsystem machines (INERTIA)
	OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP)
	OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
	OPTIONS(16) = 0	No
	OPTIONS(16) = 1	Yes
	OPTIONS(17)	Rating set for the first N-1 contingency case
	OPTIONS(17) = 1	RATE A
	OPTIONS(17) = 2	RATE B
	OPTIONS(17) = 3	RATE C
	OPTIONS(18)	Rating set for the second N-1 contingency case
	OPTIONS(18) = 1	RATE A
	OPTIONS(18) = 2	RATE B
	OPTIONS(18) = 3	RATE C
	OPTIONS(19)	Voltage limit for the first N-1 contingency case
	OPTIONS(19) = 1	normal
	OPTIONS(19) = 2	emergency
	OPTIONS(20)	Voltage limit for the second N-1 contingency case
	OPTIONS(20) = 1	normal
	OPTIONS(20) = 2	emergency
Real VALUES (2)	array of 2 elements specifying a real(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)

	VALUES(2)	Percent of rating for the first N-1 contingency and second N-1 contingency case (100.0 by default)
Character*32 LABEL	label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation (input).	
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of contingency analysis output file (input; no default allowed).	
Character*260 CONFILE	name of Contingency Description Data File for the second N-1 contingencies (input; blank for none).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Generators are converted
	IERR = 4	Buses in island(s) without a swing bus--use activity TREE
	IERR = 5	Largest mismatch exceeds tolerance
	IERR = 6	Generation subsystem not specified
	IERR = 7	Too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	No Distribution Factor Data input file specified
	IERR = 11	No Contingency Analysis Output File specified
	IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
	IERR = 13	No second N-1 contingencies are specified
	IERR = 14	Invalid base/contingency case flag combination
	IERR = 21	File is not in the form of a PSSE-25 or later DFAX file--run DFAX
	IERR = 22	Monitored elements exceed limit when adding multi-section line members
	IERR = 51	Error opening distribution factor data file
	IERR = 52	Error opening load throwover data file
	IERR = 53	Error opening inertia data file
	IERR = 54	Prerequisite requirements for function not met

1.1.167. N11_ACCC_3

This API is the second release of N-1-1 contingency analysis solution. This API is used to perform N-1-1 contingency analysis. Each pair of N-1-1 contingencies is simulated in the way that the first N-1 contingency is simulated by a full AC load flow solution with the power flow options for the first N-1 contingency; the post solution of the first N-1 contingency is used as the base case for the second N-1 contingency, the second N-1 contingency is imposed and solved by a full AC load flow solution with power flow options for the second N-1 contingency.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_N11_ACCC_3  OPTIONS(1) .. OPTIONS(16)  VALUES  LABEL  DFXFILE  ACCFILE
CONFIL  INLFILE  THRFILE
```

Python command syntax:

```
ierr =
n11_accc_3(options, values, label, dfxfile, accfile, confile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL
N11_ACCC_3(OPTIONS, VALUES, LABEL, DFXFILE, ACCFILE, CONFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (16)	array of 16 elements specifying integer specifying power flow options(input).	
	OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)

OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable
OPTIONS(9) = 1	enable stepping adjustment
OPTIONS(9) = 2	enable direct adjustment
OPTIONS(10)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(11)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable
OPTIONS(11) = 1	enable
OPTIONS(12)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)

	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	enable
	OPTIONS(13)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
	OPTIONS(13) = 0	disable
	OPTIONS(13) = 1	enable
	OPTIONS(13) = 2	enable continuous, disable discrete
	OPTIONS(14)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(14) = 0	stall
	OPTIONS(14) = 1	trip
	OPTIONS(15)	generation dispatch method
	OPTIONS(15) = 1	subsystem machines (PMAx)
	OPTIONS(15) = 2	subsystem machines (PMAx)
	OPTIONS(15) = 3	subsystem machines (INERTIA)
	OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP)
	OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
	OPTIONS(16) = 0	No
	OPTIONS(16) = 1	Yes
Real VALUES (1)	array of 1 elements specifying a real(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
Character*32 LABEL	label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation (input).	
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	name of contingency analysis output file (input; no default allowed).	
Character*260 CONFILE	name of Contingency Description Data File for the second N-1 contingencies (input; blank for none).	
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).	
Character*260 INLFILE	name of Unit Inertia Data File (input; blank for none).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Generators are converted
	IERR = 4	Buses in island(s) without a swing bus--use activity TREE
	IERR = 5	Largest mismatch exceeds tolerance

IERR = 6	Generation subsystem not specified
IERR = 7	Too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	No Distribution Factor Data input file specified
IERR = 11	No Contingency Analysis Output File specified
IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
IERR = 13	No second N-1 contingencies are specified
IERR = 14	Invalid base/contingency case flag combination
IERR = 21	File is not in the form of a PSSE-25 or later DFAX file--run DFAX
IERR = 22	Monitored elements exceed limit when adding multi-section line members
IERR = 51	Error opening distribution factor data file
IERR = 52	Error opening load throwover data file
IERR = 53	Error opening inertia data file
IERR = 54	Prerequisite requirements for function not met

1.1.168. N11_ACCC_PARALLEL

Use this API to run the N-1-1 contingency analysis in parallel when the number of contingency processors in Program Settings is greater than 1. The API distributes contingency cases among multiple processors evenly, and tests the contingency cases and following tripping actions assigned to each processor in parallel.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_N11_ACCC_PARALLEL  OPTIONS(1)..OPTIONS(20)  VALUES(1)..VALUES(2)  LABEL
                        DFXFILE ACCFILE CONFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = n11_accc_parallel(options, values, label, dfxfile, accfile,
                        confile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL N11_ACCC_PARALLEL(OPTIONS, VALUES, LABEL, DFXFILE, ACCFILE, CONFILE,
                        THRFILE, INLFILE, IERR)
```

Where:

Integer OPTIONS (20)	array of elements specifying power flow options(input).	
	OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable

OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete.
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall.
OPTIONS(6) = 1	trip.
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable.
OPTIONS(8) = 1	Enable.
OPTIONS(9)	tap adjustment flag for the second N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable.
OPTIONS(9) = 1	enable stepping adjustment.
OPTIONS(9) = 2	enable direct adjustment.
OPTIONS(10)	area interchange adjustment flag for the second N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable.
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange.
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange.
OPTIONS(11)	phase shift adjustment flag for the second N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable.
OPTIONS(11) = 1	enable.
OPTIONS(12)	dc tap adjustment flag for the second N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(12) = 0	disable.
OPTIONS(12) = 1	enable.

	OPTIONS(13)	switched shunt adjustment flag for the second N-1 contingency (switched shunt adjustment option setting by default)
	OPTIONS(13) = 0	disable
	OPTIONS(13) = 1	enable
	OPTIONS(13) = 2	enable continuous, disable discrete.
	OPTIONS(14)	induction motor treatment flag for the second N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(14) = 0	stall
	OPTIONS(14) = 1	trip
	OPTIONS(15)	generation dispatch method
	OPTIONS(15) = 0	disable.
	OPTIONS(15) = 1	subsystem machines (RESERVE).
	OPTIONS(15) = 2	subsystem machines (PMAX).
	OPTIONS(15) = 3	subsystem machines (INERTIA).
	OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP).
	OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
	OPTIONS(16) = 0	No
	OPTIONS(16) = 1	Yes
	OPTIONS(17)	Rating set for the first N-1 contingency case
	OPTIONS(17) = 1	rate A
	OPTIONS(17) = 2	rate B
	OPTIONS(17) = 3	rate C
	OPTIONS(18)	Rating set for the second N-1 contingency case
	OPTIONS(18) = 1	rate A
	OPTIONS(18) = 2	rate B
	OPTIONS(18) = 3	rate C
	OPTIONS(19)	voltage limit for the first N-1 contingency case
	OPTIONS(19) = 1	normal
	OPTIONS(19) = 2	emergency
	OPTIONS(20)	voltage limit for the second N-1 contingency case
	OPTIONS(20) = 1	normal
	OPTIONS(20) = 2	emergency
Real VALUES (2)	array of 2 elements specifying power flow options(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Percent of rating for the first N-1 contingency and second N-1 contingency case (100.0 by default)

Character*32 LABEL	The label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation output. (input).	
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	Is the name of contingency analysis output file (input; no default allowed).	
Character*260 CONFILE	Is the name of Contingency Description Data File for the second N-1 contingencies (input; blank by default).	
Character*260 THRFILE	Is the name of Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	Is the name of Unit Inertia Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Generators are converted
	IERR = 4	Buses in island(s) without a swing bus--use activity TREE
	IERR = 5	Largest mismatch exceeds tolerance
	IERR = 6	Generation subsystem not specified
	IERR = 7	Too many islands in base case.
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	No Distribution Factor Data input file specified
	IERR = 11	No Contingency Solution Output File specified
	IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
	IERR = 13	No second N-1 contingencies are specified
	IERR = 14	Invalid base/contingency case flag combination.
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	error opening Load Throwover Data File
	IERR = 53	error opening Unit Inertia and Governor Data File
	IERR = 54	prerequisite requirements for API are not met

1.1.169. N11_ACCC_PARALLEL_2

Use this API to run the N-1-1 contingency analysis in parallel when the number of contingency processors in Program Settings is greater than 1. The API distributes contingency cases among multiple processors evenly, and tests the contingency cases and following tripping actions assigned to each processor in parallel.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_N11_ACCC_PARALLEL_2  OPTIONS(1)..OPTIONS(16) VALUES LABEL DFXFILE
  ACCFILE CONFILE THRFILE INLFILE
```

Python command syntax:

```
ierr = n11_accc_parallel_2(options, values, label, dfxfile, accfile,
  confile, thrfile, inlfile)
```

Fortran command syntax:

```
CALL N11_ACCC_PARALLEL_2(OPTIONS, VALUES, LABEL, DFXFILE, ACCFILE,
  CONFILE, THRFILE, INLFILE, IERR)
```

Where:

Integer OPTIONS (16)	array of elements specifying power flow options(input).
OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable

OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete.
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall.
OPTIONS(6) = 1	trip.
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable.
OPTIONS(8) = 1	Enable.
OPTIONS(9)	tap adjustment flag for the second N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable.
OPTIONS(9) = 1	enable stepping adjustment.
OPTIONS(9) = 2	enable direct adjustment.
OPTIONS(10)	area interchange adjustment flag for the second N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable.
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange.
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange.
OPTIONS(11)	phase shift adjustment flag for the second N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable.
OPTIONS(11) = 1	enable.
OPTIONS(12)	dc tap adjustment flag for the second N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(12) = 0	disable.
OPTIONS(12) = 1	enable.

	OPTIONS(13)	switched shunt adjustment flag for the second N-1 contingency (switched shunt adjustment option setting by default)
	OPTIONS(13) = 0	disable
	OPTIONS(13) = 1	enable
	OPTIONS(13) = 2	enable continuous, disable discrete.
	OPTIONS(14)	induction motor treatment flag for the second N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(14) = 0	stall
	OPTIONS(14) = 1	trip
	OPTIONS(15)	generation dispatch method
	OPTIONS(15) = 0	disable.
	OPTIONS(15) = 1	subsystem machines (RESERVE).
	OPTIONS(15) = 2	subsystem machines (PMAX).
	OPTIONS(15) = 3	subsystem machines (INERTIA).
	OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP).
	OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
	OPTIONS(16) = 0	No
	OPTIONS(16) = 1	Yes
Real VALUES (1)	array of 1 elements specifying power flow options(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
Character*32 LABEL	The label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation output. (input).	
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	Is the name of contingency analysis output file (input; no default allowed).	
Character*260 CONFILE	Is the name of Contingency Description Data File for the second N-1 contingencies (input; blank by default).	
Character*260 THRFILE	Is the name of Load Throwover Data File (input; blank by default).	
Character*260 INLFILE	Is the name of Unit Inertia Data File (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Generators are converted
	IERR = 4	Buses in island(s) without a swing bus--use activity TREE
	IERR = 5	Largest mismatch exceeds tolerance

IERR = 6	Generation subsystem not specified
IERR = 7	Too many islands in base case.
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	No Distribution Factor Data input file specified
IERR = 11	No Contingency Solution Output File specified
IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
IERR = 13	No second N-1 contingencies are specified
IERR = 14	Invalid base/contingency case flag combination.
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Distribution Factor Data File
IERR = 52	error opening Load Throwover Data File
IERR = 53	error opening Unit Inertia and Governor Data File
IERR = 54	prerequisite requirements for API are not met

1.1.170. N11_ACCC_PSCOPF

This API routine is obsolete. It has been replaced by the API routine [n11_accc_pscopf_2](#).

The API is used to perform N-1-1 contingency analysis in either corrective mode or security constrained optimal power flow mode (SCOPF). In corrective mode, for each pair of N-1 contingencies a full AC load flow is performed for the first N-1 contingency; the post contingency solution is checked against the operation limits and corrective actions are specified to mitigate the limit violations; the post-corrective action solution is used as the base case for the secondary contingency and a full AC load flow is performed to solve the second N-1 contingency.

In the SCOPF mode, a primary contingency is imposed and solved with a full AC load flow solution. A secure control is conducted on the system condition existing after the primary contingency with the secondary contingencies, control adjustments are specified by security constrained optimal power flow to ensure security of the system after the primary contingency. The system condition after the primary contingency and adjustments is used as the base case for secondary contingency; a full AC load flow solution is then performed to solve a secondary N-1 contingency.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_N11_ACCC_PSCOPF  OPTIONS(1)..OPTIONS(18) OPTCOR(1)..OPTCOR(9)
VALUES(1)..VALUES(10) LABELS(1)..LABELS(7) DFXFILE ACCFILE CONFILE
INLFILE THRFILE
```

Python command syntax:

```
ierr = n11_accc_pscopf(options, optcor, values, labels, dfxfile, accfile,
confil, inlfile, thrfile)
```

Fortran command syntax:

```
CALL N11_ACCC_PSCOPF(OPTIONS, OPTCOR, VALUES, LABELS, DFXFILE, ACCFILE,
CONFIL, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (18)	array of 18 elements specifying integer specifying power flow options(input).	
	OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange

OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable
OPTIONS(9) = 1	enable stepping adjustment
OPTIONS(9) = 2	enable direct adjustment
OPTIONS(10)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange

	OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(11)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
	OPTIONS(11) = 0	disable
	OPTIONS(11) = 1	enable
	OPTIONS(12)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	enable
	OPTIONS(13)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
	OPTIONS(13) = 0	disable
	OPTIONS(13) = 1	enable
	OPTIONS(13) = 2	enable continuous, disable discrete
	OPTIONS(14)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(14) = 0	stall
	OPTIONS(14) = 1	trip
	OPTIONS(15)	dispatch mode (0 by default)
	OPTIONS(15) = 0	disable
	OPTIONS(15) = 1	subsystem machines (RESERVE)
	OPTIONS(15) = 2	subsystem machines (PMAX)
	OPTIONS(15) = 3	subsystem machines (INERTIA)
	OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP)
	OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
	OPTIONS(16) = 0	No
	OPTIONS(16) = 1	Yes
	OPTIONS(17)	Rating set for the first N-1 contingency case
	OPTIONS(17) = 1	RATE A
	OPTIONS(17) = 2	RATE B
	OPTIONS(17) = 3	RATE C
	OPTIONS(18)	Rating set for the second N-1 contingency case
	OPTIONS(18) = 1	RATE A
	OPTIONS(18) = 2	RATE B
	OPTIONS(18) = 3	RATE C
Integer OPTCOR (9)	array of 9 elements specifying OPTCOR Is an integer specifying control options(input).	

OPTCOR(1)	System adjustment mode
OPTCOR(1) = 0	local adjustment only
OPTCOR(1) = 1	Corrective action mode
OPTCOR(1) = 2	Preventive security constrained optimal power flow mode
OPTCOR(2)	maximum iteration number of PSCOPF, required if OPTCOR(1) is 2
OPTCOR(3)	maximum number of a contingency that does not cause limit violations and instability issue to be tested in the iterative process of PSCOPF, required if OPTCOR(1) is 2
OPTCOR(4)	generator control flag (1 by default)
OPTCOR(4) = 0	disable generation MW dispatch in the corrective action mode or preventive security constrained optimal power flow mode
OPTCOR(4) = 1	enable
OPTCOR(5)	load control flag (0 by default)
OPTCOR(5) = 0	disable load shedding control in the corrective action mode or preventive security constrained optimal power flow mode
OPTCOR(5) = 1	enable
OPTCOR(6)	phase shifter control flag (1 by default)
OPTCOR(6) = 0	disable phase shifter control in the corrective action mode or preventive security constrained optimal power flow mode
OPTCOR(6) = 1	enable
OPTCOR(7)	off-line generator control flag (0 by default)
OPTCOR(7) = 0	disable generation MW dispatch of off-line generators in the corrective action mode or preventive security constrained optimal power flow mode
OPTCOR(7) = 1	enable
OPTCOR(8)	tap setting adjustment flag (0 by default)
OPTCOR(8) = 0	disable tap setting adjustment in the corrective action mode or preventive security constrained optimal power flow mode
OPTCOR(8) = 1	enable
OPTCOR(9)	switched shunt control flag (0 by default)
OPTCOR(9) = 0	disable switch shunt control in the corrective action mode or preventive security constrained optimal power flow mode
OPTCOR(9) = 1	enable
Real VALUES (10)	array of 10 elements specifying VALUES is a real(input).
VALUES(1)	Mismatch tolerance (TOLN by default)
VALUES(2)	Percentage of rating for the base case (100.0 by default)

	VALUES(3)	Voltage tolerance in linear programming
	VALUES(4)	Flow tolerance in linear programming
	VALUES(5)	Weighting factor of generation MW dispatch (1.0 by default)
	VALUES(6)	Weighting factor of load control (1.0 by default)
	VALUES(7)	Weighting factor of phase shifter control (1.0 by default)
	VALUES(8)	Weighting factor of generation MW dispatch of off-line generators (1.0 by default)
	VALUES(9)	Weighting factor of tap setting adjustment (1.0 by default)
	VALUES(10)	Weighting factor of switched shunt control (1.0 by default)
Character*32 LABELS (7)	array of 7 elements specifying specifying subsystem labels(input).	
	LABELS(1)	label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation (blank for none by default)
	LABELS(2)	label of generation dispatch control system. MW injections of the generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none by default)
	LABELS(3)	label of load control system. Loads in the load control system are available for curtailment in the corrective action mode or preventive security constrained optimal power flow mode (blank for none by default)
	LABELS(4)	label of phase shifter adjustment system. The phase angles of phase shifters in the system are regulated either by corrective action or preventive security constrained optimal power flow (blank for none by default)
	LABELS(5)	label of generation MW control of off-line generator control system. MW injections of the off-line generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none by default)
	LABELS(6)	label of tap adjustment system. The tap positions of transformers in voltage control mode are regulated either by corrective action or

		preventive security constrained optimal power flow (blank for none by default)
	LABELS(7)	label of switched shunt control system. The admittances of switched shunts in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none by default)
Character*260 DFXFILE		name of the Distribution Factor Data File (input; no default allowed).
Character*260 ACCFILE		name of contingency analysis output file (input; no default allowed).
Character*260 CONFILE		name of Contingency Description Data File for the second N-1 contingencies (input; blank for none).
Character*260 THRFILE		name of Load Throwover Data File (input; blank for none).
Character*260 INLFILE		name of Unit Inertia Data File (input; blank for none).
Integer IERR		error code (output).
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Generators are converted
	IERR = 4	Buses in island(s) without a swing bus--use activity TREE
	IERR = 5	Largest mismatch exceeds tolerance
	IERR = 6	Generation subsystem not specified
	IERR = 7	Too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	No Distribution Factor Data input file specified
	IERR = 11	No Contingency Analysis Output File specified
	IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
	IERR = 13	No second N-1 contingencies are specified
	IERR = 14	Invalid base/contingency case flag combination
	IERR = 15	Invalid OPTCOR value
	IERR = 21	File is not in the form of a PSSE-25 or later DFAX file--run DFAX
	IERR = 22	Monitored elements exceed limit when adding multi-section line members
	IERR = 51	Error opening distribution factor data file
	IERR = 52	Error opening load throwover data file
	IERR = 53	Error opening inertia data file

IERR = 54

Prerequisite requirements for function not
met

1.1.171. N11_ACCC_PSCOPF_2

The API is the second release of N-1-1 contingency analysis solution in either corrective mode or security constrained optimal power flow mode (SCOPF). In corrective mode, for each pair of N-1 contingencies a full AC load flow is performed for the first N-1 contingency; the post contingency solution is checked against the operation limits and corrective actions are specified to mitigate the limit violations; the post-corrective action solution is used as the base case for the secondary contingency and a full AC load flow is performed to solve the second N-1 contingency.

In the PSCOPF mode, a primary contingency is imposed and solved with a full AC load flow solution. A security control is conducted on the system condition existing after the primary contingency with the secondary contingencies, control adjustments are specified by security constrained optimal power flow to ensure security of the system after the primary contingency. The system condition after the primary contingency and adjustments is used as the base case for secondary contingency; a full AC load flow solution is then performed to solve a secondary N-1 contingency.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_N11_ACCC_PSCOPF_2  OPTIONS(1)..OPTIONS(20) OPTCOR(1)..OPTCOR(9)
                        VALUES(1)..VALUES(10) LABELS(1)..LABELS(7) DFXFILE ACCFILE CONFILE
                        THRFILE INLFILE
```

Python command syntax:

```
ierr = n11_accc_pscopf_2(options, optcor, values, labels, dfxfile,
                        accfile, confile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL N11_ACCC_PSCOPF_2(OPTIONS, OPTCOR, VALUES, LABELS, DFXFILE, ACCFILE,
                        CONFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (20)	array of elements specifying power flow options(input).
OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange

OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete.
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall.
OPTIONS(6) = 1	trip.
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the second N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable.
OPTIONS(9) = 1	enable stepping adjustment.
OPTIONS(9) = 2	enable direct adjustment.
OPTIONS(10)	area interchange adjustment flag for the second N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable.
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange.
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange.

OPTIONS(11)	phase shift adjustment flag for the second N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable.
OPTIONS(11) = 1	enable.
OPTIONS(12)	dc tap adjustment flag for the second N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(12) = 0	disable.
OPTIONS(12) = 1	enable.
OPTIONS(13)	switched shunt adjustment flag for the second N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(13) = 0	disable.
OPTIONS(13) = 1	enable.
OPTIONS(13) = 2	enable continuous, disable discrete.
OPTIONS(14)	induction motor treatment flag for the second N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(14) = 0	stall.
OPTIONS(14) = 1	trip.
OPTIONS(15)	dispatch mode (0 by default)
OPTIONS(15) = 0	disable.
OPTIONS(15) = 1	subsystem machines (RESERVE).
OPTIONS(15) = 2	subsystem machines (PMAX).
OPTIONS(15) = 3	subsystem machines (INERTIA).
OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP).
OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
OPTIONS(16) = 0	No
OPTIONS(16) = 1	Yes
OPTIONS(17)	Rating set for the first N-1 contingency case
OPTIONS(17) = 1	rate A
OPTIONS(17) = 2	rate B
OPTIONS(17) = 3	rate C
OPTIONS(18)	Rating set for the second N-1 contingency case
OPTIONS(18) = 1	rate A
OPTIONS(18) = 2	rate B
OPTIONS(18) = 3	rate C
OPTIONS(19)	voltage limit for the first N-1 contingency case
OPTIONS(19) = 1	normal
OPTIONS(19) = 2	emergency

	OPTIONS(20)	voltage limit for the second N-1 contingency case
	OPTIONS(20) = 1	normal
	OPTIONS(20) = 2	emergency
Integer OPTCOR (9)	array of elements specifying control options(input).	
	OPTCOR(1)	System adjustment mode
	OPTCOR(1) = 0	local adjustment only
	OPTCOR(1) = 1	Corrective action mode
	OPTCOR(1) = 2	Preventive security constrained optimal power flow mode
	OPTCOR(2)	maximum iteration number of PSCOPF, required if OPTCOR(1) is 2
	OPTCOR(3)	maximum number of a contingency that does not cause limit violations and instability issue to be tested in the iterative process of PSCOPF, required if OPTCOR(1) is 2.
	OPTCOR(4)	generator control flag (0 by default)
	OPTCOR(4) = 0	disable generation MW dispatch in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(4) = 1	enable
	OPTCOR(5)	load control flag (0 by default)
	OPTCOR(5) = 0	disable load shedding control in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(5) = 1	enable
	OPTCOR(6)	phase shifter control flag (1 by default)
	OPTCOR(6) = 0	disable phase shifter control in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(6) = 1	enable
	OPTCOR(7)	off-line generator control flag (0 by default)
	OPTCOR(7) = 0	disable generation MW dispatch of off-line generators in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(7) = 1	enable
	OPTCOR(8)	tap setting adjustment flag (0 by default)
	OPTCOR(8) = 0	disable tap setting adjustment in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(8) = 1	enable
	OPTCOR(9)	switched shunt control flag (0 by default)
	OPTCOR(9) = 0	disable switch shunt control in the corrective action mode or preventive security constrained optimal power flow

	OPTCOR(9) = 1	enable
Real VALUES (10)	array of elements specifying power flow settings(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Percentage of rating for the base case (100.0 by default)
	VALUES(3)	Voltage tolerance in linear programming
	VALUES(4)	Flow tolerance in linear programming
	VALUES(5)	Weighting factor of generation MW dispatch (1.0 by default)
	VALUES(6)	Weighting factor of load control (1.0 by default)
	VALUES(7)	Weighting factor of phase shifter control (1.0 by default)
	VALUES(8)	Weighting factor of generation MW dispatch of off-line generators (1.0 by default)
	VALUES(9)	Weighting factor of tap setting adjustment (1.0 by default)
	VALUES(10)	Weighting factor of switched shunt control (1.0 by default)
Character*32 LABELS (7)	array of elements specifying subsystem labels (input).	
	LABELS(1)	The label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation output (blank for none).
	LABELS(2)	The label of generation dispatch control system. MW injections of the generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(3)	The label of load control system. Loads in the load control system are available for curtailment in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(4)	The label of phase shifter adjustment system. The phase angles of phase shifters in the system are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(5)	The label of generation MW control of off-line generator control system. MW injections of the off-line generators within the system are available for dispatch in the corrective ac-

		tion mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(6)	The label of tap adjustment system. The tap positions of transformers in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(7)	The label of switched shunt control system. The admittances of switched shunts in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	Is the name of contingency analysis output file (input; no default allowed).	
Character*260 CONFILE	Is the name of Contingency Description Data File for the second N-1 contingencies (blank for none) (input).	
Character*260 THRFILE	Is the name of Load Throwover Data File (blank for none). (input).	
Character*260 INLFILE	Is the name of Unit Inertia Data File (blank for none). (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	no Distribution Factor Data File specified
	IERR = 11	no Contingency Analysis Output File specified
	IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
	IERR = 13	No second N-1 contingencies are specified
	IERR = 14	Invalid base/contingency case flag combination.
	IERR = 15	Invalid OPTCOR value

IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Distribution Factor Data File
IERR = 52	error opening Load Throwover Data File
IERR = 53	error opening Unit Inertia and Governor Data File
IERR = 54	prerequisite requirements for API are not met

1.1.172. N11_ACCC_PSCOPF_3

The API is the second release of N-1-1 contingency analysis solution in either corrective mode or security constrained optimal power flow mode (SCOPF). In corrective mode, for each pair of N-1 contingencies a full AC load flow is performed for the first N-1 contingency; the post contingency solution is checked against the operation limits and corrective actions are specified to mitigate the limit violations; the post-corrective action solution is used as the base case for the secondary contingency and a full AC load flow is performed to solve the second N-1 contingency.

In the PSCOPF mode, a primary contingency is imposed and solved with a full AC load flow solution. A security control is conducted on the system condition existing after the primary contingency with the secondary contingencies, control adjustments are specified by security constrained optimal power flow to ensure security of the system after the primary contingency. The system condition after the primary contingency and adjustments is used as the base case for secondary contingency; a full AC load flow solution is then performed to solve a secondary N-1 contingency.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_N11_ACCC_PSCOPF_3  OPTIONS(1)..OPTIONS(16) OPTCOR(1)..OPTCOR(9)
VALUES(1)..VALUES(9) LABELS(1)..LABELS(7) DFXFILE ACCFILE CONFILE THRFILE
INLFILE
```

Python command syntax:

```
ierr = n11_accc_pscopf_3(options, optcor, values, labels, dfxfile,
accfile, confile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL N11_ACCC_PSCOPF_3(OPTIONS, OPTCOR, VALUES, LABELS, DFXFILE, ACCFILE,
CONFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (16)	array of elements specifying power flow options(input).
OPTIONS(1)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag for the first N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange

OPTIONS(3)	phase shift adjustment flag for the first N-1 contingency (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag for the first N-1 contingency (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag for the first N-1 contingency (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete.
OPTIONS(6)	induction motor treatment flag for the first N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall.
OPTIONS(6) = 1	trip.
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the second N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable.
OPTIONS(9) = 1	enable stepping adjustment.
OPTIONS(9) = 2	enable direct adjustment.
OPTIONS(10)	area interchange adjustment flag for the second N-1 contingency (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable.
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange.
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange.

	OPTIONS(11)	phase shift adjustment flag for the second N-1 contingency (phase shift adjustment option setting by default)
	OPTIONS(11) = 0	disable.
	OPTIONS(11) = 1	enable.
	OPTIONS(12)	dc tap adjustment flag for the second N-1 contingency (dc tap adjustment option setting by default)
	OPTIONS(12) = 0	disable.
	OPTIONS(12) = 1	enable.
	OPTIONS(13)	switched shunt adjustment flag for the second N-1 contingency (switched shunt adjustment option setting by default)
	OPTIONS(13) = 0	disable.
	OPTIONS(13) = 1	enable.
	OPTIONS(13) = 2	enable continuous, disable discrete.
	OPTIONS(14)	induction motor treatment flag for the second N-1 contingency (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
	OPTIONS(14) = 0	stall.
	OPTIONS(14) = 1	trip.
	OPTIONS(15)	dispatch mode (0 by default)
	OPTIONS(15) = 0	disable.
	OPTIONS(15) = 1	subsystem machines (RESERVE).
	OPTIONS(15) = 2	subsystem machines (PMAX).
	OPTIONS(15) = 3	subsystem machines (INERTIA).
	OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP).
	OPTIONS(16)	flag to skip the second N-1 contingencies if the first N-1 contingency is not clean
	OPTIONS(16) = 0	No
	OPTIONS(16) = 1	Yes
Integer OPTCOR (9)	array of elements specifying control options(input).	
	OPTCOR(1)	System adjustment mode
	OPTCOR(1) = 0	local adjustment only
	OPTCOR(1) = 1	Corrective action mode
	OPTCOR(1) = 2	Preventive security constrained optimal power flow mode
	OPTCOR(2)	maximum iteration number of PSCOPF, required if OPTCOR(1) is 2
	OPTCOR(3)	maximum number of a contingency that does not cause limit violations and instability issue to be tested in the iterative process of PSCOPF, required if OPTCOR(1) is 2.
	OPTCOR(4)	generator control flag (0 by default)

	OPTCOR(4) = 0	disable generation MW dispatch in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(4) = 1	enable
	OPTCOR(5)	load control flag (0 by default)
	OPTCOR(5) = 0	disable load shedding control in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(5) = 1	enable
	OPTCOR(6)	phase shifter control flag (1 by default)
	OPTCOR(6) = 0	disable phase shifter control in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(6) = 1	enable
	OPTCOR(7)	off-line generator control flag (0 by default)
	OPTCOR(7) = 0	disable generation MW dispatch of off-line generators in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(7) = 1	enable
	OPTCOR(8)	tap setting adjustment flag (0 by default)
	OPTCOR(8) = 0	disable tap setting adjustment in the corrective action mode or preventive security constrained optimal power flow mode
	OPTCOR(8) = 1	enable
	OPTCOR(9)	switched shunt control flag (0 by default)
	OPTCOR(9) = 0	disable switch shunt control in the corrective action mode or preventive security constrained optimal power flow
	OPTCOR(9) = 1	enable
Real VALUES (9)	array of elements specifying power flow settings(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Voltage tolerance in linear programming
	VALUES(3)	Flow tolerance in linear programming
	VALUES(4)	Weighting factor of generation MW dispatch (1.0 by default)
	VALUES(5)	Weighting factor of load control (1.0 by default)
	VALUES(6)	Weighting factor of phase shifter control (1.0 by default)
	VALUES(7)	Weighting factor of generation MW dispatch of off-line generators (1.0 by default)
	VALUES(8)	Weighting factor of tap setting adjustment (1.0 by default)

	VALUES(9)	Weighting factor of switched shunt control (1.0 by default)
Character*32 LABELS (7)	array of elements specifying subsystem labels (input).	
	LABELS(1)	The label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation output (blank for none).
	LABELS(2)	The label of generation dispatch control system. MW injections of the generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(3)	The label of load control system. Loads in the load control system are available for curtailment in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(4)	The label of phase shifter adjustment system. The phase angles of phase shifters in the system are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(5)	The label of generation MW control of off-line generator control system. MW injections of the off-line generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(6)	The label of tap adjustment system. The tap positions of transformers in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(7)	The label of switched shunt control system. The admittances of switched shunts in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 ACCFILE	Is the name of contingency analysis output file (input; no default allowed).	

Character*260 CONFILE	Is the name of Contingency Description Data File for the second N-1 contingencies (blank for none) (input).	
Character*260 THRFILE	Is the name of Load Throwover Data File (blank for none). (input).	
Character*260 INLFILE	Is the name of Unit Inertia Data File (blank for none). (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	generation dispatch subsystem is not defined
	IERR = 7	too many islands in base case
	IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 9	buses with bus type code and series element status inconsistencies
	IERR = 10	no Distribution Factor Data File specified
	IERR = 11	no Contingency Analysis Output File specified
	IERR = 12	Can not read the Contingency Description Data File for the second N-1 contingencies
	IERR = 13	No second N-1 contingencies are specified
	IERR = 14	Invalid base/contingency case flag combination.
	IERR = 15	Invalid OPTCOR value
	IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	error opening Load Throwover Data File
	IERR = 53	error opening Unit Inertia and Governor Data File
	IERR = 54	prerequisite requirements for API are not met

1.1.173. NETG

Use this API to change the in-service generation to negative MVA load at all Type 2 and 3 buses except those in the subsystem specified by the user.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_NETG  SID  ALL
```

Python command syntax:

```
ierr = netg(sid, all)
```

Fortran command syntax:

```
CALL NETGNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses outside of subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.174. NEWCAS

This API routine is obsolete. It has been replaced by the API routine [newcase_2](#).

Use this API to initialize a new power flow case. All existing working case data will be lost upon execution of this API.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_NEWCAS BASEMVA TITL1 TITL2
```

Python command syntax:

```
ierr = newcas(basemva, titl1, titl2)
```

Fortran command syntax:

```
CALL NEWCASNW(BASEMVA, TITL1, TITL2, IERR)
```

Where:

Real BASEMVA	new system base MVA. Valid base MVA values range from 1.0 to 10,000.0 (input; 100.0).	
Character*60 TITL1	first line of the new case title (input; blank by default).	
Character*60 TITL2	second line of the new case title (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid BASEMVA value
	IERR = 2	prerequisite requirements for API are not met

1.1.175. NEWCASE_2

This API is the second release of the function used to initialize a new power flow case. All existing working case data will be lost upon execution of this API.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_NEWCASE_2  OPTIONS(1)  OPTIONS(2)  BASEMVA  BASEFREQ  TITL1  TITL2
```

Python command syntax:

```
ierr = newcase_2(options, basemva, basefreq, titl1, titl2)
```

Fortran command syntax:

```
CALL NEWCASE_2(OPTIONS, BASEMVA, BASEFREQ, TITL1, TITL2, IERR)
```

Where:

Integer OPTIONS (2)	array of 2 elements specifying units for ratings (used to set the percent loading program option settings)(input). OPTIONS(1) units for transformer ratings OPTIONS(1) > 0 current expressed as MVA OPTIONS(1) < 0 MVA OPTIONS(2) units for ratings of non-transformer branches OPTIONS(2) > 0 current expressed as MVA OPTIONS(2) < 0 MVA
Real BASEMVA	system base MVA. Valid base MVA values range from 1.0 to 10,000.0 (input; 100.0).
Real BASEFREQ	system base frequency. Valid base frequency values range from greater than 0.0 to less than 100.0 (input; present base frequency option setting).
Character*60 TITL1	first line of the new case title (input; blank by default).
Character*60 TITL2	second line of the new case title (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid BASEMVA value IERR = 2 invalid BASEFREQ value IERR = 3 prerequisite requirements for API are not met

1.1.176. NEWTON_TOLERANCE

Use this API to specify or return the value of the default Newton-Raphson convergence tolerance.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_NEWTON_TOLERANCE  RVAL
```

Python command syntax:

```
ierr = newton_tolerance(rval)

ierr, rval = newton_tolerance()
```

Fortran command syntax:

```
CALL NEWTON_TOLERANCE_API(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0.1 by default; else output).								
Integer IOCODE	Indicates the operation mode of the API (no default allowed). <table> <tr> <td>IOCODE = 0</td><td>set the option setting to the value specified in RVAL.</td></tr> <tr> <td>IOCODE = 1</td><td>return the current value of the option setting in RVAL.</td></tr> </table>	IOCODE = 0	set the option setting to the value specified in RVAL.	IOCODE = 1	return the current value of the option setting in RVAL.				
IOCODE = 0	set the option setting to the value specified in RVAL.								
IOCODE = 1	return the current value of the option setting in RVAL.								
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid RVAL value</td></tr> <tr> <td>IERR = 2</td><td>invalid IOCODE value</td></tr> <tr> <td>IERR = 3</td><td>prerequisite requirements for API are not met</td></tr> </table>	IERR = 0	no error occurred	IERR = 1	invalid RVAL value	IERR = 2	invalid IOCODE value	IERR = 3	prerequisite requirements for API are not met
IERR = 0	no error occurred								
IERR = 1	invalid RVAL value								
IERR = 2	invalid IOCODE value								
IERR = 3	prerequisite requirements for API are not met								

1.1.177. NEW_DIMENSION

Use this API to reset PSSE to an increased bus size level.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_NEW_DIMENSION BUSES
```

Python command syntax:

```
ierr = new_dimension(buses)
```

Fortran command syntax:

```
CALL NEW_DIMENSION(BUSES, IERR)
```

Where:

Integer BUSES	maximum number of buses allowed at the new size level If BUSES is less than the current maximum number of buses, PSSE's capacity limits are not changed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid BUSES value
	IERR = 2	prerequisite requirements for API are not met
	IERR = 3	Unable to change network to new bus size. PSSE Xplore is limited to 50 buses.

1.1.178. NON_DIVERGENT

Use this API to specify or return the option to specify or return the option to enable or disable the non-divergent Newton power flow solution.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_NON_DIVERGENT IVAL
```

Python command syntax:

```
ierr = non_divergent(ival)
ierr, ival = non_divergent()
```

Fortran command syntax:

```
CALL NON_DIVERGENT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = 0	disable non-divergent Newton solution option.
	IVAL = 1	enable non-divergent Newton solution option.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.179. NON_TRANS_PERCENT_UNITS

Use this API to set the non-transformer branch percent units option setting to either MVA or current expressed as MVA.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_NON_TRANS_PERCENT_UNITS IVAL
```

Python command syntax:

```
ierr = non_trans_percent_units(ival)
ierr, ival = non_trans_percent_units()
```

Fortran command syntax:

```
CALL NON_TRANS_PERCENT_UNITS_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
	IVAL = 0 MVA.
	IVAL = 1 current expressed as MVA.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.180. NSOL

Use this API to apply the decoupled Newton-Raphson power flow calculation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_NSOL  OPTIONS(1)  OPTIONS(2)  OPTIONS(3)  OPTIONS(4)  OPTIONS(5)
          OPTIONS(6)  OPTIONS(7)
```

Python command syntax:

```
ierr = nsol(options)
```

Fortran command syntax:

```
CALL NSOLAPI(OPTIONS, IERR)
```

Where:

Integer OPTIONS (7)	array of 7 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (use tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (use area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (use phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (use dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (use switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	flat start flag (0 by default)
	OPTIONS(6) = 0	do not flat start
	OPTIONS(6) = 1	flat start
	OPTIONS(6) = 2	flat start, then estimate voltage magnitudes
	OPTIONS(6) = 3	flat start, then estimate voltage phase angles
	OPTIONS(6) = 4	flat start, then estimate voltage magnitudes and phase angles
	OPTIONS(7)	var limit flag (99 by default)
	OPTIONS(7) = 0	apply var limits immediately
	OPTIONS(7) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(7) = -1	ignore var limits
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	bus type code and series element status inconsistencies
	IERR = 5	prerequisite requirements for API are not met

1.1.181. NUMBER_THREADS

Use this API to specify or return the number of processors available for parallel operations.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_NUMBER_THREADS IVAL
```

Python command syntax:

```
ierr = number_threads(ival)
ierr, ival = number_threads()
```

Fortran command syntax:

```
CALL NUMBER_THREADS_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting between 1 and the number of processors of the computer (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).								
Integer IOCODE	Indicates the operation mode of the API (no default allowed). <table> <tr> <td>IOCODE = 0</td><td>set the option setting to the value specified in IVAL.</td></tr> <tr> <td>IOCODE = 1</td><td>return the current value of the option setting in IVAL.</td></tr> </table>	IOCODE = 0	set the option setting to the value specified in IVAL.	IOCODE = 1	return the current value of the option setting in IVAL.				
IOCODE = 0	set the option setting to the value specified in IVAL.								
IOCODE = 1	return the current value of the option setting in IVAL.								
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid IVAL value</td></tr> <tr> <td>IERR = 2</td><td>invalid IOCODE value</td></tr> <tr> <td>IERR = 3</td><td>prerequisite requirements for API are not met</td></tr> </table>	IERR = 0	no error occurred	IERR = 1	invalid IVAL value	IERR = 2	invalid IOCODE value	IERR = 3	prerequisite requirements for API are not met
IERR = 0	no error occurred								
IERR = 1	invalid IVAL value								
IERR = 2	invalid IOCODE value								
IERR = 3	prerequisite requirements for API are not met								

1.1.182. ORDR

Use this API to calculate a sparsity preserving ordering of buses in preparation for the processing of network matrices.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ORDR  OPT
```

Python command syntax:

```
ierr = ordr(opt)
```

Fortran command syntax:

```
CALL ORDRAPI(OPT, IERR)
```

Where:

Integer OPT	flag for ordering option (input; 0 by default).	
	OPT = 0	assume all branches between in-service buses are in-service
Integer IERR	OPT = 1	ignore out-of-service branches in calculating the bus ordering
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

1.1.183. OTDF

Use this API to tabulate vectors of distribution factors using a linear network (dc) model.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OTDF DFXFILE
```

Python command syntax:

```
ierr = otdf(dfxfilename)
```

Fortran command syntax:

```
CALL OTDFAPI(DFXFILE, IERR)
```

Where:

Character*260 DFXFILE	name of DFAX data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no DFAX data file specified
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	error opening file DFXFILE
	IERR = 5	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 6	file DFXFILE does not contain distribution factors; run DFAX with distribution factor option enabled
	IERR = 7	no monitored branches or interfaces defined
	IERR = 8	prerequisite requirements for API are not met

1.1.184. OUTPUT_Y_MATRIX

Use this API to display the network admittance matrix for a subsystem of the working case in the form of a list of matrix terms.

This API routine was first introduced in release 30.1.0.

Batch command syntax:

```
BAT_OUTPUT_Y_MATRIX SID ALL TIES OUT OFILE
```

Python command syntax:

```
ierr = output_y_matrix(sid, all, ties, out, ofile)
```

Fortran command syntax:

```
CALL OUTPUT_Y_MATRIX(SID, ALL, TIES, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only rows corresponding to buses in subsystem SID ALL = 1 process the complete case
Integer TIES	option for the omission or inclusion of off-diagonal terms corresponding to ties from the specified subsystem; ignored if ALL is 1 (input; 0 by default). TIES = 0 omit ties TIES = 1 include ties
Integer OUT	destination selection (input; 1 by default). OUT = 0 direct output to a data file specified by OFILE OUT = 1 direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid TIES value IERR = 4 invalid OUT value IERR = 5 error opening OFILE IERR = 6 prerequisite requirements for API are not met

1.1.185. OUTS

Use this API to tabulate those components in the working case that are removed from service.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OUTS  SID  ALL
```

Python command syntax:

```
ierr = outs(sid, all)
```

Fortran command syntax:

```
CALL OUTSNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
Integer IERR	ALL = 1	process all buses
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.186. OWNM

This API routine is obsolete. It has been replaced by the API routine [ownm_2](#).

Use this API routine to reassign the buses, load, machines, and branches in a specified subsystem of the working case from their original owner to a designated owner.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OWNM  SID  ALL  STATUS(1)..STATUS(7)  IONEW
```

Python command syntax:

```
ierr = ownm(sid, all, status, ionew)
```

Fortran command syntax:

```
CALL OWNMAPI(SID, ALL, STATUS, IONEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS (7)	array of 7 elements specifying They are used to control reassignment options(input).	
	STATUS(1)	bus owners to IONEW (0 by default)
	STATUS(1) = 0	leave bus ownership unchanged
	STATUS(1) = 1	Change bus owners to IONEW
	STATUS(2)	load owners to IONEW (0 by default)
	STATUS(2) = 0	leave load ownership unchanged
	STATUS(2) = 1	change load owners to IONEW
	STATUS(3)	machine owners to IONEW (0 by default)
	STATUS(3) = 0	leave machine ownership unchanged
	STATUS(3) = 1	change machine owners to IONEW
	STATUS(4)	branch owners to IONEW (0 by default)
	STATUS(4) = 0	leave branch ownership unchanged
	STATUS(4) = 1	change branch owners to IONEW
	STATUS(5)	FACTS device owners to IONEW (0 by default)
	STATUS(5) = 0	leave FACTS device ownership unchanged
	STATUS(5) = 1	change FACTS device owners to IONEW
	STATUS(6)	VSC dc line owners to IONEW (0 by default)
	STATUS(6) = 0	leave VSC dc line ownership unchanged

	STATUS(6) = 1	change VSC dc line owners to IONEW
	STATUS(7)	branch, series FACTS device, VSC dc line option (1 by default)
	STATUS(7) = 1	subsystem branches only
	STATUS(7) = 2	subsystem ties only
	STATUS(7) = 3	both subsystem branches and ties
Integer IONEW	new owner to which the specified equipment items are to be assigned. IONEW must be between 1 and 9999 (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid new owner number
	IERR = 5	owner table is full; cannot add owner to the working case
	IERR = 6	prerequisite requirements for API are not met

1.1.187. OWNM_2

This API routine is obsolete. It has been replaced by the API routine [ownm_3](#).

This API routine is the second release of the owner renumbering function. Use this API routine to reassign the buses, loads, machines, branches, FACTS devices, VSC dc lines, and/or GNE devices in a specified subsystem of the working case from their original owner to a designated owner.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_OWNM_2  SID  ALL  STATUS(1)..STATUS(8)  IONEW
```

Python command syntax:

```
ierr = ownm_2(sid, all, status, ionew)
```

Fortran command syntax:

```
CALL OWNMAPI_2(SID, ALL, STATUS, IONEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS (8)	array of 8 elements specifying They are used to control reassignment options(input).	
	STATUS(1)	bus owners to IONEW (0 by default)
	STATUS(1) = 0	leave bus ownership unchanged
	STATUS(1) = 1	Change bus owners to IONEW
	STATUS(2)	load owners to IONEW (0 by default)
	STATUS(2) = 0	leave load ownership unchanged
	STATUS(2) = 1	change load owners to IONEW
	STATUS(3)	machine owners to IONEW (0 by default)
	STATUS(3) = 0	leave machine ownership unchanged
	STATUS(3) = 1	change machine owners to IONEW
	STATUS(4)	branch owners to IONEW (0 by default)
	STATUS(4) = 0	leave branch ownership unchanged
	STATUS(4) = 1	change branch owners to IONEW
	STATUS(5)	FACTS device owners to IONEW (0 by default)
	STATUS(5) = 0	leave FACTS device ownership unchanged
	STATUS(5) = 1	change FACTS device owners to IONEW
	STATUS(6)	VSC dc line owners to IONEW (0 by default)

	STATUS(6) = 0	leave VSC dc line ownership unchanged
	STATUS(6) = 1	change VSC dc line owners to IONEW
	STATUS(7)	GNE device owners to IONEW (0 by default)
	STATUS(7) = 0	leave GNE device ownership unchanged
	STATUS(7) = 1	change GNE device owners to IONEW
	STATUS(8)	branch, series FACTS device, VSC dc line, and series GNE device option (1 by default)
	STATUS(8) = 1	subsystem branches only
	STATUS(8) = 2	subsystem ties only
	STATUS(8) = 3	both subsystem branches and ties
Integer IONEW	new owner to which the specified equipment items are to be assigned. IONEW must be between 1 and 9999 (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid new owner number
	IERR = 5	owner table is full; cannot add owner to the working case
	IERR = 6	prerequisite requirements for API are not met

1.1.188. OWNM_3

This API routine is the third release of the owner renumbering function. Use this API routine to reassign the buses, loads, machines, induction machines, branches, FACTS devices, VSC dc lines, and/or GNE devices in a specified subsystem of the working case from their original owner to a designated owner.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_OWNM_3  SID  ALL  STATUS(1)..STATUS(9)  IONEW
```

Python command syntax:

```
ierr = ownm_3(sid, all, status, ionew)
```

Fortran command syntax:

```
CALL OWNM_3(SID, ALL, STATUS, IONEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS (9)	array of 9 elements specifying They are used to control reassignment options(input).	
	STATUS(1)	bus owners to IONEW (0 by default)
	STATUS(1) = 0	leave bus ownership unchanged
	STATUS(1) = 1	change bus owners to IONEW
	STATUS(2)	load owners to IONEW (0 by default)
	STATUS(2) = 0	leave load ownership unchanged
	STATUS(2) = 1	change load owners to IONEW
	STATUS(3)	machine owners to IONEW (0 by default)
	STATUS(3) = 0	leave machine ownership unchanged
	STATUS(3) = 1	change machine owners to IONEW
	STATUS(4)	induction machine owners to IONEW (0 by default)
	STATUS(4) = 0	leave induction machine ownership unchanged
	STATUS(4) = 1	change induction machine owners to IONEW
	STATUS(5)	branch owners to IONEW (0 by default)
	STATUS(5) = 0	leave branch ownership unchanged
	STATUS(5) = 1	change branch owners to IONEW
	STATUS(6)	FACTS device owners to IONEW (0 by default)
	STATUS(6) = 0	leave FACTS device ownership unchanged

	STATUS(6) = 1	change FACTS device owners to IONEW
	STATUS(7)	VSC dc line owners to IONEW (0 by default)
	STATUS(7) = 0	leave VSC dc line ownership unchanged
	STATUS(7) = 1	change VSC dc line owners to IONEW
	STATUS(8)	GNE device owners to IONEW (0 by default)
	STATUS(8) = 0	leave GNE device ownership unchanged
	STATUS(8) = 1	change GNE device owners to IONEW
	STATUS(9)	branch, series FACTS device, VSC dc line, and series GNE device option (1 by default)
	STATUS(9) = 1	subsystem branches only
	STATUS(9) = 2	subsystem ties only
	STATUS(9) = 3	both subsystem branches and ties
Integer IONEW	new owner to which the specified equipment items are to be assigned. IONEW must be between 1 and 9999 (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid new owner number
	IERR = 5	owner table is full; cannot add owner to the working case
	IERR = 6	prerequisite requirements for API are not met

1.1.189. OWNR

Use this API to tabulate owner totals by owner.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OWNR  SID  ALL
```

Python command syntax:

```
ierr = ownr(sid, all)
```

Fortran command syntax:

```
CALL OWNRNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Owner subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all owners or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only owners in owner subsystem SID
Integer IERR	ALL = 1	process all owners
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.190. PATH

Use this API to specify a directory pathname. Then, whenever a simple filename preceded by an ampersand (for example, &myfile) is specified as input to a PSSE API, the file is opened in the directory specified rather than in the user's current directory.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_PATH  PATHNAME
```

Python command syntax:

```
ierr = path(pathname)
```

Fortran command syntax:

```
CALL PATHAPI(PATHNAME, IERR)
```

Where:

Character*260 PATHNAME	name of path to be used (blank to disable) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error setting path PATHNAME
	IERR = 2	prerequisite requirements for API are not met

1.1.191. PHASE_SHIFT_ADJUSTMENT

Use this API to specify or return the option to enable or disable the phase shift adjustment.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_PHASE_SHIFT_ADJUSTMENT IVAL
```

Python command syntax:

```
ierr = phase_shift_adjustment(ival)
ierr, ival = phase_shift_adjustment()
```

Fortran command syntax:

```
CALL PHASE_SHIFT_ADJUSTMENT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 disabled.
	IVAL = 1 enabled.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.192. POLY

Use this API to calculate interchange limits of a study system against two opposing systems using a linear network (dc) model.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_POLY  OPTIONS(1)..OPTIONS(15)  VALUES(1)..VALUES(6)
          LABELS(1)..LABELS(3)  DFXFILE  RESFILE
```

Python command syntax:

```
ierr = poly(options, values, labels, dfxfile, resfile)
```

Fortran command syntax:

```
CALL POLYAPI(OPTIONS, VALUES, LABELS, DFXFILE, RESFILE, IERR)
```

Where:

Integer OPTIONS (15)	array of 15 elements specifying calculation and reporting options(input).
OPTIONS(1)	base case rating set (rating set program option setting by default)
OPTIONS(1) = 1	RATEA
OPTIONS(1) = 2	RATEB
OPTIONS(1) = 3	RATEC
OPTIONS(2)	contingency case rating set (rating set program option setting by default)
OPTIONS(2) = 1	RATEA
OPTIONS(2) = 2	RATEB
OPTIONS(2) = 3	RATEC
OPTIONS(3)	base case line flow code (0 by default)
OPTIONS(3) = 0	dc base case
OPTIONS(3) = 1	ac base case
OPTIONS(4)	phase shifter code (0 by default)
OPTIONS(4) = 0	locked in base case shift solutions
OPTIONS(4) = 1	regulating in base case shift solutions
OPTIONS(5)	code for the treatment of base case line flow constraints in contingency cases (0 by default)
OPTIONS(5) = 0	ignore
OPTIONS(5) = 1	include
OPTIONS(6)	list study system buses (0 by default)
OPTIONS(6) = 0	no
OPTIONS(6) = 1	yes
OPTIONS(7)	list opposing system buses (0 by default)
OPTIONS(7) = 0	no

	OPTIONS(7) = 1	yes
	OPTIONS(8)	list study system tie lines (0 by default)
	OPTIONS(8) = 0	no
	OPTIONS(8) = 1	yes
	OPTIONS(9)	add study system tie lines to monitored line list (0 by default)
	OPTIONS(9) = 0	no
	OPTIONS(9) = 1	yes
	OPTIONS(10)	format code (0 by default)
	OPTIONS(10) = 0	summary output
	OPTIONS(10) = 1	full output
	OPTIONS(11)	convert MVA ratings to estimated MW ratings (0 by default)
	OPTIONS(11) = 0	no
	OPTIONS(11) = 1	yes
	OPTIONS(12)	discontinue activity if MW mismatch exceeds VALUES(1) (0 by default)
	OPTIONS(12) = 0	discontinue
	OPTIONS(12) = 1	continue
	OPTIONS(13)	graphical option (0 by default)
	OPTIONS(13) = 0	plot combined case only
	OPTIONS(13) = 1	plot combined case only
	OPTIONS(13) = 2	plot for all system conditions
	OPTIONS(14)	option for plotting constraints (0 by default)
	OPTIONS(14) = 0	plot all constraints
	OPTIONS(14) = 1	plot only constraints forming the boundary of the feasible region
	OPTIONS(15)	graphical format (0 by default)
	OPTIONS(15) = 0	single page per case
	OPTIONS(15) = 1	two pages per case
Real VALUES (6)	array of 6 elements specifying tolerances and thresholds(input).	
	VALUES(1)	required MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating for reporting an element as overloaded (100.0 by default)
	VALUES(3)	maximum opposing system generation shift (10000.0 by default)
	VALUES(4)	maximum opposing system delta interchange for plotting (1000.0 by default)
	VALUES(5)	minimum distribution factor magnitude (0.0 by default)
	VALUES(6)	study system generation shift (100.0 by default)

Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).
	LABELS(1) study system label (no default allowed)
	LABELS(2) first opposing system label (no default allowed)
	LABELS(3) second opposing system label (no default allowed)
Character*260 DFXFILE	name of DFAX data file (input; no default allowed).
Character*260 RESFILE	name of POLY results file (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid OPTIONS value
	IERR = 2 invalid VALUES value
	IERR = 3 no Distribution Factor Data File specified
	IERR = 4 same label specified for at least two subsystems
	IERR = 5 no POLY Results Output File specified
	IERR = 6 generators are converted
	IERR = 7 buses in island(s) without a swing bus; use activity TREE
	IERR = 8 largest mismatch exceeds mismatch tolerance
	IERR = 9 error opening file DFXFILE
	IERR = 10 file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 11 file DFXFILE does not contain distribution factors; run DFAX with distribution factor option enabled
	IERR = 12 no monitored branches or interfaces defined
	IERR = 13 no subsystems defined
	IERR = 14 subsystem not found
	IERR = 15 specified subsystems overlap
	IERR = 16 no in-service buses in subsystem WORLD
	IERR = 17 no tie lines from study system
	IERR = 18 only one subsystem defined
	IERR = 19 prerequisite requirements for API are not met

1.1.193. POUT

Use this API to print the power flow solution results with boundary condition and flow information on the left side of the report and other information on the right side.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_POUT  SID  ALL
```

Python command syntax:

```
ierr = pout(sid, all)
```

Fortran command syntax:

```
CALL POUTNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.194. POWER_OUTPUT

Use this API to specify or return the option to display power output in either MVA or kVA.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_POWER_OUTPUT IVAL
```

Python command syntax:

```
ierr = power_output(ival)
ierr, ival = power_output()
```

Fortran command syntax:

```
CALL POWER_OUTPUT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
	IVAL = 0 kVA.
	IVAL = 1 MVA.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.195. PP_ACCC

Use this API to report the results of the AC contingency calculation function.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PP_ACCC  OPTIONS(1)..OPTIONS(5)  INTVAL(1)..INTVAL(5)
              REALVAL(1)..REALVAL(6) ACCFILE
```

Python command syntax:

```
ierr = pp_accs(options, intval, realval, accfile)
```

Fortran command syntax:

```
CALL PP_ACCC(OPTIONS, INTVAL, REALVAL, ACCFILE, IERR)
```

Where:

Integer OPTIONS (5)	array of 5 elements specifying reporting options(input).
OPTIONS(1)	contingency case rating (rating set program option setting by default)
OPTIONS(1) = 0	RATEA
OPTIONS(1) = 1	RATEB
OPTIONS(1) = 2	RATEC
OPTIONS(2)	report format (3 by default)
OPTIONS(2) = 0	spreadsheet overload report
OPTIONS(2) = 1	spreadsheet loading table
OPTIONS(2) = 2	available capacity table
OPTIONS(2) = 3	non-spreadsheet overload report
OPTIONS(2) = 4	non-spreadsheet loading table
OPTIONS(2) = 5	non-converged networks report
OPTIONS(3)	exclude interfaces from report (0 by default)
OPTIONS(3) = 0	no
OPTIONS(3) = 1	yes
OPTIONS(4)	run voltage limit check (0 by default)
OPTIONS(4) = 0	no
OPTIONS(4) = 1	yes
OPTIONS(5)	exclude cases with no overloads from non-spreadsheet overload report (0 by default)
OPTIONS(5) = 0	no
OPTIONS(5) = 1	yes
Integer INTVAL (5)	array of 5 elements specifying integer reporting parameters(input).
INTVAL(1)	number of low voltage range violations (0 by default)
INTVAL(2)	number of high voltage range violations (0 by default)

	INTVAL(3)	number of voltage deviation violations (0 by default)
	INTVAL(4)	number of buses in the largest disconnected island (0 by default)
	INTVAL(5)	maximum number of elements in available capacity table (no limit by default)
Real REALVAL (6)	array of 6 elements specifying real reporting parameters(input).	
	REALVAL(1)	percent of flow rating (100.0 by default)
	REALVAL(2)	minimum contingency case flow change for overload report (0.0 by default)
	REALVAL(3)	cutoff threshold for available capacity table (99999.0 by default)
	REALVAL(4)	minimum contingency case voltage change for range violations (0.0 by default)
	REALVAL(5)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	REALVAL(6)	system mismatch converged tolerance (MVA) (5.0 by default)
Character*260 ACCFILE	name of the contingency solution output file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid INTVAL value
	IERR = 3	invalid REALVAL value
	IERR = 4	error opening RFILE
	IERR = 5	error reading RFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.196. PP_ACCC_MULTI_CASE

This API routine is obsolete. It has been replaced by the API routine [acc_multiple_run_report](#).

Use this API to report the results of up to nine executions of the AC contingency calculation function.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_PP_ACCC_MULTI_CASE  OPTIONS(1)..OPTIONS(11)  VALUES(1)..VALUES(6)
  NFILES  ACCFILES(1)..ACCFILES(NFILES)
```

Python command syntax:

```
ierr = pp_accc_multi_case(options, values, nfiles, accfiles)
```

Fortran command syntax:

```
CALL PP_ACCC_MULTI_CASE(OPTIONS, VALUES, NFILES, ACCFILES, IERR)
```

Where:

Integer OPTIONS (11)	array of 11 elements specifying reporting options(input).
OPTIONS(1)	column headings code (1 by default)
OPTIONS(1) = 1	contingency solution output file names
OPTIONS(1) = 2	saved case file names as contained in the contingency solution output files
OPTIONS(2)	rating set (rating set program option setting by default)
OPTIONS(2) = 1	RateA
OPTIONS(2) = 2	RateB
OPTIONS(2) = 3	RateC
OPTIONS(3)	print monitored elements summary report (0 by default)
OPTIONS(3) = 0	no
OPTIONS(3) = 1	yes
OPTIONS(4)	print missing monitored elements report (0 by default)
OPTIONS(4) = 0	no
OPTIONS(4) = 1	yes
OPTIONS(5)	print missing monitored voltage buses report (0 by default)
OPTIONS(5) = 0	no
OPTIONS(5) = 1	yes
OPTIONS(6)	print contingency legend (2 by default)
OPTIONS(6) = 0	no
OPTIONS(6) = 1	complete master legend report only
OPTIONS(6) = 2	reduced legend with each table

	OPTIONS(6) = 3	both master legend report and legend with each table
	OPTIONS(7)	print missing contingencies report (0 by default)
	OPTIONS(7) = 0	no
	OPTIONS(7) = 1	yes
	OPTIONS(8)	print non-converged contingencies report (0 by default)
	OPTIONS(8) = 0	no
	OPTIONS(8) = 1	yes
	OPTIONS(9)	print loading violation reports (0 by default)
	OPTIONS(9) = 0	no
	OPTIONS(9) = 1	base case and worst case contingency violations only
	OPTIONS(9) = 2	base case and all contingency violations only
	OPTIONS(9) = 3	base case, worst case contingency, and all contingency violations
	OPTIONS(10)	print voltage violation reports (0 by default)
	OPTIONS(10) = 0	no
	OPTIONS(10) = 1	base case and worst case contingency violations only
	OPTIONS(10) = 2	base case and all contingency violations only
	OPTIONS(10) = 3	base case, worst case contingency, and all contingency violations
	OPTIONS(11)	option for processing interfaces in loading violation reports (1 by default)
	OPTIONS(11) = 0	exclude interfaces from loading violation checking and reporting
	OPTIONS(11) = 1	check and report interface loading violations
Real VALUES (6)	array of 6 elements specifying integer reporting parameters(input).	
	VALUES(1)	percent of flow rating for reporting (100.0 by default)
	VALUES(2)	percent of flow rating for counting in worst case contingency violations report (> VALUES(1)) (100.0 by default)
	VALUES(3)	minimum contingency case flow change for reporting and counting (0.0 by default)
	VALUES(4)	minimum contingency case voltage change for reporting and counting in voltage range violations (0.0 by default)
	VALUES(5)	bus mismatch converged tolerance (MW or Mvar) (0.5 by default)
	VALUES(6)	system mismatch converged tolerance (MVA) (5.0 by default)

Integer NFILES	number of contingency solution output files to be processed (1 through 9) (input; no default allowed).
Character*260 ACCFILES (NFILES)	NFILES names of contingency solution output files (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid OPTIONS value
IERR = 2	invalid VALUES value
IERR = 3	invalid NFILES value
IERR = 4	the percent for counting is less than the percent for reporting
IERR = 5	file is not in the form of a current contingency solution output file
IERR = 6	error opening a contingency solution output file
IERR = 7	error reading a contingency solution output file
IERR = 8	error opening a temporary file
IERR = 9	error opening a subfile in the temporary file
IERR = 10	error reading or writing the temporary file
IERR = 11	error closing a subfile in the temporary file
IERR = 12	prerequisite requirements for API are not met

1.1.197. PRINT_OUTAGED_BRANCHES

Use this API to specify or return the option to enable or disable whether to print out-of-service branches.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PRINT_OUTAGED_BRANCHES IVAL
```

Python command syntax:

```
ierr = print_outaged_branches(ival)
ierr, ival = print_outaged_branches()
```

Fortran command syntax:

```
CALL PRINT_OUTAGED_BRANCHES_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = 0	do not print out-of-service branches.
	IVAL = 1	print out-of-service branches.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.198. PRINT_WINDING_BUSES

Use this API to specify or return the option to enable or disable whether to print winding "to" buses of three-winding transformers.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PRINT_WINDING_BUSES IVAL
```

Python command syntax:

```
ierr = print_winding_buses(ival)
ierr, ival = print_winding_buses()
```

Fortran command syntax:

```
CALL PRINT_WINDING_BUSES_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = 0	do not print winding "to" buses.
	IVAL = 1	print winding "to" buses.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.199. PROGRESS_OUTPUT

Use this API to specify the progress output device.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PROGRESS_OUTPUT ISLCT FILARG OPTIONS(1) OPTIONS(2)
```

Python command syntax:

```
ierr = progress_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL OPENPROGRESSDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
ISLCT = 1	standard destination. In the PSSE GUI standard output for progress is the Progress tab of the output bar.
ISLCT = 2	direct output to a file.
ISLCT = 3	direct output to a printer.
ISLCT = 4	direct output to progress device.
ISLCT = 5	direct output to report device.
ISLCT = 6	no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
OPTIONS(1)	file and printer open options: The OPTIONS(1) values may be summed to select multiple options
OPTIONS(1) = 0	open with carriage control format and, for files, for overwrite of existing files
OPTIONS(1) = 1	open with list format
OPTIONS(1) = 2	open file for append (file output only)
OPTIONS(1) = 2	set printer orientation to portrait mode (printer output only)
OPTIONS(1) = 4	open printer in immediate print mode (printer output only)
OPTIONS(2)	number of copies to print (printer only)
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	prerequisite requirements for API are not met
IERR = 2	failed to open device

1.1.200. PROMPT_OUTPUT

Use this API to specify the prompt output device.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PROMPT_OUTPUT ISLCT FILARG OPTIONS(1) OPTIONS(2)
```

Python command syntax:

```
ierr = prompt_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL OPENPROMPTDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
	ISLCT = 1 standard destination. In the PSSE GUI standard output for prompts is the input window generated by user input requests.
	ISLCT = 2 direct output to a file.
	ISLCT = 3 direct output to a printer.
	ISLCT = 4 direct output to progress device.
	ISLCT = 5 direct output to report device.
	ISLCT = 6 no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
	OPTIONS(1) file and printer open options: The OPTIONS(1) values may be summed to select multiple options
	OPTIONS(1) = 0 open with carriage control format and, for files, for overwrite of existing files
	OPTIONS(1) = 1 open with list format
	OPTIONS(1) = 2 open file for append (file output only)
	OPTIONS(1) = 2 set printer orientation to portrait mode (printer output only)
	OPTIONS(1) = 4 open printer in immediate print mode (printer output only)
	OPTIONS(2) number of copies to print (printer only)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met
	IERR = 2 failed to open device

1.1.201. PRTI

Use this API to print the 16 line long title.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_PRTI
```

Python command syntax:

```
ierr = prt_i()
```

Fortran command syntax:

```
CALL PRTIAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.202. PSCOPF

This API routine is obsolete. It has been replaced by the API routine [pscopf_2](#).

This API is used to find the settings of controls for a system to comply with base case and contingency case operation limits. The API is implemented with preventive security constrained optimal power flow method (PSCOPF). The objective of the PSCOPF is to minimize control adjustments subject to operation limits constraints. The available controls are generation MW outputs of on-line and off-line generators, loads, phase shifters, tap settings and switched shunts.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_PSCOPF  OPTIONS(1)..OPTIONS(26) VALUES(1)..VALUES(11)
           LABELS(1)..LABELS(7) DFXFILE INLFILE THRFILE
```

Python command syntax:

```
ierr = pscopf(options, values, labels, dfxfile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL PSCOPFAPI(OPTIONS, VALUES, LABELS, DFXFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (26)	array of 26 elements specifying integer specifying power flow options(input).	
	OPTIONS(1)	tap adjustment flag for the base case (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag for the base case (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag for the base case (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	dc tap adjustment flag for the base case (dc tap adjustment option setting by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable

OPTIONS(5)	switched shunt adjustment flag for the base case (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete
OPTIONS(6)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable
OPTIONS(9) = 1	enable stepping adjustment
OPTIONS(9) = 2	enable direct adjustment
OPTIONS(10)	area interchange adjustment flag for the contingency case (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(11)	phase shift adjustment flag for the contingency case (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable
OPTIONS(11) = 1	enable
OPTIONS(12)	dc tap adjustment flag for the contingency case (dc tap adjustment option setting by default)
OPTIONS(12) = 0	disable
OPTIONS(12) = 1	enable

OPTIONS(13)	switched shunt adjustment flag for the contingency case (switched shunt adjustment option setting by default)
OPTIONS(13) = 0	disable
OPTIONS(13) = 1	enable
OPTIONS(13) = 2	enable continuous, disable discrete
OPTIONS(14)	induction motor treatment flag for the contingency case (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(14) = 0	stall
OPTIONS(14) = 1	trip
OPTIONS(15)	dispatch mode (0 by default)
OPTIONS(15) = 0	disable
OPTIONS(15) = 1	subsystem machines (RESERVE)
OPTIONS(15) = 2	subsystem machines (PMAX)
OPTIONS(15) = 3	subsystem machines (INERTIA)
OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP)
OPTIONS(16)	Rating set for the base case
OPTIONS(16) = 1	RATE A
OPTIONS(16) = 2	RATE B
OPTIONS(16) = 3	RATE C
OPTIONS(17)	Rating set for the contingency case
OPTIONS(17) = 1	RATE A
OPTIONS(17) = 2	RATE B
OPTIONS(17) = 3	RATE C
OPTIONS(18)	maximum iteration number of PSCOPF
OPTIONS(18) = 1	RATE A
OPTIONS(18) = 2	RATE B
OPTIONS(18) = 3	RATE C
OPTIONS(19)	maximum number of a contingency that does not cause limit violations and instability issue to be tested in the iterative process of PSCOPF
OPTIONS(20)	Handle initial violations in the base case
OPTIONS(20) = 0	Ignore the initial violations in the base case from the PSCOPF analysis
OPTIONS(20) = 1	Clean the initial violations in the base case
OPTIONS(21)	generator control flag (1 by default)
OPTIONS(21) = 0	disable generation MW dispatch
OPTIONS(21) = 1	enable
OPTIONS(22)	load control flag (0 by default)
OPTIONS(22) = 0	disable load shedding control
OPTIONS(22) = 1	enable
OPTIONS(23)	phase shifter control flag (1 by default)

	OPTIONS(23) = 0	disable phase shifter control
	OPTIONS(23) = 1	enable
	OPTIONS(24)	off-line generator control flag (0 by default)
	OPTIONS(24) = 0	disable generation MW dispatch of off-line generators
	OPTIONS(24) = 1	enable
	OPTIONS(25)	tap setting adjustment flag (0 by default)
	OPTIONS(25) = 0	disable tap setting adjustment
	OPTIONS(25) = 1	enable
	OPTIONS(26)	switched shunt control flag (0 by default)
	OPTIONS(26) = 0	disable switch shunt control
	OPTIONS(26) = 1	enable
Real VALUES (11)	array of 11 elements specifying VALUES is a real(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Percentage of rating for the base case (100.0 by default)
	VALUES(3)	Percentage of rating for the contingency cases (100.0 by default)
	VALUES(4)	Voltage tolerance in linear programming
	VALUES(5)	Flow tolerance in linear programming
	VALUES(6)	Weighting factor of generation MW dispatch (1.0 by default)
	VALUES(7)	Weighting factor of load control (1.0 by default)
	VALUES(8)	Weighting factor of phase shifter control (1.0 by default)
	VALUES(9)	Weighting factor of generation MW dispatch of off-line generators (1.0 by default)
	VALUES(10)	Weighting factor of tap setting adjustment (1.0 by default)
	VALUES(11)	Weighting factor of switched shunt control (1.0 by default)
Character*32 LABELS (7)	array of 7 elements specifying a character(input).	
	LABELS(1)	label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation (blank for none by default)
	LABELS(2)	label of generation dispatch control system. MW injections of the generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none by default)

LABELS(3)	label of load control system. Loads in the load control system are available for curtailment in the corrective action mode or preventive security constrained optimal power flow mode (blank for none by default)
LABELS(4)	label of phase shifter adjustment system. The phase angles of phase shifters in the system are regulated either by corrective action or preventive security constrained optimal power flow (blank for none by default)
LABELS(5)	label of generation MW control of off-line generator control system. MW injections of the off-line generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none by default)
LABELS(6)	label of tap adjustment system. The tap positions of transformers in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none by default)
LABELS(7)	label of switched shunt control system. The admittances of switched shunts in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none by default)
Character*260 DFXFILE	name of the Distribution Factor Data File (input; no default allowed).
Character*260 INLFILE	name of Unit Inertia Data File (input; blank for none).
Character*260 THRFILE	name of Load Throwover Data File (input; blank for none).
Integer IERR	error code (output).
IERR = -2	PSCOPF terminates with active constraints
IERR = -1	PSCOPF reaches the maximum iteration
IERR = 0	No error
IERR = 1	Invalid OPTIONS value
IERR = 2	Invalid VALUES value
IERR = 3	Generators are converted
IERR = 4	Buses in island(s) without a swing bus--use activity TREE
IERR = 5	Largest mismatch exceeds tolerance
IERR = 6	Generation subsystem not specified
IERR = 7	Too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state

IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	No Distribution Factor Data input file specified
IERR = 11	No controls are specified
IERR = 12	No constraints are specified
IERR = 13	Invalid base/contingency case flag combination
IERR = 21	File is not in the form of a PSSE-25 or later DFAX file--run DFAX
IERR = 22	Monitored elements exceed limit when adding multi-section line members
IERR = 51	Error opening distribution factor data file
IERR = 52	Error opening load throwover data file
IERR = 53	Error opening inertia data file
IERR = 54	Prerequisite requirements for function not met

1.1.203. PSCOPF_2

This API is the second release of Preventive Security Constrained Optimal Power Flow solution (PSCOPF). This API is used to find the settings of controls for a system to comply with base case and contingency case operation limits. The API is implemented with preventive security constrained optimal power flow method (PSCOPF). The objective of the PSCOPF is to minimize control adjustments subject to operation limits constraints. The available controls are generation MW outputs of on-line and off-line generators, loads, phase shifters, tap settings and switched shunts.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_PSCOPF_2  OPTIONS(1)..OPTIONS(28) VALUES(1)..VALUES(11)
              LABELS(1)..LABELS(7) DFXFILE INLFILE THRFILE
```

Python command syntax:

```
ierr = pscopf_2(options, values, labels, dfxfile, inlfile, thrfile)
```

Fortran command syntax:

```
CALL PSCOPF_API_2(OPTIONS, VALUES, LABELS, DFXFILE, INLFILE, THRFILE, IERR)
```

Where:

Integer OPTIONS (28)	array of elements specifying power flow options(input).
OPTIONS(1)	tap adjustment flag for the base case (tap adjustment option by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag for the base case (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange.
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag for the base case (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag for the base case (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable

OPTIONS(5)	switched shunt adjustment flag for the base case (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable all
OPTIONS(5) = 2	enable continuous, disable discrete.
OPTIONS(6)	induction motor treatment flag (applied when an induction motor fails to solve due to low terminal bus voltage, 0 by default)
OPTIONS(6) = 0	stall.
OPTIONS(6) = 1	trip.
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	Fixed slope decoupled Newton-Raphson method
OPTIONS(7) = 1	Full Newton-Raphson method
OPTIONS(7) = 2	Optimized fixed slope decoupled Newton-Raphson method
OPTIONS(8)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(8) = 0	Disable
OPTIONS(8) = 1	Enable
OPTIONS(9)	tap adjustment flag for the first N-1 contingency (tap adjustment option setting by default)
OPTIONS(9) = 0	disable.
OPTIONS(9) = 1	enable stepping adjustment.
OPTIONS(9) = 2	enable direct adjustment.
OPTIONS(10)	area interchange adjustment flag for the contingency case (area interchange adjustment option setting by default)
OPTIONS(10) = 0	disable.
OPTIONS(10) = 1	enable using tie line flows only in calculating area interchange.
OPTIONS(10) = 2	enable using tie line flows and loads in calculating area interchange.
OPTIONS(11)	phase shift adjustment flag for the contingency case (phase shift adjustment option setting by default)
OPTIONS(11) = 0	disable.
OPTIONS(11) = 1	enable.
OPTIONS(12)	dc tap adjustment flag for the contingency case (dc tap adjustment option setting by default)
OPTIONS(12) = 0	disable.
OPTIONS(12) = 1	enable.

OPTIONS(13)	switched shunt adjustment flag for the contingency case (switched shunt adjustment option setting by default)
OPTIONS(13) = 0	disable.
OPTIONS(13) = 1	enable.
OPTIONS(13) = 2	enable continuous, disable discrete.
OPTIONS(14)	induction motor treatment flag for the contingency case(applied when an induction motor fails to solve due to low terminal bus voltage) (0 by default)
OPTIONS(14) = 0	stall.
OPTIONS(14) = 1	trip.
OPTIONS(15)	dispatch mode (0 by default)
OPTIONS(15) = 0	disable.
OPTIONS(15) = 1	subsystem machines (RESERVE).
OPTIONS(15) = 2	subsystem machines (PMAX).
OPTIONS(15) = 3	subsystem machines (INERTIA).
OPTIONS(15) = 4	subsystem machines (GOVERNOR DROOP).
OPTIONS(16)	Rating set for the base case
OPTIONS(16) = 1	rate A
OPTIONS(16) = 2	rate B
OPTIONS(16) = 3	rate C
OPTIONS(17)	Rating set for the contingency case
OPTIONS(17) = 1	rate A
OPTIONS(17) = 2	rate B
OPTIONS(17) = 3	rate C
OPTIONS(18)	base case voltage limit
OPTIONS(18) = 1	normal
OPTIONS(18) = 2	emergency
OPTIONS(19)	contingency case voltage limit
OPTIONS(19) = 1	normal
OPTIONS(19) = 2	emergency
OPTIONS(20)	maximum iteration number of PSCOPF
OPTIONS(21)	maximum number of a contingency that does not cause limit violations and instability issue to be tested in the iterative process of PSCOPF
OPTIONS(22)	Handle initial violations in the base case
OPTIONS(22) = 0	Ignore the initial violations in the base case from the PSCOPF analysis
OPTIONS(22) = 1	Clean the initial violations in the base case
OPTIONS(23)	generator control flag (1 by default)
OPTIONS(23) = 0	disable generation MW dispatch
OPTIONS(23) = 1	enable
OPTIONS(24)	load control flag (0 by default)

	OPTIONS(24) = 0	disable load shedding control
	OPTIONS(24) = 1	enable
	OPTIONS(25)	phase shifter control flag (1 by default)
	OPTIONS(25) = 0	disable phase shifter control
	OPTIONS(25) = 1	enable
	OPTIONS(26)	off-line generator control flag (0 by default)
	OPTIONS(26) = 0	disable generation MW dispatch of off-line generators
	OPTIONS(26) = 1	enable
	OPTIONS(27)	tap setting adjustment flag (0 by default)
	OPTIONS(27) = 0	disable tap setting adjustment
	OPTIONS(27) = 1	enable
	OPTIONS(28)	switched shunt control flag (0 by default)
	OPTIONS(28) = 0	disable switch shunt control
	OPTIONS(28) = 1	enable
Real VALUES (11)	array of elements specifying power flow options(input).	
	VALUES(1)	Mismatch tolerance (TOLN by default)
	VALUES(2)	Percentage of rating for the base case (100.0 by default)
	VALUES(3)	Percentage of rating for the contingency cases (100.0 by default)
	VALUES(4)	Voltage tolerance in linear programming
	VALUES(5)	Flow tolerance in linear programming
	VALUES(6)	Weighting factor of generation MW dispatch (1.0 by default)
	VALUES(7)	Weighting factor of load control (1.0 by default)
	VALUES(8)	Weighting factor of phase shifter control (1.0 by default)
	VALUES(9)	Weighting factor of generation MW dispatch of off-line generators (1.0 by default)
	VALUES(10)	Weighting factor of tap setting adjustment (1.0 by default)
	VALUES(11)	Weighting factor of switched shunt control (1.0 by default)
Character*32 LABELS (7)	array of elements specifying labels(input).	
	LABELS(1)	The label of generation dispatch system, required if the dispatch mode of OPTIONS(15) is not zero. The dispatch mode and the system provide for a default dispatch method for contingencies causing unbalance between load demand and generation output (blank for none).
	LABELS(2)	The label of generation dispatch control system. MW injections of the generators within

		the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(3)	The label of load control system. Loads in the load control system are available for curtailment in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(4)	The label of phase shifter adjustment system. The phase angles of phase shifters in the system are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(5)	The label of generation MW control of off-line generator control system. MW injections of the off-line generators within the system are available for dispatch in the corrective action mode or preventive security constrained optimal power flow mode (blank for none).
	LABELS(6)	The label of tap adjustment system. The tap positions of transformers in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
	LABELS(7)	The label of switched shunt control system. The admittances of switched shunts in voltage control mode are regulated either by corrective action or preventive security constrained optimal power flow (blank for none).
Character*260 DFXFILE	Is the name of the Distribution Factor Data File (input; no default allowed).	
Character*260 INLFILE	Is the name of Load Throwover Data File (input, blank for none). (input).	
Character*260 THRFILE	Is the name of Unit Inertia Data File (input, blank for none). (input).	
Integer IERR	error code (output).	
	IERR = -2	PSCOPF terminates with active constraints
	IERR = -1	PSCOPF reaches the maximum iteration
	IERR = 0	No error
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance

IERR = 6	Generation subsystem not specified
IERR = 7	too many islands in base case
IERR = 8	in-service induction machines are in the "stalled" or "tripped" state
IERR = 9	buses with bus type code and series element status inconsistencies
IERR = 10	no Distribution Factor Data File specified
IERR = 11	No controls are specified
IERR = 12	No constraints are specified
IERR = 13	Invalid base/contingency case flag combination.
IERR = 21	file DFXFILE is not in the form of a PSSE 25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening Distribution Factor Data File
IERR = 52	error opening Load Throwover Data File
IERR = 53	error opening Unit Inertia and Governor Data File
IERR = 54	prerequisite requirements for API are not met

1.1.204. PSEB

Use this API to convert a PSEB command file into a PSSE response file.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PSEB  INPFILE  OUTFILE
```

Python command syntax:

```
ierr, respfil = pseb(inpfile, outfile)
```

Fortran command syntax:

```
CALL PSEBAPI(INPFILE, OUTFILE, RESPFIL, IERR)
```

Where:

Character*260 INPFILE	name of the PSEB command file (input; no default allowed).	
Character*260 OUTFILE	name of response file; blank to have PSEB assign the filename (input; blank by default).	
Character*260 RESPFIL	pathname of the response file constructed by PSEB (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening INPFILE
	IERR = 2	error opening OUTFILE
	IERR = 3	errors detected while reading the PSEB Command Data input file
	IERR = 4	prerequisite requirements for API are not met

1.1.205. PSSEHALT

This API routine is obsolete. It has been replaced by the API routine [pssehalt_2](#).

Use this API to end the operation of PSSE, closes all associated files and returns to the calling application.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PSSEHALT  DELETE
```

Python command syntax:

```
ierr = pssehalt(delete)
```

Fortran command syntax:

```
CALL HALTAPI(DELETE, IERR)
```

Where:

Integer DELETE	delete working files flag (input).
	DELETE = 1 delete working files
	DELETE != 1 keep working files
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met

1.1.206. PSSEHALT_2

Use this API to end the operation of PSSE, closes all associated files and returns to the calling application.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_PSSEHALT_2
```

Python command syntax:

```
ierr = pssehalt_2()
```

Fortran command syntax:

```
CALL HALTAPI_2(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.207. PV_ENGINE

This API routine is obsolete. It has been replaced by the API routine [pv_engine_1a](#).

Use this API routine to run the first release of the PV analysis calculation engine. The same set of automatic adjustments is applied in base case and contingency case transfer increment solutions.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PV_ENGINE  OPTIONS(1)..OPTIONS(16)  VALUES(1)..VALUES(6)  LABELS(1)
              LABELS(2)  DFXFILE  THRFILE  ECDFILE  ACCFILE
```

Python command syntax:

```
ierr = pv_engine(options, values, labels, dfxfile, thrfile, ecdfile,
                 accfile)
```

Fortran command syntax:

```
CALL PV_ENGINE(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
               ACCFILE, IERR)
```

Where:

Integer OPTIONS (16)	array of 16 elements specifying solution options(input).	
	OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable
	OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable

OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(6) = 0	disable
OPTIONS(6) = 1	enable
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	FDNS
OPTIONS(7) = 1	FNSL
OPTIONS(7) = 2	optimized FDNS
OPTIONS(8)	var limit code for the contingency case initial power flow solution (0 by default)
OPTIONS(8) = 0	apply immediately
OPTIONS(8) = 1	initially ignore, then apply automatically
OPTIONS(9)	var limit code for the subsequent transfer increment cases (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	rating set (rating set program option setting by default)
OPTIONS(10) = 1	RATEA
OPTIONS(10) = 2	RATEB
OPTIONS(10) = 3	RATEC
OPTIONS(11)	study (source) system transfer dispatch method (1 by default)
OPTIONS(11) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(11) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(11) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(11) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(11) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(11) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(11) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
OPTIONS(11) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(12)	opposing (sink) system transfer dispatch method (1 by default)

	OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
	OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
	OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
	OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
	OPTIONS(13)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
	OPTIONS(13) = 0	no limits
	OPTIONS(13) = 1	honor machine active power limits
	OPTIONS(14)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
	OPTIONS(14) = 0	no limits
	OPTIONS(14) = 1	enforce non-negative net active power constant MVA load
	OPTIONS(15)	flag to check for low voltage at any monitored bus (0 by default)
	OPTIONS(15) = 0	disable check
	OPTIONS(15) = 1	enable check
	OPTIONS(16)	flag to check for excessive loading on any monitored branch (0 by default)
	OPTIONS(16) = 0	disable check
	OPTIONS(16) = 1	enable check
Real VALUES (6)	array of 6 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)
	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)

	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which the load is to be increased (no default allowed)
Character*260 DFXFILE	name of distribution factor data file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of PV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	initial transfer increment is less than transfer increment tolerance
	IERR = 7	no participating dispatch buses in study system
	IERR = 8	no participating dispatch buses in opposing system
	IERR = 9	subsystem engine error
	IERR = 10	ECDI engine in subsystem aaa
	IERR = 11	base case ECDI solution did not converge
	IERR = 12	no DFAX file specified
	IERR = 13	no PV results file specified
	IERR = 14	no economic dispatch data file specified
	IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 16	bus type code and series element status inconsistencies

IERR = 21	DFXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file
IERR = 54	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.208. PV_ENGINE_1A

This API routine is obsolete. It has been replaced by the API routine [pv_engine_2](#).

Use this API routine to run the PV analysis calculation engine. The same set of automatic adjustments and induction machine treatment is applied in base case and contingency case transfer increment solutions.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_PV_ENGINE_1A  OPTIONS(1)..OPTIONS(17)  VALUES(1)..VALUES(6)  LABELS(1)
                  LABELS(2)  DFXFILE  THRFILE  ECDFILE  ACCFILE
```

Python command syntax:

```
ierr = pv_engine_1a(options, values, labels, dfxfile, thrfile, ecdfile,
                    accfile)
```

Fortran command syntax:

```
CALL PV_ENGINE_1A(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
                  ACCFILE, IERR)
```

Where:

Integer OPTIONS (17)	array of 17 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)

OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(7) = 0	disable
OPTIONS(7) = 1	enable
OPTIONS(8)	solution method flag (0 by default)
OPTIONS(8) = 0	FDNS
OPTIONS(8) = 1	FNSL
OPTIONS(8) = 2	optimized FDNS
OPTIONS(9)	var limit code for the contingency case initial power flow solution (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	var limit code for the subsequent transfer increment cases (0 by default)
OPTIONS(10) = 0	apply immediately
OPTIONS(10) = 1	initially ignore, then apply automatically
OPTIONS(11)	rating set (rating set program option setting by default)
OPTIONS(11) = 1	RATEA
OPTIONS(11) = 2	RATEB
OPTIONS(11) = 3	RATEC
OPTIONS(12)	study (source) system transfer dispatch method (1 by default)
OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs

	OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
	OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
	OPTIONS(13)	opposing (sink) system transfer dispatch method (1 by default)
	OPTIONS(13) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
	OPTIONS(13) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(13) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(13) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(13) = 5	subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(13) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
	OPTIONS(13) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
	OPTIONS(13) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
	OPTIONS(14)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
	OPTIONS(14) = 0	no limits
	OPTIONS(14) = 1	honor machine active power limits
	OPTIONS(15)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
	OPTIONS(15) = 0	no limits
	OPTIONS(15) = 1	enforce non-negative net active power constant MVA load
	OPTIONS(16)	flag to check for low voltage at any monitored bus (0 by default)
	OPTIONS(16) = 0	disable check
	OPTIONS(16) = 1	enable check
	OPTIONS(17)	flag to check for excessive loading on any monitored branch (0 by default)
	OPTIONS(17) = 0	disable check
	OPTIONS(17) = 1	enable check
Real VALUES (6)	array of 6 elements specifying solution values(input).	

	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)
	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)
	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which the load is to be increased (no default allowed)
Character*260 DFAXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of PV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	initial transfer increment is less than transfer increment tolerance
	IERR = 7	no participating dispatch buses in study system
	IERR = 8	no participating dispatch buses in opposing system
	IERR = 9	subsystem engine error
	IERR = 10	ECDI engine error in subsystem aaa

IERR = 11	base case ECDI solution did not converge
IERR = 12	no DFAX file specified
IERR = 13	no PV results file specified
IERR = 14	no economic dispatch data file specified
IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
IERR = 16	bus type code and series element status inconsistencies
IERR = 21	file DFAX file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX File
IERR = 53	error opening load throwover data file
IERR = 54	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.209. PV_ENGINE_2

This API routine is obsolete. It has been replaced by the API routine [pv_engine_3](#).

Use this API to run PV analysis calculation engine. It provides for a different set of automatic adjustments in contingency case solutions than is used in the base case transfer increment solutions.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_PV_ENGINE_2  OPTIONS(1)..OPTIONS(21)  VALUES(1)..VALUES(6)  LABELS(1)
                  LABELS(2)  DFXFILE  THRFILE  ECDFILE  ACCFILE
```

Python command syntax:

```
ierr = pv_engine_2(options, values, labels, dfxfile, thrfile, ecdfile,
                  accfile)
```

Fortran command syntax:

```
CALL PV_ENGINE_2(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
                  ACCFILE, IERR)
```

Where:

Integer OPTIONS (21)	array of 21 elements specifying solution options(input).
OPTIONS(1)	base case tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	base case area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	base case phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	base case dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	base case switched shunt adjustment flag (switched shunt adjustment option setting by default)

OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(6) = 0	disable
OPTIONS(6) = 1	enable
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	FDNS
OPTIONS(7) = 1	FNSL
OPTIONS(7) = 2	optimized FDNS
OPTIONS(8)	var limit code for the contingency case power flow solutions (0 by default)
OPTIONS(8) = 0	apply immediately
OPTIONS(8) = 1	initially ignore, then apply automatically
OPTIONS(9)	var limit code for the base case transfer increment solutions (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	rating set (rating set program option setting by default)
OPTIONS(10) = 1	RATEA
OPTIONS(10) = 2	RATEB
OPTIONS(10) = 3	RATEC
OPTIONS(11)	study (source) system transfer dispatch method (1 by default)
OPTIONS(11) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(11) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(11) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(11) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(11) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(11) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(11) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
OPTIONS(11) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled

OPTIONS(12)	opposing (sink) system transfer dispatch method (1 by default)
OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(13)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
OPTIONS(13) = 0	no limits
OPTIONS(13) = 1	honor machine active power limits
OPTIONS(14)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
OPTIONS(14) = 0	no limits
OPTIONS(14) = 1	enforce non-negative net active power constant MVA load
OPTIONS(15)	flag to check for low voltage at any monitored bus (0 by default)
OPTIONS(15) = 0	disable check
OPTIONS(15) = 1	enable check
OPTIONS(16)	flag to check for excessive loading on any monitored branch (0 by default)
OPTIONS(16) = 0	disable check
OPTIONS(16) = 1	enable check
OPTIONS(17)	contingency case tap adjustment flag (base case tap adjustment flag, OPTIONS (1) by default)
OPTIONS(17) = 0	disable
OPTIONS(17) = 1	enable stepping adjustment
OPTIONS(17) = 2	enable direct adjustment

	OPTIONS(18)	contingency case area interchange adjustment flag (base case area interchange adjustment flag, OPTIONS (2) by default)
	OPTIONS(18) = 0	disable
	OPTIONS(18) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(18) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(19)	contingency case phase shift adjustment flag (base case phase shift adjustment flag, OPTIONS (3) by default)
	OPTIONS(19) = 0	disable
	OPTIONS(19) = 1	enable
	OPTIONS(20)	contingency case dc tap adjustment flag (base case dc tap adjustment flag, OPTIONS (4) by default)
	OPTIONS(20) = 0	disable
	OPTIONS(20) = 1	enable
	OPTIONS(21)	contingency case switched shunt adjustment flag (base case switched shunt adjustment flag, OPTIONS (5) by default)
	OPTIONS(21) = 0	disable
	OPTIONS(21) = 1	enable
	OPTIONS(21) = 2	enable continuous mode, disable discrete mode
Real VALUES (6)	array of 6 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)
	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)
	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for

	which the load is to be increased (no default allowed)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).
Character*260 ACCFILE	name of PV results file (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid VALUES value
IERR = 2	invalid OPTIONS value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	initial transfer increment is less than transfer increment tolerance
IERR = 7	no participating dispatch buses in study system
IERR = 8	no participating dispatch buses in opposing system
IERR = 9	subsystem engine error
IERR = 10	ECDI engine in subsystem aaa
IERR = 11	base case ECDI solution did not converge
IERR = 12	no DFAX file specified
IERR = 14	no economic dispatch data file specified
IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
IERR = 16	bus type code and series element status inconsistencies
IERR = 21	DFXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file

IERR = 54

prerequisite requirements for API are not met

IERR = 99

terminated by user interrupt or file error

1.1.210. PV_ENGINE_3

This API routine is obsolete. It has been replaced by the API routine [pv_engine_4](#).

Use this API to run the PV analysis calculation engine. It provides for a different set of automatic adjustments in contingency case solutions than is used in the base case transfer increment solutions, and allows a negative minimum incremental transfer to be specified..

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_PV_ENGINE_3  OPTIONS(1)..OPTIONS(21)  VALUES(1)..VALUES(7)  LABELS(1)
                LABELS(2)  DFXFILE  THRFILE  ECDFILE  ACCFILE
```

Python command syntax:

```
ierr = pv_engine_3(options, values, labels, dfxfile, thrfile, ecdfile,
                  accfile)
```

Fortran command syntax:

```
CALL PV_ENGINE_3(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
                ACCFILE, IERR)
```

Where:

Integer OPTIONS (21)	array of 21 elements specifying solution options(input).
OPTIONS(1)	base case tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	base case area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	base case phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	base case dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable

OPTIONS(5)	base case switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(6) = 0	disable
OPTIONS(6) = 1	enable
OPTIONS(7)	solution method flag (0 by default)
OPTIONS(7) = 0	FDNS
OPTIONS(7) = 1	FNSL
OPTIONS(7) = 2	optimized FDNS
OPTIONS(8)	var limit code for the contingency case power flow solutions (0 by default)
OPTIONS(8) = 0	apply immediately
OPTIONS(8) = 1	initially ignore, then apply automatically
OPTIONS(9)	var limit code for the base case transfer increment solutions (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	rating set (rating set program option setting by default)
OPTIONS(10) = 1	RATEA
OPTIONS(10) = 2	RATEB
OPTIONS(10) = 3	RATEC
OPTIONS(11)	study (source) system transfer dispatch method (1 by default)
OPTIONS(11) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(11) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(11) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(11) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(11) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(11) = 6	subsystem buses with positive MW machines in proportion to their MBASEs

OPTIONS(11) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
OPTIONS(11) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(12)	opposing (sink) system transfer dispatch method (1 by default)
OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(13)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
OPTIONS(13) = 0	no limits
OPTIONS(13) = 1	honor machine active power limits
OPTIONS(14)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
OPTIONS(14) = 0	no limits
OPTIONS(14) = 1	enforce non-negative net active power constant MVA load
OPTIONS(15)	flag to check for low voltage at any monitored bus (0 by default)
OPTIONS(15) = 0	disable check
OPTIONS(15) = 1	enable check
OPTIONS(16)	flag to check for excessive loading on any monitored branch (0 by default)
OPTIONS(16) = 0	disable check
OPTIONS(16) = 1	enable check
OPTIONS(17)	contingency case tap adjustment flag (base case tap adjustment flag, OPTIONS (1) by default)

	OPTIONS(17) = 0	disable
	OPTIONS(17) = 1	enable stepping adjustment
	OPTIONS(17) = 2	enable direct adjustment
	OPTIONS(18)	contingency case area interchange adjustment flag (base case area interchange adjustment flag, OPTIONS (2) by default)
	OPTIONS(18) = 0	disable
	OPTIONS(18) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(18) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(19)	contingency case phase shift adjustment flag (base case phase shift adjustment flag, OPTIONS (3) by default)
	OPTIONS(19) = 0	disable
	OPTIONS(19) = 1	enable
	OPTIONS(20)	contingency case dc tap adjustment flag (base case dc tap adjustment flag, OPTIONS (4) by default)
	OPTIONS(20) = 0	disable
	OPTIONS(20) = 1	enable
	OPTIONS(21)	contingency case switched shunt adjustment flag (base case switched shunt adjustment flag, OPTIONS (5) by default)
	OPTIONS(21) = 0	disable
	OPTIONS(21) = 1	enable
	OPTIONS(21) = 2	enable continuous mode, disable discrete mode
Real VALUES (7)	array of 7 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)
	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)
	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
	VALUES(7)	minimum incremental transfer in MW (< 0.0) (0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	

	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which the load is to be increased (no default allowed)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of PV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	initial transfer increment is less than transfer increment tolerance
	IERR = 7	no participating dispatch buses in study system
	IERR = 8	no participating dispatch buses in opposing system
	IERR = 9	subsystem engine error
	IERR = 10	ECDI engine in subsystem aaa
	IERR = 11	base case ECDI solution did not converge
	IERR = 12	no DFAX File specified
	IERR = 13	no PV results file specified
	IERR = 14	no economic dispatch data file specified
	IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 16	invalid base/contingency case adjustment flag combination
	IERR = 17	bus type code and series element status inconsistencies
	IERR = 21	DFXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members

IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file
IERR = 54	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.211. PV_ENGINE_4

This API routine is obsolete. It has been replaced by the API routine [pv_engine_5](#).

Use this API routine to run the PV analysis calculation engine. It provides for a different set of automatic adjustments and induction machine treatment in contingency case solutions than is used in the base case transfer increment solutions, and allows a negative minimum incremental transfer to be specified..

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_PV_ENGINE_4  OPTIONS(1)..OPTIONS(23)  VALUES(1)..VALUES(7)  LABELS(1)
                  LABELS(2)  DFXFILE  THRFILE  ECDFILE  ACCFILE
```

Python command syntax:

```
ierr = pv_engine_4(options, values, labels, dfxfile, thrfile, ecdfile,
                  accfile)
```

Fortran command syntax:

```
CALL PV_ENGINE_4(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
                  ACCFILE, IERR)
```

Where:

Integer OPTIONS (23)	array of 23 elements specifying solution options(input).
OPTIONS(1)	base case tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	base case area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	base case phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	base case dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable

OPTIONS(5)	base case switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	base case induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by de- fault)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(7) = 0	disable
OPTIONS(7) = 1	enable
OPTIONS(8)	solution method flag (0 by default)
OPTIONS(8) = 0	FDNS
OPTIONS(8) = 1	FNSL
OPTIONS(8) = 2	optimized FDNS
OPTIONS(9)	var limit code for the contingency case pow- er flow solutions (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	var limit code for the base case transfer in- crement solutions (0 by default)
OPTIONS(10) = 0	apply immediately
OPTIONS(10) = 1	initially ignore, then apply automatically
OPTIONS(11)	rating set (rating set program option setting by default)
OPTIONS(11) = 1	RATEA
OPTIONS(11) = 2	RATEB
OPTIONS(11) = 3	RATEC
OPTIONS(12)	study (source) system transfer dispatch method (1 by default)
OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load

OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(13)	opposing (sink) system transfer dispatch method (1 by default)
OPTIONS(13) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(13) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(13) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(13) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(13) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(13) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(13) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
OPTIONS(13) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(14)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
OPTIONS(14) = 0	no limits
OPTIONS(14) = 1	honor machine active power limits
OPTIONS(15)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
OPTIONS(15) = 0	no limits
OPTIONS(15) = 1	enforce non-negative net active power constant MVA load
OPTIONS(16)	flag to check for low voltage at any monitored bus (0 by default)
OPTIONS(16) = 0	disable check
OPTIONS(16) = 1	enable check
OPTIONS(17)	flag to check for excessive loading on any monitored branch (0 by default)
OPTIONS(17) = 0	disable check

	OPTIONS(17) = 1	enable check
	OPTIONS(18)	contingency case tap adjustment flag (base case tap adjustment flag, OPTIONS (1) by default)
	OPTIONS(18) = 0	disable
	OPTIONS(18) = 1	enable stepping adjustment
	OPTIONS(18) = 2	enable direct adjustment
	OPTIONS(19)	contingency case area interchange adjustment flag (base case area interchange adjustment flag, OPTIONS (2) by default)
	OPTIONS(19) = 0	disable
	OPTIONS(19) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(19) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(20)	contingency case phase shift adjustment flag (base case phase shift adjustment flag, OPTIONS (3) by default)
	OPTIONS(20) = 0	disable
	OPTIONS(20) = 1	enable
	OPTIONS(21)	contingency case dc tap adjustment flag (base case dc tap adjustment flag, OPTIONS (4) by default)
	OPTIONS(21) = 0	disable
	OPTIONS(21) = 1	enable
	OPTIONS(22)	contingency case switched shunt adjustment flag (base case switched shunt adjustment flag, OPTIONS (5) by default)
	OPTIONS(22) = 0	disable
	OPTIONS(22) = 1	enable
	OPTIONS(22) = 2	enable continuous mode, disable discrete mode
	OPTIONS(23)	contingency case induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
	OPTIONS(23) = 0	stall
	OPTIONS(23) = 1	trip
Real VALUES (7)	array of 7 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)

	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)
	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
	VALUES(7)	minimum incremental transfer in MW (< 0.0) (0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which the load is to be increased (no default allowed)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of PV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	initial transfer increment is less than transfer increment tolerance
	IERR = 7	no participating dispatch buses in study system
	IERR = 8	no participating dispatch buses in opposing system
	IERR = 9	subsystem engine error
	IERR = 10	ECDI engine in subsystem aaa
	IERR = 11	base case ECDI solution did not converge
	IERR = 12	no DFAX file specified
	IERR = 13	no PV results file specified
	IERR = 14	no economic dispatch data file specified

IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
IERR = 16	bus type code and series element status inconsistencies
IERR = 17	invalid base/contingency case flag combination
IERR = 21	DFXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file
IERR = 54	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.212. PV_ENGINE_5

This API routine is obsolete. It has been replaced by the API routine [pv_engine_6](#).

Use this API routine to run the PV analysis calculation engine. It provides for a different set of automatic adjustments, and for different treatment of induction motors that fail to solve due to low terminal voltage, in contingency case solutions than is used in the base case transfer increment solutions; it allows a negative minimum incremental transfer to be specified; for transfer increment methods involving load, it allows a power factor to be specified; and it provides for dispatching power unbalances resulting from the application of contingencies.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_PV_ENGINE_5  OPTIONS(1)..OPTIONS(24) VALUES(1)..VALUES(8)
                  LABELS(1)..LABELS(3) DFXFILE THRFILE ECDFILE INLFILE ACCFILE
```

Python command syntax:

```
ierr = pv_engine_5(options, values, labels, dfxfile, thrfile, ecdfile,
                  inlfile, accfile)
```

Fortran command syntax:

```
CALL PV_ENGINE_5(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
                 INLFILE, ACCFILE, IERR)
```

Where:

Integer OPTIONS (24)	array of 24 elements specifying solution options(input).
OPTIONS(1)	base case tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	base case area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	base case phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	base case dc tap adjustment flag (dc tap adjustment option setting by default)

OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	base case switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	base case induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by de- fault)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(7) = 0	disable
OPTIONS(7) = 1	enable
OPTIONS(8)	solution method flag (0 by default)
OPTIONS(8) = 0	FDNS
OPTIONS(8) = 1	FNSL
OPTIONS(8) = 2	optimized FDNS
OPTIONS(9)	var limit code for the contingency case pow- er flow solutions (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	var limit code for the base case transfer in- crement solutions (0 by default)
OPTIONS(10) = 0	apply immediately
OPTIONS(10) = 1	initially ignore, then apply automatically
OPTIONS(11)	rating set (rating set program option setting by default)
OPTIONS(11) = 1	RATEA
OPTIONS(11) = 2	RATEB
OPTIONS(11) = 3	RATEC
OPTIONS(12)	study (source) system transfer dispatch method (1 by default)
OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load

OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(13)	opposing (sink) system transfer dispatch method (1 by default)
OPTIONS(13) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(13) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(13) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(13) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(13) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(13) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(13) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
OPTIONS(13) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(14)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
OPTIONS(14) = 0	no limits
OPTIONS(14) = 1	honor machine active power limits
OPTIONS(15)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
OPTIONS(15) = 0	no limits
OPTIONS(15) = 1	enforce non-negative net active power constant MVA load
OPTIONS(16)	flag to check for low voltage at any monitored bus (0 by default)
OPTIONS(16) = 0	disable check
OPTIONS(16) = 1	enable check
OPTIONS(17)	flag to check for excessive loading on any monitored branch (0 by default)

OPTIONS(17) = 0	disable check
OPTIONS(17) = 1	enable check
OPTIONS(18)	dispatch mode for power unbalances resulting from the application of contingencies (1 by default)
OPTIONS(18) = 0	disable
OPTIONS(18) = 1	in-service subsystem machines using reserve
OPTIONS(18) = 2	in-service subsystem machines using Pmax
OPTIONS(18) = 3	in-service subsystem machines using inertia
OPTIONS(18) = 4	in-service subsystem machines using governor droop
OPTIONS(19)	contingency case tap adjustment flag (base case tap adjustment flag, OPTIONS (1) by default)
OPTIONS(19) = 0	disable
OPTIONS(19) = 1	enable stepping adjustment
OPTIONS(19) = 2	enable direct adjustment
OPTIONS(20)	contingency case area interchange adjustment flag (base case area interchange adjustment flag, OPTIONS (2) by default)
OPTIONS(20) = 0	disable
OPTIONS(20) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(20) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(21)	contingency case phase shift adjustment flag (base case phase shift adjustment flag, OPTIONS (3) by default)
OPTIONS(21) = 0	disable
OPTIONS(21) = 1	enable
OPTIONS(22)	contingency case dc tap adjustment flag (base case dc tap adjustment flag, OPTIONS (4) by default)
OPTIONS(22) = 0	disable
OPTIONS(22) = 1	enable
OPTIONS(23)	contingency case switched shunt adjustment flag (base case switched shunt adjustment flag, OPTIONS (5) by default)
OPTIONS(23) = 0	disable
OPTIONS(23) = 1	enable
OPTIONS(23) = 2	enable continuous mode, disable discrete mode
OPTIONS(24)	contingency case induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)

	OPTIONS(24) = 0	stall
	OPTIONS(24) = 1	trip
Real VALUES (8)	array of 8 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)
	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)
	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
	VALUES(7)	minimum incremental transfer in MW (< 0.0) (0.0 by default)
	VALUES(8)	power factor for load increases in dispatch methods 2, 3 and 4. Specify as <= 0.0 to retain the original power factor at each load that is changed (0.0 by default)
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which the load is to be increased (no default allowed)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).	
Character*260 INLFILE	name of inertia and governor response file (input).	
Character*260 ACCFILE	name of PV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE

IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	initial transfer increment is less than transfer increment tolerance
IERR = 7	no participating dispatch buses in study system
IERR = 8	no participating dispatch buses in opposing system
IERR = 9	subsystem engine error
IERR = 10	ECDI engine in subsystem aaa
IERR = 11	base case ECDI solution did not converge
IERR = 12	no DFAX file specified
IERR = 13	no PV results file specified
IERR = 14	no economic dispatch data file specified
IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
IERR = 16	bus type code and series element status inconsistencies
IERR = 17	invalid base/contingency case flag combination
IERR = 21	DFXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file
IERR = 54	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.213. PV_ENGINE_6

Use this API routine to run the PV analysis calculation engine. It provides for a different set of automatic adjustments, and for different treatment of induction motors that fail to solve due to low terminal voltage, in contingency case solutions than is used in the base case transfer increment solutions; it allows a negative minimum incremental transfer to be specified; for transfer increment methods involving load, it allows a power factor to be specified; it provides for dispatching power unbalances resulting from the application of contingencies; and it allows for the preservation of milestone results in a ZIP Archive Output File.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_PV_ENGINE_6  OPTIONS(1)..OPTIONS(25) VALUES(1)..VALUES(8)
                  LABELS(1)..LABELS(3) DFXFILE THRFILE ECDFILE INLFILE ACCFILE ZIPFILE
```

Python command syntax:

```
ierr = pv_engine_6(options, values, labels, dfxfile, thrfile, ecdfile,
                  inlfile, accfile, zipfile)
```

Fortran command syntax:

```
CALL PV_ENGINE_6(OPTIONS, VALUES, LABELS, DFXFILE, THRFILE, ECDFILE,
                 INLFILE, ACCFILE, ZIPFILE, IERR)
```

Where:

Integer OPTIONS (25)	array of 25 elements specifying solution options(input).
OPTIONS(1)	base case tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	base case area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	base case phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	base case dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable

OPTIONS(5)	base case switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode
OPTIONS(6)	base case induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by de- fault)
OPTIONS(6) = 0	stall
OPTIONS(6) = 1	trip
OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
OPTIONS(7) = 0	disable
OPTIONS(7) = 1	enable
OPTIONS(8)	solution method flag (0 by default)
OPTIONS(8) = 0	FDNS
OPTIONS(8) = 1	FNSL
OPTIONS(8) = 2	optimized FDNS
OPTIONS(9)	var limit code for the contingency case pow- er flow solutions (0 by default)
OPTIONS(9) = 0	apply immediately
OPTIONS(9) = 1	initially ignore, then apply automatically
OPTIONS(10)	var limit code for the base case transfer in- crement solutions (0 by default)
OPTIONS(10) = 0	apply immediately
OPTIONS(10) = 1	initially ignore, then apply automatically
OPTIONS(11)	rating set (rating set program option setting by default)
OPTIONS(11) = 1	RATEA
OPTIONS(11) = 2	RATEB
OPTIONS(11) = 3	RATEC
OPTIONS(12)	study (source) system transfer dispatch method (1 by default)
OPTIONS(12) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(12) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(12) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(12) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load

OPTIONS(12) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(12) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(12) = 7	subsystem buses with positive MW machines in proportion to their reserve (PMAxMC - PGENMC)
OPTIONS(12) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(13)	opposing (sink) system transfer dispatch method (1 by default)
OPTIONS(13) = 1	buses and distribution factors from DFAX file for buses with positive MW machines
OPTIONS(13) = 2	buses and distribution factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(13) = 3	buses and distribution factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(13) = 4	subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(13) = 5	subsystem buses with positive MW machines in proportion to their MW output
OPTIONS(13) = 6	subsystem buses with positive MW machines in proportion to their MBASEs
OPTIONS(13) = 7	subsystem buses with positive MW machines in proportion to their reserve (PGENMC - PMINMC)
OPTIONS(13) = 8	subsystem buses with positive MW machines via ECDI with unit commitment disabled
OPTIONS(14)	generation plant limits flag for transfer methods 1, 3, 5, 6 and 7 (0 by default)
OPTIONS(14) = 0	no limits
OPTIONS(14) = 1	honor machine active power limits
OPTIONS(15)	positive load flag for transfer methods 2, 3 and 4 (0 by default)
OPTIONS(15) = 0	no limits
OPTIONS(15) = 1	enforce non-negative net active power constant MVA load
OPTIONS(16)	flag to check for low voltage at any monitored bus (0 by default)
OPTIONS(16) = 0	disable check
OPTIONS(16) = 1	enable check
OPTIONS(17)	flag to check for excessive loading on any monitored branch (0 by default)
OPTIONS(17) = 0	disable check

OPTIONS(17) = 1	enable check
OPTIONS(18)	dispatch mode for power unbalances resulting from the application of contingencies (1 by default)
OPTIONS(18) = 0	disable
OPTIONS(18) = 1	in-service subsystem machines using reserve
OPTIONS(18) = 2	in-service subsystem machines using Pmax
OPTIONS(18) = 3	in-service subsystem machines using inertia
OPTIONS(18) = 4	in-service subsystem machines using governor droop
OPTIONS(19)	write ZIP archive flag (0 by default)
OPTIONS(19) = 0	no ZIP archive
OPTIONS(19) = 1	Write ZIP Archive file ZIPFILE; preserve each system condition at its largest solved incremental transfer level.
OPTIONS(19) = 2	Write ZIP Archive file ZIPFILE; preserve each system condition at all of its solved incremental transfer levels.
OPTIONS(20)	contingency case tap adjustment flag (base case tap adjustment flag, OPTIONS (1) by default)
OPTIONS(20) = 0	disable
OPTIONS(20) = 1	enable stepping adjustment
OPTIONS(20) = 2	enable direct adjustment
OPTIONS(21)	contingency case area interchange adjustment flag (base case area interchange adjustment flag, OPTIONS (2) by default)
OPTIONS(21) = 0	disable
OPTIONS(21) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(21) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(22)	contingency case phase shift adjustment flag (base case phase shift adjustment flag, OPTIONS (3) by default)
OPTIONS(22) = 0	disable
OPTIONS(22) = 1	enable
OPTIONS(23)	contingency case dc tap adjustment flag (base case dc tap adjustment flag, OPTIONS (4) by default)
OPTIONS(23) = 0	disable
OPTIONS(23) = 1	enable
OPTIONS(24)	contingency case switched shunt adjustment flag (base case switched shunt adjustment flag, OPTIONS (5) by default)
OPTIONS(24) = 0	disable

	OPTIONS(24) = 1	enable
	OPTIONS(24) = 2	enable continuous mode, disable discrete mode
	OPTIONS(25)	contingency case induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
	OPTIONS(25) = 0	stall
	OPTIONS(25) = 1	trip
Real VALUES (8)	array of 8 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial transfer increment in MW (100.0 by default)
	VALUES(3)	transfer increment tolerance in MW (10.0 by default)
	VALUES(4)	maximum incremental transfer in MW (1000.0 by default)
	VALUES(5)	low voltage threshold in pu in the low voltage check (0.8 by default)
	VALUES(6)	percent of rating in the excessive branch loading check (100.0 by default)
	VALUES(7)	minimum incremental transfer in MW (< 0.0) (0.0 by default)
	VALUES(8)	power factor for load increases in dispatch methods 2, 3 and 4. Specify as <= 0.0 to retain the original power factor at each load that is changed (0.0 by default)
Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).	
	LABELS(1)	label of the study (source) system for which generation is to be increased and/or for which the load is to be decreased (no default allowed)
	LABELS(2)	label of the opposing (sink) system for which generation is to be decreased and/or for which the load is to be increased (no default allowed)
	LABELS(3)	label of the dispatch subsystem; used if OPTIONS(18) is 1 through 4 (blank by default)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ECDFILE	name of economic dispatch data file; blank for none (input; blank by default).	

Character*260 INLFILE	name of inertia and governor response file (input).
Character*260 ACCFILE	name of PV results file (input; no default allowed).
Character*260 ZIPFILE	name of ZIP archive output file (input).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid VALUES value
IERR = 2	invalid OPTIONS value
IERR = 3	generators are converted
IERR = 4	buses in island(s) without a swing bus; use activity TREE
IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	initial transfer increment is less than transfer increment tolerance
IERR = 7	no participating dispatch buses in study system
IERR = 8	no participating dispatch buses in opposing system
IERR = 9	subsystem engine error
IERR = 10	ECDI engine in subsystem aaa
IERR = 11	base case ECDI solution did not converge
IERR = 12	no DFAX file specified
IERR = 13	no PV results file specified
IERR = 14	no economic dispatch data file specified
IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
IERR = 16	bus type code and series element status inconsistencies
IERR = 17	invalid base/contingency case flag combination
IERR = 21	DFXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file
IERR = 54	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.214. QV_ENGINE

This API routine is obsolete. It has been replaced by the API routine [qv_engine_2](#).

Use this API to run the QV analysis calculation engine.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_QV_ENGINE  OPTIONS(1)..OPTIONS(10)  VALUES(1)..VALUES(4)  DFXFILE
                THRFILE  ACCFILE
```

Python command syntax:

```
ierr = qv_engine(options, values, dfxfile, thrfile, accfile)
```

Fortran command syntax:

```
CALL QV_ENGINE(OPTIONS, VALUES, DFXFILE, THRFILE, ACCFILE, IERR)
```

Where:

Integer OPTIONS (10)	array of 10 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(6) = 0	disable
	OPTIONS(6) = 1	enable
	OPTIONS(7)	solution method flag (0 by default)
	OPTIONS(7) = 0	FDNS
	OPTIONS(7) = 1	FNSL
	OPTIONS(7) = 2	optimized FDNS
	OPTIONS(8)	var limit code for the VHI power flow solution (0 by default)
	OPTIONS(8) = 0	apply immediately
	OPTIONS(8) = 1	initially ignore, then apply automatically
	OPTIONS(9)	var limit code for the subsequent voltage decrement cases (0 by default)
	OPTIONS(9) = 0	apply immediately
	OPTIONS(9) = 1	initially ignore, then apply automatically
	OPTIONS(10)	study bus number (no default allowed)
Real VALUES (4)	array of 4 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial (maximum) pu voltage setpoint at the study bus (VHI) (1.1 by default)
	VALUES(3)	minimum pu voltage setpoint at the study bus (VLO) (0.9 by default)
	VALUES(4)	pu voltage setpoint decrement (positive) at the study bus (DLTAV) (0.01 by default)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of QV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	VHI is not greater than VLO
	IERR = 7	study bus not found
	IERR = 8	invalid study bus
	IERR = 9	error when adding a plant to the study bus

IERR = 10	error when adding a machine to the study bus
IERR = 11	base case VHI solution did not converge
IERR = 12	no Distribution Factor Data File specified
IERR = 13	no Q-V Solution Output File specified
IERR = 14	in-service induction machines are in the "stalled" or "tripped" state
IERR = 15	bus type code and series element status inconsistencies
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening QV Results File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 55	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.215. QV_ENGINE_2

This API routine is obsolete. It has been replaced by the API routine [qv_engine_3](#).

Use this API routine to run the QV analysis calculation engine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_QV_ENGINE_2  OPTIONS(1)..OPTIONS(11)  VALUES(1)..VALUES(4)  DFXFILE
                THRFILE  ACCFILE
```

Python command syntax:

```
ierr = qv_engine_2(options, values, dfxfile, thrfile, accfile)
```

Fortran command syntax:

```
CALL QV_ENGINE_2(OPTIONS, VALUES, DFXFILE, THRFILE, ACCFILE, IERR)
```

Where:

Integer OPTIONS (11)	array of 11 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
	OPTIONS(6) = 0	stall
	OPTIONS(6) = 1	trip
	OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(7) = 0	disable
	OPTIONS(7) = 1	enable
	OPTIONS(8)	solution method flag (0 by default)
	OPTIONS(8) = 0	FDNS
	OPTIONS(8) = 1	FNSL
	OPTIONS(8) = 2	optimized FDNS
	OPTIONS(9)	var limit code for the VHI power flow solution (0 by default)
	OPTIONS(9) = 0	apply immediately
	OPTIONS(9) = 1	initially ignore, then apply automatically
	OPTIONS(10)	var limit code for the subsequent voltage decrement cases (0 by default)
	OPTIONS(10) = 0	apply immediately
	OPTIONS(10) = 1	initially ignore, then apply automatically
	OPTIONS(11)	study bus number (no default allowed)
Real VALUES (4)	array of 4 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial (maximum) pu voltage setpoint at the study bus (VHI) (1.1 by default)
	VALUES(3)	minimum pu voltage setpoint at the study bus (VLO) (0.9 by default)
	VALUES(4)	pu voltage setpoint decrement (positive) at the study bus (DLTAV) (0.01 by default)
Character*260 DFXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of QV results file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE

IERR = 5	largest mismatch exceeds mismatch tolerance
IERR = 6	VHI is not greater than VLO
IERR = 7	study bus not found
IERR = 8	invalid study bus
IERR = 9	error when adding a plant to the study bus
IERR = 10	error when adding a machine to the study bus
IERR = 11	base case VHI solution did not converge
IERR = 12	no Distribution Factor Data File specified
IERR = 13	no Q-V Solution Output File specified
IERR = 14	in-service induction machines are in the "stalled" or "tripped" state
IERR = 15	bus type code and series element status inconsistencies
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 51	error opening QV Results File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Load Throwover Data File
IERR = 55	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.216. QV_ENGINE_3

This API routine is obsolete. It has been replaced by the API routine [qv_engine_4](#).

Use this API routine to run the QV analysis calculation engine.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_QV_ENGINE_3  OPTIONS(1)..OPTIONS(12)  VALUES(1)..VALUES(4)  LABEL
                  DFXFILE  THRFILE  INLFILE  ACCFILE
```

Python command syntax:

```
ierr = qv_engine_3(options, values, label, dfxfile, thrfile, inlfile,
                  accfile)
```

Fortran command syntax:

```
CALL QV_ENGINE_3(OPTIONS, VALUES, LABEL, DFXFILE, THRFILE, INLFILE,
                  ACCFILE, IERR)
```

Where:

Integer OPTIONS (12)	array of 12 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable

	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
	OPTIONS(6) = 0	stall
	OPTIONS(6) = 1	trip
	OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(7) = 0	disable
	OPTIONS(7) = 1	enable
	OPTIONS(8)	solution method flag (0 by default)
	OPTIONS(8) = 0	FDNS
	OPTIONS(8) = 1	FNSL
	OPTIONS(8) = 2	optimized FDNS
	OPTIONS(9)	var limit code for the VHI power flow solution (0 by default)
	OPTIONS(9) = 0	apply immediately
	OPTIONS(9) = 1	initially ignore, then apply automatically
	OPTIONS(10)	var limit code for the subsequent voltage decrement cases (0 by default)
	OPTIONS(10) = 0	apply immediately
	OPTIONS(10) = 1	initially ignore, then apply automatically
	OPTIONS(11)	study bus number (no default allowed)
	OPTIONS(12)	dispatch mode for power unbalances resulting from the application of contingencies (1 by default)
	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	in-service subsystem machines using reserve
	OPTIONS(12) = 2	in-service subsystem machines using Pmax
	OPTIONS(12) = 3	in-service subsystem machines using inertia
	OPTIONS(12) = 4	in-service subsystem machines using governor droop
Real VALUES (4)	array of 4 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial (maximum) pu voltage setpoint at the study bus (VHI) (1.1 by default)
	VALUES(3)	minimum pu voltage setpoint at the study bus (VLO) (0.9 by default)
	VALUES(4)	pu voltage setpoint decrement (positive) at the study bus (DLTAV) (0.01 by default)
Character*32 LABEL (1)	array of 1 elements specifying subsystem label(input).	

	LABEL(1)	label of the dispatch subsystem; used if OPTIONS(12) is 1 through 4 (blank by default)
Character*260 DFXFILE		name of DFAX file (input; no default allowed).
Character*260 THRFILE		name of load throwover data file; blank for none (input; blank by default).
Character*260 INLFILE		name of inertia and governor response file; blank for none (input; blank by default).
Character*260 ACCFILE		name of QV results file (input; no default allowed).
Integer IERR		error code (output).
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	VHI is not greater than VLO
	IERR = 7	study bus not found
	IERR = 8	invalid study bus
	IERR = 9	error when adding a plant to the study bus
	IERR = 10	error when adding a machine to the study bus
	IERR = 11	base case VHI solution did not converge
	IERR = 12	no Distribution Factor Data File specified
	IERR = 13	no Q-V Solution Output File specified
	IERR = 14	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 15	bus type code and series element status inconsistencies
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 22	monitored elements exceed limit when adding multi-section line members
	IERR = 51	error opening QV Results File
	IERR = 52	error opening Distribution Factor Data File
	IERR = 53	error opening Load Throwover Data File
	IERR = 55	prerequisite requirements for API are not met
	IERR = 99	terminated by user interrupt or file error

1.1.217. QV_ENGINE_4

Use this API routine to run the QV analysis calculation engine.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_QV_ENGINE_4  OPTIONS(1)..OPTIONS(13)  VALUES(1)..VALUES(4)  LABEL
                  DFXFILE  THRFILE  INLFILE  ACCFILE  ZIPFILE
```

Python command syntax:

```
ierr = qv_engine_4(options, values, label, dfxfile, thrfile, inlfile,
                  accfile, zipfile)
```

Fortran command syntax:

```
CALL QV_ENGINE_4(OPTIONS, VALUES, LABEL, DFXFILE, THRFILE, INLFILE,
                  ACCFILE, ZIPFILE, IERR)
```

Where:

Integer OPTIONS (13)	array of 13 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable stepping adjustment
OPTIONS(1) = 2	enable direct adjustment
OPTIONS(2)	area interchange adjustment flag (area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	phase shift adjustment flag (phase shift adjustment option setting by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
OPTIONS(4)	dc tap adjustment flag (dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable
OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	induction motor treatment flag; applied when an induction motor fails to solve due to low terminal voltage (0 by default)
	OPTIONS(6) = 0	stall
	OPTIONS(6) = 1	trip
	OPTIONS(7)	non-divergent solution flag (non-divergent solution option setting by default)
	OPTIONS(7) = 0	disable
	OPTIONS(7) = 1	enable
	OPTIONS(8)	solution method flag (0 by default)
	OPTIONS(8) = 0	FDNS
	OPTIONS(8) = 1	FNSL
	OPTIONS(8) = 2	optimized FDNS
	OPTIONS(9)	var limit code for the VHI power flow solution (0 by default)
	OPTIONS(9) = 0	apply immediately
	OPTIONS(9) = 1	initially ignore, then apply automatically
	OPTIONS(10)	var limit code for the subsequent voltage decrement cases (0 by default)
	OPTIONS(10) = 0	apply immediately
	OPTIONS(10) = 1	initially ignore, then apply automatically
	OPTIONS(11)	study bus number (no default allowed)
	OPTIONS(12)	dispatch mode for power unbalances resulting from the application of contingencies (1 by default)
	OPTIONS(12) = 0	disable
	OPTIONS(12) = 1	in-service subsystem machines using reserve
	OPTIONS(12) = 2	in-service subsystem machines using Pmax
	OPTIONS(12) = 3	in-service subsystem machines using inertia
	OPTIONS(12) = 4	in-service subsystem machines using governor droop
	OPTIONS(13)	write ZIP archive flag (0 by default)
	OPTIONS(13) = 0	no ZIP archive
	OPTIONS(13) = 1	Write ZIP Archive file ZIPFILE; preserve each system condition at its lowest solved study bus voltage level.
	OPTIONS(13) = 2	Write ZIP Archive file ZIPFILE; preserve each system condition at all solved study bus voltage levels.
Real VALUES (4)	array of 4 elements specifying solution values(input).	
	VALUES(1)	mismatch tolerance in MW and Mvar (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	initial (maximum) pu voltage setpoint at the study bus (VHI) (1.1 by default)

	VALUES(3)	minimum pu voltage setpoint at the study bus (VLO) (0.9 by default)
	VALUES(4)	pu voltage setpoint decrement (positive) at the study bus (DLTAV) (0.01 by default)
Character*32 LABEL (1)	array of 1 elements specifying subsystem label(input).	
	LABEL(1)	label of the dispatch subsystem; used if OPTIONS(12) is 1 through 4 (blank by default)
Character*260 DFAXFILE	name of DFAX file (input; no default allowed).	
Character*260 THRFILE	name of load throwover data file; blank for none (input; blank by default).	
Character*260 INLFILE	name of inertia and governor response file; blank for none (input; blank by default).	
Character*260 ACCFILE	name of QV results file (input; no default allowed).	
Character*260 ZIPFILE	name of ZIP archive output file (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VALUES value
	IERR = 2	invalid OPTIONS value
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 6	initial transfer increment is less than transfer increment tolerance
	IERR = 7	no participating dispatch buses in study system
	IERR = 8	no participating dispatch buses in opposing system
	IERR = 9	subsystem engine error
	IERR = 10	ECDI engine in subsystem aaa
	IERR = 11	base case ECDI solution did not converge
	IERR = 12	no DFAX file specified
	IERR = 13	no PV results file specified
	IERR = 14	no economic dispatch data file specified
	IERR = 15	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 16	bus type code and series element status inconsistencies
	IERR = 17	invalid base/contingency case flag combination
	IERR = 21	DFAXFILE file is not in the form of a PSSE-25 or later DFAX file; run DFAX

IERR = 22	monitored elements exceed limit when adding multi-section line members
IERR = 23	no subsystems defined
IERR = 24	subsystem not found
IERR = 25	specified subsystems overlap
IERR = 26	no in-service buses in subsystem WORLD
IERR = 50	error opening economic dispatch data file
IERR = 51	error opening PV results file
IERR = 52	error opening DFAX file
IERR = 53	error opening load throwover data file
IERR = 54	error opening inertia and governor response data file
IERR = 55	error opening ZIP archive output file
IERR = 56	prerequisite requirements for API are not met
IERR = 99	terminated by user interrupt or file error

1.1.218. RANK

Use this API to estimate the severity of designated single branch outage contingencies and builds a contingency solution output file with contingencies specified in decreasing order of their estimated severities.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RANK  SID  ALL  IVAL(1)..IVAL(7) RVAL(1)..RVAL(4)  SSFILE  MNFILE
          ACCFILE
```

Python command syntax:

```
ierr = rank(sid, all, ival, rval, ssfile, mnfile, accfile)
```

Fortran command syntax:

```
CALL RANKNW(SID, ALL, IVAL, RVAL, SSFILE, MNFILE, ACCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer IVAL (7)	array of 7 elements specifying ranking options(input). IVAL(1) allow ties from specified subsystem as contingencies (0 = no, 1 = yes; 0 by default) IVAL(2) number of branch contingencies from overload ranking to include (≥ 0) (0 by default) IVAL(3) rating set (1=RATEA, 2=RATEB, 3=RATEC) (rating set program option setting by default) IVAL(4) convert ratings to estimated MW ratings (0 = no, 1 = yes; 0 by default) IVAL(5) number of voltage depression contingencies to include (≥ 0) (0 by default) IVAL(6) code indicating the set of branches to include in the voltage depression performance index (0 by default) IVAL(6) = 0 include all branches IVAL(6) = 1 include only those with a nonzero rating IVAL(7) include contingencies that create swingless islands (0 by default) IVAL(7) = 0 no IVAL(7) = 1 yes
Real RVAL (4)	array of 4 elements specifying ranking parameters(input).

	RVAL(1)	MW mismatch threshold (≥ 0.0) (Newton solution convergence tolerance, TOLN by default)
	RVAL(2)	small reactance threshold (THRSHZ $\leq$ RVAL(2) ≤ 0.005) (0.0005 by default)
	RVAL(3)	percent of rating ($0.0 \leq$ RVAL(3) ≤ 200.0) (100.0 by default)
	RVAL(4)	MW threshold for islanding contingencies (≥ 0.0) (100.0 by default)
Character*260 SSFILE		name of the subsystem description file, or blank for no subsystem (input; blank by default).
Character*260 MNFILE		name of the monitored element description file (if IVAL(2) > 0 (i.e., if the branch outage overload ranker is enabled)) (input; no default allowed).
Character*260 ACCFILE		name of the contingency solution output file, or blank for output to the progress window (input; blank by default).
Integer IERR		error code (output).
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid IVAL value
	IERR = 4	invalid RVAL value
	IERR = 5	MNFILE is blank
	IERR = 6	no contingency types enabled
	IERR = 7	error opening SSFILE or MNFILE
	IERR = 8	generators are converted
	IERR = 9	buses in island(s) without a swing bus; use activity TREE
	IERR = 10	largest mismatch exceeds mismatch tolerance
	IERR = 11	prerequisite requirements for API are not met

1.1.219. RANK_BRN_AND_MAC

Use this API to estimate the severity of designated single element outage contingencies and builds a contingency description data file with contingencies specified in decreasing order of their estimated severities.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_RANK_BRN_AND_MAC  SID  ALL  IVAL(1)..IVAL(8) RVAL(1)..RVAL(4)  SSFILE
                        MNFILE  ACCFILE
```

Python command syntax:

```
ierr = rank_brn_and_mac(sid, all, ival, rval, ssfile, mnfile, accfile)
```

Fortran command syntax:

```
CALL RANKAPI(SID, ALL, IVAL, RVAL, SSFILE, MNFILE, ACCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IVAL (8)	array of 8 elements specifying ranking options(input).	
	IVAL(1)	allow ties from specified subsystem as contingencies (0 by default)
	IVAL(1) = 0	no
	IVAL(1) = 1	yes
	IVAL(2)	number of branch contingencies from overload ranking to include (≥ 0) (0 by default)
	IVAL(3)	rating set (1=RATEA, 2=RATEB, 3=RATEC) (rating set program option setting by default)
	IVAL(4)	convert ratings to estimated MW ratings (0 by default)
	IVAL(4) = 0	no
	IVAL(4) = 1	yes
	IVAL(5)	number of voltage depression contingencies to include (≥ 0) (0 by default)
	IVAL(6)	code indicating the set of branches to include in the voltage depression performance index (0 by default)
	IVAL(6) = 0	include all branches
	IVAL(6) = 1	include only those with a nonzero rating
	IVAL(7)	include contingencies that create swingless islands (0 by default)

	IVAL(7) = 0	no
	IVAL(7) = 1	yes
	IVAL(8)	number of machine contingencies from overload ranking to include (≥ 0) (0 by default)
Real RVAL (4)	array of 4 elements specifying ranking parameters(input).	
	RVAL(1)	MW mismatch threshold (≥ 0.0) (Newton solution convergence tolerance, TOLN by default)
	RVAL(2)	small reactance threshold (THRSZ $\leq$ RVAL(2) ≤ 0.005) (0.0005 by default)
	RVAL(3)	percent of rating ($0.0 \leq$ RVAL(3) ≤ 200.0) (100.0 by default)
	RVAL(4)	MW threshold for islanding contingencies (≥ 0.0) (100.0 by default)
Character*260 SSFILE	name of the subsystem description file, or blank for no subsystem (input; blank by default).	
Character*260 MNFILE	name of the monitored element description file (if IVAL(2) > 0 (i.e., if the branch outage overload ranker is enabled) or if IVAL(8) > 0 (i.e., if the machine outage overload ranker is enabled)) (input; no default allowed).	
Character*260 ACCFILE	name of the contingency description data file, or blank for output to the progress window (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid IVAL value
	IERR = 4	invalid RVAL value
	IERR = 5	MNFILE is blank
	IERR = 6	no contingency types enabled
	IERR = 7	error opening SSFILE or MNFILE
	IERR = 8	generators are converted
	IERR = 9	buses in island(s) without a swing bus; use activity TREE
	IERR = 10	largest mismatch exceeds mismatch tolerance
	IERR = 11	prerequisite requirements for API are not met

1.1.220. RATE

This API routine is obsolete. It has been replaced by the API routine [rate_2](#).

Use this API to check branch loadings.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RATE SID ALL LINFLG RATING FMAX
```

Python command syntax:

```
ierr = rate(sid, all, linflg, rating, fmax)
```

Fortran command syntax:

```
CALL RATENW(SID, ALL, LINFLG, RATING, FMAX, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only branches connected to buses in subsystem SID ALL = 1 process all branches
Integer LINFLG	branch check to be applied (input; 1 by default). LINFLG = 1 check all lines LINFLG = 2 check non-transformer branches LINFLG = 3 check transformers LINFLG = 4 check all lines, all ratings
Integer RATING	rating to be used (input; default rating set program option setting). RATING = 1 RATEA RATING = 2 RATEB RATING = 3 RATEC
Real FMAX	line loading limit, in percent; 0.0 ≤ FMAX ≤ 500.0 (input; 100.0).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid LINFLG value IERR = 4 invalid RATING value IERR = 5 invalid FMAX value IERR = 6 prerequisite requirements for API are not met

1.1.221. RATE_2

Use this API to check branch loadings.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_RATE_2 SID ALL LINFLG TRNFLG BRKFLG RATING FMAX
```

Python command syntax:

```
ierr = rate_2(sid, all, linflg, trnflg, brkflg, rating, fmax)
```

Fortran command syntax:

```
CALL RATE_2(SID, ALL, LINFLG, TRNFLG, BRKFLG, RATING, FMAX, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only branches connected to buses in subsystem SID ALL = 1 process all branches
Integer LINFLG	include non-transformer branches that are not breakers or switches in the branch check to be applied (input; 1 by default). LINFLG = 0 no LINFLG = 1 yes
Integer TRNFLG	include transformer branches in the branch check to be applied (input; 1 by default). TRNFLG = 0 no TRNFLG = 1 yes
Integer BRKFLG	include branches that are breakers or switches in the branch check to be applied (input; 1 by default). BRKFLG = 0 no BRKFLG = 1 yes
Integer RATING	rating to be used (input; default rating set program option setting). RATING = 0 all rating sets RATING = 1 RATEA RATING = 2 RATEB RATING = 3 RATEC
Real FMAX	line loading limit, in percent; 0.0 ≤ FMAX ≤ 500.0 (input; 100.0).
Integer IERR	error code (output). IERR = 0 no error

IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	invalid LINFLG value
IERR = 4	invalid TRNFLG value
IERR = 5	invalid BRKFLG value
IERR = 6	invalid RATING value
IERR = 7	invalid FMAX value
IERR = 8	prerequisite requirements for API are not met

1.1.222. RATING_SET

Use this API to specify or return the current rating set, from 1 to 12.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_RATING_SET IVAL
```

Python command syntax:

```
ierr = rating_set(ival)
ierr, ival = rating_set()
```

Fortran command syntax:

```
CALL RATING_SET_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the current rating set, from 1 to 12 (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
Integer IOCODE	indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to the value specified in IVAL IOCODE = 1 return the current value of the option setting in IVAL
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid IVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

1.1.223. RAWD

This API routine is obsolete. It has been replaced by the API routine [rawd_2](#).

Use this API to replicate the working case in the form of a power flow raw data file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RAWD  SID  ALL  STATUS(1)..STATUS(6)  OUT  OFILE
```

Python command syntax:

```
ierr = rawd(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RAWDAPI(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses when STATUS(4) = 0; area ties only when STATUS(4) = 1
Integer STATUS (6)	array of 6 elements specifying options(input). STATUS(1) include records for Type 4 buses (1 by default) STATUS(1) = 0 no STATUS(1) = 1 yes STATUS(2) include records for out-of-service branches (1 by default) STATUS(2) = 0 no STATUS(2) = 1 yes STATUS(3) include records for equipment in the subsystem (1 by default) STATUS(3) = 0 no STATUS(3) = 1 yes STATUS(4) include records for subsystem ties (0 by default) STATUS(4) = 0 no STATUS(4) = 1 yes STATUS(5) use bus names as bus identifiers (0 by default) STATUS(5) = 0 no

	STATUS(5) = 1	yes
	STATUS(6)	Raw Data File type (0 by default)
	STATUS(6) = 0	for activity READ with IC=0
	STATUS(6) = 1	for activity READ with IC=1
	STATUS(6) = 2	for activity RDCH
Integer OUT	destination selection (input; 1 by default).	
	OUT = 0	direct output to a data file specified by OFILE
	OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid OUT value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.224. RAWDX

Use this API to replicate the working case in the form of an extended power flow raw data file.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_RAWDX  SID  ALL  STATUS(1)..STATUS(6)  OUT  OFILE
```

Python command syntax:

```
ierr = rawdx(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RAWDXAPI(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses when STATUS(4) = 0; area ties only when STATUS(4) = 1
Integer STATUS (6)	array of 6 elements specifying options(input). STATUS(1) include records for Type 4 buses (1 by default) STATUS(1) = 0 no STATUS(1) = 1 yes STATUS(2) include records for out-of-service branches (1 by default) STATUS(2) = 0 no STATUS(2) = 1 yes STATUS(3) include records for equipment in the subsystem (1 by default) STATUS(3) = 0 no STATUS(3) = 1 yes STATUS(4) include records for subsystem ties (0 by default) STATUS(4) = 0 no STATUS(4) = 1 yes STATUS(5) include load record option (honored when ALL=0) (0 by default) STATUS(5) = 0 for all loads at subsystem buses STATUS(5) = 1 for subsystem loads at all buses

	STATUS(5) = 2	for all loads at subsystem buses and subsystem loads at non-subsystem buses
	STATUS(6)	Raw Data File type (0 by default)
	STATUS(6) = 0	for activity READX with IC=0
	STATUS(6) = 1	for activity READX with IC=1
Integer OUT	destination selection (input; 1 by default).	
	OUT = 0	direct output to a data file specified by OFILE
	OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid OUT value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.225. RAWD_2

Use this API to replicate the working case in the form of a power flow raw data file.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_RAWD_2  SID  ALL  STATUS(1)..STATUS(7)  OUT  OFILE
```

Python command syntax:

```
ierr = rawd_2(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RAWDAPI_2(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses when STATUS(4) = 0; only area tie branches when STATUS(4) = 1
Integer STATUS (7)	array of 7 elements specifying options(input). STATUS(1) include records for Type 4 buses (1 by default) STATUS(1) = 0 no STATUS(1) = 1 yes STATUS(2) include records for out-of-service branches (1 by default) STATUS(2) = 0 no STATUS(2) = 1 yes STATUS(3) include records for equipment in the subsystem (1 by default) STATUS(3) = 0 no STATUS(3) = 1 yes STATUS(4) include records for subsystem tie branches (0 by default) STATUS(4) = 0 no STATUS(4) = 1 yes STATUS(5) include load record option (honored when ALL=0) (0 by default) STATUS(5) = 0 for all loads at subsystem buses STATUS(5) = 1 for subsystem loads at all buses

	STATUS(5) = 2	for all loads at subsystem buses and subsystem loads at non-subsystem buses
	STATUS(6)	use bus names as bus identifiers (0 by default)
	STATUS(6) = 0	no
	STATUS(6) = 1	yes
	STATUS(7)	Raw Data File type (0 by default)
	STATUS(7) = 0	for activity READ with IC=0
	STATUS(7) = 1	for activity READ with IC=1
	STATUS(7) = 2	for activity RDCH; include all data categories
	STATUS(7) = 3	for activity RDCH; exclude the substation data category
	STATUS(7) = 4	for activity RDCH; include only the substation data category
Integer OUT	destination selection (input; 1 by default).	
	OUT = 0	direct output to a data file specified by OFILE
	OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid OUT value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.226. RAWX_TO_CSV

Use this API to export rawx (extended raw data) table to a CSV (comma-separated values) file.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_RAWX_TO_CSV
```

Python command syntax:

```
ierr = rawx_to_csv(tblname, ofile)
```

Fortran command syntax:

```
CALL RAWX_TO_CSV(TBLNAME, OFILE, IERR)
```

Where:

Character*100 TBLNAME	name of the data table to export (not case sensitive) (input; no default allowed).	
Character*260 OFILE	file path of the CSV output file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid tblname
	IERR = 2	error opening OFILE
	IERR = 3	error generating RAWX data
	IERR = 4	error reading RAWX data
	IERR = 10	prerequisite requirements for API are not met

1.1.227. RDCH

Use this API to read power flow change data into the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RDCH  NUMNAM  IFILE
```

Python command syntax:

```
ierr = rdch(numnam, ifile)
```

Fortran command syntax:

```
CALL RDCHAPI(NUMNAM, IFILE, IERR)
```

Where:

Integer NUMNAM	flag for bus number or name specification on records (input; 0 by default).
	NUMNAM = 0 bus numbers
	NUMNAM = 1 bus names
Character*260 IFILE	name of power flow data file, Options (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid NUMNAM
	IERR = 10 error opening IFILE
	IERR = 11 prerequisite requirements for API are not met

1.1.228. RDCHRAWVERSION

Use this API to read a Power Flow Change Raw Data File into the working case. Allowed raw file formats are PSSE-15 through current format.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_RDCHRAWVERSION  NUMNAM  VERNUM  IFILE
```

Python command syntax:

```
ierr = rdchrawversion(numnam, vernum, ifile)
```

Fortran command syntax:

```
CALL RDCHRAWVERSION(NUMNAM, VERNUM, IFILE, IERR)
```

Where:

Integer NUMNAM	flag for bus number or name specification on records (input; 0 by default).
	NUMNAM = 0 bus numbers
	NUMNAM = 1 bus names
Character*14 VERNUM	version number corresponding to the format of IFILE VERNUM is in the format of a PSSE release number. Example: If IFILE format is of PSSE-29.5.1: VERNUM = '29' or = '29.5' or = '29.5.1' (input; no default allowed).
Character*260 IFILE	name of power flow raw data file (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid NUMNAM value
	IERR = 2 invalid VERNUM value
	IERR = 3 unable to convert file
	IERR = 4 error opening temporary file
	IERR = 5 invalid revision number
	IERR = 10 error opening IFILE
	IERR = 11 prerequisite requirements for API are not met

1.1.229. RDEQ

Use this API to build an electrical equivalent of radial and, optionally, two-point Type 1 buses outside of a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RDEQ SID ALL STATUS(1)..STATUS(8)
```

Python command syntax:

```
ierr = rdeq(sid, all, status)
```

Fortran command syntax:

```
CALL RDEQNW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses outside of subsystem SID
	ALL = 1	process all buses
Integer STATUS (8)	array of 8 elements specifying used to control equivalencing options. A value of 0 means the option is not enabled. A value of 1 means the option is enabled. They are as follows(input).	
	STATUS(1)	build an electrical equivalent of radial buses only (0 by default)
	STATUS(2)	suppress the equivalencing option for transformers (0 by default)
	STATUS(3)	suppress the equivalencing option for zero impedance lines (0 by default)
	STATUS(4)	suppress the equivalencing option for controlled buses (0 by default)
	STATUS(5)	suppress the equivalencing option for mutually coupled branches (0 by default)
	STATUS(6)	suppress the equivalencing option for area boundary buses (0 by default)
	STATUS(7)	suppress the equivalencing option for zone boundary buses (0 by default)
	STATUS(8)	apply transformer impedance correction to zero sequence network (1 by default)
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined

IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	error writing the working case to a temporary file
IERR = 5	load table is full; restoring original working case
IERR = 6	fixed bus shunt table is full; restoring original working case
IERR = 7	error opening temporary file
IERR = 8	prerequisite requirements for API are not met

1.1.230. READ

Use this API to read a power flow raw data file and add all the data specified in it to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_READ  NUMNAM  IFILE
```

Python command syntax:

```
ierr = read(numnam, ifile)
```

Fortran command syntax:

```
CALL READAPI(NUMNAM, IFILE, IERR)
```

Where:

Integer NUMNAM	flag for bus number or name specification on records (input; 0 by default).	
	NUMNAM = 0	bus numbers
	NUMNAM = 1	bus names
Character*260 IFILE	filename of the power flow raw data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid NUMNAM value
	IERR = 2	invalid revision number
	IERR = 3	unable to convert file
	IERR = 4	error opening temporary file
	IERR = 10	error opening IFILE
	IERR = 11	prerequisite requirements for API are not met

1.1.231. READCAPCURVES

Use this API to read data contained in a Machine Capability Curve Data File into the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_READCAPCURVES FILE
```

Python command syntax:

```
ierr = readcapcurves(file)
```

Fortran command syntax:

```
CALL READCAPCURVES(FILE, IERR)
```

Where:

Character*260 FILE	filename of the Machine Capability Curve Data File (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening FILE
	IERR = 2	invalid revision number
	IERR = 3	prerequisite requirements for API are not met

1.1.232. READRAWVERSION

Use this API to read a power flow raw data file and add all the data specified in it to the working case. Allowed raw file formats are PSSE-15 through current format.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_READRAWVERSION  NUMNAM  VERNUM  IFILE
```

Python command syntax:

```
ierr = readrawversion(numnam, vernum, ifile)
```

Fortran command syntax:

```
CALL READRAWVERSION(NUMNAM, VERNUM, IFILE, IERR)
```

Where:

Integer NUMNAM	flag for bus number or name specification on records (input; 0 by default).
	NUMNAM = 0 bus numbers
	NUMNAM = 1 bus names
Character*14 VERNUM	version number corresponding to the format of IFILE. VERNUM is in the format of a PSSE release number. Example: If IFILE format is of PSSE-29.5.1: VERNUM = '29' or = '29.5' or = '29.5.1' (input; no default allowed).
Character*260 IFILE	name of power flow raw data file (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid NUMNAM value
	IERR = 2 invalid VERNUM value
	IERR = 3 unable to convert file
	IERR = 4 error opening temporary file
	IERR = 5 invalid revision number
	IERR = 10 error opening IFILE
	IERR = 11 prerequisite requirements for API are not met

1.1.233. READSUB

Use this API to read a power flow raw data file and add subsystem data specified in it to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_READSUB  NUMNAM  IFILE  STATUS(1)  STATUS(2)  STATUS(3)  USEKV
             BASEKV(1) BASEKV(2)  SIDAREA  SIDOWNER  SIDZONE
```

Python command syntax:

```
ierr = readsub(numnam, ifile, status, usekv, basekv, sidarea, sidowner,
               sidzone)
```

Fortran command syntax:

```
CALL READSUB(NUMNAM, IFILE, STATUS, USEKV, BASEKV, SIDAREA, SIDOWNER,
             SIDZONE, IERR)
```

Where:

Integer NUMNAM	flag for bus number or name specification on records (input; 0 by default).
	NUMNAM = 0 bus numbers
	NUMNAM = 1 bus names
Character*260 IFILE	name of the power flow raw data file (input; no default allowed).
Integer STATUS (3)	array of 3 elements specifying options(input).
	STATUS(1) append flag (0 by default)
	STATUS(1) = 0 initialize working case before reading data
	STATUS(1) = 1 append data to that already in the working case
	STATUS(2) boundary bus identification flag (0 by default)
	STATUS(2) = 0 do not change type codes of boundary buses
	STATUS(2) = 1 change type codes of boundary buses in preparation for the equivalencing calculation
	STATUS(3) data option (1 by default)
	STATUS(3) = 1 add only data from within subsystem
	STATUS(3) = 2 add only ties from subsystem
	STATUS(3) = 3 add subsystem data plus ties
Integer USEKV	subsystem base voltage flag (input; 0 by default).
	USEKV = 0 do not use base voltage as a subsystem selection criterion
	USEKV = 1 use base voltage as a subsystem selection criterion
Real BASEKV (2)	array of 2 elements specifying the base voltage range(input).
	BASEKV(1) minimum base voltage (0.0 by default)

	BASEKV(2)	maximum base voltage (BASEKV (1) by default)
Integer SIDAREA	area subsystem identifier (0 through 11), or -1 to bypass subsystem specification by area (input; -1).	
Integer SIDOWNER	owner subsystem identifier (0 through 11), or -1 to bypass subsystem specification by owner (input; -1).	
Integer SIDZONE	zone subsystem identifier (0 through 11), or -1 to bypass subsystem specification by zone (input; -1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid NUMNAM value
	IERR = 2	invalid STATUS value
	IERR = 3	invalid USEKV value
	IERR = 4	invalid BASEKV value(s)
	IERR = 5	BASEKV(1) is greater than BASEKV(2)
	IERR = 6	invalid SIDAREA value or area subsystem SIDAREA is not defined
	IERR = 7	invalid SIDOWNER value or owner subsystem SIDOWNER is not defined
	IERR = 8	invalid SIDZONE value or zone subsystem SIDZONE is not defined
	IERR = 9	no subsystem specified
	IERR = 10	error opening IFILE
	IERR = 11	invalid revision number
	IERR = 12	prerequisite requirements for API are not met
	IERR = 14	unable to convert file
	IERR = 15	error opening temporary file

1.1.234. READSUBRAWVERSION

Use this API to read a power flow raw data file and add subsystem data specified in it to the working case. Allowed raw file formats are PSSE-15 through current format.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_READSUBRAWVERSION  NUMNAM  VERNUM  IFILE  STATUS(1)  STATUS(2)
                        STATUS(3)  USEKV  BASEKV(1)  BASEKV(2)  SIDAREA  SIDOWNER  SIDZONE
```

Python command syntax:

```
ierr = readsubrawversion(numnam, vernum, ifile, status, usekv, basekv,
                        sidarea, sidowner, sidzone)
```

Fortran command syntax:

```
CALL READSUBRAWVERSION(NUMNAM, VERNUM, IFILE, STATUS, USEKV, BASEKV,
                        SIDAREA, SIDOWNER, SIDZONE, IERR)
```

Where:

Integer NUMNAM	flag for bus number or name specification on records (input; 0 by default).
	NUMNAM = 0 bus numbers
	NUMNAM = 1 bus names
Character*14 VERNUM	version number corresponding to the format of IFILE. VERNUM is in the format of a PSSE release number. Example: If IFILE format is of PSSE-29.5.1: VERNUM = '29' or = '29.5' or = '29.5.1' (input; no default allowed).
Character*260 IFILE	filename of the power flow raw data file (input; no default allowed).
Integer STATUS (3)	array of 3 elements specifying options(input).
	STATUS(1) append flag (0 by default)
	STATUS(1) = 0 initialize working case before reading data
	STATUS(1) = 1 append data to that already in the working case
	STATUS(2) boundary bus identification flag (0 by default)
	STATUS(2) = 0 do not change type codes of boundary buses
	STATUS(2) = 1 change type codes of boundary buses in preparation for the equivalencing calculation
	STATUS(3) data option (1 by default)
	STATUS(3) = 1 add only data from within subsystem
	STATUS(3) = 2 add only ties from subsystem
	STATUS(3) = 3 add subsystem data plus ties
Integer USEKV	subsystem base voltage flag (input; 0 by default).

	USEKV = 0	do not use base voltage as a subsystem selection criterion
	USEKV = 1	use base voltage as a subsystem selection criterion
Real BASEKV (2)	array of 2 elements specifying the base voltage range(input).	
	BASEKV(1)	minimum base voltage (0.0 by default)
	BASEKV(2)	maximum base voltage (BASEKV (1) by default)
Integer SIDAREA	area subsystem identifier (0 through 11), or -1 to bypass subsystem specification by area (input; -1).	
Integer SIDOWNER	owner subsystem identifier (0 through 11), or -1 to bypass subsystem specification by owner (input; -1).	
Integer SIDZONE	zone subsystem identifier (0 through 11), or -1 to bypass subsystem specification by zone (input; -1).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid NUMNAM value
	IERR = 2	invalid STATUS value
	IERR = 3	invalid USEKV value
	IERR = 4	invalid BASEKV value(s)
	IERR = 5	BASEKV(1) is greater than BASEKV(2)
	IERR = 6	invalid SIDAREA value or area subsystem SIDAREA is not defined
	IERR = 7	invalid SIDOWNER value or owner subsystem SIDOWNER is not defined
	IERR = 8	invalid SIDZONE value or zone subsystem SIDZONE is not defined
	IERR = 9	no subsystem specified
	IERR = 10	error opening IFILE
	IERR = 11	invalid revision number
	IERR = 12	prerequisite requirements for API are not met
	IERR = 13	invalid VERNUM value
	IERR = 14	unable to convert file
	IERR = 15	error opening temporary file

1.1.235. READVDFFROMRAWX

Use this API to read voltage droop controls defined in Rawx file as user defined data into working case.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_READVDFFROMRAWX  OPTION
```

Python command syntax:

```
ierr = readvdffromrawx(option)
```

Fortran command syntax:

```
CALL READVDFFROMRAWX(OPTION, IERR)
```

Where:

Integer OPTION	1 to append voltage droop controls in Rawx file to existing voltage droop controls, 0 to delete all existing voltage droop controls (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTION value

1.1.236. READX

Use this API to read an extended power flow raw data file and add all the data specified in it to the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_READX SFILE
```

Python command syntax:

```
ierr = readx(sfile)
```

Fortran command syntax:

```
CALL READXAPI(SFILE, IERR)
```

Where:

Character*260 SFILE	filename of the extended power flow raw data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid revision number
	IERR = 2	unable to convert file
	IERR = 3	error opening SFILE
	IERR = 4	prerequisite requirements for API are not met

1.1.237. REC�

Use this API to electrically reconnect a bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_REC� IBUS
```

Python command syntax:

```
ierr = recn(ibus)
```

Fortran command syntax:

```
CALL REC�API( IBUS, IERR)
```

Where:

Integer IBUS	bus number of bus to be reconnected (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	prerequisite requirements for API are not met

1.1.238. REGB

Use this API to tabulate those buses where voltages are controlled by generation, switched shunts, and/or other voltage controlling equipment.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_REGB SID ALL
```

Python command syntax:

```
ierr = regb(sid, all)
```

Fortran command syntax:

```
CALL REGBNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.239. RELIND

This API routine is obsolete. It has been replaced by the API routine [relind_2](#).

Use this API to run probabilistic reliability assessment for transmission systems. Probabilistic indices on system problems are calculated in entire system or a given subsystem, these problems include flow overloading, voltage violation and loss of load, etc.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_RELIND  OPTIONS(1)..OPTIONS(7)  VALUES(1)..VALUES(3)  LABEL  ACCFILE
            DFXFILE  PRBFILE  STSFILE
```

Python command syntax:

```
ierr = relind(options, values, label, accfile, dfxfile, prbfile, stsfile)
```

Fortran command syntax:

```
CALL RELINDAPI(OPTIONS, VALUES, LABEL, ACCFILE, DFXFILE, PRBFILE, STSFILE,
               IERR)
```

Where:

Integer OPTIONS (7)	array of 7 elements specifying options(input).
OPTIONS(1)	report format (1 by default)
OPTIONS(1) = 1	system problem summary report
OPTIONS(1) = 2	system loss of load report
OPTIONS(1) = 3	bus loss of load report
OPTIONS(1) = 4	branch flow overloading report
OPTIONS(1) = 5	bus voltage violation report
OPTIONS(1) = 6	contingency summary
OPTIONS(1) = 7	system problem indices
OPTIONS(1) = 8	system loss of load indices
OPTIONS(1) = 9	bus loss of load indices
OPTIONS(1) = 10	branch overload problem indices
OPTIONS(1) = 11	bus voltage problem indices
OPTIONS(1) = 12	contingency summary with outage statistics
OPTIONS(2)	mode (1 by default)
OPTIONS(2) = 1	post contingency mode
OPTIONS(2) = 2	post tripping mode
OPTIONS(2) = 3	post corrective action mode
OPTIONS(3)	rating set (rating set program option setting by default)
OPTIONS(3) = 1	RATEA
OPTIONS(3) = 2	RATEB
OPTIONS(3) = 3	RATEC

	OPTIONS(4)	include ties from study subsystem (0 by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable
	OPTIONS(5)	include interfaces (0 by default)
	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(6)	Outage Statistics Data File (0 by default)
	OPTIONS(6) = 0	disable
	OPTIONS(6) = 1	enable
	OPTIONS(7)	normalize probability (0 by default)
	OPTIONS(7) = 0	disable
	OPTIONS(7) = 1	enable
Real VALUES (3)	array of 3 elements specifying reliability assessment parameters(input).	
	VALUES(1)	percent of rating set (≥ 0 and ≤ 200.0 , 100.0 by default)
	VALUES(2)	probability cutoff (≥ 0 ; 0.0001 by default)
	VALUES(3)	frequency cutoff (≥ 0 ; 0.0001 by default)
Character*32 LABEL	name of the study subsystem (input; blank by default, probabilistic reliability assessment is carried out in entire system).	
Character*260 ACCFILE	contingency solution output file (input; no default allowed).	
Character*260 DFXFILE	DFAX data file (input; no default allowed).	
Character*260 PRBFILE	outage statistics data file (input; blank for none if OPTIONS(1) is between 1 and 6, inclusive; no default allowed if OPTIONS(1) is greater).	
Character*260 STSFILE	output outage statistics data file (input; blank for none if OPTIONS(6) is zero or OPTIONS(1) is from 1 to 6; otherwise no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPTIONS value
	IERR = 2	no dispatch subsystem specified
	IERR = 3	no Contingency Solution Output File specified
	IERR = 4	no Distribution Factor Data File specified
	IERR = 5	no Outage Statistic Data File specified
	IERR = 6	no Output Outage Statistic Data File specified
	IERR = 7	generators are converted
	IERR = 8	buses in island(s) without a swing bus--use activity TREE
	IERR = 9	subsystem not found in Distribution Factor Data File
	IERR = 10	Contingency Solution Output File is not created by Multiple Level Contingency Analysis of PSSE 31 or later

IERR = 11	case data is not the one used in contingency analysis
IERR = 12	Distribution Factor Data File is not the one used in contingency analysis
IERR = 13	error reading Contingency Solution Output file
IERR = 51	error opening Contingency Solution Output File
IERR = 52	error opening Distribution Factor Data File
IERR = 53	error opening Outage Statistic Data File
IERR = 54	error opening Output Outage Statistic Data File
IERR = 55	prerequisite requirements for function not met

1.1.240. RELIND_2

Use this API to run probabilistic reliability assessment for transmission systems. Probabilistic indices on system problems are calculated in entire system or a given subsystem, these problems include flow overloading, voltage violation and loss of load, etc.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_RELIND_2  OPTREL(1)..OPTREL(8) RELREL(1)..RELREL(3) CHAARG ACCFILE
              DFXFILE PRBFILE STSFILE
```

Python command syntax:

```
ierr = relind_2(optrel, relrel, chaarg, accfile, dfxfile, prbfile,
               stsfile)
```

Fortran command syntax:

```
CALL RELINDAPI_2(OPTREL, RELREL, CHAARG, ACCFILE, DFXFILE, PRBFILE,
                STSFILE, IERR)
```

Where:

Integer OPTREL (8)	array of elements specifying output options(input).
OPTREL(1)	report format (1 by default)
OPTREL(1) = 1	system problem summary report
OPTREL(1) = 2	system loss of load report
OPTREL(1) = 3	bus loss of load report
OPTREL(1) = 4	branch flow overloading report
OPTREL(1) = 5	bus voltage violation report
OPTREL(1) = 6	contingency summary
OPTREL(1) = 7	system problem indices
OPTREL(1) = 8	system loss of load indices
OPTREL(1) = 9	bus loss of load indices
OPTREL(1) = 10	branch overload problem indices
OPTREL(1) = 11	bus voltage problem indices
OPTREL(1) = 12	contingency summary with outage statistics
OPTREL(2)	output mode (1 by default)
OPTREL(2) = 1	post contingency mode
OPTREL(2) = 2	post tripping mode
OPTREL(2) = 3	post corrective action mode
OPTREL(3)	rating set (rating set program option setting by default)
OPTREL(3) = 1	RATEA
OPTREL(3) = 2	RATEB
OPTREL(3) = 3	RATEC
OPTREL(4)	voltage limit.
OPTREL(4) = 1	normal

	OPTREL(4) = 2	emergency
	OPTREL(5)	include ties from study subsystem (0 by default)
	OPTREL(5) = 0	disable
	OPTREL(5) = 1	enable
	OPTREL(6)	include interfaces (0 by default)
	OPTREL(6) = 0	disable
	OPTREL(6) = 1	enable
	OPTREL(7)	output Outage Statistics Data File (0 by default)
	OPTREL(7) = 0	disable
	OPTREL(7) = 1	enable
	OPTREL(8)	normalize probability (0 by default)
	OPTREL(8) = 0	disable
	OPTREL(8) = 1	enable
Real RELREL (3)	array of elements specifying reliability assessment parameters(input).	
	RELREL(1)	percent of rating set, (≥ 0 and ≤ 200.0 , 100.0 by default)
	RELREL(2)	probability cutoff (≥ 0 ; 0.0001 by default).
	RELREL(3)	frequency cutoff (≥ 0 ; 0.0001 by default).
Character*32 CHAARG	name of the study subsystem (blank by default, probabilistic reliability assessment is carried out in entire system). (input).	
Character*260 ACCFILE	contingency solution output file (input; no default allowed).	
Character*260 DFXFILE	DFAX data file (input; no default allowed).	
Character*260 PRBFILE	outage statistics data file (blank for none if OPTIONS(1) is between 1 and 6, inclusive; no default allowed if OPTIONS(1) is greater). (input).	
Character*260 STSFILE	output outage statistics data file (blank for none if OPTIONS(6) is zero or OPTIONS(1) is from 1 to 6; otherwise no default allowed). (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	no dispatch subsystem specified
	IERR = 3	no contingency solution output file specified
	IERR = 4	no DFAX data file specified
	IERR = 5	no outage statistic data file specified
	IERR = 6	no output outage statistic data file specified
	IERR = 7	generators are converted
	IERR = 8	buses in island(s) without a swing bus; use activity TREE
	IERR = 9	subsystem not found in DFAX data file

IERR = 10	contingency solution output file is not created by Multiple Level Contingency Analysis of PSSE 31 or later
IERR = 11	case data is not the one used in contingency analysis
IERR = 12	DFAX data file is not the one used in contingency analysis
IERR = 13	error reading contingency solution output file
IERR = 51	error opening contingency solution output file
IERR = 52	error opening DFAX data file
IERR = 53	error opening outage statistic data file
IERR = 54	error opening output outage statistic data file
IERR = 55	prerequisite requirements for function not met

1.1.241. REMM

Use this API to read transaction event data from a transactions raw data file and add it to PSSE working memory.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_REMM  OPT  IFILE
```

Python command syntax:

```
ierr = remm(opt, ifile)
```

Fortran command syntax:

```
CALL REMMAPI(OPT, IFILE, IERR)
```

Where:

Integer OPT	flag for new or change data records (input; 0 by default).
	OPT = 0 new data; replaces existing transactions data.
	OPT = 1 change data; modifies existing transactions data.
Character*260 IFILE	name of transactions raw data file (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid OPT value
	IERR = 2 no transactions defined; change mode invalid
	IERR = 3 error opening IFILE
	IERR = 4 prerequisite requirements for API are not met

1.1.242. REPORT_OUTPUT

Use this API to specify the report output device.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_REPORT_OUTPUT ISLCT FILARG OPTIONS(1) OPTIONS(2)
```

Python command syntax:

```
ierr = report_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL OPENREPORTDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
	ISLCT = 1 standard destination. In the PSSE GUI standard output for reports is the Report tab of the output bar.
	ISLCT = 2 direct output to a file.
	ISLCT = 3 direct output to a printer.
	ISLCT = 4 direct output to progress device.
	ISLCT = 5 direct output to report device.
	ISLCT = 6 no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
	OPTIONS(1) file and printer open options: The OPTIONS(1) values may be summed to select multiple options
	OPTIONS(1) = 0 open with carriage control format and, for files, for overwrite of existing files
	OPTIONS(1) = 1 open with list format
	OPTIONS(1) = 2 open file for append (file output only)
	OPTIONS(1) = 2 set printer orientation to portrait mode (printer output only)
	OPTIONS(1) = 4 open printer in immediate print mode (printer output only)
	OPTIONS(2) number of copies to print (printer only)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met
	IERR = 2 failed to open device

1.1.243. RESQ

Use this API to read sequence data from a sequence data file and add it to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RESQ  IFILE
```

Python command syntax:

```
ierr = resq(ifile)
```

Fortran command syntax:

```
CALL RESQAPI(IFILE, IERR)
```

Where:

Character*260 IFILE	name of the power flow sequence data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening IFILE
	IERR = 2	prerequisite requirements for API are not met

1.1.244. RESQVERSION

Use this API to read a network sequence data file and add all the data specified in it to the working case. Allowed seq file formats are PSSE-15 through the current format.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_RESQVERSION  VERNUM  IFILE
```

Python command syntax:

```
ierr = resqversion(vernum, ifile)
```

Fortran command syntax:

```
CALL RESQVERSION(VERNUM, IFILE, IERR)
```

Where:

Character*14 VERNUM	version number corresponding to the format of the IFILE. VERNUM is in the format of a PSSE release number. Example: If IFILE format is of PSSE-29.5.1: VERNUM = '29' or = '29.5' or = '29.5.1' (input; no default allowed).	
Character*260 IFILE	name of the power flow sequence data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 2	invalid VERNUM value
	IERR = 3	unable to convert file
	IERR = 4	error opening temporary file
	IERR = 5	invalid revision number
	IERR = 10	error opening IFILE
	IERR = 11	prerequisite requirements for API are not met

1.1.245. RESULT_TABLE_OUTPUT

Use this API to the result table output option.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_RESULT_TABLE_OUTPUT IVAL
```

Python command syntax:

```
ierr = result_table_output(ival)
ierr, ival = result_table_output()
```

Fortran command syntax:

```
CALL RESULT_TABLE_OUTPUT(IVAL, ICODE, IERR)
```

Where:

Integer IVAL	option setting (input; no default allowed).
IVAL = 0	no result table output
IVAL = 1	text result table output only
IVAL = 2	spreadsheet result table output only
IVAL = 3	both text and spreadsheet table output
Integer ICODE	operation mode of the API (no default allowed).
ICODE = 0	set the option setting to the value specified in IVAL
ICODE = 1	return the current value of the option setting in IVAL
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	prerequisite requirements for API are not met

1.1.246. RETI

Use this API to read the long title from an input file into the working case.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_RETI  IFILE
```

Python command syntax:

```
ierr = reti(ifile)
```

Fortran command syntax:

```
CALL RETIAPI(IFILE, IERR)
```

Where:

Character*260 IFILE	name of long title data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening IFILE
	IERR = 2	prerequisite requirements for API are not met

1.1.247. RETRY_PSSUSERPF

Use this API to allow the loading or use of the Powerflow Customization Interface (PCI) implementation module (pssuserpf) after a failure.

For efficiency reasons loading the PCI module is only attempted once. You may reset the flag controlling this with this API.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_RETRY_PSSUSERPF
```

Python command syntax:

```
ierr = retry_pssuserpf()
```

Fortran command syntax:

```
CALL RETRYPSSUSERPF_FC(IERR)
```

Where:

Integer IERR	error code (output).
IERR = 1	prerequisite requirements for API are not met.

1.1.248. REV29_NAMES

Use this API to set the extended bus name input format to either the PSSE-29 or PSSE-30 format.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_REV29_NAMES IVAL
```

Python command syntax:

```
ierr = rev29_names(ival)
```

Fortran command syntax:

```
CALL REV29_NAMES_API(IVAL, IERR)
```

Where:

Integer IVAL	extended bus name option flag (input; 0 by default).	
	IVAL = 0	PSSE-30 format (12 characters plus base voltage)
	IVAL = 1	PSSE-29 or earlier format (8 characters plus base voltage)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	prerequisite requirements for API are not met

1.1.249. RNFI

Use this API to reproduce the results of a working case bus renumbering operation in auxiliary data input files.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_RNFI  FTYPE  TRNFILE  INPFILE  OUTFILE
```

Python command syntax:

```
ierr = rnfi(ftype, trnfile, inpfile, outfile)
```

Fortran command syntax:

```
CALL RNFIAPI(FTYPE, TRNFILE, INPFILE, OUTFILE, IERR)
```

Where:

Integer FTYPE	type of data file to be processed (input; 1 by default).
	FTYPE = 1 sequence data file
	FTYPE = 2 drawing coordinate data file
	FTYPE = 3 dynamics data file
	FTYPE = 4 machine impedance data file
	FTYPE = 5 economic dispatch data file
	FTYPE = 6 inertia and governor response data file
	FTYPE = 7 breaker duty data file
	FTYPE = 8 fault dspecification data file
	FTYPE = 9 fault control data file
	FTYPE = 10 machine capability Curve data file
	FTYPE = 11 load throwover data file
	FTYPE = 12 ANSI fault specification data file
	FTYPE = 13 subsystem description data file
	FTYPE = 14 monitored element data file
	FTYPE = 15 contingency description data file
	FTYPE = 16 tripping element data file
Character*260 TRNFILE	name of bus renumbering translation file (input; no default allowed).
Character*260 INPFILE	name of data file to be renumbered (input; no default allowed).
Character*260 OUTFILE	name of data file (blank for output to the report window) (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid FTYPE value
	IERR = 2 error opening translation file
	IERR = 3 error opening input data file
	IERR = 4 error opening output data file

IERR = 5

prerequisite requirements for API are not met

1.1.250. RSOL

Use this API to perform a robust power flow solution (activity RSOL).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_RSOL OPTIONS(1)...OPTIONS(10) REALAR(1)...REALAR(2)
```

Python command syntax:

```
ierr = rsol(options, realar)
```

Fortran command syntax:

```
CALL RSOLAPI(OPTIONS, REALAR, IERR)
```

Where:

Integer OPTIONS (10)	array of 10 elements specifying (input).	
	OPTIONS(1)	Initial solution method (0 by default)
	OPTIONS(1) = 0	Fixed Slope Decoupled Newton-Raphson (FD-NS)
	OPTIONS(1) = 1	Full Newton-Raphson (FNSL)
	OPTIONS(1) = 2	Decoupled Newton-Raphson (NSOL)
	OPTIONS(2)	Initial tap adjustment flag (0 by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable stepping adjustment
	OPTIONS(2) = 2	enable direct adjustment
	OPTIONS(3)	Initial area interchange adjustment flag (0 by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(3) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(4)	Initial phase shift adjustment flag (0 by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable
	OPTIONS(5)	Initial dc tap adjustment flag (0 by default)
	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(6)	Initial switch shunt adjustment flag (0 by default)
	OPTIONS(6) = 0	disable
	OPTIONS(6) = 1	enable

	OPTIONS(6) = 2	enable continuous mode, disable discrete mode
	OPTIONS(7)	Initial flat start flag (0 by default)
	OPTIONS(7) = 0	do not flat start
	OPTIONS(7) = 1	flat start
	OPTIONS(7) = 2	flat start, then estimate voltage magnitudes
	OPTIONS(7) = 3	flat start, then estimate voltage phase angles
	OPTIONS(7) = 4	flat start, then estimate voltage magnitudes and phase angles
	OPTIONS(8)	Initial var limit flag (0 by default)
	OPTIONS(8) = 0	apply var limits immediately
	OPTIONS(8) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(8) = -1	ignore var limits
	OPTIONS(9)	Initial non-divergent flag (0 by default)
	OPTIONS(9) = 0	disable
	OPTIONS(9) = 1	enable
	OPTIONS(10)	Solution failure option (0 by default)
	OPTIONS(10) = 0	do not restore solution or settings on solution failure
	OPTIONS(10) = 1	restore original solution and settings on solution failure
	OPTIONS(10) = 2	restore best found (lowest mismatch) solution and settings on solution failure
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	Bus mismatch threshold for smoothing (200.0 by default)
	REALAR(2)	Var band (0.4 by default)
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 1	Prerequisites for api not met
	IERR = 2	Invalid OPTIONS value
	IERR = 3	Invalid realar value
	IERR = 4	Solution error occurred
	IERR = 5	Error getting mismatch
	IERR = 6	Error creating temporary case files
	IERR = 7	Error reading from temporary case files
	IERR = 8	Error writing to temporary case files
	IERR = 9	Error deleting temporary case files
	IERR = 10	Error creating script file
	IERR = 11	Error writing to script file

1.1.251. RUNLASTSOLUTION

Use this API to run the last known power flow solution. A power flow solution is 'known' if the solution method and parameters are contained within the SAV or RAW file. It is useful for solving a case from an outside source for which there is no documentation on solution methods.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_RUNLASTSOLUTION
```

Python command syntax:

```
ierr = runlastsolution()
```

Fortran command syntax:

```
CALL RUNLASTSOLUTION(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.252. RWCM

Use this API to replicate the working case in IEEE common tape format.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RWCM  OPT  OUT  OFILE
```

Python command syntax:

```
ierr = rwcm(opt, out, ofile)
```

Fortran command syntax:

```
CALL RWCMAPI(OPT, OUT, OFILE, IERR)
```

Where:

Integer OPT	dc line/FACTS/GNE device option (input; 0 by default).
	OPT = 0 ignore dc lines, FACTS devices, and GNE devices
	OPT = 1 add powers to loads
Integer OUT	selection option (input; 1 by default).
	OUT = 0 direct output to the data file specified by OFILE
	OUT = 1 direct output to the current report device
Character*260 OFILE	name of the output file (when OUT is 0) (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid OPT value
	IERR = 2 invalid OUT value
	IERR = 3 buses in case with 5 or 6 digit bus numbers
	IERR = 4 n buses in case but IEEE common format can handle only 9999
	IERR = 5 error opening OFILE
	IERR = 6 prerequisite requirements for API are not met

1.1.253. RWMA

Use this API to replicate machine parametric data from the working case in the form of a machine impedance data file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RWMA  SID  ALL  STATUS(1)  STATUS(2)  STATUS(3)  OUT  OFILE
```

Python command syntax:

```
ierr = rwma(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RWMANW(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS (3)	array of 3 elements specifying control options(input). STATUS(1) include records for out-of-service machines (0 by default) STATUS(1) = 0 exclude them STATUS(1) = 1 include them STATUS(2) used when calculating P fractions (0 by default) STATUS(2) = 0 use PGEN STATUS(2) = 1 use MBASE STATUS(2) = 2 use PMAX STATUS(3) used when calculating Q fractions (0 by default) STATUS(3) = 0 use QGEN STATUS(3) = 1 use MBASE STATUS(3) = 2 use QMAX
Integer OUT	option selection (input; 1 by default). OUT = 0 direct output to a data file specified by OFILE. OUT = 1 direct output to the current report device.
Character*260 OFILE	output filename (when OUT is 0) (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error

IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	invalid OUT value
IERR = 5	error opening OFILE
IERR = 6	prerequisite requirements for API are not met

1.1.254. RWMM

Use this API to replicate transaction event data in the form of a transactions data file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RWMM  OUT  OFILE
```

Python command syntax:

```
ierr = rwmm(out, ofile)
```

Fortran command syntax:

```
CALL RWMMAPI(OUT, OFILE, IERR)
```

Where:

Integer OUT	selection option (input; 1 by default).
	OUT = 0 direct output to the data file specified by OFILE
	OUT = 1 direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid OUT value
	IERR = 2 error opening OFILE
	IERR = 3 prerequisite requirements for API are not met

1.1.255. RWSQ

This API routine is obsolete. It has been replaced by the API routine [rwsq_2](#).

Use this API to replicate the sequence data contained in the working case in the form of a sequence data file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RWSQ  SID  ALL  STATUS(1)..STATUS(4)  OUT  OFILE
```

Python command syntax:

```
ierr = rwsq(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RWSQNW(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses when STATUS(4) is 0; area ties only when STATUS(4) is 1
Integer STATUS (4)	array of 4 elements specifying options(input). STATUS(1) include records for Type 4 buses (1 by default) STATUS(1) = 0 no STATUS(1) = 1 yes STATUS(2) include records for out-of-service branches (1 by default) STATUS(2) = 0 no STATUS(2) = 1 yes STATUS(3) include records for equipment in the subsystem (1 by default) STATUS(3) = 0 no STATUS(3) = 1 yes STATUS(4) include records for subsystem ties (0 by default) STATUS(4) = 0 no STATUS(4) = 1 yes
Integer OUT	option selection (input; 1 by default).

	OUT = 0	direct output to a data file specified by OFILE
	OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid OUT value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.256. RWSQ_2

Use this API to replicate the sequence data contained in the working case in the form of a sequence data file.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_RWSQ_2  SID  ALL  STATUS(1)..STATUS(5)  OUT  OFILE
```

Python command syntax:

```
ierr = rwsq_2(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RWSQNW_2(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses when STATUS(4) is 0; area ties only when STATUS(4) is 1
Integer STATUS (5)	array of 5 elements specifying options(input). STATUS(1) include records for Type 4 buses (1 by default) STATUS(1) = 0 no STATUS(1) = 1 yes STATUS(2) include records for out-of-service branches (1 by default) STATUS(2) = 0 no STATUS(2) = 1 yes STATUS(3) include records for equipment in the subsystem (1 by default) STATUS(3) = 0 no STATUS(3) = 1 yes STATUS(4) include records for subsystem ties (0 by default) STATUS(4) = 0 no STATUS(4) = 1 yes STATUS(5) sequence data file type (0 by default) STATUS(5) = 0 for activity RESQ with IC=0 STATUS(5) = 1 for activity RESQ with IC=1
Integer OUT	option selection (input; 1 by default).

	OUT = 0	direct output to a data file specified by OFILE
	OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid OUT value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

1.1.257. SAVE

Use this API to save the PSSE working case in a saved case file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SAVE  SFILE
```

Python command syntax:

```
ierr = save(sfile)
```

Fortran command syntax:

```
CALL SAVENW(SFILE, IERR)
```

Where:

Character*260 SFILE	name of the PSSE saved case file If SFILE is "*", SAVENW attempts to use the most recently accessed Saved Case File. If no Saved Case File was accessed in the current execution of PSSE, SAVENW returns an error code (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SFILE is blank
	IERR = 2	error writing to SFILE
	IERR = 3	error opening SFILE
	IERR = 4	prerequisite requirements for API are not met

1.1.258. SCAL

This API routine is obsolete. It has been replaced by the API routine [scal_4](#).

Use this API to uniformly increase or decrease any or all specified bus quantities for a specified group of buses (activity SCAL). It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by one reference with APIOPT=2.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SCAL SID ALL APIOPT STATUS(1)..STATUS(4) SCALVAL(1)..SCALVAL(7)
```

Python command syntax:

```
ierr, totals, moto = scal(sid, all, apiopt, status, scalval)
```

Fortran command syntax:

```
CALL SCALNW(SID, ALL, APIOPT, TOTALS, MOTO, STATUS, SCALVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer APIOPT	mode of operation in the API (input; 0 by default). APIOPT = 0 initialize for scaling, then run the scaling and post-processing housekeeping. APIOPT = 1 initialize for scaling. APIOPT = 2 run the scaling and post-processing house-keeping.
Real TOTALS (11)	array of 11 elements specifying returned when APIOPT = 0 or 1. They are as follows(output). TOTALS(1) load Mvar total TOTALS(2) load MW total TOTALS(3) generation MW total TOTALS(4) shunt MW total TOTALS(5) reactor Mvar total TOTALS(6) capacitor Mvar total TOTALS(7) motor load MW total TOTALS(8) generator PMAX TOTALS(9) generator PMIN TOTALS(10) motor load PMIN

	TOTALS(11)	motor load P _{MAX}
Integer MOTO	returned when APIOPT = 0 or 1 (output).	
	MOTO = 0	no motors in the specified subsystem.
	MOTO = 1	motors present in the specified subsystem.
Integer STATUS (4)	array of 4 elements specifying that are used to control scaling. The first three elements are checked and used when APIOPT = 0 or 2; the fourth element is checked and saved when APIOPT = 0 or 1. They are as follows(input).	
	STATUS(1)	method used to scale active power load, generation and motor data, and bus shunt data (0 by default)
	STATUS(1) = 0	no scaling
	STATUS(1) = 1	specify new total powers
	STATUS(1) = 2	specify percent changes
	STATUS(1) = 3	specify incremental powers
	STATUS(2)	flag to enforce machine power limits (0 by default)
	STATUS(2) = 0	ignore machine power limits
	STATUS(2) = 1	enforce machine power limits
	STATUS(3)	flag to specify the scaling rule to be enforced when changing the reactive power load (0 by default)
	STATUS(3) = 0	no change
	STATUS(3) = 1	constant P/Q ratio
	STATUS(3) = 2	new total Q load
	STATUS(3) = 3	percent change
	STATUS(3) = 4	new power factor
	STATUS(3) = 5	incremental Q load
	STATUS(4)	bus type code flag for load scaling; normally defaulted except when used by OPF (0 by default)
	STATUS(4) = 0	all buses in subsystem
	STATUS(4) = 1	only Type 1 buses in subsystem
	STATUS(4) = 2	only Type 2 and 3 buses in subsystem
Real SCALVAL (7)	array of 7 elements specifying used as scaling targets. Based on the value of STATUS(1), entries (1) through (6) are either total powers(input).	
	SCALVAL(1)	load MW total/percent/increment
	SCALVAL(2)	generation MW total/percent/increment
	SCALVAL(3)	shunt MW total/percent/increment
	SCALVAL(4)	reactor Mvar total/percent/increment
	SCALVAL(5)	capacitor Mvar total/percent/increment
	SCALVAL(6)	motor load MW total/percent/increment
	SCALVAL(7)	reactive load scaling parameter

	If STATUS(3)	
	SCALVAL(7) = 2	new total Mvar load (present total Mvar load by default)."
	SCALVAL(7) = 3	percent change (0.0 by default)."
	SCALVAL(7) = 4	new power factor (1.0 by default)."
	SCALVAL(7) = 5	incremental Mvar load change (0.0 by default)."
Integer IERR	error code (output).	

1.1.259. SCAL_2

This API routine is obsolete. It has been replaced by the API routine [scal_4](#).

Use this API routine to uniformly increase or decrease any or all specified bus quantities for a specified group of buses. It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by one reference with APIOPT=2.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SCAL_2  SID ALL APIOPT STATUS(1)..STATUS(5) SCALVAL(1)..SCALVAL(7)
```

Python command syntax:

```
ierr, totals, moto= scal_2(sid, all, apiopt, status, scalval)
```

Fortran command syntax:

```
CALL SCAL_2(SID, ALL, APIOPT, TOTALS, MOTO, STATUS, SCALVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer APIOPT	mode of operation in the API (input; 0 by default).	
	APIOPT = 0	initialize for scaling, then run the scaling and post-processing housekeeping.
	APIOPT = 1	initialize for scaling.
	APIOPT = 2	run the scaling and post-processing housekeeping.
Real TOTALS (11)	array of elements specifying returned when APIOPT = 0 or 1. They are as follows.(output).	
	TOTALS(1)	load Mvar total.
	TOTALS(2)	load MW total.
	TOTALS(3)	generation MW total.
	TOTALS(4)	shunt MW total.
	TOTALS(5)	reactor Mvar total.
	TOTALS(6)	capacitor Mvar total.
	TOTALS(7)	motor load MW total.

	TOTALS(8)	generator P _{MAX} .
	TOTALS(9)	generator P _{MIN} .
	TOTALS(10)	motor load P _{MIN} .
	TOTALS(11)	motor load P _{MAX} .
Integer MOTO	returned when APIOPT = 0 or 1. It indicates the presence of motors that are modeled as conventional generators with negative active power settings. (output).	
	MOTO = 0	no motors in the specified subsystem.
	MOTO = 1	motors present in the specified subsystem.
Integer STATUS (5)	array of elements specifying control scaling. The first and fifth elements are checked and saved when APIOPT = 0 or 1; the second, third and fourth elements are checked and used when APIOPT = 0 or 2. They are as follows.(input).	
	STATUS(1)	interruptible load scaling option (0 by default)
	STATUS(1) = 0	scale both interruptible and non-interruptible scalable loads.
	STATUS(1) = 1	scale only non-interruptible scalable loads.
	STATUS(1) = 2	scale only interruptible scalable loads.
	STATUS(2)	method used to scale active power load, generation and motor data, and bus shunt data (0 by default)
	STATUS(2) = 0	no scaling.
	STATUS(2) = 1	specify new total powers.
	STATUS(2) = 2	specify percent changes.
	STATUS(2) = 3	specify incremental powers.
	STATUS(3)	flag to enforce machine power limits (0 by default)
	STATUS(3) = 0	ignore machine power limits.
	STATUS(3) = 1	enforce machine power limits.
	STATUS(4)	flag to specify the scaling rule to be enforced when changing the reactive power load (0 by default)
	STATUS(4) = 0	no change.
	STATUS(4) = 1	constant P/Q ratio.
	STATUS(4) = 2	new total Q load.
	STATUS(4) = 3	percent change.
	STATUS(4) = 4	new power factor.
	STATUS(4) = 5	incremental Q load.
	STATUS(5)	is the bus type code flag for load scaling; normally defaulted except when used by OPF (0 by default)
	STATUS(5) = 0	all buses in subsystem.
	STATUS(5) = 1	only Type 1 buses in subsystem.
	STATUS(5) = 2	only Type 2 and 3 buses in subsystem.

Real SCALVAL (7)	array of elements specifying scaling targets. Based on the value of STATUS(1), entries (1) through (6) are either total powers (present total power by default), percent changes (0.0 by default), or incremental changes (0.0 by default). If STATUS(4) = 2, SCALVAL(7) = new total Mvar load (present total Mvar load by default). If STATUS(4) = 3, SCALVAL(7) = percent change (0.0 by default). If STATUS(4) = 4, SCALVAL(7) = new power factor (1.0 by default). If STATUS(4) = 5, SCALVAL(7) = incremental Mvar load change (0.0 by default).(input). SCALVAL(1) load MW total/percent/increment. SCALVAL(2) generation MW total/percent/increment. SCALVAL(3) shunt MW total/percent/increment. SCALVAL(4) reactor Mvar total/percent/increment. SCALVAL(5) capacitor Mvar total/percent/increment. SCALVAL(6) motor load MW total/percent/increment. SCALVAL(7) reactive load scaling parameter.
Integer IERR	error code (output).

1.1.260. SCAL_3

This API routine is obsolete. It has been replaced by the API routine [scal_4](#).

Use this API routine to uniformly increase or decrease any or all specified bus quantities for a specified group of buses. It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by one reference with APIOPT=2.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SCAL_3  SID ALL APIOPT STATUS(1)..STATUS(5) SCALVAL(1)..SCALVAL(7)
```

Python command syntax:

```
ierr, totals, moto= scal_3(sid, all, apiopt, status, scalval)
```

Fortran command syntax:

```
CALL SCAL_3(SID, ALL, APIOPT, TOTALS, MOTO, STATUS, SCALVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer APIOPT	mode of operation in the API (input; 0 by default).	
	APIOPT = 0	initialize for scaling, then run the scaling and post-processing housekeeping.
	APIOPT = 1	initialize for scaling.
	APIOPT = 2	run the scaling and post-processing housekeeping.
Real TOTALS (11)	array of elements specifying returned when APIOPT = 0 or 1. They are as follows.(output).	
	TOTALS(1)	load Mvar total.
	TOTALS(2)	load MW total.
	TOTALS(3)	generation MW total.
	TOTALS(4)	shunt MW total.
	TOTALS(5)	reactor Mvar total.
	TOTALS(6)	capacitor Mvar total.
	TOTALS(7)	motor load MW total.
	TOTALS(8)	generator PMAX.
	TOTALS(9)	generator PMIN.
	TOTALS(10)	motor load PMIN.

	TOTALS(11)	motor load P _{MAX} .
Integer MOTO	returned when APIOPT = 0 or 1. It indicates the presence of motors that are modeled as conventional generators with negative active power settings. (output).	
	MOTO = 0	no motors in the specified subsystem.
	MOTO = 1	motors present in the specified subsystem.
Integer STATUS (5)	array of elements specifying scaling options. The first and second elements are checked and saved when APIOPT = 0 or 1; the third, fourth and fifth elements are checked and used when APIOPT = 0 or 2. They are as follows.(input).	
	STATUS(1)	interruptible load scaling option (0 by default)
	STATUS(1) = 0	scale both interruptible and non-interruptible loads.
	STATUS(1) = 1	scale only non-interruptible loads.
	STATUS(1) = 2	scale only interruptible loads.
	STATUS(2)	base loaded generation scaling option (0 by default)
	STATUS(2) = 0	scale all subsystem machines and ignore their base load flags.
	STATUS(2) = 1	scale all subsystem machines and honor their base load flags.
	STATUS(2) = 2	scale only non-base loaded subsystem machines.
	STATUS(2) = 3	scale only base loaded subsystem machines and ignore their base load flags.
	STATUS(2) = 4	scale only base loaded subsystem machines and honor their base load flags.
	STATUS(3)	method used to scale active power load, generation and motor data, and bus shunt data (0 by default)
	STATUS(3) = 0	no scaling.
	STATUS(3) = 1	specify new total powers.
	STATUS(3) = 2	specify percent changes.
	STATUS(3) = 3	specify incremental powers.
	STATUS(4)	flag to enforce machine power limits (0 by default)
	STATUS(4) = 0	ignore machine power limits.
	STATUS(4) = 1	enforce machine power limits.
	STATUS(5)	flag to specify the scaling rule to be enforced when changing the reactive power load (0 by default)
	STATUS(5) = 0	no change.
	STATUS(5) = 1	constant P/Q ratio.
	STATUS(5) = 2	new total Q load.

	STATUS(5) = 3	percent change.
	STATUS(5) = 4	new power factor.
	STATUS(5) = 5	incremental Q load.
Real SCALVAL (7)	array of elements specifying scaling targets. Based on the value of STATUS(1), entries (1) through (6) are either total powers (present total power by default), percent changes (0.0 by default), or incremental changes (0.0 by default). If STATUS(5) = 2, SCALVAL(7) = new total Mvar load (present total Mvar load by default). If STATUS(5) = 3, SCALVAL(7) = percent change (0.0 by default). If STATUS(5) = 4, SCALVAL(7) = new power factor (1.0 by default). If STATUS(5) = 5, SCALVAL(7) = incremental Mvar load change (0.0 by default).(input). SCALVAL(1) load MW total/percent/increment. SCALVAL(2) generation MW total/percent/increment. SCALVAL(3) shunt MW total/percent/increment. SCALVAL(4) reactor Mvar total/percent/increment. SCALVAL(5) capacitor Mvar total/percent/increment. SCALVAL(6) motor load MW total/percent/increment. SCALVAL(7) reactive load scaling parameter.	
Integer IERR	error code (output).	

1.1.261. SCAL_4

Use this API routine to uniformly increase or decrease any or all specified bus quantities for a specified group of buses. It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by one reference with APIOPT=2.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SCAL_4 SID ALL APIOPT STATUS(1)..STATUS(6) SCALVAL(1)..SCALVAL(7)
```

Python command syntax:

```
ierr, totals, moto= scal_4(sid, all, apiopt, status, scalval)
```

Fortran command syntax:

```
CALL SCAL_4(SID, ALL, APIOPT, TOTALS, MOTO, STATUS, SCALVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer APIOPT	mode of operation in the API (input; 0 by default).	
	APIOPT = 0	initialize for scaling, then run the scaling and post-processing housekeeping.
	APIOPT = 1	initialize for scaling.
	APIOPT = 2	run the scaling and post-processing housekeeping.
Real TOTALS (11)	array of elements specifying returned when APIOPT = 0 or 1. They are as follows.(output).	
	TOTALS(1)	load Mvar total.
	TOTALS(2)	load MW total.
	TOTALS(3)	generation MW total.
	TOTALS(4)	shunt MW total.
	TOTALS(5)	reactor Mvar total.
	TOTALS(6)	capacitor Mvar total.
	TOTALS(7)	motor load MW total.
	TOTALS(8)	generator PMAX.
	TOTALS(9)	generator PMIN.
	TOTALS(10)	motor load PMIN.
	TOTALS(11)	motor load PMAX.

Integer MOTO	returned when APIOPT = 0 or 1. It indicates the presence of motors that are modeled as conventional generators with negative active power settings. (output). MOTO = 0 no motors in the specified subsystem. MOTO = 1 motors present in the specified subsystem.
Integer STATUS (6)	array of elements specifying scaling options. The first, second and third elements are checked and saved when APIOPT = 0 or 1; the fourth, fifth and sixth elements are checked and used when APIOPT = 0 or 2. They are as follows.(input). STATUS(1) interruptible load scaling option (0 by default) STATUS(1) = 0 scale both interruptible and non-interruptible loads. STATUS(1) = 1 scale only non-interruptible loads. STATUS(1) = 2 scale only interruptible loads. STATUS(2) load component scaling option (0 by default) STATUS(2) = 0 scale in-service net load STATUS(2) = 1 scale only in-service load STATUS(2) = 2 scale only in-service distributed generation STATUS(3) base loaded generation scaling option (0 by default) STATUS(3) = 0 scale all subsystem machines and ignore their base load flags. STATUS(3) = 1 scale all subsystem machines and honor their base load flags. STATUS(3) = 2 scale only non-base loaded subsystem machines. STATUS(3) = 3 scale only base loaded subsystem machines and ignore their base load flags. STATUS(3) = 4 scale only base loaded subsystem machines and honor their base load flags. STATUS(4) method used to scale active power load, generation and motor data, and bus shunt data (0 by default) STATUS(4) = 0 no scaling. STATUS(4) = 1 specify new total powers. STATUS(4) = 2 specify percent changes. STATUS(4) = 3 specify incremental powers. STATUS(5) flag to enforce machine power limits (0 by default) STATUS(5) = 0 ignore machine power limits. STATUS(5) = 1 enforce machine power limits. STATUS(6) flag to specify the scaling rule to be enforced when changing the reactive power load (0 by default)

	STATUS(6) = 0	no change.
	STATUS(6) = 1	constant P/Q ratio.
	STATUS(6) = 2	new total Q load.
	STATUS(6) = 3	percent change.
	STATUS(6) = 4	new power factor.
	STATUS(6) = 5	incremental Q load.
Real SCALVAL (7)	array of elements specifying scaling targets. Based on the value of STATUS(1), entries (1) through (6) are either total powers (present total power by default), percent changes (0.0 by default), or incremental changes (0.0 by default). If STATUS(5) = 2, SCALVAL(7) = new total Mvar load (present total Mvar load by default). If STATUS(5) = 3, SCALVAL(7) = percent change (0.0 by default). If STATUS(5) = 4, SCALVAL(7) = new power factor (1.0 by default). If STATUS(5) = 5, SCALVAL(7) = incremental Mvar load change (0.0 by default).(input).	
	SCALVAL(1)	load MW total/percent/increment.
	SCALVAL(2)	generation MW total/percent/increment.
	SCALVAL(3)	shunt MW total/percent/increment.
	SCALVAL(4)	reactor Mvar total/percent/increment.
	SCALVAL(5)	capacitor Mvar total/percent/increment.
	SCALVAL(6)	motor load MW total/percent/increment.
	SCALVAL(7)	reactive load scaling parameter.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid APIOPT value
	IERR = 4	invalid STATUS value
	IERR = 5	unexpected APIOPT value
	IERR = 6	invalid power factor in SCALVAL(7)
	IERR = 7	generator or motor totals beyond limits
	IERR = 8	prerequisite requirements for API are not met

1.1.262. SENSITIVITY_FLOW

This API is used to calculate sensitivity factors of a branch flow to MW power at buses, MW power at generator buses, MW at load buses, phase angle of phase shifters, tap position of tap changing transformers as well as admittance of switched shunts:

This API routine was first introduced in release 32.1.0.

Batch command syntax:

```
BAT_SENSITIVITY_FLOW FLWOPT(1) .. FLWOPT(5) OPTIONS(1) .. OPTIONS(9)
VALUES(1) VALUES(2) BRNCKT LABELS(1) LABELS(2) DFXFILE
```

Python command syntax:

```
ierr = sensitivity_flow(flwopt,options,values,brnckt,labels,dfxfile)
```

Fortran command syntax:

```
CALL SENSITIVITY_FLOW(FLWOPT,OPTIONS,VALUES,BRNCKT,LABELS,DFXFILE,IERR)
```

Where:

Integer FLWOPT (5)	array of 5 elements specifying (input).
FLWOPT(1)	from bus of the branch for which sensitivity factors are calculated (no default is allowed)
FLWOPT(2)	to bus of the branch (no default is allowed)
FLWOPT(3)	third bus connected by a three-winding transformer, or zero for a non-transformer branch or a two-winding transformer (0 by default)
FLWOPT(4)	network model on which sensitivity analysis is based
FLWOPT(4) = 0	DC network model
FLWOPT(4) = 1	AC network model
FLWOPT(5)	branch flow type to which the sensitivity factors are calculated (If DC network is used, only the branch MW flow is valid for sensitivity analysis. 0 by default)
FLWOPT(5) = 0	MW flow
FLWOPT(5) = 1	MVar flow
FLWOPT(5) = 2	MVA flow
FLWOPT(5) = 3	Amps flow
Integer OPTIONS (9)	array of 9 elements specifying options for sensitivity analysis to a branch flow(input).
OPTIONS(1)	flag to calculate sensitivity factors at buses
OPTIONS(1) = 0	Disable, do not calculate sensitivity factors at buses
OPTIONS(1) = 1	Enable, calculate sensitivity factors at buses
OPTIONS(2)	flag to calculate sensitivity factors at generator buses

OPTIONS(2) = 0	Disable
OPTIONS(2) = 1	Enable
OPTIONS(3)	flag to calculate sensitivity factors at load buses
OPTIONS(3) = 0	Disable
OPTIONS(3) = 1	Enable
OPTIONS(4)	flag to calculate sensitivity factors of the branch flow to phase shifters
OPTIONS(4) = 0	Disable
OPTIONS(4) = 1	Enable
OPTIONS(5)	flag to calculate sensitivity factors of the branch flow to tap changing transformers (ignore if DC network model is used)
OPTIONS(5) = 0	Disable
OPTIONS(5) = 1	Enable
OPTIONS(6)	flag to calculate sensitivity factors of the branch flow to switched shunts (ignore if DC network model is used)
OPTIONS(6) = 0	Disable
OPTIONS(6) = 1	Enable
OPTIONS(7)	flag to specify the transfer from the components to which sensitivity factors of the branch flow are calculated to the opposing subsystem (the flag is ignored if none of the bus, generator, or load sensitivity calculation flags is selected)
OPTIONS(7) = 0	Import. The positive transfer is from the components to the opposing subsystem
OPTIONS(7) = 1	Export. The positive transfer is from the opposing subsystem to the components
OPTIONS(8)	opposing subsystem type
OPTIONS(8) = 0	Slack bus
OPTIONS(8) = 1	Single bus
OPTIONS(8) = 2	Subsystem
OPTIONS(9)	ignored if opposing subsystem type is slack bus. It is a bus number when opposing subsystem type is a single bus, or one of the following seven dispatch modes if the opposing subsystem type is a subsystem (1 by default)
OPTIONS(9) = 1	Buses & participating factors from DFAX file for buses with positive MW machines
OPTIONS(9) = 2	Buses & participating factors from DFAX file for buses with positive MW constant MVA load

	OPTIONS(9) = 3	Buses & participating factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(9) = 4	Subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(9) = 5	Subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(9) = 6	Subsystem buses with positive MW machines in proportion to their MBASE
	OPTIONS(9) = 7	Subsystem buses with positive MW machines in proportion to their reserves (Pmaxmc-Pgenmc)
Real VALUES (2)	array of 2 elements specifying sensitivity analysis parameters(input).	
	VALUES(1)	mismatch tolerance for continuing sensitivity analysis in AC mode, ignored in DC mode
	VALUES(2)	sensitivity cutoff. Sensitivity factors less than the cutoff are not presented
Character*2 BRNCKT	branch circuit ID (input).	
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the subsystem containing components to which the sensitivity factors of the branch flow are calculated
	LABELS(2)	opposing subsystem label when the opposing subsystem type is a subsystem
Character*260 DFXFILE	DFAX file name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	The branch can not be found
	IERR = 4	Generators are converted
	IERR = 5	Buses in island(s) without a swing bus--use activity TREE
	IERR = 6	Dispatch bus does not exist
	IERR = 7	No Distribution Factor Data input file specified
	IERR = 8	Subsystem containing components to which sensitivity factors are calculated is not specified
	IERR = 9	Opposing subsystem is not specified
	IERR = 10	Largest mismatch exceeds mismatch tolerance
	IERR = 11	The branch bus does not exist
	IERR = 12	The branch is out-of-service
	IERR = 13	The branch is a zero impedance line

IERR = 14	The branch is a multi-section line but the Report Multi-Section line option is disabled
IERR = 15	Invalid FLWOPT value
IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file, run DFAX
IERR = 22	Error linearizing Jacobian matrix in AC network model
IERR = 51	error opening Distribution Factor Data File
IERR = 52	prerequisite requirements for function not met

1.1.263. SENSITIVITY_FLOWS

This API is used to calculate sensitivity factors of flows on the branches in a subsystem to MW power at buses, MW power at generator buses, MW power at load buses, phase angle of phase shifters, tap position of tap changing transformers as well as admittance of switched shunts.

This API routine was first introduced in release 32.1.0.

Batch command syntax:

```
BAT_SENSITIVITY_FLOWS  FLWOPT(1) FLWOPT(2) OPTIONS(1) .. OPTIONS(9)
                        VALUES(1) VALUES(2) LABELS(1) .. LABELS(3) DFXFILE
```

Python command syntax:

```
ierr = sensitivity_flows(flwopt,options,values,labels,dfxfile)
```

Fortran command syntax:

```
CALL SENSITIVITY_FLOWS(FLWOPT,OPTIONS,VALUES,LABELS,DFXFILE,IERR)
```

Where:

Integer FLWOPT (2)	array of 2 elements specifying options for sensitivity analysis for branches in a subsystem(input).
FLWOPT(1)	network model on which sensitivity analysis is based
FLWOPT(1) = 0	DC network model
FLWOPT(1) = 1	AC network model
FLWOPT(2)	branch flow type to which the sensitivity factors are calculated (when DC network is used, only the branch MW flow is valid for sensitivity analysis.)
FLWOPT(2) = 0	MW flow
FLWOPT(2) = 1	MVar flow
FLWOPT(2) = 2	MVA flow
FLWOPT(2) = 3	Amps flow
Integer OPTIONS (9)	array of 9 elements specifying options for sensitivity analysis to a branch flow(input).
OPTIONS(1)	flag to calculate sensitivity factors at buses
OPTIONS(1) = 0	Disable, do not calculate sensitivity factors at buses
OPTIONS(1) = 1	Enable, calculate sensitivity factors at buses
OPTIONS(2)	flag to calculate sensitivity factors at generator buses
OPTIONS(2) = 0	Disable
OPTIONS(2) = 1	Enable
OPTIONS(3)	flag to calculate sensitivity factors at load buses

OPTIONS(3) = 0	Disable
OPTIONS(3) = 1	Enable
OPTIONS(4)	flag to calculate sensitivity factors of the branch flow to phase shifters
OPTIONS(4) = 0	Disable
OPTIONS(4) = 1	Enable
OPTIONS(5)	flag to calculate sensitivity factors of the branch flow to tap changing transformers (ignore if DC network model is used)
OPTIONS(5) = 0	Disable
OPTIONS(5) = 1	Enable
OPTIONS(6)	flag to calculate sensitivity factors of the branch flow to switched shunts (ignore if DC network model is used)
OPTIONS(6) = 0	Disable
OPTIONS(6) = 1	Enable
OPTIONS(7)	flag to specify the transfer from the components to which sensitivity factors of the branch flow are calculated to the opposing subsystem (the flag is ignored if none of the bus, generator, or load sensitivity calculation flags is selected)
OPTIONS(7) = 0	Import. The positive transfer is from the components to the opposing subsystem
OPTIONS(7) = 1	Export. The positive transfer is from the opposing subsystem to the components
OPTIONS(8)	opposing subsystem type
OPTIONS(8) = 0	Slack bus
OPTIONS(8) = 1	Single bus
OPTIONS(8) = 2	Subsystem
OPTIONS(9)	ignored if opposing subsystem type is slack bus. It is a bus number when opposing subsystem type is a single bus, or one of the following seven dispatch modes if the opposing subsystem type is a subsystem (1 by default)
OPTIONS(9) = 1	Buses & participating factors from DFAX file for buses with positive MW machines
OPTIONS(9) = 2	Buses & participating factors from DFAX file for buses with positive MW constant MVA load
OPTIONS(9) = 3	Buses & participating factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
OPTIONS(9) = 4	Subsystem buses with positive MW constant MVA load in proportion to their MW load
OPTIONS(9) = 5	Subsystem buses with positive MW machines in proportion to their MW output

	OPTIONS(9) = 6	Subsystem buses with positive MW machines in proportion to their MBASE
	OPTIONS(9) = 7	Subsystem buses with positive MW machines in proportion to their reserves (Pmaxmc-Pgenmc)
Real VALUES (2)	array of 2 elements specifying sensitivity analysis parameters(input).	
	VALUES(1)	mismatch tolerance for continuing sensitivity analysis in AC mode, ignored in DC mode
	VALUES(2)	sensitivity cutoff. Sensitivity factors less than the cutoff are not presented
Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).	
	LABELS(1)	label of the subsystem containing components to which the sensitivity factors of the branch flow are calculated
	LABELS(2)	label of opposing subsystem when the opposing subsystem type is a subsystem
	LABELS(3)	label of the subsystem including branches for which sensitivity factors are calculated
Character*260 DFXFILE	DFAX file name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	The branch can not be found
	IERR = 4	Generators are converted
	IERR = 5	Buses in island(s) without a swing bus--use activity TREE
	IERR = 6	Dispatch bus does not exist
	IERR = 7	No Distribution Factor Data input file specified
	IERR = 8	Subsystem containing components to which sensitivity factors are calculated is not specified
	IERR = 9	Opposing subsystem is not specified
	IERR = 10	Largest mismatch exceeds mismatch tolerance
	IERR = 11	Invalid FLWOPT value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file, run DFAX
	IERR = 22	Error linearizing Jacobian matrix in AC network model
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	prerequisite requirements for function not met

1.1.264. SENSITIVITY_INTERFACE

This API is used to calculate sensitivity factors of an interface flow to MW power at buses, MW power at generator buses, MW power at load buses, phase angle of phase shifters, tap position of tap changing transformers as well as admittance of switched shunts.

This API routine was first introduced in release 32.1.0.

Batch command syntax:

```
BAT_SENSITIVITY_INTERFACE  MODE  OPTIONS(1) .. OPTIONS(9)  VALUES(1)
                             VALUES(2) LABELS(1) .. LABELS(3) DFXFILE
```

Python command syntax:

```
ierr = sensitivity_interface(mode,options,values,labels,dfxfile)
```

Fortran command syntax:

```
CALL SENSITIVITY_INTERFACE(MODE, OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer MODE	network model on which sensitivity analysis is based (input; 0 by default).	
	MODE = 0	DC network model
	MODE = 1	AC network model
Integer OPTIONS (9)	array of 9 elements specifying options for sensitivity analysis to a branch flow(input).	
	OPTIONS(1)	flag to calculate sensitivity factors at buses
	OPTIONS(1) = 0	Disable, do not calculate sensitivity factors at buses
	OPTIONS(1) = 1	Enable, calculate sensitivity factors at buses
	OPTIONS(2)	flag to calculate sensitivity factors at generator buses
	OPTIONS(2) = 0	Disable
	OPTIONS(2) = 1	Enable
	OPTIONS(3)	flag to calculate sensitivity factors at load buses
	OPTIONS(3) = 0	Disable
	OPTIONS(3) = 1	Enable
	OPTIONS(4)	flag to calculate sensitivity factors of the branch flow to phase shifters
	OPTIONS(4) = 0	Disable
	OPTIONS(4) = 1	Enable
	OPTIONS(5)	flag to calculate sensitivity factors of the branch flow to tap changing transformers (ignore if DC network model is used)
	OPTIONS(5) = 0	Disable
	OPTIONS(5) = 1	Enable

	OPTIONS(6)	flag to calculate sensitivity factors of the branch flow to switched shunts (ignore if DC network model is used)
	OPTIONS(6) = 0	Disable
	OPTIONS(6) = 1	Enable
	OPTIONS(7)	flag to specify the transfer from the components to which sensitivity factors of the branch flow are calculated to the opposing subsystem (the flag is ignored if none of the bus, generator, or load sensitivity calculation flags is selected)
	OPTIONS(7) = 0	Import. The positive transfer is from the components to the opposing subsystem
	OPTIONS(7) = 1	Export. The positive transfer is from the opposing subsystem to the components
	OPTIONS(8)	opposing subsystem type
	OPTIONS(8) = 0	Slack bus
	OPTIONS(8) = 1	Single bus
	OPTIONS(8) = 2	Subsystem
	OPTIONS(9)	ignored if opposing subsystem type is slack bus. It is a bus number when opposing subsystem type is a single bus, or one of the following seven dispatch modes if the opposing subsystem type is a subsystem (1 by default)
	OPTIONS(9) = 1	Buses & participating factors from DFAX file for buses with positive MW machines
	OPTIONS(9) = 2	Buses & participating factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(9) = 3	Buses & participating factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(9) = 4	Subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(9) = 5	Subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(9) = 6	Subsystem buses with positive MW machines in proportion to their MBASE
	OPTIONS(9) = 7	Subsystem buses with positive MW machines in proportion to their reserves (Pmaxmc-Pgenmc)
Real VALUES (2)	array of 2 elements specifying sensitivity analysis parameters(input).	
	VALUES(1)	mismatch tolerance for continuing sensitivity analysis in AC mode, ignored in DC mode
	VALUES(2)	sensitivity cutoff. Sensitivity factors less than the cutoff are not presented

Character* 32 LABELS (3)	array of 3 elements specifying subsystem/interface labels(input).	
	LABELS(1)	label of the subsystem containing components to which the sensitivity factors of the interface flow are calculated
	LABELS(2)	label of opposing subsystem when the opposing subsystem type is a subsystem
	LABELS(3)	label of the interface for which sensitivity factors are calculated
Character* 260 DFXFILE	DFAX file name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	Interface is not specified
	IERR = 4	Generators are converted
	IERR = 5	Buses in island(s) without a swing bus--use activity TREE
	IERR = 6	Dispatch bus does not exist
	IERR = 7	No Distribution Factor Data input file specified
	IERR = 8	Subsystem containing components to which sensitivity factors are calculated is not specified
	IERR = 9	Opposing subsystem is not specified
	IERR = 10	Largest mismatch exceeds mismatch tolerance
	IERR = 11	Invalid MODE value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file, run DFAX
	IERR = 22	Error in linearizing Jacobian matrix with AC network model
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	prerequisite requirements for function not met

1.1.265. SENSITIVITY_VOLTAGE

This API is used to calculate sensitivity factors of a bus voltage to MW and MVar power at buses, MW power at generator buses, MW and MVar at load buses, phase angle of phase shifters, tap position of tap changing transformers as well as admittance of switched shunts.

This API routine was first introduced in release 32.1.0.

Batch command syntax:

```
BAT_SENSITIVITY_VOLTAGE IBUS OPTIONS(1) .. OPTIONS(9) VALUES(1) VALUES(2)
LABELS(1) LABELS(2) DFXFILE
```

Python command syntax:

```
ierr = sensitivity_voltage(ibus, options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL SENSITIVITY_VOLTAGE(IBUS, OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer IBUS	bus number for which sensitivity factors are calculated (input).	
Integer OPTIONS (9)	array of 9 elements specifying options for sensitivity analysis to a branch flow(input).	
	OPTIONS(1)	flag to calculate sensitivity factors at buses
	OPTIONS(1) = 0	Disable, do not calculate sensitivity factors at buses
	OPTIONS(1) = 1	Enable, calculate sensitivity factors at buses
	OPTIONS(2)	flag to calculate sensitivity factors at generator buses
	OPTIONS(2) = 0	Disable
	OPTIONS(2) = 1	Enable
	OPTIONS(3)	flag to calculate sensitivity factors at load buses
	OPTIONS(3) = 0	Disable
	OPTIONS(3) = 1	Enable
	OPTIONS(4)	flag to calculate sensitivity factors of the branch flow to phase shifters
	OPTIONS(4) = 0	Disable
	OPTIONS(4) = 1	Enable
	OPTIONS(5)	flag to calculate sensitivity factors of the branch flow to tap changing transformers (ignore if DC network model is used)
	OPTIONS(5) = 0	Disable
	OPTIONS(5) = 1	Enable
	OPTIONS(6)	flag to calculate sensitivity factors of the branch flow to switched shunts (ignore if DC network model is used)
	OPTIONS(6) = 0	Disable

	OPTIONS(6) = 1	Enable
	OPTIONS(7)	flag to specify the transfer from the components to which sensitivity factors of the branch flow are calculated to the opposing subsystem (the flag is ignored if none of the bus, generator, or load sensitivity calculation flags is selected)
	OPTIONS(7) = 0	Import. The positive transfer is from the components to the opposing subsystem
	OPTIONS(7) = 1	Export. The positive transfer is from the opposing subsystem to the components
	OPTIONS(8)	opposing subsystem type
	OPTIONS(8) = 0	Slack bus
	OPTIONS(8) = 1	Single bus
	OPTIONS(8) = 2	Subsystem
	OPTIONS(9)	ignored if opposing subsystem type is slack bus. It is a bus number when opposing subsystem type is a single bus, or one of the following seven dispatch modes if the opposing subsystem type is a subsystem (1 by default)
	OPTIONS(9) = 1	Buses & participating factors from DFAX file for buses with positive MW machines
	OPTIONS(9) = 2	Buses & participating factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(9) = 3	Buses & participating factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(9) = 4	Subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(9) = 5	Subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(9) = 6	Subsystem buses with positive MW machines in proportion to their MBASE
	OPTIONS(9) = 7	Subsystem buses with positive MW machines in proportion to their reserves (Pmaxmc-Pgenmc)
Real VALUES (2)	array of 2 elements specifying sensitivity analysis parameters(input).	
	VALUES(1)	mismatch tolerance for continuing sensitivity analysis in AC mode, ignored in DC mode
	VALUES(2)	sensitivity cutoff. Sensitivity factors less than the cutoff are not presented
Character*32 LABELS (2)	array of 2 elements specifying subsystem labels(input).	
	LABELS(1)	label of the subsystem containing components to which the sensitivity factors of the bus voltage are calculated

	LABELS(2)	opposing subsystem label when the opposing subsystem type is a subsystem
Character* 260 DFXFILE	DFAX file name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	The bus does not exist
	IERR = 4	Generators are converted
	IERR = 5	Buses in island(s) without a swing bus--use activity TREE
	IERR = 6	Dispatch bus does not exist
	IERR = 7	No Distribution Factor Data input file specified
	IERR = 8	Subsystem containing components to which sensitivity factors are calculated is not specified
	IERR = 9	Opposing subsystem is not specified
	IERR = 10	Largest mismatch exceeds mismatch tolerance
	IERR = 11	The bus is a type 2 or type 3 bus
	IERR = 12	Invalid IBUS value
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file, run DFAX
	IERR = 22	Error linearizing Jacobian matrix in AC network model
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	prerequisite requirements for function not met

1.1.266. SENSITIVITY_VOLTAGES

This API is used to calculate sensitivity factors of bus voltages in a subsystem to MW and MVar power at buses, MW power at generator buses, MW and MVar at load buses, phase angle of phase shifters, tap position of tap changing transformers as well as admittance of switched shunts.

This API routine was first introduced in release 32.1.0.

Batch command syntax:

```
BAT_SENSITIVITY_VOLTAGES  OPTIONS(1) .. OPTIONS(9) VALUES(1) VALUES(2)
  LABELS(1) .. LABELS(3) DFXFILE
```

Python command syntax:

```
ierr = sensitivity_voltages(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL SENSITIVITY_VOLTAGES(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (9)	array of 9 elements specifying options for sensitivity analysis to a branch flow(input).	
	OPTIONS(1)	flag to calculate sensitivity factors at buses
	OPTIONS(1) = 0	Disable, do not calculate sensitivity factors at buses
	OPTIONS(1) = 1	Enable, calculate sensitivity factors at buses
	OPTIONS(2)	flag to calculate sensitivity factors at generator buses
	OPTIONS(2) = 0	Disable
	OPTIONS(2) = 1	Enable
	OPTIONS(3)	flag to calculate sensitivity factors at load buses
	OPTIONS(3) = 0	Disable
	OPTIONS(3) = 1	Enable
	OPTIONS(4)	flag to calculate sensitivity factors of the branch flow to phase shifters
	OPTIONS(4) = 0	Disable
	OPTIONS(4) = 1	Enable
	OPTIONS(5)	flag to calculate sensitivity factors of the branch flow to tap changing transformers (ignore if DC network model is used)
	OPTIONS(5) = 0	Disable
	OPTIONS(5) = 1	Enable
	OPTIONS(6)	flag to calculate sensitivity factors of the branch flow to switched shunts (ignore if DC network model is used)
	OPTIONS(6) = 0	Disable
	OPTIONS(6) = 1	Enable

	OPTIONS(7)	flag to specify the transfer from the components to which sensitivity factors of the branch flow are calculated to the opposing subsystem (the flag is ignored if none of the bus, generator, or load sensitivity calculation flags is selected)
	OPTIONS(7) = 0	Import. The positive transfer is from the components to the opposing subsystem
	OPTIONS(7) = 1	Export. The positive transfer is from the opposing subsystem to the components
	OPTIONS(8)	opposing subsystem type
	OPTIONS(8) = 0	Slack bus
	OPTIONS(8) = 1	Single bus
	OPTIONS(8) = 2	Subsystem
	OPTIONS(9)	ignored if opposing subsystem type is slack bus. It is a bus number when opposing subsystem type is a single bus, or one of the following seven dispatch modes if the opposing subsystem type is a subsystem (1 by default)
	OPTIONS(9) = 1	Buses & participating factors from DFAX file for buses with positive MW machines
	OPTIONS(9) = 2	Buses & participating factors from DFAX file for buses with positive MW constant MVA load
	OPTIONS(9) = 3	Buses & participating factors from DFAX file for buses with either positive MW machines or positive MW constant MVA load
	OPTIONS(9) = 4	Subsystem buses with positive MW constant MVA load in proportion to their MW load
	OPTIONS(9) = 5	Subsystem buses with positive MW machines in proportion to their MW output
	OPTIONS(9) = 6	Subsystem buses with positive MW machines in proportion to their MBASE
	OPTIONS(9) = 7	Subsystem buses with positive MW machines in proportion to their reserves (Pmaxmc-Pgenmc)
Real VALUES (2)	array of 2 elements specifying sensitivity analysis parameters(input).	
	VALUES(1)	mismatch tolerance for continuing sensitivity analysis in AC mode, ignored in DC mode
	VALUES(2)	sensitivity cutoff. Sensitivity factors less than the cutoff are not presented
Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).	
	LABELS(1)	label of the subsystem containing components to which the sensitivity factors of the branch flow are calculated

	LABELS(2)	label of opposing subsystem when the opposing subsystem type is a subsystem
	LABELS(3)	label of the subsystem including branches for which sensitivity factors are calculated
Character*260 DFXFILE	DFAX file name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid OPTIONS value
	IERR = 2	Invalid VALUES value
	IERR = 3	The bus does not exist
	IERR = 4	Generators are converted
	IERR = 5	Buses in island(s) without a swing bus--use activity TREE
	IERR = 6	Dispatch bus does not exist
	IERR = 7	No Distribution Factor Data input file specified
	IERR = 8	Subsystem containing components to which sensitivity factors are calculated is not specified
	IERR = 9	Opposing subsystem is not specified
	IERR = 10	Largest mismatch exceeds mismatch tolerance
	IERR = 21	file DFXFILE is not in the form of a PSSE-25 or later DFAX file, run DFAX
	IERR = 22	Error linearizing Jacobian matrix in AC network model
	IERR = 51	error opening Distribution Factor Data File
	IERR = 52	prerequisite requirements for function not met

1.1.267. SET_INPUT_DEV

Use this API to set the terminal input device to a file.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SET_INPUT_DEV IDVFIL
```

Python command syntax:

```
ierr = set_input_dev(idvfil)
```

Fortran command syntax:

```
CALL IDEVAPI(IDVFIL, IERR)
```

Where:

Character*260 IDVFIL	name of response file to be used for terminal (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening IDVFIL
	IERR = 2	prerequisite requirements for API are not met

1.1.268. SET_PROGRESS_VERBOSE

Use this API to to set the option progress message verbose value. This value is used to show or not show some repetitive progress messages when reading sequence data file.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Batch command syntax:

```
BAT_SET_PROGRESS_VERBOSE IVAL
```

Python command syntax:

```
ierr = set_progress_verbose(ival)
```

Fortran command syntax:

```
CALL SET_PROGRESS_VERBOSE(IVAL, IERR)
```

Where:

Integer IVAL	value of the option setting (input-1).	
	IVAL = -1	show all messages
	IVAL = 0	do not show repetitive messages
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	prerequisite requirements for API are not met

1.1.269. SHNT

Use this API to tabulate fixed and/or switched bus shunts contained in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SHNT SID ALL OPT
```

Python command syntax:

```
ierr = shnt(sid, all, opt)
```

Fortran command syntax:

```
CALL SHNTNW(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer OPT	option to select the type of bus shunts tabulated (input; 1 by default). OPT = 1 all shunts OPT = 2 fixed bus shunts OPT = 3 switched shunts
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid OPT value IERR = 4 prerequisite requirements for API are not met

1.1.270. SHORT_CIRCUIT_COORDINATES

Use this API to specify or return the option to set the fault analysis voltage and current output coordinates to either rectangular or polar coordinates.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SHORT_CIRCUIT_COORDINATES IVAL
```

Python command syntax:

```
ierr = short_circuit_coordinates(ival)
ierr, ival = short_circuit_coordinates()
```

Fortran command syntax:

```
CALL SHORT_CIRCUIT_COORDINATES_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 rectangular coordinates.
	IVAL = 1 polar coordinates.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.271. SHORT_CIRCUIT_MODELING

Use this API to specify or return the option for the fault analysis modeling setting; either normal three-phase or center tapped two-phase.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SHORT_CIRCUIT_MODELING IVAL
```

Python command syntax:

```
ierr = short_circuit_modeling(ival)
ierr, ival = short_circuit_modeling()
```

Fortran command syntax:

```
CALL SHORT_CIRCUIT_MODELING_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).
	IVAL = 0 center tapped two-phase.
	IVAL = 1 normal three-phase.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.272. SHORT_CIRCUIT_UNITS

Use this API to specify or return the option to set the fault analysis voltage and current output units to either per unit or physical units.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SHORT_CIRCUIT_UNITS IVAL
```

Python command syntax:

```
ierr = short_circuit_units(ival)
ierr, ival = short_circuit_units()
```

Fortran command syntax:

```
CALL SHORT_CIRCUIT_UNITS_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 per unit.
	IVAL = 1 physical units.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.273. SHORT_CIRCUIT_WARNING

Use this API to specify or return the option to enable or disable the fault analysis warning option setting.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SHORT_CIRCUIT_WARNING IVAL
```

Python command syntax:

```
ierr = short_circuit_warning(ival)
ierr, ival = short_circuit_warning()
```

Fortran command syntax:

```
CALL SHORT_CIRCUIT_WARNING_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 1 by default; else output).	
	IVAL = 0	disable printing of RESQ/TRSQ/solution warnings.
	IVAL = 1	print RESQ/TRSQ/solution warnings.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

1.1.274. SHORT_CIRCUIT_Z_COORDINATES

Use this API to specify or return the option to set the fault analysis output impedance coordinates to either rectangular or polar coordinates.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SHORT_CIRCUIT_Z_COORDINATES IVAL
```

Python command syntax:

```
ierr = short_circuit_z_coordinates(ival)
ierr, ival = short_circuit_z_coordinates()
```

Fortran command syntax:

```
CALL SHORT_CIRCUIT_Z_COORDINATES(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 rectangular coordinates.
	IVAL = 1 polar coordinates.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.275. SHORT_CIRCUIT_Z_UNITS

Use this API to specify or return the option to set the fault analysis output impedance units to either per unit or ohms.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SHORT_CIRCUIT_Z_UNITS IVAL
```

Python command syntax:

```
ierr = short_circuit_z_units(ival)
ierr, ival = short_circuit_z_units()
```

Fortran command syntax:

```
CALL SHORT_CIRCUIT_Z_UNITS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 per unit.
	IVAL = 1 physical units.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.276. SHOW

Use this API to tabulate summaries of Saved Case and/or Snapshot Files.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SHOW  OPTION  SFILE
```

Python command syntax:

```
ierr = show(option, sfile)
```

Fortran command syntax:

```
CALL SHOWAPI(OPTION, SFILE, IERR)
```

Where:

Integer OPTION	code for the type(s) of files to report (input; 1 by default).
OPTION = 0	file specified in SFILE
OPTION = 1	all .savx, .sav and .snp files
OPTION = 2	all .savx and .sav files
OPTION = 3	all .snp files
Character*260 SFILE	name of saved case or snapshot file (when OPTION is 0) (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid OPTION value
IERR = 2	SFILE is blank when OPTION is 0
IERR = 3	prerequisite requirements for API are not met

1.1.277. SHOWTABLE

Directs a report table to output console. Use API_NAME instead to redirect report table output to the Progress Window or Report Window.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr = showtable(tblnam, direction)
```

Fortran command syntax:

```
CALL SHOWTABLE(TBLNAM, DIRECTION, IERR)
```

Where:

Character*512 TBLNAM	(input).	
Integer DIRECTION	(input).	
	DIRECTION = 1	Progress window
	DIRECTION = 2	Report window
Integer IERR	error code (output).	

1.1.278. SHOWTABLEBYINDEX

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr = showtablebyindex(tblid, direction)
```

Fortran command syntax:

```
CALL SHOWTABLEBYINDEX(TBLID, DIRECTION, IERR)
```

Where:

Integer TBLID	(input).	
Integer DIRECTION	(input).	
	DIRECTION = 1	Progress window
	DIRECTION = 2	Report window
Integer IERR	error code (output).	

1.1.279. SIZE

Use this API to obtain a summary of the number of components in the working case (activity SIZE).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SIZE
```

Python command syntax:

```
ierr = size()
```

Fortran command syntax:

```
CALL SIZEAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.280. SOLV

Use this API to apply the Gauss-Seidel power flow calculation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SOLV  OPTIONS(1) .. OPTIONS(6)
```

Python command syntax:

```
ierr = solv(options)
```

Fortran command syntax:

```
CALL SOLVAPI(OPTIONS, IERR)
```

Where:

Integer OPTIONS (6)	array of 6 elements specifying solution options(input).
OPTIONS(1)	tap adjustment flag (use tap adjustment option setting by default)
OPTIONS(1) = 0	disable
OPTIONS(1) = 1	enable
OPTIONS(2)	area interchange adjustment flag (use area interchange adjustment option setting by default)
OPTIONS(2) = 0	disable
OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
OPTIONS(3)	flat start flag (0 by default)
OPTIONS(3) = 0	do not flat start
OPTIONS(3) = 1	flat start
OPTIONS(3) = 2	flat start, then estimate voltage magnitudes
OPTIONS(3) = 3	flat start, then estimate voltage phase angles
OPTIONS(3) = 4	flat start, then estimate voltage magnitudes and phase angles
OPTIONS(4)	dc tap adjustment flag (use dc tap adjustment option setting by default)
OPTIONS(4) = 0	disable
OPTIONS(4) = 1	enable
OPTIONS(5)	switched shunt adjustment flag (use switched shunt adjustment option setting by default)
OPTIONS(5) = 0	disable
OPTIONS(5) = 1	enable

Integer IERR	OPTIONS(5) = 2	enable continuous mode, disable discrete mode
	OPTIONS(6)	var limit flag (0 by default)
	OPTIONS(6) = 0	apply var limits
	OPTIONS(6) = 1	ignore var limits
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	generators are converted
	IERR = 3	buses in island(s) without a swing bus; use activity TREE
	IERR = 4	bus type code and series element status inconsistencies
	IERR = 5	prerequisite requirements for API are not met

1.1.281. SPCB

Use this API to calculate positive sequence equivalents of branch unbalances.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SPCB  IBUS  JBUS  CKT  OPTIONS(1)..OPTIONS(4)  VALUES(1)..VALUES(5)
```

Python command syntax:

```
ierr = spcb(ibus, jbus, ckt, options, values)
```

Fortran command syntax:

```
CALL SPCBAPI(IBUS, JBUS, CKT, OPTIONS, VALUES, IERR)
```

Where:

Integer IBUS	from bus of branch subjected to unbalance (input; no default allowed).
Integer JBUS	to bus of branch subjected to unbalance (input; no default allowed).
Character*2 CKT	circuit identifier of branch subjected to unbalance (input; '1' by default).
Integer OPTIONS (4)	array of 4 elements specifying unbalance OPTIONS(input).
	OPTIONS(1) unbalance code (0 by default)
	OPTIONS(1) = 0 no unbalance; Thevenin impedances only
	OPTIONS(1) = 1 one phase open
	OPTIONS(1) = 2 two phases open
	OPTIONS(1) = 3 in-line fault
	OPTIONS(1) = 4 one breaker open
	OPTIONS(1) = 5 no unbalance
	OPTIONS(2) path to ground code (used when OPTIONS(1) is 1 or 4) (0 by default)
	OPTIONS(2) = 0 no path to ground
	OPTIONS(2) = 1 include a path to ground
	OPTIONS(3) type of in-line fault code (used when OPTIONS(1) is 3) (1 by default)
	OPTIONS(3) = 1 line-to-ground
	OPTIONS(3) = 2 line-to-line-to-ground
	OPTIONS(3) = 3 three-phase
	OPTIONS(4) open end code (used when OPTIONS(1) is 4) (1 by default)
	OPTIONS(4) = 0 breaker at to bus is open
	OPTIONS(4) = 1 breaker at from bus is open
Real VALUES (3)	array of 3 elements specifying unbalance parameters(input).
	VALUES(1) fault location as fraction of line from from bus; $0.0 < \text{VALUES}(1) < 1.0$ (used when OP-

		TIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3) (0.5 by default) & (3) RI-g and XI-g (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3 and OPTIONS(3) is 1 or 2) (0.0 by default) VALUES(3) & (5) RI-I and XI-I (used when OPTIONS(1) is 3 and OPTIONS(3) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid with two phase modeling option enabled
	IERR = 2	bus not found
	IERR = 3	invalid OPTIONS value
	IERR = 4	invalid VALUES value
	IERR = 5	SEQD temporary file is not open
	IERR = 6	SEQD results are not compatible with the working case
	IERR = 7	terminated due to invalid fault specification or application
	IERR = 8	prerequisite requirements for API are not met

1.1.282. SPIL

Use this API to calculate transmission interchange limits using a linear network (dc) model.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SPIL  OPTIONS(1)..OPTIONS(16)  VALUES(1)..VALUES(7)
          LABELS(1)..LABELS(8)  DFXFILE  PRTFILE
```

Python command syntax:

```
ierr = spil(options, values, labels, dfxfile, prtfile)
```

Fortran command syntax:

```
CALL SPILAPI(OPTIONS, VALUES, LABELS, DFXFILE, PRTFILE, IERR)
```

Where:

Integer OPTIONS (16)	array of 16 elements specifying calculation and reporting options(input).	
	OPTIONS(1)	base case rating set (rating set program option setting by default)
	OPTIONS(1) = 1	RATEA
	OPTIONS(1) = 2	RATEB
	OPTIONS(1) = 3	RATEC
	OPTIONS(2)	contingency case rating set (rating set program option setting by default)
	OPTIONS(2) = 1	RATEA
	OPTIONS(2) = 2	RATEB
	OPTIONS(2) = 3	RATEC
	OPTIONS(3)	base case line flow code (0 by default)
	OPTIONS(3) = 0	dc base case
	OPTIONS(3) = 1	ac base case
	OPTIONS(4)	phase shifter code (0 by default)
	OPTIONS(4) = 0	locked in base case shift solutions
	OPTIONS(4) = 1	regulating in base case shift solutions
	OPTIONS(5)	list study system buses (0 by default)
	OPTIONS(5) = 0	no
	OPTIONS(5) = 1	yes
	OPTIONS(6)	list opposing system buses (0 by default)
	OPTIONS(6) = 0	no
	OPTIONS(6) = 1	yes
	OPTIONS(7)	list study system tie lines (0 by default)
	OPTIONS(7) = 0	no
	OPTIONS(7) = 1	yes
	OPTIONS(8)	add study system tie lines to monitored line list (0 by default)

	OPTIONS(8) = 0	no
	OPTIONS(8) = 1	yes
	OPTIONS(9)	format code (0 by default)
	OPTIONS(9) = 0	summary output
	OPTIONS(9) = 1	full output
	OPTIONS(10)	interchange limit code (0 by default)
	OPTIONS(10) = 0	incremental transfer capability
	OPTIONS(10) = 1	total transfer capability
	OPTIONS(11)	apply summary minimum distribution factor, VALUES(4), to solution reports (0 by default)
	OPTIONS(11) = 0	no
	OPTIONS(11) = 1	yes
	OPTIONS(12)	convert MVA ratings to estimated MW ratings (0 by default)
	OPTIONS(12) = 0	no
	OPTIONS(12) = 1	yes
	OPTIONS(13)	code to discontinue activity if MW mismatch exceeds VALUES(1) (0 by default)
	OPTIONS(13) = 0	discontinue
	OPTIONS(13) = 1	continue
	OPTIONS(14)	summary table contingency descriptions (1 by default)
	OPTIONS(14) = 0	contingency labels
	OPTIONS(14) = 1	contingency events
	OPTIONS(14) = 2	both contingency labels and events
	OPTIONS(15)	number of elements to include in flow tables (60000 by default)
	OPTIONS(16)	summary table maximum times for reporting the same element (5 by default)
Real VALUES (7)	array of 7 elements specifying tolerances and thresholds(input).	
	VALUES(1)	required MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating for reporting an element as overloaded (100.0 by default)
	VALUES(3)	summary table maximum import or export (>0.) (99999.0 by default)
	VALUES(4)	summary table minimum distribution factor magnitude (0.0 by default)
	VALUES(5)	minimum contingency case pre-shift flow change (0.0 by default)
	VALUES(6)	minimum contingency case distribution factor change (0.0 by default)
	VALUES(7)	study system generation shift (100.0 by default)

Character*32 LABELS (8)	array of 8 elements specifying subsystem and interface labels(input).
LABELS(1)	study system label (no default allowed)
LABELS(2)	opposing system label (no default allowed)
LABELS(3)	interface label for optional interface limits summary table (blank for none) (blank by default)
LABELS(4)	interface label for optional interface limits summary table (blank for none) (blank by default)
LABELS(5)	interface label for optional interface limits summary table (blank for none) (blank by default)
LABELS(6)	interface label for optional interface limits summary table (blank for none) (blank by default)
LABELS(7)	interface label for optional interface limits summary table (blank for none) (blank by default)
LABELS(8)	interface label for optional interface limits summary table (blank for none) (blank by default)
Character*260 DFXFILE	name of DFAX data file (input; no default allowed).
Character*260 PRTFILE	name of subsystem participation data file; blank for none (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid OPTIONS value
IERR = 2	invalid VALUES value
IERR = 3	no DFAX data file specified
IERR = 4	same label specified for study and opposing systems
IERR = 5	generators are converted
IERR = 6	buses in island(s) without a swing bus; use activity TREE
IERR = 7	largest mismatch exceeds mismatch tolerance
IERR = 8	error opening file DFXFILE
IERR = 9	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
IERR = 10	file DFXFILE does not contain distribution factors; run DFAX with distribution factor option enabled
IERR = 11	no monitored branches or interfaces defined
IERR = 12	no subsystems defined
IERR = 13	subsystem not found

IERR = 14

specified subsystems overlap

IERR = 15

no in-service buses in subsystem WORLD

IERR = 16

no tie lines from study system

IERR = 17

prerequisite requirements for API are not met

1.1.283. SPLT

Use this API to add a bus to the working case and place a zero impedance line between bus BUS and the new bus. No other equipment is connected to the new bus by this API.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SPLT  BUS  NEWNUM  'NEWNAM'  NEWKV
```

Python command syntax:

```
ierr = splt(bus, newnum, newnam, newkv)
```

Fortran command syntax:

```
CALL SPLTAPI(BUS, NEWNUM, NEWNAM, NEWKV, IERR)
```

Where:

Integer BUS	number of the bus to be split (input; no default allowed).
Integer NEWNUM	number to be assigned to the new bus (input; no default allowed).
Character*12 NEWNAM	name to be assigned to the new bus (input; blank by default).
Real NEWKV	base voltage to be assigned to the new bus (input; base voltage of bus BUS).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 invalid NEWNUM value
	IERR = 3 bus number is already assigned to another bus
	IERR = 4 invalid NEWKV value
	IERR = 5 bus, branch, or branch ownership tables are full
	IERR = 6 prerequisite requirements for API are not met

1.1.284. SQLI

Use this API to tabulate the sequence data in a form suitable for problem data documentation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SQLI  SID  ALL  OPT
```

Python command syntax:

```
ierr = sqli(sid, all, opt)
```

Fortran command syntax:

```
CALL SQLINW(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer OPT	category of sequence data to be tabulated (input; 1 by default).	
	OPT = 1	full listing
	OPT = 2	bus load data
	OPT = 3	generator data
	OPT = 4	branch data
	OPT = 5	two-winding positive sequence data
	OPT = 6	mutual coupling data
	OPT = 7	switched shunt data
	OPT = 8	three-winding general data
	OPT = 9	line shunt data
	OPT = 10	fixed shunt data
	OPT = 11	induction machine data
	OPT = 12	two-winding zero sequence data
	OPT = 13	three-winding positive sequence data
	OPT = 14	three-winding zero sequence data
	OPT = 15	non-conventional source machine data
	OPT = 16	non-conventional source table data
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value

IERR = 3

invalid OPT value

IERR = 4

prerequisite requirements for API are not met

1.1.285. SRAIND

Use this API to run the substation reliability analysis. It applies failure modes and affects analysis of arbitrary bus-breaker configurations and measures the impact of substation equipment failures upon the power transfer capability of the substation.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SRAIND  OPTIONS(1)..OPTIONS(3) VALUES(1)..VALUES(5)
            LABELS(1)..LABELS(3) DFXFILE PRBFILE
```

Python command syntax:

```
ierr = sraind(options, values, labels, dfxfile, prbfile)
```

Fortran command syntax:

```
CALL SRAINDAPI(OPTIONS, VALUES, LABELS, DFXFILE, PRBFILE, IERR)
```

Where:

Integer OPTIONS (3)	array of 3 elements specifying options(input).
OPTIONS(1)	report format (1 by default)
OPTIONS(1) = 1	contingency report
OPTIONS(1) = 2	bus load curtailment report
OPTIONS(1) = 3	substation load curtailment report
OPTIONS(2)	rating set (rating set program option setting by default)
OPTIONS(2) = 1	RATEA
OPTIONS(2) = 2	RATEB
OPTIONS(2) = 3	RATEC
OPTIONS(3)	include system ties (0 by default)
OPTIONS(3) = 0	disable
OPTIONS(3) = 1	enable
Real VALUES (5)	array of 5 elements specifying substation reliability assessment parameters(input).
VALUES(1)	percent of flow rating (≥ 0 , 100.0 by default)
VALUES(2)	frequency cutoff (≥ 0 , 0.0001 by default)
VALUES(3)	percent of peak load (≥ 0 , 100.0 by default)
VALUES(4)	switching time in hours (≥ 0 , 0.0 by default)
VALUES(5)	breaker failure rate in hours per year (≥ 0 , 0.0 by default)
Character*32 LABELS (3)	array of 3 elements specifying subsystem labels(input).
LABELS(1)	label of substation subsystem (no default is allowed)

	LABELS(2)	label of source subsystem (no default is allowed)
	LABELS(3)	label of sink subsystem (no default is allowed)
Character*260 DFXFILE	name of DFAX data file (input; no default allowed).	
Character*260 PRBFILE	name of outage statistic data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	substation/source/sink subsystem not specified
	IERR = 4	no DFAX data file specified
	IERR = 5	no outage Statistic Data File specified
	IERR = 6	file is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 7	subsystem not found in DFAX data file
	IERR = 8	source/sink buses not in substation subsystem
	IERR = 9	source and sink systems overlap
	IERR = 51	error opening DFAX data file
	IERR = 52	error opening outage statistic data file
	IERR = 53	file system errors

1.1.286. STOP

This API routine is obsolete. It has been replaced by the API routine [stop_2](#).

Use this API to end the operation of PSSE.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_STOP  DELETE
```

Python command syntax:

```
ierr = stop(delete)
```

Fortran command syntax:

```
CALL STOPAPI(DELETE, IERR)
```

Where:

Integer DELETE	delete working files (input; 0 by default).
DELETE = 1	delete working files
DELETE != 1	keep working files
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	prerequisite requirements for API are not met

1.1.287. STOP_2

Use this API to end the operation of PSSE.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_STOP_2
```

Python command syntax:

```
ierr = stop_2()
```

Fortran command syntax:

```
CALL STOPAPI_2(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.288. SUBS

Use this API to summarize conditions in the working case by tabulating the conditions at each swing system bus, conditions at each area slack area bus, number of components, generation/ load/shunt totals, and loss/line shunt/charging totals by voltage levels.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SUBS  SID  ALL
```

Python command syntax:

```
ierr = subs(sid, all)
```

Fortran command syntax:

```
CALL SUBSNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.289. SWITCHED_SHUNT_ADJUSTMENT

Use this API to specify or return the option to enable or disable switched shunt adjustment.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_ADJUSTMENT IVAL
```

Python command syntax:

```
ierr = switched_shunt_adjustment(ival)
ierr, ival = switched_shunt_adjustment()
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_ADJUSTMENT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 disabled.
	IVAL = 1 enabled.
	IVAL = 2 continuous mode switched shunts enabled, discrete mode switched shunts locked.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.290. TAP_ADJUSTMENT

Use this API to specify or return the option for the default tap adjustment setting; either disabled, stepping or direct.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_TAP_ADJUSTMENT IVAL
```

Python command syntax:

```
ierr = tap_adjustment(ival)
ierr, ival = tap_adjustment()
```

Fortran command syntax:

```
CALL TAP_ADJUSTMENT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 locked (i.e., tap adjustment is disabled).
	IVAL = 1 tap adjustment using the stepping method enabled.
	IVAL = 2 tap adjustment using the direct method enabled.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.291. TEXT

This API does nothing. Its purpose is to provide recordable documentation.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_TEXT 'CARG'
```

Python command syntax:

```
ierr = text(carg)
```

Fortran command syntax:

```
CALL TEXT_API(CARG, IERR)
```

Where:

Character*220 CARG

string of text (input; blank by default).

Integer IERR

error code (output).

IERR = 0

no error occurred

IERR = 1

prerequisite requirements for API are not met

1.1.292. TFLG

Use this API to set or reset the adjustment control mode flags for all automatically adjustable transformers contained in the specified subsystem.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TFLG  SID  ALL  OPT
```

Python command syntax:

```
ierr = tflg(sid, all, opt)
```

Fortran command syntax:

```
CALL TFLGNW(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer OPT	option to select the adjustment control mode flags of those transformers being processed (input; 1 by default).	
	OPT = 0	disable
	OPT = 1	enable
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 4	prerequisite requirements for API are not met

1.1.293. TIES

Use this API to tabulate the flows on all area tie lines, with tie flows grouped by area.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TIES  SID  ALL
```

Python command syntax:

```
ierr = ties(sid, all)
```

Fortran command syntax:

```
CALL TIESNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only areas in area subsystem SID
	ALL = 1	process all areas
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.294. TIEZ

Use this API to tabulate the flows on all zone tie lines, with tie flows grouped by zone.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TIEZ  SID  ALL
```

Python command syntax:

```
ierr = tiez(sid, all)
```

Fortran command syntax:

```
CALL TIEZNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Zone subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all zones or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only zones in zone subsystem SID
	ALL = 1	process all zones
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.295. TIME

Use this API to tabulate timing statistics.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_TIME  INIT
```

Python command syntax:

```
ierr = time(init)
```

Fortran command syntax:

```
CALL TIMEAPI(INIT, IERR)
```

Where:

Integer INIT	timing flag (input; positive).	
	INIT <= 0	do not initialize
	INIT > 0	initialize
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.296. TLST

Use this API to tabulate those transformers in the working case where off-nominal turns ratio or phase shift angle may be adjusted by the power flow solution activities.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TLST SID ALL OPT VREV
```

Python command syntax:

```
ierr = tlst(sid, all, opt, vrev)
```

Fortran command syntax:

```
CALL TLSTNW(SID, ALL, OPT, VREV, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer OPT	option to select the transformers tabulated (input; 0 by default). OPT = 0 all OPT = 1 violations only
Integer VREV	option to change voltage units from the default units to the alternate units (input; 0 by default). VREV = 0 use default voltage units VREV = 1 use alternate voltage units
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid OPT value IERR = 4 invalid VREV value IERR = 5 prerequisite requirements for API are not met

1.1.297. TLTG

Use this API to calculate transmission interchange limits using a linear network (dc) model.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_TLTG  OPTIONS(1)..OPTIONS(17)  VALUES(1)..VALUES(7)
          LABELS(1)..LABELS(8)  DFXFILE
```

Python command syntax:

```
ierr = tltg(options, values, labels, dfxfile)
```

Fortran command syntax:

```
CALL TLTGAPI(OPTIONS, VALUES, LABELS, DFXFILE, IERR)
```

Where:

Integer OPTIONS (17)	array of 17 elements specifying calculation and reporting options(input).	
	OPTIONS(1)	base case rating set (rating set program option setting by default)
	OPTIONS(1) = 1	RATEA
	OPTIONS(1) = 2	RATEB
	OPTIONS(1) = 3	RATEC
	OPTIONS(2)	contingency case rating set (rating set program option setting by default)
	OPTIONS(2) = 1	RATEA
	OPTIONS(2) = 2	RATEB
	OPTIONS(2) = 3	RATEC
	OPTIONS(3)	base case line flow code (0 by default)
	OPTIONS(3) = 0	dc base case
	OPTIONS(3) = 1	ac base case
	OPTIONS(4)	phase shifter code (0 by default)
	OPTIONS(4) = 0	locked in base case shift solutions
	OPTIONS(4) = 1	regulating in base case shift solutions
	OPTIONS(5)	code for the treatment of base case line flow constraints in contingency cases (0 by default)
	OPTIONS(5) = 0	ignore
	OPTIONS(5) = 1	include
	OPTIONS(6)	list study system buses (0 by default)
	OPTIONS(6) = 0	no
	OPTIONS(6) = 1	yes
	OPTIONS(7)	list opposing system buses (0 by default)
	OPTIONS(7) = 0	no
	OPTIONS(7) = 1	yes

	OPTIONS(8)	list study system tie lines (0 by default)
	OPTIONS(8) = 0	no
	OPTIONS(8) = 1	yes
	OPTIONS(9)	add study system tie lines to monitored line list (0 by default)
	OPTIONS(9) = 0	no
	OPTIONS(9) = 1	yes
	OPTIONS(10)	format code (0 by default)
	OPTIONS(10) = 0	summary output
	OPTIONS(10) = 1	full output
	OPTIONS(11)	interchange limit code (0 by default)
	OPTIONS(11) = 0	incremental transfer capability
	OPTIONS(11) = 1	total transfer capability
	OPTIONS(12)	apply summary minimum distribution factor, VALUES(4), to solution reports (0 by default)
	OPTIONS(12) = 0	no
	OPTIONS(12) = 1	yes
	OPTIONS(13)	convert MVA ratings to estimated MW ratings (0 by default)
	OPTIONS(13) = 0	no
	OPTIONS(13) = 1	yes
	OPTIONS(14)	code to discontinue activity if MW mismatch exceeds VALUES(1) (0 by default)
	OPTIONS(14) = 0	discontinue
	OPTIONS(14) = 1	continue
	OPTIONS(15)	summary table contingency descriptions (1 by default)
	OPTIONS(15) = 0	contingency labels
	OPTIONS(15) = 1	contingency events
	OPTIONS(15) = 2	both contingency labels and events
	OPTIONS(16)	number of elements to include in flow tables (60000 by default)
	OPTIONS(17)	summary table maximum times for reporting the same element (5 by default)
Real VALUES (7)	array of 7 elements specifying tolerances and thresholds(input).	
	VALUES(1)	required MW mismatch tolerance for continuing (Newton solution convergence tolerance, TOLN by default)
	VALUES(2)	percent of rating for reporting an element as overloaded (100.0 by default)
	VALUES(3)	summary table maximum import or export (>0.) (99999.0 by default)
	VALUES(4)	summary table minimum distribution factor magnitude (0.0 by default)

	VALUES(5)	minimum contingency case pre-shift flow change (0.0 by default)
	VALUES(6)	minimum contingency case distribution factor change (0.0 by default)
	VALUES(7)	study system generation shift (100.0 by default)
Character*32 LABELS (8)	array of 8 elements specifying subsystem and interface labels(input).	
	LABELS(1)	study system label (no default allowed)
	LABELS(2)	opposing system label (no default allowed)
	LABELS(3)	interface label for optional interface limits summary table (blank for none) (blank by default)
	LABELS(4)	interface label for optional interface limits summary table (blank for none) (blank by default)
	LABELS(5)	interface label for optional interface limits summary table (blank for none) (blank by default)
	LABELS(6)	interface label for optional interface limits summary table (blank for none) (blank by default)
	LABELS(7)	interface label for optional interface limits summary table (blank for none) (blank by default)
	LABELS(8)	interface label for optional interface limits summary table (blank for none) (blank by default)
Character*260 DFXFILE	name of DFAX data file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	no DFAX data file specified
	IERR = 4	same label specified for study and opposing systems
	IERR = 5	generators are converted
	IERR = 6	buses in island(s) without a swing bus; use activity TREE
	IERR = 7	largest mismatch exceeds mismatch tolerance
	IERR = 8	error opening file DFXFILE
	IERR = 9	file DFXFILE is not in the form of a PSSE-25 or later DFAX file; run DFAX
	IERR = 10	file DFXFILE does not contain distribution factors; run DFAX with distribution factor option enabled

IERR = 11	no monitored branches or interfaces defined
IERR = 12	no subsystems defined
IERR = 13	subsystem not found
IERR = 14	specified subsystems overlap
IERR = 15	no in-service buses in subsystem WORLD
IERR = 16	no tie lines from study system
IERR = 17	prerequisite requirements for API are not met

1.1.298. TPCH

Use this API to check the adjustment data associated with voltage or flow controlling transformers. It must be referenced using one of the following procedures:

- One reference with APIOPT=1, followed by any number of either APIOPT=2 references and/or pairs of references with APIOPT=2 and then 3, followed by one reference with APIOPT=4.
- One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference, followed by one APIOPT 3 reference if NTRN from the APIOPT 2 reference is greater than zero, followed by one APIOPT 4 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TPCH SID ALL APIOPT OPT STATUS(1) STATUS(2) THRSH(1) THRSH(2)
```

Python command syntax:

```
ierr, ttyp, ntrn = tpch(sid, all, apiopt, opt, status, thrsh)
```

Fortran command syntax:

```
CALL TPCHNW(SID, ALL, APIOPT, OPT, STATUS, THRSH, TTYP, NTRN, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; used only when APIOPT is 0 or 1; 0).	
Integer ALL	all buses or specified subsystem flag (input; used only when APIOPT is 0 or 1; 1).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer APIOPT	mode of operation (input; 0 by default).	
	APIOPT = 0	initialize, check, modify adjustment data, and terminate
	APIOPT = 1	initialize for check and data modification
	APIOPT = 2	check transformers
	APIOPT = 3	modify adjustment data
	APIOPT = 4	terminate transformer checks
Integer OPT	option to select the type of adjustment (input; used only when APIOPT is 0 or 2; 1).	
	OPT = 1	tap step = 0. (V/Mvar)
	OPT = 2	0. < step < minimum (V/ Mvar)
	OPT = 3	tap step > maximum (V/ Mvar)
	OPT = 4	voltage band < 2*step (V)
	OPT = 5	voltage band < minimum (V)
	OPT = 6	voltage band > maximum (V)
	OPT = 8	flow band < minimum (MW/Mvar)
	OPT = 9	flow band > maximum (MW/Mvar)

Integer STATUS (2)	array of 2 elements specifying data modification options (used only when APIOPT is 0 or 3)(input).	
	STATUS(1)	modify steps or voltage bands, when OPT = 4 (1 by default)
	STATUS(1) = 1	modify steps
	STATUS(1) = 2	modify voltage bands
	STATUS(2)	used to indicate which transformers to change where OPTs 1, 2, 3, 8 or 9 (0 by default)
	STATUS(2) = 0	change both types
	STATUS(2) = 1	change voltage controlling transformers when OPT = 1, 2 or 3; change MW controlling transformers when OPT = 8 or 9
	STATUS(2) = 2	change Mvar controlling transformers
Real THRSH (2)	array of 2 elements specifying data checking and modification parameters(input).	
	THRSH(1)	threshold to use in initial test (used only when APIOPT is 0 or 2; defaults: 0.00625 when OPT is 2 or 3; 0.02 when OPT is 5 or 6; 5.0 when OPT is 8 or 9)
	THRSH(2)	new tap step, voltage band, or flow band (used only when APIOPT is 0 or 3)
	If OPT	
	THRSH(2) = 1	new tap step (0.00625 by default)""
	THRSH(2) = 2,3	new tap step (THRSH(1) by default)""
	THRSH(2) = 5,6	new voltage band (THRSH(1) by default)""
	THRSH(2) = 8,9	new flow band (THRSH(1) by default)""
Logical TTYP	returned when APIOPT = 0, 2 or 3 and is TRUE. if both voltage (or MW if OPT = 8 or 9) and Mvar controlling transformers were found (output).	
Integer NTRN	returned when APIOPT = 0, 2 or 3 and is the number of transformers that need adjustment when applying the adjustment type indicated by OPT (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid APIOPT value
	IERR = 4	invalid OPT value
	IERR = 5	invalid STATUS value
	IERR = 6	invalid THRSH value
	IERR = 7	unexpected APIOPT value
	IERR = 8	no controlling transformers in case

IERR = 9

prerequisite requirements for API are not met

1.1.299. TRANSFORMER_PERCENT_UNITS

Use this API to specify or return the option to set the transformer percent units to either MVA or current expressed as MVA.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_TRANSFORMER_PERCENT_UNITS IVAL
```

Python command syntax:

```
ierr = transformer_percent_units(ival)
ierr, ival = transformer_percent_units()
```

Fortran command syntax:

```
CALL TRANSFORMER_PERCENT_UNITS_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 MVA.
	IVAL = 1 current expressed as MVA.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.300. TRANSMISSION_LINE_UNITS

Use this API to to specify or return the option set the transmission line units to either per unit or ohms.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_TRANSMISSION_LINE_UNITS IVAL
```

Python command syntax:

```
ierr = transmission_line_units(ival)
ierr, ival = transmission_line_units()
```

Fortran command syntax:

```
CALL TRANSMISSION_LINE_UNITS_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 per unit.
	IVAL = 1 ohms and microfarads.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.301. TREE

Use this API to check for the existence of in-service ac islands that do not contain a Type 3 (swing) bus. Following each successful call, it returns BUSES as the number of buses in a swingless island (0 for no more swingless islands). When a BUSES value of 0 is returned, no further calls are needed.

The API must be called once with APIOPT set to 1. If BUSES is returned as 0 (i.e., there are no swingless islands), no further calls are needed. Otherwise, if BUSES is greater than zero, it must be called one or more times with APIOPT set to 2 and OPTION set to indicate the disposition of the current swingless island. APIOPT 2 calls are required until either BUSES is returned as zero or an APIOPT 2 call is made with OPTION set to a negative value.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_TREE  APIOPT  OPTION
```

Python command syntax:

```
ierr, buses = tree(apiopt, option)
```

Fortran command syntax:

```
CALL TREEAPI(APIOPT, OPTION, BUSES, IERR)
```

Where:

Integer APIOPT	mode of operation (input; no default allowed).
	APIOPT = 1 initialize and check for the presence of a swingless island
	APIOPT = 2 process previously detected island as dictated by OPTION; then check for the presence of another swingless island
Integer OPTION	option for the handling of previously detected swingless island (input; used only when APIOPT is 2; -1).
	OPTION < 0 leave this island alone and terminate activity TREE
	OPTION = 0 leave this island alone and check for another swingless island
	OPTION > 0 disconnect this island, then check for another swingless island
Integer BUSES	returned as the number of buses in this swingless island; 0 if no more swingless islands (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid APIOPT value
	IERR = 2 unexpected APIOPT value
	IERR = 3 prerequisite requirements for API are not met

1.1.302. TYSL

Use this API to run switching study network solutions.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TYSL  OPT
```

Python command syntax:

```
ierr = tysl(opt)
```

Fortran command syntax:

```
CALL TYSLAPI(OPT, IERR)
```

Where:

Integer OPT	flat start flag (input; 0 by default).
	OPT = 0 use present voltage vector as starting point
	OPT = 1 flat start
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid OPT value
	IERR = 2 generators are not converted
	IERR = 3 network is not ordered
	IERR = 4 error reading the admittance matrix temporary file; one of the following occurred: Admittance matrix temporary file is not open; Reading matrix pointers: different sizes specified than were used in writing them; Reading matrix terms: different sizes specified than were used in writing them
	IERR = 5 prerequisite requirements for API are not met

1.1.303. USER

Use this API to run the user-written activity, subroutine USERAC.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_USER
```

Python command syntax:

```
ierr = user()
```

Fortran command syntax:

```
CALL USERAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.304. VAMM

Use this API to tabulate the vector absolute MW-mile report.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_VAMM
```

Python command syntax:

```
ierr = vamm()
```

Fortran command syntax:

```
CALL VAMMAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no transactions defined
	IERR = 4	prerequisite requirements for API are not met

1.1.305. VAMO

Use this API to tabulate the vector absolute MW-ohm report.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_VAMO
```

Python command syntax:

```
ierr = vamo()
```

Fortran command syntax:

```
CALL VAMOAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no transactions defined
	IERR = 4	prerequisite requirements for API are not met

1.1.306. VCHK

Use this API to tabulate those buses where voltage magnitude is outside a specified range.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_VCHK SID ALL VLO VHI
```

Python command syntax:

```
ierr = vchk(sid, all, vlo, vhi)
```

Fortran command syntax:

```
CALL VCHKNW(SID, ALL, VLO, VHI, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Real VLO	lower limit of the voltage band (input; 0.95).	
Real VHI	upper limit of the voltage band (input; 1.05).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.307. VOLTAGE_INPUT

Use this API to specify or return the voltage input option setting; either per unit or kV.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_VOLTAGE_INPUT IVAL
```

Python command syntax:

```
ierr = voltage_input(ival)
ierr, ival = voltage_input()
```

Fortran command syntax:

```
CALL VOLTAGE_INPUT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 per unit.
	IVAL = 1 kV.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.308. VOLTAGE_OUTPUT

Use this API to specify or return the voltage output option setting; either per unit or kV.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_VOLTAGE_OUTPUT IVAL
```

Python command syntax:

```
ierr = voltage_output(ival)
ierr, ival = voltage_output()
```

Fortran command syntax:

```
CALL VOLTAGE_OUTPUT_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).
	IVAL = 0 per unit.
	IVAL = 1 kV.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

1.1.309. VSMO

Use this API to tabulate the vector MW-ohm report.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_VSMO
```

Python command syntax:

```
ierr = vsmo()
```

Fortran command syntax:

```
CALL VSMOAPI(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	no transactions defined
	IERR = 4	prerequisite requirements for API are not met

1.1.310. WRITECAPCURVES

Use this API to write the capability curve data in the working case in the form of a Capability Curve Raw Data File.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_WRITECAPCURVES  SID  ALL  STATUS(1)  STATUS(2)  OUT  OFILE
```

Python command syntax:

```
ierr = writecapcurves(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL WRITECAPCURVES(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all machines or those in the specified subsystem (input; 1 by default). ALL = 0 process only machines in subsystem SID ALL = 1 process all machines
Integer STATUS (2)	array of 2 elements specifying options(input). STATUS(1) include records for out-of-service machines (1 by default) STATUS(1) = 0 no STATUS(1) = 1 yes STATUS(2) 'IC" value on the first record (0 by default) STATUS(2) = 0 for API routine ReadCapCurves with IC=0 STATUS(2) = 1 for API routine ReadCapCurves with IC=1
Integer OUT	destination selection (input; 1 by default). OUT = 0 direct output to a data file specified by OFILE OUT = 1 direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 invalid OUT value IERR = 5 capability curve data is not in the working case

IERR = 6

error opening OFILE

IERR = 7

prerequisite requirements for API are not met

1.1.311. WRITERAWVERSION

Use this API to replicate the working case in the form of power flow raw data file compatible with PSSE 15 or later.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_WRITERAWVERSION 'VERNUM' OUT OFILE
```

Python command syntax:

```
ierr = writerawversion(vernum, out, ofile)
```

Fortran command syntax:

```
CALL WRITERAWVERSION(VERNUM, OUT, OFILE, IERR)
```

Where:

Integer or Character*14 VERNUM	value of OFILE version number VERNUM ='15' or later. Example: If OFILE format is to be PSSE 29.5.1: VERNUM='29' or ='29.5' or ='29.5.1' (input; no default allowed).
Integer OUT	output destination (input; 1 by default). OUT = 0 to OFILE OUT = 1 to current report device
Character*260 OFILE	name of the power flow raw data file (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid VERNUM value IERR = 2 invalid OUT value IERR = 3 memory allocation Error IERR = 4 error reading data IERR = 5 error saving temporary 'sav' file IERR = 6 error opening temporary 'sav' file IERR = 7 error deleting temporary 'sav' file IERR = 8 error opening OFILE IERR = 9 prerequisite requirements for API are not met

1.1.312. WRITESEQVERSION

This API routine is obsolete. It has been replaced by the API routine [writeseqversion_2](#).

Use this API to replicate the working case in the form of a network sequence data file compatible with PSSE 27 or later.

This API routine was first introduced in release 32.0.4.

Batch command syntax:

```
BAT_WRITESEQVERSION  'VERNUM'  OUT  OFILE
```

Python command syntax:

```
ierr = writeseqversion(vernum, out, ofile)
```

Fortran command syntax:

```
CALL WRITESEQVERSION(VERNUM, OUT, OFILE, IERR)
```

Where:

Integer or Character*14 VERNUM	value of OFILE version number VERNUM ='27' or later. Example: If OFILE format is to be PSSE 29.5.1: VERNUM='29' or ='29.5' or ='29.5.1' (input; no default allowed).
Integer OUT	output destination (input; 1 by default). OUT = 0 to OFILE OUT = 1 to current report device
Character*260 OFILE	name of the network sequence data file (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid VERNUM value IERR = 2 invalid OUT value IERR = 3 error opening OFILE IERR = 4 prerequisite requirements for API are not met

1.1.313. WRITESEQVERSION_2

Use this API to replicate the working case in the form of a network sequence data file compatible with PSSE 27 or later.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_WRITESEQVERSION_2 'VERNUM' OUT OFILE GZOPTN
```

Python command syntax:

```
ierr = writeseqversion_2(vernum, out, ofile, gzoptyn)
```

Fortran command syntax:

```
CALL WRITESEQVERSION_2(VERNUM, OUT, OFILE, GZOPTN, IERR)
```

Where:

Integer or Character*14 VERNUM	value of OFILE version number VERNUM ='27' or later. Example: If OFILE format is to be PSSE 29.5.1: VERNUM='29' or ='29.5' or ='29.5.1' (input; no default allowed).
Integer OUT	output destination (input; 1 by default). OUT = 0 to OFILE OUT = 1 to current report device
Character*260 OFILE	name of the network sequence data file (input; no default allowed).
Integer GZOPTN	generator reactance option (input; 0 by default). GZOPTN = 0 save subtransient reactance GZOPTN = 1 save transient reactance GZOPTN = 2 save synchronous reactance
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid VERNUM value IERR = 2 invalid OUT value IERR = 3 error opening OFILE IERR = 4 prerequisite requirements for API are not met

1.1.314. WRITE_OPTIONS_FILE

Use this API to save the present values of the PSSE-25 program option settings to the file psse.opt.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_WRITE_OPTIONS_FILE
```

Python command syntax:

```
ierr = write_options_file()
```

Fortran command syntax:

```
CALL WRITE_OPTIONS_FILE_API(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

1.1.315. XEQV

Use this API to build an electrical equivalent of the portion of the working case outside of a specified subsystem of the working case.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_XEQV SID ALL STATUS(1)..STATUS(6) DVAL(1) DVAL(2)
```

Python command syntax:

```
ierr = xeqv(sid, all, status, dval)
```

Fortran command syntax:

```
CALL XEQV(SID, ALL, STATUS, DVAL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses outside of subsystem SID ALL = 1 process all buses
Integer STATUS (6)	array of 6 elements specifying They are used to control equivalencing options. A value of 0 means the option is not enabled. A value of 1 means the option is enabled. They are as follows(input). STATUS(1) retain area boundary buses (0 by default) STATUS(2) retain zone boundary buses (0 by default) STATUS(3) suppress the equivalencing option for phase shifters (0 by default) STATUS(4) retain controlled buses (0 by default) STATUS(5) retain existing branches between retained buses (0 by default) STATUS(6) net load and shunt at retained buses (0 by default)
Real DVAL (2)	array of 2 elements specifying They are as follows(input). DVAL(1) minimum active or reactive power generation for retaining generator buses (0.0 by default) DVAL(2) branch threshold tolerance (10.0 by default)
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value

IERR = 3	invalid STATUS value
IERR = 4	invalid DVAL value
IERR = 5	prerequisite requirements for API are not met

1.1.316. ZONE

This API routine is obsolete. It has been replaced by the API routine [zone_2](#).

Use this API to tabulate zone totals by zone.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ZONE  SID  ALL
```

Python command syntax:

```
ierr = zone(sid, all)
```

Fortran command syntax:

```
CALL ZONENW(SID, ALL, IERR)
```

Where:

Integer SID	a valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Zone subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all zones or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only zones in zone subsystem SID
Integer IERR	ALL = 1	process all zones
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 4	prerequisite requirements for API are not met

1.1.317. ZONE_2

Use this API to tabulate zone totals by zone.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_ZONE_2  SID  ALL  OPT
```

Python command syntax:

```
ierr = zone_2(sid, all, opt)
```

Fortran command syntax:

```
CALL ZONE_2(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Zone subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all zones or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only zones in zone subsystem SID
	ALL = 1	process all zones
Integer OPT	load reporting option (input; 2 by default).	
	OPT = 1	tabulate load connected to zone buses
	OPT = 2	tabulate load assigned to the zone
	OPT = 3	tabulate three load subtotals for each zone:
		zone load connected to zone buses; zone load connected to non-zone buses; non-zone load connected to zone buses
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 4	prerequisite requirements for API are not met

1.1.318. ZONE_AREA

Use this API to tabulate zone totals by zone, along with subtotals by area.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ZONE_AREA SID ALL
```

Python command syntax:

```
ierr = zone_area(sid, all)
```

Fortran command syntax:

```
CALL ZONE_AREA(SID, ALL, IERR)
```

Where:

Integer SID	a valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Zone subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all zones or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only zones in zone subsystem SID
	ALL = 1	process all zones
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.1.319. ZONM

This API routine is obsolete. It has been replaced by the API routine [zonm_2](#).

Use this API to reassign the buses and loads in a specified subsystem of the working case from their original zone to a designated zone.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ZONM SID ALL STATUS(1) STATUS(2) IZNEW
```

Python command syntax:

```
ierr = zonm(sid, all, status, iznew)
```

Fortran command syntax:

```
CALL ZONMNW(SID, ALL, STATUS, IZNEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS (2)	array of 2 elements specifying reporting options(input). STATUS(1) zone assignments of buses to IZNEW (0 by default) STATUS(1) = 0 don't change zone assignments of buses to IZNEW STATUS(1) = 1 change zone assignments of buses to IZNEW STATUS(2) zone assignments of loads to IZNEW (0 by default) STATUS(2) = 0 Don't change zone assignments of loads to IZNEW STATUS(2) = 1 Change zone assignments of loads to IZNEW
Integer IZNEW	new zone to be assigned to specified buses and/or loads. IZNEW must be between 1 and 9999 (input; 1 by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value

IERR = 4	invalid new zone number
IERR = 5	zone table is full; cannot add zone to the working case
IERR = 6	prerequisite requirements for API are not met

1.1.320. ZONM_2

Use this API routine to reassign the buses, loads and/or induction machines in a specified subsystem of the working case from their original zone to a designated zone.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ZONM_2  SID  ALL  STATUS(1)  STATUS(2)  STATUS(3)  IZNEW
```

Python command syntax:

```
ierr = zonm_2(sid, all, status, iznew)
```

Fortran command syntax:

```
CALL ZONM_2(SID, ALL, STATUS, IZNEW, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS (3)	array of 3 elements specifying reporting options(input).	
	STATUS(1)	zone assignments of buses to IZNEW (0 by default)
	STATUS(1) = 0	leave zone assignments of buses unchanged
	STATUS(1) = 1	change zone assignments of buses to IZNEW
	STATUS(2)	zone assignments of loads to IZNEW (0 by default)
	STATUS(2) = 0	leave zone assignments of loads unchanged
	STATUS(2) = 1	change zone assignments of loads to IZNEW
	STATUS(3)	zone assignments of induction machines to IZNEW (0 by default)
	STATUS(3) = 0	leave zone assignments of induction machines unchanged
	STATUS(3) = 1	change zone assignments of induction machines to IZNEW
Integer IZNEW	new zone to be assigned to specified buses, load, and/or induction machines. IZNEW must be between 1 and 9999 (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value

IERR = 3	invalid STATUS value
IERR = 4	invalid new zone number
IERR = 5	zone table is full; cannot add zone to the working case
IERR = 6	prerequisite requirements for API are not met

1.2. Power Flow Data

This section describes the API routines used to add, modify, or remove power flow data, other than substation data.

For most categories of power flow data, there are a pair of API routines for specifying data; one of these contains "_DATA" as part of the API name, and the other contains "_CHNG" in its API name. The "_DATA" API routines may be used to add a new network element to the working case, or to modify the data of an existing network element. The "_CHNG" API routines may be used only to modify the data of an existing network element; specifying a network element that does not already exist in the working case to one of the "_CHNG" API routines is treated as a fatal error by the API routine.

Generally, when an API is adding a new element to the working case, data items that are defaulted are set to the value listed in the data item's description. When an API is modifying the data of an existing element, defaulted data items are unchanged.

1.2.1. AREA_DATA

Use this API to modify area data in the working case (see PSSE Program Operation Manual, Areas, Zones and Owners).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_AREA_DATA IAREA IBUS REALAR(1) REALAR(2) 'ARNAME'
```

Python command syntax:

```
ierr = area_data(iarea, ibus, realar, arname)
```

Fortran command syntax:

```
CALL AREA_API_2(IAREA, IBUS, REALAR, ARNAME, IERR)
```

Where:

Integer IAREA	area number between 1 and 9999 (input; no default allowed).
Integer IBUS	area slack bus number (input; no default allowed).
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) PDES, desired MW area interchange (0.0 by default)
	REALAR(2) PTOL, desired MW interchange tolerance (0.1 * SBASE by default; for example, when system base MVA is 100.0, the default value of PTOL is 10 MW)
Character*12 ARNAME	area name (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred

IERR = 1	invalid area number
IERR = 2	area table is full
IERR = 3	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Area slack bus not found. - Slack bus is not in this area. - No plant at slack bus. - Type code of slack bus is not 2 or 3. - A Type 3 bus is in the area but it is not the area slack bus. - No equipment is assigned to area

1.2.2. BRANCH_CHNG

This API routine is obsolete. It has been replaced by the API routine [branch_chng_3](#).

Use this API routine to modify the data of an existing non-transformer branch in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_BRANCH_CHNG  IBUS  JBUS  'CKT'  INTGAR(1) .. INTGAR(6)
                  REALAR(1) .. REALAR(15)
```

Python command syntax:

```
ierr = branch_chng(ibus, jbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL BRANCH_CHNG(IBUS, JBUS, CKT, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) ST, branch status (alias is ST) (1 by default)
	INTGAR(2) METBUS, metered end bus number (IBUS or JBUS) (alias is METBUS) (IBUS by default)
	INTGAR(3) O1, first owner number (alias is O1) (owner of bus IBUS by default)
	INTGAR(4) O2, second owner number (alias is O2) (0 by default)
	INTGAR(5) O3, third owner number (alias is O3) (0 by default)
	INTGAR(6) O4, fourth owner number (alias is O4) (0 by default)
Real REALAR (15)	array of 15 elements specifying (input).
	REALAR(1) R, nominal branch resistance (alias is R) (0.0 by default)
	REALAR(2) X, nominal branch reactance (alias is X) (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALAR(3) B, total line charging (alias is B) (0.0 by default)
	REALAR(4) RATEA, rating set A line rating (alias is RATEA) (0.0 by default)

	REALAR(5)	RATEB, rating set B line rating (alias is RATEB) (0.0 by default)
	REALAR(6)	RATEC, rating set C line rating (alias is RATEC) (0.0 by default)
	REALAR(7)	GI, real line shunt at bus IBUS end (alias is GI) (0.0 by default)
	REALAR(8)	BI, reactive line shunt at bus IBUS end (alias is BI) (0.0 by default)
	REALAR(9)	GJ, real line shunt at bus JBUS end (alias is GJ) (0.0 by default)
	REALAR(10)	BJ, reactive line shunt at bus JBUS end (alias is BJ) (0.0 by default)
	REALAR(11)	LEN, line length (alias is LEN) (0.0 by default)
	REALAR(12)	F1, first owner fraction (alias is F1) (1.0 by default)
	REALAR(13)	F2, second owner fraction (alias is F2) (1.0 by default)
	REALAR(14)	F3, third owner fraction (alias is F3) (1.0 by default)
	REALAR(15)	F4, fourth owner fraction (alias is F4) (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a two-winding transformer
	IERR = 9	branch not found
	IERR = 10	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - branch reactance is 0.0 - line length is negative - zero impedance line table is full; branch is treated as a normal line - invalid metered end bus - invalid branch status - invalid owner number - invalid ownership fraction - no ownership data is specified - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - branch is no longer treated as a zero impedance line - owner table is full

1.2.3. BRANCH_CHNG_3

Use this API routine to modify the data of an existing non-transformer branch in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_BRANCH_CHNG_3  IBUS JBUS CKT INTGAR(1)..INTGAR(6)
REALAR(1)..REALAR(12) RATINGS(1)..RATINGS(12) NAMEAR
```

Python command syntax:

```
ierr = branch_chng_3(ibus, jbus, ckt, intgar, realar, ratings, namear)
```

Fortran command syntax:

```
CALL BRANCH_CHNG_3(IBUS, JBUS, CKT, INTGAR, REALAR, RATINGS, NAMEAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) ST, branch status (alias is ST) (1 by default)
	INTGAR(2) METBUS, metered end bus number (IBUS or JBUS) (alias is METBUS) (IBUS by default)
	INTGAR(3) O1, first owner number (alias is O1) (owner of bus IBUS by default)
	INTGAR(4) O2, second owner number (alias is O2) (0 by default)
	INTGAR(5) O3, third owner number (alias is O3) (0 by default)
	INTGAR(6) O4, fourth owner number (alias is O4) (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).
	REALAR(1) R, nominal branch resistance (alias is R) (0.0 by default)
	REALAR(2) X, nominal branch reactance (alias is X) (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALAR(3) B, total line charging (alias is B) (0.0 by default)
	REALAR(4) GI, real line shunt at bus IBUS end (alias is GI) (0.0 by default)
	REALAR(5) BI, reactive line shunt at bus IBUS end (alias is BI) (0.0 by default)
	REALAR(6) GJ, real line shunt at bus JBUS end (alias is GJ) (0.0 by default)

	REALAR(7)	BJ, reactive line shunt at bus JBUS end (alias is BJ) (0.0 by default)
	REALAR(8)	LEN, line length (alias is LEN) (0.0 by default)
	REALAR(9)	F1, first owner fraction (alias is F1) (1.0 by default)
	REALAR(10)	F2, second owner fraction (alias is F2) (1.0 by default)
	REALAR(11)	F3, third owner fraction (alias is F3) (1.0 by default)
	REALAR(12)	F4, fourth owner fraction (alias is F4) (1.0 by default)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1, rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2, rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3, rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4, rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5, rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6, rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7, rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8, rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9, rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10, rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11, rating set 11 line rating (alias is RATE11) (0.0 by default)
	RATINGS(12)	RATE12, rating set 12 line rating (alias is RATE12) (0.0 by default)
Character*40 NAMEAR	branch name (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a two-winding transformer
	IERR = 4	branch from a bus to itself

IERR = 5	blank circuit identifier is invalid
IERR = 6	circuit identifier may not start with &
IERR = 7	branch table is full
IERR = 8	branch ownership table is full
IERR = 9	branch not found
IERR = 10	prerequisite requirements for API are not met
IERR = 11	branch exists but it is a system switching device
IERR = 13	node-breaker terminal connection table is full
IERR = -1	data error, warning and information messages; one or more of: - branch reactance is 0.0 - line length is negative - zero impedance line table is full; branch is treated as a normal line - invalid metered end bus - invalid branch status - invalid owner number - invalid ownership fraction - no ownership data is specified - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - branch is no longer treated as a zero impedance line - owner table is full - rating is negative - branch exists but is a system switching device - name is already assigned to a branch - name contains invalid characters - non-transformer branch connects buses with different base voltages

1.2.4. BRANCH_DATA

This API routine is obsolete. It has been replaced by the API routine [branch_data_3](#).

Use this API to modify the data of an existing non-transformer branch in the working case or to add a new non-transformer branch to the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BRANCH_DATA  IBUS  JBUS  'CKT'  INTGAR(1) .. INTGAR(6)
                  REALAR(1) .. REALAR(15)
```

Python command syntax:

```
ierr = branch_data(ibus, jbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL BRANCH_API_2(IBUS, JBUS, CKT, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) ST, branch status (alias is ST) (1 by default)
	INTGAR(2) METBUS, metered end bus number (IBUS or JBUS) (alias is METBUS) (IBUS by default)
	INTGAR(3) O1, first owner number (alias is O1) (owner of bus IBUS by default)
	INTGAR(4) O2, second owner number (alias is O2) (0 by default)
	INTGAR(5) O3, third owner number (alias is O3) (0 by default)
	INTGAR(6) O4, fourth owner number (alias is O4) (0 by default)
Real REALAR (15)	array of 15 elements specifying (input).
	REALAR(1) R, nominal branch resistance (alias is R) (0.0 by default)
	REALAR(2) X, nominal branch reactance (alias is X) (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALAR(3) B, total line charging (alias is B) (0.0 by default)
	REALAR(4) RATEA, rating set A line rating (alias is RATEA) (0.0 by default)

	REALAR(5)	RATEB, rating set B line rating (alias is RATEB) (0.0 by default)
	REALAR(6)	RATEC, rating set C line rating (alias is RATEC) (0.0 by default)
	REALAR(7)	GI, real line shunt at bus IBUS end (alias is GI) (0.0 by default)
	REALAR(8)	BI, reactive line shunt at bus IBUS end (alias is BI) (0.0 by default)
	REALAR(9)	GJ, real line shunt at bus JBUS end (alias is GJ) (0.0 by default)
	REALAR(10)	BJ, reactive line shunt at bus JBUS end (alias is BJ) (0.0 by default)
	REALAR(11)	LEN, line length (alias is LEN) (0.0 by default)
	REALAR(12)	F1, first owner fraction (alias is F1) (1.0 by default)
	REALAR(13)	F2, second owner fraction (alias is F2) (1.0 by default)
	REALAR(14)	F3, third owner fraction (alias is F3) (1.0 by default)
	REALAR(15)	F4, fourth owner fraction (alias is F4) (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a two-winding transformer
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &
	IERR = 7	branch table is full
	IERR = 8	branch ownership table is full
	IERR = 10	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - branch reactance is 0.0 - line length is negative - zero impedance line table is full; branch is treated as a normal line - invalid metered end bus - invalid branch status - invalid owner number - invalid ownership fraction - no ownership data is specified - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - branch is no longer treated as a zero impedance line - owner table is full

1.2.5. BRANCH_DATA_3

Use this API to modify the data of an existing non-transformer branch in the working case or to add a new non-transformer branch to the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_BRANCH_DATA_3  IBUS JBUS CKT INTGAR(1)..INTGAR(6)
REALAR(1)..REALAR(12) RATINGS(1)..RATINGS(12) NAMEAR
```

Python command syntax:

```
ierr = branch_data_3(ibus, jbus, ckt, intgar, realar, ratings, namear)
```

Fortran command syntax:

```
CALL BRANCH_DATA_3(IBUS, JBUS, CKT, INTGAR, REALAR, RATINGS, NAMEAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) ST, branch status (alias is ST) (1 by default)
	INTGAR(2) METBUS, metered end bus number (IBUS or JBUS) (alias is METBUS) (IBUS by default)
	INTGAR(3) O1, first owner number (alias is O1) (owner of bus IBUS by default)
	INTGAR(4) O2, second owner number (alias is O2) (0 by default)
	INTGAR(5) O3, third owner number (alias is O3) (0 by default)
	INTGAR(6) O4, fourth owner number (alias is O4) (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).
	REALAR(1) R, nominal branch resistance (alias is R) (0.0 by default)
	REALAR(2) X, nominal branch reactance (alias is X) (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALAR(3) B, total line charging (alias is B) (0.0 by default)
	REALAR(4) GI, real line shunt at bus IBUS end (alias is GI) (0.0 by default)
	REALAR(5) BI, reactive line shunt at bus IBUS end (alias is BI) (0.0 by default)

	REALAR(6)	GJ, real line shunt at bus JBUS end (alias is GJ) (0.0 by default)
	REALAR(7)	BJ, reactive line shunt at bus JBUS end (alias is BJ) (0.0 by default)
	REALAR(8)	LEN, line length (alias is LEN) (0.0 by default)
	REALAR(9)	F1, first owner fraction (alias is F1) (1.0 by default)
	REALAR(10)	F2, second owner fraction (alias is F2) (1.0 by default)
	REALAR(11)	F3, third owner fraction (alias is F3) (1.0 by default)
	REALAR(12)	F4, fourth owner fraction (alias is F4) (1.0 by default)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1, rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2, rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3, rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4, rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5, rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6, rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7, rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8, rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9, rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10, rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11, rating set 11 line rating (alias is RATE11) (0.0 by default)
	RATINGS(12)	RATE12, rating set 12 line rating (alias is RATE12) (0.0 by default)
Character*40 NAMEAR	branch name (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters

IERR = 3	branch exists but it is a two-winding transformer
IERR = 4	branch from a bus to itself
IERR = 5	blank circuit identifier is invalid
IERR = 6	circuit identifier may not start with &
IERR = 7	branch table is full
IERR = 8	branch ownership table is full
IERR = 10	prerequisite requirements for API are not met
IERR = 11	branch exists but it is a system switching device
IERR = 13	node-breaker terminal connection table is full
IERR = -1	data error, warning and information messages; one or more of: - branch reactance is 0.0 - line length is negative - zero impedance line table is full; branch is treated as a normal line - invalid metered end bus - invalid branch status - invalid owner number - invalid ownership fraction - no ownership data is specified - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - branch is no longer treated as a zero impedance line - owner table is full - rating is negative - name already assigned to a branch - name contains invalid characters - non-transformer branch connects buses with different base voltages

1.2.6. BUS_CHNG_3

This API routine is obsolete. It has been replaced by the API routine [bus_chng_4](#).

Use this API routine to modify the data of an existing bus in the working case (see PSSE Program Operation Manual, Bus Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_BUS_CHNG_3  IBUS  INTGAR(1)..INTGAR(4)  REALAR(1)..REALAR(7)  'NAME'
```

Python command syntax:

```
ierr = bus_chng_3(ibus, intgar, realar, name)
```

Fortran command syntax:

```
CALL BUS_CHNG_3(IBUS, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).														
Integer INTGAR (4)	array of 4 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>IDE, bus type code (1 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>AREA, area number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>ZONE, zone number (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> </table>	INTGAR(1)	IDE, bus type code (1 by default)	INTGAR(2)	AREA, area number (1 by default)	INTGAR(3)	ZONE, zone number (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)						
INTGAR(1)	IDE, bus type code (1 by default)														
INTGAR(2)	AREA, area number (1 by default)														
INTGAR(3)	ZONE, zone number (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
Real REALAR (7)	array of 7 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>BASKV, bus base voltage in kV (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>VM, bus voltage magnitude in pu (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>VA, bus voltage phase angle (0.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(5)</td><td>NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)</td></tr> <tr> <td>REALAR(6)</td><td>EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(7)</td><td>EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)</td></tr> </table>	REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)	REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)	REALAR(3)	VA, bus voltage phase angle (0.0 by default)	REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)	REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)	REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)	REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)
REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)														
REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)														
REALAR(3)	VA, bus voltage phase angle (0.0 by default)														
REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)														
REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)														
Character*12 NAME	bus name (input; blank by default).														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid bus number</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	invalid bus number								
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	invalid bus number														

IERR = 3	working case is not initialized
IERR = 4	bus not found
IERR = 5	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the area swing for its old area. - Bus type code is 3 but is not the swing bus for its area. - Area table is full. - Zone table is full. - Owner table is full. - High voltage limit is not greater than the low voltage limit. - Normal voltage limit is less restrictive than the emergency limit

1.2.7. BUS_CHNG_4

Use this API routine to modify the data of an existing bus in the working case (see PSSE Program Operation Manual, Bus Data).

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_BUS_CHNG_4  IBUS INODE INTGAR(1)..INTGAR(4)  REALAR(1)..REALAR(7)
'NAME'
```

Python command syntax:

```
ierr = bus_chng_4(ibus, inode, intgar, realar, name)
```

Fortran command syntax:

```
CALL BUS_CHNG_4(IBUS, INODE, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).														
Integer INODE	bus section node number (input; no default allowed).														
Integer INTGAR (4)	array of 4 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>IDE, bus type code (1 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>AREA, area number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>ZONE, zone number (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> </table>	INTGAR(1)	IDE, bus type code (1 by default)	INTGAR(2)	AREA, area number (1 by default)	INTGAR(3)	ZONE, zone number (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)						
INTGAR(1)	IDE, bus type code (1 by default)														
INTGAR(2)	AREA, area number (1 by default)														
INTGAR(3)	ZONE, zone number (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
Real REALAR (7)	array of 7 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>BASKV, bus base voltage in kV (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>VM, bus voltage magnitude in pu (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>VA, bus voltage phase angle (0.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(5)</td><td>NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)</td></tr> <tr> <td>REALAR(6)</td><td>EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(7)</td><td>EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)</td></tr> </table>	REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)	REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)	REALAR(3)	VA, bus voltage phase angle (0.0 by default)	REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)	REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)	REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)	REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)
REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)														
REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)														
REALAR(3)	VA, bus voltage phase angle (0.0 by default)														
REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)														
REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)														
Character*12 NAME	bus name (input; blank by default).														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid bus number</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	invalid bus number								
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	invalid bus number														

IERR = 3	working case is not initialized
IERR = 4	bus not found
IERR = 5	invalid node number
IERR = 6	bus does not belong to a substation
IERR = 7	inode is not found in the substation
IERR = 8	inode is not connected to any bus section of bus
IERR = 10	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the area swing for its old area. - Bus type code is 3 but is not the swing bus for its area. - Area table is full. - Zone table is full. - Owner table is full. - High voltage limit is not greater than the low voltage limit. - Normal voltage limit is less restrictive than the emergency limit

1.2.8. BUS_DATA

This API routine is obsolete. It has been replaced by the API routine [bus_data_2](#).

Use this API to modify the data of an existing bus in the working case or to add a new bus to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BUS_DATA  IBUS  INTGAR(1)..INTGAR(4)  REALAR(1)..REALAR(5)  'NAME'
```

Python command syntax:

```
ierr = bus_data(ibus, intgar, realar, name)
```

Fortran command syntax:

```
CALL BUS_API(IBUS, INTGAR, REALAR, NAME, IERR, NERR)
```

Where:

Integer IBUS	bus number (input).														
Integer INTGAR (4)	array of 4 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>IDE, bus type code</td></tr> <tr> <td>INTGAR(2)</td><td>AREA, area number</td></tr> <tr> <td>INTGAR(3)</td><td>ZONE, zone number</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number</td></tr> </table>	INTGAR(1)	IDE, bus type code	INTGAR(2)	AREA, area number	INTGAR(3)	ZONE, zone number	INTGAR(4)	OWNER, owner number						
INTGAR(1)	IDE, bus type code														
INTGAR(2)	AREA, area number														
INTGAR(3)	ZONE, zone number														
INTGAR(4)	OWNER, owner number														
Real REALAR (5)	array of 5 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>GL, fixed shunt admittance (conductance)</td></tr> <tr> <td>REALAR(2)</td><td>BL, fixed shunt admittance (susceptance)</td></tr> <tr> <td>REALAR(3)</td><td>BASKV, bus base voltage in kV</td></tr> <tr> <td>REALAR(4)</td><td>VM, bus voltage magnitude in pu</td></tr> <tr> <td>REALAR(5)</td><td>VA, bus voltage phase angle</td></tr> </table>	REALAR(1)	GL, fixed shunt admittance (conductance)	REALAR(2)	BL, fixed shunt admittance (susceptance)	REALAR(3)	BASKV, bus base voltage in kV	REALAR(4)	VM, bus voltage magnitude in pu	REALAR(5)	VA, bus voltage phase angle				
REALAR(1)	GL, fixed shunt admittance (conductance)														
REALAR(2)	BL, fixed shunt admittance (susceptance)														
REALAR(3)	BASKV, bus base voltage in kV														
REALAR(4)	VM, bus voltage magnitude in pu														
REALAR(5)	VA, bus voltage phase angle														
Character*12 NAME	bus name (input).														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid bus number</td></tr> <tr> <td>IERR = 2</td><td>bus table is full</td></tr> <tr> <td>IERR = 3</td><td>working case is not initialized</td></tr> <tr> <td>IERR = 5</td><td>prerequisite requirements for API are not met</td></tr> <tr> <td>IERR = -1</td><td>data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	invalid bus number	IERR = 2	bus table is full	IERR = 3	working case is not initialized	IERR = 5	prerequisite requirements for API are not met	IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	invalid bus number														
IERR = 2	bus table is full														
IERR = 3	working case is not initialized														
IERR = 5	prerequisite requirements for API are not met														
IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the														

area swing for its old area. - Bus type code is
3 but is not the swing bus for its area. - Area
table is full. - Zone table is full. - Owner table
is full

Integer NERR

number of entries in PBUF02 containing error messages (output).

1.2.9. BUS_DATA_2

This API routine is obsolete. It has been replaced by the API routine [bus_data_3](#).

Use this API to modify the data of an existing bus in the working case or to add a new bus to the working case (see PSSE Program Operation Manual, Bus Data).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_BUS_DATA_2  IBUS  INTGAR(1)..INTGAR(4)  REALAR(1)..REALAR(3)  'NAME'
```

Python command syntax:

```
ierr = bus_data_2(ibus, intgar, realar, name)
```

Fortran command syntax:

```
CALL BUS_API_2(IBUS, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).														
Integer INTGAR (4)	array of 4 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>IDE, bus type code (1 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>AREA, area number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>ZONE, zone number (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> </table>	INTGAR(1)	IDE, bus type code (1 by default)	INTGAR(2)	AREA, area number (1 by default)	INTGAR(3)	ZONE, zone number (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)						
INTGAR(1)	IDE, bus type code (1 by default)														
INTGAR(2)	AREA, area number (1 by default)														
INTGAR(3)	ZONE, zone number (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
Real REALAR (3)	array of 3 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>BASKV, bus base voltage in kV (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>VM, bus voltage magnitude in pu (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>VA, bus voltage phase angle (0.0 by default)</td></tr> </table>	REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)	REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)	REALAR(3)	VA, bus voltage phase angle (0.0 by default)								
REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)														
REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)														
REALAR(3)	VA, bus voltage phase angle (0.0 by default)														
Character*12 NAME	bus name (input; blank by default).														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid bus number</td></tr> <tr> <td>IERR = 2</td><td>bus table is full</td></tr> <tr> <td>IERR = 3</td><td>working case is not initialized</td></tr> <tr> <td>IERR = 5</td><td>prerequisite requirements for API are not met</td></tr> <tr> <td>IERR = -1</td><td>data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	invalid bus number	IERR = 2	bus table is full	IERR = 3	working case is not initialized	IERR = 5	prerequisite requirements for API are not met	IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	invalid bus number														
IERR = 2	bus table is full														
IERR = 3	working case is not initialized														
IERR = 5	prerequisite requirements for API are not met														
IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the														

area swing for its old area. - Bus type code is 3 but is not the swing bus for its area. - Area table is full. - Zone table is full. - Owner table is full

1.2.10. BUS_DATA_3

This API routine is obsolete. It has been replaced by the API routine [bus_data_4](#).

Use this API routine to modify the data of an existing bus in the working case, or to add a new bus to the working case (see PSSE Program Operation Manual, Bus Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_BUS_DATA_3  IBUS  INTGAR(1)..INTGAR(4)  REALAR(1)..REALAR(7)  'NAME'
```

Python command syntax:

```
ierr = bus_data_3(ibus, intgar, realar, name)
```

Fortran command syntax:

```
CALL BUS_API_3(IBUS, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).														
Integer INTGAR (4)	array of 4 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>IDE, bus type code (1 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>AREA, area number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>ZONE, zone number (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> </table>	INTGAR(1)	IDE, bus type code (1 by default)	INTGAR(2)	AREA, area number (1 by default)	INTGAR(3)	ZONE, zone number (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)						
INTGAR(1)	IDE, bus type code (1 by default)														
INTGAR(2)	AREA, area number (1 by default)														
INTGAR(3)	ZONE, zone number (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
Real REALAR (7)	array of 7 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>BASKV, bus base voltage in kV (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>VM, bus voltage magnitude in pu (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>VA, bus voltage phase angle (0.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(5)</td><td>NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)</td></tr> <tr> <td>REALAR(6)</td><td>EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(7)</td><td>EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)</td></tr> </table>	REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)	REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)	REALAR(3)	VA, bus voltage phase angle (0.0 by default)	REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)	REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)	REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)	REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)
REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)														
REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)														
REALAR(3)	VA, bus voltage phase angle (0.0 by default)														
REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)														
REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)														
Character*12 NAME	bus name (input; blank by default).														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid bus number</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	invalid bus number								
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	invalid bus number														

IERR = 2	bus table is full
IERR = 3	working case is not initialized
IERR = 5	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the area swing for its old area. - Bus type code is 3 but is not the swing bus for its area. - Area table is full. - Zone table is full. - Owner table is full. - High voltage limit is not greater than the low voltage limit. - Normal voltage limit is less restrictive than the emergency limit

1.2.11. BUS_DATA_4

Use this API routine to modify the data of an existing bus in the working case, or to add a new bus to the working case (see PSSE Program Operation Manual, Bus Data).

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_BUS_DATA_4  IBUS INODE INTGAR(1)..INTGAR(4)  REALAR(1)..REALAR(7)
'NAME'
```

Python command syntax:

```
ierr = bus_data_4(ibus, inode, intgar, realar, name)
```

Fortran command syntax:

```
CALL BUS_API_4(IBUS, INODE, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).														
Integer INODE	bus section node number (input; no default allowed).														
Integer INTGAR (4)	array of 4 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>IDE, bus type code (1 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>AREA, area number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>ZONE, zone number (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> </table>	INTGAR(1)	IDE, bus type code (1 by default)	INTGAR(2)	AREA, area number (1 by default)	INTGAR(3)	ZONE, zone number (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)						
INTGAR(1)	IDE, bus type code (1 by default)														
INTGAR(2)	AREA, area number (1 by default)														
INTGAR(3)	ZONE, zone number (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
Real REALAR (7)	array of 7 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>BASKV, bus base voltage in kV (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>VM, bus voltage magnitude in pu (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>VA, bus voltage phase angle (0.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(5)</td><td>NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)</td></tr> <tr> <td>REALAR(6)</td><td>EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)</td></tr> <tr> <td>REALAR(7)</td><td>EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)</td></tr> </table>	REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)	REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)	REALAR(3)	VA, bus voltage phase angle (0.0 by default)	REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)	REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)	REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)	REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)
REALAR(1)	BASKV, bus base voltage in kV (0.0 by default)														
REALAR(2)	VM, bus voltage magnitude in pu (1.0 by default)														
REALAR(3)	VA, bus voltage phase angle (0.0 by default)														
REALAR(4)	NMAXV, normal bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(5)	NMINV, normal bus voltage magnitude low limit in pu (0.9 by default)														
REALAR(6)	EMAXV, emergency bus voltage magnitude high limit in pu (1.1 by default)														
REALAR(7)	EMINV, emergency bus voltage magnitude low limit in pu (0.9 by default)														
Character*12 NAME	bus name (input; blank by default).														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>invalid bus number</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	invalid bus number								
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	invalid bus number														

IERR = 2	bus table is full
IERR = 3	working case is not initialized
IERR = 5	invalid node number
IERR = 6	bus does not belong to a substation
IERR = 7	inode is not found in the substation
IERR = 8	inode is not connected to any bus section of bus
IERR = 9	inode must be 0 for bus not in the case
IERR = 10	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid base voltage. - Invalid bus type code. - Invalid area, zone or owner number. - Bus name is more than 12 characters. - New area number but bus is the area swing for its old area. - Bus type code is 3 but is not the swing bus for its area. - Area table is full. - Zone table is full. - Owner table is full. - High voltage limit is not greater than the low voltage limit. - Normal voltage limit is less restrictive than the emergency limit

1.2.12. BUS_NUMBER

Use this API to change the bus number of an existing bus in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BUS_NUMBER IBUS NEWBUS
```

Python command syntax:

```
ierr = bus_number(ibus, newbus)
```

Fortran command syntax:

```
CALL BUS_NUMBER_API_2(IBUS, NEWBUS, IERR)
```

Where:

Integer IBUS	current bus number of the bus for which the number is to be changed (input; no default allowed).	
Integer NEWBUS	new bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	invalid new bus number
	IERR = 3	bus number NEWBUS is already assigned to another bus
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - None

1.2.13. CASE_TITLE_DATA

Use this API to change the two line case title in the working case (see PSSE Program Operation Manual, Case Identification Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CASE_TITLE_DATA 'LINE1' 'LINE2'
```

Python command syntax:

```
ierr = case_title_data(line1, line2)
```

Fortran command syntax:

```
CALL CASE_TITLE_API_2(LINE1, LINE2, IERR)
```

Where:

Character*60 LINE1	first title line (input; unchanged).
Character*60 LINE2	second title line (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information mes-
	sages; one or more of: - Title line exceeds 60
	characters

1.2.14. CASOLUTION_PARAMETERS

Use this API to modify the contingency analysis solution parameters.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CASOLUTION_PARAMETERS  INTGAR(1)..INTGAR(9)  REALAR(1)..REALAR(4)
```

Python command syntax:

```
ierr = casolution_parameters(intgar, realar)
```

Fortran command syntax:

```
CALL CASOLUTION_PARAMETER_API(INTGAR, REALAR, IERR)
```

Where:

Integer INTGAR (9)	array of 9 elements specifying (input).	
	INTGAR(1)	RATBAS, base case rating (1 by default)
	INTGAR(2)	RATCNT, contingency case rating (2 by default)
	INTGAR(3)	MWRATE, Convert MVA to MW for DC solution (1 by default)
	INTGAR(4)	VLTBAS, base case voltage limit (1 by default)
	INTGAR(5)	VLTCNT, contingency case voltage limit (2 by default)
	INTGAR(6)	SCRCAS, enable AC contingency case screening (0 by default)
	INTGAR(7)	INCLOS, include loss estimates in DC solution (0 by default)
	INTGAR(8)	ROSOLN, Enable Robust Power flow solution for non-converged cases (0 by default)
	INTGAR(9)	BASLOD, Base loaded machine option (0 by default)
Real REALAR (4)	array of 4 elements specifying (input).	
	REALAR(1)	RATPCT, percent of loading (100 by default)
	REALAR(2)	LOADCT, loading cutoff (2 by default)
	REALAR(3)	CHAGMW, flow change cutoff in MW (100 by default)
	REALAR(4)	TOTGEN, Total generation dispatch limit (10000 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	prerequisite requirements for API are not met

1.2.15. CASOLUTION_PARAMETERS_2

Use this API to modify the contingency analysis solution parameters.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CASOLUTION_PARAMETERS  INTGAR(1)..INTGAR(10)  REALAR(1)..REALAR(4)
```

Python command syntax:

```
ierr = casolution_parameters_2(intgar, realar)
```

Fortran command syntax:

```
CALL CASOLUTION_PARAMETER_API_2(INTGAR, REALAR, IERR)
```

Where:

Integer INTGAR (10)	array of 10 elements specifying (input).
INTGAR(1)	RATBAS, base case rating (1 by default)
INTGAR(2)	RATCNT, contingency case rating (2 by default)
INTGAR(3)	MWRATE, Convert MVA to MW for DC solution (1 by default)
INTGAR(4)	VLTBAS, base case voltage limit (1 by default)
INTGAR(5)	VLTCNT, contingency case voltage limit (2 by default)
INTGAR(6)	SCRCAS, enable AC contingency case screening (0 by default)
INTGAR(7)	INCLOS, include loss estimates in DC solution (0 by default)
INTGAR(8)	ROSOLN, Enable Robust Power flow solution for non-converged cases (0 by default)
INTGAR(9)	BASLOD, Base loaded machine option (0 by default)
INTGAR(10)	RASFLG, enable RAS (0 by default)
Real REALAR (4)	array of 4 elements specifying (input).
REALAR(1)	RATPCT, percent of loading (100 by default)
REALAR(2)	LOADCT, loading cutoff (2 by default)
REALAR(3)	CHAGMW, flow change cutoff in MW (100 by default)
REALAR(4)	TOTGEN, Total generation dispatch limit (10000 by default)
Integer IERR	error code (output).
IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	prerequisite requirements for API are not met

1.2.16. EXTR

Use this API to purge specified buses and all branches connected to them from the working case (activity EXTR).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_EXTR SID ALL STATUS(1) STATUS(2)
```

Python command syntax:

```
ierr = extr(sid, all, status)
```

Fortran command syntax:

```
CALL EXTRNW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (when ALL is 0) (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; 0 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS (2)	array of 2 elements specifying They are used to control subsystem removal options. A value of 0 means the option is not enabled. A value of 1 means the option is enabled. They are as follows(input).	
	STATUS(1)	remove generator entries for out-of-service plants (0 by default)
	STATUS(2)	change codes of boundary buses (0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	prerequisite requirements for API are not met

1.2.17. FACTS_CHNG_2

This API routine is obsolete. It has been replaced by the API routine [facts_chng_3](#).

Use this API routine to modify the data of an existing FACTS device in the working case (see PSSE Program Operation Manual, FACTS Device Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_FACTS_CHNG_2  'NAME'  INTGAR(1)..INTGAR(6)  REALAR(1)..REALAR(13)
  'MNAME'
```

Python command syntax:

```
ierr, realaro = facts_chng_2(name, intgar, realari, mname)
```

Fortran command syntax:

```
CALL FACTS_CHNG_2(NAME, INTGAR, REALAR, MNAME, IERR)
```

Where:

Character*12 NAME	name of the FACTS device (input; no default allowed).												
Integer INTGAR (6)	array of 6 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>I, sending end bus number (no default allowed)</td></tr> <tr> <td>INTGAR(2)</td><td>J, terminal end bus number (0 for STATCON) (0 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>MODE, control mode (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)</td></tr> <tr> <td>INTGAR(6)</td><td>REMOT, remote bus number (0 for sending end bus) (0 by default)</td></tr> </table>	INTGAR(1)	I, sending end bus number (no default allowed)	INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)	INTGAR(3)	MODE, control mode (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)	INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)	INTGAR(6)	REMOT, remote bus number (0 for sending end bus) (0 by default)
INTGAR(1)	I, sending end bus number (no default allowed)												
INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)												
INTGAR(3)	MODE, control mode (1 by default)												
INTGAR(4)	OWNER, owner number (1 by default)												
INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)												
INTGAR(6)	REMOT, remote bus number (0 for sending end bus) (0 by default)												
Real REALAR (19)	(first thirteen are input values; last six are output values) (input (output)).												
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input). <table> <tr> <td>REALARI(1)</td><td>PDES, desired real power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(2)</td><td>QDES, desired reactive power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(3)</td><td>VSET, sending bus voltage setpoint (1.0 by default)</td></tr> <tr> <td>REALARI(4)</td><td>SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)</td></tr> </table>	REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)	REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)	REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)	REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)				
REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)												
REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)												
REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)												
REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)												

	REALARI(5)	TRMX, maximum bridge real power transfer (99.99 * SBASE by default)
	REALARI(6)	VTMN, minimum terminal bus voltage magnitude (0.9 by default)
	REALARI(7)	VTMX, maximum terminal bus voltage magnitude (1.1 by default)
	REALARI(8)	VSMX, maximum series voltage magnitude (1.0 by default)
	REALARI(9)	IMX, maximum series current (MVA at rated voltage) (0.0 by default)
	REALARI(10)	LINX, pu reactance of temporary series element (0.05 by default)
	REALARI(11)	RMPCT, percent of contributed reactive power (100.0 by default)
	REALARI(12)	SET1, real component of constant Z (MODE = 3), magnitude of constant V (MODE = 4), or VD (MODE = 7 or 8) (0.0 by default)
	REALARI(13)	SET2, imaginary component of constant Z (MODE = 3), angle of constant V (MODE = 4), or VQ (MODE = 7 or 8) (0.005 by default when MODE = 3; 0.0 otherwise)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(14) through REALAR(19) as described above(output).	
	REALARO(1)	real component of present effective series Z (returned)
	REALARO(2)	imaginary component of present effective series Z (returned)
	REALARO(3)	magnitude of present series voltage, FDVREF reference (returned)
	REALARO(4)	le of present series voltage, FDVREF reference (returned)
	REALARO(5)	real component of present series voltage, FDVREF reference (returned)
	REALARO(6)	imaginary component of present series voltage, FDVREF reference (returned)
Character*12 MNAME	name of the FACTS device that is the master device for this IPFC slave device (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 2	no sending end bus is specified
	IERR = 3	bus not found
	IERR = 4	the same bus is specified for the sending and terminal end buses
	IERR = 5	blank FACTS device name is invalid
	IERR = 6	FACTS device not found

IERR = 7

IERR = -1

prerequisite requirements for API are not met
warnings - one or more of: - Invalid FACTS device control mode. - Invalid owner number. - Invalid series voltage reference code. - Regulated bus not found. - Shunt element specified as remotely regulating itself. - Type code of regulated bus is not 1 or 2. - Shunt element voltage setpoint must be positive. - Terminal bus voltage limit must be positive. - VT-MX is less than VTMN. - Series voltage limit must be positive. - Shunt current limit must not be negative. - Bridge real power transfer limit must not be negative. - Series current limit must not be negative. - Series reactance must be positive. - Shunt current limit is not 0.0 for an IPFC device. - Bridge real power transfer limit is not 0.0 for an IPFC device. - Impedance setpoint has reactance of 0.0. - RMPCT is not positive. - Master IPFC FACTS device not found. - Bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Owner table is full

1.2.18. FACTS_CHNG_3

Use this API routine to modify the data of an existing FACTS device in the working case (see PSSE Program Operation Manual, FACTS Device Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_FACTS_CHNG_3  'NAME'  INTGAR(1)..INTGAR(7)  REALAR(1)..REALAR(13)
  'MNAME'
```

Python command syntax:

```
ierr, realaro = facts_chng_3(name, intgar, realari, mname)
```

Fortran command syntax:

```
CALL FACTS_CHNG_3(NAME, INTGAR, REALAR, MNAME, IERR)
```

Where:

Character*12 NAME	name of the FACTS device (input; no default allowed).														
Integer INTGAR (7)	array of 7 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>I, sending end bus number (no default allowed)</td></tr> <tr> <td>INTGAR(2)</td><td>J, terminal end bus number (0 for STATCON) (0 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>MODE, control mode (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)</td></tr> <tr> <td>INTGAR(6)</td><td>IREG, regulated bus number (0 by default)</td></tr> <tr> <td>INTGAR(7)</td><td>NODE, regulated node number (0 by default)</td></tr> </table>	INTGAR(1)	I, sending end bus number (no default allowed)	INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)	INTGAR(3)	MODE, control mode (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)	INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)	INTGAR(6)	IREG, regulated bus number (0 by default)	INTGAR(7)	NODE, regulated node number (0 by default)
INTGAR(1)	I, sending end bus number (no default allowed)														
INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)														
INTGAR(3)	MODE, control mode (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)														
INTGAR(6)	IREG, regulated bus number (0 by default)														
INTGAR(7)	NODE, regulated node number (0 by default)														
Real REALAR (19)	(first thirteen are input values; last six are output values) (input (output)).														
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input). <table> <tr> <td>REALARI(1)</td><td>PDES, desired real power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(2)</td><td>QDES, desired reactive power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(3)</td><td>VSET, sending bus voltage setpoint (1.0 by default)</td></tr> <tr> <td>REALARI(4)</td><td>SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)</td></tr> </table>	REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)	REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)	REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)	REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)						
REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)														
REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)														
REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)														
REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)														

	REALARI(5)	TRMX, maximum bridge real power transfer (99.99 * SBASE by default)
	REALARI(6)	VTMN, minimum terminal bus voltage magnitude (0.9 by default)
	REALARI(7)	VTMX, maximum terminal bus voltage magnitude (1.1 by default)
	REALARI(8)	VSMX, maximum series voltage magnitude (1.0 by default)
	REALARI(9)	IMX, maximum series current (MVA at rated voltage) (0.0 by default)
	REALARI(10)	LINX, pu reactance of temporary series element (0.05 by default)
	REALARI(11)	RMPCT, percent of contributed reactive power (100.0 by default)
	REALARI(12)	SET1, real component of constant Z (MODE = 3), magnitude of constant V (MODE = 4), or VD (MODE = 7 or 8) (0.0 by default)
	REALARI(13)	SET2, imaginary component of constant Z (MODE = 3), angle of constant V (MODE = 4), or VQ (MODE = 7 or 8) (0.005 by default when MODE = 3; 0.0 otherwise)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(14) through REALAR(19) as described above(output).	
	REALARO(1)	real component of present effective series Z (returned)
	REALARO(2)	imaginary component of present effective series Z (returned)
	REALARO(3)	magnitude of present series voltage, FDVREF reference (returned)
	REALARO(4)	le of present series voltage, FDVREF reference (returned)
	REALARO(5)	real component of present series voltage, FDVREF reference (returned)
	REALARO(6)	imaginary component of present series voltage, FDVREF reference (returned)
Character*12 MNAME	name of the FACTS device that is the master device for this IPFC slave device (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 2	no sending end bus is specified
	IERR = 3	bus not found
	IERR = 4	the same bus is specified for the sending and terminal end buses
	IERR = 5	blank FACTS device name is invalid
	IERR = 6	FACTS device not found

IERR = 7

IERR = 8

IERR = -1

node-breaker terminal connection table is full
prerequisite requirements for API are not met
warnings - one or more of: - Invalid FACTS device control mode. - Invalid owner number. - Invalid series voltage reference code. - Regulated bus not found. - Remote regulated bus is specified for a type 3 bus. - Type code of regulated bus is not 1 or 2. - Shunt element voltage setpoint must be positive. - Terminal bus voltage limit must be positive. - VT-MX is less than VTMN. - Series voltage limit must be positive. - Shunt current limit must not be negative. - Bridge real power transfer limit must not be negative. - Series current limit must not be negative. - Series reactance must be positive. - Shunt current limit is not 0.0 for an IPFC device. - Bridge real power transfer limit is not 0.0 for an IPFC slave. - Impedance setpoint has reactance of 0.0. - RMPCT is not positive. - Master IPFC FACTS device not found. - Bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Owner table is full - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus

1.2.19. FACTS_DATA

This API routine is obsolete. It has been replaced by the API routine [facts_data_2](#).

Use this API to modify the data of an existing FACTS device in the working case or to add a new FACTS device to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_FACTS_DATA  FD  INTGAR(1)..INTGAR(5)  REALAR(1)..REALAR(13)
```

Python command syntax:

```
ierr, realaro = facts_data(fd, intgar, realari)
```

Fortran command syntax:

```
CALL FACTS_API(FD, INTGAR, REALAR, IERR, NERR)
```

Where:

Integer FD	number (which the API converts to a left-justified name) of the FACTS device for which data is to be specified (input; no default allowed).												
Integer INTGAR (5)	array of 5 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>I, sending end bus number (alias is I)</td></tr> <tr> <td>INTGAR(2)</td><td>J, terminal end bus number (0 for STATCON) (alias is J)</td></tr> <tr> <td>INTGAR(3)</td><td>MODE, control mode (alias is MODE)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (alias is OWNER)</td></tr> <tr> <td>INTGAR(5)</td><td>VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (alias is VSREF)</td></tr> </table>	INTGAR(1)	I, sending end bus number (alias is I)	INTGAR(2)	J, terminal end bus number (0 for STATCON) (alias is J)	INTGAR(3)	MODE, control mode (alias is MODE)	INTGAR(4)	OWNER, owner number (alias is OWNER)	INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (alias is VSREF)		
INTGAR(1)	I, sending end bus number (alias is I)												
INTGAR(2)	J, terminal end bus number (0 for STATCON) (alias is J)												
INTGAR(3)	MODE, control mode (alias is MODE)												
INTGAR(4)	OWNER, owner number (alias is OWNER)												
INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (alias is VSREF)												
Real REALAR (19)	(first thirteen are input values; last six are output values) (input (output)).												
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input). <table> <tr> <td>REALARI(1)</td><td>PDES, desired real power at terminal bus (alias is PDES)</td></tr> <tr> <td>REALARI(2)</td><td>QDES, desired reactive power at terminal bus (alias is QDES)</td></tr> <tr> <td>REALARI(3)</td><td>VSET, sending bus voltage setpoint (alias is VSET)</td></tr> <tr> <td>REALARI(4)</td><td>SHMX, sending end maximum shunt current (MVA at rated voltage) (alias is SHMAX)</td></tr> <tr> <td>REALARI(5)</td><td>TRMX, maximum bridge real power transfer (alias is TRMX)</td></tr> <tr> <td>REALARI(6)</td><td>VTMN, minimum terminal bus voltage magnitude (alias is VTMN)</td></tr> </table>	REALARI(1)	PDES, desired real power at terminal bus (alias is PDES)	REALARI(2)	QDES, desired reactive power at terminal bus (alias is QDES)	REALARI(3)	VSET, sending bus voltage setpoint (alias is VSET)	REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (alias is SHMAX)	REALARI(5)	TRMX, maximum bridge real power transfer (alias is TRMX)	REALARI(6)	VTMN, minimum terminal bus voltage magnitude (alias is VTMN)
REALARI(1)	PDES, desired real power at terminal bus (alias is PDES)												
REALARI(2)	QDES, desired reactive power at terminal bus (alias is QDES)												
REALARI(3)	VSET, sending bus voltage setpoint (alias is VSET)												
REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (alias is SHMAX)												
REALARI(5)	TRMX, maximum bridge real power transfer (alias is TRMX)												
REALARI(6)	VTMN, minimum terminal bus voltage magnitude (alias is VTMN)												

	REALARI(7)	VTMX, maximum terminal bus voltage magnitude (alias is VTMX)
	REALARI(8)	VSMX, maximum series voltage magnitude (alias is VSMX)
	REALARI(9)	IMX, maximum series current (MVA at rated voltage) (alias is IMX)
	REALARI(10)	LINX, pu reactance of temporary series element (alias is LINX)
	REALARI(11)	RMPCT, percent of contributed reactive power (alias is RMPCT)
	REALARI(12)	SET1, real component of constant Z (mode = 3), magnitude of constant V (mode = 4), or VD (mode = 7 or 8) (alias is SET1)
	REALARI(13)	SET2, imaginary component of constant Z (mode = 3), angle of constant V (mode = 4), or VQ (mode = 7 or 8) (alias is SET2)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(14) through REALAR(19) as described above(output).	
	REALARO(1)	real component of present effective series Z (returned)
	REALARO(2)	imaginary component of present effective series Z (returned)
	REALARO(3)	magnitude of present series voltage, FDVREF reference (returned)
	REALARO(4)	le of present series voltage, FDVREF reference (returned)
	REALARO(5)	real component of present series voltage, FDVREF reference (returned)
	REALARO(6)	imaginary component of present series voltage, FDVREF reference (returned)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	FACTS device table is full
	IERR = 2	no sending end bus is specified
	IERR = 3	bus not found
	IERR = 4	the same bus is specified for the sending and terminal end buses
	IERR = 6	prerequisite requirements for API are not met
	IERR = 7	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - Invalid FACTS device control model. - Invalid owner number. - Invalid series voltage reference code. - Shunt element voltage setpoint must be positive. - Terminal bus voltage limit must be positive. - VTMX is less than VTMN. - Series voltage lim-

it must be positive. - Shunt current limit must not be negative. - Bridge real power transfer limit must not be negative. - Series current limit must not be negative. - Series reactance must be positive. - Shunt current limit is not 0.0 for an IPFC device. - Bridge real power transfer limit is not 0.0 for an IPFC device. - Impedance setpoint has reactance of 0.0. - RMPCT is not positive. - Master IPFC FACTS device not found. - Bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Owner table is full

Integer NERR

number of entries in PBUF02 containing error messages (output).

1.2.20. FACTS_DATA_2

This API routine is obsolete. It has been replaced by the API routine [facts_data_3](#).

Use this API to modify the data of an existing FACTS device in the working case, or to add a new FACTS device to the working case (see PSSE Program Operation Manual, FACTS Device Data).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_FACTS_DATA_2  'NAME'  INTGAR(1)..INTGAR(6)  REALAR(1)..REALAR(13)
  'MNAME'
```

Python command syntax:

```
ierr, realaro = facts_data_2(name, intgar, realari, mname)
```

Fortran command syntax:

```
CALL FACTS_API_2(NAME, INTGAR, REALAR, MNAME, IERR)
```

Where:

Character*12 NAME	name of the FACTS device (input; no default allowed).												
Integer INTGAR (6)	array of 6 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>I, sending end bus number (no default allowed)</td></tr> <tr> <td>INTGAR(2)</td><td>J, terminal end bus number (0 for STATCON) (0 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>MODE, control mode (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)</td></tr> <tr> <td>INTGAR(6)</td><td>REMOT, remote bus number (0 for sending end bus) (0 by default)</td></tr> </table>	INTGAR(1)	I, sending end bus number (no default allowed)	INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)	INTGAR(3)	MODE, control mode (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)	INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)	INTGAR(6)	REMOT, remote bus number (0 for sending end bus) (0 by default)
INTGAR(1)	I, sending end bus number (no default allowed)												
INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)												
INTGAR(3)	MODE, control mode (1 by default)												
INTGAR(4)	OWNER, owner number (1 by default)												
INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)												
INTGAR(6)	REMOT, remote bus number (0 for sending end bus) (0 by default)												
Real REALAR (19)	(first thirteen are input values; last six are output values) (input (output)).												
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input). <table> <tr> <td>REALARI(1)</td><td>PDES, desired real power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(2)</td><td>QDES, desired reactive power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(3)</td><td>VSET, sending bus voltage setpoint (1.0 by default)</td></tr> <tr> <td>REALARI(4)</td><td>SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)</td></tr> </table>	REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)	REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)	REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)	REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)				
REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)												
REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)												
REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)												
REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)												

	REALARI(5)	TRMX, maximum bridge real power transfer (99.99 * SBASE by default)
	REALARI(6)	VTMN, minimum terminal bus voltage magnitude (0.9 by default)
	REALARI(7)	VTMX, maximum terminal bus voltage magnitude (1.1 by default)
	REALARI(8)	VSMX, maximum series voltage magnitude (1.0 by default)
	REALARI(9)	IMX, maximum series current (MVA at rated voltage) (0.0 by default)
	REALARI(10)	LINX, pu reactance of temporary series element (0.05 by default)
	REALARI(11)	RMPCT, percent of contributed reactive power (100.0 by default)
	REALARI(12)	SET1, real component of constant Z (MODE = 3), magnitude of constant V (MODE = 4), or VD (MODE = 7 or 8) (0.0 by default)
	REALARI(13)	SET2, imaginary component of constant Z (MODE = 3), angle of constant V (MODE = 4), or VQ (MODE = 7 or 8) (0.005 by default when MODE = 3; 0.0 otherwise)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(14) through REALAR(19) as described above(output).	
	REALARO(1)	real component of present effective series Z (returned)
	REALARO(2)	imaginary component of present effective series Z (returned)
	REALARO(3)	magnitude of present series voltage, FDVREF reference (returned)
	REALARO(4)	le of present series voltage, FDVREF reference (returned)
	REALARO(5)	real component of present series voltage, FDVREF reference (returned)
	REALARO(6)	imaginary component of present series voltage, FDVREF reference (returned)
Character*12 MNAME	name of the FACTS device that is the master device for this IPFC slave device (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	FACTS device table is full
	IERR = 2	no sending end bus is specified
	IERR = 3	bus not found
	IERR = 4	the same bus is specified for the sending and terminal end buses
	IERR = 5	blank FACTS device name is invalid

IERR = 6

IERR = -1

prerequisite requirements for API are not met
warnings - one or more of: - Invalid FACTS device control mode. - Invalid owner number. - Invalid series voltage reference code. - Regulated bus not found. - Shunt element specified as remotely regulating itself. - Type code of regulated bus is not 1 or 2. - Shunt element voltage setpoint must be positive. - Terminal bus voltage limit must be positive. - VT-MX is less than VTMN. - Series voltage limit must be positive. - Shunt current limit must not be negative. - Bridge real power transfer limit must not be negative. - Series current limit must not be negative. - Series reactance must be positive. - Shunt current limit is not 0.0 for an IPFC device. - Bridge real power transfer limit is not 0.0 for an IPFC device. - Impedance setpoint has reactance of 0.0. - RMPCT is not positive. - Master IPFC FACTS device not found. - Bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Owner table is full

1.2.21. FACTS_DATA_3

Use this API to modify the data of an existing FACTS device in the working case, or to add a new FACTS device to the working case (see PSSE Program Operation Manual, FACTS Device Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_FACTS_DATA_3  'NAME'  INTGAR(1)..INTGAR(7)  REALAR(1)..REALAR(13)
  'MNAME'
```

Python command syntax:

```
ierr, realaro = facts_data_3(name, intgar, realari, mname)
```

Fortran command syntax:

```
CALL FACTS_API_3(NAME, INTGAR, REALAR, MNAME, IERR)
```

Where:

Character*12 NAME	name of the FACTS device (input; no default allowed).														
Integer INTGAR (7)	array of 7 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>I, sending end bus number (no default allowed)</td></tr> <tr> <td>INTGAR(2)</td><td>J, terminal end bus number (0 for STATCON) (0 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>MODE, control mode (1 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>OWNER, owner number (1 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)</td></tr> <tr> <td>INTGAR(6)</td><td>IREG, regulated bus number (0 by default)</td></tr> <tr> <td>INTGAR(7)</td><td>NODE, regulated node number (0 by default)</td></tr> </table>	INTGAR(1)	I, sending end bus number (no default allowed)	INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)	INTGAR(3)	MODE, control mode (1 by default)	INTGAR(4)	OWNER, owner number (1 by default)	INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)	INTGAR(6)	IREG, regulated bus number (0 by default)	INTGAR(7)	NODE, regulated node number (0 by default)
INTGAR(1)	I, sending end bus number (no default allowed)														
INTGAR(2)	J, terminal end bus number (0 for STATCON) (0 by default)														
INTGAR(3)	MODE, control mode (1 by default)														
INTGAR(4)	OWNER, owner number (1 by default)														
INTGAR(5)	VSREF, series voltage reference code for modes 4 and 7 (0 for sending end voltage; 1 for series current) (0 by default)														
INTGAR(6)	IREG, regulated bus number (0 by default)														
INTGAR(7)	NODE, regulated node number (0 by default)														
Real REALAR (19)	(first thirteen are input values; last six are output values) (input (output)).														
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input). <table> <tr> <td>REALARI(1)</td><td>PDES, desired real power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(2)</td><td>QDES, desired reactive power at terminal bus (0.0 by default)</td></tr> <tr> <td>REALARI(3)</td><td>VSET, sending bus voltage setpoint (1.0 by default)</td></tr> <tr> <td>REALARI(4)</td><td>SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)</td></tr> </table>	REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)	REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)	REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)	REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)						
REALARI(1)	PDES, desired real power at terminal bus (0.0 by default)														
REALARI(2)	QDES, desired reactive power at terminal bus (0.0 by default)														
REALARI(3)	VSET, sending bus voltage setpoint (1.0 by default)														
REALARI(4)	SHMX, sending end maximum shunt current (MVA at rated voltage) (99.99 * SBASE by default)														

	REALARI(5)	TRMX, maximum bridge real power transfer (99.99 * SBASE by default)
	REALARI(6)	VTMN, minimum terminal bus voltage magnitude (0.9 by default)
	REALARI(7)	VTMX, maximum terminal bus voltage magnitude (1.1 by default)
	REALARI(8)	VSMX, maximum series voltage magnitude (1.0 by default)
	REALARI(9)	IMX, maximum series current (MVA at rated voltage) (0.0 by default)
	REALARI(10)	LINX, pu reactance of temporary series element (0.05 by default)
	REALARI(11)	RMPCT, percent of contributed reactive power (100.0 by default)
	REALARI(12)	SET1, real component of constant Z (MODE = 3), magnitude of constant V (MODE = 4), or VD (MODE = 7 or 8) (0.0 by default)
	REALARI(13)	SET2, imaginary component of constant Z (MODE = 3), angle of constant V (MODE = 4), or VQ (MODE = 7 or 8) (0.005 by default when MODE = 3; 0.0 otherwise)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(14) through REALAR(19) as described above(output).	
	REALARO(1)	real component of present effective series Z (returned)
	REALARO(2)	imaginary component of present effective series Z (returned)
	REALARO(3)	magnitude of present series voltage, FDVREF reference (returned)
	REALARO(4)	le of present series voltage, FDVREF reference (returned)
	REALARO(5)	real component of present series voltage, FDVREF reference (returned)
	REALARO(6)	imaginary component of present series voltage, FDVREF reference (returned)
Character*12 MNAME	name of the FACTS device that is the master device for this IPFC slave device (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	FACTS device table is full
	IERR = 2	no sending end bus is specified
	IERR = 3	bus not found
	IERR = 4	the same bus is specified for the sending and terminal end buses
	IERR = 5	blank FACTS device name is invalid

IERR = 7

IERR = 8

IERR = -1

node-breaker terminal connection table is full
prerequisite requirements for API are not met
warnings - one or more of: - Invalid FACTS device control mode. - Invalid owner number. - Invalid series voltage reference code. - Regulated bus not found. - Remote regulated bus is specified for a type 3 bus. - Type code of regulated bus is not 1 or 2. - Shunt element voltage setpoint must be positive. - Terminal bus voltage limit must be positive. - VT-MX is less than VTMN. - Series voltage limit must be positive. - Shunt current limit must not be negative. - Bridge real power transfer limit must not be negative. - Series current limit must not be negative. - Series reactance must be positive. - Shunt current limit is not 0.0 for an IPFC device. - Bridge real power transfer limit is not 0.0 for an IPFC slave. - Impedance setpoint has reactance of 0.0. - RMPCT is not positive. - Master IPFC FACTS device not found. - Bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Owner table is full - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus

1.2.22. GNE_CHNG

Use this API routine to modify the data of an existing GNE device in the working case (see PSSE Program Operation Manual, GNE Device Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_GNE_CHNG 'NAME' 'MODEL' NTERM TRMNLS(1)..TRMNLS(NTERM)
  INTGAR(1)..INTGAR(3) NRELCN RELCON(1)..RELCON(NRELCN) NINTCN
  INTCON(1)..INTCON(NINTCN) NCHRCN CHRCON(1)..CHRCON(NCHRCN)
```

Python command syntax:

```
ierr = gne_chng(name, model, nterm, trmnls, intgar, nrelcn, relcon,
  nintcn, intcon, nchrcn, chrcon)
```

Fortran command syntax:

```
CALL GNE_CHNG(NAME, MODEL, NTERM, TRMNLS, INTGAR, NRELCN, RELCON, NINTCN,
  INTCON, NCHRCN, CHRCON, IERR)
```

Where:

Character*12 NAME	name of the GNE device (input; no default allowed).
Character*16 MODEL	name of the GMB/BOSL model to be used by this GNE device. The GMB/BOSL model file "MODEL.mac" must be available (input; no default allowed).
Integer NTERM	number of terminals (i.e., buses) to which the model is connected. NTERM must be 1 for GNE-PQ and GNE-I models, and it must be either 1 or 2 for a GNE-Y model (input; no default allowed).
Integer TRMNLS (NTERM)	containing the bus numbers of the buses to which this model is connected (input; no default allowed).
Integer INTGAR (3)	array of 3 elements specifying (input). INTGAR(1) STATUS, model status (0 for out-of-service, 1 for in-service) (1 by default) INTGAR(2) OWNER, owner number (the owner to which bus TRMNLS (1) is assigned by default) INTGAR(3) NMETR, non-metered end bus number (TRMNLS (NTERM) by default)
Integer NRELCN	number of real constants required by the model (input; no default allowed).
Real RELCON (NRELCN)	real model constants (input; 0.0).
Integer NINTCN	number of integer constants required by the model (input; no default allowed).
Integer INTCON (NINTCN)	integer model constants (usually bus numbers) (TRMNLS) (input; 1 by default).

Integer NCHRCN	number of two-character identifiers required by the model (input; no default allowed).
Character*12 CHRCON (NCHRCN)	containing character model constants (e.g., circuit identifiers) (input; '1' by default).
Integer IERR	error code (output).
IERR = 0	no errors occurred
IERR > 0	error occurred
IERR = 1	blank GNE device name is invalid
IERR = 2	invalid number of terminal buses for this GMB/BOSL model
IERR = 3	bus not found
IERR = 4	model is not a GNE model
IERR = 5	number of constants specified differs from those required in the model's.mac file
IERR = 7	blank model name is invalid for a new GNE device instance
IERR = 8	GNE.mac file is not found or an error occurred while reading it
IERR = 9	GNE device not found
IERR = 10	prerequisite requirements for API are not met
IERR = 18	BOSL/GMB not installed/initialized
IERR = -1	warnings - one or more of: - Invalid GNE device status. - Invalid owner number. - Invalid non-metered end bus. - Bus specified in an integer constant is not found. - Owner table is full

1.2.23. GNE_DATA

Use this API routine to run the GNE device data specification function. It modifies the data of an existing GNE device in the working case, or adds a new GNE device to the working case (see PSSE Program Operation Manual, GNE Device Data).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_GNE_DATA 'NAME' 'MODEL' NTERM TRMNLS(1)..TRMNLS(NTERM)
             INTGAR(1)..INTGAR(3) NRELCN RELCON(1)..RELCON(NRELCN) NINTCN
             INTCON(1)..INTCON(NINTCN) NCHRCN CHRCON(1)..CHRCON(NCHRCN)
```

Python command syntax:

```
ierr = gne_data(name, model, nterm, trmnls, intgar, nrelcn, relcon,
               nintcn, intcon, nchrcn, chrcon)
```

Fortran command syntax:

```
CALL GNE_API(NAME, MODEL, NTERM, TRMNLS, INTGAR, NRELCN, RELCON, NINTCN,
             INTCON, NCHRCN, CHRCON, IERR)
```

Where:

Character*12 NAME	name of the GNE device (input; no default allowed).
Character*16 MODEL	name of the GMB/BOSL model to be used by this GNE device. The GMB/BOSL model file "MODEL.mac" must be available (input; no default allowed).
Integer NTERM	number of terminals (i.e., buses) to which the model is connected. NTERM must be 1 for GNE-PQ and GNE-I models, and it must be either 1 or 2 for a GNE-Y model (input; no default allowed).
Integer TRMNLS (NTERM)	containing the bus numbers of the buses to which this model is connected (input; no default allowed).
Integer INTGAR (3)	array of 3 elements specifying (input). INTGAR(1) STATUS, model status (0 for out-of-service, 1 for in-service) (1 by default) INTGAR(2) OWNER, owner number (the owner to which bus TRMNLS (1) is assigned by default) INTGAR(3) NMETR, non-metered end bus number (TRMNLS (NTERM) by default)
Integer NRELCN	number of real constants required by the model (input; no default allowed).
Real RELCON (NRELCN)	real model constants (input; 0.0).
Integer NINTCN	number of integer constants required by the model (input; no default allowed).
Integer INTCON (NINTCN)	integer model constants (usually bus numbers) (TRMNLS) (input; 1 by default).

Integer NCHRCN	number of two-character identifiers required by the model (input; no default allowed).
Character*12 CHRCON (NCHRCN)	containing character model constants (e.g., circuit identifiers) (input; '1' by default).
Integer IERR	error code (output).
IERR = 0	no errors occurred
IERR > 0	error occurred
IERR = 1	blank GNE device name is invalid
IERR = 2	invalid number of terminal buses for this GMB/BOSL model
IERR = 3	bus not found
IERR = 4	model is not a GNE model
IERR = 5	number of constants specified differs from those required in the model's.mac file
IERR = 6	GNE device instance table is full
IERR = 7	blank model name is invalid for a new GNE device instance
IERR = 8	GNE.mac file is not found or an error occurred while reading it
IERR = 10	prerequisite requirements for API are not met
IERR = 18	BOSL/GMB not installed/initialized
IERR = -1	warnings - one or more of: - Invalid GNE device status. - Invalid owner number. - Invalid non-metered end bus. - Bus specified in an integer constant is not found. - Owner table is full

1.2.24. IMPEDANCE_CORRECTION_DATA

This API routine is obsolete. It has been replaced by the API routine [impedance_correction_data_3](#).

Use this API to modify the data of an existing transformer impedance correction table in the working case or to add a new transformer impedance correction table to the working case (see PSSE Program Operation Manual, Transformer Impedance Correction Table Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_IMPEDANCE_CORRECTION_DATA I REALAR(1,1) REALAR(2,1) REALAR(1,2)
REALAR(2,2) .. REALAR(1,11) REALAR(2,11)
```

Python command syntax:

```
ierr, intgar = impedance_correction_data(i, realar)
```

Fortran command syntax:

```
CALL IMPEDANCE_CORRECTION_TAB_API_2(I, INTGAR, REALAR, IERR)
```

Where:

Integer I	table number (must be between 1 and the number of tables allowed at the present size level of PSSE) (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (output). INTGAR(1) number of entries in table (returned) INTGAR(2) table type flag (0=ratio, 1=angle) (returned)
Real REALAR (22)	22 values dimensioned (2,11), where REALAR(1,i) specifies T_i , and REALAR(2,i) specifies F_i . The values are specified such that the left subscript varies more rapidly: (1,1), (2,1), (1,2), (2,2), .. (1,11), (2,11). (REALAR(1,1) = REALAR (input; 2,1) =1.0 by default; all other values are 0.0 by default).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 invalid transformer impedance correction table number IERR = 3 ABSCISSA values are not in ascending order IERR = 4 ABSCISSA value is outside of the range of -180 to +180 IERR = 5 table has fewer than 2 points IERR = 6 prerequisite requirements for API are not met IERR = -1 data error, warning and information messages; one or more of: - point is beyond previous end of table - invalid scaling factor

1.2.25. IMPEDANCE_CORRECTION_DATA_3

Use this API to modify the data of an existing transformer impedance correction table in the working case or to add a new transformer impedance correction table to the working case (see PSSE Program Operation Manual, Transformer Impedance Correction Table Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_IMPEDANCE_CORRECTION_DATA_3  I POINTS REALAR(1)..REALAR(POINTS)
  CPLXAR(1)..CPLXAR(POINTS)
```

Python command syntax:

```
ierr = impedance_correction_data_3(i, points, realar, cplxar)
```

Fortran command syntax:

```
CALL IMPEDANCE_CORRECTION_TAB_API_3(I, POINTS, REALAR, CPLXAR, IERR)
```

Where:

Integer I	table number (must be between 1 and the number of tables allowed at the present size level (input).
Integer POINTS	number of points specified in table 'I' (2 through 99) (input; no default allowed).
Real REALAR (POINTS)	array of 'POINTS' values specifying either off-nominal turns ratios in pu or phase shift angles in degrees in strictly ascending order (input).
Complex CPLXAR (POINTS)	array of 'POINTS' complex scaling factors by which transformer nominal impedance is to be multiplied to obtain the actual transformer impedance for the corresponding 'REALAR' value (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 invalid transformer impedance correction table number
	IERR = 3 REALAR values are not in ascending order
	IERR = 4 REALAR value is outside of the range of -180 to +180
	IERR = 5 table has fewer than 2 points
	IERR = 6 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - point is beyond previous end of table - invalid scaling factor

1.2.26. INDUCTION_MACHINE_CHNG

Use this API routine to modify the data of an existing induction machine in the working case (see PSSE Program Operation Manual, Induction Machine Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_INDUCION_MACHINE_CHNG  IBUS  'ID'  INTGAR(1)..INTGAR(9)
                             REALAR(1)..REALAR(23)
```

Python command syntax:

```
ierr = induction_machine_chng(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL INDUCTION_MACHINE_CHNG(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (9)	array of 9 elements specifying (input).
	INTGAR(1) STAT, induction machine status (1 by default)
	INTGAR(2) SCODE, machine standard type (1 for NEMA, 2 for IEC) (1 by default)
	INTGAR(3) DCODE, machine design code (0 for custom, 1 through 5 for MEMA designs A through E) (2 by default)
	INTGAR(4) AREA, area number (area of bus IBUS by default)
	INTGAR(5) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(6) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(7) TCODE, type of mechanical torque variation (1 for simple power law, 2 for WECC model) (1 by default)
	INTGAR(8) BCODE, base machine power code (1 for mechanical power 2 for electrical power drawn) (1 by default)
	INTGAR(9) PCODE, power setpoint code (1 for mechanical power 2 for electrical power drawn) (1 by default)
Real REALAR (23)	array of 23 elements specifying (input).
	REALAR(1) MBASE, machine base power (SBASE by default)

	REALAR(2)	RATEKV, machine rated voltage (kV line to line); 0.0 for bus base voltage (0.0 by default)
	REALAR(3)	PSET, machine power setpoint in MW (positive for a motor) (0.0 by default)
	REALAR(4)	H, machine inertia in pu on machine base power (1.0 by default)
	REALAR(5)	A, load torque variation constant (1.0 by default)
	REALAR(6)	B, load torque variation constant (1.0 by default)
	REALAR(7)	D, load torque variation constant (1.0 by default)
	REALAR(8)	E, load torque variation constant (1.0 by default)
	REALAR(9)	RA, armature resistance (0.02494 by default)
	REALAR(10)	XA, armature leakage reactance (0.07482 by default)
	REALAR(11)	XM, magnetizing reactance (2.32786 by default)
	REALAR(12)	R1, first cage resistance (0.02078 by default)
	REALAR(13)	X1, first cage reactance (0.09145 by default)
	REALAR(14)	R2, second cage resistance (0.12471 by default)
	REALAR(15)	X2, second cage reactance (0.03326 by default)
	REALAR(16)	X3, third reactance (0.0 by default)
	REALAR(17)	E1, first voltage point on saturation curve (1.0 by default)
	REALAR(18)	SE1, saturation factor at E1 (0.04 by default)
	REALAR(19)	E2, second voltage point on saturation curve (1.2 by default)
	REALAR(20)	SE2, saturation factor at E2 (0.2 by default)
	REALAR(21)	IA1, starting stator current for applying stator leakage reactance saturation (1.0 by default)
	REALAR(22)	IA2, stator current at which the stator leakage reactance is fully saturated (5.0 by default)
	REALAR(23)	XAMULT, Xa multiplier at full leakage reactance saturation (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 5	induction machine not found

IERR = 6

IERR = -1

prerequisite requirements for API are not met
data error, warning and information messages; one or more of: - invalid machine status. - invalid machine standard code. - invalid machine design code. - invalid area, zone or owner number. - invalid mechanical torque variation method code. - invalid base power code. - invalid power setpoint code. - machine base power is not positive. - machine rated voltage is negative. - machine rated voltage is ignored because the bus has no base voltage specified for it. - bus base voltage and machine rated voltage differ by more than 20%. - power setpoint exceeds the threshold determined from the standard code and the power setpoint code. - invalid machine inertia. - magnitude of load torque variation constant D is not between 0.2 and 5.0. - the sign of load torque variation constant D is not consistent with that of the machine power setpoint. - machine parameter is negative. - XM is not positive. - Rn or Xn exceeds 999.0. - Rn and Xn are both 0.0. - one of R1 and Xn is 999.0 and the other is not. - E1 is greater than E2; interchanging E1 and E2. - E1 and E2 are equal. - SE1 is greater than SE2; interchanging SE1 and SE2. - IA1 is greater than IA2; interchanging IA1 and IA2. - IA1 and IA2 are equal. - XAMULT must be between 0.0 and 1.0. - area, zone or owner table is full

1.2.27. INDUCTION_MACHINE_DATA

Use this API routine to modify the data of an existing induction machine in the working case, or to add a new induction machine to the working case (see PSSE Program Operation Manual, Induction Machine Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_INDUCTION_MACHINE_DATA  IBUS  'ID'  INTGAR(1)..INTGAR(9)
                             REALAR(1)..REALAR(23)
```

Python command syntax:

```
ierr = induction_machine_data(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL INDUCTION_MACHINE_API(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (9)	array of 9 elements specifying (input).
	INTGAR(1) STAT, induction machine status (1 by default)
	INTGAR(2) SCODE, machine standard type (1 for NEMA, 2 for IEC) (1 by default)
	INTGAR(3) DCODE, machine design code (0 for custom, 1 through 5 for MEMA designs A through E) (2 by default)
	INTGAR(4) AREA, area number (area of bus IBUS by default)
	INTGAR(5) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(6) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(7) TCODE, type of mechanical torque variation (1 for simple power law, 2 for WECC model) (1 by default)
	INTGAR(8) BCODE, base machine power code (1 for mechanical power 2 for electrical power drawn) (1 by default)
	INTGAR(9) PCODE, power setpoint code (1 for mechanical power 2 for electrical power drawn) (1 by default)
Real REALAR (23)	array of 23 elements specifying (input).
	REALAR(1) MBASE, machine base power (SBASE by default)

	REALAR(2)	RATEKV, machine rated voltage (kV line to line); 0.0 for bus base voltage (0.0 by default)
	REALAR(3)	PSET, machine power setpoint in MW (positive for a motor) (0.0 by default)
	REALAR(4)	H, machine inertia in pu on machine base power (1.0 by default)
	REALAR(5)	A, load torque variation constant (1.0 by default)
	REALAR(6)	B, load torque variation constant (1.0 by default)
	REALAR(7)	D, load torque variation constant (1.0 by default)
	REALAR(8)	E, load torque variation constant (1.0 by default)
	REALAR(9)	RA, armature resistance (0.02494 by default)
	REALAR(10)	XA, armature leakage reactance (0.07482 by default)
	REALAR(11)	XM, magnetizing reactance (2.32786 by default)
	REALAR(12)	R1, first cage resistance (0.02078 by default)
	REALAR(13)	X1, first cage reactance (0.09145 by default)
	REALAR(14)	R2, second cage resistance (0.12471 by default)
	REALAR(15)	X2, second cage reactance (0.03326 by default)
	REALAR(16)	X3, third reactance (0.0 by default)
	REALAR(17)	E1, first voltage point on saturation curve (1.0 by default)
	REALAR(18)	SE1, saturation factor at E1 (0.04 by default)
	REALAR(19)	E2, second voltage point on saturation curve (1.2 by default)
	REALAR(20)	SE2, saturation factor at E2 (0.2 by default)
	REALAR(21)	IA1, starting stator current for applying stator leakage reactance saturation (1.0 by default)
	REALAR(22)	IA2, stator current at which the stator leakage reactance is fully saturated (5.0 by default)
	REALAR(23)	XAMULT, Xa multiplier at full leakage reactance saturation (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	blank machine identifier is invalid

IERR = 4	induction machine table is full
IERR = 5	node-breaker terminal connection table is full
IERR = 6	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid machine status. - invalid machine standard code. - invalid machine design code. - invalid area, zone or owner number. - invalid mechanical torque variation method code. - invalid base power code. - invalid power setpoint code. - machine base power is not positive. - machine rated voltage is negative. - machine rated voltage is ignored because the bus has no base voltage specified for it. - bus base voltage and machine rated voltage differ by more than 20%. - power setpoint exceeds the threshold determined from the standard code and the power setpoint code. - invalid machine inertia. - magnitude of load torque variation constant D is not between 0.2 and 5.0. - the sign of load torque variation constant D is not consistent with that of the machine power setpoint. - machine parameter is negative. - XM is not positive. - Rn or Xn exceeds 999.0. - Rn and Xn are both 0.0. - one of R1 and Xn is 999.0 and the other is not. - E1 is greater than E2; interchanging E1 and E2. - E1 and E2 are equal. - SE1 is greater than SE2; interchanging SE1 and SE2. - IA1 is greater than IA2; interchanging IA1 and IA2. - IA1 and IA2 are equal. - XAMULT must be between 0.0 and 1.0. - area, zone or owner table is full

1.2.28. LOAD_CHNG_4

This API routine is obsolete. It has been replaced by the API routine [load_chng_5](#).

Use this API routine to modify the data of an existing load in the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_LOAD_CHNG_4  IBUS  'ID'  INTGAR(1)..INTGAR(6)  REALAR(1)..REALAR(6)
```

Python command syntax:

```
ierr = load_chng_4(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL LOAD_CHNG_4(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(5) SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
	INTGAR(6) INTRPT, interruptible load flag (0 = non-interruptible; 1 = interruptible) (0 by default)
Real REALAR (6)	array of 6 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)
	REALAR(4) IQ, constant current reactive load (0.0 by default)
	REALAR(5) YP, constant admittance active load (0.0 by default)

	REALAR(6)	YQ, constant admittance reactive load (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	load identifier is more than two characters
	IERR = 5	load not found
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag. - invalid interruptible load flag

1.2.29. LOAD_CHNG_5

This API routine is obsolete. It has been replaced by the API routine [load_chng_6](#).

Use this API routine to modify the data of an existing load in the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_LOAD_CHNG_5  IBUS ID INTGAR(1)..INTGAR(7) REALAR(1)..REALAR(8)
```

Python command syntax:

```
ierr = load_chng_5(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL LOAD_CHNG_5(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(5) SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
	INTGAR(6) INTRPT, interruptible load flag (0 = non-interruptible; 1 = interruptible) (0 by default)
	INTGAR(7) DGNFLG, distributed generation flag (0 = distributed generation not in-service; 1 = distributed generation in-service) (0 by default)
Real REALAR (8)	array of 8 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)

	REALAR(4)	IQ, constant current reactive load (0.0 by default)
	REALAR(5)	YP, constant admittance active load (0.0 by default)
	REALAR(6)	YQ, constant admittance reactive load (0.0 by default)
	REALAR(7)	PG, distributed generation real power (0.0 by default)
	REALAR(8)	QG, distributed generation reactive power (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	load identifier is more than two characters
	IERR = 5	load not found
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag. - invalid interruptible load flag

1.2.30. LOAD_CHNG_6

Use this API routine to modify the data of an existing load in the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LOAD_CHNG_6  IBUS ID INTGAR(1)..INTGAR(7) REALAR(1)..REALAR(8) LODTYP
```

Python command syntax:

```
ierr = load_chng_6(ibus, id, intgar, realar, lodtyp)
```

Fortran command syntax:

```
CALL LOAD_CHNG_6(IBUS, ID, INTGAR, REALAR, LODTYP, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(5) SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
	INTGAR(6) INTRPT, interruptible load flag (0 = non-interruptible; 1 = interruptible) (0 by default)
	INTGAR(7) DGNFLG, distributed generation flag (0 = distributed generation not in-service; 1 = distributed generation in-service) (0 by default)
Real REALAR (8)	array of 8 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)
	REALAR(4) IQ, constant current reactive load (0.0 by default)
	REALAR(5) YP, constant admittance active load (0.0 by default)

	REALAR(6)	YQ, constant admittance reactive load (0.0 by default)
	REALAR(7)	PG, distributed generation real power (0.0 by default)
	REALAR(8)	QG, distributed generation reactive power (0.0 by default)
character*12 LODTYP	load type description (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	load identifier is more than two characters
	IERR = 5	load not found
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag. - invalid interruptible load flag - invalid distributed generation flag - load type description is more than 12 characters

1.2.31. LOAD_DATA

This API routine is obsolete. It has been replaced by the API routine [load_data_3](#).

Use this API to modify the data of an existing load in the working case or to add a new load to the working case.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_LOAD_DATA IBUS 'ID' INTGAR(1)..INTGAR(4) REALAR(1)..REALAR(6)
```

Python command syntax:

```
ierr = load_data(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL LOAD_API_2(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (4)	array of 4 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
Real REALAR (6)	array of 6 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)
	REALAR(4) IQ, constant current reactive load (0.0 by default)
	REALAR(5) YP, constant admittance active load (0.0 by default)
	REALAR(6) YQ, constant admittance reactive load (0.0 by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred

IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	load identifier is more than two characters
IERR = 3	blank load identifier is invalid
IERR = 4	load table is full
IERR = 6	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - Area table is full. - Zone table is full. - Owner table is full

1.2.32. LOAD_DATA_3

This API routine is obsolete. It has been replaced by the API routine [load_data_4](#).

Use this API to modify the data of an existing load in the working case or to add a new load to the working case.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_LOAD_DATA_3  IBUS 'ID' INTGAR(1)..INTGAR(5) REALAR(1)..REALAR(6)
```

Python command syntax:

```
ierr = load_data_3(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL LOAD_API_3(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (5)	array of 5 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(5) SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
Real REALAR (6)	array of 6 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)
	REALAR(4) IQ, constant current reactive load (0.0 by default)
	REALAR(5) YP, constant admittance active load (0.0 by default)
	REALAR(6) YQ, constant admittance reactive load (0.0 by default)

Integer IERR

error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	load identifier is more than two characters
IERR = 3	blank load identifier is invalid
IERR = 4	load table is full
IERR = 6	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag

1.2.33. LOAD_DATA_4

This API routine is obsolete. It has been replaced by the API routine [load_data_5](#).

Use this API routine to modify the data of an existing load in the working case, or to add a new load to the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_LOAD_DATA_4  IBUS  'ID'  INTGAR(1)..INTGAR(6)  REALAR(1)..REALAR(6)
```

Python command syntax:

```
ierr = load_data_4(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL LOAD_API_4(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(5) SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
	INTGAR(6) INTRPT, interruptible load flag (0 = non-interruptible; 1 = interruptible) (0 by default)
Real REALAR (6)	array of 6 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)
	REALAR(4) IQ, constant current reactive load (0.0 by default)
	REALAR(5) YP, constant admittance active load (0.0 by default)

	REALAR(6)	YQ, constant admittance reactive load (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	load identifier is more than two characters
	IERR = 3	blank load identifier is invalid
	IERR = 4	load table is full
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag. - invalid interruptible load flag

1.2.34. LOAD_DATA_5

This API routine is obsolete. It has been replaced by the API routine [load_data_6](#).

Use this API routine to modify the data of an existing load in the working case, or to add a new load to the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_LOAD_DATA_5  IBUS  ID  INTGAR(1)..INTGAR(7)  REALAR(1)..REALAR(8)
```

Python command syntax:

```
ierr = load_data_5(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL LOAD_API_5(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
INTGAR(1)	STATUS, load status (1 by default)
INTGAR(2)	AREA, area number (area of bus IBUS by default)
INTGAR(3)	ZONE, zone number (zone of bus IBUS by default)
INTGAR(4)	OWNER, owner number (owner of bus IBUS by default)
INTGAR(5)	SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
INTGAR(6)	INTRPT, interruptible load flag (0 = non-interruptible; 1 = interruptible) (0 by default)
INTGAR(7)	DGNFLG, distributed generation flag (0 = distributed generation not in-service; 1 = distributed generation in-service) (0 by default)
Real REALAR (8)	array of 8 elements specifying (input).
REALAR(1)	PL, constant power active load (0.0 by default)
REALAR(2)	QL, constant power reactive load (0.0 by default)
REALAR(3)	IP, constant current active load (0.0 by default)

	REALAR(4)	IQ, constant current reactive load (0.0 by default)
	REALAR(5)	YP, constant admittance active load (0.0 by default)
	REALAR(6)	YQ, constant admittance reactive load (0.0 by default)
	REALAR(7)	PG, distributed generation real power (0.0 by default)
	REALAR(8)	QG, distributed generation reactive power (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	load identifier is more than two characters
	IERR = 3	blank load identifier is invalid
	IERR = 4	load table is full
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag. - invalid interruptible load flag

1.2.35. LOAD_DATA_6

Use this API routine to modify the data of an existing load in the working case, or to add a new load to the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LOAD_DATA_6  IBUS ID INTGAR(1)..INTGAR(7) REALAR(1)..REALAR(8) LODTYP
```

Python command syntax:

```
ierr = load_data_6(ibus, id, intgar, realar, lodtyp)
```

Fortran command syntax:

```
CALL LOAD_API_6(IBUS, ID, INTGAR, REALAR, LODTYP, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STATUS, load status (1 by default)
	INTGAR(2) AREA, area number (area of bus IBUS by default)
	INTGAR(3) ZONE, zone number (zone of bus IBUS by default)
	INTGAR(4) OWNER, owner number (owner of bus IBUS by default)
	INTGAR(5) SCALE, load scaling flag (0 = fixed, non-conforming; 1 = scalable, conforming) (1 by default)
	INTGAR(6) INTRPT, interruptible load flag (0 = non-interruptible; 1 = interruptible) (0 by default)
	INTGAR(7) DGNFLG, distributed generation flag (0 = distributed generation not in-service; 1 = distributed generation in-service) (0 by default)
Real REALAR (8)	array of 8 elements specifying (input).
	REALAR(1) PL, constant power active load (0.0 by default)
	REALAR(2) QL, constant power reactive load (0.0 by default)
	REALAR(3) IP, constant current active load (0.0 by default)
	REALAR(4) IQ, constant current reactive load (0.0 by default)
	REALAR(5) YP, constant admittance active load (0.0 by default)

	REALAR(6)	YQ, constant admittance reactive load (0.0 by default)
	REALAR(7)	PG, distributed generation real power (0.0 by default)
	REALAR(8)	QG, distributed generation reactive power (0.0 by default)
character*12 LODTYP	load type description (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	load identifier is more than two characters
	IERR = 3	blank load identifier is invalid
	IERR = 4	load table is full
	IERR = 6	prerequisite requirements for API are not met
	IERR = 7	node-breaker terminal connection table is full
	IERR = -1	data error, warning and information messages; one or more of: - invalid load status. - invalid area, zone or owner number. - area table is full. - zone table is full. - owner table is full. - invalid load scaling flag. - invalid interruptible load flag - invalid distributed generation flag - load type description is more than 12 characters

1.2.36. LONG_TITLE_DATA

Use this API to change the sixteen line long title in the working case (see PSSE Program Operation Manual, activity CHTI).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_LONG_TITLE_DATA 'LNLNS(1)'.. 'LNLNS(16)'
```

Python command syntax:

```
ierr = long_title_data(lnlns)
```

Fortran command syntax:

```
CALL LONG_TITLE_API_2(LNLNS, IERR)
```

Where:

Character*72 LNLNS (16)	sixteen title lines (defaulted lines are unchanged) (input).
Integer IERR	error code (output).
IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Title line exceeds 72 characters

1.2.37. MACHINE_CAP_CURVE_CHNG

Use this API routine to modify the capability curve data of an existing machine in the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MACHINE_CAP_CURVE_CHNG IBUS ID POINTS PGENAR(1)...PGENAR(POINTS)
  QMAXAR(1)...QMAXAR(POINTS) QMINAR(1)...QMINAR(POINTS)
```

Python command syntax:

```
ierr = machine_cap_curve_chng(ibus, id, points, pgenar, qmaxar, qminar)
```

Fortran command syntax:

```
CALL MACHINE_CAP_CURVE_CHNG(IBUS, ID, POINTS, PGENAR, QMAXAR, QMINAR,
  IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer POINTS	number of points specified in the capability curve (input).
real PGENAR (POINTS)	array of 'POINTS' values specifying machine active power outputs in MW along the MW axis of the machine's capability curve (input).
real QMAXAR (POINTS)	array of 'POINTS' values specifying machine maximum reactive power outputs in MVAR at the corresponding PGENAR values of the machine's capability curve (input).
real QMINAR (POINTS)	array of 'POINTS' values specifying machine minimum reactive power outputs in MVAR at the corresponding PGENAR values of the machine's capability curve (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found
	IERR = 4 invalid POINTS value
	IERR = 5 a motor capability curve is specified for a generator
	IERR = 6 a generator capability curve is specified for a motor
	IERR = 7 capability curve P's for a generator are not in increasing order
	IERR = 8 capability curve P's for a motor are not in decreasing order

IERR = 9
IERR = 10
IERR = -1

capability curve not found for this machine
prerequisite requirements for API are not met
data error, warning and information messages; one or more of: - Machine active power is outside the limits of the capability curve.
- For at least one curve point, QMAX is less than QMIN - Non-conventional machine with machine control mode greater than 1

1.2.38. MACHINE_CAP_CURVE_DATA

Use this API routine to specify or modify the capability curve data of an existing machine in the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MACHINE_CAP_CURVE_DATA IBUS ID POINTS PGENAR(1)...PGENAR(POINTS)
  QMAXAR(1)...QMAXAR(POINTS) QMINAR(1)...QMINAR(POINTS)
```

Python command syntax:

```
ierr = machine_cap_curve_data(ibus, id, points, pgenar, qmaxar, qminar)
```

Fortran command syntax:

```
CALL MACHINE_CAP_CURVE_DATA(IBUS, ID, POINTS, PGENAR, QMAXAR, QMINAR,
  IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer POINTS	number of points specified in the capability curve (input).
real PGENAR (POINTS)	array of 'POINTS' values specifying machine active power outputs in MW along the MW axis of the machine's capability curve (input).
real QMAXAR (POINTS)	array of 'POINTS' values specifying machine maximum reactive power outputs in MVAR at the corresponding PGENAR values of the machine's capability curve (input).
real QMINAR (POINTS)	array of 'POINTS' values specifying machine minimum reactive power outputs in MVAR at the corresponding PGENAR values of the machine's capability curve (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found
	IERR = 4 invalid POINTS value
	IERR = 5 a motor capability curve is specified for a generator
	IERR = 6 a generator capability curve is specified for a motor
	IERR = 7 capability curve P's for a generator are not in increasing order

IERR = 8	capability curve P"s for a motor are not in decreasing order
IERR = 10	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Machine active power is outside the limits of the capability curve. - For at least one curve point, QMAX is less than QMIN - Non-conventional machine with machine control mode greater than 1

1.2.39. MACHINE_CHNG_2

This API routine is obsolete. It has been replaced by the API routine [machine_chng_3](#).

Use this API routine to modify the data of an existing machine in the working case (see PSSE Program Operation Manual, Plant Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MACHINE_CHNG_2  IBUS  'ID'  INTGAR(1) .. INTGAR(6)
                     REALAR(1) .. REALAR(17)
```

Python command syntax:

```
ierr = machine_chng_2(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL MACHINE_CHNG_2(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) STAT, machine status (1 by default)
	INTGAR(2) O1, first owner number (owner of bus I by default)
	INTGAR(3) O2, second owner number (0 by default)
	INTGAR(4) O3, third owner number (0 by default)
	INTGAR(5) O4, fourth owner number (0 by default)
	INTGAR(6) WMOD, wind machine reactive power limits mode (0 if this machine is not a wind machine) (0 by default)
Real REALAR (17)	array of 17 elements specifying (input).
	REALAR(1) PG, machine active power (0.0 by default)
	REALAR(2) QG, machine reactive power (0.0 by default)
	REALAR(3) QT, machine reactive power upper limit (9999.0 by default)
	REALAR(4) QB, machine reactive power lower limit (-9999.0 by default)
	REALAR(5) PT, machine active power upper limit (9999.0 by default)
	REALAR(6) PB, machine active power lower limit (-9999.0 by default)
	REALAR(7) MBASE, machine MVA base (SBASE by default)

	REALAR(8)	ZR, machine resistance (0.0 by default)
	REALAR(9)	ZX, machine reactance (1.0 by default)
	REALAR(10)	RT, step-up transformer resistance (0.0 by default)
	REALAR(11)	XT, step-up transformer reactance (0.0 by default)
	REALAR(12)	GTAP, step-up transformer tap ratio (1.0 by default)
	REALAR(13)	F1, first owner fraction (1.0 by default)
	REALAR(14)	F2, second owner fraction (1.0 by default)
	REALAR(15)	F3, third owner fraction (1.0 by default)
	REALAR(16)	F4, fourth owner fraction (1.0 by default)
	REALAR(17)	WPF, wind machine power factor (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	no plant data at this bus
	IERR = 7	machine not found
	IERR = 8	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid wind machine control mode - invalid wind machine power factor - invalid ZSORCE reactance - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - non-conventional machine has negative active power - machine is no longer treated as a non-conventional machine - non-conventional machine table is full--retained as a conventional machine - capability curve is assigned to a non-conventional machine with machine control mode greater than 1 - machine ownership table is full--only first n owners retained - owner table is full

1.2.40. MACHINE_CHNG_3

Use this API routine to modify the data of an existing machine in the working case (see PSSE Program Operation Manual, Plant Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MACHINE_CHNG_3  IBUS  'ID'  INTGAR(1)..INTGAR(7)
                     REALAR(1)..REALAR(17)
```

Python command syntax:

```
ierr = machine_chng_3(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL MACHINE_CHNG_3(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STAT, machine status (1 by default)
	INTGAR(2) O1, first owner number (owner of bus I by default)
	INTGAR(3) O2, second owner number (0 by default)
	INTGAR(4) O3, third owner number (0 by default)
	INTGAR(5) O4, fourth owner number (0 by default)
	INTGAR(6) WMOD, non-conventional machine reactive power limits mode (0 if this machine is a conventional machine) (0 by default)
	INTGAR(7) BASFLG, baseloaded machine flag
Real REALAR (17)	array of 17 elements specifying (input).
	REALAR(1) PG, machine active power (0.0 by default)
	REALAR(2) QG, machine reactive power (0.0 by default)
	REALAR(3) QT, machine reactive power upper limit (9999.0 by default)
	REALAR(4) QB, machine reactive power lower limit (-9999.0 by default)
	REALAR(5) PT, machine active power upper limit (9999.0 by default)
	REALAR(6) PB, machine active power lower limit (-9999.0 by default)
	REALAR(7) MBASE, machine MVA base (SBASE by default)
	REALAR(8) ZR, machine resistance (0.0 by default)

	REALAR(9)	ZX, machine reactance (1.0 by default)
	REALAR(10)	RT, step-up transformer resistance (0.0 by default)
	REALAR(11)	XT, step-up transformer reactance (0.0 by default)
	REALAR(12)	GTAP, step-up transformer tap ratio (1.0 by default)
	REALAR(13)	F1, first owner fraction (1.0 by default)
	REALAR(14)	F2, second owner fraction (1.0 by default)
	REALAR(15)	F3, third owner fraction (1.0 by default)
	REALAR(16)	F4, fourth owner fraction (1.0 by default)
	REALAR(17)	WPF, non-conventional machine power factor (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	no plant data at this bus
	IERR = 8	machine not found
	IERR = 9	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid non-conventional (renewable and infeed type) machine control mode - invalid renewable machine power factor - invalid ZSORCE reactance - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - machine is no longer treated as a non-conventional machine - non-conventional machine table is full--retained as a conventional machine - machine ownership table is full--only first n owners retained - owner table is full - infeed machine QGEN is greater than QMAX - QGEN set equal to QMAX - infeed machine QGEN is less than QMIN - QGEN set equal to QMIN - capability curve is assigned to a non-conventional machine with machine control mode greater than 1 - invalid base-loaded machine flag - baseloaded machine has negative active power

1.2.41. MACHINE_CHNG_4

Use this API routine to modify the data of an existing machine in the working case (see PSSE Program Operation Manual, Plant Data).

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_MACHINE_CHNG_4  IBUS  'ID'  INTGAR(1)..INTGAR(7)
                     REALAR(1)..REALAR(17),NAME
```

Python command syntax:

```
ierr = machine_chng_4(ibus, id, intgar, realar, name)
```

Fortran command syntax:

```
CALL MACHINE_CHNG_4(IBUS, ID, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STAT, machine status (1 by default)
	INTGAR(2) O1, first owner number (owner of bus I by default)
	INTGAR(3) O2, second owner number (0 by default)
	INTGAR(4) O3, third owner number (0 by default)
	INTGAR(5) O4, fourth owner number (0 by default)
	INTGAR(6) WMOD, non-conventional machine reactive power limits mode (0 if this machine is a conventional machine) (0 by default)
	INTGAR(7) BASFLG, baseloaded machine flag
Real REALAR (17)	array of 17 elements specifying (input).
	REALAR(1) PG, machine active power (0.0 by default)
	REALAR(2) QG, machine reactive power (0.0 by default)
	REALAR(3) QT, machine reactive power upper limit (9999.0 by default)
	REALAR(4) QB, machine reactive power lower limit (-9999.0 by default)
	REALAR(5) PT, machine active power upper limit (9999.0 by default)
	REALAR(6) PB, machine active power lower limit (-9999.0 by default)
	REALAR(7) MBASE, machine MVA base (SBASE by default)
	REALAR(8) ZR, machine resistance (0.0 by default)

REALAR(9)	ZX, machine reactance (1.0 by default)
REALAR(10)	RT, step-up transformer resistance (0.0 by default)
REALAR(11)	XT, step-up transformer reactance (0.0 by default)
REALAR(12)	GTAP, step-up transformer tap ratio (1.0 by default)
REALAR(13)	F1, first owner fraction (1.0 by default)
REALAR(14)	F2, second owner fraction (1.0 by default)
REALAR(15)	F3, third owner fraction (1.0 by default)
REALAR(16)	F4, fourth owner fraction (1.0 by default)
REALAR(17)	WPF, non-conventional machine power factor (1.0 by default)
Character*40 NAME	name of the voltage droop control (input; " ").
Integer IERR	error code (output).
IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	machine identifier is more than two characters
IERR = 3	no plant data at this bus
IERR = 8	machine not found
IERR = 9	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid non-conventional (renewable and infeed type) machine control mode - invalid renewable machine power factor - invalid ZSORCE reactance - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - machine is no longer treated as a non-conventional machine - non-conventional machine table is full--retained as a conventional machine - machine ownership table is full--only first n owners retained - owner table is full - infeed machine QGEN is greater than QMAX - QGEN set equal to QMAX - infeed machine QGEN is less than QMIN - QGEN set equal to QMIN - capability curve is assigned to a non-conventional machine with machine control mode greater than 1 - invalid base-loaded machine flag - baseloaded machine has negative active power

1.2.42. MACHINE_DATA

This API routine is obsolete. It has been replaced by the API routine [machine_data_2](#).

Use this API to modify the data of an existing machine in the working case or to add a new machine to a plant bus in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MACHINE_DATA  IBUS  'ID'  INTGAR(1)..INTGAR(5)  REALAR(1)..REALAR(16)
```

Python command syntax:

```
ierr = machine_data(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL MACHINE_API(IBUS, ID, INTGAR, REALAR, IERR, NERR)
```

Where:

Integer IBUS	bus number (input).
Character*2 ID	machine identifier (input).
Integer INTGAR (5)	array of 5 elements specifying (input).
	INTGAR(1) STAT, machine status
	INTGAR(2) O1, first owner number
	INTGAR(3) O2, second owner number
	INTGAR(4) O3, third owner number
	INTGAR(5) O4, fourth owner number
Real REALAR (16)	array of 16 elements specifying (input).
	REALAR(1) PG, machine active power
	REALAR(2) QG, machine reactive power
	REALAR(3) QT, machine reactive power upper limit
	REALAR(4) QB, machine reactive power lower limit
	REALAR(5) PT, machine active power upper limit
	REALAR(6) PB, machine active power lower limit
	REALAR(7) MBASE, machine MVA base
	REALAR(8) ZR, machine resistance
	REALAR(9) ZX, machine reactance
	REALAR(10) RT, step-up transformer resistance
	REALAR(11) XT, step-up transformer reactance
	REALAR(12) GTAP, step-up transformer tap ratio
	REALAR(13) F1, first owner fraction
	REALAR(14) F2, second owner fraction
	REALAR(15) F3, third owner fraction

	REALAR(16)	F4, fourth owner fraction
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	no plant data at bus
	IERR = 4	blank machine identifier is invalid
	IERR = 5	machine table full
	IERR = 6	machine ownership table full
	IERR = 7	prerequisite requirements for API are not met
	IERR = 8	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid ZSORCE reactance - invalid ZSORCE: (0.0,0.0) - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - machine ownership table is full--only first n owners retained - owner table is full
Integer NERR	number of entries in PBUF02 containing error messages (output).	

1.2.43. MACHINE_DATA_2

This API routine is obsolete. It has been replaced by the API routine [machine_data_3](#).

Use this API to modify the data of an existing machine in the working case, or to add a new machine to a plant bus in the working case (see PSSE Program Operation Manual, Plant Data).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_MACHINE_DATA_2 I 'ID' INTGAR(1)..INTGAR(6) REALAR(1)..REALAR(17)
```

Python command syntax:

```
ierr = machine_data_2(i, id, intgar, realar)
```

Fortran command syntax:

```
CALL MACHINE_API_2(I, ID, INTGAR, REALAR, IERR)
```

Where:

Integer I	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) STAT, machine status (1 by default)
	INTGAR(2) O1, first owner number (owner of bus I by default)
	INTGAR(3) O2, second owner number (0 by default)
	INTGAR(4) O3, third owner number (0 by default)
	INTGAR(5) O4, fourth owner number (0 by default)
	INTGAR(6) WMOD, wind machine reactive power limits mode (0 if this machine is not a wind machine) (0 by default)
Real REALAR (17)	array of 17 elements specifying (input).
	REALAR(1) PG, machine active power (0.0 by default)
	REALAR(2) QG, machine reactive power (0.0 by default)
	REALAR(3) QT, machine reactive power upper limit (9999.0 by default)
	REALAR(4) QB, machine reactive power lower limit (-9999.0 by default)
	REALAR(5) PT, machine active power upper limit (9999.0 by default)
	REALAR(6) PB, machine active power lower limit (-9999.0 by default)
	REALAR(7) MBASE, machine MVA base (SBASE by default)

	REALAR(8)	ZR, machine resistance (0.0 by default)
	REALAR(9)	ZX, machine reactance (1.0 by default)
	REALAR(10)	RT, step-up transformer resistance (0.0 by default)
	REALAR(11)	XT, step-up transformer reactance (0.0 by default)
	REALAR(12)	GTAP, step-up transformer tap ratio (1.0 by default)
	REALAR(13)	F1, first owner fraction (1.0 by default)
	REALAR(14)	F2, second owner fraction (1.0 by default)
	REALAR(15)	F3, third owner fraction (1.0 by default)
	REALAR(16)	F4, fourth owner fraction (1.0 by default)
	REALAR(17)	WPF, wind machine power factor (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	no plant data at this bus
	IERR = 4	blank machine identifier is invalid
	IERR = 5	machine table is full
	IERR = 6	machine ownership table is full
	IERR = 8	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid wind machine control mode - invalid wind machine power factor - invalid ZSORCE: reactance - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - non-conventional machine has negative active power - machine is no longer treated as a non-conventional machine - non-conventional machine table is full--retained as a conventional machine - capability curve is assigned to a non-conventional machine with machine control mode greater than 1 - machine ownership table is full--only first n owners retained - owner table is full

1.2.44. MACHINE_DATA_3

Use this API to modify the data of an existing machine in the working case, or to add a new machine to a plant bus in the working case (see PSSE Program Operation Manual, Plant Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MACHINE_DATA_3  IBUS  'ID'  INTGAR(1) .. INTGAR(7)
                     REALAR(1) .. REALAR(17)
```

Python command syntax:

```
ierr = machine_data_3(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL MACHINE_API_3(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STAT, machine status (1 by default)
	INTGAR(2) O1, first owner number (owner of bus I by default)
	INTGAR(3) O2, second owner number (0 by default)
	INTGAR(4) O3, third owner number (0 by default)
	INTGAR(5) O4, fourth owner number (0 by default)
	INTGAR(6) WMOD, non-conventional machine reactive power limits mode (0 if this machine is a conventional machine) (0 by default)
	INTGAR(7) BASFLG, baseloaded machine flag
Real REALAR (17)	array of 17 elements specifying (input).
	REALAR(1) PG, machine active power (0.0 by default)
	REALAR(2) QG, machine reactive power (0.0 by default)
	REALAR(3) QT, machine reactive power upper limit (9999.0 by default)
	REALAR(4) QB, machine reactive power lower limit (-9999.0 by default)
	REALAR(5) PT, machine active power upper limit (9999.0 by default)
	REALAR(6) PB, machine active power lower limit (-9999.0 by default)
	REALAR(7) MBASE, machine MVA base (SBASE by default)
	REALAR(8) ZR, machine resistance (0.0 by default)

	REALAR(9)	ZX, machine reactance (1.0 by default)
	REALAR(10)	RT, step-up transformer resistance (0.0 by default)
	REALAR(11)	XT, step-up transformer reactance (0.0 by default)
	REALAR(12)	GTAP, step-up transformer tap ratio (1.0 by default)
	REALAR(13)	F1, first owner fraction (1.0 by default)
	REALAR(14)	F2, second owner fraction (1.0 by default)
	REALAR(15)	F3, third owner fraction (1.0 by default)
	REALAR(16)	F4, fourth owner fraction (1.0 by default)
	REALAR(17)	WPF, non-conventional machine power factor (1.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	no plant data at this bus
	IERR = 4	blank machine identifier is invalid
	IERR = 5	machine table is full
	IERR = 6	machine ownership table is full
	IERR = 7	node-breaker terminal connection table is full
	IERR = 9	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid non-conventional (renewable and infeed type) machine control mode - invalid renewable machine power factor - invalid ZSORCE reactance - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - machine is no longer treated as a non-conventional machine - non-conventional machine table is full--retained as a conventional machine - machine ownership table is full--only first n owners retained - owner table is full - infeed machine QGEN is greater than QMAX - QGEN set equal to QMAX - infeed machine QGEN is less than QMIN - QGEN set equal to QMIN - capability curve is assigned to a non-conventional machine with machine control mode greater than 1 - invalid base-loaded machine flag - baseloaded machine has negative active power

1.2.45. MACHINE_DATA_4

Use this API to modify the data of an existing machine in the working case, or to add a new machine to a plant bus in the working case (see PSSE Program Operation Manual, Plant Data).

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_MACHINE_DATA_4  IBUS  'ID'  INTGAR(1)..INTGAR(7)
                     REALAR(1)..REALAR(17), NAME
```

Python command syntax:

```
ierr = machine_data_4(ibus, id, intgar, realar, name)
```

Fortran command syntax:

```
CALL MACHINE_API_4(IBUS, ID, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (7)	array of 7 elements specifying (input).
	INTGAR(1) STAT, machine status (1 by default)
	INTGAR(2) O1, first owner number (owner of bus I by default)
	INTGAR(3) O2, second owner number (0 by default)
	INTGAR(4) O3, third owner number (0 by default)
	INTGAR(5) O4, fourth owner number (0 by default)
	INTGAR(6) WMOD, non-conventional machine reactive power limits mode (0 if this machine is a conventional machine) (0 by default)
	INTGAR(7) BASFLG, baseloaded machine flag
Real REALAR (17)	array of 17 elements specifying (input).
	REALAR(1) PG, machine active power (0.0 by default)
	REALAR(2) QG, machine reactive power (0.0 by default)
	REALAR(3) QT, machine reactive power upper limit (9999.0 by default)
	REALAR(4) QB, machine reactive power lower limit (-9999.0 by default)
	REALAR(5) PT, machine active power upper limit (9999.0 by default)
	REALAR(6) PB, machine active power lower limit (-9999.0 by default)
	REALAR(7) MBASE, machine MVA base (SBASE by default)
	REALAR(8) ZR, machine resistance (0.0 by default)
	REALAR(9) ZX, machine reactance (1.0 by default)

	REALAR(10)	RT, step-up transformer resistance (0.0 by default)
	REALAR(11)	XT, step-up transformer reactance (0.0 by default)
	REALAR(12)	GTAP, step-up transformer tap ratio (1.0 by default)
	REALAR(13)	F1, first owner fraction (1.0 by default)
	REALAR(14)	F2, second owner fraction (1.0 by default)
	REALAR(15)	F3, third owner fraction (1.0 by default)
	REALAR(16)	F4, fourth owner fraction (1.0 by default)
	REALAR(17)	WPF, non-conventional machine power factor (1.0 by default)
Character*40 NAME	name of the voltage droop control (input; " ").	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	no plant data at this bus
	IERR = 4	blank machine identifier is invalid
	IERR = 5	machine table is full
	IERR = 6	machine ownership table is full
	IERR = 7	node-breaker terminal connection table is full
	IERR = 9	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid machine status - invalid non-conventional (renewable and infeed type) machine control mode - invalid renewable machine power factor - invalid ZSORCE reactance - invalid owner number - invalid ownership fraction - no ownership data is specified - QMAX is less than QMIN - PMAX is less than PMIN - MBASE is not positive - machine is no longer treated as a non-conventional machine - non-conventional machine table is full--retained as a conventional machine - machine ownership table is full--only first n owners retained - owner table is full - infeed machine QGEN is greater than QMAX - QGEN set equal to QMAX - infeed machine QGEN is less than QMIN - QGEN set equal to QMIN - capability curve is assigned to a non-conventional machine with machine control mode greater than 1 - invalid base-

loaded machine flag - baseloaded machine
has negative active power

1.2.46. MBID2DC

Use this API to change the name of the specified two-terminal dc line.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBID2DC DC DCNEW
```

Python command syntax:

```
ierr = mbid2dc(dc, dcnew)
```

Fortran command syntax:

```
CALL MBID2DC(NUM, NUMNEW, IERR)
CALL MBID2DC_II(NUM, NUMNEW, IERR)
CALL MBID2DC_IC(NUM, NAMENEW, IERR)
CALL MBID2DC_CI(NAME, NUMNEW, IERR)
CALL MBID2DC_CC(NAME, NAMENEW, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which the dc line name is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer or Character*12 DCNEW	quoted new name to be assigned to the two-terminal dc line; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which the dc line name is to be changed (input; no default allowed).
Integer NUMNEW	new number to be assigned to the two-terminal dc line as a left-justified name (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line for which the dc line name is to be changed (input; no default allowed).
Character*12 NAMENEW	new dc line name to be assigned to the two-terminal dc line (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 dc line DC not found
	IERR = 2 dc line DCNEW already exists
	IERR = 3 a non-blank new identifier must be specified
	IERR = 4 prerequisite requirements for API are not met

1.2.47. MBID3WND

Use this API to change the identifier of the specified three-winding transformer.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBID3WND IBUS JBUS1 JBUS2 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbid3wnd(ibus, jbus1, jbus2, id, idnew)
```

Fortran command syntax:

```
CALL MBID3WND(IBUS, JBUS1, JBUS2, ID, IDNEW, IERR)
```

Where:

Integer IBUS	one of the buses connected by the three-winding transformer (input; no default allowed).
Integer JBUS1	other bus connected by the three-winding transformer (input; no default allowed).
Integer JBUS2	other bus connected by the three-winding transformer (input; no default allowed).
Character*2 ID	present circuit identifier of the three-winding transformer for which the identifier is to be changed (input; '1' by default).
Character*2 IDNEW	new identifier to be assigned to the three-winding transformer (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 circuit ID bus IBUS to JBUS1 to JBUS2 not found
	IERR = 3 circuit IDNEW bus IBUS to JBUS1 to JBUS2 already exists
	IERR = 4 invalid new identifier; cannot start with &, * or @
	IERR = 5 a non-blank new identifier must be specified
	IERR = 6 prerequisite requirements for API are not met

1.2.48. MBIDATRN

Use this API to change the identifier of the specified inter-area transfer.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDATRN FRMAREA TOAREA 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidatrnrn(frmarea, toarea, id, idnew)
```

Fortran command syntax:

```
CALL MBIDATRN(FRMAREA, TOAREA, ID, IDNEW, IERR)
```

Where:

Integer FRMAREA	one of the areas involved in the transfer (input; no default allowed).
Integer TOAREA	other area involved in the transfer (input; no default allowed).
Character*1 ID	present inter-area transfer identifier (input; '1' by default).
Character*1 IDNEW	new identifier to be assigned to the inter-area transfer (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid area number
	IERR = 2 inter-area transfer ID from area FRMAREA to TOAREA not found
	IERR = 3 inter-area transfer ID from area FRMAREA to TOAREA already exists
	IERR = 4 invalid new identifier--must be 0 through 9 or A through Z
	IERR = 5 prerequisite requirements for API are not met

1.2.49. MBIDBRN

Use this API to change the identifier of the specified non-transformer branch or two-winding transformer.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDBRN IBUS JBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidbrn(ibus, jbus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDBRN(IBUS, JBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	one of the buses connected by the branch (input; no default allowed).
Integer JBUS	other bus connected by the branch (input; no default allowed).
Character*2 ID	present circuit identifier of the branch for which the identifier is to be changed (input; '1' by default).
Character*2 IDNEW	new identifier to be assigned to the branch (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 circuit ID from IBUS to JBUS not found
	IERR = 3 circuit ID from IBUS to JBUS already exists
	IERR = 4 invalid new identifier; cannot start with &, * or @
	IERR = 5 a non-blank new identifier must be specified
	IERR = 6 prerequisite requirements for API are not met

1.2.50. MBIDFACTS

Use this API to change the name of the specified FACTS device.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDFACTS  FD  FDNEW
```

Python command syntax:

```
ierr = mbidfacts(fd, fdnew)
```

Fortran command syntax:

```
CALL MBIDFACTS(NUM, NUMNEW, IERR)
CALL MBIDFACTS_II(NUM, NUMNEW, IERR)
CALL MBIDFACTS_IC(NUM, NAMENEW, IERR)
CALL MBIDFACTS_CI(NAME, NUMNEW, IERR)
CALL MBIDFACTS_CC(NAME, NAMENEW, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which the FACTS device name is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer or Character*12 FDNEW	quoted new name to be assigned to the FACTS device; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which the FACTS device name is to be changed (input; no default allowed).	
Integer NUMNEW	new number to be assigned to the FACTS device as a left-justified name (input; no default allowed).	
Character*12 NAME	name of the FACTS device for which the FACTS device name is to be changed (input; no default allowed).	
Character*12 NAMENEW	new FACTS device name to be assigned to the FACTS device (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	FACTS device FD not found
	IERR = 2	FACTS device FDNEW already exists
	IERR = 3	a non-blank new identifier must be specified
	IERR = 4	prerequisite requirements for API are not met

1.2.51. MBIDGNE

Use this API routine to change the GNE device name of the specified GNE device.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_MBIDGNE  'NAME'  'NAMNEW'
```

Python command syntax:

```
ierr = mbidgne(name, namnew)
```

Fortran command syntax:

```
CALL MBIDGNE(NAME, NAMNEW, IERR)
```

Where:

Character*12 NAME	name of the GNE device for which the GNE device name is to be changed (input; no default allowed).	
Character*12 NAMNEW	new name to be assigned to the GNE device (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	GNE device NAME not found
	IERR = 2	GNE device NEWNAM already exists
	IERR = 3	a non-blank new identifier must be specified
	IERR = 4	prerequisite requirements for API are not met

1.2.52. MBIDINDMAC

Use this API routine to change the identifier of the specified induction machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MBIDINDMAC IBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidindmac(ibus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDINDMAC(IBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	bus to which induction machine ID is connected (input; no default allowed).	
Character*2 ID	present induction machine identifier of the induction machine for which the identifier is to be changed (input; '1' by default).	
Character*2 IDNEW	new identifier to be assigned to the induction machine (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	induction machine ID at bus IBUS not found
	IERR = 3	induction machine ID at bus IBUS already exists
	IERR = 4	a non-blank new identifier must be specified
	IERR = 5	prerequisite requirements for API are not met

1.2.53. MBIDLOAD

Use this API to change the identifier of the specified load.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDLOAD IBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidload(ibus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDLOAD(IBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	bus to which the load ID is connected (input; no default allowed).	
Character*2 ID	present load identifier of the load for which the identifier is to be changed (input; '1' by default).	
Character*2 IDNEW	new identifier to be assigned to the load (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	load ID at bus IBUS not found
	IERR = 3	load ID at bus IBUS already exists
	IERR = 4	a non-blank new identifier must be specified
	IERR = 5	prerequisite requirements for API are not met

1.2.54. MBIDMAC

Use this API to change the identifier of the specified machine.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDMAC IBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidmac(ibus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDMAC(IBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	bus to which the machine ID is connected (input; no default allowed).	
Character*2 ID	present machine identifier of the machine for which the identifier is to be changed (input; '1' by default).	
Character*2 IDNEW	new identifier to be assigned to the machine (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	machine ID at bus IBUS not found
	IERR = 3	machine ID at bus IBUS already exists
	IERR = 4	a non-blank new identifier must be specified
	IERR = 5	prerequisite requirements for API are not met

1.2.55. MBIDMDC

Use this API to change the name of the specified multi-terminal dc line.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDMDC DC DCNEW
```

Python command syntax:

```
ierr = mbidmdc(dc, dcnew)
```

Fortran command syntax:

```
CALL MBIDMDC(NUM, NUMNEW, IERR)
CALL MBIDMDC_II(NUM, NUMNEW, IERR)
CALL MBIDMDC_IC(NUM, NAMENEW, IERR)
CALL MBIDMDC_CI(NAME, NUMNEW, IERR)
CALL MBIDMDC_CC(NAME, NAMENEW, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which the dc line name is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer or Character*12 DCNEW	quoted new name to be assigned to the multi-terminal dc line; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which the dc line name is to be changed (input; no default allowed).	
Integer NUMNEW	new number to be assigned to the multi-terminal dc line as a left-justified name (input; no default allowed).	
Character*12 NAME	name of the multi-terminal dc line for which the dc line name is to be changed (input; no default allowed).	
Character*12 NAMENEW	new dc line name to be assigned to the multi-terminal dc line (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	dc line DC not found
	IERR = 2	dc line DCNEW already exists
	IERR = 3	a non-blank new identifier must be specified
	IERR = 4	prerequisite requirements for API are not met

1.2.56. MBIDMSL

Use this API to change the identifier of the specified multi-section line.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MBIDMSL IBUS JBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidmsl(ibus, jbus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDMSL(IBUS, JBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	one of the endpoint buses connected by the multi-section line (input; no default allowed).	
Integer JBUS	other endpoint bus connected by the multi-section line (input; no default allowed).	
Character*2 ID	present multi-section identifier of the multi-section line for which the identifier is to be changed (input; '&1' by default).	
Character*2 IDNEW	new identifier to be assigned to the multi-section line (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	multi-section line ID from IBUS to JBUS not found
	IERR = 3	multi-section line ID from IBUS to JBUS already exists
	IERR = 4	invalid new identifier; must start with &
	IERR = 5	prerequisite requirements for API are not met

1.2.57. MBIDSHUNT

Use this API to change the identifier of the specified fixed bus shunt.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_MBIDSHUNT IBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidshunt(ibus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDSHUNT(IBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	bus to which the shunt ID is connected (input; no default allowed).	
Character*2 ID	present shunt identifier of the shunt for which the identifier is to be changed (input; '1' by default).	
Character*2 IDNEW	new identifier to be assigned to the shunt (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	shunt ID at bus IBUS not found
	IERR = 3	shunt ID at bus IBUS already exists
	IERR = 4	a non-blank new identifier must be specified
	IERR = 5	prerequisite requirements for API are not met

1.2.58. MBIDSWSHUNT

Use this API to change the identifier of the specified switched bus shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MBIDSWSHUNT IBUS 'ID' 'IDNEW'
```

Python command syntax:

```
ierr = mbidswshunt(ibus, id, idnew)
```

Fortran command syntax:

```
CALL MBIDSWSHUNT(IBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	bus to which switched shunt "ID" is connected (input; no default allowed).	
Character*2 ID	present shunt identifier of the shunt for which the identifier is to be changed (input; '1' by default).	
Character*2 IDNEW	new identifier to be assigned to the shunt (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	switched shunt "ID" at bus IBUS not found
	IERR = 3	switched shunt "ID" at bus IBUS already exists
	IERR = 4	a non-blank new identifier must be specified
	IERR = 5	prerequisite requirements for API are not met

1.2.59. MBIDVD

Use this API to change the voltage droop control name of the specified voltage droop control in the working case.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_MBIDVD 'NAME' 'NAMNEW'
```

Python command syntax:

```
ierr = mbidvd(name, namnew)
```

Fortran command syntax:

```
CALL MBIDVD(NAME, NAMNEW, IERR)
```

Where:

Character*40 NAME	name of the voltage droop control for which the voltage droop control name is to be changed (input; no default allowed).	
Character*40 NAMNEW	new name to be assigned to the voltage droop control (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	voltage droop control NAME not found
	IERR = 2	voltage droop control NEWNAM already exists
	IERR = 3	a non-blank new identifier must be specified
	IERR = 4	prerequisite requirements for API are not met

1.2.60. MBIDVSC

Use this API to change the VSC dc line name of the specified VSC dc line.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_MBIDVSC  'NAME'  'NAMNEW'
```

Python command syntax:

```
ierr = mbidvsc(name, namnew)
```

Fortran command syntax:

```
CALL MBIDVSC(NAME, NAMNEW, IERR)
```

Where:

Character*12 NAME	name of the VSC dc line for which the VSC dc line name is to be changed (input; no default allowed).	
Character*12 NAMNEW	new name to be assigned to the VSC dc line (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	dc line NAME not found
	IERR = 2	dc line NEWNAM already exists
	IERR = 3	a non-blank new identifier must be specified
	IERR = 4	prerequisite requirements for API are not met

1.2.61. MULTI_SECTION_LINE_DATA

Use this API to modify the definition of an existing multi-section line grouping in the working case or to add a new multi-section line grouping to the working case (see PSSE Program Operation Manual, Multi-Section Line Grouping Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MULTI_SECTION_LINE_DATA  IBUS  JBUS  'ID'  INTGAR(1)..INTGAR(10)
```

Python command syntax:

```
ierr = multi_section_line_data(ibus, jbus, id, intgar)
```

Fortran command syntax:

```
CALL MULTI_SECTION_LINE_API_2(IBUS, JBUS, ID, INTGAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 ID	a multi-section line identifier; ID(1:1) must be '&' (input; '&1' by default).
Integer INTGAR (10)	array of 10 elements specifying (input).
	INTGAR(1) METBUS, metered end bus number (must be IBUS or JBUS) (IBUS by default)
	INTGAR(2) DUM1 through DUM9 entries 2 through 10 are the bus numbers of the dummy buses encountered along this multi-section line, starting with the bus to which bus 'IBUS' is connected and ending with the bus to which bus 'JBUS' is connected; entries used are 2 through n+1, where n is the number of dummy buses; if n+1 is less than 10, entries n+2 through 10 must be set to 0 (No default is allowed for entry 2; entries 3 through 10 are 0)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 multi-section line identifier is more than two characters
	IERR = 3 multi-section line identifier does not start with &
	IERR = 4 no dummy buses specified
	IERR = 5 line section not found

IERR = 6	circuit is already a member of another multi-section line
IERR = 7	bus appears more than once in the multi-section line path
IERR = 8	dummy bus does not have exactly two branches connected to it
IERR = 9	dummy bus is a converter bus of a dc line
IERR = 10	a FACTS device is connected to a dummy bus
IERR = 11	line section table is full
IERR = 12	multi-section line table is full
IERR = 13	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - branch status and bus type code changes

1.2.62. MULTI_SECTION_LINE_EDIT

Use this API to modify the status and/or metered end designation of an existing multi-section line grouping in the working case (see PSSE Program Operation Manual, Multi-Section Line Grouping Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MULTI_SECTION_LINE_EDIT IBUS JBUS 'ID' INTGAR(1) INTGAR(2)
```

Python command syntax:

```
ierr = multi_section_line_edit(ibus, jbus, id, intgar)
```

Fortran command syntax:

```
CALL MULTI_SECTION_LINE_EDIT_API_2(IBUS, JBUS, ID, INTGAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 ID	multi-section line identifier; ID(1:1) must be '&' (input; '&1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) STAT, branch status (unchanged by default)
	INTGAR(1) = 1 for in-service
	INTGAR(1) = 0 for out-of-service
	INTGAR(2) METBUS, metered end bus number (must be IBUS or JBUS) (unchanged by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 multi-section line identifier is more than two characters
	IERR = 3 multi-section line identifier does not start with &
	IERR = 4 multi-section line not found
	IERR = 5 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - invalid metered end bus. - invalid branch status

1.2.63. MULTI_TERM_DC_BUS_DATA

Use this API to modify the data of a dc bus of an existing multi-terminal dc line in the working case or to add a new dc bus to a multi-terminal dc line in the working case (see PSSE Program Operation Manual, Multi-Terminal DC Transmission Line Data). The dc line must have previously been specified via the MULTI_TERM_DC_LINE_DATA API.

just some stupid words to see if they show up

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MULTI_TERM_DC_BUS_DATA DC IDC INTGAR(1)..INTGAR(5) REALAR(1)
'DCNAME'
```

Python command syntax:

```
ierr, realaro = multi_term_dc_bus_data(dc, idc, intgar, realari, dcname)
```

Fortran command syntax:

```
CALL MULTI_TERMINAL_DC_BUS_API(NUM, IDC, INTGAR, REALAR, DCNAME, IERR)
CALL MULTI_TERMINAL_DC_BUS_API_I(NUM, IDC, INTGAR, REALAR, DCNAME, IERR)
CALL MULTI_TERMINAL_DC_BUS_API_C(NAME, IDC, INTGAR, REALAR, DCNAME, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which data for a dc bus is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which data for a dc bus is to be specified; no default allowed
Character*12 NAME	name of the multi-terminal dc line for which data for a dc bus is to be specified; no default allowed
Integer IDC	dc bus number (must be between 1 and the number of dc buses in multi-terminal dc line DC) (input; no default allowed).
Integer INTGAR (5)	array of 5 elements specifying (input). INTGAR(1) IB, converter bus number or zero (0 by default) INTGAR(2) AREA, area number (1 by default) INTGAR(3) ZONE, zone number (1 by default) INTGAR(4) OWNER, owner number (1 by default) INTGAR(5) IDC2, second dc bus number (0 by default)
Real REALAR (2)	(first value is input; second value is output) (input (output).).
Real REALARI (1)	array of 1 elements specifying one element corresponding to values REALAR(1) as described above(input). REALARI(1) RGRND, resistance to ground (0.0 by default)

Real REALARO (1)	array of 1 elements specifying one element corresponding to value REALAR(2) as described above(output).
	REALARO(1) dc voltage (kV) (returned)
Character*12 DCNAME	dc bus name (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 dc line not found
	IERR = 2 invalid dc bus number
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information mes-
	sages; one or more of: - data for lower num-
	bered dc bus has not yet been entered. - con-
	verter bus not found. - bus is not a converter
	of this multi-terminal dc line. - this dc bus is
	not the first dc bus of any converter. - the first
	dc bus of some converter is set to this dc bus.
	- invalid second dc bus number. - this dc bus
	is being connected to a converter bus. - dc
	bus no longer connected to some other con-
	verter. - dc bus is being specified with no con-
	verter bus. - dc bus no longer connected to
	converter as its first dc bus. - dc bus no longer
	connected to converter as its second dc bus.
	- bus invalid as second dc bus because it is
	the first dc bus of another converter. - invalid
	area/zone/owner number. - area table is full. -
	zone table is full. - owner table is full

1.2.64. MULTI_TERM_DC_CONV_DATA

Use this API to modify the data of a dc converter of an existing multi-terminal dc line in the working case or to add a new converter to a multi-terminal dc line in the working case (see PSSE Program Operation Manual, Multi-Terminal DC Transmission Line Data). The dc line must have previously been specified via the MULTI_TERM_DC_LINE_DATA API.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MULTI_TERM_DC_CONV_DATA  DC  INTGAR(1)..INTGAR(4)
    REALAR(1)..REALAR(13)
```

Python command syntax:

```
ierr, realaro = multi_term_dc_conv_data(dc, intgar, realari)
```

Fortran command syntax:

```
CALL MULTI_TERM_DC_CONVERTER_API(NUM, INTGAR, REALAR, IERR)
CALL MULTI_TERM_DC_CONVERTER_API_I(NUM, INTGAR, REALAR, IERR)
CALL MULTI_TERM_DC_CONVERTER_API_C(NAME, INTGAR, REALAR, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which data for a converter is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).																
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which data for a converter is to be specified; no default allowed																
Character*12 NAME	name of the multi-terminal dc line for which data for a converter is to be specified; no default allowed																
Integer INTGAR (4)	array of 4 elements specifying (input). <table border="0"> <tr> <td>INTGAR(1)</td><td>IB, converter bus number (no default allowed)</td></tr> <tr> <td>INTGAR(2)</td><td>N, number of bridges in series (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>CNVCOD, pole code (0 by default)</td></tr> <tr> <td>INTGAR(3) >= 0</td><td>for a positive pole converter</td></tr> <tr> <td>INTGAR(3) < 0</td><td>for a negative pole converter</td></tr> <tr> <td>INTGAR(4)</td><td>VCCFLG, pole's voltage controlling converter flag (0 by default)</td></tr> <tr> <td>INTGAR(4) <= 0</td><td>no</td></tr> <tr> <td>INTGAR(4) > 0</td><td>yes</td></tr> </table>	INTGAR(1)	IB, converter bus number (no default allowed)	INTGAR(2)	N, number of bridges in series (1 by default)	INTGAR(3)	CNVCOD, pole code (0 by default)	INTGAR(3) >= 0	for a positive pole converter	INTGAR(3) < 0	for a negative pole converter	INTGAR(4)	VCCFLG, pole's voltage controlling converter flag (0 by default)	INTGAR(4) <= 0	no	INTGAR(4) > 0	yes
INTGAR(1)	IB, converter bus number (no default allowed)																
INTGAR(2)	N, number of bridges in series (1 by default)																
INTGAR(3)	CNVCOD, pole code (0 by default)																
INTGAR(3) >= 0	for a positive pole converter																
INTGAR(3) < 0	for a negative pole converter																
INTGAR(4)	VCCFLG, pole's voltage controlling converter flag (0 by default)																
INTGAR(4) <= 0	no																
INTGAR(4) > 0	yes																
Real REALAR (17)	(first thirteen are input values; last four are output values) (input (output)).																
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input).																

	REALARI(1)	SETVL, scheduled current (amps), power (MW) or voltage (kv) (0.0 by default)
	REALARI(2)	MN, minimum firing angle (0.0 by default)
	REALARI(3)	MX, maximum firing angle (90.0 by default)
	REALARI(4)	TR, transformer ratio (1.0 by default)
	REALARI(5)	RC, commutating resistance (0.0 by default)
	REALARI(6)	XC, commutating reactance (0.0 by default)
	REALARI(7)	EBAS, primary base ac voltage (1.0 by default)
	REALARI(8)	TAP, tap setting (1.0 by default)
	REALARI(9)	TPMX, maximum tap setting (1.5 by default)
	REALARI(10)	TPMN, minimum tap setting (0.51 by default)
	REALARI(11)	TSTP, tap step (0.00625 by default)
	REALARI(12)	MARG, margin (pu) (0.0 by default)
	REALARI(13)	DCPF, converter participation factor (1.0 by default)
Real REALARO (4)	array of 4 elements specifying corresponding to values REALAR(14) through REALAR(17) as described above(output).	
	REALARO(1)	firing angle (returned)
	REALARO(2)	converter current (amps) (returned)
	REALARO(3)	active power into converter (MW or kW) (returned)
	REALARO(4)	reactive power into converter (MW or kW) (returned)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	dc line not found
	IERR = 2	no converter bus is specified
	IERR = 3	converter bus not found
	IERR = 4	too many converters specified
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - converter bus is a dummy bus of a multi-section line. - multi-section line grouping deleted. - invalid number of bridges. - invalid base ac voltage. - converter maximum angle is less than its minimum angle. - converter maximum tap is less than its minimum tap. - invalid tap step. - dc voltage setpoint is not positive. - scheduled voltage is less than mode switch voltage. - this converter bus is now on the other pole; it

is no longer the voltage controlling converter of its previous pole. - there is no voltage controlling converter on a pole. - this converter replaces another converter as its pole's voltage controlling converter. - this converter must remain its pole's voltage controlling converter because it is the only converter on the pole

1.2.65. MULTI_TERM_DC_LINE_CHNG

Use this API routine to modify the control mode and mode switch voltage of an existing multi-terminal dc line in the working case (see PSSE Program Operation Manual, Multi-Terminal DC Transmission Line Data). Converter data, dc bus data, and dc link data are specified via the MULTI_TERM_DC_CONVR_DATA, MULTI_TERM_DC_BUS_DATA, and MULTI_TERM_DC_LINK_DATA API routines respectively.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_MULTI_TERM_DC_LINE_CHNG DC INTGAR(1) REALAR(1)
```

Python command syntax:

```
ierr, intgaro = multi_term_dc_line_chng(dc, intgari, realar)
```

Fortran command syntax:

```
CALL MULTI_TERMINAL_DC_LINE_CHNG(NUM, INTGAR, REALAR, IERR)
CALL MULTI_TERMINAL_DC_LINE_CHNG_I(NUM, INTGAR, REALAR, IERR)
CALL MULTI_TERMINAL_DC_LINE_CHNG_C(NAME, INTGAR, REALAR, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which data is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which data is to be specified; no default allowed
Character*12 NAME	name of the multi-terminal dc line for which data is to be specified; no default allowed
Integer INTGAR (8)	(first value is input; last seven are output values) (input (output)).
Integer INTGARI (1)	array of 1 elements specifying one element corresponding to value INTGAR(1) as described above(input). INTGARI(1) MDC, control mode (0 by default)
Integer INTGARO (7)	array of 7 elements specifying corresponding to values INTGAR(2) through INTGAR(8) as described above(output). INTGARO(1) positive pole voltage controlling converter index (returned) INTGARO(2) negative pole voltage controlling converter index, or zero if the negative pole is not being modeled (returned) INTGARO(3) positive pole voltage controlling converter bus number (returned) INTGARO(4) positive pole voltage controlling converter bus number (returned)

	INTGARO(5)	number of converters (returned)
	INTGARO(6)	number of dc buses (returned)
	INTGARO(7)	number of dc links (returned)
Real REALAR (1)	array of 1 elements specifying (input).	
	REALAR(1)	VCMOD, mode switch dc voltage (kV) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 2	blank dc line name is invalid
	IERR = 3	dc line not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode

1.2.66. MULTI_TERM_DC_LINE_DATA

Use this API to modify the control mode and mode switch voltage of an existing multi-terminal dc line in the working case or to add a new multi-terminal dc line to the working case (see PSSE Program Operation Manual, Multi-Terminal DC Transmission Line Data). Converter data, dc bus data, and dc link data are specified via the MULTI_TERM_DC_CONV_DATA, MULTI_TERM_DC_BUS_DATA, and MULTI_TERM_DC_LINK_DATA APIs respectively.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MULTI_TERM_DC_LINE_DATA DC INTGAR(1) REALAR(1)
```

Python command syntax:

```
ierr, intgaro = multi_term_dc_line_data(dc, intgari, realar)
```

Fortran command syntax:

```
CALL MULTI_TERMINAL_DC_LINE_API(NUM, INTGAR, REALAR, IERR)
CALL MULTI_TERMINAL_DC_LINE_API_I(NUM, INTGAR, REALAR, IERR)
CALL MULTI_TERMINAL_DC_LINE_API_C(NAME, INTGAR, REALAR, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which data is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which data is to be specified; no default allowed
Character*12 NAME	name of the multi-terminal dc line for which data is to be specified; no default allowed
Integer INTGAR (8)	(first value is input; last seven are output values) (input (output)).
Integer INTGARI (1)	array of 1 elements specifying one element corresponding to value INTGAR(1) as described above(input). INTGARI(1) MDC, control mode (0 by default)
Integer INTGARO (7)	array of 7 elements specifying corresponding to values INTGAR(2) through INTGAR(8) as described above(output). INTGARO(1) positive pole voltage controlling converter index (returned) INTGARO(2) negative pole voltage controlling converter index, or zero if the negative pole is not being modeled (returned) INTGARO(3) positive pole voltage controlling converter bus number (returned) INTGARO(4) positive pole voltage controlling converter bus number (returned)

	INTGARO(5)	number of converters (returned)
	INTGARO(6)	number of dc buses (returned)
	INTGARO(7)	number of dc links (returned)
Real REALAR (1)	array of 1 elements specifying (input).	
	REALAR(1)	VCMOD, mode switch dc voltage (kV) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	multi-terminal dc line table is full
	IERR = 2	blank dc line name is invalid
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode

1.2.67. MULTI_TERM_DC_LINK_DATA

Use this API to modify the data of a dc link of an existing multi-terminal dc line in the working case or to add a new dc link to a multi-terminal dc line in the working case (see PSSE Program Operation Manual, Multi-Terminal DC Transmission Line Data). The dc line must have previously been specified via the MULTI_TERM_DC_LINE_DATA API.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MULTI_TERM_DC_LINK_DATA DC IDC JDC 'DCCKT' INTGAR(1) REALAR(1)
REALAR(2)
```

Python command syntax:

```
ierr = multi_term_dc_link_data(dc, idc, jdc, dcckt, intgar, realar)
```

Fortran command syntax:

```
CALL MULTI_TERMINAL_DC_LINK_API(NUM, IDC, JDC, DCCKT, INTGAR, REALAR,
IERR)

CALL MULTI_TERMINAL_DC_LINK_API_I(NUM, IDC, JDC, DCCKT, INTGAR, REALAR,
IERR)

CALL MULTI_TERMINAL_DC_LINK_API_C(NAME, IDC, JDC, DCCKT, INTGAR, REALAR,
IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which data for a dc link is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which data for a dc link is to be specified; no default allowed
Character*12 NAME	name of the multi-terminal dc line for which data for a dc link is to be specified; no default allowed
Integer IDC	dc bus number of from bus (must be between 1 and the number of dc buses in multi-terminal dc line DC) (input; no default allowed).
Integer JDC	dc bus number of to bus (must be between 1 and the number of dc buses in multi-terminal dc line DC) (input; no default allowed).
Character*1 DCCKT	circuit identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) METBUS, metered end dc bus number (IDC by default)
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) RDC, dc link resistance (0.0 by default) REALAR(2) LDC, dc link inductance (0.0 by default)

Integer IERR

error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	dc line not found
IERR = 2	invalid dc bus number
IERR = 3	circuit identifier is more than one character
IERR = 4	dc bus not present in this multi-terminal dc line
IERR = 5	branch from a bus to itself
IERR = 6	too many dc links in this multi-terminal dc line
IERR = 7	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus. - invalid dc link resistance. - invalid dc link inductance

1.2.68. OWNER_DATA

Use this API to modify owner data in the working case (see PSSE Program Operation Manual, Interarea Transfer Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OWNER_DATA IOWNER 'OWNAME'
```

Python command syntax:

```
ierr = owner_data(iowner, owname)
```

Fortran command syntax:

```
CALL OWNER_API_2(IOWNER, OWNAME, IERR)
```

Where:

Integer IOWNER	owner number between 1 and 9999 (input; no default allowed).
Character*12 OWNAME	owner name (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 invalid owner number
	IERR = 2 owner table is full
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information mes-
	sages; one or more of: - no equipment is as-
	signed to owner

1.2.69. PBUS_ADD_MOD

Use this API to add or modify transaction event participating bus data.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PBUS_ADD_MOD  EVENT  IBUS  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = pbus_add_mod(event, ibus, realar)
```

Fortran command syntax:

```
CALL PBUS_ADD_MOD(EVENT, IBUS, REALAR, IERR, NERR)
```

Where:

Integer EVENT	transaction event number (input).
Integer IBUS	number of the participating bus (input).
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) participating bus load value
	REALAR(2) participating bus generation value
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 error occurred
	IERR = 2 invalid transaction event number
	IERR = 3 transaction event not found
	IERR > 3 unable to add or modify participating bus data; error condition detected in data access routine
	IERR = 10 prerequisite requirements for API are not met
	IERR = -1 warnings: - None
Integer NERR	number of error entries in PBUF02 (output).

1.2.70. PBUS_DELETE

Use this API to remove a bus from the set of buses that are participating in a transaction event.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PBUS_DELETE  EVENT  IBUS
```

Python command syntax:

```
ierr = pbus_delete(event, ibus)
```

Fortran command syntax:

```
CALL PBUS_DELETE(EVENT, IBUS, IERR, NERR)
```

Where:

Integer EVENT	transaction event number (input).	
Integer IBUS	number of the participating bus (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid transaction event number
	IERR = 2	transaction event not found
	IERR = 3	prerequisite requirements for API are not met
Integer NERR	number of error entries in PBUF02 (output).	

1.2.71. PLANT_CHNG

This API routine is obsolete. It has been replaced by the API routine [plant_chng_3](#).

Use this API routine to modify the data of an existing plant in the working case, if the plant bus is not a bus section within a substation. Use `plant_chng_3` if data is to be modified at a plant associated with a bus section.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_PLANT_CHNG  IBUS  INTGAR(1)  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = plant_chng(ibus, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_CHNG(IBUS, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input).
	INTGAR(1) IREG, remote bus number (0 to control voltage at bus IBUS) (0 by default)
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) VS, scheduled voltage magnitude (1.0 by default)
	REALAR(2) RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 3 no plant at bus
	IERR = 4 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - plant specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - RMPCT is not positive

1.2.72. PLANT_CHNG_3

This API routine is obsolete. It has been replaced by the API routine [plant_chng_4](#).

Use this API routine to modify the data of an existing plant that is part of a substation in the working case. If the substation has been split into multiple bus sections, use this API to designate the bus number and a node number within the bus section of the plant that the data is to be changed.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_PLANT_CHNG_3  IBUS  INODE  INTGAR(1)  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = plant_chng_3(ibus, inode, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_CHNG_3(IBUS, INODE, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INODE	node number within the bus section for which the plant resides (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) IREG, remote bus number (0 to control voltage at bus IBUS) (0 by default)
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) VS, scheduled voltage magnitude (1.0 by default) REALAR(2) RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 bus not found IERR = 3 no plant at bus IERR = 4 prerequisite requirements for API are not met IERR = -1 data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - plant specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - RMPCT is not positive

1.2.73. PLANT_CHNG_4

Use this API routine to modify the data of an existing plant that is part of a substation in the working case. If the substation has been split into multiple bus sections, use this API to designate the bus number and a node number within the bus section of the plant that the data is to be changed.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_PLANT_CHNG_4  IBUS  INODE  INTGAR(1)  INTGAR(2)  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = plant_chng_4(ibus, inode, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_CHNG_4(IBUS, INODE, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INODE	node number within the bus section for which the plant resides (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) IREG, remote bus number (0 to control voltage at bus IBUS) (0 by default) INTGAR(2) NREG, regulated bus node number (0 to control voltage at the "parent" bus section of bus IBUS)
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) VS, scheduled voltage magnitude (1.0 by default) REALAR(2) RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 bus not found IERR = 3 no plant at bus IERR = 4 invalid bus number IERR = 5 INODE is an invalid node number IERR = 6 bus IBUS does not belong to a substation IERR = 7 node INODE is not found in the substation of bus IBUS IERR = 8 node INODE is not connected to any bus section of bus IBUS

IERR = 9	INODE must be 0 for a bus that is not yet a generator bus
IERR = 10	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - type code of regulated bus is not 1 or 2 - RMPCT is not positive - per unit scheduled voltage is outside of the band 0.5 to 1.5 p.u. - invalid node number - non-zero regulated node specified but regulated bus does not belong to a substation - regulated node not found - regulated node is not connected to any bus section of the regulated bus - a remote regulated bus is specified for a type 3 bus

1.2.74. PLANT_DATA

This API routine is obsolete. It has been replaced by the API routine [plant_data_3](#).

Use this API to modify the data of an existing plant in the working case, or to add a new plant to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLANT_DATA  IBUS  INTGAR(1)  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = plant_data(ibus, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_API_2(IBUS, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input).
	INTGAR(1) IREG, remote bus number (0 to control voltage at bus IBUS) (0 by default)
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) VS, scheduled voltage magnitude (1.0 by default)
	REALAR(2) RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 plant table is full
	IERR = 4 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - plant specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - RMPCT is not positive

1.2.75. PLANT_DATA_3

This API routine is obsolete. It has been replaced by the API routine [plant_data_4](#).

Use this API to modify the data of an existing plant in the working case, or to add a new plant to the working case (see PSSE Program Operation Manual, Fixed Bus Shunt Data).

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_PLANT_DATA_3  IBUS  INODE  INTGAR(1)  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = plant_data_3(ibus, inode, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_API_3(IBUS, INODE, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INODE	bus section node number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) IREG, remote bus number (0 to control voltage at bus IBUS) (0 by default)
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) VS, scheduled voltage magnitude (1.0 by default) REALAR(2) RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 bus not found IERR = 2 plant table is full IERR = 4 prerequisite requirements for API are not met IERR = -1 data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - plant specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - RMPCT is not positive

1.2.76. PLANT_DATA_4

Use this API to modify the data of an existing plant in the working case, or to add a new plant to the working case (see PSSE Program Operation Manual, Fixed Bus Shunt Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_PLANT_DATA_4  IBUS  INODE  INTGAR(1)  INTGAR(2)  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = plant_data_4(ibus, inode, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_API_4(IBUS, INODE, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INODE	bus section node number (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) IREG, remote bus number (0 to control voltage at bus IBUS) (0 by default)
	INTGAR(2) NREG, regulated bus node number (0 to control voltage at the "parent" bus section of bus IBUS) (0 by default)
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) VS, scheduled voltage magnitude (1.0 by default)
	REALAR(2) RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 plant table is full
	IERR = 4 invalid bus number
	IERR = 5 INODE is an invalid node number
	IERR = 6 bus IBUS does not belong to a substation
	IERR = 7 node INODE is not found in the substation of bus IBUS
	IERR = 8 node INODE is not connected to any bus section of bus IBUS
	IERR = 9 INODE must be 0 for a bus that is not yet a generator bus

IERR = 10

IERR = -1

prerequisite requirements for API are not met
data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - type code of regulated bus is not 1 or 2 - RMPCT is not positive - per unit scheduled voltage is outside of the band 0.5 to 1.5 p.u. - invalid node number - non-zero regulated node specified but regulated bus does not belong to a substation - regulated node not found - regulated node is not connected to any bus section of the regulated bus - a remote regulated bus is specified for a type 3 bus

1.2.77. PURG

Use this API routine to delete specified outaged equipment items from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURG  SID  ALL  OPT  STATUS
```

Python command syntax:

```
ierr = purg(sid, all, opt, status)
```

Fortran command syntax:

```
CALL PURGNW(SID, ALL, OPT, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer OPT	equipment type to remove (input; 1 by default). OPT = 1 ac lines OPT = 2 switched shunts OPT = 3 machines OPT = 4 plants OPT = 5 two-terminal dc lines OPT = 6 multi-terminal dc lines OPT = 7 loads OPT = 8 FACTS devices OPT = 9 three-winding transformers OPT = 10 VSC dc lines OPT = 11 fixed bus shunts OPT = 12 GNE devices OPT = 13 induction machines
Integer STATUS	option for the treatment of out-of-service ties to other systems (input; 0 by default). STATUS = 0 keep out-of-service ties STATUS = 1 remove out-of-service ties
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined

IERR = 2	invalid ALL value
IERR = 3	invalid OPT value
IERR = 4	invalid STATUS value
IERR = 5	prerequisite requirements for API are not met

1.2.78. PURG2DC

Use this API to delete the specified two-terminal dc line from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURG2DC  DC
```

Python command syntax:

```
ierr = purg2dc(dc)
```

Fortran command syntax:

```
CALL PURG2DC(NUM, IERR)
```

```
CALL PURG2DC_I(NUM, IERR)
```

```
CALL PURG2DC_C(NAME, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line to be removed; no default allowed	
Character*12 NAME	name of the two-terminal dc line to be removed; no default allowed	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	dc line not found
	IERR = 2	prerequisite requirements for API are not met

1.2.79. PURG3WND

Use this API to delete the specified three-winding transformer from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURG3WND  IBUS  JBUS  KBUS  'CKT'
```

Python command syntax:

```
ierr = purg3wnd(ibus, jbus, kbus, ckt)
```

Fortran command syntax:

```
CALL PURG3WND(IBUS, JBUS, KBUS, CKT, IERR)
```

Where:

Integer IBUS	one of the buses connected by the three-winding transformer (input; no default allowed).	
Integer JBUS	the bus connected by the three-winding transformer (input; no default allowed).	
Integer KBUS	other bus connected by the three-winding transformer (input; no default allowed).	
Character*2 CKT	circuit identifier of the three-winding transformer to be deleted (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	three-winding transformer not found
	IERR = 3	prerequisite requirements for API are not met

1.2.80. PURGAREA

Use this API to delete areas with no equipment assigned to them from the working case.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_PURGAREA  SID  ALL
```

Python command syntax:

```
ierr = purgarea(sid, all)
```

Fortran command syntax:

```
CALL PURGAREA(SID, ALL, IERR)
```

Where:

Integer SID	a valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all areas or specified subsystem flag (input; 1 by default).	
	ALL = 0	delete only areas in area subsystem SID with no equipment assigned to them.
	ALL = 1	delete all areas with no equipment assigned to them.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.2.81. PURGATRN

Use this API to delete the specified inter-area transfer from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGATRN FRMAREA TOAREA 'ID'
```

Python command syntax:

```
ierr = purgatrn(frmarea, toarea, id)
```

Fortran command syntax:

```
CALL PURGATRN(FRMAREA, TOAREA, ID, IERR)
```

Where:

Integer FRMAREA	one of the areas involved in the transfer (input; no default allowed).
Integer TOAREA	other area involved in the transfer (input; no default allowed).
Character*1 ID	inter-area transfer identifier (input; '1' by default).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 area not found
	IERR = 2 inter-area transfer not found
	IERR = 3 prerequisite requirements for API are not met

1.2.82. PURGBRN

Use this API to delete the specified non-transformer branch or two-winding transformer from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGBRN  IBUS  JBUS  'CKT'
```

Python command syntax:

```
ierr = purgbrn(ibus, jbus, ckt)
```

Fortran command syntax:

```
CALL PURGBRN(IBUS, JBUS, CKT, IERR)
```

Where:

Integer IBUS	one of the buses connected by the branch (input; no default allowed).	
Integer JBUS	other bus connected by the branch (input; no default allowed).	
Character*2 CKT	circuit identifier of the branch to be deleted (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	branch not found
	IERR = 3	prerequisite requirements for API are not met

1.2.83. PURGCAPCURVE

Use this API to delete the specified machine's capability curve from the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PURGCAPCURVE  IBUS  'ID'
```

Python command syntax:

```
ierr = purgcapcurve(ibus, id)
```

Fortran command syntax:

```
CALL PURGCAPCURVE(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus to which the specified machine is connected (input; no default allowed).	
Character*2 ID	identifier of the machine whose capability curve is to be removed (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no machines at the bus
	IERR = 3	machine not found
	IERR = 4	capability curve not found for this machine
	IERR = 5	prerequisite requirements for API are not met

1.2.84. PURGE_MULTI_TERM_DC_BUS

Use this API to delete the specified dc bus from the specified multi-terminal dc line in the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_MULTI_TERM_DC_BUS  DC  IBUS
```

Python command syntax:

```
ierr = purge_multi_term_dc_bus(dc, ibus)
```

Fortran command syntax:

```
CALL PURGMDC_DC_BUS_API(NUM, IBUS, IERR, NERR)
```

```
CALL PURGMDC_DC_BUS_API_I(NUM, IBUS, IERR)
```

```
CALL PURGMDC_DC_BUS_API_C(NAME, IBUS, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line from which a dc bus is to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line from which a dc bus is to be removed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line from which a dc bus is to be removed (input; no default allowed).
Integer IBUS	number of the dc bus to be removed (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 dc line not found
	IERR = 2 invalid dc bus number
	IERR = 3 dc bus not present in this multi-terminal dc line
	IERR = 4 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - dc bus no longer connected to converter as first dc bus. - dc bus no longer connected to converter as second dc bus. - dc link deleted
Integer NERR	number of error entries in PBUF02

1.2.85. PURGE_MULTI_TERM_DC_CONVR

Use this API to delete the specified converter from the specified multi-terminal dc line in the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_MULTI_TERM_DC_CONVR  DC  IBUS
```

Python command syntax:

```
ierr = purge_multi_term_dc_convr(dc, ibus)
```

Fortran command syntax:

```
CALL PURGMDC_CONVERTER_API(NUM, IBUS, IERR)
```

```
CALL PURGMDC_CONVERTER_API_I(NUM, IBUS, IERR)
```

```
CALL PURGMDC_CONVERTER_API_C(NAME, IBUS, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line from which a converter is to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line from which a converter is to be removed (input; no default allowed).	
Character*12 NAME	name of the multi-terminal dc line from which a converter is to be removed (input; no default allowed).	
Integer IBUS	number of the ac bus from which the converter is to be removed (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	dc line not found
	IERR = 2	converter bus not found
	IERR = 3	bus is not a converter bus of this multi-terminal dc line
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - this converter bus is no longer its pole's voltage controlling converter. - the voltage setpoint of the new voltage controlling converter is not positive. - the voltage setpoint of the new voltage controlling converter is less than the mode switch voltage

1.2.86. PURGE_MULTI_TERM_DC_LINK

Use this API to delete the specified dc link from the specified multi-terminal dc line in the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_MULTI_TERM_DC_LINK DC IBUS JBUS 'CKT'
```

Python command syntax:

```
ierr = purge_multi_term_dc_link(dc, ibus, jbus, ckt)
```

Fortran command syntax:

```
CALL PURGMDC_DC_LINK_API(NUM, IBUS, JBUS, CKT, IERR)
CALL PURGMDC_DC_LINK_API_I(NUM, IBUS, JBUS, CKT, IERR)
CALL PURGMDC_DC_LINK_API_C(NAME, IBUS, JBUS, CKT, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line from which a dc link is to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line from which a dc link is to be removed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line from which a dc link is to be removed (input; no default allowed).
Integer IBUS	one of the dc buses connected by the dc link to be removed (input).
Integer JBUS	other dc bus connected by the dc link (input).
Character*1 CKT	circuit identifier of the dc link to be deleted (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 dc line not found
	IERR = 2 invalid dc bus number
	IERR = 3 dc bus not present in this multi-terminal dc line
	IERR = 4 circuit identifier is more than one character
	IERR = 5 dc link not found in this multi-terminal dc line
	IERR = 6 prerequisite requirements for API are not met

1.2.87. PURGFACTS

Use this API to delete the specified FACTS device from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGFACTS  FD
```

Python command syntax:

```
ierr = purgfacts(fd)
```

Fortran command syntax:

```
CALL PURGFACTS(NUM, IERR)
```

```
CALL PURGFACTS_I(NUM, IERR)
```

```
CALL PURGFACTS_C(NAME, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device to be removed (input; no default allowed).	
Character*12 NAME	name of the FACTS device to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	FACTS device not found
	IERR = 2	prerequisite requirements for API are not met

1.2.88. PURGGNE

Use this API routine to delete the specified GNE device from the working case.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_PURGGNE  'NAME'
```

Python command syntax:

```
ierr = purggne(name)
```

Fortran command syntax:

```
CALL PURGGNE(NAME, IERR)
```

Where:

Character*12 NAME	name of the GNE device to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	GNE device not found
	IERR = 2	prerequisite requirements for API are not met

1.2.89. PURGINDMAC

Use this API routine to delete the specified induction machine from the working case.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_PURGINDMAC  IBUS  'ID'
```

Python command syntax:

```
ierr = purgindmac(ibus, id)
```

Fortran command syntax:

```
CALL PURGINDMAC(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus to which induction machine ID is connected (input; no default allowed).	
Character*2 ID	identifier of the induction machine to be removed (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no induction machines at bus
	IERR = 3	induction machine not found
	IERR = 4	prerequisite requirements for API are not met

1.2.90. PURGINDMACS

Use this API routine to delete all induction machines from the specified bus in the working case.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_PURGINDMACS IBUS
```

Python command syntax:

```
ierr = purgindmacs(ibus)
```

Fortran command syntax:

```
CALL PURGINDMACS(IBUS, IERR)
```

Where:

Integer IBUS	bus from which all induction machines are to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no induction machines at bus
	IERR = 3	prerequisite requirements for API are not met

1.2.91. PURGLOAD

Use this API to delete the specified load from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGLOAD IBUS 'ID'
```

Python command syntax:

```
ierr = purgload(ibus, id)
```

Fortran command syntax:

```
CALL PURGLOAD(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus to which the load ID is connected (input; no default allowed).	
Character*2 ID	identifier of the load to be removed (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no loads at bus
	IERR = 3	load not found
	IERR = 4	prerequisite requirements for API are not met

1.2.92. PURGLOADS

Use this API to delete all loads from the specified bus in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGLOADS IBUS
```

Python command syntax:

```
ierr = purgloads(ibus)
```

Fortran command syntax:

```
CALL PURGLOADS(IBUS, IERR)
```

Where:

Integer IBUS	bus from which all loads are to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no loads at bus
	IERR = 3	prerequisite requirements for API are not met

1.2.93. PURGMAC

Use this API to delete the specified machine from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGMAC  IBUS  'ID'
```

Python command syntax:

```
ierr = purgmac(ibus, id)
```

Fortran command syntax:

```
CALL PURGMAC(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus to which the machine ID is connected (input; no default allowed).	
Character*2 ID	identifier of the machine to be removed (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no machines at bus
	IERR = 3	machine not found
	IERR = 4	prerequisite requirements for API are not met

1.2.94. PURGMDC

Use this API to delete the specified multi-terminal dc line from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGMDC DC
```

Python command syntax:

```
ierr = purgmdc(dc)
```

Fortran command syntax:

```
CALL PURGMDC(NUM, IERR)
```

```
CALL PURGMDC_I(NUM, IERR)
```

```
CALL PURGMDC_C(NAME, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line to be removed (input; no default allowed).	
Character*12 NAME	name of the multi-terminal dc line to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	dc line not found
	IERR = 2	prerequisite requirements for API are not met

1.2.95. PURGMSL

Use this API to delete the specified multi-section line grouping from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGMSL  IBUS  JBUS  'CKT'
```

Python command syntax:

```
ierr = purgmsl(ibus, jbus, ckt)
```

Fortran command syntax:

```
CALL PURGMSL(IBUS, JBUS, CKT, IERR)
```

Where:

Integer IBUS	one of the endpoint buses of the multi-section line (input; no default allowed).	
Integer JBUS	other endpoint bus of the multi-section line (input; no default allowed).	
Character*2 CKT	circuit identifier of the multi-section line to be deleted; the first character must be an ampersand (input; '&1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	multi-section line not found
	IERR = 3	invalid multi-section line identifier (first character not &)
	IERR = 4	prerequisite requirements for API are not met

1.2.96. PURGMUT

Use this API to delete the specified zero sequence mutual coupling from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGMUT IBUS1 JBUS1 'CKT1' IBUS2 JBUS2 'CKT2'
```

Python command syntax:

```
ierr = purgmut(ibus1, jbus1, ckt1, ibus2, jbus2, ckt2)
```

Fortran command syntax:

```
CALL PURGMUT(IBUS1, JBUS1, CKT1, IBUS2, JBUS2, CKT2, IERR)
```

Where:

Integer IBUS1	one of the buses connected by the first branch of the mutual coupling (input; no default allowed).
Integer JBUS1	other bus connected by the first branch of the mutual coupling (input; no default allowed).
Character*2 CKT1	circuit identifier of the first branch of the mutual coupling (input; '1' by default).
Integer IBUS2	one of the buses connected by the second branch of the mutual coupling (input; no default allowed).
Integer JBUS2	other bus connected by the second branch of the mutual coupling (input; no default allowed).
Character*2 CKT2	circuit identifier of the second branch of the mutual coupling (input; '1' by default).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 branch not found
	IERR = 3 mutual coupling not found
	IERR = 4 prerequisite requirements for API are not met

1.2.97. PURGOWNER

Use this API to delete owners with no equipment assigned to them from the working case.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_PURGOWNER SID ALL
```

Python command syntax:

```
ierr = purgowner(sid, all)
```

Fortran command syntax:

```
CALL PURGOWNER(SID, ALL, IERR)
```

Where:

Integer SID	a valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Owner subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all owners or specified subsystem flag (input; 1 by default).	
	ALL = 0	delete only owners in owner subsystem SID with no equipment assigned to them
	ALL = 1	delete all owners with no equipment assigned to them
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.2.98. PURGPLNT

Use this API to delete the plant and machine data at the specified bus from the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGPLNT  IBUS
```

Python command syntax:

```
ierr = purgplnt(ibus)
```

Fortran command syntax:

```
CALL PURGPLNT(IBUS, IERR)
```

Where:

Integer IBUS	bus from which the plant is to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no machines at bus
	IERR = 3	prerequisite requirements for API are not met

1.2.99. PURGSHUNT

Use this API to delete the specified fixed bus shunt from the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGSHUNT IBUS 'ID'
```

Python command syntax:

```
ierr = purgshunt(ibus, id)
```

Fortran command syntax:

```
CALL PURGSHUNT(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus to which the shunt is connected (input; no default allowed).	
Character*2 ID	identifier of the shunt to be removed (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no fixed shunts at bus
	IERR = 3	shunt not found
	IERR = 4	prerequisite requirements for API are not met

1.2.100. PURGSHUNTS

Use this API to delete all fixed shunts from the specified bus in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGSHUNTS  IBUS
```

Python command syntax:

```
ierr = purgshunts(ibus)
```

Fortran command syntax:

```
CALL PURGSHUNTS( IBUS, IERR)
```

Where:

Integer IBUS	bus from which all fixed shunts are to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no fixed shunts at bus
	IERR = 3	prerequisite requirements for API are not met

1.2.101. PURGSWS

Use this API to delete all switched shunts from the specified bus in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PURGSWS  IBUS
```

Python command syntax:

```
ierr = purgsws(ibus)
```

Fortran command syntax:

```
CALL PURGSWS(IBUS, IERR)
```

Where:

Integer IBUS	bus from which all switched shunts are to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no switched shunts at bus
	IERR = 3	prerequisite requirements for API are not met

1.2.102. PURGSWSHUNT

Use this API to delete the specified switched bus shunt from the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PURGSWSHUNT IBUS 'ID'
```

Python command syntax:

```
ierr = purgswshunt(ibus, id)
```

Fortran command syntax:

```
CALL PURGSWSHUNT(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus to which the switched shunt is connected (input; no default allowed).	
Character*2 ID	identifier of the switched shunt to be removed (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	bus not found
	IERR = 2	no switched shunts at bus
	IERR = 3	switched shunt not found
	IERR = 4	prerequisite requirements for API are not met

1.2.103. PURGVSC

Use this API to delete the specified VSC dc line from the working case.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_PURGVSC  'NAME'
```

Python command syntax:

```
ierr = purgvsc(name)
```

Fortran command syntax:

```
CALL PURGVSC(NAME, IERR)
```

Where:

Character*12 NAME	name of the VSC dc line to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	dc line not found
	IERR = 2	prerequisite requirements for API are not met

1.2.104. PURGZONE

Use this API to delete zones with no equipment assigned to them from the working case.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_PURGZONE  SID  ALL
```

Python command syntax:

```
ierr = purgzone(sid, all)
```

Fortran command syntax:

```
CALL PURGZONE(SID, ALL, IERR)
```

Where:

Integer SID	a valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Zone subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all zones or specified subsystem flag (input; 1 by default).	
	ALL = 0	delete only zones in zone subsystem SID with no equipment assigned to them
	ALL = 1	delete all zones with no equipment assigned to them
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

1.2.105. PURG_VOLTAGE_DROOP

Use this API to delete an existing voltage droop control from the working case.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_PURG_VOLTAGE_DROOP  'NAME'
```

Python command syntax:

```
ierr = purg_voltage_droop(name)
```

Fortran command syntax:

```
CALL PURG_VOLTAGE_DROOP(NAME, IERR)
```

Where:

character*40 NAME	voltage droop control name (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	voltage droop control not found
	IERR = 2	prerequisite requirements for API are not met

1.2.106. RATINGSETTEXTDATA

Use this API to change the column and descriptions for a particular rating set used in reporting.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_RATINGSETTEXTDATA  IRATE NAME DESCR
```

Python command syntax:

```
ierr = ratingsettextdata(irate, name, descr)
```

Fortran command syntax:

```
CALL RATINGSETTEXTDATA(IRATE, NAME, DESCR, IERR)
```

Where:

Integer IRATE	rating set number (1 through 12) (input; no default allowed).
Character*6 NAME	rating set column heading (input; blank by default).
Character*32 DESCR	rating set description (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no errors
	IERR = 1 invalid rating set number
	IERR = 2 prerequisite requirements for API are not met

1.2.107. SHUNT_CHNG

Use this API routine to modify the data of an existing fixed bus shunt in the working case (see PSSE Program Operation Manual, Fixed Bus Shunt Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SHUNT_CHNG IBUS 'ID' INTGAR(1) REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = shunt_chng(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SHUNT_CHNG(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	shunt identifier (input; '1' by default).
Integer INTGAR (1)	See the SHUNT_DATA API routine for details (input).
Real REALAR (2)	See the SHUNT_DATA API routine for details (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 shunt identifier is more than two characters
	IERR = 5 fixed bus shunt not found
	IERR = 6 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - invalid shunt status

1.2.108. SHUNT_DATA

Use this API to modify the data of an existing fixed bus shunt in the working case or to add a new fixed bus shunt to the working case (see PSSE Program Operation Manual, Fixed Bus Shunt Data).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SHUNT_DATA IBUS 'ID' INTGAR(1) REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = shunt_data(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SHUNT_API(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	shunt identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) STATUS, shunt status (1 by default)
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) GL, fixed shunt admittance (conductance) (0.0 by default) REALAR(2) BL, fixed shunt admittance (susceptance) (0.0 by default)
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 bus not found IERR = 2 shunt identifier is more than two characters IERR = 3 blank shunt identifier is invalid IERR = 4 fixed bus shunt table is full IERR = 6 prerequisite requirements for API are not met IERR = 7 node-breaker terminal connection table is full IERR = -1 data error, warning and information messages; one or more of: - invalid shunt status

1.2.109. SOLUTION_PARAMETERS

This API routine is obsolete. It has been replaced by the API routine [solution_parameters_2](#).

Use this API to modify the power flow solution parameters in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SOLUTION_PARAMETERS  INTGAR(1)..INTGAR(3)  REALAR(1)..REALAR(16)
```

Python command syntax:

```
ierr = solution_parameters(intgar, realar)
```

Fortran command syntax:

```
CALL SOLUTION_PARAMETER_API(INTGAR, REALAR, IERR, NERR)
```

Where:

Integer INTGAR (3)	array of 3 elements specifying (input).
INTGAR(1)	ITMX, Gauss-Seidel maximum number of iterations
INTGAR(2)	ITMXN, Newton-Raphson maximum number of iterations
INTGAR(3)	ITMXTY, TYSL maximum number of iterations
Real REALAR (16)	array of 16 elements specifying (input).
REALAR(1)	ACCP, Gauss-Seidel real component acceleration factor
REALAR(2)	ACCQ, Gauss-Seidel imaginary component acceleration factor
REALAR(3)	ACCM, special MSLV acceleration factor
REALAR(4)	TOL, Gauss-Seidel convergence tolerance
REALAR(5)	ACCN, Newton-Raphson acceleration factor
REALAR(6)	TOLN, Newton-Raphson mismatch convergence tolerance
REALAR(7)	ACCTY, TYSL acceleration factor
REALAR(8)	TOLTY, TYSL convergence tolerance
REALAR(9)	BLOWUP, blow-up threshold
REALAR(10)	PQBRK, constant power load characteristic breakpoint
REALAR(11)	THRSHZ, zero impedance line threshold
REALAR(12)	ADJTHR, automatic adjustment threshold tolerance
REALAR(13)	ACCTAP, tap movement deceleration factor
REALAR(14)	TAPLIM, maximum tap change per adjustment

	REALAR(15)	DVLIM, largest $\text{abs}(\Delta v)/\text{abs}(v)$ for Newton solutions
	REALAR(16)	NDVFCT, non-divergent required improvement factor
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	prerequisite requirements for API are not met
	IERR = -1	warnings: - None
Integer NERR	number of entries in PBUF02 containing error messages (output).	

1.2.110. SOLUTION_PARAMETERS_2

This API routine is obsolete. It has been replaced by the API routine [solution_parameters_3](#).

Use this API to modify the power flow solution parameters in the working case.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_SOLUTION_PARAMETERS_2  INTGAR(1)..INTGAR(3)  REALAR(1)..REALAR(18)
```

Python command syntax:

```
ierr = solution_parameters_2(intgar, realar)
```

Fortran command syntax:

```
CALL SOLUTION_PARAMETER_API_2(INTGAR, REALAR, IERR, NERR)
```

Where:

Integer INTGAR (3)	array of 3 elements specifying (input).
INTGAR(1)	ITMX, Gauss-Seidel maximum number of iterations
INTGAR(2)	ITMXN, Newton-Raphson maximum number of iterations
INTGAR(3)	ITMXTY, TYSL maximum number of iterations
Real REALAR (18)	array of 18 elements specifying (input).
REALAR(1)	ACCP, Gauss-Seidel real component acceleration factor
REALAR(2)	ACCQ, Gauss-Seidel imaginary component acceleration factor
REALAR(3)	ACCM, special MSLV acceleration factor
REALAR(4)	TOL, Gauss-Seidel convergence tolerance
REALAR(5)	ACCN, Newton-Raphson acceleration factor
REALAR(6)	TOLN, Newton-Raphson mismatch convergence tolerance
REALAR(7)	ACCTY, TYSL acceleration factor
REALAR(8)	TOLTY, TYSL convergence tolerance
REALAR(9)	BLOWUP, blow-up threshold
REALAR(10)	PQBRK, constant power load characteristic breakpoint
REALAR(11)	THRSHZ, zero impedance line threshold
REALAR(12)	ADJTHR, automatic adjustment threshold tolerance
REALAR(13)	ACCTAP, tap movement deceleration factor
REALAR(14)	TAPLIM, maximum tap change per adjustment

	REALAR(15)	DVLIM, largest $\text{abs}(\Delta v)/\text{abs}(v)$ for Newton solutions
	REALAR(16)	NDVFCT, non-divergent required improvement factor
	REALAR(17)	VCTOLQ, Newton-Raphson voltage controlled bus reactive power mismatch convergence tolerance
	REALAR(18)	VCTOLV, Newton-Raphson voltage controlled bus voltage error convergence tolerance
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	prerequisite requirements for API are not met
	IERR = -1	warnings: - None
Integer NERR	number of entries in PBUF02 containing error messages (output).	

1.2.111. SOLUTION_PARAMETERS_3

This API routine is obsolete. It has been replaced by the API routine [solution_parameters_4](#).

Use this API to modify the power flow solution parameters in the working case (see PSSE Program Operation Manual, Sections 6.3.13, 6.3.18, 6.5.1 and 11.7).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SOLUTION_PARAMETERS_3  INTGAR(1)..INTGAR(3)  REALAR(1)..REALAR(19)
```

Python command syntax:

```
ierr = solution_parameters_3(intgar, realar)
```

Fortran command syntax:

```
CALL SOLUTION_PARAMETER_API_3(INTGAR, REALAR, IERR)
```

Where:

Integer INTGAR (3)	array of 3 elements specifying (input).
INTGAR(1)	ITMX, Gauss-Seidel maximum number of iterations (100 by default)
INTGAR(2)	ITMXN, Newton-Raphson maximum number of iterations (20 by default)
INTGAR(3)	ITMXTY, TYSL maximum number of iterations (20 by default)
Real REALAR (19)	array of 19 elements specifying (input).
REALAR(1)	ACCP, Gauss-Seidel real component acceleration factor (1.6 by default)
REALAR(2)	ACCQ, Gauss-Seidel imaginary component acceleration factor (1.6 by default)
REALAR(3)	ACCM, special MSLV acceleration factor (1.0 by default)
REALAR(4)	TOL, Gauss-Seidel convergence tolerance (0.0001 by default)
REALAR(5)	ACCN, Newton-Raphson acceleration factor (1.0 by default)
REALAR(6)	TOLN, Newton-Raphson mismatch convergence tolerance (default Newton power flow solution tolerance option setting)
REALAR(7)	ACCTY, TYSL acceleration factor (1.0 by default)
REALAR(8)	TOLTY, TYSL convergence tolerance (0.00001 by default)
REALAR(9)	BLOWUP, blow-up threshold (5.0 by default)

	REALAR(10)	PQBRAK, constant power load characteristic breakpoint (0.7 by default)
	REALAR(11)	THRSHZ, zero impedance line threshold (0.0001 by default)
	REALAR(12)	ADJTHR, automatic adjustment threshold tolerance (0.005 by default)
	REALAR(13)	ACCTAP, tap movement deceleration factor (1.0 by default)
	REALAR(14)	TAPLIM, maximum tap change per adjustment (0.05 by default)
	REALAR(15)	DVLIM, largest $\text{abs}(\Delta v)/\text{abs}(v)$ for Newton solutions (0.99 by default)
	REALAR(16)	NDVFCT, non-divergent required improvement factor (0.99 by default)
	REALAR(17)	VCTOLQ, Newton-Raphson voltage controlled bus reactive power mismatch convergence tolerance (default Newton power flow solution tolerance option setting)
	REALAR(18)	VCTOLV, Newton-Raphson voltage controlled bus voltage error convergence tolerance (0.00001 by default)
	REALAR(19)	SWVBND, percent of voltage controlling band mode switched shunts to be adjusted per power flow iteration (100.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Invalid percent value for switched shunt adjustment

1.2.112. SOLUTION_PARAMETERS_4

This API routine is obsolete. It has been replaced by the API routine [solution_parameters_5](#).

Use this API to modify the power flow solution parameters in the working case (see PSSE Program Operation Manual, Sections 6.3.13, 6.3.18, 6.5.1 and 11.7).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SOLUTION_PARAMETERS_4  INTGAR(1)..INTGAR(5)  REALAR(1)..REALAR(19)
```

Python command syntax:

```
ierr = solution_parameters_4(intgar, realar)
```

Fortran command syntax:

```
CALL SOLUTION_PARAMETER_API_4(INTGAR, REALAR, IERR)
```

Where:

Integer INTGAR (5)	array of 5 elements specifying (input).
INTGAR(1)	ITMX, Gauss-Seidel maximum number of iterations (100 by default)
INTGAR(2)	ITMXN, Newton-Raphson maximum number of iterations (20 by default)
INTGAR(3)	ITMXTY, TYSL maximum number of iterations (20 by default)
INTGAR(4)	MXTPSS, maximum number of times taps and/or switched shunts are adjusted during power flow solutions (100 by default)
INTGAR(5)	MXSWIM, maximum number of times an induction machine can change state (e.g., from "running" to "stalled") during power flow solutions (10 by default)
Real REALAR (19)	array of 19 elements specifying (input).
REALAR(1)	ACCP, Gauss-Seidel real component acceleration factor (1.6 by default)
REALAR(2)	ACCQ, Gauss-Seidel imaginary component acceleration factor (1.6 by default)
REALAR(3)	ACCM, special MSLV acceleration factor (1.0 by default)
REALAR(4)	TOL, Gauss-Seidel convergence tolerance (0.0001 by default)
REALAR(5)	ACCN, Newton-Raphson acceleration factor (1.0 by default)
REALAR(6)	TOLN, Newton-Raphson mismatch convergence tolerance (default Newton power flow solution tolerance option setting)

	REALAR(7)	ACCTY, TYSL acceleration factor (1.0 by default)
	REALAR(8)	TOLTY, TYSL convergence tolerance (0.00001 by default)
	REALAR(9)	BLOWUP, blow-up threshold (5.0 by default)
	REALAR(10)	PQBRAK, constant power load characteristic breakpoint (0.7 by default)
	REALAR(11)	THRSHZ, zero impedance line threshold (0.0001 by default)
	REALAR(12)	ADJTHR, automatic adjustment threshold tolerance (0.005 by default)
	REALAR(13)	ACCTAP, tap movement deceleration factor (1.0 by default)
	REALAR(14)	TAPLIM, maximum tap change per adjustment (0.05 by default)
	REALAR(15)	DVLIM, largest abs(delta v)/abs(v) for Newton solutions (0.99 by default)
	REALAR(16)	NDVFCT, non-divergent required improvement factor (0.99 by default)
	REALAR(17)	VCTOLQ, Newton-Raphson voltage controlled bus reactive power mismatch convergence tolerance (default Newton power flow solution tolerance option setting)
	REALAR(18)	VCTOLV, Newton-Raphson voltage controlled bus voltage error convergence tolerance (0.00001 by default)
	REALAR(19)	SWVBND, percent of voltage controlling band mode switched shunts to be adjusted per power flow iteration (100.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Invalid percent value for switched shunt adjustment. - Invalid induction motor treatment code

1.2.113. SOLUTION_PARAMETERS_5

Use this API to modify the power flow solution parameters in the working case (see PSSE Program Operation Manual, Sections 6.3.13, 6.3.18, 6.5.1 and 11.7).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SOLUTION_PARAMETERS_5  INTGAR(1)..INTGAR(9)  REALAR(1)..REALAR(21)
```

Python command syntax:

```
ierr = solution_parameters_5(intgar, realar)
```

Fortran command syntax:

```
CALL SOLUTION_PARAMETER_API_5(INTGAR, REALAR, IERR)
```

Where:

Integer INTGAR (9)	array of 9 elements specifying (input).
INTGAR(1)	ITMX, Gauss-Seidel maximum number of iterations (100 by default)
INTGAR(2)	ITMXN, Newton-Raphson maximum number of iterations (20 by default)
INTGAR(3)	ITMXTY, TYSL maximum number of iterations (20 by default)
INTGAR(4)	MXTPSS, maximum number of times taps and/or switched shunts are adjusted during power flow solutions (100 by default)
INTGAR(5)	MXSWIM, maximum number of times an induction machine can change state (e.g., from "running" to "stalled") during power flow solutions (10 by default)
INTGAR(6)	MovIterMax, maximum number of MOV iterations in short circuit solutions (20 by default)
INTGAR(7)	IsolLvl, Maximum number of levels to go outward when isolating an element by breaker actions (4 by default)
INTGAR(8)	CalterMax, Maximum number of repeat solutions for each contingency case (20 by default)
INTGAR(9)	CntChk, Check for duplicate contingency labels (<=0 = no, >0 = yes) (0 by default)
Real REALAR (21)	array of 21 elements specifying (input).
REALAR(1)	ACCP, Gauss-Seidel real component acceleration factor (1.6 by default)
REALAR(2)	ACCQ, Gauss-Seidel imaginary component acceleration factor (1.6 by default)

	REALAR(3)	ACCM, special MSLV acceleration factor (1.0 by default)
	REALAR(4)	TOL, Gauss-Seidel convergence tolerance (0.0001 by default)
	REALAR(5)	ACCN, Newton-Raphson acceleration factor (1.0 by default)
	REALAR(6)	TOLN, Newton-Raphson mismatch convergence tolerance (default Newton power flow solution tolerance option setting)
	REALAR(7)	ACCTY, TYSL acceleration factor (1.0 by default)
	REALAR(8)	TOLTY, TYSL convergence tolerance (0.00001 by default)
	REALAR(9)	BLOWUP, blow-up threshold (5.0 by default)
	REALAR(10)	PQBRAK, constant power load characteristic breakpoint (0.7 by default)
	REALAR(11)	THRSHZ, zero impedance line threshold (0.0001 by default)
	REALAR(12)	ADJTHR, automatic adjustment threshold tolerance (0.005 by default)
	REALAR(13)	ACCTAP, tap movement deceleration factor (1.0 by default)
	REALAR(14)	TAPLIM, maximum tap change per adjustment (0.05 by default)
	REALAR(15)	DVLIM, largest $\text{abs}(\Delta V)/\text{abs}(V)$ for Newton solutions (0.99 by default)
	REALAR(16)	NDVFACT, non-divergent required improvement factor (0.99 by default)
	REALAR(17)	VCTOLQ, Newton-Raphson voltage controlled bus reactive power mismatch convergence tolerance (default Newton power flow solution tolerance option setting)
	REALAR(18)	VCTOLV, Newton-Raphson voltage controlled bus voltage error convergence tolerance (0.00001 by default)
	REALAR(19)	SWVBND, percent of voltage controlling band mode switched shunts to be adjusted per power flow iteration (100.0 by default)
	REALAR(20)	MovTolerance, MOV iteration tolerance in short circuit solutions (0.01 by default)
	REALAR(21)	MovAlpha, MOV acceleration factor in short circuit solutions (0.3 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	prerequisite requirements for API are not met

IERR = -1

data error, warning and information messages; one or more of: - Invalid percent value for switched shunt adjustment. - Invalid induction motor treatment code

1.2.114. SWITCHED_SHUNT_CHNG_3

This API routine is obsolete. It has been replaced by the API routine [switched_shunt_chng_4](#).

Use this API routine to modify the data of an existing switched shunt in the working case (see PSSE Program Operation Manual, Switched Shunt Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_CHNG_3  IBUS  INTGAR(1) .. INTGAR(12)
    REALAR(1) .. REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_chng_3(ibus, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_CHNG_3(IBUS, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INTGAR (12)	array of 12 elements specifying (input).
INTGAR(1)	N1, number of steps for block 1 (0 by default)
INTGAR(2)	N2, number of steps for block 2 (0 by default)
INTGAR(3)	N3, number of steps for block 3 (0 by default)
INTGAR(4)	N4, number of steps for block 4 (0 by default)
INTGAR(5)	N5, number of steps for block 5 (0 by default)
INTGAR(6)	N6, number of steps for block 6 (0 by default)
INTGAR(7)	N7, number of steps for block 7 (0 by default)
INTGAR(8)	N8, number of steps for block 8 (0 by default)
INTGAR(9)	MODSW, control mode (1 by default)
INTGAR(10)	SWREM, remote bus number (0 by default)
INTGAR(11)	STAT, status (1 by default)
INTGAR(12)	ADJM, adjustment method (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).
REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)

	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)
	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 3	switched shunt not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - invalid switched shunt control mode - control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - control mode is 6 and a blank FACTS device name is specified - FACTS device not found - non-blank device name specified with control mode 0, 1, 2, 3 or 5 - regulated bus not found - voltage controlling switched shunt specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - VHIG is less than VLOW for voltage controlling switched shunt - no regulated bus specified for plant, VSC converter, or switched shunt control - control mode is 3 and the regulated bus has no generation - control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - control mode

is 5 and the regulated bus has no switched shunt - regulated bus is not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC converter, switched shunt, or FACTS device control - VHIGH is greater than 1.0 for plant, VSC converter, switched shunt, or FACTS device control - VLOW is less than 0.0 for plant, VSC converter, switched shunt, or FACTS device control - RMPCT is not positive - block has N or B zero and the other non-zero - invalid number of steps in block - block with non-zero N is beyond a previous N=0 block - block 1 has no steps. - Reactor block is out of sequence. - Initial admittance is below minimum. - Initial admittance is above maximum. - Initial admittance is not on a step. - Block has admittances with different signs in positive and zero sequences. - Invalid switched shunt status. - Invalid switched shunt adjustment method

1.2.115. SWITCHED_SHUNT_CHNG_4

This API routine is obsolete. It has been replaced by the API routine [switched_shunt_chng_5](#).

Use this API routine to modify the data of an existing switched shunt in the working case (see PSSE Program Operation Manual, Switched Shunt Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_CHNG_4  IBUS  INTGAR(1)..INTGAR(13)
    REALAR(1)..REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_chng_4(ibus, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_CHNG_4(IBUS, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INTGAR (13)	array of 13 elements specifying (input).
INTGAR(1)	N1, number of steps for block 1 (0 by default)
INTGAR(2)	N2, number of steps for block 2 (0 by default)
INTGAR(3)	N3, number of steps for block 3 (0 by default)
INTGAR(4)	N4, number of steps for block 4 (0 by default)
INTGAR(5)	N5, number of steps for block 5 (0 by default)
INTGAR(6)	N6, number of steps for block 6 (0 by default)
INTGAR(7)	N7, number of steps for block 7 (0 by default)
INTGAR(8)	N8, number of steps for block 8 (0 by default)
INTGAR(9)	MODSW, control mode (1 by default)
INTGAR(10)	SWREM, regulated bus number (0 by default)
INTGAR(11)	NODE, regulated node number (0 by default)
INTGAR(12)	STAT, status (1 by default)
INTGAR(13)	ADJM, adjustment method (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).
REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)

	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)
	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 3	switched shunt not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - Invalid switched shunt control mode - Control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - Control mode is 6 and a blank FACTS device name is specified - FACTS device not found - Non-blank device name specified with control mode 0, 1, 2, 3 or 5 - Regulated bus not found - Type code of regulated bus is not 1 or 2 - VHIG is less than VLOW for voltage controlling switched shunt - No regulated bus specified for plant, VSC converter, or switched shunt control - Control mode is 3 and the regulated bus has no generation - Control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - Control mode is 5 and the regulated bus has no switched shunt - Regulated bus is

not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC converter, switched shunt, or FACTS device control - VHIGH is greater than 1.0 for plant, VSC converter, switched shunt, or FACTS device control - VLOW is less than 0.0 for plant, VSC converter, switched shunt, or FACTS device control - RMPCT is not positive - Block has N or B zero and the other non-zero - Invalid number of steps in block - Block with non-zero N is beyond a previous N=0 block - Block 1 has no steps. - Reactor block is out of sequence. - Initial admittance is below minimum. - Initial admittance is above maximum. - Initial admittance is not on a step. - Block has admittances with different signs in positive and zero sequences. - Invalid switched shunt status. - Invalid switched shunt adjustment method - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus - Regulated bus is 0 but a non-zero regulated node is specified - A remote regulated bus is specified for a type 3 bus

1.2.116. SWITCHED_SHUNT_CHNG_5

Use this API routine to modify the data of an existing switched shunt in the working case (see PSSE Program Operation Manual, Switched Shunt Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_CHNG_5  IBUS  'ID'  INTGAR(1)..INTGAR(21)
    REALAR(1)..REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_chng_5(ibus, id, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_CHNG_5(IBUS, ID, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
character*2 ID	Switched shunt identifier (input; '1' by default).
Integer INTGAR (21)	array of 21 elements specifying (input).
INTGAR(1)	N1, number of steps for block 1 (0 by default)
INTGAR(2)	N2, number of steps for block 2 (0 by default)
INTGAR(3)	N3, number of steps for block 3 (0 by default)
INTGAR(4)	N4, number of steps for block 4 (0 by default)
INTGAR(5)	N5, number of steps for block 5 (0 by default)
INTGAR(6)	N6, number of steps for block 6 (0 by default)
INTGAR(7)	N7, number of steps for block 7 (0 by default)
INTGAR(8)	N8, number of steps for block 8 (0 by default)
INTGAR(9)	MODSW, control mode (1 by default)
INTGAR(10)	SWREM, regulated bus number (0 by default)
INTGAR(11)	NODE, regulated node number (0 by default)
INTGAR(12)	STAT, status (1 by default)
INTGAR(13)	ADJM, adjustment method (0 by default)
INTGAR(14)	ST1, status of block 1 (1 by default)
INTGAR(15)	ST2, status of block 2 (1 by default)
INTGAR(16)	ST3, status of block 3 (1 by default)
INTGAR(17)	ST4, status of block 4 (1 by default)

	INTGAR(18)	ST5, status of block 5 (1 by default)
	INTGAR(19)	ST6, status of block 6 (1 by default)
	INTGAR(20)	ST7, status of block 7 (1 by default)
	INTGAR(21)	ST8, status of block 8 (1 by default)
Real REALAR (12)	array of 12 elements specifying (input).	
	REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)
	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)
	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 3	identifier is more than two characters
	IERR = 5	switched shunt not found
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - Invalid switched shunt control mode - Control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - Control mode is 6 and a blank FACTS device name is specified - FACTS device not found - Non-blank device name specified with control mode 0, 1, 2, 3 or 5 - Regulated bus not found - Type code of reg-

ulated bus is not 1 or 2 - VHIGH is less than VLOW for voltage controlling switched shunt - No regulated bus specified for plant, VSC converter, or switched shunt control - Control mode is 3 and the regulated bus has no generation - Control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - Control mode is 5 and the regulated bus has no switched shunt - Regulated bus is not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC converter, switched shunt, or FACTS device control - VHIGH is greater than 1.0 for plant, VSC converter, switched shunt, or FACTS device control - VLOW is less than 0.0 for plant, VSC converter, switched shunt, or FACTS device control - RMPCT is not positive - Block has N or B zero and the other non-zero - Invalid number of steps in block - Block with non-zero N is beyond a previous N=0 block - Block 1 has no steps. - Reactor block is out of sequence. - Initial admittance is below minimum. - Initial admittance is above maximum. - Initial admittance is not on a step. - Block has admittances with different signs in positive and zero sequences. - Invalid switched shunt status. - Invalid switched shunt adjustment method - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus - Regulated bus is 0 but a non-zero regulated node is specified - A remote regulated bus is specified for a type 3 bus

1.2.117. SWITCHED_SHUNT_DATA

This API routine is obsolete. It has been replaced by the API routine [switched_shunt_data_3](#).

Use this API to modify the data of an existing switched shunt in the working case or to add a new switched shunt to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_DATA  IBUS  INTGAR(1)..INTGAR(10)
                          REALAR(1)..REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_data(ibus, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_API_2(IBUS, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).	
Integer INTGAR (10)	array of 10 elements specifying (input).	
	INTGAR(1)	N1, number of steps for block 1 (0 by default)
	INTGAR(2)	N2, number of steps for block 2 (0 by default)
	INTGAR(3)	N3, number of steps for block 3 (0 by default)
	INTGAR(4)	N4, number of steps for block 4 (0 by default)
	INTGAR(5)	N5, number of steps for block 5 (0 by default)
	INTGAR(6)	N6, number of steps for block 6 (0 by default)
	INTGAR(7)	N7, number of steps for block 7 (0 by default)
	INTGAR(8)	N8, number of steps for block 8 (0 by default)
	INTGAR(9)	MODSW, control mode (1 by default)
	INTGAR(10)	SWREM, remote bus number (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).	
	REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)
	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)

	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	switched shunt table is full
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - invalid switched shunt control mode - control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - control mode is 6 and a blank FACTS device name is specified - FACTS device not found - non-blank device name specified with control mode 0, 1, 2, 3 or 5 - regulated bus not found - voltage controlling switched shunt specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - VHIGH is less than VLOW for voltage controlling switched shunt - no regulated bus specified for plant, VSC converter, or switched shunt control - control mode is 3 and the regulated bus has no generation - control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - control mode is 5 and the regulated bus has no switched shunt - regulated bus is not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC convert-

er, switched shunt, or FACTS device control -
VHIGH is greater than 1.0 for plant, VSC con-
verter, switched shunt, or FACTS device con-
trol - VLOW is less than 0.0 for plant, VSC con-
verter, switched shunt, or FACTS device con-
trol - - RMPCT is not positive - block has N or
B zero and the other non-zero - invalid num-
ber of steps in block - block with non-zero N
is beyond a previous N=0 block - block 1 has
no steps. - Reactor block is out of sequence. -
Initial admittance is below minimum. - Initial
admittance is above maximum. - Initial admit-
tance is not on a step. - Block has admittances
with different signs in positive and zero se-
quences

1.2.118. SWITCHED_SHUNT_DATA_3

This API routine is obsolete. It has been replaced by the API routine [switched_shunt_data_4](#).

Use this API to modify the data of an existing switched shunt in the working case or to add a new switched shunt to the working case (see PSSE Program Operation Manual, Switched Shunt Data).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_DATA_3  IBUS  INTGAR(1) .. INTGAR(12)
    REALAR(1) .. REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_data_3(ibus, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_API_3(IBUS, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INTGAR (12)	array of 12 elements specifying (input).
INTGAR(1)	N1, number of steps for block 1 (0 by default)
INTGAR(2)	N2, number of steps for block 2 (0 by default)
INTGAR(3)	N3, number of steps for block 3 (0 by default)
INTGAR(4)	N4, number of steps for block 4 (0 by default)
INTGAR(5)	N5, number of steps for block 5 (0 by default)
INTGAR(6)	N6, number of steps for block 6 (0 by default)
INTGAR(7)	N7, number of steps for block 7 (0 by default)
INTGAR(8)	N8, number of steps for block 8 (0 by default)
INTGAR(9)	MODSW, control mode (1 by default)
INTGAR(10)	SWREM, remote bus number (0 by default)
INTGAR(11)	STAT, status (1 by default)
INTGAR(12)	ADJM, adjustment method (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).
REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)

	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)
	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	switched shunt table is full
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - invalid switched shunt control mode - control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - control mode is 6 and a blank FACTS device name is specified - FACTS device not found - non-blank device name specified with control mode 0, 1, 2, 3 or 5 - regulated bus not found - voltage controlling switched shunt specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - VHIG is less than VLOW for voltage controlling switched shunt - no regulated bus specified for plant, VSC converter, or switched shunt control - control mode is 3 and the regulated bus has no generation - control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - control mode

is 5 and the regulated bus has no switched shunt - regulated bus is not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC converter, switched shunt, or FACTS device control - VHIGH is greater than 1.0 for plant, VSC converter, switched shunt, or FACTS device control - VLOW is less than 0.0 for plant, VSC converter, switched shunt, or FACTS device control - RMPCT is not positive - block has N or B zero and the other non-zero - invalid number of steps in block - block with non-zero N is beyond a previous N=0 block - block 1 has no steps. - Reactor block is out of sequence. - Initial admittance is below minimum. - Initial admittance is above maximum. - Initial admittance is not on a step. - Block has admittances with different signs in positive and zero sequences. - Invalid switched shunt status. - Invalid switched shunt adjustment method

1.2.119. SWITCHED_SHUNT_DATA_4

This API routine is obsolete. It has been replaced by the API routine [switched_shunt_data_5](#).

Use this API to modify the data of an existing switched shunt in the working case or to add a new switched shunt to the working case (see PSSE Program Operation Manual, Switched Shunt Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_DATA_4  IBUS  INTGAR(1)..INTGAR(13)
    REALAR(1)..REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_data_4(ibus, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_API_4(IBUS, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INTGAR (13)	array of 13 elements specifying (input).
INTGAR(1)	N1, number of steps for block 1 (0 by default)
INTGAR(2)	N2, number of steps for block 2 (0 by default)
INTGAR(3)	N3, number of steps for block 3 (0 by default)
INTGAR(4)	N4, number of steps for block 4 (0 by default)
INTGAR(5)	N5, number of steps for block 5 (0 by default)
INTGAR(6)	N6, number of steps for block 6 (0 by default)
INTGAR(7)	N7, number of steps for block 7 (0 by default)
INTGAR(8)	N8, number of steps for block 8 (0 by default)
INTGAR(9)	MODSW, control mode (1 by default)
INTGAR(10)	SWREM, regulated bus number (0 by default)
INTGAR(11)	NODE, regulated node number (0 by default)
INTGAR(12)	STAT, status (1 by default)
INTGAR(13)	ADJM, adjustment method (0 by default)
Real REALAR (12)	array of 12 elements specifying (input).
REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)

	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)
	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	switched shunt table is full
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - Invalid switched shunt control mode - Control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - Control mode is 6 and a blank FACTS device name is specified - FACTS device not found - Non-blank device name specified with control mode 0, 1, 2, 3 or 5 - Regulated bus not found - Type code of regulated bus is not 1 or 2 - VHIGH is less than VLOW for voltage controlling switched shunt - No regulated bus specified for plant, VSC converter, or switched shunt control - Control mode is 3 and the regulated bus has no generation - Control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - Control mode is 5 and the regulated bus has no switched shunt - Regulated bus is

not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC converter, switched shunt, or FACTS device control - VHIGH is greater than 1.0 for plant, VSC converter, switched shunt, or FACTS device control - VLOW is less than 0.0 for plant, VSC converter, switched shunt, or FACTS device control - RMPCT is not positive - Block has N or B zero and the other non-zero - Invalid number of steps in block - Block with non-zero N is beyond a previous N=0 block - Block 1 has no steps. - Reactor block is out of sequence. - Initial admittance is below minimum. - Initial admittance is above maximum. - Initial admittance is not on a step. - Block has admittances with different signs in positive and zero sequences. - Invalid switched shunt status. - Invalid switched shunt adjustment method - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus - Regulated bus is 0 but a non-zero regulated node is specified - A remote regulated bus is specified for a type 3 bus

1.2.120. SWITCHED_SHUNT_DATA_5

Use this API to modify the data of an existing switched shunt in the working case or to add a new switched shunt to the working case (see PSSE Program Operation Manual, Switched Shunt Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SWITCHED_SHUNT_DATA_5  IBUS  'ID'  INTGAR(1)..INTGAR(21)
                           REALAR(1)..REALAR(12)  'RMIDNT'
```

Python command syntax:

```
ierr = switched_shunt_data_5(ibus, id, intgar, realar, rmidnt)
```

Fortran command syntax:

```
CALL SWITCHED_SHUNT_API_5(IBUS, ID, INTGAR, REALAR, RMIDNT, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
character*2 ID	Switched shunt identifier (input; '1' by default).
Integer INTGAR (21)	array of 21 elements specifying (input).
INTGAR(1)	N1, number of steps for block 1 (0 by default)
INTGAR(2)	N2, number of steps for block 2 (0 by default)
INTGAR(3)	N3, number of steps for block 3 (0 by default)
INTGAR(4)	N4, number of steps for block 4 (0 by default)
INTGAR(5)	N5, number of steps for block 5 (0 by default)
INTGAR(6)	N6, number of steps for block 6 (0 by default)
INTGAR(7)	N7, number of steps for block 7 (0 by default)
INTGAR(8)	N8, number of steps for block 8 (0 by default)
INTGAR(9)	MODSW, control mode (1 by default)
INTGAR(10)	SWREM, regulated bus number (0 by default)
INTGAR(11)	NODE, regulated node number (0 by default)
INTGAR(12)	STAT, status (1 by default)
INTGAR(13)	ADJM, adjustment method (0 by default)
INTGAR(14)	ST1, status of block 1 (1 by default)
INTGAR(15)	ST2, status of block 2 (1 by default)
INTGAR(16)	ST3, status of block 3 (1 by default)
INTGAR(17)	ST4, status of block 4 (1 by default)

	INTGAR(18)	ST5, status of block 5 (1 by default)
	INTGAR(19)	ST6, status of block 6 (1 by default)
	INTGAR(20)	ST7, status of block 7 (1 by default)
	INTGAR(21)	ST8, status of block 8 (1 by default)
Real REALAR (12)	array of 12 elements specifying (input).	
	REALAR(1)	B1, admittance increment per step for block 1 (0.0 by default)
	REALAR(2)	B2, admittance increment per step for block 2 (0.0 by default)
	REALAR(3)	B3, admittance increment per step for block 3 (0.0 by default)
	REALAR(4)	B4, admittance increment per step for block 4 (0.0 by default)
	REALAR(5)	B5, admittance increment per step for block 5 (0.0 by default)
	REALAR(6)	B6, admittance increment per step for block 6 (0.0 by default)
	REALAR(7)	B7, admittance increment per step for block 7 (0.0 by default)
	REALAR(8)	B8, admittance increment per step for block 8 (0.0 by default)
	REALAR(9)	VSWHI, desired voltage upper limit (1.0 by default)
	REALAR(10)	VSWLO, desired voltage lower limit (1.0 by default)
	REALAR(11)	BINIT, present switched shunt admittance (0.0 by default)
	REALAR(12)	RMPCT, percent of contributed reactive power (100.0 by default)
Character*12 RMIDNT	VSC dc line name (MODSW =4) or FACTS device name (MODSW = 6) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	switched shunt table is full
	IERR = 3	identifier is more than two characters
	IERR = 4	blank shunt identifier is invalid
	IERR = 6	prerequisite requirements for API are not met
	IERR = 7	node-breaker terminal connection table is full
	IERR = -1	warnings - one or more of: - Invalid switched shunt control mode - Control mode is 4 and a blank VSC dc line name is specified - VSC dc line not found - Control mode is 6 and a blank FACTS device name is specified - FAC-

TS device not found - Non-blank device name specified with control mode 0, 1, 2, 3 or 5 - Regulated bus not found - Type code of regulated bus is not 1 or 2 - VHIGH is less than VLOW for voltage controlling switched shunt - No regulated bus specified for plant, VSC converter, or switched shunt control - Control mode is 3 and the regulated bus has no generation - Control mode is 4 and the regulated bus is not a converter of the specified VSC dc line - Control mode is 5 and the regulated bus has no switched shunt - Regulated bus is not the sending end bus of the specified FACTS device - VLOW is not less than VHIGH for plant, VSC converter, switched shunt, or FACTS device control - VHIGH is greater than 1.0 for plant, VSC converter, switched shunt, or FACTS device control - VLOW is less than 0.0 for plant, VSC converter, switched shunt, or FACTS device control - RMPCT is not positive - Block has N or B zero and the other non-zero - Invalid number of steps in block - Block with non-zero N is beyond a previous N=0 block - Block 1 has no steps. - Reactor block is out of sequence. - Initial admittance is below minimum. - Initial admittance is above maximum. - Initial admittance is not on a step. - Block has admittances with different signs in positive and zero sequences. - Invalid switched shunt status. - Invalid switched shunt adjustment method - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus - Regulated bus is 0 but a non-zero regulated node is specified - A remote regulated bus is specified for a type 3 bus

1.2.121. THREE_WINDING_DATA

This API routine is obsolete. It has been replaced by the API routines [three_wnd_impedance_data](#) and [three_wnd_winding_data](#).

Use this API to modify the data of an existing three-winding transformer in the working case or to add a new three-winding transformer to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_THREE_WINDING_DATA  IBUS  JBUS  KBUS  'CKT'  INTGAR(1)..INTGAR(17)
                        REALAR(1)..REALAR(41)  'NAME'
```

Python command syntax:

```
ierr, realaro = three_winding_data(ibus, jbus, kbus, ckt, intgar, realari,
                                   name)
```

Fortran command syntax:

```
CALL THREE_WINDING_API(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, NAME, IERR,
                       NERR)
```

Where:

Integer IBUS	bus number of one of the buses (input).
Integer JBUS	bus number one of the other buses (input).
Integer KBUS	bus number of the third bus (input).
Character*2 CKT	transformer circuit identifier (input).
Integer INTGAR (17)	array of 17 elements specifying (input).
	INTGAR(1) O1, first owner number
	INTGAR(2) O2, second owner number
	INTGAR(3) O3, third owner number
	INTGAR(4) O4, fourth owner number
	INTGAR(5) NTP1, number of tap positions
	INTGAR(6) TAB1, impedance correction table number
	INTGAR(7) CONT1, controlled bus number
	INTGAR(8) SICOD1, negative for controlled bus on winding one side
	INTGAR(9) COD1, adjustment control mode flag (-3 through +3)
	INTGAR(10) CW, winding data I/O code
	INTGAR(11) CZ, impedance data I/O code
	INTGAR(12) CM, magnetizing admittance data I/O code
	INTGAR(13) STAT, branch status
	INTGAR(14) NMETBS, non-metered end bus number (IBUS, JBUS or KBUS)

	INTGAR(15)	WN1BUS, winding one side bus number (IBUS, JBUS or KBUS)
	INTGAR(16)	WN2BUS, winding two side bus number (IBUS, JBUS or KBUS)
	INTGAR(17)	WN3BUS, winding three side bus number (IBUS, JBUS or KBUS)
Real REALAR (53)	array of elements specifying (first 41 are input values; last 12 are output values)(input).(output).	
	REALAR(1)	R1-2, nominal bus one to two transformer resistance
	REALAR(2)	X1-2, nominal bus one to two transformer reactance
	REALAR(3)	R3-1, nominal bus three to one transformer resistance
	REALAR(4)	X3-1, nominal bus three to one transformer reactance
	REALAR(5)	R2-3, nominal bus two to three transformer resistance
	REALAR(6)	X2-3, nominal bus two to three transformer reactance
	REALAR(7)	SBS1-2, winding one to two base MVA
	REALAR(8)	SBS2-3, winding two to three base MVA
	REALAR(9)	SBS3-1, winding three to one base MVA
	REALAR(10)	MAG1, magnetizing conductance or no-load losses
	REALAR(11)	MAG2, magnetizing susceptance or exciting current
	REALAR(12)	WINDV1, winding one ratio or voltage
	REALAR(13)	NOMV1, winding one nominal voltage
	REALAR(14)	1, winding one phase shift angle
	REALAR(15)	RATA1, winding one rating set A line rating
	REALAR(16)	RATB1, winding one rating set B line rating
	REALAR(17)	RATC1, winding one rating set C line rating
	REALAR(18)	WINDV2, winding two ratio or voltage
	REALAR(19)	NOMV2, winding two nominal voltage
	REALAR(20)	2, winding two phase shift angle
	REALAR(21)	RATA2, winding two rating set A line rating
	REALAR(22)	RATB2, winding two rating set B line rating
	REALAR(23)	RATC2, winding two rating set C line rating
	REALAR(24)	WINDV3, winding three ratio or voltage
	REALAR(25)	NOMV3, winding three nominal voltage
	REALAR(26)	3, winding three phase shift angle
	REALAR(27)	RATA3, winding three rating set A line rating
	REALAR(28)	RATB3, winding three rating set B line rating
	REALAR(29)	RATC3, winding three rating set C line rating

	REALAR(30)	F1, first owner fraction
	REALAR(31)	F2, second owner fraction
	REALAR(32)	F3, third owner fraction
	REALAR(33)	F4, fourth owner fraction
	REALAR(34)	RMA1, winding one ratio/angle high limit
	REALAR(35)	RMI1, winding one ratio/angle low limit
	REALAR(36)	VMA1, voltage or flow upper limit
	REALAR(37)	VMI1, voltage or flow lower limit
	REALAR(38)	CR1, load drop compensating resistance
	REALAR(39)	CX1, load drop compensating reactance
	REALAR(40)	VMSTAR, star bus voltage magnitude
	REALAR(41)	TAR, star bus voltage angle
	REALAR(42)	actual bus one to two resistance (returned)
	REALAR(43)	actual bus one to two reactance (returned)
	REALAR(44)	actual bus three to one resistance (returned)
	REALAR(45)	actual bus three to one reactance (returned)
	REALAR(46)	nominal winding one resistance (returned)
	REALAR(47)	nominal winding one reactance (returned)
	REALAR(48)	nominal winding two resistance (returned)
	REALAR(49)	nominal winding two reactance (returned)
	REALAR(50)	nominal winding three resistance (returned)
	REALAR(51)	nominal winding three reactance (returned)
	REALAR(52)	actual winding one resistance (returned)
	REALAR(53)	actual winding one reactance (returned)
Character*40 NAME	transformer name (input).	
Real REALARI	(input).	
Real REALARO	(output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW, CZ and/or CM >1 but no base voltage at one or more buses
	IERR = 5	three different buses must be specified
	IERR = 6	blank circuit identifier
	IERR = 7	circuit identifier may not start with '&'
	IERR = 8	three-winding transformer table full
	IERR = 9	bus table full
	IERR = 10	not enough branch table entries available
	IERR = 11	not enough room in two winding transformer table

IERR = 12 not enough room in branch ownership table
IERR = 13 prerequisite requirements for API are not met
IERR = -1 warnings - one or more of: - Invalid set of
 winding buses. - Invalid transformer status. -
 Invalid non-metered end bus. - Winding side
 buses interchanged. - Losses are too big rela-
 tive to total impedance at winding base MVA.
 - Magnitude of winding impedance is less
 than 0.00001. - Controlled bus not found. -
 Invalid adjustment control mode flag. - Any
 two-winding transformer warnings

Integer NERR number of entries in PBUF02 containing error messages (output).

1.2.122. THREE_WND_IMPEDANCE_DATA

This API routine is obsolete. It has been replaced by the API routine [three_wnd_imped_data_3](#).

Use this API routine to modify the impedance data of an existing three-winding transformer in the working case, or to add a new three-winding transformer to the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_THREE_WND_IMPEDANCE_DATA IBUS JBUS KBUS 'CKT'
    INTGAR(1)..INTGAR(12) REALAR(1)..REALAR(17) 'NAME'
```

Python command syntax:

```
ierr, realaro = three_wnd_impedance_data(ibus, jbus, kbus, ckt, intgar,
    realari, name)
```

Fortran command syntax:

```
CALL THREE_WINDING_IMPEDANCE_API_2(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR,
    NAME, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (12)	array of 12 elements specifying (input).
INTGAR(1)	O1, first owner number (owner of bus IBUS by default)
INTGAR(2)	O2, second owner number (0 by default)
INTGAR(3)	O3, third owner number (0 by default)
INTGAR(4)	O4, fourth owner number (0 by default)
INTGAR(5)	CW, winding data I/O code (1 by default)
INTGAR(6)	CZ, impedance data I/O code (1 by default)
INTGAR(7)	CM, magnetizing admittance data I/O code (1 by default)
INTGAR(8)	STAT, branch status (1 by default)
INTGAR(9)	NMETBS, non-metered end bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(10)	WN1BUS, winding one side bus number (IBUS, JBUS or KBUS) (IBUS by default)
INTGAR(11)	WN2BUS, winding two side bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(12)	WN3BUS, winding three side bus number (IBUS, JBUS or KBUS) (KBUS by default)

Real REALAR (23)	(first seventeen are input values; last six are output values) (input (output)).	
Real REALARI (17)	array of 17 elements specifying corresponding to values REALAR(1) through REALAR(17) as described above(input).	
	REALARI(1)	R1-2, nominal bus one to two transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal bus one to two transformer reactance (0.0002 by default)
	REALARI(3)	R2-3, nominal bus two to three transformer resistance (0.0 by default)
	REALARI(4)	X2-3, nominal bus two to three transformer reactance (0.0002 by default)
	REALARI(5)	R3-1, nominal bus three to one transformer resistance (0.0 by default)
	REALARI(6)	X3-1, nominal bus three to one transformer reactance (0.0002 by default)
	REALARI(7)	SBS1-2, winding one to two base MVA (SBASE by default)
	REALARI(8)	SBS2-3, winding two to three base MVA (SBASE by default)
	REALARI(9)	SBS3-1, winding three to one base MVA (SBASE by default)
	REALARI(10)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(11)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (0.0 by default)
	REALARI(14)	F3, third owner fraction (0.0 by default)
	REALARI(15)	F4, fourth owner fraction (0.0 by default)
	REALARI(16)	VMSTAR, star bus voltage magnitude (1.0 by default)
	REALARI(17)	TAR, star bus voltage angle (0.0 by default)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(18) through REALAR(23) as described above(output).	
	REALARO(1)	actual bus one to two resistance (returned)
	REALARO(2)	actual bus one to two reactance (returned)
	REALARO(3)	actual bus two to three resistance (returned)
	REALARO(4)	actual bus two to three reactance (returned)
	REALARO(5)	actual bus three to one resistance (returned)
	REALARO(6)	actual bus three to one reactance (returned)
Character*40 NAME	transformer name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred

IERR = 1	bus not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	invalid CW, CZ and/or CM value
IERR = 4	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 5	three different buses must be specified
IERR = 6	blank circuit identifier is invalid
IERR = 7	transformer circuit identifier may not start with &, * or @
IERR = 8	three-winding transformer table is full
IERR = 9	bus table is full
IERR = 10	not enough branch table entries are available
IERR = 11	not enough two-winding transformer table entries are available
IERR = 12	not enough branch ownership table entries are available
IERR = 14	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid set of winding buses. - Invalid CW, CZ and/or CM data value. - Invalid transformer status. - Invalid non-metered end bus. - Winding side buses interchanged. - Losses are too big relative to total impedance at winding base MVA. - Magnitude of winding impedance is less than 0.00001. - Any two-winding transformer warnings

1.2.123. THREE_WND_IMPED_CHNG_3

This API routine is obsolete. It has been replaced by the API routine [three_wnd_imped_chng_4](#).

Use this API routine to modify the impedance data of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_THREE_WND_IMPED_CHNG_3 IBUS JBUS KBUS 'CKT' INTGAR(1)..INTGAR(12)
REALAR(1)..REALAR(17) 'CHARAR(1)' 'CHARAR(2)'
```

Python command syntax:

```
ierr, realaro = three_wnd_imped_chng_3(ibus, jbus, kbus, ckt, intgar,
realari, charar)
```

Fortran command syntax:

```
CALL THREE_WINDING_IMPEDANCE_CHNG_3(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR,
CHARAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (12)	array of 12 elements specifying (input).
INTGAR(1)	O1, first owner number (owner of bus IBUS by default)
INTGAR(2)	O2, second owner number (0 by default)
INTGAR(3)	O3, third owner number (0 by default)
INTGAR(4)	O4, fourth owner number (0 by default)
INTGAR(5)	CW, winding data I/O code (1 by default)
INTGAR(6)	CZ, impedance data I/O code (1 by default)
INTGAR(7)	CM, magnetizing admittance data I/O code (1 by default)
INTGAR(8)	STAT, branch status (1 by default)
INTGAR(9)	NMETBS, non-metered end bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(10)	WN1BUS, winding one side bus number (IBUS, JBUS or KBUS) (IBUS by default)
INTGAR(11)	WN2BUS, winding two side bus number (IBUS, JBUS or KBUS) (JBUS by default)

	INTGAR(12)	WN3BUS, winding three side bus number (IBUS, JBUS or KBUS) (KBUS by default)
Real REALAR (23)	(first seventeen are input values; last six are output values) (input (output)).	
Real REALARI (17)	array of 17 elements specifying corresponding to values REALAR(1) through REALAR(17) as described above(input).	
	REALARI(1)	R1-2, nominal bus one to two transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal bus one to two transformer reactance (0.0002 by default)
	REALARI(3)	R2-3, nominal bus two to three transformer resistance (0.0 by default)
	REALARI(4)	X2-3, nominal bus two to three transformer reactance (0.0002 by default)
	REALARI(5)	R3-1, nominal bus three to one transformer resistance (0.0 by default)
	REALARI(6)	X3-1, nominal bus three to one transformer reactance (0.0002 by default)
	REALARI(7)	SBS1-2, winding one to two base MVA (SBASE by default)
	REALARI(8)	SBS2-3, winding two to three base MVA (SBASE by default)
	REALARI(9)	SBS3-1, winding three to one base MVA (SBASE by default)
	REALARI(10)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(11)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (0.0 by default)
	REALARI(14)	F3, third owner fraction (0.0 by default)
	REALARI(15)	F4, fourth owner fraction (0.0 by default)
	REALARI(16)	VMSTAR, star bus voltage magnitude (1.0 by default)
	REALARI(17)	TAR, star bus voltage angle (0.0 by default)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(18) through REALAR(23) as described above(output).	
	REALARO(1)	actual bus one to two resistance (returned)
	REALARO(2)	actual bus one to two reactance (returned)
	REALARO(3)	actual bus two to three resistance (returned)
	REALARO(4)	actual bus two to three reactance (returned)
	REALARO(5)	actual bus three to one resistance (returned)
	REALARO(6)	actual bus three to one reactance (returned)
Character*40 CHARAR (2)	array of 2 elements specifying (input).	
	CHARAR(1)	NAME, transformer name (blank by default)

	CHARAR(2)	VGRP, vector group name (blank by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
	IERR = 13	three-winding transformer not found
	IERR = 14	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Invalid set of winding buses. - Invalid CW, CZ and/or CM data value. - Invalid transformer status. - Invalid non-metered end bus. - Winding side buses interchanged. - Losses are too big relative to total impedance at winding base MVA. - Magnitude of winding impedance is less than 0.00001. - Vector group not found. - Any two-winding transformer warnings

1.2.124. THREE_WND_IMPED_CHNG_4

Use this API routine to modify the impedance data of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_THREE_WND_IMPED_CHNG_4 IBUS JBUS KBUS CKT INTGAR(1)..INTGAR(13)
REALAR(1)..REALAR(17) NAMEAR VGRPAR
```

Python command syntax:

```
ierr, realaro = three_wnd_imped_chng_4(ibus, jbus, kbus, ckt, intgar,
realari, namear, vgrpar)
```

Fortran command syntax:

```
CALL THREE_WINDING_IMPEDANCE_CHNG_4(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR,
NAMEAR, VGRPAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (13)	array of 13 elements specifying (input).
INTGAR(1)	O1, first owner number (owner of bus IBUS by default)
INTGAR(2)	O2, second owner number (0 by default)
INTGAR(3)	O3, third owner number (0 by default)
INTGAR(4)	O4, fourth owner number (0 by default)
INTGAR(5)	CW, winding data I/O code (1 by default)
INTGAR(6)	CZ, impedance data I/O code (1 by default)
INTGAR(7)	CM, magnetizing admittance data I/O code (1 by default)
INTGAR(8)	STAT, branch status (1 by default)
INTGAR(9)	NMETBS, non-metered end bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(10)	WN1BUS, winding one side bus number (IBUS, JBUS or KBUS) (IBUS by default)
INTGAR(11)	WN2BUS, winding two side bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(12)	WN3BUS, winding three side bus number (IBUS, JBUS or KBUS) (KBUS by default)
INTGAR(13)	ZCOD, impedance adjustment code (0 by default)

Real REALAR (23)	(first seventeen are input values; last six are output values) (input (output)).
Real REALARI (17)	array of 17 elements specifying corresponding to values REALAR(1) through REALAR(17) as described above(input).
REALARI(1)	R1-2, nominal bus one to two transformer resistance (0.0 by default)
REALARI(2)	X1-2, nominal bus one to two transformer reactance (0.0002 by default)
REALARI(3)	R2-3, nominal bus two to three transformer resistance (0.0 by default)
REALARI(4)	X2-3, nominal bus two to three transformer reactance (0.0002 by default)
REALARI(5)	R3-1, nominal bus three to one transformer resistance (0.0 by default)
REALARI(6)	X3-1, nominal bus three to one transformer reactance (0.0002 by default)
REALARI(7)	SBS1-2, winding one to two base MVA (SBASE by default)
REALARI(8)	SBS2-3, winding two to three base MVA (SBASE by default)
REALARI(9)	SBS3-1, winding three to one base MVA (SBASE by default)
REALARI(10)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
REALARI(11)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
REALARI(12)	F1, first owner fraction (1.0 by default)
REALARI(13)	F2, second owner fraction (0.0 by default)
REALARI(14)	F3, third owner fraction (0.0 by default)
REALARI(15)	F4, fourth owner fraction (0.0 by default)
REALARI(16)	VMSTAR, star bus voltage magnitude (1.0 by default)
REALARI(17)	TAR, star bus voltage angle (0.0 by default)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(18) through REALAR(23) as described above(output).
REALARO(1)	actual bus one to two resistance (returned)
REALARO(2)	actual bus one to two reactance (returned)
REALARO(3)	actual bus two to three resistance (returned)
REALARO(4)	actual bus two to three reactance (returned)
REALARO(5)	actual bus three to one resistance (returned)
REALARO(6)	actual bus three to one reactance (returned)
Character*40 NAMEAR	transformer name (input; blank by default).
Character*12 VGRPAR	vector group name (input; blank by default).
Integer IERR	error code (output).

IERR = 0	no error occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	invalid CW, CZ and/or CM value
IERR = 4	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 13	three-winding transformer not found
IERR = 14	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid set of winding buses. - Invalid CW, CZ and/or CM data value. - Invalid transformer status. - Invalid non-metered end bus. - Winding side buses interchanged. - Losses are too big relative to total impedance at winding base MVA. - Magnitude of winding impedance is less than 0.00001. - Vector group not found. - Any two-winding transformer warnings

1.2.125. THREE_WND_IMPED_DATA_3

This API routine is obsolete. It has been replaced by the API routine [three_wnd_imped_data_4](#).

Use this API routine to modify the impedance data of an existing three-winding transformer in the working case, or to add a new three-winding transformer to the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_THREE_WND_IMPED_DATA_3 IBUS JBUS KBUS 'CKT' INTGAR(1)..INTGAR(12)
REALAR(1)..REALAR(17) 'CHARAR(1)' 'CHARAR(2)'
```

Python command syntax:

```
ierr, realaro = three_wnd_imped_data_3(ibus, jbus, kbus, ckt, intgar,
realari, charar)
```

Fortran command syntax:

```
CALL THREE_WINDING_IMPEDANCE_API_3(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR,
CHARAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (12)	array of 12 elements specifying (input).
INTGAR(1)	O1, first owner number (owner of bus IBUS by default)
INTGAR(2)	O2, second owner number (0 by default)
INTGAR(3)	O3, third owner number (0 by default)
INTGAR(4)	O4, fourth owner number (0 by default)
INTGAR(5)	CW, winding data I/O code (1 by default)
INTGAR(6)	CZ, impedance data I/O code (1 by default)
INTGAR(7)	CM, magnetizing admittance data I/O code (1 by default)
INTGAR(8)	STAT, branch status (1 by default)
INTGAR(9)	NMETBS, non-metered end bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(10)	WN1BUS, winding one side bus number (IBUS, JBUS or KBUS) (IBUS by default)
INTGAR(11)	WN2BUS, winding two side bus number (IBUS, JBUS or KBUS) (JBUS by default)

	INTGAR(12)	WN3BUS, winding three side bus number (IBUS, JBUS or KBUS) (KBUS by default)
Real REALAR (23)	(first seventeen are input values; last six are output values) (input (output)).	
Real REALARI (17)	array of 17 elements specifying corresponding to values REALAR(1) through REALAR(17) as described above(input).	
	REALARI(1)	R1-2, nominal bus one to two transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal bus one to two transformer reactance (0.0002 by default)
	REALARI(3)	R2-3, nominal bus two to three transformer resistance (0.0 by default)
	REALARI(4)	X2-3, nominal bus two to three transformer reactance (0.0002 by default)
	REALARI(5)	R3-1, nominal bus three to one transformer resistance (0.0 by default)
	REALARI(6)	X3-1, nominal bus three to one transformer reactance (0.0002 by default)
	REALARI(7)	SBS1-2, winding one to two base MVA (SBASE by default)
	REALARI(8)	SBS2-3, winding two to three base MVA (SBASE by default)
	REALARI(9)	SBS3-1, winding three to one base MVA (SBASE by default)
	REALARI(10)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(11)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (0.0 by default)
	REALARI(14)	F3, third owner fraction (0.0 by default)
	REALARI(15)	F4, fourth owner fraction (0.0 by default)
	REALARI(16)	VMSTAR, star bus voltage magnitude (1.0 by default)
	REALARI(17)	TAR, star bus voltage angle (0.0 by default)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(18) through REALAR(23) as described above(output).	
	REALARO(1)	actual bus one to two resistance (returned)
	REALARO(2)	actual bus one to two reactance (returned)
	REALARO(3)	actual bus two to three resistance (returned)
	REALARO(4)	actual bus two to three reactance (returned)
	REALARO(5)	actual bus three to one resistance (returned)
	REALARO(6)	actual bus three to one reactance (returned)
Character*40 CHARAR (2)	array of 2 elements specifying (input).	
	CHARAR(1)	NAME, transformer name (blank by default)

	CHARAR(2)	VGRP, vector group name (blank by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
	IERR = 5	three different buses must be specified
	IERR = 6	blank circuit identifier is invalid
	IERR = 7	transformer circuit identifier may not start with &, * or @
	IERR = 8	three-winding transformer table is full
	IERR = 9	bus table is full
	IERR = 10	not enough branch table entries are available
	IERR = 11	not enough two-winding transformer table entries are available
	IERR = 12	not enough branch ownership table entries are available
	IERR = 14	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Invalid set of winding buses. - Invalid CW, CZ and/or CM data value. - Invalid transformer status. - Invalid non-metered end bus. - Winding side buses interchanged. - Losses are too big relative to total impedance at winding base MVA. - Magnitude of winding impedance is less than 0.00001. - Vector group not found. - Any two-winding transformer warnings

1.2.126. THREE_WND_IMPED_DATA_4

Use this API routine to modify the impedance data of an existing three-winding transformer in the working case, or to add a new three-winding transformer to the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_THREE_WND_IMPED_DATA_4  IBUS JBUS KBUS CKT INTGAR(1)..INTGAR(13)
                             REALAR(1)..REALAR(17) NAMEAR VGRPAR
```

Python command syntax:

```
ierr, realaro = three_wnd_imped_data_4(ibus, jbus, kbus, ckt, intgar,
                                         realari, namear, vgrpar)
```

Fortran command syntax:

```
CALL THREE_WINDING_IMPEDANCE_API_4(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR,
                                     NAMEAR, VGRPAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (13)	array of 13 elements specifying (input).
INTGAR(1)	O1, first owner number (owner of bus IBUS by default)
INTGAR(2)	O2, second owner number (0 by default)
INTGAR(3)	O3, third owner number (0 by default)
INTGAR(4)	O4, fourth owner number (0 by default)
INTGAR(5)	CW, winding data I/O code (1 by default)
INTGAR(6)	CZ, impedance data I/O code (1 by default)
INTGAR(7)	CM, magnetizing admittance data I/O code (1 by default)
INTGAR(8)	STAT, branch status (1 by default)
INTGAR(9)	NMETBS, non-metered end bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(10)	WN1BUS, winding one side bus number (IBUS, JBUS or KBUS) (IBUS by default)
INTGAR(11)	WN2BUS, winding two side bus number (IBUS, JBUS or KBUS) (JBUS by default)
INTGAR(12)	WN3BUS, winding three side bus number (IBUS, JBUS or KBUS) (KBUS by default)

	INTGAR(13)	ZCOD, transformer impedance adjustment code (0 for winding impedances, 1 for bus-to-bus impedances) (0 by default)
Real REALAR (23)	(first seventeen are input values; last six are output values) (input (output).).	
Real REALARI (17)	array of 17 elements specifying corresponding to values REALAR(1) through REALAR(17) as described above(input).	
	REALARI(1)	R1-2, nominal bus one to two transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal bus one to two transformer reactance (0.0002 by default)
	REALARI(3)	R2-3, nominal bus two to three transformer resistance (0.0 by default)
	REALARI(4)	X2-3, nominal bus two to three transformer reactance (0.0002 by default)
	REALARI(5)	R3-1, nominal bus three to one transformer resistance (0.0 by default)
	REALARI(6)	X3-1, nominal bus three to one transformer reactance (0.0002 by default)
	REALARI(7)	SBS1-2, winding one to two base MVA (SBASE by default)
	REALARI(8)	SBS2-3, winding two to three base MVA (SBASE by default)
	REALARI(9)	SBS3-1, winding three to one base MVA (SBASE by default)
	REALARI(10)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(11)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (0.0 by default)
	REALARI(14)	F3, third owner fraction (0.0 by default)
	REALARI(15)	F4, fourth owner fraction (0.0 by default)
	REALARI(16)	VMSTAR, star bus voltage magnitude (1.0 by default)
	REALARI(17)	TAR, star bus voltage angle (0.0 by default)
Real REALARO (6)	array of 6 elements specifying corresponding to values REALAR(18) through REALAR(23) as described above(output).	
	REALARO(1)	actual bus one to two resistance (returned)
	REALARO(2)	actual bus one to two reactance (returned)
	REALARO(3)	actual bus two to three resistance (returned)
	REALARO(4)	actual bus two to three reactance (returned)
	REALARO(5)	actual bus three to one resistance (returned)
	REALARO(6)	actual bus three to one reactance (returned)
Character*40 NAMEAR	transformer name (input; blank by default).	

Character*12 VGRPAR	vector group name (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	invalid CW, CZ and/or CM value
IERR = 4	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 5	three different buses must be specified
IERR = 6	blank circuit identifier is invalid
IERR = 7	transformer circuit identifier may not start with &, * or @
IERR = 8	three-winding transformer table is full
IERR = 9	bus table is full
IERR = 10	not enough branch table entries are available
IERR = 11	not enough two-winding transformer table entries are available
IERR = 12	not enough branch ownership table entries are available
IERR = 14	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid set of winding buses. - Invalid CW, CZ and/or CM data value. - Invalid transformer status. - Invalid non-metered end bus. - Winding side buses interchanged. - Losses are too big relative to total impedance at winding base MVA. - Magnitude of winding impedance is less than 0.00001. - Vector group not found. - Any two-winding transformer warnings

1.2.127. THREE_WND_WINDING_DATA

This API routine is obsolete. It has been replaced by the API routine [three_wnd_winding_data_3](#).

Use this API to modify the data of one winding of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_THREE_WND_WINDING_DATA IBUS JBUS KBUS 'CKT' WARG
    INTGAR(1)..INTGAR(5) REALAR(1)..REALAR(12)
```

Python command syntax:

```
ierr, realaro = three_wnd_winding_data(ibus, jbus, kbus, ckt, warg,
    intgar, realari)
```

Fortran command syntax:

```
CALL THREE_WINDING_WINDING_API_2(IBUS, JBUS, KBUS, CKT, WARG, INTGAR,
    REALAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer WARG	winding number (1, 2 or 3) (input; no default allowed).
Integer INTGAR (5)	array of 5 elements specifying (input). INTGAR(1) NTPi, number of tap positions (33 by default) INTGAR(2) TABi, impedance correction table number (0 by default) INTGAR(3) CONTi, controlled bus number (0 by default) INTGAR(4) SICODi, negative for controlled bus on winding bus side (1 by default) INTGAR(5) CODi, adjustment control mode flag (-3 through +3) (0 by default)
Real REALAR (16)	(first twelve are input values; last four are output values) (input (output)).).
Real REALARI (12)	array of 12 elements specifying corresponding to values REALAR(1) through REALAR(12) as described above(input). REALARI(1) WINDVi, winding ratio or voltage (1.0 by default if CW of this transformer is 1 or 3; base voltage of the winding bus by default if CW is 2)

	REALARI(2)	NOMVi, winding nominal voltage (0.0 by default)
	REALARI(3)	i, winding phase shift angle (0.0 by default)
	REALARI(4)	RATAi, winding rating set A line rating (0.0 by default)
	REALARI(5)	RATBi, winding rating set B line rating (0.0 by default)
	REALARI(6)	RATCi, winding rating set C line rating (0.0 by default)
	REALARI(7)	RMAi, winding ratio/angle high limit (1.1 by default)
	REALARI(8)	RMLi, winding ratio/angle low limit (0.9 by default)
	REALARI(9)	VMAi, winding voltage or flow upper limit (1.1 by default)
	REALARI(10)	VMli, winding voltage or flow lower limit (0.9 by default)
	REALARI(11)	CRi, winding load drop compensating resistance (0.0 by default)
	REALARI(12)	CXi, winding load drop compensating reactance (0.0 by default)
Real REALARO (4)	array of 4 elements specifying corresponding to values REALAR(13) through REALAR(16) as described above(output).	
	REALARO(1)	winding nominal resistance (returned)
	REALARO(2)	winding nominal reactance (returned)
	REALARO(3)	winding actual resistance (returned)
	REALARO(4)	winding actual reactance (returned)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW and/or CZ >1 but no base voltage at winding bus
	IERR = 5	three winding transformer not found
	IERR = 6	invalid winding number
	IERR = 7	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Controlled bus not found. - Invalid adjustment control mode flag. - Any two-winding transformer warnings

1.2.128. THREE_WND_WINDING_DATA_3

This API routine is obsolete. It has been replaced by the API routine [three_wnd_winding_data_4](#).

Use this API to modify the data of one winding of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_THREE_WND_WINDING_DATA_3 IBUS JBUS KBUS 'CKT' WARG
    INTGAR(1)..INTGAR(5) REALAR(1)..REALAR(12)
```

Python command syntax:

```
ierr, realaro = three_wnd_winding_data_3(ibus, jbus, kbus, ckt, warg,
    intgar, realari)
```

Fortran command syntax:

```
CALL THREE_WINDING_WINDING_API_3(IBUS, JBUS, KBUS, CKT, WARG, INTGAR,
    REALAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).										
Integer JBUS	bus number one of the other buses (input; no default allowed).										
Integer KBUS	bus number of the third bus (input; no default allowed).										
Character*2 CKT	transformer circuit identifier (input; '1' by default).										
Integer WARG	winding number (1, 2 or 3) (input; no default allowed).										
Integer INTGAR (5)	array of 5 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>NTPi, number of tap positions (33 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>TABi, impedance correction table number (0 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>CONTi, controlled bus number (0 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>SICODi, negative for controlled bus on winding bus side (1 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>CODi, adjustment control mode flag (-3 through +3, -5 or 5) (0 by default)</td></tr> </table>	INTGAR(1)	NTPi, number of tap positions (33 by default)	INTGAR(2)	TABi, impedance correction table number (0 by default)	INTGAR(3)	CONTi, controlled bus number (0 by default)	INTGAR(4)	SICODi, negative for controlled bus on winding bus side (1 by default)	INTGAR(5)	CODi, adjustment control mode flag (-3 through +3, -5 or 5) (0 by default)
INTGAR(1)	NTPi, number of tap positions (33 by default)										
INTGAR(2)	TABi, impedance correction table number (0 by default)										
INTGAR(3)	CONTi, controlled bus number (0 by default)										
INTGAR(4)	SICODi, negative for controlled bus on winding bus side (1 by default)										
INTGAR(5)	CODi, adjustment control mode flag (-3 through +3, -5 or 5) (0 by default)										
Real REALAR (17)	(first thirteen are input values; last four are output values) (input (output).).										
Real REALARI (13)	array of 13 elements specifying corresponding to values REALAR(1) through REALAR(13) as described above(input). <table> <tr> <td>REALARI(1)</td><td>WINDVi, winding ratio or voltage (1.0 by default if CW of this transformer is 1 or 3; base voltage of the winding bus by default if CW is 2)</td></tr> <tr> <td>REALARI(2)</td><td>NOMVi, winding nominal voltage (0.0 by default)</td></tr> </table>	REALARI(1)	WINDVi, winding ratio or voltage (1.0 by default if CW of this transformer is 1 or 3; base voltage of the winding bus by default if CW is 2)	REALARI(2)	NOMVi, winding nominal voltage (0.0 by default)						
REALARI(1)	WINDVi, winding ratio or voltage (1.0 by default if CW of this transformer is 1 or 3; base voltage of the winding bus by default if CW is 2)										
REALARI(2)	NOMVi, winding nominal voltage (0.0 by default)										

	REALARI(3)	i, winding phase shift angle (0.0 by default)
	REALARI(4)	RATAi, winding rating set A line rating (0.0 by default)
	REALARI(5)	RATBi, winding rating set B line rating (0.0 by default)
	REALARI(6)	RATCi, winding rating set C line rating (0.0 by default)
	REALARI(7)	RMAi, winding ratio/angle high limit (1.1 by default)
	REALARI(8)	RMLi, winding ratio/angle low limit (0.9 by default)
	REALARI(9)	VMAi, winding voltage or flow upper limit (1.1 by default)
	REALARI(10)	VMli, winding voltage or flow lower limit (0.9 by default)
	REALARI(11)	CRi, winding load drop compensating resistance (0.0 by default)
	REALARI(12)	CXi, winding load drop compensating reactance (0.0 by default)
	REALARI(13)	CNXAi, winding connection angle (0.0 by default). Used with adjustment control mode 5 (unsymmetric phase shift control of active power) implemented in PSSE version 32.1)
Real REALARO (4)	array of 4 elements specifying corresponding to values REALAR(14) through REALAR(17) as described above(output).	
	REALARO(1)	winding nominal resistance (returned)
	REALARO(2)	winding nominal reactance (returned)
	REALARO(3)	winding actual resistance (returned)
	REALARO(4)	winding actual reactance (returned)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW and/or CZ >1 but no base voltage at winding bus
	IERR = 5	three winding transformer not found
	IERR = 6	invalid winding number
	IERR = 7	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Controlled bus not found. - Invalid adjustment control mode flag. - Any two-winding transformer warnings

1.2.129. THREE_WND_WINDING_DATA_4

This API routine is obsolete. It has been replaced by the API routine [three_wnd_winding_data_5](#).

Use this API to modify the data of one winding of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_THREE_WND_WINDING_DATA_4 IBUS JBUS KBUS CKT WARG INTGAR(1)..INTGAR(5)
REALAR(1)..REALAR(10) RATINGS(1)..RATINGS(12)
```

Python command syntax:

```
ierr, realaro = three_wnd_winding_data_4(ibus, jbus, kbus, ckt, warg,
intgar, realari, ratings)
```

Fortran command syntax:

```
CALL THREE_WINDING_WINDING_DATA_4(IBUS, JBUS, KBUS, CKT, WARG, INTGAR,
REALAR, RATINGS, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer WARG	winding number (1, 2 or 3) (input; no default allowed).
Integer INTGAR (5)	array of 5 elements specifying (input). INTGAR(1) NTPI, number of tap positions (33 by default) INTGAR(2) TABi, impedance correction table number (0 by default) INTGAR(3) CONTi, controlled bus number (0 by default) INTGAR(4) SICODi, negative for controlled bus on winding bus side (1 by default) INTGAR(5) CODi, adjustment control mode flag (-3 through +3, -5 or 5) (0 by default)
Real REALAR (14)	(first ten are input values; last four are output values) (input (output)).).
Real REALARI (10)	array of 10 elements specifying corresponding to values REALAR(1) through REALAR(10) as described above(input). REALARI(1) WINDVi, winding ratio or voltage (1.0 by default if CW of this transformer is 1 or 3; base voltage of the winding bus by default if CW is 2) REALARI(2) NOMVi, winding nominal voltage (0.0 by default)

	REALARI(3)	i, winding phase shift angle (0.0 by default)
	REALARI(4)	RMAi, winding ratio/angle high limit (1.1 by default)
	REALARI(5)	RMLi, winding ratio/angle low limit (0.9 by default)
	REALARI(6)	VMAi, winding voltage or flow upper limit (1.1 by default)
	REALARI(7)	VMLi, winding voltage or flow lower limit (0.9 by default)
	REALARI(8)	CRi, winding load drop compensating resistance (0.0 by default)
	REALARI(9)	CXi, winding load drop compensating reactance (0.0 by default)
	REALARI(10)	CNXAi, winding connection angle (0.0 by default). Used with adjustment control mode 5 (unsymmetric phase shift control of active power) implemented in PSSE version 32.1)
Real REALARO (4)	array of 4 elements specifying corresponding to values REALAR(11) through REALAR(14) as described above(output).	
	REALARO(1)	winding nominal resistance (returned)
	REALARO(2)	winding nominal reactance (returned)
	REALARO(3)	winding actual resistance (returned)
	REALARO(4)	winding actual reactance (returned)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1i, winding rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2i, winding rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3i, winding rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4i, winding rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5i, winding rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6i, winding rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7i, winding rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8i, winding rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9i, winding rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10i, winding rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11i, winding rating set 11 line rating (alias is RATE11) (0.0 by default)

	RATINGS(12)	RATE12i, winding rating set 12 line rating (alias is RATE12) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW and/or CZ >1 but no base voltage at winding bus
	IERR = 5	three winding transformer not found
	IERR = 6	invalid winding number
	IERR = 7	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Controlled bus not found. - Invalid adjustment control mode flag. - Any two-winding transformer warnings

1.2.130. THREE_WND_WINDING_DATA_5

Use this API to modify the data of one winding of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Non-Transformer Branch Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_THREE_WND_WINDING_DATA_5 IBUS JBUS KBUS CKT WARG INTGAR(1)..INTGAR(6)
REALAR(1)..REALAR(10) RATINGS(1)..RATINGS(12)
```

Python command syntax:

```
ierr, realaro = three_wnd_winding_data_5(ibus, jbus, kbus, ckt, warg,
intgar, realari, ratings)
```

Fortran command syntax:

```
CALL THREE_WINDING_WINDING_DATA_5(IBUS, JBUS, KBUS, CKT, WARG, INTGAR,
REALAR, RATINGS, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer WARG	winding number (1, 2 or 3) (input; no default allowed).
Integer INTGAR (6)	array of 6 elements specifying (input).
	INTGAR(1) NTPI, number of tap positions (33 by default)
	INTGAR(2) TABi, impedance correction table number (0 by default)
	INTGAR(3) CONTi, controlled bus number (0 by default)
	INTGAR(4) NODEi, controlled node number (0 by default)
	INTGAR(5) SICODi, negative for controlled bus on winding bus side (1 by default)
	INTGAR(6) CODi, adjustment control mode flag (-3 through +3, -5 or 5) (0 by default)
Real REALAR (14)	(first ten are input values; last four are output values) (input (output)).).
Real REALARI (10)	array of 10 elements specifying corresponding to values REALAR(1) through REALAR(10) as described above(input).
	REALARI(1) WINDVi, winding ratio or voltage (1.0 by default if CW of this transformer is 1 or 3; base voltage of the winding bus by default if CW is 2)
	REALARI(2) NOMVi, winding nominal voltage (0.0 by default)

	REALARI(3)	i, winding phase shift angle (0.0 by default)
	REALARI(4)	RMAi, winding ratio/angle high limit (1.1 by default)
	REALARI(5)	RMLi, winding ratio/angle low limit (0.9 by default)
	REALARI(6)	VMAi, winding voltage or flow upper limit (1.1 by default)
	REALARI(7)	VMLi, winding voltage or flow lower limit (0.9 by default)
	REALARI(8)	CRi, winding load drop compensating resistance (0.0 by default)
	REALARI(9)	CXi, winding load drop compensating reactance (0.0 by default)
	REALARI(10)	CNXAi, winding connection angle (0.0 by default). Used with adjustment control mode 5 (unsymmetric phase shift control of active power) implemented in PSSE version 32.1)
Real REALARO (4)	array of 4 elements specifying corresponding to values REALAR(11) through REALAR(14) as described above(output).	
	REALARO(1)	winding nominal resistance (returned)
	REALARO(2)	winding nominal reactance (returned)
	REALARO(3)	winding actual resistance (returned)
	REALARO(4)	winding actual reactance (returned)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1i, winding rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2i, winding rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3i, winding rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4i, winding rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5i, winding rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6i, winding rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7i, winding rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8i, winding rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9i, winding rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10i, winding rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11i, winding rating set 11 line rating (alias is RATE11) (0.0 by default)

	RATINGS(12)	RATE12i, winding rating set 12 line rating (alias is RATE12) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	invalid CW, CZ and/or CM value
	IERR = 4	CW and/or CZ >1 but no base voltage at winding bus
	IERR = 5	three winding transformer not found
	IERR = 6	invalid winding number
	IERR = 7	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Controlled bus not found. - Invalid adjustment control mode flag. - Any two-winding transformer warnings

1.2.131. TRANSACTION_ADD_MOD

Use this API to add or modify transaction event data in PSSE working memory.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_TRANSACTION_ADD_MOD  EVENT  INTGAR(1)  INTGAR(2)  REALAR(1)  REALAR(2)
'DSCRP'
```

Python command syntax:

```
ierr = transaction_add_mod(event, intgar, realar, dscrp)
```

Fortran command syntax:

```
CALL TRANSACTION_ADD_MOD(EVENT, INTGAR, REALAR, DSCRP, IERR, NERR)
```

Where:

Integer EVENT	transaction event number (input).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) transaction event status (0 = out-of-service, 1 = in-service)
	INTGAR(2) transaction event priority
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) transaction event magnitude in MW
	REALAR(2) transaction event curtailment in MW
Character*24 DSCRP	transaction event description (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 error occurred
	IERR = 2 invalid transaction event number
	IERR > 2 unable to add or modify transaction event data: error condition detected in data access routine
	IERR = 10 prerequisite requirements for API are not met
	IERR = -1 warnings: - None
Integer NERR	number of error entries in PBUF02 (output).

1.2.132. TRANSACTION_DELETE

Use this API to delete a transaction event from PSSE working memory.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_TRANSACTION_DELETE  EVENT
```

Python command syntax:

```
ierr = transaction_delete(event)
```

Fortran command syntax:

```
CALL TRANSACTION_DELETE(EVENT, IERR, NERR)
```

Where:

Integer EVENT	transaction event number (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid transaction event number
	IERR = 2 prerequisite requirements for API are not met
Integer NERR	number of error entries in PBUF02 (output).

1.2.133. TRANSFER_CHNG

Use this API routine to modify the data of an inter-area transfer in the working case (see PSSE Program Operation Manual, Zone Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_TRANSFER_CHNG APPLYF ARFROM ARTO 'TRID' REALAR(1)
```

Python command syntax:

```
ierr = transfer_chng(applyf, arfrom, arto, trid, realar)
```

Fortran command syntax:

```
CALL TRANSFER_CHNG(APPLYF, ARFROM, ARTO, TRID, REALAR, IERR)
```

Where:

Integer APPLYF	APPLYF = 1 to modify from and to area desired net interchange entries (DESINT) (input). APPLYF = 2 to leave DESINT entries unchanged. (Input; no default allowed.)
Integer ARFROM	from area number (must be an area already defined) (input; no default allowed).
Integer ARTO	to area number (must be an area already defined) (input; no default allowed).
Character*1 TRID	inter-area transfer identifier (input; '1' by default).
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) PTRAN, MW comprising this inter-area transfer (0.0 by default)
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 invalid area number IERR = 2 inter-area transfer identifier is more than one character IERR = 3 invalid APPLYF value IERR = 8 area not found IERR = 9 inter-area transfer not found IERR = 10 prerequisite requirements for API are not met IERR = -1 data error, warning and information messages; one or more of: - Changes to desired area net interchanges if APPLYF = 1

1.2.134. TRANSFER_DATA

Use this API routine to modify the data of an inter-area transfer in the working case, or to add a new inter-area transfer to the working case (see PSSE Program Operation Manual, Zone Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TRANSFER_DATA APPLYF ARFROM ARTO 'TRID' REALAR(1)
```

Python command syntax:

```
ierr = transfer_data(applyf, arfrom, artto, trid, realar)
```

Fortran command syntax:

```
CALL TRANSFER_API_2(APPLYF, ARFROM, ARTO, TRID, REALAR, IERR)
```

Where:

Integer APPLYF	APPLYF = 1 to modify from and to area desired net interchange entries (DESINT) (input). APPLYF = 2 to leave DESINT entries unchanged. (Input; no default allowed.)
Integer ARFROM	from area number (must be an area already defined) (input; no default allowed).
Integer ARTO	to area number (must be an area already defined) (input; no default allowed).
Character*1 TRID	inter-area transfer identifier (input; '1' by default).
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) PTRAN, MW comprising this inter-area transfer (0.0 by default)
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 invalid area number IERR = 2 inter-area transfer identifier is more than one character IERR = 3 invalid APPLYF value IERR = 4 invalid inter-area transfer identifier IERR = 5 transfer from an area to itself IERR = 6 inter-area transfer table is full IERR = 7 inter-area transfer already exists IERR = 8 area not found IERR = 10 prerequisite requirements for API are not met IERR = -1 data error, warning and information messages; one or more of: - Changes to desired area net interchanges if APPLYF = 1

1.2.135. TWO_TERMINAL_DC_LINE_CHNG

Use this API routine to modify the link data of an existing two-terminal dc line in the working case (see PSSE Program Operation Manual, Area Interchange Data). Converter data for the rectifier and inverter are specified via the TWO_TERM_DC_CONVR_DATA API routine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_TWO_TERMINAL_DC_LINE_CHNG DC INTGAR(1) INTGAR(2) REALAR(1)..REALAR(8)
'METER'
```

Python command syntax:

```
ierr, realaro = two_terminal_dc_line_chng(dc, intgar, realari, meter)
```

Fortran command syntax:

```
CALL TWO_TERMINAL_DC_LINE_CHNG(NUM, INTGAR, REALAR, METER, IERR)

CALL TWO_TERMINAL_DC_LINE_CHNG_I(NUM, INTGAR, REALAR, METER, IERR)

CALL TWO_TERMINAL_DC_LINE_CHNG_C(NAME, INTGAR, REALAR, METER, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which data is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which data is to be specified; no default allowed
Character*12 NAME	name of the two-terminal dc line for which data is to be specified; no default allowed
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) MDC, control mode (0, 1 or 2) (0 by default) INTGAR(2) CCITMX, CCC Newton solution iteration limit (20 by default)
Real REALAR (9)	first eight are input values; last value is output (input (output)).
Real REALARI (8)	array of 8 elements specifying values REALAR(1) through REALAR(8) as described above(input). REALARI(1) SETVL, scheduled current (amps) or power (MW) demand (0.0 by default) REALARI(2) VSCHD, scheduled dc voltage (kV) (1.0 by default) REALARI(3) VCMOD, mode switch dc voltage (kV) (0.0 by default) REALARI(4) DELTI, margin (pu, > 0) (0.0 by default) REALARI(5) RDC, dc line resistance (0.0 by default)

	REALARI(6)	RCOMP, compounding resistance (0.0 by default)
	REALARI(7)	DCVMIN, minimum dc voltage (kV) (0.0 by default)
	REALARI(8)	CCCACC, CCC Newton solution acceleration (1.0 by default)
Real REALARO (1)	array of 1 elements specifying value REALAR(9) as described above(output).	
	REALARO(1)	dc line current (amps) (returned)
Character*1 METER	metered end flag: 'R' or 'I' (input; 'I' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 2	metered end code is more than one character
	IERR = 3	blank dc line name is invalid
	IERR = 4	two-terminal dc line not found
	IERR = 5	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid compounding resistance - compounding resistance exceeds line resistance - scheduled voltage must exceed mode switch voltage - invalid metered end code

1.2.136. TWO_TERMINAL_DC_LINE_DATA

Use this API routine to modify the link data of an existing two-terminal dc line in the working case, or to add a new two-terminal dc line and its link data to the working case (see PSSE Program Operation Manual, Area Interchange Data). Converter data for the rectifier and inverter are specified via the TWO_TERM_DC_CONVR_DATA API routine.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TWO_TERMINAL_DC_LINE_DATA DC INTGAR(1) INTGAR(2) REALAR(1)..REALAR(8)
'METER'
```

Python command syntax:

```
ierr, realaro = two_terminal_dc_line_data(dc, intgar, realari, meter)
```

Fortran command syntax:

```
CALL TWO_TERMINAL_DC_LINE_API(NUM, INTGAR, REALAR, METER, IERR)
CALL TWO_TERMINAL_DC_LINE_API_I(NUM, INTGAR, REALAR, METER, IERR)
CALL TWO_TERMINAL_DC_LINE_API_C(NAME, INTGAR, REALAR, METER, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which data is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which data is to be specified; no default allowed
Character*12 NAME	name of the two-terminal dc line for which data is to be specified; no default allowed
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) MDC, control mode (0, 1 or 2) (0 by default) INTGAR(2) CCITMX, CCC Newton solution iteration limit (20 by default)
Real REALAR (9)	first eight are input values; last value is output (input (output)).
Real REALARI (8)	array of 8 elements specifying values REALAR(1) through REALAR(8) as described above(input). REALARI(1) SETVL, scheduled current (amps) or power (MW) demand (0.0 by default) REALARI(2) VSCHD, scheduled dc voltage (kV) (1.0 by default) REALARI(3) VCMOD, mode switch dc voltage (kV) (0.0 by default) REALARI(4) DELTI, margin (pu, > 0) (0.0 by default) REALARI(5) RDC, dc line resistance (0.0 by default)

	REALARI(6)	RCOMP, compounding resistance (0.0 by default)
	REALARI(7)	DCVMIN, minimum dc voltage (kV) (0.0 by default)
	REALARI(8)	CCCACC, CCC Newton solution acceleration (1.0 by default)
Real REALARO (1)	array of 1 elements specifying value REALAR(9) as described above(output).	
	REALARO(1)	dc line current (amps) (returned)
Character*1 METER	metered end flag: 'R' or 'I' (input; 'I' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	two-terminal dc line table is full
	IERR = 2	metered end code is more than one character
	IERR = 3	blank dc line name is invalid
	IERR = 5	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid compounding resistance - compounding resistance exceeds line resistance - scheduled voltage must exceed mode switch voltage - invalid metered end code

1.2.137. TWO_TERM_DC_CONVERTER_DATA_3

Use this API to modify the data of a dc converter of an existing two-terminal dc line in the working case (see PSSE Program Operation Manual, Area Interchange Data). The dc line must have previously been specified via the TWO_TERMINAL_DC_LINE_DATA API.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_TWO_TERM_DC_CONVERTER_DATA_3 CNVFLG NAME INTGAR(1)..INTGAR(6)
REALAR(1)..REALAR(11) 'ID'
```

Python command syntax:

```
ierr, realaro = two_term_dc_converter_data_3(cnvflg, name, intgar,
realari, id)
```

Fortran command syntax:

```
CALL TWO_TERM_DC_CONVERTER_DATA_3 (CNVFLG, NAME, INTGAR, REALAR, ID, IERR)
```

Where:

Integer CNVFLG	converter type (input; no default allowed). CNVFLG = 1 for rectifier data. CNVFLG = 2 for inverter data.
Character*12 NAME	name of the two-terminal dc line for which data for one of its converters is to be specified (input; no default allowed).
Integer INTGAR (6)	array of 6 elements specifying (input). INTGAR(1) IPR or IPI, converter bus number (no default allowed) INTGAR(2) NBR or NBI, number of bridges in series (0 by default) INTGAR(3) ICR or ICI, zero or bus number of firing angle bus (0 by default) INTGAR(4) NDR or NDI, zero or node number of firing angle bus node (0 by default) INTGAR(5) IFR or IFI, zero or bus number of winding one side of a two-winding ac transformer (0 by default) INTGAR(6) ITR or ITI, zero or bus number of winding two side of a two-winding ac transformer (0 by default)
Real REALAR (15)	(first eleven are input values; last four are output values) (input (output)).
Real REALARI (11)	array of elements specifying values REALAR(1) through REALAR(11) as described above(input). REALARI(1) NR or ANMNI, minimum firing angle (90.0 by default)

	REALARI(2)	XR or ANMXI, maximum firing angle (0.0 by default)
	REALARI(3)	RCR or RCI, commutating resistance (0.0 by default)
	REALARI(4)	XCR or XCI, commutating reactance (0.0 by default)
	REALARI(5)	EBASR or EBASI, primary base ac voltage (0.0 by default)
	REALARI(6)	TRR or TRI, transformer ratio (1.0 by default)
	REALARI(7)	TAPR or TAPI, tap setting (1.0 by default)
	REALARI(8)	TMXR or TMXI, maximum tap setting (1.5 by default)
	REALARI(9)	TMNR or TMNI, minimum tap setting (0.51 by default)
	REALARI(10)	STPR or STPI, tap step (0.00625 by default)
	REALARI(11)	XCAPR or XCAPI, capacitive reactance of CCC type converter (0.0 by default)
Real REALARO (4)	array of elements specifying values REALAR(12) through REALAR(15) as described above(output).	
	REALARO(1)	firing angle (returned)
	REALARO(2)	dc voltage (kV) (returned)
	REALARO(3)	real power into converter (PWRCOD) (returned)
	REALARO(4)	reactive power into converter (PWRCOD) (returned)
Character*2 ID	ac transformer circuit identifier, IDR or IDI (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	dc line not found
	IERR = 2	converter type is not 1 or 2
	IERR = 3	transformer circuit identifier is more than two characters
	IERR = 4	no converter bus is specified
	IERR = 5	converter bus not found
	IERR = 6	node-breaker terminal connection table is full
	IERR = 7	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Converter bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Converter maximum angle is less than its minimum angle. - Converter maximum tap is less than its minimum tap. - Invalid tap step. - Commutating bus not found. - ac transformer bus not

found. - Specified branch not found. - Specified branch is not a transformer. - From bus of specified branch is not winding one side bus

1.2.138. TWO_TERM_DC_CONVR_DATA

This API routine is obsolete. It has been replaced by the API routine [two_term_dc_converter_data_3](#).

Use this API to modify the data of a dc converter of an existing two-terminal dc line in the working case (see PSSE Program Operation Manual, Area Interchange Data). The dc line must have previously been specified via the TWO_TERMINAL_DC_LINE_DATA API.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_TWO_TERM_DC_CONVR_DATA CNVFLG DC INTGAR(1)..INTGAR(5)
REALAR(1)..REALAR(11) 'ID'
```

Python command syntax:

```
ierr, realaro = two_term_dc_convr_data(cnvflg, dc, intgar, realari, id)
```

Fortran command syntax:

```
CALL TWO_TERMINAL_DC_CONVERTER_API (CNVFLG, NUM, INTGAR, REALAR, ID, IERR)

CALL TWO_TERMINAL_DC_CONVERTER_API_I (CNVFLG, NUM, INTGAR, REALAR, ID,
IERR)

CALL TWO_TERMINAL_DC_CONVERTER_API_C (CNVFLG, NAME, INTGAR, REALAR, ID,
IERR)
```

Where:

Integer CNVFLG	converter type (input; no default allowed). CNVFLG = 1 for rectifier data. CNVFLG = 2 for inverter data.
Integer or Character*12 DC	quoted name of the two-terminal dc line for which data for one of its converters is to be specified; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which data for one of its converters is to be specified; no default allowed
Character*12 NAME	name of the two-terminal dc line for which data for one of its converters is to be specified; no default allowed
Integer INTGAR (5)	array of 5 elements specifying (input). INTGAR(1) IPR or IPI, converter bus number (no default allowed) INTGAR(2) NBR or NBI, number of bridges in series (0 by default) INTGAR(3) ICR or ICI, zero or bus number of firing angle bus (0 by default)

	INTGAR(4)	IFR or IFI, zero or bus number of winding one side of a two-winding ac transformer (0 by default)
	INTGAR(5)	ITR or ITI, zero or bus number of winding two side of a two-winding ac transformer (0 by default)
Real REALAR (15)	(first eleven are input values; last four are output values) (input (output)).	
Real REALARI (11)	array of elements specifying values REALAR(1) through REALAR(11) as described above(input).	
	REALARI(1)	NR or ANMNI, minimum firing angle (90.0 by default)
	REALARI(2)	XR or ANMXI, maximum firing angle (0.0 by default)
	REALARI(3)	RCR or RCI, commutating resistance (0.0 by default)
	REALARI(4)	XCR or XCI, commutating reactance (0.0 by default)
	REALARI(5)	EBASR or EBASI, primary base ac voltage (0.0 by default)
	REALARI(6)	TRR or TRI, transformer ratio (1.0 by default)
	REALARI(7)	TAPR or TAPI, tap setting (1.0 by default)
	REALARI(8)	TMXR or TMXI, maximum tap setting (1.5 by default)
	REALARI(9)	TMNR or TMNI, minimum tap setting (0.51 by default)
	REALARI(10)	STPR or STPI, tap step (0.00625 by default)
	REALARI(11)	XCAPR or XCAPI, capacitive reactance of CCC type converter (0.0 by default)
Real REALARO (4)	array of elements specifying values REALAR(12) through REALAR(15) as described above(output).	
	REALARO(1)	firing angle (returned)
	REALARO(2)	dc voltage (kV) (returned)
	REALARO(3)	real power into converter (PWRCOD) (returned)
	REALARO(4)	reactive power into converter (PWRCOD) (returned)
Character*2 ID	ac transformer circuit identifier, IDR or IDI (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	dc line not found
	IERR = 2	converter type is not 1 or 2
	IERR = 3	transformer circuit identifier is more than two characters

IERR = 4	no converter bus is specified
IERR = 5	converter bus not found
IERR = 6	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Converter bus is dummy bus of a multi-section line. - Multi-section line grouping deleted. - Converter maximum angle is less than its minimum angle. - Converter maximum tap is less than its minimum tap. - Invalid tap step. - Commutating bus not found. - ac transformer bus not found. - Specified branch not found. - Specified branch is not a transformer. - From bus of specified branch is not winding one side bus

1.2.139. TWO_WINDING_CHNG_4

This API routine is obsolete. It has been replaced by the API routine [two_winding_chng_5](#).

Use this API routine to modify the data of an existing two-winding transformer in the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_CHNG_4  IBUS  JBUS  'CKT'  INTGAR(1)..INTGAR(15)
                        REALAR(1)..REALAR(24)  'CHARAR(1)'  'CHARAR(2)'
```

Python command syntax:

```
ierr, realaro = two_winding_chng_4(ibus, jbus, ckt, intgar, realari,
                                   charar)
```

Fortran command syntax:

```
CALL TWO_WINDING_CHNG_4(IBUS, JBUS, CKT, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (15)	array of 15 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(12)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(13)	CW, winding data I/O code (1 by default)
INTGAR(14)	CZ, impedance data I/O code (1 by default)

	INTGAR(15)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (26)	(first twenty-four are input values; last two are output values) (input (output)).	
Real REALARI (24)	array of 24 elements specifying corresponding to values REALAR(1) through REALAR(24) as described above(input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSZ by default; 0.0001 if THRSZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	RATA1, rating set A line rating (0.0 by default)
	REALARI(10)	RATB1, rating set B line rating (0.0 by default)
	REALARI(11)	RATC1, rating set C line rating (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (1.0 by default)
	REALARI(14)	F3, third owner fraction (1.0 by default)
	REALARI(15)	F4, fourth owner fraction (1.0 by default)
	REALARI(16)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(17)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(18)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(19)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(20)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(21)	VMI1, voltage or flow lower limit (0.9 by default)

	REALARI(22)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(23)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(24)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode 5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Character*40 CHARAR (2)	array of 2 elements specifying (input).	
	CHARAR(1)	NAME, transformer name (blank by default)
	CHARAR(2)	VGRP, vector group name (blank by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
	IERR = 11	invalid CW, CZ and/or CM value
	IERR = 12	two-winding transformer not found
	IERR = 13	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage

age - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ. - Vector group not found

1.2.140. TWO_WINDING_CHNG_5

This API routine is obsolete. It has been replaced by the API routine [two_winding_chng_6](#).

Use this API routine to modify the data of an existing two-winding transformer in the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_CHNG_5  IBUS JBUS CKT INTGAR(1)..INTGAR(15)
                        REALAR(1)..REALAR(21) RATINGS(1)..RATINGS(12) NAMEAR VGRPAR
```

Python command syntax:

```
ierr, realaro = two_winding_chng_5(ibus, jbus, ckt, intgar, realari,
                                   ratings, namear, vgrpar)
```

Fortran command syntax:

```
CALL TWO_WINDING_CHNG_5(IBUS, JBUS, CKT, INTGAR, REALAR, RATINGS, NAMEAR,
                        VGRPAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (15)	array of 15 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(12)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(13)	CW, winding data I/O code (1 by default)

	INTGAR(14)	CZ, impedance data I/O code (1 by default)
	INTGAR(15)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (23)	(first twenty-four are input values; last two are output values) (input (output)).	
Real REALARI (21)	array of 21 elements specifying (input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	F1, first owner fraction (1.0 by default)
	REALARI(10)	F2, second owner fraction (1.0 by default)
	REALARI(11)	F3, third owner fraction (1.0 by default)
	REALARI(12)	F4, fourth owner fraction (1.0 by default)
	REALARI(13)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(14)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(15)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(16)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(17)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(18)	VMI1, voltage or flow lower limit (0.9 by default)
	REALARI(19)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(20)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(21)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode

	5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)	
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1, rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2, rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3, rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4, rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5, rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6, rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7, rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8, rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9, rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10, rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11, rating set 11 line rating (alias is RATE11) (0.0 by default)
	RATINGS(12)	RATE12, rating set 12 line rating (alias is RATE12) (0.0 by default)
Character*40 NAMEAR	transformer name (input; blank by default).	
Character*12 VGRPAR	vector group name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full

IERR = 8	branch ownership table is full
IERR = 9	two-winding transformer table is full
IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 11	invalid CW, CZ and/or CM value
IERR = 13	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ. - vector group not found

1.2.141. TWO_WINDING_CHNG_6

Use this API routine to modify the data of an existing two-winding transformer in the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_CHNG_6( IBUS JBUS CKT INTGAR(1)..INTGAR(16)
  REALAR(1)..REALAR(21) RATINGS(1)..RATINGS(12) NAMEAR VGRPAR
```

Python command syntax:

```
ierr, realaro = two_winding_chng_6(ibus, jbus, ckt, intgar, realari,
  ratings, namear, vgrpar)
```

Fortran command syntax:

```
CALL TWO_WINDING_CHNG_6(IBUS, JBUS, CKT, INTGAR, REALAR, RATINGS, NAMEAR,
  VGRPAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (16)	array of 16 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	NODE1, controlled node number (0 by default)
INTGAR(12)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(13)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(14)	CW, winding data I/O code (1 by default)

	INTGAR(15)	CZ, impedance data I/O code (1 by default)
	INTGAR(16)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (23)	(first twenty-one are input values; last two are output values) (input (output)).	
Real REALARI (21)	array of 21 elements specifying (input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSZ by default; 0.0001 if THRSZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	F1, first owner fraction (1.0 by default)
	REALARI(10)	F2, second owner fraction (1.0 by default)
	REALARI(11)	F3, third owner fraction (1.0 by default)
	REALARI(12)	F4, fourth owner fraction (1.0 by default)
	REALARI(13)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(14)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(15)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(16)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(17)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(18)	VMI1, voltage or flow lower limit (0.9 by default)
	REALARI(19)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(20)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(21)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode

	5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)	
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1, rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2, rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3, rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4, rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5, rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6, rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7, rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8, rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9, rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10, rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11, rating set 11 line rating (alias is RATE11) (0.0 by default)
	RATINGS(12)	RATE12, rating set 12 line rating (alias is RATE12) (0.0 by default)
Character*40 NAMEAR	transformer name (input; blank by default).	
Character*12 VGRPAR	vector group name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full

IERR = 8	branch ownership table is full
IERR = 9	two-winding transformer table is full
IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 11	invalid CW, CZ and/or CM value
IERR = 12	branch not found
IERR = 13	node-breaker terminal connection table is full
IERR = 14	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ. - vector group not found - Invalid node number - Non-zero con-

trolled node specified but controlled bus does not belong to a substation - Controlled node not found - Controlled node is not connected to any bus section of the regulated bus - Controlled bus is 0 but a non-zero controlled node is specified

1.2.142. TWO_WINDING_DATA

This API routine is obsolete. It has been replaced by the API routine [two_winding_data_3](#).

Use this API to modify the data of an existing two-winding transformer in the working case, or to add a new two-winding transformer to the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_DATA IBUS JBUS 'CKT' INTGAR(1)..INTGAR(15)
REALAR(1)..REALAR(23) 'NAME'
```

Python command syntax:

```
ierr, realaro = two_winding_data(ibus, jbus, ckt, intgar, realari, name)
```

Fortran command syntax:

```
CALL TWO_WINDING_API_2(IBUS, JBUS, CKT, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (15)	array of 15 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(12)	COD1, adjustment control mode flag (-4 through +4) (0 by default)
INTGAR(13)	CW, winding data I/O code (1 by default)
INTGAR(14)	CZ, impedance data I/O code (1 by default)

	INTGAR(15)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (25)	(first twenty-three are input values; last two are output values) (input (output)).	
Real REALARI (23)	array of 23 elements specifying corresponding to values REALAR(1) through REALAR(23) as described above(input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSZ by default; 0.0001 if THRSZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	RATA1, rating set A line rating (0.0 by default)
	REALARI(10)	RATB1, rating set B line rating (0.0 by default)
	REALARI(11)	RATC1, rating set C line rating (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (1.0 by default)
	REALARI(14)	F3, third owner fraction (1.0 by default)
	REALARI(15)	F4, fourth owner fraction (1.0 by default)
	REALARI(16)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(17)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(18)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(19)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(20)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(21)	VMI1, voltage or flow lower limit (0.9 by default)

	REALARI(22)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(23)	CX1, load drop compensating reactance (0.0 by default)
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(24) through REALAR(25) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Character*12 NAME	transformer name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full
	IERR = 8	branch ownership table is full
	IERR = 9	two-winding transformer table is full
	IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
	IERR = 11	invalid CW, CZ and/or CM value
	IERR = 13	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to

1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged)

1.2.143. TWO_WINDING_DATA_3

This API routine is obsolete. It has been replaced by the API routine [two_winding_data_4](#).

Use this API to modify the data of an existing two-winding transformer in the working case, or to add a new two-winding transformer to the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_DATA_3  IBUS  JBUS  'CKT'  INTGAR(1)..INTGAR(15)
                        REALAR(1)..REALAR(24)  'NAME'
```

Python command syntax:

```
ierr, realaro = two_winding_data_3(ibus, jbus, ckt, intgar, realari, name)
```

Fortran command syntax:

```
CALL TWO_WINDING_API_3(IBUS, JBUS, CKT, INTGAR, REALAR, NAME, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (15)	array of 15 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(12)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(13)	CW, winding data I/O code (1 by default)
INTGAR(14)	CZ, impedance data I/O code (1 by default)

	INTGAR(15)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (26)	(first twenty-four are input values; last two are output values) (input (output)).	
Real REALARI (24)	array of 24 elements specifying corresponding to values REALAR(1) through REALAR(24) as described above(input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	RATA1, rating set A line rating (0.0 by default)
	REALARI(10)	RATB1, rating set B line rating (0.0 by default)
	REALARI(11)	RATC1, rating set C line rating (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (1.0 by default)
	REALARI(14)	F3, third owner fraction (1.0 by default)
	REALARI(15)	F4, fourth owner fraction (1.0 by default)
	REALARI(16)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(17)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(18)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(19)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(20)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(21)	VMI1, voltage or flow lower limit (0.9 by default)

	REALARI(22)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(23)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(24)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode 5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Character*12 NAME	transformer name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full
	IERR = 8	branch ownership table is full
	IERR = 9	two-winding transformer table is full
	IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
	IERR = 11	invalid CW, CZ and/or CM value
	IERR = 13	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base

voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ

1.2.144. TWO_WINDING_DATA_4

This API routine is obsolete. It has been replaced by the API routine [two_winding_data_5](#).

Use this API to modify the data of an existing two-winding transformer in the working case, or to add a new two-winding transformer to the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_DATA_4 IBUS JBUS 'CKT' INTGAR(1)..INTGAR(15)
REALAR(1)..REALAR(24) 'CHARAR(1)' 'CHARAR(2)'
```

Python command syntax:

```
ierr, realaro = two_winding_data_4(ibus, jbus, ckt, intgar, realari,
charar)
```

Fortran command syntax:

```
CALL TWO_WINDING_API_4(IBUS, JBUS, CKT, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (15)	array of 15 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(12)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(13)	CW, winding data I/O code (1 by default)
INTGAR(14)	CZ, impedance data I/O code (1 by default)

	INTGAR(15)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (26)	(first twenty-four are input values; last two are output values) (input (output).).	
Real REALARI (24)	array of 24 elements specifying corresponding to values REALAR(1) through REALAR(24) as described above(input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	RATA1, rating set A line rating (0.0 by default)
	REALARI(10)	RATB1, rating set B line rating (0.0 by default)
	REALARI(11)	RATC1, rating set C line rating (0.0 by default)
	REALARI(12)	F1, first owner fraction (1.0 by default)
	REALARI(13)	F2, second owner fraction (1.0 by default)
	REALARI(14)	F3, third owner fraction (1.0 by default)
	REALARI(15)	F4, fourth owner fraction (1.0 by default)
	REALARI(16)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(17)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(18)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(19)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(20)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(21)	VMI1, voltage or flow lower limit (0.9 by default)

	REALARI(22)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(23)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(24)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode 5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Character*40 CHARAR (2)	array of 2 elements specifying (input).	
	CHARAR(1)	NAME, transformer name (blank by default)
	CHARAR(2)	VGRP, vector group name (blank by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full
	IERR = 8	branch ownership table is full
	IERR = 9	two-winding transformer table is full
	IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
	IERR = 11	invalid CW, CZ and/or CM value
	IERR = 13	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nom-

inal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ. - vector group not found

1.2.145. TWO_WINDING_DATA_5

This API routine is obsolete. It has been replaced by the API routine [two_winding_data_6](#).

Use this API to modify the data of an existing two-winding transformer in the working case, or to add a new two-winding transformer to the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_TWO_WINDING_DATA_5  IBUS JBUS CKT INTGAR(1)..INTGAR(15)
                        REALAR(1)..REALAR(21) RATINGS(1)..RATINGS(12) NAMEAR VGRPAR
```

Python command syntax:

```
ierr, realaro = two_winding_data_5(ibus, jbus, ckt, intgar, realari,
                                   ratings, namear, vgrpar)
```

Fortran command syntax:

```
CALL TWO_WINDING_DATA_5(IBUS, JBUS, CKT, INTGAR, REALAR, RATINGS, NAMEAR,
                        VGRPAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (15)	array of 15 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(12)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(13)	CW, winding data I/O code (1 by default)

	INTGAR(14)	CZ, impedance data I/O code (1 by default)
	INTGAR(15)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (23)	(first twenty-one are input values; last two are output values) (input (output)).	
Real REALARI (21)	array of 21 elements specifying (input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSHZ by default; 0.0001 if THRSHZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	F1, first owner fraction (1.0 by default)
	REALARI(10)	F2, second owner fraction (1.0 by default)
	REALARI(11)	F3, third owner fraction (1.0 by default)
	REALARI(12)	F4, fourth owner fraction (1.0 by default)
	REALARI(13)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(14)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(15)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(16)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(17)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(18)	VMI1, voltage or flow lower limit (0.9 by default)
	REALARI(19)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(20)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(21)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode

	5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)	
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1, rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2, rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3, rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4, rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5, rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6, rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7, rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8, rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9, rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10, rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11, rating set 11 line rating (alias is RATE11) (0.0 by default)
	RATINGS(12)	RATE12, rating set 12 line rating (alias is RATE12) (0.0 by default)
Character*40 NAMEAR	transformer name (input; blank by default).	
Character*12 VGRPAR	vector group name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full

IERR = 8	branch ownership table is full
IERR = 9	two-winding transformer table is full
IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 11	invalid CW, CZ and/or CM value
IERR = 13	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ. - vector group not found

1.2.146. TWO_WINDING_DATA_6

Use this API to modify the data of an existing two-winding transformer in the working case, or to add a new two-winding transformer to the working case (see PSSE Program Operation Manual, Owner Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_TWO_WINDING_DATA_6 IBUS JBUS CKT INTGAR(1)..INTGAR(16)
REALAR(1)..REALAR(21) RATINGS(1)..RATINGS(12) NAMEAR VGRPAR
```

Python command syntax:

```
ierr, realaro = two_winding_data_6(ibus, jbus, ckt, intgar, realari,
ratings, namear, vgrpar)
```

Fortran command syntax:

```
CALL TWO_WINDING_DATA_6(IBUS, JBUS, CKT, INTGAR, REALAR, RATINGS, NAMEAR,
VGRPAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (16)	array of 16 elements specifying (input).
INTGAR(1)	STAT, branch status (1 by default)
INTGAR(2)	METBUS, metered end bus number (IBUS or JBUS) (IBUS by default)
INTGAR(3)	O1, first owner number (owner of bus IBUS by default)
INTGAR(4)	O2, second owner number (0 by default)
INTGAR(5)	O3, third owner number (0 by default)
INTGAR(6)	O4, fourth owner number (0 by default)
INTGAR(7)	NTP1, number of tap positions (33 by default)
INTGAR(8)	TAB1, impedance correction table number (0 by default)
INTGAR(9)	WN1BUS, winding one side bus number (IBUS or JBUS) (IBUS by default)
INTGAR(10)	CONT1, controlled bus number (0 by default)
INTGAR(11)	NODE1, controlled node number (0 by default)
INTGAR(12)	SICOD1, negative for controlled bus on winding one side (1 by default)
INTGAR(13)	COD1, adjustment control mode flag (-5 through +5) (0 by default)
INTGAR(14)	CW, winding data I/O code (1 by default)

	INTGAR(15)	CZ, impedance data I/O code (1 by default)
	INTGAR(16)	CM, magnetizing admittance data I/O code (1 by default)
Real REALAR (23)	(first twenty-one are input values; last two are output values) (input (output)).	
Real REALARI (21)	array of 21 elements specifying (input).	
	REALARI(1)	R1-2, nominal transformer resistance (0.0 by default)
	REALARI(2)	X1-2, nominal transformer reactance (THRSZ by default; 0.0001 if THRSZ = 0.0)
	REALARI(3)	SBS1-2, winding base MVA (SBASE by default)
	REALARI(4)	WINDV1, winding one ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus IBUS by default if CW is 2)
	REALARI(5)	NOMV1, winding one nominal voltage (0.0 by default)
	REALARI(6)	1, winding one phase shift angle (0.0 by default)
	REALARI(7)	WINDV2, winding two ratio/voltage (1.0 by default if CW is 1 or 3; base voltage of bus JBUS by default if CW is 2)
	REALARI(8)	NOMV2, winding two nominal voltage (0.0 by default)
	REALARI(9)	F1, first owner fraction (1.0 by default)
	REALARI(10)	F2, second owner fraction (1.0 by default)
	REALARI(11)	F3, third owner fraction (1.0 by default)
	REALARI(12)	F4, fourth owner fraction (1.0 by default)
	REALARI(13)	MAG1, magnetizing conductance or no-load losses (0.0 by default)
	REALARI(14)	MAG2, magnetizing susceptance or exciting current (0.0 by default)
	REALARI(15)	RMA1, winding one ratio/angle high limit (1.1 by default)
	REALARI(16)	RMI1, winding one ratio/angle low limit (0.9 by default)
	REALARI(17)	VMA1, voltage or flow upper limit (1.1 by default)
	REALARI(18)	VMI1, voltage or flow lower limit (0.9 by default)
	REALARI(19)	CR1, load drop compensating resistance (0.0 by default)
	REALARI(20)	CX1, load drop compensating reactance (0.0 by default)
	REALARI(21)	CNXA1, winding connection angle (0.0 by default). Used with adjustment control mode

	5 (unsymmatric phase shift control of active power) implemented in PSSE version 32.1)	
Real REALARO (2)	array of 2 elements specifying corresponding to values REALAR(25) through REALAR(26) as described above(output).	
	REALARO(1)	actual transformer resistance (returned)
	REALARO(2)	actual transformer reactance (returned)
Real RATINGS (12)	array of 12 elements specifying (input).	
	RATINGS(1)	RATE1, rating set 1 line rating (alias is RATE1) (0.0 by default)
	RATINGS(2)	RATE2, rating set 2 line rating (alias is RATE2) (0.0 by default)
	RATINGS(3)	RATE3, rating set 3 line rating (alias is RATE3) (0.0 by default)
	RATINGS(4)	RATE4, rating set 4 line rating (alias is RATE4) (0.0 by default)
	RATINGS(5)	RATE5, rating set 5 line rating (alias is RATE5) (0.0 by default)
	RATINGS(6)	RATE6, rating set 6 line rating (alias is RATE6) (0.0 by default)
	RATINGS(7)	RATE7, rating set 7 line rating (alias is RATE7) (0.0 by default)
	RATINGS(8)	RATE8, rating set 8 line rating (alias is RATE8) (0.0 by default)
	RATINGS(9)	RATE9, rating set 9 line rating (alias is RATE9) (0.0 by default)
	RATINGS(10)	RATE10, rating set 10 line rating (alias is RATE10) (0.0 by default)
	RATINGS(11)	RATE11, rating set 11 line rating (alias is RATE11) (0.0 by default)
	RATINGS(12)	RATE12, rating set 12 line rating (alias is RATE12) (0.0 by default)
Character*40 NAMEAR	transformer name (input; blank by default).	
Character*12 VGRPAR	vector group name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	branch exists but it is a non-transformer branch
	IERR = 4	branch from a bus to itself
	IERR = 5	blank circuit identifier is invalid
	IERR = 6	circuit identifier may not start with &, * or @
	IERR = 7	branch table is full

IERR = 8	branch ownership table is full
IERR = 9	two-winding transformer table is full
IERR = 10	CW, CZ and/or CM >1 but at least one end-point bus has no base voltage
IERR = 11	invalid CW, CZ and/or CM value
IERR = 13	node-breaker terminal connection table is full
IERR = 14	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid metered end bus - invalid transformer status - invalid owner number - invalid ownership fraction - no ownership data specified. - multi-section line grouping deleted - branch ownership table is full--only first n owners retained - owner table is full - rating is negative - invalid winding 1 side bus number - invalid CW, CZ and/or CM data value - controlled bus not found - invalid adjustment control mode flag - invalid impedance correction table number - invalid number of tap positions - winding nominal voltage is negative - winding bus base voltage and nominal voltage differ by more than 20% - invalid winding voltage - winding voltage and bus base voltage differ by more than 50% - RMAX is greater than 150% of bus base voltage - RMIN is less than 50% of bus base voltage - invalid tap ratio - tap ratio is outside the band 0.5 to 1.5 pu - RMAX is greater than 1.5 - RMIN is less than 0.5 - RMAX is less than RMIN - VMAX is less than VMIN - phase shift angle normalized between -180 and 180 - winding base MVA must be positive - MAG1 is too big relative to MAG2 at winding base MVA - magnetizing susceptance MAG2 is positive - losses are too big relative to total impedance at winding base MVA - branch reactance is 0.0 - winding 1 and winding 2 sides are interchanged (any two-terminal dc lines controlled by this transformer are logged). - winding connection angle normalized between -360 and 360 - adjustment control mode flag and the winding connection angle are inconsistent. - for asymmetric phase shifter, abnormally large or small tap setting results at RMA1 (or RMI1) and CNXA1. - for asymmetric phase shifter, the specified and derived winding tap settings differ. - vector group not found - Invalid node number - Non-zero controlled node specified but controlled bus does not belong to a substation - Con-

trolled node not found - Controlled node is not connected to any bus section of the regulated bus - Controlled bus is 0 but a non-zero controlled node is specified

1.2.147. VOLTAGE_DROOP_CHNG

Use this API routine to modify the voltage droop control in the working case(see PSSE Program Operation Manual).

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_VOLTAGE_DROOP_CHNG NAME INTGAR(1) INTGAR(2) REALAR(1)..REALAR(7)
```

Python command syntax:

```
ierr = voltage_droop_chng(name, intgar, realari)
```

Fortran command syntax:

```
CALL VOLTAGE_DROOP_CHNG(NAME, INTGAR, REALAR, IERR)
```

Where:

Character*40 NAME	name of the voltage droop control for which data is to be specified (input; no default allowed).														
Integer INTGAR (2)	array of 2 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>STATUS, voltage droop control status (0, 1) (0 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>REGBUS, regulated bus of voltage droop control (20 by default)</td></tr> </table>	INTGAR(1)	STATUS, voltage droop control status (0, 1) (0 by default)	INTGAR(2)	REGBUS, regulated bus of voltage droop control (20 by default)										
INTGAR(1)	STATUS, voltage droop control status (0, 1) (0 by default)														
INTGAR(2)	REGBUS, regulated bus of voltage droop control (20 by default)														
Real REALAR (7)	seven input values (input).														
Real REALARI (7)	array of 7 elements specifying values REALAR(1) through REALAR(7) as described above(input). <table> <tr> <td>REALARI(1)</td><td>QMAX, upper Q limit of voltage droop control (1.0 by default)</td></tr> <tr> <td>REALARI(2)</td><td>QDB, Q output when voltage is within deadband (0.0 by default)</td></tr> <tr> <td>REALARI(3)</td><td>QMIN, lower Q limit of voltage droop control (-1.0 by default)</td></tr> <tr> <td>REALARI(4)</td><td>VLOW, lower voltage limit of voltage droop control (0.9 by default)</td></tr> <tr> <td>REALARI(5)</td><td>VDVLW, lower voltage deadband limit of voltage droop control (0.98 by default)</td></tr> <tr> <td>REALARI(6)</td><td>VDBVHI, higher voltage deadband limit of voltage droop control (1.02 by default)</td></tr> <tr> <td>REALARI(7)</td><td>VHIGH, higher voltage limit of voltage droop control (1.1 by default)</td></tr> </table>	REALARI(1)	QMAX, upper Q limit of voltage droop control (1.0 by default)	REALARI(2)	QDB, Q output when voltage is within deadband (0.0 by default)	REALARI(3)	QMIN, lower Q limit of voltage droop control (-1.0 by default)	REALARI(4)	VLOW, lower voltage limit of voltage droop control (0.9 by default)	REALARI(5)	VDVLW, lower voltage deadband limit of voltage droop control (0.98 by default)	REALARI(6)	VDBVHI, higher voltage deadband limit of voltage droop control (1.02 by default)	REALARI(7)	VHIGH, higher voltage limit of voltage droop control (1.1 by default)
REALARI(1)	QMAX, upper Q limit of voltage droop control (1.0 by default)														
REALARI(2)	QDB, Q output when voltage is within deadband (0.0 by default)														
REALARI(3)	QMIN, lower Q limit of voltage droop control (-1.0 by default)														
REALARI(4)	VLOW, lower voltage limit of voltage droop control (0.9 by default)														
REALARI(5)	VDVLW, lower voltage deadband limit of voltage droop control (0.98 by default)														
REALARI(6)	VDBVHI, higher voltage deadband limit of voltage droop control (1.02 by default)														
REALARI(7)	VHIGH, higher voltage limit of voltage droop control (1.1 by default)														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>voltage droop control table is full</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	voltage droop control table is full								
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	voltage droop control table is full														

IERR = 2	blank voltage droop control name is invalid
IERR = 3	voltage droop control characteristic curve is invalid
IERR = 4	Voltage Droop control not found
IERR = 5	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid voltage droop control status - qmax is less than qmin - vhigh is less than vlow - vdbhigh is less than vdblow - vdblow is less than vlow

1.2.148. VOLTAGE_DROOP_DATA

Use this API routine to modify the voltage droop control in the working case, or to add a new voltage droop control to the working case (see PSSE Program Operation Manual).

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_VOLTAGE_DROOP_DATA NAME INTGAR(1) INTGAR(2) REALAR(1)..REALAR(7)
```

Python command syntax:

```
ierr = voltage_droop_data(name, intgar, realari)
```

Fortran command syntax:

```
CALL VOLTAGE_DROOP_DATA(NAME, INTGAR, REALAR, IERR)
```

Where:

Character*40 NAME	name of the voltage droop control for which data is to be specified (input; no default allowed).														
Integer INTGAR (2)	array of 2 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>STATUS, voltage droop control status (0, 1) (0 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>REGBUS, regulated bus of voltage droop control (0 by default)</td></tr> </table>	INTGAR(1)	STATUS, voltage droop control status (0, 1) (0 by default)	INTGAR(2)	REGBUS, regulated bus of voltage droop control (0 by default)										
INTGAR(1)	STATUS, voltage droop control status (0, 1) (0 by default)														
INTGAR(2)	REGBUS, regulated bus of voltage droop control (0 by default)														
Real REALAR (7)	seven input values (input).														
Real REALARI (7)	array of 7 elements specifying values REALAR(1) through REALAR(7) as described above(input). <table> <tr> <td>REALARI(1)</td><td>QMAX, upper Q limit of voltage droop control (1.0 by default)</td></tr> <tr> <td>REALARI(2)</td><td>QDB, Q output when voltage is within deadband (0.0 by default)</td></tr> <tr> <td>REALARI(3)</td><td>QMIN, lower Q limit of voltage droop control (-1.0 by default)</td></tr> <tr> <td>REALARI(4)</td><td>VLOW, lower voltage limit of voltage droop control (0.9 by default)</td></tr> <tr> <td>REALARI(5)</td><td>VDVLW, lower voltage deadband limit of voltage droop control (0.98 by default)</td></tr> <tr> <td>REALARI(6)</td><td>VDBVHI, higher voltage deadband limit of voltage droop control (1.02 by default)</td></tr> <tr> <td>REALARI(7)</td><td>VHIGH, higher voltage limit of voltage droop control (1.1 by default)</td></tr> </table>	REALARI(1)	QMAX, upper Q limit of voltage droop control (1.0 by default)	REALARI(2)	QDB, Q output when voltage is within deadband (0.0 by default)	REALARI(3)	QMIN, lower Q limit of voltage droop control (-1.0 by default)	REALARI(4)	VLOW, lower voltage limit of voltage droop control (0.9 by default)	REALARI(5)	VDVLW, lower voltage deadband limit of voltage droop control (0.98 by default)	REALARI(6)	VDBVHI, higher voltage deadband limit of voltage droop control (1.02 by default)	REALARI(7)	VHIGH, higher voltage limit of voltage droop control (1.1 by default)
REALARI(1)	QMAX, upper Q limit of voltage droop control (1.0 by default)														
REALARI(2)	QDB, Q output when voltage is within deadband (0.0 by default)														
REALARI(3)	QMIN, lower Q limit of voltage droop control (-1.0 by default)														
REALARI(4)	VLOW, lower voltage limit of voltage droop control (0.9 by default)														
REALARI(5)	VDVLW, lower voltage deadband limit of voltage droop control (0.98 by default)														
REALARI(6)	VDBVHI, higher voltage deadband limit of voltage droop control (1.02 by default)														
REALARI(7)	VHIGH, higher voltage limit of voltage droop control (1.1 by default)														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>voltage droop control table is full</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	voltage droop control table is full								
IERR = 0	no errors occurred														
IERR > 0	fatal error occurred														
IERR = 1	voltage droop control table is full														

IERR = 2	blank voltage droop control name is invalid
IERR = 3	voltage droop control characteristic curve is invalid
IERR = 5	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid voltage droop control status - qmax is less than qmin - vhigh is less than vlow - vdbhigh is less than vdblow - vdblow is less than vlow

1.2.149. VSC_DC_CONVERTER_DATA

This API routine is obsolete. It has been replaced by the API routine [vsc_dc_converter_data_3](#).

Use this API to modify the data of a dc converter of an existing VSC dc line in the working case (see PSSE Program Operation Manual, Voltage Source Converter (VSC) DC Transmission Line Data).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_VSC_DC_CONVERTER_DATA 'NAME' IC INTGAR(1) .. INTGAR(4)
REALAR(1) .. REALAR(11)
```

Python command syntax:

```
ierr = vsc_dc_converter_data(name, ic, intgar, realar)
```

Fortran command syntax:

```
CALL VSC_DC_LINE_CONVERTER_API_2(NAME, IC, INTGAR, REALAR, IERR)
```

Where:

Character*12 NAME	VSC dc line name (input; no default allowed).
Integer IC	dc converter index (1 or 2) (input; no default allowed).
Integer INTGAR (4)	array of 4 elements specifying (input).
	INTGAR(1) IBUS, converter bus number (no default allowed)
	INTGAR(2) TYPE, dc control code (1 by default)
	INTGAR(2) = 0 out-of-service
	INTGAR(2) = 1 kV
	INTGAR(2) = 2 MW
	INTGAR(3) MODE, ac control code (1 = voltage, 2 = power factor) (1 by default)
	INTGAR(4) REMOT, remote bus number (0 for this converter to regulate voltage at bus IBUS) (0 by default)
Real REALAR (11)	array of 11 elements specifying (input).
	REALAR(1) DCSET, dc setpoint (kV or MW) (1.0 by default)
	REALAR(2) ACSET, ac setpoint (pu voltage or power factor) (1.0 by default)
	REALAR(3) ALOSS, A loss coefficient (kW) (0.0 by default)
	REALAR(4) BLOSS, B loss coefficient (kW/amps) (0.0 by default)
	REALAR(5) MINLOS, minimum converter losses (kW) (0.0 by default)

	REALAR(6)	SMAX, converter ac MVA rating (0.0 by default)
	REALAR(7)	IMAX, converter ac current rating (amps) (0.0 by default)
	REALAR(8)	PWF, power weighting factor fraction (1.0 by default)
	REALAR(9)	MAXQ, reactive power upper limit (Mvar) (9999.0 by default)
	REALAR(10)	MINQ, reactive power lower limit (Mvar) (-9999.0 by default)
	REALAR(11)	RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid converter index
	IERR = 2	no converter bus is specified
	IERR = 3	dc line not found
	IERR = 4	converter bus not found
	IERR = 5	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Converter bus is dummy bus of a multi-section line - Multi-section line grouping deleted. - Invalid dc control code - Invalid ac control mode - Regulated bus not found - Converter specified as remotely regulating itself. - Type code of regulated bus is not 1 or 2. - dc voltage setpoint is not positive - ac voltage setpoint is outside the band 0.75 to 1.25 pu - ac power factor setpoint is in error (magnitude exceeds 1.0) - Invalid power weighting factor fraction - MAXQ is less than MINQ. - RMPCT is not positive

1.2.150. VSC_DC_CONVERTER_DATA_3

Use this API to modify the data of a dc converter of an existing VSC dc line in the working case (see PSSE Program Operation Manual, Voltage Source Converter (VSC) DC Transmission Line Data).

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_VSC_DC_CONVERTER_DATA_3 'NAME' IC INTGAR(1)..INTGAR(5)
REALAR(1)..REALAR(11)
```

Python command syntax:

```
ierr = vsc_dc_converter_data_3(name, ic, intgar, realar)
```

Fortran command syntax:

```
CALL VSC_DC_LINE_CONVERTER_API_3(NAME, IC, INTGAR, REALAR, IERR)
```

Where:

Character*12 NAME	VSC dc line name (input; no default allowed).
Integer IC	dc converter index (1 or 2) (input; no default allowed).
Integer INTGAR (5)	array of 5 elements specifying (input).
	INTGAR(1) IBUS, converter bus number (no default allowed)
	INTGAR(2) TYPE, dc control code (1 by default)
	INTGAR(2) = 0 out-of-service
	INTGAR(2) = 1 kV
	INTGAR(2) = 2 MW
	INTGAR(3) MODE, ac control code (1 = voltage, 2 = power factor) (1 by default)
	INTGAR(4) VSREG, regulated bus number (0 by default)
	INTGAR(5) NODE, regulated node number (0 by default)
Real REALAR (11)	array of 11 elements specifying (input).
	REALAR(1) DCSET, dc setpoint (kV or MW) (1.0 by default)
	REALAR(2) ACSET, ac setpoint (pu voltage or power factor) (1.0 by default)
	REALAR(3) ALOSS, A loss coefficient (kW) (0.0 by default)
	REALAR(4) BLOSS, B loss coefficient (kW/amps) (0.0 by default)
	REALAR(5) MINLOS, minimum converter losses (kW) (0.0 by default)
	REALAR(6) SMAX, converter ac MVA rating (0.0 by default)

	REALAR(7)	IMAX, converter ac current rating (amps) (0.0 by default)
	REALAR(8)	PWF, power weighting factor fraction (1.0 by default)
	REALAR(9)	MAXQ, reactive power upper limit (Mvar) (9999.0 by default)
	REALAR(10)	MINQ, reactive power lower limit (Mvar) (-9999.0 by default)
	REALAR(11)	RMPCT, percent of contributed reactive power (100.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid converter index
	IERR = 2	no converter bus is specified
	IERR = 3	dc line not found
	IERR = 4	converter bus not found
	IERR = 5	prerequisite requirements for API are not met
	IERR = 6	node-breaker terminal connection table is full
	IERR = -1	data error, warning and information messages; one or more of: - Converter bus is dummy bus of a multi-section line - Multi-section line grouping deleted. - Invalid dc control code - Invalid ac control mode - Regulated bus not found - A remote regulated bus is specified for a type 3 bus - Type code of regulated bus is not 1 or 2 - dc voltage setpoint is not positive - ac voltage setpoint is outside the band 0.75 to 1.25 pu - ac power factor setpoint is in error (magnitude exceeds 1.0) - Invalid power weighting factor fraction - MAXQ is less than MINQ. - RMPCT is not positive - Invalid node number - Non-zero regulated node specified but regulated bus does not belong to a substation - Regulated node not found - Regulated node is not connected to any bus section of the regulated bus

1.2.151. VSC_DC_LINE_CHNG

Use this API routine to modify the link data of an existing VSC dc line in the working case (see PSSE Program Operation Manual, Voltage Source Converter (VSC) DC Transmission Line Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_VSC_DC_LINE_CHNG  'NAME'  INTGAR(1)..INTGAR(5)  REALAR(1)..REALAR(5)
```

Python command syntax:

```
ierr = vsc_dc_line_chng(name, intgar, realar)
```

Fortran command syntax:

```
CALL VSC_DC_LINE_CHNG(NAME, INTGAR, REALAR, IERR)
```

Where:

Character*12 NAME	VSC dc line name (input; no default allowed).												
Integer INTGAR (5)	array of 5 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>MDC, control mode (0 or 1) (0 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>O1, first owner number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>O2, second owner number (0 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>O3, third owner number (0 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>O4, fourth owner number (0 by default)</td></tr> </table>	INTGAR(1)	MDC, control mode (0 or 1) (0 by default)	INTGAR(2)	O1, first owner number (1 by default)	INTGAR(3)	O2, second owner number (0 by default)	INTGAR(4)	O3, third owner number (0 by default)	INTGAR(5)	O4, fourth owner number (0 by default)		
INTGAR(1)	MDC, control mode (0 or 1) (0 by default)												
INTGAR(2)	O1, first owner number (1 by default)												
INTGAR(3)	O2, second owner number (0 by default)												
INTGAR(4)	O3, third owner number (0 by default)												
INTGAR(5)	O4, fourth owner number (0 by default)												
Real REALAR (5)	array of 5 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>RDC, dc line resistance (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>F1, first owner fraction (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>F2, second owner fraction (1.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>F3, third owner fraction (1.0 by default)</td></tr> <tr> <td>REALAR(5)</td><td>F4, fourth owner fraction (1.0 by default)</td></tr> </table>	REALAR(1)	RDC, dc line resistance (0.0 by default)	REALAR(2)	F1, first owner fraction (1.0 by default)	REALAR(3)	F2, second owner fraction (1.0 by default)	REALAR(4)	F3, third owner fraction (1.0 by default)	REALAR(5)	F4, fourth owner fraction (1.0 by default)		
REALAR(1)	RDC, dc line resistance (0.0 by default)												
REALAR(2)	F1, first owner fraction (1.0 by default)												
REALAR(3)	F2, second owner fraction (1.0 by default)												
REALAR(4)	F3, third owner fraction (1.0 by default)												
REALAR(5)	F4, fourth owner fraction (1.0 by default)												
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 2</td><td>blank dc line name is invalid</td></tr> <tr> <td>IERR = 3</td><td>dc line not found</td></tr> <tr> <td>IERR = 4</td><td>prerequisite requirements for API are not met</td></tr> <tr> <td>IERR = -1</td><td>data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid owner number - invalid ownership fraction - no ownership data specified - owner table is full</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 2	blank dc line name is invalid	IERR = 3	dc line not found	IERR = 4	prerequisite requirements for API are not met	IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid owner number - invalid ownership fraction - no ownership data specified - owner table is full
IERR = 0	no errors occurred												
IERR > 0	fatal error occurred												
IERR = 2	blank dc line name is invalid												
IERR = 3	dc line not found												
IERR = 4	prerequisite requirements for API are not met												
IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid owner number - invalid ownership fraction - no ownership data specified - owner table is full												

1.2.152. VSC_DC_LINE_DATA

Use this API routine to modify the link data of an existing VSC dc line in the working case, or to add a new VSC dc line to the working case (see PSSE Program Operation Manual, Voltage Source Converter (VSC) DC Transmission Line Data).

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_VSC_DC_LINE_DATA  'NAME'  INTGAR(1)..INTGAR(5)  REALAR(1)..REALAR(5)
```

Python command syntax:

```
ierr = vsc_dc_line_data(name, intgar, realar)
```

Fortran command syntax:

```
CALL VSC_DC_LINE_API_2(NAME, INTGAR, REALAR, IERR)
```

Where:

Character*12 NAME	VSC dc line name (input; no default allowed).												
Integer INTGAR (5)	array of 5 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>MDC, control mode (0 or 1) (0 by default)</td></tr> <tr> <td>INTGAR(2)</td><td>O1, first owner number (1 by default)</td></tr> <tr> <td>INTGAR(3)</td><td>O2, second owner number (0 by default)</td></tr> <tr> <td>INTGAR(4)</td><td>O3, third owner number (0 by default)</td></tr> <tr> <td>INTGAR(5)</td><td>O4, fourth owner number (0 by default)</td></tr> </table>	INTGAR(1)	MDC, control mode (0 or 1) (0 by default)	INTGAR(2)	O1, first owner number (1 by default)	INTGAR(3)	O2, second owner number (0 by default)	INTGAR(4)	O3, third owner number (0 by default)	INTGAR(5)	O4, fourth owner number (0 by default)		
INTGAR(1)	MDC, control mode (0 or 1) (0 by default)												
INTGAR(2)	O1, first owner number (1 by default)												
INTGAR(3)	O2, second owner number (0 by default)												
INTGAR(4)	O3, third owner number (0 by default)												
INTGAR(5)	O4, fourth owner number (0 by default)												
Real REALAR (5)	array of 5 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>RDC, dc line resistance (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>F1, first owner fraction (1.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>F2, second owner fraction (1.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>F3, third owner fraction (1.0 by default)</td></tr> <tr> <td>REALAR(5)</td><td>F4, fourth owner fraction (1.0 by default)</td></tr> </table>	REALAR(1)	RDC, dc line resistance (0.0 by default)	REALAR(2)	F1, first owner fraction (1.0 by default)	REALAR(3)	F2, second owner fraction (1.0 by default)	REALAR(4)	F3, third owner fraction (1.0 by default)	REALAR(5)	F4, fourth owner fraction (1.0 by default)		
REALAR(1)	RDC, dc line resistance (0.0 by default)												
REALAR(2)	F1, first owner fraction (1.0 by default)												
REALAR(3)	F2, second owner fraction (1.0 by default)												
REALAR(4)	F3, third owner fraction (1.0 by default)												
REALAR(5)	F4, fourth owner fraction (1.0 by default)												
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> <tr> <td>IERR = 1</td><td>VSC dc line table is full</td></tr> <tr> <td>IERR = 2</td><td>blank dc line name is invalid</td></tr> <tr> <td>IERR = 4</td><td>prerequisite requirements for API are not met</td></tr> <tr> <td>IERR = -1</td><td>data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid owner number - invalid ownership fraction - no ownership data specified - owner table is full</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred	IERR = 1	VSC dc line table is full	IERR = 2	blank dc line name is invalid	IERR = 4	prerequisite requirements for API are not met	IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid owner number - invalid ownership fraction - no ownership data specified - owner table is full
IERR = 0	no errors occurred												
IERR > 0	fatal error occurred												
IERR = 1	VSC dc line table is full												
IERR = 2	blank dc line name is invalid												
IERR = 4	prerequisite requirements for API are not met												
IERR = -1	data error, warning and information messages; one or more of: - invalid dc line control mode - invalid dc line resistance - invalid owner number - invalid ownership fraction - no ownership data specified - owner table is full												

1.2.153. ZONE_DATA

Use this API to modify zone data in the working case (see PSSE Program Operation Manual, Zone Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ZONE_DATA IZONE 'ZONAME'
```

Python command syntax:

```
ierr = zone_data(izone, zname)
```

Fortran command syntax:

```
CALL ZONE_API_2(IZONE, ZONAME, IERR)
```

Where:

Integer IZONE	zone number between 1 and 9999 (input; no default allowed).
Character*12 ZONAME	zone name (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 invalid zone number
	IERR = 2 zone table is full
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information mes-
	sages; one or more of: - No equipment is as-
	signed to zone

Chapter 2

Node Breaker

This chapter describes the API routines used in PSS®E Node Breaker operations and data changing functions for substation data.

2.1. Node Breaker Operation

2.1.1. CONVERT_SECTION_TO_BUS

Use this API routine to convert a bus section, one that had been automatically created within a substation due to open substation switching devices, into a main network bus. After the conversion, the new network bus will reside in the same substation and all prior network connections will remain.

Only bus sections that are not the main parent bus can be converted.

If a plant exists at the parent bus of the bus section to be converted and if all machines are connected to the bus section, then the plant will be removed from the parent bus once the conversion of the bus section to a main network bus is made. The newly converted network bus will remain as a plant.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_CONVERT_SECTION_TO_BUS IBUS INODE IARG 'NAME'
```

Python command syntax:

```
ierr = convert_section_to_bus(ibus, inode, iarg, name)
```

Fortran command syntax:

```
CALL CONVERT_SECTION_TO_BUS(IBUS, INODE, IARG, NAME, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Integer INODE	node number (input; no default allowed).
Integer IARG	bus number of the new network bus that is being converted from a bus section (input; no default allowed).
Character*12 NAME	new bus name (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 invalid bus number
	IERR = 4 bus not found
	IERR = 5 invalid node number
	IERR = 6 bus does not belong to a substation
	IERR = 7 node is not found in the substation
	IERR = 8 node is not connected to any bus section of the specified bus
	IERR = 9 selected bus section is the parent bus and therefore is already a network bus
	IERR = -1 data error, warning and information messages; one or more of: - Bus name is more than 12 characters.

2.1.2. ISOLATE2DCLINEBYBREAKER

Use this API to isolate a two-terminal DC line using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATE2DCLINEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the two-terminal dc line. If inadequate system or substation breakers are found, such that the line is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the line.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_ISOLATE2DCLINEBYBREAKER NAMEARG
```

Python command syntax:

```
ierr = isolate2dclinebybreaker(namearg)
```

Fortran command syntax:

```
CALL ISOLATE2DCLINEBYBREAKER(NAMEARG, IERR)
```

Where:

Character*12 NAMEARG	Two-terminal DC line identifier (input).
Integer IERR	error code (output).
IERR = 0	No error
IERR = 1	two-terminal dc line is not found
IERR = 2	topology error in bus branch model
IERR = 3	maximum levels reached and unable to isolate line
IERR = 4	prerequisite requirements for API are not met

2.1.3. ISOLATE3WTBYBREAKER

Use this API to isolate a three-winding transformer using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATE3WTBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the three-winding transformer. If inadequate system or substation breakers are found, such that the three-winding transformer is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATE3WTBYBREAKER IBUS JBUS KBUS CKTARG
```

Python command syntax:

```
ierr = isolate3wtbybreaker(ibus, jbus, kbus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATE3WTBYBREAKER(IBUS, JBUS, KBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Integer KBUS	last bus number (input).
Character*2 CKTARG	circuit identifier (input).
Integer IERR	error code (output).
IERR = 0	No error
IERR > 0	fatal error occurred
IERR = 1	bus does not exist
IERR = 2	circuit identifier may not start with &
IERR = 3	circuit identifier is more than two characters
IERR = 4	circuit is not found
IERR = 5	topology error in bus branch model
IERR = 6	maximum levels reached and unable to isolate line
IERR = 7	prerequisite requirements for API are not met

2.1.4. ISOLATEBUSBYBREAKER

Use this API to isolate a bus using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATEBUSBYBREAKER API can search outward into the network for breakers to open when attempting to successfully isolate the bus. If inadequate system or substation breakers are found, such that the bus is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the bus.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATEBUSBYBREAKER IBUS
```

Python command syntax:

```
ierr = isolatebusbybreaker(ibus)
```

Fortran command syntax:

```
CALL ISOLATEBUSBYBREAKER(IBUS, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	topology error in bus branch model
	IERR = 3	maximum levels reached and unable to isolate bus
	IERR = 4	prerequisite requirements for API are not met

2.1.5. ISOLATEFACTSBYBREAKER

Use this API to isolate a FACTS device using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATEFACTSBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the FACTS device. If inadequate system or substation breakers are found, such that the device is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the FACTS device.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_ISOLATEFACTSBYBREAKER NAMEARG
```

Python command syntax:

```
ierr = isolatefactsbybreaker(namearg)
```

Fortran command syntax:

```
CALL ISOLATEFACTSBYBREAKER(NAMEARG, IERR)
```

Where:

Character*12 NAMEARG	FACTS device name identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	FACTS device is not found
	IERR = 2	topology error in bus branch model
	IERR = 3	maximum levels reached and unable to isolate device
	IERR = 4	prerequisite requirements for API are not met

2.1.6. ISOLATEINDMACHINEBYBREAKER

Use this API to isolate an induction machine using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATE_LOADBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the induction machine. If inadequate system or substation breakers are found, such that the induction machine is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the induction machine.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_ISOLATEINDMACHINEBYBREAKER  IBUS  CKTARG
```

Python command syntax:

```
ierr = isolateindmachinebybreaker(ibus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATEINDMACHINEBYBREAKER(IBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Character*2 CKTARG	induction machine identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	induction machine is not found
	IERR = 3	topology error in bus branch model
	IERR = 4	maximum levels reached and unable to isolate line
	IERR = 5	prerequisite requirements for API are not met

2.1.7. ISOLATELINEBYBREAKER

Use this API to isolate a two-winding transformer or non-transformer line using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATELINEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the two-winding transformer or non-transformer line. If inadequate system or substation breakers are found, such that the line is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the line.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATELINEBYBREAKER  IBUS JBUS CKTARG
```

Python command syntax:

```
ierr = isolatelinebybreaker(ibus, jbus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATELINEBYBREAKER(IBUS, JBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Integer JBUS	to bus number (input).	
Character*2 CKTARG	circuit identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	circuit identifier may not start with &
	IERR = 3	circuit identifier is more than two characters
	IERR = 4	circuit is not found
	IERR = 5	topology error in bus branch model
	IERR = 6	maximum levels reached and unable to isolate line
	IERR = 7	prerequisite requirements for API are not met

2.1.8. ISOLATELOADBYBREAKER

Use this API to isolate a load using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATELOADBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the load. If inadequate system or substation breakers are found, such that the load is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the load.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATELOADBYBREAKER IBUS CKTARG
```

Python command syntax:

```
ierr = isolateloadbybreaker(ibus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATELOADBYBREAKER(IBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Character*2 CKTARG	load identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	load is not found
	IERR = 3	topology error in bus branch model
	IERR = 4	maximum levels reached and unable to isolate line
	IERR = 5	prerequisite requirements for API are not met

2.1.9. ISOLATEMACHINEBYBREAKER

Use this API to isolate a machine using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATEMACHINEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the machine. If inadequate system or substation breakers are found, such that the machine is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the machine.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATEMACHINEBYBREAKER  IBUS CKTARG
```

Python command syntax:

```
ierr = isolatemachinebybreaker(ibus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATEMACHINEBYBREAKER(IBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Character*2 CKTARG	machine identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	machine is not found
	IERR = 3	topology error in bus branch model
	IERR = 4	maximum levels reached and unable to isolate line
	IERR = 5	prerequisite requirements for API are not met

2.1.10. ISOLATEMSLINEBYBREAKER

Use this API to isolate a multi-section line using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API used to set the number of levels the ISOLATEMSLINEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the multi-section line. If inadequate system or substation breakers are found, such that the multi-section line is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the multi-section line.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATEMSLINEBYBREAKER IBUS JBUS CKTARG
```

Python command syntax:

```
ierr = isolatemslinebybreaker(ibus, jbus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATEMSLINEBYBREAKER(IBUS, JBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Integer JBUS	to bus number (input).	
Character*2 CKTARG	circuit identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	circuit is not found
	IERR = 4	topology error in bus branch model
	IERR = 5	maximum levels reached and unable to isolate line
	IERR = 6	prerequisite requirements for API are not met

2.1.11. ISOLATEMTDCLINEBYBREAKER

Use this API to isolate a multi-terminal dc line using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATEMTDCLINEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the multi-terminal dc line. If inadequate system or substation breakers are found, such that the line is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the line.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_ISOLATEMTDCLINEBYBREAKER NAMEARG
```

Python command syntax:

```
ierr = isolatemtdclinebybreaker(namearg)
```

Fortran command syntax:

```
CALL ISOLATEMTDCLINEBYBREAKER(NAMEARG, IERR)
```

Where:

Character*12 NAMEARG	Multi-terminal dc line identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	multi-terminal dc line is not found
	IERR = 2	topology error in bus branch model
	IERR = 3	maximum levels reached and unable to isolate line
	IERR = 4	prerequisite requirements for API are not met

2.1.12. ISOLATENODEBYBREAKER

Use this API to isolate a substation node using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATENODEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the substation node. If inadequate system or substation breakers are found, such that the node is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the node.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATENODEBYBREAKER  ISTARG IARG
```

Python command syntax:

```
ierr = isolatenodebybreaker(istarg, iarg)
```

Fortran command syntax:

```
CALL ISOLATENODEBYBREAKER(ISTARG, IARG, IERR)
```

Where:

Integer ISTARG	substation number (input).	
Integer IARG	node number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	substation in not found
	IERR = 2	node not found in substation
	IERR = 3	topology error in bus branch model
	IERR = 4	maximum levels reached and unable to isolate line
	IERR = 5	prerequisite requirements for API are not met

2.1.13. ISOLATESHUNTBYBREAKER

Use this API to isolate a fixed shunt using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATESHUNTBYBREAKER API can search outward into the network for breakers to open when attempting to successfully isolate the fixed shunt. If inadequate system or substation breakers are found, such that the shunt is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the shunt.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATESHUNTBYBREAKER  IBUS CKTARG
```

Python command syntax:

```
ierr = isolateshuntbybreaker(ibus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATESHUNTBYBREAKER(IBUS, CKTARG, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	fixed shunt identifier (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 fixed shunt is not found
	IERR = 3 topology error in bus branch model
	IERR = 4 maximum levels reached and unable to isolate line
	IERR = 5 prerequisite requirements for API are not met

2.1.14. ISOLATESWDBYBREAKER

Use this API to isolate a substation switching device using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATESWDBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the substation switching device. If inadequate system or substation breakers are found, such that the substation switching device is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATESWDBYBREAKER STATION IBUS JBUS CKTARG
```

Python command syntax:

```
ierr = isolateswdbybreaker(station, ibus, jbus, cktarg)
```

Fortran command syntax:

```
CALL ISOLATESWDBYBREAKER(STATION, IBUS, JBUS, CKTARG, IERR)
```

Where:

Integer STATION	substation number (input).
Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Character*2 CKTARG	circuit identifier (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 substation in not found
	IERR = 2 node not found in substation
	IERR = 3 circuit identifier is more than two characters
	IERR = 4 circuit is not found
	IERR = 5 topology error in bus branch model
	IERR = 6 maximum levels reached and unable to isolate line
	IERR = 7 prerequisite requirements for API are not met

2.1.15. ISOLATESWSHUNTBYBREAKER

This API routine is obsolete. It has been replaced by the API routine [IsolateSwShuntByBreaker_2](#).

Use this API to isolate a switched shunt using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATESWSHUNTBYBREAKER API can search outward into the network for breakers to open when attempting to successfully isolate the switched shunt. If inadequate system or substation breakers are found, such that the switched shunt is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_ISOLATESWSHUNTBYBREAKER  IBUS
```

Python command syntax:

```
ierr = isolateswshuntbybreaker(ibus)
```

Fortran command syntax:

```
CALL ISOLATESWSHUNTBYBREAKER(IBUS, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	switched shunt is not found
	IERR = 3	topology error in bus branch model
	IERR = 4	maximum levels reached and unable to isolate line
	IERR = 5	prerequisite requirements for API are not met

2.1.16. ISOLATESWSHUNTBYBREAKER_2

Use this API to isolate a switched shunt using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATESWSHUNTBYBREAKER API can search outward into the network for breakers to open when attempting to successfully isolate the switched shunt. If inadequate system or substation breakers are found, such that the switched shunt is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ISOLATESWSHUNTBYBREAKER_2 IBUS, 'ID'
```

Python command syntax:

```
ierr = isolateswshuntbybreaker_2(ibus, id)
```

Fortran command syntax:

```
CALL ISOLATESWSHUNTBYBREAKER_2(IBUS, ID, IERR)
```

Where:

Integer IBUS	from bus number (input).
character*2 ID	Switched shunt identifier (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 switched shunt is not found
	IERR = 3 topology error in bus branch model
	IERR = 4 maximum levels reached and unable to isolate line
	IERR = 5 prerequisite requirements for API are not met

2.1.17. ISOLATEVSCDCLINEBYBREAKER

Use this API to isolate a VSC DC line using system or substation breakers.

This API works in conjunction with the ISOLATE_LEVELS() API which sets the number of levels the ISOLATEVSCDCLINEBYBREAKER API can search outward into the network for breakers to open when attempting to isolate the VSC dc line. If inadequate system or substation breakers are found, such that the line is not successfully isolated, then specifying a larger ISOLATE_LEVELS() value may find enough additional breakers to open to achieve isolation of the line.

Use the RESTORESTATESFROMISOLATE API to restore the original network working case after an Isolate. It is recommended that you save your network case prior to running any "Isolate". Multiple "Isolate" actions can be run, and other network changes can be made, but only the original network working case prior to the initial "Isolate", or prior to the first "Isolate" after a "Restore", will be restored.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_ISOLATEVSCDCLINEBYBREAKER NAMEARG
```

Python command syntax:

```
ierr = isolatevscdclinebybreaker(namearg)
```

Fortran command syntax:

```
CALL ISOLATEVSCDCLINEBYBREAKER(NAMEARG, IERR)
```

Where:

Character*12 NAMEARG	VSC DC line identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	vsc dc line is not found
	IERR = 2	topology error in bus branch model
	IERR = 3	maximum levels reached and unable to isolate line
	IERR = 4	prerequisite requirements for API are not met

2.1.18. RESTORESTATESFROMISOLATE

Use this API to restore the network working case back to its original state; the state prior to all "Isolate By Breaker" actions that have been taken.

Caution: Any network changes that may have been made since the initial "Isolate" action will be lost.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_RESTORESTATESFROMISOLATE IERR
```

Python command syntax:

```
restorestatesfromisolate(ierr)
```

Fortran command syntax:

```
CALL RESTORESTATESFROMISOLATE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	error restoring working case
	IERR = 2	prerequisite requirements for API are not met

2.1.19. STATION_BUILD_CONFIG

Use this API to automatically build a substation for a bus in specific configuration. Once the substation is built, it can be modified to meet specific configurations.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_BUILD_CONFIG IBUS ISTARG NAMEAR SUBTYP
```

Python command syntax:

```
ierr = station_build_config(ibus, istarg, namear, subtyp)
```

Fortran command syntax:

```
CALL BUILDBUSCONFIGURATION(IBUS, ISTARG, NAMEAR, SUBTYP, IERR)
```

Where:

Integer IBUS	bus the substation is built for (input).
Integer ISTARG	station number used to uniquely identify this substation (input).
Character*40 NAMEAR	station name used to uniquely identify this substation (input).
Integer SUBTYP	basic configuration to build for this substation (input).
	SUBTYP = 1 single bus
	SUBTYP = 2 ring bus
	SUBTYP = 3 double breaker, double bus
	SUBTYP = 4 breaker and a half bus
	SUBTYP = 5 single breaker, double bus
	SUBTYP = 6 main transfer bus
	SUBTYP = 7 breaker and a half bus, with odd/even nodes in columns
	SUBTYP = 8 single breaker, double bus, with odd/even nodes in columns
Integer IERR	error code (output).
	IERR = 1 bus does not exist
	IERR = 2 invalid substation number
	IERR = 3 substation model already exists for bus
	IERR = 4 nodes to be added in the substation greater than maximum
	IERR = 5 total nodes in the substation greater than maximum
	IERR = 6 error building the substation
	IERR = 7 error building the nodes and switching de- vices
	IERR = 8 Prerequisite requirements for function not met

2.1.20. STATION_LIST

Use this API to list components in a substation.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_LIST  OPTION  STATION
```

Python command syntax:

```
ierr = station_list(option, station)
```

Fortran command syntax:

```
CALL SLIST(OPTION, STATION, IERR)
```

Where:

Integer OPTION	(input).	
	OPTION = 1	list all substations
	OPTION = 2	list substation STATION
Integer STATION	substation number (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid OPTION value
	IERR = 2	STATION does not exist
	IERR = 3	prerequisite requirements for API are not met

2.1.21. STATION_POUT

This API routine is obsolete. It has been replaced by the API routine [station_pout_2](#).

Use this API to print power flows in a substation.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_POUT  OPTION  STATION
```

Python command syntax:

```
ierr = station_pout(option, station)
```

Fortran command syntax:

```
CALL SPOUT(OPTION, STATION, IERR)
```

Where:

Integer OPTION	(input).	
	OPTION = 1	report the power flows of all substations
	OPTION = 2	report the power flows of substation STATION
Integer STATION	substation number (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid OPTION value
	IERR = 2	STATION does not exist
	IERR = 3	prerequisite requirements for API are not met

2.1.22. STATION_POUT_2

Use this API to print power flows within a substation.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_STATION_POUT_2 ALL STATION OPTION
```

Python command syntax:

```
ierr = station_pout_2(all, station, option)
```

Fortran command syntax:

```
CALL SPOUT_2(ALL, STATION, OPTION, IERR)
```

Where:

Integer ALL	(input).	
	ALL = 1	report the power flows of all substations
	ALL = 2	report the power flows of substation STATION
Integer STATION	substation number (input).	
Integer OPTION	(input).	
	OPTION = 0	Do not display loop flow values
	OPTION = 1	Show all flow values
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid ALL value
	IERR = 2	STATION does not exist
	IERR = 3	invalid OPTION value
	IERR = 4	prerequisite requirements for API are not met

2.1.23. STATION_TREE

Use this API routine to check the node breaker model and the consistency between node breaker and bus branch models.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_TREE  INTOPT STATION
```

Python command syntax:

```
ierr = station_tree(intopt, station)
```

Fortran command syntax:

```
CALL STREE(INTOPT, STATION, IERR)
```

Where:

Integer INTOPT	operation mode (input; 1 by default).
	INTOPT = 0 check all changed substations
	INTOPT = 1 check all substations
	INTOPT = 2 check individual substation
Integer STATION	substation number. Used if INTOPT = 2. (input).
Integer IERR	error code (output).
	IERR = 1 invalid INTOPT value
	IERR = 2 invalid substation number
	IERR = 3 substation does not exist
	IERR = 4 topology error in bus branch model
	IERR = 5 topology error in node breaker model
	IERR = 6 Prerequisite requirements for function not met

This chapter describes the API routines used in PSS®E Node Breaker operations.

2.2. Node Breaker Data

2.2.1. FETCH_ADJVAR_TERM_NODE

Use this API to obtain the terminal node to which an OPF adjustable bus shunt is connected to.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Python command syntax:

```
ierr,intgar = fetch_adjvar_term_node(ibus, cktarg)
```

Fortran command syntax:

```
CALL FETCH_ADJVAR_TERM_NODE(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	OPF adjustable var identifier (input).
Integer INTGAR	node terminal number (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 OPF adjustable bus shunt identifier is more than two characters
	IERR = 3 OPF adjustable bus shunt not found

2.2.2. FETCH_INDMACHINE_TERM_NODE

Use this API to obtain the terminal node to which a machine is connected to.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Python command syntax:

```
ierr,intgar = fetch_indmachine_term_node(ibus, cktarg)
```

Fortran command syntax:

```
CALL FETCH_INDMACHINE_TERM_NODE(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	induction machine identifier (input).
Integer INTGAR	node terminal number (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found

2.2.3. FETCH_LOAD_TERM_NODE

Use this API to obtain the terminal node to which a load is connected to.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Python command syntax:

```
ierr,intgar = fetch_load_term_node(ibus, cktarg)
```

Fortran command syntax:

```
CALL FETCH_LOAD_TERM_NODE(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	load identifier (input).
Integer INTGAR	node terminal number (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 load identifier is more than two characters
	IERR = 3 load not found

2.2.4. FETCH_MACHINE_TERM_NODE

Use this API to obtain the terminal node to which a machine is connected to.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Python command syntax:

```
ierr,intgar = fetch_machine_term_node(ibus, cktarg)
```

Fortran command syntax:

```
CALL FETCH_MACHINE_TERM_NODE(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	machine identifier (input).
Integer INTGAR	node terminal number (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found

2.2.5. FETCH_SHUNT_TERM_NODE

Use this API to obtain the terminal node to which a shunt is connected to.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Python command syntax:

```
ierr,intgar = fetch_shunt_term_node(ibus, cktarg)
```

Fortran command syntax:

```
CALL FETCH_SHUNT_TERM_NODE(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	shunt identifier (input).
Integer INTGAR	node terminal number (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 shunt identifier is more than two characters
	IERR = 3 shunt not found

2.2.6. FETCH_SWS_SHUNT_TERM_NODE

This API routine is obsolete. It has been replaced by the API routine [fetch_sws_shunt_term_node_2](#).

Use this API to obtain the terminal node to which a switched shunt is connected to.

This API routine was first introduced in release 34.8.0.

Python command syntax:

```
ierr,intgar = fetch_sws_shunt_term_node(ibus)
```

Fortran command syntax:

```
CALL FETCH_SWS_SHUNT_TERM_NODE(IBUS, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).	
Integer INTGAR	node terminal number (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	switched shunt not found

2.2.7. FETCH_SWS_SHUNT_TERM_NODE_2

Use this API to obtain the terminal node to which a switched shunt is connected to.

This API routine was first introduced in release 35.2.

Python command syntax:

```
ierr,intgar = fetch_sws_shunt_term_node_2(ibus, cktarg)
```

Fortran command syntax:

```
CALL FETCH_SWS_SHUNT_TERM_NODE_2(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	switched shunt identifier (input).
Integer INTGAR	node terminal number (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 switched shunt identifier is more than two characters
	IERR = 3 switched shunt not found

2.2.8. PLANT_BUS_SECTION_CHNG

This API routine is obsolete. It has been replaced by the API routine [plant_chng_3](#).

Use this API routine to modify the data of an existing plant in the working case (see PSSE Data Formats Reference Manual, Generator Data).

This API routine was first introduced in release 34.0.1.

Batch command syntax:

```
BAT_PLANT_BUS_SECTION_CHNG  I  NODE  INTGAR  REALAR(1)..REALAR(2)
```

Python command syntax:

```
ierr = plant_bus_section_chng(i, node, intgar, realar)
```

Fortran command syntax:

```
CALL PLANT_BUS_SECTION_CHNG(I, NODE, INTGAR, REALAR, IERR)
```

Where:

Integer I	bus number (input; no default allowed).
Integer NODE	node number (input; no default allowed).
Integer INTGAR (1)	one element. See the PLANT_DATA_3 API routine for details (input).
Real REALAR (2)	See the PLANT_DATA_3 API routine for details (input).
Integer IERR	error code (output).
IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 3	no plant at bus
IERR = 4	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - invalid scheduled voltage - regulated bus not found - plant specified as remotely regulating itself - type code of regulated bus is not 1 or 2 - RMPCT is not positive

2.2.9. STATION_2DC_CONV_TERM_CHNG

Use this API to access existing station two-term dc rectifier and inverter terminal data in the working case.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_STATION_2DC_CONV_TERM_CHNG  NAME  NODES(1)  NODES(2)
```

Python command syntax:

```
ierr = station_2dc_conv_term_chng(name, nodes)
```

Fortran command syntax:

```
CALL ST_NTWOTERMDC(NAME, NODES, IERR)
```

Where:

character*12 NAME	quoted name of the two-terminal dc line for which node terminal data for one or both of its converters is to be specified (input; no default allowed).	
Integer NODES (2)	array of elements specifying (input).	
	NODES(1)	node number to which the dc rectifier end is attached
	NODES(2)	node number to which the dc inverter end is attached
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	two-terminal dc line not found
	IERR = 2	bus associated with node is not part of a substation
	IERR = 3	node does not exist
	IERR = 4	Invalid node number
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

2.2.10. STATION_ADJVAR_TERM_CHNG

Use this API to change a substation OPF adjustable bus shunt node terminal connection in the working case.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_STATION_ADJVAR_TERM_CHNG  BUS CKTARG INTGAR
```

Python command syntax:

```
ierr = station_adjvar_term_chng(bus, cktarg, intgar)
```

Fortran command syntax:

```
CALL ST_NADJVAR(BUS, CKTARG, INTGAR, IERR)
```

Where:

Integer BUS	from bus number (input).
Character*2 CKTARG	adjustable bus shunt identifier (input).
Integer INTGAR	node terminal number (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 OPF adjustable bus shunt identifier is more than two characters
	IERR = 3 OPF adjustable bus shunt is not found
	IERR = 4 bus does not belong to a substation
	IERR = 5 node not found in substation
	IERR = 6 invalid node number
	IERR = 7 node-breaker terminal connection table is full
	IERR = 8 error when moving OPF adjustable bus shunt terminal connection
	IERR = 9 prerequisite requirements for API are not met

2.2.11. STATION_BRANCH_TERM_CHNG

Use this API to access existing station branch terminal data in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_BRANCH_TERM_CHNG  IBUS  JBUS  CKTARG  NODES(1)  NODES(2)
```

Python command syntax:

```
ierr = station_branch_term_chng(ibus, jbus, cktarg, nodes)
```

Fortran command syntax:

```
CALL ST_NBRANCH(IBUS, JBUS, CKTARG, NODES, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Character*2 CKTARG	circuit identifier (input).
Integer NODES (2)	array of 2 elements specifying (input).
	NODES(1) from node number
	NODES(2) to node number
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 bus does not belong to a substation
	IERR = 3 node does not exist in substation
	IERR = 4 invalid node number
	IERR = 5 circuit not found
	IERR = 6 circuit identifier is more than two characters
	IERR = 7 circuit identifier may not start with &
	IERR = 8 error encountered when moving branch connection
	IERR = 9 node-breaker terminal connection table is full
	IERR = 10 prerequisite requirements for API are not met

2.2.12. STATION_BRANCH_TERM_MOVE

Use this API to move one terminal node connection of a branch in the working case. The second bus argument (JBUS) is the bus at which the bus at which the node connection will be moved to the node designated in the DSNODE argument.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_BRANCH_TERM_MOVE  IBUS  JBUS  CKTARG  DSNODE
```

Python command syntax:

```
ierr = station_branch_term_move(ibus, jbus, cktarg, dsnode)
```

Fortran command syntax:

```
CALL MOVEBRANCHTERMINAL( IBUS, JBUS, CKTARG, DSNODE, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number. This is the bus for which the node connection will be moved to the node designated in DSNODE. (input).
Character*2 CKTARG	circuit identifier (input).
Integer DSNODE	new terminal node number (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 bus does not belong to a substation
	IERR = 3 node not found in substation
	IERR = 4 invalid node number
	IERR = 5 circuit not found
	IERR = 6 circuit identifier is more than two characters
	IERR = 7 circuit identifier may not start with &
	IERR = 8 error encountered when moving branch
	IERR = 9 node-breaker terminal connection table is full
	IERR = 10 prerequisite requirements for API are not met

2.2.13. STATION_BUS_PURG

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_STATION_BUS_PURG STATION IBUS
```

Python command syntax:

```
ierr = station_bus_purg(station,ibus)
```

Fortran command syntax:

```
CALL PURG_STATION_BUS(STATION, IBUS, IERR)
```

Where:

Integer STATION	substation number (input).	
Integer IBUS	bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid STATION number
	IERR = 2	STATION does not exist
	IERR = 3	BUS does not exist
	IERR = 4	unable to move all connections back to original network bus
	IERR = 5	prerequisite requirements for API are not met

2.2.14. STATION_CHNG

Use this API to modify the data of an existing substation data in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_CHNG STATION REALAR(1)..REALAR(3) NAMEAR
```

Python command syntax:

```
ierr = station_chng(station, realar, namear)
```

Fortran command syntax:

```
CALL STATION_CHNG(STATION, REALAR, NAMEAR, IERR)
```

Where:

Integer STATION	substation number (input; no default allowed).
Real REALAR (3)	array of elements specifying (input).
	REALAR(1) substation latitude
	REALAR(2) substation longitude
	REALAR(3) substation grounding resistance
Character*40 NAMEAR	substation name (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 invalid substation number
	IERR = 2 substation not found
	IERR = 3 substation name has been used
	IERR = 4 substation table is full
	IERR = 5 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - Latitude/longitude out of range - Substation grounding dc resistance is less than 0.0 - Substation name is more than STATIONNAMLEN characters

2.2.15. STATION_DATA

Use this API to modify the data of an existing substation data in the working case, or to add a new substation to the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_DATA STATION REALAR(1)..REALAR(3) NAMEAR
```

Python command syntax:

```
ierr = station_data(station, realar, namear)
```

Fortran command syntax:

```
CALL STATION_API(STATION, REALAR, NAMEAR, IERR)
```

Where:

Integer STATION	substation number (input; no default allowed).
Real REALAR (3)	array of elements specifying (input).
	REALAR(1) substation latitude
	REALAR(2) substation longitude
	REALAR(3) substation grounding resistance
Character*40 NAMEAR	substation name (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 invalid substation number
	IERR = 2 substation not found
	IERR = 3 substation name has been used
	IERR = 4 substation table is full
	IERR = 5 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - Latitude/longitude out of range - Substation grounding dc resistance is less than 0.0 - Substation name is more than STATIONNAMLEN characters

2.2.16. STATION_FACTS_TERM_CHNG

Use this API to access existing station FACTS device sending and terminal end node-breaker terminal data in the working case.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_STATION_FACTS_TERM_CHNG  NAME  INTGAR(1)  INTGAR(2)
```

Python command syntax:

```
ierr = station_facts_term_chng(name, intgar)
```

Fortran command syntax:

```
CALL ST_NFACTS(NAME, INTGAR, IERR)
```

Where:

character*12 NAME	quoted name of the FACTS device for which node terminal data for the sending and terminal end is to be changed (input; no default allowed).	
Integer INTGAR (2)	array of elements specifying (input).	
	INTGAR(1)	node number to which the FACTS device sending end is attached
	INTGAR(2)	node number to which the FACTS device terminal end is attached
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	FACTS device not found
	IERR = 2	bus associated with node does not belong to substation
	IERR = 3	node does not exist
	IERR = 4	Invalid node number
	IERR = 5	Node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

2.2.17. STATION_INDMACHINE_TERM_CHNG

Use this API to change a substation induction machine node terminal connection in the working case.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_STATION_INDMACHINE_TERM_CHNG  IBUS CKTARG INTGAR
```

Python command syntax:

```
ierr = station_indmachine_term_chng(ibus, cktarg, intgar)
```

Fortran command syntax:

```
CALL ST_NINDMAC(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	induction machine identifier (input).
Integer INTGAR	node terminal number (input).
Integer IERR	error code (output).
IERR = 0	No error
IERR > 0	fatal error occurred
IERR = 1	bus does not exist
IERR = 2	induction machine identifier is more than two characters
IERR = 3	induction machine not found
IERR = 4	bus does not belong to a substation
IERR = 5	node does not exist in substation
IERR = 6	invalid node number
IERR = 7	node-breaker terminal connection table is full
IERR = 8	error when moving induction machine terminal connection
IERR = 9	prerequisite requirements for API are not met

2.2.18. STATION_LOAD_TERM_CHNG

Use this API to access existing station load terminal data in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_LOAD_TERM_CHNG  IBUS CKTARG INTGAR
```

Python command syntax:

```
ierr = station_load_term_chng(ibus, cktarg, intgar)
```

Fortran command syntax:

```
CALL ST_NLOAD(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	load identifier (input).
Integer INTGAR	node terminal number (input).
Integer IERR	error code (output).
IERR = 0	No error
IERR > 0	fatal error occurred
IERR = 1	bus does not exist
IERR = 2	load identifier is more than two characters
IERR = 3	load is not found
IERR = 4	bus does not belong to a substation
IERR = 5	node does not exist in substation
IERR = 6	invalid node number
IERR = 7	node-breaker terminal connection table is full
IERR = 8	error when moving load terminal connection
IERR = 9	prerequisite requirements for API are not met

2.2.19. STATION_MACHINE_TERM_CHNG

Use this API to change a substation machine terminal connection in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_MACHINE_TERM_CHNG  IBUS CKTARG INTGAR
```

Python command syntax:

```
ierr = station_machine_term_chng(ibus, cktarg, intgar)
```

Fortran command syntax:

```
CALL ST_NMACHINE(IBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Character*2 CKTARG	machine identifier (input).
Integer INTGAR	node terminal number (input).
Integer IERR	error code (output).
IERR = 0	No error
IERR > 0	fatal error occurred
IERR = 1	bus does not exist
IERR = 2	machine identifier is more than two characters
IERR = 3	machine not found
IERR = 4	bus does not belong to a substation
IERR = 5	node does not exist in substation
IERR = 6	Invalid node number
IERR = 7	node-breaker terminal connection table is full
IERR = 8	error encountered when moving machine terminal connection
IERR = 9	prerequisite requirements for API are not met

2.2.20. STATION_MTDC_TERM_CHNG

Use this API to access existing station multi-terminal converter terminal data in the working case.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_STATION_MTDC_TERM_CHNG  NAME  INTGAR(1)  INTGAR(2)
```

Python command syntax:

```
ierr = station_mtdc_term_chng(name, intgar)
```

Fortran command syntax:

```
CALL ST_NMTDC(NAME, INTGAR, IERR)
```

Where:

character*12 NAME	quoted name of the multi-terminal dc line for which node terminal data is to be specified for one of the ac converter buses (input; no default allowed).	
Integer INTGAR (2)	array of elements specifying (input).	
	INTGAR(1)	converter bus to which the node is attached
	INTGAR(2)	node number to which the converter end is attached
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	multi-terminal dc line not found
	IERR = 2	bus associated with node does not belong to substation
	IERR = 3	node does not exist
	IERR = 4	Invalid node number
	IERR = 5	bus is not a recognized ac converter bus within multi-terminal dc line
	IERR = 6	node-breaker terminal connection table is full
	IERR = 7	prerequisite requirements for API are not met

2.2.21. STATION_NODE_CHNG

Use this API to modify the data of an existing substation node in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_NODE_CHNG STATION NODE INTGAR(1) INTGAR(2) NAMEAR
```

Python command syntax:

```
ierr = station_node_chng(station, node, intgar, namear)
```

Fortran command syntax:

```
CALL NODE_CHNG(STATION, NODE, INTGAR, NAMEAR, IERR)
```

Where:

Integer STATION	substation number (input; no default allowed).
Integer NODE	node number (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying array of two integer values(input). INTGAR(1) bus number to which the node is connected INTGAR(2) node status INTGAR(2) = 0 out-of-service INTGAR(2) = 1 in-service
Character*40 NAMEAR	node name (input; blank by default).
Integer IERR	error code (output). IERR = -1 data error, warning and information mes- sages IERR = 0 no errors IERR = 1 invalid substation number IERR = 2 substation not found IERR = 3 invalid node number IERR = 4 node not found IERR = 5 no bus associated with this node IERR = 6 prerequisite requirements for API are not met

2.2.22. STATION_NODE_DATA

Use this API to modify the data of an existing substation node in the working case, or to add a new substation node to the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_NODE_DATA STATION NODE INTGAR(1) INTGAR(2) NAMEAR
```

Python command syntax:

```
ierr = station_node_data(station, node, intgar, namear)
```

Fortran command syntax:

```
CALL NODE_API(STATION, NODE, INTGAR, NAMEAR, IERR)
```

Where:

Integer STATION	substation number (input; no default allowed).
Integer NODE	node number (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying Array of two integer values(input). INTGAR(1) bus number to which the node is connected INTGAR(2) node status INTGAR(2) = 0 out-of-service INTGAR(2) = 1 in-service
Character*40 NAMEAR	Node name (input; blank by default).
Integer IERR	error code (output). IERR = -1 data error, warning and information messages IERR = 0 no errors IERR = 1 invalid substation number IERR = 2 substation not found IERR = 3 invalid node number IERR = 4 node not found IERR = 5 no bus associated with this node IERR = 7 node table is full IERR = 8 node-breaker terminal connection table is full IERR = 9 prerequisite requirements for API are not met

2.2.23. STATION_NODE_NUMBER

Use this API to change a node number in an existing substation.

This API routine was first introduced in release 34.0.1.

Batch command syntax:

```
BAT_STATION_NODE_NUMBER STATION NODE NEWNODE
```

Python command syntax:

```
ierr = station_node_number(station, node, newnode)
```

Fortran command syntax:

```
CALL NODE_NUMBER(STATION, NODE, NEWNODE, IERR)
```

Where:

Integer STATION	substation number (input; no default allowed).
Integer NODE	number of the node to be changed (input; no default allowed).
Integer NEWNODE	new number to be assigned to the node (input; no default allowed).
Integer IERR	error code (output).
	IERR = 1 invalid substation number.
	IERR = 2 substation not found.
	IERR = 3 invalid node number.
	IERR = 4 node not found.
	IERR = 5 invalid new node number.
	IERR = 6 node number is already assigned to another node in the substation.
	IERR = 7 prerequisite requirements for API are not met

2.2.24. STATION_NODE_PURG

Use this API to delete a node in an existing substation.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_NODE_PURG STATION NODE
```

Python command syntax:

```
ierr = station_node_purg(station, node)
```

Fortran command syntax:

```
CALL PURG_NODE(STATION, NODE, IERR)
```

Where:

Integer STATION	substation number (input; no default allowed).	
Integer NODE	node number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	working case is empty
	IERR = 2	invalid substation number
	IERR = 3	substation not found
	IERR = 4	invalid node number
	IERR = 5	node not found
	IERR = 6	prerequisite requirements for API are not met

2.2.25. STATION_NUMBER

Use this API to change a substation number for an existing substation.

This API routine was first introduced in release 34.0.1.

Batch command syntax:

```
BAT_STATION_NUMBER STATION NEWSTATION
```

Python command syntax:

```
ierr = station_number(station, newstation)
```

Fortran command syntax:

```
CALL STATION_NUMBER(STATION, NEWSTATION, IERR)
```

Where:

Integer STATION	substation number (input).
Integer NEWSTATION	new substation number (input).
Integer IERR	error code (output).
	IERR = 1 invalid substation number.
	IERR = 2 substation not found.
	IERR = 3 invalid new substation number.
	IERR = 4 substation number is already assigned to another substation.
	IERR = 5 prerequisite requirements for API are not met

2.2.26. STATION_PURG

Use this API to delete a substation and all node-breaker components within that substation from the working case. All network elements will remain in the working case and any bus sections will be merged back into the original bus.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_PURG STATION
```

Python command syntax:

```
ierr = station_purg(station)
```

Fortran command syntax:

```
CALL PURG_STATION(STATION, IERR)
```

Where:

Integer STATION	substation number (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	invalid substation number
	IERR = 2	substation not found
	IERR = 3	unable to move all connections back to original network bus
	IERR = 4	prerequisite requirements for API are not met

2.2.27. STATION_SHUNT_TERM_CHNG

Use this API to change a substation fixed shunt terminal connection in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SHUNT_TERM_CHNG BUS CKTARG INTGAR
```

Python command syntax:

```
ierr = station_shunt_term_chng(bus, cktarg, intgar)
```

Fortran command syntax:

```
CALL ST_NSHUNT(BUS, CKTARG, INTGAR, IERR)
```

Where:

Integer BUS	from bus number (input).
Character*2 CKTARG	fixed bus shunt identifier (input).
Integer INTGAR	node terminal number (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 fixed shunt identifier is more than two characters
	IERR = 3 fixed shunt is not found
	IERR = 4 bus does not have substation model
	IERR = 5 node does not exist in substation
	IERR = 6 invalid node number
	IERR = 7 node-breaker terminal connection table is full
	IERR = 8 error when moving shunt terminal connection
	IERR = 9 prerequisite requirements for API are not met

2.2.28. STATION_SWD_CHNG

Use this API to modify the data of an existing station switching device in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SWD_CHNG STATION INODE JNODE CKTARG INTGAR(1)..INTGAR(3)
REALAR(1)..REALAR(4) NAMEAR
```

Python command syntax:

```
ierr = station_swd_chng(station, inode, jnode, cktarg, intgar, realar,
namear)
```

Fortran command syntax:

```
CALL STATION_SWD_CHNG(STATION, INODE, JNODE, CKTARG, INTGAR, REALAR,
NAMEAR, IERR)
```

Where:

Integer STATION	substation number (input).
Integer INODE	from node number (input).
Integer JNODE	to node number (input).
Character*2 CKTARG	circuit identifier (input).
Integer INTGAR (3)	array of 3 elements specifying (input). INTGAR(1) device status INTGAR(2) device normal status INTGAR(3) device type
Real REALAR (4)	array of 4 elements specifying (input). REALAR(1) device reactance REALAR(2) RateA rating REALAR(3) RateB rating REALAR(4) RateC rating
Character*40 NAMEAR	substation switching device name (input).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 substation is not found IERR = 2 node is not found IERR = 3 circuit identifier is more than two characters IERR = 4 switching device from node to itself IERR = 5 circuit identifier is invalid IERR = 6 switching device is not found IERR = 11 prerequisite requirements for API are not met

IERR = -1

data error, warning and information messages; one or more of: - switching device reactance is 0.0. - switching device rating is less than 0.0. - invalid status. -switching device name truncated to 40 characters.

2.2.29. STATION_SWD_DATA

Use this API to modify the data of an existing substation switching device in the working case, or to add a new substation switching device to the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SWD_DATA STATION INODE JNODE CKTARG INTGAR(1)..INTGAR(3)
REALAR(1)..REALAR(4) NAMEAR
```

Python command syntax:

```
ierr = station_swd_data(station, inode, jnode, cktarg, intgar, realar,
namear)
```

Fortran command syntax:

```
CALL STATION_SWD_DATA(STATION, INODE, JNODE, CKTARG, INTGAR, REALAR,
NAMEAR, IERR)
```

Where:

Integer STATION	substation number (input).
Integer INODE	from node number (input).
Integer JNODE	to node number (input).
Character*2 CKTARG	circuit identifier (input).
Integer INTGAR (3)	array of 3 elements specifying (input). INTGAR(1) device status INTGAR(2) device normal status INTGAR(3) device type
Real REALAR (4)	array of 4 elements specifying (input). REALAR(1) device reactance REALAR(2) RateA rating REALAR(3) RateB rating REALAR(4) RateC rating
Character*40 NAMEAR	substation switching device name (input).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 substation is not found IERR = 2 node is not found IERR = 3 circuit identifier is more than two characters IERR = 4 switching device from node to itself IERR = 5 circuit identifier is invalid IERR = 6 switching device already exists

IERR = 7	station switching device table is full
IERR = 8	system switching device table is full
IERR = 9	cannot place substation switching device between nodes residing in different substations
IERR = 10	cannot place substation switching device between nodes belonging to two different buses in the same substation
IERR = 11	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - switching device reactance is 0.0. - switching device rating is less than 0.0. - invalid status. - switching device name truncated to 40 characters.

2.2.30. STATION_SWD_MPID

Use this API to modify the circuit identifier of an existing station switching device in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SWD_MPID STATION INODE JNODE CKTARG CKTNEW
```

Python command syntax:

```
ierr = station_swd_mpid(station, inode, jnode, cktarg, cktnew)
```

Fortran command syntax:

```
CALL STATION_MSWDID(STATION, INODE, JNODE, CKTARG, CKTNEW, IERR)
```

Where:

Integer STATION	substation number (input).
Integer INODE	from node number (input).
Integer JNODE	to node number (input).
Character*2 CKTARG	circuit identifier (input).
Character*2 CKTNEW	new circuit identifier (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 substation is not found
	IERR = 2 node is not found
	IERR = 3 circuit identifier is more than two characters
	IERR = 4 switching device from node to itself
	IERR = 5 circuit identifier is invalid
	IERR = 6 switching device is not found
	IERR = 7 circuit identifier connecting these nodes already exists
	IERR = 8 prerequisite requirements for API are not met

2.2.31. STATION_SWD_MOVE

Use this API to move the "to" node of an existing substation switching device in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SWD_MOVE STATION INODE JNODE CKTARG KNODE CKTNEW
```

Python command syntax:

```
ierr = station_swd_move(station, inode, jnode, cktarg, knode, cktnew)
```

Fortran command syntax:

```
CALL MOVE_STATION_SWD(STATION, INODE, JNODE, CKTARG, KNODE, CKTNEW, IERR)
```

Where:

Integer STATION	substation number (input).	
Integer INODE	from node number (input).	
Integer JNODE	to node number (input).	
Character*2 CKTARG	circuit identifier (input).	
Integer KNODE	new to node number (input).	
Character*2 CKTNEW	new circuit identifier (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	working case is empty
	IERR = 2	invalid substation number
	IERR = 3	substation is not found
	IERR = 4	invalid node number
	IERR = 5	node number is not found in substation
	IERR = 6	switching device is not found
	IERR = 7	switching device already exists
	IERR = 8	prerequisite requirements for API are not met

2.2.32. STATION_SWD_PURG

Use this API to delete an existing substation switching device in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SWD_PURG STATION INODE JNODE CKTARG
```

Python command syntax:

```
ierr = station_swd_purg(station, inode, jnode, cktarg)
```

Fortran command syntax:

```
CALL PURG_STATION_SWD(STATION, INODE, JNODE, CKTARG, IERR)
```

Where:

Integer STATION	substation number (input).
Integer INODE	from node number (input).
Integer JNODE	to node number (input).
Character*2 CKTARG	circuit identifier (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 working case is empty
	IERR = 2 invalid substation number
	IERR = 3 substation is not found
	IERR = 4 invalid node number
	IERR = 5 node number is not found in substation
	IERR = 6 switching device is not found
	IERR = 7 prerequisite requirements for API are not met

2.2.33. STATION_SWS_SHUNT_TERM_CHNG

This API routine is obsolete. It has been replaced by the API routine [station_sws_shunt_term_chng_2](#).

Use this API to change a substation switched shunt node terminal connection in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_SWS_SHUNT_TERM_CHNG  BUS  INTGAR
```

Python command syntax:

```
ierr = station_sws_shunt_term_chng(bus, intgar)
```

Fortran command syntax:

```
CALL ST_NSWSHUNT(BUS, INTGAR, IERR)
```

Where:

Integer BUS	(input).	
Integer INTGAR	(input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	bus does not exist
	IERR = 2	switched shunt does not exist
	IERR = 3	bus does not belong to a substation
	IERR = 4	node not found in substation
	IERR = 5	invalid node number
	IERR = 6	error when moving switched shunt
	IERR = 7	prerequisite requirements for API are not met

2.2.34. STATION_SWS_SHUNT_TERM_CHNG_2

Use this API to change a substation switched shunt node terminal connection in the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_STATION_SWS_SHUNT_TERM_CHNG_2  BUS ID INTGAR
```

Python command syntax:

```
ierr = station_sws_shunt_term_chng_2(bus, id, intgar)
```

Fortran command syntax:

```
CALL ST_NSWSHUNT_2(BUS, ID, INTGAR, IERR)
```

Where:

Integer BUS	Number of the bus to which the switched shunt is connected (input).
character*2 ID	switched shunt identifier (input).
Integer INTGAR	Terminal node number (input).
Integer IERR	error code (output).
IERR = 0	No error
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	switched shunt identifier is more than two characters
IERR = 3	switched shunt not found
IERR = 4	bus does not belong to a substation
IERR = 5	node not found in substation
IERR = 6	invalid node number
IERR = 7	node-breaker terminal connection table is full
IERR = 8	error when moving switched shunt terminal connection
IERR = 9	prerequisite requirements for API are not met

2.2.35. STATION_THREE_WND_TERM_CHNG

Use this API to access existing substation three-winding transformer terminal data in the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_THREE_WND_TERM_CHNG  IBUS JBUS KBUS CKTARG
  INTGAR(1) .. INTGAR(3)
```

Python command syntax:

```
ierr = station_three_wnd_term_chng(ibus, jbus, kbus, cktarg, intgar)
```

Fortran command syntax:

```
CALL ST_NTHREE_WINDING(IBUS, JBUS, KBUS, CKTARG, INTGAR, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Integer KBUS	to bus number (input).
Character*2 CKTARG	circuit identifier (input).
Integer INTGAR (3)	array of 3 elements specifying (input).
	INTGAR(1) from node number
	INTGAR(2) to node number
	INTGAR(3) to node number
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 bus does not belong to a substation
	IERR = 3 node does not exist
	IERR = 4 node number is invalid
	IERR = 5 circuit identifier is more than two characters
	IERR = 6 circuit identifier may not start with &
	IERR = 7 circuit does not exist
	IERR = 8 error encountered when moving transformer
	IERR = 9 node-breaker terminal connection table is full
	IERR = 10 prerequisite requirements for API are not met

2.2.36. STATION_THREE_WND_TERM_MOVE

Use this API to move one terminal node connection of a three-winding transformer in the working case. The third bus argument (KBUS) is the bus at which the node connection will be moved to the node designated in the DSNODE argument. IBUS and JBUS are the other two three winding transformer bus connections.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_STATION_THREE_WND_TERM_MOVE IBUS JBUS KBUS CKTARG DSNODE
```

Python command syntax:

```
ierr = station_three_wnd_term_move(ibus, jbus, kbus, cktarg, dsnode)
```

Fortran command syntax:

```
CALL MOVE3WTERMINAL(IBUS, JBUS, KBUS, CKTARG, DSNODE, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Integer KBUS	third bus number. This is the bus for which the node connection will be moved to the node designated in DSNODE. (input).
Character*2 CKTARG	circuit identifier (input).
Integer DSNODE	new terminal node number (input).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR > 0 fatal error occurred
	IERR = 1 bus does not exist
	IERR = 2 bus does not belong to a substation
	IERR = 3 node does not exist
	IERR = 4 invalid node number
	IERR = 5 circuit identifier is more than two characters
	IERR = 6 circuit identifier may not start with &
	IERR = 7 circuit does not exist
	IERR = 8 error encountered when moving transformer
	IERR = 9 node-breaker terminal connection table is full
	IERR = 10 prerequisite requirements for API are not met

2.2.37. STATION_VSCDC_CONV_TERM_CHNG

Use this API to access existing station vsc dc converter terminal data in the working case.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_STATION_VSCDC_CONV_TERM_CHNG  NAME  INTGAR(1)  INTGAR(2)
```

Python command syntax:

```
ierr = station_vscdc_conv_term_chng(name, intgar)
```

Fortran command syntax:

```
CALL ST_NVSCDC(NAME, INTGAR, IERR)
```

Where:

character*12 NAME	quoted name of the vsc dc line for which node terminal data for one or both of its converters is to be specified (input; no default allowed).	
Integer INTGAR (2)	array of elements specifying (input).	
	INTGAR(1)	node number to which the first converter end is attached
	INTGAR(2)	node number to which the second converter end is attached
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR > 0	fatal error occurred
	IERR = 1	vsc dc line not found
	IERR = 2	bus associated with node is not part of a sub-station
	IERR = 3	node does not exist
	IERR = 4	Invalid node number
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met

2.2.38. SYSTEM_SWD_CHNG

Use this API to modify the data of an existing system switching device in the working case, or to add a new system switching device to the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SYSTEM_SWD_CHNG  IBUS JBUS CKTARG INTGAR(1)..INTGAR(4) RBRXAR
REALAR(1)..REALAR(12) NAMEAR
```

Python command syntax:

```
ierr = system_swd_chng(ibus, jbus, cktarg, intgar, rbrxar, realar, namear)
```

Fortran command syntax:

```
CALL SYSTEM_SWD_CHNG(IBUS, JBUS, CKTARG, INTGAR, RBRXAR, REALAR, NAMEAR,
IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Character*2 CKTARG	circuit identifier (input).
Integer INTGAR (4)	array of 4 elements specifying (input). INTGAR(1) device status INTGAR(2) device normal status INTGAR(3) metered end bus number INTGAR(4) device type
Real RBRXAR	nominal branch reactance (input).
Real REALAR (12)	array of 12 elements specifying (input). REALAR(1) rating set 1 rating REALAR(2) rating set 2 rating REALAR(3) rating set 3 rating REALAR(4) rating set 4 rating REALAR(5) rating set 5 rating REALAR(6) rating set 6 rating REALAR(7) rating set 7 rating REALAR(8) rating set 8 rating REALAR(9) rating set 9 rating REALAR(10) rating set 10 rating REALAR(11) rating set 11 rating REALAR(12) rating set 12 rating
Character*40 NAMEAR	switching device name (input).
Integer IERR	error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus is not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	branch exists but it is a two-winding transformer
IERR = 4	branch exists but it is a regular, non-transformer barhcn
IERR = 5	switching device from bus to itself
IERR = 6	blank circuit identifier is invalid
IERR = 7	circuit identifier may not start with &
IERR = 8	branch table is full
IERR = 9	branch ownership table is full
IERR = 10	switching device table is full
IERR = 11	prerequisite requirements for API are not met
IERR = 12	zero impedance line table is full
IERR = 13	branch not found
IERR = 14	node-breaker terminal connection table is full
IERR = -1	data error, warning and information messages; one or more of: - switching device reactance is 0.0 or greater than zero impedance line threshold. - invalid metered end bus. - invalid switching device status. - system switching device name has too many characters - system switching device rate is negative - zero impedance line table is full - multi-section line grouping deleted - name is already assigned to a branch - name contains invalid characters

2.2.39. SYSTEM_SWD_DATA

Use this API to add or modify the data of an existing system switching device in the working case, or to add a new system switching device to the working case.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SYSTEM_SWD_DATA  IBUS JBUS CKTARG INTGAR(1)..INTGAR(4) RBRXAR
REALAR(1)..REALAR(12) NAMEAR
```

Python command syntax:

```
ierr = system_swd_data(ibus, jbus, cktarg, intgar, rbrxar, realar, namear)
```

Fortran command syntax:

```
CALL SYSTEM_SWD_DATA(IBUS, JBUS, CKTARG, INTGAR, RBRXAR, REALAR, NAMEAR,
IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Character*2 CKTARG	circuit identifier (input).
Integer INTGAR (4)	array of 4 elements specifying (input).
	INTGAR(1) device status
	INTGAR(2) device normal status
	INTGAR(3) metered end bus number
	INTGAR(4) device type
Real RBRXAR	nominal branch reactance (input).
Real REALAR (12)	array of 12 elements specifying (input).
	REALAR(1) rating set 1 rating
	REALAR(2) rating set 2 rating
	REALAR(3) rating set 3 rating
	REALAR(4) rating set 4 rating
	REALAR(5) rating set 5 rating
	REALAR(6) rating set 6 rating
	REALAR(7) rating set 7 rating
	REALAR(8) rating set 8 rating
	REALAR(9) rating set 9 rating
	REALAR(10) rating set 10 rating
	REALAR(11) rating set 11 rating
	REALAR(12) rating set 12 rating
Character*40 NAMEAR	switching device name (input).
Integer IERR	error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus is not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	branch exists but it is a two-winding transformer
IERR = 4	branch exists but it is a regular, non-transformer barhcn
IERR = 5	switching device from bus to itself
IERR = 6	blank circuit identifier is invalid
IERR = 7	circuit identifier may not start with &
IERR = 8	branch table is full
IERR = 9	branch ownership table is full
IERR = 10	switching device table is full
IERR = 11	prerequisite requirements for API are not met
IERR = 12	zero impedance line table is full
IERR = 13	branch already exists
IERR = 14	node-breaker terminal connection table is full
IERR = -1	data error, warning and information messages; one or more of: - switching device reactance is 0.0 or greater than zero impedance line threshold. - invalid metered end bus. - invalid switching device status. - system switching device name has too many characters - system switching device rate is negative - zero impedance line table is full - multi-section line grouping deleted. - name is already assigned to a branch - name contains invalid characters

This section describes the API routines used to add or modify power flow data pertaining to substation data.

For most categories of power flow substation data, there are a pair of API routines for specifying data; one of these contains "_DATA" as part of the API name, and the other contains "_CHNG" in its API name. The "_DATA" API routines may be used to add a new network element to the working case, or to modify the data of an existing network element. The "_CHNG" API routines may be used only to modify the data of an existing network element; specifying a network element that does not already exist in the working case to one of the "_CHNG" API routines is treated as a fatal error by the API routine.

Generally, when an API is adding a new element to the working case, data items that are defaulted are set to the value listed in the data item's description. When an API is modifying the data of an existing element, defaulted data items are unchanged.

Chapter 3

Optimal Power Flow

This chapter describes the API routines used in PSS®E Optimal Power Flow, or OPF.

3.1. Optimal Power Flow Operation

3.1.1. ADD_DETAILS_TO_OPF_LOG

Use this API to specify or return the value of the OPF solution option to add details of the sensitivity values and Lagrange multipliers to the OPF Output Log file.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_ADD_DETAILS_TO_OPF_LOG IVAL
```

Python command syntax:

```
ierr = add_details_to_opf_log(ival)
ierr, ival = add_details_to_opf_log()
```

Fortran command syntax:

```
CALL ADD_DETAILS_TO_OPF_LOG(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to append the OPF log file with information on sensitivity values and Lagrange multipliers (input; input if Batch command or for Python if specified as an argument, or for FORTRAN if IOCODE is 0; else output, 0 by default).
	IVAL = 0 do not print additional details in log file.
	IVAL = 1 print additional details.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to the value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.2. APPLY_ALTERNATE_STEP_SIZE

Use this API to specify or return the value of the OPF solution option for applying an alternate lambda mismatch step size. This option works in conjunction with the OPF_BARRIER_STEP_LENGTH option setting (Section 3.1.25), which specifies the alternate barrier step length value.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_APPLY_ALTERNATE_STEP_SIZE    IVAL
```

Python command syntax:

```
ierr = apply_alternate_step_size(ival)

ierr, ival = apply_alternate_step_size()
```

Fortran command syntax:

```
CALL APPLY_ALTERNATE_STEP_SIZE(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to limit the step size taken during the OPF solution (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not limit the step size.
	IVAL = 1 limit the step size.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.3. APPLY_AUTOMATIC_SCALING

Use this API to specify or return the value of the OPF solution option to apply automatic scaling of the objective coefficients and derivatives to improve convergence of the OPF solution.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_APPLY_AUTOMATIC_SCALING    IVAL
```

Python command syntax:

```
ierr = apply_automatic_scaling(ival)
ierr, ival = apply_automatic_scaling()
```

Fortran command syntax:

```
CALL APPLY_AUTOMATIC_SCALING(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to apply automatic scaling of the objective during the solution (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not apply automatic scaling of the objective.
	IVAL = 1	apply automatic scaling of the objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.4. BAD_ITER_COARSE_LIMIT

Use this API to specify or return the number of bad iterations allowed when the barrier coefficient is greater than 0.011 (μ greater than -2) before the solution progress is terminated as being infeasible.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_BAD_ITER_COARSE_LIMIT IVAL
```

Python command syntax:

```
ierr = bad_iter_coarse_limit(ival)
ierr, ival = bad_iter_coarse_limit()
```

Fortran command syntax:

```
CALL BAD_ITER_COARSE_LIMIT(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Bad iteration coarse limit value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.5. BAD_ITER_FINE_LIMIT

Use this API to specify or return the the bad iteration limit when the barrier coefficient is less than, or equal to 0.011 (μ less than or equal to -2) before the solution progress is terminated as being infeasible.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_BAD_ITER_FINE_LIMIT IVAL
```

Python command syntax:

```
ierr = bad_iter_fine_limit(ival)
ierr, ival = bad_iter_fine_limit()
```

Fortran command syntax:

```
CALL BAD_ITER_FINE_LIMIT(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Bad iteration fine limit value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.6. CLAMP_NONOPTIMIZED_GENS

Use this API to specify or return the value of the OPF solution option to apply the clamp equation to non-optimized generators. The behavior of the clamp equation may be further customized through the OPF_INITIAL_CLAMP_TOL, OPF_FINAL_CLAMP_TOL and the OPF_CLAMP_DECAY_FACTOR option settings. For additional information on the clamp treatment of non-optimized generators, refer to Clamp Treatment in the PSSE Program Operation Manual.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_CLAMP_NONOPTIMIZED_GENS    IVAL
```

Python command syntax:

```
ierr = clamp_nonoptimized_gens(ival)
ierr, ival = clamp_nonoptimized_gens()
```

Fortran command syntax:

```
CALL CLAMP_NONOPTIMIZED_GENS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to apply the clamp equation to nonoptimized generators (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not clamp nonoptimized generators.
	IVAL = 1	clamp nonoptimized generators.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.7. CONSTRAIN_INTERFACE_FLOWS

Use this API to specify or return the value of the OPF option to constrain interface flows. The setting of this option affects recognition of any interface flow constraints and the behavior of the MINIMIZE_INTERFACE_FLOWS objective function option.

If the Constrain Interface Flows option is not enabled, the Minimize Interface Flows objective and any interface flow constraints will be ignored and not used.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_CONSTRAIN_INTERFACE_FLOWS    IVAL
```

Python command syntax:

```
ierr = constrain_interface_flows(ival)
ierr, ival = constrain_interface_flows()
```

Fortran command syntax:

```
CALL CONSTRAIN_INTERFACE_FLOWS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the option to constrain interface flows (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not constrain interface flows.
	IVAL = 1 constrain interface flows.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.8. FINAL_OPF_BARRIER_COEFF

Use this API to specify or return the value of the final coefficient value that the barrier function is attempting to attain. It may be used in conjunction with the INITIAL_OPF_BARRIER_COEFF value.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_FINAL_OPF_BARRIER_COEFF    RVAL
```

Python command syntax:

```
ierr = final_opf_barrier_coeff(rval)
ierr, rval = final_opf_barrier_coeff()
```

Fortran command syntax:

```
CALL FINAL_OPF_BARRIER_COEFF(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	final barrier coefficient value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.9. IMPORT_ECDI

Use this API to import data from an Economics Dispatch Data File, as prepared for use in activity ECDI, into the OPF working data. This function removes all existing Optimal Power Flow Generator Dispatch Data, Active Power Dispatch Data, and Cost Curve Data, before adding new records from the ECD file.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_IMPORT_ECDI  FILE
```

Python command syntax:

```
ierr = import_ecdi(file)
```

Fortran command syntax:

```
CALL IMPORT_ECDI(FILE, IERR)
```

Where:

Character*260 FILE	name of the Economics Dispatch Data File (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	NEWOPF_API error occurred
	IERR = 2	ECDIAPI error occurred
	IERR = 3	CSTTBL_QUAD_API error occurred
	IERR = 4	OPFDSP_TBL_API error occurred
	IERR = 5	GENDSP_INDV_API error occurred
	IERR = 6	prerequisite requirements for API are not met

3.1.10. INITIAL_OPF_BARRIER_COEFF

Use this API to specify or return the value of the initial OPF barrier coefficient. It may be used in conjunction with the FINAL_OPF_BARRIER_COEFF value.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_INITIAL_OPF_BARRIER_COEFF    RVAL
```

Python command syntax:

```
ierr = initial_opf_barrier_coeff(rval)
ierr, rval = initial_opf_barrier_coeff()
```

Fortran command syntax:

```
CALL INITIAL_OPF_BARRIER_COEFF(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	initial barrier coefficient value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in RVAL.
	IOCODE = 1	return the current value of the option setting in RVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid RVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.11. INTERFACE_FLOW_COST_COEFF

Use this API to specify or return the value of the coefficient for the interface flow objective. This API works in conjunction with the MINIMIZE_INTERFACE_FLOWS objective function option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_INTERFACE_FLOW_COST_COEFF    RVAL
```

Python command syntax:

```
ierr = interface_flow_cost_coeff(rval)

ierr, rval = interface_flow_cost_coeff()
```

Fortran command syntax:

```
CALL INTERFACE_FLOW_COST_COEFF(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the interface flow cost coefficient (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.12. LSTO

Use this API to list OPF working case data in a form suitable for data documentation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LSTO  SID  ALL  OPT  VREV
```

Python command syntax:

```
ierr = lsto(sid, all, opt, vrev)
```

Fortran command syntax:

```
CALL LSTONW(SID, ALL, OPT, VREV, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer OPT	number corresponding to the category of OPF data that is to be tabulated (input; no default allowed). OPT = 1 case summary OPT = 2 bus attribute data OPT = 3 adjustable bus shunt data OPT = 4 bus load data OPT = 5 adjustable bus load table data OPT = 6 generator dispatch data OPT = 7 active power dispatch data OPT = 8 generation reserve data OPT = 9 generator reactive capability data OPT = 10 adjustable branch reactance data OPT = 11 linear cost table data OPT = 12 quadratic cost table data OPT = 13 polynomial and exponential cost table data OPT = 14 period reserve constraint data OPT = 15 branch flow constraint data OPT = 16 interface flow constraint data OPT = 17 linear constraint dependency data OPT = 21 full listing
Integer VREV	option to change voltage units from the default units to the alternate units (input; no default allowed). VREV = 0 use default voltage units.

Integer IERR	VREV = 1	use alternate voltage units.
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 4	invalid VREV value
	IERR = 5	prerequisite requirements for API are not met

3.1.13. MINIMIZE_ADJ_BUS_SHUNTS

Use this API to specify or return the value of the OPF minimize adjustable bus shunts (var compensation) objective function option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_ADJ_BUS_SHUNTS IVAL
```

Python command syntax:

```
ierr = minimize_adj_bus_shunts(ival)
ierr, ival = minimize_adj_bus_shunts()
```

Fortran command syntax:

```
CALL MINIMIZE_ADJ_BUS_SHUNTS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize adjustable bus shunts objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize adjustable bus shunts objective.
	IVAL = 1	enable the minimize adjustable bus shunts objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.14. MINIMIZE_FUEL_COST

Use this API to specify or return the value of the OPF minimize fuel cost objective option. The Minimize fuel cost objective and Minimize active power loss objective cannot be simultaneously employed due to the competing goals.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_FUEL_COST    IVAL
```

Python command syntax:

```
ierr = minimize_fuel_cost(ival)

ierr, ival = minimize_fuel_cost()
```

Fortran command syntax:

```
CALL MINIMIZE_FUEL_COST(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize fuel cost objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize fuel cost objective.
	IVAL = 1	enable the minimize fuel cost objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.15. MINIMIZE_INTERFACE_FLOWS

Use this API to specify or return the value of the OPF minimize interface flows objective option. Used in conjunction with INTERFACE_FLOW_COST_COEFFICIENT. A negative coefficient value will maximize interface flows.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_INTERFACE_FLOWS    IVAL
```

Python command syntax:

```
ierr = minimize_interface_flows(ival)

ierr, ival = minimize_interface_flows()
```

Fortran command syntax:

```
CALL MINIMIZE_INTERFACE_FLOWS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize interface flows objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize interface flows objective.
	IVAL = 1	enable the minimize interface flows objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.16. MINIMIZE_LOAD_ADJUSTMENTS

Use this API to specify or return the value of the OPF minimize adjustable bus load objective option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_LOAD_ADJUSTMENTS IVAL
```

Python command syntax:

```
ierr = minimize_load_adjustments(ival)
ierr, ival = minimize_load_adjustments()
```

Fortran command syntax:

```
CALL MINIMIZE_LOAD_ADJUSTMENTS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize adjustable bus loads objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize adjustable bus loads objective.
	IVAL = 1	enable the minimize adjustable bus loads objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.17. MINIMIZE_P_LOSSES

Use this API to specify or return the value of the OPF minimize active power loss objective option. The Minimize active power loss objective and Minimize fuel cost objective cannot be simultaneously employed due to the competing goals

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_P_LOSSES IVAL
```

Python command syntax:

```
ierr = minimize_p_losses(ival)
ierr, ival = minimize_p_losses()
```

Fortran command syntax:

```
CALL MINIMIZE_P_LOSSES(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize active power loss objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize active power loss objective.
	IVAL = 1	enable the minimize active power loss objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.18. MINIMIZE_P_SLACK

Use this API to specify or return the value of the OPF minimize active power slack objective option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_P_SLACK    IVAL
```

Python command syntax:

```
ierr = minimize_p_slack(ival)

ierr, ival = minimize_p_slack()
```

Fortran command syntax:

```
CALL MINIMIZE_P_SLACK(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize active power slack objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize active power slack objective.
	IVAL = 1	enable the minimize active power slack objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.19. MINIMIZE_Q_LOSSES

Use this API to specify or return the value of the OPF minimize reactive power loss objective option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_Q_LOSSES  IVAL
```

Python command syntax:

```
ierr = minimize_q_losses(ival)
ierr, ival = minimize_q_losses()
```

Fortran command syntax:

```
CALL MINIMIZE_Q_LOSSES(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize reactive power loss objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize reactive power loss objective.
	IVAL = 1	enable the minimize reactive power loss objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.20. MINIMIZE_Q_SLACK

Use this API to specify or return the value of the OPF minimize reactive power slack objective option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_Q_SLACK    IVAL
```

Python command syntax:

```
ierr = minimize_q_slack(ival)
ierr, ival = minimize_q_slack()
```

Fortran command syntax:

```
CALL MINIMIZE_Q_SLACK(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize reactive power slack objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize reactive power slack objective.
	IVAL = 1	enable the minimize reactive power slack objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.21. MINIMIZE_REACTIVE_RESERVE

Use this API to specify or return the value of the OPF minimize reactive reserve objective option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_REACTIVE_RESERVE    IVAL
```

Python command syntax:

```
ierr = minimize_reactive_reserve(ival)
ierr, ival = minimize_reactive_reserve()
```

Fortran command syntax:

```
CALL MINIMIZE_REACTIVE_RESERVE(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize reactive reserves objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize reactive reserves objective.
	IVAL = 1	enable the minimize reactive reserves objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.22. MINIMIZE_SERIES_COMP

Use this API to specify or return the value of the OPF minimize series compensation (adjustable branch reactance) objective option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_MINIMIZE_SERIES_COMP IVAL
```

Python command syntax:

```
ierr = minimize_series_comp(ival)
ierr, ival = minimize_series_comp()
```

Fortran command syntax:

```
CALL MINIMIZE_SERIES_COMP(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the minimize series compensation objective (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not enable the minimize series compensation objective.
	IVAL = 1	enable the minimize series compensation objective.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.23. NOPF

Use this API to run the Optimal Power Flow solution. Subsystems that have been specified will be optimized to the objectives and tolerances specified, if a solution is achievable.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_NOPF    SID  ALL
```

Python command syntax:

```
ierr = nopf(sid, all)
```

Fortran command syntax:

```
CALL NOPF_SOLVE(SID, ALL, IERR)
```

Where:

Integer SID	a valid bus subsystem ID from 0 to 11. A bus subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	error initializing OPF data
	IERR = 4	generators are converted
	IERR = 5	Topology error: buses exist with bus type code and series element status inconsistencies
	IERR = 6	prerequisite requirements for API are not met

3.1.24. OPEN_BUS_VOLTAGE_LIMITS

Use this API to specify or return the value of the OPF solution option to automatically adjust bus voltage limits, making them more open for initial feasibility.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPEN_BUS_VOLTAGE_LIMITS    IVAL
```

Python command syntax:

```
ierr = open_bus_voltage_limits(ival)
ierr, ival = open_bus_voltage_limits()
```

Fortran command syntax:

```
CALL OPEN_BUS_VOLTAGE_LIMITS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to open bus voltage limits for initial feasibility (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not open up bus voltage limits.
	IVAL = 1 open bus voltage limits for initial feasibility.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.25. OPF_BARRIER_STEP_LENGTH

Use this API to specify or return the value of the barrier function step length setting.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_BARRIER_STEP_LENGTH    RVAL
```

Python command syntax:

```
ierr = opf_barrier_step_length(rval)
ierr, rval = opf_barrier_step_length()
```

Fortran command syntax:

```
CALL OPF_BARRIER_STEP_LENGTH(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the barrier function step length (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.26. OPF_CLAMP_DECAY_FACTOR

Use this API to specify or return the value of the clamp equation decay factor. This API works in conjunction with the API option to CLAMP_NONOPTIMIZED_GENS, and is associated with the APIs for OPF_INITIAL_CLAMP_TOL and OPF_FINAL_CLAMP_TOL.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_CLAMP_DECAY_FACTOR    RVAL
```

Python command syntax:

```
ierr = opf_clamp_decay_factor(rval)

ierr, rval = opf_clamp_decay_factor()
```

Fortran command syntax:

```
CALL OPF_CLAMP_DECAY_FACTOR(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the clamp equation decay factor (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).								
Integer IOCODE	Indicates the operation mode of the API (no default allowed). <table> <tr> <td>IOCODE = 0</td><td>set the option setting to value specified in RVAL.</td></tr> <tr> <td>IOCODE = 1</td><td>return the current value of the option setting in RVAL.</td></tr> </table>	IOCODE = 0	set the option setting to value specified in RVAL.	IOCODE = 1	return the current value of the option setting in RVAL.				
IOCODE = 0	set the option setting to value specified in RVAL.								
IOCODE = 1	return the current value of the option setting in RVAL.								
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no error</td></tr> <tr> <td>IERR = 1</td><td>invalid RVAL value</td></tr> <tr> <td>IERR = 2</td><td>invalid IOCODE value</td></tr> <tr> <td>IERR = 3</td><td>prerequisite requirements for API are not met</td></tr> </table>	IERR = 0	no error	IERR = 1	invalid RVAL value	IERR = 2	invalid IOCODE value	IERR = 3	prerequisite requirements for API are not met
IERR = 0	no error								
IERR = 1	invalid RVAL value								
IERR = 2	invalid IOCODE value								
IERR = 3	prerequisite requirements for API are not met								

3.1.27. OPF_FINAL_CLAMP_TOL

Use this API to specify or return the value of the final clamp tolerance. This API works in conjunction with the API option to CLAMP_NONOPTIMIZED_GENS, and is associated with the APIs for OPF_INITIAL_CLAMP_TOL and the OPF_CLAMP_DECAY_FACTOR.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_FINAL_CLAMP_TOL    RVAL
```

Python command syntax:

```
ierr = opf_final_clamp_tol(rval)

ierr, rval = opf_final_clamp_tol()
```

Fortran command syntax:

```
CALL OPF_FINAL_CLAMP_TOL(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the final clamp tolerance (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).								
Integer IOCODE	Indicates the operation mode of the API (no default allowed). <table> <tr> <td>IOCODE = 0</td><td>set the option setting to value specified in RVAL.</td></tr> <tr> <td>IOCODE = 1</td><td>return the current value of the option setting in RVAL.</td></tr> </table>	IOCODE = 0	set the option setting to value specified in RVAL.	IOCODE = 1	return the current value of the option setting in RVAL.				
IOCODE = 0	set the option setting to value specified in RVAL.								
IOCODE = 1	return the current value of the option setting in RVAL.								
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no error</td></tr> <tr> <td>IERR = 1</td><td>invalid RVAL value</td></tr> <tr> <td>IERR = 2</td><td>invalid IOCODE value</td></tr> <tr> <td>IERR = 3</td><td>prerequisite requirements for API are not met</td></tr> </table>	IERR = 0	no error	IERR = 1	invalid RVAL value	IERR = 2	invalid IOCODE value	IERR = 3	prerequisite requirements for API are not met
IERR = 0	no error								
IERR = 1	invalid RVAL value								
IERR = 2	invalid IOCODE value								
IERR = 3	prerequisite requirements for API are not met								

3.1.28. OPF_FIXED_VOLTAGE_PENALTY

Use this API to specify or return the value of the penalty for fixed voltage excursions.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_FIXED_VOLTAGE_PENALTY    RVAL
```

Python command syntax:

```
ierr = opf_fixed_voltage_penalty(rval)
ierr, rval = opf_fixed_voltage_penalty()
```

Fortran command syntax:

```
CALL OPF_FIXED_VOLTAGE_PENALTY(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the penalty for fixed voltage excursions (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.29. OPF_FIX_ALL_GENERATORS

Use this API to specify or return the value of the OPF option to treat all generators as nonoptimized (fixed).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_FIX_ALL_GENERATORS    IVAL
```

Python command syntax:

```
ierr = opf_fix_all_generators(ival)
ierr, ival = opf_fix_all_generators()
```

Fortran command syntax:

```
CALL OPF_FIX_ALL_GENERATORS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the option to treat all generators as nonoptimized and fix their settings (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not treat all generators as nonoptimized.
	IVAL = 1 treat all generators as nonoptimized.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.30. OPF_FIX_PHASE_SHIFTERS

Use this API to specify or return the value of the OPF option to fix transformer phase shift angle settings.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_FIX_PHASE_SHIFTERS    IVAL
```

Python command syntax:

```
ierr = opf_fix_phase_shifters(ival)
ierr, ival = opf_fix_phase_shifters()
```

Fortran command syntax:

```
CALL OPF_FIX_PHASE_SHIFTERS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the option to fix transformer phase shift angles (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not fix transformer phase shift angle settings.
	IVAL = 1	fix transformer phase shift angle settings.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.31. OPF_FIX_SWITCHED_SHUNTS

Use this API to specify or return the value of the OPF option to fix switched shunt settings.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_FIX_SWITCHED_SHUNTS    IVAL
```

Python command syntax:

```
ierr = opf_fix_switched_shunts(ival)

ierr, ival = opf_fix_switched_shunts()
```

Fortran command syntax:

```
CALL OPF_FIX_SWITCHED_SHUNTS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the option to fix switched shunt settings (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not fix switched shunt settings.
	IVAL = 1 fix switched shunt settings.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.32. OPF_FIX_TAP_RATIOS

Use this API to specify or return the value of the OPF option to fix transformer tap ratio settings.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_FIX_TAP_RATIOS    IVAL
```

Python command syntax:

```
ierr = opf_fix_tap_ratios(ival)
ierr, ival = opf_fix_tap_ratios()
```

Fortran command syntax:

```
CALL OPF_FIX_TAP_RATIOS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the option to fix transformer tap ratio settings (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not fix transformer tap ratio settings.
	IVAL = 1	fix transformer tap ratio settings.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.33. OPF_INITIAL_CLAMP_TOL

Use this API to specify or return the value of the initial clamp tolerance. This API works in conjunction with the API option to CLAMP_NONOPTIMIZED_GENS, and is associated with the APIs for OPF_FINAL_CLAMP_TOL and the OPF_CLAMP_DECAY_FACTOR.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_INITIAL_CLAMP_TOL    RVAL
```

Python command syntax:

```
ierr = opf_initial_clamp_tol(rval)
ierr, rval = opf_initial_clamp_tol()
```

Fortran command syntax:

```
CALL OPF_INITIAL_CLAMP_TOL(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the initial clamp tolerance (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.34. OPF_INTERIOR_SHIFT_FACTOR

Use this API to specify or return the value of the interior shift factor multiplier. This value indicates by how much a variable should be moved "more interior" of the upper and lower limits.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPF_INTERIOR_SHIFT_FACTOR    RVAL
```

Python command syntax:

```
ierr = opf_interior_shift_factor(rval)
ierr, rval = opf_interior_shift_factor()
```

Fortran command syntax:

```
CALL OPF_INTERIOR_SHIFT_FACTOR(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	interior shift factor multiplier value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in RVAL.
	IOCODE = 1	return the current value of the option setting in RVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid RVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.35. OPF_LAMBDA_TOLERANCE

Use this API to specify or return the value of the Lagrange multiplier blow-up tolerance during an optimal power flow solution.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_LAMBDA_TOLERANCE    RVAL
```

Python command syntax:

```
ierr = opf_lambda_tolerance(rval)

ierr, rval = opf_lambda_tolerance()
```

Fortran command syntax:

```
CALL OPF_LAMBDA_TOLERANCE(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	lambda tolerance value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in RVAL.
	IOCODE = 1	return the current value of the option setting in RVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid RVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.36. OPF_LF_CONTROL_PENALTY

Use this API to specify or return the value of the quadratic penalty for loadflow controls. This penalty is applied to optimized loadflow control variable excursions from their initial condition, in \$/pu.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_LF_CONTROL_PENALTY    RVAL
```

Python command syntax:

```
ierr = opf_lf_control_penalty(rval)
ierr, rval = opf_lf_control_penalty()
```

Fortran command syntax:

```
CALL OPF_LF_CONTROL_PENALTY(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the quadratic penalty for loadflow controls (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.37. OPF_MAX_TAP_RATIO_STEP

Use this API to specify or return the value of the maximum transformer tap ratio step.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_MAX_TAP_RATIO_STEP    RVAL
```

Python command syntax:

```
ierr = opf_max_tap_ratio_step(rval)

ierr, rval = opf_max_tap_ratio_step()
```

Fortran command syntax:

```
CALL OPF_MAX_TAP_RATIO_STEP(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	maximum tap ratio step value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.38. OPF_MIN_TAP_RATIO_STEP

Use this API to set or return the value of the minimum transformer tap ratio step.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_MIN_TAP_RATIO_STEP    RVAL
```

Python command syntax:

```
ierr = opf_min_tap_ratio_step(rval)

ierr, rval = opf_min_tap_ratio_step()
```

Fortran command syntax:

```
CALL OPF_MIN_TAP_RATIO_STEP(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	minimum tap ratio step value (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.39. OPF_REGULATE_AREA_INT

Use this API to set or return the value of the OPF option to regulate area interchange.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_REGULATE_AREA_INT    IVAL
```

Python command syntax:

```
ierr = opf_regulate_area_int(ival)
ierr, ival = opf_regulate_area_int()
```

Fortran command syntax:

```
CALL OPF_REGULATE_AREA_INT(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to enable the option to regulate area interchange (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output). IVAL = 0 do not regulate area interchange. IVAL = 1 regulate area interchange.
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in IVAL. IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid IVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.40. OPF_ROUND_SWITCHED_SHUNTS

Use this API to set or return the value of the OPF solution option to discretize switched shunts.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_ROUND_SWITCHED_SHUNTS    IVAL
```

Python command syntax:

```
ierr = opf_round_switched_shunts(ival)
ierr, ival = opf_round_switched_shunts()
```

Fortran command syntax:

```
CALL OPF_ROUND_SWITCHED_SHUNTS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to discretize switched shunt settings after initial solution. (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not discretize switched shunt settings.
	IVAL = 1	discretize switched shunt settings.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.41. OPF_ROUND_TAP_RATIOS

Use this API to set or return the value of the OPF solution option to round transformer tap ratio settings.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_ROUND_TAP_RATIOS    IVAL
```

Python command syntax:

```
ierr = opf_round_tap_ratios(ival)
ierr, ival = opf_round_tap_ratios()
```

Fortran command syntax:

```
CALL OPF_ROUND_TAP_RATIOS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to round transformer tap ratio settings (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not round transformer tap ratio settings.
	IVAL = 1 round transformer tap ratio settings.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.42. OPF_SCALE_QGEN_LIMITS

Use this API to set or return the value of the OPF option to scale reactive generation limits in the clamped constraint equation.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_SCALE_QGEN_LIMITS    IVAL
```

Python command syntax:

```
ierr = opf_scale_qgen_limits(ival)
ierr, ival = opf_scale_qgen_limits()
```

Fortran command syntax:

```
CALL OPF_SCALE_QGEN_LIMITS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to scale reactive generation limits in the clamp equation (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not scale reactive generation limits.
	IVAL = 1	scale reactive generation limits.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.43. OPF_STEP_LENGTH_TOLERANCE

Use this API to set or return the value of the OPF minimum barrier step length tolerance.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_STEP_LENGTH_TOLERANCE    RVAL
```

Python command syntax:

```
ierr = opf_step_length_tolerance(rval)
ierr, rval = opf_step_length_tolerance()
```

Fortran command syntax:

```
CALL OPF_STEP_LENGTH_TOLERANCE(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the minimum barrier step length tolerance (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.44. OPF_USE_GENERATOR_VSCHED

Use this API to set or return the value of the OPF option to employ the generator scheduled voltage.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPF_USE_GENERATOR_VSCHED    IVAL
```

Python command syntax:

```
ierr = opf_use_generator_vsched(ival)
ierr, ival = opf_use_generator_vsched()
```

Fortran command syntax:

```
CALL OPF_USE_GENERATOR_VSCHED(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to use generator scheduled voltage values (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
	IVAL = 0 do not use generator scheduled voltages.
	IVAL = 1 use generator scheduled voltages.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.45. OPTO

Please use the individual OPF option setting API's described in this section.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPTO  SID  ALL  IARY(1) .. IARY(36)  RARY(1) .. RARY(19)  OPFILE
RCFILE
```

Python command syntax:

```
ierr = opto(sid, all, iary, rary, opfile, rcfile)
```

Fortran command syntax:

```
CALL OPTONW(SID, ALL, IARY, RARY, OPFILE, RCFILE, IERR)
```

Where:

Integer SID	a valid bus subsystem ID from 0 to 11. A bus subsystem must have been previously defined (input).
Integer ALL	all buses or specified subsystem flag (input). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer IARY (36)	array of 36 elements specifying 36 integers, which are defined as follows(input). IARY(1) specifies the fuel cost objective IARY(1) = 0 do not employ minimize fuel cost objective IARY(1) = 1 employ the minimize fuel cost objective IARY(2) specifies the active power slack bus generation objective IARY(2) = 0 do not employ minimize active power slack bus generation objective IARY(2) = 1 employ the minimize active power slack bus generation objective IARY(3) specifies the reactive power slack generation objective IARY(3) = 0 do not employ the minimize reactive power slack generation objective IARY(3) = 1 employ the minimize reactive power slack generation objective IARY(4) specifies the active power loss objective IARY(4) = 0 do not employ the minimize active power loss objective IARY(4) = 1 employ the minimize active power loss objective IARY(5) specifies the reactive power loss objective IARY(5) = 0 do not employ the minimize reactive power loss objective

IARY(5) = 1	employ the minimize reactive power loss objective
IARY(6)	specifies the adjustable branch reactance (series compensation) objective
IARY(6) = 0	do not employ the minimize adjustable branch reactance objective
IARY(6) = 1	employ the minimize adjustable branch reactance objective
IARY(7)	specifies the adjustable bus shunt (var compensation) objective
IARY(7) = 0	do not employ the minimize adjustable bus shunt objective
IARY(7) = 1	employ the minimize adjustable bus shunt objective
IARY(8)	specifies the adjustable bus load (load shedding/increase) objective
IARY(8) = 0	do not employ the adjustable bus load objective
IARY(8) = 1	employ the adjustable bus load objective
IARY(9)	specifies the interface flow objective
IARY(9) = 0	do not employ the interface flow objective
IARY(9) = 1	employ the interface flow objective
IARY(10)	specifies the reactive generation reserve objective
IARY(10) = 0	do not employ the reactive generation reserve objective
IARY(10) = 1	employ the reactive generation reserve objective
IARY(11)	specifies whether to apply the power flow mismatch tolerance to the dual variable problem
IARY(11) = 0	apply tolerance to the mismatch equation only
IARY(11) = 1	apply tolerance to the entire equation
IARY(12)	specifies whether to apply the clamp equation to nonoptimized generators
IARY(12) = 0	do not clamp nonoptimized generators
IARY(12) = 1	clamp nonoptimized generators
IARY(13)	specifies whether to apply the clamp equation to nonoptimized transformers. (Not currently functional)
IARY(13) = 0	do not clamp nonoptimized transformers
IARY(13) = 1	clamp nonoptimized transformers
IARY(14)	specifies whether to constrain interface flows
IARY(14) = 0	do not constrain interface flows

IARY(14) = 1	constrain interface flows
IARY(15)	specifies whether to employ automatic scaling of the objective
IARY(15) = 0	do not employ automatic scaling
IARY(15) = 1	employ automatic scaling
IARY(16)	specifies whether to regulate area interchange
IARY(16) = 0	do not regulate area interchange
IARY(16) = 1	regulate area interchange
IARY(17)	specifies whether to fix transformer tap ratio settings
IARY(17) = 0	do not fix transformer tap ratio settings
IARY(17) = 1	fix transformer tap ratio settings
IARY(18)	specifies whether to fix transformer phase shift angles
IARY(18) = 0	do not fix transformer phase shift angles
IARY(18) = 1	fix transformer phase shift angles
IARY(19)	specifies whether to fix switched shunt settings
IARY(19) = 0	do not fix switched shunt settings
IARY(19) = 1	fix switched shunt settings
IARY(20)	specifies whether to treat all generators as nonoptimized
IARY(20) = 0	do not treat all generators as nonoptimized
IARY(20) = 1	treat all generators as nonoptimized
IARY(21)	specifies whether to employ the generator scheduled voltage
IARY(21) = 0	do not employ generator scheduled voltage
IARY(21) = 1	use generator scheduled voltage
IARY(22)	specifies whether to scale reactive generation limits on clamped constraint equations
IARY(22) = 0	do not scale reactive generation limits
IARY(22) = 1	scale reactive generation limits
IARY(23)	specifies whether to round transformer tap settings
IARY(23) = 0	do not round transformer tap settings
IARY(23) = 1	round transformer tap settings
IARY(24)	specifies whether to round switched shunt settings
IARY(24) = 0	do not round switched shunt settings
IARY(24) = 1	round switched shunt settings
IARY(25)	specifies whether to limit the step size taken during solution
IARY(25) = 0	do not limit the step size
IARY(25) = 1	limit the step size taken

IARY(26)	specifies whether to produce an optimization log file
IARY(26) = 0	do not produce an optimization log file
IARY(26) = 1	produce an optimization log file
IARY(27)	specifies whether to include a detailed listing of Lagrange multipliers in the optimization log file. IARY(26) must be set to 1 for this to take effect
IARY(27) = 0	do not print details
IARY(27) = 1	print Lagrange multipliers
IARY(28)	specifies whether to produce a PSSE raw data change file. (Not currently functional)
IARY(28) = 0	do not produce an Read/Change File
IARY(28) = 1	produce an Read/Change File
IARY(29)	specifies whether to save the OPF solution option settings to the OPF Options File, PSSOPF.OPT
IARY(29) = 0	do not save settings
IARY(29) = 1	save settings to PSSOPF.OPT
IARY(30)	indicates whether the program should open voltage limits to ensure an initial feasible condition
IARY(30) = 0	do not have the program open the limits for an initial feasible condition
IARY(30) = 1	have the program open the limits for an initial feasible condition
IARY(31)	specifies whether to impose emergency bus voltage limits or normal bus voltage limits
IARY(31) = 0	impose normal voltage limits
IARY(31) = 1	impose emergency bus voltage limits
IARY(32)	specifies whether to impose emergency branch flow limits or normal branch flow limits
IARY(32) = 0	impose normal branch flow limits
IARY(32) = 1	impose emergency branch flow limits
IARY(33)	specifies whether to include transformer adjustment data in the Read/Change File (if one is produced according to the setting of IARY(28)). (Not currently functional)
IARY(33) = 0	do not include transformer adjustment data
IARY(33) = 1	include transformer adjustment data
IARY(34)	specifies the maximum iteration limit (corresponds to ITMXN of the power flow solution parameters)
IARY(35)	specifies the bad iteration coarse limit
IARY(36)	specifies the bad iteration fine limit

Real RARY (19)	array of 19 elements specifying which are defined as follows(input).
RARY(1)	specifies the initial barrier function coefficient
RARY(2)	specifies the final barrier function coefficient
RARY(3)	specifies the step length blow-up tolerance
RARY(4)	specifies the final clamp equation tolerance value
RARY(5)	specifies the initial clamp equation tolerance value
RARY(6)	specifies the clamp equation decay factor
RARY(7)	specifies the cost coefficient for the active power loss objective
RARY(8)	specifies the cost coefficient for the reactive power loss objective
RARY(9)	specifies the penalty value for power flow controls
RARY(10)	specifies the cost coefficient for the interface flow objective
RARY(11)	specifies the cost coefficient for the reactive generation reserve objective
RARY(12)	specifies the penalty value for fixed voltage
RARY(13)	specifies the lambda (Lagrange multiplier) blow-up tolerance
RARY(14)	specifies the minimum amount to open up tap settings by
RARY(15)	specifies the maximum amount to open up tap settings by
RARY(16)	specifies the amount to shift the interior point by during solution
RARY(17)	specifies the step length taken for the barrier method
RARY(18)	specifies the tolerance value used to determine which bus shunts get added to the Read/Change File as switched shunts (if an RDCH file is produced according to IARY(28) and the minimize added vars objective is employed according to IARY(7)). (Not currently functional)
RARY(19)	specifies the solution convergence tolerance, in MVA (corresponds to TOLN of the power flow solution parameters)
Character*260 OPFILE	name of the OPF Optimization Log File that will be produced if IARY(26) is set to 1. It is a good idea to specify the filename in quotes (input).

Character*260 RCFILE	name of the PTI Read Change Data File that will be produced if IARY(28) is set to 1. It is a good idea to specify the filename in quotes. (Not currently functional) (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid IARY value
	IERR = 4	invalid RARY value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

3.1.46. PRODUCE_OPF_LOG_FILE

Use this API to set or return the value of the OPF solution option to produce an OPF solution log file, and if so, the name of the log file. This API can be used in conjunction with the ADD_DETAILS_TO_OPF_LOG API if additional details of the Lagrange multipliers are desired.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PRODUCE_OPF_LOG_FILE    IVAL    OFILE
```

Python command syntax:

```
ierr = produce_opf_log_file(ival, ofile)

ierr, ival, ofile = produce_opf_log_file()
```

Fortran command syntax:

```
CALL PRODUCE_OPF_LOG_FILE(IVAL, IOCODE, OFILE, IERR)
```

Where:

Integer IVAL	Indicates whether to produce an OPF Optimization Log File (input; if Batch command or for Python if specified as an argument, or for Fortran if IOCODE is 0; else 0 by default for input).
	IVAL = 0 do not produce an OPF solution log file.
	IVAL = 1 produce an OPF solution log file.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).
	IOCODE = 0 set the option setting to value specified in IVAL.
	IOCODE = 1 return the current value of the option setting in IVAL.
Character*260 OFILE	OPF Optimization Log output filename (input; if Batch command or for Python if specified as an argument, or for FORTRAN if IOCODE is 0; else DETAIL.DAT by default for input).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IVAL value
	IERR = 2 invalid IOCODE value
	IERR = 3 prerequisite requirements for API are not met

3.1.47. P_LOSSES_COST_COEFF

Use this API to set or return the value of the coefficient for the active power loss objective (OPF Solution Options). This API works in conjunction with the MINIMIZE_P_LOSSES objective function option.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_P_LOSSES_COST_COEFF    RVAL
```

Python command syntax:

```
ierr = p_losses_cost_coeff(rval)
ierr, rval = p_losses_cost_coeff()
```

Fortran command syntax:

```
CALL P_LOSSES_COST_COEFF(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the active power loss cost coefficient (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).								
Integer IOCODE	Indicates the operation mode of the API (no default allowed). <table> <tr> <td>IOCODE = 0</td><td>set the option setting to value specified in RVAL.</td></tr> <tr> <td>IOCODE = 1</td><td>return the current value of the option setting in RVAL.</td></tr> </table>	IOCODE = 0	set the option setting to value specified in RVAL.	IOCODE = 1	return the current value of the option setting in RVAL.				
IOCODE = 0	set the option setting to value specified in RVAL.								
IOCODE = 1	return the current value of the option setting in RVAL.								
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no error</td></tr> <tr> <td>IERR = 1</td><td>invalid RVAL value</td></tr> <tr> <td>IERR = 2</td><td>invalid IOCODE value</td></tr> <tr> <td>IERR = 3</td><td>prerequisite requirements for API are not met</td></tr> </table>	IERR = 0	no error	IERR = 1	invalid RVAL value	IERR = 2	invalid IOCODE value	IERR = 3	prerequisite requirements for API are not met
IERR = 0	no error								
IERR = 1	invalid RVAL value								
IERR = 2	invalid IOCODE value								
IERR = 3	prerequisite requirements for API are not met								

3.1.48. Q_LOSSES_COST_COEFF

Use this API to set or return the value of the coefficient for the reactive power loss objective. This API works in conjunction with the API option to MINIMIZE_Q_LOSSES.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_Q_LOSSES_COST_COEFF  RVAL
```

Python command syntax:

```
ierr = q_losses_cost_coeff(rval)
ierr, rval = q_losses_cost_coeff()
```

Fortran command syntax:

```
CALL Q_LOSSES_COST_COEFF(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the reactive power loss cost coefficient (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.49. REACTIVE_RESV_COST_COEFF

Use this API to set or return the value of the coefficient for the reactive reserve objective. This API works in conjunction with the API option to MINIMIZE_REACTIVE_RESERVE.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_REACTIVE_RESV_COST_COEFF    RVAL
```

Python command syntax:

```
ierr = reactive_resv_cost_coeff(rval)
ierr, rval = reactive_resv_cost_coeff()
```

Fortran command syntax:

```
CALL REACTIVE_RESV_COST_COEFF(RVAL, IOCODE, IERR)
```

Where:

Real RVAL	value of the reactive reserve cost coefficient (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).
Integer IOCODE	Indicates the operation mode of the API (no default allowed). IOCODE = 0 set the option setting to value specified in RVAL. IOCODE = 1 return the current value of the option setting in RVAL.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid RVAL value IERR = 2 invalid IOCODE value IERR = 3 prerequisite requirements for API are not met

3.1.50. ROPF

Use this API to read an Optimal Power Flow Raw Data File.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ROPF    RFILE
```

Python command syntax:

```
ierr = ropf(rfile)
```

Fortran command syntax:

```
CALL ROPFNW(RFILE, IERR)
```

Where:

Character*260 RFILE

Optimal Power Flow Data File name, or '1' if is coming directly from the terminal or Response file (input; no default allowed).

Integer IERR

error code (output).

IERR = 0

no error

IERR = 1

error opening file

IERR = 2

prerequisite requirements for API are not met

3.1.51. RWOP

Use this API to replicate the OPF data contained in the working case in the form of an Optimal Power Flow Data File.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RWOP  SID  ALL  STATUS(1)..STATUS(4)  OUT  OFILE
```

Python command syntax:

```
ierr = rwop(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL RWOPNW(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid bus subsystem ID from 0 to 11. A bus subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified buses subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer STATUS (4)	array of 4 elements specifying Specifies whether to use various control options. A value of 0 means the option is not enabled. A value of 1 means the option is enabled.(input). STATUS(1) include isolated buses STATUS(2) include out-of-service branches STATUS(3) include subsystem data STATUS(4) include subsystem tie lines
Integer OUT	option selection (input; no default allowed). OUT = 0 direct output to a data file specified by OFILE. OUT = 1 direct output to the current report device.
Character*260 OFILE	output filename (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS(n) value IERR = 4 invalid OUT value IERR = 5 error opening OFILE IERR = 6 prerequisite requirements for API are not met

3.1.52. SET_OPF_REPORT_SUBSYSTEM

Use this API to define the subsystem to be used when producing the opf output report. The records contained in the report will be limited to just the equipment residing within the defined subsystem. This includes bounded and infeasible reactive power generation, regulated buses, transformer tap ratios, transformer phase shift angles and bounded switched shunts.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SET_OPF_REPORT_SUBSYSTEM  OSID ALL
```

Python command syntax:

```
ierr = set_opf_report_subsystem(osid, all)
```

Fortran command syntax:

```
CALL SET_OPF_REPORT_SUBSYSTEM(OSID, ALL, IERR)
```

Where:

Integer OSID	Indicates the previously defined subsystem number to be used for the opf report (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.1.53. USE_DUAL_CRITERIA

Use this API to set or return the value of the OPF solution option to apply the power flow mismatch tolerance to the dual variable problem.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_USE_DUAL_CRITERIA    IVAL
```

Python command syntax:

```
ierr = use_dual_criteria(ival)

ierr, ival = use_dual_criteria()
```

Fortran command syntax:

```
CALL USE_DUAL_CRITERIA(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to apply the power flow mismatch tolerance to the dual variable problem (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	apply tolerance to the mismatch equation only.
	IVAL = 1	apply tolerance to the entire equation.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.54. USE_EMERGENCY_FLOW_LIMITS

Use this API to set or return the value of the OPF solution option to impose the emergency flow limits instead of the normal flow limits.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_USE_EMERGENCY_FLOW_LIMITS    IVAL
```

Python command syntax:

```
ierr = use_emergency_flow_limits(ival)

ierr, ival = use_emergency_flow_limits()
```

Fortran command syntax:

```
CALL USE_EMERGENCY_FLOW_LIMITS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to use the emergency flow limits instead of the normal bus voltage limits (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not impose the emergency flow limits (normal flow limits will be imposed).
	IVAL = 1	impose emergency flow limits.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.55. USE_EMERGENCY_VOLT_LIMITS

Use this API to set or return the value of the OPF solution option to impose the emergency bus voltage limits instead of the normal bus voltage limits.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_USE_EMERGENCY_VOLT_LIMITS    IVAL
```

Python command syntax:

```
ierr = use_emergency_volt_limits(ival)

ierr, ival = use_emergency_volt_limits()
```

Fortran command syntax:

```
CALL USE_EMERGENCY_VOLT_LIMITS(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	Indicates whether to use the emergency bus voltage limits instead of the normal bus voltage limits (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, then input of 0 by default; else output).	
	IVAL = 0	do not impose the emergency bus voltage limits (normal voltage limits will be imposed).
	IVAL = 1	impose emergency bus voltage limits.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

3.1.56. WRITE_OPF_OPTIONS_FILE

Use this API to save the PSSE OPF solution option settings to the PSSOPF.OPT file.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_WRITE_OPF_OPTIONS_FILE
```

Python command syntax:

```
ierr = write_opf_options_file()
```

Fortran command syntax:

```
CALL WRITE_OPF_OPTIONS_FILE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

Optimal Power Flow Operation APIs contains API routines corresponding to the operational functions of the PSS®E OPF.

3.2. Optimal Power Flow Data

3.2.1. NEWOPF

Use this API to initialize the working case with default OPF data for all bus oriented data records. It must be called prior to introducing any OPF data records. It has no effect if OPF data already exists in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_NEWOPF
```

Python command syntax:

```
ierr = newopf()
```

Fortran command syntax:

```
CALL NEWOPF_API(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

3.2.2. OPF_ADJBRX_INDV

Use this API to add an individual adjustable branch reactance data record to the working case. It may also be used to modify an existing adjustable branch reactance data record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_ADJBRX_INDV  EIBUS  EJBUS  CKTID  INTGAR(1) .. INTGAR(3)
REALAR(1) .. REALAR(4)
```

Python command syntax:

```
ierr = opf_adjbrx_indv(eibus, ejbus, cktid, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_ADJBRX_INDV(EIBUS, EJBUS, CKTID, INTGAR, REALAR, IERR)
```

Where:

Integer EIBUS	from bus number (input; no default allowed).
Integer EJBUS	to bus number (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Integer INTGAR (3)	array of 3 elements specifying (input).
	INTGAR(1) cost curve type. This value is not currently used by the program
	INTGAR(1) = 1 polynomial and exponential cost curve
	INTGAR(1) = 2 linear cost curve
	INTGAR(1) = 3 quadratic cost curve
	INTGAR(2) adjustable branch reactance status (default of 1 if new record, current value otherwise)
	INTGAR(2) = 0 out of service
	INTGAR(2) = 1 in service
	INTGAR(3) cost table cross reference number. This value is not currently used by the program
Real REALAR (4)	array of 4 elements specifying (input).
	REALAR(1) reactance multiplier in pu (default value of 1.0 if new record, current value otherwise)
	REALAR(2) maximum reactance multiplier in pu (default value of 1.0 if new record, current value otherwise)
	REALAR(3) minimum reactance multiplier in pu (default value of 1.0 if new record, current value otherwise)
	REALAR(4) cost scale coefficient in \$/pu (default value of 1.0 if new record, current value otherwise)
Integer IERR	error code (output).

IERR = -1	non-fatal error occurred. Warning messages are as follows: - Invalid cost curve type specified - Invalid branch reactance status specified. - Maximum branch reactance multiplier less than minimum multiplier - Branch reactance multiplier cannot be less than 0.1. - Branch reactance multiplier cannot be set to zero
IERR = 0	no error occurred
IERR = 1	invalid bus number
IERR = 2	specified branch does not exist
IERR = 3	branch reactance table full
IERR = 4	specified branch cannot be a transformer
IERR = 5	prerequisite requirements for API are not met

3.2.3. OPF_ADJBRX_SUBSYS

Use this API to add or modify all OPF branch reactance data records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_ADJBRX_SUBSYS  SID  ALL  INTGAR(1) .. INTGAR(3)
                        REALAR(1) .. REALAR(4)  USEVAL(1) .. USEVAL(4)
```

Python command syntax:

```
ierr = opf_adjbrx_subsys(sid, all, intgar, realar, useval)
```

Fortran command syntax:

```
CALL OPF_ADJBRX_SUBSYS(SID, ALL, INTGAR, REALAR, USEVAL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer INTGAR (3)	array of 3 elements specifying (input). INTGAR(1) cost curve type. This value is not currently used by the program INTGAR(1) = 1 polynomial and exponential cost curve INTGAR(1) = 2 linear cost curve INTGAR(1) = 3 quadratic cost curve INTGAR(2) adjustable branch reactance status (default value of 1 for new records, current values otherwise) INTGAR(2) = 0 out of service INTGAR(2) = 1 in service INTGAR(3) cost table cross reference number. This value is not currently used by the program
Real REALAR (4)	array of 4 elements specifying (input). REALAR(1) reactance multiplier in pu (default value of 1.0 for new records, current value otherwise) REALAR(2) maximum reactance multiplier in pu (default value of 1.0 for new records, current value otherwise) REALAR(3) minimum reactance multiplier in pu (default value of 1.0 for new records, current value otherwise)

	REALAR(4)	cost scale coefficient in \$/pu (default value of 1.0 for new records, current value otherwise)
Integer USEVAL (4)	array of 4 elements specifying (default treatment same as value of 0) (input).	
	USEVAL(1)	indicates how the value of REALAR(1) should be used
	USEVAL(1) = 0	if the value of REALAR(1) is to be used as defined
	USEVAL(1) = 1	if the value of REALAR(1) is to be multiplied by the present value of the branch reactance multiplier
	USEVAL(1) = 2	if the value of REALAR(1) is to be added to the present value of the branch reactance multiplier
	USEVAL(2)	indicates how the value of REALAR(2) should be used
	USEVAL(2) = 0	if the value of REALAR(2) is to be used as defined
	USEVAL(2) = 1	if the value of REALAR(2) is to be multiplied by the present value of the maximum branch reactance multiplier
	USEVAL(2) = 2	if the value of REALAR(2) is to be added to the present value of the maximum branch reactance multiplier
	USEVAL(3)	indicates how the value of REALAR(3) should be used
	USEVAL(3) = 0	if the value of REALAR(3) is to be used as defined
	USEVAL(3) = 1	if the value of REALAR(3) is to be multiplied by the present value of the minimum branch reactance multiplier
	USEVAL(3) = 2	if the value of REALAR(3) is to be added to the present value of the minimum branch reactance multiplier
	USEVAL(4)	indicates how the value of REALAR(4) should be used
	USEVAL(4) = 0	if the value of REALAR(4) is to be used as defined
	USEVAL(4) = 1	if the value of REALAR(4) is to be multiplied by the present value of the cost scale coefficient
	USEVAL(4) = 2	if the value of REALAR(4) is to be added to the present value of the cost scale coefficient
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Warning messages are as follows: - Invalid cost curve spec-

	ified - Invalid branch reactance status specified. - Maximum branch reactance multiplier less than minimum multiplier - Branch reactance multiplier cannot be less than 0.1. - Branch reactance multiplier cannot be set to zero
IERR = 0	no error occurred
IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	adjustable branch reactance table is full
IERR = 4	prerequisite requirements for API are not met

3.2.4. OPF_ADJLOAD_TBL

Use this API to add an individual adjustable bus load table record to the working case. It may also be used to modify an existing adjustable bus load table record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_ADJLOAD_TBL   TBL   INTGAR(1) .. INTGAR(3)   REALAR(1) .. REALAR(7)
```

Python command syntax:

```
ierr = opf_adjload_tbl(tbl, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_ADJLOAD_TBL(TBL, INTGAR, REALAR, IERR)
```

Where:

Integer TBL	adjustable bus load table number (input; no default allowed).
Integer INTGAR (3)	array of 3 elements specifying (input).
	INTGAR(1) cost curve type. This value is not currently used by the program
	INTGAR(1) = 1 polynomial and exponential cost curve
	INTGAR(1) = 2 linear cost curve
	INTGAR(1) = 3 quadratic cost curve
	INTGAR(2) adjustable bus load status (default of 1 if new record, current value otherwise)
	INTGAR(2) = 0 out of service
	INTGAR(2) = 1 in service
	INTGAR(3) cost table cross reference number. This value is not currently used by the program
Real REALAR (7)	array of 7 elements specifying (input).
	REALAR(1) load multiplier (default value of 1.0 if new record, current value otherwise)
	REALAR(2) maximum load multiplier (default value of 1.0 if new record, current value otherwise)
	REALAR(3) minimum load multiplier (default value of 1.0 if new record, current value otherwise)
	REALAR(4) load ratio multiplier. This value is not currently used by the program
	REALAR(5) maximum load ratio multiplier. This value is not currently used by the program
	REALAR(6) minimum load ratio multiplier. This value is not currently used by the program
	REALAR(7) load cost scale coefficient (default value of 1.0 if new record, current value otherwise)

Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Warning messages are as follows: - invalid cost curve type specified - invalid load table status specified - Maximum load multiplier less than 0.0 - Minimum load multiplier less than 0.0 - maximum load multiplier less than minimum load multiplier - maximum load ratio multiplier less than minimum load ratio multiplier
	IERR = 0	no error occurred
	IERR = 1	adjustable bus load table is full
	IERR = 2	prerequisite requirements for API are not met

3.2.5. OPF_ADJVAR_INDV

This API routine is obsolete. It has been replaced by the API routine [opf_adjvar_indv_2](#).

Use this API to add an individual OPF adjustable bus shunt data record to the working case. It may also be used to modify an existing adjustable bus shunt data record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_ADJVAR_INDV  EIBUS  SHNTID  INTGAR(1) .. INTGAR(3)
REALAR(1) .. REALAR(4)
```

Python command syntax:

```
ierr = opf_adjvar_indv(eibus, shntid, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_ADJVAR_INDV(EIBUS, SHNTID, INTGAR, REALAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 SHNTID	bus shunt identifier (input; no default allowed).
Integer INTGAR (3)	array of 3 elements specifying The value of each is as follows(input).
	INTGAR(1) cost curve type. This value is not currently used by the program
	INTGAR(1) = 1 polynomial and exponential cost curve
	INTGAR(1) = 2 linear cost curve
	INTGAR(1) = 3 quadratic cost curve
	INTGAR(2) status (default value of 1 if new record, current value otherwise)
	INTGAR(2) = 0 out of service
	INTGAR(2) = 1 in service
	INTGAR(3) cost table cross reference number. This value is not currently used by the program
Real REALAR (4)	array of 4 elements specifying (input).
	REALAR(1) initial bus shunt susceptance in Mvar at nominal voltage (default value of 0.0 if new record, current value otherwise)
	REALAR(2) maximum bus shunt susceptance in Mvar (default value of 0.0 if new record, current value otherwise)
	REALAR(3) minimum bus shunt susceptance in Mvar (default value of 0.0 if new record, current value otherwise)

	REALAR(4)	cost scale coefficient in \$/Mvar (default value of 1.0 if new record, current value otherwise)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Possible warning messages are as follows: - Invalid cost curve type specified. - Invalid adjustable bus shunt status specified. - Maximum shunt susceptance less than minimum shunt susceptance
	IERR = 0	no error occurred
	IERR = 1	adjustable bus shunt identifier is more than two characters
	IERR = 2	invalid bus number specified
	IERR = 3	blank adjustable bus shunt identifier is invalid
	IERR = 4	adjustable bus shunt table is full
	IERR = 5	prerequisite requirements for API are not met

3.2.6. OPF_ADJVAR_INDV_2

Use this API to add an individual OPF adjustable bus shunt data record to the working case. It may also be used to modify an existing adjustable bus shunt data record.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_OPF_ADJVAR_INDV_2  EIBUS  ENOD SHNTID  INTGAR(1)..INTGAR(3)
REALAR(1)..REALAR(4)
```

Python command syntax:

```
ierr = opf_adjvar_indv_2(eibus, enod, shntid, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_ADJVAR_INDV_2(EIBUS, ENOD, SHNTID, INTGAR, REALAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).																
Integer ENOD	Bus section number of the node number of one of the nodes in the bus section of interest. 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, the bus data of the parent bus and not that of one of the topology bus sections will be changed. (input; no default allowed).																
Character*2 SHNTID	bus shunt identifier (input; no default allowed).																
Integer INTGAR (3)	array of 3 elements specifying The value of each is as follows(input). <table border="0"> <tr> <td>INTGAR(1)</td><td>cost curve type. This value is not currently used by the program</td></tr> <tr> <td>INTGAR(1) = 1</td><td>polynomial and exponential cost curve</td></tr> <tr> <td>INTGAR(1) = 2</td><td>linear cost curve</td></tr> <tr> <td>INTGAR(1) = 3</td><td>quadratic cost curve</td></tr> <tr> <td>INTGAR(2)</td><td>status (default value of 1 if new record, current value otherwise)</td></tr> <tr> <td>INTGAR(2) = 0</td><td>out of service</td></tr> <tr> <td>INTGAR(2) = 1</td><td>in service</td></tr> <tr> <td>INTGAR(3)</td><td>cost table cross reference number. This value is not currently used by the program</td></tr> </table>	INTGAR(1)	cost curve type. This value is not currently used by the program	INTGAR(1) = 1	polynomial and exponential cost curve	INTGAR(1) = 2	linear cost curve	INTGAR(1) = 3	quadratic cost curve	INTGAR(2)	status (default value of 1 if new record, current value otherwise)	INTGAR(2) = 0	out of service	INTGAR(2) = 1	in service	INTGAR(3)	cost table cross reference number. This value is not currently used by the program
INTGAR(1)	cost curve type. This value is not currently used by the program																
INTGAR(1) = 1	polynomial and exponential cost curve																
INTGAR(1) = 2	linear cost curve																
INTGAR(1) = 3	quadratic cost curve																
INTGAR(2)	status (default value of 1 if new record, current value otherwise)																
INTGAR(2) = 0	out of service																
INTGAR(2) = 1	in service																
INTGAR(3)	cost table cross reference number. This value is not currently used by the program																
Real REALAR (4)	array of 4 elements specifying (input). <table border="0"> <tr> <td>REALAR(1)</td><td>initial bus shunt susceptance in Mvar at nominal voltage (default value of 0.0 if new record, current value otherwise)</td></tr> <tr> <td>REALAR(2)</td><td>maximum bus shunt susceptance in Mvar (default value of 0.0 if new record, current value otherwise)</td></tr> </table>	REALAR(1)	initial bus shunt susceptance in Mvar at nominal voltage (default value of 0.0 if new record, current value otherwise)	REALAR(2)	maximum bus shunt susceptance in Mvar (default value of 0.0 if new record, current value otherwise)												
REALAR(1)	initial bus shunt susceptance in Mvar at nominal voltage (default value of 0.0 if new record, current value otherwise)																
REALAR(2)	maximum bus shunt susceptance in Mvar (default value of 0.0 if new record, current value otherwise)																

	REALAR(3)	minimum bus shunt susceptance in Mvar (default value of 0.0 if new record, current value otherwise)
	REALAR(4)	cost scale coefficient in \$/Mvar (default value of 1.0 if new record, current value otherwise)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	adjustable bus shunt identifier is more than two characters
	IERR = 2	invalid bus number
	IERR = 3	blank adjustable bus shunt identifier is invalid
	IERR = 4	adjustable bus shunt table is full
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	bus not found
	IERR = 7	invalid node number
	IERR = 8	bus does not belong to a substation
	IERR = 9	node is not found in the substation
	IERR = 10	node is not connected to any bus section of bus
	IERR = 11	prerequisite requirements for function not met
	IERR = -1	warnings - one or more of: - Invalid cost curve type specified. - Invalid adjustable bus shunt status specified. - Maximum shunt suscep- tance less than minimum shunt susceptance, values have been switched

3.2.7. OPF_ADJVAR_SUBSYS

Use this API to add or modify all OPF adjustable bus shunt records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_ADJVAR_SUBSYS  SID  ALL  AUTOADD  SHNTID  INTGAR(1)..INTGAR(4)
                        REALAR(1)..REALAR(4)  USEVAL(1)..USEVAL(4)
```

Python command syntax:

```
ierr = opf_adjvar_subsys(sid, all, autoadd, shntid, intgar, realar,
                        useval)
```

Fortran command syntax:

```
CALL OPF_ADJVAR_SUBSYS(SID, ALL, AUTOADD, SHNTID, INTGAR, REALAR, USEVAL,
                        IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer AUTOADD	Indicates whether new records can be added (default treatment same as value of 3) (input). AUTOADD = 0 do not add a new var record if it does not already exist. AUTOADD = 1 add a new var record if it does not already exist. AUTOADD = 2 add a separate shunt record at the bus. AUTOADD = 3 only modify existing bus shunt records that correspond to the shunt identifier given in SHNTID.
Character*2 SHNTID	adjustable bus shunt identifier (input; '1' by default).
Integer INTGAR (4)	array of 4 elements specifying (input). INTGAR(1) cost curve type. This value is not currently used by the program INTGAR(1) = 1 polynomial and exponential cost curve INTGAR(1) = 2 piece-wise linear cost curve INTGAR(1) = 3 piece-wise quadratic cost curve INTGAR(2) status (default value of 1 for new records, current value otherwise) INTGAR(2) = 0 out of service INTGAR(2) = 1 in service

	INTGAR(3)	cost table cross reference number. This value is not currently used by the program
	INTGAR(4)	indicates which bus types should be processed (default treatment same as value of 0)
	INTGAR(4) = 0	process all buses in subsystem
	INTGAR(4) = 1	process only Type 1 buses in subsystem
	INTGAR(4) = 2	process only Type 2 and 3 buses in subsystem
Real REALAR (4)	array of 4 elements specifying (input).	
	REALAR(1)	bus shunt susceptance in Mvar at nominal voltage (default value of 0.0 for new records, current values used for existing ones)
	REALAR(2)	maximum bus shunt susceptance in Mvar (default value of 0.0 for new records, current value otherwise)
	REALAR(3)	minimum bus shunt susceptance in Mvar (default value of 0.0 for new records, current value otherwise)
	REALAR(4)	cost scale coefficient in \$/Mvar (default value of 1.0 for new records, current value otherwise)
Integer USEVAL (4)	array of 4 elements specifying Used to indicate actions to be taken on the REALAR values. If USEVAL is 1 then value REALAR value is multiplied by the current value. If USEVAL is 2 then REALAR value is added to current real value. If USEVAL is 0 (default) then REALAR is used as provided.(input).	
	USEVAL(1)	indicates how the value of REALAR(1) should be adjusted
	USEVAL(1) = 0	if the value of REALAR(1) is to be used as defined
	USEVAL(1) = 1	if the value of REALAR(1) is to be multiplied by the present value of the bus shunt susceptance
	USEVAL(1) = 2	if the value of REALAR(1) is to be added to the present value of the bus shunt susceptance
	USEVAL(2)	indicates how the value of REALAR(2) should be used
	USEVAL(2) = 0	if the value of REALAR(2) is to be used as defined
	USEVAL(2) = 1	if the value of REALAR(2) is to be multiplied by the present value of the maximum bus shunt susceptance
	USEVAL(2) = 2	if the value of REALAR(2) is to be added to the present value of the maximum bus shunt susceptance

	USEVAL(3)	indicates how the value of REALAR(3) should be used
	USEVAL(3) = 0	if the value of REALAR(3) is to be used as defined
	USEVAL(3) = 1	if the value of REALAR(3) is to be multiplied by the present value of the minimum bus shunt susceptance
	USEVAL(3) = 2	if the value of REALAR(3) is to be added to the present value of the minimum bus shunt susceptance
	USEVAL(4)	indicates how the value of REALAR(4) should be used
	USEVAL(4) = 0	if the value of REALAR(4) is to be used as defined
	USEVAL(4) = 1	if the value of REALAR(4) is to be multiplied by the present value of the cost scale coefficient
	USEVAL(4) = 2	if the value of REALAR(4) is to be added to the present value of the cost scale coefficient
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	adjustable bus shunt identifier is more than two characters
	IERR = 2	invalid SID value or subsystem SID is not defined
	IERR = 3	invalid ALL value
	IERR = 4	adjustable bus shunt table is full
	IERR = 5	node-breaker terminal connection table is full
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - Invalid cost curve type specified. - Invalid adjustable bus shunt status specified. - Maximum shunt susceptance less than minimum shunt susceptance

3.2.8. OPF_APDSP_TBL

Use this API to add an individual active power dispatch table record to the working case. It may also be used to modify an existing active power dispatch table record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_APDSP_TBL   TBL   INTGAR(1)..INTGAR(3)   REALAR(1)..REALAR(3)
```

Python command syntax:

```
ierr = opf_apdsp_tbl(tbl, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_APDSP_TBL(TBL, INTGAR, REALAR, IERR)
```

Where:

Integer TBL	active power dispatch table number (input; no default allowed).	
Integer INTGAR (3)	array of 3 elements specifying (input).	
	INTGAR(1)	cost curve type (default value of 1 if new record, current value otherwise)
	INTGAR(1) = 1	polynomial and exponential cost curve
	INTGAR(1) = 2	linear cost curve
	INTGAR(1) = 3	quadratic cost curve
	INTGAR(2)	active power dispatch table status (default value of 1 if new record, current value otherwise)
	INTGAR(2) = 0	out of service
	INTGAR(2) = 1	in service
	INTGAR(3)	cost table cross reference number (default value of 0, current value otherwise)
Real REALAR (3)	array of 3 elements specifying (input).	
	REALAR(1)	maximum active power generation, in MW (default value of 9999.0, current value otherwise)
	REALAR(2)	minimum active power generation, in MW (default value of -9999.0, current value otherwise)
	REALAR(3)	fuel cost scale coefficient (default value of 1.0, current value otherwise)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Warning messages are as follows: - invalid cost curve type specified - invalid active power dispatch table status specified - maximum active power gener-

	ation less than minimum active power gener- ation
IERR = 0	no error occurred
IERR = 1	active power dispatch table is full
IERR = 2	prerequisite requirements for API are not met

3.2.9. OPF_BRFLW_3WT_INDV

Use this API to add a flow constraint record for an individual winding of a three-winding transformer in the working case. It may also be used to modify an existing three-winding transformer flow constraint record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_BRFLW_3WT_INDV  EIBUS  EJBUS  EKBUS  CKTID  BFLWID  INTGAR(1)
                        INTGAR(2)  REALAR(1)..REALAR(5)
```

Python command syntax:

```
ierr = opf_brflw_3wt_indv(eibus, ejbus, ekbus, cktid, bflwid, intgar,
                           realar)
```

Fortran command syntax:

```
CALL OPF_BRFLW_3WT_INDV(EIBUS, EJBUS, EKBUS, CKTID, BFLWID, INTGAR,
                        REALAR, IERR)
```

Where:

Integer EIBUS	from bus number The value of EIBUS indicates the from bus of the winding for which the flow constraint is being introduced (input; no default allowed).
Integer EJBUS	to bus number (input; no default allowed).
Integer EKBUS	third bus number (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Character*1 BFLWID	branch flow constraint identifier (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) branch flow type (default value of 4 if new record, current value otherwise)
	INTGAR(1) = 1 MW
	INTGAR(1) = 2 Mvar
	INTGAR(1) = 3 MVA
	INTGAR(1) = 4 Ampere
	INTGAR(2) limit type imposed on the branch flow limits (default value of 1 if new record, current value otherwise)
	INTGAR(2) = 0 reporting only
	INTGAR(2) = 1 hard limit
	INTGAR(2) = 2 linear soft limit
	INTGAR(2) = 3 quadratic soft limit
Real REALAR (5)	array of 5 elements specifying (input).
	REALAR(1) maximum normal flow limit in physical units (default value of 0.0 for new record, current value otherwise)

	REALAR(2)	minimum normal flow limit in physical units (default value of 0.0 for new record, current value otherwise)
	REALAR(3)	maximum emergency flow limit in physical units (default value of 0.0 for new record, current value otherwise)
	REALAR(4)	minimum emergency flow limit in physical units (default value of 0.0 for new record, current value otherwise)
	REALAR(5)	soft limit penalty weight (default value of 1.0 for new record, current value otherwise)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Possible warning messages are: - Invalid branch flow type specified. - Invalid branch flow limit type specified. - Maximum normal flow limit is less than the minimum normal flow limit. - Maximum emergency flow limit is less than the minimum emergency flow limit
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	specified three-winding transformer does not exist
	IERR = 3	specified winding of three-winding transformer not found
	IERR = 4	branch flow constraint table is full
	IERR = 5	prerequisite requirements for API are not met

3.2.10. OPF_BRFLW_BRN_INDV

Use this API to add an individual branch or two-winding transformer flow constraint record to the working case. It may also be used to modify an existing branch or two-winding transformer flow constraint.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_BRFLW_BRN_INDV  EIBUS  EJBUS  CKTID  BFLWID  INTGAR(1)  INTGAR(2)
REALAR(1) .. REALAR(5)
```

Python command syntax:

```
ierr = opf_brflw_brn_indv(eibus, ejbus, cktid, bflwid, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_BRFLW_BRN_INDV(EIBUS, EJBUS, CKTID, BFLWID, INTGAR, REALAR, IERR)
```

Where:

Integer EIBUS	from bus number (input; no default allowed).
Integer EJBUS	to bus number (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Character*1 BFLWID	branch flow constraint identifier (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) branch flow type (default value of 4 if new record, current value otherwise)
	INTGAR(1) = 1 MW
	INTGAR(1) = 2 Mvar
	INTGAR(1) = 3 MVA
	INTGAR(1) = 4 Ampere
	INTGAR(2) limit type imposed on the branch flow limits (default value of 1 if new record, current value otherwise)
	INTGAR(2) = 0 reporting only
	INTGAR(2) = 1 hard limit
	INTGAR(2) = 2 linear soft limit
	INTGAR(2) = 3 quadratic soft limit
Real REALAR (5)	array of 5 elements specifying (input).
	REALAR(1) maximum normal flow limit in physical units (default value of 0.0 if new record, current value otherwise)
	REALAR(2) minimum normal flow limit in physical units (default value of 0.0 if new record, current value otherwise)
	REALAR(3) maximum emergency flow limit in physical units (default value of 0.0 if new record, current value otherwise)

Integer IERR	REALAR(4)	minimum emergency flow limit in physical units (default value of 0.0 if new record, current value otherwise)
	REALAR(5)	soft limit penalty weight (default value of 1.0 if new record, current value otherwise)
	error code (output).	
	IERR = -1	non-fatal error occurred. Possible warning messages are: - Invalid branch flow type specified. - Invalid branch flow limit type specified. - Maximum normal flow limit is less than the minimum normal flow limit. - Maximum emergency flow limit is less than the minimum emergency flow limit
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	specified branch does not exist
	IERR = 3	branch flow constraint table is full
	IERR = 4	prerequisite requirements for API are not met

3.2.11. OPF_BRFLW_SUBSYS

Use this API to add or modify all branch flow data records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_BRFLW_SUBSYS  SID  ALL  AUTOADD  BFLWID  INTGAR(1)..INTGAR(3)
REALAR(1)..REALAR(5)  USEVAL(1)..USEVAL(5)
```

Python command syntax:

```
ierr = opf_brflw_subsys(sid, all, autoadd, bflwid, intgar, realar, useval)
```

Fortran command syntax:

```
CALL OPF_BRFLW_SUBSYS(SID, ALL, AUTOADD, BFLWID, INTGAR, REALAR, USEVAL,
IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer AUTOADD	Indicates whether new records can be added, or are to be modified (input; no default allowed). AUTOADD = 0 do not add a new branch flow record if it does not already exist. AUTOADD = 1 add a new branch flow record if it does not already exist. AUTOADD = 2 only modify existing branch flow records that correspond to the flow identifier given in BFLWID.
Character*1 BFLWID	branch flow identifier (input; no default allowed).
Integer INTGAR (3)	array of 3 elements specifying (input). INTGAR(1) branch flow type (default value of 4 for new records, current value otherwise) INTGAR(1) = 1 MW INTGAR(1) = 2 Mvar INTGAR(1) = 3 MVA INTGAR(1) = 4 Ampere INTGAR(2) limit type imposed on the branch flow limits (default value of 1 for new records, current value otherwise) INTGAR(2) = 0 reporting only INTGAR(2) = 1 hard limit INTGAR(2) = 2 linear soft limit

	INTGAR(2) = 3	quadratic soft limit
	INTGAR(3)	default rate setting (default value of 0)
	INTGAR(3) = 0	use the limits that have been defined
	INTGAR(3) = 1	base flow limits on RATEA
	INTGAR(3) = 2	base flow limits on RATEB
	INTGAR(3) = 3	base flow limits on RATEC
Real REALAR (5)	array of 5 elements specifying (input).	
	REALAR(1)	maximum normal flow limit in physical units (default value of 0.0 for new records, current value otherwise)
	REALAR(2)	minimum normal flow limit in physical units (default value of 0.0 for new records, current value otherwise)
	REALAR(3)	maximum emergency flow limit in physical units (default value of 0.0 for new records, current value otherwise)
	REALAR(4)	minimum emergency flow limit in physical units (default value of 0.0 for new records, current value otherwise)
	REALAR(5)	soft limit penalty weight (default value of 1.0 for new records, current value otherwise)
Integer USEVAL (5)	array of 5 elements specifying Specifies whether the corresponding REALAR value should be applied as provided, or multiplied by the present value or added to the present value.(input).	
	USEVAL(1)	indicates how the value of REALAR(1) should be used
	USEVAL(1) = 0	if the value of REALAR(1) is to be used as defined
	USEVAL(1) = 1	if the value of REALAR(1) is to be multiplied by the present value of the maximum normal flow limit
	USEVAL(1) = 2	if the value of REALAR(1) is to be added to the present value of the maximum normal flow limit
	USEVAL(2)	indicates how the value of REALAR(2) should be used
	USEVAL(2) = 0	if the value of REALAR(2) is to be used as defined
	USEVAL(2) = 1	if the value of REALAR(2) is to be multiplied by the present value of the minimum normal flow limit
	USEVAL(2) = 2	if the value of REALAR(2) is to be added to the present value of the minimum normal flow limit
	USEVAL(3)	indicates how the value of REALAR(3) should be used

	USEVAL(3) = 0	if the value of REALAR(3) is to be used as defined
	USEVAL(3) = 1	if the value of REALAR(3) is to be multiplied by the present value of the maximum emergency flow limit
	USEVAL(3) = 2	if the value of REALAR(3) is to be added to the present value of the maximum emergency flow limit
	USEVAL(4)	indicates how the value of REALAR(4) should be used
	USEVAL(4) = 0	if the value of REALAR(4) is to be used as defined
	USEVAL(4) = 1	if the value of REALAR(4) is to be multiplied by the present value of the minimum emergency flow limit
	USEVAL(4) = 2	if the value of REALAR(4) is to be added to the present value of the minimum emergency flow limit
	USEVAL(5)	indicates how the value of REALAR(5) should be used
	USEVAL(5) = 0	if the value of REALAR(5) is to be used as defined
	USEVAL(5) = 1	if the value of REALAR(5) is to be multiplied by the present value of the soft limit penalty weight
	USEVAL(5) = 2	if the value of REALAR(5) is to be added to the present value of the soft limit penalty weight
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Possible warning messages are: - Invalid flow type specified. - Invalid branch flow limit type specified. - Maximum normal flow limit is less than the minimum normal flow limit. - Maximum emergency flow limit is less than the minimum emergency flow limit
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	branch flow constraint table is full
	IERR = 4	prerequisite requirements for API are not met

3.2.12. OPF_BUS_INDV

This API routine is obsolete. It has been replaced by the API routine [opf_bus_indv_2](#).

Use this API to add OPF bus voltage magnitude data to the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_BUS_INDV  EIBUS  INTGAR(1)  INTGAR(2)  REALAR(1) .. REALAR(5)
```

Python command syntax:

```
ierr = opf_bus_indv(eibus, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_BUS_INDV(EIBUS, INTGAR, REALAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) limit type imposed on the bus voltage limits (default is the current value; initialized to 1)
	INTGAR(1) = 0 reporting only
	INTGAR(1) = 1 hard limit
	INTGAR(1) = 2 linear soft limit
	INTGAR(1) = 3 quadratic soft limit
	INTGAR(2) indicates what to do with the defined voltage limits (default treatment same as value of 0)
	INTGAR(2) = 0 leave voltage limits as defined by REALAR(1) and REALAR(2)
	INTGAR(2) = 1 fix normal voltage limit at present voltage values, ignoring any values defined by REALAR(1) and REALAR(2)
	INTGAR(2) = 2 allow normal voltage limits to open up if they exceed the bounds defined by REALAR(1) or REALAR(2)
	INTGAR(2) = 3 set normal and emergency OPF voltage limits to the normal and emergency voltage limits as defined in the network bus data
Real REALAR (5)	array of 5 elements specifying (input).
	REALAR(1) normal maximum voltage limit in pu (default is the current value; initialized to 9999.0)
	REALAR(2) normal minimum voltage limit in pu (default is the current value; initialized to -9999.0)

	REALAR(3)	emergency maximum voltage limit in pu (default is the current value; initialized to 9999.0)
	REALAR(4)	emergency minimum voltage limit in pu (default is the current value; initialized to -9999.0)
	REALAR(5)	soft-limit penalty weight (default is the current value; initialized to 1.0)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Warning messages are as follows: - Invalid limit type specified. - Maximum normal voltage limit less than minimum limit. - Maximum emergency voltage limit less than minimum limit
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	prerequisite requirements for API are not met

3.2.13. OPF_BUS_INDV_2

Use this API to add OPF bus voltage magnitude data to the working case.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_OPF_BUS_INDV_2  EIBUS  ENOD  INTGAR(1)  INTGAR(2)
REALAR(1) .. REALAR(5)
```

Python command syntax:

```
ierr = opf_bus_indv_2(eibus, enod, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_BUS_INDV_2(EIBUS, ENOD, INTGAR, REALAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).																				
Integer ENOD	The bus section number or the external node number of one of the nodes in the bus section of interest. Specify 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, the data of the parent bus and not that of the bus sections will be changed. (input; no default allowed).																				
Integer INTGAR (2)	array of 2 elements specifying (input). <table> <tr> <td>INTGAR(1)</td><td>limit type imposed on the bus voltage limits (default is the current value; initialized to 1)</td></tr> <tr> <td>INTGAR(1) = 0</td><td>reporting only</td></tr> <tr> <td>INTGAR(1) = 1</td><td>hard limit</td></tr> <tr> <td>INTGAR(1) = 2</td><td>linear soft limit</td></tr> <tr> <td>INTGAR(1) = 3</td><td>quadratic soft limit</td></tr> <tr> <td>INTGAR(2)</td><td>indicates what to do with the defined voltage limits (default treatment same as value of 0)</td></tr> <tr> <td>INTGAR(2) = 0</td><td>leave voltage limits as defined by REALAR(1) and REALAR(2)</td></tr> <tr> <td>INTGAR(2) = 1</td><td>fix normal voltage limit at present voltage values, ignoring any values defined by REALAR(1) and REALAR(2)</td></tr> <tr> <td>INTGAR(2) = 2</td><td>allow normal voltage limits to open up if they exceed the bounds defined by REALAR(1) or REALAR(2)</td></tr> <tr> <td>INTGAR(2) = 3</td><td>set normal and emergency OPF voltage limits to the normal and emergency voltage limits as defined in the network bus data</td></tr> </table>	INTGAR(1)	limit type imposed on the bus voltage limits (default is the current value; initialized to 1)	INTGAR(1) = 0	reporting only	INTGAR(1) = 1	hard limit	INTGAR(1) = 2	linear soft limit	INTGAR(1) = 3	quadratic soft limit	INTGAR(2)	indicates what to do with the defined voltage limits (default treatment same as value of 0)	INTGAR(2) = 0	leave voltage limits as defined by REALAR(1) and REALAR(2)	INTGAR(2) = 1	fix normal voltage limit at present voltage values, ignoring any values defined by REALAR(1) and REALAR(2)	INTGAR(2) = 2	allow normal voltage limits to open up if they exceed the bounds defined by REALAR(1) or REALAR(2)	INTGAR(2) = 3	set normal and emergency OPF voltage limits to the normal and emergency voltage limits as defined in the network bus data
INTGAR(1)	limit type imposed on the bus voltage limits (default is the current value; initialized to 1)																				
INTGAR(1) = 0	reporting only																				
INTGAR(1) = 1	hard limit																				
INTGAR(1) = 2	linear soft limit																				
INTGAR(1) = 3	quadratic soft limit																				
INTGAR(2)	indicates what to do with the defined voltage limits (default treatment same as value of 0)																				
INTGAR(2) = 0	leave voltage limits as defined by REALAR(1) and REALAR(2)																				
INTGAR(2) = 1	fix normal voltage limit at present voltage values, ignoring any values defined by REALAR(1) and REALAR(2)																				
INTGAR(2) = 2	allow normal voltage limits to open up if they exceed the bounds defined by REALAR(1) or REALAR(2)																				
INTGAR(2) = 3	set normal and emergency OPF voltage limits to the normal and emergency voltage limits as defined in the network bus data																				
Real REALAR (5)	array of 5 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>normal maximum voltage limit in pu (default is the current value; initialized to 9999.0)</td></tr> </table>	REALAR(1)	normal maximum voltage limit in pu (default is the current value; initialized to 9999.0)																		
REALAR(1)	normal maximum voltage limit in pu (default is the current value; initialized to 9999.0)																				

	REALAR(2)	normal minimum voltage limit in pu (default is the current value; initialized to -9999.0)
	REALAR(3)	emergency maximum voltage limit in pu (default is the current value; initialized to 9999.0)
	REALAR(4)	emergency minimum voltage limit in pu (default is the current value; initialized to -9999.0)
	REALAR(5)	soft-limit penalty weight (default is the current value; initialized to 1.0)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Warning messages are as follows: - Invalid limit type specified. - Maximum normal voltage limit less than minimum limit. - Maximum emergency voltage limit less than minimum limit
	IERR = 0	no error occurred
	IERR = 1	invalid bus number
	IERR = 2	bus not found
	IERR = 3	invalid node number
	IERR = 4	node not found in substation of bus
	IERR = 5	node not connected to any bus section of bus in substation
	IERR = 6	prerequisite requirements for API are not met

3.2.14. OPF_BUS_SUBSYS

Use this API to add OPF bus attribute data for all records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_BUS_SUBSYS  SID  ALL  INTGAR(1)..INTGAR(3)  REALAR(1)..REALAR(5)
USEVAL(1)..USEVAL(5)
```

Python command syntax:

```
ierr = opf_bus_subsys(sid, all, intgar, realar, useval)
```

Fortran command syntax:

```
CALL OPF_BUS_SUBSYS(SID, ALL, INTGAR, REALAR, USEVAL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses, use existing data values.
	ALL = 2	process all buses, use default data values.
Integer INTGAR (3)	array of 3 elements specifying (input).	
	INTGAR(1)	limit type imposed on the bus voltage limits (default is the current value; initialized to 1)
	INTGAR(1) = 0	reporting only
	INTGAR(1) = 1	hard limit
	INTGAR(1) = 2	linear soft limit
	INTGAR(1) = 3	quadratic soft limit
	INTGAR(2)	indicates what to do with the defined voltage limits (default treatment same as value of 0)
	INTGAR(2) = 0	leave voltage limits as defined by REALAR(1) and REALAR(2)
	INTGAR(2) = 1	fix normal voltage limit at present voltage values, ignoring any values defined by REALAR(1) and REALAR(2)
	INTGAR(2) = 2	allow normal voltage limits to open up if they exceed the bounds defined by REALAR(1) or REALAR(2)
	INTGAR(2) = 3	set normal and emergency OPF voltage limits to the normal and emergency voltage limits as defined in the network bus data
	INTGAR(3)	indicates which bus types should be processed (default treatment same as value of 0)
	INTGAR(3) = 0	all buses in subsystem

	INTGAR(3) = 1	only Type 1 buses in subsystem
	INTGAR(3) = 2	only Type 2 and 3 buses in subsystem
Real REALAR (5)	array of 5 elements specifying (input).	
	REALAR(1)	normal maximum voltage limit in pu (default is the current value; initialized to 9999.0)
	REALAR(2)	normal minimum voltage limit in pu (default is the current value; initialized to -9999.0)
	REALAR(3)	emergency maximum voltage limit in pu (default is the current value; initialized to 9999.0)
	REALAR(4)	emergency minimum voltage limit in pu (default is the current value; initialized to -9999.0)
	REALAR(5)	soft-limit penalty weight (default is the current value; initialized to 1.0)
Integer USEVAL (5)	array of 5 elements specifying (default treatment same as value of 0) (input).	
	USEVAL(1)	indicates how the value of REALAR(1) should be used
	USEVAL(1) = 0	if the value of REALAR(1) is to be used as defined
	USEVAL(1) = 1	if the value of REALAR(1) is to be multiplied by the present value of the normal bus voltage minimum limit
	USEVAL(1) = 2	if the value of REALAR(1) is to be added to the present value of the normal bus voltage minimum limit
	USEVAL(2)	indicates how the value of REALAR(2) should be used
	USEVAL(2) = 0	if the value of REALAR(2) is to be used as defined
	USEVAL(2) = 1	if the value of REALAR(2) is to be multiplied by the present value of the normal bus voltage maximum limit
	USEVAL(2) = 2	if the value of REALAR(2) is to be added to the present value of the normal bus voltage maximum limit
	USEVAL(3)	indicates how the value of REALAR(3) should be used
	USEVAL(3) = 0	if the value of REALAR(3) is to be used as defined
	USEVAL(3) = 1	if the value of REALAR(3) is to be multiplied by the present value of the emergency bus voltage minimum limit

	USEVAL(3) = 2	if the value of REALAR(3) is to be added to the present value of the emergency bus voltage minimum limit
	USEVAL(4)	indicates how the value of REALAR(4) should be used
	USEVAL(4) = 0	if the value of REALAR(4) is to be used as defined
	USEVAL(4) = 1	if the value of REALAR(4) is to be multiplied by the present value of the emergency bus voltage maximum limit
	USEVAL(4) = 2	if the value of REALAR(4) is to be added to the present value of the emergency bus voltage maximum limit
	USEVAL(5)	indicates how the value of PENWGT should be used
	USEVAL(5) = 0	if the value of PENWGT is to be used as defined
	USEVAL(5) = 1	if the value of PENWGT is to be multiplied by the present value of the soft limit penalty weight
	USEVAL(5) = 2	if the value of PENWGT is to be added to the present value of the soft limit penalty weight
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met
	IERR = -1	non-fatal error occurred. Warning messages are as follows: - Invalid limit type specified. - Maximum normal voltage limit less than minimum limit. - Maximum emergency voltage limit less than minimum limit

3.2.15. OPF_CHANGE_3WT_FLOW_ID

Use this API to change the identifier of a flow constraint record for an individual winding of a three-winding transformer in the working case.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Batch command syntax:

```
OPF_CHANGE_3WT_FLOW_ID  IBUS  JBUS  KBUS  CKTID  ID  IDNEW
```

Python command syntax:

```
ierr = opf_change_3wt_flow_id(ibus, jbus, kbus, cktid, id, idnew)
```

Fortran command syntax:

```
CALL OPF_CHANGE_3WT_FLOW_ID(IBUS, JBUS, KBUS, CKTID, ID, IDNEW, IERR)
```

Where:

Integer IBUS	from bus number The value of IBUS indicates the from bus of the winding for which the flow constraint is being introduced (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Character*1 ID	branch flow constraint identifier (input; no default allowed).
Character*1 IDNEW	new branch flow constraint identifier (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid bus number specified
IERR = 2	a non-blank new identifier must be specified
IERR = 3	specified three-winding transformer does not exist
IERR = 4	branch flow identifier is more than one character
IERR = 5	specified winding of three-winding transformer not found
IERR = 6	specified OPF branch flow constraint does not exist
IERR = 7	branch flow constraint already exists
IERR = 8	prerequisite requirements for API are not met

3.2.16. OPF_CHANGE_ADJVAR_ID

This API routine is obsolete. It has been replaced by the API routine [opf_change_adjvar_id](#).

Use this API to change the identifier of an OPF adjustable bus shunt data record in the working case.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Batch command syntax:

```
BAT_OPF_CHANGE_ADJVAR_ID  IBUS  ID  IDNEW
```

Python command syntax:

```
ierr = opf_change_adjvar_id(ibus, id, idnew)
```

Fortran command syntax:

```
CALL OPF_CHANGE_ADJVAR_ID(IBUS, ID, IDNEW, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	OPF adjustable bus shunt identifier (input; no default allowed).
Character*2 IDNEW	new OPF adjustable bus shunt identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 blank adjustable bus shunt identifier is invalid
	IERR = 3 adjustable bus shunt identifier is more than two characters
	IERR = 4 adjustable bus shunt not found
	IERR = 5 adjustable bus shunt already exists
	IERR = 6 prerequisite requirements for API are not met

3.2.17. OPF_CHANGE_BRN_FLOW_ID

Use this API to change the identifier of a branch or two-winding transformer OPF flow constraint record in the working case.

This API routine was first introduced in release 34.8.0 and 35.2.0.

Batch command syntax:

```
OPF_CHANGE_BRN_FLOW_ID  IBUS  JBUS  CKTID  ID  IDNEW
```

Python command syntax:

```
ierr = opf_change_brn_flow_id(ibus, jbus, cktid, id, idnew)
```

Fortran command syntax:

```
CALL OPF_CHANGE_BRN_FLOW_ID(IBUS, JBUS, CKTID, ID, IDNEW, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Character*1 ID	branch flow constraint identifier (input; no default allowed).
Character*1 IDNEW	new branch flow constraint identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 a non-blank new identifier must be specified
	IERR = 3 specified branch does not exist
	IERR = 4 branch flow identifier is more than one character
	IERR = 5 branch flow constraint does not exist
	IERR = 6 branch flow constraint already exists
	IERR = 7 prerequisite requirements for API are not met

3.2.18. OPF_CSTTBL_LIN

Use this API to add a linear cost curve table record to the working case. It may also be used to modify an existing linear cost curve table record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_CSTTBL_LIN  TBL  LABL  NPRS
```

Python command syntax:

```
ierr = opf_csttbl_lin(tbl, labl, nprs, xy)
```

Fortran command syntax:

```
CALL OPF_CSTTBL_LIN(TBL, LABL, NPRS, XY, IERR)
```

Where:

Integer TBL	linear cost curve table number (input; no default allowed).	
Character*12 LABL	cost table description of, at most, 12 characters (input; '' by default).	
Integer NPRS	number of (Xi, Yi) coordinate pairs being specified (input; no default allowed).	
Real XY (2*NPRS)	Coordinate pairs from 1 to NPRS. Xi is the control variable value. Yi is the total cost or energy consumption value. (input; Xi and Yi have defaults of 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	cost table data table is full
	IERR = 2	exceeded maximum number of allowable cost curve data pairs
	IERR = 3	number of data pairs must not be less than zero
	IERR = 4	incremental costs are not monotonically increasing
	IERR = 5	MW values are not monotonically increasing
	IERR = 6	prerequisite requirements for API are not met

3.2.19. OPF_CSTTBL_POLY

Use this API to add a polynomial and exponential cost curve table record to the working case. It may also be used to modify an existing polynomial and exponential cost curve table record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_CSTTBL_POLY  TBL  LABL  COST  LINCST  QUACST  EXPCST  EXPON
```

Python command syntax:

```
ierr = opf_csttbl_poly(tbl, labl, cost, lincst, quacst, expcst, expon)
```

Fortran command syntax:

```
CALL OPF_CSTTBL_POLY(TBL, LABL, COST, LINCST, QUACST, EXPCST, EXPON, IERR)
```

Where:

Integer TBL	polynomial and exponential cost curve table number (input; no default allowed).
Character*12 LABL	cost table description of, at most, 12 characters (input; '' by default).
Real COST	cost integration constant (input; 0.0).
Real LINCST	linear cost coefficient value (input; 1.0).
Real QUACST	quadratic cost coefficient value (input; 1.0).
Real EXPCST	exponential cost coefficient value (input; 0.0).
Real EXPON	exponent of the exponential cost coefficient (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 cost table data table full
	IERR = 2 exceeded maximum number of allowable cost curve data values
	IERR = 3 prerequisite requirements for API are not met

3.2.20. OPF_CSTTBL_QUAD

Use this API to add a quadratic cost curve table record to the working case. It may also be used to modify an existing quadratic cost curve table record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_CSTTBL_QUAD  TBL  LABL  COST  NPRS
```

Python command syntax:

```
ierr = opf_csttbl_quad(tbl, labl, cost, nprs, xy)
```

Fortran command syntax:

```
CALL OPF_CSTTBL_QUAD(TBL, LABL, COST, NPRS, XY, IERR)
```

Where:

Integer TBL	quadratic cost curve table number (input; no default allowed).	
Character*12 LABL	cost table description of, at most, 12 characters (input; '' by default).	
Real COST	cost integration constant (input; 0.0).	
Integer NPRS	number of (Xi, Yi) coordinate pairs to be specified (no default) (input).	
Real XY (2*NPRS)	Coordinate pairs from 1 to NPRS. Xi is the control variable value. Yi is the total cost or energy consumption value. (input; Xi and Yi have defaults of 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	cost table data table is full
	IERR = 2	exceeded maximum number of allowable cost curve data pairs
	IERR = 3	number of data pairs must not be negative
	IERR = 4	incremental costs are not monotonically increasing
	IERR = 5	MW values are not monotonically increasing
	IERR = 6	prerequisite requirements for API are not met

3.2.21. OPF_GENDSP_INDV

Use this API to add generator dispatch data to an individual record in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_GENDSP_INDV  EIBUS  GENID  APDTBL  DSPTCH
```

Python command syntax:

```
ierr = opf_gendsp_indv(eibus, genid, apdtbl, dsptch)
```

Fortran command syntax:

```
CALL OPF_GENDSP_INDV(EIBUS, GENID, APDTBL, DSPTCH, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; no default allowed).
Integer APDTBL	active power dispatch table cross reference number (input; default of 0 if new record, current value otherwise).
Real DSPTCH	dispatch fraction (default value of 1.0 if new record, current value otherwise) (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified machine does not exist
	IERR = 3 prerequisite requirements for API are not met

3.2.22. OPF_GENDSP_SUBSYS

Use this API to add OPF generator dispatch data to all records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_GENDSP_SUBSYS  SID  ALL  APDTBL  DSPTCH  USEVAL
```

Python command syntax:

```
ierr = opf_gendsp_subsys(sid, all, apdtbl, dsptch, useval)
```

Fortran command syntax:

```
CALL OPF_GENDSP_SUBSYS(SID, ALL, APDTBL, DSPTCH, USEVAL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses, use existing data values.
	ALL = 2	process all buses, use default data values.
Integer APDTBL	active power dispatch table cross reference number (input; default of 0 for new record, current value otherwise).	
Real DSPTCH	dispatch fraction (input; default of 1.0 for new record, current value otherwise).	
Integer USEVAL	Indicates how the value of DSPTCH should be applied (default treatment same as value of 0) (input).	
	useval = 0	if the value of DSPTCH is to be used as defined.
	useval = 1	if the value of DSPTCH is to be multiplied by the present value of the dispatch fraction.
	useval = 2	if the value of DSPTCH is to be added to the present value of the dispatch fraction.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.23. OPF_GENRSV_INDV

Use this API to add an individual generator reserve data record to the working case. It may also be used to modify an existing generator reserve data record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_GENRSV_INDV  EIBUS  GENID  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = opf_genrsv_indv(eibus, genid, realar)
```

Fortran command syntax:

```
CALL OPF_GENRSV_INDV(EIBUS, GENID, REALAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; no default allowed).
Real REALAR (2)	array of 2 elements specifying (input).
	REALAR(1) unit ramp rate in MW/minute (default value of 9999.0 if new record, current value otherwise)
	REALAR(2) unit capability in MW (default value of 9999.0 if new record, current value otherwise)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified machine does not exist
	IERR = 3 generator reserve unit table full
	IERR = 4 prerequisite requirements for API are not met

3.2.24. OPF_GENRSV_SUBSYS

Use this API to add or modify all OPF generator reserve records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_GENRSV_SUBSYS  SID  ALL  REALAR(1)  REALAR(2)  USEVAL(1)
                        USEVAL(2)
```

Python command syntax:

```
ierr = opf_genrsv_subsys(sid, all, realar, useval)
```

Fortran command syntax:

```
CALL OPF_GENRSV_SUBSYS(SID, ALL, REALAR, USEVAL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	unit ramp rate in MW/minute (default value of 9999.0 for new records, current value used otherwise)
	REALAR(2)	unit capability in MW (default value of 9999.0 for new records, current value used otherwise)
Integer USEVAL (2)	array of 2 elements specifying (default treatment same as value of 0) (input).	
	USEVAL(1)	indicates how the value of REALAR(1) should be used
	USEVAL(1) = 0	if the value of REALAR(1) is to be used as defined
	USEVAL(1) = 1	if the value of REALAR(1) is to be multiplied by the present value of the unit ramp rate
	USEVAL(1) = 2	if the value of REALAR(1) is to be added to the present value of the unit ramp rate
	USEVAL(2)	indicates how the value of REALAR(2) should be used
	USEVAL(2) = 0	if the value of REALAR(2) is to be used as defined
	USEVAL(2) = 1	if the value of REALAR(2) is to be multiplied by the present value of the unit capability

	USEVAL(2) = 2	if the value of REALAR(2) is to be added to the present value of the unit capability
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	generator reserve unit table is full
	IERR = 4	prerequisite requirements for API are not met

3.2.25. OPF_GEN_RCAP_INDV

Use this API to add an individual generation reactive capability data record to the working case. It may also be used to modify an existing generation reactive capability data record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_GEN_RCAP_INDV  EIBUS  GENID  RCSTAT  REALAR(1)..REALAR(5)
```

Python command syntax:

```
ierr = opf_gen_rcap_indv(eibus, genid, rcstat, realar)
```

Fortran command syntax:

```
CALL OPF_GEN_RCAP_INDV(EIBUS, GENID, RCSTAT, REALAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; '' by default).
Integer RCSTAT	reactive capability limit status (input; 4 by default).
	rcstat = 0 out of service.
	rcstat = 1 in service, no reactive generation limits.
	rcstat = 2 in service, inhibiting field increase.
	rcstat = 3 in service, inhibiting field decrease.
	rcstat = 4 in service, fixed Efd.
	rcstat = 5 in service, apply reactive generation limits.
Real REALAR (5)	array of 5 elements specifying (input).
	REALAR(1) direct-axis synchronous reactance in pu on Mbase (default of 1.0 if new record, current value otherwise)
	REALAR(2) stator current limit in pu on Mbase (default of 1.0 if new record, current value otherwise)
	REALAR(3) rated lagging power factor (default of 1.0 if new record, current value otherwise)
	REALAR(4) rated leading power factor (default of 1.0 if new record, current value otherwise)
	REALAR(5) maximum reactive absorption in pu on Mbase (default of 1.0 if new record, current value otherwise)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified machine does not exist
	IERR = 3 generator reactive capability data table is full

IERR = 4

IERR = -1

prerequisite requirements for API are not met
non-fatal error occurred. Possible warning
messages are: - Invalid reactive capability sta-
tus specified

3.2.26. OPF_GEN_RCAP_SUBSYS

Use this API to add or modify all OPF generator reactive capability records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_GEN_RCAP_SUBSYS  SID  ALL  RCSTAT  REALAR(1) . . REALAR(5)
USEVAL(1) . . USEVAL(5)
```

Python command syntax:

```
ierr = opf_gen_rcap_subsys(sid, all, rcstat, realar, useval)
```

Fortran command syntax:

```
CALL OPF_GEN_RCAP_SUBSYS(SID, ALL, RCSTAT, REALAR, USEVAL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Integer RCSTAT	reactive capability limit status (default value of 4 for new records, current value otherwise) (input). rcstat = 0 out of service. rcstat = 1 in service, no reactive generation limits. rcstat = 2 in service, inhibiting field increase. rcstat = 3 in service, inhibiting field decrease. rcstat = 4 in service, fixed Efd. rcstat = 5 in service, apply reactive generation limits.
Real REALAR (5)	array of 5 elements specifying The value of each is as follows(input). REALAR(1) direct-axis synchronous reactance in pu on Mbase (default value of 1.0 for new records, current value otherwise) REALAR(2) stator current limit in pu on Mbase (default value of 1.0 for new records, current value otherwise) REALAR(3) rated lagging power factor (default value of 1.0 for new records, current value otherwise) REALAR(4) rated leading power factor (default value of 1.0 for new records, current value otherwise) REALAR(5) maximum reactive absorption in pu on Mbase (default value of 1.0 for new records, current value otherwise)

Integer USEVAL (5)	array of 5 elements specifying (default treatment same as value of 0) (input).	
	USEVAL(1)	indicates how the value of REALAR(1) should be used
	USEVAL(1) = 0	if the value of REALAR(1) is to be used as defined
	USEVAL(1) = 1	if the value of REALAR(1) is to be multiplied by the present value of the direct-axis synchronous reactance
	USEVAL(1) = 2	if the value of REALAR(1) is to be added to the present value of the direct-axis synchronous reactance
	USEVAL(2)	indicates how the value of REALAR(2) should be used
	USEVAL(2) = 0	if the value of REALAR(2) is to be used as defined
	USEVAL(2) = 1	if the value of REALAR(2) is to be multiplied by the present value of the stator current limit
	USEVAL(2) = 2	if the value of REALAR(2) is to be added to the present value of the stator current limit
	USEVAL(3)	indicates how the value of REALAR(3) should be used
	USEVAL(3) = 0	if the value of REALAR(3) is to be used as defined
	USEVAL(3) = 1	if the value of REALAR(3) is to be multiplied by the present value of the rated lagging power factor
	USEVAL(3) = 2	if the value of REALAR(3) is to be added to the present value of the rated lagging power factor
	USEVAL(4)	indicates how the value of REALAR(4) should be used
	USEVAL(4) = 0	if the value of REALAR(4) is to be used as defined
	USEVAL(4) = 1	if the value of REALAR(4) is to be multiplied by the present value of the rated leading power factor
	USEVAL(4) = 2	if the value of REALAR(4) is to be added to the present value of the rated leading power factor
	USEVAL(5)	indicates how the value of REALAR(5) should be used
	USEVAL(5) = 0	if the value of REALAR(5) is to be used as defined

	USEVAL(5) = 1	if the value of REALAR(5) is to be multiplied by the present value of the maximum reactive absorption
	USEVAL(5) = 2	if the value of REALAR(5) is to be added to the present value of the maximum reactive absorption
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	generator reactive capability data table is full
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	non-fatal error occurred. Possible warning messages are: - Invalid reactive capability status specified

3.2.27. OPF_INTFLW_3WT

Use this API to add a participating three-winding transformer winding to a specified interface flow constraint in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_INTFLW_3WT  IFID  EIBUS  EJBUS  EKBUS  CKTID
```

Python command syntax:

```
ierr = opf_intflw_3wt(ifid, eibus, ejbus, ekbus, cktid)
```

Fortran command syntax:

```
CALL OPF_INTFLW_3WT(IFID, EIBUS, EJBUS, EKBUS, CKTID, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Integer EIBUS	from bus number The value of EIBUS indicates the from bus of the winding for which the flow constraint is being introduced (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Integer EKBUS	third bus number (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	participating branch table is full
	IERR = 2	invalid interface flow identifier specified
	IERR = 3	invalid bus number specified
	IERR = 4	specified three-winding transformer does not exist
	IERR = 5	specified winding is already participating in the interface
	IERR = 6	prerequisite requirements for API are not met

3.2.28. OPF_INTFLW_BRN

Use this API to add a participating branch to a specified interface flow constraint in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_INTFLW_BRN  IFID  EIBUS  EJBUS  CKTID
```

Python command syntax:

```
ierr = opf_intflw_brn(ifid, eibus, ejbus, cktid)
```

Fortran command syntax:

```
CALL OPF_INTFLW_BRN(IFID, EIBUS, EJBUS, CKTID, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Integer EIBUS	from bus number (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	participating branch table is full
	IERR = 2	invalid interface flow identifier specified
	IERR = 3	invalid bus number specified
	IERR = 4	specified branch does not exist
	IERR = 5	specified branch is already participating in the interface
	IERR = 6	prerequisite requirements for API are not met

3.2.29. OPF_INTFLW_MAIN

Use this API to add an interface flow constraint record to the working case. It may also be used to modify an existing interface flow constraint record.

This API must be invoked prior to adding any participating branch or three-winding transformer flows to the interface flow constraint.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_INTFLW_MAIN  IFID  LABL  INTGAR(1)  INTGAR(2)
                      REALAR(1) .. REALAR(3)
```

Python command syntax:

```
ierr = opf_intflw_main(ifid, labl, intgar, realar)
```

Fortran command syntax:

```
CALL OPF_INTFLW_MAIN(IFID, LABL, INTGAR, REALAR, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Character*32 LABL	interface flow description made up of, at most, 32 characters (input; '' by default).	
Integer INTGAR (2)	array of 2 elements specifying (input).	
	INTGAR(1)	interface flow type (default value of 1 if new record, current value otherwise)
	INTGAR(1) = 1	MW
	INTGAR(1) = 2	Mvar
	INTGAR(2)	interface flow limit type (default value of 1 if new record, current value otherwise)
	INTGAR(2) = 0	reporting only
	INTGAR(2) = 1	hard limit
	INTGAR(2) = 2	linear soft limit
	INTGAR(2) = 3	quadratic soft limit
Real REALAR (3)	array of 3 elements specifying (input).	
	REALAR(1)	maximum interface flow, in physical units (default value of 0.0 if new record, current value otherwise)
	REALAR(2)	minimum interface flow, in physical units (default value of 0.0 if new record, current value otherwise)
	REALAR(3)	soft limit penalty weight (default value of 1.0 if new record, current value otherwise)
Integer IERR	error code (output).	
	IERR = 0	no error occurred

IERR = 1	interface flow constraint table is full
IERR = 2	prerequisite requirements for API are not met
IERR = -1	non-fatal error occurred. Possible warning messages are: - Invalid flow type specified. - Invalid interface flow limit type specified. - Maximum interface flow is less than the minimum interface flow

3.2.30. OPF_INTFLW_RESET

Use this API to remove all interface branches associated with a particular interface flow constraint in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_INTFLW_RESET    IFID
```

Python command syntax:

```
ierr = opf_intflw_reset(ifid)
```

Fortran command syntax:

```
CALL OPF_INTFLW_RESET(IFID, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid interface flow identifier specified
	IERR = 2	prerequisite requirements for API are not met

3.2.31. OPF_LNCEQN_ADJLOAD

Use this API to add a participating adjustable bus load variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_ADJLOAD  IQID  ITBL  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_adjload(iqid, itbl, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_ADJLOAD(IQID, ITBL, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer ITBL	adjustable bus load table identifier (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; default of 1.0 if new record, current value otherwise).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	specified adjustable bus load table does not exist
	IERR = 4	prerequisite requirements for API are not met

3.2.32. OPF_LNCEQN_ADJVAR

Use this API to add a participating adjustable bus shunt variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_ADJVAR  IQID  EIBUS  SHNTID  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_adjvar(iqid, eibus, shntid, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_ADJVAR(IQID, EIBUS, SHNTID, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Character*2 SHNTID	OPF adjustable bus shunt identifier (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; default of 1.0 if new record, current value otherwise).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	invalid bus number specified
	IERR = 4	specified adjustable bus shunt does not exist
	IERR = 5	prerequisite requirements for API are not met

3.2.33. OPF_LNCEQN_BRFLOW

Use this API to add a participating branch flow variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_BRFLOW  IQID  EIBUS  EJBUS  EKBUS  CKTID  FLWID  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_brflow(iqid, eibus, ejbus, ekbus, cktid, flwid, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_BRFLOW(IQID, EIBUS, EJBUS, EKBUS, CKTID, FLWID, COEFF,  
IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).
Integer EIBUS	from bus number (input; no default allowed).
Integer EJBUS	to bus number (input; no default allowed).
Integer EKBUS	third bus number for a three-winding transformer and zero for a two-winding transformer (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Character*1 FLWID	branch flow identifier (input; no default allowed).
Real COEFF	value of the coefficient associated with the equation variable. (input; Default value of 1.0 if new record, current value otherwise.).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 specified linear constraint equation does not exist
	IERR = 2 participating equation variable table is full
	IERR = 3 invalid bus number specified
	IERR = 4 specified branch/transformer does not exist
	IERR = 5 specified three-winding transformer does not exist
	IERR = 6 flow constraint does not exist at the specified branch
	IERR = 7 flow constraint does not exist at the specified three-winding transformer
	IERR = 8 prerequisite requirements for API are not met

3.2.34. OPF_LNCEQN_INTFLOW

Use this API to add a participating interface flow constraint variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_INTFLOW    IQID  ITBL  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_intflow(iqid, itbl, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_INTFLOW(IQID, ITBL, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer ITBL	interface flow identifier (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise.).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	specified interface identifier does not exist
	IERR = 4	prerequisite requirements for API are not met

3.2.35. OPF_LNCEQN_MAIN

Use this API to add a linear constraint dependency record to the working case. It may also be used to modify an existing linear constraint dependency record.

This API must be invoked prior to adding any participating linear constraint equation variable records to the specified linear constraint dependency equation.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_MAIN  IQID  LABL  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = opf_lnceqn_main(iqid, labl, realar)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_MAIN(IQID, LABL, REALAR, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Character*12 LABL	linear constraint description made up of, at most, 12 characters (input; '' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	maximum constraint slack value (Default value of 1.0 if new record, current value otherwise. by default)
	REALAR(2)	minimum constraint slack value (Default value of 1.0 if new record, current value otherwise. by default)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Possible warning messages are: - Maximum linear constraint slack is less than the minimum linear constraint slack
	IERR = 0	no error occurred
	IERR = 1	linear constraint table is full
	IERR = 2	prerequisite requirements for API are not met

3.2.36. OPF_LNCEQN_PGEN

Use this API to add a participating active power dispatch variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_PGEN  IQID  ITBL  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_pgen(iqid, itbl, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_PGEN(IQID, ITBL, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer ITBL	active power dispatch table number (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise.).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	invalid active power dispatch table number specified
	IERR = 4	prerequisite requirements for API are not met

3.2.37. OPF_LNCEQN_QGEN

Use this API to add a participating reactive power dispatch variable of a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_QGEN  IQID  EIBUS  GENID  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_qgen(iqid, eibus, genid, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_QGEN(IQID, EIBUS, GENID, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Character*2 GENID	machine identifier (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise.).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	specified bus does not exist
	IERR = 4	specified machine does not exist at bus
	IERR = 5	prerequisite requirements for API are not met

3.2.38. OPF_LNCEQN_RESET

Use this API to remove all participating variables from a particular OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_RESET    IQID
```

Python command syntax:

```
ierr = opf_lnceqn_reset(iqid)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_RESET(IQID, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	Invalid linear constraint identifier specified
	IERR = 2	prerequisite requirements for API are not met

3.2.39. OPF_LNCEQN_SWSHUNT

This API routine is obsolete. It has been replaced by the API routine [opf_lnceqn_swshunt_2](#).

Use this API to add a participating switched shunt variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_SWSHUNT    IQID    EIBUS    COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_swshunt(iqid, eibus, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_SWSHUNT(IQID, EIBUS, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).
Integer EIBUS	bus number (input; no default allowed).
Real COEFF	value of the coefficient associated with the equation variable (input; Default of 1.0 if new record, current value otherwise).
Integer IERR	error code (output).

3.2.40. OPF_LNCEQN_SWSHUNT_2

Use this API to add a participating switched shunt variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_SWSHUNT_2    IQID  EIBUS  SWSHID COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_swshunt_2(iqid, eibus, swshid, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_SWSHUNT_2(IQID, EIBUS, SWSHID, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
character*2 SWSHID	Switched shunt identifier (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default of 1.0 if new record, current value otherwise).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	invalid bus number specified
	IERR = 4	specified switched shunt does not exist
	IERR = 5	prerequisite requirements for API are not met

3.2.41. OPF_LNCEQN_TRAN

Use this API to add a participating transformer control variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_TRAN  IQID  EIBUS  EJBUS  EKBUS  CKTID  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_tran(iqid, eibus, ejbus, ekbus, cktid, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_TRAN(IQID, EIBUS, EJBUS, EKBUS, CKTID, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	from bus number (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Integer EKBUS	third bus number if a three-winding transformer is specified and zero for a two-winding transformer (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	invalid bus number specified
	IERR = 3	specified branch/transformer does not exist
	IERR = 4	specified three-winding transformer does not exist
	IERR = 5	specified branch is not a transformer
	IERR = 6	specified branch is not a three-winding transformer
	IERR = 8	prerequisite requirements for API are not met

3.2.42. OPF_LNCEQN_VANG

This API routine is obsolete. It has been replaced by the API routine [opf_lnceqn_vang_2](#).

Use this API to add a participating bus voltage angle variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_VANG  IQID  EIBUS  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_vang(iqid, eibus, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_VANG(IQID, EIBUS, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	invalid bus number specified
	IERR = 4	prerequisite requirements for API are not met

3.2.43. OPF_LNCEQN_VANG_2

Use this API to add a participating bus voltage angle variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_VANG_2  IQID  EIBUS  ENODE  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_vang_2(iqid, eibus, enode, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_VANG_2(IQID, EIBUS, ENODE, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).
Integer EIBUS	bus number (input; no default allowed).
Integer ENODE	The bus section number or the external node number of one of the nodes in the bus section of interest. Specify 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, the data of the parent bus and not that of the bus sections will be changed. (input).
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 specified linear constraint equation does not exist
	IERR = 2 participating equation variable table is full
	IERR = 3 invalid bus number
	IERR = 4 bus not found
	IERR = 5 invalid node number
	IERR = 6 node not found in substation of bus
	IERR = 7 node not connected to any bus section of bus in substation
	IERR = 8 prerequisite requirements for API are not met

3.2.44. OPF_LNCEQN_VMAG

This API routine is obsolete. It has been replaced by the API routine [opf_lnceqn_vmag_2](#).

Use this API to add a participating bus voltage magnitude variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_VMAG  IQID  EIBUS  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_vmag(iqid, eibus, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_VMAG(IQID, EIBUS, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	participating equation variable table is full
	IERR = 3	invalid bus number specified
	IERR = 4	prerequisite requirements for API are not met

3.2.45. OPF_LNCEQN_VMAG_2

Use this API to add a participating bus voltage magnitude variable to a specified linear constraint dependency equation in the working case. It may also be used to modify an existing record.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_OPF_LNCEQN_VMAG_2  IQID  EIBUS  ENODE  COEFF
```

Python command syntax:

```
ierr = opf_lnceqn_vmag_2(iqid, eibus, enode, coeff)
```

Fortran command syntax:

```
CALL OPF_LNCEQN_VMAG_2(IQID, EIBUS, ENODE, COEFF, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).
Integer EIBUS	bus number (input; no default allowed).
Integer ENODE	The bus section number or the external node number of one of the nodes in the bus section of interest. Specify 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, the data of the parent bus and not that of the bus sections will be changed. (input).
Real COEFF	value of the coefficient associated with the equation variable (input; Default value of 1.0 if new record, current value otherwise).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 specified linear constraint equation does not exist
	IERR = 2 participating equation variable table is full
	IERR = 3 invalid bus number
	IERR = 4 bus not found
	IERR = 5 invalid node number
	IERR = 6 node not found in substation of bus
	IERR = 7 node not connected to any bus section of bus in substation
	IERR = 8 prerequisite requirements for API are not met

3.2.46. OPF_LOAD_INDV

Use this API to add an individual OPF bus load data record to the working case. It may also be used to modify an existing bus load data record.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LOAD_INDV  EIBUS  LOADID  INTGAR
```

Python command syntax:

```
ierr = opf_load_indv(eibus, loadid, intgar)
```

Fortran command syntax:

```
CALL OPF_LOAD_INDV(EIBUS, LOADID, INTGAR, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 LOADID	bus load identifier (input; no default allowed).
Integer INTGAR	adjustable bus load table cross reference number (input; Default value of 0 if new record, current value otherwise).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified load does not exist
	IERR = 3 prerequisite requirements for API are not met

3.2.47. OPF_LOAD_SUBSYS

Use this API to add or modify all OPF bus load data records in a specified subsystem of the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_LOAD_SUBSYS  SID  ALL  INTGAR(1)  INTGAR(2)
```

Python command syntax:

```
ierr = opf_load_subsys(sid, all, intgar)
```

Fortran command syntax:

```
CALL OPF_LOAD_SUBSYS(SID, ALL, INTGAR, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses, use existing data values.
	ALL = 2	process all buses, use default data values.
Integer INTGAR (2)	array of 2 elements specifying (input).	
	INTGAR(1)	bus load table cross reference number (default value of 0, current value otherwise)
	INTGAR(2)	indicates which bus types should be processed (default treatment same as value of 0)
	INTGAR(2) = 0	all buses in subsystem
	INTGAR(2) = 1	only Type 1 buses in subsystem
	INTGAR(2) = 2	only Type 2 and 3 buses in subsystem
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.48. OPF_PERRSV_GEN

Use this API to add a participating generation reserve unit to a previously defined period reserve constraint in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_PERRSV_GEN  RSVID  EIBUS  GENID
```

Python command syntax:

```
ierr = opf_perrsv_gen(rsvid, eibus, genid)
```

Fortran command syntax:

```
CALL OPF_PERRSV_GEN(RSVID, EIBUS, GENID, IERR)
```

Where:

Integer RSVID	period reserve identifier (1 through 15) (input; no default allowed).
Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid period reserve identifier specified
	IERR = 2 invalid bus number specified
	IERR = 3 specified machine does not exist
	IERR = 4 specified unit does not have any generator reserve data defined
	IERR = 5 specified unit is already participating in the reserve constraint
	IERR = 6 generator reserve participating unit table full
	IERR = 7 prerequisite requirements for API are not met

3.2.49. OPF_PERRSV_MAIN

Use this API to add a period reserve constraint record to the working case. It may also be used to modify an existing period reserve constraint record.

This API must be invoked prior to adding any participating generator reserve units (via OPF_PERRSV_GEN) to a specified period reserve constraint.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_PERRSV_MAIN  RSVID  STATUS  REALAR(1)  REALAR(2)
```

Python command syntax:

```
ierr = opf_perrsv_main(rsvid, status, realar)
```

Fortran command syntax:

```
CALL OPF_PERRSV_MAIN(RSVID, STATUS, REALAR, IERR)
```

Where:

Integer RSVID	a valid period reserve identifier (1 through 15) (input; no default allowed).	
Integer STATUS	status of the period reserve constraint (input; default value of 1 if new record, current value otherwise).	
	status = 0	out of service.
	status = 1	in service.
Real REALAR (2)	array of 2 elements specifying The value for each is as follows(input).	
	REALAR(1)	reserve limit, in MW (default value of 0.0 if new record, current value otherwise)
	REALAR(2)	period, in minutes (default value of 9999.0 if new record, current value otherwise)
Integer IERR	error code (output).	
	IERR = -1	non-fatal error occurred. Possible warning messages are: - Invalid period reserve status specified
	IERR = 0	no error occurred
	IERR = 1	invalid period reserve identifier specified
	IERR = 2	prerequisite requirements for API are not met

3.2.50. OPF_PERRSV_RESET

Use this API to remove all generation reserve units associated with a particular period reserve constraint in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_OPF_PERRSV_RESET    RSVID
```

Python command syntax:

```
ierr = opf_perrsv_reset(rsvid)
```

Fortran command syntax:

```
CALL OPF_PERRSV_RESET(RSVID, IERR)
```

Where:

Integer RSVID	period reserve identifier (1 through 15) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid period reserve identifier specified
	IERR = 2	prerequisite requirements for API are not met

3.2.51. PURGE_ALL_OPF_DATA

Use this API to purge and re-initialize all OPF data records in the working case. Unlike the NEWOPF_API call, any OPF data in the working case will be purged and re-initialized.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_ALL_OPF_DATA
```

Python command syntax:

```
ierr = purge_all_opf_data()
```

Fortran command syntax:

```
CALL PURGE_ALL_OPF_DATA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

3.2.52. PURGE_OPF_ADJBRX_INDV

Use this API to purge an individual adjustable branch reactance data record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_ADJBRX_INDV  EIBUS  EJBUS  CKTID
```

Python command syntax:

```
ierr = purge_opf_adjbrx_indv(eibus, ejbus, cktid)
```

Fortran command syntax:

```
CALL PURGE_OPF_ADJBRX_INDV_2(EIBUS, EJBUS, CKTID, IERR)
```

Where:

Integer EIBUS	from bus number (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	specified branch does not exist
	IERR = 3	prerequisite requirements for API are not met
	IERR = 4	specified branch cannot be a transformer

3.2.53. PURGE_OPF_ADJBRX_SUBSYS

Use this API to purge all OPF branch reactance data records from a specified subsystem of the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_ADJBRX_SUBSYS    SID  ALL
```

Python command syntax:

```
ierr = purge_opf_adjbrx_subsys(sid, all)
```

Fortran command syntax:

```
CALL PURGE_OPF_ADJBRX_SUBSYS_2(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.54. PURGE_OPF_ADJLOAD_TBL

Use this API to purge an individual adjustable bus load table from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_ADJLOAD_TBL    TBL
```

Python command syntax:

```
ierr = purge_opf_adjload_tbl(tbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_ADJLOAD_TBL_2(TBL, IERR)
```

Where:

Integer TBL	adjustable bus load table number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	adjustable bus load table does not exist
	IERR = 2	load table still referenced by bus load(s) -- unable to delete
	IERR = 3	prerequisite requirements for API are not met

3.2.55. PURGE_OPF_ADJVAR_INDV

This API routine is obsolete. It has been replaced by the API routine [purge_opf_adjvar_indv_3](#).

Use this API to purge an individual OPF adjustable bus shunt data record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_ADJVAR_INDV    EIBUS    SHNTID
```

Python command syntax:

```
ierr = purge_opf_adjvar_indv(eibus, shntid)
```

Fortran command syntax:

```
CALL PURGE_OPF_ADJVAR_INDV_2(EIBUS, SHNTID, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 SHNTID	bus shunt identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 adjustable bus shunt identifier is more than two characters
	IERR = 2 invalid bus number specified
	IERR = 3 blank adjustable bus shunt identifier is invalid
	IERR = 4 OPF adjustable bus shunt at bus not found
	IERR = 5 prerequisite requirements for API are not met

3.2.56. PURGE_OPF_ADJVAR_INDV_3

Use this API to purge an individual OPF adjustable bus shunt data record from the working case.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_PURGE_OPF_ADJVAR_INDV_3  EIBUS  ENOD  SHNTID
```

Python command syntax:

```
ierr = purge_opf_adjvar_indv_3(eibus, enod, shntid)
```

Fortran command syntax:

```
CALL PURGE_OPF_ADJVAR_INDV_3(EIBUS, ENOD, SHNTID, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Integer ENOD	The section number or the node number of one of the nodes in the bus section of interest. Specify 0 (zero) if the bus is represented by a single bus section. If 0 is specified and the bus is represented by multiple bus sections, then the data of the parent bus and not that of one of the bus sections is changed. (input).
Character*2 SHNTID	bus shunt identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 adjustable bus shunt identifier is more than two characters
	IERR = 2 invalid bus number specified
	IERR = 3 blank adjustable bus shunt identifier is invalid
	IERR = 4 OPF adjustable bus shunt at bus not found
	IERR = 5 prerequisite requirements for API are not met
	IERR = 6 bus not found
	IERR = 7 invalid node number
	IERR = 8 bus does not belong to a substation
	IERR = 9 node is not found in the substation
	IERR = 10 node is not connected to any bus section of bus

3.2.57. PURGE_OPF_ADJVAR_SUBSYS

Use this API to purge all OPF adjustable bus shunt records from a specified subsystem of the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_ADJVAR_SUBSYS  SID  ALL  SHNTID
```

Python command syntax:

```
ierr = purge_opf_adjvar_subsys(sid, all, shntid)
```

Fortran command syntax:

```
CALL PURGE_OPF_ADJVAR_SUBSYS_2(SID, ALL, SHNTID, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Character*2 SHNTID	Adjustable bus shunt identifier. If blank then all adjustable bus shunts in subsystem will be deleted. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 adjustable bus shunt identifier is more than two characters IERR = 2 invalid SID value or subsystem SID is not defined IERR = 3 invalid ALL value IERR = 4 prerequisite requirements for API are not met

3.2.58. PURGE_OPF_APDSP_TBL

Use this API to purge an individual active power dispatch table record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_APDSP_TBL    TBL
```

Python command syntax:

```
ierr = purge_opf_apdsp_tbl(tbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_APDSP_TBL_2(TBL, IERR)
```

Where:

Integer TBL	active power dispatch table number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	active power dispatch table does not exist
	IERR = 2	active power dispatch table still referenced -- unable to delete
	IERR = 3	prerequisite requirements for API are not met

3.2.59. PURGE_OPF_BRFLW_3WT

Use this API to purge an individual flow constraint record of a three-winding transformer from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_BRFLW_3WT  EIBUS  EJBUS  EKBUS  CKTID  BFLWID
```

Python command syntax:

```
ierr = purge_opf_brflw_3wt(eibus, ejbus, ekbus, cktid, bflwid)
```

Fortran command syntax:

```
CALL PURGE_OPF_BRFLW_3WT_2(EIBUS, EJBUS, EKBUS, CKTID, BFLWID, IERR)
```

Where:

Integer EIBUS	from bus of the winding from which the flow constraint is being purged (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Integer EKBUS	third bus number (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Character*1 BFLWID	branch flow constraint identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	specified three-winding transformer does not exist
	IERR = 3	specified winding of three-winding transformer not found
	IERR = 4	prerequisite requirements for API are not met

3.2.60. PURGE_OPF_BRFLW_BRN

Use this API to purge an individual branch or two-winding transformer flow constraint record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_BRFLW_BRN  EIBUS  EJBUS  CKTID  BFLWID
```

Python command syntax:

```
ierr = purge_opf_brflw_brn(eibus, ejbus, cktid, bflwid)
```

Fortran command syntax:

```
CALL PURGE_OPF_BRFLW_BRN_2(EIBUS, EJBUS, CKTID, BFLWID, IERR)
```

Where:

Integer EIBUS	from bus number (input; no default allowed).
Integer EJBUS	to bus number (input; no default allowed).
Character*2 CKTID	circuit identifier (input; no default allowed).
Character*1 BFLWID	branch flow constraint identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified branch does not exist
	IERR = 3 prerequisite requirements for API are not met

3.2.61. PURGE_OPF_BRFLW_SUBSYS

Use this API to purge all branch flow data records in a specified subsystem in the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_BRFLW_SUBSYS SID ALL BFLWID
```

Python command syntax:

```
ierr = purge_opf_brflw_subsys(sid, all, bflwid)
```

Fortran command syntax:

```
CALL PURGE_OPF_BRFLW_SUBSYS_2(SID, ALL, BFLWID, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).
Integer ALL	all buses or specified subsystem flag (input; no default allowed). ALL = 0 process only specified buses. ALL = 1 process all buses.
Character*1 BFLWID	branch flow identifier (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 prerequisite requirements for API are not met

3.2.62. PURGE_OPF_BUS_INDV

This API routine is obsolete. It has been replaced by the API routine [purge_opf_bus_indv_3](#).

Use this API to purge (re-initialize) OPF bus voltage magnitude data for an individual record in the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_BUS_INDV    EIBUS
```

Python command syntax:

```
ierr = purge_opf_bus_indv(eibus)
```

Fortran command syntax:

```
CALL PURGE_OPF_BUS_INDV_2(EIBUS, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	prerequisite requirements for API are not met

3.2.63. PURGE_OPF_BUS_INDV_3

Use this API to purge (re-initialize) OPF bus voltage magnitude data for an individual bus or bus section record in the working case.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_PURGE_OPF_BUS_INDV_3    EIBUS ENOD
```

Python command syntax:

```
ierr = purge_opf_bus_indv_3(eibus, enod)
```

Fortran command syntax:

```
CALL PURGE_OPF_BUS_INDV_3(EIBUS, ENOD, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).	
Integer ENOD	The bus section number or the external node number of one of the nodes in the bus sections of interest. Specify 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, then the data of parent bus and not that of one of the bus sections is changed. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	prerequisite requirements for API are not met

3.2.64. PURGE_OPF_BUS_SUBSYS

Use this API to purge (re-initialize) OPF bus attribute data for all records in a specified subsystem of the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_BUS_SUBSYS    SID  ALL
```

Python command syntax:

```
ierr = purge_opf_bus_subsys(sid, all)
```

Fortran command syntax:

```
CALL PURGE_OPF_BUS_SUBSYS_2(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses, use existing data values.
Integer IERR	ALL = 2	process all buses, use default data values.
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.65. PURGE_OPF_CSTTBL_LIN

Use this API to purge an optimal power flow linear cost curve record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_CSTTBL_LIN    TBL
```

Python command syntax:

```
ierr = purge_opf_csttbl_lin(tbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_CSTTBL_LIN_2(TBL, IERR)
```

Where:

Integer TBL	linear cost curve table number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear cost table does not exist
	IERR = 2	prerequisite requirements for API are not met

3.2.66. PURGE_OPF_CSTTBL_POLY

Use this API to purge an optimal power flow polynomial and exponential cost curve record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_CSTTBL_POLY    TBL
```

Python command syntax:

```
ierr = purge_opf_csttbl_poly(tbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_CSTTBL_POLY_2(TBL, IERR)
```

Where:

Integer TBL	polynomial and exponential cost curve table number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified polynomial cost table does not exist
	IERR = 2	prerequisite requirements for API are not met

3.2.67. PURGE_OPF_CSTTBL_QUAD

Use this API to purge an optimal power flow quadratic cost curve record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_CSTTBL_QUAD    TBL
```

Python command syntax:

```
ierr = purge_opf_csttbl_quad(tbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_CSTTBL_QUAD_2(TBL, IERR)
```

Where:

Integer TBL	quadratic cost curve table number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified quadratic cost table does not exist
	IERR = 2	prerequisite requirements for API are not met

3.2.68. PURGE_OPF_GENDSP_INDV

Use this API to purge generator dispatch data for an individual record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_GENDSP_INDV  EIBUS  GENID
```

Python command syntax:

```
ierr = purge_opf_gendsp_indv(eibus, genid)
```

Fortran command syntax:

```
CALL PURGE_OPF_GENDSP_INDV_2(EIBUS, GENID, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified machine does not exist
	IERR = 3 prerequisite requirements for API are not met

3.2.69. PURGE_OPF_GENDSP_SUBSYS

Use this API to purge generator dispatch data for all records from a specified subsystem of the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_GENDSP_SUBSYS  SID  ALL
```

Python command syntax:

```
ierr = purge_opf_gendsp_subsys(sid, all)
```

Fortran command syntax:

```
CALL PURGE_OPF_GENDSP_SUBSYS_2(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses, use existing data values.
Integer IERR	ALL = 2	process all buses, use default data values.
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.70. PURGE_OPF_GENRSV_INDV

Use this API to purge an individual optimal power flow generator reserve data record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_GENRSV_INDV  EIBUS  GENID
```

Python command syntax:

```
ierr = purge_opf_genrsv_indv(eibus, genid)
```

Fortran command syntax:

```
CALL PURGE_OPF_GENRSV_INDV_2(EIBUS, GENID, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified machine does not exist
	IERR = 3 prerequisite requirements for API are not met

3.2.71. PURGE_OPF_GENRSV_SUBSYS

Use this API to purge all OPF generator reserve records in a specified subsystem from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_GENRSV_SUBSYS    SID  ALL
```

Python command syntax:

```
ierr = purge_opf_genrsv_subsys(sid, all)
```

Fortran command syntax:

```
CALL PURGE_OPF_GENRSV_SUBSYS_2(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.72. PURGE_OPF_GEN_RCAP_INDV

Use this API to purge an individual OPF generation reactive capability data record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_GEN_RCAP_INDV    EIBUS    GENID
```

Python command syntax:

```
ierr = purge_opf_gen_rcap_indv(eibus, genid)
```

Fortran command syntax:

```
CALL PURGE_OPF_GEN_RCAP_INDV_2(EIBUS, GENID, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).
Character*2 GENID	machine identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid bus number specified
	IERR = 2 specified machine does not exist
	IERR = 3 prerequisite requirements for API are not met

3.2.73. PURGE_OPF_GEN_RCAP_SUBSYS

Use this API to purge all OPF generator reactive capability records in a specified subsystem from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_GEN_RCAP_SUBSYS  SID  ALL
```

Python command syntax:

```
ierr = purge_opf_gen_rcap_subsys(sid, all)
```

Fortran command syntax:

```
CALL PURGE_OPF_GEN_RCAP_SUBSYS_2(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.74. PURGE_OPF_INTFLW

Use this API to purge an OPF interface flow constraint record, including all of its participating branches, from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_INTFLW    IFID
```

Python command syntax:

```
ierr = purge_opf_intflw(ifid)
```

Fortran command syntax:

```
CALL PURGE_OPF_INTFLW_2(IFID, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	interface flow identifier not found
	IERR = 2	unable to remove interface flow record due to participation in linear constraint record
	IERR = 3	prerequisite requirements for API are not met

3.2.75. PURGE_OPF_INTFLW_3WT

Use this API to remove a participating three-winding transformer winding from a specified OPF interface flow constraint in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_INTFLW_3WT  IFID  EIBUS  EJBUS  EKBUS  CKTID
```

Python command syntax:

```
ierr = purge_opf_intflw_3wt(ifid, eibus, ejbus, ekbus, cktid)
```

Fortran command syntax:

```
CALL PURGE_OPF_INTFLW_3WT(IFID, EIBUS, EJBUS, EKBUS, CKTID, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Integer EIBUS	from bus number The value of EIBUS indicates the from bus of the winding to be removed from the flow constraint (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Integer EKBUS	third bus number (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid interface flow identifier specified
	IERR = 2	invalid bus number specified
	IERR = 3	specified three-winding transformer does not exist
	IERR = 4	prerequisite requirements for API are not met

3.2.76. PURGE_OPF_INTFLW_BRN

Use this API to remove a participating branch from a specified OPF interface flow constraint in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_INTFLW_BRN  IFID  EIBUS  EJBUS  CKTID
```

Python command syntax:

```
ierr = purge_opf_intflw_brn(ifid, eibus, ejbus, cktid)
```

Fortran command syntax:

```
CALL PURGE_OPF_INTFLW_BRN(IFID, EIBUS, EJBUS, CKTID, IERR)
```

Where:

Integer IFID	interface flow identifier (input; no default allowed).	
Integer EIBUS	from bus number (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid interface flow identifier specified
	IERR = 2	invalid bus number specified
	IERR = 3	specified branch does not exist
	IERR = 4	prerequisite requirements for API are not met

3.2.77. PURGE_OPF_LNCEQN

Use this API to purge an OPF linear constraint dependency record, including all of its participating variables, from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN    IQID
```

Python command syntax:

```
ierr = purge_opf_lnceqn(iqid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_2(IQID, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	linear constraint equation number not found
	IERR = 2	prerequisite requirements for API are not met

3.2.78. PURGE_OPF_LNCEQN_ADJLOAD

Use this API to remove a participating adjustable bus load variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_ADJLOAD    IQID  ITBL
```

Python command syntax:

```
ierr = purge_opf_lnceqn_adjload(iqid, itbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_ADJLOAD(IQID, ITBL, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer ITBL	adjustable bus load table identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	specified adjustable bus load table does not exist
	IERR = 3	prerequisite requirements for API are not met

3.2.79. PURGE_OPF_LNCEQN_ADJVAR

Use this API to remove a participating adjustable bus shunt variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_ADJVAR  IQID  EIBUS  SHNTID
```

Python command syntax:

```
ierr = purge_opf_lnceqn_adjvar(iqid, eibus, shntid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_ADJVAR(IQID, EIBUS, SHNTID, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Character*2 SHNTID	adjustable bus shunt identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number specified
	IERR = 3	specified adjustable bus shunt does not exist
	IERR = 4	prerequisite requirements for API are not met

3.2.80. PURGE_OPF_LNCEQN_BRFLOW

Use this API to remove a participating branch flow variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_BRFLOW IQID EIBUS EJBUS EKBUS CKTID FLWID
```

Python command syntax:

```
ierr = purge_opf_lnceqn_brflow(iqid, eibus, ejbus, ekbus, cktid, flwid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_BRFLOW(IQID, EIBUS, EJBUS, EKBUS, CKTID, FLWID,  
IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	from bus number (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Integer EKBUS	third bus number for a three-winding transformer and zero for a two-winding transformer (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Character*1 FLWID	branch flow identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number specified
	IERR = 3	specified branch/transformer does not exist
	IERR = 4	specified three-winding transformer does not exist
	IERR = 5	flow constraint does not exist at the specified branch
	IERR = 6	flow constraint does not exist at the specified three-winding transformer
	IERR = 7	prerequisite requirements for API are not met

3.2.81. PURGE_OPF_LNCEQN_INTFLOW

Use this API to remove a participating interface flow constraint variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_INTFLOW    IQID  ITBL
```

Python command syntax:

```
ierr = purge_opf_lnceqn_intflow(iqid, itbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_INTFLOW(IQID, ITBL, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer ITBL	interface flow identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	specified interface identifier does not exist
	IERR = 3	prerequisite requirements for API are not met

3.2.82. PURGE_OPF_LNCEQN_PGEN

Use this API to remove a participating active power dispatch variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_PGEN    IQID  ITBL
```

Python command syntax:

```
ierr = purge_opf_lnceqn_pgen(iqid, itbl)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_PGEN(IQID, ITBL, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer ITBL	active power dispatch table number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid active power dispatch table number specified
	IERR = 3	prerequisite requirements for API are not met

3.2.83. PURGE_OPF_LNCEQN_QGEN

Use this API to remove a participating reactive power dispatch variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_QGEN  IQID  EIBUS  GENID
```

Python command syntax:

```
ierr = purge_opf_lnceqn_qgen(iqid, eibus, genid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_QGEN(IQID, EIBUS, GENID, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Character*2 GENID	machine identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	specified bus does not exist
	IERR = 3	specified machine does not exist at bus
	IERR = 4	prerequisite requirements for API are not met

3.2.84. PURGE_OPF_LNCEQN_SWSHUNT

This API routine is obsolete. It has been replaced by the API routine [purge_opf_lnceqn_swshunt_2](#).

Use this API to remove a participating switched shunt variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_SWSHUNT    IQID  EIBUS
```

Python command syntax:

```
ierr = purge_opf_lnceqn_swshunt(iqid, eibus)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_SWSHUNT(IQID, EIBUS, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).
Integer EIBUS	bus number (input; no default allowed).
Integer IERR	error code (output).

3.2.85. PURGE_OPF_LNCEQN_SWSHUNT_2

Use this API to remove a participating switched shunt variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_SWSHUNT_2    IQID  EIBUS  SWSHID
```

Python command syntax:

```
ierr = purge_opf_lnceqn_sws hunt_2(iqid, eibus, swshid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_SWSHUNT_2(IQID, EIBUS, SWSHID, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
character*2 SWSHID	Switched shunt identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number specified
	IERR = 3	specified switched shunt does not exist
	IERR = 4	prerequisite requirements for API are not met

3.2.86. PURGE_OPF_LNCEQN_TRAN

Use this API to remove a participating transformer control variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_TRAN IQID EIBUS EJBUS EKBUS CKTID
```

Python command syntax:

```
ierr = purge_opf_lnceqn_tran(iqid, eibus, ejbus, ekbus, cktid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_TRAN(IQID, EIBUS, EJBUS, EKBUS, CKTID, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	from bus number (input; no default allowed).	
Integer EJBUS	to bus number (input; no default allowed).	
Integer EKBUS	third bus number if a three-winding transformer is specified and zero for a two-winding transformer (input; no default allowed).	
Character*2 CKTID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number specified
	IERR = 3	specified branch/transformer does not exist
	IERR = 4	specified three-winding transformer does not exist
	IERR = 5	specified branch is not a transformer
	IERR = 6	specified branch is not a three-winding transformer
	IERR = 7	prerequisite requirements for API are not met

3.2.87. PURGE_OPF_LNCEQN_VANG

This API routine is obsolete. It has been replaced by the API routine [purge_opf_lnceqn_vang_2](#).

Use this API to remove a participating bus voltage angle variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_VANG    IQID  EIBUS
```

Python command syntax:

```
ierr = purge_opf_lnceqn_vang(iqid, eibus)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_VANG(IQID, EIBUS, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number specified
	IERR = 3	prerequisite requirements for API are not met

3.2.88. PURGE_OPF_LNCEQN_VANG_2

Use this API to remove a participating bus voltage angle variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_VANG_2  IQID  EIBUS  ENODE
```

Python command syntax:

```
ierr = purge_opf_lnceqn_vang_2(iqid, eibus, enode)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_VANG_2(IQID, EIBUS, ENODE, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Integer ENODE	The bus section number or the external node number of one of the nodes in the bus section of interest. Specify 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, the data of the parent bus and not that of the bus sections will be changed. (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number
	IERR = 3	prerequisite requirements for API are not met
	IERR = 4	bus not found
	IERR = 5	invalid node number
	IERR = 6	node not found in substation of bus
	IERR = 7	node not connected to any bus section of bus in substation

3.2.89. PURGE_OPF_LNCEQN_VMAG

This API routine is obsolete. It has been replaced by the API routine [purge_opf_lnceqn_vmag_2](#).

Use this API to remove a participating bus voltage magnitude variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_VMAG    IQID  EIBUS
```

Python command syntax:

```
ierr = purge_opf_lnceqn_vmag(iqid, eibus)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_VMAG(IQID, EIBUS, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number specified
	IERR = 3	prerequisite requirements for API are not met

3.2.90. PURGE_OPF_LNCEQN_VMAG_2

Use this API to remove a participating bus voltage magnitude variable from a specified OPF linear constraint dependency equation in the working case.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_PURGE_OPF_LNCEQN_VMAG_2  IQID  EIBUS  ENODE
```

Python command syntax:

```
ierr = purge_opf_lnceqn_vmag_2(iqid, eibus, enode)
```

Fortran command syntax:

```
CALL PURGE_OPF_LNCEQN_VMAG_2(IQID, EIBUS, ENODE, IERR)
```

Where:

Integer IQID	linear constraint equation identification number (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Integer ENODE	The bus section number or the external node number of one of the nodes in the bus section of interest. Specify 0 if bus is represented by a single bus section. If 0 is specified and bus is represented by multiple bus sections, the data of the parent bus and not that of the bus sections will be changed. (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	specified linear constraint equation does not exist
	IERR = 2	invalid bus number
	IERR = 3	prerequisite requirements for API are not met
	IERR = 4	bus not found
	IERR = 5	invalid node number
	IERR = 6	node not found in substation of bus
	IERR = 7	node not connected to any bus section of bus in substation

3.2.91. PURGE_OPF_LOAD_INDV

Use this API to purge (re-initialize) an individual OPF bus load data record from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LOAD_INDV    EIBUS    LOADID
```

Python command syntax:

```
ierr = purge_opf_load_indv(eibus, loadid)
```

Fortran command syntax:

```
CALL PURGE_OPF_LOAD_INDV_2(EIBUS, LOADID, IERR)
```

Where:

Integer EIBUS	bus number (input; no default allowed).	
Character*2 LOADID	bus load identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid bus number specified
	IERR = 2	specified load does not exist
	IERR = 3	prerequisite requirements for API are not met

3.2.92. PURGE_OPF_LOAD_SUBSYS

Use this API to purge (re-initialize) all OPF bus load data records in a specified subsystem of the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_LOAD_SUBSYS   SID   ALL
```

Python command syntax:

```
ierr = purge_opf_load_subsys(sid, all)
```

Fortran command syntax:

```
CALL PURGE_OPF_LOAD_SUBSYS_2(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem ID from 0 to 11. A subsystem must have been previously defined (input; no default allowed).	
Integer ALL	all buses or specified subsystem flag (input; no default allowed).	
	ALL = 0	process only specified buses.
	ALL = 1	process all buses.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

3.2.93. PURGE_OPF_PERRSV

Use this API to purge an OPF period reserve constraint record and its association with participating reserve units from the working case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_PERRSV    RSVID
```

Python command syntax:

```
ierr = purge_opf_perrsv(rsvid)
```

Fortran command syntax:

```
CALL PURGE_OPF_PERRSV_2(RSVID, IERR)
```

Where:

Integer RSVID	a valid period reserve identifier (1 through 15) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid period reserve identifier specified
	IERR = 2	prerequisite requirements for API are not met

3.2.94. PURGE_OPF_PERRSV_GEN

Use this API to remove a participating period reserve unit from a specified OPF period reserve constraint.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PURGE_OPF_PERRSV_GEN  RSVID  EIBUS  GENID
```

Python command syntax:

```
ierr = purge_opf_perrsv_gen(rsvid, eibus, genid)
```

Fortran command syntax:

```
CALL PURGE_OPF_PERRSV_GEN(RSVID, EIBUS, GENID, IERR)
```

Where:

Integer RSVID	a valid period reserve identifier (1 through 15) (input; no default allowed).	
Integer EIBUS	bus number (input; no default allowed).	
Character*2 GENID	machine identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	period reserve constraint does not exist
	IERR = 2	bus not found
	IERR = 3	machine not found
	IERR = 4	machine does not have generator reserve data defined
	IERR = 5	prerequisite requirements for API are not met

Optimal Power Flow Data Changing APIs contains API routines specific to adding, modifying, and deleting optimal power flow data.

Chapter 4

Fault Analysis

This chapter describes the API routines used in PSS®E Fault Analysis, also called PSS®E Short Circuit.

4.1. Fault Analysis Operation

4.1.1. ANSI

This API routine is obsolete. It has been replaced by the API routine [ansi_2](#).

Use this API to calculate fault currents according to the ANSI standard (activity ANSI). To designate fault specification data as part of the API's calling sequence, INARG must be positive; to designate fault specification data in an ANSI Fault Specification Data input file, INARG must be zero and the filename specified as FILARG.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ANSI  OPTIONS(1)..OPTIONS(3)  VALUES(1)..VALUES(4)
          INARG  BUSARY(1)..BUSARY(INARG)  VLTARY(1)..VLTARY(INARG)
          CPTARY(1)..CPTARY(INARG)  FILARG
```

Python command syntax:

```
ierr = ansi(options, values, inarg, busary, vltary, cptary, filarg)
```

Fortran command syntax:

```
CALL ANSIAPI(OPTIONS, VALUES, INARG, BUSARY, VLTARY, CPTARY, FILARG, IERR)
```

Where:

Integer OPTIONS (3)	array of 3 elements specifying solution and reporting options(input).
OPTIONS(1)	transformer impedance correction option (1 by default)
OPTIONS(1) = 0	do not apply to zero sequence
OPTIONS(1) = 1	apply to zero sequence
OPTIONS(2)	set of ANSI decrement factors to use (1 by default)
OPTIONS(2) = 0	account for dc decrement only (use ANSI table 3)
OPTIONS(2) = 1	account for ac and dc decrements (use ANSI tables 1 and 2)
OPTIONS(3)	option (0 by default)
OPTIONS(3) = 0	summary output using ANSI X only, report format (blank delimited output fields)
OPTIONS(3) = 1	summary output using ANSI X only, spreadsheet input format (comma delimited output fields)
OPTIONS(3) = 2	detailed output using ANSI X only
OPTIONS(3) = 3	detailed output using ANSI R and X
OPTIONS(3) = 4	summary output using ANSI R and X, report format (blank delimited output fields)

	OPTIONS(3) = 5	summary output using ANSI R and X, spreadsheet input format (comma delimited output fields)
Real VALUES (4)	array of 4 elements specifying divisors for calculating resistances of network elements where resistance is zero in the working case(input).	
	VALUES(1)	used for branches in the positive sequence network (40.0 by default)
	VALUES(2)	used for machines in the positive sequence network (80.0 by default)
	VALUES(3)	used for branches in the zero sequence network (40.0 by default)
	VALUES(4)	used for machines in the zero sequence network (80.0 by default)
Integer INARG	fault specification option (input; 0 by default).	
	INARG = 0	fault specifications specified in input file.
	INARG > 0	fault specifications specified in calling sequence.
Integer BUSARY (INARG)	a list of faulted buses; ignored if INARG is 0 (if INARG > 0) (input; no default allowed).	
Real VLTARY (INARG)	a list of maximum operating voltages in pu; ignored if INARG is 0 (input; 1.0).	
Real CPTARY (INARG)	a list of contact parting times in seconds; ignored if INARG is 0 (input; 1 cycle).	
Character*260 FILARG	filename of ANSI Fault Specification Data File; ignored if INARG > 0 (if INARG is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	invalid INARG value
	IERR = 4	fault analysis is invalid due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 5	bus type code and series element status inconsistencies
	IERR = 6	error opening file FILARG
	IERR = 7	prerequisite requirements for API are not met

4.1.2. ANSI_2

This API routine is obsolete. It has been replaced by the API routine [ansi_3](#).

This API routine executes the second release of the ANSI fault calculation function. Use this API routine to calculate fault currents according to the ANSI standard (activity ANSI). To designate fault specification data as part of the API's calling sequence, INARG must be positive; to designate fault specification data in an ANSI Fault Specification Data input file, INARG must be zero and the filename specified as FILARG.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ANSI_2  OPTIONS(1)..OPTIONS(5)  VALUES(1)..VALUES(4)
           INARG  BUSARY(1)..BUSARY(INARG)  VLTARY(1)..VLTARY(INARG)
           CPTARY(1)..CPTARY(INARG)  FILARG
```

Python command syntax:

```
ierr = ansi_2(options, values, inarg, busary, vltary, cptary, filarg)
```

Fortran command syntax:

```
CALL ANSI_2(OPTIONS, VALUES, INARG, BUSARY, VLTARY, CPTARY, FILARG, IERR)
```

Where:

Integer OPTIONS (5)	array of 5 elements specifying solution and reporting options(input).
OPTIONS(1)	fault analysis generator reactance option (0 by default)
OPTIONS(1) = 0	use subtransient reactance
OPTIONS(1) = 1	use transient reactance
OPTIONS(1) = 2	use synchronous reactance
OPTIONS(2)	transformer impedance correction option (1 by default)
OPTIONS(2) = 0	do not apply to zero sequence
OPTIONS(2) = 1	apply to zero sequence
OPTIONS(3)	set of ANSI decrement factors to use (1 by default)
OPTIONS(3) = 0	account for dc decrement only (use ANSI table 3)
OPTIONS(3) = 1	account for ac and dc decrements (use ANSI tables 1 and 2)
OPTIONS(4)	option (0 by default)
OPTIONS(4) = 0	summary output using ANSI X only, report format (blank delimited output fields)
OPTIONS(4) = 1	summary output using ANSI X only, spreadsheet input format (comma delimited output fields)
OPTIONS(4) = 2	detailed output using ANSI X only

	OPTIONS(4) = 3	detailed output using ANSI R and X
	OPTIONS(4) = 4	summary output using ANSI R and X, report format (blank delimited output fields)
	OPTIONS(4) = 5	summary output using ANSI R and X, spreadsheet input format (comma delimited output fields)
	OPTIONS(5)	breaker rating option (0 by default)
	OPTIONS(5) = 0	IEEE total current basis
	OPTIONS(5) = 1	IEEE symmetrical current basis
Real VALUES (4)	array of 4 elements specifying divisors for calculating resistances of network elements where resistance is zero in the working case(input).	
	VALUES(1)	used for branches in the positive sequence network (40.0 by default)
	VALUES(2)	used for machines in the positive sequence network (80.0 by default)
	VALUES(3)	used for branches in the zero sequence network (40.0 by default)
	VALUES(4)	used for machines in the zero sequence network (80.0 by default)
Integer INARG	fault specification option (input; 0 by default).	
	INARG = 0	fault specifications specified in input file.
	INARG > 0	fault specifications specified in calling sequence.
Integer BUSARY (INARG)	a list of faulted buses; ignored if INARG is 0 (if INARG > 0) (input; no default allowed).	
Real VLTARY (INARG)	a list of maximum operating voltages in pu; ignored if INARG is 0 (input; 1.0).	
Real CPTARY (INARG)	a list of contact parting times in seconds; ignored if INARG is 0 (input; 1 cycle).	
Character*260 FILARG	filename of ANSI Fault Specification Data File; ignored if INARG > 0 (if INARG is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	invalid INARG value
	IERR = 4	fault analysis is invalid due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 5	bus type code and series element status inconsistencies
	IERR = 6	error opening file FILARG
	IERR = 7	prerequisite requirements for API are not met

4.1.3. ANSI_3

This API routine executes the third release of the ANSI fault calculation function. Use this API routine to calculate fault currents according to the ANSI standard (activity ANSI). To designate fault specification data as part of the API's calling sequence, INARG must be positive; to designate fault specification data in an ANSI Fault Specification Data input file, INARG must be zero and the filename specified as FILARG.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_ANSI_3  OPTIONS(1)..OPTIONS(5)  VALUES(1)..VALUES(4)
           INARG  BUSARY(1)..BUSARY(INARG)  NODARY(1)..NODARY(INARG)
           VLTARY(1)..VLTARY(INARG)  CPTARY(1)..CPTARY(INARG)  FILARG
```

Python command syntax:

```
ierr = ansi_3(options, values, inarg, busary, nodary, vltary, cptary,
              filarg)
```

Fortran command syntax:

```
CALL ANSI_3(OPTIONS, VALUES, INARG, BUSARY, NODARY, VLTARY, CPTARY, FILARG, IERR)
```

Where:

Integer OPTIONS (5)	array of 5 elements specifying solution and reporting options(input).
OPTIONS(1)	fault analysis generator reactance option (0 by default)
OPTIONS(1) = 0	use subtransient reactance
OPTIONS(1) = 1	use transient reactance
OPTIONS(1) = 2	use synchronous reactance
OPTIONS(2)	transformer impedance correction option (1 by default)
OPTIONS(2) = 0	do not apply to zero sequence
OPTIONS(2) = 1	apply to zero sequence
OPTIONS(3)	set of ANSI decrement factors to use (1 by default)
OPTIONS(3) = 0	account for dc decrement only (use ANSI table 3)
OPTIONS(3) = 1	account for ac and dc decrements (use ANSI tables 1 and 2)
OPTIONS(4)	option (0 by default)
OPTIONS(4) = 0	summary output using ANSI X only, report format (blank delimited output fields)
OPTIONS(4) = 1	summary output using ANSI X only, spreadsheet input format (comma delimited output fields)
OPTIONS(4) = 2	detailed output using ANSI X only
OPTIONS(4) = 3	detailed output using ANSI R and X

	OPTIONS(4) = 4	summary output using ANSI R and X, report format (blank delimited output fields)
	OPTIONS(4) = 5	summary output using ANSI R and X, spreadsheet input format (comma delimited output fields)
	OPTIONS(5)	breaker rating option (0 by default)
	OPTIONS(5) = 0	IEEE total current basis
	OPTIONS(5) = 1	IEEE symmetrical current basis
Real VALUES (4)	array of 4 elements specifying divisors for calculating resistances of network elements where resistance is zero in the working case(input).	
	VALUES(1)	used for branches in the positive sequence network (40.0 by default)
	VALUES(2)	used for machines in the positive sequence network (80.0 by default)
	VALUES(3)	used for branches in the zero sequence network (40.0 by default)
	VALUES(4)	used for machines in the zero sequence network (80.0 by default)
Integer INARG	fault specification option (input; 0 by default).	
	INARG = 0	fault specifications specified in input file.
	INARG > 0	fault specifications specified in calling sequence.
Integer BUSARY (INARG)	a list of faulted buses; ignored if INARG is 0 (if INARG > 0) (input; no default allowed).	
Integer NODARY (INARG)	a list of node numbers whose bus sections are to be faulted; ignored if INARG is 0 (if INARG > 0) (input; 0 by default).	
Real VLTARY (INARG)	a list of maximum operating voltages in pu; ignored if INARG is 0 (input; 1.0).	
Real CPTARY (INARG)	a list of contact parting times in seconds; ignored if INARG is 0 (input; 1 cycle).	
Character*260 FILARG	filename of ANSI Fault Specification Data File; ignored if INARG > 0 (if INARG is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	invalid INARG value
	IERR = 4	fault analysis is invalid due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 5	bus type code and series element status inconsistencies
	IERR = 6	error opening file FILARG

IERR = 7

prerequisite requirements for API are not met

4.1.4. ASCC

This API routine is obsolete. It has been replaced by the API routine [ASCC_1A](#).

This API is used to apply a series of faults at various locations in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ASCC  SID  ALL  STATUS(1)..STATUS(10)  RELFILE  FCDFILE
```

Python command syntax:

```
ierr = ascc(sid, all, status, relfile, fcdfile)
```

Fortran command syntax:

```
CALL ASCCNW(SID, ALL, STATUS, RELFILE, FCDFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS (10)	array of 10 elements specifying integer options(input). STATUS(1) Three phase and line-to-ground fault (alias is flt3phlg) (0 by default) STATUS(1) = 0 three phase faults only STATUS(1) = 1 three phase and line-to-ground faults STATUS(2) line-out faults (alias is linout) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-end faults (alias is linend) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) flat conditions option (alias is flatop) (0 by default) STATUS(4) = 0 pre-fault conditions taken from working case STATUS(4) = 1 impose flat conditions as pre-fault condition STATUS(5) double-precision fault calculation option (alias is nouse1) (ignored, but must be specified as 0 or 1; 0 by default; double precision always used) STATUS(6) report option (alias is rptop) (1 by default)

	STATUS(6) = 1	full output at home bus and N levels away
	STATUS(6) = 2	full output at home bus, summary N levels away
	STATUS(6) = 3	fault current summary table
	STATUS(7)	number of levels back for contributions if STATUS(6) = 1 or 2. STATUS(7) > 0 (alias is rptlvl) (0 by default)
	STATUS(8)	branch quantity code for line to ground faults (alias is brnop) (0 by default)
	STATUS(8) = 0	A phase
	STATUS(8) = 1	3 * IO
	STATUS(8) = 2	both
	STATUS(9)	dc line and FACTS device option (alias is dcload) (0 by default)
	STATUS(9) = 0	blocked
	STATUS(9) = 1	represent as load
	STATUS(10)	transformer impedance correction option (alias is zcorec) (1 by default)
	STATUS(10) = 0	do not apply to zero sequence
	STATUS(10) = 1	apply to zero sequence
Character*260 RELFILE	Relay Data (.rel) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Integer IERR	error code (output).	

4.1.5. ASCC_1A

This API routine is obsolete. It has been replaced by the API routine [ASCC_2](#).

This API is used to apply a series of faults at various locations in the working case.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ASCC_1A  SID  ALL  STATUS(1)..STATUS(10)  RELFILE  FCDFILE
```

Python command syntax:

```
ierr = ascc_1a(sid, all, status, relfile, fcdfile)
```

Fortran command syntax:

```
CALL ASCC_1A(SID, ALL, STATUS, RELFILE, FCDFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS (10)	array of 10 elements specifying integer options(input). STATUS(1) Three phase and line-to-ground fault (alias is flt3phlg) (0 by default) STATUS(1) = 0 three phase faults only STATUS(1) = 1 three phase and line-to-ground faults STATUS(2) line-out faults (alias is linout) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-end faults (alias is linend) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) flat conditions option (alias is flatop) (0 by default) STATUS(4) = 0 pre-fault conditions taken from working case STATUS(4) = 1 impose flat conditions as pre-fault condition STATUS(5) fault analysis generator reactance option; ignored if generators are already "converted" (alias is genxop) (0 by default) STATUS(5) = 0 use subtransient reactance STATUS(5) = 1 use transient reactance

	STATUS(5) = 2	use synchronous reactance
	STATUS(6)	option (alias is rptop) (1 by default)
	STATUS(6) = 1	full output at home bus and N levels away
	STATUS(6) = 2	full output at home bus, summary N levels away
	STATUS(6) = 3	fault current summary table
	STATUS(7)	number of levels back for contributions if STATUS(6) = 1 or 2. STATUS(7) > 0 (alias is rptlvl) (0 by default)
	STATUS(8)	branch quantity code for line to ground faults (alias is brnop) (0 by default)
	STATUS(8) = 0	A phase
	STATUS(8) = 1	3 * IO
	STATUS(8) = 2	both
	STATUS(9)	dc line and FACTS device option (alias is dcload) (0 by default)
	STATUS(9) = 0	blocked
	STATUS(9) = 1	represent as load
	STATUS(10)	transformer impedance correction option (alias is zcorec) (1 by default)
	STATUS(10) = 0	do not apply to zero sequence
	STATUS(10) = 1	apply to zero sequence
Character*260 RELFILE	Relay Data (.rel) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	line end fault is invalid; bus table is full
	IERR = 5	fault analysis is invalid due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 6	bus type code and series element status inconsistencies
	IERR = 7	error opening RELFILE
	IERR = 8	error opening FCDFILE
	IERR = 9	prerequisite requirements for API are not met

4.1.6. ASCC_2

This API routine is obsolete. It has been replaced by the API routine [ASCC_3](#).

This API is used to apply a series of faults at various locations in the working case.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_ASCC_2  SID ALL STATUS(1)..STATUS(13) RELFILE FCDFILE SCFILE
```

Python command syntax:

```
ierr = ascc_2(sid, all, status, relfile, fcdfile, scfile)
```

Fortran command syntax:

```
CALL ASCC2(SID, ALL, STATUS, RELFILE, FCDFILE, SCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or selected subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS (13)	array of 13 elements specifying integer options(input). STATUS(1) line-to-ground faults (alias is fltlg) (0 by default) STATUS(1) = 0 omit STATUS(1) = 1 include STATUS(2) line-out faults (alias is linout) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-end faults (alias is linend) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) flat conditions option (alias is flatop) (0 by default) STATUS(4) = 0 pre-fault conditions taken from working case STATUS(4) = 1 impose flat conditions as pre-fault condition STATUS(5) double-precision fault calculation option (alias is nouse1) (ignored, but must be specified as 0 or 1; 0 by default; double precision always used) STATUS(6) report option (alias is rptop) (1 by default)

	STATUS(6) = 1	total fault currents
	STATUS(6) = 2	fault contributions to N levels away
	STATUS(6) = 3	total fault currents and fault contributions to N levels away
	STATUS(7)	number of levels back for contributions (alias is rptlvl) (0 by default)
	STATUS(7) >= 0	used if STATUS(6) = 2 or 3
	STATUS(8)	branch quantity code (alias is nouse2) (ignored, but must be specified as 0 or 1; 0 by default)
	STATUS(9)	dc line and FACTS device option (alias is dcload) (0 by default)
	STATUS(9) = 0	blocked
	STATUS(9) = 1	represent as load
	STATUS(10)	zero sequence transformer impedance correction option (alias is zcorec) (0 by default)
	STATUS(10) = 0	ignore
	STATUS(10) = 1	apply
	STATUS(11)	three phase faults (alias is flt3ph) (0 by default)
	STATUS(11) = 0	omit
	STATUS(11) = 1	include
	STATUS(12)	line-line-to-ground faults (alias is fltllg) (0 by default)
	STATUS(12) = 0	omit
	STATUS(12) = 1	include
	STATUS(13)	line-to-line faults (alias is fltll) (0 by default)
	STATUS(13) = 0	omit
	STATUS(13) = 1	include
Character*260 RELFILE	Relay Data (.rel) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Character*260 SCFILE	ASCC_2 Results (.sc) file (input; blank by default).	
	scfile =	temporary file created
	scfile = nooutput	no file created
Integer IERR	error code (output).	

4.1.7. ASCC_3

This API is used to apply a series of faults at various locations in the working case.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ASCC_3  SID ALL STATUS(1)..STATUS(17) VALUES(1) RELFILE FCDFILE SCFILE
```

Python command syntax:

```
ierr = ascc_3(sid, all, status, values, relfile, fcdfile, scfile)
```

Fortran command syntax:

```
CALL ASCC3(SID, ALL, STATUS, VALUES, RELFILE, FCDFILE, SCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS (17)	array of 17 elements specifying integer options(input).	
	STATUS(1)	line-to-ground faults (alias is fltlg) (0 by default)
	STATUS(1) = 0	omit
	STATUS(1) = 1	include
	STATUS(2)	line-out faults (alias is linout) (0 by default)
	STATUS(2) = 0	omit
	STATUS(2) = 1	include
	STATUS(3)	line-end faults (alias is linend) (0 by default)
	STATUS(3) = 0	omit
	STATUS(3) = 1	include
	STATUS(4)	bus voltage option (alias is voltop) (0 by default)
	STATUS(4) = 0	use bus voltages from power flow solution
	STATUS(4) = 1	set all bus voltages at specified value and at 0 deg
	STATUS(4) = 2	set faulted bus voltage at specified value and at 0 deg
	STATUS(5)	fault analysis generator reactance option; ignored if generators are already "converted" (alias is genxop) (0 by default)
	STATUS(5) = 0	use subtransient reactance
	STATUS(5) = 1	use transient reactance
	STATUS(5) = 2	use synchronous reactance

STATUS(6)	report option (alias is rptop) (1 by default)
STATUS(6) = 0	fault current summary table
STATUS(6) = 1	total fault currents
STATUS(6) = 2	fault contributions to N levels away
STATUS(6) = 3	total fault currents and fault contributions to N levels away
STATUS(7)	number of levels back for contributions (alias is rptlvl) (0 by default)
STATUS(7) >= 0	used if STATUS(6) = 2 or 3
STATUS(8)	transformer tap ratios and phase shift angles option (alias is tpunty) (0 by default)
STATUS(8) = 0	leave tap ratios and phase shift angles unchanged
STATUS(8) = 1	set tap ratios to 1.0 pu and phase shift angles to 0
STATUS(8) = 2	set tap ratios to 1.0 pu and phase shift angles unchanged
STATUS(8) = 3	set tap ratios unchanged and phase shift angles to 0
STATUS(9)	dc line and FACTS device option (alias is dcload) (0 by default)
STATUS(9) = 0	blocked
STATUS(9) = 1	represent as load
STATUS(10)	zero sequence transformer impedance correction option (alias is zcorec) (1 by default)
STATUS(10) = 0	ignore
STATUS(10) = 1	apply
STATUS(11)	three phase faults (alias is flt3ph) (0 by default)
STATUS(11) = 0	omit
STATUS(11) = 1	include
STATUS(12)	line-line-to-ground faults (alias is fltllg) (0 by default)
STATUS(12) = 0	omit
STATUS(12) = 1	include
STATUS(13)	line-to-line faults (alias is fltll) (0 by default)
STATUS(13) = 0	omit
STATUS(13) = 1	include
STATUS(14)	line charging option (alias is lnchrg) (0 by default)
STATUS(14) = 0	leave unchanged
STATUS(14) = 1	set to 0.0 in the positive and negative sequences
STATUS(14) = 2	set to 0.0 in all sequences

	STATUS(15)	line, fixed and switched shunts, and magnetizing admittance option (alias is shntop) (0 by default)
	STATUS(15) = 0	leave unchanged
	STATUS(15) = 1	set to 0.0 in the positive and negative sequences
	STATUS(15) = 2	set to 0.0 in all sequences
	STATUS(16)	load option (alias is loadop) (0 by default)
	STATUS(16) = 0	leave unchanged
	STATUS(16) = 1	set to 0.0 in the positive and negative sequences
	STATUS(16) = 2	set to 0.0 in all sequences
	STATUS(17)	synchronous and asynchronous machines power option (alias is machpq) (0 by default)
	STATUS(17) = 0	use real and reactive power outputs from power flow solution
	STATUS(17) = 1	set real and reactive power outputs to 0.0
Real VALUES (1)	array of 1 elements specifying real values(input).	
	VALUES(1)	User specified pu bus voltage value (Used when STATUS (4) = 1 or 2) (alias is volts)
Character*260 RELFILE	Relay Data (.rel) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Character*260 SCFILE	Results (.sc) file (input; blank by default).	
	scfile =	temporary file created
	scfile = nooutput	no file created
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	line end fault invalid; bus table is full
	IERR = 5	error opening RELFILE
	IERR = 6	error opening FCDFILE
	IERR = 7	prerequisite requirements for function not met
	IERR = 8	no faults specified
	IERR = 9	error opening SCFILE
	IERR = 10	SCFILE error
	IERR = 11	bus SC results not available
	IERR = 12	branch SC results not available
	IERR = 13	three winding transformer SC results not available
	IERR = 14	incorrect SCFILE

IERR = 15	SCFILE not allowed
IERR = 16	fault analysis invalid
IERR = 17	invalid VALUES value
IERR = 18	SC result file size exceeded. Define smaller size bus subsystems and re-run if SCFILE is required.
IERR = 19	topology error - bus(es) with bus type code and series element status inconsistencies

4.1.8. ASCC_SCFILE

This API reads ASCC short circuit results from SCFILE and produces same ASCC output report that was generated when SCFILE was created. SCFILE is read into PSSE memory to enable displaying ASCC results onto slider diagrams. For this API to work properly, it is required that working case in PSSE memory should be the same Saved case that was used when creating the SCFILE.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_ASCC_SCFILE  SCFILE
```

Python command syntax:

```
ierr = ascc_scfile(scfile)
```

Fortran command syntax:

```
CALL ASCC_SCFILE(SCFILE, IERR)
```

Where:

Character*260 SCFILE	Activity ASCC Results (.sc) file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 7	prerequisite requirements for function not met
	IERR = 9	error opening SCFILE
	IERR = 10	SCFILE error
	IERR = 11	bus SC results not available
	IERR = 12	branch SC results not available
	IERR = 13	three winding transformer SC results not available
	IERR = 14	incorrect SCFILE
	IERR = 15	SCFILE not allowed

4.1.9. BKDY

Use this API to calculate and report circuit breaker interrupting duty for 3-phase faults at all buses in a specified subsystem of the working case (activity BKDY).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BKDY  SID  ALL  APIOPT  LVLBAK  FLTTIM  BFILE  FFILE
```

Python command syntax:

```
ierr = bkdy(sid, all, apiopt, lvlbak, flttim, bfile, ffile)
```

Fortran command syntax:

```
CALL BKDYNW(SID, ALL, APIOPT, LVLBAK, FLTTIM, BFILE, FFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer APIOPT	mode of operation in the API (input; 1 by default). APIOPT = 1 fault applications specified in subsystem. APIOPT = 2 fault applications specified in FFILE.
Integer LVLBAK	number of levels back for contributions (input; 0 by default). LVLBAK < 0 fault currents only. LVLBAK = 0 fault currents and local contributions. LVLBAK > 0 fault currents and local contributions, plus contributions LVLBAK levels back.
Real FLTTIM	default fault duty time. FLTTIM >= 0.0 (input; 0.0).
Character*260 BFILE	Breaker Duty Data file (input; no default allowed).
Character*260 FFILE	Fault Specification Data file (if APIOPT is 2) (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid APIOPT value IERR = 4 invalid FLTTIM value IERR = 5 BFILE is blank IERR = 6 FFILE is blank

IERR = 7	generators are not converted
IERR = 8	fixed bus shunt table is full
IERR = 9	error opening BFILE or FFILE
IERR = 10	prerequisite requirements for API are not met

4.1.10. CHECK_SEQUENCE_DATA

Use this API routine to perform data checks on the selected categories of sequence data for all buses in the working case or for all buses in a specified subsystem.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_CHECK_SEQUENCE_DATA SID ALL OPT
```

Python command syntax:

```
ierr = check_sequence_data(sid, all, opt)
```

Fortran command syntax:

```
CALL CHECK_SEQUENCE_DATA(SID, ALL, OPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer OPT	sequence data category to be checked (input; 0 by default).	
	OPT = 0	all data categories
	OPT = 1	load data
	OPT = 2	generator unit data
	OPT = 3	induction machine data
	OPT = 4	fixed bus shunt data
	OPT = 5	switched shunt data
	OPT = 6	non-transformer branch data
	OPT = 7	two-winding transformer data
	OPT = 8	three-winding transformer data
	OPT = 9	zero sequence mutual data
	OPT = 10	non-conforming source table data
	OPT = 11	non-conforming source machine data
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid OPT value
	IERR = 5	prerequisite requirements for API are not met

4.1.11. FLAT

This API routine is obsolete. It has been replaced by the API routine [flat_2](#).

Use this API to specify various levels of flat conditions in preparation for fault analysis calculations (activity FLAT).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_FLAT  OPTIONS(1) .. OPTIONS(4)  VALUES(1)  VALUES(2)
```

Python command syntax:

```
ierr = flat(options, values)
```

Fortran command syntax:

```
CALL FLATAPI(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (4)	array of 4 elements specifying boundary condition options(input).
OPTIONS(1)	flat option (0 by default)
OPTIONS(1) = 0	only change voltages (activity FLAT)
OPTIONS(1) = 1	set classical fault analysis conditions (activity FLAT,CL)
OPTIONS(1) = 2	set conditions in preparation for IEC standard 909 calculations (activity FLAT,IEC)
OPTIONS(2)	tap ratio treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(2) = 0	leave tap ratios unchanged
OPTIONS(2) = 1	set tap ratios to 1.0
OPTIONS(3)	charging treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(3) = 0	leave charging unchanged
OPTIONS(3) = 1	set charging to 0.0
OPTIONS(4)	shunt treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(4) = 0	leave shunts unchanged
OPTIONS(4) = 1	set line shunts to 0.0 in the positive (and hence negative) sequence, and fixed and switched shunts to 0.0 in all three sequence networks
OPTIONS(4) = 2	set line shunts, fixed shunts, and switched shunts to 0.0 in all sequence networks, and negative and zero sequence shunt loads to 0.0

Real VALUES (2)	array of 2 elements specifying boundary condition values (ignored unless OPTIONS(1) is 2)(input).	
	VALUES(1)	voltage magnitude for all buses, or 0.0 to use present voltage magnitudes (0.0 by default)
	VALUES(2)	generator power factor, or 0.0 to leave generator Mvar unchanged (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	prerequisite requirements for API are not met

4.1.12. FLAT_2

This API routine is the second release of the flat conditions function. Use this API routine to specify various levels of flat conditions in preparation for fault analysis calculations (activity FLAT)

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_FLAT_2  OPTIONS(1) .. OPTIONS(8)  VALUES(1)  VALUES(2)
```

Python command syntax:

```
ierr = flat_2(options, values)
```

Fortran command syntax:

```
CALL FLAT_2(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying boundary condition options(input).
OPTIONS(1)	flat option (0 by default)
OPTIONS(1) = 0	only change voltages (activity FLAT)
OPTIONS(1) = 1	set classical fault analysis conditions (activity FLAT,CL)
OPTIONS(1) = 2	set conditions in preparation for IEC standard 909 calculations (activity FLAT,IEC)
OPTIONS(2)	tap ratio treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(2) = 0	leave tap ratios unchanged
OPTIONS(2) = 1	set tap ratios to 1.0
OPTIONS(3)	charging treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(3) = 0	leave charging unchanged
OPTIONS(3) = 1	set charging to 0.0
OPTIONS(4)	fixed bus shunt treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(4) = 0	leave fixed bus shunts unchanged
OPTIONS(4) = 1	set fixed bus shunts to 0.0 in the positive (and hence negative) sequence
OPTIONS(4) = 2	set fixed bus shunts to 0.0 in all sequence networks
OPTIONS(5)	switched shunt treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(5) = 0	leave switched shunts unchanged
OPTIONS(5) = 1	set switched shunts to 0.0 in all sequence networks
OPTIONS(6)	line shunt treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
OPTIONS(6) = 0	leave line shunts unchanged

	OPTIONS(6) = 1	set line shunts to 0.0 in the positive (and hence negative) sequence
	OPTIONS(6) = 2	set line shunts to 0.0 in all sequence networks
	OPTIONS(7)	transformer magnetizing admittance treatment flag (ignored if OPTIONS(1) is 0) (0 by default)
	OPTIONS(7) = 0	leave transformer magnetizing admittances unchanged
	OPTIONS(7) = 1	set transformer magnetizing admittances to 0.0 in the positive (and hence negative) sequence
	OPTIONS(8)	load treatment flag; this option applies to the constant power, current, and admittance load characteristic data (specified on Load Data records in the Power Flow Raw Data File), and to the exceptional negative and zero sequence load data (specified on Load Data records in the Sequence Data File) (ignored if OPTIONS(1) is 0) (0 by default)
	OPTIONS(8) = 0	leave loads unchanged
	OPTIONS(8) = 1	set the constant power, current and admittance load to 0.0 in all sequence networks; model (GNEG + j BNEG) in the negative sequence, and (GZERO + j BZERO) in the zero sequence
	OPTIONS(8) = 2	set the constant power, current and admittance load to 0.0 in all sequence networks, and (GNEG + j BNEG) to 0.0 in the negative sequence; model (GZERO + j BZERO) in the zero sequence
	OPTIONS(8) = 3	set the constant power, current and admittance load to 0.0 in all sequence networks, (GNEG + j BNEG) to 0.0 in the negative sequence, and (GZERO + j BZERO) to 0.0 in the zero sequence
Real VALUES (2)	array of 2 elements specifying boundary condition values (ignored unless OPTIONS(1) is 2)(input).	
	VALUES(1)	voltage magnitude for all buses, or 0.0 to use present voltage magnitudes (0.0 by default)
	VALUES(2)	generator power factor, or 0.0 to leave generator Mvar unchanged (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	invalid VALUES value
	IERR = 3	prerequisite requirements for API are not met

4.1.13. IECS

This API routine is obsolete. It has been replaced by the API routine [iecs_2](#).

Use this API to apply a series of faults at various locations in the working case to compute short circuit currents according to IEC 60909 standard.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_IECS  SID ALL STATUS(1)..STATUS(8) BRKTIM IECFILE FCDFILE
```

Python command syntax:

```
ierr = iecs(sid, all, status, brktim, iecfile, fcdfile)
```

Fortran command syntax:

```
CALL IECSAPI(SID, ALL, STATUS, BRKTIM, IECFILE, FCDFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (8)	array of 8 elements specifying integer options(input). STATUS(1) three phase faults (alias is flt3ph) (0 by default) STATUS(1) = 0 omit STATUS(1) = 1 include STATUS(2) line-to-ground faults (alias is fltlg) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-line-to-ground faults (alias is fltllg) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) line-to-line faults (alias is fltll) (0 by default) STATUS(4) = 0 omit STATUS(4) = 1 include STATUS(5) report option (alias is rptop) (1 by default) STATUS(5) = 1 total fault currents STATUS(5) = 2 fault contributions to N levels away

	STATUS(5) = 3	total fault currents and fault contributions to N levels away
	STATUS(6)	number of levels back for contributions (alias is rptlvl) (0 by default)
	STATUS(6) >= 0	used if STATUS(5) = 2 or 3
	STATUS(7)	location of fault (alias is fltloc) (0 by default)
	STATUS(7) = 1	fault at network bus
	STATUS(7) = 2	fault at LV bus of Power Station Unit (PSU)
	STATUS(7) = 3	fault at auxiliary transformer (connected to PSU) LV bus
	STATUS(8)	report total fault currents in descending order of magnitude (AMPS) (0 by default)
	STATUS(8) = 0	do not order
	STATUS(8) = 1	descending order
Real BRKTIM	breaker contact parting time in seconds (input; 5/BaseFrequency).	
Character*260 IECFILE	IEC Fault Calculation Data (.iec) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Integer IERR	error code (output).	

4.1.14. IECS_2

This API routine is obsolete. It has been replaced by the API routine [iecs_3](#).

This API executes the second release of the IEC short circuit calculations function. This API is used to apply a series of faults at various locations in the working case to compute short circuit currents according to IEC 60909 standard.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_IECS_2  SID ALL STATUS(1)..STATUS(14) BRKTIM IECFILE FCDFILE SCFILE
```

Python command syntax:

```
ierr = iecs_2(sid, all, status, brktim, iecfile, fcdfile, scfile)
```

Fortran command syntax:

```
CALL IECSAPI2(SID, ALL, STATUS, BRKTIM, IECFILE, FCDFILE, SCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (14)	array of 14 elements specifying integer options(input). STATUS(1) three phase faults (alias is flt3ph) (0 by default) STATUS(1) = 0 omit STATUS(1) = 1 include STATUS(2) line-to-ground faults (alias is fltlg) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-line-to-ground faults (alias is fltllg) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) line-to-line faults (alias is fltll) (0 by default) STATUS(4) = 0 omit STATUS(4) = 1 include STATUS(5) report option (alias is rptop) (1 by default) STATUS(5) = 1 total fault currents STATUS(5) = 2 fault contributions to N levels away

STATUS(5) = 3	total fault currents and fault contributions to N levels away
STATUS(6)	number of levels back for contributions (alias is rptlvl) (0 by default)
STATUS(6) >= 0	used if STATUS(5) = 2 or 3
STATUS(7)	location of fault (alias is fltloc) (1 by default)
STATUS(7) = 1	fault at network bus
STATUS(7) = 2	fault at LV bus of Power Station Unit (PSU)
STATUS(7) = 3	fault at auxiliary transformer (connected to PSU) LV bus
STATUS(8)	line-out faults (alias is linout) (0 by default)
STATUS(8) = 0	omit
STATUS(8) = 1	include
STATUS(9)	line-end faults (alias is linend) (0 by default)
STATUS(9) = 0	omit
STATUS(9) = 1	include
STATUS(10)	transformer tap ratios and phase angles option (alias is tpunty) (0 by default)
STATUS(10) = 0	leave tap ratios and phase angles unchanged
STATUS(10) = 1	set tap ratios 1.0 pu and phase angles to 0.0 deg
STATUS(11)	line charging option (alias is Inchrg) (1 by default)
STATUS(11) = 1	set to 0.0 in positive and negative sequences
STATUS(11) = 2	set to 0.0 in all sequences
STATUS(11) = 3	leave line charging unchanged
STATUS(12)	loads, fixed and switched shunts and and magnetizing admittance option (alias is shn-top) (1 by default)
STATUS(12) = 1	set to 0.0 in the positive and negative sequences
STATUS(12) = 2	set to 0.0 in all sequences
STATUS(12) = 3	leave unchanged
STATUS(13)	dc line and FACTS device option (alias is dcload) (0 by default)
STATUS(13) = 0	blocked
STATUS(13) = 1	represent as load
STATUS(14)	zero sequence transformer impedance correction option (alias is zcorec) (0 by default)
STATUS(14) = 0	ignore
STATUS(14) = 1	apply
Real BRKTIM	breaker contact parting time in seconds (input; 5/BaseFrequency).
Character*260 IECFILE	IEC Fault Calculation Data (.iec) file (input; blank by default).
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).

Character*260 SCFILE	Results (.sc) file (input; blank by default).
	scfile = temporary file created
	scfile = nooutput no file created
Integer IERR	error code (output).

4.1.15. IECS_3

This API routine is obsolete. It has been replaced by the API routine [iecs_4](#).

This API executes the third release of the IEC short circuit calculations function. This API is used to apply a series of faults at various locations in the working case to compute short circuit currents according to IEC 60909 standard.

This API routine was first introduced in release 32.0.5.

Batch command syntax:

```
BAT_IECS_3  SID ALL STATUS(1)..STATUS(15) VALUES(1) VALUES(2) IECFILE
FCDFILE SCFILE
```

Python command syntax:

```
ierr = iecs_3(sid, all, status, values, iecfile, fcdfile, scfile)
```

Fortran command syntax:

```
CALL IECSAPI3(SID, ALL, STATUS, VALUES, IECFILE, FCDFILE, SCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (15)	array of 15 elements specifying integer options(input). STATUS(1) three phase faults (alias is flt3ph) (0 by default) STATUS(1) = 0 omit STATUS(1) = 1 include STATUS(2) line-to-ground faults (alias is fltlg) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-line-to-ground faults (alias is fltllg) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) line-to-line faults (alias is fltll) (0 by default) STATUS(4) = 0 omit STATUS(4) = 1 include STATUS(5) report option (alias is rptop) (1 by default) STATUS(5) = 1 total fault currents STATUS(5) = 2 fault contributions to N levels away

STATUS(5) = 3	total fault currents and fault contributions to N levels away
STATUS(6)	number of levels back for contributions (alias is rptlvl) (0 by default)
STATUS(6) >= 0	used if STATUS(5) = 2 or 3
STATUS(7)	location of fault (alias is fltloc) (1 by default)
STATUS(7) = 1	fault at network bus
STATUS(7) = 2	fault at LV bus of Power Station Unit (PSU)
STATUS(7) = 3	fault at auxiliary transformer (connected to PSU) LV bus
STATUS(8)	line-out faults (alias is linout) (0 by default)
STATUS(8) = 0	omit
STATUS(8) = 1	include
STATUS(9)	line-end faults (alias is linend) (0 by default)
STATUS(9) = 0	omit
STATUS(9) = 1	include
STATUS(10)	transformer tap ratios and phase angles option (alias is tpunty) (0 by default)
STATUS(10) = 0	leave tap ratios and phase angles unchanged
STATUS(10) = 1	set tap ratios 1.0 pu and phase angles to 0.0 deg
STATUS(11)	line charging option (alias is Inchrg) (1 by default)
STATUS(11) = 1	set to 0.0 in positive and negative sequences
STATUS(11) = 2	set to 0.0 in all sequences
STATUS(11) = 3	leave line charging unchanged
STATUS(12)	loads, fixed and switched shunts and and magnetizing admittance option (alias is shn-top) (1 by default)
STATUS(12) = 1	set to 0.0 in the positive and negative sequences
STATUS(12) = 2	set to 0.0 in all sequences
STATUS(12) = 3	leave unchanged
STATUS(13)	dc line and FACTS device option (alias is dcload) (0 by default)
STATUS(13) = 0	blocked
STATUS(13) = 1	represent as load
STATUS(14)	zero sequence transformer impedance correction option (alias is zcorec) (0 by default)
STATUS(14) = 0	ignore
STATUS(14) = 1	apply
STATUS(15)	option for Voltage Factor C (alias is cfactor) (1 by default)
STATUS(15) = 1	Voltage Factor C for maximum fault currents (default)

	STATUS(15) = 2	Voltage Factor C for minimum fault currents
	STATUS(15) = 3	Voltage Factor C as specified by 'vfactorc' value
Real VALUES (2)	array of 2 elements specifying real values(input).	
	VALUES(1)	breaker contact parting time in seconds (alias is brktim) (5/base Frequency by default)
	VALUES(2)	user specified voltage factor c (alias is ucfactor) (1.0 by default) This is used only when STATUS(15)=3)
Character*260 IECFILE	IEC Fault Calculation Data (.iec) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Character*260 SCFILE	Results (.sc) file (input; blank by default).	
	scfile =	temporary file created
	scfile = nooutput	no file created
Integer IERR	error code (output).	

4.1.16. IECS_4

This API executes the fourth release of the IEC short circuit calculations function. This API is used to apply a series of faults at various locations in the working case to compute short circuit currents according to IEC 60909 standard.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IECS_4  SID ALL STATUS(1)..STATUS(17) VALUES(1) VALUES(2) IECFILE
FCDFILE SCFILE
```

Python command syntax:

```
ierr = iecs_4(sid, all, status, values, iecfile, fcdfile, scfile)
```

Fortran command syntax:

```
CALL IECSAPI4(SID, ALL, STATUS, VALUES, IECFILE, FCDFILE, SCFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (17)	array of 17 elements specifying integer options(input). STATUS(1) three phase faults (alias is flt3ph) (0 by default) STATUS(1) = 0 omit STATUS(1) = 1 include STATUS(2) line-to-ground faults (alias is fltlg) (0 by default) STATUS(2) = 0 omit STATUS(2) = 1 include STATUS(3) line-line-to-ground faults (alias is fltllg) (0 by default) STATUS(3) = 0 omit STATUS(3) = 1 include STATUS(4) line-to-line faults (alias is fltll) (0 by default) STATUS(4) = 0 omit STATUS(4) = 1 include STATUS(5) report option (alias is rptop) (1 by default) STATUS(5) = 0 fault current summary table STATUS(5) = 1 total fault currents STATUS(5) = 2 fault contributions to N levels away

STATUS(5) = 3	total fault currents and fault contributions to N levels away
STATUS(6)	number of levels back for contributions (alias is rptlvl) (0 by default)
STATUS(6) >= 0	used if STATUS(5) = 2 or 3
STATUS(7)	location of fault (alias is fltloc) (0 by default)
STATUS(7) = 0	fault at network bus
STATUS(7) = 1	fault at LV bus of Power Station Unit (PSU)
STATUS(7) = 2	fault at auxiliary transformer (connected to PSU) LV bus
STATUS(8)	line-out faults (alias is linout) (0 by default)
STATUS(8) = 0	omit
STATUS(8) = 1	include
STATUS(9)	line-end faults (alias is linend) (0 by default)
STATUS(9) = 0	omit
STATUS(9) = 1	include
STATUS(10)	transformer tap ratios and phase shift angles option (alias is tpunty) (0 by default)
STATUS(10) = 0	leave tap ratios and phase shift angles unchanged
STATUS(10) = 1	set tap ratios to 1.0 pu and phase shift angles to 0 deg
STATUS(10) = 2	set tap ratios to 1.0 pu and phase shift angles unchanged
STATUS(10) = 3	set tap ratios unchanged and phase shift angles to 0 deg
STATUS(11)	line charging option (alias is Inchrg) (1 by default)
STATUS(11) = 0	leave unchanged
STATUS(11) = 1	set to 0.0 in the positive and negative sequences
STATUS(11) = 2	set to 0.0 in all sequences
STATUS(12)	line, fixed and switched shunts, and magnetizing admittance option (alias is shntop) (1 by default)
STATUS(12) = 0	leave unchanged
STATUS(12) = 1	set to 0.0 in the positive and negative sequences
STATUS(12) = 2	set to 0.0 in all sequences
STATUS(13)	dc line and FACTS device option (alias is dclload) (0 by default)
STATUS(13) = 0	blocked
STATUS(13) = 1	represent as load
STATUS(14)	zero sequence transformer impedance correction option (alias is zcorec) (0 by default)

	STATUS(14) = 0	ignore
	STATUS(14) = 1	apply
	STATUS(15)	option for Voltage Factor C (alias is cfactor) (0 by default)
	STATUS(15) = 0	Voltage Factor C for maximum fault currents
	STATUS(15) = 1	Voltage Factor C for minimum fault currents
	STATUS(15) = 2	Voltage Factor C as specified by 'vfactorc' value for maximum fault current calculations
	STATUS(15) = 3	Voltage Factor C as specified by 'vfactorc' value for minimum fault current calculations
	STATUS(16)	load option (alias is loadop) (1 by default)
	STATUS(16) = 0	leave unchanged
	STATUS(16) = 1	set to 0.0 in the positive and negative sequences
	STATUS(16) = 2	set to 0.0 in all sequences
	STATUS(17)	fault analysis generator reactance option; ignored if generators are already "converted" (alias is genxop) (0 by default)
	STATUS(17) = 0	use subtransient reactance
	STATUS(17) = 1	use transient reactance
	STATUS(17) = 2	use synchronous reactance
Real VALUES (2)	array of 2 elements specifying real values(input).	
	VALUES(1)	breaker contact parting time in seconds (alias is brktim) (5/base Frequency by default)
	VALUES(2)	user specified voltage factor c (alias is ucfactor) (1.0 by default) This is used only when STATUS(15)=2
Character*260 IECFILE	IEC Fault Calculation Data (.iec) file (input; blank by default).	
Character*260 FCDFILE	Fault Control (.fcd) file (input; blank by default).	
Character*260 SCFILE	Results (.sc) file (input; blank by default).	
	scfile =	temporary file created
	scfile = nooutput	no file created
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid VALUES value
	IERR = 5	no faults specified
	IERR = 6	error opening IECFILE
	IERR = 7	error opening FCDFILE
	IERR = 8	prerequisite requirements for API are not met

IERR = 9	error opening SCFILE
IERR = 10	SCFILE error
IERR = 11	bus SC results not available
IERR = 12	branch SC results not available
IERR = 13	three winding transformer SC results not available
IERR = 14	incorrect SCFILE
IERR = 15	SCFILE not allowed

4.1.17. IECS_SCFILE

This API reads IECS short circuit results from SCFILE and produces same IECS output report that was generated when SCFILE was created. SCFILE is read into PSSE memory to enable displaying IECS results onto slider diagrams. For this API to work properly, it is required that working case in PSSE memory should be the same Saved case that was used when creating the SCFILE.

This API routine was first introduced in release 32.0.3.

Batch command syntax:

```
BAT_IECS_SCFILE  SCFILE
```

Python command syntax:

```
ierr = ieecs_scfile(scfile)
```

Fortran command syntax:

```
CALL IECS_SCFILE(SCFILE, IERR)
```

Where:

Character*260 SCFILE	IEC Results (.sc) file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 7	prerequisite requirements for function not met
	IERR = 9	error opening SCFILE
	IERR = 10	SCFILE error
	IERR = 11	bus SC results not available
	IERR = 12	branch SC results not available
	IERR = 13	three winding transformer SC results not available
	IERR = 14	incorrect SCFILE
	IERR = 15	SCFILE not allowed

4.1.18. NEWSEQ

Use this API to initialize the fault analysis data arrays, set them to default values, and set the flag indicating that sequence data is present in the working case.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_NEWSEQ
```

Python command syntax:

```
ierr = newseq()
```

Fortran command syntax:

```
CALL NEWSEQ(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

4.1.19. SCEQ

Use this API to construct network equivalents of the positive and zero sequence networks and calculates source impedances at equivalent source nodes for all three sequences in preparation for the unbalanced fault analysis activities of PSSE.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SCEQ SID ALL STATUS THRESH RFILE SFILE
```

Python command syntax:

```
ierr = sceq(sid, all, status, thresh, rfile, sfile)
```

Fortran command syntax:

```
CALL SCEQNW(SID, ALL, STATUS, THRESH, RFILE, SFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	transformer impedance correction option (input; 1 by default). STATUS = 0 do not apply to zero sequence STATUS = 1 apply to zero sequence
Real THRESH	equivalent branch threshold tolerance (input; 10.0).
Character*260 RFILE	power flow raw data file; blank for none (input; blank by default).
Character*260 SFILE	sequence data file; blank for none (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 case is not subject to classical assumptions IERR = 5 generators are not converted IERR = 6 error writing the working case to a temporary file IERR = 7 no buses being retained IERR = 8 no buses being processed for equivalence IERR = 9 too many branches in the equivalent IERR = 10 bus type codes other than 1, 2, 4, 5 and 6 present

IERR = 11	substations present in subsystem to be equivalent
IERR = 12	error opening RFILE or SFILE
IERR = 13	error opening temporary file
IERR = 14	prerequisite requirements for API are not met

4.1.20. SCGR

This API routine is obsolete. It has been replaced by the API routine [ascc_2](#).

This API no longer performs any action. Usage in previous releases described below.

Use this API routine to calculate three phase and line-to-ground fault solutions. Results may be programmatically accessed via the internally accessible fetch routines SCGTX, SCGBUS, SCGBRN, and SCG3WN.

Usage is:

- invoke SCGR API with APIOPT = 0;
- multiple calls to fetch routines;
- optionally, repeat of above steps for different fault and/or different pre-fault conditions;
- final invocation of SCGR API with APIOPT = 1.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SCGR SID ALL APIOPT STATUS(1)..STATUS(8)
```

Python command syntax:

```
ierr = scgr(sid, all, apiopt, status)
```

Fortran command syntax:

```
CALL SCGRAPI(SID, ALL, APIOPT, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer APIOPT	mode of operation of SCGRAPI (input; 0 by default).	
	APIOPT = 0	apply fault calculations and fill arrays used by fetch routines
	APIOPT = 1	deallocate arrays used by fetch routines
Integer STATUS (8)	array of 8 elements specifying fault and options(input).	
	STATUS(1)	fault type (0 by default)
	STATUS(1) = 0	three-phase
	STATUS(1) = 1	line-to-ground
	STATUS(2)	L-G fault (ignored if STATUS(1) is 0) (0 by default)
	STATUS(2) = 0	A phase
	STATUS(2) = 1	3 * IO
	STATUS(3)	fault location (0 by default)
	STATUS(3) = 0	all buses in subsystem

	STATUS(3) > 0	bus number of the subsystem bus to be faulted
	STATUS(4)	flat conditions option (0 by default)
	STATUS(4) = 0	working case conditions
	STATUS(4) = 1	flat conditions
	STATUS(5)	double-precision fault calculation option (ignored, but must be specified as 0 or 1; 0 by default; double precision always used)
	STATUS(6)	dc line and FACTS device option (ignored if STATUS(4) is 1) (0 by default)
	STATUS(6) = 0	block
	STATUS(6) = 1	represent as load
	STATUS(7)	transformer impedance correction option (ignored if STATUS(1) is 0 or STATUS(4) is 1 (1 by default)
	STATUS(7) = 0	do not apply to zero sequence
	STATUS(7) = 1	apply to zero sequence
	STATUS(8)	branch results option (0 by default)
	STATUS(8) = 0	currents
	STATUS(8) = 1	apparent impedances
Integer IERR	error code (output).	
	IERR = 1	SCGR is obsolete; use "Fault>Automatic sequencing fault calculation (ASCC).." (API routine ASCC_2)
	IERR = 8	prerequisite requirements for API are not met

4.1.21. SCMU

This API routine is obsolete. It has been replaced by the API routine [scmu_2](#).

Use this API to calculate simultaneous unbalances. It must be called once with APIOPT set to 1, once for each of the simultaneous faults to be applied with APIOPT set to 2, and once with APIOPT set to 3.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SCMU  APIOPT  OPTIONS(1)..OPTIONS(7)  RVAL(1)..RVAL(5)  CKTARG
```

Python command syntax:

```
ierr = scmu(apiopt, options, rval, cktarg)
```

Fortran command syntax:

```
CALL SCMUAPI(APIOPT, OPTIONS, RVAL, CKTARG, IERR)
```

Where:

Integer APIOPT	mode of operation (input; no default allowed).
APIOPT = 1	Initialize; automatically runs activity SEQD if the sequence network setup option setting is enabled.
APIOPT = 2	Specify an unbalance to be applied; must be called once for each simultaneous unbalance to be imposed.
APIOPT = 3	Solve in the presence of the specified unbalances and terminate.
APIOPT = 4	Remove specified unbalances (cancels any unbalances specified by any preceding APIOPT 2 references, and leaves memory as it is immediately following an APIOPT 1 reference).
Integer OPTIONS (7)	array of 7 elements specifying options and input values to be used in the current calculation phase. It is ignored when APIOPT is 3 or 4. When APIOPT is 1, OPTIONS(1), OPTIONS(2) and OPTIONS(3) define options to be used in the construction of the sequence admittance matrices. These values are used only when the sequence network setup option is enabled, and activity SEQD is to be automatically executed.(input).
OPTIONS(1)	Specify it per additional conditions as below. When APIOPT=1, dc line and FACTS device option, 0 by default.
OPTIONS(1) = 0	Block and ignore
OPTIONS(1) = 1	Convert to constant admittance load
	When APIOPT=2, define the type of unbalance to be applied, no default allowed
OPTIONS(1) = 1	First line-to-ground fault

OPTIONS(1) = 2	Second line-to-ground fault
OPTIONS(1) = 3	First line-to-line or line-to-line-to-ground fault
OPTIONS(1) = 4	Second line-to-line or line-to-line-to-ground fault
OPTIONS(1) = 5	One phase closed
OPTIONS(1) = 6	Two phases closed
OPTIONS(1) = 7	Three-phase fault (uses fault types 2 and 4)
OPTIONS(1) = 8	Branch unbalance with one end opened
OPTIONS(1) = 9	Branch unbalance with both ends closed
OPTIONS(2)	Specify it per additional conditions as below.

When APIOPT=1, transformer impedance correction option, 1 by default.

OPTIONS(2) = 0	Do not apply to zero sequence
OPTIONS(2) = 1	Apply to zero sequence

When APIOPT=2 and OPTIONS(1)=1 or 2 (LG), no default allowed.

OPTIONS(2) = None	Bus to be faulted
-------------------	-------------------

When APIOPT=2 and OPTIONS(1)=3 or 4 (LLG), no default allowed.

OPTIONS(2) = None	Bus to be faulted
-------------------	-------------------

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), no default allowed.

OPTIONS(2) = None	One of the buses to be connected by the phase closed unbalance
-------------------	--

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), no default allowed.

OPTIONS(2) = None	One of the buses to be connected by the phase closed unbalance
-------------------	--

When APIOPT=2 and OPTIONS(1)=7 (3PH), no default allowed.

OPTIONS(2) = None	Bus to be faulted
-------------------	-------------------

When APIOPT=2 and OPTIONS(1)=8 (one end open), no default allowed.

OPTIONS(2) = None	One of the buses connected by the branch to be faulted
-------------------	--

When APIOPT=2 and OPTIONS(1)=9 (both ends closed), no default allowed.

OPTIONS(2) = None	One of the buses connected by the branch to be faulted
-------------------	--

OPTIONS(3)	Specify it per additional conditions as below.
------------	--

When APIOPT=1, fault analysis generator reactance option, ignored if generators are already "converted", 0 by default.

OPTIONS(3) = 0	Use subtransient reactance
OPTIONS(3) = 1	Use transient reactance
OPTIONS(3) = 2	Use synchronous reactance

When APIOPT=2 and OPTIONS(1)=1 or 2 (LG), faulted phase, 1 by default.

OPTIONS(3) = 1 Phase A

OPTIONS(3) = 2 Phase B

OPTIONS(3) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=3 or 4 (LLG), excluded phase, 1 by default.

OPTIONS(3) = 1 Phase A

OPTIONS(3) = 2 Phase B

OPTIONS(3) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), no default allowed.

OPTIONS(3) = None The other bus to be connected by the phase closed unbalance

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), no default allowed.

OPTIONS(3) = None The other bus to be connected by the phase closed unbalance

When APIOPT=2 and OPTIONS(1)=8 (one end open), no default allowed.

OPTIONS(3) = None Another bus connected by the branch to be faulted

When APIOPT=2 and OPTIONS(1)=9 (both ends closed), no default allowed.

OPTIONS(3) = None The other bus connected by the branch to be faulted

OPTIONS(4) Specify it per additional conditions as below.

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), phase to be closed, 1 by default.

OPTIONS(4) = 1 Phase A

OPTIONS(4) = 2 Phase B

OPTIONS(4) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), excluded phase, 1 by default.

OPTIONS(4) = 1 Phase A

OPTIONS(4) = 2 Phase B

OPTIONS(4) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=8 (one end open), 0 by default.

OPTIONS(4) = None Third bus connected by the three-winding transformer to be faulted, or zero for a two terminal branch

When APIOPT=2 and OPTIONS(1)=9 (both ends closed), type of in-line fault to be applied (1 by default).

OPTIONS(4) = 1 Line-to-ground

OPTIONS(4) = 2 Line-to-line or line-to-line-to-ground fault
 OPTIONS(4) = 3 Three-phase
 OPTIONS(5) Specify it per additional conditions as below.
When APIOPT=2 and OPTIONS(1)=8 (one end open), type of in-line fault to be applied (1 by default).
 OPTIONS(5) = 1 Line-to-ground
 OPTIONS(5) = 2 Line-to-line or line-to-line-to-ground fault
 OPTIONS(5) = 3 Three-phase
When APIOPT=2, OPTIONS(1)=9 (both ends closed) and OPTIONS(4)=1, faulted phase (1 by default).
 OPTIONS(5) = 1 Phase A
 OPTIONS(5) = 2 Phase B
 OPTIONS(5) = 3 Phase C
When APIOPT=2, OPTIONS(1)=9 (both ends closed) and OPTIONS(4)=2, excluded phase (1 by default).
 OPTIONS(5) = 1 Phase A
 OPTIONS(5) = 2 Phase B
 OPTIONS(5) = 3 Phase C
 OPTIONS(6) Specify it per additional conditions as below.
When APIOPT=2, OPTIONS(1)=8 (one end open) and OPTIONS(5)=1, faulted phase (1 by default).
 OPTIONS(6) = 1 Phase A
 OPTIONS(6) = 2 Phase B
 OPTIONS(6) = 3 Phase C
When APIOPT=2, OPTIONS(1)=8 (one end open) and OPTIONS(5)=2, excluded phase (1 by default).
 OPTIONS(6) = 1 Phase A
 OPTIONS(6) = 2 Phase B
 OPTIONS(6) = 3 Phase C
 OPTIONS(7) Specify it per additional conditions as below.
When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(2) by default.
 OPTIONS(7) = None Opened end bus (must be identical to one of OPTIONS(2), OPTIONS(3), or, if it is non-zero, OPTIONS(4))

Real RVAL (5)

array of 5 elements specifying input values used to define the current fault; ignored except when APIOPT is 2. The elements of RVAL are dependent on the value specified for OPTIONS(1).(input).

RVAL(1) Specify it per additional conditions as below.
When APIOPT=2, OPTIONS(1)=1 or 2 (LG), 0.0 by default.
 RVAL(1) = None Resistance of the complex L-G fault impedance in pu
When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

RVAL(1) = None	Resistance of the complex L-L fault impedance in pu
When APIOPT=2, OPTIONS(1)=5 (1 phase closed), 0.0 by default.	
RVAL(1) = None	Resistance of the complex phase impedance in pu
When APIOPT=2, OPTIONS(1)=6 (2 phases closed), 0.0 by default.	
RVAL(1) = None	Resistance of the complex phase impedance in pu
When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=1, 0.0 by default.	
RVAL(1) = None	Resistance of the complex L-G fault impedance in pu
When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.	
RVAL(1) = None	Resistance of the complex L-L fault impedance in pu
When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=1, 0.0 by default.	
RVAL(1) = None	Resistance of the complex L-G fault impedance in pu
When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.	
RVAL(1) = None	Resistance of the complex L-L fault impedance in pu
RVAL(2)	Specify it per additional conditions as below.
When APIOPT=2, OPTIONS(1)=1 or 2 (LG), 0.0 by default.	
RVAL(2) = None	Reactance of the complex L-G fault impedance in pu
When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.	
RVAL(2) = None	Reactance of the complex L-L fault impedance in pu
When APIOPT=2, OPTIONS(1)=5 (1 phase closed), 0.0 by default.	
RVAL(2) = None	Reactance of the complex phase impedance in pu
When APIOPT=2, OPTIONS(1)=6 (2 phases closed), 0.0 by default.	
RVAL(2) = None	Reactance of the complex phase impedance in pu
When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=1, 0.0 by default.	
RVAL(2) = None	Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.

RVAL(2) = None Reactance of the complex L-L fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=1, 0.0 by default.

RVAL(2) = None Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.

RVAL(2) = None Reactance of the complex L-L fault impedance in pu

RVAL(3) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

RVAL(3) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.

RVAL(3) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.

RVAL(3) = None Resistance of the complex L-G fault impedance in pu

RVAL(4) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

RVAL(4) = None Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.

RVAL(4) = None Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.

RVAL(4) = None Reactance of the complex L-G fault impedance in pu

RVAL(5) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=8 (one end open), 1.0 by default.

RVAL(5) = None fault location from closed end bus in pu of total line length; must be 1.0 if the branch is a transformer

When APIOPT=2, OPTIONS(1)=9 (both ends closed), 0.5 by default.

RVAL(5) = None fault location from bus OPTIONS(2) in pu of total line length

Character*2 CKTARG	circuit identifier of branch to be faulted; ignored except when APIOPT is 2 and OPTIONS(1) is 8 or 9 (input; '1' by default).
Integer IERR	error code (output).

4.1.22. SCMU_2

Use this API to calculate simultaneous unbalances. It must be called once with APIOPT set to 1, once for each of the simultaneous faults to be applied with APIOPT set to 2, and once with APIOPT set to 3.

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_SCMU_2  APIOPT  OPTIONS(1)..OPTIONS(7)  RVAL(1)..RVAL(5)  CKTARG
```

Python command syntax:

```
ierr = scmu_2(apiopt, options, rval, cktarg)
```

Fortran command syntax:

```
CALL SCMU_2(APIOPT, OPTIONS, RVAL, CKTARG, IERR)
```

Where:

Integer APIOPT	mode of operation (input; no default allowed).
APIOPT = 1	Initialize; automatically runs activity SEQD if the sequence network setup option setting is enabled.
APIOPT = 2	Specify an unbalance to be applied; must be called once for each simultaneous unbalance to be imposed.
APIOPT = 3	Solve in the presence of the specified unbalances and terminate.
APIOPT = 4	Remove specified unbalances (cancels any unbalances specified by any preceding APIOPT 2 references, and leaves memory as it is immediately following an APIOPT 1 reference).
Integer OPTIONS (7)	array of 7 elements specifying options and input values to be used in the current calculation phase. It is ignored when APIOPT is 3 or 4. When APIOPT is 1, OPTIONS(1), OPTIONS(2) and OPTIONS(3) define options to be used in the construction of the sequence admittance matrices. These values are used only when the sequence network setup option is enabled, and activity SEQD is to be automatically executed.(input).
OPTIONS(1)	Specify it per additional conditions as below. When APIOPT=1, dc line and FACTS device option, 0 by default.
OPTIONS(1) = 0	Block and ignore
OPTIONS(1) = 1	Convert to constant admittance load
	When APIOPT=2, define the type of unbalance to be applied, no default allowed
OPTIONS(1) = 1	First line-to-ground fault
OPTIONS(1) = 2	Second line-to-ground fault
OPTIONS(1) = 3	First line-to-line or line-to-line-to-ground fault

OPTIONS(1) = 4	Second line-to-line or line-to-line-to-ground fault
OPTIONS(1) = 5	One phase closed
OPTIONS(1) = 6	Two phases closed
OPTIONS(1) = 7	Three-phase fault (uses fault types 2 and 4)
OPTIONS(1) = 8	Branch unbalance with one end opened
OPTIONS(1) = 9	Branch unbalance with both ends closed
OPTIONS(2)	Specify it per additional conditions as below.

When APIOPT=1, transformer impedance correction option, 1 by default.

OPTIONS(2) = 0	Do not apply to zero sequence
OPTIONS(2) = 1	Apply to zero sequence

When APIOPT=2 and OPTIONS(1)=1 or 2 (LG), no default allowed.

OPTIONS(2) = None	Bus to be faulted
-------------------	-------------------

When APIOPT=2 and OPTIONS(1)=3 or 4 (LLG), no default allowed.

OPTIONS(2) = None	Bus to be faulted
-------------------	-------------------

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), no default allowed.

OPTIONS(2) = None	One of the buses to be connected by the phase closed unbalance
-------------------	--

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), no default allowed.

OPTIONS(2) = None	One of the buses to be connected by the phase closed unbalance
-------------------	--

When APIOPT=2 and OPTIONS(1)=7 (3PH), no default allowed.

OPTIONS(2) = None	Bus to be faulted
-------------------	-------------------

When APIOPT=2 and OPTIONS(1)=8 (one end open), no default allowed.

OPTIONS(2) = None	One of the buses connected by the branch to be faulted
-------------------	--

When APIOPT=2 and OPTIONS(1)=9 (both ends closed), no default allowed.

OPTIONS(2) = None	One of the buses connected by the branch to be faulted
-------------------	--

OPTIONS(3)	Specify it per additional conditions as below.
------------	--

When APIOPT=1, fault analysis generator reactance option, ignored if generators are already "converted", 0 by default.

OPTIONS(3) = 0	Use subtransient reactance
OPTIONS(3) = 1	Use transient reactance
OPTIONS(3) = 2	Use synchronous reactance

When APIOPT=2 and OPTIONS(1)=1 or 2 (LG), 0 by default.

OPTIONS(3) = None	Number of node whose bus section is to be faulted
-------------------	---

When APIOPT=2 and OPTIONS(1)=3 or 4 (LLG), 0 by default.

OPTIONS(3) = None Number of node whose bus section is to be faulted

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), 0 by default.

OPTIONS(3) = None Number of node whose bus section is to be connected

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), 0 by default.

OPTIONS(3) = None Number of node whose bus section is to be connected

When APIOPT=2 and OPTIONS(1)=7 (3PH), 0 by default.

OPTIONS(3) = None Number of node whose bus section is to be faulted

When APIOPT=2 and OPTIONS(1)=8 (one end open), no default allowed.

OPTIONS(3) = None Another bus connected by the branch to be faulted

When APIOPT=2 and OPTIONS(1)=9 (both ends closed), no default allowed.

OPTIONS(3) = None The other bus connected by the branch to be faulted

OPTIONS(4) Specify it per additional conditions as below.

When APIOPT=2 and OPTIONS(1)=1 or 2 (LG), faulted phase, 1 by default.

OPTIONS(4) = 1 Phase A

OPTIONS(4) = 2 Phase B

OPTIONS(4) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=3 or 4 (LLG), excluded phase, 1 by default.

OPTIONS(4) = 1 Phase A

OPTIONS(4) = 2 Phase B

OPTIONS(4) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), no default allowed.

OPTIONS(4) = None The other bus to be connected by the phase closed unbalance

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), no default allowed.

OPTIONS(4) = None The other bus to be connected by the phase closed unbalance

When APIOPT=2 and OPTIONS(1)=8 (one end open), 0 by default.

OPTIONS(4) = None Third bus connected by the three-winding transformer to be faulted, or zero for a two terminal branch

When APIOPT=2 and OPTIONS(1)=9 (both ends closed), type of in-line fault to be applied (1 by default).

OPTIONS(4) = 1 Line-to-ground

OPTIONS(4) = 2 Line-to-line or line-to-line-to-ground fault

OPTIONS(4) = 3 Three-phase

OPTIONS(5) Specify it per additional conditions as below.

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), 0 by default.

OPTIONS(5) = None Number of node whose bus section is to be connected

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), 0 by default.

OPTIONS(5) = None Number of node whose bus section is to be connected

When APIOPT=2 and OPTIONS(1)=8 (one end open), type of in-line fault to be applied (1 by default).

OPTIONS(5) = 1 Line-to-ground

OPTIONS(5) = 2 Line-to-line or line-to-line-to-ground fault

OPTIONS(5) = 3 Three-phase

When APIOPT=2, OPTIONS(1)=9 (both ends closed) and OPTIONS(4)=1, faulted phase (1 by default).

OPTIONS(5) = 1 Phase A

OPTIONS(5) = 2 Phase B

OPTIONS(5) = 3 Phase C

When APIOPT=2, OPTIONS(1)=9 (both ends closed) and OPTIONS(4)=2, excluded phase (1 by default).

OPTIONS(5) = 1 Phase A

OPTIONS(5) = 2 Phase B

OPTIONS(5) = 3 Phase C

OPTIONS(6) Specify it per additional conditions as below.

When APIOPT=2 and OPTIONS(1)=5 (1 phase closed), phase to be closed, 1 by default.

OPTIONS(6) = 1 Phase A

OPTIONS(6) = 2 Phase B

OPTIONS(6) = 3 Phase C

When APIOPT=2 and OPTIONS(1)=6 (2 phases closed), excluded phase, 1 by default.

OPTIONS(6) = 1 Phase A

OPTIONS(6) = 2 Phase B

OPTIONS(6) = 3 Phase C

When APIOPT=2, OPTIONS(1)=8 (one end open) and OPTIONS(5)=1, faulted phase (1 by default).

OPTIONS(6) = 1 Phase A

OPTIONS(6) = 2 Phase B

OPTIONS(6) = 3 Phase C

When APIOPT=2, OPTIONS(1)=8 (one end open) and OPTIONS(5)=2, excluded phase (1 by default).

OPTIONS(6) = 1 Phase A

OPTIONS(6) = 2 Phase B

OPTIONS(6) = 3 Phase C

OPTIONS(7) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(2) by default.

OPTIONS(7) = None Opened end bus (must be identical to one of OPTIONS(2), OPTIONS(3), or, if it is non-zero, OPTIONS(4))

Real RVAL (5)

array of 5 elements specifying input values used to define the current fault; ignored except when APIOPT is 2. The elements of RVAL are dependent on the value specified for OPTIONS(1).(input).

RVAL(1) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=1 or 2 (LG), 0.0 by default.

RVAL(1) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

RVAL(1) = None Resistance of the complex L-L fault impedance in pu

When APIOPT=2, OPTIONS(1)=5 (1 phase closed), 0.0 by default.

RVAL(1) = None Resistance of the complex phase impedance in pu

When APIOPT=2, OPTIONS(1)=6 (2 phases closed), 0.0 by default.

RVAL(1) = None Resistance of the complex phase impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=1, 0.0 by default.

RVAL(1) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.

RVAL(1) = None Resistance of the complex L-L fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=1, 0.0 by default.

RVAL(1) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.

RVAL(1) = None Resistance of the complex L-L fault impedance in pu

RVAL(2) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=1 or 2 (LG), 0.0 by default.

RVAL(2) = None Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

RVAL(2) = None Reactance of the complex L-L fault impedance in pu

When APIOPT=2, OPTIONS(1)=5 (1 phase closed), 0.0 by default.

RVAL(2) = None Reactance of the complex phase impedance in pu

When APIOPT=2, OPTIONS(1)=6 (2 phases closed), 0.0 by default.

RVAL(2) = None Reactance of the complex phase impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=1, 0.0 by default.

RVAL(2) = None Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.

RVAL(2) = None Reactance of the complex L-L fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=1, 0.0 by default.

RVAL(2) = None Reactance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.

RVAL(2) = None Reactance of the complex L-L fault impedance in pu

RVAL(3) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

RVAL(3) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.

RVAL(3) = None Resistance of the complex L-G fault impedance in pu

When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.

RVAL(3) = None Resistance of the complex L-G fault impedance in pu

RVAL(4) Specify it per additional conditions as below.

When APIOPT=2, OPTIONS(1)=3 or 4 (LLG), 0.0 by default.

	RVAL(4) = None	Reactance of the complex L-G fault impedance in pu
	When APIOPT=2, OPTIONS(1)=8 (one end open), OPTIONS(5)=2, 0.0 by default.	
	RVAL(4) = None	Reactance of the complex L-G fault impedance in pu
	When APIOPT=2, OPTIONS(1)=9 (both ends closed), OPTIONS(4)=2, 0.0 by default.	
	RVAL(4) = None	Reactance of the complex L-G fault impedance in pu
	RVAL(5)	Specify it per additional conditions as below.
	When APIOPT=2, OPTIONS(1)=8 (one end open), 1.0 by default.	
	RVAL(5) = None	fault location from closed end bus in pu of total line length; must be 1.0 if the branch is a transformer
	When APIOPT=2, OPTIONS(1)=9 (both ends closed), 0.5 by default.	
	RVAL(5) = None	fault location from bus OPTIONS(2) in pu of total line length
Character*2 CKTARG	circuit identifier of branch to be faulted; ignored except when APIOPT is 2 and OPTIONS(1) is 8 or 9 (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	unexpected APIOPT value
	IERR = 2	invalid APIOPT value
	IERR = 3	invalid unbalance type
	IERR = 4	bus not found
	IERR = 5	bus is out-of-service
	IERR = 6	invalid phase value
	IERR = 7	branch not found
	IERR = 8	three-winding transformer not found
	IERR = 9	invalid open end bus
	IERR = 10	invalid distance factor
	IERR = 11	terminated due to invalid fault specification or application
	IERR = 12	SEQD results are not compatible with the working case
	IERR = 13	fault analysis is invalid due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 14	bus type code and series element status inconsistencies
	IERR = 15	invalid OPTIONS value (from SEQD)
	IERR = 16	prerequisite requirements for API are not met

4.1.23. SCOP

Use this API to tabulate unbalanced fault solution output. It gives fault currents arriving at a bus. It must be preceded by the execution of activity SCMU, either interactively, from a response file, or via Python. It must then be referenced using one of the following procedures: (a) One reference with APIOPT=1, followed by any number of references with APIOPT=2, followed by one reference with APIOPT=3. (b) One reference with APIOPT=0. This automatically combines the processing of one APIOPT 1 reference, followed by one APIOPT 2 reference, followed by one APIOPT 3 reference.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SCOP SID ALL UNITS APIOPT
```

Python command syntax:

```
ierr = scop(sid, all, units, apiopt)
```

Fortran command syntax:

```
CALL SCOPAPI(SID, ALL, UNITS, APIOPT, IERR)
```

Where:

Integer SID	a valid subsystem identifier; used only when APIOPT is 0 or 2 and ALL is 0. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag; used only when APIOPT is 0 or 2 (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer UNITS	branch quantity flag; used only when APIOPT is 0 or 2 (input; 1 by default). UNITS = 1 currents UNITS = 2 apparent impedances UNITS = 3 apparent admittances
Integer APIOPT	mode of operation (input; 0 by default). APIOPT = 0 initialize for short circuit output, produce the output, and run post-processing clean up APIOPT = 1 initialize for short circuit output APIOPT = 2 produce output APIOPT = 3 post-processing clean up
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid UNITS value

IERR = 4	invalid APIOPT value
IERR = 5	unexpected APIOPT value
IERR = 6	SCMU results error; one of the these occurred: No SCMU results file is open; SCMU results are not compatible with the working case; Error reading the SCMU results file
IERR = 7	prerequisite requirements for API are not met

4.1.24. SEQD

This API routine is obsolete. It has been replaced by the API routine [seqd_2](#).

Use this API to factorize the sequence matrices in preparation for unbalanced fault calculations.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SEQD  OPTIONS(1)  OPTIONS(2)
```

Python command syntax:

```
ierr = seqd(options)
```

Fortran command syntax:

```
CALL SEQDAPI(OPTIONS, IERR)
```

Where:

Integer OPTIONS (2)	array of 2 elements specifying options to be used in constructing the sequence matrices(input).	
	OPTIONS(1)	dc line and FACTS device option (0 by default)
	OPTIONS(1) = 0	block and ignore
	OPTIONS(1) = 1	convert to constant admittance load
	OPTIONS(2)	transformer impedance correction option (1 by default)
	OPTIONS(2) = 0	do not apply to zero sequence
	OPTIONS(2) = 1	apply to zero sequence
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	prerequisite requirements for API are not met

4.1.25. SEQD_2

Use this API routine to factorize the sequence matrices in preparation for unbalanced fault calculations SC-MU and SPCB.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SEQD_2  OPTIONS(1)  OPTIONS(2)  OPTIONS(3)
```

Python command syntax:

```
ierr = seqd_2(options)
```

Fortran command syntax:

```
CALL SEQD_2(OPTIONS, IERR)
```

Where:

Integer OPTIONS (3)	array of 3 elements specifying options to be used in constructing the sequence matrices(input).	
	OPTIONS(1)	dc line and FACTS device option (0 by default)
	OPTIONS(1) = 0	block and ignore
	OPTIONS(1) = 1	convert to constant admittance load
	OPTIONS(2)	transformer impedance correction option (1 by default)
	OPTIONS(2) = 0	do not apply to zero sequence
	OPTIONS(2) = 1	apply to zero sequence
	OPTIONS(3)	fault analysis generator reactance option; ignored if generators are already "converted" (0 by default)
	OPTIONS(3) = 0	use subtransient reactance
	OPTIONS(3) = 1	use transient reactance
	OPTIONS(3) = 2	use synchronous reactance
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	fault analysis is invalid due to the presence of in-service induction machines that are in the "stalled" or "tripped" state
	IERR = 3	bus type code and series element status inconsistencies
	IERR = 4	prerequisite requirements for API are not met

4.1.26. SEQUENCE_NETWORK_SETUP

Use this API to specify or return the option to enable or disable automatic fault analysis sequence network setup.

This API routine was first introduced in release 29.0.0.

Batch command syntax:

```
BAT_SEQUENCE_NETWORK_SETUP IVAL
```

Python command syntax:

```
ierr = sequence_network_setup(ival)
ierr, ival = sequence_network_setup()
```

Fortran command syntax:

```
CALL SEQUENCE_NETWORK_SETUP_API(IVAL, IOCODE, IERR)
```

Where:

Integer IVAL	value of the option setting (input; if Batch command, or for Python if specified as an argument, or for Fortran if IOCODE is 0, 0 by default; else output).	
	IVAL = 0	SCMU assumes SEQD has already been executed.
	IVAL = 1	SCMU always executes activity SEQD.
Integer IOCODE	Indicates the operation mode of the API (no default allowed).	
	IOCODE = 0	set the option setting to the value specified in IVAL.
	IOCODE = 1	return the current value of the option setting in IVAL.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid IVAL value
	IERR = 2	invalid IOCODE value
	IERR = 3	prerequisite requirements for API are not met

4.1.27. SQEX

Use this API to tabulate all fault analysis data pertaining to a specified bus.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SQEX  SID  ALL
```

Python command syntax:

```
ierr = sqex(sid, all)
```

Fortran command syntax:

```
CALL SQEXNW(SID, ALL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
Integer IERR	ALL = 1	process all buses
	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	prerequisite requirements for API are not met

Fault Analysis Operation APIs contains API routines corresponding to the operational functions of PSS®E Fault Analysis.

4.2. Fault Analysis Data

Fault Analysis, or Short Circuit, Data Changing APIs contains API routines specific to adding, modifying and deleting short circuit data.

Note that, except for the SEQ_MUTUAL_DATA API, the SEQ_ APIs always modify data of an existing element.

4.2.1. MBIDNCS

Use this API to change the table name of the specified non-conventional source fault contribution table in the working case.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_MBIDNCS  'NAME'  'NAMNEW'
```

Python command syntax:

```
ierr = mbidncs(name, namnew)
```

Fortran command syntax:

```
CALL MBIDNCS(NAME, NAMNEW, IERR)
```

Where:

Character*12 NAME	name of the NCSFCC table for which the NCSFCC table name is to be changed (input; no default allowed).	
Character*12 NAMNEW	new name to be assigned to the NCSFCC table (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	NCSFCC table NAME not found
	IERR = 2	NCSFCC table NEWNAM already exists
	IERR = 3	a non-blank new identifier must be specified
	IERR = 4	prerequisite requirements for API are not met

4.2.2. SEQ_3_WIND_GROUNDING_DATA

Use this API to modify the zero sequence grounding data of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Zero Sequence Transformer Data).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SEQ_3_WIND_GROUNDING_DATA IBUS JBUS KBUS 'CKT' INTGAR(1)
REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = seq_3_wind_grounding_data(ibus, jbus, kbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_3_WINDING_GROUNDING_API_2( IBUS,JBUS,KBUS,CKT,INTGAR,REALAR,IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying one element (defaulted data items are unchanged)(input). INTGAR(1) CC, connection code
Real REALAR (2)	array of 2 elements specifying (defaulted data items are unchanged)(input). REALAR(1) RG, zero sequence grounding resistance REALAR(2) XG, zero sequence grounding reactance
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 fatal error occurred IERR = 1 bus not found IERR = 2 circuit identifier is more than two characters IERR = 3 three-winding transformer not found IERR = 4 prerequisite requirements for API are not met IERR = -1 data error, warning and information messages; one or more of: - Invalid winding connection code. - Connection code is such that more than one winding requires a grounding impedance

4.2.3. SEQ_3_WIND_WINDING_DATA

Use this API to modify the zero sequence impedance data of one winding of an existing three-winding transformer in the working case (see PSSE Program Operation Manual, Zero Sequence Transformer Data).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SEQ_3_WIND_WINDING_DATA IBUS JBUS KBUS 'CKT' WARG REALAR(1)
REALAR(2)
```

Python command syntax:

```
ierr = seq_3_wind_winding_data(ibus, jbus, kbus, ckt, warg, realar)
```

Fortran command syntax:

```
CALL SEQ_THREE_WINDING_WINDING_API_2( IBUS,JBUS,KBUS,CKT,WARG,REALAR,IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).	
Integer JBUS	bus number one of the other buses (input; no default allowed).	
Integer KBUS	bus number of the third bus (input; no default allowed).	
Character*2 CKT	transformer circuit identifier (input; '1' by default).	
Integer WARG	winding number (1, 2 or 3) (input; no default allowed).	
Real REALAR (2)	array of 2 elements specifying (defaulted data items are unchanged)(input).	
	REALAR(1)	Ri, zero sequence winding resistance
	REALAR(2)	Xi, zero sequence winding reactance
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	three-winding transformer not found
	IERR = 4	invalid winding number
	IERR = 5	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - None

4.2.4. SEQ_BRANCH_DATA

This API routine is obsolete. It has been replaced by the API routine [seq_branch_data_3](#).

Use this API to modify the zero sequence data of an existing non-transformer branch in the working case (see PSSE Program Operation Manual, Zero Sequence Non-Transformer Branch Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_BRANCH_DATA IBUS JBUS 'CKT' REALAR(1)..REALAR(7)
```

Python command syntax:

```
ierr = seq_branch_data(ibus, jbus, ckt, realar)
```

Fortran command syntax:

```
CALL SEQ_BRANCH_API_2(IBUS, JBUS, CKT, REALAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Real REALAR (7)	array of 7 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) RLINZ, zero sequence branch resistance
	REALAR(2) XLINZ, zero sequence branch reactance
	REALAR(3) BCHZ, zero sequence total line charging
	REALAR(4) GI, zero sequence active line shunt at bus IBUS end
	REALAR(5) BI, zero sequence reactive line shunt at bus IBUS end
	REALAR(6) GJ, zero sequence active line shunt at bus JBUS end
	REALAR(7) BJ, zero sequence reactive line shunt at bus JBUS end
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 circuit identifier is more than two characters
	IERR = 3 circuit identifier may not start with &
	IERR = 4 branch not found
	IERR = 5 branch exists but it is a two-winding transformer

IERR = 6

IERR = -1

prerequisite requirements for API are not met
data error, warning and information messages; one or more of: - branch is treated as a zero impedance line but its zero sequence impedance is non-zero

4.2.5. SEQ_BRANCH_DATA_3

Use this API to modify the zero sequence data of an existing non-transformer branch in the working case (see PSSE Program Operation Manual, Zero Sequence Non-Transformer Branch Data).

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SEQ_BRANCH_DATA_3 IBUS JBUS CKT INTGAR REALAR(1)..REALAR(8)
```

Python command syntax:

```
ierr = seq_branch_data_3(ibus, jbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_BRANCH_API_3(IBUS, JBUS, CKT, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying MOV-protected series capacitor flag(input).
	INTGAR(1) MOV-protected series capacitor flag
	INTGAR(1) = 0 not a MOV-protected branch
	INTGAR(1) = 1 MOV-protected series capacitor with MOV protection enabled
	INTGAR(1) = 2 MOV-protected series capacitor with MOV protection disabled
	INTGAR(1) = 3 spark gap protection enabled
Real REALAR (8)	array of 8 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) RLINZ, zero sequence branch resistance
	REALAR(2) XLINZ, zero sequence branch reactance
	REALAR(3) BCHZ, zero sequence total line charging
	REALAR(4) GI, zero sequence active line shunt at bus IBUS end
	REALAR(5) BI, zero sequence reactive line shunt at bus IBUS end
	REALAR(6) GJ, zero sequence active line shunt at bus JBUS end
	REALAR(7) BJ, zero sequence reactive line shunt at bus JBUS end
	REALAR(8) MOVI, mov protected current level in kA
Integer IERR	error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	circuit identifier may not start with &
IERR = 4	branch not found
IERR = 5	branch exists but it is a two-winding transformer
IERR = 6	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - branch is treated as a zero impedance line but its zero sequence impedance is non-zero

4.2.6. SEQ_BUS_DATA

Bus load sequence data is now accessible as load sequence data.

Use this API routine to modify the sequence data of an existing bus in the working case (see PSSE Program Operation Manual, Negative Sequence Shunt Load Data and Zero Sequence Shunt Load Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_BUS_DATA  IBUS  REALAR(1) .. REALAR(4)
```

Python command syntax:

```
ierr = seq_bus_data(ibus, realar)
```

Fortran command syntax:

```
CALL SEQ_BUS_API_2(IBUS, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).	
Real REALAR (4)	array of 4 elements specifying (defaulted data items are unchanged)(input).	
	REALAR(1)	GNEG, negative sequence shunt admittance active component
	REALAR(2)	BNEG, negative sequence shunt admittance reactive component
	REALAR(3)	GZERO, zero sequence shunt admittance active component
	REALAR(4)	BZERO, zero sequence shunt admittance reactive component
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	the SEQ_BUS_DATA API routine is obsolete
	IERR = 2	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - None

4.2.7. SEQ_FIXED_SHUNT_DATA

Use this API to modify the zero sequence data of an existing fixed bus shunt in the working case (see PSSE Program Operation Manual, Zero Sequence Fixed Shunt Data).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SEQ_FIXED_SHUNT_DATA IBUS 'ID' REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = seq_fixed_shunt_data(ibus, id, realar)
```

Fortran command syntax:

```
CALL SEQ_FIXED_SHUNT_API(IBUS, ID, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).	
Character*2 ID	shunt identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (defaulted data items are unchanged)(input).	
	REALAR(1)	GSZERO, active power component of fixed shunt zero sequence admittance (conductance)
	REALAR(2)	BSZERO, reactive power component of fixed shunt zero sequence admittance (susceptance)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	shunt identifier is more than two characters
	IERR = 3	fixed shunt not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Admittance components with different signs in the positive and zero sequences

4.2.8. SEQ_INDUCTION_MACH_DATA

This API routine is obsolete. It has been replaced by the API routine [seq_induction_mach_data_2](#).

Use this API routine to modify the sequence data of an existing induction machine in the working case (see PSSE Program Operation Manual, Induction Machine Impedance Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SEQ_INDUCTION_MACH_DATA IBUS 'ID' INTGAR(1) INTGAR(2)
REALAR(1) . . REALAR(6)
```

Python command syntax:

```
ierr = seq_induction_mach_data(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_INDUCTION_MACH_API(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (defaulted data items are unchanged)(input).
INTGAR(1)	CZG, code indicating the units in which the zero sequence grounding impedance is specified
INTGAR(1) = 1	for per unit
INTGAR(1) = 2	for ohms
INTGAR(2)	CGR, grounding code (0 = ungrounded; 1 = grounded) (0 by default)
Real REALAR (6)	array of 6 elements specifying (defaulted data items are unchanged)(input).
REALAR(1)	ILK2IR, ratio of positive sequence locked rotor current to rated current
REALAR(2)	ROVERX, ratio of positive sequence resistance to reactance
REALAR(3)	R0, machine zero sequence fault analysis resistance
REALAR(4)	X0, machine zero sequence fault analysis reactance
REALAR(5)	RG, machine zero sequence grounding resistance
REALAR(6)	XG, machine zero sequence grounding reactance

Integer IERR

error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	machine identifier is more than two characters
IERR = 3	induction machine not found
IERR = 4	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid CZG data value. - invalid grounding code. - CZG is 2 but the bus has no base voltage specified

4.2.9. SEQ_INDUCTION_MACH_DATA_2

Use this API routine to modify the sequence data of an existing induction machine in the working case (see PSSE Program Operation Manual, Induction Machine Impedance Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SEQ_INDUCTION_MACH_DATA_2  IBUS ID INTGAR(1)..INTGAR(2)
                                REALAR(1)..REALAR(10)
```

Python command syntax:

```
ierr = seq_induction_mach_data_2(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_INDUCTION_MACH_API_2(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (defaulted data items are unchanged)(input).
	INTGAR(1) CZG, code indicating the units in which the zero sequence grounding impedance is specified
	INTGAR(1) = 1 for per unit
	INTGAR(1) = 2 for ohms
	INTGAR(2) CGR, grounding code (0 = ungrounded; 1 = grounded) (0 by default)
Real REALAR (10)	array of 10 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) ILK2IR, ratio of positive sequence locked rotor current to rated current
	REALAR(2) ROVERX, ratio of positive sequence resistance to reactance
	REALAR(3) R0, machine zero sequence fault analysis resistance
	REALAR(4) X0, machine zero sequence fault analysis reactance
	REALAR(5) RG, machine zero sequence grounding resistance
	REALAR(6) XG, machine zero sequence grounding reactance
	REALAR(7) RT, ratio of locked rotor current to rated current (transient)

	REALAR(8)	XT, ratio of Rpos to Xpos (these two used to set IMZPSN)(transient)
	REALAR(9)	RN, ratio of locked rotor current to rated current (negative sequence)
	REALAR(10)	XN, ratio of Rpos to Xpos (these two used to set IMZPSN)(negative sequence)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	induction machine not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Invalid CZG data value. - invalid grounding code. - CZG is 2 but the bus has no base voltage specified

4.2.10. SEQ_LOAD_DATA

Use this API routine to modify the sequence data of an existing load in the working case (see PSSE Program Operation Manual, Load Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SEQ_LOAD_DATA IBUS 'ID' INTGAR(1) REALAR(1)..REALAR(4)
```

Python command syntax:

```
ierr = seq_load_data(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_LOAD_API(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying one element(input).
	INTGAR(1) CGR, load grounding code (0 = ungrounded; 1 = grounded) (0 by default)
Real REALAR (4)	array of 4 elements specifying (input).
	REALAR(1) GNEG, negative sequence active power load component; entered as admittance in MW at 1.0 per unit voltage (0.0 by default)
	REALAR(2) BNEG, negative sequence reactive power load component; BNEG is negative for an inductive load and positive for a capacitive load; entered as admittance in MVar at 1.0 per unit voltage (0.0 by default)
	REALAR(3) GZERO, zero sequence active power load component; entered as admittance in MW at 1.0 per unit voltage (0.0 by default)
	REALAR(4) BZERO, zero sequence reactive power load component; BZERO is negative for an inductive load and positive for a capacitive load; entered as admittance in MVar at 1.0 per unit voltage (0.0 by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 load identifier is more than two characters
	IERR = 3 load not found

IERR = 4

IERR = -1

prerequisite requirements for API are not met
data error, warning and information mes-
sages; one or more of: - invalid grounding
code

4.2.11. SEQ_MACHINE_DATA

This API routine is obsolete. It has been replaced by the API routine [seq_machine_data_3](#).

Use this API routine to modify the sequence data of an existing machine in the working case (see PSSE Program Operation Manual, Positive Sequence Generator Impedance Data, Negative Sequence Generator Impedance Data and Zero Sequence Generator Impedance Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_MACHINE_DATA  IBUS  'ID'  REALAR(1) .. REALAR(6)
```

Python command syntax:

```
ierr = seq_machine_data(ibus, id, realar)
```

Fortran command syntax:

```
CALL SEQ_MACHINE_API_2(IBUS, ID, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Real REALAR (6)	array of 6 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) ZRPOS, machine positive sequence fault analysis resistance
	REALAR(2) ZXPOS, machine positive sequence fault analysis reactance
	REALAR(3) ZRNEG, machine negative sequence fault analysis resistance
	REALAR(4) ZXNEG, machine negative sequence fault analysis reactance
	REALAR(5) RZERO, machine zero sequence fault analysis resistance
	REALAR(6) XZERO, machine zero sequence fault analysis reactance
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found
	IERR = 4 prerequisite requirements for API are not met

IERR = -1

data error, warning and information messages; one or more of: - Machine impedance is (0.0,0.0)

4.2.12. SEQ_MACHINE_DATA_3

This API routine is obsolete. It has been replaced by the API routine [seq_machine_data_4](#).

Use this API routine to modify the sequence data of an existing machine in the working case (see PSSE Program Operation Manual, Positive Sequence Generator Impedance Data, Negative Sequence Generator Impedance Data and Zero Sequence Generator Impedance Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SEQ_MACHINE_DATA_3  IBUS  'ID'  INTGAR(1)  REALAR(1) .. REALAR(10)
```

Python command syntax:

```
ierr = seq_machine_data_3(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_MACHINE_API_3(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying one element (defaulted data items are unchanged)(input).
	INTGAR(1) CZG, code indicating the units in which the zero sequence grounding impedance is specified
	INTGAR(1) = 1 for per unit
	INTGAR(1) = 2 for ohms
Real REALAR (10)	array of 10 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) RPOS, machine positive sequence fault analysis resistance
	REALAR(2) X", machine positive sequence fault analysis subtransient reactance
	REALAR(3) RNEG, machine negative sequence fault analysis resistance
	REALAR(4) XNEG, machine negative sequence fault analysis reactance
	REALAR(5) RZERO, machine zero sequence fault analysis resistance
	REALAR(6) XZERO, machine zero sequence fault analysis reactance
	REALAR(7) X', machine positive sequence fault analysis transient reactance

	REALAR(8)	Xs, machine positive sequence fault analysis synchronous reactance
	REALAR(9)	RG, machine zero sequence grounding resistance
	REALAR(10)	XG, machine zero sequence grounding reactance
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	machine not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Grounding impedance units code indicates input in ohms but no base voltage has been specified for the bus. - Invalid grounding impedance units code. - Invalid grounding impedance units code. - Invalid positive sequence reactance value. - Negative sequence impedance is (0.0,0.0). - Zero sequence impedance is (0.0,0.0)

4.2.13. SEQ_MACHINE_DATA_4

Use this API routine to modify the sequence data of an existing machine in the working case (see PSSE Program Operation Manual, Positive Sequence Generator Impedance Data, Negative Sequence Generator Impedance Data and Zero Sequence Generator Impedance Data).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SEQ_MACHINE_DATA_4  IBUS ID INTGAR REALAR(1)..REALAR(11)
```

Python command syntax:

```
ierr = seq_machine_data_4(ibus, id, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_MACHINE_API_4(IBUS, ID, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (1)	array of 1 elements specifying one element (defaulted data items are unchanged)(input).
	INTGAR(1) CZG, code indicating the units in which the zero sequence grounding impedance is specified
	INTGAR(1) = 1 for per unit
	INTGAR(1) = 2 for ohms
Real REALAR (11)	array of 11 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) RPOS, machine positive sequence fault analysis resistance
	REALAR(2) X", machine positive sequence fault analysis subtransient reactance
	REALAR(3) RNEG, machine negative sequence fault analysis resistance
	REALAR(4) XNEG, machine negative sequence fault analysis reactance
	REALAR(5) RZERO, machine zero sequence fault analysis resistance
	REALAR(6) XZERO, machine zero sequence fault analysis reactance
	REALAR(7) X', machine positive sequence fault analysis transient reactance
	REALAR(8) Xs, machine positive sequence fault analysis synchronous reactance

Integer IERR	REALAR(9)	RG, machine zero sequence grounding resistance
	REALAR(10)	XG, machine zero sequence grounding reactance
	REALAR(11)	RFDG, machine reference angle in degrees
	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	machine not found
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Grounding impedance units code indicates input in ohms but no base voltage has been specified for the bus. - Invalid grounding impedance units code. - Invalid grounding impedance units code. - Invalid positive sequence reactance value. - Negative sequence impedance is (0.0,0.0). - Zero sequence impedance is (0.0,0.0)

4.2.14. SEQ_MACHINE_NCS_DATA

Use this API routine to modify a machine's existing non-conventional source fault current contribution (NCSFCC) data or to add NCSFCC data to an existing machine in the working case.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SEQ_MACHINE_NCS_DATA  IBUS ID INTGAR REALAR(1) REALAR(2) REALAR(3)
                           NAMEAR(1) NAMEAR(2)
```

Python command syntax:

```
ierr = seq_machine_ncs_data(ibus, id, intgar, realar, namear)
```

Fortran command syntax:

```
CALL SEQ_MACHINE_NCS_DATA(IBUS, ID, INTGAR, REALAR, NAMEAR, IERR)
```

Where:

Integer IBUS	bus number (input).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR	characteristic type; 0 for none, 1 for time dependent, 2 for voltage dependent (input; 0 by default).
real REALAR (3)	array of 3 elements specifying Real Options(input).
	REALAR(1) IFMAX, per unit total current magnitude allowed during a fault (1.1 by default)
	REALAR(2) DBVMIN, per unit dead-band minimum voltage at POI (0.9 by default)
	REALAR(3) DBVMAX, per unit dead-band maximum voltage at POI (1.1 by default)
character*12 NAMEAR (2)	array of 2 elements specifying Specifies the names of the non-conventional source fault contribution (NCSFCC) tables(input).
	NAMEAR(1) positive sequence table name (by default)
	NAMEAR(2) negative sequence table name (by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found
	IERR = 4 no table specified for the positive sequence
	IERR = 5 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - Invalid characteristic type flag. - Table not found. - Machine and ta-

ble characteristic type mismatch. - IFMAX is
less than 1.0. - DBVMAX is less than DBVMIN.

4.2.15. SEQ_MACHINE_NCS_DATA_PURG

Use this API routine to delete a machine's existing non-conventional source fault current contribution (NCSFCC) data.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SEQ_MACHINE_NCS_DATA_PURG IBUS ID
```

Python command syntax:

```
ierr = seq_machine_ncs_data_purg(ibus, id)
```

Fortran command syntax:

```
CALL SEQ_MACHINE_NCS_DATA_PURG(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus number (input).
Character*2 ID	machine identifier (input; '1' by default).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 bus not found
	IERR = 2 machine identifier is more than two characters
	IERR = 3 machine not found
	IERR = 4 no non-conventional source data specified for this machine

4.2.16. SEQ_MUTUAL_DATA

Use this API to modify existing zero sequence mutual impedance data in the working case or to add a new zero sequence mutual coupling to the working case (see PSSE Program Operation Manual, Zero Sequence Mutual Impedance Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_MUTUAL_DATA IBUS JBUS 'CKT1' KBUS LBUS 'CKT2'
REALAR(1) .. REALAR(6)
```

Python command syntax:

```
ierr = seq_mutual_data(ibus, jbus, ckt1, kbus, lbus, ckt2, realar)
```

Fortran command syntax:

```
CALL SEQ_MUTUAL_API_2(IBUS, JBUS, CKT1, KBUS, LBUS, CKT2, REALAR, IERR)
```

Where:

Integer IBUS	bus number of the from bus of the first branch (input; no default allowed).												
Integer JBUS	bus number of the to bus of the first branch (input; no default allowed).												
Character*2 CKT1	first branch circuit identifier (input; '1' by default).												
Integer KBUS	bus number of the from bus of the second branch (input; no default allowed).												
Integer LBUS	bus number of the to bus of the second branch to bus (input; no default allowed).												
Character*2 CKT2	second branch circuit identifier (input; '1' by default).												
Real REALAR (6)	array of 6 elements specifying (input). <table> <tr> <td>REALAR(1)</td><td>RM, branch-to-branch mutual resistance (0.0 by default)</td></tr> <tr> <td>REALAR(2)</td><td>XM, branch-to-branch mutual reactance (0.0 by default)</td></tr> <tr> <td>REALAR(3)</td><td>BIJ1, B factor at IBUS end of the first branch (0.0 by default)</td></tr> <tr> <td>REALAR(4)</td><td>BIJ2, B factor at JBUS end of the first branch (1.0 by default)</td></tr> <tr> <td>REALAR(5)</td><td>BKL1, B factor at KBUS end of the second branch (0.0 by default)</td></tr> <tr> <td>REALAR(6)</td><td>BKL2, B factor at LBUS end of the second branch (1.0 by default)</td></tr> </table>	REALAR(1)	RM, branch-to-branch mutual resistance (0.0 by default)	REALAR(2)	XM, branch-to-branch mutual reactance (0.0 by default)	REALAR(3)	BIJ1, B factor at IBUS end of the first branch (0.0 by default)	REALAR(4)	BIJ2, B factor at JBUS end of the first branch (1.0 by default)	REALAR(5)	BKL1, B factor at KBUS end of the second branch (0.0 by default)	REALAR(6)	BKL2, B factor at LBUS end of the second branch (1.0 by default)
REALAR(1)	RM, branch-to-branch mutual resistance (0.0 by default)												
REALAR(2)	XM, branch-to-branch mutual reactance (0.0 by default)												
REALAR(3)	BIJ1, B factor at IBUS end of the first branch (0.0 by default)												
REALAR(4)	BIJ2, B factor at JBUS end of the first branch (1.0 by default)												
REALAR(5)	BKL1, B factor at KBUS end of the second branch (0.0 by default)												
REALAR(6)	BKL2, B factor at LBUS end of the second branch (1.0 by default)												
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>no errors occurred</td></tr> <tr> <td>IERR > 0</td><td>fatal error occurred</td></tr> </table>	IERR = 0	no errors occurred	IERR > 0	fatal error occurred								
IERR = 0	no errors occurred												
IERR > 0	fatal error occurred												

IERR = 1	bus not found
IERR = 2	circuit identifier is more than two characters
IERR = 3	circuit identifier may not start with &
IERR = 4	branch not found
IERR = 5	mutual couples a branch to itself
IERR = 6	branch is a transformer
IERR = 7	branch is a zero impedance line
IERR = 8	mutual coupling table is full
IERR = 9	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid B factor (<0.0 or >1.0). - B1 is not less than B2

4.2.17. SEQ_NCS_FLT_CNTRB_CHNG

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SEQ_NCS_FLT_CNTRB_CHNG  IBUS ID POINTS REALAR(1)..REALAR(POINTS)
                              CPLXAR(1)..CPLXAR(POINTS)
```

Python command syntax:

```
ierr = seq_ncs_flt_cntrb_chng(ibus, id, points, realar, cplxar)
```

Fortran command syntax:

```
CALL SEQ_NCS_FLT_CNTRB_CHNG(IBUS, ID, POINTS, REALAR, CPLXAR, IERR)
```

Where:

Integer IBUS	bus number (input).
Character*2 ID	machine identifier (input; '1' by default).
Integer POINTS	number of data points (input; no default allowed).
Real REALAR	Array of 'POINTS' values specifying T_i in seconds, in strictly ascending order of T_i (input; no default allowed).
Complex CPLXAR	Array of 'POINTS' values specifying C_iP and C_iQ (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no errors occurred

4.2.18. SEQ_NCS_FLT_CNTRB_DATA

This API routine is obsolete. It has been replaced by the API routines [SEQ_NCS_TABLE_DATA](#) and [SEQ_MACHINE_NCS_DATA](#).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SEQ_NCS_FLT_CNTRB_DATA  IBUS ID POINTS REALAR(1)..REALAR(POINTS)
                             CPLXAR(1)..CPLXAR(POINTS)
```

Python command syntax:

```
ierr = seq_ncs_flt_cntrb_data(ibus, id, points, realar, cplxar)
```

Fortran command syntax:

```
CALL SEQ_NCS_FLT_CNTRB_DATA(IBUS, ID, POINTS, REALAR, CPLXAR, IERR)
```

Where:

Integer IBUS	bus number (input).
Character*2 ID	machine identifier (input; '1' by default).
Integer POINTS	number of data points (input; no default allowed).
Real REALAR	Array of 'POINTS' values specifying T_i in seconds, in strictly ascending order of T_i (input; no default allowed).
Complex CPLXAR	Array of 'POINTS' values specifying C_iP and C_iQ (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no errors occurred

4.2.19. SEQ_NCS_FLT_CNTRB_PURG

This API routine is obsolete. It has been replaced by the API routine [SEQ_MACHINE_NCS_DATA_PURG](#).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SEQ_NCS_FLT_CNTRB_PURG IBUS ID
```

Python command syntax:

```
ierr = seq_ncs_flt_cntrb_purg(ibus, id)
```

Fortran command syntax:

```
CALL SEQ_NCS_FLT_CNTRB_PURG(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus number (input).	
Character*2 ID	machine identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	machine identifier is more than two characters
	IERR = 3	machine not found
	IERR = 4	Non-Conventional Source data not found
	IERR = 5	prerequisite requirements for API are not met

4.2.20. SEQ_NCS_TABLE_DATA

Use this API to modify the data of an existing non-conventional source fault contribution table in the working case or to add a new non-conventional source fault contribution table to the working case.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SEQ_NCS_TABLE_DATA 'NAME' POINTS TYPARG REALAR(1) .. REALAR(POINTS)
CPLXAR(1) .. CPLXAR(POINTS)
```

Python command syntax:

```
ierr = seq_ncs_table_data(name, points, typarg, realar, cplxar)
```

Fortran command syntax:

```
CALL SEQ_NCS_TABLE_DATA(NAME, POINTS, TYPARG, REALAR, CPLXAR, IERR)
```

Where:

character*12 NAME	table name (input; no default allowed).
Integer POINTS	number of points specified in table 'NAME' (1 through 20) (input; no default allowed).
Integer TYPARG	characteristic type; 0 for time dependent, 1 for voltage dependent (input; 0 by default).
Real REALAR (POINTS)	array of 'POINTS' values specifying T_i in seconds or V_i in per unit, in strictly ascending order of T_i or V_i (input).
Complex CPLXAR (POINTS)	array of 'POINTS' values specifying C_iP and C_iQ (input).
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR > 0 fatal error occurred
	IERR = 1 blank table name is invalid
	IERR = 2 invalid POINTS value
	IERR = 3 table does not have at least 1 point
	IERR = 4 maximum number of tables are already in the case
	IERR = 5 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - invalid characteristic type flag - point is beyond the previous end of table - T_i or V_i is negative - C_i is (0.0,0.0) - T_i or V_i values are not in increasing order

4.2.21. SEQ_NCS_TABLE_PURG

Use this API to delete an existing non-conventional source fault contribution table from the working case.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SEQ_TABLE_PURG  'NAME'
```

Python command syntax:

```
ierr = seq_ncs_table_purg(name)
```

Fortran command syntax:

```
CALL SEQ_NCS_TABLE_PURG(NAME, IERR)
```

Where:

character*12 NAME	table name (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	table not found
	IERR = 2	prerequisite requirements for API are not met

4.2.22. SEQ_SWITCHED_SHUNT_DATA

This API routine is obsolete. It has been replaced by the API routine [SEQ_SWITCHED_SHUNT_DATA_3](#).

Use this API to modify the zero sequence data of an existing switched shunt in the working case (see PSSE Program Operation Manual, Zero Sequence Switched Shunt Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_SWITCHED_SHUNT_DATA  IBUS  REALAR(1) .. REALAR(8)
```

Python command syntax:

```
ierr, realaro = seq_switched_shunt_data(ibus, realari)
```

Fortran command syntax:

```
CALL SEQ_SWITCHED_SHUNT_API_2(IBUS, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Real REALAR (9)	(first eight are input values; last value is output) (defaulted data items are unchanged) (input (output)).
Real REALARI (8)	array of 8 elements specifying corresponding to values REALAR(1) through REALAR(8) as described above(input).
	REALARI(1) BZ1, zero sequence increment in MVAR per step for block 1
	REALARI(2) BZ2, zero sequence increment in MVAR per step for block 2
	REALARI(3) BZ3, zero sequence increment in MVAR per step for block 3
	REALARI(4) BZ4, zero sequence increment in MVAR per step for block 4
	REALARI(5) BZ5, zero sequence increment in MVAR per step for block 5
	REALARI(6) BZ6, zero sequence increment in MVAR per step for block 6
	REALARI(7) BZ7, zero sequence increment in MVAR per step for block 7
	REALARI(8) BZ8, zero sequence increment in MVAR per step for block 8
Real REALARO (1)	array of 1 elements specifying one element corresponding to value REALAR(9) as described above(output).
	REALARO(1) present zero sequence switched shunt admittance in MVAR (returned)
Integer IERR	error code (output).

IERR = 0	no errors occurred
IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	no switched shunt at bus
IERR = 3	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Block has N zero and B non-zero. - Block has admittances with different signs in positive and zero sequences

4.2.23. SEQ_SWITCHED_SHUNT_DATA_3

Use this API to modify the zero sequence data of an existing switched shunt in the working case (see PSSE Program Operation Manual, Zero Sequence Switched Shunt Data).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SEQ_SWITCHED_SHUNT_DATA_3  IBUS  'ID', REALAR(1)..REALAR(8)
```

Python command syntax:

```
ierr, realaro = seq_switched_shunt_data_3(ibus, id, realari)
```

Fortran command syntax:

```
CALL SEQ_SWITCHED_SHUNT_API_3(IBUS, ID, REALAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
character*2 ID	Switched shunt identifier (input; 1 by default).
Real REALAR (9)	(first eight are input values; last value is output) (defaulted data items are unchanged) (input (output)).
Real REALARI (8)	array of 8 elements specifying corresponding to values REALAR(1) through REALAR(8) as described above(input).
	REALARI(1) BZ1, zero sequence increment in MVAR per step for block 1
	REALARI(2) BZ2, zero sequence increment in MVAR per step for block 2
	REALARI(3) BZ3, zero sequence increment in MVAR per step for block 3
	REALARI(4) BZ4, zero sequence increment in MVAR per step for block 4
	REALARI(5) BZ5, zero sequence increment in MVAR per step for block 5
	REALARI(6) BZ6, zero sequence increment in MVAR per step for block 6
	REALARI(7) BZ7, zero sequence increment in MVAR per step for block 7
	REALARI(8) BZ8, zero sequence increment in MVAR per step for block 8
Real REALARO (1)	array of 1 elements specifying one element corresponding to value REALAR(9) as described above(output).
	REALARO(1) present zero sequence switched shunt admittance in MVAR (returned)
Integer IERR	error code (output).
	IERR = 0 no errors occurred

IERR > 0	fatal error occurred
IERR = 1	bus not found
IERR = 2	shunt identifier is more than two characters
IERR = 2	switched shunt not found
IERR = 3	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Block has N zero and B non-zero. - Block has admittances with different signs in positive and zero sequences

4.2.24. SEQ_THREE_WINDING_DATA

This API routine is obsolete. It has been replaced by the API routine [seq_three_winding_data_3](#).

Use this API to modify the zero sequence data of an existing three-winding transformer in the working case.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_THREE_WINDING_DATA IBUS JBUS KBUS 'CKT' INTGAR(1)
REALAR(1) . . REALAR(8)
```

Python command syntax:

```
ierr = seq_three_winding_data(ibus, jbus, kbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_THREE_WINDING_API(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, IERR,
NERR)
```

Where:

Integer IBUS	bus number of one of the buses (input).
Integer JBUS	bus number one of the other buses (input).
Integer KBUS	bus number of the third bus (input).
Character*2 CKT	transformer circuit identifier (input).
Integer INTGAR (1)	array of 1 elements specifying one element(input). INTGAR(1) CC, connection code
Real REALAR (8)	array of 8 elements specifying (input). REALAR(1) RG, zero sequence grounding resistance REALAR(2) XG, zero sequence grounding reactance REALAR(3) R1, zero sequence winding one resistance REALAR(4) X1, zero sequence winding one reactance REALAR(5) R2, zero sequence winding two resistance REALAR(6) X2, zero sequence winding two reactance REALAR(7) R3, zero sequence winding three resistance REALAR(8) X3, zero sequence winding three reactance
Integer IERR	error code (output). IERR = 0 no errors occurred IERR > 0 error occurred IERR = 1 bus not found IERR = 2 circuit identifier is more than two characters IERR = 3 three-winding transformer not found IERR = 4 prerequisite requirements for API are not met

	IERR = -1	warnings - one or more of: - Invalid winding connection code. - Connection code is such that more than one winding requires a grounding impedance
Integer NERR	number of entries in PBUF02 containing error messages (output).	

4.2.25. SEQ_THREE_WINDING_DATA_3

Use this API to modify the zero sequence data of an existing three-winding transformer in the working case.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SEQ_THREE_WINDING_DATA_3 IBUS JBUS KBUS 'CKT'
  INTGAR(1)..INTGAR(3) REALAR(1)..REALAR(14)
```

Python command syntax:

```
ierr = seq_three_winding_data_3(ibus, jbus, kbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_THREE_WINDING_API_3(IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input).
Integer JBUS	bus number one of the other buses (input).
Integer KBUS	bus number of the third bus (input).
Character*2 CKT	transformer circuit identifier (input).
Integer INTGAR (3)	array of 3 elements specifying (defaulted data items are unchanged)(input).
	INTGAR(1) CZ0, non-grounding impedance data I/O code
	INTGAR(2) CZG, grounding impedance data I/O code
	INTGAR(3) CC, connection code
Real REALAR (14)	array of 14 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) RG1, grounding resistance on winding 1 for an impedance grounded transformer
	REALAR(2) XG1, grounding reactance on winding 1 for an impedance grounded transformer
	REALAR(3) R01, winding 1, or winding 1 bus to winding 2 bus, leakage resistance
	REALAR(4) X01, winding 1, or winding 1 bus to winding 2 bus, leakage reactance
	REALAR(5) RG2, grounding resistance on winding 2 for an impedance grounded transformer
	REALAR(6) XG2, grounding reactance on winding 2 for an impedance grounded transformer
	REALAR(7) R02, winding 2, or winding 2 bus to winding 3 bus, leakage resistance

	REALAR(8)	X02, winding 2, or winding 2 bus to winding 3 bus, leakage reactance
	REALAR(9)	RG3, grounding resistance on winding 3 for an impedance grounded transformer
	REALAR(10)	XG3, grounding reactance on winding 3 for an impedance grounded transformer
	REALAR(11)	R03, winding 3, or winding 3 bus to winding 1 bus, leakage resistance
	REALAR(12)	X03, winding 3, or winding 3 bus to winding 1 bus, leakage reactance
	REALAR(13)	RN, common neutral grounding resistance
	REALAR(14)	XN, common neutral grounding reactance
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	three-winding transformer not found
	IERR = 4	CZG is 3 but at least one endpoint bus has no base voltage specified
	IERR = 5	invalid CZ0 or CZG value
	IERR = 6	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - Invalid winding connection code. - Invalid CZ0 or CZG data value. - CZ0 or CZG is not 1 with connection code 1 through 9 or a three-digit connection code. - CZG data value is 3 but at least one endpoint bus has no base voltage specified. - Non-zero neutral impedance specified but at least one endpoint bus has no base or nominal voltage specified. - A non-zero value is specified for an impedance that is not used with the specified connection code. - A value of zero is specified for an impedance that is used with the specified connection code. - Both ZGn and Z0n are used with the specified connection code and both are (0.0,0.0). - Connection code is 17 or 18 but at least one endpoint bus has no base or nominal voltage specified

4.2.26. SEQ_TWO_WINDING_DATA

This API routine is obsolete. It has been replaced by the API routine [seq_two_winding_data_3](#).

Use this API to modify the zero sequence data of an existing two-winding transformer in the working case (see PSSE Program Operation Manual, Zero Sequence Transformer Data).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SEQ_TWO_WINDING_DATA  IBUS  JBUS  'CKT'  INTGAR(1)
REALAR(1) .. REALAR(6)
```

Python command syntax:

```
ierr = seq_two_winding_data(ibus, jbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_TWO_WINDING_API_2(IBUS, JBUS, CKT, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).	
Integer JBUS	bus number of to bus (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Integer INTGAR (1)	array of 1 elements specifying one element (defaulted data items are unchanged)(input).	
	INTGAR(1)	CC, connection code (1 through 8)
Real REALAR (6)	array of 6 elements specifying (defaulted data items are unchanged)(input).	
	REALAR(1)	RG, grounding resistance if connection code < 8; winding 1 side resistance to ground if CC = 8
	REALAR(2)	XG, grounding reactance if connection code < 8; winding 1 side reactance to ground if CC = 8
	REALAR(3)	R1, zero sequence transformer resistance
	REALAR(4)	X1, zero sequence transformer reactance
	REALAR(5)	RG2, winding 2 side resistance to ground if CC = 8; 0.0 otherwise
	REALAR(6)	XG2, winding 2 side reactance to ground if CC = 8; 0.0 otherwise
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found

IERR = 2	circuit identifier is more than two characters
IERR = 3	circuit identifier may not start with &, * or @
IERR = 4	branch not found
IERR = 5	branch exists but it is a non-transformer branch
IERR = 6	prerequisite requirements for API are not met
IERR = -1	data error, warning and information messages; one or more of: - Invalid winding connection code. - Zero sequence impedance is (0.0,0.0). - Non-zero winding 2 impedance to ground not used with the specified connection code. - Winding n impedance to ground is (0.0,0.0) with connection code 8. - Grounding impedance is (0.0,0.0) with connection code 9. - A specified series impedance is (0.0,0.0) with connection code 9

4.2.27. SEQ_TWO_WINDING_DATA_3

Use this API to modify the zero sequence data of an existing two-winding transformer in the working case (see PSSE Program Operation Manual, Zero Sequence Transformer Data).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SEQ_TWO_WINDING_DATA_3  IBUS  JBUS  'CKT'  INTGAR(1) .. INTGAR(3)
                              REALAR(1) .. REALAR(10)
```

Python command syntax:

```
ierr = seq_two_winding_data_3(ibus, jbus, ckt, intgar, realar)
```

Fortran command syntax:

```
CALL SEQ_TWO_WINDING_API_3(IBUS, JBUS, CKT, INTGAR, REALAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	circuit identifier (input; '1' by default).
Integer INTGAR (3)	array of 3 elements specifying (defaulted data items are unchanged)(input).
	INTGAR(1) CC, connection code
	INTGAR(2) CZ0, leakage impedance data I/O code
	INTGAR(3) CZG, grounding impedance data I/O code
Real REALAR (10)	array of 10 elements specifying (defaulted data items are unchanged)(input).
	REALAR(1) RG1, grounding resistance at the winding 1 bus for an impedance grounded transformer
	REALAR(2) XG1, grounding reactance at the winding 1 bus for an impedance grounded transformer
	REALAR(3) R01, zero sequence leakage resistance connected to the winding 1 bus
	REALAR(4) X01, zero sequence leakage reactance connected to the winding 1 bus
	REALAR(5) RG2, grounding resistance at the winding 2 bus for an impedance grounded transformer
	REALAR(6) XG2, grounding reactance at the winding 2 bus for an impedance grounded transformer
	REALAR(7) R02, zero sequence leakage resistance connected to the winding 2 bus
	REALAR(8) X02, zero sequence leakage reactance connected to the winding 2 bus
	REALAR(9) RN, common neutral grounding resistance

	REALAR(10)	XN, common neutral grounding reactance
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	fatal error occurred
	IERR = 1	bus not found
	IERR = 2	circuit identifier is more than two characters
	IERR = 3	circuit identifier may not start with &, * or @
	IERR = 4	branch not found
	IERR = 5	branch exists but it is a non-transformer branch
	IERR = 6	CZG is 3 but at least one endpoint bus has no base voltage specified
	IERR = 7	invalid CZ0 or CZG value
	IERR = 8	prerequisite requirements for API are not met
	IERR = -1	data error, warning and information messages; one or more of: - Invalid winding connection code. - Z01 is set to its positive sequence value. - A non-zero value is specified for an impedance that is not used with the specified connection code.. - A value of zero is specified for an impedance that is used with the specified connection code. - Invalid CZ0 or CZG data value. - CZ0 or CZG is not 1 with connection code 1 through 9. - CZG data value is 3 but at least one endpoint bus has no base voltage specified. - Non-zero neutral impedance specified but at least one endpoint bus has no base or nominal voltage specified. - Connection code is 18 through 22 but at least one endpoint bus has no base or nominal voltage specified

Chapter 5

Harmonics

This chapter describes the API routines used in PSS®E Harmonics.

5.1. Harmonics Operation

5.1.1. HARMONICS

Use this API to run the Harmonics calculation.

This API routine was first introduced in release 34.5.0.

Batch command syntax:

```
BAT_HARMONICS  SID  ALL  OPTIONS(1)..OPTIONS(6)  VALUES(1)..VALUES(5)
HARMRSLTFILE
```

Python command syntax:

```
ierr = harmonics(sid, all, options, values, harmrsltfile)
```

Fortran command syntax:

```
CALL HARMONICS(SID, ALL, OPTIONS, VALUES, HARMRSLTFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or selected subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
integer OPTIONS (6)	array of 6 elements specifying harmonics options(input).	
	OPTIONS(1)	Harmonic Weighting Type
	OPTIONS(1) = 0	None
	OPTIONS(1) = 1	IEEE 519 (Telephone influence factor)
	OPTIONS(1) = 2	THFF (Telephone high frequency factor)
	OPTIONS(1) = 3	NY x VNY
	OPTIONS(1) = 4	IEC 61000-2-4 class 1
	OPTIONS(1) = 5	IEC 61000-2-4 class 2
	OPTIONS(1) = 6	IEC 61000-2-4 class 3
	OPTIONS(2)	Frequency Resonse at Node
	OPTIONS(2) = 0	For all same values
	OPTIONS(2) = 1	Individual values
	OPTIONS(3)	Wave Resistance Equation for Lines
	OPTIONS(3) = 0	Not In Use
	OPTIONS(3) = 1	In Use
	OPTIONS(4)	Include Resonance Network in Frequency
	OPTIONS(4) = 0	Not In Use
	OPTIONS(4) = 1	In Use
	OPTIONS(5)	Ignore Consumer

	OPTIONS(5) = 0	Not In Use
	OPTIONS(5) = 1	In Use
	OPTIONS(6)	Voltage Angle Consideration
	OPTIONS(6) = 0	Not In Use
	OPTIONS(6) = 1	In Use
real VALUES (5)	array of 5 elements specifying harmonics values(input).	
	VALUES(1)	Detuning Factor (1.0 by default)
	VALUES(2)	Initial Frequency (60.0 by default)
	VALUES(3)	End Frequency (2400.0 by default)
	VALUES(4)	Large Frequency Step (60.0 by default)
	VALUES(5)	Small Frequency Step (6.0 by default)
character*260 HARMRSLTFILE	(input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred

5.1.2. HAR_NEW

Use this API to initialize all data records required for Harmonics analysis. It must be called prior to introducing any Harmonics data records. It has no effect if Harmonics data already exists in the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_NEW
```

Python command syntax:

```
ierr = har_new()
```

Fortran command syntax:

```
CALL HAR_NEW(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.1.3. HAR_PURG

Use this API to purge all harmonics data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_PURG
```

Python command syntax:

```
ierr = har_purg()
```

Fortran command syntax:

```
CALL HAR_PURG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.1.4. HAR_READ

Use this API to read Harmonics Data Text (.har) File into the working case memory.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_READ RFILE
```

Python command syntax:

```
ierr = har_read(rfile)
```

Fortran command syntax:

```
CALL HAR_READ(RFILE, IERR)
```

Where:

Character*260 RFILE	Harmonics Data File name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	error opening file
	IERR = 2	prerequisite requirements for API are not met

5.1.5. HAR_READX

Use this API to read Harmonics Data XML (.xhar) File into the working case memory.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_READX RFILE
```

Python command syntax:

```
ierr = har_readx(rfile)
```

Fortran command syntax:

```
CALL HAR_READX(RFILE, IERR)
```

Where:

Character*260 RFILE	Harmonics Data XML File name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	error opening file
	IERR = 2	prerequisite requirements for API are not met

5.1.6. HAR_WRITE

Use this API to write working case Harmonics Data to text (.har) file or report window.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_WRITE RFILE
```

Python command syntax:

```
ierr = har_write(rfile)
```

Fortran command syntax:

```
CALL HAR_WRITE(RFILE, IERR)
```

Where:

Character*260 RFILE	Harmonics Data File name, when file name is not provided file created in Report Window (input; blank).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met
	IERR = 2	no harmonics data in working case
	IERR = 3	error opening file

5.1.7. HAR_WRITEX

Use this API to write working case Harmonics Data to XML (.xhar) file.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_WRITEX RFILE
```

Python command syntax:

```
ierr = har_writex(rfile)
```

Fortran command syntax:

```
CALL HAR_WRITEX(RFILE, IERR)
```

Where:

Character*260 RFILE	Harmonics Data XML File name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met
	IERR = 2	no harmonics data in working case
	IERR = 3	error opening file
	IERR = 4	rfile is blank

Harmonics Operation APIs contains API routines corresponding to the operational functions of the Harmonics features of PSS®E.

5.2. Harmonics Data

5.2.1. HAR_2TDC

Use this API to modify or add new harmonics Two Terminal DC data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_2TDC NAME IBUS INTGAR(1) CHARAR(1) CHARAR(2)
```

Python command syntax:

```
ierr = har_2tdc(name,ibus,intgar,charar)
```

Fortran command syntax:

```
CALL HAR_2TDC(NAME, IBUS, INTGAR, CHARAR, IERR)
```

Where:

Character*12 NAME	two term dc line name (input; no default allowed).
Integer IBUS	rectifier or inverter bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Voltage Source Table Name CHARAR(2) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.2. HAR_2TDC_CHNG

Use this API to modify harmonics Two Terminal DC data in the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_2TDC_CHNG NAME IBUS INTGAR(1) CHARAR(1) CHARAR(2)
```

Python command syntax:

```
ierr = har_2tdc_chng(name,ibus,intgar,charar)
```

Fortran command syntax:

```
CALL HAR_2TDC_CHNG(NAME,IBUS,INTGAR,CHARAR,IERR)
```

Where:

Character*12 NAME	two term dc line name (input; no default allowed).
Integer IBUS	rectifier or inverter bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Voltage Source Table Name CHARAR(2) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.3. HAR_2TDC_PURG

Use this API to purge specified harmonics Two Terminal DC data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_2TDC_PURG NAME IBUS
```

Python command syntax:

```
ierr = har_2tdc_purg(name, ibus)
```

Fortran command syntax:

```
CALL HAR_2TDC_PURG(NAME, IBUS, IERR)
```

Where:

Character*12 NAME	two term dc line name (input; no default allowed).	
Integer IBUS	rectifier or inverter bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.4. HAR_BRN

Use this API to modify or add new harmonics branch data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_BRN IBUS JBUS CKT INTGAR(1)..INTGAR(2) REALAR(1) CHARAR(1)
```

Python command syntax:

```
ierr = har_brn(ibus,jbus,ckt,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_BRN( IBUS, JBUS, CKT, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	branch identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) Harmonics Mode (1 by default)
	INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input).
	REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (1)	array of 1 elements specifying (input).
	CHARAR(1) Harmonics Impedance Characteristics Name
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR = 1 prerequisite requirements for API are not met

5.2.5. HAR_BRN_CHNG

Use this API to modify harmonics branch data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_BRN_CHNG IBUS JBUS CKT INTGAR(1)..INTGAR(2) REALAR(1) CHARAR(1)
```

Python command syntax:

```
ierr = har_brn_chng(ibus,jbus,ckt,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_BRN_CHNG( IBUS, JBUS, CKT, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Character*2 CKT	branch identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) Harmonics Mode (1 by default)
	INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input).
	REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (1)	array of 1 elements specifying (input).
	CHARAR(1) Harmonics Impedance Characteristics Name
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR = 1 prerequisite requirements for API are not met

5.2.6. HAR_BRN_PURG

Use this API to purge specified harmonics branch data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_BRN_PURG IBUS JBUS CKT
```

Python command syntax:

```
ierr = har_brn_purg(ibus,jbus,ckt)
```

Fortran command syntax:

```
CALL HAR_BRN_PURG(IBUS, JBUS, CKT, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).	
Integer JBUS	bus number of to bus (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.7. HAR_CURSRC

Use this API to modify or add new harmonics current source table data to the working case. This API is used to add new table of current and angle type data, harmonic numbers and corresponding I/I0 and Angle data points. This can be used to add a new data point of harmonic number, I/I0 and Angle data to existing table. This can be used to change current and angle type data, I/I0 and Angle data points of existing harmonic number in the table. This API cannot be used to change table name and harmonic numbers.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC NAME NPTS INTGAR(1) INTGAR(2) HAR(1)..HAR(NPTS)
IAR(1)..IAR(NPTS) ANAR(1)..ANAR(NPTS)
```

Python command syntax:

```
ierr = har_cursrc(name, npts, intgar, har, iar, anar)
```

Fortran command syntax:

```
CALL HAR_CURSRC(NAME, NPTS, INTGAR, HAR, IAR, ANAR, IERR)
```

Where:

Character*40 NAME	Harmonics current Source Data table name (input; no default allowed).	
Integer NPTS	number of data points specified in the table (input; no default allowed).	
Integer INTGAR (2)	array of 2 elements specifying (input).	
	INTGAR(1)	CRTYP, Harmonics current Source type (1 by default)
	INTGAR(2)	ANTYP, Harmonics current Source angle type (1 by default)
Real HAR (NPTS)	array of 'NPTS' values specifying harmonic numbers. All the harmonic numbers in HAR array must be non zero. (input).	
Real IAR (NPTS)	array of 'NPTS' values specifying current magnitude (input).	
Real ANAR (NPTS)	array of 'NPTS' values specifying angle (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.8. HAR_CURSRC_CHNG

Use this API to change harmonics current source table data in the working case. This API is used to change current and angle type data, I/I0 and Angle data points of existing harmonic number and existing table in working case harmonics data. This API cannot be used to change table name and harmonic numbers. All the harmonic numbers in HAR array must be non zero.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_CHNG NAME NPTS INTGAR(1) INTGAR(2) HAR(1)..HAR(NPTS)
  IAR(1)..IAR(NPTS) ANAR(1)..ANAR(NPTS)
```

Python command syntax:

```
ierr = har_cursrc_chng(name, npts, intgar, har, iar, anar)
```

Fortran command syntax:

```
CALL HAR_CURSRC_CHNG(NAME, NPTS, INTGAR, HAR, IAR, ANAR, IERR)
```

Where:

Character*40 NAME	Harmonics current Source Data table name (input; no default allowed).
Integer NPTS	number of data points specified in the table (input; no default allowed).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) CRTYP, Harmonics current Source type (1 by default) INTGAR(2) ANTYP, Harmonics current Source angle type (1 by default)
Real HAR (NPTS)	array of 'NPTS' values specifying harmonic numbers. All the harmonic numbers in HAR array must be non zero. (input).
Real IAR (NPTS)	array of 'NPTS' values specifying current magnitude (input).
Real ANAR (NPTS)	array of 'NPTS' values specifying angle (input).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.9. HAR_CURSRC_CHNG_NAME

Use this API to change harmonics current source table name in the working case. This API is used to change table name from working case harmonics data. NAMNEW must not exist in working case harmonics data. NAME must be provided and it must exist in working case harmonics data, then table name changed from NAME to NAMNEW.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_CHNG_NAME 'NAME' 'NAMNEW' INTGAR
```

Python command syntax:

```
ierr = har_cursrc_chng_name(name, namnew, intgar)
```

Fortran command syntax:

```
CALL HAR_CURSRC_CHNG_NAME(NAME, NAMNEW, INTGAR, IERR)
```

Where:

Character*40 NAME	Harmonics current Source table name whose name is to be changed. NAME must be provided and it must exist in working case harmonics data. (input; no default allowed).	
Character*40 NAMNEW	New Harmonics current Source table name to be assigned. NAMNEW must not exist in working case harmonics data. (input; no default allowed).	
Integer INTGAR (2)	array of 2 elements specifying (input).	
	INTGAR(1)	CRTYP, Harmonics current Source type (1 by default)
	INTGAR(2)	ANTYP, Harmonics current Source angle type (1 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.10. HAR_CURSRC_CHNG_ONEPT

Use this API to modify one data point to harmonics current source table in the working case. This API is used to change H, I/I0, and Angle data of existing harmonic number (HPTOLD) in the existing working case harmonics data table. This API cannot be used to change table name.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_CHNG_ONEPT NAME HPTOLD HPT IPT ANPT
```

Python command syntax:

```
ierr = har_cursrc_chng_onept(name, hptold, hpt, ipt, anpt)
```

Fortran command syntax:

```
CALL HAR_CURSRC_CHNG_ONEPT(NAME, HPTOLD, HPT, IPT, ANPT, IERR)
```

Where:

Character*40 NAME	Harmonics current Source Data table name (input; no default allowed).	
Real HPTOLD	Harmonics number at point in data table where provided data is changed (input; no default allowed).	
Real HPT	New Harmonics number to be changed (input; 1 by default).	
Real IPT	current Source magnitude for harmonics number HPT to be changed (input; 1 by default).	
Real ANPT	current Source angle for harmonics number HPT to be changed (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.11. HAR_CURSRC_NAME

Use this API to add or change harmonics current source table name in the working case. This API is used to add new table name with no harmonics data points or change table name from working case harmonics data.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_CHNG_NAME 'NAME' 'NAMNEW' INTGAR
```

Python command syntax:

```
ierr = har_cursrc_name(name, namnew, intgar)
```

Fortran command syntax:

```
CALL HAR_CURSRC_NAME(NAME, NAMNEW, INTGAR, IERR)
```

Where:

Character*40 NAME	Harmonics current Source table name whose name is to be changed. When NAME is provided, it must exist in working case harmonics data, then table name changed from NAME to NAMNEW. If NAME is blank, a new table NAMNEW will be added with no harmonics data points. (input; " by default).	
Character*40 NAMNEW	New Harmonics current Source table name to be assigned. NAMNEW must not exist in working case harmonics data. (input; no default allowed).	
Integer INTGAR (2)	array of 2 elements specifying (input).	
	INTGAR(1)	CRTYP, Harmonics current Source type (1 by default)
	INTGAR(2)	ANTYP, Harmonics current Source angle type (1 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.12. HAR_CURSRC_ONEPT

Use this API to modify or add new one data point to harmonics current source table in the working case. This API is used to add one new data point of H, I/I0, and Angle data to existing table of existing working case harmonics data. This can be used to change H, V/V0, and Angle data points of existing harmonic number in the table. This API cannot be used to change table name.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_ONEPT NAME HPTOLD HPT IPT ANPT
```

Python command syntax:

```
ierr = har_cursrc_onept(name, hptold, hpt, ipt, anpt)
```

Fortran command syntax:

```
CALL HAR_CURSRC_ONEPT(NAME, HPTOLD, HPT, IPT, ANPT, IERR)
```

Where:

Character*40 NAME	Harmonics current Source Data table name (input; no default allowed).	
Real HPTOLD	Harmonics number at point in data table where provided data is added or changed. When HPTOLD is specified and found, the H, I/I0, and Angle values specified will be used to change existing data. When HPTOLD is zero, the H, I/I0, and Angle values specified will be used to add data point to existing data. (input; no default allowed).	
Real HPT	New Harmonics number to be added or changed at specified data point (input; no default allowed).	
Real IPT	current Source magnitude for harmonics number HPT to be added or changed (input; 1 by default).	
Real ANPT	current source angle for harmonics number HPT to be added or changed (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.13. HAR_CURSRC_PURG

Use this API to purge specified harmonics current source table data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_PURG NAME
```

Python command syntax:

```
ierr = har_cursrc_purg(name)
```

Fortran command syntax:

```
CALL HAR_CURSRC_PURG(NAME, IERR)
```

Where:

Character*40 NAME	Harmonics current source table name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.14. HAR_CURSRC_PURG_ONEPT

Use this API to purge specified data point in harmonics current source table.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_CURSRC_PURG_ONEPT NAME HPT
```

Python command syntax:

```
ierr = har_cursrc_purg_onept(name, hpt)
```

Fortran command syntax:

```
CALL HAR_CURSRC_PURG_ONEPT(NAME, HPT, IERR)
```

Where:

Character*40 NAME	Harmonics current source table name (input; no default allowed).	
Real HPT	Harmonic number (H) at a point in data table where H, R/R0, L/) and C/CO data is purged (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.15. HAR_FACTS

Use this API to modify or add new harmonics FACTS device data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_FACTS NAME SENDBUS SENDBUS INTGAR(1) INTGAR(2) CHARAR(1) CHARAR(2)
CHARAR(3)
```

Python command syntax:

```
ierr = har_facts(name, sendbus, termbus, intgar, realar, charar)
```

Fortran command syntax:

```
CALL HAR_FACTS(NAME, SENDBUS, TERMBUS, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Character*12 NAME	FACTS device name (input; no default allowed).
Integer SENDBUS	FACTS Device sending bus number (input; no default allowed).
Integer TERMBUS	FACTS Device terminal bus number (input; 0 by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics State (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.16. HAR_FACTS_CHNG

Use this API to modify harmonics FACTS device data in the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_FACTS_CHNG NAME SENDBUS SENDBUS INTGAR(1) INTGAR(2) CHARAR(1)
CHARAR(2) CHARAR(3)
```

Python command syntax:

```
ierr = har_facts_chng(name, sendbus, termbus, intgar, realar, charar)
```

Fortran command syntax:

```
CALL HAR_FACTS_CHNG(NAME, SENDBUS, TERMBUS, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Character*12 NAME	FACTS device name (input; no default allowed).
Integer SENDBUS	FACTS Device sending bus number (input; no default allowed).
Integer TERMBUS	FACTS Device terminal bus number (input; 0 by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics State (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.17. HAR_FACTS_PURG

Use this API to purge specified harmonics FACTS device data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_FACTS_PURG NAME SENDBUS TERMBUS
```

Python command syntax:

```
ierr = har_facts_purg(name, sendbus, termbus)
```

Fortran command syntax:

```
CALL HAR_FACTS_PURG(NAME, SENDBUS, TERMBUS, IERR)
```

Where:

Character*12 NAME	FACTS device name (input; no default allowed).	
Integer SENDBUS	FACTS Device sending bus number (input; no default allowed).	
Integer TERMBUS	FACTS Device terminal bus number (input; 0 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.18. HAR_IMPCHAR

Use this API to modify or add new harmonics impedance characteristics table data to the working case. This API is used to add new table of harmonic numbers and corresponding R/R0, L/L0 and C/C0 data points. This can be used to add a new data point of harmonic number, R/R0, L/L0 and C/C0 data to existing table. This can be used to change R/R0, L/L0 and C/C0 data points of existing harmonic number in the table. This API cannot be used to change table name and harmonic numbers.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR NAME NPTS HAR(1)..HAR(NPTS) RAR(1)..RAR(NPTS)
LAR(1)..LAR(NPTS) CAR(1)..CAR(NPTS)
```

Python command syntax:

```
ierr = har_impchar(name, npts, har, rar, lar, car)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR(NAME, NPTS, HAR, RAR, LAR, CAR, IERR)
```

Where:

Character*40 NAME	Harmonics Impedance Characteristics Data table name (input; no default allowed).	
Integer NPTS	number of data points specified in the table (input; no default allowed).	
Real HAR (NPTS)	array of 'NPTS' values specifying harmonic numbers. All the harmonic numbers in HAR array must be non zero. (input).	
Real RAR (NPTS)	array of 'NPTS' values specifying R/R0 ratio (input).	
Real LAR (NPTS)	array of 'NPTS' values specifying L/L0 ratio (input).	
Real CAR (NPTS)	array of 'NPTS' values specifying C/C0 ratio (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.19. HAR_IMPCHAR_CHNG

Use this API to change harmonics impedance characteristics table data in the working case. This API is used to change R/R0, L/L0 and C/C0 data points of existing harmonic number and existing table in working case harmonics data. This API cannot be used to change table name and harmonic numbers. All the harmonic numbers in HAR array must be non zero.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_CHNG NAME NPTS HAR(1)..HAR(NPTS) RAR(1)..RAR(NPTS)
LAR(1)..LAR(NPTS) CAR(1)..CAR(NPTS)
```

Python command syntax:

```
ierr = har_impchar_chng(name, npts, har, rar, lar, car)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_CHNG(NAME, NPTS, HAR, RAR, LAR, CAR, IERR)
```

Where:

Character*40 NAME	Harmonics Impedance Characteristics Data table name (input; no default allowed).	
Integer NPTS	number of data points specified in the table (input; no default allowed).	
Real HAR (NPTS)	array of 'NPTS' values specifying harmonic numbers. All the harmonic numbers in HAR array must be non zero. (input).	
Real RAR (NPTS)	array of 'NPTS' values specifying R/R0 ratio (input).	
Real LAR (NPTS)	array of 'NPTS' values specifying L/L0 ratio (input).	
Real CAR (NPTS)	array of 'NPTS' values specifying C/C0 ratio (input).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.20. HAR_IMPCHAR_CHNG_NAME

Use this API to change harmonics impedance characteristics table name in the working case. This API is used to change table name from working case harmonics data. NAMNEW must not exist in working case harmonics data. NAME must be provided and it must exist in working case harmonics data, then table name changed from NAME to NAMNEW.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_CHNG_NAME 'NAME' 'NAMNEW'
```

Python command syntax:

```
ierr = har_impchar_chng_name(name, namnew)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_CHNG_NAME(NAME, NAMNEW, IERR)
```

Where:

Character*40 NAME	Harmonics impedance characteristics table name whose name is to be changed. NAME must be provided and it must exist in working case harmonics data. (input; no default allowed).	
Character*40 NAMNEW	New Harmonics Impedance Characteristics table name to be assigned. NAMNEW must not exist in working case harmonics data. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.21. HAR_IMPCHAR_CHNG_ONEPT

Use this API to modify one data point to harmonics impedance characteristics table in the working case. This API is used to change H, R/R0, L/L0 and C/C0 data of existing harmonic number (HPTOLD) in the existing working case harmonics data table. This API cannot be used to change table name.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_CHNG_ONEPT NAME HPTOLD HPT RPT LPT CPT
```

Python command syntax:

```
ierr = har_impchar_chng_onept(name, hptold, hpt, rpt, lpt, cpt)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_CHNG_ONEPT(NAME, HPTOLD, HPT, RPT, LPT, CPT, IERR)
```

Where:

Character*40 NAME	Harmonics Impedance Characteristics Data table name (input; no default allowed).	
Real HPTOLD	Harmonics number at point in data table where provided data is changed (input; no default allowed).	
Real HPT	New Harmonics number to be changed (input; 1 by default).	
Real RPT	Impedance characteristics R/R0 for harmonics number HPT to be changed (input; 1 by default).	
Real LPT	Impedance characteristics L/L0 for harmonics number HPT to be changed (input; 1 by default).	
Real CPT	Impedance characteristics C/C0 for harmonics number HPT to be changed (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.22. HAR_IMPCHAR_NAME

Use this API to add or change harmonics impedance characteristics table name in the working case. This API is used to add new table name with no harmonics data points or change table name from working case harmonics data.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_CHNG_NAME 'NAME' 'NAMNEW'
```

Python command syntax:

```
ierr = har_impchar_name(name, namnew)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_NAME(NAME, NAMNEW, IERR)
```

Where:

Character*40 NAME	Harmonics Impedance Characteristics table name whose name is to be changed. When NAME is provided, it must exist in working case harmonics data, then table name changed from NAME to NAMNEW. If NAME is blank, a new table NAMNEW will be added with no harmonics data points. (input; " by default).	
Character*40 NAMNEW	New Harmonics Impedance Characteristics table name to be assigned. NAMNEW must not exist in working case harmonics data. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.23. HAR_IMPCHAR_ONEPT

Use this API to modify or add new one data point to harmonics impedance characteristics table in the working case. This API is used to add one new data point of H, R/RO, L/LO and C/CO data to existing table of existing working case harmonics data. This can be used to change H, R/RO, L/LO and C/CO data points of existing harmonic number in the table. This API cannot be used to change table name.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_ONEPT NAME HPTOLD HPT RPT LPT CPT
```

Python command syntax:

```
ierr = har_impchar_onept(name, hptold, hpt, rpt, lpt, cpt)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_ONEPT(NAME, HPTOLD, HPT, RPT, LPT, CPT, IERR)
```

Where:

Character*40 NAME	Harmonics Impedance Characteristics Data table name (input; no default allowed).	
Real HPTOLD	Harmonics number at point in data table where provided data is added or changed. When HPTOLD is specified and found, the H, R/RO, L/LO and C/CO values specified will be used to change existing data. When HPTOLD is zero, the H, R/RO, L/LO and C/CO values specified will be used to add data point to existing data. (input; no default allowed).	
Real HPT	New Harmonics number to be added or changed at specified data point (input; no default allowed).	
Real RPT	Impedance characteristics R/RO for harmonics number HPT to be added or changed (input; 1 by default).	
Real LPT	Impedance characteristics L/LO for harmonics number HPT to be added or changed (input; 1 by default).	
Real CPT	Impedance characteristics C/CO for harmonics number HPT to be added or changed (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.24. HAR_IMPCHAR_PURG

Use this API to purge specified harmonics impedance characteristics table data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_PURG NAME
```

Python command syntax:

```
ierr = har_impchar_purg(name)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_PURG(NAME, IERR)
```

Where:

Character*40 NAME	Harmonics impedance characteristics table name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.25. HAR_IMPCHAR_PURG_ONEPT

Use this API to purge specified data point in harmonics impedance characteristics table.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_IMPCHAR_PURG_ONEPT NAME HPT
```

Python command syntax:

```
ierr = har_impchar_purg_onept(name, hpt)
```

Fortran command syntax:

```
CALL HAR_IMPCHAR_PURG_ONEPT(NAME, HPT, IERR)
```

Where:

Character*40 NAME	Harmonics impedance characteristics table name (input; no default allowed).	
Real HPT	Harmonic number (H) at a point in data table where H, R/R0, L/) and C/CO data is purged (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.26. HAR_INDMC

Use this API to modify or add new harmonics induction machine data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_INDMC IBUS ID INTGAR(1)..INTGAR(2) REALAR(1) CHARAR(1)..CHARAR(3)
```

Python command syntax:

```
ierr = har_indmc(ibus,id,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_INDMC (IBUS, ID, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	induction machine identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.27. HAR_INDMC_CHNG

Use this API to modify harmonics induction machine data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_INDMC_CHNG IBUS ID INTGAR(1)..INTGAR(2) REALAR(1)
CHARAR(1)..CHARAR(3)
```

Python command syntax:

```
ierr = har_indmc_chng(ibus,id,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_INDMC_CHNG( IBUS, ID, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	induction machine identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.28. HAR_INDMC_PURG

Use this API to purge specified harmonics induction machine data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_INDMC_PURG IBUS ID
```

Python command syntax:

```
ierr = har_indmc_purg(ibus,id)
```

Fortran command syntax:

```
CALL HAR_INDMC_PURG(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).	
Character*2 ID	induction machine identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.29. HAR_LOAD

Use this API to modify or add new harmonics load data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_LOAD IBUS ID INTGAR(1)..INTGAR(2) REALAR(1) CHARAR(1)..CHARAR(3)
```

Python command syntax:

```
ierr = har_load(ibus,id,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_LOAD( IBUS, ID, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.30. HAR_LOAD_CHNG

Use this API to modify harmonics load data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_LOAD_CHNG IBUS ID INTGAR(1)..INTGAR(2) REALAR(1)
CHARAR(1)..CHARAR(3)
```

Python command syntax:

```
ierr = har_load_chng(ibus,id,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_LOAD_CHNG( IBUS, ID, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.31. HAR_LOAD_PURG

Use this API to purge specified harmonics load data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_LOAD_PURG IBUS ID
```

Python command syntax:

```
ierr = har_load_purg(ibus,id)
```

Fortran command syntax:

```
CALL HAR_LOAD_PURG(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met

5.2.32. HAR_MACH

Use this API to modify or add new harmonics machine data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_MACH IBUS ID INTGAR(1)..INTGAR(2) REALAR(1) CHARAR(1)..CHARAR(3)
```

Python command syntax:

```
ierr = har_mach(ibus,id,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_MACH( IBUS, ID, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.33. HAR_MACH_CHNG

Use this API to modify harmonics machine data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_MACH_CHNG IBUS ID INTGAR(1)..INTGAR(2) REALAR(1)
CHARAR(1)..CHARAR(3)
```

Python command syntax:

```
ierr = har_mach_chng(ibus,id,intgar,realar,charar)
```

Fortran command syntax:

```
CALL HAR_MACH_CHNG( IBUS, ID, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (3)	array of 3 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Voltage Source Table Name CHARAR(3) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.34. HAR_MACH_PURG

Use this API to purge specified harmonics machine data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_MACH_PURG IBUS ID
```

Python command syntax:

```
ierr = har_mach_purg(ibus,id)
```

Fortran command syntax:

```
CALL HAR_MACH_PURG(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).	
Character*2 ID	mach identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.35. HAR_MTDC

Use this API to modify or add new harmonics Multi Terminal DC data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_MTDC NAME IBUS INTGAR(1) CHARAR(1) CHARAR(2)
```

Python command syntax:

```
ierr = har_mtdc(name,ibus,intgar,charar)
```

Fortran command syntax:

```
CALL HAR_MTDC(NAME,IBUS,INTGAR,CHARAR,IERR)
```

Where:

Character*12 NAME	multi term dc line name (input; no default allowed).
Integer IBUS	converter bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Voltage Source Table Name CHARAR(2) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.36. HAR_MTDC_CHNG

Use this API to modify harmonics Multi Terminal DC data in the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_MTDC_CHNG NAME IBUS INTGAR(1) CHARAR(1) CHARAR(2)
```

Python command syntax:

```
ierr = har_mtdc_chng(name,ibus,intgar,charar)
```

Fortran command syntax:

```
CALL HAR_MTDC_CHNG(NAME,IBUS,INTGAR,CHARAR,IERR)
```

Where:

Character*12 NAME	multi term dc line name (input; no default allowed).
Integer IBUS	converter bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Voltage Source Table Name CHARAR(2) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.37. HAR_MTDC_PURG

Use this API to purge specified harmonics Multi Terminal DC data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_MTDC_PURG NAME IBUS
```

Python command syntax:

```
ierr = har_mtdc_purg(name, ibus)
```

Fortran command syntax:

```
CALL HAR_MTDC_PURG(NAME, IBUS, IERR)
```

Where:

Character*12 NAME	multi term dc line name (input; no default allowed).	
Integer IBUS	converter bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.38. HAR_TRN

Use this API to modify or add new harmonics transformer data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_TRN IBUS JBUS KBUS CKT INTGAR(1)..INTGAR(2) REALAR(1)
CHARAR(1)..CHARAR(2)
```

Python command syntax:

```
ierr = har_trn(ibus, jbus, kbus, ckt, intgar, realar, charar)
```

Fortran command syntax:

```
CALL HAR_TRN( IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Integer KBUS	bus number of third bus (input; 0 by default).
Character*2 CKT	transformer identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default) INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input). REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Impedance Characteristics Name CHARAR(2) Harmonics Current Source Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.39. HAR_TRN_CHNG

Use this API to modify harmonics transformer data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_TRN_CHNG IBUS JBUS KBUS CKT INTGAR(1)..INTGAR(2) REALAR(1)
CHARAR(1)..CHARAR(2)
```

Python command syntax:

```
ierr = har_trn_chng(ibus, jbus, kbus, ckt, intgar, realar, charar)
```

Fortran command syntax:

```
CALL HAR_TRN_CHNG( IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, CHARAR, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).
Integer JBUS	bus number of to bus (input; no default allowed).
Integer KBUS	bus number of third bus (input; 0 by default).
Character*2 CKT	transformer identifier (input; '1' by default).
Integer INTGAR (2)	array of 2 elements specifying (input).
	INTGAR(1) Harmonics Mode (1 by default)
	INTGAR(2) Harmonics Type (1 by default)
Real REALAR (1)	array of 1 elements specifying (input).
	REALAR(1) Harmonics Quality (1.0 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input).
	CHARAR(1) Harmonics Impedance Characteristics Name
	CHARAR(2) Harmonics Current Source Name
Integer IERR	error code (output).
	IERR = 0 no errors occurred
	IERR = 1 prerequisite requirements for API are not met

5.2.40. HAR_TRN_PURG

Use this API to purge specified harmonics transformer data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_TRN_PURG IBUS JBUS KBUS CKT
```

Python command syntax:

```
ierr = har_trn_purg(ibus,jbus,kbus,ckt)
```

Fortran command syntax:

```
CALL HAR_TRN_PURG(IBUS, JBUS, KBUS, CKT, IERR)
```

Where:

Integer IBUS	bus number of from bus (input; no default allowed).	
Integer JBUS	bus number of to bus (input; no default allowed).	
Integer KBUS	bus number of third bus (input; 0 by default).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.41. HAR_VLTSRC

Use this API to modify or add new harmonics voltage source table data to the working case. This API is used to add new table of angle type data, harmonic numbers and corresponding V/V0 and Angle data points. This can be used to add a new data point of harmonic number, V/V0 and Angle data to existing table. This can be used to change angle type data, V/V0 and Angle data points of existing harmonic number in the table. This API cannot be used to change table name and harmonic numbers.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC NAME NPTS INTGAR(1) HAR(1)..HAR(NPTS) VAR(1)..VAR(NPTS)
ANAR(1)..ANAR(NPTS)
```

Python command syntax:

```
ierr = har_vltsrc(name, npts, intgar, har, var, anar)
```

Fortran command syntax:

```
CALL HAR_VLTSRC(NAME, NPTS, INTGAR, HAR, VAR, ANAR, IERR)
```

Where:

Character*40 NAME	Harmonics Voltage Source Data table name (input; no default allowed).
Integer NPTS	number of data points specified in the table (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) ANTYP, Harmonics Voltage Source angle type (1 by default)
Real HAR (NPTS)	array of 'NPTS' values specifying harmonic numbers. All the harmonic numbers in HAR array must be non zero. (input).
Real VAR (NPTS)	array of 'NPTS' values specifying R/R0 ratio (input).
Real ANAR (NPTS)	array of 'NPTS' values specifying L/L0 ratio (input).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.42. HAR_VLTSRC_CHNG

Use this API to change harmonics voltage source table data in the working case. This API is used to change angle type data, V/V0 and Angle data points of existing harmonic number and existing table in working case harmonics data. This API cannot be used to change table name and harmonic numbers. All the harmonic numbers in HAR array must be non zero.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_CHNG NAME NPTS INTGAR(1) HAR(1) .. HAR(NPTS)
VAR(1) .. VAR(NPTS) ANAR(1) .. ANAR(NPTS)
```

Python command syntax:

```
ierr = har_vltsrc_chng(name, npts, intgar, har, var, anar)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_CHNG(NAME, NPTS, INTGAR, HAR, VAR, ANAR, IERR)
```

Where:

Character*40 NAME	Harmonics Voltage Source Data table name (input; no default allowed).
Integer NPTS	number of data points specified in the table (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) ANTYP, Harmonics Voltage Source angle type (1 by default)
Real HAR (NPTS)	array of 'NPTS' values specifying harmonic numbers. All the harmonic numbers in HAR array must be non zero. (input).
Real VAR (NPTS)	array of 'NPTS' values specifying magnitude (input).
Real ANAR (NPTS)	array of 'NPTS' values specifying angle (input).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.43. HAR_VLTSRC_CHNG_NAME

Use this API to change harmonics voltage source table name in the working case. This API is used to change table name from working case harmonics data. NAMNEW must not exist in working case harmonics data. NAME must be provided and it must exist in working case harmonics data, then table name changed from NAME to NAMNEW.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_CHNG_NAME 'NAME' 'NAMNEW' INTGAR
```

Python command syntax:

```
ierr = har_vltsrc_chng_name(name, namnew, intgar)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_CHNG_NAME(NAME, NAMNEW, INTGAR, IERR)
```

Where:

Character*40 NAME	Harmonics Voltage Source table name whose name is to be changed. NAME must be provided and it must exist in working case harmonics data. (input; no default allowed).	
Character*40 NAMNEW	New Harmonics Voltage Source table name to be assigned. NAMNEW must not exist in working case harmonics data. (input; no default allowed).	
Integer INTGAR (1)	array of 1 elements specifying (input).	
	INTGAR(1)	ANTYP, Harmonics Voltage Source angle type (1 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.44. HAR_VLTSRC_CHNG_ONEPT

Use this API to modify one data point to harmonics voltage source table in the working case. This API is used to change H, V/V0, and Angle data of existing harmonic number (HPTOLD) in the existing working case harmonics data table. This API cannot be used to change table name.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_CHNG_ONEPT NAME HPTOLD HPT VPT ANPT
```

Python command syntax:

```
ierr = har_vltsrc_chng_onept(name, hptold, hpt, vpt, anpt)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_CHNG_ONEPT(NAME, HPTOLD, HPT, VPT, ANPT, IERR)
```

Where:

Character*40 NAME	Harmonics Voltage Source Data table name (input; no default allowed).	
Real HPTOLD	Harmonics number at point in data table where provided data is changed (input; no default allowed).	
Real HPT	New Harmonics number to be changed (input; no default allowed).	
Real VPT	Voltage Source magnitude for harmonics number HPT to be changed (input; 1 by default).	
Real ANPT	Voltage Source angle for harmonics number HPT to be changed (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.45. HAR_VLTSRC_NAME

Use this API to add or change harmonics voltage source table name in the working case. This API is used to add new table name with no harmonics data points or change table name from working case harmonics data.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_CHNG_NAME 'NAME' 'NAMNEW' INTGAR
```

Python command syntax:

```
ierr = har_vltsrc_name(name, namnew, intgar)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_NAME(NAME, NAMNEW, INTGAR, IERR)
```

Where:

Character*40 NAME	Harmonics Voltage Source table name whose name is to be changed. When NAME is provided, it must exist in working case harmonics data, then table name changed from NAME to NAMNEW. If NAME is blank, a new table NAMNEW will be added with no harmonics data points. (input; " by default).	
Character*40 NAMNEW	New Harmonics Voltage Source table name to be assigned. NAMNEW must not exist in working case harmonics data. (input; no default allowed).	
Integer INTGAR (1)	array of 1 elements specifying (input).	
	INTGAR(1)	ANTYP, Harmonics Voltage Source angle type (1 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.46. HAR_VLTSRC_ONEPT

Use this API to modify or add new one data point to harmonics voltage source table in the working case. This API is used to add one new data point of H, V/V0, and Angle data to existing table of existing working case harmonics data. This can be used to change H, V/V0, and Angle data points of existing harmonic number in the table. This API cannot be used to change table name.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_ONEPT NAME HPTOLD HPT VPT ANPT
```

Python command syntax:

```
ierr = har_vltsrc_onept(name, hptold, hpt, vpt, anpt)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_ONEPT(NAME, HPTOLD, HPT, VPT, ANPT, IERR)
```

Where:

Character*40 NAME	Harmonics Voltage Source Data table name (input; no default allowed).	
Real HPTOLD	Harmonics number at point in data table where provided data is added or changed. When HPTOLD is specified and found, the H, V/V0, and Angle values specified will be used to change existing data. When HPTOLD is zero, the H, V/V0, and Angle values specified will be used to add data point to existing data. (input; no default allowed).	
Real HPT	New Harmonics number to be added or changed at specified data point (input; no default allowed).	
Real VPT	Voltage Source magnitude for harmonics number HPT to be added or changed (input; 1 by default).	
Real ANPT	Voltage Source angle for harmonics number HPT to be added or changed (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.47. HAR_VLTSRC_PURG

Use this API to purge specified harmonics voltage source table data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_PURG NAME
```

Python command syntax:

```
ierr = har_vltsrc_purg(name)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_PURG(NAME, IERR)
```

Where:

Character*40 NAME	Harmonics voltage source table name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.48. HAR_VLTSRC_PURG_ONEPT

Use this API to purge specified data point in harmonics voltage source table.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VLTSRC_PURG_ONEPT NAME HPT
```

Python command syntax:

```
ierr = har_vltsrc_purg_onept(name, hpt)
```

Fortran command syntax:

```
CALL HAR_VLTSRC_PURG_ONEPT(NAME, HPT, IERR)
```

Where:

Character*40 NAME	Harmonics voltage source table name (input; no default allowed).	
Real HPT	Harmonic number (H) at a point in data table where H, magnitude, L/) and C/CO data is purged (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

5.2.49. HAR_VSCDC

Use this API to modify or add new harmonics VSCDC data to the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VSCDC NAME IBUS INTGAR(1) CHARAR(1) CHARAR(2)
```

Python command syntax:

```
ierr = har_vscdc(name,ibus,intgar,charar)
```

Fortran command syntax:

```
CALL HAR_VSCDC(NAME,IBUS,INTGAR,CHARAR,IERR)
```

Where:

Character*12 NAME	VSC DC line name (input; no default allowed).
Integer IBUS	converter bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Voltage Source Table Name CHARAR(2) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.50. HAR_VSCDC_CHNG

Use this API to modify harmonics VSCDC data in the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VSCDC_CHNG NAME IBUS INTGAR(1) CHARAR(1) CHARAR(2)
```

Python command syntax:

```
ierr = har_vscdc_chng(name,ibus,intgar,charar)
```

Fortran command syntax:

```
CALL HAR_VSCDC_CHNG(NAME,IBUS,INTGAR,CHARAR,IERR)
```

Where:

Character*12 NAME	VSC DC line name (input; no default allowed).
Integer IBUS	converter bus number (input; no default allowed).
Integer INTGAR (1)	array of 1 elements specifying (input). INTGAR(1) Harmonics Mode (1 by default)
Character*40 CHARAR (2)	array of 2 elements specifying (input). CHARAR(1) Harmonics Voltage Source Table Name CHARAR(2) Harmonics Current Source Table Name
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

5.2.51. HAR_VSCDC_PURG

Use this API to purge specified harmonics VSCDC data from the working case.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_HAR_VSCDC_PURG NAME IBUS
```

Python command syntax:

```
ierr = har_vscdc_purg(name, ibus)
```

Fortran command syntax:

```
CALL HAR_VSCDC_PURG(NAME, IBUS, IERR)
```

Where:

Character*12 NAME	VSC DC line name (input; no default allowed).
Integer IBUS	converter bus number (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met

Harmonics Data Changing APIs contains API routines specific to adding, modifying, and deleting Harmonics data.

Chapter 6

GIC

This chapter describes the API routines used in PSS®E GIC.

6.1. GIC Operation

6.1.1. GIC

This API routine is obsolete. It has been replaced by the API routine [gic_2](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 32.2.0 and 33.3.0.

Batch command syntax:

```
BAT_GIC  SID ALL APIOPTNS(1)..APIOPTNS(4) VALUES(1)..VALUES(5)
        RPTOPTNS(1)..RPTOPTNS(7) GICDATAFIL GICADDFIL GICPURGFIL GICRNWKFIL
```

Python command syntax:

```
ierr = gic(sid, all, apioptns, values, rptoptns, gicdatafil, gicaddfil,
          gicpurgfil, gicrnwkfil)
```

Fortran command syntax:

```
CALL GIC(SID, ALL, APIOPTNS, VALUES, RPTOPTNS, GICDATAFIL, GICADDFIL,
        GICPURGFIL, GICRNWKFIL, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer APIOPTNS (4)	array of 4 elements specifying Integer Options(input). APIOPTNS(1) Electric Field Type (alias is efield_type) (0 by default) APIOPTNS(1) = 0 for uniform geoelectric field APIOPTNS(2) Units of Electric Field Magnitude (alias is efield_unit) (0 by default) APIOPTNS(2) = 0 for volts/km APIOPTNS(2) = 1 for volts/mile APIOPTNS(3) Option to add GIC updates to base case (alias is addfile_optn) (1 by default) APIOPTNS(3) = 0 add updates to Saved Case APIOPTNS(3) = 1 create RDCH raw file of GIC updates APIOPTNS(4) Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default)

	APIOPTNS(4) = 0	consider only study subsystem buses, no buses from inter-ties
	APIOPTNS(4) > 0	consider only study subsystem buses, no buses from inter-ties
Real VALUES (5)	array of 5 elements specifying Real Options(input).	
	VALUES(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag) (0 by default)
	VALUES(1) > 0	when charoptns(1)=uniform, no default allowed
	VALUES(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
	VALUES(1) > 0	for charoptns(1)=benchmark, used as specified
	VALUES(2)	electric field direction in degrees, range 0 to 360 degrees (alias is efield_deg) (0 by default)
	VALUES(2) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
	VALUES(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
	VALUES(3) = 0	Substation is ungrounded
	VALUES(3) > 0	Use specified grounding dc resistance
	VALUES(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
	VALUES(4) = 0	Use default
	VALUES(4) > 0	Use specified
	VALUES(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
	VALUES(5) = 0	Use default
	VALUES(5) > 0	Use specified
Integer RPTOPTNS (7)	array of 7 elements specifying Report Options(input).	
	RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
	RPTOPTNS(1) = -1	report all
	RPTOPTNS(1) = 0	no report
	RPTOPTNS(1) > 0	Report these many maximum values in each category
	RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)

	RPTOPTNS(2) = 0	No
	RPTOPTNS(2) = 1	Yes
	RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
	RPTOPTNS(3) = 0	No
	RPTOPTNS(3) = 1	Yes
	RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
	RPTOPTNS(4) = 0	No
	RPTOPTNS(4) = 1	Yes
	RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
	RPTOPTNS(5) = 0	No
	RPTOPTNS(5) = 1	Yes
	RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
	RPTOPTNS(6) = 0	No
	RPTOPTNS(6) = 1	Yes
	RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
	RPTOPTNS(7) = 0	No
	RPTOPTNS(7) = 1	Yes
Character*260 GICDATAFIL	GIC data file name (input). (input; no default allowed).	
Character*260 GICADDFIL	GIC updates to Base Case file name (output). (input; blank by default).	
Character*260 GICPURGFIL	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (input; blank by default).	
Character*260 GICRNWKFIL	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow (output). (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 1	DLL not loaded or entry point not found.

6.1.2. GIC_2

This API routine is obsolete. It has been replaced by the API routine [gic_3](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_GIC_2  SID ALL  INTGOPTNS(1)..INTGOPTNS(4) REALOPTNS(1)..REALOPTNS(7)
           CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
           FILEOPTNS(1)..FILEOPTNS(4) RPTOPTNS(1)..RPTOPTNS(7)
```

Python command syntax:

```
ierr = gic_2(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
             fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_2(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
           FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer INTGOPTNS (4)	array of 4 elements specifying Integer Options(input).	
	INTGOPTNS(1)	Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default)
	INTGOPTNS(1) = 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(1) > 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(2)	Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude and earth model on the estimated geoelectric field magnitude and are provided in NERC TPL-007-1. (alias is study_year) (0 by default)
	INTGOPTNS(2) = 0	current year, used in benchmark geoelectric field calculations only.
	INTGOPTNS(2) > 0	specific year

	INTGOPTNS(3)	Subsystem sid for local GMD hot spots (alias is sid_local) (0 by default)
	INTGOPTNS(3) = 0	No local GMD hot spots
	INTGOPTNS(3) > 0	subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to local GMD hot spots.
	INTGOPTNS(4)	Option for Transformer Thermal Analysis (not implemented yet) (alias is thermal_ana_optn) (0 by default)
	INTGOPTNS(4) = -1	perform on all transformers
	INTGOPTNS(4) = 0	do not perform
	INTGOPTNS(4) > 0	perform on these many top transformers ordered by effective GIC flow
Real REALOPTNS (7)	array of 7 elements specifying Real Options(input).	
	REALOPTNS(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag) (0 by default)
	REALOPTNS(1) > 0	when charoptns(1)=uniform, no default allowed
	REALOPTNS(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
	REALOPTNS(1) > 0	for charoptns(1)=benchmark, used as specified
	REALOPTNS(2)	electric field direction in degrees, range 0 to 360 degrees (alias is efield_deg) (0 by default)
	REALOPTNS(2) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
	REALOPTNS(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
	REALOPTNS(3) = 0	Substation is ungrounded
	REALOPTNS(3) > 0	Use specified grounding dc resistance
	REALOPTNS(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
	REALOPTNS(4) = 0	Use default
	REALOPTNS(4) > 0	Use specified
	REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
	REALOPTNS(5) = 0	Use default
	REALOPTNS(5) > 0	Use specified

	REALOPTNS(6)	local GMD hot spots electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_local) (realoptns(1) by default)
	REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
	REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees (alias is efield_deg_local) (realoptns(2) by default)
	REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).	
	CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
	CHAROPTNS(1) = uniform	for uniform geoelectric field
	CHAROPTNS(1) = benchmark	for benchmark event geoelectric field
	CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field
	CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
	CHAROPTNS(2) = v/km	for volts/km
	CHAROPTNS(2) = v/mi	for volts/mile
	CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
	CHAROPTNS(3) = sav	add updates to Saved Case
	CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
	CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)
	CHAROPTNS(4) = kfactors	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
	CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
	CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Thermal Analysis is to be performed. (alias is earth_model_name) (by default)
	CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)

CHAROPTNS(6) =	no storm orientation and/or magnitude scan
CHAROPTNS(6) = scan_deg	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for each orientation scanned
CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for only final electric field magnitude.
CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for each scanned electric field magnitude.
CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and mangitude scans performed
CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
CHAROPTNS(7) =	do not perform power flow solution
CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
CHAROPTNS(7) = fnsi	use Full Newton-Raphson method
CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
Real EJETOPTNS (5)	array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).
EJETOPTNS(1)	eleetrojet current in million amperes, must be >0 (alias is ejet_million_amps) (no default allowed)

	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ej_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ejet_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ejet_height_km) (no default allowed)
	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ejet_center_deg) (no default allowed)
Character* 260	FILEOPTNS (4)	array of 4 elements specifying File Used(input).
	FILEOPTNS(1)	GIC data file name (input). (alias is gicfile) (no default allowed)
	FILEOPTNS(2)	GIC updates to Base Case file name (output). (alias is addfile) (by default)
	FILEOPTNS(2) =	no file created
	FILEOPTNS(3)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (by default)
	FILEOPTNS(3) =	no file created
	FILEOPTNS(4)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow. (output) (alias is rnwkfile) (by default)
	FILEOPTNS(4) =	no file created
Integer	RPTOPTNS (7)	array of 7 elements specifying Report Options(input).
	RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
	RPTOPTNS(1) = -1	report all
	RPTOPTNS(1) = 0	no report
	RPTOPTNS(1) > 0	Report these many maximum values in each category
	RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
	RPTOPTNS(2) = 0	No
	RPTOPTNS(2) = 1	Yes
	RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
	RPTOPTNS(3) = 0	No
	RPTOPTNS(3) = 1	Yes
	RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
	RPTOPTNS(4) = 0	No
	RPTOPTNS(4) = 1	Yes

	RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
	RPTOPTNS(5) = 0	No
	RPTOPTNS(5) = 1	Yes
	RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
	RPTOPTNS(6) = 0	No
	RPTOPTNS(6) = 1	Yes
	RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
	RPTOPTNS(7) = 0	No
	RPTOPTNS(7) = 1	Yes
Integer IERR	error code (output).	
	IERR = 1	DLL not loaded or entry point not found.

6.1.3. GIC_3

This API routine is obsolete. It has been replaced by the API routine [gic_4](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_GIC_3  SID ALL  INTGOPTNS(1)..INTGOPTNS(4) REALOPTNS(1)..REALOPTNS(7)
           CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
           FILEOPTNS(1)..FILEOPTNS(5) RPTOPTNS(1)..RPTOPTNS(7)
```

Python command syntax:

```
ierr = gic_3(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
             fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_3(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
           FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer INTGOPTNS (4)	array of 4 elements specifying Integer Options(input).	
	INTGOPTNS(1)	Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default)
	INTGOPTNS(1) = 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(1) > 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(2)	Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude and earth model on the estimated geoelectric field magnitude and are provided in NERC TPL-007-1. (alias is study_year) (0 by default)
	INTGOPTNS(2) = 0	current year, used in benchmark geoelectric field calculations only.
	INTGOPTNS(2) > 0	specific year

	INTGOPTNS(3)	Subsystem sid for local GMD hot spots (alias is sid_local) (0 by default)
	INTGOPTNS(3) = 0	No local GMD hot spots
	INTGOPTNS(3) > 0	subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to local GMD hot spots.
	INTGOPTNS(4)	Option for Transformer Thermal Analysis (not implemented yet) (alias is thermal_ana_optn) (0 by default)
	INTGOPTNS(4) = -1	perform on all transformers
	INTGOPTNS(4) = 0	do not perform
	INTGOPTNS(4) > 0	perform on these many top transformers ordered by effective GIC flow
Real REALOPTNS (7)	array of 7 elements specifying Real Options(input).	
	REALOPTNS(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag) (0 by default)
	REALOPTNS(1) > 0	when charoptns(1)=uniform, no default allowed
	REALOPTNS(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
	REALOPTNS(1) > 0	for charoptns(1)=benchmark, used as specified
	REALOPTNS(2)	electric field direction in degrees, range 0 to 360 degrees (alias is efield_deg) (0 by default)
	REALOPTNS(2) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
	REALOPTNS(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
	REALOPTNS(3) = 0	Substation is ungrounded
	REALOPTNS(3) > 0	Use specified grounding dc resistance
	REALOPTNS(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
	REALOPTNS(4) = 0	Use default
	REALOPTNS(4) > 0	Use specified
	REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
	REALOPTNS(5) = 0	Use default
	REALOPTNS(5) > 0	Use specified

	REALOPTNS(6)	local GMD hot spots electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_local) (realoptns(1) by default)
	REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
	REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees (alias is efield_deg_local) (realoptns(2) by default)
	REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark, not used when charoptns(1)=nonuniform
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).	
	CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
	CHAROPTNS(1) = uniform	for uniform geoelectric field
	CHAROPTNS(1) = benchmark	for benchmark event geoelectric field
	CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field
	CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
	CHAROPTNS(2) = v/km	for volts/km
	CHAROPTNS(2) = v/mi	for volts/mile
	CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
	CHAROPTNS(3) = sav	add updates to Saved Case
	CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
	CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)
	CHAROPTNS(4) = kfactors	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
	CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
	CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Thermal Analysis is to be performed. (alias is earth_model_name) (by default)
	CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)

CHAROPTNS(6) =	no storm orientation and/or magnitude scan
CHAROPTNS(6) = scan_deg	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for each orientation scanned
CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for only final electric field magnitude.
CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for each scanned electric field magnitude.
CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and mangitude scans performed
CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
CHAROPTNS(7) =	do not perform power flow solution
CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
CHAROPTNS(7) = fnsi	use Full Newton-Raphson method
CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
Real EJETOPTNS (5)	array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).
EJETOPTNS(1)	eleetrojet current in million amperes, must be >0 (alias is ejet_million_amps) (no default allowed)

	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ejet_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ejet_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ejet_height_km) (no default allowed)
	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ejet_center_deg) (no default allowed)
Character* 260	FILEOPTNS (5)	array of 5 elements specifying File Used(input).
	FILEOPTNS(1)	GIC data file name (input). (alias is gicfile) (no default allowed)
	FILEOPTNS(2)	GIC updates to Base Case file name (output). (alias is addfile) (by default)
	FILEOPTNS(2) =	no file created
	FILEOPTNS(3)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (by default)
	FILEOPTNS(3) =	no file created
	FILEOPTNS(4)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow. (output) (alias is rnwkfile) (by default)
	FILEOPTNS(4) =	no file created
	FILEOPTNS(5)	GIC Results map data file for given Efield magnitude and degrees OR Efield magnitude and degrees scans which give maximum Var losses when scans are performed (output). This is used by GICMAPS to plot GIC results on network map. (alias is pygicfile) (by default)
	FILEOPTNS(5) =	temporary file created
	FILEOPTNS(5) =	no file created
	nooutput	
Integer	RPTOPTNS (7)	array of 7 elements specifying Report Options(input).
	RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
	RPTOPTNS(1) = -1	report all
	RPTOPTNS(1) = 0	no report
	RPTOPTNS(1) > 0	Report these many maximum values in each category
	RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
	RPTOPTNS(2) = 0	No

	RPTOPTNS(2) = 1	Yes
	RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
	RPTOPTNS(3) = 0	No
	RPTOPTNS(3) = 1	Yes
	RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
	RPTOPTNS(4) = 0	No
	RPTOPTNS(4) = 1	Yes
	RPTOPTNS(5)	report transformer GIC flows (alias is rpstrn_gic) (1 by default)
	RPTOPTNS(5) = 0	No
	RPTOPTNS(5) = 1	Yes
	RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
	RPTOPTNS(6) = 0	No
	RPTOPTNS(6) = 1	Yes
	RPTOPTNS(7)	report transformer losses (alias is rpstrn_q) (1 by default)
	RPTOPTNS(7) = 0	No
	RPTOPTNS(7) = 1	Yes
Integer IERR	error code (output).	
	IERR = 1	DLL not loaded or entry point not found.

6.1.4. GIC_4

This API routine is obsolete. It has been replaced by the API routine [gic_5](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_GIC_4  SID ALL  INTGOPTNS(1)..INTGOPTNS(4) REALOPTNS(1)..REALOPTNS(9)
           CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
           FILEOPTNS(1)..FILEOPTNS(6) RPTOPTNS(1)..RPTOPTNS(7)
```

Python command syntax:

```
ierr = gic_4(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
             fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_4(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
           FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer INTGOPTNS (4)	array of 4 elements specifying Integer Options(input).	
	INTGOPTNS(1)	Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default)
	INTGOPTNS(1) = 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(1) > 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(2)	Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude on the estimated geoelectric field magnitude and are provided in NERC TPL-007. (alias is study_year) (0 by default)
	INTGOPTNS(2) = 0	current year, used in benchmark and supplemental geoelectric field calculations only.
	INTGOPTNS(2) > 0	specific year

	INTGOPTNS(3)	Subsystem sid for supplemental GMD event (alias is sid_supp) (0 by default)
	INTGOPTNS(3) = 0	No supplemental GMD event
	INTGOPTNS(3) > 0	subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to supplemental GMD event.
	INTGOPTNS(4)	Option for Transformer Thermal Analysis (alias is thermal_ana_optn) (0 by default)
	INTGOPTNS(4) = -1	perform on all transformers
	INTGOPTNS(4) = 0	do not perform
	INTGOPTNS(4) > 0	perform on these many top transformers ordered by effective GIC flow
Real REALOPTNS (9)	array of 9 elements specifying Real Options(input).	
	REALOPTNS(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform or supplemental (alias is efield_mag) (0 by default)
	REALOPTNS(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
	REALOPTNS(1) > 0	when charoptns(1)=uniform, no default allowed
	REALOPTNS(1) > 0	when charoptns(1)=benchmark, used as specified
	REALOPTNS(2)	electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform or supplemental (alias is efield_deg) (0 by default)
	REALOPTNS(2) > 0	when charoptns(1)=uniform or benchmark
	REALOPTNS(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
	REALOPTNS(3) = 0	Substation is ungrounded
	REALOPTNS(3) > 0	Use specified grounding dc resistance
	REALOPTNS(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
	REALOPTNS(4) = 0	Use default
	REALOPTNS(4) > 0	Use specified
	REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
	REALOPTNS(5) = 0	Use default
	REALOPTNS(5) > 0	Use specified

	REALOPTNS(6)	supplemental event electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_supp) (realoptns(1) by default)
	REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is not zero
	REALOPTNS(6) > 0	when charoptns(1)=supplemental
	REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform (alias is efield_deg_supp) (realoptns(2) by default)
	REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is non-zero
	REALOPTNS(7) > 0	when charoptns(1)=supplemental
	REALOPTNS(8)	transmission line AC to DC resistance conversion factor, must be >0 (alias is branch_rac2rdc) (1.0 by default)
	REALOPTNS(8) = 0	Use default
	REALOPTNS(8) > 0	Use specified
	REALOPTNS(9)	transformer winding AC to DC resistance conversion factor, must be >0 (alias is transformer_rac2rdc) (1.0 by default)
	REALOPTNS(9) = 0	Use default
	REALOPTNS(9) > 0	Use specified
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).	
	CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
	CHAROPTNS(1) = uniform	for uniform geoelectric field and also supplemental event electric field when intgoptns(3) and realoptns(6) are non-zero
	CHAROPTNS(1) = benchmark	for benchmark event geoelectric field and beta factors (B) and also supplemental event electric field and beta factors (Bs) when intgoptns(3) and realoptns(6) are non-zero
	CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field
	CHAROPTNS(1) = supplemental	for supplemental event geoelectric field and beta factors (Bs)
	CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
	CHAROPTNS(2) = v/km	for volts/km
	CHAROPTNS(2) = v/mi	for volts/mile
	CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
	CHAROPTNS(3) = sav	add updates to Saved Case

CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)
CHAROPTNS(4) = kfactors	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Thermal Analysis is to be performed. (alias is earth_model_name) (by default)
CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)
CHAROPTNS(6) = CHAROPTNS(6) = scan_deg	no storm orientation and/or magnitude scan perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for each orientation scanned
CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for only final electric field magnitude.
CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for each scanned electric field magnitude.
CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans tiil they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is

		uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and magnitude scans performed
	CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
	CHAROPTNS(7) =	do not perform power flow solution
	CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
	CHAROPTNS(7) = fnsf	use Full Newton-Raphson method
	CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
Real EJETOPTNS (5)		array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).
	EJETOPTNS(1)	electrojet current in million amperes, must be >0 (alias is ej_million_amps) (no default allowed)
	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ej_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ej_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ej_height_km) (no default allowed)
	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ej_center_deg) (no default allowed)
Character*260 FILEOPTNS (6)		array of 6 elements specifying File Used(input).
	FILEOPTNS(1)	GIC data file name (input). (alias is gicfile) (no default allowed)
	FILEOPTNS(2)	GIC updates to Base Case file name (output). (alias is addfile) (blank by default)
	FILEOPTNS(2) = ''	no file created
	FILEOPTNS(3)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (blank by default)
	FILEOPTNS(3) = ''	no file created
	FILEOPTNS(4)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow (output). (alias is rnwkfile) (blank by default)
	FILEOPTNS(4) = ''	no file created
	FILEOPTNS(5)	GIC Results map data file for given Efield magnitude and degrees OR Efield magnitude and degrees scans which give maximum Var

	losses when scans are performed (output). This is used by GICMAPS to plot GIC results on network map. (alias is pygicfile) (nooutput by default)
FILEOPTNS(5) = ''	temporary file created
FILEOPTNS(5) = nooutput	no file created
FILEOPTNS(6)	Transformer Thermal Analysis GIC(t) CSV file (output). (alias is gictfile) (nooutput by default)
FILEOPTNS(6) = ''	temporary file created
FILEOPTNS(6) = nooutput	no file created
Integer RPTOPTNS (7)	array of 7 elements specifying Report Options(input).
RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
RPTOPTNS(1) = -1	report all
RPTOPTNS(1) = 0	no report
RPTOPTNS(1) > 0	Report these many maximum values in each category
RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
RPTOPTNS(2) = 0	No
RPTOPTNS(2) = 1	Yes
RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
RPTOPTNS(3) = 0	No
RPTOPTNS(3) = 1	Yes
RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
RPTOPTNS(4) = 0	No
RPTOPTNS(4) = 1	Yes
RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
RPTOPTNS(5) = 0	No
RPTOPTNS(5) = 1	Yes
RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
RPTOPTNS(6) = 0	No
RPTOPTNS(6) = 1	Yes
RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
RPTOPTNS(7) = 0	No
RPTOPTNS(7) = 1	Yes
Integer IERR	error code (output).

IERR = 1

DLL not loaded or entry point not found.

6.1.5. GIC_5

This API routine is obsolete. It has been replaced by the API routine [gic_6](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 34.5.0.

Batch command syntax:

```
BAT_GIC_5  SID ALL INTGOPTNS(1)..INTGOPTNS(5) REALOPTNS(1)..REALOPTNS(13)
          CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
          FILEOPTNS(1)..FILEOPTNS(6) RPTOPTNS(1)..RPTOPTNS(7)
```

Python command syntax:

```
ierr = gic_5(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
            fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_5(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
          FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer INTGOPTNS (5)	array of 5 elements specifying Integer Options(input). INTGOPTNS(1) Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default) INTGOPTNS(1) = 0 consider only study subsystem buses, no buses from inter-ties INTGOPTNS(1) > 0 1 through 5, consider study subsystem buses + these many levels of inter-tie buses and ignore subsystem definition voltage limits for intertie buses added INTGOPTNS(1) < 0 -1 through -5, consider study subsystem buses + these many levels of inter-tie buses and consider subsystem definition voltage limits for intertie buses added INTGOPTNS(2) Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude on the estimated geoelectric field magnitude

		and are provided in NERC TPL-007. (alias is study_year) (0 by default)
INTGOPTNS(2) = 0		current year, used in benchmark and supplemental geoelectric field calculations only.
INTGOPTNS(2) > 0		specific year
INTGOPTNS(3)		Subsystem sid for supplemental GMD event (alias is sid_supp) (0 by default)
INTGOPTNS(3) = 0		No supplemental GMD event
INTGOPTNS(3) > 0		subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to supplemental GMD event.
INTGOPTNS(4)		Option for Transformer Thermal Analysis (alias is thermal_ana_optn) (0 by default)
INTGOPTNS(4) = -1		perform on all transformers
INTGOPTNS(4) = 0		do not perform
INTGOPTNS(4) > 0		perform on these many top transformers ordered by effective GIC flow
INTGOPTNS(5)		Option to run power flow for each degree scan calculation (alias is degscan_pf_optn) (0 by default)
INTGOPTNS(5) = 0		Solve power flow only for worst degree
INTGOPTNS(5) = 1		Solve power flow for each degree scan calculation
Real REALOPTNS (13)	array of 13 elements specifying Real Options(input).	
REALOPTNS(1)		electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform or supplemental (alias is efield_mag) (0 by default)
REALOPTNS(1) = 0		when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
REALOPTNS(1) > 0		when charoptns(1)=uniform, no default allowed
REALOPTNS(1) > 0		when charoptns(1)=benchmark, used as specified
REALOPTNS(2)		electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform or supplemental (alias is efield_deg) (0 by default)
REALOPTNS(2) > 0		when charoptns(1)=uniform or benchmark
REALOPTNS(3)		substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
REALOPTNS(3) = 0		Substation is ungrounded
REALOPTNS(3) > 0		Use specified grounding dc resistance
REALOPTNS(4)		transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in

	network data (alias is branch_xbyr) (30 by default)
REALOPTNS(4) = 0	Use default
REALOPTNS(4) > 0	Use specified
REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
REALOPTNS(5) = 0	Use default
REALOPTNS(5) > 0	Use specified
REALOPTNS(6)	supplemental event electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_supp) (realoptns(1) by default)
REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is not zero
REALOPTNS(6) > 0	when charoptns(1)=supplemental
REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform (alias is efield_deg_supp) (realoptns(2) by default)
REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is non-zero
REALOPTNS(7) > 0	when charoptns(1)=supplemental
REALOPTNS(8)	transmission line AC to DC resistance conversion factor, must be >0 (alias is branch_rac2rdc) (1.0 by default)
REALOPTNS(8) = 0	Use default
REALOPTNS(8) > 0	Use specified
REALOPTNS(9)	transformer winding AC to DC resistance conversion factor, must be >0 (alias is transformer_rac2rdc) (1.0 by default)
REALOPTNS(9) = 0	Use default
REALOPTNS(9) > 0	Use specified
REALOPTNS(10)	Degree Scan step size, range 1.0 to 180 degrees (alias is degscan_step) (10.0 by default)
REALOPTNS(10) = 0	Use default
REALOPTNS(10) > 0	Use specified
REALOPTNS(11)	Magnitude Scan step size, must be >1.0 V/km (alias is magscan_step) (4.0 by default)
REALOPTNS(11) = 0	Use default
REALOPTNS(11) > 0	Use specified
REALOPTNS(12)	Percent GMD Mvar loss step size. Total GMD Mvar losses added incrementally to the base case to obtain power flow solution, must

	be >1.0 (alias is pf_qpct_step) (100.0 by default)
REALOPTNS(12) = 0	Use default
REALOPTNS(12) > 0	Use specified
REALOPTNS(13)	Magnitude Scan maximum storm strength, must be >1.0 (alias is magscan_max) (20.0 by default)
REALOPTNS(13) = 0	Use default
REALOPTNS(13) > 0	Use specified
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).
CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
CHAROPTNS(1) = uniform	for uniform geoelectric field and also supplemental event electric field when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = benchmark	for benchmark event geoelectric field and beta factors (B) and also supplemental event electric field and beta factors (Bs) when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field
CHAROPTNS(1) = supplemental	for supplemental event geoelectric field and beta factors (Bs)
CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
CHAROPTNS(2) = v/km	for volts/km
CHAROPTNS(2) = v/mi	for volts/mile
CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
CHAROPTNS(3) = sav	add updates to Saved Case
CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)
CHAROPTNS(4) = kfactors	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Ther-

	mal Analysis is to be performed. (alias is earth_model_name) (by default)
CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)
CHAROPTNS(6) =	no storm orientation and/or magnitude scan
CHAROPTNS(6) = scan_deg	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for each orientation scanned
CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orienation specified and creates report for only final electric field magnitude.
CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orienation specified and creates report for each scanned electric field magnitude.
CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans tiil they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and mangitude scans performed
CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
CHAROPTNS(7) =	do not perform power flow solution
CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
CHAROPTNS(7) = fnsl	use Full Newton-Raphson method
CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
Real EJETOPTNS (5)	array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).

	EJETOPTNS(1)	electrojet current in million amperes, must be >0 (alias is ej_million_amps) (no default allowed)
	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ej_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ej_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ej_height_km) (no default allowed)
	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ej_center_deg) (no default allowed)
Character*260	FILEOPTNS (6)	array of 6 elements specifying File Used(input).
	FILEOPTNS(1)	GIC data file name (input). (alias is gicfile) (no default allowed)
	FILEOPTNS(2)	GIC updates to Base Case file name (output). (alias is addfile) (blank by default)
	FILEOPTNS(2) = ''	no file created
	FILEOPTNS(3)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (blank by default)
	FILEOPTNS(3) = ''	no file created
	FILEOPTNS(4)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow (output). (alias is rnwkfile) (blank by default)
	FILEOPTNS(4) = ''	no file created
	FILEOPTNS(5)	GIC Results map data file for given Efield magnitude and degrees OR Efield magnitude and degrees scans which give maximum Var losses when scans are performed (output). This is used by GICMAPS to plot GIC results on network map. (alias is pygicfile) (nooutput by default)
	FILEOPTNS(5) = ''	temporary file created
	FILEOPTNS(5) = nooutput	no file created
	FILEOPTNS(6)	Transformer Thermal Analysis GIC(t) CSV file (output). (alias is gictfile) (nooutput by default)
	FILEOPTNS(6) = ''	temporary file created
	FILEOPTNS(6) = nooutput	no file created
Integer	RPTOPTNS (7)	array of 7 elements specifying Report Options(input).

	RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
	RPTOPTNS(1) = -1	report all
	RPTOPTNS(1) = 0	no report
	RPTOPTNS(1) > 0	Report these many maximum values in each category
	RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
	RPTOPTNS(2) = 0	No
	RPTOPTNS(2) = 1	Yes
	RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
	RPTOPTNS(3) = 0	No
	RPTOPTNS(3) = 1	Yes
	RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
	RPTOPTNS(4) = 0	No
	RPTOPTNS(4) = 1	Yes
	RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
	RPTOPTNS(5) = 0	No
	RPTOPTNS(5) = 1	Yes
	RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
	RPTOPTNS(6) = 0	No
	RPTOPTNS(6) = 1	Yes
	RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
	RPTOPTNS(7) = 0	No
	RPTOPTNS(7) = 1	Yes
Integer IERR	error code (output).	
	IERR = 1	DLL not loaded or entry point not found.

6.1.6. GIC_6

This API routine is obsolete. It has been replaced by the API routine [gic_7](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_GIC_6  SID ALL INTGOPTNS(1)..INTGOPTNS(10) REALOPTNS(1)..REALOPTNS(17)
          CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
          FILEOPTNS(1)..FILEOPTNS(6) RPTOPTNS(1)..RPTOPTNS(8)
```

Python command syntax:

```
ierr = gic_6(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
            fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_6(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
          FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer INTGOPTNS (10)	array of 10 elements specifying Integer Options(input). INTGOPTNS(1) Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default) INTGOPTNS(1) = 0 consider only study subsystem buses, no buses from inter-ties INTGOPTNS(1) > 0 1 through 5, consider study subsystem buses + these many levels of inter-tie buses and ignore subsystem definition voltage limits for intertie buses added INTGOPTNS(1) < 0 -1 through -5, consider study subsystem buses + these many levels of inter-tie buses and consider subsystem definition voltage limits for intertie buses added INTGOPTNS(2) Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude on the estimated geoelectric field magnitude

	and are provided in NERC TPL-007. (alias is study_year) (0 by default)
INTGOPTNS(2) = 0	current year, used in benchmark and supplemental geoelectric field calculations only.
INTGOPTNS(2) > 0	specific year
INTGOPTNS(3)	Subsystem sid for supplemental GMD event (alias is sid_supp) (0 by default)
INTGOPTNS(3) = 0	No supplemental GMD event
INTGOPTNS(3) > 0	subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to supplemental GMD event.
INTGOPTNS(4)	Option for Transformer Thermal Analysis (alias is thermal_ana_optn) (0 by default)
INTGOPTNS(4) = -1	perform on all transformers
INTGOPTNS(4) = 0	do not perform
INTGOPTNS(4) > 0	perform on these many top transformers ordered by effective GIC flow
INTGOPTNS(5)	Option to run power flow for each degree scan calculation (alias is degscan_pf_optn) (0 by default)
INTGOPTNS(5) = 0	Solve power flow only for worst degree
INTGOPTNS(5) = 1	Solve power flow for each degree scan calculation
INTGOPTNS(6)	Option to include buses of boundary transformers in study subsystem (alias is boundary_trn) (0 by default)
INTGOPTNS(6) = 0	consider only study subsystem buses
INTGOPTNS(6) = 1	Include buses of boundary transformers considering subsystem definition voltage limits
INTGOPTNS(6) = 2	Include buses of boundary transformers ignoring subsystem definition voltage limits
INTGOPTNS(7)	Option for Transformers to include in worst case determination (alias is worstcase_trn) (0 by default)
INTGOPTNS(7) = 0	All transformers in study subsystem
INTGOPTNS(7) = 1	All transformers in report subsystem
INTGOPTNS(8)	Option for Supplemental event Moving Box (alias is supp_evt) (0 by default)
INTGOPTNS(8) = 0	No supplemental event
INTGOPTNS(8) = 1	Use supplemental event subsystem SID as the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(8) = 2	Rank substations with maximum GIC flows as center of the moving box from storm orientation scans that results in maximum VAR losses. For CHAROPTNS(6)="", Orientation of

	Efield=Supplemental Efield=Orientation that gives Maximum VAR losses
INTGOPTNS(8) = 3	Rank transformers with maximum GIC flows as center of the moving box from storm orientation scans. For CHAROPTNS(6)="", Orientation of Efield=Orientation that gives Maximum VAR losses, Orientation of Supplemental Efield=Orientation that gives Maximum GICs in transformer
INTGOPTNS(8) = 4	Use substation number provided as center of the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(8) = 5	Use location provided as center of the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(9)	Option for number of Supplemental event moving boxes. It is not used when intgoptns(8)=0 and intgoptns(8)=4 (alias is supp_box_num) (0 by default)
INTGOPTNS(9) = 0	Do not perform moving box calculations when when intgoptns(8)=1, 2, 3
INTGOPTNS(9) > 0	When intgoptns(8)=1, number of substations to consider for center of moving box
INTGOPTNS(9) > 0	When intgoptns(8)=2, number of transformers to consider for center of moving box
INTGOPTNS(9) > 0	When intgoptns(8)=3, valid substation number to consider for center of moving box
INTGOPTNS(10)	Option for treatment of the transmission line that intersect with Supplemental event moving box (alias is brn_seg_efld) (0 by default)
INTGOPTNS(10) = 0	Apply Supplemental event Efield to line segment inside the box and Benchmark event Efield to line segments outside the box
INTGOPTNS(10) = 1	Apply Supplemental event Efield to entire line when any segment of the line is inside the box
Real REALOPTNS (17)	array of 17 elements specifying Real Options(input).
REALOPTNS(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform or supplemental (alias is efield_mag) (0 by default)
REALOPTNS(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
REALOPTNS(1) > 0	when charoptns(1)=uniform, no default allowed

REALOPTNS(1) > 0	when charoptns(1)=benchmark, used as specified
REALOPTNS(2)	electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform or supplemental (alias is efield_deg) (0 by default)
REALOPTNS(2) > 0	when charoptns(1)=uniform or benchmark
REALOPTNS(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
REALOPTNS(3) = 0	Substation is ungrounded
REALOPTNS(3) > 0	Use specified grounding dc resistance
REALOPTNS(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
REALOPTNS(4) = 0	Use default
REALOPTNS(4) > 0	Use specified
REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
REALOPTNS(5) = 0	Use default
REALOPTNS(5) > 0	Use specified
REALOPTNS(6)	supplemental event electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_supp) (realoptns(1) by default)
REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is not zero
REALOPTNS(6) > 0	when charoptns(1)=supplemental
REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform (alias is efield_deg_supp) (realoptns(2) by default)
REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is non-zero
REALOPTNS(7) > 0	when charoptns(1)=supplemental
REALOPTNS(8)	transmission line AC to DC resistance conversion factor, must be >0 (alias is branch_rac2rdc) (1.0 by default)
REALOPTNS(8) = 0	Use default
REALOPTNS(8) > 0	Use specified
REALOPTNS(9)	transformer winding AC to DC resistance conversion factor, must be >0 (alias is transformer_rac2rdc) (1.0 by default)
REALOPTNS(9) = 0	Use default
REALOPTNS(9) > 0	Use specified

REALOPTNS(10)	Degree Scan step size, range 1.0 to 180 degrees (alias is degscan_step) (10.0 by default)
REALOPTNS(10) = 0	Use default
REALOPTNS(10) > 0	Use specified
REALOPTNS(11)	Magnitude Scan step size, must be >1.0 V/km (alias is magscan_step) (4.0 by default)
REALOPTNS(11) = 0	Use default
REALOPTNS(11) > 0	Use specified
REALOPTNS(12)	Percent GMD Mvar loss step size. Total GMD Mvar losses added incrementally to the base case to obtain power flow solution, must be >1.0 (alias is pf_qpct_step) (100.0 by default)
REALOPTNS(12) = 0	Use default
REALOPTNS(12) > 0	Use specified
REALOPTNS(13)	Magnitude Scan maximum storm strength, must be >1.0 (alias is magscan_max) (20.0 by default)
REALOPTNS(13) = 0	Use default
REALOPTNS(13) > 0	Use specified
REALOPTNS(14)	Supplemental event moving box North-South length in km, must be >1.0, used when intgoptns(8)>0 (alias is supp_box_ns_km) (100.0 by default)
REALOPTNS(14) = 0	Use default
REALOPTNS(14) > 0	Use specified
REALOPTNS(15)	Supplemental event moving box East-West length in km, must be >1.0, used when intgoptns(8)>0 (alias is supp_box_ew_km) (500.0 by default)
REALOPTNS(15) = 0	Use default
REALOPTNS(15) > 0	Use specified
REALOPTNS(16)	Supplemental event moving box center point longitude in degrees, used only when intgoptns(8)=4 (alias is supp_box_lon_c) (0.0 by default)
REALOPTNS(16) = 0	Use default
REALOPTNS(16) > 0	Use specified
REALOPTNS(17)	Supplemental event moving box center point latitude in degrees, used only when intgoptns(8)=4 (alias is supp_box_lat_c) (0.0 by default)
REALOPTNS(17) = 0	Use default
REALOPTNS(17) > 0	Use specified
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).

CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
CHAROPTNS(1) = uniform	for uniform geoelectric field and also supplemental event electric field when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = benchmark	for benchmark event geoelectric field and beta factors (B) and also supplemental event electric field and beta factors (Bs) when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field
CHAROPTNS(1) = supplemental	for supplemental event geoelectric field and beta factors (Bs)
CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
CHAROPTNS(2) = v/km	for volts/km
CHAROPTNS(2) = v/mi	for volts/mile
CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
CHAROPTNS(3) = sav	add updates to Saved Case
CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)
CHAROPTNS(4) = kfactors	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Thermal Analysis is to be performed. (alias is earth_model_name) (by default)
CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)
CHAROPTNS(6) = scan_deg	no storm orientation and/or magnitude scan
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is

		uniform or benchmark, create report for each orientation scanned
	CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for only final electric field magnitude.
	CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for each scanned electric field magnitude.
	CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
	CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and mangitude scans performed
	CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
	CHAROPTNS(7) =	do not perform power flow solution
	CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
	CHAROPTNS(7) = fnsl	use Full Newton-Raphson method
	CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
Real EJETOPTNS (5)		array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).
	EJETOPTNS(1)	eleetrojet current in million amperes, must be >0 (alias is ejeta_million_amps) (no default allowed)
	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ejeta_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ejeta_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ejeta_height_km) (no default allowed)

	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ej_center_deg) (no default allowed)
Character* 260	FILEOPTNS (6)	array of 6 elements specifying File Used(input).
	FILEOPTNS(1)	GIC data file name (input). (alias is gicfile) (no default allowed)
	FILEOPTNS(2)	GIC updates to Base Case file name (output). (alias is addfile) (blank by default)
	FILEOPTNS(2) = ''	no file created
	FILEOPTNS(3)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (blank by default)
	FILEOPTNS(3) = ''	no file created
	FILEOPTNS(4)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow (output). (alias is rnwkfile) (blank by default)
	FILEOPTNS(4) = ''	no file created
	FILEOPTNS(5)	GIC Results map data file for given Efield magnitude and degrees OR Efield magnitude and degrees scans which give maximum Var losses when scans are performed (output). This is used by GICMAPS to plot GIC results on network map. (alias is pygicfile) (nooutput by default)
	FILEOPTNS(5) = ''	temporary file created
	FILEOPTNS(5) = nooutput	no file created
	FILEOPTNS(6)	Transformer Thermal Analysis GIC(t) CSV file (output). (alias is gictfile) (nooutput by default)
	FILEOPTNS(6) = ''	temporary file created
	FILEOPTNS(6) = nooutput	no file created
Integer	RPTOPTNS (8)	array of 8 elements specifying Report Options(input).
	RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
	RPTOPTNS(1) = -1	report all
	RPTOPTNS(1) = 0	no report
	RPTOPTNS(1) > 0	Report these many maximum values in each category
	RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
	RPTOPTNS(2) = 0	No
	RPTOPTNS(2) = 1	Yes

	RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
	RPTOPTNS(3) = 0	No
	RPTOPTNS(3) = 1	Yes
	RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
	RPTOPTNS(4) = 0	No
	RPTOPTNS(4) = 1	Yes
	RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
	RPTOPTNS(5) = 0	No
	RPTOPTNS(5) = 1	Yes
	RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
	RPTOPTNS(6) = 0	No
	RPTOPTNS(6) = 1	Yes
	RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
	RPTOPTNS(7) = 0	No
	RPTOPTNS(7) = 1	Yes
	RPTOPTNS(8)	Subsystem sid for report (alias is rpt_sid) (0 by default)
	RPTOPTNS(8) = 0	Use study subsystem as report subsystem
	RPTOPTNS(8) = 1	Subsystem number (1 - 11). GIC report created for buses and branches in this subsystem.
Integer IERR	error code (output).	
	IERR = 1	DLL not loaded or entry point not found.

6.1.7. GIC_7

This API routine is obsolete. It has been replaced by the API routine [gic_8](#).

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_7  SID ALL INTGOPTNS(1)..INTGOPTNS(10) REALOPTNS(1)..REALOPTNS(17)
          CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
          FILEOPTNS(1)..FILEOPTNS(5) RPTOPTNS(1)..RPTOPTNS(8)
```

Python command syntax:

```
ierr = gic_7(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
            fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_7(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
          FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer INTGOPTNS (10)	array of 10 elements specifying Integer Options(input). INTGOPTNS(1) Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default) INTGOPTNS(1) = 0 consider only study subsystem buses, no buses from inter-ties INTGOPTNS(1) > 0 1 through 5, consider study subsystem buses + these many levels of inter-tie buses and ignore subsystem definition voltage limits for intertie buses added INTGOPTNS(1) < 0 -1 through -5, consider study subsystem buses + these many levels of inter-tie buses and consider subsystem definition voltage limits for intertie buses added INTGOPTNS(2) Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude on the estimated geoelectric field magnitude

	and are provided in NERC TPL-007. (alias is study_year) (0 by default)
INTGOPTNS(2) = 0	current year, used in benchmark and supplemental geoelectric field calculations only.
INTGOPTNS(2) > 0	specific year
INTGOPTNS(3)	Subsystem sid for supplemental GMD event (alias is sid_supp) (0 by default)
INTGOPTNS(3) = 0	No supplemental GMD event
INTGOPTNS(3) > 0	subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to supplemental GMD event.
INTGOPTNS(4)	Option for Transformer Thermal Analysis (alias is thermal_ana_optn) (0 by default)
INTGOPTNS(4) = -1	perform on all transformers
INTGOPTNS(4) = 0	do not perform
INTGOPTNS(4) > 0	perform on these many top transformers ordered by effective GIC flow
INTGOPTNS(5)	Option to run power flow for each degree scan calculation (alias is degscan_pf_optn) (0 by default)
INTGOPTNS(5) = 0	Solve power flow only for worst degree
INTGOPTNS(5) = 1	Solve power flow for each degree scan calculation
INTGOPTNS(6)	Option to include buses of boundary transformers in study subsystem (alias is boundary_trn) (0 by default)
INTGOPTNS(6) = 0	consider only study subsystem buses
INTGOPTNS(6) = 1	Include buses of boundary transformers considering subsystem definition voltage limits
INTGOPTNS(6) = 2	Include buses of boundary transformers ignoring subsystem definition voltage limits
INTGOPTNS(7)	Option for Transformers to include in worst case determination (alias is worstcase_trn) (0 by default)
INTGOPTNS(7) = 0	All transformers in study subsystem
INTGOPTNS(7) = 1	All transformers in report subsystem
INTGOPTNS(8)	Option for Supplemental event Moving Box (alias is supp_evt) (0 by default)
INTGOPTNS(8) = 0	No supplemental event
INTGOPTNS(8) = 1	Use supplemental event subsystem SID as the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(8) = 2	Rank substations with maximum GIC flows as center of the moving box from storm orientation scans that results in maximum VAR losses. For CHAROPTNS(6)="", Orientation of

	Efield=Supplemental Efield=Orientation that gives Maximum VAR losses
INTGOPTNS(8) = 3	Rank transformers with maximum GIC flows as center of the moving box from storm orientation scans. For CHAROPTNS(6)="", Orientation of Efield=Orientation that gives Maximum VAR losses, Orientation of Supplemental Efield=Orientation that gives Maximum GICs in transformer
INTGOPTNS(8) = 4	Use substation number provided as center of the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(8) = 5	Use location provided as center of the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(9)	Option for number of Supplemental event moving boxes. It is not used when intgoptns(8)=0 and intgoptns(8)=4 (alias is supp_box_num) (0 by default)
INTGOPTNS(9) = 0	Do not perform moving box calculations when when intgoptns(8)=1, 2, 3
INTGOPTNS(9) > 0	When intgoptns(8)=1, number of substations to consider for center of moving box
INTGOPTNS(9) > 0	When intgoptns(8)=2, number of transformers to consider for center of moving box
INTGOPTNS(9) > 0	When intgoptns(8)=3, valid substation number to consider for center of moving box
INTGOPTNS(10)	Option for treatment of the transmission line that intersect with Supplemental event moving box (alias is brn_seg_efld) (0 by default)
INTGOPTNS(10) = 0	Apply Supplemental event Efield to line segment inside the box and Benchmark event Efield to line segments outside the box
INTGOPTNS(10) = 1	Apply Supplemental event Efield to entire line when any segment of the line is inside the box
Real REALOPTNS (17)	array of 17 elements specifying Real Options(input).
REALOPTNS(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform or supplemental (alias is efield_mag) (0 by default)
REALOPTNS(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
REALOPTNS(1) > 0	when charoptns(1)=uniform, no default allowed

REALOPTNS(1) > 0	when charoptns(1)=benchmark, used as specified
REALOPTNS(2)	electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform or supplemental (alias is efield_deg) (0 by default)
REALOPTNS(2) > 0	when charoptns(1)=uniform or benchmark
REALOPTNS(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
REALOPTNS(3) = 0	Substation is ungrounded
REALOPTNS(3) > 0	Use specified grounding dc resistance
REALOPTNS(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
REALOPTNS(4) = 0	Use default
REALOPTNS(4) > 0	Use specified
REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
REALOPTNS(5) = 0	Use default
REALOPTNS(5) > 0	Use specified
REALOPTNS(6)	supplemental event electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_supp) (realoptns(1) by default)
REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is not zero
REALOPTNS(6) > 0	when charoptns(1)=supplemental
REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform (alias is efield_deg_supp) (realoptns(2) by default)
REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is non-zero
REALOPTNS(7) > 0	when charoptns(1)=supplemental
REALOPTNS(8)	transmission line AC to DC resistance conversion factor, must be >0 (alias is branch_rac2rdc) (1.0 by default)
REALOPTNS(8) = 0	Use default
REALOPTNS(8) > 0	Use specified
REALOPTNS(9)	transformer winding AC to DC resistance conversion factor, must be >0 (alias is transformer_rac2rdc) (1.0 by default)
REALOPTNS(9) = 0	Use default
REALOPTNS(9) > 0	Use specified

REALOPTNS(10)	Degree Scan step size, range 1.0 to 180 degrees (alias is degscan_step) (10.0 by default)
REALOPTNS(10) = 0	Use default
REALOPTNS(10) > 0	Use specified
REALOPTNS(11)	Magnitude Scan step size, must be >1.0 V/km (alias is magscan_step) (4.0 by default)
REALOPTNS(11) = 0	Use default
REALOPTNS(11) > 0	Use specified
REALOPTNS(12)	Percent GMD Mvar loss step size. Total GMD Mvar losses added incrementally to the base case to obtain power flow solution, must be >1.0 (alias is pf_qpct_step) (100.0 by default)
REALOPTNS(12) = 0	Use default
REALOPTNS(12) > 0	Use specified
REALOPTNS(13)	Magnitude Scan maximum storm strength, must be >1.0 (alias is magscan_max) (20.0 by default)
REALOPTNS(13) = 0	Use default
REALOPTNS(13) > 0	Use specified
REALOPTNS(14)	Supplemental event moving box North-South length in km, must be >1.0, used when intgoptns(8)>0 (alias is supp_box_ns_km) (100.0 by default)
REALOPTNS(14) = 0	Use default
REALOPTNS(14) > 0	Use specified
REALOPTNS(15)	Supplemental event moving box East-West length in km, must be >1.0, used when intgoptns(8)>0 (alias is supp_box_ew_km) (500.0 by default)
REALOPTNS(15) = 0	Use default
REALOPTNS(15) > 0	Use specified
REALOPTNS(16)	Supplemental event moving box center point longitude in degrees, used only when intgoptns(8)=4 (alias is supp_box_lon_c) (0.0 by default)
REALOPTNS(16) = 0	Use default
REALOPTNS(16) > 0	Use specified
REALOPTNS(17)	Supplemental event moving box center point latitude in degrees, used only when intgoptns(8)=4 (alias is supp_box_lat_c) (0.0 by default)
REALOPTNS(17) = 0	Use default
REALOPTNS(17) > 0	Use specified
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).

CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
CHAROPTNS(1) = uniform	for uniform geoelectric field and also supplemental event electric field when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = benchmark	for benchmark event geoelectric field and beta factors (B) and also supplemental event electric field and beta factors (Bs) when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field
CHAROPTNS(1) = supplemental	for supplemental event geoelectric field and beta factors (Bs)
CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
CHAROPTNS(2) = v/km	for volts/km
CHAROPTNS(2) = v/mi	for volts/mile
CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
CHAROPTNS(3) = sav	add updates to Saved Case
CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)
CHAROPTNS(4) = kfactors	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Thermal Analysis is to be performed. (alias is earth_model_name) (by default)
CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)
CHAROPTNS(6) = scan_deg	no storm orientation and/or magnitude scan
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
	perform storm orientation scan that give maximum Var losses when charoptns(1) is

		uniform or benchmark, create report for each orientation scanned
	CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for only final electric field magnitude.
	CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orientation specified and creates report for each scanned electric field magnitude.
	CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
	CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and mangitude scans performed
	CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
	CHAROPTNS(7) =	do not perform power flow solution
	CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
	CHAROPTNS(7) = fnsf	use Full Newton-Raphson method
	CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
Real EJETOPTNS (5)		array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).
	EJETOPTNS(1)	eleetrojet current in million amperes, must be >0 (alias is ejeta_million_amps) (no default allowed)
	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ejeta_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ejeta_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ejeta_height_km) (no default allowed)

	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ej_center_deg) (no default allowed)
Character* 260 FILEOPTNS (5)	array of 5 elements specifying File Used(input).	
	FILEOPTNS(1)	GIC updates to Base Case file name (output). (alias is addfile) (blank by default)
	FILEOPTNS(1) = ''	no file created
	FILEOPTNS(2)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (blank by default)
	FILEOPTNS(2) = ''	no file created
	FILEOPTNS(3)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow (output). (alias is rnwkfile) (blank by default)
	FILEOPTNS(3) = ''	no file created
	FILEOPTNS(4)	GIC Results map data file for given Efield magnitude and degrees OR Efield magnitude and degrees scans which give maximum Var losses when scans are performed (output). This is used by GICMAPS to plot GIC results on network map. (alias is pygicfile) (nooutput by default)
	FILEOPTNS(4) = ''	temporary file created
	FILEOPTNS(4) = nooutput	no file created
	FILEOPTNS(5)	Transformer Thermal Analysis GIC(t) CSV file (output). (alias is gictfile) (nooutput by default)
	FILEOPTNS(5) = ''	temporary file created
	FILEOPTNS(5) = nooutput	no file created
Integer RPTOPTNS (8)	array of 8 elements specifying Report Options(input).	
	RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
	RPTOPTNS(1) = -1	report all
	RPTOPTNS(1) = 0	no report
	RPTOPTNS(1) > 0	Report these many maximum values in each category
	RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
	RPTOPTNS(2) = 0	No
	RPTOPTNS(2) = 1	Yes
	RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)

	RPTOPTNS(3) = 0	No
	RPTOPTNS(3) = 1	Yes
	RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
	RPTOPTNS(4) = 0	No
	RPTOPTNS(4) = 1	Yes
	RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
	RPTOPTNS(5) = 0	No
	RPTOPTNS(5) = 1	Yes
	RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
	RPTOPTNS(6) = 0	No
	RPTOPTNS(6) = 1	Yes
	RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
	RPTOPTNS(7) = 0	No
	RPTOPTNS(7) = 1	Yes
	RPTOPTNS(8)	Subsystem sid for report (alias is rpt_sid) (0 by default)
	RPTOPTNS(8) = 0	Use study subsystem as report subsystem
	RPTOPTNS(8) = 1	Subsystem number (1 - 11). GIC report created for buses and branches in this subsystem.
Integer IERR	error code (output).	
	IERR = 1	DLL not loaded or entry point not found.

6.1.8. GIC_8

Use this API to calculate Geomagnetically Induced Currents (GIC) in electric power system network as a result of Geomagnetic Disturbance (GMD).

This API routine was first introduced in release 34.8.0 and 35.1.0.

Batch command syntax:

```
BAT_GIC_8  SID ALL INTGOPTNS(1)..INTGOPTNS(10) REALOPTNS(1)..REALOPTNS(19)
CHAROPTNS(1)..CHAROPTNS(7) EJETOPTNS(1)..EJETOPTNS(5)
FILEOPTNS(1)..FILEOPTNS(5) RPTOPTNS(1)..RPTOPTNS(8)
```

Python command syntax:

```
ierr = gic_8(sid, all, intgoptns, realoptns, charoptns, ejetoptns,
fileoptns, rptoptns)
```

Fortran command syntax:

```
CALL GIC_8(SID, ALL, INTGOPTNS, REALOPTNS, CHAROPTNS, EJETOPTNS,
FILEOPTNS, RPTOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer INTGOPTNS (10)	array of 10 elements specifying Integer Options(input).	
	INTGOPTNS(1)	Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default)
	INTGOPTNS(1) = 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(1) > 0	1 through 5, consider study subsystem buses + these many levels of inter-tie buses and ignore subsystem definition voltage limits for intertie buses added
	INTGOPTNS(1) < 0	-1 through -5, consider study subsystem buses + these many levels of inter-tie buses and consider subsystem definition voltage limits for intertie buses added
	INTGOPTNS(2)	Year number to scale benchmark event GMD storm. These scaling factors account in the influence of geomagnetic latitude on the estimated geoelectric field magnitude and are provided in NERC TPL-007. (alias is study_year) (0 by default)

INTGOPTNS(2) = 0	current year, used in benchmark and supplemental geoelectric field calculations only.
INTGOPTNS(2) > 0	specific year
INTGOPTNS(3)	Subsystem sid for supplemental GMD event (alias is sid_supp) (0 by default)
INTGOPTNS(3) = 0	No supplemental GMD event
INTGOPTNS(3) > 0	subsystem number (1 - 11). Buses and branches in this subsystem will have Efield due to supplemental GMD event.
INTGOPTNS(4)	Option for Transformer Thermal Analysis (alias is thermal_ana_optn) (0 by default)
INTGOPTNS(4) = -1	perform on all transformers
INTGOPTNS(4) = 0	do not perform
INTGOPTNS(4) > 0	perform on these many top transformers ordered by effective GIC flow
INTGOPTNS(5)	Option to run power flow for each degree scan calculation (alias is degscan_pf_optn) (0 by default)
INTGOPTNS(5) = 0	Solve power flow only for worst degree
INTGOPTNS(5) = 1	Solve power flow for each degree scan calculation
INTGOPTNS(6)	Option to include buses of boundary transformers in study subsystem (alias is boundary_trn) (0 by default)
INTGOPTNS(6) = 0	consider only study subsystem buses
INTGOPTNS(6) = 1	Include buses of boundary transformers considering subsystem definition voltage limits
INTGOPTNS(6) = 2	Include buses of boundary transformers ignoring subsystem definition voltage limits
INTGOPTNS(7)	Option for Transformers to include in worst case determination (alias is worstcase_trn) (0 by default)
INTGOPTNS(7) = 0	All transformers in study subsystem
INTGOPTNS(7) = 1	All transformers in report subsystem
INTGOPTNS(8)	Option for Supplemental event Moving Box (alias is supp_evt) (0 by default)
INTGOPTNS(8) = 0	No supplemental event
INTGOPTNS(8) = 1	Use supplemental event subsystem SID as the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(8) = 2	Rank substations with maximum GIC flows as center of the moving box from storm orientation scans that results in maximum VAR losses. For CHAROPTNS(6)="", Orientation of Efield=Supplemental Efield=Orientation that gives Maximum VAR losses

INTGOPTNS(8) = 3	Rank transformers with maximum GIC flows as center of the moving box from storm orientation scans. For CHAROPTNS(6)="", Orientation of Efield=Orientation that gives Maximum VAR losses, Orientation of Supplemental Efield=Orientation that gives Maximum GICs in transformer
INTGOPTNS(8) = 4	Use substation number provided as center of the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(8) = 5	Use location provided as center of the moving box. For CHAROPTNS(6)="", Orientation of Efield=REALOPTNS(2), Orientation of Supplemental Efield=REALOPTNS(7)
INTGOPTNS(9)	Option for number of Supplemental event moving boxes. It is not used when intgoptns(8)=0 and intgoptns(8)=4 (alias is supp_box_num) (0 by default)
INTGOPTNS(9) = 0	Do not perform moving box calculations when when intgoptns(8)=1, 2, 3
INTGOPTNS(9) > 0	When intgoptns(8)=1, number of substations to consider for center of moving box
INTGOPTNS(9) > 0	When intgoptns(8)=2, number of transformers to consider for center of moving box
INTGOPTNS(9) > 0	When intgoptns(8)=3, valid substation number to consider for center of moving box
INTGOPTNS(10)	Option for treatment of the transmission line that intersect with Supplemental event moving box (alias is brn_seg_efld) (0 by default)
INTGOPTNS(10) = 0	Apply Supplemental event Efield to line segment inside the box and Benchmark event Efield to line segments outside the box
INTGOPTNS(10) = 1	Apply Supplemental event Efield to entire line when any segment of the line is inside the box
Real REALOPTNS (19)	array of 19 elements specifying Real Options(input).
REALOPTNS(1)	electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform or supplemental (alias is efield_mag) (0 by default)
REALOPTNS(1) = 0	when charoptns(1)=benchmark, when specified as 0.0, it will be set to 8.0 V/km (default benchmark event strength)
REALOPTNS(1) > 0	when charoptns(1)=uniform, no default allowed
REALOPTNS(1) > 0	when charoptns(1)=benchmark, used as specified

REALOPTNS(2)	electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform or supplemental (alias is efield_deg) (0 by default)
REALOPTNS(2) > 0	when charoptns(1)=uniform or benchmark
REALOPTNS(3)	substation grounding dc resistance in ohms (alias is substation_r) (0.1 by default)
REALOPTNS(3) = 0	Substation is ungrounded
REALOPTNS(3) > 0	Use specified grounding dc resistance
REALOPTNS(4)	transmission line X/R ratio, must be >0, used to calculate branch DC resistance if R=0.0 in network data (alias is branch_xbyr) (30 by default)
REALOPTNS(4) = 0	Use default
REALOPTNS(4) > 0	Use specified
REALOPTNS(5)	transformer winding X/R ratio, must be >0, used to calculate winding DC resistance if R=0.0 in network data (alias is transformer_xbyr) (30 by default)
REALOPTNS(5) = 0	Use default
REALOPTNS(5) > 0	Use specified
REALOPTNS(6)	supplemental event electric field magnitude in units defined by charoptns(2), not used when charoptns(1)=nonuniform (alias is efield_mag_supp) (realoptns(1) by default)
REALOPTNS(6) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is not zero
REALOPTNS(6) > 0	when charoptns(1)=supplemental
REALOPTNS(7)	local GMD hot spots electric field direction in degrees, range 0 to 360 degrees, not used when charoptns(1)=nonuniform (alias is efield_deg_supp) (realoptns(2) by default)
REALOPTNS(7) > 0	when charoptns(1)=uniform or benchmark and intgoptns(3) is non-zero
REALOPTNS(7) > 0	when charoptns(1)=supplemental
REALOPTNS(8)	transmission line AC to DC resistance conversion factor, must be >0 (alias is branch_rac2rdc) (1.0 by default)
REALOPTNS(8) = 0	Use default
REALOPTNS(8) > 0	Use specified
REALOPTNS(9)	transformer winding AC to DC resistance conversion factor, must be >0 (alias is transformer_rac2rdc) (1.0 by default)
REALOPTNS(9) = 0	Use default
REALOPTNS(9) > 0	Use specified

REALOPTNS(10)	Degree Scan step size, range 1.0 to 180 degrees (alias is degscan_step) (10.0 by default)
REALOPTNS(10) = 0	Use default
REALOPTNS(10) > 0	Use specified
REALOPTNS(11)	Magnitude Scan step size, must be >1.0 V/km (alias is magscan_step) (4.0 by default)
REALOPTNS(11) = 0	Use default
REALOPTNS(11) > 0	Use specified
REALOPTNS(12)	Percent GMD Mvar loss step size. Total GMD Mvar losses added incrementally to the base case to obtain power flow solution, must be >1.0 (alias is pf_qpct_step) (100.0 by default)
REALOPTNS(12) = 0	Use default
REALOPTNS(12) > 0	Use specified
REALOPTNS(13)	Magnitude Scan maximum storm strength, must be >1.0 (alias is magscan_max) (20.0 by default)
REALOPTNS(13) = 0	Use default
REALOPTNS(13) > 0	Use specified
REALOPTNS(14)	Supplemental event moving box North-South length in km, must be >1.0, used when intgoptns(8)>0 (alias is supp_box_ns_km) (100.0 by default)
REALOPTNS(14) = 0	Use default
REALOPTNS(14) > 0	Use specified
REALOPTNS(15)	Supplemental event moving box East-West length in km, must be >1.0, used when intgoptns(8)>0 (alias is supp_box_ew_km) (500.0 by default)
REALOPTNS(15) = 0	Use default
REALOPTNS(15) > 0	Use specified
REALOPTNS(16)	Supplemental event moving box center point longitude in degrees, used only when intgoptns(8)=4 (alias is supp_box_lon_c) (0.0 by default)
REALOPTNS(16) = 0	Use default
REALOPTNS(16) > 0	Use specified
REALOPTNS(17)	Supplemental event moving box center point latitude in degrees, used only when intgoptns(8)=4 (alias is supp_box_lat_c) (0.0 by default)
REALOPTNS(17) = 0	Use default
REALOPTNS(17) > 0	Use specified
REALOPTNS(18)	Branch segment length in km, used to calculate branch induced voltage from Efield

	Grid, must be >0.0. Branch is subdivided into number of segments (points along the branch route) and NN algorithm finds nearest geoelectric efield grid data point to arrive efield at that branch route point. (alias is brn_segkm) (5.0 by default)
REALOPTNS(18) = 0.0	Use default
REALOPTNS(18) > 0	Use specified
REALOPTNS(19)	Branch subsegment length in km, used to calculate branch induced voltage from Efield Grid, range 0.02 to 1.0 km. When efield value at branch route point changes, that branch segment is further subdivided into smaller segments to arrive at branch route point where NN algorithm efield change occurs. (alias is brn_subsegkm) (0.1 by default)
REALOPTNS(19) = 0.0	Use default
REALOPTNS(19) > 0	Use specified
Character*12 CHAROPTNS (7)	array of 7 elements specifying Character Options(input).
CHAROPTNS(1)	Electric Field Type (alias is efield_type) (uniform by default)
CHAROPTNS(1) = uniform	for uniform geoelectric field and also supplemental event electric field when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = benchmark	for benchmark event geoelectric field and beta factors (B) and also supplemental event electric field and beta factors (Bs) when intgoptns(3) and realoptns(6) are non-zero
CHAROPTNS(1) = nonuniform	for nonuniform geoelectric field per elctrojet characteristics and complex image method
CHAROPTNS(1) = supplemental	for supplemental event geoelectric field and beta factors (Bs)
CHAROPTNS(1) = efieldgrid	for nonuniform geoelectric field per specified efield grid data and nearest neighbor algorithm
CHAROPTNS(2)	Units of Electric Field Magnitude (alias is efield_unit) (v/km by default)
CHAROPTNS(2) = v/km	for volts/km
CHAROPTNS(2) = v/mi	for volts/mile
CHAROPTNS(3)	Option to add GIC updates to base case (alias is addfile_optn) (rdch by default)
CHAROPTNS(3) = sav	add updates to Saved Case
CHAROPTNS(3) = rdch	create RDCH raw file of GIC updates
CHAROPTNS(4)	Option to select method for GIC to Mvar Calculation (alias is gic2mvar_optn) (kfactors by default)

CHAROPTNS(4) = kfactor	for GIC to Mvar scaling factors from GIC data file when provided, otherwise default scaling factors
CHAROPTNS(4) = capchar	for GIC to Mvar scaling factors from GIC data file when provided, otherwise scaling factors from default transformer Mvar and GIC characteristics
CHAROPTNS(5)	Earth Model Name. A Standard or User defined model name must be provided when Benchmark Event or Non-uniform electric field is to be modeled or Transformer Thermal Analysis is to be performed. (alias is earth_model_name) (by default)
CHAROPTNS(6)	Option to scan storm event scenarios (alias is scan_storm_event) (by default)
CHAROPTNS(6) = scan_deg	no storm orientation and/or magnitude scan
CHAROPTNS(6) = scan_deg_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, create report for only orientation that gives maximum VAR losses
CHAROPTNS(6) = scan_mag	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orienation specified and creates report for only final electric field magnitude.
CHAROPTNS(6) = scan_mag_rpt	perform storm electric field magnitude that yield converged power flow solution when charoptns(1) is uniform or benchmark and charoptns(7) specifies PF method. It uses orienation specified and creates report for each scanned electric field magnitude.
CHAROPTNS(6) = scan_d_m	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans tiil they yield converged power flow solution, create report for only orientation that gives maximum VAR losses and final electric field magnitude
CHAROPTNS(6) = scan_d_m_rpt	perform storm orientation scan that give maximum Var losses when charoptns(1) is uniform or benchmark, then perform magnitude scans till they yield converged power flow solution, create report for all orientation scans and mangitude scans performed

	CHAROPTNS(7)	Option to solve Power Flow with GIC losses added to the base case (alias is power_flow_optn) (by default)
	CHAROPTNS(7) =	do not perform power flow solution
	CHAROPTNS(7) = fdns	use fixed slope decoupled Newton-Raphson method
	CHAROPTNS(7) = fns1	use Full Newton-Raphson method
	CHAROPTNS(7) = nsol	use Decoupled Newton-Raphson method
	CHAROPTNS(7) = rsol	use Robust solution method
	CHAROPTNS(7) = last	use solution method used in input Saved case file
Real	EJETOPTNS (5)	array of 5 elements specifying Electrojet Characteristics, used only if charoptns(1)=nonuniform(input).
	EJETOPTNS(1)	electrojet current in million amperes, must be >0 (alias is ejet_million_amps) (no default allowed)
	EJETOPTNS(2)	Cauchy distribution half-width in km, must be >0 (alias is ejet_halfwidth_km) (no default allowed)
	EJETOPTNS(3)	period of variation in minutes, must be >0 (alias is ejet_period_min) (no default allowed)
	EJETOPTNS(4)	height of current in km, must be >0 (alias is ejet_height_km) (no default allowed)
	EJETOPTNS(5)	latitude of center of electrojet in degrees (alias is ejet_center_deg) (no default allowed)
Character*260	FILEOPTNS (5)	array of 5 elements specifying File Used(input).
	FILEOPTNS(1)	GIC updates to Base Case file name (output). (alias is addfile) (blank by default)
	FILEOPTNS(1) = ''	no file created
	FILEOPTNS(2)	RDCH file to remove GIC updates from GIC updated case in working memory to set it back to Base Case network condition (output). (alias is purgfile) (blank by default)
	FILEOPTNS(2) = ''	no file created
	FILEOPTNS(3)	GIC dc resistive network raw file. This represents the dc network used to calculate GIC flow (output). (alias is rnwkfile) (blank by default)
	FILEOPTNS(3) = ''	no file created
	FILEOPTNS(4)	GIC Results map data file for given Efield magnitude and degrees OR Efield magnitude and degrees scans which give maximum Var losses when scans are performed (output). This is used by GICMAPS to plot GIC results

	on network map. (alias is pygicfile) (nooutput by default)
FILEOPTNS(4) = ''	temporary file created
FILEOPTNS(4) = nooutput	no file created
FILEOPTNS(5)	Transformer Thermal Analysis GIC(t) CSV file (output). (alias is gictfile) (nooutput by default)
FILEOPTNS(5) = ''	temporary file created
FILEOPTNS(5) = nooutput	no file created
Integer RPTOPTNS (8)	array of 8 elements specifying Report Options(input).
RPTOPTNS(1)	what to report (alias is rptoptn) (-1 by default)
RPTOPTNS(1) = -1	report all
RPTOPTNS(1) = 0	no report
RPTOPTNS(1) > 0	Report these many maximum values in each category
RPTOPTNS(2)	report induced branch voltages (alias is rptbrn_indv) (0 by default)
RPTOPTNS(2) = 0	No
RPTOPTNS(2) = 1	Yes
RPTOPTNS(3)	report DC bus voltages (alias is rptdc_busv) (0 by default)
RPTOPTNS(3) = 0	No
RPTOPTNS(3) = 1	Yes
RPTOPTNS(4)	report branch GIC flows (alias is rptbrn_gic) (0 by default)
RPTOPTNS(4) = 0	No
RPTOPTNS(4) = 1	Yes
RPTOPTNS(5)	report transformer GIC flows (alias is rpttrn_gic) (1 by default)
RPTOPTNS(5) = 0	No
RPTOPTNS(5) = 1	Yes
RPTOPTNS(6)	report substation GIC flows (alias is rptstn_gic) (0 by default)
RPTOPTNS(6) = 0	No
RPTOPTNS(6) = 1	Yes
RPTOPTNS(7)	report transformer losses (alias is rpttrn_q) (1 by default)
RPTOPTNS(7) = 0	No
RPTOPTNS(7) = 1	Yes
RPTOPTNS(8)	Subsystem sid for report (alias is rpt_sid) (0 by default)
RPTOPTNS(8) = 0	Use study subsystem as report subsystem

	RPTOPTNS(8) = 1	Subsystem number (1 - 11). GIC report created for buses and branches in this subsystem.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	Invalid SID value or subsystem SID is not defined
	IERR = 2	Invalid ALL value
	IERR = 3	Topology error, bus type code and series element status inconsistencies
	IERR = 4	Invalid INTGOPTNS value, set to default
	IERR = 5	Invalid REALOPTNS value, no default allowed
	IERR = 6	Invalid REALOPTNS value, set to default
	IERR = 7	Invalid RPTOPTNS value, set to default value
	IERR = 8	Electric Field Value must be greater than 0.0
	IERR = 9	Error opening GIC File
	IERR = 10	Error opening GIC ADD File
	IERR = 11	Error opening GIC PURG File
	IERR = 12	Error opening GIC DC NETWORK File
	IERR = 13	No substation data provided
	IERR = 14	No substation data specified for following GIC study subsystem buses
	IERR = 15	No buses in GIC study subsystem
	IERR = 16	No GIC data input file provided
	IERR = 17	No non-transformer branches in working case
	IERR = 18	No non-transformer branches in GIC study subsystem
	IERR = 19	Prerequisite requirements for API are not met
	IERR = 20	Invalid localized GMD hot spots subsystem SID
	IERR = 21	No buses in local GMD hot spots subsystem
	IERR = 22	Invalid CHAROPTNS value, set to default
	IERR = 23	Invalid EJETOPTNS value
	IERR = 24	Benchmark Event default GMD strength different than standard strength
	IERR = 25	Invalid REALOPTNS value, set to default value
	IERR = 26	Transformer T model GIC data: WRI, WRJ and WRK dc resistances must be specified for T model
	IERR = 27	Info - The Geographic Coordinates of the magnetic dipole axis for study year %% are not defined, used data from year %%
	IERR = 28	gic.dll not loaded or entry point not found
	IERR = 29	Error - All transformers must have vector group specified

IERR = 30	Invalid Magnitude Scan maximum storm strength
IERR = 31	Error - No substations exist in specified moving box
IERR = 32	Error - Specified moving box center substation does not exist in the case
IERR = 33	Error - No Geoelectric Efield Grid Data provided

6.1.9. GIC_BRANCH_EFIELD_NN

Use this API to calculate geoelectric efield induced in the network branches from specified geoelectric efield grid data using nearest neighbor (NN) algorithm.

This API routine was first introduced in release 4.8.0 and 35.1.0.

Batch command syntax:

```
BAT_GIC_BRANCH_EFIELD_NN SID ALL INTGOPTNS(1)..INTGOPTNS(3)
REALOPTNS(1)..REALOPTNS(2)
```

Python command syntax:

```
ierr = gic_branch_efield_nn(sid, all, intgoptns, realoptns)
```

Fortran command syntax:

```
CALL GIC_BRANCH_EFIELD_NN(SID, ALL, INTGOPTNS, REALOPTNS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID.
	ALL = 1	process all buses.
Integer INTGOPTNS (4)	array of 4 elements specifying Integer Options(input).	
	INTGOPTNS(1)	Number of levels of inter-tie buses to add to study subsystem (alias is tielevels) (0 by default)
	INTGOPTNS(1) = 0	consider only study subsystem buses, no buses from inter-ties
	INTGOPTNS(1) > 0	1 through 5, consider study subsystem buses + these many levels of inter-tie buses and ignore subsystem definition voltage limits for intertie buses added
	INTGOPTNS(1) < 0	-1 through -5, consider study subsystem buses + these many levels of inter-tie buses and consider subsystem definition voltage limits for intertie buses added
	INTGOPTNS(2)	Flag to do branch route segment scan to find efield grid index same as previous route point efield grid index (alias is brn_segscan) (1 by default)
	INTGOPTNS(2) = 0	no branch segment scan, efield grid index at each segment point is used to get segment induced voltage
	INTGOPTNS(2) = 1	perform branch segment scan

	INTGOPTNS(3)	Flag to merge branch route segments with same efield grid index. This only affects how the branch route induced voltage is reported. (alias is brn_segmerge) (1 by default)
	INTGOPTNS(3) = 0	do not merge segments
	INTGOPTNS(3) = 1	merge segments
	INTGOPTNS(4)	Report Option (alias is rptoptn) (1 by default)
	INTGOPTNS(4) = 0	no report
	INTGOPTNS(4) = 1	summary report
	INTGOPTNS(4) = 2	detailed report
	INTGOPTNS(4) = 3	both summary and detailed reports
Real REALOPTNS (2)	array of 2 elements specifying Real Options(input).	
	REALOPTNS(1)	Branch segment length in km, used to calculate branch induced voltage from Efield Grid, must be >0.0. Branch is subdivided into number of segments (points along the branch route) and NN algorithm finds nearest geoelectric efield grid data point to arrive efield at that branch route point. (alias is brn_segkm) (5.0 by default)
	REALOPTNS(1) = 0.0	Use default
	REALOPTNS(1) > 0	Use specified
	REALOPTNS(2)	Branch subsegment length in km, used to calculate branch induced voltage from Efield Grid, range 0.02 to 1.0 km. When efield value at branch route point changes, that branch segment is further subdivided into smaller segments to arrive at branch route point where NN efield change occurs. (alias is brn_subsegkm) (0.1 by default)
	REALOPTNS(2) = 0.0	Use default
	REALOPTNS(2) > 0	Use specified
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	Invalid SID value or subsystem SID is not defined
	IERR = 2	Invalid ALL value
	IERR = 3	Invalid INTGOPTNS value, set to default
	IERR = 4	Invalid REALOPTNS value, set to default
	IERR = 5	Topology error, bus type code and series element status inconsistencies
	IERR = 6	No Efield Grid Data provided'
	IERR = 7	No substations in the working case (or added from GIC data)
	IERR = 8	No buses in GIC study subsystem

6.1.10. GIC_EARTH1D_USR_PURG

Use this API to purge GIC User 1D Earth Model data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_EARTH1D_USR_PURG NAME
```

Python command syntax:

```
ierr = gic_earth1d_usr_purg(name)
```

Fortran command syntax:

```
CALL GIC_EARTH1D_USR_PURG(NAME, IERR)
```

Where:

Character*32 NAME	1D Earth Model name. The non-blank alphanumeric identifier assigned to earth model. The name should be unique and different than standard earth model names defined in TPL-007. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.1.11. GIC_EFIELD_WAVESHAPE

For Transformer Thermal Impact assesement due to geomagnetic disturbance event, set the geoelectric field waveshape as provided in EFLDFILE.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_GIC_EFIELD_WAVESHAPE EFLDFILE
```

Python command syntax:

```
ierr = gic_efield_waveshape(efldfile)
```

Fortran command syntax:

```
CALL GIC_EFIELD_WAVESHAPE(EFLDFILE, IERR)
```

Where:

Character*260 EFLDFILE	name of the Geoelectric Field Waveshape data points file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 1	Prerequisite requirements for API are not met, GIC(t) calculations not done
	IERR = 2	Error opening GIC Electric Field Waveshape Data file, GIC(t) calculations not done
	IERR = 3	Error reading GIC Electric Field Waveshape Data file, GIC(t) calculations not done

6.1.12. GIC_EFIELD_WAVESHAPE_REF

For Transformer Thermal Impact assesement due to geomagnetic disturbance event, set the geoelectric field waveshape as NERC TPL-007-2 benhcmark event.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_GIC_EFIELD_WAVESHAPE_REF
```

Python command syntax:

```
ierr = gic_efield_waveshape_ref()
```

Fortran command syntax:

```
CALL GIC_EFIELD_WAVESHAPE_REF(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	DLL not loaded or entry point not found.

6.1.13. GIC_EFIELD_WAVESHAPE_SUPP

For Transformer Thermal Impact assesement due to geomagnetic disturbance event, set the geoelectric field waveshape as NERC TPL-007-2 supplemental event.

This API routine was first introduced in release 33.12.0 and 34.4.0.

Batch command syntax:

```
BAT_GIC_EFIELD_WAVESHAPE_SUPP
```

Python command syntax:

```
ierr = gic_efield_waveshape_supp()
```

Fortran command syntax:

```
CALL GIC_EFIELD_WAVESHAPE_SUPP(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	DLL not loaded or entry point not found.

6.1.14. GIC_MVARLOSS_SCALING_FACTORS

Specify KFACTORS to determine transformer reactive power losses due to geomagnetic currents (GICs) flow.

This API routine was first introduced in release 32.2.1.

Batch command syntax:

```
BAT_GIC_MVARLOSS_SCALING_FACTORS KFACTORS(1) . . KFACTORS(9)
```

Python command syntax:

```
ierr = gic_mvarloss_scaling_factors(kfactors)
```

Fortran command syntax:

```
CALL GIC_MVARLOSS_SCALING_FACTORS(KFACTORS, IERR)
```

Where:

Real KFACTORS (9)	array of elements specifying Kfactor values. The values are as follows.(input).	
	KFACTORS(1)	Voltage level at which these kfactors are specified
	KFACTORS(2)	kfactor value for Shell form transformers
	KFACTORS(3)	kfactor value for core design - Single Phase (three separate cores) transformers
	KFACTORS(4)	kfactor value for core design - Three Phase 3 legged core form transformers
	KFACTORS(5)	kfactor value for core design - Three Phase 5 legged core form transformers
	KFACTORS(6)	kfactor value for core design - Three Phase 7 legged core form transformers
	KFACTORS(7)	kfactor value for unknown core, voltage level of <=200 kV
	KFACTORS(8)	kfactor value for unknown core, voltage level of <200 kV and <=400 kV
	KFACTORS(9)	kfactor value for unknown core, voltage level of >400 kV
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	DLL not loaded or entry point not found.

6.1.15. GIC_NEW

Use this API to initialize all data records required for GIC analysis. It must be called prior to introducing any GIC data records. It has no effect if GIC data already exists in the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_NEW
```

Python command syntax:

```
ierr = gic_new()
```

Fortran command syntax:

```
CALL GIC_NEW(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met
	IERR = 2	error initializing GIC data

6.1.16. GIC_PF_OPTIONS

Use this API to specify the Newton-Raphson power flow solution options used in GIC.

This API routine was first introduced in release 34.5.0.

Batch command syntax:

```
BAT_GIC_PF_OPTIONS  OPTIONS(1) .. OPTIONS(8)
```

Python command syntax:

```
ierr = gic_pf_options(options)
```

Fortran command syntax:

```
CALL GIC_PF_OPTIONS(OPTIONS, IERR)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying Newton-Raphson power flow solution options(input).	
	OPTIONS(1)	tap adjustment flag (use tap adjustment option setting by default)
	OPTIONS(1) = 0	disable
	OPTIONS(1) = 1	enable stepping adjustment
	OPTIONS(1) = 2	enable direct adjustment
	OPTIONS(2)	area interchange adjustment flag (use area interchange adjustment option setting by default)
	OPTIONS(2) = 0	disable
	OPTIONS(2) = 1	enable using tie line flows only in calculating area interchange
	OPTIONS(2) = 2	enable using tie line flows and loads in calculating area interchange
	OPTIONS(3)	phase shift adjustment flag (use phase shift adjustment option setting by default)
	OPTIONS(3) = 0	disable
	OPTIONS(3) = 1	enable
	OPTIONS(4)	dc tap adjustment flag (use dc tap adjustment option setting by default)
	OPTIONS(4) = 0	disable
	OPTIONS(4) = 1	enable
	OPTIONS(5)	switched shunt adjustment flag (use switched shunt adjustment option setting by default)
	OPTIONS(5) = 0	disable
	OPTIONS(5) = 1	enable
	OPTIONS(5) = 2	enable continuous mode, disable discrete mode

	OPTIONS(6)	flat start flag (0 by default)
	OPTIONS(6) = 0	do not flat start
	OPTIONS(6) = 1	flat start
	OPTIONS(6) = 2	flat start, then estimate voltage magnitudes
	OPTIONS(6) = 3	flat start, then estimate voltage phase angles
	OPTIONS(6) = 4	flat start, then estimate voltage magnitudes and phase angles
	OPTIONS(7)	var limit flag (99 by default)
	OPTIONS(7) = 0	apply var limits immediately
	OPTIONS(7) > 0	apply var limits on iteration n (or sooner if mismatch gets small)
	OPTIONS(7) = -1	ignore var limits
	OPTIONS(8)	non-divergent solution flag (use non-divergent solution option setting by default)
	OPTIONS(8) = 0	disable
	OPTIONS(8) = 1	enable
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid OPTIONS value
	IERR = 2	prerequisite requirements for API are not met

6.1.17. GIC_PURG

Use this API to purge all GIC data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_PURG
```

Python command syntax:

```
ierr = gic_purg()
```

Fortran command syntax:

```
CALL GIC_PURG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

6.1.18. GIC_READ

Use this API to read GIC Data Text (.gic) File into the working case memory.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_READ RFILE
```

Python command syntax:

```
ierr = gic_read(rfile)
```

Fortran command syntax:

```
CALL GIC_READ(RFILE, IERR)
```

Where:

Character*260 RFILE	GIC Data File name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	error opening file
	IERR = 2	prerequisite requirements for API are not met

6.1.19. GIC_READ_EFIELD_GRID

Use this API to read Geoelectric Efield Grid Data File into the working case memory.

This API routine was first introduced in release 34.8.0 and 35.1.0.

Batch command syntax:

```
BAT_GIC_READ_EFIELD_GRID FTYPE, FNAME
```

Python command syntax:

```
ierr = gic_read_efield_grid(ftyp, fnam)
```

Fortran command syntax:

```
CALL GIC_READ_EFIELD_GRID(FTYP, FNAME, IERR)
```

Where:

Integer FTYPE	File format type (input; 0 by default).
	FTYPE = 0 csv format, column order: latitude (deg), longitude (deg), Ee (V/km), En (V/km)
	FTYPE = 1 USGS json format [coordinates [lon, lat] in deg, Ex(=En) and Ey(=Ee) in mV/km
Character*260 FNAME	Efield Grid Data File name (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 prerequisite requirements for API are not met
	IERR = 2 error opening Efield Grid data file
	IERR = 3 error reading Efield Grid data file

6.1.20. GIC_THERMAL_IMPACT

This API routine is obsolete. It has been replaced by the API routine [gic_thermal_impact_1](#).

Use this API to calculate Transformer Thermal Impact assesement GIC(t) curve using specified effective Eastward GIC(E) and Nortward GIC(N) for one specific transformer. The geoelectric field waveshape used could be NERC TPL-007-2 Benchmark event, NERC TPL-007-2 Supplemental event or User specified event.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_GIC_THERMAL_IMPACT GICEARG, GICNARG, XMERLBL, GICTFARG
```

Python command syntax:

```
ierr = gic_thermal_impact(gicearg, gicnarg, xmerlbl, gictfarg)
```

Fortran command syntax:

```
CALL GIC_THERMAL_IMPACT(GICEARG, GICNARG, XMERLBL, GICTFARG, IERR)
```

Where:

Real GICEARG	Transfomer effective per phase GIC due to Eastward geoelectric field, GIC(E) due to $E_e=1$ V/km and $E_n=0$, with alpha and beta factors applied (input; 0 by default).	
Real GICNARG	Transfomer effective per phase GIC due to Northward geoelectric field, GIC(N) due to $E_n=1$ V/km and $E_e=0$, with alpha and beta factors applied (input; 0 by default).	
Character*40 XMERLBL	Transformer Name (input; " by default).	
Character*260 GICTFARG	Transformer Thermal Analysis GIC(t) CSV file (output) (input; " by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	No or invalid GICEARG value provided
	IERR = 1	No or invalid GICNARG value provided
	IERR = 3	No GMD Event $EE(t)$ and $EN(t)$ data available
	IERR = 4	Error opening GIC(t) File

6.1.21. GIC_THERMAL_IMPACT_1

Use this API to calculate Transformer Thermal Impact assesement GIC(t) curve using specified effective Eastward GIC(E) and Nortward GIC(N) for one specific transformer. The geoelectric field waveshape used could be NERC TPL-007 Benchmark event, NERC TPL-007 Supplemental event or User specified event.

This API routine was first introduced in release 34.8.0 and 35.1.0.

Batch command syntax:

```
BAT_GIC_THERMAL_IMPACT_1 GICEARG, GICNARG, XMERLBL, GICTFARG IEVT
```

Python command syntax:

```
ierr = gic_thermal_impact_1(gicearg, gicnarg, xmerlbl, gictfarg, ievt)
```

Fortran command syntax:

```
CALL GIC_THERMAL_IMPACT_1(GICEARG, GICNARG, XMERLBL, GICTFARG, IEVT, IERR)
```

Where:

Real GICEARG	Transformer effective per phase GIC due to Eastward geoelectric field, GIC(E) due to $E_e=1$ V/km and $E_n=0$, with alpha and beta factors applied (input; 0 by default).
Real GICNARG	Transformer effective per phase GIC due to Northward geoelectric field, GIC(N) due to $E_n=1$ V/km and $E_e=0$, with alpha and beta factors applied (input; 0 by default).
Character*40 XMERLBL	Transformer Name (input; " by default).
Character*260 GICTFARG	Transformer Thermal Analysis GIC(t) CSV file (output) (input; " by default).
Integer IEVT	GMD Event Type (input; 0 by default). IEVT = 0 TPL-007 Benchmark or User Specified Reference GMD Event IEVT = 1 TPL-007 Supplemental GMD Event
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 No or invalid GICEARG value provided IERR = 1 No or invalid GICNARG value provided IERR = 3 No GMD Event EE(t) and EN(t) data available IERR = 4 Error opening GIC(t) File IERR = 5 No or invalid IEVT value provided

6.1.22. GIC_WRITE

Use this API to write working case GIC Data to text (.gic) file.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_WRITE RFILE
```

Python command syntax:

```
ierr = gic_write(rfile)
```

Fortran command syntax:

```
CALL GIC_WRITE(RFILE, IERR)
```

Where:

Character*260 RFILE	GIC Data File name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	error opening file
	IERR = 2	prerequisite requirements for API are not met

6.1.23. GIC_WRITE_STN

Use this API to write working case GIC Data to text (.gic) file version 4 that has substation data.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_GIC_WRITE_STN RFILE
```

Python command syntax:

```
ierr = gic_write_stn(rfile)
```

Fortran command syntax:

```
CALL GIC_WRITE_STN(RFILE, IERR)
```

Where:

Character*260 RFILE	GIC Data File name (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	error opening file
	IERR = 2	prerequisite requirements for API are not met

GIC Operation APIs contains API routines corresponding to the operational functions of the GIC features of PSS®E.

6.2. GIC Data

6.2.1. GIC_2TDC

Use this API to modify or add new two terminal dc GIC shunt data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_2TDC NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_2tdc(name,bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_2TDC(NAME, BUS, CKT, REALAR, IERR)
```

Where:

Character*12 NAME	DC line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, two terminal dc shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, two terminal dc is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.2. GIC_2TDC_CHNG

Use this API to modify new two terminal dc GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_2TDC_CHNG NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_2tdc_chng(name,bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_2TDC_CHNG(NAME,BUS,CKT,REALAR,IERR)
```

Where:

Character*12 NAME	DC line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, two terminal dc shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, two terminal dc is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.3. GIC_2TDC_PURG

Use this API to purge new two terminal dc GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_2TDC_PURG NAME BUS CKT
```

Python command syntax:

```
ierr = gic_2tdc_purg(name, bus, ckt)
```

Fortran command syntax:

```
CALL GIC_2TDC_PURG(NAME, BUS, CKT, IERR)
```

Where:

Character*12 NAME	DC line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.4. GIC_BRN

Use this API to modify or add new GIC branch data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_BRN IBUS JBUS CKT REALAR(1)..REALAR(5)
```

Python command syntax:

```
ierr = gic_brn(ibus,jbus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_BRN( IBUS, JBUS, CKT, REALAR, IERR)
```

Where:

Integer IBUS	From bus number of the branch as in the working case. (input; no default allowed).
Integer JBUS	To bus number of the branch as in the working case. (input; no default allowed).
Character*2 CKT	branch circuit identifier (input; '1' by default).
Real REALAR (5)	array of 5 elements specifying (input).
	REALAR(1) DC resistance of the branch in ohms/phase. When RBRN is not specified, working case resistance is used to determine RBRN. (alias is rbrn) (0.0 by default)
	REALAR(2) Real part of total branch GMD-induced geoelectric field in volts. When INDVP is not specified, it is calculated as per GMD event. (alias is indvp) (no default allowed)
	REALAR(3) Imaginary part of total branch GMD-induced geoelectric field in volts. When INDVP is not specified, it is calculated as per GMD event. (alias is indvq) (no default allowed)
	REALAR(4) DC resistance in ohms/phase of the line shunt at bus IBUS end of the branch. When RLNSHI=0.0 or not specified, there is no ground path this line shunt in DC network. (alias is rlnsi) (0.0 by default)
	REALAR(5) DC resistance in ohms/phase of the line shunt at bus JBUS end of the branch. When RLNSHJ=0.0 or not specified, there is no ground path this line shunt in DC network. (alias is rlnsj) (0.0 by default)
Integer IERR	error code (output).
	IERR = 0 no errors occurred

IERR = 1

prerequisite requirements for API are not met

6.2.5. GIC_BRN_CHNG

Use this API to modify new GIC branch data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_BRN_CHNG IBUS JBUS CKT REALAR(1)..REALAR(5)
```

Python command syntax:

```
ierr = gic_brn_chng(ibus,jbus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_BRN_CHNG( IBUS, JBUS, CKT, REALAR, IERR)
```

Where:

Integer IBUS	From bus number of the branch as in the working case. (input; no default allowed).	
Integer JBUS	To bus number of the branch as in the working case. (input; no default allowed).	
Character*2 CKT	branch circuit identifier (input; '1' by default).	
Real REALAR (5)	array of 5 elements specifying (input).	
	REALAR(1)	DC resistance of the branch in ohms/phase. When RBRN is not specified, working case resistance is used to determine RBRN. (alias is rbrn) (0.0 by default)
	REALAR(2)	Real part of total branch GMD-induced geoelectric field in volts. When INDVP is not specified, it is calculated as per GMD event. (alias is indvp) (no default allowed)
	REALAR(3)	Imaginary part of total branch GMD-induced geoelectric field in volts. When INDVP is not specified, it is calculated as per GMD event. (alias is indvq) (no default allowed)
	REALAR(4)	DC resistance in ohms/phase of the line shunt at bus IBUS end of the branch. When RLNSHI=0.0 or not specified, there is no ground path this line shunt in DC network. (alias is rlnsi) (0.0 by default)
	REALAR(5)	DC resistance in ohms/phase of the line shunt at bus JBUS end of the branch. When RLNSHJ=0.0 or not specified, there is no ground path this line shunt in DC network. (alias is rlnsj) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred

IERR = 1

prerequisite requirements for API are not met

6.2.6. GIC_BRN_PURG

Use this API to purge GIC branch data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_BRN_PURG IBUS JBUS CKT
```

Python command syntax:

```
ierr = gic_brn_purg(ibus,jbus,ckt)
```

Fortran command syntax:

```
CALL GIC_BRN_PURG( IBUS, JBUS, CKT, IERR)
```

Where:

Integer IBUS	From bus number of the branch as in the working case. (input; no default allowed).	
Integer JBUS	To bus number of the branch as in the working case. (input; no default allowed).	
Character*2 CKT	branch circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.7. GIC_EARTH1D_USR

Use this API to modify or add new GIC User 1D Earth Model data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_EARTH1D_USR NAME DESC REALAR(1) REALAR(2) LAYERS RHO(1)..RHO(N)
  THICKNESS(1)..THICKNESS(N)
```

Python command syntax:

```
ierr = gic_earth1d_usr(name, desc, realar, layers, rho, thickness)
```

Fortran command syntax:

```
CALL GIC_EARTH1D_USR(NAME, DESC, REALAR, LAYERS, RHO, THICKNESS, IERR)
```

Where:

Character*32 NAME	1D Earth Model name. The non-blank alphanumeric identifier assigned to earth model. The name should be unique and different than standard earth model names defined in TPL-007. (input; no default allowed).
Character*32 DESC	Earth Model description. It is used for information purpose only.. (input; blank).
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) Benchmark event scaling factor (alias is beta) (1.0 by default) REALAR(2) Supplemental event scaling factor (alias is betas) (1.0 by default)
Integer LAYERS	number of layers of earth model rho and thickness (input; no default allowed).
Real RHO (layers)	array of 'layers' values specifying earth model layer resistivity in ohm-m. All values must be > 0. (input; no default allowed).
Real THICKNESS (layers)	array of 'layers' values specifying earth model layer thickness in km. All values must be > 0 except last layer. The last layer thickness is infinity, specified as any number < 0. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

6.2.8. GIC_EARTH1D_USR_CHNG

Use this API to modify GIC User 1D Earth Model data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_EARTH1D_USR_CHNG NAME DESC REALAR(1) REALAR(2) LAYERS
    RHO(1) .. RHO(N) THICKNESS(1) .. THICKNESS(N)
```

Python command syntax:

```
ierr = gic_earth1d_usr_chng(name, desc, realar, layers, rho, thickness)
```

Fortran command syntax:

```
CALL GIC_EARTH1D_USR_CHNG(NAME, DESC, REALAR, LAYERS, RHO, THICKNESS, IERR)
```

Where:

Character*32 NAME	1D Earth Model name. The non-blank alphanumeric identifier assigned to earth model. The name should be unique and different than standard earth model names defined in TPL-007. (input; no default allowed).
Character*32 DESC	Earth Model description. It is used for information purpose only.. (input; blank).
Real REALAR (2)	array of 2 elements specifying (input). REALAR(1) Benchmark event scaling factor (alias is beta) (1.0 by default) REALAR(2) Supplemental event scaling factor (alias is betas) (1.0 by default)
Integer LAYERS	number of layers of earth model rho and thickness (input; no default allowed).
Real RHO (layers)	array of 'layers' values specifying earth model layer resistivity in ohm-m. All values must be > 0. (input; no default allowed).
Real THICKNESS (layers)	array of 'layers' values specifying earth model layer thickness in km. All values must be > 0 except last layer. The last layer thickness is infinity, specified as any number < 0. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no errors occurred IERR = 1 prerequisite requirements for API are not met

6.2.9. GIC_FACTS

Use this API to modify or add new FACTS device GIC shunt data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_FACTS NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_facts(name,bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_FACTS(NAME,BUS,CKT,REALAR,IERR)
```

Where:

Character*12 NAME	FACTS device name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, FACTS device shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, FACTS device is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.10. GIC_FACTS_CHNG

Use this API to modify new FACTS device GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_FACTS_CHNG NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_facts_chng(name, bus, ckt, realar)
```

Fortran command syntax:

```
CALL GIC_FACTS_CHNG(NAME, BUS, CKT, REALAR, IERR)
```

Where:

Character*12 NAME	FACTS device name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, FACTS device shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, FACTS device is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.11. GIC_FACTS_PURG

Use this API to purge new FACTS device GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_FACTS_PURG NAME BUS CKT
```

Python command syntax:

```
ierr = gic_facts_purg(name, bus, ckt)
```

Fortran command syntax:

```
CALL GIC_FACTS_PURG(NAME, BUS, CKT, IERR)
```

Where:

Character*12 NAME	FACTS device name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.12. GIC_FXSH

Use this API to modify or add new fixed shunt GIC shunt data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_FXSH BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_fxsh(bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_FXSH(BUS,CKT,REALAR,IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, fixed shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, fixed shunt is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.13. GIC_FXSH_CHNG

Use this API to modify fixed shunt GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_FXSH_CHNG BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_fxsh_chng(bus, ckt, realar)
```

Fortran command syntax:

```
CALL GIC_FXSH_CHNG(BUS, CKT, REALAR, IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, fixed shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, fixed shunt is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.14. GIC_FXSH_PURG

Use this API to purge fixed shunt GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_FXSH_PURG BUS CKT
```

Python command syntax:

```
ierr = gic_fxsh_purg(bus, ckt)
```

Fortran command syntax:

```
CALL GIC_FXSH_PURG(BUS, CKT, IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.15. GIC_LOAD

Use this API to modify or add new load GIC shunt data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_LOAD BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_load(bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_LOAD(BUS,CKT,REALAR,IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, fixed shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, fixed shunt is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.16. GIC_LOAD_CHNG

Use this API to modify load GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_LOAD_CHNG BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_load_chng(bus, ckt, realar)
```

Fortran command syntax:

```
CALL GIC_LOAD_CHNG(BUS, CKT, REALAR, IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, fixed shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, fixed shunt is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.17. GIC_LOAD_PURG

Use this API to purge load GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_LOAD_PURG BUS CKT
```

Python command syntax:

```
ierr = gic_load_purg(bus, ckt)
```

Fortran command syntax:

```
CALL GIC_LOAD_PURG(BUS, CKT, IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.18. GIC_MTDC

Use this API to modify or add new multi terminal dc GIC shunt data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_MTDC NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_mtdc(name,bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_MTDC(NAME,BUS,CKT,REALAR,IERR)
```

Where:

Character*12 NAME	mtdc line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, multi terminal dc shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, multi terminal dc is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.19. GIC_MTDC_CHNG

Use this API to modify new multi terminal dc GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_MTDC_CHNG NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_mtdc_chng(name,bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_MTDC_CHNG(NAME,BUS,CKT,REALAR,IERR)
```

Where:

Character*12 NAME	mtdc line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, multi terminal dc shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, multi terminal dc is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.20. GIC_MTDC_PURG

Use this API to purge new multi terminal dc GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_MTDC_PURG NAME BUS CKT
```

Python command syntax:

```
ierr = gic_mtdc_purg(name,bus,ckt)
```

Fortran command syntax:

```
CALL GIC_MTDC_PURG(NAME,BUS,CKT,IERR)
```

Where:

Character*12 NAME	mtdc line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.21. GIC_SUBSTN

Use this API to modify or add new GIC sub station data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_SUBSTN SUBNUM REALAR(1) CHARAR(1) EARTHMDL
```

Python command syntax:

```
ierr = gic_substn(subnum, realar, charar, earthmdl)
```

Fortran command syntax:

```
CALL GIC_SUBSTN(SUBNUM, REALAR, CHARAR, EARTHMDL, IERR)
```

Where:

Integer SUBNUM	sub station number (input; no default allowed).	
Real REALAR (1)	array of 1 elements specifying (input).	
	REALAR(1)	Substation grounding DC resistance in ohms. For ungrounded substation RG <=0 or RG >=99 (alias is rg) (0.1 by default)
Character*40 CHARAR (1)	array of 1 elements specifying (input).	
	CHARAR(1)	Method used to specify RG value, RGFLAG may be up to 40 characters. It is used for informational purposes only. (alias is rgflag)
Character*32 EARTHMDL	sub station earth conductivity model name (input; " by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.22. GIC_SUBSTN_CHNG

Use this API to modify GIC sub station data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_SUBSTN_CHNG SUBNUM REALAR(1) CHARAR(1) EARTHMDL
```

Python command syntax:

```
ierr = gic_substn_chng(subnum, realar, charar, earthmdl)
```

Fortran command syntax:

```
CALL GIC_SUBSTN_CHNG(SUBNUM, REALAR, CHARAR, EARTHMDL, IERR)
```

Where:

Integer SUBNUM	sub station number (input; no default allowed).	
Real REALAR (1)	array of 1 elements specifying (input).	
	REALAR(1)	Substation grounding DC resistance in ohms. For ungrounded substation RG <=0 or RG >=99 (alias is rg) (0.1 by default)
Character*40 CHARAR (1)	array of 1 elements specifying (input).	
	CHARAR(1)	Method used to specify RG value, RGFLAG may be up to 40 characters. It is used for informational purposes only. (alias is rgflag)
Character*32 EARTHMDL	sub station earth conductivity model name (input; " by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.23. GIC_SUBSTN_PURG

Use this API to purge GIC sub station data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_SUBSTN_PURG SUBNUM
```

Python command syntax:

```
ierr = gic_substn_purg(subnum)
```

Fortran command syntax:

```
CALL GIC_SUBSTN_PURG(SUBNUM, IERR)
```

Where:

Integer SUBNUM	sub station number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.24. GIC_SWSH

Use this API to modify or add new GIC switched shunt data to the working case. Use this when switched shunt is described by the bus number and its circuit identifier.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_SWSH BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_swsh(bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_SWSH(BUS,CKT,REALAR,IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, switched shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, switched shunt is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.25. GIC_SWSH_CHNG

Use this API to modify GIC switched shunt data from the working case. Use this when switched shunt is described by the bus number and its circuit identifier.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_SWSH_CHNG BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_swsh_chng(bus, ckt, realar)
```

Fortran command syntax:

```
CALL GIC_SWSH_CHNG(BUS, CKT, REALAR, IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, switched shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, switched shunt is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.26. GIC_SWSH_PURG

Use this API to purge GIC switched shunt data from the working case. Use this when switched shunt is described by the bus number and its circuit identifier.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_SWSH_PURG BUS CKT
```

Python command syntax:

```
ierr = gic_swsh_purg(bus, ckt)
```

Fortran command syntax:

```
CALL GIC_SWSH_PURG(BUS, CKT, IERR)
```

Where:

Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.27. GIC_TRN

Use this API to modify or add new GIC transformer data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_TRN IBUS JBUS KBUS CKT INTGAR(1)..INTGAR(5) REALAR(1)..REALAR(7)
VECGRP
```

Python command syntax:

```
ierr = gic_trn(ibus, jbus, kbus, ckt, intgar, realar, vecgrp)
```

Fortran command syntax:

```
CALL GIC_TRN( IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, VECGRP, IERR)
```

Where:

Integer IBUS	The bus number of the bus to which Winding 1 is connected. It must be same Winding 1 bus of the same transformer in the working case. (input; no default allowed).
Integer JBUS	The bus number of the bus to which Winding 2 is connected. It must be same Winding 2 bus of the same transformer in the working case. (input; no default allowed).
Integer KBUS	The bus number of the bus to which Winding 3 is connected. It must be same Winding 3 bus of the same transformer in the working case. KBUS=0 for two winding transformers. No default allowed for three winding transformers. (input; 0 by default).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (5)	array of 5 elements specifying (input).
	INTGAR(1) GIC blocking device in neutral of Winding 1. For an auto-transformers, if either BDI=1 or BDJ=1, that auto-transformer is treated as if it has GIC blocking device present. (alias is bdi) (0 by default)
	INTGAR(1) = 0 no GIC blocking device present
	INTGAR(1) = 1 GIC blocking device present
	INTGAR(2) GIC blocking device in neutral of Winding 2. For an auto-transformers, if either BDI=1 or BDJ=1, that auto-transformer is treated as if it has GIC blocking device present. (alias is bdj) (0 by default)
	INTGAR(2) = 0 no GIC blocking device present
	INTGAR(2) = 1 GIC blocking device present
	INTGAR(3) GIC blocking device in neutral of Winding 3. (alias is bdk) (0 by default)
	INTGAR(3) = 0 no GIC blocking device present
	INTGAR(3) = 1 GIC blocking device present

	INTGAR(4)	Number of cores in transformer core design. This information is used to calculate transformer reactive power loss from GIC flowing its winding. (alias is core) (0 by default)
	INTGAR(4) = -1	three phase shell form
	INTGAR(4) = 0	unknown core design
	INTGAR(4) = 1	single phase core
	INTGAR(4) = 3	three phase 3-legged core form
	INTGAR(4) = 5	three phase 5-legged core form
	INTGAR(5)	Model transformer as T-model in GIC DC Network (alias is tmodel) (0 by default)
	INTGAR(5) = 0	two/three/auto transformer model as defined by its vector group
	INTGAR(5) = 1	transformer as T-model in DC network
Real REALAR (7)	array of 7 elements specifying (input).	
	REALAR(1)	DC resistance of Winding 1 in ohms/phase. When WRI is not specified, working case resistance is used to determine WRI. (alias is wri) (0.0 by default)
	REALAR(2)	DC resistance of Winding 2 in ohms/phase. When WRJ is not specified, working case resistance is used to determine WRJ. (alias is wrj) (0.0 by default)
	REALAR(3)	DC resistance of Winding 2 in ohms/phase. When WRK is not specified, working case resistance is used to determine WRK. (alias is wrk) (0.0 by default)
	REALAR(4)	Factor to calculate transformer reactive power loss from the GIC flow in its winding (MVAR/AMP) (alias is kfactor) (0.0 by default)
	REALAR(5)	Winding 1 grounding DC resistance in ohms. When GRDWRI=0.0, there is no grounding resistance and winding is solidly grounded. (alias is grdwri) (0.0 by default)
	REALAR(6)	Winding 2 grounding DC resistance in ohms. When GRDWRJ=0.0, there is no grounding resistance and winding is solidly grounded. (alias is grdwrj) (0.0 by default)
	REALAR(7)	Winding 3 grounding DC resistance in ohms. When GRDWRK=0.0, there is no grounding resistance and winding is solidly grounded. (alias is grdwrk) (0.0 by default)
Character*12 VECGRP	Alphanumeric identifier specifying vector group based on transformer winding connections and phase angles. When vector group is blank, its value is taken from power flow data. (input; " by default).	
Integer IERR	error code (output).	

IERR = 0

no errors occurred

IERR = 1

prerequisite requirements for API are not met

6.2.28. GIC_TRN_CHNG

Use this API to modify GIC transformer data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_TRN_CHNG IBUS JBUS KBUS CKT INTGAR(1)..INTGAR(5)
REALAR(1)..REALAR(7) VECGRP
```

Python command syntax:

```
ierr = gic_trn_chng(ibus, jbus, kbus, ckt, intgar, realar, vecgrp)
```

Fortran command syntax:

```
CALL GIC_TRN_CHNG( IBUS, JBUS, KBUS, CKT, INTGAR, REALAR, VECGRP, IERR)
```

Where:

Integer IBUS	The bus number of the bus to which Winding 1 is connected. It must be same Winding 1 bus of the same transformer in the working case. (input; no default allowed).
Integer JBUS	The bus number of the bus to which Winding 2 is connected. It must be same Winding 2 bus of the same transformer in the working case. (input; no default allowed).
Integer KBUS	The bus number of the bus to which Winding 3 is connected. It must be same Winding 3 bus of the same transformer in the working case. KBUS=0 for two winding transformers. No default allowed for three winding transformers. (input; 0 by default).
Character*2 CKT	transformer circuit identifier (input; '1' by default).
Integer INTGAR (5)	array of 5 elements specifying (input).
	INTGAR(1) GIC blocking device in neutral of Winding 1. For an auto-transformers, if either BDI=1 or BDJ=1, that auto-transformer is treated as if it has GIC blocking device present. (alias is bdi) (0 by default)
	INTGAR(1) = 0 no GIC blocking device present
	INTGAR(1) = 1 GIC blocking device present
	INTGAR(2) GIC blocking device in neutral of Winding 2. For an auto-transformers, if either BDI=1 or BDJ=1, that auto-transformer is treated as if it has GIC blocking device present. (alias is bdj) (0 by default)
	INTGAR(2) = 0 no GIC blocking device present
	INTGAR(2) = 1 GIC blocking device present
	INTGAR(3) GIC blocking device in neutral of Winding 3. (alias is bdk) (0 by default)
	INTGAR(3) = 0 no GIC blocking device present
	INTGAR(3) = 1 GIC blocking device present

	INTGAR(4)	Number of cores in transformer core design. This information is used to calculate transformer reactive power loss from GIC flowing its winding. (alias is core) (0 by default)
	INTGAR(4) = -1	three phase shell form
	INTGAR(4) = 0	unknown core design
	INTGAR(4) = 1	single phase core
	INTGAR(4) = 3	three phase 3-legged core form
	INTGAR(4) = 5	three phase 5-legged core form
	INTGAR(5)	Model transformer as T-model in GIC DC Network (alias is tmodel) (0 by default)
	INTGAR(5) = 0	two/three/auto transformer model as defined by its vector group
	INTGAR(5) = 1	transformer as T-model in DC network
Real REALAR (7)	array of 7 elements specifying (input).	
	REALAR(1)	DC resistance of Winding 1 in ohms/phase. When WRI is not specified, working case resistance is used to determine WRI. (alias is wri) (0.0 by default)
	REALAR(2)	DC resistance of Winding 2 in ohms/phase. When WRJ is not specified, working case resistance is used to determine WRJ. (alias is wrj) (0.0 by default)
	REALAR(3)	DC resistance of Winding 2 in ohms/phase. When WRK is not specified, working case resistance is used to determine WRK. (alias is wrk) (0.0 by default)
	REALAR(4)	Factor to calculate transformer reactive power loss from the GIC flow in its winding (MVAR/AMP) (alias is kfactor) (0.0 by default)
	REALAR(5)	Winding 1 grounding DC resistance in ohms. When GRDWRI=0.0, there is no grounding resistance and winding is solidly grounded. (alias is grdwri) (0.0 by default)
	REALAR(6)	Winding 2 grounding DC resistance in ohms. When GRDWRJ=0.0, there is no grounding resistance and winding is solidly grounded. (alias is grdwrj) (0.0 by default)
	REALAR(7)	Winding 3 grounding DC resistance in ohms. When GRDWRK=0.0, there is no grounding resistance and winding is solidly grounded. (alias is grdwrk) (0.0 by default)
Character*12 VECGRP	Alphanumeric identifier specifying vector group based on transformer winding connections and phase angles. When vector group is blank, its value is taken from power flow data. (input; " by default).	
Integer IERR	error code (output).	

IERR = 0

no errors occurred

IERR = 1

prerequisite requirements for API are not met

6.2.29. GIC_TRN_PURG

Use this API to purge GIC transformer data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_TRN_PURG IBUS JBUS KBUS CKT
```

Python command syntax:

```
ierr = gic_trn_purg(ibus,jbus,kbus,ckt)
```

Fortran command syntax:

```
CALL GIC_TRN_PURG( IBUS, JBUS, KBUS, CKT, IERR)
```

Where:

Integer IBUS	The bus number of the bus to which Winding 1 is connected. It must be same Winding 1 bus of the same transformer in the working case. (input; no default allowed).	
Integer JBUS	The bus number of the bus to which Winding 2 is connected. It must be same Winding 2 bus of the same transformer in the working case. (input; no default allowed).	
Integer KBUS	The bus number of the bus to which Winding 3 is connected. It must be same Winding 3 bus of the same transformer in the working case. KBUS=0 for two winding transformers. No default allowed for three winding transformers. (input; 0 by default).	
Character*2 CKT	transformer circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.30. GIC_VSCDC

Use this API to modify or add new vscdc GIC shunt data to the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_VSCDC NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_vscdc(name,bus,ckt,realar)
```

Fortran command syntax:

```
CALL GIC_VSCDC(NAME,BUS,CKT,REALAR,IERR)
```

Where:

Character*12 NAME	vscdc line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, vscdc shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, vscdc is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.31. GIC_VSCDC_CHNG

Use this API to modify new vsdc GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_VSCDC_CHNG NAME BUS CKT REALAR(1) REALAR(2)
```

Python command syntax:

```
ierr = gic_vscdc_chng(name, bus, ckt, realar)
```

Fortran command syntax:

```
CALL GIC_VSCDC_CHNG(NAME, BUS, CKT, REALAR, IERR)
```

Where:

Character*12 NAME	vsdc line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Real REALAR (2)	array of 2 elements specifying (input).	
	REALAR(1)	DC resistance in ohms/phase. R must be > 0. When R is not specified or R=0, vsdc shunt is ignored in DC network. (alias is r) (0.0 by default)
	REALAR(2)	Grounding DC resistance in ohms/phase. When RG is not specified or RG=0, vsdc is treated as solidly grounded when part of DC network. (alias is rg) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

6.2.32. GIC_VSCDC_PURG

Use this API to purge new vsdc GIC shunt data from the working case.

This API routine was first introduced in release 34.8.0.

Batch command syntax:

```
BAT_GIC_VSCDC_PURG NAME BUS CKT
```

Python command syntax:

```
ierr = gic_vscdc_purg(name, bus, ckt)
```

Fortran command syntax:

```
CALL GIC_VSCDC_PURG(NAME, BUS, CKT, IERR)
```

Where:

Character*12 NAME	vsdc line name, must exist in the working case (input; no default allowed).	
Integer BUS	base case bus number, must exist in the working case (input; no default allowed).	
Character*2 CKT	GIC DC shunt circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR = 1	prerequisite requirements for API are not met

GIC Data Changing APIs contains API routines specific to adding, modifying, and deleting GIC data.

Chapter 7

Dynamics Simulation

This chapter describes the API routines used in PSS®E Dynamic Simulation.

This chapter is divided into sections for General Operations, Output Channel Operations, detailed routines for dealing with models, by type, and finally setting disturbances.

7.1. Dynamic Simulation Operation

Dynamic Simulation Operation contains API routines that deals with general operations of dynamics simulation functions, including option settings and reports.

7.1.1. ADDMODELLIBRARY

Use this API to add a library to the list to be searched for library models.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_ADDMODELLIBRARY  LIBRARYNAME
```

Python command syntax:

```
ierr = addmodellibrary(libraryname)
```

Fortran command syntax:

```
CALL ADDMODELLIBRARY(LIBRARYNAME, IERR)
```

Where:

Character*260 LIBRARYNAME	name of the library of model programs (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	library not found
	IERR = 2	library load failed
	IERR = 3	prerequisite requirements for API are not met

7.1.2. ASTR

Use this API to calculate and replicates the state variable system matrices in the form required by the Linear Dynamic Analysis Program, LSYSAN (activity ASTR).

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ASTR  OPTION  MAXDERIV  PERTURB  NSTATE  MINSTATE(1)..MINSTATE(NSTATE)
          MAXSTATE(1)..MAXSTATE(NSTATE)  NOUTPUT  MINCHAN(1)..MINCHAN(NOUTPUT)
          MAXCHAN(1)..MAXCHAN(NOUTPUT)  NINPUT  INTYPE(1)..INTYPE(NINPUT)
          INPERT(1)..INPERT(NINPUT)  INBUS(1)..INBUS(NINPUT)
          INMCID(1)..INMCID(NINPUT)  INIDENT(1)..INIDENT(NINPUT)  OUTFILE
```

Python command syntax:

```
ierr = astr(option, maxderiv, perturb, nstate, minstate, maxstate,
            noutput, minchan, maxchan, ninput, intype, inpert, inbus, inmcid,
            inident, outfile)
```

Fortran command syntax:

```
CALL ASTRAPI(OPTION, MAXDERIV, PERTURB, NSTATE, MINSTATE, MAXSTATE,
             NOUTPUT, MINCHAN, MAXCHAN, NINPUT, INTYPE, INPERT, INBUS, INMCID,
             INIDENT, OUTFILE, IERR)
```

Where:

Integer OPTION	network solution convergence monitor option (input; 0 by default). OPTION = 1 automatically print the convergence monitor. OPTION = 0 print the convergence monitor only if it is enabled via the CM interrupt control code.
Real MAXDERIV	largest derivative threshold for considering that the initialization reflects a steady-state condition (input; 0.01).
Real PERTURB	amount by which the specified state variables are to be perturbed (input; 0.01).
Integer NSTATE	number of state variable ranges defining those state variables that are to be perturbed; 0 to include all STATES (input; 0 by default).
Integer MINSTATE (NSTATE)	a list of starting STATE indices defining the ranges of state variables to be perturbed; ignored if NSTATE = 0 (input; no default allowed).
Integer MAXSTATE (NSTATE)	a list of ending STATE indices defining the ranges of state variables to be perturbed; ignored if NSTATE = 0 (input; no default allowed).
Integer NOUTPUT	number of channel ranges defining those output channels that are to be included in the system output vector; 0 to use the first 'NCHAN' or 50, whichever is less (input; 0 by default).
Integer MINCHAN (NOUTPUT)	a list of starting channel indices defining the ranges of output channels to be included in the system output vector; ignored if NOUTPUT = 0 (input; no default allowed).

Integer MAXCHAN (NOUTPUT)	a list of ending channel indices defining the ranges of output channels to be included in the system output vector; ignored if NOUTPUT = 0 (input; no default allowed).
Integer NINPUT	number of system variables that are to be perturbed (input; 0 by default).
Integer INTYPE (NINPUT)	a list of variable type codes; ignored if NINPUT = 0 (input; no default allowed). INTYPE = 1 EFD, generator main field voltage (pu) INTYPE = 2 PMECH, turbine mechanical power (pu on MBASE) INTYPE = 3 VOTHSG, stabilizer output signal (pu) INTYPE = 4 VREF, voltage regulator voltage setpoint (pu) INTYPE = 5 VAR
Real INPERT (NINPUT)	a list of perturbation factors to be applied to those system variables that are to be perturbed; ignored if NINPUT = 0 (input; PERTURB).
Integer INBUS (NINPUT)	a list of buses (when the corresponding INTYPE is 1 through 4) and/or VAR indices (when the corresponding INTYPE is 5) used to define those system variables that are to be perturbed; ignored if NINPUT = 0 (input; no default allowed).
Character*2 INMCID (NINPUT)	a list of machine identifiers used to define those system variables that are to be perturbed (when the corresponding INTYPE is 1 through 4; ignored when the corresponding INTYPE is 5); ignored if NINPUT = 0 (input; '1' by default).
Character*32 INIDENT (NINPUT)	a list of text strings used to identify those system variables that are to be perturbed; ignored if NINPUT = 0. If a blank identifier is specified, the ASTR API provides an appropriate identifier (input; blank by default).
Character*260 OUTFILE	name of the Matrix Output File into which the results of this API's calculation are to be placed; this file may then be used as to the LSYSAN program (input; no default allowed).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 generators are not converted IERR = 2 invalid OPTION value IERR = 3 invalid MAXDERIV value IERR = 4 invalid PERTURB value IERR = 5 derivative threshold exceeded--not in steady state IERR = 6 invalid code of input to be perturbed IERR = 7 invalid perturbation amount IERR = 8 machine is out-of-service IERR = 9 invalid VAR index IERR = 10 attempting to select more STATES than are in the system model IERR = 11 too many channels selected

IERR = 12	prior initialization modified the loads--pick up original converted case
IERR = 13	error opening OUTFILE
IERR = 14	prerequisite requirements for API are not met

7.1.3. AULIST

Use this API to list auxiliary signal models that inject signals into dc lines or FACTS devices connected to subsystem buses, along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_AULIST  SID  ALL  STATUS
```

Python command syntax:

```
ierr = aulist(sid, all, status)
```

Fortran command syntax:

```
CALL AULIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.1.4. CHANGE_CHANNEL_OUT_FILE

Use this API to modify the dynamic simulation channel output filename in dynamics working memory (see PSSE Program Operation Manual, activity ALTR).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_CHANNEL_OUT_FILE  OUTFILE
```

Python command syntax:

```
ierr = change_channel_out_file(outfile)
```

Fortran command syntax:

```
CALL CHANGE_CHANNEL_OUT_FILE(OUTFILE, IERR)
```

Where:

Character*260 OUTFILE	name of the Channel Output File (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	error opening OUTFILE
	IERR = 2	prerequisite requirements for API are not met
	IERR = -1	warnings: - None

7.1.5. CHANGE_CHRICN

Use this API to change the value of an element of the CHRICN array (a character ICON). The element is specified relative to the beginning of the CHRICN array.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHANGE_CHRICN  NUMBER  'NEWVAL '
```

Python command syntax:

```
ierr = change_chricn(number, newval)
```

Fortran command syntax:

```
CALL CHANGE_CHRICN(NUMBER, NEWVAL, IERR)
```

Where:

Integer NUMBER	CHRICN number or array index (must be between 1 and the number of ICONs allowed at the present size level of PSSE) (input; no default allowed).	
Character*12 NEWVAL	new value to be assigned to CHRICN (NUMBER) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid CHRICN index
	IERR = 2	prerequisite requirements for API are not met

7.1.6. CHANGE_CON

Use this API to change the value of an element of the CON array. The element is specified relative to the beginning of the CON array.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHANGE_CON  NUMBER  NEWVAL
```

Python command syntax:

```
ierr = change_con(number, newval)
```

Fortran command syntax:

```
CALL CHANGE_CON(NUMBER, NEWVAL, IERR)
```

Where:

Integer NUMBER	CON number or array index (must be between 1 and the number of CONs allowed at the present size level of PSSE) (input; no default allowed).	
Real NEWVAL	new value to be assigned to CON (NUMBER) (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid CON index
	IERR = 2	prerequisite requirements for API are not met

7.1.7. CHANGE_GREF

Use this API to change the value of the element of the GREF (governor reference) array associated with a specified machine.

This API routine was first introduced in release 31.0.2.

Batch command syntax:

```
BAT_CHANGE_GREF  IBUS  'ID'  NEWVAL
```

Python command syntax:

```
ierr = change_gref(ibus, id, newval)
```

Fortran command syntax:

```
CALL CHANGE_GREF(IBUS, ID, NEWVAL, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Real NEWVAL	new value to be assigned to the GREF array entry associated with machine ID at bus IBUS (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 machine not found
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 warnings - one or more of: - No turbine-governor model at this machine - Turbine-governor model at this machine is bypassed

7.1.8. CHANGE_ICON

Use this API to change the value of an element of the ICON array (an integer ICON). The element is specified relative to the beginning of the ICON array.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHANGE_ICON  NUMBER  NEWVAL
```

Python command syntax:

```
ierr = change_icon(number, newval)
```

Fortran command syntax:

```
CALL CHANGE_ICON(NUMBER, NEWVAL, IERR)
```

Where:

Integer NUMBER	ICON number or array index (must be between 1 and the number of ICONs allowed at the present size level of PSSE) (input; no default allowed).	
Integer NEWVAL	new value to be assigned to ICON (NUMBER) (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid ICON index
	IERR = 2	prerequisite requirements for API are not met

7.1.9. CHANGE_STATE

Use this API to change the value of an element of the STATE array, as well as the values of the corresponding time derivative (DSTATE) and the associated memory cell used in the integration algorithm (STORE).

The element is specified relative to the beginning of the STATE array.

Note: Although this API may be used to modify the value of a state variable (along with its time derivative and integration memory cell) used in state-space and response test simulations, this ability is rarely required in normal dynamic simulation work. Unless some very special purpose is being served, this API should not be used.

Note: This API should never be used during extended term simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_STATE  NUMBER  NEWVAL(1) . . NEWVAL(3)
```

Python command syntax:

```
ierr = change_state(number, newval)
```

Fortran command syntax:

```
CALL CHANGE_STATE(NUMBER, NEWVAL, IERR)
```

Where:

Integer NUMBER	STATE number or array index (must be between 1 and the number of STATES allowed at the present size level of PSSE) (input; no default allowed).	
Real NEWVAL (3)	array of 3 elements specifying (input).	
	NEWVAL(1)	new value to be assigned to STATE(NUMBER) (unchanged by default)
	NEWVAL(2)	new value to be assigned to DSTATE(NUMBER) (unchanged by default)
	NEWVAL(3)	new value to be assigned to STORE(NUMBER) (unchanged by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATE index
	IERR = 2	prerequisite requirements for API are not met

7.1.10. CHANGE_SWSREF

This API routine is obsolete. It has been replaced by the API routine [change_swsref_2](#).

Use this API to change the value of the element of the SWSREF array associated with a specified switched shunt.

This API routine was first introduced in release 32.2.1.

Batch command syntax:

```
BAT_CHANGE_SWSREF  IBUS  NEWVAL
```

Python command syntax:

```
ierr = change_swsref(ibus, newval)
```

Fortran command syntax:

```
CALL CHANGE_SWSREF(IBUS, NEWVAL, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input).
Real NEWVAL	new value to be assigned to the SWSREF array entry associated with switched shunt at bus IBUS (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 switched shunt not found
	IERR = 2 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information messages; one or more of: - no table mode for switched shunt at this bus. - switched shunt dynamic model at this switched shunt is bypassed.

7.1.11. CHANGE_SWSREF_2

Use this API to change the value of the element of the SWSREF array associated with a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSREF_2  IBUS ID  NEWVAL
```

Python command syntax:

```
ierr = change_swsref_2(ibus, id, newval)
```

Fortran command syntax:

```
CALL CHANGE_SWSREF_2(IBUS, ID, NEWVAL, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input).
Character*2 ID	switched shunt identifier (input; blank by default).
Real NEWVAL	new value to be assigned to the SWSREF array entry associated with switched shunt at bus IBUS (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 bus not found
	IERR = 2 switched shunt not found
	IERR = 2 prerequisite requirements for API are not met
	IERR = -1 data error, warning and information mes-
	sages; one or more of: - no table mode for
	switched shunt at this bus. - switched shunt
	dynamic model at this switched shunt is by-
	passed.

7.1.12. CHANGE_VAR

Use this API to change the value of an element of the VAR array. The element is specified relative to the beginning of the VAR array.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VAR  NUMBER  NEWVAL
```

Python command syntax:

```
ierr = change_var(number, newval)
```

Fortran command syntax:

```
CALL CHANGE_VAR(NUMBER, NEWVAL, IERR)
```

Where:

Integer NUMBER	VAR number or array index (must be between 1 and the number of VARs allowed at the present size level of PSSE) (input; no default allowed).	
Real NEWVAL	new value to be assigned to VAR (NUMBER) (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid VAR index
	IERR = 2	prerequisite requirements for API are not met

7.1.13. CHANGE_VREF

Use this API to change the value of the element of the VREF array associated with a specified machine.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

BAT_CHANGE_VREF IBUS 'ID' NEWVAL

Python command syntax:

```
ierr = change_vref(ibus, id, newval)
```

Fortran command syntax:

CALL CHANGE_VREF(IBUS, ID, NEWVAL, IERR)

Where:

Integer IBUS	plant bus number (input; no default allowed).	
Character*2 ID	machine identifier (input; '1' by default).	
Real NEWVAL	new value to be assigned to the VREF array entry associated with machine ID at bus IBUS (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	machine not found
	IERR = 3	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - No excitation system model at this machine - Excitation system model at this machine is bypassed

7.1.14. DCLIST

Use this API to list dc line models connected to subsystem buses along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DCLIST  SID  ALL  STATUS(1)  STATUS(2)
```

Python command syntax:

```
ierr = dclist(sid, all, status)
```

Fortran command syntax:

```
CALL DCLIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses. ALL = 0 process only buses in subsystem SID.
Integer STATUS (2)	array of 2 elements specifying a two-element array(input). STATUS(1) active/bypassed flag (0 by default) STATUS(1) = 0 list active and bypassed models STATUS(1) = 1 list active models only STATUS(1) = 2 list bypassed models only STATUS(2) dc line model type (1 by default) STATUS(2) = 1 two-terminal dc line models STATUS(2) = 2 multi-terminal dc line models STATUS(2) = 3 VSC dc line models
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.1.15. DLST

Use this API to tabulate specified portions of one or more of the PSSE dynamics data storage arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DLST  NTYPE  ATYPE(1) .. ATYPE(NTYPE)  FIRST(1) .. FIRST(NTYPE)
          LAST(1) .. LAST(NTYPE)
```

Python command syntax:

```
ierr = dlst(ntype, atype, first, last)
```

Fortran command syntax:

```
CALL DLSTAPI(NTYPE, ATYPE, FIRST, LAST, IERR)
```

Where:

Integer NTYPE	number of array portion specifications to be supplied; must be between 1 and 6, inclusive (input; no default allowed).
Integer ATYPE (NTYPE)	a list of PSSE array type codes. No more than one occurrence of each of the valid ATYPE values is allowed in each use of this API (input; no default allowed). ATYPE = 1 for CONs ATYPE = 2 for STATEs ATYPE = 3 for VARs ATYPE = 4 for ICONs and CHRICNs ATYPE = 5 for output channels ATYPE = 6 for CRT plot channels
Integer FIRST (NTYPE)	a list of starting indices in the data array(s) specified by the corresponding ATYPE entry (input; 1 by default).
Integer LAST (NTYPE)	a list of ending indices in the data array(s) specified by the corresponding ATYPE entry (input; next available - 1 by default for ATYPE = 1 through 5; 6 by default for ATYPE = 6).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid NTYPE value IERR = 2 invalid ATYPE value (entry skipped) IERR = 3 ATYPE value previously specified (entry skipped) IERR = 4 prerequisite requirements for API are not met

7.1.16. DOCU

Use this API to tabulate the data associated with equipment models referenced in the user's simulation set-up.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DOCU  SID  ALL  STATUS(1)..STATUS(3)
```

Python command syntax:

```
ierr = docu(sid, all, status)
```

Fortran command syntax:

```
CALL DOCUNW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (3)	array of 3 elements specifying reporting options(input). STATUS(1) processing mode (0 by default) STATUS(1) = 0 reporting mode STATUS(1) = 1 data checking mode STATUS(2) models to process (3 by default) STATUS(2) = 0 process all CONEC models STATUS(2) = 1 process all CONET models STATUS(2) = 2 process all CHAN models STATUS(2) = 3 process models by subsystem STATUS(2) = 4 process Miscellaneous, "other," type models STATUS(3) value depends on the value of STATUS(2). If STATUS(2) = 3 then STATUS(3) is the type of model for which data is to be processed (1 by default) If STATUS(2) = 4: STATUS(3) = 0 Miscellaneous "Other" model. DOCU for every model instance STATUS(3) > 0 Miscellaneous "Other" model. DOCU for the specified model instance If STATUS(2) = 3: STATUS(3) = 1 all models STATUS(3) = 2 all plant models STATUS(3) = 3 generator models

STATUS(3) = 4	compensator models
STATUS(3) = 5	stabilizer models
STATUS(3) = 6	minimum excitation limiter models
STATUS(3) = 7	maximum excitation limiter models
STATUS(3) = 8	excitation system models
STATUS(3) = 9	turbine governor models
STATUS(3) = 10	load characteristic models
STATUS(3) = 11	load relay models
STATUS(3) = 12	line relay models
STATUS(3) = 13	auxiliary signal models
STATUS(3) = 14	two-terminal dc line models
STATUS(3) = 15	multi-terminal dc line models
STATUS(3) = 16	VSC dc line models
STATUS(3) = 17	FACTS device models
STATUS(3) = 18	CONEC models
STATUS(3) = 19	CONET models
STATUS(3) = 20	CHAN models
STATUS(3) = 21	turbine load controller
STATUS(3) = 22	switched shunt models
STATUS(3) = 23	all renewable models
STATUS(3) = 24	renewable generator models
STATUS(3) = 25	renewable electrical control models
STATUS(3) = 26	renewable mechanical system models
STATUS(3) = 27	renewable pitch models
STATUS(3) = 28	renewable aerodynamic models
STATUS(3) = 29	renewable gust models
STATUS(3) = 30	renewable plant control models
STATUS(3) = 31	induction machine models
STATUS(3) = 32	branch device models
STATUS(3) = 33	two-winding transformer device models
STATUS(3) = 34	three-winding transformer models
STATUS(3) = 35	protection models associated with machines
STATUS(3) = 36	"other" models associated with machines
STATUS(3) = 37	"other" models associated with bus
STATUS(3) = 38	"other" models associated with two-terminal dc lines
STATUS(3) = 40	renewable torque control models
STATUS(3) = 41	"other" models associated with branch
STATUS(3) = 42	"other" models associated with switched shunt
STATUS(3) = 43	renewable weak grid control models
STATUS(3) = 44	renewable Paux Control models

Integer IERR

error code (output).

IERR = 0	no error
IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	prerequisite requirements for API are not met

7.1.17. DROPMODELLIBRARY

Use this API to remove a library from the list being searched for library models.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_DROPMODELLIBRARY  LIBRARYNAME
```

Python command syntax:

```
ierr = dropmodellibrary(libraryname)
```

Fortran command syntax:

```
CALL DROPMODELLIBRARY(LIBRARYNAME, IERR)
```

Where:

Character*260 LIBRARYNAME	name of the library of model programs (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	library not found
	IERR = 2	there are still models in use from this library; unload not done
	IERR = 3	library unload failed
	IERR = 4	prerequisite requirements for API are not met

7.1.18. DROPMODELPROGRAM

Use this API to remove a model from the list of known library models; library models are added to this list the first time that they are called.

This API routine was first introduced in release 30.3.0.

Batch command syntax:

```
BAT_DROPMODELPROGRAM PROGRAMNAME
```

Python command syntax:

```
ierr = dropmodelprogram(programname)
```

Fortran command syntax:

```
CALL DROPMODELPROGRAM(PROGRAMNAME, IERR)
```

Where:

Character*260 PROGRAMNAME	name of the model program (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	program not found
	IERR = 2	program unload failed
	IERR = 3	prerequisite requirements for API are not met

7.1.19. DYDA

Use this API to replicate dynamics model data in the form of a Dynamics Data Input file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_DYDA  SID  ALL  STATUS(1)..STATUS(3)  OUT  OFILE
```

Python command syntax:

```
ierr = dyda(sid, all, status, out, ofile)
```

Fortran command syntax:

```
CALL DYDANW(SID, ALL, STATUS, OUT, OFILE, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 1	process all buses.
	ALL = 0	process only buses in subsystem SID.
Integer STATUS (3)	array of 3 elements specifying a three-element array(input).	
	STATUS(1)	models to process (2 by default)
	STATUS(1) = 0	process all CONEC models
	STATUS(1) = 1	process all CONET models
	STATUS(1) = 2	process models by subsystem
	STATUS(1) = 3	process Miscellaneous other type models
	STATUS(2)	value depends on the value of STATUS(1). If STATUS(1) = 2 then STATUS(2) is the type of model for which data is to be processed (1 by default)
	If STATUS(1) = 3:	
	STATUS(2) = 0	Miscellaneous, "Other," model DYDA for every model instance.
	STATUS(2) > 0	Miscellaneous, "Other," model DYDA for the specified model instance.
	If STATUS(1) = 2:	
	STATUS(2) = 1	all models
	STATUS(2) = 2	all plant models
	STATUS(2) = 3	generator models
	STATUS(2) = 4	compensator models
	STATUS(2) = 5	stabilizer models
	STATUS(2) = 6	minimum excitation limiter models
	STATUS(2) = 7	maximum excitation limiter models
	STATUS(2) = 8	excitation system models

STATUS(2) = 9	turbine governor models
STATUS(2) = 10	load characteristic models
STATUS(2) = 11	load relay models
STATUS(2) = 12	line relay models
STATUS(2) = 13	auxiliary signal models
STATUS(2) = 14	two-terminal dc line models
STATUS(2) = 15	multi-terminal dc line models
STATUS(2) = 16	VSC dc line models
STATUS(2) = 17	FACTS device models
STATUS(2) = 18	CONEC models
STATUS(2) = 19	CONET models
STATUS(2) = 20	turbine load controller
STATUS(2) = 21	switched shunt models
STATUS(2) = 22	all renewable models
STATUS(2) = 23	renewable generator models
STATUS(2) = 24	renewable electrical control models
STATUS(2) = 25	renewable mechanical system models
STATUS(2) = 26	renewable pitch models
STATUS(2) = 27	renewable aerodynamic models
STATUS(2) = 28	renewable gust models
STATUS(2) = 29	renewable plant control models
STATUS(2) = 30	induction machine models
STATUS(2) = 31	branch device models
STATUS(2) = 32	two-winding transformer device models
STATUS(2) = 33	three-winding transformer models
STATUS(2) = 34	protection models associated with machines
STATUS(2) = 35	"other" models associated with machines
STATUS(2) = 36	"other" models associated with bus
STATUS(2) = 37	"other" models associated with two-terminal dc lines
STATUS(2) = 39	renewable torque control models
STATUS(2) = 40	"other" models associated with branch
STATUS(2) = 41	"other" models associated with switched shunt
STATUS(2) = 42	renewable weak grid control models
STATUS(2) = 43	renewable Paux Control models
STATUS(3)	load model option (0 by default)
STATUS(3) = 0	include all subsystem load models attached to loads in the specified subsystem
STATUS(3) = 1	exclude subsystem load models attached to loads in the specified subsystem except when subsystem number is explicitly in the list
Integer OUT	destination selection (input; 1 by default).

	OUT = 0	direct output to a data file specified by OFILE.
	OUT = 1	direct output to the current report device.
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	invalid OUT value
	IERR = 5	error opening OFILE
	IERR = 6	prerequisite requirements for API are not met

7.1.20. DYNAMICSMODE

Use this API to return PSSE to dynamics mode following the use of the POWERFLOWMODE API while in dynamics mode. (The POWERFLOWMODE API would normally be followed by the use of one or more of the power flow data editor APIs).

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_DYNAMICSMODE  OPT
```

Python command syntax:

```
ierr = dynamicsmode(opt)
```

Fortran command syntax:

```
CALL DSMODE(OPT, IERR)
```

Where:

Logical OPT	factorize admittance matrix flag (input; FALSE).	
	OPT = TRUE	(or T or 1 in batch command and Python) to factorize the admittance matrix
	OPT = FALSE	(or F or 0 in batch command and Python) to omit the matrix factorization
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	PSSE was started up at its powerflow entry point
	IERR = 2	prerequisite requirements for API are not met

7.1.21. DYNAMICS_SOLUTION_PARAMS

This API routine is obsolete. It has been replaced by the API routine [dynamics_solution_param_2](#).

Use this API to modify the dynamic simulation solution parameters in dynamics working memory.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DYNAMICS_SOLUTION_PARAMS  INTGAR(1)..INTGAR(8)  REALAR(1)..REALAR(8)
                                OUTFILE
```

Python command syntax:

```
ierr = dynamics_solution_params(intgar, realar, outfile)
```

Fortran command syntax:

```
CALL DYNAMICS_SOLUTION_PARAMETERS(INTGAR, REALAR, OUTFILE, IERR)
```

Where:

Integer INTGAR (8)	array of 8 elements specifying (input).	
	INTGAR(1)	network solution maximum number of iterations
	INTGAR(2)	number of channels being monitored; must be less than or equal to the number of output channels defined
	INTGAR(3)	number of state variables in use in the simulation model; should not normally be changed by the user
	INTGAR(4)	next available location in the CON array
	INTGAR(5)	next available location in the STATE array
	INTGAR(6)	next available location in the VAR array
	INTGAR(7)	next available location in the ICON and CHRICN arrays
Real REALAR (8)	INTGAR(8)	next available location in the channel arrays
	array of 8 elements specifying (input).	
	REALAR(1)	acceleration sfactor used in the network solution
	REALAR(2)	convergence tolerance used in the network solution
	REALAR(3)	simulation time step (DELT)
	REALAR(4)	filter time constant used in calculating bus frequency deviations
	REALAR(5)	intermediate simulation mode time step threshold used in extended term simulations

	REALAR(6)	large (island frequency) simulation mode time step threshold used in extended term simulations
	REALAR(7)	large (island frequency) simulation mode acceleration factor used in extended term simulations
	REALAR(8)	large (island frequency) simulation mode convergence tolerance used in extended term simulations
Character*260	OUTFILE	name of the Channel Output File (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).
Integer	IERR	error code (output).
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	error opening OUTFILE
	IERR = 2	prerequisite requirements for API are not met
	IERR = -1	warnings: - None

7.1.22. DYNAMICS_SOLUTION_PARAM_2

Use this API to modify the dynamic simulation solution parameters (except the channel output filename) in dynamics working memory (see PSSE Program Operation Manual, activity ALTR).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_DYNAMICS_SOLUTION_PARAM_2  INTGAR(1)..INTGAR(8)  REALAR(1)..REALAR(8)
```

Python command syntax:

```
ierr = dynamics_solution_param_2(intgar, realar)
```

Fortran command syntax:

```
CALL DYNAMICS_SOLUTION_PARAMETERS_2(INTGAR, REALAR, IERR)
```

Where:

Integer INTGAR (8)	array of 8 elements specifying (input).
INTGAR(1)	network solution maximum number of iterations
INTGAR(2)	number of channels being monitored; must be less than or equal to the number of output channels defined
INTGAR(3)	number of state variables in use in the simulation model; should not normally be changed by the user
INTGAR(4)	next available location in the CON array
INTGAR(5)	next available location in the STATE array
INTGAR(6)	next available location in the VAR array
INTGAR(7)	next available location in the ICON and CHRICN arrays
INTGAR(8)	next available location in the channel arrays
Real REALAR (8)	array of 8 elements specifying (input).
REALAR(1)	acceleration sfactor used in the network solution
REALAR(2)	convergence tolerance used in the network solution
REALAR(3)	simulation time step (DELT)
REALAR(4)	filter time constant used in calculating bus frequency deviations
REALAR(5)	intermediate simulation mode time step threshold used in extended term simulations
REALAR(6)	large (island frequency) simulation mode time step threshold used in extended term simulations

	REALAR(7)	large (island frequency) simulation mode acceleration factor used in extended term simulations
	REALAR(8)	large (island frequency) simulation mode convergence tolerance used in extended term simulations
Integer IERR	error code (output).	
	IERR = 0	no errors occurred
	IERR > 0	error occurred
	IERR = 1	prerequisite requirements for API are not met
	IERR = -1	warnings: - None

7.1.23. DYNEXPORTCSV

Use this API to export dynamics engine and dynamics model messages that are displayed after running a dynamics simulation to CSV file format. If applicable the following data will be included in the specified output file:

type, severity, model, model type, bus number, bus name, base kv, area number, owner number, and engine/model messages

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_DYNEXPORTCSV CSVFILENAME
```

Python command syntax:

```
ierr = dynexportcsv(csvfilename)
```

Fortran command syntax:

```
CALL DYNEXPORTCSV(CSVFILENAME, IERR)
```

Where:

character*260 CSVFILENAME	name of the CSV file to hold exported data (input).	
Integer IERR	error code (output).	
	IERR = -1	Prerequisite requirements for API not met
	IERR = 0	no error
	IERR = 1	error opening csv file
	IERR = 2	error closing csv file; data may not have been written to file
	IERR = 3	error writing data to csv file

7.1.24. DYRE_ADD

Use this API to read a Dynamics Model Raw Data File and append the model references specified in its data records to the simulation data already contained in dynamics working memory (activity DYRE,ADD).

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DYRE_ADD  STARTINDX(1)..STARTINDX(4)  DYREFILE  CONECFILE  CONETFILE
```

Python command syntax:

```
ierr = dyre_add(startindx, dyrefile, conecfile, conetfile)
```

Fortran command syntax:

```
CALL DYRE_ADD(STARTINDX, DYREFILE, CONECFILE, CONETFILE, IERR)
```

Where:

Integer STARTINDX (4)	array of 4 elements specifying starting locations in the dynamics data storage arrays(input).
STARTINDX(1)	starting CON index (the next available CON by default)
STARTINDX(2)	starting STATE index (the next available STATE by default)
STARTINDX(3)	starting VAR index (the next available VAR by default)
STARTINDX(4)	starting ICON index (the next available ICON by default)
Character*260 DYREFILE	name of the Dynamics Model Raw Data File (input; no default allowed).
Character*260 CONECFILE	name of the output file for CONEC additions; blank to route data to the progress area (input; blank by default).
Character*260 CONETFILE	name of the output file for CONET additions; blank to route data to the progress area (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid STARTINDX value
IERR = 2	machine model connection tables full--use pack plant model tables function
IERR = 3	error opening output file DYREFILE
IERR = 4	prerequisite requirements for API are not met

7.1.25. DYRE_NEW

Use this API to clear dynamics working memory, read a Dynamics Data File, and place the model references specified on its data records into dynamics working memory. It optionally creates a command file for compiling the CONEC and CONET subroutines.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DYRE_NEW  STARTINDX(1)..STARTINDX(4)  DYREFILE  CONECFILE  CONETFILE
              COMPILFIL
```

Python command syntax:

```
ierr = dyre_new(startindx,dyrefile,conecfile,conetfile,compilfil)
```

Fortran command syntax:

```
CALL DYRE_NEW(STARTINDX, DYREFILE, CONECFILE, CONETFILE, COMPILFIL, IERR)
```

Where:

Integer STARTINDX (4)	array of 4 elements specifying starting locations in the dynamics data storage arrays(input). STARTINDX(1) starting CON index (1 by default) STARTINDX(2) starting STATE index (1 by default) STARTINDX(3) starting VAR index (1 by default) STARTINDX(4) starting ICON index (1 by default)
Character*260 DYREFILE	name of the Dynamics Model Raw Data File (input; no default allowed).
Character*260 CONECFILE	name of CONEC output file; blank for output to the progress area (input; blank by default).
Character*260 CONETFILE	name of CONET output file; blank for output to the progress area (input; blank by default).
Character*260 COMPILFIL	name of file containing commands to compile the CONEC and CONET output files; blank for none (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid STARTINDX value IERR = 3 error opening output file DYREFILE IERR = 4 prerequisite requirements for API are not met

7.1.26. ERUN

Use this API to calculate PSSE state-space dynamic simulations of excitation system response tests.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ERUN  TPAUSE  NPRT  NPLT  CRTPLT
```

Python command syntax:

```
ierr = erun(tpause, nprt, nplt, crtplt)
```

Fortran command syntax:

```
CALL ERUNAPI(TPAUSE, NPRT, NPLT, CRTPLT, IERR)
```

Where:

Real TPAUSE	value of simulated time at which the simulation should next pause (input; no default allowed).
Integer NPRT	number of time steps between the printing of the channel values (input; unchanged).
Integer NPLT	number of time steps between the writing of the output channel values to the current Channel Output File (input; unchanged).
Integer CRTPLT	number of time steps between the plotting of those channel values that have been designated as CRT output channels (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 activity ESTR needs to be executed
	IERR = 2 error opening the current Channel Output File
	IERR = 3 prerequisite requirements for API are not met

7.1.27. ESTR_OPEN_CIRCUIT_TEST

Use this API to initialize a PSSE dynamic simulation for excitation system open circuit response simulations (i.e., in preparation for activity ERUN) and to specify the Channel Output File into which the output channel values are to be recorded during the simulation.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ESTR_OPEN_CIRCUIT_TEST  OPTION  VDELTA  OUTFILE
```

Python command syntax:

```
ierr = estr_open_circuit_test(option, vdelta, outfile)
```

Fortran command syntax:

```
CALL ESTR_OPEN_CIRCUIT_TEST(OPTION, VDELTA, OUTFILE, IERR)
```

Where:

Integer OPTION	bus flag indicating those buses to be tested (input; 0 by default). OPTION = 0 run test on all in-service machines with excitation system models. OPTION > 0 bus number for which machines are to be tested.
Real VDELTA	per unit voltage reference step applied at TIME = 0.0 (input; 0.05).
Character*260 OUTFILE	name of the Channel Output File (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 bus not found IERR = 2 error opening OUTFILE IERR = 3 generators are not "converted" IERR = 4 prerequisite requirements for API are not met

7.1.28. ESTR_RESPONSE_RATIO_TEST

Use this API to initialize a PSSE dynamic simulation for excitation system response ratio test simulations (i.e., in preparation for activity ERUN) and to specify the Channel Output File into which the output channel values are to be recorded during the simulation.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ESTR_RESPONSE_RATIO_TEST  OPTION  PFDEFAULT  NMACHS
    BUSARY(1) .. BUSARY(NMACHS)  IDARY(1) .. IDARY(NMACHS)
    PFARY(1) .. PFARY(NMACHS)  OUTFILE
```

Python command syntax:

```
ierr = estr_response_ratio_test(option, pfdefault, nmachs, busary, idary,
                                pfary, outfile)
```

Fortran command syntax:

```
CALL ESTR_RESPONSE_RATIO_TEST(OPTION, PFDEFAULT, NMACHS, BUSARY, IDARY,
                                PFARY, OUTFILE, IERR)
```

Where:

Integer OPTION	bus flag indicating those buses to be tested (input; 0 by default). OPTION = 0 run test on all in-service machines with excitation system models. OPTION > 0 bus number for which machines are to be tested.
Real PFDEFAULT	default power factor at which machines are initialized (input; 0.95).
Integer NMACHS	number of machines to be initialized at other power factors (input; 0 by default).
Integer BUSARY (NMACHS)	a list of bus numbers identifying machines to be initialized at other power factors; ignored if NMACHS = 0 (input; no default allowed).
Character*2 IDARY (NMACHS)	a list of machine identifiers identifying machines to be initialized at other power factors; ignored if NMACHS = 0 (input; '1' by default).
Real PFARY (NMACHS)	a list of power factors; ignored if NMACHS = 0. Machine IDARY(n) at bus BUSARY(n) is initialized to the power factor specified in PFARY(n) (input; PFDEFAULT).
Character*260 OUTFILE	name of the Channel Output File (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 bus not found IERR = 2 invalid power factor IERR = 3 error opening OUTFILE

IERR = 4

generators are not "converted"

IERR = 5

prerequisite requirements for API are not met

7.1.29. FCLIST

Use this API to list FACTS device models connected to subsystem buses along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCLIST  SID  ALL  STATUS
```

Python command syntax:

```
ierr = fclist(sid, all, status)
```

Fortran command syntax:

```
CALL FCLIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.1.30. GRUN

Use this API to calculate PSSE state-space dynamic simulations of turbine-governor response tests.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_GRUN  TPAUSE  NPRT  NPLT  CRTPLT
```

Python command syntax:

```
ierr = grun(tpause, nprt, nplt, crtplt)
```

Fortran command syntax:

```
CALL GRUNAPI(TPAUSE, NPRT, NPLT, CRTPLT, IERR)
```

Where:

Real TPAUSE	value of simulated time at which the simulation should next pause (input; no default allowed).
Integer NPRT	number of time steps between the printing of the channel values (input; unchanged).
Integer NPLT	number of time steps between the writing of the output channel values to the current Channel Output File (input; unchanged).
Integer CRTPLT	number of time steps between the plotting of those channel values that have been designated as CRT output channels (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 activity GSTR needs to be executed
	IERR = 2 error opening the current Channel Output File
	IERR = 3 prerequisite requirements for API are not met

7.1.31. GSTR

Use this API to initialize a PSSE dynamic simulation for governor response simulations and to specify the Channel Output File into which the output channel values are to be recorded during the simulation.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_GSTR  OPTION  PINITIAL  PDELTA  OUTFILE
```

Python command syntax:

```
ierr = gstr(option, pinitial, pdelta, outfile)
```

Fortran command syntax:

```
CALL GSTRAPI(OPTION, PINITIAL, PDELTA, OUTFILE, IERR)
```

Where:

Integer OPTION	bus flag indicating those buses to be tested (input; 0 by default). OPTION = 0 run test on all in-service machines with turbine-governor models. OPTION = 0 bus number for which machines are to be tested.
Real PINITIAL	initial per unit loading of all machines being tested (input; 0.8).
Real PDELTA	per unit loading step applied at TIME = 0.0 (input; 0.1).
Character*260 OUTFILE	name of the Channel Output File (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 bus not found IERR = 2 error opening OUTFILE IERR = 3 generators are not, "converted" IERR = 4 prerequisite requirements for API are not met

7.1.32. INCREMENT_GREF

Use this API to add a specified value to the value of the element of the GREF (governor reference) array associated with a specified machine.

This API routine was first introduced in release 31.0.2.

Batch command syntax:

```
BAT_INCREMENT_GREF  IBUS  'ID'  NEWVAL
```

Python command syntax:

```
ierr = increment_gref(ibus, id, newval)
```

Fortran command syntax:

```
CALL INCREMENT_GREF(IBUS, ID, NEWVAL, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Real NEWVAL	new value to be added to the GREF array entry associated with machine ID at bus IBUS (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 error occurred
	IERR = 1 bus not found
	IERR = 2 machine not found
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 warnings - one or more of: - No turbine-governor model at this machine - Turbine-governor model at this machine is bypassed

7.1.33. INCREMENT_SWSREF

This API routine is obsolete. It has been replaced by the API routine [increment_swsref_2](#).

Use this API to add a specified value to the value of the element of the SWSREF (switched shunt reference) array associated with a specified switched shunt.

This API routine was first introduced in release 32.2.1.

Batch command syntax:

```
BAT_INCREMENT_SWSREF  IBUS NEWVAL
```

Python command syntax:

```
ierr = increment_swsref(ibus, newval)
```

Fortran command syntax:

```
CALL INCREMENT_SWSREF (IBUS, NEWVAL, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input).	
Real NEWVAL	new value to be added to the SWSREF array entry associated with switched shunt at bus IBUS (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	error occurred
	IERR = 1	bus not found
	IERR = 2	switched shunt not found
	IERR = 3	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - no table model for switched shunt at this bus. - switched shunt dynamic model as this bus is bypassed.

7.1.34. INCREMENT_SWSREF_2

Use this API to add a specified value to the value of the element of the SWREF (switched shunt reference) array associated with a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_INCREMENT_SWSREF_2 IBUS ID NEWVAL
```

Python command syntax:

```
ierr = increment_swsref_2(ibus, id, newval)
```

Fortran command syntax:

```
CALL INCREMENT_SWSREF_2(IBUS, ID, NEWVAL, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input).
Character*2 ID	switched shunt identifier (input; blank by default).
Real NEWVAL	new value to be added to the SWREF array entry associated with switched shunt at bus IBUS (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 error occurred
	IERR = 1 bus not found
	IERR = 2 switched shunt not found
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 warnings - one or more of: - no table model for switched shunt at this bus. - switched shunt dynamic model as this bus is bypassed.

7.1.35. INCREMENT_VREF

Use this API to add a specified value to the value of the element of the VREF (voltage reference) array associated with a specified machine.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_INCREMENT_VREF  IBUS  'ID'  NEWVAL
```

Python command syntax:

```
ierr = increment_vref(ibus, id, newval)
```

Fortran command syntax:

```
CALL INCREMENT_VREF(IBUS, ID, NEWVAL, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Real NEWVAL	new value to be added to the VREF array entry associated with machine ID at bus IBUS (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 error occurred
	IERR = 1 bus not found
	IERR = 2 machine not found
	IERR = 3 prerequisite requirements for API are not met
	IERR = -1 warnings - one or more of: - no excitation system model at this machine - excitation system model at this machine is bypassed

7.1.36. LDLIST

Use this API to list load models connected to subsystem loads along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDLIST  SID  ALL  STATUS(1)  STATUS(2)
```

Python command syntax:

```
ierr = ldlist(sid, all, status)
```

Fortran command syntax:

```
CALL LDLIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (2)	array of 2 elements specifying a two-element array(input). STATUS(1) active/bypassed flag (0 by default) STATUS(1) = 0 active and bypassed models STATUS(1) = 1 active models only STATUS(1) = 2 bypassed models only STATUS(2) model connection report option (0 by default) STATUS(2) = 0 list models connected to loads STATUS(2) = 1 list loads connected to model
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.1.37. LOAD_ARRAY_CHANNEL

Use this API to add an output channel containing the active or reactive component of a designated load.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_LOAD_ARRAY_CHANNEL STATUS(1)..STATUS(3) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = load_array_channel(status, id, ident)
```

Fortran command syntax:

```
CALL LOAD_ARRAY_CHANNEL (STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (3)	array of 3 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	used to indicate the quantity to be placed in an channel (1 by default)
STATUS(2) = 1	PLOAD
STATUS(2) = 2	QLOAD
STATUS(3)	number of the bus to which the load for which quantity is to be placed in an channel is connected (no default allowed)
Character*2 ID	load identifier (input; '1' by default).
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	bus not found
IERR = 4	load not found
IERR = 5	prerequisite requirements for API are not met

7.1.38. MLST

Use this API to list plant models connected to subsystem machines along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_MLST  SID  ALL  STATUS(1)..STATUS(3)
```

Python command syntax:

```
ierr = mlst(sid, all, status)
```

Fortran command syntax:

```
CALL MLSTNW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (3)	array of 3 elements specifying a three-element array(input). STATUS(1) connected/unconnected flag (1 by default) STATUS(1) = 0 list all unconnected models STATUS(1) = 1 list connected subsystem models STATUS(2) active/bypassed flag (0 by default) STATUS(2) = 0 active and bypassed models STATUS(2) = 1 active models only STATUS(2) = 2 bypassed models only STATUS(3) plant model type (1 by default) STATUS(3) = 1 all plant models STATUS(3) = 2 generator models STATUS(3) = 3 compensator models STATUS(3) = 4 stabilizer models STATUS(3) = 5 minimum excitation models STATUS(3) = 6 maximum excitation models STATUS(3) = 7 excitation system models STATUS(3) = 8 governor models STATUS(3) = 9 turbine load controller models
Integer IERR	error code (output). IERR = 0 no error

IERR = 1	invalid SID value or subsystem SID is not defined
IERR = 2	invalid ALL value
IERR = 3	invalid STATUS value
IERR = 4	prerequisite requirements for API are not met

7.1.39. MRUN

Use this API to calculate PSSE extended term dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MRUN  OPTION  TPAUSE  NPRT  NPLT  CRTPLT
```

Python command syntax:

```
ierr = mrun(option, tpause, nprt, nplt, crtplt)
```

Fortran command syntax:

```
CALL MRUNAPI(OPTION, TPAUSE, NPRT, NPLT, CRTPLT, IERR)
```

Where:

Integer OPTION	network solution convergence monitor option (input; 0 by default). OPTION = 1 automatically print the convergence monitor. OPTION = 0 print the convergence monitor only if it is enabled via the CM interrupt control code.
Real TPAUSE	value of simulated time at which the simulation should next pause (input; no default allowed).
Integer NPRT	number of time steps between the printing of the channel values (input; unchanged).
Integer NPLT	number of time steps between the writing of the output channel values to the current Channel Output File (input; unchanged).
Integer CRTPLT	number of time steps between the plotting of those channel values that have been designated as CRT output channels (input; unchanged).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 long time step mode threshold is at or below intermediate mode threshold IERR = 2 activity MSTR needs to be executed IERR = 3 invalid OPTION value IERR = 4 generators are not converted IERR = 5 error opening the current Channel Output File IERR = 6 prerequisite requirements for API are not met

7.1.40. MSTR

Use this API to initialize a PSSE dynamic simulation for extended term simulations and to specify the Channel Output File into which the output channel values are to be recorded during the dynamic simulation.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MSTR  OPTION  OUTFILE
```

Python command syntax:

```
ierr = mstr(option, outfile)
```

Fortran command syntax:

```
CALL MSTRAPI(OPTION, OUTFILE, IERR)
```

Where:

Integer OPTION	network solution convergence monitor option (input; 0 by default).
OPTION = 1	automatically print the convergence monitor.
OPTION = 0	print the convergence monitor only if it is enabled via the CM interrupt control code.
Character*260 OUTFILE	name of the Channel Output File (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	long time step mode threshold is at or below intermediate mode threshold
IERR = 2	DELT is greater than intermediate time step mode threshold
IERR = 3	generators are not converted
IERR = 4	invalid OPTION value
IERR = 5	Prior initialization modified the loads--pick up original converted case
IERR = 6	error opening OUTFILE
IERR = 7	prerequisite requirements for API are not met

7.1.41. POWERFLOWMODE

Use this API to switch PSSE from dynamics mode to power flow mode. (This API would normally be followed by the use of one or more of the power flow data editor APIs, and then the DYNAMICSMODE API).

Batch command syntax.

BAT_POWERFLOWMODE

This API routine was first introduced in release 30.0.0.

Batch command syntax:

BAT_POWERFLOWMODE

Python command syntax:

```
ierr = powerflowmode()
```

Fortran command syntax:

```
CALL PFMODE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

7.1.42. PSAS

Use this API to convert a PSAS Command File into a PSSE Response File.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PSAS  INPFILE  OUTFILE
```

Python command syntax:

```
ierr, respfil = psas(inpfile, outfile)
```

Fortran command syntax:

```
CALL PSASAPI(INPFILE, OUTFILE, RESPFIL, IERR)
```

Where:

Character*260 INPFILE	name of the PSAS command file (input; no default allowed).	
Character*260 OUTFILE	name of Response file; blank to have PSAS assign the filename (input; blank by default).	
Character*260 RESPFIL	pathname of the Response file constructed by PSAS (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening INPFILE
	IERR = 2	error opening OUTFILE
	IERR = 3	errors detected while reading the PSAS command data input file
	IERR = 4	prerequisite requirements for API are not met

7.1.43. RLLIST

Use this API to list line relay models connected to subsystem buses along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RLLIST  SID  ALL  STATUS
```

Python command syntax:

```
ierr = rllist(sid, all, status)
```

Fortran command syntax:

```
CALL RLLIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.1.44. RSTR

Use this API to read a dynamics Snapshot File into PSSE working memory.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RSTR  SFILE
```

Python command syntax:

```
ierr = rstr(sfile)
```

Fortran command syntax:

```
CALL RSTRNW(SFILE, IERR)
```

Where:

Character*260 SFILE	snapshot file; '*' to restore the most recently accessed snapshot file in the current execution of PSSE (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	error opening SFILE
	IERR = 2	error reading from SFILE
	IERR = 3	prerequisite requirements for API are not met

7.1.45. RUN

Use this API to calculate PSSE state-space dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_RUN  OPTION  TPAUSE  NPRT  NPLT  CRTPLT
```

Python command syntax:

```
ierr = run(option, tpause, nprt, nplt, crtplt)
```

Fortran command syntax:

```
CALL RUNAPI(OPTION, TPAUSE, NPRT, NPLT, CRTPLT, IERR)
```

Where:

Integer OPTION	network solution convergence monitor option (input; 0 by default). OPTION = 1 automatically print the convergence monitor OPTION = 0 print the convergence monitor only if it is enabled via the CM interrupt control code
Real TPAUSE	value of simulated time at which the simulation should next pause (input; no default allowed).
Integer NPRT	number of time steps between the printing of the channel values (input; unchanged).
Integer NPLT	number of time steps between the writing of the output channel values to the current channel output file (input; unchanged).
Integer CRTPLT	number of time steps between the plotting of those channel values that have been designated as CRT output channels (input; unchanged).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 activity STRT needs to be executed IERR = 2 invalid OPTION value IERR = 3 generators are not converted IERR = 4 error opening the current channel output file IERR = 5 prerequisite requirements for API are not met

7.1.46. RWDY

Use this API to replicate portions of dynamics model data in the form of either a breaker duty data file, unit inertia and governor data file, or PSSPLT relay characteristic data file.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_RWDY  OPTIONS(1)..OPTIONS(3)  OUT  OFILE
```

Python command syntax:

```
ierr = rwdy(options, out, ofile)
```

Fortran command syntax:

```
CALL RWDYAPI(OPTIONS, OUT, OFILE, IERR)
```

Where:

Integer OPTIONS (3)	array of 3 elements specifying (input).
OPTIONS(1)	type of file to be (1 by default)
OPTIONS(1) = 1	breaker duty data file
OPTIONS(1) = 2	unit inertia and governor data file
OPTIONS(1) = 3	PSSPLT relay characteristic data file
OPTIONS(2)	machine limits flag for activity INLF (ignored unless OPTIONS(1) = 2) (0 by default)
OPTIONS(2) = 0	include machine limits
OPTIONS(2) = 1	suppress machine limits
OPTIONS(3)	flag indicating the treatment of machines without governor models in activity INLF (ignored unless OPTIONS(1) = 2) (0 by default)
OPTIONS(3) = 0	use the working case limits
OPTIONS(3) = 1	treat them as non-dispatchable
Integer OUT	destination selection (input; 1 by default).
OUT = 0	direct output to a data file specified by OFILE
OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid OPTIONS value
IERR = 2	invalid OUT value
IERR = 3	error opening OFILE
IERR = 4	prerequisite requirements for API are not met

7.1.47. SET_CHNFIL_TYPE

Use this API to set/Get the channel output file type (extended type or not).

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_SET_CHNFIL_TYPE STATUS ICODE
```

Python command syntax:

```
ierr = set_chnfil_type(status)
ierr, status = set_chnfil_type()
```

Fortran command syntax:

```
CALL SET_CHNFIL_TYPE(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	value of the option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).	
	STATUS = 0	channel output file is not of extended type (.out)
Integer ICODE	STATUS = 1	channel output file is of extended type (.outx)
	indicates the operation mode of the API (1 by default).	
	ICODE = 0	set the option setting to the value specified in STATUS
Integer IERR	ICODE > 0	return the current value of the option setting in STATUS
	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.1.48. SET_DISABLE_RUN

Use this API to enable or disable the simulation option setting that precludes dynamic simulation runs in the event there are fatal errors in the model data.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_SET_DISABLE_RUN    STATUS
```

Python command syntax:

```
ierr = set_disable_run(status)

ierr, status = set_disable_run()
```

Fortran command syntax:

```
CALL SET_DISABLE_RUN(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).	
	STATUS = 0	Do not disable dynamic simulation run if there is fatal data error
	STATUS = 1	Disable dynamic simulation run if there is fatal data error
Integer ICODE	operation mode of the API (no default allowed).	
	ICODE = 0	set the option setting to the value specified in STATUS
	ICODE > 0	return the current value of the option setting in STATUS
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	pre-requisite requirements for API are not met

7.1.49. SET_FREQ_RELAY_V_THRESH

This API is used to set voltage threshold for use in frequency relay models.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_SET_FREQ_RELAY_V_THRESH FRELVTHRESH
```

Python command syntax:

```
ierr = set_freq_relay_v_thresh(frelvthresh)
ierr, frelvthresh = set_freq_relay_v_thresh()
```

Fortran command syntax:

```
CALL SET_FREQ_RELAY_V_THRESH(FRELVTHRESH, ICODE, IERR)
```

Where:

Real FRELVTHRESH	(input; Voltage threshold for use in frequency relay models: if batch command or ICODE is 0 or negative; unchanged by default if ICODE is positive. This value can be used in frequency relay models as the minimum PU voltage for frequency measurement.).	
Integer ICODE	operation mode of API (no default allowed).	
	ICODE = 0	set the option setting to the value specified in FRelVThresh.
	ICODE = 1	return the current value of the option setting in FRelVThresh.
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API not met

7.1.50. SET_GENANG

This API routine is obsolete. It has been replaced by the API routine [set_genang_2](#).

Use this API to enable or disable the simulation option setting that scans for generators for which the angle differs from the angular average by more than a specified threshold.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_GENANG STATUS ANGLE
```

Python command syntax:

```
ierr = set_genang(status, angle)
ierr, status, angle = set_genang()
```

Fortran command syntax:

```
CALL SET_GENANG(STATUS, ANGLE, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 1 enable scanning for generators exceeding angle threshold.
	STATUS = 0 disable scanning option.
Real ANGLE	deviation threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in STATUS and the threshold to the value specified in ANGLE.
	ICODE > 0 return the current value of the option setting in STATUS and the threshold in ANGLE.
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid angle threshold--must be >0.0 and <360.0
	IERR = 2 prerequisite requirements for API are not met

7.1.51. SET_GENANG_2

This API routine is obsolete. It has been replaced by the API routine [set_genang_3](#).

Use this API to enable or disable the simulation option setting that scans for generators for which the angle differs from the angular average by more than a specified threshold. Scanning, if enabled, will be done for all machines whose machine MVA is greater than the specified value

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SET_GENANG_2 STATUS ANGLE MBASE
```

Python command syntax:

```
ierr = set_genang_2(status, angle, mbase)
ierr, status, angle, mbase = set_genang_2()
```

Fortran command syntax:

```
CALL SET_GENANG_2(STATUS, ANGLE, MBASE, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 1 enable scanning for generators exceeding angle threshold.
	STATUS = 0 disable scanning option.
Real ANGLE	deviation threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Real MBASE	machine size (MVA) (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive). All machines whose MVAR ratings are above this threshold will be scanned).
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in STATUS and the threshold values specified in ANGLE and MBASE.
	ICODE > 0 return the current value of the option setting in STATUS and the threshold values in ANGLE and MBASE
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid angle threshold--must be >0.0 and <360.0
	IERR = 2 invalid angle threshold--must be ≥ 0.0
	IERR = 3 prerequisite requirements for API are not met

7.1.52. SET_GENANG_3

Use this API to enable or disable the simulation option setting that scans for generators for which the angle differs from the angular average by more than a specified threshold. Scanning, if enabled, will be done for all machines whose machine MVA is greater than the specified value

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_GENANG_3 STATUS ANGLE MBASE TRIP
```

Python command syntax:

```
ierr = set_genang_3(status, angle, mbase, trip)
ierr, status, angle, mbase, trip = set_genang_3()
```

Fortran command syntax:

```
CALL SET_GENANG_3(STATUS, ANGLE, MBASE, TRIP, ICODE, IERR)
```

Where:

Integer STATUS	value of the option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 1 enable scanning for generators exceeding angle threshold.
	STATUS = 0 disable scanning option.
Real ANGLE	value of the deviation threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Real MBASE	machine size (MVA) (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive). All machines whose MVAR ratings are above this threshold will be scanned).
Integer TRIP	monitor trip flag (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive). All machines whose MVAR ratings are above this threshold will be scanned).
	TRIP = 1 trip generators
	TRIP = 1 monitor generators only
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in STATUS and the threshold values specified in ANGLE, MBASE and TRIP
	ICODE > 0 return the current value of the option setting in STATUS and the threshold values in ANGLE, MBASE and TRIP
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid angle threshold--must be >0.0 and <360.0

IERR = 2

invalid angle threshold--must be ≥ 0.0

IERR = 3

prerequisite requirements for API are not met

7.1.53. SET_GENANG_SUBSYS_FLAG

Use this API api for get/set the flag that is used for the subsystem definition for performing scan for generators exceeding angle threshold. When the subsystem flag is set, the API will also flag those buses contained in subsystem SID.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_GENANG_SUBSYS_FLAG ALL SID
```

Python command syntax:

```
ierr = set_genang_subsys_flag(all, sid)
ierr, all = set_genang_subsys_flag()
```

Fortran command syntax:

```
CALL SET_GENANG_SUBSYS_FLAG(ALL, SID, ICODE, IERR)
```

Where:

Integer ALL	all buses or specified subsystem flag (input; 1 by default).
	ALL = 0 process only buses in subsystem SID
	ALL = 1 process all buses
Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in ALL
	ICODE > 0 return the current value of the option setting in ALL
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid ALL value
	IERR = 2 invalid SID value
	IERR = 3 prerequisite requirements for API are not met

7.1.54. SET_GENPWR

Use this API to enable or disable the simulation option setting that scans for generators for which the mechanical power differs from its electrical power by more than a specified threshold.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_GENPWR STATUS POWER
```

Python command syntax:

```
ierr = set_genpwr(status, power)

ierr, status, power = set_genpwr()
```

Fortran command syntax:

```
CALL SET_GENPWR(STATUS, POWER, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 1 enable scanning for generators exceeding power unbalance threshold
	STATUS = 0 disable scanning option
Real POWER	power unbalance threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in STATUS and the threshold values specified in POWER
	ICODE > 0 return the current value of the option setting in STATUS and the threshold values in POWER
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid power unbalance threshold - must be >0.0 and <10.0
	IERR = 2 prerequisite requirements for API are not met

7.1.55. SET_GENSPDEV

Use this API to enable or disable the simulation option setting that scans for generators for which the speed deviation is more than a specified threshold.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_GENSPDEV STATUS SPEED TRIP
```

Python command syntax:

```
ierr = set_genspdev(status, speed, trip)

ierr, status, speed, trip = set_genspdev()
```

Fortran command syntax:

```
CALL SET_GENSPDEV(STATUS, SPEED, TRIP, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 1 enable scanning for generator speeds exceeding speed deviation threshold
	STATUS = 0 disable scanning option
Real SPEED	speed deviation threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Integer TRIP	monitor trip flag (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive). All machines whose MVAR ratings are above this threshold will be scanned).
	TRIP = 1 trip generators
	TRIP = 0 monitor generators only
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in STATUS and the threshold values specified in SPEED and TRIP
	ICODE > 0 return the current value of the option setting in STATUS and the threshold values in SPEED and TRIP
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 invalid speed deviation threshold - must be >0.0
	IERR = 2 prerequisite requirements for API are not met

7.1.56. SET_GENSPDEV_SUBSYS_FLAG

Use this API api for get/set the flag that is used for the subsystem definition for performing scans for generators for which the speed deviation is more than a specified threshold.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_GENSPDEV_SUBSYS_FLAG ALL SID
```

Python command syntax:

```
ierr = set_genspdev_subsys_flag(all, sid)
ierr, all = set_genspdev_subsys_flag()
```

Fortran command syntax:

```
CALL SET_GENSPDEV_SUBSYS_FLAG(ALL, SID, ICODE, IERR)
```

Where:

Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ICODE	operation mode of the API (no default allowed). ICODE ≤ 0 set the option setting to the value specified in ALL ICODE > 0 return the current value of the option setting in ALL
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid ALL value IERR = 2 invalid SID value IERR = 3 prerequisite requirements for API are not met

7.1.57. SET_LOAD_MODEL_THRESH

This API is used to set the MW, P over Q, and load bus voltage thresholds for load models.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_SET_LOAD_MODEL_THRESH LMWTHRESH LPQTHRESH LVTTHRESH
```

Python command syntax:

```
ierr = set_load_model_thresh(lmwthresh, lpqthresh, lvtthresh)
ierr, lmwthresh, lpqthresh, lvtthresh = set_load_model_thresh()
```

Fortran command syntax:

```
CALL SET_LOAD_MODEL_THRESH(LMWTHRESH, LPQTHRESH, LVTTHRESH, ICODE, IERR)
```

Where:

Real LMWTHRESH	(input; MW threshold for applying load models: if batch command or ICODE is 0 or negative; unchanged by default if ICODE is positive. This threshold can be used in load models to decide whether the load model should be applied or not.).
Real LPQTHRESH	(input; P by Q (absolute value) threshold for applying load models: if batch command or ICODE is 0 or negative; unchanged by default if ICODE is positive. This threshold can be used in load models to decide whether the load model should be applied or not.).
Real LVTTHRESH	(input; pu load bus voltage threshold for applying load models: if batch command or ICODE is 0 or negative; unchanged by default if ICODE is positive. This threshold can be used in load models to decide whether the load model should be applied or not.).
Integer ICODE	operation mode of API (no default allowed). ICODE = 0 set the option setting to the value specified in LMWThresh, LPQThresh, and LVtThresh. ICODE = 1 return the current value of the option setting in LMWThresh, LPQThresh, and LVtThresh.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 prerequisite requirements for API not met

7.1.58. SET_MODEL_DEBUG_OUTPUT_FLAG

Use this API to enable or disable the simulation option setting for dynamic model debug output.

This API routine was first introduced in release 33.12.0 and 34.5.0.

Batch command syntax:

```
BAT_SET_MODEL_DEBUG_OUTPUT_FLAG STATUS
```

Python command syntax:

```
ierr = set_model_debug_output_flag(status)
ierr, status = set_model_debug_output_flag()
```

Fortran command syntax:

```
CALL SET_MODEL_DEBUG_OUTPUT_FLAG(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if Batch command or for Python if specified as an argument, or for Fortran if ICODE is 0; no default allowed).
	STATUS = 0 disable dynamic model debug output
	STATUS = 1 enable dynamic model debug output
Integer ICODE	operation mode of the API (no default allowed).
	ICODE = 0 set the option setting to the value specified in STATUS
	ICODE = 1 return the current value of the option setting in STATUS
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 prerequisite requirements for API are not met

7.1.59. SET_NETFRQ

Use this API to enable or disable the simulation option setting that models the frequency dependence of network parameters.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_NETFRQ STATUS
```

Python command syntax:

```
ierr = set_netfrq(status)

ierr, status = set_netfrq()
```

Fortran command syntax:

```
CALL SET_NETFRQ(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 0 disable network frequency dependence
	STATUS = 1 enable network frequency dependence
Integer ICODE	operation mode of the API (no default allowed).
	ICODE = 0 set the option setting to the value specified in STATUS
	ICODE > 0 return the current value of the option setting in STATUS
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 prerequisite requirements for API are not met

7.1.60. SET_NEXT_CHANNEL

Use this API to assign the next available channel index value.

This API routine was first introduced in release 31.0.2.

Batch command syntax:

```
BAT_SET_NEXT_CHANNEL IVAL
```

Python command syntax:

```
ierr = set_next_channel(ival)
```

Fortran command syntax:

```
CALL SET_NEXT_CHANNEL(IVAL, IERR)
```

Where:

Integer IVAL	value to assign as the next available channel index (input).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid channel index
	IERR = 2	index is beyond the maximum allowed
	IERR = 3	prerequisite requirements for API are not met

7.1.61. SET_NEXT_ICON

Use this API to assign the next available ICON index value.

This API routine was first introduced in release 31.0.2.

Batch command syntax:

```
BAT_SET_NEXT_ICON IVAL
```

Python command syntax:

```
ierr = set_next_icon(ival)
```

Fortran command syntax:

```
CALL SET_NEXT_ICON(IVAL, IERR)
```

Where:

Integer IVAL	value to assign as the next available ICON index (input).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid ICON index
	IERR = 2	index is beyond the maximum allowed
	IERR = 3	prerequisite requirements for API are not met

7.1.62. SET_NEXT_VAR

Use this API to assign the next available VAR index value.

This API routine was first introduced in release 31.0.2.

Batch command syntax:

```
BAT_SET_NEXT_VAR IVAL
```

Python command syntax:

```
ierr = set_next_var(ival)
```

Fortran command syntax:

```
CALL SET_NEXT_VAR(IVAL, IERR)
```

Where:

Integer IVAL	value to assign as the next available VAR index (input).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid VAR index
	IERR = 2	index is beyond the maximum allowed
	IERR = 3	prerequisite requirements for API are not met

7.1.63. SET_OSSCAN

Use this API to enable or disable the simulation option setting that scans for out-of-step conditions using a generic relay.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_OSSCAN STATUS TRIP
```

Python command syntax:

```
ierr = set_ossan(status, trip)
ierr, status, trip = set_ossan()
```

Fortran command syntax:

```
CALL SET_OSSCAN(STATUS, TRIP, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 0 disable out-of-step scanning
	STATUS = 1 enable out-of-step scanning
Integer TRIP	monitor trip flag (input; unchanged).
	TRIP = 0 monitor only
	TRIP = 1 trip out-of-step circuits
Integer ICODE	operation mode of the API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in STATUS and the trip flag to the value specified in TRIP.
	ICODE > 0 return the current value of the option setting in STATUS and the trip flag in TRIP.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 prerequisite requirements for API are not met

7.1.64. SET_OSSCAN_2

This API routine is obsolete. It has been replaced by the API routine [SET_OSSCAN_2](#).

Use this API to enable or disable the simulation option setting that scans for out-of-step conditions using a generic relay.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SET_OSSCAN_2 STATUS TRIP EXCLXFMR
```

Python command syntax:

```
ierr = set_ossan_2(status, trip, exclxfmr)
ierr, status, trip, exclxfmr = set_ossan_2()
```

Fortran command syntax:

```
CALL SET_OSSCAN_2(STATUS, TRIP, EXCLXFMR, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive). STATUS = 0 disable out-of-step scanning STATUS = 1 enable out-of-step scanning
Integer TRIP	monitor or trip flag (input; unchanged). TRIP = 0 monitor only TRIP = 1 trip out-of-step circuits
Integer EXCLXFMR	flag to include or exclude transformer for out-of-step check (input; no default allowed). EXCLXFMR = 1 exclude transformer in out-of-step scan EXCLXFMR = 0 do not exclude (i.e., include) transformer in out-of-step scan
Integer ICODE	operation mode of the API (no default allowed). ICODE <= 0 set the option setting to the value specified in STATUS, TRIP, and EXCLXFMR. ICODE > 0 return the current value of the option setting in STATUS, TRIP, and EXCLXFMR.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 prerequisite requirements for API are not met

7.1.65. SET_OSSCAN_SUBSYS_FLAG

Use this API for get/set the flag that is used for the subsystem definition for performing scans for out-of-step conditions using a generic relay.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_OSSCAN_SUBSYS_FLAG ALL SID
```

Python command syntax:

```
ierr = set_osscan_subsys_flag(all, sid)
ierr, all = set_osscan_subsys_flag()
```

Fortran command syntax:

```
CALL SET_OSSCAN_SUBSYS_FLAG(ALL, SID, ICODE, IERR)
```

Where:

Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ICODE	indicates the operation mode of the API (no default allowed). ICODE ≤ 0 set the option setting to the value specified in ALL ICODE > 0 return the current value of the option setting in ALL
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid ALL value IERR = 2 invalid SID value IERR = 3 prerequisite requirements for API are not met

7.1.66. SET_RELANG

Use this API to enable or disable the simulation option setting that expresses the ANGLE array relative to a designated reference angle.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_RELANG SWITCH IBUSEX 'ID'
```

Python command syntax:

```
ierr = set_relang(switch, ibusex, id)
ierr, switch, ibusex, id = set_relang()
```

Fortran command syntax:

```
CALL SET_RELANG(SWITCH, IBUSEX, ID, ICODE, IERR)
```

Where:

Integer SWITCH	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	SWITCH = 0 disable relative angle calculation (use absolute angles)
	SWITCH = 1 enable relative angle calculation
Integer IBUSEX	relative angle calculation to be applied (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	IBUSEX > 0 use machine ID at bus IBUSEX as the reference machine
	IBUSEX = 0 use system average angle
	IBUSEX = -1 use system weighted average angle
Character*2 ID	machine identifier (input; if batch command or ICODE is 0 or negative; '1' by default) (if ICODE is positive).
Integer ICODE	operation mode of the API (no default allowed).
	ICODE < 0 set the option setting to the value specified in SWITCH and the relative angle parameters to the values specified in IBUSEX and ID.
	ICODE > 0 return the current value of the option setting in SWITCH and the relative angle parameters in IBUSEX and ID.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid IBUSEX value
	IERR = 2 bus not found
	IERR = 3 machine not found
	IERR = 4 prerequisite requirements for API are not met

7.1.67. SET_RELSCN

Use this API to enable or disable the simulation option setting that scans branches using a generic branch relay.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_RELSCN STATUS
```

Python command syntax:

```
ierr = set_relscn(status)

ierr, status = set_relscn()
```

Fortran command syntax:

```
CALL SET_RELSCN(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 0 disable relay scanning
	STATUS = 1 enable relay scanning
Integer ICODE	operation mode of the API (no default allowed).
	ICODE < 0 set the option setting to the value specified in STATUS
	ICODE > 0 return the current value of the option setting in STATUS
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 prerequisite requirements for API are not met

7.1.68. SET_RELSCN_SUBSYS_FLAG

Use this API api for get/set the flag that is used for the subsystem definition for performing scans of branches using a generic branch relay.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_RELSCN_SUBSYS_FLAG ALL SID
```

Python command syntax:

```
ierr = set_relscn_subsys_flag(all, sid)
ierr, all = set_relscn_subsys_flag()
```

Fortran command syntax:

```
CALL SET_RELSCN_SUBSYS_FLAG(ALL, SID, ICODE, IERR)
```

Where:

Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ICODE	indicates the operation mode of the API (no default allowed). ICODE ≤ 0 set the option setting to the value specified in ALL ICODE > 0 return the current value of the option setting in ALL
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid ALL value IERR = 2 invalid SID value IERR = 3 prerequisite requirements for API are not met

7.1.69. SET_VLTSCN

Use this API to enable or disable the simulation option setting that scans buses for high or low values of voltage magnitude.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SET_VLTSCN STATUS VHI VLO
```

Python command syntax:

```
ierr = set_vltscn(status, vhi, vlo)
ierr, status, vhi, vlo = set_vltscn()
```

Fortran command syntax:

```
CALL SET_VLTSCN(STATUS, VHI, VLO, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	STATUS = 1 enable voltage scanning
	STATUS = 1 disable voltage scanning
Real VHI	high voltage threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Real VLO	low voltage threshold (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
Integer ICODE	operation mode of the API (no default allowed).
	ICODE < 0 set the option setting to the value specified in STATUS and the voltage limits to VHI and VLO.
	ICODE > 0 return the current value of the option setting in STATUS and the voltage limits in VHI and VLO.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid specification of VHI and VLO
	IERR = 2 prerequisite requirements for API are not met

7.1.70. SET_VLTSCN_SUBSYS_FLAG

Use this API api for get/set the flag that is used for the subsystem definition for performing scans of buses for high or low voltage magnitudes.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SET_VLTSCN_SUBSYS_FLAG ALL SID
```

Python command syntax:

```
ierr = set_vltscn_subsys_flag(all, sid)
ierr, all = set_vltscn_subsys_flag()
```

Fortran command syntax:

```
CALL SET_VLTSCN_SUBSYS_FLAG(ALL, SID, ICODE, IERR)
```

Where:

Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ICODE	indicates the operation mode of the API (no default allowed). ICODE ≤ 0 set the option setting to the value specified in ALL ICODE > 0 return the current value of the option setting in ALL
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid ALL value IERR = 2 invalid SID value IERR = 3 prerequisite requirements for API are not met

7.1.71. SET_VOLTAGE_DIP_CHECK

This API is used to enable or disable the simulation option setting which scans buses for voltage dip (back-swing).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SET_VOLTAGE_DIP_CHECK VDPCHK VDPTHR VDPDUR
```

Python command syntax:

```
ierr = set_voltage_dip_check(vdpchk, vdpthr, vdpdur)
ierr, vdpchk, vdpthr, vdpdur = set_voltage_dip_check()
```

Fortran command syntax:

```
CALL SET_VOLTAGE_DIP_CHECK(VDPCHK, VDPTHR, VDPDUR, ICODE, IERR)
```

Where:

Integer VDPCHK	(input; flag to set voltage dip check: if command or ICODE is 0 or negative; unchanged). VDPCHK = 0 disable voltage dip check VDPCHK = 1 enable voltage dip check
Real VDPTHR	(input; voltage dip threshold in per unit: if batch command or ICODE is 0 or negative; unchanged by default. if ICODE is positive. If the voltage swings-back below this threshold a timer is initiated to check for the dip duration).
Real VDPDUR	(input; voltage dip duration in seconds: if batch command or ICODE is 0 or negative; unchanged).
Integer ICODE	operation mode of API (no default allowed). ICODE ≤ 0 set the option setting to the value specified in VDPCHK, VDPTHR, and VDPDUR. ICODE > 0 return the current value of the option setting in VDPCHK, VDPTHR, and VDPDUR.
Integer IERR	error code (output). IERR = 0 no error IERR = 1 prerequisite requirements for API not met

7.1.72. SET_VOLTAGE_REC_CHECK

This API is used to enable or disable the simulation option setting which scans buses for voltage recovery (primary and secondary recovery).

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SET_VOLTAGE_REC_CHECK VPRCHK VSRCHK VPRTHR VPRTIM VSRTHR
VSRTIM
```

Python command syntax:

```
ierr = set_voltage_rec_check(vprchk, vsrchk, vprthr, vprtim, vsrthr,
vsrtim)

ierr, vprchk, vsrchk, vprthr, vprtim, vsrthr, vsrtim =
set_voltage_rec_check()
```

Fortran command syntax:

```
CALL SET_VOLTAGE_REC_CHECK(VPRCHK, VSRCHK, VPRTHR, VPRTIM, VSRTHR, VSRTIM,
ICODE, IERR)
```

Where:

Integer VPRCHK	(input; flag to set voltage primary recovery check: if batch command or ICODE is 0 or negative; unchanged). VPRCHK = 0 disable primary recovery check VPRCHK = 1 enable primary recovery check
Integer VSRCHK	(input; flag to set voltage secondary recovery check: if batch command or ICODE is 0 or negative; unchanged). VSRCHK = 0 disable secondary recovery check VSRCHK = 1 enable secondary recovery check
Real VPRTHR	(input; voltage primary recovery threshold in per unit: if batch command or ICODE is 0 or negative; unchanged).
Real VPRTIM	(input; voltage primary recovery time in seconds: if batch command or ICODE is 0 or negative; unchanged).
Real VSRTHR	(input; voltage secondary recovery threshold in per unit: if batch command or ICODE is 0 or negative; unchanged).
Real VSRTIM	(input; voltage secondary recovery time in seconds: if batch command or ICODE is 0 or negative; unchanged).
Integer ICODE	operation mode of API (no default allowed). ICODE ≤ 0 set the option setting to the value specified in VPRCHK, VSRCHK, VPRTHR, VPRTIM, VSRTHR and VSRTIM. ICODE > 0 return the current value of the option setting in VPRCHK, VSRCHK, VPRTHR, VPRTIM, VSRTHR and VSRTIM.

Integer IERR

error code (output).

IERR = 0	no error
IERR = 1	invalid specification of VPRTHR and VSRTHR
IERR = 2	invalid specification of VPRTIM and VSRTIM
IERR = 3	prerequisite requirements for API not met

7.1.73. SET_VOLT_VIOL_SUBSYS_FLAG

This API is used to set the flag to denote the bus subsystem to be used for voltage violation (voltage recovery and voltage dip) checks.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SET_VOLT_VIOL_SUBSYS_FLAG  ALL
```

Python command syntax:

```
ierr = set_volt_viol_subsys_flag(all)
ierr, all = set_volt_viol_subsys_flag()
```

Fortran command syntax:

```
CALL SET_VOLT_VIOL_SUBSYS_FLAG(ALL, ICODE, IERR)
```

Where:

Integer ALL	flag to set the subsystem definition for performing voltage violation check (input; if batch command or ICODE is 0 or negative; unchanged by default) (if ICODE is positive).
	ALL = 0 Use existing bus subsystem definition
	ALL = 1 Do voltage violation check on all buses
Integer ICODE	Indicates the operation mode of API (no default allowed).
	ICODE ≤ 0 set the option setting to the value specified in ALL
	ICODE > 0 return the current value of the option setting in ALL
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 Invalid ALL value
	IERR = 2 prerequisite requirements for API not met

7.1.74. SET_ZSORCE_RECONCILE_FLAG

Use this API to enable or disable the simulation option setting for automatic ZSORCE reconciliation.

This API routine was first introduced in release 33.10.0 and 34.2.0.

Batch command syntax:

```
BAT_SET_ZSORCE_RECONCILE_FLAG STATUS
```

Python command syntax:

```
ierr = set_zsorce_reconcile_flag(status)

ierr, status = set_zsorce_reconcile_flag()
```

Fortran command syntax:

```
CALL SET_ZSORCE_RECONCILE_FLAG(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input; if Batch command or for Python if specified as an argument, or for Fortran if ICODE is 0; no default allowed).
	STATUS = 0 disable ZSORCE reconciliation
	STATUS = 1 enable ZSORCE reconciliation
Integer ICODE	operation mode of the API (no default allowed).
	ICODE = 0 set the option setting to the value specified in STATUS
	ICODE = 1 return the current value of the option setting in STATUS
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 prerequisite requirements for API are not met

7.1.75. SIZE_DS

Use this API to obtain a summary of utilization in the general purpose dynamics data storage arrays as well as in the various model connection and allocation tables contained in dynamics working memory.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_SIZE_DS
```

Python command syntax:

```
ierr = size_ds()
```

Fortran command syntax:

```
CALL SIZE_DS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

7.1.76. SNAP

Use this API to save PSSE dynamics working memory into a Snapshot file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_SNAP STATUS(1)..STATUS(5) SFILE
```

Python command syntax:

```
ierr = snap(status, sfile)
```

Fortran command syntax:

```
CALL SNAPNW(STATUS, SFILE, IERR)
```

Where:

Integer STATUS (5)	array of 5 elements specifying save options. For each entry, -1 may be specified to indicate that the number of elements of the corresponding array(s) to save in the Snapshot File is 1 through the next available - 1(input).
STATUS(1)	number of CONs to save (next available-1 by default)
STATUS(2)	number of STATES to save (next available-1 by default)
STATUS(3)	number of VARs to save (next available-1 by default)
STATUS(4)	number of ICONs to save (next available-1 by default)
STATUS(5)	number of channels to save (next available-1 by default)
Character*260 SFILE	snapshot file; '*' to use the most recently accessed snapshot file in the current execution of PSSE (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	invalid STATUS value
IERR = 2	error opening SFILE
IERR = 3	error writing to SFILE
IERR = 4	prerequisite requirements for API are not met

7.1.77. STRT

This API routine is obsolete. It has been replaced by the API routine [strt_2](#).

Use this API to initialize a PSSE dynamic simulation for state-space simulations (i.e., in preparation for activity RUN) and to specify the channel output file into which the output channel values are to be recorded during the dynamic simulation.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_STRT  OPTION  OUTFILE
```

Python command syntax:

```
ierr = strt(option, outfile)
```

Fortran command syntax:

```
CALL STRTAPI(OPTION, OUTFILE, IERR)
```

Where:

Integer OPTION	network solution convergence monitor option (input; 0 by default).	
	OPTION = 0	print the convergence monitor only if it is enabled via the CM interrupt control code.
	OPTION = 1	automatically print the convergence monitor.
Character*260 OUTFILE	name of the channel output file (blank to bypass recording of the output channel values in a Channel Output File) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	generators are not converted
	IERR = 2	invalid OPTION value
	IERR = 3	Prior initialization modified the loads--pick up original converted case
	IERR = 4	error opening OUTFILE
	IERR = 5	prerequisite requirements for API are not met

7.1.78. STRT_2

This API routine is the second release of the dynamic simulation initialization function. Use this API routine to initialize a PSSE dynamic simulation for state-space simulations (i.e., in preparation for activity RUN) and to specify the channel output file into which the output channel values are to be recorded during the dynamic simulation.

This API routine was first introduced in release 33.9.0 and 34.2.0.

Batch command syntax:

```
BAT_STRT_2  OPTIONS  OUTFILE
```

Python command syntax:

```
ierr = strt_2(options, outfile)
```

Fortran command syntax:

```
CALL STRT_2(OPTIONS, OUTFILE, IERR)
```

Where:

Integer OPTIONS (2)	array of 2 elements specifying simulation initialization options(input).	
	OPTIONS(1)	Network solution convergence monitor option
	OPTIONS(1) = 0	bypass printing of the network solution convergence monitor
	OPTIONS(1) = 1	print the network solution convergence monitor
	OPTIONS(2)	Missing machine model netting option.
	OPTIONS(2) = 0	treat as a fatal error
	OPTIONS(2) = 1	net machine power
Character*260 OUTFILE	channel output file (blank to bypass recording of the output channel values in a channel output file) (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	generators are not converted
	IERR = 2	invalid OPTIONS value
	IERR = 3	prior initialization modified the loads - pick up original converted case
	IERR = 4	error opening OUTFILE
	IERR = 5	prerequisite requirements for API are not met

7.1.79. SWSLIST

Use this API to list switched shunt models connected to subsystem buses along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SWSLIST  SID  ALL  STATUS
```

Python command syntax:

```
ierr = swslist(sid, all, status)
```

Fortran command syntax:

```
CALL SWSLIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).	
Integer ALL	all buses or specified subsystem flag (input; 1 by default).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS	active/bypassed flag (input; 0 by default).	
	STATUS = 0	active and bypassed models
	STATUS = 1	active models only
	STATUS = 2	bypassed models only
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	prerequisite requirements for API are not met

7.1.80. TRIG_VOLT_VIOLATION_CHECK

This API is used to trigger voltage violation (voltage recovery, voltage dip) checks.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_TRIG_VOLT_VIOLATION_CHECK STATUS
```

Python command syntax:

```
ierr = trig_volt_violation_check(status)
ierr, status = trig_volt_violation_check()
```

Fortran command syntax:

```
CALL TRIG_VOLT_VIOLATION_CHECK(STATUS, ICODE, IERR)
```

Where:

Integer STATUS	option setting (input).	
	STATUS = 0	disable voltage violation check
Integer ICODE	STATUS = 1	trigger voltage violation
	operation mode of the API (no default allowed).	
	ICODE ≤ 0	set the option setting to the value specified in STATUS
Integer IERR	ICODE > 0	return the current value of the option setting in STATUS
	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API not met

7.1.81. WNLIST

Use this API to list wind models connected to subsystem buses along with their storage locations in the dynamics data arrays.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNLIST  SID  ALL  STATUS
```

Python command syntax:

```
ierr = wnlist(sid, all, status)
```

Fortran command syntax:

```
CALL WNLIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 0 process only buses in subsystem SID. ALL = 1 process all buses.
Integer STATUS (2)	array of 2 elements specifying API options(input). STATUS(1) active/bypassed flag (0 by default) STATUS(1) = 0 active and bypassed models STATUS(1) = 1 active models only STATUS(1) = 2 bypassed models only STATUS(2) wind model type (1 by default) STATUS(2) = 1 all wind models STATUS(2) = 2 wind generator models STATUS(2) = 3 wind electrical models STATUS(2) = 4 wind mechanical models STATUS(2) = 5 wind pitch models STATUS(2) = 6 wind aerodynamic models STATUS(2) = 7 wind gust models STATUS(2) = 8 wind auxiliary signal models
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.2. Output Channel Operations

Output Channel Operations contains API routines that deals with managing channel output operations, and with assigning quantities to output channels.

7.2.1. Dynamic Simulation Output Channel Operation

7.2.1.1. CHANGE_CHANNEL

Use this API to change the channel address and the channel identifier of a specified output channel.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_CHANNEL CHNARG ADRARG IDNARG
```

Python command syntax:

```
ierr = change_channel(chnarg, adrarg, idnarg)
```

Fortran command syntax:

```
CALL CHANGE_CHANNEL(CHNARG, ADRARG, IDNARG, IERR)
```

Where:

Integer CHNARG	channel number for which the channel address and/or channel identifier has to be changed (input; no default allowed).	
Integer ADRARG	channel address (input; unchanged).	
Character*32 IDNARG	channel identifier (input; unchanged).	
Integer IERR	error code (output).	
	IERR = -1	warnings - one or more of: - channel number is larger than NCHAN
	IERR = 0	no error
	IERR = 1	invalid channel number
	IERR = 2	channel number is at or beyond the next available channel
	IERR = 3	invalid channel address
	IERR = 4	prerequisite requirements for API are not met

7.2.1.2. CHSB

Use this API to specify, on a subsystem basis, the simulation variables to monitor during dynamic simulation runs (activity CHSB).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHSB  SID  ALL  STATUS(1)..STATUS(6)
```

Python command syntax:

```
ierr = chsb(sid, all, status)
```

Fortran command syntax:

```
CALL CHSBNW(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid area, bus, owner, or zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Area, bus, owner, or zone subsystem SID must have been previously defined (input; 0 by default).
Integer ALL	all buses or specified subsystem flag (input; 1 by default). ALL = 1 process all buses ALL = 0 process only buses in subsystem SID
Integer STATUS (6)	array of 6 elements specifying (input). STATUS(1) starting channel index, or -1 for the next available (next available by default) STATUS(2) starting VAR index, or -1 for the next available (next available by default) STATUS(3) starting ICON index, or -1 for the next available (next available by default) STATUS(4) used to indicate the type of quantities to be placed in channels (1 by default) STATUS(4) = 1 machine, bus, load, branch quantities by bus subsystem STATUS(4) = 2 tie quantity by area subsystem STATUS(4) = 3 tie quantity by zone subsystem STATUS(4) = 4 power totals for an area subsystem STATUS(4) = 5 power totals for a zone subsystem STATUS(4) = 6 power totals for an owner subsystem STATUS(4) = 7 power totals for all buses STATUS(4) = 8 machine angle statistics STATUS(5) quantity code (1 by default). If STATUS(4) = 4, 5, 6, 7 or 8 then STATUS(5) is ignored If STATUS(4) = 1: STATUS(5) = 1 ANGLE, machine relative rotor angle (degrees).

STATUS(5) = 2	PELEC, machine electrical power (pu on SBASE).
STATUS(5) = 3	QELEC, machine reactive power.
STATUS(5) = 4	ETERM, machine terminal voltage (pu).
STATUS(5) = 5	EFD, generator main field voltage (pu).
STATUS(5) = 6	PMECH, turbine mechanical power (pu on MBASE).
STATUS(5) = 7	SPEED, machine speed deviation from nominal (pu).
STATUS(5) = 8	XADIFD, machine field current (pu).
STATUS(5) = 9	ECOMP, voltage regulator compensated voltage (pu).
STATUS(5) = 10	VOTHSG, stabilizer output signal (pu).
STATUS(5) = 11	VREF, voltage regulator voltage setpoint (pu).
STATUS(5) = 12	BSFREQ, bus pu frequency deviations.
STATUS(5) = 13	VOLT, bus pu voltages (complex).
STATUS(5) = 14	voltage and angle
STATUS(5) = 15	flow (P).
STATUS(5) = 16	flow (P and Q).
STATUS(5) = 17	flow (MVA).
STATUS(5) = 18	apparent impedance (R and X).
STATUS(5) = 21	ITERM.
STATUS(5) = 22	machine apparent impedance
STATUS(5) = 23	VUEL, minimum excitation limiter output signal (pu).
STATUS(5) = 24	VOEL, maximum excitation limiter output signal (pu).
STATUS(5) = 25	PLOAD.
STATUS(5) = 26	QLOAD.
STATUS(5) = 27	GREF, turbine governor reference.
STATUS(5) = 28	LCREF, turbine load control reference.
STATUS(5) = 29	WVLCTY, wind velocity (m/s).
STATUS(5) = 30	WTRBSP, wind turbine rotor speed deviation (pu).
STATUS(5) = 31	WPITCH, pitch angle (degrees).
STATUS(5) = 32	WAEROT, aerodynamic torque (pu on MBASE).
STATUS(5) = 33	WROTRV, rotor voltage (pu on MBASE).
STATUS(5) = 34	WROTRI, rotor current (pu on MBASE).
STATUS(5) = 35	WPCMND, active power command from wind control (pu on MBASE).
STATUS(5) = 36	WQCMND, reactive power command from wind control (pu on MBASE).

	STATUS(5) = 37	WAUXSG, output of wind auxiliary control (pu on MBASE).
	STATUS(6)	out-of-service equipment option (0 by default)
	STATUS(6) = 0	omit out-of-service equipment
	STATUS(6) = 1	include out-of-service equipment
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	have just assigned channel n, which is the highest channel number
	IERR = 5	trying to assign locations beyond the end of the VAR or ICON array
	IERR = 6	machine angle statistics are already assigned to channels
	IERR = 7	n monitoring models specified--pointer table full
	IERR = 8	next channel is greater than the maximum allowed channel number
	IERR = 9	prerequisite requirements for API are not met

7.2.1.3. CRT_PLOT_CHANNEL

Use this API to assign one of the main simulation output channels to a designated CRT plot channel.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CRT_PLOT_CHANNEL CRTCHAN CHANNEL CMIN CMAX
```

Python command syntax:

```
ierr = crt_plot_channel(crtchan, channel, cmin, cmax)
```

Fortran command syntax:

```
CALL CRT_PLOT_CHANNEL(CRTCHAN, CHANNEL, CMIN, CMAX, IERR)
```

Where:

Integer CRTCHAN	CRT plot channel number (1 through 6) (input; no default allowed).	
Integer CHANNEL	number of the main simulation channel to be assigned to CRT channel number CRTCHAN (must be between 1 and the number of output channels allowed at the present size level of PSSE), or 0 to disable CRT plot channel CRTCHAN (input; unchanged).	
Real CMIN	minimum plotting scale value for this CRT plot channel (input; unchanged).	
Real CMAX	maximum plotting scale value for this CRT plot channel (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	error occurred
	IERR = 1	invalid CRTCHAN value
	IERR = 2	invalid CHANNEL value
	IERR = 3	CMIN is not less than CMAX
	IERR = 4	prerequisite requirements for API are not met
	IERR = -1	warnings - one or more of: - CHANNEL is larger than NCHAN

7.2.1.4. DELETE_ALL_PLOT_CHANNELS

Use this API to delete all the plot channels in the working case. Use of this API will reset the number of plot channels to zero and the next channel to one.

This API routine was first introduced in release 32.2.1.

Batch command syntax:

```
BAT_DELETE_ALL_PLOT_CHANNELS
```

Python command syntax:

```
ierr = delete_all_plot_channels()
```

Fortran command syntax:

```
CALL DELETE_ALL_PLOT_CHANNELS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

7.2.1.5. DMPC

Use this API to replicate the output channel specifications from dynamics working memory in the form of a response file suitable for transferring them to another snapshot that models essentially the same system.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DMPC  OPTIONS(1) .. OPTIONS(4)  OUT  OFILE
```

Python command syntax:

```
ierr = dmpe(options, out, ofile)
```

Fortran command syntax:

```
CALL DMPCAPI(OPTIONS, OUT, OFILE, IERR)
```

Where:

Integer OPTIONS (4)	array of 4 elements specifying (input).
OPTIONS(1)	channel selection code (1 by default)
OPTIONS(1) = 0	skip channels containing STATES or VARs not associated with channel monitoring models
OPTIONS(1) = 1	include all channels
OPTIONS(2)	starting channel code (-1 by default)
OPTIONS(2) < 0	start at next available channel
OPTIONS(2) = 0	keep existing channel numbers
OPTIONS(2) > 0	starting channel number
OPTIONS(3)	starting VAR code for channel monitoring models (-1 by default)
OPTIONS(3) < 0	start at next available VAR
OPTIONS(3) = 0	keep existing VAR indices
OPTIONS(3) > 0	starting VAR index
OPTIONS(4)	starting ICON code for channel monitoring models (-1 by default)
OPTIONS(4) < 0	start at next available ICON
OPTIONS(4) = 0	keep existing ICON indices
OPTIONS(4) > 0	starting ICON index
Integer OUT	destination selection (input; 1 by default).
OUT = 0	direct output to a data file specified by OFILE
OUT = 1	direct output to the current report device
Character*260 OFILE	name of the file to which data records are to be written (when OUT is 0) (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid OPTIONS(1) value

IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	invalid OUT value
IERR = 6	error opening file OFILE
IERR = 7	prerequisite requirements for API are not met

7.2.1.6. LIST_CHANNEL_MODELS

Use this API to tabulate the output channel monitoring models referenced in the dynamic model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

BAT_LIST_CHANNEL_MODELS STATUS

Python command syntax:

ierr = list_channel_models(status)

Fortran command syntax:

CALL LIST_CHANNEL_MODELS(STATUS, IERR)

Where:

Integer STATUS	category of channel monitoring models to be listed (input; 0 by default).	
	STATUS = 0	all output channel monitoring models
	STATUS = 1	only models monitoring equipment that exists in the power flow working case
	STATUS = 2	only models monitoring equipment that is not present in the power flow working case
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid STATUS value
	IERR = 2	prerequisite requirements for API are not met

7.2.1.7. REMOVE_UNUSED_CHAN_MODELS

Use this API to delete from the output channel monitoring model table those model references indicating equipment that is not present in the power flow working case.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_REMOVE_UNUSED_CHAN_MODELS
```

Python command syntax:

```
ierr = remove_unused_chan_models()
```

Fortran command syntax:

```
CALL REMOVE_UNUSED_CHAN_MODELS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	prerequisite requirements for API are not met

7.2.2. Assign Machine Quantities to Output Channels

7.2.2.1. MACHINE_APP_R_X_CHANNEL

Use this API to add a pair of output channels containing the apparent impedance of the system, as seen from the terminals of a specified machine, along with a corresponding call to the GENTMZ monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MACHINE_APP_R_X_CHANNEL STATUS(1) . . STATUS(4) 'ID' 'IDENT(1)'
'IDENT(2)'
```

Python command syntax:

```
ierr = machine_app_r_x_channel(status, id, ident)
```

Fortran command syntax:

```
CALL MACHINE_APP_R_X_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (4)	array of 4 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the bus to which the machine for which the apparent impedance is to be placed in channels is connected (no default allowed)
Character*2 ID	machine identifier (input; '1' by default).
Character*32 IDENT (2)	two identifiers to be assigned to the two channels. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed

IERR = 5	model GENTMZ needs 2 VARs but the last one exceeds the largest VAR index allowed
IERR = 6	model GENTMZ needs 2 ICONs but the last one exceeds the largest ICON index allowed
IERR = 7	the maximum number of channel monitoring models has already been specified
IERR = 8	model GENTMZ needs 2 channels but the last one exceeds the largest channel number allowed
IERR = 9	bus not found
IERR = 10	machine not found
IERR = 11	prerequisite requirements for API are not met

7.2.2.2. MACHINE_ARRAY_CHANNEL

Use this API to add an output channel containing a plant related model variable of a designated type for a specified machine.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MACHINE_ARRAY_CHANNEL STATUS(1) .. STATUS(3) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = machine_array_channel(status, id, ident)
```

Fortran command syntax:

```
CALL MACHINE_ARRAY_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (3)	array of 3 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	used to indicate the quantity to be placed in an channel (1 by default)
STATUS(2) = 1	ANGLE, machine relative rotor angle (degrees)
STATUS(2) = 2	PELEC, machine electrical power (pu on SBASE)
STATUS(2) = 3	QELEC, machine reactive power
STATUS(2) = 4	ETERM, machine terminal voltage (pu)
STATUS(2) = 5	EFD, generator main field voltage (pu)
STATUS(2) = 6	PMECH, turbine mechanical power (pu on MBASE)
STATUS(2) = 7	SPEED, machine speed deviation from nominal (pu)
STATUS(2) = 8	XADIFD, machine field current (pu)
STATUS(2) = 9	ECOMP, voltage regulator compensated voltage (pu)
STATUS(2) = 10	VOTHSG, stabilizer output signal (pu)
STATUS(2) = 11	VREF, voltage regulator voltage setpoint (pu)
STATUS(2) = 12	VUEL, minimum excitation limiter output signal (pu)
STATUS(2) = 13	VOEL, maximum excitation limiter output signal (pu)
STATUS(2) = 14	GREF, turbine governor reference
STATUS(2) = 15	LCREF, turbine load control reference
STATUS(2) = 16	WVLCTY, wind velocity (m/s)

	STATUS(2) = 17	WTRBSP, wind turbine rotor speed deviation (pu)
	STATUS(2) = 18	WPITCH, pitch angle (degrees)
	STATUS(2) = 19	WAEROT, aerodynamic torque (pu on MBASE)
	STATUS(2) = 20	WROTRV, rotor voltage (pu on MBASE)
	STATUS(2) = 21	WROTRI, rotor current (pu on MBASE)
	STATUS(2) = 22	WPCMND, active power command from wind control (pu on MBASE)
	STATUS(2) = 23	WQCMND, reactive power command from wind control (pu on MBASE)
	STATUS(2) = 24	WAUXSG, output of wind auxiliary control (pu on MBASE)
	STATUS(3)	number of the bus to which the machine for which the quantity is to be placed in an channel is connected (no default allowed)
Character*2 ID	machine identifier (input; '1' by default).	
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid STATUS value
	IERR = 2	starting channel number is greater than the largest channel number allowed
	IERR = 3	bus not found
	IERR = 4	machine not found
	IERR = 5	prerequisite requirements for API are not met

7.2.2.3. MACHINE_ITEM_CHANNEL

Use this API to add an output channel containing the terminal current of a specified machine, along with a corresponding call to the GENTMC monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MACHINE_ITEM_CHANNEL STATUS(1)..STATUS(4) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = machine_itterm_channel(status, id, ident)
```

Fortran command syntax:

```
CALL MACHINE_ITEM_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (4)	array of 4 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the bus to which the machine for which the terminal current is to be placed in an channel is connected (no default allowed)
Character*2 ID	machine identifier (input; '1' by default).
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model GENTMC needs 2 VARs but the last one exceeds the largest VAR index allowed
IERR = 6	model GENTMC needs 2 ICONs but the last one exceeds the largest ICON index allowed
IERR = 7	the maximum number of channel monitoring models has already been specified

IERR = 8	bus not found
IERR = 9	machine not found
IERR = 10	prerequisite requirements for API are not met

7.2.3. Assign Branch Quantities to Output Channels

7.2.3.1. BRANCH_APP_R_X_CHANNEL

Use this API to add a pair of output channels containing the apparent impedance, as seen at the from bus of a specified branch, along with a corresponding call to the RELAY2 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_BRANCH_APP_R_X_CHANNEL STATUS(1)..STATUS(5) 'ID' 'IDENT(1)'
'IDENT(2)'
```

Python command syntax:

```
ierr = branch_app_r_x_channel(status, id, ident)
```

Fortran command syntax:

```
CALL BRANCH_APP_R_X_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (5)	array of 5 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the branch for which apparent impedance is to be placed in channels (no default allowed)
STATUS(5)	number of the to bus of the branch for which apparent impedance is to be placed in channels (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT (2)	two identifiers to be assigned to the two channels. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed

IERR = 5	model RELAY2 needs 3 ICONs but the last one exceeds the largest ICON index allowed
IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	model RELAY2 needs 2 VARs but the last one exceeds the largest VAR index allowed
IERR = 8	model RELAY2 needs 2 channels but the last one exceeds the largest channel number allowed
IERR = 9	bus not found
IERR = 10	branch not found
IERR = 11	prerequisite requirements for API are not met

7.2.3.2. BRANCH_MVA_CHANNEL

Use this API to add an output channel containing the MVA flow at the from bus of a specified branch, along with a corresponding call to the FLOW1 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_BRANCH_MVA_CHANNEL STATUS(1)..STATUS(5) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = branch_mva_channel(status, id, ident)
```

Fortran command syntax:

```
CALL BRANCH_MVA_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (5)	array of 5 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the branch for which MVA flow is to be placed in an channel (no default allowed)
STATUS(5)	number of the to bus of the branch for which MVA is to be placed in an channel (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model FLOW1 needs 3 ICONs but the last one exceeds the largest ICON index allowed

IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	bus not found
IERR = 8	branch not found
IERR = 9	prerequisite requirements for API are not met

7.2.3.3. BRANCH_P_AND_Q_CHANNEL

Use this API to add a pair of output channels containing the active and reactive power flow at the from bus of a specified branch, along with a corresponding call to the FLOW1 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_BRANCH_P_AND_Q_CHANNEL STATUS(1)..STATUS(5) 'ID' 'IDENT(1)'
'IDENT(2)'
```

Python command syntax:

```
ierr = branch_p_and_q_channel(status, id, ident)
```

Fortran command syntax:

```
CALL BRANCH_P_AND_Q_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (5)	array of 5 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the branch for which active and reactive power flows are to be placed in channels (no default allowed)
STATUS(5)	number of the to bus of the branch for which active and reactive power flows are to be placed in channels (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT (2)	two identifiers to be assigned to the two channels. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model FLOW1 needs 3 ICONs but the last one exceeds the largest ICON index allowed

IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	model FLOW1 needs 2 VARs but the last one exceeds the largest VAR index allowed
IERR = 8	model FLOW1 needs 2 channels but the last one exceeds the largest channel number allowed
IERR = 9	bus not found
IERR = 10	branch not found
IERR = 11	prerequisite requirements for API are not met

7.2.3.4. BRANCH_P_CHANNEL

Use this API to add an output channel containing the active power flow at the from bus of a specified branch, along with a corresponding call to the FLOW1 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_BRANCH_P_CHANNEL STATUS(1) .. STATUS(5) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = branch_p_channel(status, id, ident)
```

Fortran command syntax:

```
CALL BRANCH_P_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (5)	array of 5 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the branch for which active power flow is to be placed in an channel (no default allowed)
STATUS(5)	number of the to bus of the branch for which active power flow is to be placed in an channel (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model FLOW1 needs 3 ICONs but the last one exceeds the largest ICON index allowed

IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	bus not found
IERR = 8	branch not found
IERR = 9	prerequisite requirements for API are not met

7.2.3.5. THREE_WND_APP_R_X_CHANNEL

Use this API to add a pair of output channels containing the apparent impedance as seen at the from bus of a specified three-winding transformer, along with a corresponding call to the RELAY3 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_THREE_WND_APP_R_X_CHANNEL STATUS(1)..STATUS(6) 'ID' 'IDENT(1)'
  'IDENT(2)'
```

Python command syntax:

```
ierr = three_wnd_app_r_x_channel(status, id, ident)
```

Fortran command syntax:

```
CALL THREE_WINDING_APP_R_X_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (6)	array of 6 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the three-winding transformer for which apparent impedance is to be placed in channels (no default allowed)
STATUS(5)	number of one of the to buses of the three-winding transformer for which apparent impedance is to be placed in channels (no default allowed)
STATUS(6)	number of the third bus of the three-winding transformer for which apparent impedance is to be placed in channels (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT (2)	two identifiers to be assigned to the two channels. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed

IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model RELAY3 needs 4 ICONs but the last one exceeds the largest ICON index allowed
IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	model RELAY3 needs 2 VARs but the last one exceeds the largest VAR index allowed
IERR = 8	model RELAY3 needs 2 channels but the last one exceeds the largest channel number al- lowed
IERR = 9	bus not found
IERR = 10	branch not found
IERR = 11	prerequisite requirements for API are not met

7.2.3.6. THREE_WND_MVA_CHANNEL

Use this API to add an output channel containing the MVA flow at the from bus of a specified three-winding transformer, along with a corresponding call to the FLOW3 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_THREE_WND_MVA_CHANNEL STATUS(1)..STATUS(6) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = three_wnd_mva_channel(status, id, ident)
```

Fortran command syntax:

```
CALL THREE_WINDING_MVA_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (6)	array of 6 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the three-winding transformer for which MVA flow is to be placed in an channel (no default allowed)
STATUS(5)	number of one of the to buses of the three-winding transformer for which MVA flow is to be placed in an channel (no default allowed)
STATUS(6)	number of the third bus of the three-winding transformer for which MVA flow is to be placed in an channel (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed

IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model FLOW3 needs 4 ICONs but the last one exceeds the largest ICON index allowed
IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	bus not found
IERR = 8	branch not found
IERR = 9	prerequisite requirements for API are not met

7.2.3.7. THREE_WND_P_AND_Q_CHANNEL

Use this API to add a pair of output channels containing the active and reactive power flow at the from bus of a specified three-winding transformer, along with a corresponding call to the FLOW3 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_THREE_WND_P_AND_Q_CHANNEL STATUS(1)..STATUS(6) 'ID' 'IDENT(1)'
'IDENT(2)'
```

Python command syntax:

```
ierr = three_wnd_p_and_q_channel(status, id, ident)
```

Fortran command syntax:

```
CALL THREE_WINDING_P_AND_Q_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (6)	array of 6 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the three-winding transformer for which active and reactive power flows are to be placed in channels (no default allowed)
STATUS(5)	number of one of the to buses of the three-winding transformer for which active and reactive power flows are to be placed in channels (no default allowed)
STATUS(6)	number of the third bus of the three-winding transformer for which active and reactive power flows are to be placed in channels (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT (2)	two identifiers to be assigned to the two channels. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid STATUS value
	IERR = 2 starting channel number is greater than the largest channel number allowed

IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model FLOW3 needs 4 ICONs but the last one exceeds the largest ICON index allowed
IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	model FLOW3 needs 2 VARs but the last one exceeds the largest VAR index allowed
IERR = 8	model FLOW3 needs 2 channels but the last one exceeds the largest channel number allowed
IERR = 9	bus not found
IERR = 10	branch not found
IERR = 11	prerequisite requirements for API are not met

7.2.3.8. THREE_WND_P_CHANNEL

Use this API to add an output channel containing the active power flow at the from bus of a specified three-winding transformer, along with a corresponding call to the FLOW3 monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_THREE_WND_P_CHANNEL STATUS(1) .. STATUS(6) 'ID' 'IDENT'
```

Python command syntax:

```
ierr = three_wnd_p_channel(status, id, ident)
```

Fortran command syntax:

```
CALL THREE_WINDING_P_CHANNEL(STATUS, ID, IDENT, IERR)
```

Where:

Integer STATUS (6)	array of 6 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the from bus of the three-winding transformer for which active power flow is to be placed in an channel (no default allowed)
STATUS(5)	number of one of the to buses of the three-winding transformer for which active power flow is to be placed in an channel (no default allowed)
STATUS(6)	number of the third bus of the three-winding transformer for which active power flow is to be placed in an channel (no default allowed)
Character*2 ID	circuit identifier (input; '1' by default).
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed

IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	model FLOW3 needs 4 ICONs but the last one exceeds the largest ICON index allowed
IERR = 6	the maximum number of channel monitoring models has already been specified
IERR = 7	bus not found
IERR = 8	branch not found
IERR = 9	prerequisite requirements for API are not met

7.2.4. Assign Other Quantities to Output Channels

7.2.4.1. BUS_FREQUENCY_CHANNEL

Use this API to add an output channel containing the per unit frequency deviation at a specified bus.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_BUS_FREQUENCY_CHANNEL STATUS(1) STATUS(2) 'IDENT'
```

Python command syntax:

```
ierr = bus_frequency_channel(status, ident)
```

Fortran command syntax:

```
CALL BUS_FREQUENCY_CHANNEL(STATUS, IDENT, IERR)
```

Where:

Integer STATUS (2)	array of 2 elements specifying (input).
	STATUS(1) starting channel index, or -1 for the next available (next available by default)
	STATUS(2) number of the bus for which frequency deviation is to be placed in a channel is connected (no default allowed)
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid STATUS value
	IERR = 2 starting channel number is greater than the largest channel number allowed
	IERR = 3 bus not found
	IERR = 4 prerequisite requirements for API are not met

7.2.4.2. STATE_CHANNEL

Use this API to add an output channel containing the value of a specified STATE.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_STATE_CHANNEL STATUS(1) STATUS(2) 'IDENT'
```

Python command syntax:

```
ierr = state_channel(status, ident)
```

Fortran command syntax:

```
CALL STATE_CHANNEL(STATUS, IDENT, IERR)
```

Where:

Integer STATUS (2)	array of 2 elements specifying (input).	
	STATUS(1)	starting channel index, or -1 for the next available (next available by default)
	STATUS(2)	index of the STATE for which the value is to be placed in an channel (no default allowed)
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid STATUS value
	IERR = 2	starting channel number is greater than the largest channel number allowed
	IERR = 3	invalid STATE index
	IERR = 4	prerequisite requirements for API are not met

7.2.4.3. VAR_CHANNEL

Use this API to add an output channel containing the value of a specified VAR.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VAR_CHANNEL STATUS(1) STATUS(2) 'IDENT'
```

Python command syntax:

```
ierr = var_channel(status, ident)
```

Fortran command syntax:

```
CALL VAR_CHANNEL(STATUS, IDENT, IERR)
```

Where:

Integer STATUS (2)	array of 2 elements specifying (input).	
	STATUS(1)	starting channel index, or -1 for the next available (next available by default)
	STATUS(2)	index of the VAR for which the value is to be placed in an channel (no default allowed)
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid STATUS value
	IERR = 2	starting channel number is greater than the largest channel number allowed
	IERR = 3	invalid VAR index
	IERR = 4	prerequisite requirements for API are not met

7.2.4.4. VOLTAGE_AND_ANGLE_CHANNEL

Use this API to add a pair of output channels containing the voltage magnitude in per unit and phase angle in degrees of a specified bus, along with a corresponding call to the VOLMAG monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VOLTAGE_AND_ANGLE_CHANNEL STATUS(1) . . STATUS(4) ' IDENT(1) '
' IDENT(2) '
```

Python command syntax:

```
ierr = voltage_and_angle_channel(status, ident)
```

Fortran command syntax:

```
CALL VOLTAGE_AND_ANGLE_CHANNEL(STATUS, IDENT, IERR)
```

Where:

Integer STATUS (4)	array of 4 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the bus for which voltage magnitude and phase angle are to be placed in channels (no default allowed)
Character*32 IDENT (2)	two identifiers to be assigned to the two channels. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	the maximum number of channel monitoring models has already been specified
IERR = 6	bus not found
IERR = 7	model VOLMAG needs 2 VARs but the last one exceeds the largest VAR index allowed

IERR = 8	model VOLMAG needs 2 channels but the last one exceeds the largest channel number allowed
IERR = 9	prerequisite requirements for API are not met

7.2.4.5. VOLTAGE_CHANNEL

Use this API to add an output channel containing the voltage magnitude in per unit of a specified bus, along with a corresponding call to the VOLMAG monitoring model.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VOLTAGE_CHANNEL STATUS(1)..STATUS(4) 'IDENT'
```

Python command syntax:

```
ierr = voltage_channel(status, ident)
```

Fortran command syntax:

```
CALL VOLTAGE_CHANNEL(STATUS, IDENT, IERR)
```

Where:

Integer STATUS (4)	array of 4 elements specifying (input).
STATUS(1)	starting channel index, or -1 for the next available (next available by default)
STATUS(2)	starting VAR index, or -1 for the next available (next available by default)
STATUS(3)	starting ICON index, or -1 for the next available (next available by default)
STATUS(4)	number of the bus for which voltage magnitude is to be placed in a channel (no default allowed)
Character*32 IDENT	identifier to be assigned to the channel. If a blank channel identifier is specified, the API generates an appropriate channel identifier (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	invalid STATUS value
IERR = 2	starting channel number is greater than the largest channel number allowed
IERR = 3	starting VAR index is greater than the largest VAR index allowed
IERR = 4	starting ICON index is greater than the largest ICON index allowed
IERR = 5	the maximum number of channel monitoring models has already been specified
IERR = 6	bus not found
IERR = 7	prerequisite requirements for API are not met

7.3. Plant Related Models

7.3.1. ADD_PLANT_MODEL

Use this API to add a plant related model of a designated type to a specified machine. If a model of the designated type already exists at the machine, it is replaced.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ADD_PLANT_MODEL  IBUS  'ID'  MTYPE  'NAME'  IBUS2  'ID2'  NICN  IDATA
                     CHDATA  NCON  RDATA
```

Python command syntax:

```
ierr = add_plant_model(ibus, id, mtype, name, ibus2, id2, nicn, idata,
                      chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_PLANT_MODEL(IBUS, ID, MTYPE, NAME, IBUS2, ID2, NICN, IDATA,
                     CHDATA, NCON, RDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Integer MTYPE	model type (input; 1 by default).
	MTYPE = 1 generator model.
	MTYPE = 2 compensator model.
	MTYPE = 3 stabilizer model.
	MTYPE = 4 minimum excitation limiter model.
	MTYPE = 5 maximum excitation limiter model.
	MTYPE = 6 excitation system model.
	MTYPE = 7 turbine-governor model.
	MTYPE = 8 turbine-load controller model.
Character*16 NAME	model name (input; no default allowed).
Integer IBUS2	bus number of the second machine if this is a two machine model, or 0 for a single machine model (input; 0 by default).
Character*2 ID2	machine identifier of the second machine if this is a two machine model, or '' for a single machine model (input; blank by default).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended

	for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).	
Integer NCON	number of CONs required by the model (input; no default allowed).	
Real RDATA (NCON)	CON data (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	machine model connection tables full--use pack plant model tables function
	IERR = 2	plant model tables are corrupt
	IERR = 3	invalid MTYPE value
	IERR = 4	unknown model NAME
	IERR = 5	model is not consistent with MTYPE
	IERR = 6	# CONs specified is not the number expected
	IERR = 7	# ICONs specified is not the number expected
	IERR = 8	second machine not found where one is re- quired
	IERR = 9	same machine specified as the first and sec- ond machines
	IERR = 10	maximum number of array elements exceed- ed
	IERR = 11	bus not found
	IERR = 12	machine not found
	IERR = 13	prerequisite requirements for API are not met

7.3.2. CHANGE_PLMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of a designated plant related model at a specified machine. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_PLMOD_CHRICN  IBUS  'ID'  'NAME'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_plmod_chricn(ibus, id, name, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_PLMOD_CHRICN(IBUS, ID, NAME, J, CHDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).	
Character*2 ID	machine identifier (input; blank by default).	
Character*16 NAME	model name (input; no default allowed).	
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).	
Character*12 CHDATA	new character ICON value (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model NAME
	IERR = 2	model NAME is not a plant-related model
	IERR = 3	no <model type> model at this machine
	IERR = 4	the <model type> model at this machine is aaa not NAME
	IERR = 5	no input ICONs used in model NAME
	IERR = 6	ICON number outside of the ICON range of this model
	IERR = 7	bus not found
	IERR = 8	machine not found
	IERR = 9	prerequisite requirements for API are not met

7.3.3. CHANGE_PLMOD_CON

Use this API to change the value of a CON of a designated plant related model at a specified machine.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_PLMOD_CON  IBUS  'ID'  'NAME'  J  RDATA
```

Python command syntax:

```
ierr = change_plmod_con(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_PLMOD_CON(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a plant-related model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no CONs used in model NAME
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 bus not found
	IERR = 8 machine not found
	IERR = 9 prerequisite requirements for API are not met

7.3.4. CHANGE_PLMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_PLMOD_CON](#), [CHANGE_PLMOD_ICON](#), and [CHANGE_PLMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of a plant related model of a designated type at a specified machine.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHANGE_PLMOD_DATA  IBUS  'ID'  MTYPE  'NAME'  J  RDATA  I  IDATA
                        'CHDATA'
```

Python command syntax:

```
ierr = change_plmod_data(ibus,id,mtype,name,j,rdata,i,idata,chdata)
```

Fortran command syntax:

```
CALL CHANGE_PLMOD_DATA( IBUS, ID, MTYPE, NAME, J, RDATA, I, IDATA, CHDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; '1' by default).
Integer MTYPE	model type (input; 1 by default).
	MTYPE = 1 generator model.
	MTYPE = 2 compensator model.
	MTYPE = 3 stabilizer model.
	MTYPE = 4 minimum excitation limiter model.
	MTYPE = 5 maximum excitation limiter model.
	MTYPE = 6 excitation system model.
	MTYPE = 7 turbine-governor model.
	MTYPE = 8 turbine-load controller model.
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value,

the CHDATA entry must be either defaulted or specified as either '\$\$' or '''; the character ICON is set to '\$\$' (input; blank by default).

Integer IERR

error code (output).

IERR = 0	no error
IERR = 1	invalid MTYPE value
IERR = 2	unknown model NAME
IERR = 3	no model of type MTYPE at this machine
IERR = 4	type MTYPE model at this machine is aaa not xxx
IERR = 5	CON number exceeds the number of CONs used by the model
IERR = 6	ICON number exceeds the number of ICONs used by the model
IERR = 7	neither the CON nor ICON number is positive
IERR = 8	bus not found
IERR = 9	machine not found
IERR = 10	prerequisite requirements for API are not met

7.3.5. CHANGE_PLMOD_ICON

Use this API to change the value of an integer ICON of a designated plant related model at a specified machine. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_PLMOD_ICON  IBUS  'ID'  'NAME'  J  IDATA
```

Python command syntax:

```
ierr = change_plmod_icon(ibus, id, name, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_PLMOD_ICON(IBUS, ID, NAME, J, IDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a plant-related model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no input ICONs used in model NAME
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 bus not found
	IERR = 8 machine not found
	IERR = 9 prerequisite requirements for API are not met

7.3.6. CHANGE_PLMOD_VAR

Use this API to change the value of a VAR of a designated plant related model at a specified machine.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_PLMOD_VAR  IBUS  'ID'  'NAME'  J  RDATA
```

Python command syntax:

```
ierr = change_plmod_var(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_PLMOD_VAR(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a plant-related model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no VARs used in model NAME
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 bus not found
	IERR = 8 machine not found
	IERR = 9 prerequisite requirements for API are not met

7.3.7. GMB_ADD_PLANT_MODEL

Use this API to add a plant related GMB model to a specified machine. If a model of the designated type already exists at the machine, it is replaced.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_GMB_ADD_PLANT_MODEL  IBUS  'ID'  'NAME'  IBUS2 'ID2'  NICN  IDATA
                          CHDATA  NCON  RDATA
```

Python command syntax:

```
ierr = gmb_add_plant_model(ibus, id, name, ibus2, id2, nicn, idata,
                          chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL GMB_ADD_PLANT_MODEL(IBUS, ID, NAME, IBUS2, ID2, NICN, IDATA, CHDATA,
                          NCON, RDATA, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer IBUS2	bus number of the second machine if this is a two machine model, or 0 for a single machine model (input; 0 by default).
Character*2 ID2	machine identifier of the second machine if this is a two machine model, or ' ' for a single machine model (input; blank by default).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ' '; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 machine model connection tables full--use pack plant model tables function
	IERR = 2 plant model tables are corrupt
	IERR = 3 unlicensed GMB model

IERR = 4	error reading GMB model
IERR = 5	GMB model is not a plant type model
IERR = 6	# CONs specified is not the number expected
IERR = 7	# ICONs specified is not the number expected
IERR = 8	second machine not found where one is required
IERR = 9	same machine specified as the first and second machines
IERR = 10	maximum number of array elements exceeded
IERR = 11	number of user-defined models exceeds maximum allowed
IERR = 12	bus not found
IERR = 13	machine not found
IERR = 14	prerequisite requirements for API are not met

7.3.8. PLMOD_CONSISTENCY

Use this API to check consistency among the plant related models referenced at each machine.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLMOD_CONSISTENCY
```

Python command syntax:

```
ierr = plmod_consistency()
```

Fortran command syntax:

```
CALL PLMOD_CONSISTENCY(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.3.9. PLMOD_PACK

Use this API to remove entries that are marked as unused from the plant model connection tables and the plant model array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLMOD_PACK
```

Python command syntax:

```
ierr = plmod_pack()
```

Fortran command syntax:

```
CALL PLMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.3.10. PLMOD_REMOVE

Use this API to remove a plant related model of a designated type from a specified machine.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLMOD_REMOVE  IBUS  'ID'  MTYPE
```

Python command syntax:

```
ierr = plmod_remove(ibus, id, mtype)
```

Fortran command syntax:

```
CALL PLMOD_REMOVE(IBUS, ID, MTYPE, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Integer MTYPE	model type (input; 1 by default).
	MTYPE = 1 generator model
	MTYPE = 2 compensator model
	MTYPE = 3 stabilizer model
	MTYPE = 4 minimum excitation limiter model
	MTYPE = 5 maximum excitation limiter model
	MTYPE = 6 excitation system model
	MTYPE = 7 turbine-governor model
	MTYPE = 8 turbine-load controller model.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid MTYPE value
	IERR = 2 no model of type MTYPE at this machine
	IERR = 3 bus not found
	IERR = 4 machine not found
	IERR = 5 prerequisite requirements for API are not met

7.3.11. PLMOD_STATUS

Use this API to change the status of a plant related model of a designated type at a specified machine.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLMOD_STATUS  IBUS  'ID'  MTYPE  STATUS
```

Python command syntax:

```
ierr = plmod_status(ibus, id, mtype, status)
```

Fortran command syntax:

```
CALL PLMOD_STATUS(IBUS, ID, MTYPE, STATUS, IERR)
```

Where:

Integer IBUS	plant bus number (input; no default allowed).
Character*2 ID	machine identifier (input; blank by default).
Integer MTYPE	model type (input; 1 by default).
	MTYPE = 1 generator model
	MTYPE = 2 compensator model
	MTYPE = 3 stabilizer model
	MTYPE = 4 minimum excitation limiter model
	MTYPE = 5 maximum excitation limiter model
	MTYPE = 6 excitation system model
	MTYPE = 7 turbine-governor model
	MTYPE = 8 turbine-load controller model.
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid MTYPE value
	IERR = 2 no model of type MTYPE at this machine
	IERR = 3 invalid STATUS value
	IERR = 4 bus not found
	IERR = 5 machine not found
	IERR = 6 prerequisite requirements for API are not met

7.3.12. PLMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those plant related models that are assigned to machines that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLMOD_UNCONNECTED OPT
```

Python command syntax:

```
ierr = plmod_unconnected(opt)
```

Fortran command syntax:

```
CALL PLMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected plant models
	OPT = 1	remove unconnected plant models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.3.13. PLMOD_USER

Use this API to list user-written plant model definitions or to remove user-written plant model definitions that are not assigned to any machines (unused) from the user model definition tables.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_PLMOD_USER  OPT
```

Python command syntax:

```
ierr = plmod_user(opt)
```

Fortran command syntax:

```
CALL PLMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).
	OPT = 0 list user-written plant model definitions
	OPT = 1 remove unused user-written plant model definitions
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid OPT value
	IERR = 2 prerequisite requirements for API are not met

7.4. Wind Related Models

7.4.1. ADD_WIND_MODEL

Use this API to add a renewable related model of a designated type to a specified renewable machine. If a model of the designated type already exists at the machine, it is replaced.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ADD_WIND_MODEL  IBUS  'ID'  MTYPE  'NAME'  NICN  IDATA  CHDATA  NCON
                     RDATA
```

Python command syntax:

```
ierr = add_wind_model(ibus, id, mtype, name, nicn, idata, chdata, ncon,
                      rdata)
```

Fortran command syntax:

```
CALL ADD_WIND_MODEL( IBUS, ID, MTYPE, NAME, NICN, IDATA, CHDATA, NCON,
                    RDATA, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Integer MTYPE	model type (input; 1 by default). MTYPE = 1 wind generator model). MTYPE = 2 renewable electrical control model MTYPE = 3 renewable mechanical system model MTYPE = 4 renewable pitch control model MTYPE = 5 renewable aerodynamic model MTYPE = 6 renewable gust model MTYPE = 7 renewable auxiliary control model
Character*16 NAME	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).

IERR = 0	no error
IERR = 1	renewable machine model connection tables full--use pack renewable model tables func- tion
IERR = 2	renewable model tables are corrupt
IERR = 3	invalid MTYPE value
IERR = 4	unknown model NAME
IERR = 5	model is not consistent with MTYPE
IERR = 6	# CONs specified is not the number expected
IERR = 7	# ICONs specified is not the number expected
IERR = 8	maximum number of array elements exceed- ed
IERR = 9	machine is not designated as a renewable machine in power flow
IERR = 10	bus not found
IERR = 11	machine not found
IERR = 12	prerequisite requirements for API are not met

7.4.2. CHANGE_WNMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of a designated renewable related model at a specified renewable machine. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_WNMOD_CHRICN  IBUS  'ID'  'NAME'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_wnmod_chricn(ibus, id, name, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_WNMOD_CHRICN(IBUS, ID, NAME, J, CHDATA, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a renewable machine model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no input ICONs used in model NAME
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 machine is not designated as a renewable machine in power flow
	IERR = 8 bus not found
	IERR = 9 machine not found
	IERR = 10 prerequisite requirements for API are not met

7.4.3. CHANGE_WNMOD_CON

Use this API to change the value of a CON of a designated renewable machine related model at a specified renewable machine.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_WNMOD_CON  IBUS  'ID'  'NAME'  J  RDATA
```

Python command syntax:

```
ierr = change_wnmod_con(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_WNMOD_CON(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a renewable machine model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no input CONs used in model NAME
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 machine is not designated as a renewable machine in power flow
	IERR = 8 bus not found
	IERR = 9 machine not found
	IERR = 10 prerequisite requirements for API are not met

7.4.4. CHANGE_WNMOD_ICON

Use this API to change the value of an integer ICON of a designated renewable machine related model at a specified renewable machine. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_WNMOD_ICON  IBUS  'ID'  'NAME'  J  IDATA
```

Python command syntax:

```
ierr = change_wnmod_icon(ibus, id, name, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_WNMOD_ICON(IBUS, ID, NAME, J, IDATA, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(l), 2 for ICON(l+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a renewable machine model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no input ICONs used in model NAME
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 machine is not designated as a renewable machine in power flow
	IERR = 8 bus not found
	IERR = 9 machine not found
	IERR = 10 prerequisite requirements for API are not met

7.4.5. CHANGE_WNMOD_VAR

Use this API to change the value of a VAR of a designated renewable machine related model at a specified renewable machine.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_WNMOD_VAR  IBUS  'ID'  'NAME'  J  RDATA
```

Python command syntax:

```
ierr = change_wnmod_var(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_WNMOD_VAR(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a renewable machine model
	IERR = 3 no <model type> model at this machine
	IERR = 4 the <model type> model at this machine is aaa not NAME
	IERR = 5 no input VARs used in model NAME
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 machine is not designated as a renewable machine in power flow
	IERR = 8 bus not found
	IERR = 9 machine not found
	IERR = 10 prerequisite requirements for API are not met

7.4.6. WNMOD_CONSISTENCY

Use this API to check consistency among the renewable machine related models referenced at each machine.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNMOD_CONSISTENCY
```

Python command syntax:

```
ierr = wnmod_consistency()
```

Fortran command syntax:

```
CALL WNMOD_CONSISTENCY(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.4.7. WNMOD_PACK

Use this API to remove entries that are marked as unused from the wind model connection tables and the renewable machine model array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNMOD_PACK
```

Python command syntax:

```
ierr = wnmod_pack()
```

Fortran command syntax:

```
CALL WNMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.4.8. WNMOD_REMOVE

Use this API to remove a renewable machine related model of a designated type from a specified renewable machine.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNMOD_REMOVE  IBUS  'ID'  MTYPE
```

Python command syntax:

```
ierr = wnmod_remove(ibus, id, mtype)
```

Fortran command syntax:

```
CALL WNMOD_REMOVE(IBUS, ID, MTYPE, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Integer MTYPE	model type (input; 1 by default).
	MTYPE = 1 renewable generator model
	MTYPE = 2 renewable electrical control model
	MTYPE = 3 renewable mechanical system model
	MTYPE = 4 renewable pitch control model
	MTYPE = 5 renewable aerodynamic model
	MTYPE = 6 renewable gust model
	MTYPE = 7 renewable auxiliary control model
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid MTYPE value
	IERR = 2 no model of type MTYPE at this machine
	IERR = 3 machine is not designated as a renewable machine in power flow
	IERR = 4 bus not found
	IERR = 5 machine not found
	IERR = 6 prerequisite requirements for API are not met

7.4.9. WNMOD_STATUS

Use this API to change the status of a renewable machine related model of a designated type at a specified renewable machine.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNMOD_STATUS  IBUS  'ID'  MTYPE  STATUS
```

Python command syntax:

```
ierr = wnmmod_status(ibus, id, mtype, status)
```

Fortran command syntax:

```
CALL WNMOD_STATUS(IBUS, ID, MTYPE, STATUS, IERR)
```

Where:

Integer IBUS	renewable machine bus number (input; no default allowed).
Character*2 ID	renewable machine identifier (input; blank by default).
Integer MTYPE	model type (input; 1 by default).
	MTYPE = 1 renewable generator model
	MTYPE = 2 renewable electrical control model
	MTYPE = 3 renewable mechanical system model
	MTYPE = 4 renewable pitch control model
	MTYPE = 5 renewable aerodynamic model
	MTYPE = 6 renewable gust model
	MTYPE = 7 renewable auxiliary control model
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid MTYPE value
	IERR = 2 no model of type MTYPE at this machine
	IERR = 3 invalid STATUS value
	IERR = 4 machine is not designated as a renewable machine in power flow
	IERR = 5 bus not found
	IERR = 6 machine not found
	IERR = 7 prerequisite requirements for API are not met

7.4.10. WNMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those renewable machine related models that are assigned to renewable machines that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNMOD_UNCONNECTED OPT
```

Python command syntax:

```
ierr = wnmod_unconnected(opt)
```

Fortran command syntax:

```
CALL WNMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected renewable machine models
	OPT = 1	remove unconnected renewable machine models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.4.11. WNMOD_USER

Use this API to list user-written renewable machine model definitions or to remove user-written renewable machine model definitions that are not assigned to any renewable machines (unused) from the user model definition tables.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_WNMOD_USER  OPT
```

Python command syntax:

```
ierr = wnmod_user(opt)
```

Fortran command syntax:

```
CALL WNMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written renewable machine model definitions
Integer IERR	OPT = 1	remove unused user-written renewable machine model definitions
	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.5. Load Related Models

7.5.1. ADD_LOAD_MODEL

Use this API to add a load related model of a designated type to a specified load or subsystem. If a model of the designated type already exists at the load or subsystem, it is replaced.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ADD_LOAD_MODEL  IBUS  'ID'  MTYPE  LTYPE  'NAME'  NICN  IDATA  CHDATA
                    NCON  RDATA
```

Python command syntax:

```
ierr = add_load_model(ibus, id, mtype, ltype, name, nicn, idata, chdata,
                    ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_LOAD_MODEL(IBUS, ID, MTYPE, LTYPE, NAME, NICN, IDATA, CHDATA,
                    NCON, RDATA, IERR)
```

Where:

Integer IBUS	bus, owner, zone or area number. Ignored when MTYPE is 4 (when MTYPE is less than 4) (input; no default allowed).
Character*2 ID	load identifier, or "*" to apply the model to all loads in the subsystem (input; blank by default).
Integer MTYPE	subsystem type (input; 0 by default). MTYPE = 0 bus model MTYPE = 1 owner model MTYPE = 2 zone model MTYPE = 3 area model MTYPE = 4 all model
Integer LTYPE	load model type (input; 1 by default). LTYPE = 1 load characteristic model LTYPE = 2 load relay model
Character*16 NAME	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).

Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	load model connection tables full--use pack load model tables function
IERR = 2	invalid MTYPE value
IERR = 3	invalid LTYPE value
IERR = 4	unknown model NAME
IERR = 5	model is not consistent with LTYPE
IERR = 6	model is not consistent with MTYPE
IERR = 7	# CONs specified is not the number expected
IERR = 8	# ICONs specified is not the number expected
IERR = 9	maximum number of array elements exceeded
IERR = 10	type MTYPE load model table is full
IERR = 11	no loads with the specified load identifier
IERR = 12	invalid area/owner/zone number
IERR = 13	no loads with the specified load identifier for specified subsystem
IERR = 14	no loads at bus
IERR = 15	bus not found
IERR = 16	load not found
IERR = 17	prerequisite requirements for API are not met

7.5.2. CHANGE_LDMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of a load related model at a specified load or subsystem. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_LDMOD_CHRICN  IBUS  'ID'  'NAME'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_ldmod_chricn(ibus, id, name, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_LDMOD_CHRICN(IBUS, ID, NAME, J, CHDATA, IERR)
```

Where:

Integer IBUS	bus, owner, zone or area number. Ignored when an all type load model is specified (unless an all type load model is specified) (input; no default allowed).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a load-related model
	IERR = 3 no <subsystem type> type <load type> model for this id in tables for <subsystem type> IBUS
	IERR = 4 no all type <load type> model for this id in tables
	IERR = 5 <subsystem type> <load type> model for this id for <subsystem type> IBUS is aaa not xxx
	IERR = 6 all type <load type> model for this id is aaa not xxx
	IERR = 7 no input ICONs used in model NAME
	IERR = 8 ICON number outside of the ICON range of this model
	IERR = 9 prerequisite requirements for API are not met

7.5.3. CHANGE_LDMOD_CON

Use this API to change the value of a CON of a load related model at a specified load or subsystem.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_LDMOD_CON  IBUS  'ID'  'NAME'  J  RDATA
```

Python command syntax:

```
ierr = change_ldmod_con(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_LDMOD_CON(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	bus, owner, zone or area number. Ignored when an all type load model is specified (unless an all type load model is specified) (input; no default allowed).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a load-related model
	IERR = 3 no <subsystem type> type <load type> model for this id in tables for <subsystem type> IBUS
	IERR = 4 no all type <load type> model for this id in tables
	IERR = 5 <subsystem type> <load type> model for this id for <subsystem type> IBUS is aaa not xxx
	IERR = 6 all type <load type> model for this id is aaa not xxx
	IERR = 7 no CONs used in model NAME
	IERR = 8 CON number outside of the CON range of this model
	IERR = 9 prerequisite requirements for API are not met

7.5.4. CHANGE_LDMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_LDMOD_CON](#), [CHANGE_LDMOD_ICON](#), and [CHANGE_LDMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of a load related model of a designated type at a specified load or subsystem.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHANGE_LDMOD_DATA IBUS 'ID' MTYPE LTYPE 'NAME' J RDATA I
IDATA 'CHDATA'
```

Python command syntax:

```
ierr = change_ldmod_data(ibus, id, mtype, ltype, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_LDMOD_DATA(IBUS, ID, MTYPE, LTYPE, NAME, J, RDATA, I, IDATA,
CHDATA, IERR)
```

Where:

Integer IBUS	bus, owner, zone or area number. Ignored when MTYPE is 4 (when MTYPE is less than 4) (input; no default allowed).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Integer MTYPE	subsystem type (input; 0 by default). MTYPE = 0 bus model MTYPE = 1 owner model MTYPE = 2 zone model MTYPE = 3 area model MTYPE = 4 all model
Integer LTYPE	load model type (input; 1 by default). LTYPE = 1 load characteristic model LTYPE = 2 load relay model
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).

Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).	
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '''; the character ICON is set to '\$\$' (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid MTYPE value
	IERR = 2	invalid LTYPE value
	IERR = 3	unknown model NAME
	IERR = 4	no all type LTYPE model for this id in tables
	IERR = 5	no STYPE type LTYPE model for this id in tables for MTYPE IBUS
	IERR = 6	all type LTYPE model for this id is aaa not xxx
	IERR = 7	MTYPE type LTYPE model for this id for MTYPE IBUS is aaa not xxx
	IERR = 8	CON number exceeds the number of CONs used by the model
	IERR = 9	ICON number exceeds the number of input ICONs used by the model
	IERR = 10	neither the CON nor ICON number is positive
	IERR = 11	prerequisite requirements for API are not met

7.5.5. CHANGE_LDMOD_ICON

Use this API to change the value of an integer ICON of a load related model at a specified load or subsystem. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_LDMOD_ICON  IBUS  'ID'  'NAME'  J  IDATA
```

Python command syntax:

```
ierr = change_ldmod_icon(ibus, id, name, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_LDMOD_ICON(IBUS, ID, NAME, J, IDATA, IERR)
```

Where:

Integer IBUS	bus, owner, zone or area number. Ignored when an all type load model is specified (unless an all type load model is specified) (input; no default allowed).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a load-related model
	IERR = 3 no <subsystem type> type <load type> model for this id in tables for <subsystem type> IBUS
	IERR = 4 no all type <load type> model for this id in tables
	IERR = 5 <subsystem type> <load type> model for this id for <subsystem type> IBUS is aaa not xxx
	IERR = 6 all type <load type> model for this id is aaa not xxx
	IERR = 7 no input ICONs used in model NAME
	IERR = 8 ICON number outside of the ICON range of this model
	IERR = 9 prerequisite requirements for API are not met

7.5.6. CHANGE_LDMOD_VAR

Use this API to change the value of a VAR of a load related model at a specified load or subsystem. This API can be used only for bus based load models. It cannot be used for changing VARs of owner, zone, area, and "all" type load models.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_LDMOD_VAR IBUS 'ID' 'NAME' J RDATA
```

Python command syntax:

```
ierr = change_ldmod_var(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_LDMOD_VAR(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	load bus number (input).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 model NAME is not a load-related model
	IERR = 3 no <subsystem type> type <load type> model for this id in tables for <subsystem type> IBUS
	IERR = 4 no "all" type <load type> model for this id in tables
	IERR = 5 <subsystem type> <load type> model for this id for <subsystem type> IBUS is aaa not xxx
	IERR = 6 "all" type <load type> model for this id is aaa not xxx
	IERR = 7 no VARs used in model NAME
	IERR = 8 VAR number outside of the VAR range of this model
	IERR = 9 VARs of only bus based (load type) models can be changed using this API
	IERR = 10 prerequisite requirements for API are not met

7.5.7. LDMOD_PACK

Use this API to remove entries that are marked as unused from the load model connection tables and the load model array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDMOD_PACK
```

Python command syntax:

```
ierr = ldmod_pack()
```

Fortran command syntax:

```
CALL LDMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.5.8. LDMOD_REMOVE

Use this API to remove a load related model of a designated type from a specified load or subsystem.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDMOD_REMOVE  MTYPE  IBUS  'ID'  LTYPE
```

Python command syntax:

```
ierr = ldmod_remove(mtype, ibus, id, ltype)
```

Fortran command syntax:

```
CALL LDMOD_REMOVE(MTYPE, IBUS, ID, LTYPE, IERR)
```

Where:

Integer MTYPE	subsystem type (input; 0 by default).
	MTYPE = 0 bus model.
	MTYPE = 1 owner model.
	MTYPE = 2 zone model.
	MTYPE = 3 area model.
	MTYPE = 4 all model.
Integer IBUS	bus, owner, zone or area number. Ignored when MTYPE is 4 (when MTYPE is less than 4) (input; no default allowed).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Integer LTYPE	load model type (input; 1 by default).
	LTYPE = 1 load characteristic model
	LTYPE = 2 load relay model
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid number specified for IBUS
	IERR = 2 invalid LTYPE value
	IERR = 3 invalid MTYPE value
	IERR = 4 no all type LTYPE model for this id in tables
	IERR = 5 no MTYPE type LTYPE model for this id in tables for MTYPE IBUS
	IERR = 6 prerequisite requirements for API are not met

7.5.9. LDMOD_STATUS

Use this API to change the status of a load related model of a designated type for all subsystem loads at which it is applied.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDMOD_STATUS  MTYPE  IBUS  'ID'  LTYPE  STATUS
```

Python command syntax:

```
ierr = ldmod_status(mtype, ibus, id, ltype, status)
```

Fortran command syntax:

```
CALL LDMOD_STATUS(MTYPE, IBUS, ID, LTYPE, STATUS, IERR)
```

Where:

Integer MTYPE	subsystem type (input; 0 by default).
	MTYPE = 0 bus model
	MTYPE = 1 owner model
	MTYPE = 2 zone model
	MTYPE = 3 area model
	MTYPE = 4 all model
Integer IBUS	bus, owner, zone or area number. Ignored when MTYPE is 4 (when MTYPE is less than 4) (input; no default allowed).
Character*2 ID	load identifier, or "*" if the model is applied to all loads in the subsystem (input; blank by default).
Integer LTYPE	load model type (input; 1 by default).
	LTYPE = 1 load characteristic model
	LTYPE = 2 load relay model
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid number specified for IBUS
	IERR = 2 invalid LTYPE value
	IERR = 3 invalid MTYPE value
	IERR = 4 no all type LTYPE model for this id in tables
	IERR = 5 no MTYPE type LTYPE model for this id in tables for MTYPE IBUS
	IERR = 6 invalid STATUS value
	IERR = 7 prerequisite requirements for API are not met

7.5.10. LDMOD_STATUS2

Use this API to change the status of a load related model of a designated type at a specified load.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDMOD_STATUS2  IBUS  'ID'  LTYPE  STATUS
```

Python command syntax:

```
ierr = ldmod_status2(ibus, id, ltype, status)
```

Fortran command syntax:

```
CALL LDMOD_STATUS2(IBUS, ID, LTYPE, STATUS, IERR)
```

Where:

Integer IBUS	load bus number (input; no default allowed).
Character*2 ID	load identifier (input; '1' by default).
Integer LTYPE	load model type (input; 1 by default).
	LTYPE = 1 load characteristic model
	LTYPE = 2 load relay model
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid LTYPE value
	IERR = 2 invalid STATUS value
	IERR = 3 no LTYPE model at this load
	IERR = 4 bus not found
	IERR = 5 load not found
	IERR = 6 prerequisite requirements for API are not met

7.5.11. LDMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those load related models that are assigned to loads that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDMOD_UNCONNECTED OPT
```

Python command syntax:

```
ierr = ldmod_unconnected(opt)
```

Fortran command syntax:

```
CALL LDMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected load models
	OPT = 1	remove unconnected load models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.5.12. LDMOD_USER

Use this API to list user-written load model definitions or to remove user-written load model definitions that are not assigned to any loads (unused) from the user model definition tables.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_LDMOD_USER  OPT
```

Python command syntax:

```
ierr = ldmod_user(opt)
```

Fortran command syntax:

```
CALL LDMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written load model definitions
	OPT = 1	remove unused user-written load model definitions
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.6. Line Relay Models

7.6.1. ADD_RELAY_MODEL

Use this API to add a line relay model in the designated relay slot of the from bus end of a specified branch. If a model already exists in the designated relay slot at the from bus end of the branch, it is replaced.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_ADD_RELAY_MODEL  IBUS  JBUS  'ID'  RS  'NAME'  NICN  IDATA  CHDATA
                     NCON  RDATA
```

Python command syntax:

```
ierr = add_relay_model(ibus, jbus, id, rs, name, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_RELAY_MODEL( IBUS, JBUS, ID, RS, NAME, NICN, IDATA, CHDATA, NCON,
                     RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; blank by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 unknown model NAME
	IERR = 3 model is not a line relay model
	IERR = 4 # CONs specified is not the number expected
	IERR = 5 # ICONs specified is not the number expected

IERR = 6	maximum number of array elements exceeded
IERR = 7	line relay model connection tables full--use pack line relay model tables function
IERR = 8	line relay model tables are corrupt
IERR = 9	bus not found
IERR = 10	branch not found
IERR = 11	prerequisite requirements for API are not met

7.6.2. CHANGE_RLMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the line relay model in the designated relay slot of the from bus end of a specified branch. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_RLMOD_CHRICN IBUS JBUS 'ID' RS 'NAME' J 'CHDATA'
```

Python command syntax:

```
ierr = change_rlmod_chricn(ibus, jbus, id, rs, name, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_RLMOD_CHRICN(IBUS,JBUS,ID,RS,NAME,J,CHDATA,IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; blank by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 unknown model NAME
	IERR = 3 no relay model on this branch at the bus IBUS end
	IERR = 4 relay model at bus IBUS end is aaa not xxx
	IERR = 5 no input ICONs used in model NAME
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 bus not found
	IERR = 8 branch not found
	IERR = 9 prerequisite requirements for API are not met

7.6.3. CHANGE_RLMOD_CON

Use this API to change the value of a CON of the line relay model in the designated relay slot of the from bus end of a specified branch.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_RLMOD_CON IBUS JBUS 'ID' RS 'NAME' J RDATA
```

Python command syntax:

```
ierr = change_rlmod_con(ibus, jbus, id, rs, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_RLMOD_CON(IBUS, JBUS, ID, RS, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; blank by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 unknown model NAME
	IERR = 3 no relay model on this branch at the bus IBUS end
	IERR = 4 relay model at bus IBUS end is aaa not xxx
	IERR = 5 no CONs used in model NAME
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 bus not found
	IERR = 8 branch not found
	IERR = 9 prerequisite requirements for API are not met

7.6.4. CHANGE_RLMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_RLMOD_CON](#), [CHANGE_RLMOD_ICON](#), and [CHANGE_RLMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of the line relay model in the designated relay slot of the from bus end of a specified branch.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_CHANGE_RLMOD_DATA  IBUS  JBUS  'ID'  RS  'NAME'  J  RDATA  I  IDATA
  'CHDATA'
```

Python command syntax:

```
ierr = change_rlmod_data(ibus, jbus, id, rs, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_RLMOD_DATA(IBUS, JBUS, ID, RS, NAME, J, RDATA, I, IDATA,
  CHDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; blank by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value

IERR = 2	unknown model NAME
IERR = 3	no relay model on this branch at the bus IBUS end
IERR = 4	relay model at bus IBUS end is aaa not xxx
IERR = 5	CON number exceeds the number of CONs used by the model
IERR = 6	ICON number exceeds the number of ICONs used by the model
IERR = 7	neither the CON nor ICON number is positive
IERR = 8	bus not found
IERR = 9	branch not found
IERR = 10	prerequisite requirements for API are not met

7.6.5. CHANGE_RLMOD_ICON

Use this API to change the value of an integer ICON of the line relay model in the designated relay slot of the from bus end of a specified branch. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_RLMOD_ICON IBUS JBUS 'ID' RS 'NAME' J IDATA
```

Python command syntax:

```
ierr = change_rlmod_icon(ibus, jbus, id, rs, name, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_RLMOD_ICON(IBUS, JBUS, ID, RS, NAME, J, IDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; blank by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 unknown model NAME
	IERR = 3 no relay model on this branch at the bus IBUS end
	IERR = 4 relay model at bus IBUS end is aaa not xxx
	IERR = 5 no input ICONs used in model NAME
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 bus not found
	IERR = 8 branch not found
	IERR = 9 prerequisite requirements for API are not met

7.6.6. CHANGE_RLMOD_VAR

Use this API to change the value of a VAR of the line relay model in the designated relay slot of the from bus end of a specified branch.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_RLMOD_VAR IBUS JBUS 'ID' RS 'NAME' J RDATA
```

Python command syntax:

```
ierr = change_rlmod_var(ibus, jbus, id, rs, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_RLMOD_VAR(IBUS, JBUS, ID, RS, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; blank by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 unknown model NAME
	IERR = 3 no relay model on this branch at the bus IBUS end
	IERR = 4 relay model at bus IBUS end is aaa not xxx
	IERR = 5 no VARs used in model NAME
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 bus not found
	IERR = 8 branch not found
	IERR = 9 prerequisite requirements for API are not met

7.6.7. RLMOD_PACK

Use this API to remove entries that are marked as unused from the line relay model connection tables and the line relay model array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RLMOD_PACK
```

Python command syntax:

```
ierr = rlmmod_pack()
```

Fortran command syntax:

```
CALL RLMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.6.8. RLMOD_REMOVE

Use this API to remove the line relay model in the designated relay slot of the from bus end of a specified branch.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RLMOD_REMOVE IBUS JBUS 'ID' RS
```

Python command syntax:

```
ierr = rlm_remove(ibus, jbus, id, rs)
```

Fortran command syntax:

```
CALL RLMOD_REMOVE(IBUS, JBUS, ID, RS, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; '1' by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 no relay model on this branch at the bus IBUS end
	IERR = 3 bus not found
	IERR = 4 branch not found
	IERR = 5 prerequisite requirements for API are not met

7.6.9. RLMOD_STATUS

Use this API to change the status of the line relay model in the designated relay slot of the from bus end of a specified branch.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RLMOD_STATUS  IBUS  JBUS  'ID'  RS  STATUS
```

Python command syntax:

```
ierr = rlmmod_status(ibus, jbus, id, rs, status)
```

Fortran command syntax:

```
CALL RLMOD_STATUS(IBUS, JBUS, ID, RS, STATUS, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; '1' by default).
Integer RS	relay slot (1 or 2) (input; 1 by default).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid RS value
	IERR = 2 no relay model on this branch at the bus IBUS end
	IERR = 3 invalid STATUS value
	IERR = 4 bus not found
	IERR = 5 branch not found
	IERR = 6 prerequisite requirements for API are not met

7.6.10. RLMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those line relay models that are assigned to branches that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RLMOD_UNCONNECTED OPT
```

Python command syntax:

```
ierr = rlmод_unconnected(opt)
```

Fortran command syntax:

```
CALL RLMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected line relay models
	OPT = 1	remove unconnected line relay models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.6.11. RLMOD_USER

Use this API to list user-written line relay model definitions or to remove user-written line relay model definitions that are not assigned to any branches (unused) from the user model definition tables.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_RLMOD_USER  OPT
```

Python command syntax:

```
ierr = rlmmod_user(opt)
```

Fortran command syntax:

```
CALL RLMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).
	OPT = 0 list user-written line relay definitions
	OPT = 1 remove unused user-written line relay definitions
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid OPT value
	IERR = 2 prerequisite requirements for API are not met

7.7. DC Line Related Models

7.7.1. ADD_MTDCLINE_MODEL

Use this API to add a multi-terminal dc line model to the specified multi-terminal dc line. If a model already exists at the multi-terminal dc line, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_MTDCLINE_MODEL  DC  'MODEL'  NICN  IDATA  CHDATA  NCON  RDATA
IERR
```

Python command syntax:

```
ierr = add_mtdcline_model(dc, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_MTDCLINE_MODEL(NUM, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)

CALL ADD_MTDCLINE_MODEL_I(NUM, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)

CALL ADD_MTDCLINE_MODEL_C(NAME, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line to which the model is to be added; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line to which the model is to be added (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line to which the model is to be added (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).

Real RDATA (NCON)

CON data (input; 0.0).

Integer IERR

error code (output).

IERR = 0	no error
IERR = 1	dc line not found
IERR = 2	multi-terminal dc line model connection tables full--use pack dc line model tables function
IERR = 3	unknown model name
IERR = 4	model is not a multi-terminal dc line model
IERR = 5	# CONs specified is not the number expected
IERR = 6	# ICONs specified is not the number expected
IERR = 7	maximum number of array elements exceeded
IERR = 8	prerequisite requirements for API are not met

7.7.2. ADD_TTDCLINE_MODEL

Use this API to add a two-terminal dc line model to the specified two-terminal dc line. If a model already exists at the two-terminal dc line, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_TTDCLINE_MODEL DC 'MODEL' NICN IDATA CHDATA NCON RDATA
IERR
```

Python command syntax:

```
ierr = add_ttdcline_model(dc, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_TTDCLINE_MODEL(NUM, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)

CALL ADD_TTDCLINE_MODEL_I(NUM, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)

CALL ADD_TTDCLINE_MODEL_C(NAME, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line to which the model is to be added; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line to which the model is to be added (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line to which the model is to be added (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).

IERR = 0	no error
IERR = 1	dc line not found
IERR = 2	two-terminal dc line model connection tables full--use pack dc line model tables function
IERR = 3	unknown model name
IERR = 4	model is not a two-terminal dc line model
IERR = 5	# CONs specified is not the number expected
IERR = 6	# ICONs specified is not the number expected
IERR = 7	maximum number of array elements exceeded
IERR = 8	prerequisite requirements for API are not met

7.7.3. ADD_VSDCLINE_MODEL

Use this API to add a VSC dc line model to the specified VSC dc line. If a model already exists at the VSC dc line, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_VSDCLINE_MODEL 'DCNAME' 'MODEL' NICN IDATA CHDATA NCON
  RDATA IERR
```

Python command syntax:

```
ierr = add_vsdcline_model(dcname,model,nicn,idata,chdata,ncon,rdata)
```

Fortran command syntax:

```
CALL ADD_VSDCLINE_MODEL (DCNAME, MODEL, NICN, IDATA, CHDATA, NCON, RDATA, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 VSC dc line model connection tables full--use pack dc line model tables function
	IERR = 3 unknown model name
	IERR = 4 model is not a VSC dc line model
	IERR = 5 # CONs specified is not the number expected
	IERR = 6 # ICONs specified is not the number expected
	IERR = 7 maximum number of array elements exceed- ed
	IERR = 8 prerequisite requirements for API are not met

7.7.4. CHANGE_MTDCLMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the multi-terminal dc line model of a specified multi-terminal dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCLMOD_CHRICN DC 'MODEL' J 'CHDATA'
```

Python command syntax:

```
ierr = change_mtdclmod_chricn(dc, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCLMOD_CHRICN(NUM, MODEL, J, CHDATA, IERR)
CALL CHANGE_MTDCLMOD_CHRICN_I(NUM, MODEL, J, CHDATA, IERR)
CALL CHANGE_MTDCLMOD_CHRICN_C(NAME, MODEL, J, CHDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.5. CHANGE_MTDCLMOD_CON

Use this API to change the value of a CON of the multi-terminal dc line model of a specified multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCLMOD_CON DC 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_mtdclmod_con(dc, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCLMOD_CON(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCLMOD_CON_I(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCLMOD_CON_C(NAME, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no CONs used in model
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.6. CHANGE_MTDCLMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_MTDCLMOD_CON](#), [CHANGE_MTDCLMOD_ICON](#), and [CHANGE_MTDCLMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of the multi-terminal dc line model of a specified multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCLMOD_DATA DC 'NAME' J RDATA I IDATA 'CHDATA'
```

Python command syntax:

```
ierr = change_mtdclmod_data(dc, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCLMOD_DATA(DC, NAME, J, RDATA, I, IDATA, CHDATA, IERR)
```

Where:

Integer DC	multi-terminal dc line number (input; no default allowed).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output).
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no CONs used in model; or
	IERR = 5 no input ICONs used in model
	IERR = 6 CON number outside of the CON range of this model; or

IERR = 6

ICON number outside of the ICON range of
this model

IERR = 7

prerequisite requirements for API are not met

7.7.7. CHANGE_MTDCLMOD_ICON

Use this API to change the value of an integer ICON of the multi-terminal dc line model of a specified multi-terminal dc line. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCLMOD_ICON DC 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_mtdclmod_icon(dc, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCLMOD_ICON(NUM, MODEL, J, IDATA, IERR)
```

```
CALL CHANGE_MTDCLMOD_ICON_I(NUM, MODEL, J, IDATA, IERR)
```

```
CALL CHANGE_MTDCLMOD_ICON_C(NAME, MODEL, J, IDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.8. CHANGE_MTDCLMOD_VAR

Use this API to change the value of a VAR of the multi-terminal dc line model of a specified multi-terminal dc line.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_MTDCLMOD_VAR DC 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_mtdclmod_var(dc, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCLMOD_VAR(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCLMOD_VAR_I(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCLMOD_VAR_C(NAME, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no VARs used in model
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.9. CHANGE_TTDCLMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the two-terminal dc line model of a specified two-terminal dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCLMOD_CHRICN DC 'MODEL' J 'CHDATA'
```

Python command syntax:

```
ierr = change_ttdclmod_chricn(dc, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCLMOD_CHRICN(NUM, MODEL, J, CHDATA, IERR)
CALL CHANGE_TTDCLMOD_CHRICN_I(NUM, MODEL, J, CHDATA, IERR)
CALL CHANGE_TTDCLMOD_CHRICN_C(NAME, MODEL, J, CHDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.10. CHANGE_TTDCLMOD_CON

Use this API to change the value of a CON of the two-terminal dc line model of a specified two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCLMOD_CON DC 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_ttdclmod_con(dc, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCLMOD_CON(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCLMOD_CON_I(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCLMOD_CON_C(NAME, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no CONs used in model
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.11. CHANGE_TTDCLMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_TTDCLMOD_CON](#), [CHANGE_TTDCLMOD_ICON](#), and [CHANGE_TTDCLMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of the two-terminal dc line model of a specified two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCLMOD_DATA IDC 'NAME' J RDATA I IDATA 'CHDATA'
```

Python command syntax:

```
ierr = change_ttdclmod_data(idc, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCLMOD_DATA(IDC, NAME, J, RDATA, I, IDATA, CHDATA, IERR)
```

Where:

Integer IDC	two-terminal dc line number (input; no default allowed).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no CONs used in model; or
	IERR = 5 no input ICONs used in model

IERR = 6	CON number outside of the CON range of this model; or
IERR = 6	ICON number outside of the ICON range of this model
IERR = 7	prerequisite requirements for API are not met

7.7.12. CHANGE_TTDCLMOD_ICON

Use this API to change the value of an integer ICON of the two-terminal dc line model of a specified two-terminal dc line. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCLMOD_ICON DC 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_ttdclmod_icon(dc, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCLMOD_ICON(NUM, MODEL, J, IDATA, IERR)
```

```
CALL CHANGE_TTDCLMOD_ICON_I(NUM, MODEL, J, IDATA, IERR)
```

```
CALL CHANGE_TTDCLMOD_ICON_C(NAME, MODEL, J, IDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.13. CHANGE_TTDCLMOD_VAR

Use this API to change the value of a VAR of the two-terminal dc line model of a specified two-terminal dc line.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_TTDCLMOD_VAR DC 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_ttdclmod_var(dc, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCLMOD_VAR(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCLMOD_VAR_I(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCLMOD_VAR_C(NAME, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no VARs used in model
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.14. CHANGE_VSDCLMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICON array) of the VSC dc line model of a specified VSC dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCLMOD_CHRICN 'DCNAME' 'MODEL' J 'CHDATA'
```

Python command syntax:

```
ierr = change_vsdclmod_chricn(dcname, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCLMOD_CHRICN(DCNAME, MODEL, J, CHDATA, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.15. CHANGE_VSDCLMOD_CON

Use this API to change the value of a CON of the VSC dc line model of a specified VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCLMOD_CON 'DCNAME' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_vsdclmod_con(dcname, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCLMOD_CON(DCNAME, MODEL, J, RDATA, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 VSC dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no CONs used in model
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.16. CHANGE_VSDCLMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_VSDCLMOD_CON](#), [CHANGE_VSDCLMOD_ICON](#), and [CHANGE_VSDCLMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of the VSC dc line model of a specified VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCLMOD_DATA 'VSDCNM' 'NAME' J RDATA I IDATA 'CHDATA'
```

Python command syntax:

```
ierr = change_vsdclmod_data(vsdcnm, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCLMOD_DATA(VSDCNM, NAME, J, RDATA, I, IDATA, CHDATA, IERR)
```

Where:

Character*12 VSDCNM	VSC dc line name (input; no default allowed).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no CONs used in model; or
	IERR = 5 no input ICONs used in model
	IERR = 6 CON number outside of the CON range of this model; or

IERR = 6

ICON number outside of the ICON range of
this model

IERR = 7

prerequisite requirements for API are not met

7.7.17. CHANGE_VSDCLMOD_ICON

Use this API to change the value of an integer ICON of the VSC dc line model of a specified VSC dc line. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCLMOD_ICON 'DCNAME' 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_vsdclmod_icon(dcname, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCLMOD_ICON(DCNAME, MODEL, J, IDATA, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.18. CHANGE_VSDCLMOD_VAR

Use this API to change the value of a VAR of the VSC dc line model of a specified VSC dc line.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_VSDCLMOD_VAR 'DCNAME' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_vsdclmod_var(dcname, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCLMOD_VAR(DCNAME, MODEL, J, RDATA, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 VSC dc line not found
	IERR = 2 unknown model name
	IERR = 3 no model at this dc line
	IERR = 4 model at this dc line is aaa not xxx
	IERR = 5 no VARs used in model
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 prerequisite requirements for API are not met

7.7.19. DCLMOD_PACK

Use this API to remove entries that are marked as unused from the dc line model connection tables and the dc line array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DCLMOD_PACK
```

Python command syntax:

```
ierr = dclmod_pack()
```

Fortran command syntax:

```
CALL DCLMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.7.20. DCLMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those dc line models that are assigned to dc lines that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DCLMOD_UNCONNECTED  OPT
```

Python command syntax:

```
ierr = dclmod_unconnected(opt)
```

Fortran command syntax:

```
CALL DCLMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected dc line models
	OPT = 1	remove unconnected dc line models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.7.21. DCLMOD_USER

Use this API to list user-written dc line model definitions or to remove user-written dc line model definitions that are not assigned to any dc lines (unused) from the user model definition tables.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DCLMOD_USER  OPT
```

Python command syntax:

```
ierr = dclmod_user(opt)
```

Fortran command syntax:

```
CALL DCLMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).
	OPT = 0 list user-written dc line model definitions.
	OPT = 1 remove unused user-written dc line model definitions.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 invalid OPT value
	IERR = 2 prerequisite requirements for API are not met

7.7.22. MTDCLMOD_REMOVE

Use this API to remove the multi-terminal dc line model from a specified multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MTDCLMOD_REMOVE DC
```

Python command syntax:

```
ierr = mtdclmod_remove(dc)
```

Fortran command syntax:

```
CALL MTDCLMOD_REMOVE(NUM, IERR)
```

```
CALL MTDCLMOD_REMOVE_I(NUM, IERR)
```

```
CALL MTDCLMOD_REMOVE_C(NAME, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which the model is to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which the model is to be removed (input; no default allowed).	
Character*12 NAME	name of the multi-terminal dc line for which the model is to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	dc line not found
	IERR = 2	no model at this dc line
	IERR = 3	prerequisite requirements for API are not met

7.7.23. MTDCLMOD_STATUS

Use this API to change the status of the multi-terminal dc line model at a specified multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MTDCLMOD_STATUS DC STATUS
```

Python command syntax:

```
ierr = mtdclmod_status(dc, status)
```

Fortran command syntax:

```
CALL MTDCLMOD_STATUS(NUM, STATUS, IERR)
CALL MTDCLMOD_STATUS_I(NUM, STATUS, IERR)
CALL MTDCLMOD_STATUS_C(NAME, STATUS, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line for which the model status is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line for which the model status is to be changed (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line for which the model status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 dc line not found IERR = 2 no model at this dc line IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.7.24. TTDCLMOD_REMOVE

Use this API to remove the two-terminal dc line model from a specified two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_TTDCLMOD_REMOVE DC
```

Python command syntax:

```
ierr = ttdclmod_remove(dc)
```

Fortran command syntax:

```
CALL TTDCLMOD_REMOVE(NUM, IERR)
CALL TTDCLMOD_REMOVE_I(NUM, IERR)
CALL TTDCLMOD_REMOVE_C(NAME, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which the model is to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which the model is to be removed (input; no default allowed).	
Character*12 NAME	name of the two-terminal dc line for which the model is to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	dc line not found
	IERR = 2	no model at this dc line
	IERR = 3	prerequisite requirements for API are not met

7.7.25. TTDCLMOD_STATUS

Use this API to change the status of the two-terminal dc line model at a specified two-terminal end line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_TTDCLMOD_STATUS DC STATUS
```

Python command syntax:

```
ierr = ttdclmod_status(dc, status)
```

Fortran command syntax:

```
CALL TTDCLMOD_STATUS(NUM, STATUS, IERR)
CALL TTDCLMOD_STATUS_I(NUM, STATUS, IERR)
CALL TTDCLMOD_STATUS_C(NAME, STATUS, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line for which the model status is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line for which the model status is to be changed (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line for which the model status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 dc line not found IERR = 2 no model at this dc line IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.7.26. VSDCLMOD_REMOVE

Use this API to remove the VSC dc line model from a specified VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VSDCLMOD_REMOVE 'DCNAME'
```

Python command syntax:

```
ierr = vsdclmod_remove(dcname)
```

Fortran command syntax:

```
CALL VSDCLMOD_REMOVE(DCNAME, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	VSC dc line not found
	IERR = 2	no model at this VSC dc line
	IERR = 3	prerequisite requirements for API are not met

7.7.27. VSDCLMOD_STATUS

Use this API to change the status of the VSC dc line model at a specified VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VSDCLMOD_STATUS 'DCNAME' STATUS
```

Python command syntax:

```
ierr = vsdc_lmod_status(dcname, status)
```

Fortran command syntax:

```
CALL VSDCLMOD_STATUS(DCNAME, STATUS, IERR)
```

Where:

Character*12 DCNAME	VSC dc line name (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 VSC dc line not found
	IERR = 2 no model at this VSC dc line
	IERR = 3 invalid STATUS value
	IERR = 4 prerequisite requirements for API are not met

7.8. FACTS Device Models

7.8.1. ADD_FACTS_DEVICE_MODEL

Use this API to add a FACTS device model to the specified FACTS device. If a model already exists at the FACTS device, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_FACTS_DEVICE_MODEL  FD  'MODEL'  NICN  IDATA  CHDATA  NCON  RDATA
IERR
```

Python command syntax:

```
ierr = add_facts_device_model(fd, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_FACTS_DEVICE_MODEL(NUM, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
IERR)

CALL ADD_FACTS_DEVICE_MODEL_I(NUM, MODEL, NICN, IDATA, CHDATA, NCON,
RDATA, IERR)

CALL ADD_FACTS_DEVICE_MODEL_C(NAME, MODEL, NICN, IDATA, CHDATA, NCON,
RDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device to which the model is to be added; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device to which the model is to be added (input; no default allowed).
Character*12 NAME	name of the FACTS device to which the model is to be added (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).

Integer IERR

error code (output).

IERR = 0	no error
IERR = 1	FACTS device not found
IERR = 2	unknown model name
IERR = 3	model is not a FACTS device model
IERR = 4	# CONs specified is not the number expected
IERR = 5	# ICONs specified is not the number expected
IERR = 6	maximum number of array elements exceeded
IERR = 7	FACTS device model connection tables full; use pack FACTS device model tables function
IERR = 8	prerequisite requirements for API are not met

7.8.2. CHANGE_FCTMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the FACTS device model of a specified FACTS device. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTMOD_CHRICN  FD  'MODEL'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_fctmod_chricn(fd, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTMOD_CHRICN(NUM, MODEL, J, CHDATA, IERR)
CALL CHANGE_FCTMOD_CHRICN_I(NUM, MODEL, J, CHDATA, IERR)
CALL CHANGE_FCTMOD_CHRICN_C(NAME, MODEL, J, CHDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the FACTS device for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(1), 2 for ICON(1+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 unknown model name
	IERR = 3 no model at this FACTS device
	IERR = 4 model at this FACTS device is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.8.3. CHANGE_FCTMOD_CON

Use this API to change the value of a CON of the FACTS device model of a specified FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTMOD_CON  FD  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_fctmod_con(fd, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTMOD_CON(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTMOD_CON_I(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTMOD_CON_C(NAME, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the FACTS device for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 unknown model name
	IERR = 3 no model at this FACTS device
	IERR = 4 model at this FACTS device is aaa not xxx
	IERR = 5 no CONs used in model
	IERR = 6 CON number outside of the CON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.8.4. CHANGE_FCTMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_FCTMOD_CON](#), [CHANGE_FCTMOD_ICON](#), and [CHANGE_FCTMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of the FACTS device model of a specified FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTMOD_DATA  FD  'NAME'  J  RDATA  I  IDATA  'CHDATA'
```

Python command syntax:

```
ierr = change_fctmod_data(fd, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTMOD_DATA(FD, NAME, J, RDATA, I, IDATA, CHDATA, IERR)
```

Where:

Integer FD	FACTS device number (input; no default allowed).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 unknown model name
	IERR = 3 no model at this FACTS device
	IERR = 4 model at this FACTS device is aaa not xxx
	IERR = 5 no CONs used in model
	IERR = 6 no input ICONs used in model

IERR = 6	CON number outside of the CON range of this model
IERR = 6	ICON number outside of the ICON range of this model
IERR = 7	prerequisite requirements for API are not met

7.8.5. CHANGE_FCTMOD_ICON

Use this API to change the value of an integer ICON of the FACTS device model of a specified FACTS device. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTMOD_ICON  FD  'MODEL'  J  IDATA
```

Python command syntax:

```
ierr = change_fctmod_icon(fd, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_FCTMOD_ICON(NUM, MODEL, J, IDATA, IERR)
CALL CHANGE_FCTMOD_ICON_I(NUM, MODEL, J, IDATA, IERR)
CALL CHANGE_FCTMOD_ICON_C(NAME, MODEL, J, IDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the FACTS device for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(l), 2 for ICON(l+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 unknown model name
	IERR = 3 no model at this FACTS device
	IERR = 4 model at this FACTS device is aaa not xxx
	IERR = 5 no input ICONs used in model
	IERR = 6 ICON number outside of the ICON range of this model
	IERR = 7 prerequisite requirements for API are not met

7.8.6. CHANGE_FCTMOD_VAR

Use this API to change the value of a VAR of the FACTS device model of a specified FACTS device.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_FCTMOD_VAR  FD  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_fctmod_var(fd, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTMOD_VAR(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTMOD_VAR_I(NUM, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTMOD_VAR_C(NAME, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which model data is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which model data is to be changed (input; no default allowed).
Character*12 NAME	name of the FACTS device for which model data is to be changed (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 unknown model name
	IERR = 3 no model at this FACTS device
	IERR = 4 model at this FACTS device is aaa not xxx
	IERR = 5 no VARs used in model
	IERR = 6 VAR number outside of the VAR range of this model
	IERR = 7 prerequisite requirements for API are not met

7.8.7. FCTMOD_PACK

Use this API to remove entries that are marked as unused from the FACTS device model connection tables and the FACTS device model array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTMOD_PACK
```

Python command syntax:

```
ierr = fctmod_pack()
```

Fortran command syntax:

```
CALL FCTMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.8.8. FCTMOD_REMOVE

Use this API to remove the FACTS device model from a specified FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTMOD_REMOVE  FD
```

Python command syntax:

```
ierr = fctmod_remove(fd)
```

Fortran command syntax:

```
CALL FCTMOD_REMOVE(NUM, IERR)
```

```
CALL FCTMOD_REMOVE_I(NUM, IERR)
```

```
CALL FCTMOD_REMOVE_C(NAME, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which the model is to be removed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which the model is to be removed (input; no default allowed).	
Character*12 NAME	name of the FACTS device for which the model is to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	FACTS device not found
	IERR = 2	no model at this FACTS device
	IERR = 3	prerequisite requirements for API are not met

7.8.9. FCTMOD_STATUS

Use this API to change the status of the FACTS device model at a specified FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTMOD_STATUS  FD  STATUS
```

Python command syntax:

```
ierr = fctmod_status(fd, status)
```

Fortran command syntax:

```
CALL FCTMOD_STATUS(NUM, STATUS, IERR)
CALL FCTMOD_STATUS_I(NUM, STATUS, IERR)
CALL FCTMOD_STATUS_C(NAME, STATUS, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device for which the model status is to be changed; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device for which the model status is to be changed (input; no default allowed).
Character*12 NAME	name of the FACTS device for which the model status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 FACTS device not found IERR = 2 no model at this FACTS device IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.8.10. FCTMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those FACTS device models that are assigned to FACTS device that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTMOD_UNCONNECTED  OPT
```

Python command syntax:

```
ierr = fctmod_unconnected(opt)
```

Fortran command syntax:

```
CALL FCTMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected FACTS device models
	OPT = 1	remove unconnected FACTS device models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.8.11. FCTMOD_USER

Use this API to list user-written FACTS device model definitions or to remove user-written FACTS device model definitions that are not assigned to any FACTS devices (unused) from the user model definition tables.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTMOD_USER  OPT
```

Python command syntax:

```
ierr = fctmod_user(opt)
```

Fortran command syntax:

```
CALL FCTMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written FACTS device model definitions
Integer IERR	OPT = 1	remove unused user-written FACTS device model definitions
	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.8.12. GMB_ADD_FACTS_DEV_MODEL

Use this API to add a GMB FACTS device model to the specified FACTS device. If a model already exists at the FACTS device, it is replaced.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_GMB_ADD_FACTS_DEV_MODEL  FD  'MODEL'  NICN  IDATA  CHDATA  NCON  RDATA
                                IERR
```

Python command syntax:

```
ierr = gmb_add_facts_dev_model(fd,model,nicn,idata,chdata,ncon,rdata)
```

Fortran command syntax:

```
CALL  GMB_ADD_FACTS_DEV_MODEL ( FD, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,  IERR)
```

Where:

Character*12 FD	quoted name of the FACTS device to which the model is to be added; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device to which the model is to be added (input; no default allowed).
Character*12 NAME	name of the FACTS device to which the model is to be added (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 error reading GMB model name
	IERR = 3 model is not a FACTS device model
	IERR = 4 # CONs specified is not the number expected
	IERR = 5 # ICONs specified is not the number expected

IERR = 6	maximum number of array elements exceeded
IERR = 7	FACTS device model connection tables full; use pack FACTS device model tables function
IERR = 8	unlicensed GMB model name
IERR = 9	number of user-defined models exceeds maximum allowed
IERR = 10	prerequisite requirements for API are not met

7.9. Switched Shunt Models

7.9.1. ADD_SWSHUNT_MODEL

This API routine is obsolete. It has been replaced by the API routine [add_swshunt_model_2](#).

Use this API to add a switched shunt model to the specified switched shunt device. If a model already exists at the switched shunt, it is replaced.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ADD_SWSHUNT_MODEL  IBUS  'MODEL'  NICN  IDATA  CHDATA  NCON  RDATA
                        IERR
```

Python command syntax:

```
ierr = add_swshunt_model(ibus,model,nicn,idata,chdata,ncon,rdata)
```

Fortran command syntax:

```
CALL ADD_SWSHUNT_MODEL ( IBUS, MODEL, NICN, IDATA, CHDATA, NCON, RDATA, IERR )
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a switched shunt model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded

IERR = 6	switched shunt model connection tables full-- use pack switched shunt model tables function
IERR = 7	bus not found
IERR = 8	switched shunt not found
IERR = 9	prerequisite requirements for API are not met

7.9.2. ADD_SWSHUNT_MODEL_2

Use this API to add a switched shunt model to the specified switched shunt device. If a model already exists at the switched shunt, it is replaced.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ADD_SWSHUNT_MODEL_2  IBUS  ID  'MODEL'  NICN  IDATA  CHDATA  NCON
                          RDATA  IERR
```

Python command syntax:

```
ierr = add_swshunt_model_2(ibus,id,model,nicn,idata,chdata,ncon,rdata)
```

Fortran command syntax:

```
CALL ADD_SWSHUNT_MODEL_2( IBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a switched shunt model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 switched shunt model connection tables full-- use pack switched shunt model tables function
	IERR = 7 bus not found

IERR = 8

switched shunt not found

IERR = 9

prerequisite requirements for API are not met

7.9.3. CHANGE_SWSMOD_CHRICN

This API routine is obsolete. It has been replaced by the API routine [change_swsmod_chricn_2](#).

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the switched shunt model of a specified switched shunt device. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_CHRICN  IBUS  'MODEL'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_swsmod_chricn(ibus, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_CHRICN(IBUS, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	unknown model name
IERR = 2	no model at this switched shunt device
IERR = 3	model at this switched shunt is aaa not xxx
IERR = 4	no input ICONs used in model
IERR = 5	ICON number outside of the ICON range of this model
IERR = 6	bus not found
IERR = 7	switched shunt not found
IERR = 8	prerequisite requirements for API are not met

7.9.4. CHANGE_SWSMOD_CHRICN_2

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the switched shunt model of a specified switched shunt device. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_CHRICN_2  IBUS  ID  'MODEL'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_swsmod_chricn_2(ibus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_CHRICN_2(IBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(l), 2 for ICON(l+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no model at this switched shunt device
	IERR = 3 model at this switched shunt is aaa not xxx
	IERR = 4 no input ICONs used in model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 switched shunt not found
	IERR = 8 prerequisite requirements for API are not met

7.9.5. CHANGE_SWSMOD_CON

This API routine is obsolete. It has been replaced by the API routine [change_swsmmod_con_2](#).

Use this API to change the value of a CON of the switched shunt model of a specified switched shunt device.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_CON IBUS 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_swsmmod_con(ibus, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_CON(IBUS, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).	
Real RDATA	new CON value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no model at this switched shunt device
	IERR = 3	model at this switched shunt is aaa not xxx
	IERR = 4	no input CONs used in model
	IERR = 5	CON number outside of the CON range of this model
	IERR = 6	bus not found
	IERR = 7	switched shunt not found
	IERR = 8	prerequisite requirements for API are not met

7.9.6. CHANGE_SWSMOD_CON_2

Use this API to change the value of a CON of the switched shunt model of a specified switched shunt device.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_CON_2  IBUS  ID  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_swsmod_con_2(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_CON_2(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no model at this switched shunt device
	IERR = 3 model at this switched shunt is aaa not xxx
	IERR = 4 no input CONs used in model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 switched shunt not found
	IERR = 8 prerequisite requirements for API are not met

7.9.7. CHANGE_SWSMOD_ICON

This API routine is obsolete. It has been replaced by the API routine [change_swsmmod_icon_2](#).

Use this API to change the value of an integer ICON (i.e., an element of the ICON array) of the switched shunt model of a specified switched shunt device. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_ICON  IBUS  'MODEL'  J  IDATA
```

Python command syntax:

```
ierr = change_swsmmod_icon(ibus, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_ICON(IBUS, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no model at this switched shunt device
	IERR = 3 model at this switched shunt is aaa not xxx
	IERR = 4 no input ICONs used in model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 switched shunt not found
	IERR = 8 prerequisite requirements for API are not met

7.9.8. CHANGE_SWSMOD_ICON_2

Use this API to change the value of an integer ICON (i.e., an element of the ICON array) of the switched shunt model of a specified switched shunt device. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_ICON_2  IBUS  ID  'MODEL'  J  IDATA
```

Python command syntax:

```
ierr = change_swsmod_icon_2(ibus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_ICON_2(IBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*2 ID	switched shunt identifier (input; blank by default).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(l), 2 for ICON(l+1), etc.) (input; no default allowed).	
Integer IDATA	new integer ICON value (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no model at this switched shunt device
	IERR = 3	model at this switched shunt is aaa not xxx
	IERR = 4	no input ICONs used in model
	IERR = 5	ICON number outside of the ICON range of this model
	IERR = 6	bus not found
	IERR = 7	switched shunt not found
	IERR = 8	prerequisite requirements for API are not met

7.9.9. CHANGE_SWSMOD_VAR

This API routine is obsolete. It has been replaced by the API routine [change_swsmode_var_2](#).

Use this API to change the value of a VAR of the switched shunt model of a specified switched shunt device.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_VAR IBUS 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_swsmode_var(ibus, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_VAR(IBUS, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).	
Real RDATA	new VAR value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no model at this switched shunt device
	IERR = 3	model at this switched shunt is aaa not xxx
	IERR = 4	no input VARs used in model
	IERR = 5	VAR number outside of the VAR range of this model
	IERR = 6	bus not found
	IERR = 7	switched shunt not found
	IERR = 8	prerequisite requirements for API are not met

7.9.10. CHANGE_SWSMOD_VAR_2

Use this API to change the value of a VAR of the switched shunt model of a specified switched shunt device.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_SWSMOD_VAR_2  IBUS  ID  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_swsmod_var_2(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_SWSMOD_VAR_2(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no model at this switched shunt device
	IERR = 3 model at this switched shunt is aaa not xxx
	IERR = 4 no input VARs used in model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 switched shunt not found
	IERR = 8 prerequisite requirements for API are not met

7.9.11. GMB_ADD_SWSHUNT_MODEL

This API routine is obsolete. It has been replaced by the API routine [gmb_add_swshunt_model_2](#).

Use this API to add a GMB switched shunt model to the specified switched shunt device. If a model already exists at the switched shunt, it is replaced.

This API routine was first introduced in release 32.0.2.

Batch command syntax:

```
BAT_GMB_ADD_SWSHUNT_MODEL  IBUS  'MODEL'  NICN  IDATA  CHDATA  NCON  RDATA
IERR
```

Python command syntax:

```
ierr = gmb_add_swshunt_model(ibus,model,nicn,idata,chdata,ncon,rdata)
```

Fortran command syntax:

```
CALL GMB_ADD_SWSHUNT_MODEL( IBUS, MODEL, NICN, IDATA, CHDATA, NCON, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 error reading GMB model name
	IERR = 2 model is not a switched shunt model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 switched shunt model connection tables full-- use pack switched shunt model tables function

IERR = 7	unlicensed GMB model name
IERR = 8	number of user-defined models exceeds maximum allowed
IERR = 9	bus not found
IERR = 10	switched shunt not found
IERR = 11	prerequisite requirements for API are not met

7.9.12. GMB_ADD_SWSHUNT_MODEL_2

Use this API to add a GMB switched shunt model to the specified switched shunt device. If a model already exists at the switched shunt, it is replaced.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_GMB_ADD_SWSHUNT_MODEL_2  IBUS  ID  'MODEL'  NICN  IDATA  CHDATA  NCON
                                RDATA  IERR
```

Python command syntax:

```
ierr = gmb_add_swshunt_model_2(ibus,id,model,nicn,idata,chdata,ncon,rdata)
```

Fortran command syntax:

```
CALL
  GMB_ADD_SWSHUNT_MODEL_2( IBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 error reading GMB model name
	IERR = 2 model is not a switched shunt model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 switched shunt model connection tables full-- use pack switched shunt model tables function
	IERR = 7 unlicensed GMB model name

IERR = 8	number of user-defined models exceeds maximum allowed
IERR = 9	bus not found
IERR = 10	switched shunt not found
IERR = 11	prerequisite requirements for API are not met

7.9.13. SWSMOD_PACK

Use this API to remove entries that are marked as unused from the switched shunt model connection tables and the switched shunt model array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SWSMOD_PACK
```

Python command syntax:

```
ierr = swsmod_pack()
```

Fortran command syntax:

```
CALL SWSMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.9.14. SWSMOD_REMOVE

This API routine is obsolete. It has been replaced by the API routine [swsmod_remove_2](#).

Use this API to remove the switched shunt model from a specified switched shunt.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SWSMOD_REMOVE  IBUS
```

Python command syntax:

```
ierr = swsmod_remove(ibus)
```

Fortran command syntax:

```
CALL SWSMOD_REMOVE(IBUS, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no model at this switched shunt device
	IERR = 2	bus not found
	IERR = 3	switched shunt not found
	IERR = 4	prerequisite requirements for API are not met

7.9.15. SWSMOD_REMOVE_2

Use this API to remove the switched shunt model from a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SWSMOD_REMOVE_2  IBUS  ID
```

Python command syntax:

```
ierr = swsmod_remove_2(ibus,id)
```

Fortran command syntax:

```
CALL SWSMOD_REMOVE_2(IBUS, ID, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*2 ID	switched shunt identifier (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no model at this switched shunt device
	IERR = 2	bus not found
	IERR = 3	switched shunt not found
	IERR = 4	prerequisite requirements for API are not met

7.9.16. SWSMOD_STATUS

This API routine is obsolete. It has been replaced by the API routine [swsmod_status_2](#).

Use this API to change the status of the switched shunt model at a specified switched shunt device.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SWSMOD_STATUS  IBUS  STATUS
```

Python command syntax:

```
ierr = swsmod_status(ibus, status)
```

Fortran command syntax:

```
CALL SWSMOD_STATUS(IBUS, STATUS, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service.
	STATUS = 1 in-service.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no model at this switched shunt device
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 switched shunt not found
	IERR = 5 prerequisite requirements for API are not met

7.9.17. SWSMOD_STATUS_2

Use this API to change the status of the switched shunt model at a specified switched shunt device.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SWSMOD_STATUS_2 IBUS ID STATUS
```

Python command syntax:

```
ierr = swsmod_status_2(ibus, id, status)
```

Fortran command syntax:

```
CALL SWSMOD_STATUS_2(IBUS, ID, STATUS, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service.
	STATUS = 1 in-service.
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no model at this switched shunt device
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 switched shunt not found
	IERR = 5 prerequisite requirements for API are not met

7.9.18. SWSMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those switched shunt models that are assigned to switched shunt that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SWSMOD_UNCONNECTED  OPT
```

Python command syntax:

```
ierr = swsmod_unconnected(opt)
```

Fortran command syntax:

```
CALL SWSMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected switched shunt models
	OPT = 1	remove unconnected switched shunt models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.9.19. SWSMOD_USER

Use this API to list user-written switched shunt model definitions or to remove user-written switched shunt model definitions that are not assigned to any switched shunt devices (unused) from the user model definition tables.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SWSMOD_USER  OPT
```

Python command syntax:

```
ierr = swsmod_user(opt)
```

Fortran command syntax:

```
CALL SWSMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written switched shunt model definitions
	OPT = 1	remove unused user-written switched shunt model definitions
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.10. Induction Machine Models

7.10.1. ADD_INDMAC_MODEL

Use this API to add an induction machine model to a specified machine. If a model of the designated type already exists at the machine, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_INDMAC_MODEL  IBUS  'ID'  'NAME'  NICN  IDATA  CHDATA  NCON  RDATA
```

Python command syntax:

```
ierr = add_indmac_model(ibus, id, name, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_INDMAC_MODEL (IBUS, ID, NAME, NICN, IDATA, CHDATA, NCON, RDATA,
  IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).	
Character*2 ID	induction machine identifier (input; blank by default).	
Character*16 NAME	model name (input; no default allowed).	
Integer NICN	number of ICONs required by the model (input; no default allowed).	
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).	
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).	
Integer NCON	number of CONs required by the model (input; no default allowed).	
Real RDATA (NCON)	CON data (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	Induction machine model connection tables full--use pack induction machine model tables function
	IERR = 2	Induction machine model tables are corrupt
	IERR = 3	unknown model NAME
	IERR = 4	model is not an induction machine model
	IERR = 5	# CONs specified is not the number expected
	IERR = 6	# ICONs specified is not the number expected

IERR = 7	maximum number of array elements exceeded
IERR = 8	bus not found
IERR = 9	machine not found
IERR = 10	prerequisite requirements for API are not met

7.10.2. CHANGE_IMMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of an induction machine model at a specified machine. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_IMMOD_CHRICN  IBUS  'ID'  'NAME'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_immod_chricn(ibus, id, name, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_IMMOD_CHRICN(IBUS, ID, NAME, J, CHDATA, IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).
Character*2 ID	induction machine identifier (input; blank by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model NAME
	IERR = 2 No model at this induction machine
	IERR = 3 model at this machine is aaa not NAME
	IERR = 4 no input ICONs used in model NAME
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.10.3. CHANGE_IMMOD_CON

Use this API to change the value of a CON of a designated induction machine model at a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_IMMOD_CON  IBUS  'ID'  'NAME'  J  RDATA
```

Python command syntax:

```
ierr = change_immod_con(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_IMMOD_CON(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).	
Character*2 ID	induction machine identifier (input; blank by default).	
Character*16 NAME	model name (input; no default allowed).	
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).	
Real RDATA	new CON value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model NAME
	IERR = 2	No model at this induction machine
	IERR = 3	model at this machine is aaa not NAME
	IERR = 4	no input ICONs used in model NAME
	IERR = 5	ICON number outside of the ICON range of this model
	IERR = 6	bus not found
	IERR = 7	machine not found
	IERR = 8	prerequisite requirements for API are not met

7.10.4. CHANGE_IMMOD_ICON

Use this API to change the value of an integer ICON of a designated induction machine model at a specified machine. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_IMMOD_ICON  IBUS  'ID'  'NAME'  J  IDATA
```

Python command syntax:

```
ierr = change_immod_icon(ibus, id, name, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_IMMOD_ICON(IBUS, ID, NAME, J, IDATA, IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).	
Character*2 ID	induction machine identifier (input; blank by default).	
Character*16 NAME	model name (input; no default allowed).	
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).	
Integer IDATA	new integer ICON value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model NAME
	IERR = 2	No model at this induction machine
	IERR = 3	model at this machine is aaa not NAME
	IERR = 4	no input CONs used in model NAME
	IERR = 5	CON number outside of the CON range of this model
	IERR = 6	bus not found
	IERR = 7	machine not found
	IERR = 8	prerequisite requirements for API are not met

7.10.5. CHANGE_IMMOD_VAR

Use this API to change the value of a VAR of a designated induction machine model at a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_IMMOD_VAR IBUS 'ID' 'NAME' J RDATA
```

Python command syntax:

```
ierr = change_immod_var(ibus, id, name, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_IMMOD_VAR(IBUS, ID, NAME, J, RDATA, IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).	
Character*2 ID	induction machine identifier (input; blank by default).	
Character*16 NAME	model name (input; no default allowed).	
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).	
Real RDATA	new VAR value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model NAME
	IERR = 2	No model at this induction machine
	IERR = 3	model at this machine is aaa not NAME
	IERR = 4	no input VARs used in model NAME
	IERR = 5	VAR number outside of the VAR range of this model
	IERR = 6	bus not found
	IERR = 7	machine not found
	IERR = 8	prerequisite requirements for API are not met

7.10.6. IMMOD_PACK

Use this API to remove entries that are marked as unused from the induction machine model contables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMMOD_PACK
```

Python command syntax:

```
ierr = immod_pack()
```

Fortran command syntax:

```
CALL IMMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.10.7. IMMOD_REMOVE

Use this API to remove an induction machine model of a designated type from a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMMOD_REMOVE  IBUS  'ID'
```

Python command syntax:

```
ierr = immod_remove(ibus, id)
```

Fortran command syntax:

```
CALL IMMOD_REMOVE(IBUS, ID, IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).	
Character*2 ID	induction machine identifier (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no induction machine model at this machine
	IERR = 2	bus not found
	IERR = 3	machine not found
	IERR = 4	prerequisite requirements for API are not met

7.10.8. IMMOD_STATUS

Use this API to change the status of an induction machine model at a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMMOD_STATUS  IBUS  'ID'  STATUS
```

Python command syntax:

```
ierr = immod_status(ibus, id, status)
```

Fortran command syntax:

```
CALL IMMOD_STATUS(IBUS, ID, STATUS, IERR)
```

Where:

Integer IBUS	induction machine bus number (input; no default allowed).
Character*2 ID	induction machine identifier (input; blank by default).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no induction machine model at this machine
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 machine not found
	IERR = 5 prerequisite requirements for API are not met

7.10.9. IMMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those induction machine models that are assigned to machines that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMMOD_UNCONNECTED OPT
```

Python command syntax:

```
ierr = immod_unconnected(opt)
```

Fortran command syntax:

```
CALL IMMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected induction machine models
	OPT = 1	remove unconnected induction machine models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.10.10. IMMOD_USER

Use this API to list user-written induction machine model definitions or to remove user-written induction machine model definitions that are not assigned to any machines (unused) from the user model definition tables.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_IMMOD_USER  OPT
```

Python command syntax:

```
ierr = immod_user(opt)
```

Fortran command syntax:

```
CALL IMMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written induction machine model definitions
	OPT = 1	remove unused user-written induction machine model definitions
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.11. CCT Models

7.11.1. ADD_CCT2DCO_MODEL

Use this API to add an "other" type model attached to a 2-terminal dc line. If another model exists, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCT2DCO_MODEL DC 'MODEL' NICN IDATA CHDATA NCON RDATA
```

Python command syntax:

```
ierr = add_cct2dco_model(dc, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCT2DCO_MODEL(DC, MODEL, NICN, IDATA, CHDATA, NCON, RDATA, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer NICN	number of ICONs required by the model (input; no default allowed).	
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).	
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).	
Integer NCON	number of CONs required by the model (input; no default allowed).	
Real RDATA (NCON)	CON data (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	model is not a 2-terminal dc line "other" type model
	IERR = 3	# CONs specified is not the number expected
	IERR = 4	# ICONs specified is not the number expected
	IERR = 5	maximum number of array elements exceeded
	IERR = 6	CCT model connection tables full-use pack CCT model tables function

IERR = 7

dc line not found

IERR = 8

prerequisite requirements for API are not met

7.11.2. ADD_CCT2WTD_MODEL

Use this API to add a 2-winding transformer device model to the specified 2-winding transformer. If a model already exists at the 2-winding transformer, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCT2WTD_MODEL IBUS JBUS 'ID' 'MODEL' NICN IDATA CHDATA
NCON RDATA
```

Python command syntax:

```
ierr = add_cct2wtd_model(ibus, jbus, id, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCT2WTD_MODEL(IBUS, JBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON,
RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a 2-winding transformer device model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function

IERR = 7	branch is not a transformer
IERR = 8	bus not found
IERR = 9	2-winding transformer not found
IERR = 10	prerequisite requirements for API are not met

7.11.3. ADD_CCT3WTD_MODEL

Use this API to add a 3-winding transformer device model to the specified 3-winding transformer. If a model already exists at the 3-winding transformer, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCT3WTD_MODEL  IBUS JBUS KBUS ID MODEL NICN IDATA CHDATA NCON
                        RDATA
```

Python command syntax:

```
ierr = add_cct3wtd_model(ibus, jbus, kbus, id, model, nicn, idata, chdata,
                        ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCT3WTD_MODEL(IBUS, JBUS, KBUS, ID, MODEL, NICN, IDATA, CHDATA,
                        NCON, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a 3-winding transformer device model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded

IERR = 6	CCT model connection tables full-use pack CCT model tables function
IERR = 7	branch is not a transformer
IERR = 8	bus not found
IERR = 9	3-winding transformer not found
IERR = 10	prerequisite requirements for API are not met

7.11.4. ADD_CCTBRND_MODEL

Use this API to add a branch device model to the specified branch. If a model already exists at the branch, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCTBRND_MODEL  IBUS  JBUS  'ID'  'MODEL'  NICN  IDATA  CHDATA
                        NCON  RDATA
```

Python command syntax:

```
ierr = add_cctbrnd_model(ibus, jbus, id, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCTBRND_MODEL(IBUS, JBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON,
                        RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a branch device model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function

IERR = 7	branch is a transformer
IERR = 8	bus not found
IERR = 9	branch not found
IERR = 10	prerequisite requirements for API are not met

7.11.5. ADD_CCTBRNO_MODEL

Use this API to add a branch "other" model to the specified branch. If a model already exists at the branch, it is replaced.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_ADD_CCTBRNO_MODEL  IBUS JBUS ID MODEL NICN IDATA(1)..IDATA(NICN)
                        CHDATA(1)..CHDATA(NICN) NCON RDATA(1)..RDATA(NCON)
```

Python command syntax:

```
ierr = add_cctbrno_model(ibus, jbus, id, model, nicn, idata, chdata, ncon,
                        rdata)
```

Fortran command syntax:

```
CALL ADD_CCTBRNO_MODEL(IBUS, JBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON,
                        RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a branch device model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function

IERR = 7	branch is a transformer
IERR = 8	bus not found
IERR = 9	branch not found
IERR = 10	prerequisite requirements for API are not met

7.11.6. ADD_CCTBUSO_MODEL

Use this API to add an "other" type model attached to a bus. If another model exists, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCTBUSO_MODEL IBUS 'MODEL' NICN IDATA CHDATA NCON RDATA
```

Python command syntax:

```
ierr = add_cctbuso_model(ibus, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCTBUSO_MODEL(IBUS, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,  
IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a bus "other" type model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function
	IERR = 7 bus not found
	IERR = 8 prerequisite requirements for API are not met

7.11.7. ADD_CCTMCNO_MODEL

Use this API to add a machine other model to the specified machine. If another model exists, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCTMCNO_MODEL  IBUS  'ID'  'MODEL'  NICN  IDATA  CHDATA  NCON
                        RDATA
```

Python command syntax:

```
ierr = add_cctmcno_model(ibus, id, model, nicn, idata, chdata, ncon,
                        rdata)
```

Fortran command syntax:

```
CALL ADD_CCTMCNO_MODEL (IBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
                        IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a machine protection model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function
	IERR = 7 bus not found

IERR = 8

machine not found

IERR = 9

prerequisite requirements for API are not met

7.11.8. ADD_CCTMCNP_MODEL

Use this API to add a machine protection model to the specified machine. If another model exists, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCTMCNP_MODEL  IBUS  'ID'  'MODEL'  NICN  IDATA  CHDATA  NCON
                        RDATA
```

Python command syntax:

```
ierr = add_cctmcnp_model(ibus, id, model, nicn, idata, chdata, ncon,
                        rdata)
```

Fortran command syntax:

```
CALL ADD_CCTMCNP_MODEL (IBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
                        IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a machine protection model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function
	IERR = 7 bus not found

IERR = 8

machine not found

IERR = 9

prerequisite requirements for API are not met

7.11.9. ADD_CCTMSCO_MODEL

Use this API to add a miscellaneous "other" type model with the specified model instance. If another model exists with the same model instance, it is replaced.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_ADD_CCTMSCO_MODEL 'MODEL' MINS NICN IDATA CHDATA NCON RDATA
```

Python command syntax:

```
ierr = add_cctmsco_model(model, mins, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCTMSCO_MODEL(MODEL, MINS, NICN, IDATA, CHDATA, NCON, RDATA,  
IERR)
```

Where:

Character*16 MODEL	model name (input; no default allowed).
Integer MINS	model instance (>0) (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a bus "other" type model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function
	IERR = 7 invalid model instance
	IERR = 8 prerequisite requirements for API are not met

7.11.10. ADD_CCTSWSO_MODEL

This API routine is obsolete. It has been replaced by the API routine [add_cctswso_model_2](#).

Use this API to add a switched shunt "other" model to the specified bus. If a model already exists at the bus, it is replaced.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_ADD_CCTSWSO_MODEL  IBUS MODEL NICN IDATA(1)..IDATA(NICN)
                        CHDATA(1)..CHDATA(NICN) NCON RDATA(1)..RDATA(NCON)
```

Python command syntax:

```
ierr = add_cctswso_model(ibus, model, nicn, idata, chdata, ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_CCTSWSO_MODEL (IBUS, MODEL, NICN, IDATA, CHDATA, NCON, RDATA,
                        IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a switched shunt other model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack CCT model tables function

IERR = 7

bus not found

IERR = 8

switched shunt not found

IERR = 9

prerequisite requirements for API are not met

7.11.11. ADD_CCTSWSO_MODEL_2

Use this API to add a switched shunt "other" model to the specified bus. If a model already exists at the bus, it is replaced.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ADD_CCTSWSO_MODEL_2  IBUS ID MODEL NICN IDATA(1)..IDATA(NICN)
                          CHDATA(1)..CHDATA(NICN) NCON RDATA(1)..RDATA(NCON)
```

Python command syntax:

```
ierr = add_cctswso_model_2(ibus, id, model, nicn, idata, chdata, ncon,
                           rdata)
```

Fortran command syntax:

```
CALL ADD_CCTSWSO_MODEL_2(IBUS, ID, MODEL, NICN, IDATA, CHDATA, NCON,
                          RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 model is not a switched shunt other model
	IERR = 3 # CONs specified is not the number expected
	IERR = 4 # ICONs specified is not the number expected
	IERR = 5 maximum number of array elements exceeded
	IERR = 6 CCT model connection tables full-use pack
	CCT model tables function
	IERR = 7 bus not found

IERR = 8

switched shunt not found

IERR = 9

prerequisite requirements for API are not met

7.11.12. CCT2DCOMOD_REMOVE

Use this API to remove an "other" type model attached to a 2-terminal dc line.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCT2DCOMOD_REMOVE DC MODEL
```

Python command syntax:

```
ierr = cct2dcomod_remove(dc, model)
```

Fortran command syntax:

```
CALL CCT2DCOMOD_REMOVE(DC, MODEL, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	name of the model to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no "other" model at this dc line
	IERR = 2	dc line not found
	IERR = 3	prerequisite requirements for API are not met

7.11.13. CCT2DCOMOD_STATUS

Use this API to change status of an "other" type model attached to a 2-terminal dc line.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCT2DCOMOD_STATUS DC MODEL STATUS
```

Python command syntax:

```
ierr = cct2dcomod_status(dc, model, status)
```

Fortran command syntax:

```
CALL CCT2DCOMOD_STATUS(DC, MODEL, STATUS, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	name of the model whose status is to be changed (input; no default allowed).	
Integer STATUS	new model status (input; 1 by default).	
	STATUS = 0	out-of-service
	STATUS = 1	in-service
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no "other" model at this dc line
	IERR = 2	invalid STATUS value
	IERR = 3	dc line not found
	IERR = 4	prerequisite requirements for API are not met

7.11.14. CCT2DCO_LIST

Use this API to list "other" type models attached to 2-terminal dc lines.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCT2DCO_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cct2dco_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCT2DCO_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.15. CCT2WTDMOD_REMOVE

Use this API to remove a 2-winding transformer device model attached to the specified 2-winding transformer.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCT2WTDMOD_REMOVE  IBUS  JBUS  'ID'
```

Python command syntax:

```
ierr = cct2wtdmod_remove(ibus, jbus, id)
```

Fortran command syntax:

```
CALL CCT2WTDMOD_REMOVE(IBUS, JBUS, ID, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no 2-winding transformer device model on this branch
	IERR = 2 bus not found
	IERR = 3 2-winding transformer not found
	IERR = 4 prerequisite requirements for API are not met

7.11.16. CCT2WTDMOD_STATUS

Use this API to change the status of a 2-winding transformer device model attached to the specified 2-winding transformer.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCT2WTDMOD_STATUS IBUS JBUS 'ID' STATUS
```

Python command syntax:

```
ierr = cct2wtdmod_status(ibus, jbus, id, status)
```

Fortran command syntax:

```
CALL CCT2WTDMOD_STATUS(IBUS, JBUS, ID, STATUS, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no 2-winding transformer device model on this branch
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 2-winding transformer not found
	IERR = 5 prerequisite requirements for API are not met

7.11.17. CCT2WTD_LIST

Use this API to list "other" type models attached to 2-winding transformers.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCT2WTD_LIST SID ALL STATUS
```

Python command syntax:

```
ierr = cct2wtd_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCT2WTD_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).	
Integer ALL	all buses or specified subsystem flag (1 by default) (input).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS	active/bypassed flag (input; 0 by default).	
	STATUS = 0	active and bypassed models
	STATUS = 1	active models only
	STATUS = 2	bypassed models only
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	prerequisite requirements for API are not met

7.11.18. CCT3WTDMOD_REMOVE

Use this API to remove a 3-winding transformer device model attached to the specified 3-winding transformer.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCT3WTDMOD_REMOVE IBUS JBUS KBUS 'ID'
```

Python command syntax:

```
ierr = cct3wtdmod_remove(ibus, jbus, kbus, id)
```

Fortran command syntax:

```
CALL CCT3WTDMOD_REMOVE(IBUS, JBUS, KBUS, ID, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).	
Integer JBUS	to bus number (input; no default allowed).	
Integer KBUS	third bus number (input; no default allowed).	
Character*2 ID	circuit identifier (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no 3-winding transformer device model on this branch
	IERR = 2	bus not found
	IERR = 3	3-winding transformer not found
	IERR = 4	prerequisite requirements for API are not met

7.11.19. CCT3WTDMOD_STATUS

Use this API to change the status of a 3-winding transformer device model attached to the specified 3-winding transformer.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCT3WTDMOD_STATUS IBUS JBUS KBUS 'ID' STATUS
```

Python command syntax:

```
ierr = cct3wtdmod_status(ibus, jbus, kbus, id, status)
```

Fortran command syntax:

```
CALL CCT3WTDMOD_STATUS(IBUS, JBUS, KBUS, ID, STATUS, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no 3-winding transformer device model on this branch
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 3-winding transformer not found
	IERR = 5 prerequisite requirements for API are not met

7.11.20. CCT3WTD_LIST

Use this API to list "other" type models attached to 3-winding transformers.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCT3WTD_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cct3wtd_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCT3WTD_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.21. CCTBRNDMOD_REMOVE

Use this API to remove a branch device model attached to the specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTBRNMOD_REMOVE IBUS JBUS ID
```

Python command syntax:

```
ierr = cctbrndmod_remove(ibus, jbus, id)
```

Fortran command syntax:

```
CALL CCTBRNDMOD_REMOVE(IBUS, JBUS, ID, IERR)
```

Where:

Integer IBUS	from bus number (input; Not Allowed).
Integer JBUS	to bus number (input; Not Allowed).
Character*2 ID	circuit identifier (input; Not Allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no branch device model on the branch
	IERR = 2 bus not found
	IERR = 3 branch not found
	IERR = 4 prerequisite requirements for API are not met

7.11.22. CCTBRNDMOD_STATUS

Use this API to change the status of a branch device model attached to the specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTBRNDMOD_STATUS IBUS JBUS 'ID' STATUS
```

Python command syntax:

```
ierr = cctbrndmod_status(ibus, jbus, id, status)
```

Fortran command syntax:

```
CALL CCTBRNDMOD_STATUS(IBUS, JBUS, ID, STATUS, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input; Not Allowed).
Character*2 ID	circuit identifier (input).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no branch device model on this branch
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 branch not found
	IERR = 5 prerequisite requirements for API are not met

7.11.23. CCTBRND_LIST

Use this API to list device type models attached to branches.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTBRND_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctbrnd_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTBRND_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.24. CCTBRNOMOD_REMOVE

Use this API to remove a branch "other" model attached to the specified branch.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_CCTBRNOMOD_REMOVE IBUS JBUS ID MODEL
```

Python command syntax:

```
ierr = cctbrnomod_remove(ibus, jbus, id, model)
```

Fortran command syntax:

```
CALL CCTBRNOMOD_REMOVE(IBUS, JBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	from bus number (input; Not Allowed).
Integer JBUS	to bus number (input; Not Allowed).
Character*2 ID	circuit identifier (input; Not Allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no branch other model on the branch
	IERR = 2 bus not found
	IERR = 3 branch not found
	IERR = 4 prerequisite requirements for API are not met

7.11.25. CCTBRNOMOD_STATUS

Use this API to change the status of a branch "other" model attached to the specified branch.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_CCTBRNOMOD_STATUS IBUS JBUS ID MODEL STATUS
```

Python command syntax:

```
ierr = cctbrnomod_status(ibus, jbus, id, model, status)
```

Fortran command syntax:

```
CALL CCTBRNOMOD_STATUS(IBUS, JBUS, ID, MODEL, STATUS, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input; Not Allowed).
Character*2 ID	circuit identifier (input).
Character*16 MODEL	model name (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no branch other model on this branch
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 branch not found
	IERR = 5 prerequisite requirements for API are not met

7.11.26. CCTBRNO_LIST

Use this API to list "other" type models attached to branches.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTBRNO_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctbrno_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTBRNO_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.27. CCTBUSOMOD_REMOVE

Use this API to remove an "other" type model attached to a bus.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTBUSOMOD_REMOVE IBUS MODEL
```

Python command syntax:

```
ierr = cctbusomod_remove(ibus, model)
```

Fortran command syntax:

```
CALL CCTBUSOMOD_REMOVE(IBUS, MODEL, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).	
Character*16 MODEL	name of the model to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no bus other model
	IERR = 2	bus not found
	IERR = 3	prerequisite requirements for API are not met

7.11.28. CCTBUSOMOD_STATUS

Use this API to change status of an "other" type model attached to a bus.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTBUSOMOD_STATUS IBUS MODEL STATUS
```

Python command syntax:

```
ierr = cctbusomod_status(ibus, model, status)
```

Fortran command syntax:

```
CALL CCTBUSOMOD_STATUS(IBUS, MODEL, STATUS, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*16 MODEL	name of the model whose status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no bus other model at this bus
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 prerequisite requirements for API are not met

7.11.29. CCTBUSO_LIST

Use this API to list "other" type models attached to buses.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTBUSO_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctbuso_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTBUSO_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.30. CCTMCNOMOD_REMOVE

Use this API to remove a machine "other" model attached to the specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMCNOMOD_REMOVE IBUS 'ID' 'MODEL'
```

Python command syntax:

```
ierr = cctmcnomod_remove(ibus, id, model)
```

Fortran command syntax:

```
CALL CCTMCNOMOD_REMOVE(IBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	name of the model to be removed (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no machine protection model at this machine
	IERR = 2 bus not found
	IERR = 3 machine not found
	IERR = 4 prerequisite requirements for API are not met

7.11.31. CCTMCNOMOD_STATUS

Use this API to change status of a machine "other" model attached to the specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMCNOMOD_STATUS IBUS 'ID' MODEL STATUS
```

Python command syntax:

```
ierr = cctmcnomod_status(ibus, id, model, status)
```

Fortran command syntax:

```
CALL CCTMCNOMOD_STATUS(IBUS, ID, MODEL, STATUS, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	name of the model whose status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no machine other model at this machine
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 machine not found
	IERR = 5 prerequisite requirements for API are not met

7.11.32. CCTMCNO_LIST

Use this API to list "other" type models attached to machines.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTMCNO_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctmcno_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTMCNO_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).	
Integer ALL	all buses or specified subsystem flag (1 by default) (input).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS	active/bypassed flag (input; 0 by default).	
	STATUS = 0	active and bypassed models
	STATUS = 1	active models only
	STATUS = 2	bypassed models only
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	prerequisite requirements for API are not met

7.11.33. CCTMCNPMOD_REMOVE

Use this API to remove a machine protection model attached to the specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMCNPMOD_REMOVE IBUS 'ID' 'MODEL '
```

Python command syntax:

```
ierr = cctmcnpmod_remove(ibus, id, model)
```

Fortran command syntax:

```
CALL CCTMCNPMOD_REMOVE(IBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	name of the model to be removed (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no machine protection model at this machine
	IERR = 2 bus not found
	IERR = 3 machine not found
	IERR = 4 prerequisite requirements for API are not met

7.11.34. CCTMCNPMOD_STATUS

Use this API to change status of a machine protection model attached to the specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMCNPMOD_STATUS IBUS 'ID' MODEL STATUS
```

Python command syntax:

```
ierr = cctmcnpmod_status(ibus, id, model, status)
```

Fortran command syntax:

```
CALL CCTMCNPMOD_STATUS(IBUS, ID, MODEL, STATUS, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	name of the model whose status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no machine protection model at this machine
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 machine not found
	IERR = 5 prerequisite requirements for API are not met

7.11.35. CCTMCNP_LIST

Use this API to list protection models attached to machines.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTMCNP_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctmcnp_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTMCNP_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).	
Integer ALL	all buses or specified subsystem flag (1 by default) (input).	
	ALL = 0	process only buses in subsystem SID
	ALL = 1	process all buses
Integer STATUS	active/bypassed flag (input; 0 by default).	
	STATUS = 0	active and bypassed models
	STATUS = 1	active models only
	STATUS = 2	bypassed models only
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid SID value or subsystem SID is not defined
	IERR = 2	invalid ALL value
	IERR = 3	invalid STATUS value
	IERR = 4	prerequisite requirements for API are not met

7.11.36. CCTMOD_PACK

Use this API to pack CCT model definition tables.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMOD_PACK
```

Python command syntax:

```
ierr = cctmod_pack()
```

Fortran command syntax:

```
CALL CCTMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.11.37. CCTMOD_USER

Use this API to list or remove user-written CCT model definitions.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMOD_USER  OPT
```

Python command syntax:

```
ierr = cctmod_user(opt)
```

Fortran command syntax:

```
CALL CCTMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written model definitions
	OPT = 1	remove unused user-written model definitions
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.11.38. CCTMSCOMOD_REMOVE

Use this API to remove a miscellaneous "other" type model with the specified model instance.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMSCOMOD_REMOVE MINS
```

Python command syntax:

```
ierr = cctmscomod_remove(mins)
```

Fortran command syntax:

```
CALL CCTMSCOMOD_REMOVE(MINS, IERR)
```

Where:

Integer MINS	model instance (>0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no bus other model with this model instance at this bus
	IERR = 2	invalid model instance
	IERR = 3	prerequisite requirements for API are not met

7.11.39. CCTMSCOMOD_STATUS

Use this API to change status of a miscellaneous "other" type model with the specified model instance.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CCTMSCOMOD_STATUS MINS STATUS
```

Python command syntax:

```
ierr = cctmscomod_status(mins, status)
```

Fortran command syntax:

```
CALL CCTMSCOMOD_STATUS(MINS, STATUS, IERR)
```

Where:

Integer MINS	model instance (>0) (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no miscellaneous other model with this model instance
	IERR = 2 invalid STATUS value
	IERR = 3 invalid model instance
	IERR = 4 prerequisite requirements for API are not met

7.11.40. CCTMSCO_LIST

Use this API to list miscellaneous "other" type models.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTMSCO_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctmsco_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTMSCO_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.41. CCTSWMOD_REMOVE

This API routine is obsolete. It has been replaced by the API routine [cctswmod_remove_2](#).

Use this API to remove an "other" type model attached to a switched shunt.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_CCTSWMOD_REMOVE  IBUS  MODEL
```

Python command syntax:

```
ierr = cctswmod_remove(ibus, model)
```

Fortran command syntax:

```
CALL CCTSWMOD_REMOVE(IBUS, MODEL, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*16 MODEL	name of the model to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no bus other model
	IERR = 2	bus not found
	IERR = 3	prerequisite requirements for API are not met

7.11.42. CCTSWMOD_REMOVE_2

Use this API to remove an "other" type model attached to a switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CCTSWMOD_REMOVE_2  IBUS ID MODEL
```

Python command syntax:

```
ierr = cctswmod_remove_2(ibus, id, model)
```

Fortran command syntax:

```
CALL CCTSWMOD_REMOVE_2(IBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*2 ID	switched shunt identifier (input; blank by default).	
Character*16 MODEL	name of the model to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	no bus other model
	IERR = 2	bus not found
	IERR = 3	prerequisite requirements for API are not met

7.11.43. CCTSWMOD_STATUS

This API routine is obsolete. It has been replaced by the API routine [cctswmod_status_2](#).

Use this API to change status of an "other" type model attached to a switched shunt.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_CCTSWMOD_STATUS  IBUS  MODEL  STATUS
```

Python command syntax:

```
ierr = cctswmod_status(ibus, model, status)
```

Fortran command syntax:

```
CALL CCTSWMOD_STATUS(IBUS, MODEL, STATUS, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	name of the model whose status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no bus other model at this bus
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 prerequisite requirements for API are not met

7.11.44. CCTSWMOD_STATUS_2

Use this API to change status of an "other" type model attached to a switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CCTSWMOD_STATUS_2 IBUS ID MODEL STATUS
```

Python command syntax:

```
ierr = cctswmod_status_2(ibus, id, model, status)
```

Fortran command syntax:

```
CALL CCTSWMOD_STATUS_2(IBUS, ID, MODEL, STATUS, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	name of the model whose status is to be changed (input; no default allowed).
Integer STATUS	new model status (input; 1 by default).
	STATUS = 0 out-of-service
	STATUS = 1 in-service
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 no bus other model at this bus
	IERR = 2 invalid STATUS value
	IERR = 3 bus not found
	IERR = 4 prerequisite requirements for API are not met

7.11.45. CCTSWSO_LIST

Use this API to list "other" type models attached to switched shunts.

This API routine was first introduced in release 33.12.0 and 34.1.0.

Batch command syntax:

```
BAT_CCTSWSO_LIST  SID ALL STATUS
```

Python command syntax:

```
ierr = cctswso_list(sid, all, status)
```

Fortran command syntax:

```
CALL CCTSWSO_LIST(SID, ALL, STATUS, IERR)
```

Where:

Integer SID	valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (0 by default). (input).
Integer ALL	all buses or specified subsystem flag (1 by default) (input). ALL = 0 process only buses in subsystem SID ALL = 1 process all buses
Integer STATUS	active/bypassed flag (input; 0 by default). STATUS = 0 active and bypassed models STATUS = 1 active models only STATUS = 2 bypassed models only
Integer IERR	error code (output). IERR = 0 no error IERR = 1 invalid SID value or subsystem SID is not defined IERR = 2 invalid ALL value IERR = 3 invalid STATUS value IERR = 4 prerequisite requirements for API are not met

7.11.46. CHANGE_CCT2DCOMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the "other" type model attached to a specified 2-terminal dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2DCOMOD_CHRICN DC 'MODEL' J CHDATA
```

Python command syntax:

```
ierr = change_cct2dcomod_chricn(dc, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2DCOMOD_CHRICN(DC, MODEL, J, CHDATA, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).	
Character*12 CHDATA	new character ICON value (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no CCT table entry for the model
	IERR = 3	model names do not match - model is aaa not xxx
	IERR = 4	no ICONs used in the model
	IERR = 5	ICON number outside of the ICON range of this model
	IERR = 6	dc line not found
	IERR = 7	prerequisite requirements for API are not met

7.11.47. CHANGE_CCT2DCOMOD_CON

Use this API to change the value of a real constant (CON) of the "other" type model attached to a specified 2-terminal dc line.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2DCOMOD_CON DC 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cct2dcomod_con(dc, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2DCOMOD_CON(DC, MODEL, J, RDATA, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).	
Real RDATA	new CON value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no CCT table entry for the model
	IERR = 3	model names do not match - model is aaa not xxx
	IERR = 4	no CONs used in the model
	IERR = 5	CON number outside of the CON range of this model
	IERR = 6	dc line not found
	IERR = 6	prerequisite requirements for API are not met

7.11.48. CHANGE_CCT2DCOMOD_ICON

Use this API to change the value of an integer ICON of the "other" type model attached to a specified 2-terminal dc line.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2DCOMOD_ICON DC 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_cct2dcomod_icon(dc, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2DCOMOD_ICON(DC, MODEL, J, IDATA, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).	
Integer IDATA	new ICON value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no CCT table entry for the model
	IERR = 3	model names do not match - model is aaa not xxx
	IERR = 4	no ICONs used in the model
	IERR = 5	ICON number outside of the ICON range of this model
	IERR = 6	dc line not found
	IERR = 7	prerequisite requirements for API are not met

7.11.49. CHANGE_CCT2DCOMOD_VAR

Use this API to change the value of VAR of the "other" type model attached to a specified 2-terminal dc line.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2DCOMOD_VAR DC 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cct2dcomod_var(dc, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2DCOMOD_VAR(DC, MODEL, J, RDATA, IERR)
```

Where:

Character*12 DC	quoted name of the two-terminal dc line for which model data is to be changed (input; no default allowed).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).	
Real RDATA	new VAR value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no CCT table entry for the model
	IERR = 3	model names do not match - model is aaa not xxx
	IERR = 4	no VARs used in the model
	IERR = 5	VAR number outside of the VAR range of this model
	IERR = 6	dc line not found
	IERR = 7	prerequisite requirements for API are not met

7.11.50. CHANGE_CCT2WTDMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICON array) of the 2-winding transformer device model of a specified branch. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2WTDMOD_CHRICN  IBUS  JBUS  'ID'  'MODEL'  J  CHDATA
```

Python command syntax:

```
ierr = change_cct2wtdmod_chricn(ibus, jbus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2WTDMOD_CHRICN(IBUS, JBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.51. CHANGE_CCT2WTDMOD_CON

Use this API to change the value of a real constant (CON) of the 2-winding transformer device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2WTDMOD_CON IBUS JBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cct2wtdmod_con(ibus, jbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2WTDMOD_CON(IBUS, JBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.52. CHANGE_CCT2WTDMOD_ICON

Use this API to change the value of an integer ICON of the 2-winding transformer device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2WTDMOD_ICON IBUS JBUS 'ID' 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_cct2wtdmod_icon(ibus, jbus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2WTDMOD_ICON(IBUS, JBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.53. CHANGE_CCT2WTDMOD_VAR

Use this API to change the value of VAR of the 2-winding transformer device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT2WTDMOD_VAR IBUS JBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cct2wtdmod_var(ibus, jbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT2WTDMOD_VAR(IBUS, JBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.54. CHANGE_CCT3WTDMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the 3-winding transformer device model of a specified branch. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT3WTDMOD_CHRICN IBUS JBUS KBUS 'ID' 'MODEL' J CHDATA
```

Python command syntax:

```
ierr = change_cct3wtdmod_chricn(ibus, jbus, kbus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT3WTDMOD_CHRICN(IBUS, JBUS, KBUS, ID, MODEL, J, CHDATA,  
IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.55. CHANGE_CCT3WTDMOD_CON

Use this API to change the value of a real constant (CON) of the 3-winding transformer device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT3WTDMOD_CON IBUS JBUS KBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cct3wtdmod_con(ibus, jbus, kbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT3WTDMOD_CON(IBUS, JBUS, KBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.56. CHANGE_CCT3WTDMOD_ICON

Use this API to change the value of an integer ICON of the 3-winding transformer device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT3WTDMOD_ICON IBUS JBUS KBUS 'ID' 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_cct3wtdmod_icon(ibus, jbus, kbus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCT3WTDMOD_ICON(IBUS, JBUS, KBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.57. CHANGE_CCT3WTDMOD_VAR

Use this API to change the value of VAR of the 3-winding transformer device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCT3WTDMOD_VAR IBUS JBUS KBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cct3wtdmod_var(ibus, jbus, kbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCT3WTDMOD_VAR(IBUS, JBUS, KBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Integer KBUS	third bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.58. CHANGE_CCTBRNDMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the branch device model of a specified branch. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNDMOD_CHRICN  IBUS  JBUS  'ID'  'MODEL'  J  CHDATA
```

Python command syntax:

```
ierr = change_cctbrndmod_chricn(ibus, jbus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNDMOD_CHRICN(IBUS, JBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.59. CHANGE_CCTBRNDMOD_CON

Use this API to change the value of a real constant (CON) of the branch device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNDMOD_CON IBUS JBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cctbrndmod_con(ibus, jbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNDMOD_CON(IBUS, JBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.60. CHANGE_CCTBRNDMOD_ICON

Use this API to change the value of an integer ICON of the branch device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNDMOD_ICON IBUS JBUS 'ID' 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_cctbrndmod_icon(ibus, jbus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNDMOD_ICON(IBUS, JBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.61. CHANGE_CCTBRNDMOD_VAR

Use this API to change the value of VAR of the branch device model of a specified branch.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNDMOD_VAR IBUS JBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cctbrndmod_var(ibus, jbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNDMOD_VAR(IBUS, JBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.62. CHANGE_CCTBRNOMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICON array) of the branch "other" model of a specified branch. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNOMOD_CHRICN  IBUS JBUS ID MODEL J CHDATA
```

Python command syntax:

```
ierr = change_cctbrnomod_chricn(ibus, jbus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNOMOD_CHRICN(IBUS, JBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.63. CHANGE_CCTBRNOMOD_CON

Use this API to change the value of a real constant (CON) of the branch "other" model of a specified branch.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNOMOD_CON IBUS JBUS ID MODEL J RDATA
```

Python command syntax:

```
ierr = change_cctbrnomod_con(ibus, jbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNOMOD_CON(IBUS, JBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.64. CHANGE_CCTBRNOMOD_ICON

Use this API to change the value of an integer ICON of the branch "other" model of a specified branch.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNOMOD_ICON IBUS JBUS ID MODEL J IDATA
```

Python command syntax:

```
ierr = change_cctbrnomod_icon(ibus, jbus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNOMOD_ICON(IBUS, JBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.65. CHANGE_CCTBRNOMOD_VAR

Use this API to change the value of VAR of the branch "other" model of a specified branch.

This API routine was first introduced in release 33.6.0.

Batch command syntax:

```
BAT_CHANGE_CCTBRNOMOD_VAR IBUS JBUS ID MODEL J RDATA
```

Python command syntax:

```
ierr = change_cctbrnomod_var(ibus, jbus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBRNOMOD_VAR(IBUS, JBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	from bus number (input; no default allowed).
Integer JBUS	to bus number (input; no default allowed).
Character*2 ID	circuit identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 branch not found
	IERR = 8 prerequisite requirements for API are not met

7.11.66. CHANGE_CCTBUSOMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the "other" type model attached to a specified bus. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBUSOMOD_CHRICN IBUS 'MODEL' J CHDATA
```

Python command syntax:

```
ierr = change_cctbusomod_chricn(ibus, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBUSOMOD_CHRICN(IBUS, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.67. CHANGE_CCTBUSOMOD_CON

Use this API to change the value of a real constant (CON) of the "other" type model attached to a specified bus.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBUSOMOD_CON IBUS 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cctbusomod_con(ibus, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBUSOMOD_CON(IBUS, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.68. CHANGE_CCTBUSOMOD_ICON

Use this API to change the value of an integer ICON of the "other" type model attached to a specified bus.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBUSOMOD_ICON IBUS 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_cctbusomod_icon(ibus, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBUSOMOD_ICON(IBUS, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.69. CHANGE_CCTBUSOMOD_VAR

Use this API to change the value of VAR of the "other" type model attached to a specified bus.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTBUSOMOD_VAR IBUS 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cctbusomod_var(ibus, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTBUSOMOD_VAR(IBUS, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.70. CHANGE_CCTMCNOMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICH array) of the machine "other" model for a specified machine. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNOMOD_CHRICN  IBUS  'ID'  'MODEL' J  CHDATA
```

Python command syntax:

```
ierr = change_cctmcnomod_chricn(ibus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNOMOD_CHRICN(IBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.71. CHANGE_CCTMCNOMOD_CON

Use this API to change the value of a real constant (CON) of the machine "other" model for a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNOMOD_CON  IBUS  'ID'  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_cctmcnomod_con(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNOMOD_CON(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.72. CHANGE_CCTMCNOMOD_ICON

Use this API to change the value of an integer ICON of the machine "other" model for a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNOMOD_ICON  IBUS  'ID'  'MODEL'  J  IDATA
```

Python command syntax:

```
ierr = change_cctmcnomod_icon(ibus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNOMOD_ICON(IBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.73. CHANGE_CCTMCNOMOD_VAR

Use this API to change the value of VAR of the machine "other" model for a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNOMOD_VAR IBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cctmcnomod_var(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNOMOD_VAR(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.74. CHANGE_CCTMCNPMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICON array) of the machine protection model of a specified machine. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNPMOD_CHRICN  IBUS  'ID'  'MODEL' J  CHDATA
```

Python command syntax:

```
ierr = change_cctmcnpmod_chricn(ibus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNPMOD_CHRICN(IBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.75. CHANGE_CCTMCNPMOD_CON

Use this API to change the value of a real constant (CON) of the machine protection model of a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNPMOD_CON  IBUS  'ID'  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_cctmcnmod_con(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNPMOD_CON(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.76. CHANGE_CCTMCNPMOD_ICON

Use this API to change the value of an integer ICON of the machine protection model of a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNPMOD_ICON  IBUS  'ID'  'MODEL'  J  IDATA
```

Python command syntax:

```
ierr = change_cctmcnmod_icon(ibus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNPMOD_ICON(IBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.77. CHANGE_CCTMCNPMOD_VAR

Use this API to change the value of VAR of the machine protection model of a specified machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMCNPMOD_VAR IBUS 'ID' 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_cctmcnmod_var(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMCNPMOD_VAR(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	machine bus number (input; no default allowed).
Character*2 ID	machine identifier (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 machine not found
	IERR = 8 prerequisite requirements for API are not met

7.11.78. CHANGE_CCTMSCOMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the miscellaneous "other" type model with the specified model instance. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMSCOMOD_CHRICN  MODEL MINS J CHDATA
```

Python command syntax:

```
ierr = change_cctmscomod_chricn(model, mins, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMSCOMOD_CHRICN(MODEL, MINS, J, CHDATA, IERR)
```

Where:

Character*16 MODEL	model name (input; no default allowed).
Integer MINS	model instance (>0) (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model aaa with model instance xxx
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 invalid model instance value
	IERR = 7 prerequisite requirements for API are not met

7.11.79. CHANGE_CCTMSCOMOD_CON

Use this API to change the value of a real constant (CON) of the miscellaneous "other" type model with the specified model instance.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMSCOMOD_CON 'MODEL' MINS J RDATA
```

Python command syntax:

```
ierr = change_cctmscomod_con(model, mins, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMSCOMOD_CON(MODEL, MINS, J, RDATA, IERR)
```

Where:

Character*16 MODEL	model name (input; no default allowed).
Integer MINS	model instance (>0) (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model aaa with model instance xxx
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 invalid model instance value
	IERR = 7 prerequisite requirements for API are not met

7.11.80. CHANGE_CCTMSCOMOD_ICON

Use this API to change the value of an integer ICON of the miscellaneous "other" type model with the specified model instance.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMSCOMOD_ICON 'MODEL' MINS J IDATA
```

Python command syntax:

```
ierr = change_cctmscomod_icon(model, mins, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMSCOMOD_ICON(MODEL, MINS, J, IDATA, IERR)
```

Where:

Character*16 MODEL	model name (input; no default allowed).
Integer MINS	model instance (>0) (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model aaa with model instance xxx
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 invalid model instance value
	IERR = 7 prerequisite requirements for API are not met

7.11.81. CHANGE_CCTMSCOMOD_VAR

Use this API to change the value of VAR of the miscellaneous "other" type model with the specified model instance.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTMSCOMOD_VAR 'MODEL' MINS J RDATA
```

Python command syntax:

```
ierr = change_cctmscomod_var(model, mins, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTMSCOMOD_VAR(MODEL, MINS, J, RDATA, IERR)
```

Where:

Character*16 MODEL	model name (input; no default allowed).
Integer MINS	model instance (>0) (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model aaa with model instance xxx
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 invalid model instance value
	IERR = 7 prerequisite requirements for API are not met

7.11.82. CHANGE_CCTSWMOD_CHRICN

This API routine is obsolete. It has been replaced by the API routine [change_cctswsmod_chricn_2](#).

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the "other" type model attached to a specified switched shunt. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_CHRICN  IBUS  MODEL  J  CHDATA
```

Python command syntax:

```
ierr = change_cctswsmod_chricn(ibus, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_CHRICN(IBUS, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	unknown model name
IERR = 2	no CCT table entry for the model
IERR = 3	model names do not match - model is aaa not xxx
IERR = 4	no ICONs used in the model
IERR = 5	ICON number outside of the ICON range of this model
IERR = 6	bus not found
IERR = 7	prerequisite requirements for API are not met

7.11.83. CHANGE_CCTSWMOD_CHRICN_2

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of the "other" type model attached to a specified switched shunt. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_CHRICN_2  IBUS ID MODEL J CHDATA
```

Python command syntax:

```
ierr = change_cctswmod_chricn_2(ibus, id, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_CHRICN_2(IBUS, ID, MODEL, J, CHDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.84. CHANGE_CCTSWMOD_CON

This API routine is obsolete. It has been replaced by the API routine [change_cctswmod_con_2](#).

Use this API to change the value of a real constant (CON) of the "other" type model attached to a specified switched shunt.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_CON  IBUS MODEL J RDATA
```

Python command syntax:

```
ierr = change_cctswmod_con(ibus, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_CON(IBUS, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.85. CHANGE_CCTSWMOD_CON_2

Use this API to change the value of a real constant (CON) of the "other" type model attached to a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_CON_2  IBUS ID MODEL J RDATA
```

Python command syntax:

```
ierr = change_cctswmod_con_2(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_CON_2(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change (J is relative to the start of the block of CONs assigned to this model, e.g., 1 for first CON(K), 2 for CON(K+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no CONs used in the model
	IERR = 5 CON number outside of the CON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.86. CHANGE_CCTSWMOD_ICON

This API routine is obsolete. It has been replaced by the API routine [change_cctswmod_icon_2](#).

Use this API to change the value of an integer ICON of the "other" type model attached to a specified switched shunt.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_ICON  IBUS MODEL J IDATA
```

Python command syntax:

```
ierr = change_cctswmod_icon(ibus, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_ICON(IBUS, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).
Integer IDATA	new ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no ICONs used in the model
	IERR = 5 ICON number outside of the ICON range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.87. CHANGE_CCTSWMOD_ICON_2

Use this API to change the value of an integer ICON of the "other" type model attached to a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_ICON_2  IBUS ID MODEL J IDATA
```

Python command syntax:

```
ierr = change_cctswmod_icon_2(ibus, id, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_ICON_2(IBUS, ID, MODEL, J, IDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*2 ID	switched shunt identifier (input; blank by default).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	ICON number to change (J is relative to the start of the block of ICONs assigned to this model, e.g., 1 for first ICON(M), 2 for ICON(M+1), etc.) (input; no default allowed).	
Integer IDATA	new ICON value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no CCT table entry for the model
	IERR = 3	model names do not match - model is aaa not xxx
	IERR = 4	no ICONs used in the model
	IERR = 5	ICON number outside of the ICON range of this model
	IERR = 6	bus not found
	IERR = 7	prerequisite requirements for API are not met

7.11.88. CHANGE_CCTSWMOD_VAR

This API routine is obsolete. It has been replaced by the API routine [change_cctswmod_var_2](#).

Use this API to change the value of VAR of the "other" type model attached to a specified switched shunt.

This API routine was first introduced in release 33.8.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_VAR  IBUS MODEL J RDATA
```

Python command syntax:

```
ierr = change_cctswmod_var(ibus, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_VAR(IBUS, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 unknown model name
	IERR = 2 no CCT table entry for the model
	IERR = 3 model names do not match - model is aaa not xxx
	IERR = 4 no VARs used in the model
	IERR = 5 VAR number outside of the VAR range of this model
	IERR = 6 bus not found
	IERR = 7 prerequisite requirements for API are not met

7.11.89. CHANGE_CCTSWMOD_VAR_2

Use this API to change the value of VAR of the "other" type model attached to a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGE_CCTSWMOD_VAR_2  IBUS ID MODEL J RDATA
```

Python command syntax:

```
ierr = change_cctswmod_var_2(ibus, id, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_CCTSWMOD_VAR_2(IBUS, ID, MODEL, J, RDATA, IERR)
```

Where:

Integer IBUS	switched shunt bus number (input; no default allowed).	
Character*2 ID	switched shunt identifier (input; blank by default).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	VAR number to change (J is relative to the start of the block of VARs assigned to this model, e.g., 1 for first VAR(L), 2 for VAR(L+1), etc.) (input; no default allowed).	
Real RDATA	new VAR value (input; unchanged).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	unknown model name
	IERR = 2	no CCT table entry for the model
	IERR = 3	model names do not match - model is aaa not xxx
	IERR = 4	no VARs used in the model
	IERR = 5	VAR number outside of the VAR range of this model
	IERR = 6	bus not found
	IERR = 7	prerequisite requirements for API are not met

7.12. Auxiliary Signal Models

Auxiliary Signal Model APIs handle the models that inject supplementary signals into dc lines and FACTS devices (auxiliary signal models).

7.12.1. ADD_FCTSAUXSIGNAL_MODEL

Use this API to add a FACTS device auxiliary signal model at the specified injection point of the designated FACTS device. If a model already exists at the specified injection point of the FACTS device, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_FCTSAUXSIGNAL_MODEL  FD  ISGNDX  'MODEL'  NICN  IDATA  CHDATA
NCON  RDATA  IERR
```

Python command syntax:

```
ierr = add_fctsauxsignal_model(fd, isgndx, model, nicn, idata, chdata,
ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_FCTSAUXSIGNAL_MODEL(NUM, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)

CALL ADD_FCTSAUXSIGNAL_MODEL_I(NUM, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)

CALL ADD_FCTSAUXSIGNAL_MODEL_C(NAME, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).

Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).	
Integer NCON	number of CONs required by the model (input; no default allowed).	
Real RDATA (NCON)	CON data (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	FACTS device not found
	IERR = 2	invalid ISGNDX value for a FACTS device
	IERR = 3	unknown model name
	IERR = 4	model is not an auxiliary signal model
	IERR = 5	# CONs specified is not the number expected
	IERR = 6	# ICONs specified is not the number expected
	IERR = 7	maximum number of array elements exceeded
	IERR = 8	auxiliary signal model connection tables full-- use pack auxiliary signal model tables function
	IERR = 9	this auxiliary signal may be used only with two-terminal dc lines
	IERR = 10	prerequisite requirements for API are not met

7.12.2. ADD_MTDCAUXSIGNAL_MODEL

Use this API to add a multi-terminal dc line auxiliary signal model at the specified auxiliary signal index of the designated multi-terminal dc line. If a model already exists at the specified auxiliary signal index of the multi-terminal dc line, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_MTDCAUXSIGNAL_MODEL DC ISGNDX 'MODEL' NICN IDATA CHDATA
NCON RDATA IERR
```

Python command syntax:

```
ierr = add_mtdcauxsignal_model(dc, isgndx, model, nicn, idata, chdata,
ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_MTDCAUXSIGNAL_MODEL(NUM, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)

CALL ADD_MTDCAUXSIGNAL_MODEL_I(NUM, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)

CALL ADD_MTDCAUXSIGNAL_MODEL_C(NAME, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).

Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	dc line not found
IERR = 2	invalid ISGNDX value for a multi-terminal dc line
IERR = 3	unknown model name
IERR = 4	model is not an auxiliary signal model
IERR = 5	# CONs specified is not the number expected
IERR = 6	# ICONs specified is not the number expected
IERR = 7	maximum number of array elements exceeded
IERR = 8	auxiliary signal model connection tables full--use pack auxiliary signal model tables function
IERR = 9	this auxiliary signal may be used only with two-terminal dc lines
IERR = 10	prerequisite requirements for API are not met

7.12.3. ADD_TTDCAUXSIGNAL_MODEL

Use this API to add a two-terminal dc line auxiliary signal model at the specified injection point of the designated two-terminal dc line. If a model already exists at the specified injection point of the two-terminal dc line, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_TTDCAUXSIGNAL_MODEL DC ISGNDX 'MODEL' NICN IDATA CHDATA
NCON RDATA IERR
```

Python command syntax:

```
ierr = add_ttdcauxsignal_model(dc, isgndx, model, nicn, idata, chdata,
ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_TTDCAUXSIGNAL_MODEL(NUM, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)

CALL ADD_TTDCAUXSIGNAL_MODEL_I(NUM, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)

CALL ADD_TTDCAUXSIGNAL_MODEL_C(NAME, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).

Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
IERR = 0	no error
IERR = 1	dc line not found
IERR = 2	invalid ISGNDX value for a two-terminal dc line
IERR = 3	unknown model name
IERR = 4	model is not an auxiliary signal model
IERR = 5	# CONs specified is not the number expected
IERR = 6	# ICONs specified is not the number expected
IERR = 7	maximum number of array elements exceeded
IERR = 8	auxiliary signal model connection tables full--use pack auxiliary signal model tables function
IERR = 10	prerequisite requirements for API are not met

7.12.4. ADD_VSDCAUXSIGNAL_MODEL

Use this API to add a VSC dc line auxiliary signal model at the specified injection point of the designated VSC dc line. If a model already exists at the specified injection point of the VSC dc line, it is replaced.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_ADD_VSDCAUXSIGNAL_MODEL 'DCNAME' ISGNDX 'MODEL' NICN IDATA
CHDATA NCON RDATA IERR
```

Python command syntax:

```
ierr = add_vsdcauxsignal_model(dcname, isgndx, model, nicn, idata, chdata,
ncon, rdata)
```

Fortran command syntax:

```
CALL ADD_VSDCAUXSIGNAL_MODEL(DCNAME, ISGNDX, MODEL, NICN, IDATA, CHDATA,
NCON, RDATA, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer NICN	number of ICONs required by the model (input; no default allowed).
Integer IDATA (NICN)	ICON data (input; 0 by default). When a character value is intended for an ICON value, the corresponding IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA (NICN)	character ICON data (no default allowed for an ICON for which a character value is to be specified). When an integer value is intended for an ICON value, the corresponding CHDATA entry must be either defaulted or specified as either '\$\$' or ''; the character ICON is set to '\$\$' (input; blank by default).
Integer NCON	number of CONs required by the model (input; no default allowed).
Real RDATA (NCON)	CON data (input; 0.0).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a VSC dc line
	IERR = 3 unknown model name
	IERR = 4 model is not an auxiliary signal model
	IERR = 5 # CONs specified is not the number expected
	IERR = 6 # ICONs specified is not the number expected

IERR = 7	maximum number of array elements exceeded
IERR = 8	auxiliary signal model connection tables full-- use pack auxiliary signal model tables function
IERR = 9	this auxiliary signal may be used only with two-terminal dc lines
IERR = 10	prerequisite requirements for API are not met

7.12.5. AUXMOD_PACK

Use this API to remove entries that are marked as unused from the auxiliary signal model connection tables and the auxiliary signal array allocation tables. It packs the entries remaining in these tables at the front of the various arrays.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_AUXMOD_PACK
```

Python command syntax:

```
ierr = auxmod_pack()
```

Fortran command syntax:

```
CALL AUXMOD_PACK(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	prerequisite requirements for API are not met

7.12.6. AUXMOD_UNCONNECTED

Use this API to list or remove from dynamics working memory those auxiliary signal models that are assigned to dc lines or FACTS devices that are not present in the current power flow working case (unconnected).

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_AUXMOD_UNCONNECTED  OPT
```

Python command syntax:

```
ierr = auxmod_unconnected(opt)
```

Fortran command syntax:

```
CALL AUXMOD_UNCONNECTED(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list unconnected auxiliary signal models
	OPT = 1	remove unconnected auxiliary signal models
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.12.7. AUXMOD_USER

Use this API to list user-written auxiliary signal model definitions or to remove user-written auxiliary signal model definitions that are not assigned to any dc lines or FACTS devices (unused) from the user model definition tables.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_AUXMOD_USER  OPT
```

Python command syntax:

```
ierr = auxmod_user(opt)
```

Fortran command syntax:

```
CALL AUXMOD_USER(OPT, IERR)
```

Where:

Integer OPT	option code (input; 0 by default).	
	OPT = 0	list user-written auxiliary signal model definitions
	OPT = 1	remove unused user-written auxiliary signal model definitions
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	invalid OPT value
	IERR = 2	prerequisite requirements for API are not met

7.12.8. CHANGE_FCTSAUXMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of an auxiliary signal model of a specified FACTS device. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTSAUXMOD_CHRICN  FD  ISGNDX  'MODEL'  J  'CHDATA'
```

Python command syntax:

```
ierr = change_fctsauxmod_chricn(fd, isgndx, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTSAUXMOD_CHRICN(NUM, ISGNDX, MODEL, J, CHDATA, IERR)
CALL CHANGE_FCTSAUXMOD_CHRICN_I(NUM, ISGNDX, MODEL, J, CHDATA, IERR)
CALL CHANGE_FCTSAUXMOD_CHRICN_C(NAME, ISGNDX, MODEL, J, CHDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 invalid ISGNDX value for a FACTS device
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this FACTS device
	IERR = 5 model at this index for this FACTS device is aaa not xxx

IERR = 6	no input ICONs used in model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.9. CHANGE_FCTSAUXMOD_CON

Use this API to change the value of a CON of an auxiliary signal model of a specified FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTSAUXMOD_CON  FD  ISGNDX  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_fctsauxmod_con(fd, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTSAUXMOD_CON(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTSAUXMOD_CON_I(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTSAUXMOD_CON_C(NAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 invalid ISGNDX value for a FACTS device
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this FACTS device
	IERR = 5 model at this index for this FACTS device is aaa not xxx
	IERR = 6 no CONs used in model

IERR = 7

CON number outside of the CON range of this model

IERR = 8

prerequisite requirements for API are not met

7.12.10. CHANGE_FCTSAUXMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_FCTSAUXMOD_CON](#), [CHANGE_FCTSAUXMOD_ICON](#), and [CHANGE_FCTSAUXMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of an auxiliary signal model of a specified FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTSAUXMOD_DATA  FD  ISGNDX  'NAME'  J  RDATA  I  IDATA
  'CHDATA'
```

Python command syntax:

```
ierr = change_fctsauxmod_data(fd, isgndx, name, j, rdata, i, idata,
                               chdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTSAUXMOD_DATA(FD, ISGNDX, NAME, J, RDATA, I, IDATA, CHDATA,
                             IERR)
```

Where:

Integer FD	number of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 FACTS device not found

IERR = 2	invalid ISGNDX value for a FACTS device
IERR = 3	unknown model name
IERR = 4	no auxiliary signal model at this index for this FACTS device
IERR = 5	model at this index for this FACTS device is aaa not xxx
IERR = 6	no CONs used in model; or
IERR = 6	no input ICONs used in model; or
IERR = 7	CON number outside of the CON range of this model; or
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.11. CHANGE_FCTSAUXMOD_ICON

Use this API to change the value of an integer ICON of an auxiliary signal model of a specified FACTS device. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_FCTSAUXMOD_ICON  FD  ISGNDX  'MODEL'  J  IDATA
```

Python command syntax:

```
ierr = change_fctsauxmod_icon(fd, isgndx, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_FCTSAUXMOD_ICON(NUM, ISGNDX, MODEL, J, IDATA, IERR)
CALL CHANGE_FCTSAUXMOD_ICON_I(NUM, ISGNDX, MODEL, J, IDATA, IERR)
CALL CHANGE_FCTSAUXMOD_ICON_C(NAME, ISGNDX, MODEL, J, IDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 2 FACTS device not found
	IERR = 3 invalid ISGNDX value for a FACTS device
	IERR = 4 unknown model name
	IERR = 5 no auxiliary signal model at this index for this FACTS device
	IERR = 6 model at this index for this FACTS device is aaa not xxx

IERR = 7	no input ICONs used in model
IERR = 8	ICON number outside of the ICON range of this model
IERR = 9	prerequisite requirements for API are not met

7.12.12. CHANGE_FCTSAUXMOD_VAR

Use this API to change the value of a VAR of an auxiliary signal model of a specified FACTS device.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_FCTSAUXMOD_VAR  FD  ISGNDX  'MODEL'  J  RDATA
```

Python command syntax:

```
ierr = change_fctsauxmod_var(fd, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_FCTSAUXMOD_VAR(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTSAUXMOD_VAR_I(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_FCTSAUXMOD_VAR_C(NAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 FACTS device not found
	IERR = 2 invalid ISGNDX value for a FACTS device
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this FACTS device
	IERR = 5 model at this index for this FACTS device is aaa not xxx
	IERR = 6 no VARs used in model

IERR = 7	VAR number outside of the VAR range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.13. CHANGE_MTDCAUXMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of an auxiliary signal model of a specified multi-terminal dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCAUXMOD_CHRICN DC ISGNDX 'MODEL' J 'CHDATA'
```

Python command syntax:

```
ierr = change_mtdcauxmod_chricn(dc, isgndx, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCAUXMOD_CHRICN(NUM, ISGNDX, MODEL, J, CHDATA, IERR)
CALL CHANGE_MTDCAUXMOD_CHRICN_I(NUM, ISGNDX, MODEL, J, CHDATA, IERR)
CALL CHANGE_MTDCAUXMOD_CHRICN_C(NAME, ISGNDX, MODEL, J, CHDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a multi-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this multi-terminal dc line
	IERR = 5 model at this index for this multi-terminal dc line is aaa not xxx

IERR = 6	no input ICONs used in model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.14. CHANGE_MTDCAUXMOD_CON

Use this API to change the value of a CON of an auxiliary signal model of a specified multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCAUXMOD_CON DC ISGNDX 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_mtdcauxmod_con(dc, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCAUXMOD_CON(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCAUXMOD_CON_I(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCAUXMOD_CON_C(NAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a multi-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this multi-terminal dc line
	IERR = 5 model at this index for this multi-terminal dc line is aaa not xxx

IERR = 6	no CONs used in model
IERR = 7	CON number outside of the CON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.15. CHANGE_MTDCAUXMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_MTDCAUXMOD_CON](#), [CHANGE_MTDCAUXMOD_ICON](#), and [CHANGE_MTDCAUXMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of an auxiliary signal model of a specified multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCAUXMOD_DATA DC ISGNDX 'NAME' J RDATA I IDATA
'CHDATA'
```

Python command syntax:

```
ierr = change_mtdcauxmod_data(dc, isgndx, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCAUXMOD_DATA(DC, ISGNDX, NAME, J, RDATA, I, IDATA, CHDATA,
IERR)
```

Where:

Integer DC	number of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '''; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 dc line not found

IERR = 2	invalid ISGNDX value for a multi-terminal dc line
IERR = 3	unknown model name
IERR = 4	no auxiliary signal model at this index for this multi-terminal dc line
IERR = 5	model at this index for this multi-terminal dc line is aaa not xxx
IERR = 6	no CONs used in model; or
IERR = 6	no input ICONs used in model; or
IERR = 7	CON number outside of the CON range of this model; or
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.16. CHANGE_MTDCAUXMOD_ICON

Use this API to change the value of an integer ICON of an auxiliary signal model of a specified multi-terminal dc line. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_MTDCAUXMOD_ICON DC ISGNDX 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_mtdcauxmod_icon(dc, isgndx, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCAUXMOD_ICON(NUM, ISGNDX, MODEL, J, IDATA, IERR)
CALL CHANGE_MTDCAUXMOD_ICON_I(NUM, ISGNDX, MODEL, J, IDATA, IERR)
CALL CHANGE_MTDCAUXMOD_ICON_C(NAME, ISGNDX, MODEL, J, IDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a multi-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this multi-terminal dc line
	IERR = 5 model at this index for this multi-terminal dc line is aaa not xxx

IERR = 6	no input ICONs used in model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.17. CHANGE_MTDCAUXMOD_VAR

Use this API to change the value of a VAR of an auxiliary signal model of a specified multi-terminal dc line.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_MTDCAUXMOD_VAR DC ISGNDX 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_mtdcauxmod_var(dc, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_MTDCAUXMOD_VAR(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCAUXMOD_VAR_I(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_MTDCAUXMOD_VAR_C(NAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a multi-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this multi-terminal dc line
	IERR = 5 model at this index for this multi-terminal dc line is aaa not xxx

IERR = 6

no VARs used in model

IERR = 7

VAR number outside of the VAR range of this model

IERR = 8

prerequisite requirements for API are not met

7.12.18. CHANGE_TTDCAUXMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of an auxiliary signal model of a specified two-terminal dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCAUXMOD_CHRICN DC ISGNDX 'MODEL' J 'CHDATA'
```

Python command syntax:

```
ierr = change_ttdcauxmod_chricn(dc, isgndx, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCAUXMOD_CHRICN(NUM, ISGNDX, MODEL, J, CHDATA, IERR)
CALL CHANGE_TTDCAUXMOD_CHRICN_I(NUM, ISGNDX, MODEL, J, CHDATA, IERR)
CALL CHANGE_TTDCAUXMOD_CHRICN_C(NAME, ISGNDX, MODEL, J, CHDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Character*12 CHDATA	new character ICON value (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a two-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this two-terminal dc line
	IERR = 5 model at this index for this two-terminal dc line is aaa not xxx

IERR = 6	no input ICONs used in model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.19. CHANGE_TTDCAUXMOD_CON

Use this API to change the value of a CON of an auxiliary signal model of a specified two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCAUXMOD_CON DC ISGNDX 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_ttdcauxmod_con(dc, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCAUXMOD_CON( NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCAUXMOD_CON_I(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCAUXMOD_CON_C(NAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a two-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this two-terminal dc line
	IERR = 5 model at this index for this two-terminal dc line is aaa not xxx

IERR = 6	no CONs used in model
IERR = 7	CON number outside of the CON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.20. CHANGE_TTDCAUXMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_TTDCAUXMOD_CON](#), [CHANGE_TTDCAUXMOD_ICON](#), and [CHANGE_TTDCAUXMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of an auxiliary signal model of a specified two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCAUXMOD_DATA DC ISGNDX 'NAME' J RDATA I IDATA
'CHDATA'
```

Python command syntax:

```
ierr = change_ttdcauxmod_data(dc, isgndx, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCAUXMOD_DATA(DC, ISGNDX, NAME, J, RDATA, I, IDATA, CHDATA,
IERR)
```

Where:

Integer DC	number of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '''; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output). IERR = 0 no error IERR = 1 dc line not found

IERR = 2	invalid ISGNDX value for a two-terminal dc line
IERR = 3	unknown model name
IERR = 4	no auxiliary signal model at this index for this two-terminal dc line
IERR = 5	model at this index for this two-terminal dc line is aaa not xxx
IERR = 6	no CONs used in model
IERR = 6	no input ICONs used in model
IERR = 7	CON number outside of the CON range of this model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.21. CHANGE_TTDCAUXMOD_ICON

Use this API to change the value of an integer ICON of an auxiliary signal model of a specified two-terminal dc line. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_TTDCAUXMOD_ICON DC ISGNDX 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_ttdcauxmod_icon(dc, isgndx, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCAUXMOD_ICON(NUM, ISGNDX, MODEL, J, IDATA, IERR)
CALL CHANGE_TTDCAUXMOD_ICON_I(NUM, ISGNDX, MODEL, J, IDATA, IERR)
CALL CHANGE_TTDCAUXMOD_ICON_C(NAME, ISGNDX, MODEL, J, IDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(I), 2 for ICON(I+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a two-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this two-terminal dc line
	IERR = 5 model at this index for this two-terminal dc line is aaa not xxx

IERR = 6	no input ICONs used in model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.22. CHANGE_TTDCAUXMOD_VAR

Use this API to change the value of a VAR of an auxiliary signal model of a specified two-terminal dc line.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_TTDCAUXMOD_VAR DC ISGNDX 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_ttdcauxmod_var(dc, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_TTDCAUXMOD_VAR(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCAUXMOD_VAR_I(NUM, ISGNDX, MODEL, J, RDATA, IERR)
CALL CHANGE_TTDCAUXMOD_VAR_C(NAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a two-terminal dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this two-terminal dc line
	IERR = 5 model at this index for this two-terminal dc line is aaa not xxx

IERR = 6	no VARs used in model
IERR = 7	VAR number outside of the VAR range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.23. CHANGE_VSDCAUXMOD_CHRICN

Use this API to change the value of a character ICON (i.e., an element of the CHRICN array) of an auxiliary signal model of a specified VSC dc line. The corresponding integer ICON is set to 0.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCAUXMOD_CHRICN 'DCNAME' ISGNDX 'MODEL' J 'CHDATA'
```

Python command syntax:

```
ierr = change_vsdcauxmod_chricn(dcname, isgndx, model, j, chdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCAUXMOD_CHRICN(DCNAME, ISGNDX, MODEL, J, CHDATA, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).	
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).	
Character*16 MODEL	model name (input; no default allowed).	
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(l), 2 for ICON(l+1), etc.) (input; no default allowed).	
Character*12 CHDATA	new character ICON value (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	dc line not found
	IERR = 2	invalid ISGNDX value for a VSC dc line
	IERR = 3	unknown model name
	IERR = 4	no auxiliary signal model at this index for this VSC dc line
	IERR = 5	model at this index for this VSC dc line is aaa not xxx
	IERR = 6	no input ICONs used in model
	IERR = 7	ICON number outside of the ICON range of this model
	IERR = 8	prerequisite requirements for API are not met

7.12.24. CHANGE_VSDCAUXMOD_CON

Use this API to change the value of a CON of an auxiliary signal model of a specified VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCAUXMOD_CON 'DCNAME' ISGNDX 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_vsdcauxmod_con(dcname, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCAUXMOD_CON(DCNAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model (1 for CON(J), 2 for CON(J+1), etc.) (input; no default allowed).
Real RDATA	new CON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a VSC dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this VSC dc line
	IERR = 5 model at this index for this VSC dc line is aaa not xxx
	IERR = 6 no CONs used in model
	IERR = 7 CON number outside of the CON range of this model
	IERR = 8 prerequisite requirements for API are not met

7.12.25. CHANGE_VSDCAUXMOD_DATA

This API routine is obsolete. It has been replaced by the API routines [CHANGE_VSDCAUXMOD_CON](#), [CHANGE_VSDCAUXMOD_ICON](#), and [CHANGE_VSDCAUXMOD_CHRICN](#).

Use this API to change the value of an ICON and/or CON of an auxiliary signal model of a specified VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCAUXMOD_DATA 'DCNAME' ISGNDX 'NAME' J RDATA I IDATA
'CHDATA'
```

Python command syntax:

```
ierr = change_vsdcauxmod_data(dcname, isgndx, name, j, rdata, i, idata, chdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCAUXMOD_DATA(DCNAME, ISGNDX, NAME, J, RDATA, I, IDATA,
CHDATA, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 NAME	model name (input; no default allowed).
Integer J	CON number to change relative to the start of the block of CONs assigned to this model, or 0 for no CON change (1 for CON(J), 2 for CON(J+1), etc.) (input; 0 by default).
Real RDATA	new CON value (input; unchanged).
Integer I	ICON number to change relative to the start of the block of ICONs assigned to this model, or 0 for no ICON change (1 for ICON(I), 2 for ICON(I+1), etc.) (input; 0 by default).
Integer IDATA	new integer ICON value (input; unchanged by default). When a character value is intended for an ICON value, the IDATA entry is ignored and the integer ICON is set to 0).
Character*12 CHDATA	new character ICON value (no default allowed if the character ICON is to be changed). When an integer value is intended for an ICON value, the CHDATA entry must be either defaulted or specified as either '\$\$' or '' ; the character ICON is set to '\$\$' (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a VSC dc line

IERR = 3	unknown model name
IERR = 4	no auxiliary signal model at this index for this VSC dc line
IERR = 5	model at this index for this VSC dc line is aaa not xxx
IERR = 6	no CONs used in model
IERR = 6	no input ICONs used in model
IERR = 7	CON number outside of the CON range of this model
IERR = 7	ICON number outside of the ICON range of this model
IERR = 8	prerequisite requirements for API are not met

7.12.26. CHANGE_VSDCAUXMOD_ICON

Use this API to change the value of an integer ICON of an auxiliary signal model of a specified VSC dc line. The corresponding character CHRICON is set to '\$\$'.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CHANGE_VSDCAUXMOD_ICON 'DCNAME' ISGNDX 'MODEL' J IDATA
```

Python command syntax:

```
ierr = change_vsdcauxmod_icon(dcname, isgndx, model, j, idata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCAUXMOD_ICON(DCNAME, ISGNDX, MODEL, J, IDATA, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	ICON number to change relative to the start of the block of ICONs assigned to this model (1 for ICON(l), 2 for ICON(l+1), etc.) (input; no default allowed).
Integer IDATA	new integer ICON value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a VSC dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this VSC dc line
	IERR = 5 model at this index for this VSC dc line is aaa not xxx
	IERR = 6 no input ICONs used in model
	IERR = 7 ICON number outside of the ICON range of this model
	IERR = 8 prerequisite requirements for API are not met

7.12.27. CHANGE_VSDCAUXMOD_VAR

Use this API to change the value of a VAR of an auxiliary signal model of a specified VSC dc line.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CHANGE_VSDCAUXMOD_VAR 'DCNAME' ISGNDX 'MODEL' J RDATA
```

Python command syntax:

```
ierr = change_vsdcauxmod_var(dcname, isgndx, model, j, rdata)
```

Fortran command syntax:

```
CALL CHANGE_VSDCAUXMOD_VAR(DCNAME, ISGNDX, MODEL, J, RDATA, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Character*16 MODEL	model name (input; no default allowed).
Integer J	VAR number to change relative to the start of the block of VARs assigned to this model (1 for VAR(J), 2 for VAR(J+1), etc.) (input; no default allowed).
Real RDATA	new VAR value (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error
	IERR = 1 dc line not found
	IERR = 2 invalid ISGNDX value for a VSC dc line
	IERR = 3 unknown model name
	IERR = 4 no auxiliary signal model at this index for this VSC dc line
	IERR = 5 model at this index for this VSC dc line is aaa not xxx
	IERR = 6 no VARs used in model
	IERR = 7 VAR number outside of the VAR range of this model
	IERR = 8 prerequisite requirements for API are not met

7.12.28. FCTSAUXMOD_REMOVE

Use this API to remove an auxiliary signal model from the specified injection point of a designated FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTSAUXMOD_REMOVE  FD  ISGNDX
```

Python command syntax:

```
ierr = fctsauxmod_remove(fd, isgndx)
```

Fortran command syntax:

```
CALL FCTSAUXMOD_REMOVE(NUM, ISGNDX, IERR)
CALL FCTSAUXMOD_REMOVE_I(NUM, ISGNDX, IERR)
CALL FCTSAUXMOD_REMOVE_C(NAME, ISGNDX, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).	
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).	
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	FACTS device not found
	IERR = 2	invalid ISGNDX value for a FACTS device
	IERR = 3	no auxiliary signal model at this index for this FACTS device
	IERR = 4	prerequisite requirements for API are not met

7.12.29. FCTSAUXMOD_STATUS

Use this API to change the status of the auxiliary signal model at the specified injection point of a designated FACTS device.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_FCTSAUXMOD_STATUS  FD  ISGNDX  STATUS
```

Python command syntax:

```
ierr = fctsauxmod_status(fd, isgndx, status)
```

Fortran command syntax:

```
CALL FCTSAUXMOD_STATUS(NUM
    , ISGNDX, STATUS, IERR)

CALL FCTSAUXMOD_STATUS_I(NUM, ISGNDX, STATUS, IERR)

CALL FCTSAUXMOD_STATUS_C(NAME, ISGNDX, STATUS, IERR)
```

Where:

Integer or Character*12 FD	quoted name of the FACTS device receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the FACTS device receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 FACTS device not found IERR = 2 invalid ISGNDX value for a FACTS device IERR = 3 no auxiliary signal model at this index for this FACTS device IERR = 4 invalid STATUS value IERR = 5 prerequisite requirements for API are not met

7.12.30. MTDCAUXMOD_REMOVE

Use this API to remove an auxiliary signal model from the specified auxiliary signal index of the designated multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MTDCAUXMOD_REMOVE DC ISGNDX
```

Python command syntax:

```
ierr = mtdcauxmod_remove(dc, isgndx)
```

Fortran command syntax:

```
CALL MTDCAUXMOD_REMOVE(NUM, ISGNDX, IERR)
CALL MTDCAUXMOD_REMOVE_I(NUM, ISGNDX, IERR)
CALL MTDCAUXMOD_REMOVE_C(NAME, ISGNDX, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).	
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).	
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	dc line not found
	IERR = 2	invalid ISGNDX value for a multi-terminal dc line
	IERR = 3	no auxiliary signal model at this index for this multi-terminal dc line
	IERR = 4	prerequisite requirements for API are not met

7.12.31. MTDCAUXMOD_STATUS

Use this API to change the status of the auxiliary signal model at the specified auxiliary signal index of the designated multi-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_MTDCAUXMOD_STATUS DC ISGNDX STATUS
```

Python command syntax:

```
ierr = mtdcauxmod_status(dc, isgndx, status)
```

Fortran command syntax:

```
CALL MTDCAUXMOD_STATUS(NUM, ISGNDX, STATUS, IERR)
CALL MTDCAUXMOD_STATUS_I(NUM, ISGNDX, STATUS, IERR)
CALL MTDCAUXMOD_STATUS_C(NAME, ISGNDX, STATUS, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the multi-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the multi-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 dc line not found IERR = 2 invalid ISGNDX value for a multi-terminal dc line IERR = 3 no auxiliary signal model at this index for this multi-terminal dc line IERR = 4 invalid STATUS value IERR = 5 prerequisite requirements for API are not met

7.12.32. TTDCAUXMOD_REMOVE

Use this API to remove an auxiliary signal model from the specified injection point of the designated two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_TTDCAUXMOD_REMOVE DC ISGNDX
```

Python command syntax:

```
ierr = ttdcauxmod_remove(dc, isgndx)
```

Fortran command syntax:

```
CALL TTDCAUXMOD_REMOVE(NUM, ISGNDX, IERR)
CALL TTDCAUXMOD_REMOVE_I(NUM, ISGNDX, IERR)
CALL TTDCAUXMOD_REMOVE_C(NAME, ISGNDX, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).	
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).	
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).	
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	dc line not found
	IERR = 2	invalid ISGNDX value for a two-terminal dc line
	IERR = 3	no auxiliary signal model at this index for this two-terminal dc line
	IERR = 4	prerequisite requirements for API are not met

7.12.33. TTDCAUXMOD_STATUS

Use this API to change the status of the auxiliary signal model at the specified injection point of the designated two-terminal dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_TTDCAUXMOD_STATUS DC ISGNDX STATUS
```

Python command syntax:

```
ierr = ttdcauxmod_status(dc, isgndx, status)
```

Fortran command syntax:

```
CALL TTDCAUXMOD_STATUS(NUM, ISGNDX, STATUS, IERR)
CALL TTDCAUXMOD_STATUS_I(NUM, ISGNDX, STATUS, IERR)
CALL TTDCAUXMOD_STATUS_C(NAME, ISGNDX, STATUS, IERR)
```

Where:

Integer or Character*12 DC	quoted name of the two-terminal dc line receiving the of the auxiliary signal model; if an unquoted integer value is specified, the API converts it to a left-justified name (input; no default allowed).
Integer NUM	number (which the API converts to a left-justified name) of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Character*12 NAME	name of the two-terminal dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 2 dc line not found IERR = 3 invalid ISGNDX value for a two-terminal dc line IERR = 4 no auxiliary signal model at this index for this two-terminal dc line IERR = 5 invalid STATUS value IERR = 6 prerequisite requirements for API are not met

7.12.34. VSDCAUXMOD_REMOVE

Use this API to remove an auxiliary signal model from the specified injection point of the designated VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VSDCAUXMOD_REMOVE 'DCNAME' ISGNDX
```

Python command syntax:

```
ierr = vsdcauxmod_remove(dcname, isgndx)
```

Fortran command syntax:

```
CALL VSDCAUXMOD_REMOVE(DCNAME, ISGNDX, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).	
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	dc line not found
	IERR = 2	invalid ISGNDX value for a VSC dc line
	IERR = 3	no auxiliary signal model at this index for this VSC dc line
	IERR = 4	prerequisite requirements for API are not met

7.12.35. VSDCAUXMOD_STATUS

Use this API to change the status of the auxiliary signal model at the specified injection point of the designated VSC dc line.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_VSDCAUXMOD_STATUS 'DCNAME' ISGNDX STATUS
```

Python command syntax:

```
ierr = vsdcauxmod_status(dcname, isgndx, status)
```

Fortran command syntax:

```
CALL VSDCAUXMOD_STATUS(DCNAME, ISGNDX, STATUS, IERR)
```

Where:

Character*12 DCNAME	name of the VSC dc line receiving the of the auxiliary signal model (input; no default allowed).
Integer ISGNDX	auxiliary signal injection point number, or the auxiliary signal index (input; 1 by default).
Integer STATUS	new model status (input; 1 by default). STATUS = 0 out-of-service STATUS = 1 in-service
Integer IERR	error code (output). IERR = 0 no error IERR = 1 VSC dc line not found IERR = 2 invalid ISGNDX value for a VSC dc line IERR = 3 no auxiliary signal model at this index for this VSC dc line IERR = 4 invalid STATUS value IERR = 5 prerequisite requirements for API are not met

7.13. Set Disturbance

The last section, Set Disturbance, contains API routines for applying and removing disturbances during dynamics simulations.

7.13.1. DIST_3PHASE_BUS_FAULT

This API routine is obsolete.

Use this API to apply a three phase fault at a bus during dynamic simulations.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_DIST_3PHASE_BUS_FAULT IBUS  NODE  UNITS  BASEKV  VALUES(1)  VALUES(2)
```

Python command syntax:

```
ierr = dist_3phase_bus_fault(ibus, node, units, basekv, values)
```

Fortran command syntax:

```
CALL DIST_3PHASE_BUS_FAULT(IBUS, NODE, UNITS, BASEKV, VALUES, IERR)
```

Where:

Integer IBUS	bus number of the bus at which the fault is to be placed (input; no default allowed).
Integer NODE	node number of a substation node connected to the specified bus; this defines the bus section to be faulted. If 0 is specified for a bus in a substation, the 'parent' bus is faulted; 0 must be specified for a bus that is not in a substation (input; 0 by default).
Integer UNITS	units in which fault admittance or impedance is specified in VALUES (input; 1 by default). UNITS = 1 admittance in MVA UNITS = 2 admittance in mhos UNITS = 3 impedance in ohms
Real BASEKV	base voltage in kV used to calculate the per unit fault admittance if UNITS is 2 or 3; ignored if UNITS is 1. If BASEKV is specified as 0.0, the base voltage of bus IBUS is used (input; 0.0).
Real VALUES (2)	array of 2 elements specifying (input). VALUES(1) real component of the complex fault admittance or impedance according to the value specified for UNITS (0.0 by default) VALUES(2) reactive component of the complex fault admittance or impedance according to the value specified for UNITS (-2.0E11 by default)
Integer IERR	error code (output).

IERR = 0	no error occurred
IERR = 1	STRT or MSTR has not been successfully executed
IERR = 2	fixed bus shunt table is full
IERR = 3	bus is out-of-service
IERR = 4	invalid UNITS value
IERR = 5	invalid BASEKV value (<0.0)
IERR = 6	both BASEKV and the base voltage of bus IBUS are 0.0
IERR = 7	invalid bus number
IERR = 8	bus not found
IERR = 9	invalid node number
IERR = 10	bus does not belong to a substation
IERR = 11	node not found in the substation of this bus
IERR = 12	node is not connected to any bus section of this bus
IERR = 13	prerequisite requirements for API are not met

7.13.2. DIST_3WIND_CLOSE

Use this API to set a three-winding transformer to in-service during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_3WIND_CLOSE IBUS JBUS KBUS 'ID'
```

Python command syntax:

```
ierr = dist_3wind_close(ibus, jbus, kbus, id)
```

Fortran command syntax:

```
CALL DIST_3WIND_CLOSEAPI(IBUS, JBUS, KBUS, ID, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number of one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 ID	circuit identifier (input; '1' by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	STRT or MSTR has not been successfully executed
IERR = 2	bus not found
IERR = 3	three-winding transformer not found
IERR = 4	three-winding transformer is already in-service
IERR = 5	bus is out-of-service
IERR = 6	prerequisite requirements for API are not met

7.13.3. DIST_3WIND_FAULT

Use this API to apply a fault at the IBUS end of a three-winding transformer during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_3WIND_FAULT IBUS JBUS KBUS 'ID' UNITS BASEKV VALUES(1)
VALUES(2)
```

Python command syntax:

```
ierr = dist_3wind_fault(ibus, jbus, kbus, id, units, basekv, values)
```

Fortran command syntax:

```
CALL DIST_3WIND_FAULTAPI( IBUS, JBUS, KBUS, ID, UNITS, BASEKV, VALUES, IERR)
```

Where:

Integer IBUS	bus number of the bus at which the fault is to be placed (input; no default allowed).
Integer JBUS	bus number of one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 ID	circuit identifier (input; '1' by default).
Integer UNITS	units in which fault admittance or impedance is specified in VALUES (input; 1 by default). UNITS = 1 admittance in MVA UNITS = 2 admittance in mhos UNITS = 3 impedance in ohms
Real BASEKV	base voltage in kV used to calculate the per unit fault admittance if UNITS is 2 or 3; ignored if UNITS is 1. If BASEKV is specified as 0.0, the base voltage of bus IBUS is used (input; 0.0).
Real VALUES (2)	array of 2 elements specifying (input). VALUES(1) real component of the complex fault admittance or impedance according to the value specified for UNITS (0.0 by default) VALUES(2) reactive component of the complex fault admittance or impedance according to the value specified for UNITS (-2.0E11 by default)
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 STRT or MSTR has not been successfully executed IERR = 2 bus not found IERR = 3 three-winding transformer not found IERR = 4 three-winding transformer winding is out-of-service

IERR = 5	invalid UNITS value
IERR = 6	invalid BASEKV value (<0.0)
IERR = 7	both BASEKV and the base voltage of bus IBUS are 0.0
IERR = 8	prerequisite requirements for API are not met

7.13.4. DIST_3WIND_TRIP

Use this API to set a three-winding transformer to out-of-service during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_3WIND_TRIP IBUS JBUS KBUS 'ID'
```

Python command syntax:

```
ierr = dist_3wind_trip(ibus, jbus, kbus, id)
```

Fortran command syntax:

```
CALL DIST_3WIND_TRIPAPI(IBUS, JBUS, KBUS, ID, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number of one of the other buses (input; no default allowed).
Integer KBUS	bus number of the third bus (input; no default allowed).
Character*2 ID	circuit identifier (input; '1' by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	STRT or MSTR has not been successfully executed
IERR = 2	bus not found
IERR = 3	three-winding transformer not found
IERR = 4	three-winding transformer is already out-of-service
IERR = 5	prerequisite requirements for API are not met

7.13.5. DIST_BRANCH_CLOSE

Use this API to set a non-transformer branch or a two-winding transformer to in-service during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_BRANCH_CLOSE IBUS JBUS 'ID'
```

Python command syntax:

```
ierr = dist_branch_close(ibus, jbus, id)
```

Fortran command syntax:

```
CALL DIST_BRANCH_CLOSEAPI(IBUS, JBUS, ID, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).
Integer JBUS	bus number of the other bus (input; no default allowed).
Character*2 ID	circuit identifier (input; '1' by default).
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	STRT or MSTR has not been successfully executed
IERR = 2	bus not found
IERR = 3	branch not found
IERR = 4	branch is already in-service
IERR = 5	bus is out-of-service
IERR = 6	prerequisite requirements for API are not met

7.13.6. DIST_BRANCH_FAULT

Use this API to apply a fault at the IBUS end of a non-transformer branch or a two-winding transformer during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_BRANCH_FAULT IBUS JBUS 'ID' UNITS BASEKV VALUES(1)
VALUES(2)
```

Python command syntax:

```
ierr = dist_branch_fault(ibus, jbus, id, units, basekv, values)
```

Fortran command syntax:

```
CALL DIST_BRANCH_FAULTAPI( IBUS, JBUS, ID, UNITS, BASEKV, VALUES, IERR)
```

Where:

Integer IBUS	bus number of the bus at which the fault is to be placed (input; no default allowed).	
Integer JBUS	bus number of the other bus (input; no default allowed).	
Character*2 ID	circuit identifier (input; '1' by default).	
Integer UNITS	units in which fault admittance or impedance is specified in VALUES (input; 1 by default).	
	UNITS = 1	admittance in MVA
	UNITS = 2	admittance in mhos
	UNITS = 3	impedance in ohms
Real BASEKV	base voltage in kV used to calculate the per unit fault admittance if UNITS is 2 or 3; ignored if UNITS is 1. If BASEKV is specified as 0.0, the base voltage of bus IBUS is used (input; 0.0).	
Real VALUES (2)	array of 2 elements specifying (input).	
	VALUES(1)	real component of the complex fault admittance or impedance according to the value specified for UNITS (0.0 by default)
	VALUES(2)	reactive component of the complex fault admittance or impedance according to the value specified for UNITS (-2.0E11 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR has not been successfully executed
	IERR = 2	bus not found
	IERR = 3	branch not found
	IERR = 4	branch is out-of-service
	IERR = 5	invalid UNITS value

IERR = 6	invalid BASEKV value (<0.0)
IERR = 7	both BASEKV and the base voltage of bus IBUS are 0.0
IERR = 8	prerequisite requirements for API are not met

7.13.7. DIST_BRANCH_TRIP

Use this API to set a non-transformer branch or a two-winding transformer to out-of-service during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_BRANCH_TRIP IBUS JBUS 'ID'
```

Python command syntax:

```
ierr = dist_branch_trip(ibus, jbus, id)
```

Fortran command syntax:

```
CALL DIST_BRANCH_TRIPAPI(IBUS, JBUS, ID, IERR)
```

Where:

Integer IBUS	bus number of one of the buses (input; no default allowed).	
Integer JBUS	bus number of the other bus (input; no default allowed).	
Character*2 ID	circuit identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR has not been successfully executed
	IERR = 2	bus not found
	IERR = 3	branch not found
	IERR = 4	branch is already out-of-service
	IERR = 5	prerequisite requirements for API are not met

7.13.8. DIST_BUS_FAULT

This API routine is obsolete. It has been replaced by the API routine [dist_3phase_bus_fault](#).

Use this API to apply a fault at a bus during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_BUS_FAULT IBUS UNITS BASEKV VALUES(1) VALUES(2)
```

Python command syntax:

```
ierr = dist_bus_fault(ibus, units, basekv, values)
```

Fortran command syntax:

```
CALL DIST_BUS_FAULTAPI(IBUS, UNITS, BASEKV, VALUES, IERR)
```

Where:

Integer IBUS	bus number of the bus at which the fault is to be placed (input; no default allowed).
Integer UNITS	units in which fault admittance or impedance is specified in VALUES (input; 1 by default). UNITS = 1 admittance in MVA UNITS = 2 admittance in mhos UNITS = 3 impedance in ohms
Real BASEKV	base voltage in kV used to calculate the per unit fault admittance if UNITS is 2 or 3; ignored if UNITS is 1. If BASEKV is specified as 0.0, the base voltage of bus IBUS is used (input; 0.0).
Real VALUES (2)	array of 2 elements specifying (input). VALUES(1) real component of the complex fault admittance or impedance according to the value specified for UNITS (0.0 by default) VALUES(2) reactive component of the complex fault admittance or impedance according to the value specified for UNITS (-2.0E11 by default)
Integer IERR	error code (output). IERR = 0 no error occurred IERR > 0 as in DIST_3PHASE_BUS_FAULT

7.13.9. DIST_BUS_FAULT_2

This API routine is obsolete. It has been replaced by the API routine [dist_bus_fault_3](#).

Use this API to apply a fault at a bus during dynamic simulations.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_DIST_BUS_FAULT_2  UNITS BASEKV OPTIONS(1)..OPTIONS(4)
                      VALUES(1)..VALUES(6)
```

Python command syntax:

```
ierr = dist_bus_fault_2(units, basekv, options, values)
```

Fortran command syntax:

```
CALL DIST_BUS_FAULT_2(UNITS, BASEKV, OPTIONS, VALUES, IERR)
```

Where:

Integer UNITS	units in which fault admittance or impedance is specified in VALUES (input; 1 by default).
	UNITS = 1 admittance in MVA
	UNITS = 2 admittance in mhos
	UNITS = 3 impedance in ohms
Real BASEKV	base voltage in kV used to calculate the per unit fault admittance if UNITS is 2 or 3; ignored if UNITS is 1. If BASEKV is specified as 0.0, the base voltage of bus IBUS is used (input; 0.0).
Integer OPTIONS (4)	array of 4 elements specifying options and values. The first element of OPTIONS defines the option to be used in the construction of the sequence admittance matrices; the remaining entries define the fault to be applied(input).
	OPTIONS(1) transformer impedance correction option (1 by default)
	OPTIONS(1) = 0 do not apply to zero sequence
	OPTIONS(1) = 1 apply to zero sequence
	OPTIONS(2) unbalanced type (1 by default)
	OPTIONS(2) = 1 line-to-ground fault
	OPTIONS(2) = 2 line-to-line or line-to-line-to-ground fault
	OPTIONS(3) bus to be faulted (no default allowed)
	OPTIONS(4) exceptional phase (1 by default)
	OPTIONS(4) = 1 phase A
	OPTIONS(4) = 2 phase B
	OPTIONS(4) = 3 phase C
Real VALUES (6)	array of 6 elements specifying values used to define the fault. The first two elements of VALUES define the fault admittance or imped-

ance to be used in the simulation; the remaining entries are used to define the fault if phase voltages are to be calculated during the simulation.(input).

VALUES(1)	real component of the complex fault admittance or impedance according to the value specified for UNITS (0.0 by default)
VALUES(2)	reactive component of the complex fault admittance or impedance according to the value specified for UNITS (-2.0E11 by default)
VALUES(3)	resistance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(2) is 2) fault impedance in pu (0.0 by default)
VALUES(4)	reactance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(2) is 2) fault impedance in pu (0.0 by default)
VALUES(5)	resistance of the complex L-G fault impedance in pu (if OPTIONS(2) is 2) (0.0 by default)
VALUES(6)	reactance of the complex L-G fault impedance in pu (if OPTIONS(2) is 2) (0.0 by default)

Integer IERR

error code (output).

IERR = 0	no error occurred
IERR > 0	as in DIST_BUS_FAULT_3

7.13.10. DIST_BUS_FAULT_3

Use this API to apply an unbalanced fault at a bus during dynamic simulations.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_DIST_BUS_FAULT_3  UNITS BASEKV OPTIONS(1)..OPTIONS(5)
                      VALUES(1)..VALUES(6)
```

Python command syntax:

```
ierr = dist_bus_fault_3(units, basekv, options, values)
```

Fortran command syntax:

```
CALL DIST_BUS_FAULT_3(UNITS, BASEKV, OPTIONS, VALUES, IERR)
```

Where:

Integer UNITS	units in which fault admittance or impedance is specified in VALUES (input; 1 by default).
	UNITS = 1 admittance in MVA
	UNITS = 2 admittance in mhos
	UNITS = 3 impedance in ohms
Real BASEKV	base voltage in kV used to calculate the per unit fault admittance if UNITS is 2 or 3; ignored if UNITS is 1. If BASEKV is specified as 0.0, the base voltage of bus IBUS is used (input; 0.0).
Integer OPTIONS (5)	array of 5 elements specifying options and values. The first element of OPTIONS defines the option to be used in the construction of the sequence admittance matrices; the remaining entries define the fault to be applied(input).
	OPTIONS(1) transformer impedance correction option (1 by default)
	OPTIONS(1) = 0 do not apply to zero sequence
	OPTIONS(1) = 1 apply to zero sequence
	OPTIONS(2) unbalanced type (1 by default)
	OPTIONS(2) = 1 line-to-ground fault
	OPTIONS(2) = 2 line-to-line or line-to-line-to-ground fault
	OPTIONS(3) bus to be faulted (no default allowed)
	OPTIONS(4) node number of a substation node connected to the specified bus; this defines the bus section to be faulted. If 0 is specified for a bus in a substation, the 'parent' bus is faulted; 0 must be specified for a bus that is not in a substation (0 by default)
	OPTIONS(5) exceptional phase (1 by default)
	OPTIONS(5) = 1 phase A
	OPTIONS(5) = 2 phase B

	OPTIONS(5) = 3	phase C
Real VALUES (6)	array of 6 elements specifying values used to define the fault. The first two elements of VALUES define the fault admittance or impedance to be used in the simulation; the remaining entries are used to define the fault if phase voltages are to be calculated during the simulation.(input).	
	VALUES(1)	real component of the complex fault admittance or impedance according to the value specified for UNITS (0.0 by default)
	VALUES(2)	reactive component of the complex fault admittance or impedance according to the value specified for UNITS (-2.0E11 by default)
	VALUES(3)	resistance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(2) is 2) fault impedance in pu (0.0 by default)
	VALUES(4)	reactance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(2) is 2) fault impedance in pu (0.0 by default)
	VALUES(5)	resistance of the complex L-G fault impedance in pu (if OPTIONS(2) is 2) (0.0 by default)
	VALUES(6)	reactance of the complex L-G fault impedance in pu (if OPTIONS(2) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR has not been successfully executed
	IERR = 2	fixed bus shunt table is full
	IERR = 3	bus is out-of-service
	IERR = 4	invalid UNITS value
	IERR = 5	invalid BASEKV value (<0.0)
	IERR = 6	both BASEKV and the base voltage of bus IBUS are 0.0
	IERR = 7	invalid bus number
	IERR = 8	bus not found
	IERR = 9	invalid node number
	IERR = 10	bus does not belong to a substation
	IERR = 11	node not found in the substation of this bus
	IERR = 12	node is not connected to any bus section of this bus
	IERR = 13	prerequisite requirements for API are not met

7.13.11. DIST_BUS_TRIP

Use this API to disconnect a bus during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_BUS_TRIP IBUS
```

Python command syntax:

```
ierr = dist_bus_trip(ibus)
```

Fortran command syntax:

```
CALL DIST_BUS_TRIPAPI(IBUS, IERR)
```

Where:

Integer IBUS	bus number of the bus to be disconnected (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR not successfully executed
	IERR = 2	bus not found
	IERR = 3	bus is already disconnected
	IERR = 4	prerequisite requirements for API are not met

7.13.12. DIST_CLEAR_FAULT

Use this API to clear a fault during dynamic simulations. The fault must have previously been applied using one of the following APIs:

- DIST_3WIND_FAULT
- DIST_BRANCH_FAULT
- DIST_BUS_FAULT_3
- DIST_SCMU_FAULT_3
- DIST_SPCB_FAULT_2

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_CLEAR_FAULT  FAULT
```

Python command syntax:

```
ierr = dist_clear_fault(fault)
```

Fortran command syntax:

```
CALL DIST_CLEAR_FAULTAPI(FAULT, IERR)
```

Where:

Integer FAULT	index in the fault memory tables of the fault to be cleared (input; 1 by default). Faults are stored in the fault memory tables in the order in which they are applied; the index assigned to a fault is the next available location in the tables. Each time a fault is cleared using this API, the fault memory tables are compressed. Thus, if there are three faults active, the most recently applied fault will have index number 3).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR not successfully executed
	IERR = 2	bus not found
	IERR = 3	branch not found
	IERR = 4	three-winding transformer not found
	IERR = 5	fixed bus shunt not found
	IERR = 6	no faults in the fault memory tables
	IERR = 7	invalid bus number
	IERR = 8	bus not found
	IERR = 9	invalid node number
	IERR = 10	bus does not belong to a substation
	IERR = 11	node not found in the substation of this bus
	IERR = 12	node is not connected to any bus section of this bus
	IERR = 13	invalid FAULT value
	IERR = 14	prerequisite requirements for API are not met

7.13.13. DIST_MACHINE_TRIP

Use this API to set a machine to out-of-service during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_MACHINE_TRIP IBUS 'ID'
```

Python command syntax:

```
ierr = dist_machine_trip(ibus,id)
```

Fortran command syntax:

```
CALL DIST_MACHINE_TRIPAPI(IBUS, ID, IERR)
```

Where:

Integer IBUS	bus number of machine to be tripped (input; no default allowed).	
Character*2 ID	machine identifier (input; '1' by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR not successfully executed
	IERR = 2	bus not found
	IERR = 3	machine not found
	IERR = 4	machine is already out-of-service
	IERR = 5	prerequisite requirements for API are not met

7.13.14. DIST_SCMU_FAULT

This API routine is obsolete. It has been replaced by the API routine [dist_scmu_fault_2](#).

Use this API to calculate an unbalanced fault and apply the equivalent positive sequence fault admittance at a bus during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_SCMU_FAULT  OPTIONS(1)..OPTIONS(4)  VALUES(1)..VALUES(4)
```

Python command syntax:

```
ierr = dist_scmu_fault(options, values)
```

Fortran command syntax:

```
CALL DIST_SCMU_FAULTAPI(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (4)	array of 4 elements specifying options and values. The first two elements of OPTIONS define options to be used in the construction of the sequence admittance matrices; the remaining entries define the fault to be applied(input).
OPTIONS(1)	dc line and FACTS device option (0 by default)
OPTIONS(1) = 0	block and ignore
OPTIONS(1) = 1	convert to constant admittance load
OPTIONS(2)	transformer impedance correction option (1 by default)
OPTIONS(2) = 0	do not apply to zero sequence
OPTIONS(2) = 1	apply to zero sequence
OPTIONS(3)	unbalanced type (1 by default)
OPTIONS(3) = 1	line-to-ground fault
OPTIONS(3) = 2	line-to-line or line-to-line-to-ground fault
OPTIONS(4)	bus to be faulted (no default allowed)
Real VALUES (4)	array of 4 elements specifying values used to define the fault. They are dependent on the value specified for OPTIONS(3)(input).
VALUES(1)	resistance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(3) is 2) fault impedance in pu (0.0 by default)
VALUES(2)	reactance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(3) is 2) fault impedance in pu (0.0 by default)
VALUES(3)	resistance of the complex L-G fault impedance in pu (if OPTIONS(3) is 2) (0.0 by default)

	VALUES(4)	reactance of the complex L-G fault impedance in pu (if OPTIONS(3) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR not successfully executed
	IERR = 2	fixed bus shunt table is full
	IERR = 3	error encountered in executing SCMUAPI
	IERR = 4	prerequisite requirements for API are not met

7.13.15. DIST_SCMU_FAULT_2

This API routine is obsolete. It has been replaced by the API routine [dist_scmu_fault_3](#).

Use this API to calculate an unbalanced fault and apply the equivalent positive sequence fault admittance at a bus during dynamic simulations.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_DIST_SCMU_FAULT_2  OPTIONS(1)..OPTIONS(5)  VALUES(1)..VALUES(4)
```

Python command syntax:

```
ierr = dist_scmu_fault_2(options, values)
```

Fortran command syntax:

```
CALL DIST_SCMU_FAULT_2(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (5)	array of 5 elements specifying options and values. The first two elements of OPTIONS define options to be used in the construction of the sequence admittance matrices; the remaining entries define the fault to be applied(input).
OPTIONS(1)	dc line and FACTS device option (0 by default)
OPTIONS(1) = 0	block and ignore
OPTIONS(1) = 1	convert to constant admittance load
OPTIONS(2)	transformer impedance correction option (1 by default)
OPTIONS(2) = 0	do not apply to zero sequence
OPTIONS(2) = 1	apply to zero sequence
OPTIONS(3)	unbalanced type (1 by default)
OPTIONS(3) = 1	line-to-ground fault
OPTIONS(3) = 2	line-to-line or line-to-line-to-ground fault
OPTIONS(4)	bus to be faulted (no default allowed)
OPTIONS(5)	exceptional phase (1 by default)
OPTIONS(5) = 1	phase A
OPTIONS(5) = 2	phase B
OPTIONS(5) = 3	phase C
Real VALUES (4)	array of 4 elements specifying values used to define the fault. They are dependent on the value specified for OPTIONS(3)(input).
VALUES(1)	resistance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(3) is 2) fault impedance in pu (0.0 by default)

	VALUES(2)	reactance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(3) is 2) fault impedance in pu (0.0 by default)
	VALUES(3)	resistance of the complex L-G fault impedance in pu (if OPTIONS(3) is 2) (0.0 by default)
	VALUES(4)	reactance of the complex L-G fault impedance in pu (if OPTIONS(3) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	as in DIST_SCMU_FAULT_3

7.13.16. DIST_SCMU_FAULT_3

Use this API to calculate an unbalanced fault and apply the equivalent positive sequence fault admittance at a bus during dynamic simulations.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_DIST_SCMU_FAULT_3  OPTIONS(1)..OPTIONS(6)  VALUES(1)..VALUES(4)
```

Python command syntax:

```
ierr = dist_scmu_fault_3(options, values)
```

Fortran command syntax:

```
CALL DIST_SCMU_FAULT_3(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (6)

array of 6 elements specifying options and values. The first two elements of OPTIONS define options to be used in the construction of the sequence admittance matrices; the remaining entries define the fault to be applied(input).

OPTIONS(1)	dc line and FACTS device option (0 by default)
OPTIONS(1) = 0	block and ignore
OPTIONS(1) = 1	convert to constant admittance load
OPTIONS(2)	transformer impedance correction option (1 by default)
OPTIONS(2) = 0	do not apply to zero sequence
OPTIONS(2) = 1	apply to zero sequence
OPTIONS(3)	unbalanced type (1 by default)
OPTIONS(3) = 1	line-to-ground fault
OPTIONS(3) = 2	line-to-line or line-to-line-to-ground fault
OPTIONS(4)	bus to be faulted (no default allowed)
OPTIONS(5)	node number of a substation node connected to the specified bus; this defines the bus section to be faulted. If 0 is specified for a bus in a substation, the 'parent' bus is faulted; 0 must be specified for a bus that is not in a substation (0 by default)
OPTIONS(6)	exceptional phase
OPTIONS(6) = 1	phase A
OPTIONS(6) = 2	phase B
OPTIONS(6) = 3	phase C

Real VALUES (4)

array of 4 elements specifying values used to define the fault. They are dependent on the value specified for OPTIONS(3)(input).

	VALUES(1)	resistance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(3) is 2) fault impedance in pu (0.0 by default)
	VALUES(2)	reactance of the complex L-G (if OPTIONS(3) is 1) or L-L (if OPTIONS(3) is 2) fault impedance in pu (0.0 by default)
	VALUES(3)	resistance of the complex L-G fault impedance in pu (if OPTIONS(3) is 2) (0.0 by default)
	VALUES(4)	reactance of the complex L-G fault impedance in pu (if OPTIONS(3) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR not successfully executed
	IERR = 2	fixed bus shunt table is full
	IERR = 3	error encountered in executing SCMU_2
	IERR = 4	prerequisite requirements for API are not met
	IERR = 7	invalid bus number
	IERR = 8	bus not found
	IERR = 9	invalid node number
	IERR = 10	bus does not belong to a substation
	IERR = 11	node not found in the substation of this bus
	IERR = 12	node is not connected to any bus section of this bus

7.13.17. DIST_SPCB_FAULT

This API routine is obsolete. It has been replaced by the API routine [dist_spcb_fault_2](#).

Use this API to calculate a branch unbalance and apply the equivalent positive sequence pi model at a branch during dynamic simulations.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_DIST_SPCB_FAULT IBUS JBUS 'ID' OPTIONS(1)..OPTIONS(6)
VALUES(1)..VALUES(5)
```

Python command syntax:

```
ierr = dist_spcb_fault(ibus, jbus, id, options, values)
```

Fortran command syntax:

```
CALL DIST_SPCB_FAULTAPI(IBUS, JBUS, ID, OPTIONS, VALUES, IERR)
```

Where:

Integer IBUS	from bus of branch to be subjected to unbalance (input; no default allowed).
Integer JBUS	to bus of branch to be subjected to unbalance (input; no default allowed).
Character*2 ID	circuit identifier of branch to be subjected to unbalance (input; '1' by default).
Integer OPTIONS (6)	array of 6 elements specifying unbalance options(input).
	OPTIONS(1) unbalance code (1 by default)
	OPTIONS(1) = 1 one phase open
	OPTIONS(1) = 2 two phases open
	OPTIONS(1) = 3 in-line fault
	OPTIONS(1) = 4 one breaker open
	OPTIONS(2) path to ground code (used when OPTIONS(1) is 1 or 4) (0 by default)
	OPTIONS(2) = 0 no path to ground
	OPTIONS(2) = 1 include a path to ground
	OPTIONS(3) type of in-line fault code (used when OPTIONS(1) is 3) (1 by default)
	OPTIONS(3) = 1 line-to-ground fault
	OPTIONS(3) = 2 line-to-line-to-ground fault
	OPTIONS(3) = 3 three phase fault
	OPTIONS(4) open end code (used when OPTIONS(1) is 4) (1 by default)
	OPTIONS(4) = 0 breaker at bus JBUS is open

	OPTIONS(4) = 1	breaker at bus IBUS is open
	OPTIONS(5)	dc line and FACTS device option (0 by default)
	OPTIONS(5) = 0	block and ignore
	OPTIONS(5) = 1	convert to constant admittance load
	OPTIONS(6)	transformer impedance correction option (1 by default)
	OPTIONS(6) = 0	do not apply to zero sequence
	OPTIONS(6) = 1	apply to zero sequence
Real VALUES (5)	array of 5 elements specifying unbalance parameters(input).	
	VALUES(1)	fault location as fraction of line from bus IBUS; $0.0 < \text{VALUES}(1) < 1.0$ (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3) (0.5 by default)
	VALUES(2)	RI-g (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3 and OPTIONS(3) is 1 or 2) (0.0 by default)
	VALUES(3)	XI-g (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3 and OPTIONS(3) is 1 or 2) (0.0 by default)
	VALUES(4)	RI-I used when OPTIONS(1) is 3 and OPTIONS(3) is 2) (0.0 by default)
	VALUES(5)	XI-I (used when OPTIONS(1) is 3 and OPTIONS(3) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR has not been successfully executed
	IERR = 2	bus not found
	IERR = 3	branch not found
	IERR = 4	branch is out-of-service
	IERR = 5	error encountered in executing SPCBAPI
	IERR = 6	prerequisite requirements for API are not met

7.13.18. DIST_SPCB_FAULT_2

Use this API routine to run the second release of the dynamics branch unbalance function. Use this API routine to calculate a branch unbalance and apply the equivalent positive sequence pi model at a branch during dynamic simulations.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_DIST_SPCB_FAULT_2  IBUS  JBUS  'ID'  OPTIONS(1)..OPTIONS(7)
                        VALUES(1)..VALUES(5)
```

Python command syntax:

```
ierr = dist_spcb_fault_2(ibus, jbus, id, options, values)
```

Fortran command syntax:

```
CALL DIST_SPCB_FAULT_2(IBUS, JBUS, ID, OPTIONS, VALUES, IERR)
```

Where:

Integer IBUS	from bus of branch to be subjected to unbalance (input; no default allowed).
Integer JBUS	to bus of branch to be subjected to unbalance (input; no default allowed).
Character*2 ID	circuit identifier of branch to be subjected to unbalance (input; '1' by default).
Integer OPTIONS (7)	array of 7 elements specifying unbalance options(input).
	OPTIONS(1) unbalance code (1 by default)
	OPTIONS(1) = 1 one phase open
	OPTIONS(1) = 2 two phases open
	OPTIONS(1) = 3 in-line fault
	OPTIONS(1) = 4 one breaker open
	OPTIONS(2) path to ground code (used when OPTIONS(1) is 1 or 4) (0 by default)
	OPTIONS(2) = 0 no path to ground
	OPTIONS(2) = 1 include a path to ground
	OPTIONS(3) type of in-line fault code (used when OPTIONS(1) is 3) (1 by default)
	OPTIONS(3) = 1 line-to-ground fault
	OPTIONS(3) = 2 line-to-line-to-ground fault
	OPTIONS(3) = 3 three phase fault
	OPTIONS(4) open end code (used when OPTIONS(1) is 4) (1 by default)
	OPTIONS(4) = 0 breaker at bus JBUS is open
	OPTIONS(4) = 1 breaker at bus IBUS is open

	OPTIONS(5)	dc line and FACTS device option (0 by default)
	OPTIONS(5) = 0	block and ignore
	OPTIONS(5) = 1	convert to constant admittance load
	OPTIONS(6)	transformer impedance correction option (1 by default)
	OPTIONS(6) = 0	do not apply to zero sequence
	OPTIONS(6) = 1	apply to zero sequence
	OPTIONS(7)	fault analysis generator reactance option (0 by default)
	OPTIONS(7) = 0	use subtransient reactance
	OPTIONS(7) = 1	use transient reactance
	OPTIONS(7) = 2	use synchronous reactance
Real VALUES (5)	array of 5 elements specifying unbalance parameters(input).	
	VALUES(1)	fault location as fraction of line from bus IBUS; $0.0 < \text{VALUES}(1) < 1.0$ (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3) (0.5 by default)
	VALUES(2)	RI-g (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3 and OPTIONS(3) is 1 or 2) (0.0 by default)
	VALUES(3)	XI-g (used when OPTIONS(1) is 1 or 4 and OPTIONS(2) is 1; or when OPTIONS(1) is 3 and OPTIONS(3) is 1 or 2) (0.0 by default)
	VALUES(4)	RI-I used when OPTIONS(1) is 3 and OPTIONS(3) is 2) (0.0 by default)
	VALUES(5)	XI-I (used when OPTIONS(1) is 3 and OPTIONS(3) is 2) (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	STRT or MSTR has not been successfully executed
	IERR = 2	bus not found
	IERR = 3	branch not found
	IERR = 4	branch is out-of-service
	IERR = 5	error encountered in executing SPCBAPI
	IERR = 6	prerequisite requirements for API are not met

Chapter 8

Subsystem Definition

This chapter defines API routines that control subsystems. There are four kinds of subsystems in PSS®E: area subsystems, bus subsystems, owner subsystems, and zone subsystems. Area subsystems are a set of areas, bus subsystems are a set of buses, etc.

Many PSS®E API routines accept a subsystem definition to limit the scope of operation of the routine. Most such use bus subsystems. Bus subsystems can be defined in terms of areas, zones, and/or owners; but a bus subsystem defined by areas, for example, is not an area subsystem, which is a set of areas, not a set of buses in an area.

8.1. Area Subsystems

8.1.1. ASYS

Use this API to define an area subsystem.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_ASYS  SID  NUM  AREAS(1) .. AREAS(NUM)
```

Python command syntax:

```
ierr = asys(sid, num, areas)
```

Fortran command syntax:

```
CALL SBSASET(SID, NUM, AREAS, IERR)
```

Where:

Integer SID	valid area subsystem ID. Valid area subsystem IDs range from 0 to 11 (input).	
Integer NUM	number of areas to set (input).	
Integer AREAS (NUM)	array that contains the areas to set (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	SID is not defined

8.1.2. ASYSDEF

Use this API to set the definition of an area subsystem. This can be used to toggle a particular area subsystem on or off.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ASYSDEF  SID  DEFINED
```

Python command syntax:

```
ierr = asysdef(sid, defined)
```

Fortran command syntax:

```
CALL SBSASETDEF(SID, DEFINED, IERR)
```

Where:

Integer SID	valid area subsystem ID. Valid area subsystem IDs range from 0 to 11 (input).	
Integer DEFINED	flag used to mark the area subsystem as undefined/defined (input).	
	DEFINED = 0	mark the area subsystem as undefined
	DEFINED = 1	mark the area subsystem as defined
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.1.3. ASYSINIT

Use this API to initialize or re-initialize an area subsystem.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ASYSINIT SID
```

Python command syntax:

```
asysinit(sid)
```

Fortran command syntax:

```
CALL SBSACREATE(SID, IERR)
```

Where:

Integer SID	valid area subsystem ID. Valid area subsystem IDs range from 0 to 11 (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.2. Bus Subsystems

8.2.1. BSYS

Use this API to define a bus subsystem. The criteria used to define the bus subsystem are evaluated using an AND criteria. That is to say, if a bus kV range, Areas and Zones are specified, to be in the bus subsystem a bus must be in the specified kV range AND must be in one of the Areas defined AND must be in one of the Zones defined. Failure to meet ANY of the specified criteria will remove the bus from the bus subsystem.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_BSYS  SID  USEKV BASEKV(1)  BASEKV(2) NUMAREA
          AREAS(1)..AREAS(NUMAREA)  NUMBUS  BUSES(1)..BUSES(NUMBUS) NUMOWNER
          OWNERS(1)..OWNERS(NUMOWNER)  NUMZONE  ZONES(1)..ZONES(NUMZONE)
```

Python command syntax:

```
ierr = bsys(sid, usekv, basekv, numarea, areas, numbus, buses, numowner,
            owners, numzone, zones)
```

Fortran command syntax:

```
CALL SBSBSET_A (SID, USEKV, BASEKV, NUMAREA, AREAS, NUMBUS, BUSES_C,
               NUMOWNER, OWNERS, NUMZONE, ZONES, IERR)

CALL SBSBSET_N (SID, USEKV, BASEKV, NUMAREA, AREAS, NUMBUS, BUSES_I,
               NUMOWNER, OWNERS, NUMZONE, ZONES, IERR)
```

Where:

Integer SID	valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).
Integer USEKV	flag to determine whether to use BASEKV values in setting the subsystem (input). USEKV = 0 don't use BASEKV values USEKV = 1 use BASEKV values
Real BASEKV (2)	array of 2 elements specifying (input). BASEKV(1) minimum basekV limit BASEKV(2) maximum basekV limit
Integer NUMAREA	number of areas to set (input).
Integer AREAS (NUMAREA)	array that contains the areas to set (input).
Integer NUMBUS	number of buses to set (input).
Integer or Character*18 BUSES (NUMBUS)	A union type array describing the network element's BUS value. BUSES_I refers to Integer, BUSES_C refers to Character value in the Fortran syntax. (input).
Integer NUMOWNER	number of owners to set (input).

Integer OWNERS (NUMOWNER)	array that contains the owners to set (input).	
Integer NUMZONE	number of zones to set (input).	
Integer ZONES (NUMZONE)	array that contains the zones to set (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	SID is not defined

8.2.2. BSYSADD

Use this API to add elements to an existing bus subsystem.

The criteria used to define a bus subsystem are evaluated using an AND criteria. That is to say, if a bus kV range, Areas and Zones are specified, to be in the bus subsystem a bus must be in the specified kV range AND must be in one of the Areas defined AND must be in one of the Zones defined. Failure to meet ANY of the specified criteria will remove the bus from the bus subsystem.

Adding to an existing bus subsystem with this API adds additional AND criteria, not OR criteria, to be used in the evaluation.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_BSYSADD  SID  USEKV  BASEKV(1)  BASEKV(2)  NUMAREA
              AREAS(1) .. AREAS(NUMAREA)  NUMBUS  BUSES(1) .. BUSES(NUMBUS)  NUMOWNER
              OWNERS(1) .. OWNERS(NUMOWNER)  NUMZONE  ZONES(1) .. ZONES(NUMZONE)
```

Python command syntax:

```
ierr = bsysadd(sid, usekv, basekv, numarea, areas, numbus, buses,
               numowner, owners, numzone, zones)
```

Fortran command syntax:

```
CALL SBSBADD(SID, USEKV, BASEKV, NUMAREA, AREAS, NUMBUS, BUSES, NUMOWNER,
             OWNERS, NUMZONE, ZONES, IERR)
```

Where:

Integer SID	valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).
Integer USEKV	flag to determine whether to use BASEKV values in setting the subsystem (input). USEKV = 0 don't use BASEKV values USEKV = 1 use BASEKV values
Real BASEKV (2)	array of 2 elements specifying (input). BASEKV(1) minimum basekV limit BASEKV(2) maximum basekV limit
Integer NUMAREA	number of areas to set (input).
Integer AREAS (NUMAREA)	array that contains the areas to set (input).
Integer NUMBUS	number of buses to set (input).
Integer BUSES (NUMBUS)	array that contains the buses to set (input).
Integer NUMOWNER	number of owners to set (input).
Integer OWNERS (NUMOWNER)	array that contains the owners to set (input).
Integer NUMZONE	number of zones to set (input).
Integer ZONES (NUMZONE)	array that contains the zones to set (input).
Integer IERR	error code (output).

IERR = 0	no error occurred
IERR = 1	SID is not valid

8.2.3. BSYSDEF

Use this API to set the definition of a bus subsystem. This can be used to toggle a particular bus subsystem on or off.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_BSYSDEF  SID  DEFINED
```

Python command syntax:

```
ierr = bsysdef(sid, defined)
```

Fortran command syntax:

```
CALL SBSBSETDEF(SID, DEFINED, IERR)
```

Where:

Integer SID	valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).	
Integer DEFINED	flag used to mark the bus subsystem as undefined/defined (input).	
	DEFINED = 0	mark the bus subsystem as undefined
	DEFINED = 1	mark the bus subsystem as defined
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.2.4. BSYSDELO

Use this API to delete a single bus from a bus subsystem.

This API routine was first introduced in release 33.4.0.

Batch command syntax:

```
BAT_BSYSDELO  SID  BUSNUM
```

Python command syntax:

```
ierr = bsysdelo(sid, busnum)
```

Fortran command syntax:

```
CALL SBSBDELO(SID, BUSNUM, IERR)
```

Where:

Integer SID	valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).	
Integer BUSNUM	bus number to delete from the subsystem (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	bus subsystem is not defined
	IERR = 3	no buses defined in subsystem
	IERR = 4	BUSNUM doesn't exist in subsystem

8.2.5. BSYSINIT

Use this API to initialize or re-initialize a bus subsystem.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_BSYSINIT SID
```

Python command syntax:

```
bsysinit(sid)
```

Fortran command syntax:

```
CALL SBSBCREATE(SID, IERR)
```

Where:

Integer SID	valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.2.6. BSYSMEM

Use this API to replicate the specified bus subsystem in a bus subsystem file. This bus subsystem file may then be recalled at a later time to restore the specified bus subsystem.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BSYSMEM  SID  SFILE
```

Python command syntax:

```
ierr = bsysmem(sid, sfile)
```

Fortran command syntax:

```
CALL SBSBSMEM(SID, SFILE, IERR)
```

Where:

Integer SID	a valid bus subsystem id. Valid bus subsystem ids range from 0 to 11 (input).	
Character*260 SFILE	bus subsystem filename (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	error opening SFILE

8.2.7. BSYSO

Use this API to build a bus subsystem one bus at a time.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_BSYSO  SID  BUSNUM
```

Python command syntax:

```
ierr = bsyso(sid, busnum)
```

Fortran command syntax:

```
CALL SBSBSET0(SID, BUSNUM, IERR)
```

Where:

Integer SID	valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).	
Integer BUSNUM	bus number to add to subsystem (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	Bus subsystem contains other elements, not just buses

8.2.8. BSYSRCL

Use this API to recall a specified bus subsystem saved in a bus subsystem file.

This API routine was first introduced in release 28.0.0.

Batch command syntax:

```
BAT_BSYSRCL  SID  SFILE
```

Python command syntax:

```
ierr = bsysrcl(sid, sfile)
```

Fortran command syntax:

```
CALL SBSBSRCL(SID, SFILE, IERR)
```

Where:

Integer SID	a valid bus subsystem id. Valid bus subsystem ids range from 0 to 11 (input).	
Character*260 SFILE	bus subsystem filename (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	error opening SFILE
	IERR = 3	not a valid bus subsystem file
	IERR = 4	items in bus subsystem file not found in working case

8.3. Owner Subsystems

8.3.1. OSYS

Use this API to define an owner subsystem.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OSYS  SID  NUM  OWNERS(1) .. OWNERS(NUM)
```

Python command syntax:

```
ierr = osys(sid, num, owners)
```

Fortran command syntax:

```
CALL SBSOSET(SID, NUM, OWNERS, IERR)
```

Where:

Integer SID	valid owner subsystem ID. Valid owner subsystem IDs range from 0 to 11 (input).	
Integer NUM	number of owners to set (input).	
Integer OWNERS (NUM)	array that contains the owners to set (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	SID is not defined

8.3.2. OSYSDEF

Use this API to set the definition of an owner subsystem. This can be used to toggle a particular owner subsystem on or off.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_OSYSDEF  SID  DEFINED
```

Python command syntax:

```
ierr = osysdef(sid, defined)
```

Fortran command syntax:

```
CALL SBSOSETDEF(SID, DEFINED, IERR)
```

Where:

Integer SID	a valid owner subsystem ID. Valid owner subsystem IDs range from 0 to 11 (input).	
Integer DEFINED	flag to mark the owner subsystem as undefined/defined (input).	
	DEFINED = 0	mark the owner subsystem as undefined
	DEFINED = 1	mark the owner subsystem as defined
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.3.3. OSYSINIT

Use this API to initialize or re-initialize an owner subsystem.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_OSYSINIT SID
```

Python command syntax:

```
osysinit(sid)
```

Fortran command syntax:

```
CALL SBSOCREATE(SID, IERR)
```

Where:

Integer SID	a valid owner subsystem ID. Valid owner subsystem IDs range from 0 to 11 (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.4. Zone Subsystems

8.4.1. ZSYS

Use this API to define a zone subsystem.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_ZSYS  SID  NUM  ZONES(1) .. ZONES(NUM)
```

Python command syntax:

```
ierr = zsys(sid, num, zones)
```

Fortran command syntax:

```
CALL SBSZSET(SID, NUM, ZONES, IERR)
```

Where:

Integer SID	valid zone subsystem ID. Valid zone subsystem IDs range from 0 to 11 (input).	
Integer NUM	number of zones to set (input).	
Integer ZONES (NUM)	array that contains the zones to set (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid
	IERR = 2	SID is not defined

8.4.2. ZSYSDEF

Use this API to set the definition of an zone subsystem. This can be used to toggle a particular zone subsystem on or off.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ZSYSDEF  SID  DEFINED
```

Python command syntax:

```
ierr = zsysdef(sid, defined)
```

Fortran command syntax:

```
CALL SBSZSETDEF(SID, DEFINED, IERR)
```

Where:

Integer SID	a valid zone subsystem ID. Valid zone subsystem IDs range from 0 to 11 (input).	
Integer DEFINED	flag to mark the zone subsystem as undefined/defined (input).	
	DEFINED = 0	mark the zone subsystem as undefined
	DEFINED = 1	mark the zone subsystem as defined
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

8.4.3. ZSYSINIT

Use this API to initialize or re-initialize a zone subsystem.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ZSYSINIT SID
```

Python command syntax:

```
zsysinit(sid)
```

Fortran command syntax:

```
CALL SBSZCREATE(SID, IERR)
```

Where:

Integer SID	a valid zone subsystem ID. Valid zone subsystem IDs range from 0 to 11 (input).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	SID is not valid

Chapter 9

Diagram View

This chapter defines API routines that are used to manipulate Slider Diagrams in the interface. They will elicit no action if a GUI is not present when invoked.

9.1. CHANGEDIAGCONTOUR

Use this API to change the contour parameters for the contour in the active Slider diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_CHANGEDIAGCONTOUR ELEMENT QUANTITY METHOD COLOR ENABLE RES INFLUENCE
BOUND MAX MIN
```

Python command syntax:

```
changeddiagcontour(element, quantity, method, color, enable, res,
influence, bound, max, min)
```

Fortran command syntax:

```
CALL CHANGEDIAGCONTOUR(ELEMENT, QUANTITY, METHOD, COLOR, ENABLE, RES,
INFLUENCE, BOUND, MAX, MIN)
```

Where:

Integer ELEMENT	item to be contoured e.g. Buses, branches, machines (input). ELEMENT = 1 bus ELEMENT = 2 branch ELEMENT = 3 machine
Integer QUANTITY	element quantity to generate the contour on (input).
Integer METHOD	algorithm used to generate the contour (input). METHOD = 1 linear method METHOD = 2 linear approximation method METHOD = 3 quad tree method
Integer COLOR	color gradient to use for the contour (input). COLOR = 0 red scale COLOR = 1 green scale COLOR = 2 blue scale COLOR = 3 gray scale COLOR = 4 blue/low to red/high COLOR = 5 red/low to blue/high
Integer ENABLE	"switch" used to toggle the contour on/off (input). ENABLE = 0 off ENABLE = 1 on
Real RES	resolution of the contour (10 to 2000). A higher resolution will result in greater computation times. (input).
Real INFLUENCE	influence range (1 to 100). A larger range will result in greater blending. (input).

Real BOUND	value that controls how far beyond the outermost ELEMENTs on the diagram the contour extends (input).
Real MAX	maximum "quantity" value associated with the "high" color (input).
Real MIN	minimum "quantity" value associated with the "low" color (input).

9.2. CHECKDIAGFILE

Use this API to check the active Slider Diagram in the GUI against the current network case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_CHECKDIAGFILE
```

Python command syntax:

```
checkdiagfile()
```

Fortran command syntax:

```
CALL CHECKDIAGFILE
```

9.3. CLOSEDIAGFILE

Use this API to close the active Slider Diagram in the GUI without prompting to save the Diagram.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_CLOSEDIAGFILE
```

Python command syntax:

```
closeddiagfile()
```

Fortran command syntax:

```
CALL CLOSEDIAGFILE
```

9.4. DELETEDIAGCONTOUR

Use this API to delete the contour from the active Slider Diagram in the GUI.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_DELETEDIAGCONTOUR
```

Python command syntax:

```
deletediagcontour()
```

Fortran command syntax:

```
CALL DELETEDIAGCONTOUR
```

9.5. ENABLEDIAGCONTOUR

Use this API to specify the contour parameters and display a contour in the active Slider Diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_ENABLEDIAGCONTOUR ELEMENT QUANTITY METHOD COLOR ENABLE RES INFLUENCE
BOUND MAX MIN
```

Python command syntax:

```
enablediagcontour(element, quantity, method, color, enable, res,
    influence, bound, max, min)
```

Fortran command syntax:

```
CALL ENABLEDIAGCONTOUR(ELEMENT, QUANTITY, METHOD, COLOR, ENABLE, RES,
    INFLUENCE, BOUND, MAX, MIN)
```

Where:

Integer ELEMENT	item to be contoured e.g. Buses, branches, machines (input). ELEMENT = 1 Bus ELEMENT = 2 Branch ELEMENT = 3 Machine
Integer QUANTITY	element quantity to generate the contour on (input).
Integer METHOD	algorithm used to generate the contour (input). METHOD = 1 Linear method METHOD = 2 Linear approximation method METHOD = 3 Quad tree method
Integer COLOR	color gradient to use for the contour (input). COLOR = 0 Red scale COLOR = 1 Green scale COLOR = 2 Blue scale COLOR = 3 Gray scale COLOR = 4 Blue/low to Red/high COLOR = 5 Red/low to Blue/high
Integer ENABLE	"switch" used to toggle the contour on/off (input). ENABLE = 0 Off ENABLE = 1 On
Real RES	is the resolution of the contour (10 to 2000). A higher resolution will result in greater computation times. (input).
Real INFLUENCE	influence range (1 to 100). A larger range will result in greater blending. (input).

Real BOUND	a value that controls how far beyond the outermost ELEMENTs on the diagram the contour extends (input).
Real MAX	maximum "quantity" value associated with the "high" color (input).
Real MIN	minimum "quantity" value associated with the "low" color (input).

9.6. EXPORTBUSLOCFILE

This API routine is obsolete. It has been replaced by the API routine [exportbuslocfile_2](#).

Use this API to export the bus location from the active Slider Diagram in the GUI to a file.

This API routine was first introduced in release 30.2.0.

Batch command syntax:

```
BAT_EXPORTBUSLOCFILE  BUSLOCFILE
```

Python command syntax:

```
exportbuslocfile(buslocfile)
```

Fortran command syntax:

```
CALL EXPORTBUSLOCFILE(BUSLOCFILE)
```

Where:

Character*260 BUSLOCFILE name of the Bus Location Data File to be written (input).

9.7. EXPORTBUSLOCFILE_2

Use this API to export the bus location from the active Slider Diagram in the GUI to a file.

This API routine was first introduced in release 34.8.0 and 35.1.0.

Batch command syntax:

```
BAT_EXPORTBUSLOCFILE_2  BUSLOCFILE  EXPORTGEO
```

Python command syntax:

```
exportbuslocfile_2(buslocfile, exportgeo)
```

Fortran command syntax:

```
CALL EXPORTBUSLOCFILE_2(BUSLOCFILE, EXPORTGEO)
```

Where:

Character*260 BUSLOCFILE	name of the Bus Location Data File to be written (input).	
Integer EXPORTGEO	export geophysical coordinates or Cartesian coordinates (input; 1 by default).	
	ExportGeo = 1	export in geophysical coordinates
	ExportGeo = 0	export in Cartesian coordinates

9.8. EXPORTIMAGEFILE

This API routine is obsolete. It has been replaced by the API routine [exportimagefile_2](#).

Use this API to export an image of the active Slider Diagram in the GUI to a file.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_EXPORTIMAGEFILE TYPE IMAGEFILE QUALITY
```

Python command syntax:

```
exportimagefile(type, imagefile, quality)
```

Fortran command syntax:

```
CALL EXPORTIMAGEFILE(TYPE, IMAGEFILE, QUALITY)
```

Where:

Integer TYPE	type of image to export (input).
	Type = 1 Bitmap
	Type = 2 JPEG
	Type = 3 PNG
	Type = 4 GIF
	Type = 5 TIF
Character*260 IMAGEFILE	name of the image file to be written (input).
Integer QUALITY	a value, between 1 and 100, used to control the quality of the exported image if TYPE = 2 (input).

9.9. EXPORTIMAGEFILE_2

Use this API to export an image of the active Slider Diagram in the GUI to a file.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_EXPORTIMAGEFILE_2 TYPE IMAGEFILE QUALITY WIDTH HEIGHT SCALE X Y
```

Python command syntax:

```
exportimagefile_2(type, imagefile, quality, width, height, scale, x, y)
```

Fortran command syntax:

```
CALL EXPORTIMAGEFILE_2(TYPE, IMAGEFILE, QUALITY, WIDTH, HEIGHT, SCALE, X,  
Y)
```

Where:

Integer TYPE	type of image to export (input). Type = 1 Bitmap Type = 2 JPEG Type = 3 PNG Type = 4 GIF Type = 5 TIF
Character*260 IMAGEFILE	name of the image file to be written (input).
Integer QUALITY	a value, between 1 and 100, used to control the quality of the exported image if TYPE = 2 (input).
Integer WIDTH	width of the image to capture in pixels (input).
Integer HEIGHT	height of the image to capture in pixels (input).
real SCALE	scale at which to capture the image. (input).
real X	x location on the diagram that will be the center of the image (input).
real Y	y location on the diagram that will be the center of the image (input).

9.10. GEXMBUS

Use this API to create a GEXM/GOUT display of a bus in an active Slider diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_GEXMBUS  BUS
```

Python command syntax:

```
gexmbus( bus )
```

Fortran command syntax:

```
CALL GEXMBUS( BUS )
```

Where:

Integer BUS	bus number of the bus for which to create the GEXM display (input).
-------------	---

9.11. GROWBUS

Use this API to GROW a bus in an active Slider diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 30.1.0.

Batch command syntax:

```
BAT_GROWBUS  BUSNUMBER XPOSITION YPOSITION
```

Python command syntax:

```
growbus(busnumber, xposition, yposition)
```

Fortran command syntax:

```
CALL GROWBUS(BUSNUMBER, XPOSITION, YPOSITION)
```

Where:

Integer BUSNUMBER	bus number of the bus to GROW (no default) (input).
Real XPOSITION	X coordinate of the bus on the Slider diagram (input).
Real YPOSITION	Y coordinate of the bus on the Slider diagram (input).

9.12. GROWBUSLEVELS

Use this API to GROW a bus and all the connected buses up to the specified number of levels away in an active Slider diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_GROWBUSLEVELS  BUSNUMBER XPOSITION YPOSITION NUMLEVELS
```

Python command syntax:

```
growbuslevels(busnumber, xposition, yposition, numlevels)
```

Fortran command syntax:

```
CALL GROWBUSLEVELS(BUSNUMBER, XPOSITION, YPOSITION, NUMLEVELS)
```

Where:

Integer BUSNUMBER	bus number of the bus to GROW (no default) (input).
Real XPOSITION	X coordinate of the bus on the Slider diagram (input).
Real YPOSITION	Y coordinate of the bus on the Slider diagram (input).
Integer NUMLEVELS	number of levels; include all buses up to this number of connections from BUSNUMBER in the GROW operation (no default) (input).

9.13. GROWDIAGRAM

This API routine is obsolete. It has been replaced by the API routine [growdiagram_2](#).

Use this API to GROW a bus and all the connected buses in an active Slider diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_GROWDIAGRAM  NUMLEVELS  ITEMCOUNT  ITEMLIST  XPOSITION  YPOSITION
```

Python command syntax:

```
growdiagram(numlevels, itemcount, itemlist, xposition, yposition)
```

Fortran command syntax:

```
CALL GROWDIAGRAM(NUMLEVELS, ITEMCOUNT, ITEMLIST, XPOSITION, YPOSITION)
```

Where:

Integer NUMLEVELS	number of levels; include all buses up to this number of connections from each item in ITEMLIST in the GROW operation. A value of -1 can be used to grow all buses (subsystem and in-service options still apply), however attempting to lay out several hundred buses or more will take a very large amount of time to complete as PSSE attempts to calculate best positions for each bus. It is still recommended that the user only grow several levels at once (input).
Integer ITEMCOUNT	number of items in ITEMLIST. ITEMCOUNT can be 0 if NUMLEVELS is -1. Under this condition diagram growth will start at an arbitrary bus (input; 0 by default).
Character*40 ITEMLIST (ITEM-COUNT)	list of items to grow. Each item is given by its generated map string (input).
Real XPOSITION	X coordinate of the first bus on the Slider diagram (input).
Real YPOSITION	X coordinate of the first bus on the Slider diagram (input).

9.14. GROWDIAGRAM_2

Use this API to GROW a bus and all the connected buses in an active Slider diagram in the GUI. Requires a current network case.

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_GROWDIAGRAM_2  NUMLEVELS  ITEMCOUNT  ITEMLIST  XPOSITION  YPOSITION
EXCLUDELIST
```

Python command syntax:

```
growdiagram_2(numlevels, itemcount, itemlist, xposition, yposition,
excludelist)
```

Fortran command syntax:

```
CALL GROWDIAGRAM_2(NUMLEVELS, ITEMCOUNT, ITEMLIST, XPOSITION, YPOSITION,
EXCLUDELIST)
```

Where:

Integer NUMLEVELS	number of levels; include all buses up to this number of connections from each item in ITEMLIST in the GROW operation. A value of -1 can be used to grow all buses (subsystem and in-service options still apply), however attempting to lay out several hundred buses or more will take a very large amount of time to complete as PSSE attempts to calculate best positions for each bus. It is still recommended that the user only grow several levels at once (input).
Integer ITEMCOUNT	number of items in ITEMLIST. ITEMCOUNT can be 0 if NUMLEVELS is -1. Under this condition diagram growth will start at an arbitrary bus (input; 0 by default).
Character*40 ITEMLIST (ITEMCOUNT)	list of items to grow. Each item is given by its generated map string (input).
Real XPOSITION	X coordinate of the first bus on the Slider diagram (input).
Real YPOSITION	X coordinate of the first bus on the Slider diagram (input).
integer EXCLUDELIST (13)	array of 13 elements specifying list of element types to exclude from the grow operation(input). EXCLUDELIST(1) Exclude machines (0 by default) EXCLUDELIST(1) = 0 disabled EXCLUDELIST(1) = 1 enabled EXCLUDELIST(2) Exclude loads (0 by default) EXCLUDELIST(2) = 0 disabled EXCLUDELIST(2) = 1 enabled EXCLUDELIST(3) Exclude fixed shunts (0 by default) EXCLUDELIST(3) = 0 disabled EXCLUDELIST(3) = 1 enabled

EXCLUDELIST(4)	Exclude switched shunts (0 by default)
EXCLUDELIST(4) = 0	disabled
EXCLUDELIST(4) = 1	enabled
EXCLUDELIST(5)	Exclude induction machines (0 by default)
EXCLUDELIST(5) = 0	disabled
EXCLUDELIST(5) = 1	enabled
EXCLUDELIST(6)	Exclude AC branches (0 by default)
EXCLUDELIST(6) = 0	disabled
EXCLUDELIST(6) = 1	enabled
EXCLUDELIST(7)	Exclude 2 winding transformers (0 by default)
EXCLUDELIST(7) = 0	disabled
EXCLUDELIST(7) = 1	enabled
EXCLUDELIST(8)	Exclude 3 winding transformers (0 by default)
EXCLUDELIST(8) = 0	disabled
EXCLUDELIST(8) = 1	enabled
EXCLUDELIST(9)	Exclude system switching devices (0 by default)
EXCLUDELIST(9) = 0	disabled
EXCLUDELIST(9) = 1	enabled
EXCLUDELIST(10)	Exclude DC lines (0 by default)
EXCLUDELIST(10) = 0	disabled
EXCLUDELIST(10) = 1	enabled
EXCLUDELIST(11)	Exclude VSC DC lines (0 by default)
EXCLUDELIST(11) = 0	disabled
EXCLUDELIST(11) = 1	enabled
EXCLUDELIST(12)	Exclude N-term DC lines (0 by default)
EXCLUDELIST(12) = 0	disabled
EXCLUDELIST(12) = 1	enabled
EXCLUDELIST(13)	Exclude FACTS devices (0 by default)
EXCLUDELIST(13) = 0	disabled
EXCLUDELIST(13) = 1	enabled

9.15. GROWSTATION

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_GROWSTATION STATIONNUM
```

Python command syntax:

```
growstation(stationnum)
```

Fortran command syntax:

```
CALL GROWSTATION(STATIONNUM)
```

Where:

Integer STATIONNUM substation number (input).

9.16. GRPG

Use this API to produce a GRPG report in the active Slider diagram in the GUI.

This API routine was first introduced in release 30.3.3.

Batch command syntax:

```
BAT_GRPG IMAGEFILE DUMFILE
```

Python command syntax:

```
ierr = grpg(imagefile, dumfile)
```

Fortran command syntax:

```
CALL GRPGAPI(IMAGEFILE, DUMFILE, IERR)
```

Where:

Character*260 IMAGEFILE	name of the GRPG file to be used (input).
Character*260 DUMFILE	dummy filename; this should be initialized to " " (input).
Integer IERR	error code (output).

9.17. IMPORTDRAWFILE

Use this API to import a Draw Data File into an active Slider diagram in the GUI.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_IMPORTDRAWFILE  DRAWFILE
```

Python command syntax:

```
importdrawfile(drawfile)
```

Fortran command syntax:

```
CALL IMPORTDRAWFILE(DRAWFILE)
```

Where:

Character*260 DRAWFILE name of an existing Draw Data File, .drw (input).

9.18. IMPORTIMAGEFILE

Use this API to import an image into the background layer of the active Slider diagram in the GUI.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_IMPORTIMAGEFILE IMAGEFILE
```

Python command syntax:

```
importimagefile(imagefile)
```

Fortran command syntax:

```
CALL IMPORTIMAGEFILE(IMAGEFILE)
```

Where:

Character*260 IMAGEFILE	name of the image file to be imported (input).
-------------------------	--

9.19. NEWDIAGFILE

Use this API to open a new Slider diagram in the GUI.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_NEWDIAGFILE
```

Python command syntax:

```
newdiagfile()
```

Fortran command syntax:

```
CALL NEWDIAGFILE
```

9.20. NEXTDIAGFILEDATASET

This API is used to display the next element in the active data set on the active Slider diagram. Currently, this API is only used with ACCC results.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_NEXTDIAGFILEDATASET
```

Python command syntax:

```
nextdiagfileset()
```

Fortran command syntax:

```
CALL NEXTDIAGFILEDATASET
```

9.21. OPENACCFILE

This API routine is obsolete. It has been replaced by the API routine [openaccfile_2](#).

This API is used to open an existing ACC results file for displaying results on diagram.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_OPENACCFILE  NBASERATE  NCNTGRATE  FPERRATE  SZFILENAME
```

Python command syntax:

```
openaccfile(nbaserate, ncntgrate, fperrate, szfilename)
```

Fortran command syntax:

```
CALL OPENACCFILE(NBASERATE, NCNTGRATE, FPERRATE, SZFILENAME)
```

Where:

Integer NBASERATE	base case rating to use for results display (input).
	nBaseRate = 1 RateA
	nBaseRate = 2 RateB
	nBaseRate = 3 RateC
Integer NCNTGRATE	contingency case rating to use for results display (input).
	nCntgRate = 1 RateA
	nCntgRate = 2 RateB
	nCntgRate = 3 RateC
Real FPERRATE	loading percentage to use for results display (input).
Character*260 SZFILENAME	ACC file to open (input).

9.22. OPENACCFILE_2

This API is used to open an existing ACC results file for displaying results on diagram.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_OPENACCFILE_2 NBASERATE NCNTGRATE NBASEVOLTLM NCNTGVOLTLM FPERRATE
SZFILENAME
```

Python command syntax:

```
openaccfile_2(nbaserate, ncntgrate, nbasevoltlim, ncntgvoltlim, fperrate,
szfilename)
```

Fortran command syntax:

```
CALL OPENACCFILE_2(NBASERATE, NCNTGRATE, NBASEVOLTLM, NCNTGVOLTLM,
FPERRATE, SZFILENAME)
```

Where:

Integer NBASERATE	base case rating to use for results display (input).
	nBaseRate = 1 RateA
	nBaseRate = 2 RateB
	nBaseRate = 3 RateC
Integer NCNTGRATE	contingency case rating to use for results display (input).
	nCntgRate = 1 RateA
	nCntgRate = 2 RateB
	nCntgRate = 3 RateC
Integer NBASEVOLTLM	base case voltage limit for results display (input).
	nBaseVoltLim = 1 Don't use the limit
	nBaseVoltLim = 2 Use the limit
Integer NCNTGVOLTLM	contingency case voltage limit for results display (input).
	nCntgVoltLim = 1 don't use the limit
	nCntgVoltLim = 2 use the limit
Real FPERRATE	loading percentage to use for results display (input).
Character*260 SZFILENAME	ACC file to open (input).

9.23. OPENBUSLOCFILE

Use this API to open an existing bus location file in the GUI. The bus location file can be used to control the placement of buses on a diagram during auto-draw and grow operations

This API routine was first introduced in release 30.0.1.

Batch command syntax:

```
BAT_OPENBUSLOCFILE  BUSLOCFILE
```

Python command syntax:

```
openbuslocfile(buslocfile)
```

Fortran command syntax:

```
CALL OPENBUSLOCFILE(BUSLOCFILE)
```

Where:

Character*260 BUSLOCFILE name of existing Bus Location Data File (input).

9.24. OPENDIAGFILE

Use this API to open an existing Slider diagram in the GUI.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_OPENDIAGFILE SFILE
```

Python command syntax:

```
opendiagfile(sfile)
```

Fortran command syntax:

```
CALL OPENDIAGFILE(SFILE)
```

Where:

Character*260 SFILE	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	error opening the diagram file

9.25. PREVDIAGFILEDATASET

This API is used to display the previous element in the active data set on the active Slider diagram. Currently, this API is only used with ACCC results.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_PREVDIAGFILEDATASET
```

Python command syntax:

```
prevdiagfiledataset()
```

Fortran command syntax:

```
CALL PREVDIAGFILEDATASET
```

9.26. PRINTDIAGFILE

This API routine is obsolete. It has been replaced by the API routine [printdiagfile_2](#).

Use this API to print the active Slider diagram in the GUI.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PRINTDIAGFILE SDEV COPIES ORIENT
```

Python command syntax:

```
printdiagfile(sdev, copies, orient)
```

Fortran command syntax:

```
CALL PRINTDIAGFILE(SDEV, COPIES, ORIENT)
```

Where:

Character*260 SDEV	name of valid attached Windows printer (input).
Integer COPIES	number of copies to print (input).
Integer ORIENT	orientation (input).
	orient = 1 Portrait
	orient = 2 Landscape

9.27. PRINTDIAGFILE_2

Use this API to print the active Slider diagram in the GUI.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_PRINTDIAGFILE_2  PAGESETUP VIEWSETUP SDEV FILENAME
```

Python command syntax:

```
printdiagfile_2(pagesetup, viewsetup, sdev, filename)
```

Fortran command syntax:

```
CALL PRINTDIAGFILE_2(PAGESETUP, VIEWSETUP, SDEV, FILENAME)
```

Where:

Integer PAGESETUP (2)	array of 2 elements specifying print options(input).
PAGESETUP(1)	number of copies to print (alias is copies) (1 by default)
PAGESETUP(2)	orientation (alias is orient) (1 by default)
PAGESETUP(2) = 1	Portrait
PAGESETUP(2) = 2	Landscape
Real VIEWSETUP (5)	array of 5 elements specifying view setup options(input).
VIEWSETUP(1)	left extent of view to print (alias is xmin)
VIEWSETUP(2)	bottom extent of view to print (alias is ymin)
VIEWSETUP(3)	right extent of view to print (alias is xmax)
VIEWSETUP(4)	top extent of view to print (alias is ymax)
VIEWSETUP(5)	scale to print view at, 0.0 to fit view extents to a single page (alias is scale) (0.0 by default)
Character*260 SDEV	name of valid attached Windows printer (input).
character*260 FILENAME	name of a file to save the print to, if printing to a file (input).

9.28. REFRESHDIAGCONTOUR

Use this API to refresh the contour in the active Slider diagram in the GUI. Requires a current network case. This API would be used in an automation file to force a contour refresh that wouldn't normally take place until the automation file completed.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_REFRESHDIAGCONTOUR
```

Python command syntax:

```
refreshdiagcontour()
```

Fortran command syntax:

```
CALL REFRESHDIAGCONTOUR
```

9.29. REFRESHDIAGFILE

Use this API to refresh the results and styles in the active Slider diagram in the GUI. It requires a current network case. This API would be used in an automation file to force a results refresh that wouldn't normally take place until the automation file completed.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_REFRESHDIAGFILE
```

Python command syntax:

```
refreshdiagfile()
```

Fortran command syntax:

```
CALL REFRESHDIAGFILE
```


9.30. RENUMDIAGFILE

Use this API to renumber buses in the active Slider diagram in the GUI.

This API routine was first introduced in release 30.2.1.

Batch command syntax:

```
BAT_RENUMDIAGFILE  TRNFILE
```

Python command syntax:

```
renumdiagfile(trnfile)
```

Fortran command syntax:

```
CALL RENUMDIAGFILE(TRNFILE)
```

Where:

Character*260 TRNFILE	name of Bus Number Translation File (input).
-----------------------	--

9.31. SAVEDIAGFILE

Use this API to save the active Slider diagram in the GUI.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SAVEDIAGFILE SFILE
```

Python command syntax:

```
savediagfile(sfile)
```

Fortran command syntax:

```
CALL SAVEDIAGFILE(SFILE)
```

Where:

Character*260 SFILE name of file to save the Slider diagram in (input).

9.32. SETDIAGAUTOFILE

Use this API to specify an automation file that is run each time results are updated on the active Slider diagram.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SETDIAGAUTOFILE AUTONAME
```

Python command syntax:

```
setdiagautofile(autoname)
```

Fortran command syntax:

```
CALL SETDIAGAUTOFILE(AUTONAME)
```

Where:

Character*260 AUTONAME name of the automation file (input).

9.33. SETDIAGFONT

Use this API to specify the default text font in the active Slider diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGFONT  FNTSIZ FNTWGT FNTNAM
```

Python command syntax:

```
setdiagfont(fntsiz, fntwgt, fntnam)
```

Fortran command syntax:

```
CALL SETDIAGFONT(FNTSIZ, FNTWGT, FNTNAM)
```

Where:

Integer FNTSIZ	font point size (input).
Integer FNTWGT	font weight (input).
character*260 FNTNAM	name of the font family (input).

9.34. SETDIAGPREC

This API routine is obsolete. It has been replaced by the API routine [setdiagprec_2](#).

Use this API to specify the precision of results displayed in Slider diagrams.

This API routine was first introduced in release 30.1.0.

Batch command syntax:

```
BAT_SETDIAGPREC  DIAGPREC
```

Python command syntax:

```
setdiagprec(diagprec)
```

Fortran command syntax:

```
CALL SETDIAGPREC(DIAGPREC)
```

Where:

Integer DIAGPREC (8)	number of digits after the decimal point for various result types. Currently, only DIAGPREC(1) is used for power flow results; valid values are 1 through 4 (input).
----------------------	--

9.35. SETDIAGPREC_2

Use this API to specify the precision of results displayed in Slider Diagrams.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGPREC_2  SETSCOP  DIAGPREC(1) . .DIAGPREC(8)
```

Python command syntax:

```
setdiagprec_2(setscop, diagprec)
```

Fortran command syntax:

```
CALL SETDIAGPREC_2(SETSCOP, DIAGPREC)
```

Where:

Integer SETSCOP	scope of the API (input).
SETSCOP = 0	defaults for new diagrams
SETSCOP = 1	defaults for new diagrams and settings for the active diagram
SETSCOP = 2	settings for the active diagram
Integer DIAGPREC	number of digits after the decimal point for various result types. DIAGPREC(1) is used for power flow results, DIAGPREC(2) is used for short circuit results, DIAGPREC(3) is used for OPF results and DIAGPREC(4) is used for PU values. Valid values are 1 through 4. (input).

9.36. SETDIAGPROP

This API routine is obsolete. It has been replaced by the API routine [setdiagprop_2](#).

Use this API to specify basic properties in the active Slider diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGPROP  UNBNDCLR(1)..UNBNDCLR(3) BNDCLR(1)..BNDCLR(3)
                  BKGCLR(1)..BKGCLR(3) PRTCLR(1)..PRTCLR(3) GRDCLR(1)..GRDCLR(3)
                  UPARWCLR(1)..UPARWCLR(3) DWNARWCLR(1)..DWNARWCLR(3) LABCLR(1)..LABCLR(3)
                  GRDSTYL GRDPTRN FLTVAL(1) FLTVAL(2) DBLVAL(1)..DBLVAL(10)
                  LOGVAL(1)..LOGVAL(6) BARCHRT LABLHIDE PRNTMODE IMGDIR
```

Python command syntax:

```
setdiagprop(unbndclr, bndclr, bkgclr, prtclr, grdclr, uparwclr, dwnarwclr,
            labclr, grdstyl, grdptrn, fltval, dblval, logval, barchrt, lablhide,
            prntmode, imgdir)
```

Fortran command syntax:

```
CALL SETDIAGPROP(UNBNDCLR, BNDCLR, BKGCLR, PRTCLR, GRDCLR, UPARWCLR,
                 DWNARWCLR, LABCLR, GRDSTYL, GRDPTRN, FLTVAL, DBLVAL, LOGVAL, BARCHRT,
                 LABLHIDE, PRNTMODE, IMGDIR)
```

Where:

Integer UNBNDCLR (3)	array of 3 elements specifying unbound item color(input). UNBNDCLR(1) 0->255 Red component UNBNDCLR(2) 0->255 Blue component UNBNDCLR(3) 0->255 Green component
Integer BNDCLR (3)	array of 3 elements specifying bound item color(input). BNDCLR(1) 0->255 Red component BNDCLR(2) 0->255 Blue component BNDCLR(3) 0->255 Green component
Integer BKGCLR (3)	array of 3 elements specifying background color(input). BKGCLR(1) 0->255 Red component BKGCLR(2) 0->255 Blue component BKGCLR(3) 0->255 Green component
Integer PRTCLR (3)	array of 3 elements specifying item connection port color(input). PRTCLR(1) 0->255 Red component PRTCLR(2) 0->255 Blue component PRTCLR(3) 0->255 Green component
Integer GRDCLR (3)	array of 3 elements specifying on-diagram layout grid color(input). GRDCLR(1) 0->255 Red component GRDCLR(2) 0->255 Blue component

	GRDCLR(3)	0->255 Green component
Integer UPARWCLR (3)	array of 3 elements specifying active power animation arrow color(input).	
	UPARWCLR(1)	0->255 Red component
	UPARWCLR(2)	0->255 Blue component
	UPARWCLR(3)	0->255 Green component
Integer DWNARWCLR (3)	array of 3 elements specifying reactive power animation arrow color(input).	
	DWNARWCLR(1)	0->255 Red component
	DWNARWCLR(2)	0->255 Blue component
	DWNARWCLR(3)	0->255 Green component
Integer LABCLR (3)	array of 3 elements specifying label color(input).	
	LABCLR(1)	0->255 Red component
	LABCLR(2)	0->255 Blue component
	LABCLR(3)	0->255 Green component
Integer GRDSTYL	grid style (input).	
	GRDSTYL = 0	Dotted
	GRDSTYL = 1	Lined
Integer GRDPTRN	grid pattern (input).	
Real FLTVAL (2)	array of 2 elements specifying (input).	
	FLTVAL(1)	grid point size
	FLTVAL(2)	default line width in pixels
Real DBLVAL (10)	array of 10 elements specifying (input).	
	DBLVAL(1)	maximum zoom factor x 100, i.e. 10=1000% zoom
	DBLVAL(2)	minimum zoom factor
	DBLVAL(3)	zoom increment
	DBLVAL(4)	zoom at which to hide selection handles
	DBLVAL(5)	zoom at which to hide text
	DBLVAL(6)	zoom at which to hide grid
	DBLVAL(7)	multi-page print scaling
	DBLVAL(8)	pan distance
	DBLVAL(9)	grid spacing
	DBLVAL(10)	grid snap distance
Integer LOGVAL (6)	array of 6 elements specifying Each element has only two possible values. 0 = FALSE and 1 = TRUE. The elements are as follows(input).	
	LOGVAL(1)	no upside down text
	LOGVAL(2)	high quality printing
	LOGVAL(3)	display tooltips
	LOGVAL(4)	stipple grid
	LOGVAL(5)	hide unbound network items
	LOGVAL(6)	display filled busbars

Integer BARCHRT	Two-winding transformer bar chart display side (input).	
	BARCHRT = 0	high current loading side
	BARCHRT = 1	low current loading side
	BARCHRT = 2	both sides
Integer LABLHIDE	Label hide mode (input).	
	LABLHIDE = 0	show all labels and results
	LABLHIDE = 1	hide results
	LABLHIDE = 2	hide all labels and results
Integer PRNTMODE	Printing mode (input).	
	PRNTMODE = 0	as seen on the screen, WYSIWYG
	PRNTMODE = 1	fit the whole diagram on the page
	PRNTMODE = 2	multi-page
Character*260 IMGDIR	name of directory where image files for this diagram are stored (input).	

9.37. SETDIAGPROP_2

This API routine is obsolete. It has been replaced by the API routine [setdiagprop_3](#).

Use this API to specify basic properties in the active Slider diagram.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SETDIAGPROP_2  BKGCLR(1)..BKGCLR(3) PRTCLR(1)..PRTCLR(3)
GRDCLR(1)..GRDCLR(3) UPARWCLR(1)..UPARWCLR(3) DWNARWCLR(1)..DWNARWCLR(3)
LABCLR(1)..LABCLR(3) GRDSTYL GRDPTRN FLTVAL(1) FLTVAL(2)
DBLVAL(1)..DBLVAL(10) LOGVAL(1)..LOGVAL(6) LABLHIDE PRNTMODE IMGDIR
```

Python command syntax:

```
setdiagprop_2(bkgclr, prtclr, grdclr, uparwclr, dwnarwclr, labclr,
grdstyl, grdptrn, fltval, dblval, logval, lablhide, prntmode, imgdir)
```

Fortran command syntax:

```
CALL SETDIAGPROP_2(BKGCLR, PRTCLR, GRDCLR, UPARWCLR, DWNARWCLR, LABCLR,
GRDSTYL, GRDPTRN, FLTVAL, DBLVAL, LOGVAL, LABLHIDE, PRNTMODE, IMGDIR)
```

Where:

Integer BKGCLR (3)	array of 3 elements specifying background color(input). BKGCLR(1) 0->255 Red component BKGCLR(2) 0->255 Blue component BKGCLR(3) 0->255 Green component
Integer PRTCLR (3)	array of 3 elements specifying item connection port color(input). PRTCLR(1) 0->255 Red component PRTCLR(2) 0->255 Blue component PRTCLR(3) 0->255 Green component
Integer GRDCLR (3)	array of 3 elements specifying on-diagram layout grid color(input). GRDCLR(1) 0->255 Red component GRDCLR(2) 0->255 Blue component GRDCLR(3) 0->255 Green component
Integer UPARWCLR (3)	array of 3 elements specifying active power animation arrow color(input). UPARWCLR(1) 0->255 Red component UPARWCLR(2) 0->255 Blue component UPARWCLR(3) 0->255 Green component
Integer DWNARWCLR (3)	array of 3 elements specifying reactive power animation arrow color(input). DWNARWCLR(1) 0->255 Red component DWNARWCLR(2) 0->255 Blue component

	DWNARWCLR(3)	0->255 Green component
Integer LABCLR (3)	array of 3 elements specifying label color(input).	
	LABCLR(1)	0->255 Red component
	LABCLR(2)	0->255 Blue component
	LABCLR(3)	0->255 Green component
Integer GRDSTYL	grid style (input).	
	GRDSTYL = 0	Dotted
	GRDSTYL = 1	Lined
Integer GRDPTRN	grid pattern (input).	
Real FLTVAL (2)	array of 2 elements specifying (input).	
	FLTVAL(1)	grid point size
	FLTVAL(2)	default line width in pixels
Real DBLVAL (10)	array of 10 elements specifying (input).	
	DBLVAL(1)	maximum zoom factor x 100, i.e. 10=1000% zoom
	DBLVAL(2)	minimum zoom factor
	DBLVAL(3)	zoom increment
	DBLVAL(4)	zoom at which to hide selection handles
	DBLVAL(5)	zoom at which to hide text
	DBLVAL(6)	zoom at which to hide grid
	DBLVAL(7)	multi-page print scaling
	DBLVAL(8)	pan distance
	DBLVAL(9)	grid spacing
	DBLVAL(10)	grid snap distance
Integer LOGVAL (6)	array of 6 elements specifying Each element has only two possible values. 0 = FALSE and 1 = TRUE. The elements are as follows(input).	
	LOGVAL(1)	no upside down text
	LOGVAL(2)	high quality printing
	LOGVAL(3)	display tooltips
	LOGVAL(4)	stipple grid
	LOGVAL(5)	hide unbound network items
	LOGVAL(6)	display filled busbars
Integer LABLHIDE	Label hide mode (input).	
	LABLHIDE = 0	show all labels and results
	LABLHIDE = 1	hide results
	LABLHIDE = 2	hide all labels and results
Integer PRNTMODE	Printing mode (input).	
	PRNTMODE = 0	as seen on the screen, WYSIWYG
	PRNTMODE = 1	fit the whole diagram on the page
	PRNTMODE = 2	multi-page
Character*260 IMGDIR	name of the directory where image files for this diagram are stored (input).	

9.38. SETDIAGPROP_3

This API routine is obsolete. It has been replaced by the API routine [setdiagprop_4](#).

Use this API to specify basic properties in the active Slider diagram.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SETDIAGPROP_3  BKGCLR(1)..BKGCLR(3) PRTCLR(1)..PRTCLR(3)
GRDCLR(1)..GRDCLR(3) UPARWCLR(1)..UPARWCLR(3) DWNARWCLR(1)..DWNARWCLR(3)
LABCLR(1)..LABCLR(3) GRDSTYL GRDPTRN FLTVAL(1)..FLTVAL(2)
DBLVAL(1)..DBLVAL(10) LOGVAL(1)..LOGVAL(7) LABLHIDE PRNTMODE IMGDIR
```

Python command syntax:

```
setdiagprop_3(bkgclr, prtclr, grdclr, uparwclr, dwnarwclr, labclr,
grdstyl, grdptrn, fltval, dblval, logval, lablhide, prntmode, imgdir)
```

Fortran command syntax:

```
CALL SETDIAGPROP_3(BKGCLR, PRTCLR, GRDCLR, UPARWCLR, DWNARWCLR, LABCLR,
GRDSTYL, GRDPTRN, FLTVAL, DBLVAL, LOGVAL, LABLHIDE, PRNTMODE, IMGDIR)
```

Where:

Integer BKGCLR (3)	array of 3 elements specifying background color(input). BKGCLR(1) 0->255 Red component BKGCLR(2) 0->255 Blue component BKGCLR(3) 0->255 Green component
Integer PRTCLR (3)	array of 3 elements specifying item connection port color(input). PRTCLR(1) 0->255 Red component PRTCLR(2) 0->255 Blue component PRTCLR(3) 0->255 Green component
Integer GRDCLR (3)	array of 3 elements specifying on-diagram layout grid color(input). GRDCLR(1) 0->255 Red component GRDCLR(2) 0->255 Blue component GRDCLR(3) 0->255 Green component
Integer UPARWCLR (3)	array of 3 elements specifying active power animation arrow color(input). UPARWCLR(1) 0->255 Red component UPARWCLR(2) 0->255 Blue component UPARWCLR(3) 0->255 Green component
Integer DWNARWCLR (3)	array of 3 elements specifying reactive power animation arrow color(input). DWNARWCLR(1) 0->255 Red component DWNARWCLR(2) 0->255 Blue component DWNARWCLR(3) 0->255 Green component

Integer LABCLR (3)	array of 3 elements specifying label color(input). LABCLR(1) 0->255 Red component LABCLR(2) 0->255 Blue component LABCLR(3) 0->255 Green component
Integer GRDSTYL	grid style (input). GRDSTYL = 0 dotted GRDSTYL = 1 lined
Integer GRDPTRN	grid pattern (input).
Real FLTVAL (2)	array of 2 elements specifying (input). FLTVAL(1) grid point size FLTVAL(2) default line width in pixels
Real DBLVAL (10)	array of 10 elements specifying (input). DBLVAL(1) maximum zoom factor x 100, i.e. 10=1000% zoom DBLVAL(2) minimum zoom factor DBLVAL(3) zoom increment DBLVAL(4) zoom at which to hide selection handles DBLVAL(5) zoom at which to hide text DBLVAL(6) zoom at which to hide grid DBLVAL(7) multi-page print scaling DBLVAL(8) pan distance DBLVAL(9) grid spacing DBLVAL(10) grid snap distance
Integer LOGVAL (7)	array of 7 elements specifying Each element has only two possible values. 0 = FALSE and 1 = TRUE. The elements are as follows(input). LOGVAL(1) no upside down text LOGVAL(2) high quality printing LOGVAL(3) display tooltips LOGVAL(4) stipple grid LOGVAL(5) hide unbound network items LOGVAL(6) display filled busbars LOGVAL(7) make branch connections perpendicular to branches
Integer LABLHIDE	label hide mode (input). LABLHIDE = 0 show all labels and results LABLHIDE = 1 hide results LABLHIDE = 2 hide all labels and results
Integer PRNTMODE	printing mode (input). PRNTMODE = 0 as seen on the screen, WYSIWYG PRNTMODE = 1 fit the whole diagram on the page PRNTMODE = 2 multi-page

Character*260 IMGDIR

name of directory where image files for this diagram are stored (input).

9.39. SETDIAGPROP_4

This API routine is obsolete. It has been replaced by the API routine [setdiagprop_5](#).

Use this API to specify basic properties in the active Slider diagram.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SETDIAGPROP_4 BKGCLR(1)..BKGCLR(3) PRTCLR(1)..PRTCLR(3)
GRDCLR(1)..GRDCLR(3) UPARWCLR(1)..UPARWCLR(3) DWNARWCLR(1)..DWNARWCLR(3)
LABCLR(1)..LABCLR(3) GRDSTYL GRDPTRN FLTVAL(1)..FLTVAL(2)
DBLVAL(1)..DBLVAL(11) LOGVAL(1)..LOGVAL(7) LABLHIDE PRNTMODE IMGDIR
```

Python command syntax:

```
setdiagprop_4(bkgclr, prtclr, grdclr, uparwclr, dwnarwclr, labclr,
grdstyl, grdptrn, fltval, dblval, logval, lablhide, prntmode, imgdir)
```

Fortran command syntax:

```
CALL SETDIAGPROP_4(BKGCLR, PRTCLR, GRDCLR, UPARWCLR, DWNARWCLR, LABCLR,
GRDSTYL, GRDPTRN, FLTVAL, DBLVAL, LOGVAL, LABLHIDE, PRNTMODE, IMGDIR)
```

Where:

Integer BKGCLR (3)	array of 3 elements specifying background color(input). BKGCLR(1) 0->255 Red component BKGCLR(2) 0->255 Blue component BKGCLR(3) 0->255 Green component
Integer PRTCLR (3)	array of 3 elements specifying item connection port color(input). PRTCLR(1) 0->255 Red component PRTCLR(2) 0->255 Blue component PRTCLR(3) 0->255 Green component
Integer GRDCLR (3)	array of 3 elements specifying on-diagram layout grid color(input). GRDCLR(1) 0->255 Red component GRDCLR(2) 0->255 Blue component GRDCLR(3) 0->255 Green component
Integer UPARWCLR (3)	array of 3 elements specifying active power animation arrow color(input). UPARWCLR(1) 0->255 Red component UPARWCLR(2) 0->255 Blue component UPARWCLR(3) 0->255 Green component
Integer DWNARWCLR (3)	array of 3 elements specifying reactive power animation arrow color(input). DWNARWCLR(1) 0->255 Red component DWNARWCLR(2) 0->255 Blue component DWNARWCLR(3) 0->255 Green component

Integer LABCLR (3)	array of 3 elements specifying label color(input). LABCLR(1) 0->255 Red component LABCLR(2) 0->255 Blue component LABCLR(3) 0->255 Green component
Integer GRDSTYL	grid style (input). GRDSTYL = 0 dotted GRDSTYL = 1 lined
Integer GRDPTRN	grid pattern (input).
Real FLTVAL (2)	array of 2 elements specifying (input). FLTVAL(1) grid point size FLTVAL(2) default line width in pixels
Real DBLVAL (11)	array of 11 elements specifying (input). DBLVAL(1) maximum zoom factor x 100, i.e. 10=1000% zoom DBLVAL(2) minimum zoom factor DBLVAL(3) zoom increment DBLVAL(4) zoom at which to hide selection handles DBLVAL(5) zoom at which to hide text DBLVAL(6) zoom at which to hide grid DBLVAL(7) multi-page print scaling DBLVAL(8) pan distance DBLVAL(9) grid spacing DBLVAL(10) grid snap distance DBLVAL(11) branch spacing
Integer LOGVAL (7)	array of 7 elements specifying Each element has only two possible values. 0 = FALSE and 1 = TRUE. The elements are as follows(input). LOGVAL(1) no upside down text LOGVAL(2) high quality printing LOGVAL(3) display tooltips LOGVAL(4) stipple grid LOGVAL(5) hide unbound network items LOGVAL(6) display filled busbars LOGVAL(7) make branch connections perpendicular to branches
Integer LABLHIDE	label hide mode (input). LABLHIDE = 0 show all labels and results LABLHIDE = 1 hide results LABLHIDE = 2 hide all labels and results
Integer PRNTMODE	printing mode (input). PRNTMODE = 0 as seen on the screen, WYSIWYG PRNTMODE = 1 fit the whole diagram on the page PRNTMODE = 2 multi-page

Character*260 IMGDIR

name of directory where image files for this diagram are stored (input).

9.40. SETDIAGPROP_5

Use this API to specify basic properties in the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGPROP_5  SETSCOPE BKGCLR(1)..BKGCLR(3) PRTCLR(1)..PRTCLR(3)
GRDCLR(1)..GRDCLR(3) UPARWCLR(1)..UPARWCLR(3) DWNARWCLR(1)..DWNARWCLR(3)
LABCLR(1)..LABCLR(3) GRDSTYL GRDPTRN FLTVAL(1)..FLTVAL(2)
DBLVAL(1)..DBLVAL(11) LOGVAL(1)..LOGVAL(7) PRNTMODE IMGDIR
```

Python command syntax:

```
setdiagprop_5(setscope, bkgclr, prtclr, grdclr, uparwclr, dwnarwclr,
labclr, grdstyl, grdptrn, fltval, dblval, logval, prntmode, imgdir)
```

Fortran command syntax:

```
CALL SETDIAGPROP_5(SETSCOPE, BKGCLR, PRTCLR, GRDCLR, UPARWCLR, DWNARWCLR,
LABCLR, GRDSTYL, GRDPTRN, FLTVAL, DBLVAL, LOGVAL, PRNTMODE, IMGDIR)
```

Where:

Integer SETSCOPE	is the scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer BKGCLR (3)	array of 3 elements specifying background color(input).
	BKGCLR(1) 0->255 Red component
	BKGCLR(2) 0->255 Blue component
	BKGCLR(3) 0->255 Green component
Integer PRTCLR (3)	array of 3 elements specifying item connection port color(input).
	PRTCLR(1) 0->255 Red component
	PRTCLR(2) 0->255 Blue component
	PRTCLR(3) 0->255 Green component
Integer GRDCLR (3)	array of 3 elements specifying on-diagram layout grid color(input).
	GRDCLR(1) 0->255 Red component
	GRDCLR(2) 0->255 Blue component
	GRDCLR(3) 0->255 Green component
Integer UPARWCLR (3)	array of 3 elements specifying active power animation arrow color(input).
	UPARWCLR(1) 0->255 Red component
	UPARWCLR(2) 0->255 Blue component
	UPARWCLR(3) 0->255 Green component
Integer DWNARWCLR (3)	array of 3 elements specifying reactive power animation arrow color(input).

	DWNARWCLR(1)	0->255 Red component
	DWNARWCLR(2)	0->255 Blue component
	DWNARWCLR(3)	0->255 Green component
Integer LABCLR (3)	array of 3 elements specifying label color(input).	
	LABCLR(1)	0->255 Red component
	LABCLR(2)	0->255 Blue component
	LABCLR(3)	0->255 Green component
Integer GRDSTYL	grid style (input).	
	GRDSTYL = 0	dotted
	GRDSTYL = 1	lined
Integer GRDPTRN	grid pattern (input).	
Real FLTVAL (2)	array of 2 elements specifying (input).	
	FLTVAL(1)	grid point size
	FLTVAL(2)	default line width in pixels
Real DBLVAL (11)	array of 11 elements specifying (input).	
	DBLVAL(1)	maximum zoom factor x 100, i.e. 10=1000% zoom
	DBLVAL(2)	minimum zoom factor
	DBLVAL(3)	zoom increment
	DBLVAL(4)	zoom at which to hide selection handles
	DBLVAL(5)	zoom at which to hide text
	DBLVAL(6)	zoom at which to hide grid
	DBLVAL(7)	multi-page print scaling
	DBLVAL(8)	pan distance
	DBLVAL(9)	grid spacing
	DBLVAL(10)	grid snap distance
	DBLVAL(11)	branch spacing
Integer LOGVAL (7)	array of 7 elements specifying Each element has only two possible values. 0 = FALSE and 1 = TRUE. The elements are as follows(input).	
	LOGVAL(1)	no upside down text
	LOGVAL(2)	high quality printing
	LOGVAL(3)	display tooltips
	LOGVAL(4)	stipple grid
	LOGVAL(5)	hide unbound network items
	LOGVAL(6)	display filled busbars
	LOGVAL(7)	make branch connections perpendicular to branches
Integer PRNTMODE	printing mode (input).	
	PRNTMODE = 0	as seen on the screen, WYSIWYG
	PRNTMODE = 1	fit the whole diagram on the page
	PRNTMODE = 2	multi-page

Character*260 IMGDIR

name of directory where image files for this diagram are stored (input).

9.41. SETDIAGRESACCC

This API routine is obsolete. It has been replaced by the API routine [setdiagresaccc_2](#).

Use this API to set the ACCC analysis annotation options in the active Slider diagram.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SETDIAGRESACCC RATE CNTGOPT CONTOUR CNTROPT LOADPER FILE
```

Python command syntax:

```
setdiagresaccc(rate, cntgopt, contour, cntropt, loader, file)
```

Fortran command syntax:

```
CALL SETDIAGRESACCC(RATE, CNTGOPT, CONTOUR, CNTROPT, LOADPER, FILE)
```

Where:

Integer RATE	branch rating set (input).
	RATE = 1 RateA
	RATE = 2 RateB
	RATE = 3 RateC
Integer CNTGOPT	contingencies to view (input).
	CNTGOPT = 1 all contingencies
	CNTGOPT = 2 contingencies causing overload violations
	CNTGOPT = 3 contingencies causing any violations
Integer CONTOUR	contour selection (input).
	CONTOUR = 0 display data values as text
	CONTOUR = 1 display data values as a contour
Integer CNTROPT	contour value selection (input).
	CNTROPT = 0 contour bus voltages
	CNTROPT = 1 contour % branch flows
Real LOADPER	loading percentage (input).
Character*260 FILE	ACCC Contingency Solution data file (input; Not Allowed).

9.42. SETDIAGRESACCC_2

This API routine is obsolete. It has been replaced by the API routine [setdiagresaccc_3](#).

Use this API to set the ACCC analysis annotation options in the active Slider diagram

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SETDIAGRESACCC_2 CNTGOPT SELCNTG CONTOUR CNTROPT
```

Python command syntax:

```
setdiagresaccc_2(cntgopt, selcntg, contour, cntropt)
```

Fortran command syntax:

```
CALL SETDIAGRESACCC_2(CNTGOPT, SELCNTG, CONTOUR, CNTROPT)
```

Where:

Integer SELCNTG	selected contingency (input).
	SELCNTG = 0 none selected
	SELCNTG != 0 selected contingency from list determined by CNTGOPT
Integer CNTGOPT	contingency to view (input).
	CNTGOPT = 1 all contingencies
	CNTGOPT = 2 contingencies causing overload violations
	CNTGOPT = 3 contingencies causing any violations
Integer CONTOUR	contour selection (input).
	CONTOUR = 0 display data values as text
	CONTOUR = 1 display data values as a contour
Integer CNTROPT	contour value selection (input).
	CNTROPT = 0 contour bus voltages
	CNTROPT = 1 contour % branch flows

9.43. SETDIAGRESACCC_3

Use this API to set the ACCC analysis annotation options in the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESACCC_3 SETSCOPE CNTGOPT SELCNTG CONTOUR CNTROPT
```

Python command syntax:

```
setdiagresaccc_3(setscope, cntgopt, selcntg, contour, cntropt)
```

Fortran command syntax:

```
CALL SETDIAGRESACCC_3(SETSCOPE, CNTGOPT, SELCNTG, CONTOUR, CNTROPT)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer SELCNTG	selected contingency (input).
	SELCNTG = 0 none selected
	SELCNTG != 0 selected contingency from list determined by CNTGOPT
Integer CNTGOPT	contingency to view (input).
	CNTGOPT = 1 all contingencies
	CNTGOPT = 2 contingencies causing overload violations
	CNTGOPT = 3 contingencies causing any violations
Integer CONTOUR	contour selection (input).
	CONTOUR = 0 display data values as text
	CONTOUR = 1 display data values as a contour
Integer CNTROPT	contour value selection (input).
	CNTROPT = 0 contour bus voltages
	CNTROPT = 1 contour % branch flows

9.44. SETDIAGRESASCC

This API routine is obsolete. It has been replaced by the API routine [setdiagresascc_2](#).

This API is used to set the ASCC short circuit analysis annotation options in the active Slider diagram.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SETDIAGRESASCC  ANNOT TYPE BUS BOE CTRIB FRM TO LAST ID STYLE WIDTH
COLOR(1) . .COLOR(3)
```

Python command syntax:

```
setdiagresascc(annot, type, bus, boe, ctrib, frm, to, last, id, style,
width, color)
```

Fortran command syntax:

```
CALL SETDIAGRESASCC(ANNOT, TYPE, BUS, BOE, CTRIB, FRM, TO, LAST, ID,
STYLE, WIDTH, COLOR)
```

Where:

Integer ANNOT	fault to display (input).
	ANNOT = 0 fault currents (only bus faults)
	ANNOT = 1 three phase
	ANNOT = 2 line to Ground (LG)
	ANNOT = 3 line Line to Ground (LLG)
	ANNOT = 4 line to Line (LL)
Integer TYPE	fault display quantity (input).
	TYPE = 1 Ia1
	TYPE = 2 Ia2
	TYPE = 3 Ia0
	TYPE = 4 IA
	TYPE = 5 IB
	TYPE = 6 IC
	TYPE = 7 3Ia0
Integer BUS	faulted bus (input).
	BUS = 0 no bus faulted
	BUS > 0 bus to be faulted
Integer BOE	fault location (input).
	BOE = 1 fault located at the faulted bus
	BOE = 2 fault located at the faulted bus with lines out- aged
	BOE = 3 fault located at the end of lines
Integer CTRIB	contributions at home bus for bus faults (input).

	CTTRIB = 0	contributions for selected fault
	CTTRIB = 1	contributions at home bus for all faulted buses for selected fault
Integer FRM	from bus if a line fault is applied (input).	
	FRM = 0	no line fault applied
	FRM > 0	from bus
Integer TO	to bus if a line fault is applied (input).	
	TO = 0	no line fault applied
	TO > 0	to bus
Integer LAST	third bus if a line fault is applied to a 3-winding transformer (input).	
	LAST = 0	no line fault applied
	LAST > 0	to bus
Character*2 ID	branch/transformer identifier (input).	
Integer STYLE	line style applied to the faulted bus diagram item (input).	
Integer WIDTH	line width applied to the faulted bus diagram item, >= 1 (input).	
Integer COLOR (3)	array of 3 elements specifying color for diagram items that are faulted(input).	
	COLOR(1)	0->255 Red component
	COLOR(2)	0->255 Blue component
	COLOR(3)	0->255 Green component

9.45. SETDIAGRESASCC_2

This API routine is obsolete. It has been replaced by the API routine [setdiagresascc_3](#).

This API is used to set the ASCC short circuit analysis annotation options in the active Slider diagram.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SETDIAGRESASCC_2  SETSCOPE ANNOT TYPE BUS BOE CTRIB FRM TO LAST ID
```

Python command syntax:

```
setdiagresascc_2(setscope, annot, type, bus, boe, ctrib, frm, to, last, id)
```

Fortran command syntax:

```
CALL SETDIAGRESASCC_2(SETSCOPE, ANNOT, TYPE, BUS, BOE, CTRIB, FRM, TO, LAST, ID)
```

Where:

Integer SETSCOPE	scope of the API (input).	
	SETSCOPE = 0	defaults for new diagrams
	SETSCOPE = 1	defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2	settings for the active diagram
Integer ANNOT	fault to display (input).	
	ANNOT = 0	fault currents (only bus faults)
	ANNOT = 1	three phase
	ANNOT = 2	line to Ground (LG)
	ANNOT = 3	line Line to Ground (LLG)
Integer TYPE	ANNOT = 4	line to Line (LL)
	fault display quantity (input).	
	TYPE = 1	Ia1
	TYPE = 2	Ia2
	TYPE = 3	Ia0
	TYPE = 4	IA
	TYPE = 5	IB
	TYPE = 6	IC
Integer BUS	TYPE = 7	3Ia0
	faulted bus (input).	
	BUS = 0	no bus faulted
Integer BOE	BUS > 0	bus to be faulted
	fault location (input).	
	BOE = 1	fault located at the faulted bus

Integer CTRIB	BOE = 2	fault located at the faulted bus with lines out-aged
	BOE = 3	fault located at the end of lines
	contributions at home bus for bus faults (input).	
	CTTRIB = 0	contributions for selected fault
Integer FRM	CTTRIB = 1	contributions at home bus for all faulted buses for selected fault
	from bus if a line fault is applied (input).	
	FRM = 0	no line fault applied
	FRM > 0	from bus
Integer TO	to bus if a line fault is applied (input).	
	TO = 0	no line fault applied
	TO > 0	to bus
Integer LAST	third bus if a line fault is applied to a 3-winding transformer (input).	
	LAST = 0	no line fault applied
	LAST > 0	to bus
Character*2 ID	branch/transformer identifier (input).	

9.46. SETDIAGRESASCC_3

This API is used to set the ASCC short circuit analysis annotation options in the active Slider diagram.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_SETDIAGRESASCC_3  SETSCOPE ANNOT TYPE BUS BUSSECT BOE CTRIB FRM TO
LAST ID
```

Python command syntax:

```
setdiagresascc_3(setscope, annot, type, bus, bussect, boe, ctrib, frm, to,
last, id)
```

Fortran command syntax:

```
CALL SETDIAGRESASCC_3(SETSCOPE, ANNOT, TYPE, BUS, BUSSECT, BOE, CTRIB,
FRM, TO, LAST, ID)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer ANNOT	fault to display (input).
	ANNOT = 0 fault currents (only bus faults)
	ANNOT = 1 three phase
	ANNOT = 2 line to Ground (LG)
	ANNOT = 3 line Line to Ground (LLG)
	ANNOT = 4 line to Line (LL)
Integer TYPE	fault display quantity (input).
	TYPE = 1 Ia1
	TYPE = 2 Ia2
	TYPE = 3 Ia0
	TYPE = 4 IA
	TYPE = 5 IB
	TYPE = 6 IC
	TYPE = 7 3Ia0
Integer BUS	faulted bus (input).
	BUS = 0 no bus faulted
	BUS > 0 bus to be faulted
Integer BUSSECT	faulted bus section (input).
	BUSSECT = 0 no bus section faulted
	BUSSECT > 0 bus section to be faulted

Integer BOE	fault location (input). BOE = 1 fault located at the faulted bus BOE = 2 fault located at the faulted bus with lines out- aged BOE = 3 fault located at the end of lines
Integer CTRIB	contributions at home bus for bus faults (input). CTRIB = 0 contributions for selected fault CTRIB = 1 contributions at home bus for all faulted bus- es for selected fault
Integer FRM	from bus if a line fault is applied (input). FRM = 0 no line fault applied FRM > 0 from bus
Integer TO	to bus if a line fault is applied (input). TO = 0 no line fault applied TO > 0 to bus
Integer LAST	third bus if a line fault is applied to a 3-winding transformer (input). LAST = 0 no line fault applied LAST > 0 to bus
Character*2 ID	branch/transformer identifier (input).

9.47. SETDIAGRESDATA

This API routine is obsolete. It has been replaced by the API routine [setdiagresdata_2](#).

Use this API to specify the impedance data voltage and range checking annotation options in the active Slider Diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESDATA  USEVLT VLNWDT(1)..VLNWD(8) VLNSTY(1)..VLNSTY(8)
  VLTVAL(1)..VLTVAL(7) VLNCLRR(1)..VLNCLRR(8) VLNCLRG(1)..VLNCLRG(8)
  VLNCLRB(1)..VLNCLRB(8) OUTWDT OUTSTY OUTCLR(1)..OUTCLR(3) BUSANN BRNANN
  EQPANN BUSVLT
```

Python command syntax:

```
setdiagresdata(usevlt, vlnwdt, vlnsty, vltval, vlnclrr, vlnclrg, vlnclrb,
  outwdt, outsty, outclr, busann, brnann, eqpann, busvlt)
```

Fortran command syntax:

```
CALL SETDIAGRESDATA(USEVLT, VLNWDT, VLNSTY, VLTVAL, VLNCLRR, VLNCLRG,
  VLNCLRB, OUTWDT, OUTSTY, OUTCLR, BUSANN, BRNANN, EQPANN, BUSVLT)
```

Where:

Integer USEVLT	option to apply voltage level annotation to the Diagram elements (input).
	USEVLT = 0 don't apply voltage level annotation
	USEVLT = 1 apply voltage level annotation
Integer VLNWDT (8)	array of 8 elements specifying used to set the width of Diagram elements that fall in the appropriate voltage range(input).
	VLNWDT(1) base voltage < VLTVAL(1)
	VLNWDT(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNWDT(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNWDT(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNWDT(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNWDT(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNWDT(7) VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNWDT(8) base voltage >= VLTVAL(7)
Integer VLNSTY (8)	array of 8 elements specifying used to set the line style of Diagram elements that fall in the appropriate voltage range(input).
	VLNSTY(1) base voltage < VLTVAL(1)
	VLNSTY(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNSTY(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNSTY(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNSTY(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNSTY(6) VLTVAL(5) >= base voltage < VLTVAL(6)

	VLNSTY(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNSTY(8)	base voltage >= VLTVAL(7)
Real VLTVAL (7)	used to set the voltage ranges used to assign annotation Diagram. Base voltage values should be in ascending order (input).	
Integer VLNCLRR (8)	array of 8 elements specifying used to set the Red color component of Diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRR(1)	base voltage < VLTVAL(1)
	VLNCLRR(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRR(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRR(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRR(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRR(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRR(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRR(8)	base voltage >= VLTVAL(7)
Integer VLNCLRG (8)	array of 8 elements specifying used to set Green color component of Diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRG(1)	base voltage < VLTVAL(1)
	VLNCLRG(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRG(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRG(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRG(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRG(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRG(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRG(8)	base voltage >= VLTVAL(7)
Integer VLNCLRB (8)	array of 8 elements specifying used to set Blue color component of Diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRB(1)	base voltage < VLTVAL(1)
	VLNCLRB(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRB(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRB(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRB(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRB(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRB(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRB(8)	base voltage >= VLTVAL(7)
Integer OUTWDT	line width applied to out of service Diagram items, >= 1 (input).	
Integer OUTSTY	line style applied to out of service Diagram items (input).	
Integer OUTCLR (3)	array of 3 elements specifying color of Diagram items that are out of service(input).	
	OUTCLR(1)	0->255 Red component
	OUTCLR(2)	0->255 Blue component

	OUTCLR(3)	0->255 Green component
Integer BUSANN	bus ID annotation (input).	
	BUSANN = 0	number, no name
	BUSANN = 1	name, no number
	BUSANN = 2	number and name
	BUSANN = 3	no number, no name
Integer BRNANN	branch annotation (input).	
	BRNANN = 0	MW/MVAR flows
	BRNANN = 1	MVA
	BRNANN = 2	MVA/% rating
	BRNANN = 3	Amps/pu current
	BRNANN = 4	MW/%rating
	BRNANN = 5	Amps/% rating
	BRNANN = 6	None
Integer EQPANN	equipment annotation (input).	
	EQPANN = 0	MW/MVAR
	EQPANN = 2	none
Integer BUSVLT	bus voltage annotation (input).	
	BUSVLT = 0	magnitude (pu)
	BUSVLT = 1	magnitude (kV)
	BUSVLT = 2	angle (degrees)
	BUSVLT = 3	magnitude (pu) and angle (degrees)
	BUSVLT = 4	magnitude (pu) and magnitude (kV)
	BUSVLT = 5	magnitude (kV) and angle (degrees)
	BUSVLT = 7	magnitude (pu), magnitude (kV) and angle (degrees)
	BUSVLT = 8	none

9.48. SETDIAGRESDATA_2

This API routine is obsolete. It has been replaced by the API routine [setdiagresdata_3](#).

Use this API to specify the basic Power Flow annotation options in the active Slider Diagram.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SETDIAGRESDATA_2 BRNANN BUSANN
```

Python command syntax:

```
setdiagresdata_2(brnann, busann)
```

Fortran command syntax:

```
CALL SETDIAGRESDATA_2(BRNANN, BUSANN)
```

Where:

Integer BRNANN	branch annotation (input).	
	BRNANN = 6	display impedances
	BRNANN = 7	display ratings
	BRNANN = 8	display impedances & ratings
Integer BUSANN	BRNANN = 9	display nothing
	bus voltage annotation (input).	
	BUSANN = 0	don't display base kV
	BUSANN = 1	display base kV

9.49. SETDIAGRESDATA_3

Use this API to specify the basic Power Flow annotation options in the active Slider Diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESDATA_3 SETSCOPE BRNANN BUSANN
```

Python command syntax:

```
setdiagresdata_3(setscope, brnann, busann)
```

Fortran command syntax:

```
CALL SETDIAGRESDATA_3(SETSCOPE, BRNANN, BUSANN)
```

Where:

Integer SETSCOPE	scope of the API (input).	
	SETSCOPE = 0	defaults for new diagrams
	SETSCOPE = 1	defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2	settings for the active diagram
Integer BRNANN	branch annotation (input).	
	BRNANN = 6	display impedances
	BRNANN = 7	display ratings
	BRNANN = 8	display impedances & ratings
Integer BUSANN	BRNANN = 9	display nothing
	bus voltage annotation (input).	
	BUSANN = 0	don't display base kV
	BUSANN = 1	display base kV

9.50. SETDIAGRESHDYN

This API routine is obsolete. It has been replaced by the API routine [setdiagresdyn_2](#).

This API is used to set the dynamic simulation annotation options in the active Slider diagram.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SETDIAGRESHDYN  MODE  CONTOUR
```

Python command syntax:

```
setdiagresdyn(mode, contour)
```

Fortran command syntax:

```
CALL SETDIAGRESHDYN(MODE, CONTOUR)
```

Where:

Integer MODE	specifies the simulation result/value to display (input).
MODE = 0	voltage violations as specified by SET_VOLTAGE_REC_CHECK and SET_VOLTAGE_DIP_CHECK
MODE = 1	contour simulation quantities
Integer CONTOUR	specifies the dynamic quantity to contour (input).
CONTOUR = 0	bus voltage - kV

9.51. SETDIAGRESDYN_2

This API is used to set the dynamic simulation annotation options in the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESDYN_2 SETSCOPE MODE CONTOUR
```

Python command syntax:

```
setdiagresdyn_2(setscope, mode, contour)
```

Fortran command syntax:

```
CALL SETDIAGRESDYN_2(SETSCOPE, MODE, CONTOUR)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer MODE	specifies the simulation result/value to display (input).
	MODE = 0 voltage violations as specified by SET_VOLTAGE_REC_CHECK and SET_VOLTAGE_DIP_CHECK
	MODE = 1 contour simulation quantities
Integer CONTOUR	specifies the dynamic quantity to contour (input).
	CONTOUR = 0 Bus voltage - kV

9.52. SETDIAGRESGDIF

Use this API to specify the case comparison voltage and range checking annotation options in the active Slider diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESGDIF  USEVLT VLNWDT(1)..VLNWD(8) VLNSTY(1)..VLNSTY(8)
  VLTVAL(1)..VLTVAL(7) VLNCLRR(1)..VLNCLRR(8) VLNCLRG(1)..VLNCLRG(8)
  VLNCLRB(1)..VLNCLRB(8) OUTWDT OUTSTY OUTCLR(1)..OUTCLR(3) BUSANN
```

Python command syntax:

```
setdiagresgdif(usevlt, vlnwdt, vlnsty, vltval, vlnclrr, vlnclrg, vlnclrb,
  outwdt, outsty, outclr, busann)
```

Fortran command syntax:

```
CALL SETDIAGRESGDIF(USEVLT, VLNWDT, VLNSTY, VLTVAL, VLNCLRR, VLNCLRG,
  VLNCLRB, OUTWDT, OUTSTY, OUTCLR, BUSANN)
```

Where:

Integer USEVLT	flag to apply voltage level annotation to the diagram elements (input).
	USEVLT = 0 don't apply voltage level annotation
	USEVLT = 1 apply voltage level annotation
Integer VLNWDT (8)	array of 8 elements specifying the width of diagram elements that fall in the appropriate voltage range(input).
	VLNWD(1) base voltage < VLTVAL(1)
	VLNWD(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNWD(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNWD(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNWD(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNWD(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNWD(7) VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNWD(8) base voltage >= VLTVAL(7)
Integer VLNSTY (8)	array of 8 elements specifying the line style of diagram elements that fall in the appropriate voltage range(input).
	VLNSTY(1) base voltage < VLTVAL(1)
	VLNSTY(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNSTY(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNSTY(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNSTY(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNSTY(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNSTY(7) VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNSTY(8) base voltage >= VLTVAL(7)

Real VLTVAL (7)	the voltage ranges used to assign annotation diagram. Base voltage values should be in ascending order (input).
Integer VLNCLRR (8)	array of 8 elements specifying the Red color component of diagram elements that fall in the appropriate voltage range, 0->255(input). VLNCLRR(1) base voltage < VLTVAL(1) VLNCLRR(2) VLTVAL(1) >= base voltage < VLTVAL(2) VLNCLRR(3) VLTVAL(2) >= base voltage < VLTVAL(3) VLNCLRR(4) VLTVAL(3) >= base voltage < VLTVAL(4) VLNCLRR(5) VLTVAL(4) >= base voltage < VLTVAL(5) VLNCLRR(6) VLTVAL(5) >= base voltage < VLTVAL(6) VLNCLRR(7) VLTVAL(6) >= base voltage < VLTVAL(7) VLNCLRR(8) base voltage >= VLTVAL(7)
Integer VLNCLRG (8)	array of 8 elements specifying the Green color component of diagram elements that fall in the appropriate voltage range, 0->255(input). VLNCLRG(1) base voltage < VLTVAL(1) VLNCLRG(2) VLTVAL(1) >= base voltage < VLTVAL(2) VLNCLRG(3) VLTVAL(2) >= base voltage < VLTVAL(3) VLNCLRG(4) VLTVAL(3) >= base voltage < VLTVAL(4) VLNCLRG(5) VLTVAL(4) >= base voltage < VLTVAL(5) VLNCLRG(6) VLTVAL(5) >= base voltage < VLTVAL(6) VLNCLRG(7) VLTVAL(6) >= base voltage < VLTVAL(7) VLNCLRG(8) base voltage >= VLTVAL(7)
Integer VLNCLRB (8)	array of 8 elements specifying the Blue color component of diagram elements that fall in the appropriate voltage range, 0->255(input). VLNCLRB(1) base voltage < VLTVAL(1) VLNCLRB(2) VLTVAL(1) >= base voltage < VLTVAL(2) VLNCLRB(3) VLTVAL(2) >= base voltage < VLTVAL(3) VLNCLRB(4) VLTVAL(3) >= base voltage < VLTVAL(4) VLNCLRB(5) VLTVAL(4) >= base voltage < VLTVAL(5) VLNCLRB(6) VLTVAL(5) >= base voltage < VLTVAL(6) VLNCLRB(7) VLTVAL(6) >= base voltage < VLTVAL(7) VLNCLRB(8) base voltage >= VLTVAL(7)
Integer OUTWDT	line width applied to out of service diagram items, >= 1 (input).
Integer OUTSTY	line style applied to out of service diagram items (input).
Integer OUTCLR (3)	array of 3 elements specifying color for diagram items that are out of service(input). OUTCLR(1) 0->255 Red component OUTCLR(2) 0->255 Blue component OUTCLR(3) 0->255 Green component
Integer BUSANN	bus ID annotation (input). BUSANN = 0 number, no name BUSANN = 1 name, no number

BUSANN = 2

number and name

BUSANN = 3

no number, no name

9.53. SETDIAGRESIEC

This API routine is obsolete. It has been replaced by the API routine [setdiagresiec_2](#).

Use this API to specify the IEC annotation options in the active Slider diagram.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETDIAGRESIEC  ANNOT TYPE FLTBUS BOE CONTRIB FRM TO LAST ID STYLE
                    WIDTH COLOR(1).. COLOR(3)
```

Python command syntax:

```
setdiagresiec(annot, type, fltbus, boe, contrib, frm, to, last, id, style,
              width, color)
```

Fortran command syntax:

```
CALL SETDIAGRESIEC(ANNOT, TYPE, FLTBUS, BOE, CONTRIB, FRM, TO, LAST, ID,
                   STYLE, WIDTH, COLOR)
```

Where:

Integer ANNOT	specifies the fault to display (input).
ANNOT = 0	fault currents (only bus faults)
ANNOT = 1	three phase
ANNOT = 2	line to Ground (LG)
ANNOT = 3	line Line to Ground (LLG)
ANNOT = 4	line to Line (LL)
Integer TYPE	specifies the fault display quantity (input).
TYPE = 1	Ia1
TYPE = 2	Ia2
TYPE = 3	Ia0
TYPE = 4	IA
TYPE = 5	IB
TYPE = 6	IC
TYPE = 7	3Ia0
Integer FLTBUS	specifies the faulted bus (input).
FLTBUS = 0	no bus faulted
FLTBUS > 0	bus to be faulted
Integer BOE	specifies the fault location (input).
BOE = 1	fault located at the faulted bus
BOE = 2	fault located at the faulted bus with lines out- aged
BOE = 3	fault located at the end of lines
Integer CONTRIB	specifies contributions at home bus for bus faults (input).

	CONTRIB = 0	contributions for selected fault
	CONTRIB = 1	contributions at home bus for all faulted buses for selected fault
Integer FRM	specifies the from bus if a line fault is applied (input).	
	FRM = 0	no line fault applied
	FRM > 0	from bus
Integer TO	specifies the to bus if a line fault is applied (input).	
	TO = 0	no line fault applied
	TO > 0	to bus
Integer LAST	specifies the third bus if a line fault is applied to a 3-winding transformer (input).	
	LAST = 0	no line fault applied
	LAST > 0	to bus
Character*2 ID	branch/transformer identifier (input).	
Integer STYLE	line style applied to the faulted bus diagram item (input).	
Integer WIDTH	line width applied to the faulted bus diagram item, >= 1 (input).	
Integer COLOR (3)	array of 3 elements specifying color for diagram items that are faulted(input).	
	COLOR(1)	0->255 Red component
	COLOR(2)	0->255 Blue component
	COLOR(3)	0->255 Green component

9.54. SETDIAGRESIEC_2

This API routine is obsolete. It has been replaced by the API routine [setdiagresiec_3](#).

Use this API to specify the IEC annotation options in the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESIEC_2 SETSCOPE ANNOT TYPE FLTBUS BOE CONTRIB FRM TO LAST ID
```

Python command syntax:

```
setdiagresiec_2(setscope, annot, type, fltbus, boe, contrib, frm, to,
last, id)
```

Fortran command syntax:

```
CALL SETDIAGRESIEC_2(SETSCOPE, ANNOT, TYPE, FLTBUS, BOE, CONTRIB, FRM, TO,
LAST, ID)
```

Where:

Integer SETSCOPE	scope of the API (input).	
	SETSCOPE = 0	defaults for new diagrams
	SETSCOPE = 1	defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2	settings for the active diagram
Integer ANNOT	fault to display (input).	
	ANNOT = 0	fault currents (only bus faults)
	ANNOT = 1	three phase
	ANNOT = 2	line to Ground (LG)
	ANNOT = 3	line Line to Ground (LLG)
Integer TYPE	ANNOT = 4	line to Line (LL)
	fault display quantity (input).	
	TYPE = 1	Ia1
	TYPE = 2	Ia2
	TYPE = 3	Ia0
	TYPE = 4	IA
	TYPE = 5	IB
	TYPE = 6	IC
	TYPE = 7	3Ia0
Integer FLTBUS	faulted bus (input).	
	FLTBUS = 0	no bus faulted
	FLTBUS > 0	bus to be faulted
Integer BOE	fault location (input).	
	BOE = 1	fault located at the faulted bus

Integer CONTRIB	BOE = 2	fault located at the faulted bus with lines out-aged
	BOE = 3	fault located at the end of lines
	contributions at home bus for bus faults (input).	
	CONTRIB = 0	contributions for selected fault
Integer FRM	CONTRIB = 1	contributions at home bus for all faulted buses for selected fault
	from bus if a line fault is applied (input).	
	FRM = 0	no line fault applied
	FRM > 0	from bus
Integer TO	to bus if a line fault is applied (input).	
	TO = 0	no line fault applied
	TO > 0	to bus
Integer LAST	third bus if a line fault is applied to a 3-winding transformer (input).	
	LAST = 0	no line fault applied
	LAST > 0	to bus
Character*2 ID	branch/transformer identifier (input).	

9.55. SETDIAGRESIEC_3

Use this API to specify the IEC annotation options in the active Slider diagram.

This API routine was first introduced in release 34.2.0.

Batch command syntax:

```
BAT_SETDIAGRESIEC_3  SETSCOPE ANNOT TYPE FLTBUS FLTBUSSECT BOE CONTRIB FRM
TO LAST ID
```

Python command syntax:

```
setdiagresiec_3(setscope, annot, type, fltbus, fltbussect, boe, contrib,
frm, to, last, id)
```

Fortran command syntax:

```
CALL SETDIAGRESIEC_3(SETSCOPE, ANNOT, TYPE, FLTBUS, FLTBUSSECT, BOE,
CONTRIB, FRM, TO, LAST, ID)
```

Where:

Integer SETSCOPE	scope of the API (input).
SETSCOPE = 0	defaults for new diagrams
SETSCOPE = 1	defaults for new diagrams and settings for the active diagram
SETSCOPE = 2	settings for the active diagram
Integer ANNOT	fault to display (input).
ANNOT = 0	fault currents (only bus faults)
ANNOT = 1	three phase
ANNOT = 2	line to Ground (LG)
ANNOT = 3	line Line to Ground (LLG)
ANNOT = 4	line to Line (LL)
Integer TYPE	fault display quantity (input).
TYPE = 1	Ia1
TYPE = 2	Ia2
TYPE = 3	Ia0
TYPE = 4	IA
TYPE = 5	IB
TYPE = 6	IC
TYPE = 7	3Ia0
Integer FLTBUS	faulted bus (input).
FLTBUS = 0	no bus faulted
FLTBUS > 0	bus to be faulted
Integer FLTBUSSECT	faulted bus section (input).
FLTBUSSECT = 0	no bus section faulted
FLTBUSSECT > 0	bus section to be faulted

Integer BOE	fault location (input). BOE = 1 fault located at the faulted bus BOE = 2 fault located at the faulted bus with lines out- aged BOE = 3 fault located at the end of lines
Integer CONTRIB	contributions at home bus for bus faults (input). CONTRIB = 0 contributions for selected fault CONTRIB = 1 contributions at home bus for all faulted bus- es for selected fault
Integer FRM	from bus if a line fault is applied (input). FRM = 0 no line fault applied FRM > 0 from bus
Integer TO	to bus if a line fault is applied (input). TO = 0 no line fault applied TO > 0 to bus
Integer LAST	third bus if a line fault is applied to a 3-winding transformer (input). LAST = 0 no line fault applied LAST > 0 to bus
Character*2 ID	branch/transformer identifier (input).

9.56. SETDIAGRESMUST

This API is used to set the MUST simulation annotation options in the active Slider diagram.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETDIAGRESMUST SETSCOPE OPTION1 OPTION2 OPTION3 OPTION4
```

Python command syntax:

```
setdiagresmust(setscope, option1, option2, option3, option4)
```

Fortran command syntax:

```
CALL SETDIAGRESMUST(SETSCOPE, OPTION1, OPTION2, OPTION3, OPTION4)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer OPTION1	scope of the API (input).
	OPTION1 = 0 defaults for new diagrams
	OPTION1 = 1 defaults for new diagrams and settings for the active diagram
	OPTION1 = 2 settings for the active diagram
Integer OPTION2	specifies the simulation result/value to display (input).
	OPTION2 = 0 voltage violations as specified by SET_VOLTAGE_REC_CHECK and SET_VOLTAGE_DIP_CHECK
	OPTION2 = 1 contour simulation quantities
Integer OPTION3	specifies the dynamic quantity to contour (input).
	OPTION3 = 0 Bus voltage - kV
Integer OPTION4	specifies the dynamic quantity to contour (input).
	OPTION4 = 0 Bus voltage - kV

9.57. SETDIAGRESOPF

This API routine is obsolete. It has been replaced by the API routine [setdiagresopf_2](#).

Use this API to specify the OPF annotation options in the active Slider diagram.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_SETDIAGRESOPF OPFBUSVOLTMAJ OPFBUSPINJ OPFBUSQINJ OPFLOADSENS  
OPFFXSSENS OPFSWSSENS
```

Python command syntax:

```
setdiagresopf(opfbusvoltmag, opfbuspinj, opfbusqinj, opfloadsens,  
opffxsens, opfswsens)
```

Fortran command syntax:

```
CALL SETDIAGRESOPF(OPFBUSVOLTMAJ, OPFBUSPINJ, OPFBUSQINJ, OPFLOADSENS,  
OPFFXSSENS, OPFSWSSENS)
```

Where:

Integer OPFBUSVOLTMAJ	bus voltage magnitude flag (input).
Integer OPFBUSPINJ	bus P injection flag (input).
Integer OPFBUSQINJ	bus Q injection flag (input).
Integer OPFLOADSENS	load sensitivities flag (input).
Integer OPFFXSSENS	fixed shunt sensitivities flag (input).
Integer OPFSWSSENS	switched shunt sensitivities flag (input).

9.58. SETDIAGRESOPF_2

Use this API to specify the OPF annotation options in the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESOPF_2 SETSCOPE OPFBUSVOLTMAg OPFBUSPINJ OPFBUSQINJ  
OPFLOADSENS OPFFXSSENS OPFSWSSENS
```

Python command syntax:

```
setdiagresopf_2(setscope, opfbusvoltmag, opfbuspinj, opfbusqinj,  
opfloadsens, opffxsens, opfswsens)
```

Fortran command syntax:

```
CALL SETDIAGRESOPF_2(SETSCOPE, OPFBUSVOLTMAg, OPFBUSPINJ, OPFBUSQINJ,  
OPFLOADSENS, OPFFXSSENS, OPFSWSSENS)
```

Where:

Integer SETSCOPE	is the scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer OPFBUSVOLTMAg	bus voltage magnitude flag (input).
Integer OPFBUSPINJ	bus P injection flag (input).
Integer OPFBUSQINJ	bus Q injection flag (input).
Integer OPFLOADSENS	load sensitivities flag (input).
Integer OPFFXSSENS	fixed shunt sensitivities flag (input).
Integer OPFSWSSENS	switched shunt sensitivities flag (input).

9.59. SETDIAGRESOPF_3

Use this API to specify the OPF annotation options in the active Slider diagram.

This API routine was first introduced in release 34.5.0.

Batch command syntax:

```
BAT_SETDIAGRESOPF_3  SETSCOPE OPFBUSVOLTMAg OPFBUSPINJ OPFBUSQINJ
  OPFLOADSENS OPFFXSSENS OPFSWSENS OPFMACSENS1 OPFMACSENS2 OPFMACSENS3
  OPFMACSENS4 OPFMACSENS5
```

Python command syntax:

```
setdiagresopf_3(setscope, opfbusvoltmag, opfbuspinj, opfbusqinj,
  opfloadsens, opffxsens, opfswsens, opfmacsens1, opfmacsens2,
  opfmacsens3, opfmacsens4, opfmacsens5)
```

Fortran command syntax:

```
CALL SETDIAGRESOPF_3(SETSCOPE, OPFBUSVOLTMAg, OPFBUSPINJ, OPFBUSQINJ,
  OPFLOADSENS, OPFFXSSENS, OPFSWSENS, OPFMACSENS1, OPFMACSENS2,
  OPFMACSENS3, OPFMACSENS4, OPFMACSENS5)
```

Where:

Integer SETSCOPE	is the scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer OPFBUSVOLTMAg	bus voltage magnitude flag (input).
Integer OPFBUSPINJ	bus P injection flag (input).
Integer OPFBUSQINJ	bus Q injection flag (input).
Integer OPFLOADSENS	load sensitivities flag (input).
Integer OPFFXSSENS	fixed shunt sensitivities flag (input).
Integer OPFSWSENS	switched shunt sensitivities flag (input).
Integer OPFMACSENS1	machine sensitivities flag (input).
Integer OPFMACSENS2	machine sensitivities flag (input).
Integer OPFMACSENS3	machine sensitivities flag (input).
Integer OPFMACSENS4	machine sensitivities flag (input).
Integer OPFMACSENS5	machine sensitivities flag (input).

9.60. SETDIAGRESPFLOWCHECK

This API routine is obsolete. It has been replaced by the API routine [setdiagrespflowcheck_2](#).

Use this API to specify the Power Flow voltage and range checking annotation options in the active Slider diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESPFLOWCHECK LOGARR(1)..LOGARR(4) VLNWDT(1)..VLNWDT(8)
VLNSTY(1)..VLNSTY(8) VLTVAL(1)..VLTVAL(7) VLNCLRR(1)..VLNCLRR(8)
VLNCLRG(1)..VLNCLRG(8) VLNCLRB(1)..VLNCLRB(8) LINLOD LLODARR(1)
LLODARR(2) LLODCLR(1)..LLODCLR(3) BUSVLT(1) BUSVLT(2) BUSVLTWDT(1)
BUSVLTWDT(2) BUSCLRR(1) BUSCLRR(2) BUSCLRG(1) BUSCLRG(2) BUSCLRB(1)
BUSCLRB(2) OUTARR(1) OUTARR(2) OUTCLR(1)..OUTCLR(3) BRNRAT BARPERCENT
BARCLRR(1) BARCLRR(2) BARCLRR(3) BARCLRR(4) BARCLRG(1) BARCLRG(2)
BARCLRG(3) BARCLRG(4) BARCLRB(1) BARCLRB(2) BARCLRB(3) BARCLRB(4)
```

Python command syntax:

```
setdiagrespflowcheck(logarr, vlnwdt, vlnsty, vltval, vlnclrr, vlnclrg,
vlnclrb, linlod, lloдarr, lloдclr, busvlt, busvltwdt, busclrr, busclrg,
busclrb, outarr, outclr, brnrat, barpercent, barclrr, barclrg, barclrb)
```

Fortran command syntax:

```
CALL SETDIAGRESPFLOWCHECK(LOGARR, VLNWDT, VLNSTY, VLTVAL, VLNCLRR,
VLNCLRG, VLNCLRB, LINLOD, LLODARR, LLODCLR, BUSVLT, BUSVLTWDT, BUSCLRR,
BUSCLRG, BUSCLRB, OUTARR, OUTCLR, BRNRAT, BARPERCENT, BARCLRR, BARCLRG,
BARCLRB)
```

Where:

Integer LOGARR (4)	array of 4 elements specifying flag to determine what annotation is applied. Each element has only two possible values. 0 = FALSE and 1 = TRUE(input).
	LOGARR(1) use Voltage level thresholds
	LOGARR(2) use Line ratings
	LOGARR(3) use Bus voltage
	LOGARR(4) use out of service
Integer VLNWDT (8)	array of 8 elements specifying the width of diagram elements that fall in the appropriate voltage range(input).
	VLNWDT(1) base voltage < VLTVAL(1)
	VLNWDT(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNWDT(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNWDT(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNWDT(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNWDT(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNWDT(7) VLTVAL(6) >= base voltage < VLTVAL(7)

	VLNWD(8)	base voltage $\geq$ VLTVAL(7)
Integer VLNSTY (8)	array of 8 elements specifying the line style of diagram elements that fall in the appropriate voltage range(input).	
	VLNSTY(1)	base voltage $<$ VLTVAL(1)
	VLNSTY(2)	VLTVAL(1) $\geq$ base voltage $<$ VLTVAL(2)
	VLNSTY(3)	VLTVAL(2) $\geq$ base voltage $<$ VLTVAL(3)
	VLNSTY(4)	VLTVAL(3) $\geq$ base voltage $<$ VLTVAL(4)
	VLNSTY(5)	VLTVAL(4) $\geq$ base voltage $<$ VLTVAL(5)
	VLNSTY(6)	VLTVAL(5) $\geq$ base voltage $<$ VLTVAL(6)
	VLNSTY(7)	VLTVAL(6) $\geq$ base voltage $<$ VLTVAL(7)
	VLNSTY(8)	base voltage $\geq$ VLTVAL(7)
Real VLTVAL (7)	set the voltage ranges used to assign annotation diagram. Base voltage values should be in ascending order (input).	
Integer VLNCLRR (8)	array of 8 elements specifying the Red color component of diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRR(1)	base voltage $<$ VLTVAL(1)
	VLNCLRR(2)	VLTVAL(1) $\geq$ base voltage $<$ VLTVAL(2)
	VLNCLRR(3)	VLTVAL(2) $\geq$ base voltage $<$ VLTVAL(3)
	VLNCLRR(4)	VLTVAL(3) $\geq$ base voltage $<$ VLTVAL(4)
	VLNCLRR(5)	VLTVAL(4) $\geq$ base voltage $<$ VLTVAL(5)
	VLNCLRR(6)	VLTVAL(5) $\geq$ base voltage $<$ VLTVAL(6)
	VLNCLRR(7)	VLTVAL(6) $\geq$ base voltage $<$ VLTVAL(7)
	VLNCLRR(8)	base voltage $\geq$ VLTVAL(7)
Integer VLNCLRG (8)	array of 8 elements specifying the Green color component of diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRG(1)	base voltage $<$ VLTVAL(1)
	VLNCLRG(2)	VLTVAL(1) $\geq$ base voltage $<$ VLTVAL(2)
	VLNCLRG(3)	VLTVAL(2) $\geq$ base voltage $<$ VLTVAL(3)
	VLNCLRG(4)	VLTVAL(3) $\geq$ base voltage $<$ VLTVAL(4)
	VLNCLRG(5)	VLTVAL(4) $\geq$ base voltage $<$ VLTVAL(5)
	VLNCLRG(6)	VLTVAL(5) $\geq$ base voltage $<$ VLTVAL(6)
	VLNCLRG(7)	VLTVAL(6) $\geq$ base voltage $<$ VLTVAL(7)
	VLNCLRG(8)	base voltage $\geq$ VLTVAL(7)
Integer VLNCLRB (8)	array of 8 elements specifying the Blue color component of diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRB(1)	base voltage $<$ VLTVAL(1)
	VLNCLRB(2)	VLTVAL(1) $\geq$ base voltage $<$ VLTVAL(2)
	VLNCLRB(3)	VLTVAL(2) $\geq$ base voltage $<$ VLTVAL(3)
	VLNCLRB(4)	VLTVAL(3) $\geq$ base voltage $<$ VLTVAL(4)
	VLNCLRB(5)	VLTVAL(4) $\geq$ base voltage $<$ VLTVAL(5)
	VLNCLRB(6)	VLTVAL(5) $\geq$ base voltage $<$ VLTVAL(6)
	VLNCLRB(7)	VLTVAL(6) $\geq$ base voltage $<$ VLTVAL(7)

	VLNCLRB(8)	base voltage $\geq$ VLTVAL(7)
Real LINLOD	% loading for line rating (input).	
Integer LLODARR (2)	array of 2 elements specifying the width and style of diagram items that exceed the % of line loading(input).	
	LLODARR(1)	Line width $\geq$ 1
	LLODARR(2)	Line style
Integer LLODCLR (3)	array of 3 elements specifying color for lines that exceed the % loading rating, LINLOD(input).	
	LLODCLR(1)	0->255 Red component
	LLODCLR(2)	0->255 Blue component
	LLODCLR(3)	0->255 Green component
Real BUSVLT (2)	array of 2 elements specifying the bus voltage check Min and Max(input).	
	BUSVLT(1)	Min. bus voltage
	BUSVLT(2)	Max. bus voltage
Integer BUSVLTWDT (2)	array of 2 elements specifying the bus voltage check width of diagram items at the Min and Max(input).	
	BUSVLTWDT(1)	Min. bus voltage width $\geq$ 1
	BUSVLTWDT(2)	Max. bus voltage width $\geq$ 1
Integer BUSCLRR (2)	array of 2 elements specifying the Red color component of diagram elements that fall in the appropriate bus voltage range, 0->255(input).	
	BUSCLRR(1)	base voltage $<$ BUSVLTWDT(1)
	BUSCLRR(2)	BUSVLTWDT(1) $\geq$ base voltage $<$ BUSVLTWDT (2)
Integer BUSCLRG (2)	array of 2 elements specifying the Green color component of diagram elements that fall in the appropriate bus voltage range, 0->255(input).	
	BUSCLRG(1)	base voltage $<$ BUSVLTWDT (1)
	BUSCLRG(2)	BUSVLTWDT (1) $\geq$ base voltage $<$ BUSVLTWDT (2)
Integer BUSCLRB (2)	array of 2 elements specifying the Blue color component of diagram elements that fall in the appropriate bus voltage range, 0->255(input).	
	BUSCLRB(1)	base voltage $<$ BUSVLTWDT (1)
	BUSCLRB(2)	BUSVLTWDT(1) $\geq$ base voltage $<$ BUSVLTWDT (2)
Integer OUTARR (2)	array of 2 elements specifying the width and style of diagram items that are out of service(input).	
	OUTARR(1)	Line width $\geq$ 1
	OUTARR(2)	Line style
Integer OUTCLR (3)	array of 3 elements specifying color for diagram items that are out of service(input).	

	OUTCLR(1)	0->255 Red component
	OUTCLR(2)	0->255 Blue component
	OUTCLR(3)	0->255 Green component
Integer BRNRAT	branch rating set (input).	
	BRNRAT = 0	RateA
	BRNRAT = 1	RateB
	BRNRAT = 2	RateC
Integer BARPERCENT (4)	array of 4 elements specifying percent overloads at which to apply different color schemes for the line loading charts on the diagram(input).	
	BARPERCENT(1)	first overload voltage point
	BARPERCENT(2)	second overload voltage point
	BARPERCENT(3)	third overload voltage point
	BARPERCENT(4)	fourth overload voltage point
Integer BARCLRR (4)	array of 4 elements specifying the Red color component for the line loading charts on the diagram, 0->255(input).	
	BARCLRR(1)	first line loading chart red value
	BARCLRR(2)	second line loading chart red value
	BARCLRR(3)	third line loading chart red value
	BARCLRR(4)	fourth line loading chart red value
Integer BARCLRG (4)	array of 4 elements specifying the Green color component for the line loading charts on the diagram, 0->255(input).	
	BARCLRG(1)	first line loading chart green value
	BARCLRG(2)	second line loading chart green value
	BARCLRG(3)	third line loading chart green value
	BARCLRG(4)	fourth line loading chart green value
Integer BARCLRB (4)	array of 4 elements specifying the Blue color component for the line loading charts on the diagram, 0->255(input).	
	BARCLRB(1)	first line loading chart blue value
	BARCLRB(2)	second line loading chart blue value
	BARCLRB(3)	third line loading chart blue value
	BARCLRB(4)	fourth line loading chart blue value

9.61. SETDIAGRESPFLOWCHECK_2

This API routine is obsolete. It has been replaced by the API routine [setdiagrespflowcheck_3](#).

Use this API to specify the Power Flow voltage and range checking annotation options in the active Slider Diagram.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SETDIAGRESPFLOWCHECK_2 LOGARR(1) LOGARR(2) LINLOD LLODARR(1)
LLODARR(2) LLODCLR(1) LLODCLR(2) LLODCLR(3) BUSVLT(1) BUSVLT(2) BUSVLTWDT(1)
BUSVLTWDT(2) BUSCLRR(1) BUSCLRR(2) BUSCLRG(1) BUSCLRG(2) BUSCLRB(1)
BUSCLRB(2) BRNRAT BARPERCENT BARCLRR(1) BARCLRR(2) BARCLRR(3) BARCLRR(4)
BARCLRG(1) BARCLRG(2) BARCLRG(3) BARCLRG(4) BARCLRB(1) BARCLRB(2)
BARCLRB(3) BARCLRB(4)
```

Python command syntax:

```
setdiagrespflowcheck_2(logarr, linlod, llodarr, llodclr, busvlt,
busvltwdt, busclrr, busclrg, busclrb, brnrat, barpercent, barclrr,
barclrg, barclrb)
```

Fortran command syntax:

```
CALL SETDIAGRESPFLOWCHECK_2(LOGARR, LINLOD, LLODARR, LLODCLR, BUSVLT,
BUSVLTWDT, BUSCLRR, BUSCLRG, BUSCLRB, BRNRAT, BARPERCENT, BARCLRR,
BARCLRG, BARCLRB)
```

Where:

Integer LOGARR (2)	array of 2 elements specifying flag to determine what annotation is applied. Each element has only two possible values. 0 = FALSE and 1 = TRUE(input).
	LOGARR(1) use Line ratings
	LOGARR(2) use Bus voltage
Real LINLOD	% loading for line rating (input).
Integer LLODARR (2)	array of 2 elements specifying the width and style of Diagram items that exceed the % of line loading(input).
	LLODARR(1) Line width >= 1
	LLODARR(2) Line style
Integer LLODCLR (3)	array of 3 elements specifying the color for lines that exceed the % loading rating, LINLOD(input).
	LLODCLR(1) 0->255 Red component
	LLODCLR(2) 0->255 Blue component
	LLODCLR(3) 0->255 Green component
Real BUSVLT (2)	array of 2 elements specifying the bus voltage check Min and Max(input).
	BUSVLT(1) Min. bus voltage

	BUSVLT(2)	Max. bus voltage
Integer BUSVLTWDT (2)	array of 2 elements specifying the bus voltage check width of diagram items at the Min and Max(input).	
	BUSVLTWDT(1)	Min. bus voltage width ≥ 1
	BUSVLTWDT(2)	Max. bus voltage width ≥ 1
Integer BUSCLRR (2)	array of 2 elements specifying the Red color component of Diagram elements that fall in the appropriate bus voltage range, 0->255(input).	
	BUSCLRR(1)	base voltage < BUSVLTWDT(1)
	BUSCLRR(2)	BUSVLTWDT(1) $\geq$ base voltage < BUSVLTWDT (2)
Integer BUSCLRG (2)	array of 2 elements specifying the Green color component of Diagram elements that fall in the appropriate bus voltage range, 0->255(input).	
	BUSCLRG(1)	base voltage < BUSVLTWDT (1)
	BUSCLRG(2)	BUSVLTWDT (1) $\geq$ base voltage < BUSVLTWDT (2)
Integer BUSCLRB (2)	array of 2 elements specifying the Blue color component of Diagram elements that fall in the appropriate bus voltage range, 0->255(input).	
	BUSCLRB(1)	base voltage < BUSVLTWDT (1)
	BUSCLRB(2)	BUSVLTWDT(1) $\geq$ base voltage < BUSVLTWDT (2)
Integer BRNRAT	branch rating set (input).	
	BRNRAT = 0	RateA
	BRNRAT = 1	RateB
	BRNRAT = 2	RateC
Integer BARPERCENT (4)	array of 4 elements specifying percent overloads at which to apply different color schemes for the line loading charts on the Diagram(input).	
	BARPERCENT(1)	first overload voltage point
	BARPERCENT(2)	second overload voltage point
	BARPERCENT(3)	third overload voltage point
	BARPERCENT(4)	fourth overload voltage point
Integer BARCLRR (4)	array of 4 elements specifying the Red color component for the line loading charts on the Diagram, 0->255(input).	
	BARCLRR(1)	first line loading chart red value
	BARCLRR(2)	second line loading chart red value
	BARCLRR(3)	third line loading chart red value
	BARCLRR(4)	fourth line loading chart red value
Integer BARCLRG (4)	array of 4 elements specifying the Green color component for the line loading charts on the Diagram, 0->255(input).	
	BARCLRG(1)	first line loading chart green value

	BARCLRG(2)	second line loading chart green value
	BARCLRG(3)	third line loading chart green value
	BARCLRG(4)	fourth line loading chart green value
Integer BARCLRB (4)	array of 4 elements specifying the Blue color component for the line loading charts on the Diagram, 0->255(input).	
	BARCLRB(1)	first line loading chart blue value
	BARCLRB(2)	second line loading chart blue value
	BARCLRB(3)	third line loading chart blue value
	BARCLRB(4)	fourth line loading chart blue value

9.62. SETDIAGRESPFLOWCHECK_3

Use this API to specify the Power Flow voltage and range checking annotation options in the active Slider Diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESPFLOWCHECK_3  SETSCOPE LOGARR(1)..LOGARR(2) LINLOD
  LLODARR(1)..LLODARR(2) LLODCLR(1)..LLODCLR(3) BUSVLT(1)..BUSVLT(2)
  BUSVLTWDT(1)..BUSVLTWDT(2) BUSCLRR(1)..BUSCLRR(2) BUSCLRG(1)..BUSCLRG(2)
  BUSCLRB(1)..BUSCLRB(2) BRNRAT BARPERCENT(1)..BARPERCENT(4)
  BARCLRR(1)..BARCLRR(4) BARCLRG(1)..BARCLRG(4) BARCLRB(1)..BARCLRB(4)
  TBARCHRT
```

Python command syntax:

```
setdiagrespflowcheck_3(setscope, logarr, linlod, lloadarr, lloadclr, busvlt,
  busvltwdt, busclrr, busclrg, busclrb, brnrat, barpercent, barclrr,
  barclrg, barclrb, tbarchrt)
```

Fortran command syntax:

```
CALL SETDIAGRESPFLOWCHECK_3(SETSCOPE, LOGARR, LINLOD, LLODARR, LLODCLR,
  BUSVLT, BUSVLTWDT, BUSCLRR, BUSCLRG, BUSCLRB, BRNRAT, BARPERCENT,
  BARCLRR, BARCLRG, BARCLRB, TBARCHRT)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 dettings for the active diagram
Integer LOGARR (2)	array of 2 elements specifying flag to determine what annotation is applied. Each element has only two possible values. 0 = FALSE and 1 = TRUE(input).
	LOGARR(1) use Line ratings
	LOGARR(2) use Bus voltage
Real LINLOD	% loading for line rating (input).
Integer LLODARR (2)	array of 2 elements specifying the width and style of Diagram items that exceed the % of line loading(input).
	LLODARR(1) Line width >= 1
	LLODARR(2) Line style
Integer LLODCLR (3)	array of 3 elements specifying color for lines that exceed the % load-ing rating, LINLOD(input).
	LLODCLR(1) 0->255 Red component
	LLODCLR(2) 0->255 Blue component
	LLODCLR(3) 0->255 Green component

Real BUSVLT (2)	array of 2 elements specifying the bus voltage check Min and Max(input). BUSVLT(1) Min. bus voltage BUSVLT(2) Max. bus voltage
Integer BUSVLTWDT (2)	array of 2 elements specifying the bus voltage check width of diagram items at the Min and Max(input). BUSVLTWDT(1) Min. bus voltage width >= 1 BUSVLTWDT(2) Max. bus voltage width >= 1
Integer BUSCLRR (2)	array of 2 elements specifying the Red color component of Diagram elements that fall in the appropriate bus voltage range, 0->255(input). BUSCLRR(1) base voltage < BUSVLTWDT(1) BUSCLRR(2) BUSVLTWDT(1) >= base voltage < BUSVLTWDT (2)
Integer BUSCLRG (2)	array of 2 elements specifying the Green color component of Diagram elements that fall in the appropriate bus voltage range, 0->255(input). BUSCLRG(1) base voltage < BUSVLTWDT (1) BUSCLRG(2) BUSVLTWDT (1) >= base voltage < BUSVLTWDT (2)
Integer BUSCLRB (2)	array of 2 elements specifying the Blue color component of Diagram elements that fall in the appropriate bus voltage range, 0->255(input). BUSCLRB(1) base voltage < BUSVLTWDT (1) BUSCLRB(2) BUSVLTWDT(1) >= base voltage < BUSVLTWDT (2)
Integer BRNRAT	branch rating set (input). BRNRAT = 0 RateA BRNRAT = 1 RateB BRNRAT = 2 RateC
Integer BARPERCENT (4)	array of 4 elements specifying percent overloads at which to apply different color schemes for the line loading charts on the Diagram(input). BARPERCENT(1) first overload voltage point BARPERCENT(2) second overload voltage point BARPERCENT(3) third overload voltage point BARPERCENT(4) fourth overload voltage point
Integer BARCLRR (4)	array of 4 elements specifying the Red color component for the line loading charts on the Diagram, 0->255(input). BARCLRR(1) first line loading chart red value BARCLRR(2) second line loading chart red value BARCLRR(3) third line loading chart red value BARCLRR(4) fourth line loading chart red value

Integer BARCLRG (4)	array of 4 elements specifying the Green color component for the line loading charts on the Diagram, 0->255(input). BARCLRG(1) first line loading chart green value BARCLRG(2) second line loading chart green value BARCLRG(3) third line loading chart green value BARCLRG(4) fourth line loading chart green value
Integer BARCLRB (4)	array of 4 elements specifying the Blue color component for the line loading charts on the Diagram, 0->255(input). BARCLRB(1) first line loading chart blue value BARCLRB(2) second line loading chart blue value BARCLRB(3) third line loading chart blue value BARCLRB(4) fourth line loading chart blue value
Integer TBARCHRT	toggle for the display of the line loading bar charts (input).

9.63. SETDIAGRESPFLOWOPTIONS

This API routine is obsolete. It has been replaced by the API routine [setdiagrespflowoptions_2](#).

Use this API to specify the basic Power Flow annotation options in the active Slider diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESPFLOWOPTIONS BRNANN FLWOPT BUSANN BUSVLT EQPANN DIAGTTL
PMVALINE PMVATRAN USEPGMSET
```

Python command syntax:

```
setdiagrespflowoptions(brnann, flwopt, busann, busvlt, eqpann, diagttl,
pmvaline, pmvatran, usepgmset)
```

Fortran command syntax:

```
CALL SETDIAGRESPFLOWOPTIONS(BRNANN, FLWOPT, BUSANN, BUSVLT, EQPANN,
DIAGTTL, PMVALINE, PMVATRAN, USEPGMSET)
```

Where:

Integer BRNANN	branch annotation (input).
	BRNANN = 0 MW/MVAR flows
	BRNANN = 1 MVA
	BRNANN = 2 MVA/% rating
	BRNANN = 3 Amps/pu current
	BRNANN = 4 MW/%rating
	BRNANN = 5 Amps/% rating
	BRNANN = 6 None
Integer FLWOPT	flow direction (input).
	FLWOPT = 0 arrows
	FLWOPT = 1 signs
Integer BUSANN	bus ID annotation (input).
	BUSANN = 0 number, no name
	BUSANN = 1 name, no number
	BUSANN = 2 number and name
	BUSANN = 3 no number, no name
Integer BUSVLT	bus voltage annotation (input).
	BUSVLT = 0 magnitude (pu)
	BUSVLT = 1 magnitude (kV)
	BUSVLT = 2 angle (degrees)
	BUSVLT = 3 magnitude (pu) and angle (degrees)
	BUSVLT = 4 magnitude (pu) and magnitude (kV)
	BUSVLT = 5 magnitude (kV) and angle (degrees)

	BUSVLT = 7	magnitude (pu), magnitude (kV) and angle (degrees)
	BUSVLT = 8	none
Integer EQPANN	equipment annotation (input).	
	EQPANN = 0	MW/MVAR
	EQPANN = 1	MVA
	EQPANN = 2	none
Character*260 DIAGTTL	diagram title (input).	
Integer PMVALINE	loading basis for % loading on non-transformer branches (input).	
	PMVALINE = 0	current loading
	PMVALINE = 1	MVA loading
Integer PMVATRAN	loading basis for % loading on transformer branches (input).	
	PMVATRAN = 0	current loading
	PMVATRAN = 1	MVA loading
Integer USEPGMSET	flag for system or diagram settings for displaying MVATrans and MVA-Line values (input).	
	USEPGMSET = 0	use diagram settings
	USEPGMSET = 1	use System settings

9.64. SETDIAGRESPFLOWOPTIONS_2

This API routine is obsolete. It has been replaced by the API routine [setdiagrespflowoptions_3](#).

Use this API to specify the basic Power Flow annotation options in the active Slider diagram.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SETDIAGRESPFLOWOPTIONS_2 BRNANN FLWOPT BUSVLT PMVALINE PMVATRAN
USEPGMSET DIAGTTL
```

Python command syntax:

```
setdiagrespflowoptions_2(brnann, flwopt, busvlt, pmvaline, pmvatran,
usepgmset, diagttl)
```

Fortran command syntax:

```
CALL SETDIAGRESPFLOWOPTIONS_2(BRNANN, FLWOPT, BUSVLT, PMVALINE, PMVATRAN,
USEPGMSET, DIAGTTL)
```

Where:

Integer BRNANN	branch annotation (input).
	BRNANN = 0 MW/MVAR flows
	BRNANN = 1 MVA
	BRNANN = 2 MVA/% rating
	BRNANN = 3 Amps/pu current
	BRNANN = 4 MW/%rating
	BRNANN = 5 Amps/% rating
	BRNANN = 6 None
Integer FLWOPT	flow direction (input).
	FLWOPT = 0 arrows
	FLWOPT = 1 signs
Integer BUSVLT	bus voltage annotation (input).
	BUSVLT = 0 magnitude (pu)
	BUSVLT = 1 magnitude (kV)
	BUSVLT = 2 angle (degrees)
	BUSVLT = 3 magnitude (pu) and angle (degrees)
	BUSVLT = 4 magnitude (pu) and magnitude (kV)
	BUSVLT = 5 magnitude (kV) and angle (degrees)
	BUSVLT = 7 magnitude (pu), magnitude (kV) and angle (degrees)
	BUSVLT = 8 none
Integer PMVALINE	loading basis for % loading on non-transformer branches (input).
	PMVALINE = 0 current loading

Integer PMVATRAN	PMVALINE = 1	MVA loading
	loading basis for % loading on transformer branches (input).	
	PMVATRAN = 0	current loading
Integer USEPGMSET	PMVATRAN = 1	MVA loading
	flag for system or diagram settings for displaying MVATrans and MVA-Line values (input).	
	USEPGMSET = 0	use diagram settings
	USEPGMSET = 1	use System settings
Character*260 DIAGTTL	diagram title (input).	

9.65. SETDIAGRESPFLOWOPTIONS_3

Use this API to specify the basic Power Flow annotation options in the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESPFLOWOPTIONS_3 SETSCOPE BRNANN FLWOPT BUSVLT EQUIPANN
PMVALINE PMVATRAN USEPGMSET MSLOPT BUSIDANN BRNIDANN EQUIPIDANN
```

Python command syntax:

```
setdiagrespflowoptions_3(setscope, brnann, flwopt, busvlt, equipann,
    pmvaline, pmvatran, usepgmset, mslopt, busidann, brnidann, equipidann)
```

Fortran command syntax:

```
CALL SETDIAGRESPFLOWOPTIONS_3(SETSCOPE, BRNANN, FLWOPT, BUSVLT, EQUIPANN,
    PMVALINE, PMVATRAN, USEPGMSET, MSLOPT, BUSIDANN, BRNIDANN, EQUIPIDANN)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer BRNANN	branch annotation (input).
	BRNANN = 0 MW/MVAR flows
	BRNANN = 1 MVA
	BRNANN = 2 MVA/% rating
	BRNANN = 3 Amps/pu current
	BRNANN = 4 MW/%rating
	BRNANN = 5 Amps/% rating
	BRNANN = 6 none
Integer FLWOPT	flow direction (input).
	FLWOPT = 0 arrows
	FLWOPT = 1 signs
Integer BUSVLT	bus voltage annotation (input).
	BUSVLT = 0 magnitude (pu)
	BUSVLT = 1 magnitude (kV)
	BUSVLT = 2 angle (degrees)
	BUSVLT = 3 magnitude (pu) and angle (degrees)
	BUSVLT = 4 magnitude (pu) and magnitude (kV)
	BUSVLT = 5 magnitude (kV) and angle (degrees)
	BUSVLT = 7 magnitude (pu), magnitude (kV) and angle (degrees)

	BUSVLT = 8	none
Integer EQIPANN	equipment annotation (input).	
	EQIPANN = 1	MW/Mvar
	EQIPANN = 2	MVA
	EQIPANN = 3	Mvar
	EQIPANN = 4	None
Integer PMVALINE	loading basis for % loading on non-transformer branches (input).	
	PMVALINE = 0	current loading
	PMVALINE = 1	MVA loading
Integer PMVATRAN	loading basis for % loading on transformer branches (input).	
	PMVATRAN = 0	current loading
	PMVATRAN = 1	MVA loading
Integer USEPGMSET	flag for system or diagram settings for displaying MVATrans and MVA-Line values (input).	
	USEPGMSET = 0	use diagram settings
	USEPGMSET = 1	use System settings
Integer MSLOPT	multi-section line (MSL) option (input).	
	MSLOPT = 0	MSL are not displayed
	MSLOPT = 1	MSL are displayed
Integer BUSIDANN	bus id annotation (input).	
	BUSIDANN = 0	magnitude (pu)
	BUSIDANN = 1	magnitude (kV)
	BUSIDANN = 2	angle (degrees)
	BUSIDANN = 3	magnitude (pu) and angle (degrees)
	BUSIDANN = 4	magnitude (pu) and magnitude (kV)
	BUSIDANN = 5	magnitude (kV) and angle (degrees)
	BUSIDANN = 7	magnitude (pu), magnitude (kV) and angle (de-grees)
	BUSIDANN = 8	none
Integer BRNIDANN	branch id annotation (input).	
	BRNIDANN = 0	MW/MVAR flows
	BRNIDANN = 1	MVA
	BRNIDANN = 2	MVA/% rating
	BRNIDANN = 3	Amps/pu current
	BRNIDANN = 4	MW/%rating
	BRNIDANN = 5	Amps/% rating
	BRNIDANN = 6	none
Integer EQUIPIDANN	equipment id annotation (input).	
	EQUIPIDANN = 0	MW/Mvar
	EQUIPIDANN = 2	none

9.66. SETDIAGRESREL

This API routine is obsolete. It has been replaced by the API routine [setdiagresrel_2](#).

Use this API to specify the reliability annotation options in the active Slider diagram.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETDIAGRESREL  OUTMODE MODE BUSMODE CNTBUS CNTBRN DETBUS DETBRN PRBBUS
PRBBRN VOLTREC CNTLABEL CNTLIST
```

Python command syntax:

```
setdiagresrel(outmode, mode, busmode, cntbus, cntbrn, detbus, detbrn,
prbbus, prbbnr, voltrec, cntlabel, cntlist)
```

Fortran command syntax:

```
CALL SETDIAGRESREL(OUTMODE, MODE, BUSMODE, CNTBUS, CNTBRN, DETBUS, DETBRN,
PRBBUS, PRBBNR, VOLTREC, CNTLABEL, CNTLIST)
```

Where:

Integer OUTMODE	mode of results displayed (input). OUTMODE = 1 post contingency stage OUTMODE = 2 post tripping stage OUTMODE = 3 post corrective actions stage
Integer MODE	type of reliability results displayed (input). MODE = 0 contingency analysis results MODE = 1 deterministic reliability results MODE = 2 probabilistic reliability results
Integer BUSMODE	mode of bus reporting (input). BUSMODE = 0 bus voltage violations BUSMODE = 1 bus load curtailments
Integer CNTBUS	If MODE = 0, is the option to specify whether Bus voltage is displayed (input). CNTBUS = 0 don't display Bus voltage CNTBUS = 1 display Bus voltage
Integer CNTBRN	If MODE = 0, is the option to specify whether Branch flow loading is displayed (input). CNTBRN = 0 don't display Branch flow loading CNTBRN = 1 display MVA loading CNTBRN = 2 display Percent (%) CNTBRN = 3 display both MVA and Percent (%)
Integer DETBUS	If MODE = 1, is the option to specify which bus voltage violations are displayed. Non-zero values may be summed (input).

	DETBUS = 0	don't display bus voltage violations
	DETBUS = 1	# of contingencies resulting in violations
	DETBUS = 2	contingency with maximum violation
	DETBUS = 4	average violations (AV)
	DETBUS = 8	maximum violation (MV)
Integer DETBRN	If MODE = 1, is the option to specify which branch flow overloading violations are displayed (input).	
	DETBRN = 0	don't display bus voltage violations
	DETBRN = 1	# of contingencies resulting in violations
	DETBRN = 2	Contingency with maximum loading
	DETBRN = 4	available capacity (AC)
	DETBRN = 6	maximum loading % (ML)
	DETBRN = 8	average violations (AV)
Integer PRBBUS	If MODE = 2, is the option to specify which bus voltage violations are displayed (input).	
	PRBBUS = 0	don't display bus voltage violations
	PRBBUS = 1	frequency (OC/Y)
	PRBBUS = 2	impact (VI)
	PRBBUS = 4	probability (H/Y)
	PRBBUS = 8	expected energy curtailed
Integer PRBBRN	If MODE = 2, is the option to specify which branch flow overloading violations are displayed (input).	
	PRBBRN = 0	don't display bus voltage violations
	PRBBRN = 1	frequency (OC/Y)s
	PRBBRN = 2	impact (FI)
	PRBBRN = 4	probability (H/Y)
Integer VOLTREC	index into the voltage limit record array for the current DFAX file (input).	
Character*32 CNTLABEL	contingency to display results for (input).	
Integer CNTLIST	what contingencies are listed for selection (input).	
	CNTLIST = 1	all contingencies are listed
	CNTLIST = 2	only those contingencies that cause overloading violations are listed
	CNTLIST = 3	only those contingencies that cause violations are listed

9.67. SETDIAGRESREL_2

This API routine is obsolete. It has been replaced by the API routine [setdiagresrel_3](#).

Use this API to specify the reliability annotation options in the active Slider diagram.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SETDIAGRESREL_2 OUTMODE RELMODE BUSMODE BUSDETANN BRNDDETANN BUSPRBANN
BRNPRBANN VOLTREC
```

Python command syntax:

```
setdiagresrel_2(outmode, relmode, busmode, busdetann, brndetann,
busprbann, brnprbann, voltrec)
```

Fortran command syntax:

```
CALL SETDIAGRESREL_2(OUTMODE, RELMODE, BUSMODE, BUSDETANN, BRNDDETANN,
BUSPRBANN, BRNPRBANN, VOLTREC)
```

Where:

Integer OUTMODE	mode of results displayed (input). OUTMODE = 1 post contingency stage OUTMODE = 2 post tripping stage OUTMODE = 3 post corrective actions stage
Integer RELMODE	type of reliability results displayed (input). RELMODE = 0 deterministic reliability results RELMODE = 1 probabilistic reliability results
Integer BUSMODE	mode of bus reporting (input). BUSMODE = 0 bus voltage violations BUSMODE = 1 bus load curtailments
Integer BUSDETANN	If MODE = 1, is the option to specify which bus voltage violations are displayed (input). BUSDETANN = 0 don't display Bus voltage violations BUSDETANN = # of contingencies resulting in violations BUSDETANN + 1 BUSDETANN = contingency with maximum violations BUSDETANN + 2 BUSDETANN = average violations (AV) BUSDETANN + 4 BUSDETANN = maximum violations (MV) BUSDETANN + 8
Integer BRNDDETANN	If MODE = 1, is the option to specify which branch flow overloading violations are displayed (input).

	BRNDETANN = 0	don't display branch flow violations
	BRNDETANN = BRN- DETANN + 1	# of contingencies resulting in violations
	BRNDETANN = BRN- DETANN + 2	contingency with maximum loading
	BRNDETANN = BRN- DETANN + 4	available capacity (AC)
	BRNDETANN = BRN- DETANN + 8	average violations (AV)
	BRNDETANN = BRN- DETANN + 16	maximum loading % (ML)
Integer BUSPRBANN	If MODE = 2, is the option to specify which bus voltage violations are displayed (input).	
	BUSPRBANN = 0	don't display Bus voltage violations
	BUSPRBANN = BUSPRBANN + 1	frequency (OC/Y)
	BUSPRBANN = BUSPRBANN + 2	impact (VI)
	BUSPRBANN = BUSPRBANN + 4	probability (H/Y)
	BUSPRBANN = BUSPRBANN + 8	expected energy curtailed
Integer BRNPRBANN	If MODE = 2, is the option to specify which branch flow overloading violations are displayed (input).	
	BRNPRBANN = 0	don't display branch flow violations
	BRNPRBANN = BRN- PRBANN + 1	Ffrequency (OC/Y)
	BRNPRBANN = BRN- PRBANN + 2	impact (VI)
	BRNPRBANN = BRN- PRBANN + 4	probability (H/Y)
Integer VOLTREC	index into the voltage limit record array for the current DFAX file (input).	

9.68. SETDIAGRESREL_3

Use this API to specify the reliability annotation options in the active Slider diagram.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SETDIAGRESREL_3  SETSCOPE OUTMODE RELMODE BUSMODE BUSDETANN BRNDETANN
  BUSPRBANN BRNPRBANN VOLTREC
```

Python command syntax:

```
setdiagresrel_3(setscope, outmode, relmode, busmode, busdetann, brndetann,
  busprbann, brnprbann, voltrec)
```

Fortran command syntax:

```
CALL SETDIAGRESREL_3(SETSCOPE, OUTMODE, RELMODE, BUSMODE, BUSDETANN,
  BRNDETANN, BUSPRBANN, BRNPRBANN, VOLTREC)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer OUTMODE	mode of results displayed (input).
	OUTMODE = 1 post contingency stage
	OUTMODE = 2 post tripping stage
	OUTMODE = 3 post corrective actions stage
Integer RELMODE	type of reliability results displayed (input).
	RELMODE = 0 deterministic reliability results
	RELMODE = 1 probabilistic reliability results
Integer BUSMODE	mode of bus reporting (input).
	BUSMODE = 0 bus voltage violations
	BUSMODE = 1 bus load curtailments
Integer BUSDETANN	If MODE = 1, is the option to specify which bus voltage violations are displayed (input).
	BUSDETANN = 0 don't display Bus voltage violations
	BUSDETANN = # of contingencies resulting in violations
	BUSDETANN + 1 contingency with maximum violations
	BUSDETANN + 2 average violations (AV)
	BUSDETANN + 4 maximum violations (MV)
	BUSDETANN + 8

Integer BRNDETANN	If MODE = 1, is the option to specify which branch flow overloading violations are displayed (input). BRNDETANN = 0 don't display branch flow violations BRNDETANN = BRN-DETANN + 1 # of contingencies resulting in violations BRNDETANN = BRN-DETANN + 2 contingency with maximum loading BRNDETANN = BRN-DETANN + 4 available capacity (AC) BRNDETANN = BRN-DETANN + 8 average violations (AV) BRNDETANN = BRN-DETANN + 16 maximum loading % (ML)
Integer BUSPRBANN	If MODE = 2, is the option to specify which bus voltage violations are displayed (input). BUSPRBANN = 0 don't display Bus voltage violations BUSPRBANN = BUSPRBANN + 1 frequency (OC/Y) BUSPRBANN = BUSPRBANN + 2 impact (VI) BUSPRBANN = BUSPRBANN + 4 probability (H/Y) BUSPRBANN = BUSPRBANN + 8 expected energy curtailed
Integer BRNPRBANN	If MODE = 2, is the option to specify which branch flow overloading violations are displayed (input). BRNPRBANN = 0 don't display branch flow violations BRNPRBANN = BRN-PRBANN + 1 frequency (OC/Y) BRNPRBANN = BRN-PRBANN + 2 impact (VI) BRNPRBANN = BRN-PRBANN + 4 probability (H/Y)
Integer VOLTREC	index into the voltage limit record array for the current DFAX file (input).

9.69. SETDIAGRESSCGR

Use this API to specify the short circuit analysis voltage and range checking annotation options in the active Slider diagram.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESSCGR  USEVLT VLNWDT(1)..VLNWD(8) VLNSTY(1)..VLNSTY(8)
  VLTVAL(1)..VLTVAL(7) VLNCLRR(1)..VLNCLRR(8) VLNCLRG(1)..VLNCLRG(8)
  VLNCLRB(1)..VLNCLRB(8) OUTWDT OUTSTY OUTCLR(1)..OUTCLR(3) FLTWDT FLTSTY
  FLTCLR(1)..FLTCLR(3) BUSANN
```

Python command syntax:

```
setdiagresscgr(usevlt, vlnwdt, vlnsty, vltval, vlnclrr, vlnclrg, vlnclrb,
  outwdt, outsty, outclr, fltwdt, fltsty, fltclr, busann)
```

Fortran command syntax:

```
CALL SETDIAGRESSCGR(USEVLT, VLNWDT, VLNSTY, VLTVAL, VLNCLRR, VLNCLRG,
  VLNCLRB, OUTWDT, OUTSTY, OUTCLR, FLTWDT, FLTSTY, FLTCLR, BUSANN)
```

Where:

Integer USEVLT	flag to apply voltage level annotation to the diagram elements (input).
	USEVLT = 0 don't apply voltage level annotation
	USEVLT = 1 apply voltage level annotation
Integer VLNWDT (8)	array of 8 elements specifying width of diagram elements that fall in the appropriate voltage range(input).
	VLNWD(1) base voltage < VLTVAL(1)
	VLNWD(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNWD(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNWD(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNWD(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNWD(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNWD(7) VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNWD(8) base voltage >= VLTVAL(7)
Integer VLNSTY (8)	array of 8 elements specifying line style of diagram elements that fall in the appropriate voltage range(input).
	VLNSTY(1) base voltage < VLTVAL(1)
	VLNSTY(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNSTY(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNSTY(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNSTY(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNSTY(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNSTY(7) VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNSTY(8) base voltage >= VLTVAL(7)

Real VLTVAL (7)	voltage ranges used to assign annotation diagram. Base voltage values should be in ascending order (input).
Integer VLNCLRR (8)	array of 8 elements specifying set the Red color component of diagram elements that fall in the appropriate voltage range, 0->255(input). VLNCLRR(1) base voltage < VLTVAL(1) VLNCLRR(2) VLTVAL(1) >= base voltage < VLTVAL(2) VLNCLRR(3) VLTVAL(2) >= base voltage < VLTVAL(3) VLNCLRR(4) VLTVAL(3) >= base voltage < VLTVAL(4) VLNCLRR(5) VLTVAL(4) >= base voltage < VLTVAL(5) VLNCLRR(6) VLTVAL(5) >= base voltage < VLTVAL(6) VLNCLRR(7) VLTVAL(6) >= base voltage < VLTVAL(7) VLNCLRR(8) base voltage >= VLTVAL(7)
Integer VLNCLRG (8)	array of 8 elements specifying set Green color component of diagram elements that fall in the appropriate voltage range, 0->255(input). VLNCLRG(1) base voltage < VLTVAL(1) VLNCLRG(2) VLTVAL(1) >= base voltage < VLTVAL(2) VLNCLRG(3) VLTVAL(2) >= base voltage < VLTVAL(3) VLNCLRG(4) VLTVAL(3) >= base voltage < VLTVAL(4) VLNCLRG(5) VLTVAL(4) >= base voltage < VLTVAL(5) VLNCLRG(6) VLTVAL(5) >= base voltage < VLTVAL(6) VLNCLRG(7) VLTVAL(6) >= base voltage < VLTVAL(7) VLNCLRG(8) base voltage >= VLTVAL(7)
Integer VLNCLRB (8)	array of 8 elements specifying set Blue color component of diagram elements that fall in the appropriate voltage range, 0->255(input). VLNCLRB(1) base voltage < VLTVAL(1) VLNCLRB(2) VLTVAL(1) >= base voltage < VLTVAL(2) VLNCLRB(3) VLTVAL(2) >= base voltage < VLTVAL(3) VLNCLRB(4) VLTVAL(3) >= base voltage < VLTVAL(4) VLNCLRB(5) VLTVAL(4) >= base voltage < VLTVAL(5) VLNCLRB(6) VLTVAL(5) >= base voltage < VLTVAL(6) VLNCLRB(7) VLTVAL(6) >= base voltage < VLTVAL(7) VLNCLRB(8) base voltage >= VLTVAL(7)
Integer OUTWDT	line width applied to out of service diagram items, >= 1 (input).
Integer OUTSTY	line style applied to out of service diagram items (input).
Integer OUTCLR (3)	array of 3 elements specifying color for diagram items that are out of service(input). OUTCLR(1) 0->255 Red component OUTCLR(2) 0->255 Blue component OUTCLR(3) 0->255 Green component
Integer FLTWDT	line width applied to the faulted bus diagram item, >= 1 (input).
Integer FLTSTY	line style applied to the faulted bus diagram item (input).

Integer FLTCLR (3)	array of 3 elements specifying color for Diagram items that are out of service(input).	
	FLTCLR(1)	0->255 Red component
	FLTCLR(2)	0->255 Blue component
	FLTCLR(3)	0->255 Green component
Integer BUSANN	bus ID annotation (input).	
	BUSANN = 0	number, no name
	BUSANN = 1	name, no number
	BUSANN = 2	number and name
	BUSANN = 3	no number, no name

9.70. SETDIAGRESTYPEACC

Use this API to set the type of results displayed in the active Slider diagram to ACCC results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 33.1.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEACC
```

Python command syntax:

```
setdiagrestypeacc()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEACC
```

9.71. SETDIAGRESTYPEASCC

Use this API to set the type of results displayed in the active Slider diagram to ASCC fault calculation results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEASCC
```

Python command syntax:

```
setdiagrestypeascc()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEASCC
```

9.72. SETDIAGRESTYPEDATA

Use this API to set the type of results displayed in the active Slider diagram to impedance data values. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEDATA
```

Python command syntax:

```
setdiagrestypedata()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEDATA
```

9.73. SETDIAGRESTYPEDYN

Use this API to set the type of results displayed in the active Slider diagram to Dynamics data results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEDYN
```

Python command syntax:

```
setdiagrestypedyn()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEDYN
```

9.74. SETDIAGRESTYPEGDIF

Use this API to set the type of results displayed in the active Slider diagram to the differences in values between the current network case and a supplied comparison case.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEGDIF  NAMEARG  SFILE
```

Python command syntax:

```
setdiagrestypegdif(namearg, sfile)
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEGDIF(NAMEARG, SFILE)
```

Where:

Integer NAMEARG	flag indicating how to match up buses in the two cases (input).
	NameArg = 0 by bus number only
	NameArg = 1 by extended bus name only
	NameArg = 2 by both number and name.
Character*260 SFILE	name of an existing Saved case to compare the current case against (input).

9.75. SETDIAGRESTYPEGIC

Use this API to set the type of results displayed in the active Slider diagram to GIC solution results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 32.2.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEGIC
```

Python command syntax:

```
setdiagrestypegic()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEGIC
```

9.76. SETDIAGRESTYPEHARM

Use this API to set the type of results displayed in the active Slider diagram to Harmonics solution results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPHARM
```

Python command syntax:

```
setdiagrestypeharm()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEHARM
```

9.77. SETDIAGRESTYPEIEC

Use this API to set the type of results displayed in the active Slider diagram to IEC Fault calculation results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEIEC
```

Python command syntax:

```
setdiagrestypeiec()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEIEC
```

9.78. SETDIAGRESTYPEMUST

Use this API to set the type of results displayed in the active Slider diagram to MUST solution results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEMUST
```

Python command syntax:

```
setdiagrestypemust()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEMUST
```

9.79. SETDIAGRESTYPEOPF

Use this API to set the type of results displayed in the active Slider diagram to OPF solution results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEOPF
```

Python command syntax:

```
setdiagrestypeopf()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEOPF
```

9.80. SETDIAGRESTYPEPFLOW

Use this API to set the type of results displayed in the active Slider diagram to Power Flow results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEPFLOW
```

Python command syntax:

```
setdiagrestypepflow()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEPFLOW
```

9.81. SETDIAGRESTYPEREL

Use this API to set the type of results displayed in the active Slider diagram to reliability analysis results. Requires that current network elements are being displayed in the diagram view.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPEREL
```

Python command syntax:

```
setdiagrestyperel()
```

Fortran command syntax:

```
CALL SETDIAGRESTYPEREL
```

9.82. SETDIAGRESTYPESCGR

Use this API to set the type of results displayed in the active Slider diagram to the results of a short circuit analysis.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETDIAGRESTYPESCGR  OPTIONS(1) .. OPTIONS(8)
```

Python command syntax:

```
setdiagrestypescgr(options)
```

Fortran command syntax:

```
CALL SETDIAGRESTYPESCGR(OPTIONS)
```

Where:

Integer OPTIONS (8)	array of 8 elements specifying analysis options(input).
OPTIONS(1)	faults
OPTIONS(1) = 0	3 phase
OPTIONS(1) = 1	3 phase and L-G
OPTIONS(2)	L-G fault
OPTIONS(2) = 0	A phase
OPTIONS(2) = 1	zero sequence
OPTIONS(3)	fault location
OPTIONS(3) = 0	all
OPTIONS(3) > 0	faulted bus number
OPTIONS(4)	flat conditions
OPTIONS(4) = 0	no
OPTIONS(4) = 1	yes
OPTIONS(5)	double precision
OPTIONS(5) = 0	no
OPTIONS(5) = 1	yes (ignored)
OPTIONS(6)	dc line/FACTS device option
OPTIONS(6) = 0	block
OPTIONS(6) = 1	model as load
OPTIONS(7)	zero sequence transformer impedance correction option
OPTIONS(7) = 0	ignore
OPTIONS(7) = 1	apply
OPTIONS(8)	branch quantity option
OPTIONS(8) = 0	currents
OPTIONS(8) = 1	apparent impedances

9.83. SETDIAGRESVRCS

This API routine is obsolete. It has been replaced by the API routine [setdiagresvrCS_2](#).

Use this API to specify the system diagram defaults for Voltage coloring and style, Out of Service coloring and style etc.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SETDIAGRESVRCS  BUSANN EQPANN USEVCLR VLNWDT(1)..VLNWDT(8)
VLNSTY(1)..VLNSTY(8) VLTVAL(1)..VLTVAL(7) VLNCLRR(1)..VLNCLRR(8)
VLNCLRG(1)..VLNCLRG(8) VLNCLRB(1)..VLNCLRB(8) USEOOSCLR OOSWDT OOSSTY
OUTCLR(1)..OUTCLR(3) BNDCLR(1)..BNDCLR(3) UNBNDCLR(1)..UNBNDCLR(3)
TRANBARCHRT
```

Python command syntax:

```
setdiagresvrCS(busann, eqpann, usevclr, vlnwdt, vlnsty, vltval, vlnclrr,
vlnclrg, vlnclrb, useoosclr, ooswdt, oossty, outclr, bndclr, unbndclr,
tranbarchrt)
```

Fortran command syntax:

```
CALL SETDIAGRESVRCS(BUSANN, EQPANN, USEVCLR, VLNWDT, VLNSTY, VLTVAL,
VLNCLRR, VLNCLRG, VLNCLRB, USEOOSCLR, OOSWDT, OOSSTY, OUTCLR, BNDCLR,
UNBNDCLR, TRANBARCHRT)
```

Where:

Integer BUSANN	bus ID annotation (input).
	BUSANN = 0 number, no name
	BUSANN = 1 name, no number
	BUSANN = 2 number and name
	BUSANN = 3 no number, no name
Integer EQPANN	equipment annotation (input).
	EQPANN = 0 MW/MVAR
	EQPANN = 1 MVA
	EQPANN = 2 none
Integer USEVCLR	use voltage level coloring . The element has only two possible values. 0 = FALSE and 1 = TRUE (input).
Integer VLNWDT (8)	array of 8 elements specifying width of diagram elements that fall in the appropriate voltage range(input).
	VLNWDT(1) base voltage < VLTVAL(1)
	VLNWDT(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNWDT(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNWDT(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNWDT(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNWDT(6) VLTVAL(5) >= base voltage < VLTVAL(6)

	VLNWD(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNWD(8)	base voltage >= VLTVAL(7)
Integer VLNSTY (8)	array of 8 elements specifying line style of diagram elements that fall in the appropriate voltage range(input).	
	VLNSTY(1)	base voltage < VLTVAL(1)
	VLNSTY(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNSTY(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNSTY(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNSTY(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNSTY(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNSTY(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNSTY(8)	base voltage >= VLTVAL(7)
Real VLTVAL (7)	voltage ranges used to assign annotation diagram. Base voltage values should be in ascending order (input).	
Integer VLNCLRR (8)	array of 8 elements specifying the Red color component of diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRR(1)	base voltage < VLTVAL(1)
	VLNCLRR(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRR(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRR(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRR(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRR(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRR(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRR(8)	base voltage >= VLTVAL(7)
Integer VLNCLRG (8)	array of 8 elements specifying the Green color component of diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRG(1)	base voltage < VLTVAL(1)
	VLNCLRG(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRG(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRG(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRG(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRG(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRG(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRG(8)	base voltage >= VLTVAL(7)
Integer VLNCLRB (8)	array of 8 elements specifying the Blue color component of diagram elements that fall in the appropriate voltage range, 0->255(input).	
	VLNCLRB(1)	base voltage < VLTVAL(1)
	VLNCLRB(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRB(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRB(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRB(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRB(6)	VLTVAL(5) >= base voltage < VLTVAL(6)

	VLNCLRB(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRB(8)	base voltage >= VLTVAL(7)
Integer USEOOSCLR	Out-of-Service coloring. The element has only two possible values. 0 = FALSE and 1 = TRUE (input).	
Integer OOSWDT	width of diagram items that are out of service. OOSWDT Line width >= 1 (input).	
Integer OOSSTY	line style of diagram items that are out of service. OOSSTY Line style (input).	
Integer OUTCLR (3)	array of 3 elements specifying color for diagram items that are out of service(input).	
	OUTCLR(1)	0->255 Red component
	OUTCLR(2)	0->255 Blue component
	OUTCLR(3)	0->255 Green component
Integer BNDCLR (3)	array of 3 elements specifying bound item color(input).	
	BNDCLR(1)	0->255 Red component
	BNDCLR(2)	0->255 Blue component
	BNDCLR(3)	0->255 Green component
Integer UNBNDCLR (3)	array of 3 elements specifying unbound item color(input).	
	UNBNDCLR(1)	0->255 Red component
	UNBNDCLR(2)	0->255 Blue component
	UNBNDCLR(3)	0->255 Green component
Integer TRANBARCHRT	two-winding transformer bar chart display side. TRANBARCHRT = 0 High current loading side (input).	
	TRANBARCHRT = 1	low current loading side
	TRANBARCHRT = 2	both sides

9.84. SETDIAGRESVRCS_2

Use this API to specify the system diagram defaults for Voltage coloring and style, Out of Service coloring and style etc.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGRESVRCS_2  SETSCOPE USEVOLT VLNWDT(1)..VLNWDT(8)
VLNSTY(1)..VLNSTY(8) VLTVAL(1)..VLTVAL(7) VLNCLRR(1)..VLNCLRR(8)
VLNCLRG(1)..VLNCLRG(8) VLNCLRB(1)..VLNCLRB(8) USEOOSCLR OOSWDT OOSSTY
OUTCLR(1)..OUTCLR(3) BNDCLR(1)..BNDCLR(3) UNBNDCLR(1)..UNBNDCLR(3)
BRKOPNCLR(1)..BRKOPNCLR(3) BRKCLSCLR(1)..BRKCLSCLR(3) USEVOLTLAY
HIDEUNBND FLTBUSWIDTH FLTBUSSTYLE FLTBUSCLR(1)..FLTBUSCLR(3)
```

Python command syntax:

```
setdiagresvrCS_2(setscope, usevolt, vlnwdt, vlnsty, vltval, vlnclrr,
vlnclrg, vlnclrb, useoosclr, ooswdt, oossty, outclr, bndclr, unbndclr,
brkopnclr, brkclsclr, usevoltlay, hideunbnd, fltbuswidth, fltbusstyle,
fltbusclr)
```

Fortran command syntax:

```
CALL SETDIAGRESVRCS_2(SETSCOPE, USEVOLT, VLNWDT, VLNSTY, VLTVAL, VLNCLRR,
VLNCLRG, VLNCLRB, USEOOSCLR, OOSWDT, OOSSTY, OUTCLR, BNDCLR, UNBNDCLR,
BRKOPNCLR, BRKCLSCLR, USEVOLTLAY, HIDEUNBND, FLTBUSWIDTH, FLTBUSSTYLE,
FLTBUSCLR)
```

Where:

Integer SETSCOPE	scope of the API (input).
	SETSCOPE = 0 defaults for new diagrams
	SETSCOPE = 1 defaults for new diagrams and settings for the active diagram
	SETSCOPE = 2 settings for the active diagram
Integer USEVOLT	voltage level coloring. The element has only two possible values. 0 = FALSE and 1 = TRUE (input).
Integer VLNWDT (8)	array of 8 elements specifying width of Diagram elements that fall in the appropriate voltage range(input).
	VLNWDT(1) base voltage < VLTVAL(1)
	VLNWDT(2) VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNWDT(3) VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNWDT(4) VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNWDT(5) VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNWDT(6) VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNWDT(7) VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNWDT(8) base voltage >= VLTVAL(7)
Integer VLNSTY (8)	array of 8 elements specifying line style of diagram elements that fall in the appropriate voltage range(input).

	VLNSTY(1)	base voltage < VLTVAL(1)
	VLNSTY(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNSTY(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNSTY(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNSTY(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNSTY(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNSTY(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNSTY(8)	base voltage >= VLTVAL(7)
Real VLTVAL (7)		voltage ranges used to assign annotation diagram. Base voltage values should be in ascending order (input).
Integer VLNCLRR (8)		array of 8 elements specifying the Red color component of diagram elements that fall in the appropriate voltage range, 0->255(input).
	VLNCLRR(1)	base voltage < VLTVAL(1)
	VLNCLRR(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRR(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRR(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRR(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRR(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRR(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRR(8)	base voltage >= VLTVAL(7)
Integer VLNCLRG (8)		array of 8 elements specifying the Green color component of diagram elements that fall in the appropriate voltage range, 0->255(input).
	VLNCLRG(1)	base voltage < VLTVAL(1)
	VLNCLRG(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRG(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRG(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRG(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRG(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRG(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRG(8)	base voltage >= VLTVAL(7)
Integer VLNCLRB (8)		array of 8 elements specifying the Blue color component of diagram elements that fall in the appropriate voltage range, 0->255(input).
	VLNCLRB(1)	base voltage < VLTVAL(1)
	VLNCLRB(2)	VLTVAL(1) >= base voltage < VLTVAL(2)
	VLNCLRB(3)	VLTVAL(2) >= base voltage < VLTVAL(3)
	VLNCLRB(4)	VLTVAL(3) >= base voltage < VLTVAL(4)
	VLNCLRB(5)	VLTVAL(4) >= base voltage < VLTVAL(5)
	VLNCLRB(6)	VLTVAL(5) >= base voltage < VLTVAL(6)
	VLNCLRB(7)	VLTVAL(6) >= base voltage < VLTVAL(7)
	VLNCLRB(8)	base voltage >= VLTVAL(7)
Integer USEOOSCLR		Out-of-Service coloring. The element has only two possible values. 0 = FALSE and 1 = TRUE (input).

Integer OOSWDT	width of diagram items that are out of service. OOSWDT Line width >= 1 (input).
Integer OOSSTY	line style of diagram items that are out of service. OOSSTY Line style (input).
Integer OUTCLR (3)	array of 3 elements specifying color of diagram items that are out of service(input). OUTCLR(1) 0->255 Red component OUTCLR(2) 0->255 Blue component OUTCLR(3) 0->255 Green component
Integer BNDCLR (3)	array of 3 elements specifying bound item color(input). BNDCLR(1) 0->255 Red component BNDCLR(2) 0->255 Blue component BNDCLR(3) 0->255 Green component
Integer UNBNDCLR (3)	array of 3 elements specifying unbound item color(input). UNBNDCLR(1) 0->255 Red component UNBNDCLR(2) 0->255 Blue component UNBNDCLR(3) 0->255 Green component
Integer BRKOPNCLR (3)	array of 3 elements specifying open breaker/switch item color(input). BRKOPNCLR(1) 0->255 Red component BRKOPNCLR(2) 0->255 Blue component BRKOPNCLR(3) 0->255 Green component
Integer BRKCLSCLR (3)	array of 3 elements specifying closed breaker/switch item color(input). BRKCLSCLR(1) 0->255 Red component BRKCLSCLR(2) 0->255 Blue component BRKCLSCLR(3) 0->255 Green component
Integer USEVOLTLAY	assign items to layers based on base kV (input). USEVOLTLAY = 0 don't assign to layer USEVOLTLAY = 1 assign to layer
Integer HIDEUNBND	not used (input).
Integer FLTBUSWIDTH	line width applied to the faulted bus item (input).
Integer FLTBUSSTYLE	line style applied to the faulted bus item (input).
Integer FLTBUSCLR (3)	array of 3 elements specifying faulted bus item color(input). FLTBUSCLR(1) 0->255 Red component FLTBUSCLR(2) 0->255 Blue component FLTBUSCLR(3) 0->255 Green component

9.85. SETDIAGTITLE

Use this API to set the title of the active Slider diagram.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_SETDIAGTITLE  DIAGTITLE
```

Python command syntax:

```
setdiagtitle(diagtitle)
```

Fortran command syntax:

```
CALL SETDIAGTITLE(DIAGTITLE)
```

Where:

Character*260 DIAGTITLE new title of the diagram (input).

9.86. SWITCHDIAGFILEDATASET

This API is used to rotate through values for the current element in the active data set on the active Slider diagram. Currently, this API is only used with ACCC results and is used for displaying the post contingency, post tripping and post corrective actions values.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SWITCHDIAGFILEDATASET
```

Python command syntax:

```
switchdiagfileset()
```

Fortran command syntax:

```
CALL SWITCHDIAGFILEDATASET
```


9.87. UPDATEBUSLOCDIAGFILE

Use this API to update bus locations in the active Slider diagram in the GUI using the positions found in the current bus location file.

This API routine was first introduced in release 30.2.1.

Batch command syntax:

```
BAT_UPDATEBUSLOCDIAGFILE
```

Python command syntax:

```
updatebuslocdiagfile()
```

Fortran command syntax:

```
CALL UPDATEBUSLOCDIAGFILE
```

Chapter 10

Single Element Data

This chapter defines API routines that are used to retrieve data for a single element (e.g., bus, branch, area, etc.) from the PSS®E engine and test on various program states.

These routines do not record themselves when called with recording enabled.

10.1. APIERRSTR

Use this API to return the message string associated with a specific error code returned from a recordable PSSE API routine.

This API routine was first introduced in release 34.4.0.

Python command syntax:

```
ierr, string = apierrstr(api, errcode)
```

Fortran command syntax:

```
CALL APIERRSTR(API, ERRCODE, STRING, IERR)
```

IPLAN command syntax:

```
CALL APIERRSTR(API, ERRCODE, STRING, IERR)
```

Where:

Character API	Name of the API. (input).	
Integer ERRCODE	Error code for API (input).	
Character*148 STRING	Error message for API and ERRCODE (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'STRING' returned
	IERR = 1	API not found; 'STRING' set to spaces
	IERR = 2	ERRCODE out of range; 'STRING' set to spaces

10.2. ARDAT

Use this API to return area totals.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = ardat(iar, string)
```

Fortran command syntax:

```
CALL ARDAT(IAR, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL ARDAT(IAR, STRING, P, Q, IERR)
```

Where:

Integer IAR	Area number (input).	
Character STRING	String indicating the area total desired (input).	
	'LOAD'	Total area load by bus area assignment (net of load plus in-service distributed generation on load feeder)
	'LOADLD'	Total area load by load area assignment
	'LDGN'	Total distributed generation on load feeder by bus area assignment
	'LDGNLD'	Total distributed generation on load feeder by load area assignment
	'GEN'	Total area generation
	'LOSS'	Total area losses; $I^2 * (R + jX)$ for ac branches with non-metered end in the area
	'XFRMAG'	Magnetizing admittance powers for transformers with winding 1 bus in the area
	'LNSHNT'	Powers flowing into line shunts of non-transformer branches with non-metered end in the area
	'CHARGE'	Powers flowing from line charging of non-transformer branches with non-metered end in the area
	'INT'	Net area interchange
	'INDMAC'	Total area induction machine powers by bus area assignment
	'INDMACMC'	Total area induction machine powers by machine area assignment
	'INDGEN'	Total area induction generator powers by bus area assignment
	'INDGENMC'	Total area induction generator powers by machine area assignment

	'INDMOT'	Total area induction motor powers by bus area assignment
	'INDMOTMC'	Total area induction motor powers by machine area assignment
Real P	Real component of the desired complex power	
Real Q	Reactive component of the desired complex power	
Complex CMPVAL	Desired complex power (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Area number < 0 or > largest allowable area number; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	No in-service buses with in-service loads (for 'LOAD'), no in-service loads (for 'LOADLD'), no type 2 or type 3 buses (for 'GEN'), no branches (for 'LOSS'), or no ties (for 'INT') in area; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3	Area not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4	Bad 'STRING' value; 'P' and 'Q' or 'CMPVAL' unchanged

10.3. AREDAT

Use this API to return real area data items.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = aredat(iar, string)
```

Fortran command syntax:

```
CALL AREDAT(IAR, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL AREDAT(IAR, STRING, RVAL, IERR)
```

Where:

Integer IAR	Area number (input).	
Character STRING	String indicating the area quantity desired (input).	
	'PDES'	Desired net interchange leaving area in MW
	'PTOL'	Interchange tolerance bandwidth in MW
	'O_PDES'	Same as 'PDES' in units determined by the power output option setting
Real RVAL	'O_PTOL'	Same as 'PTOL' in units determined by the power output option setting
	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Area number <= 0 or > largest allowable area number; 'RVAL' unchanged
	IERR = 2	Area not found; 'RVAL' unchanged
	IERR = 3	Bad 'STRING' value; 'RVAL' unchanged

10.4. AREINT

Use this API to return integer area data items.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = areint(iar, string)
```

Fortran command syntax:

```
CALL AREINT(IAR, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL AREINT(IAR, STRING, IVAL, IERR)
```

Where:

Integer IAR	Area number (input).
Character STRING	String indicating the area quantity desired (input). 'SWING' Area slack bus number
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output). IERR = 0 No error; 'IVAL' returned IERR = 1 Area number <= 0 or > largest allowable area number; 'IVAL' unchanged IERR = 2 Area not found; 'IVAL' unchanged IERR = 3 Bad 'STRING' value; 'IVAL' unchanged

10.5. ARENAM

Use this API to return the area name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = arenam(iar)
```

Fortran command syntax:

```
CALL ARENAM(IAR, CVAL, IERR)
```

IPLAN command syntax:

```
CALL ARENAM(IAR, CVAL, IERR)
```

Where:

Integer IAR	Area number (input).	
Character*12 CVAL	Area name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Area number <= 0 or > largest allowable area number; 'CVAL' unchanged
	IERR = 2	Area not found; 'CVAL' unchanged

10.6. ARENUM

Use this API to return the area number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, iar = arenum(cval)
```

Fortran command syntax:

```
CALL ARENUM(IAR, CVAL, IERR)
```

IPLAN command syntax:

```
CALL ARENUM(IAR, CVAL, IERR)
```

Where:

Integer IAR	Area number (output).
Character CVAL	Area name (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IAR' returned
	IERR = 1 Area with name 'CVAL' not found; 'IAR' unchanged
	IERR > 1 Multiple areas with the name 'CVAL' found, 'IAR' returned as lowest number of these

10.7. AREUSE

Use this API to indicate if an area is in use.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ival = areuse(iar)
```

Fortran command syntax:

```
CALL AREUSE(IAR, IVAL)
```

IPLAN command syntax:

```
CALL AREUSE(IAR, IVAL)
```

Where:

Integer IAR	Area number (input).	
Integer IVAL	Area status (output).	
	IVAL = -1	Area number <= 0 or > largest allowable area number.
	IVAL = 0	If no equipment is assigned to area IAR.
	IVAL = 1	If any equipment is assigned to area IAR.

10.8. ARITJ

Use this API to return the interchange between two areas.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = aritj(iar, jar)
```

Fortran command syntax:

```
CALL ARITJ(IAR, JAR, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL ARITJ(IAR, JAR, P, Q, IERR)
```

Where:

Integer IAR	From area number (input).
Integer JAR	To area number (input).
Real P	Real component of the complex interchange
Real Q	Reactive component of the complex interchange
Complex CMPVAL	Complex interchange (output).
Integer IERR	error code (output).
IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
IERR = 1	Area number <= 0 or > largest allowable area number; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 2	No in-service branches between areas; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 3	Area not found; 'P' and 'Q' or 'CMPVAL' unchanged

10.9. BRNCUR

This API routine is obsolete. It has been replaced by the API routine [BRNMSC](#).

Use this API to return branch flow values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = brncur(ibus,jbus,ickt)
```

Fortran command syntax:

```
CALL BRNCUR(IBUS, JBUS, ICKT, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNCUR(IBUS, JBUS, ICKT, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*2 ICKT	Circuit or multisection line identifier (input).
Real RVAL	Flow value (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Branch not found; 'RVAL' unchanged
	IERR = 3 Branch out-of-service; 'RVAL' returned set to zero
	IERR = 4 No base kV at IBUS; 'RVAL' returned = per unit current

10.10. BRNDAT

Use this API to return real branch parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = brndat(ibus,jbus,ickt,string)
```

Fortran command syntax:

```
CALL BRNDAT(IBUS, JBUS, ICKT, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNDAT(IBUS, JBUS, ICKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*12 ICKT	Circuit identifier (input).
Character STRING	String indicating the branch quantity desired (input).
	'RATEn' Rating from rating set "n" (n = 1 through 12)
	'RATEA' First rating
	'RATEB' Second rating
	'RATEC' Third rating
	'RATE' Default rating
	'LENGTH' Line length
	'CHARG' Total branch charging
	'CHARGZ' Zero sequence charging
	'FRACT1' Fraction of total ownership assigned to the first owner
	'FRACT2' Fraction of total ownership assigned to the second owner
	'FRACT3' Fraction of total ownership assigned to the third owner
	'FRACT4' Fraction of total ownership assigned to the fourth owner
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Branch not found; 'RVAL' unchanged
	IERR = 3 Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4 'BRNDAT' invalid with multisection line identifier; 'RVAL' unchanged

IERR = 5

Sequence data not in case; 'RVAL' unchanged

IERR = 6

For STRING = 'FRACTn', n > number of owners; 'RVAL' unchanged

10.11. BRNDT2

Use this API to return complex positive and zero sequence parameters for non-transformer branches, and complex positive sequence parameters for transformer branches.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = brndt2(ibus,jbus,ickt,string)
```

Fortran command syntax:

```
CALL BRNDT2(IBUS, JBUS, ICKT, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNDT2(IBUS, JBUS, ICKT, STRING, P, Q, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*12 ICKT	Circuit identifier (input).
Character STRING	String indicating the branch quantity desired (input).
	'RX' Branch resistance and reactance in per unit
	'ISHNT' Admittance of line shunt at IBUS end of the branch
	'JSHNT' Admittance of line shunt at JBUS end of the branch
	'RXZ' Zero sequence branch resistance and reactance
	'ISHNTZ' Zero sequence admittance of line shunt at IBUS end of the branch
	'JSHNTZ' Zero sequence admittance of line shunt at JBUS end of the branch
	'LOSSES' Branch losses in MW and Mvar
	'O_LOSSES' Branch losses in units determined by the power output option setting
Real P	Real component of the complex value indicated by STRING
Real Q	Reactive component of the complex value indicated by STRING
Complex CMPVAL	Complex value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Branch not found; 'P' and 'Q' or 'CMPVAL' unchanged

IERR = 3	Invalid value of 'STRING'; 'P' and 'Q' or 'CMP- VAL' unchanged
IERR = 4	'BRNDT2' invalid with multisection line identifier; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 5	Sequence data not in case; 'P' and 'Q' or 'CMP- VAL' unchanged

10.12. BRNFLO

Use this API to return the complex branch flow ($P+jQ$) as calculated at IBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = brnflo(ibus,jbus,ickt)
```

Fortran command syntax:

```
CALL BRNFLO(IBUS, JBUS, ICKT, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNFLO(IBUS, JBUS, ICKT, P, Q, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*2 ICKT	Circuit or multisection line identifier (input).
Real P	Real component of the complex branch flow
Real Q	Reactive component of the complex branch flow
Complex CMPVAL	Complex branch flow (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Branch not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Branch is out-of-service; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.13. BRNINT

Use this API to return integer branch parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = brnint(ibus,jbus,ickt,string)
```

Fortran command syntax:

```
CALL BRNINT(IBUS, JBUS, ICKT, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNINT(IBUS, JBUS, ICKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*12 ICKT	Circuit or multisection line identifier (input).
Character STRING	String indicating the branch quantity desired (input).
	'STATUS' Branch status
	'METER' Bus number of metered end
	'NMETR' Bus number of non-metered end
	'OWNERS' Number of owners for this branch
	'OWN1' Owner number of the first owner
	'OWN2' Owner number of the second owner
	'OWN3' Owner number of the third owner
	'OWN4' Owner number of the fourth owner
	'STATION_I' Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'STATION_J' Bus JBUS substation number (returned as 0 if bus JBUS is not in a substation)
	'SECTION_I' Bus IBUS bus section number (returned as 0 if bus IBUS is not in a substation)
	'SECTION_J' Bus JBUS bus section number (returned as 0 if bus JBUS is not in a substation)
	'NODE_I' Number of the node to which the branch is connected at the bus IBUS end (returned as 0 if bus IBUS is not in a substation)
	'NODE_J' Number of the node to which the branch is connected at the bus JBUS end (returned as 0 if bus JBUS is not in a substation)
	'TYPE' System switching device type (returned as 0 if the branch is not a system switching device).
	'SCTYPE' MOV protection mode

Integer IVAL

Value indicated by STRING (output).

Integer IERR

error code (output).

IERR = 0	No error; 'IVAL' returned
IERR = 1	Bus not found; 'IVAL' unchanged
IERR = 2	Branch not found; 'IVAL' unchanged
IERR = 3	Invalid value of 'STRING'; 'IVAL' unchanged
IERR = 6	For 'STRING' = 'OWNn', n > number of owners; 'IVAL' unchanged

10.14. BRNMSC

Use this API to return real branch flow values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = brnmsc(ibus,jbus,ickt,string)
```

Fortran command syntax:

```
CALL BRNMSC(IBUS, JBUS, ICKT, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNMSC(IBUS, JBUS, ICKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character ICKT	Circuit or multisection line identifier (input).
Character STRING	String indicating the branch quantity desired (input).
	'MVA' Branch MVA flow
	'O_MVA' Same as 'MVA' in units determined by the power output option setting
	'AMPS' Branch current in amps
	'PUCUR' Branch current in pu
	'CURANG' Angle of branch current in degrees
	'PCTRTA' Percent current loading of RATEA
	'PCTRTB' Percent current loading of RATEB
	'PCTRTC' Percent current loading of RATEC
	'PCTMVA' Percent MVA loading of RATEA
	'PCTMVB' Percent MVA loading of RATEB
	'PCTMVC' Percent MVA loading of RATEC
	'PCTCPA' Percent current or MVA loading (according to the appropriate percent loading units program option setting) of RATEA
	'PCTCPB' Percent current or MVA loading (according to the appropriate percent loading units program option setting) of RATEB
	'PCTCPC' Percent current or MVA loading (according to the appropriate percent loading units program option setting) of RATEC
	'P' Branch MW flow at the IBUS end of the branch
	'O_P' Same as 'P' in units determined by the power output option setting

	'Q'	Branch Mvar flow at the IBUS end of the branch
	'O_Q'	Same as 'Q' in units determined by the power output option setting
	'PLOS'	Branch active power losses in MW
	'O_PLOS'	Branch active power losses in units determined by the power output option setting
	'QLOS'	Branch reactive power losses in Mvar
	'O_QLOS'	Branch reactive power losses in units determined by the power output option setting
Real RVAL	Flow value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Branch not found; 'RVAL' unchanged
	IERR = 3	Branch out-of-service; 'RVAL' returned set to zero
	IERR = 4	No base kV at IBUS; 'RVAL' returned = per unit current
	IERR = 5	Invalid 'STRING'; 'RVAL' unchanged
	IERR = 6	Rating is zero; 'RVAL' returned set to zero

10.15. BRNMVA

This API routine is obsolete. It has been replaced by the API routine [BRNMSC](#).

Use this API to return return branch MVA.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = brnmva(ibus,jbus,ickt)
```

Fortran command syntax:

```
CALL BRNMVA(IBUS, JBUS, ICKT, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNMVA(IBUS, JBUS, ICKT, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*2 ICKT	Circuit or multisection line identifier (input).
Real RVAL	Flow value (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Branch not found; 'RVAL' unchanged
	IERR = 3 Branch out-of-service; 'RVAL' returned set to zero

10.16. BRNNAM

Use this API to return the name of an AC branch.

This API routine was first introduced in release 34.3.0.

Python command syntax:

```
ierr, string = brnnam(ibus, jbus, ickt)
```

Fortran command syntax:

```
CALL BRNNAM(IBUS, JBUS, ICKT, STRING, IERR)
```

IPLAN command syntax:

```
CALL BRNNAM(IBUS, JBUS, ICKT, STRING, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character ICKT	Circuit identifier (input).
Character*40 STRING	Branch name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'STRING' returned
	IERR = 1 Bus not found; 'STRING' unchanged
	IERR = 2 Branch not found; 'STRING' unchanged
	IERR = 4 'BRNNAM' invalid with multisection line identifier; 'STRING' unchanged

10.17. BRNSTT

This API routine is obsolete. It has been replaced by the API routine [BRNINT](#).

Return branch status.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = brnstt(ibus,jbus,ickt)
```

Fortran command syntax:

```
CALL BRNSTT(IBUS, JBUS, ICKT, IVAL, IERR)
```

IPLAN command syntax:

```
CALL BRNSTT(IBUS, JBUS, ICKT, IVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*2 ICKT	Circuit or multisection line identifier (input).
Integer IVAL	Branch status (output).
	IVAL = 0 out of service
	IVAL = 1 in-service
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 2 Branch not found; 'IVAL' unchanged

10.18. BSYSISDEF

Use this API to check whether a bus subsystem has been defined for a given subsystem ID. A return value of FALSE means that the given subsystem ID is operating in ALL buses mode, e.g., all buses are operated on.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
exist = bsysisdef(sid)
```

Fortran command syntax:

```
CALL SBSBDEF(SID, EXIST)
```

IPLAN command syntax:

```
CALL BSYSISDEF(SID, EXIST)
```

Where:

Integer SID	a valid bus subsystem ID. Valid bus subsystem IDs range from 0 to 11 (input).	
Logical EXIST	function return (output).	
	EXIST = False	no subsystem defined, operating in ALL buses mode.
	EXIST = True	subsystem is defined.

10.19. BUSDAT

Use this API to return real bus values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = busdat(ibus ,string)
```

Fortran command syntax:

```
CALL BUSDAT(IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSDAT(IBUS, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character STRING	String indicating the bus quantity desired (input).
	'BASE' Bus base voltage, in kV
	'PU' Actual bus voltage magnitude, in pu
	'KV' Actual bus voltage magnitude, in kV
	'ANGLE' Bus voltage angle, in radians
	'ANGLED' Bus voltage angle, in degrees
	'NVLMIH' Normal high voltage limit, in pu
	'NVLMILO' Normal low voltage limit, in pu
	'EVLMIH' Emergency high voltage limit, in pu
	'EVLMILO' Emergency low voltage limit, in pu
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Bad value of 'STRING'; 'RVAL' unchanged
	IERR = 3 Bus type code 4 or greater; 'RVAL' returned
	IERR = 4 No base voltage and 'STRING' = 'KV'; 'RVAL' unchanged

10.20. BUSDT1

Use this API to return complex bus parameters as MVA. Values may be either nominal or actual.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = busdt1(ibus, string1, string2)
```

Fortran command syntax:

```
CALL BUSDT1(IBUS, STRING1, STRING2, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSDT1(IBUS, STRING1, STRING2, RVAL, IERR)
```

Note:

When STRNG1 is one of the following: 'MVA', 'IL', 'YL', 'TOTAL', 'SC_MVA', 'SC_IL', 'SC_YL', 'SC_TOTAL', 'FX_MVA', 'FX_IL', 'FX_YL', 'FX_TOTAL', the values returned are the net load values (i.e., value includes the load plus contribution from any in-service distributed generation on the load feeder at that bus)

Where:

Integer IBUS	Bus number (input).	
Character STRING1	String indicating the bus quantity desired (input).	
	'MVA'	Total in-service constant MVA load
	'IL'	Total in-service constant current load
	'YL'	Total in-service constant admittance load
	'TOTAL'	Total in-service load
	'SC_MVA'	Total in-service scalable constant MVA load
	'SC_IL'	Total in-service scalable constant current load
	'SC_YL'	Total in-service scalable constant admittance load
	'SC_TOTAL'	Total in-service scalable load
	'FX_MVA'	Total in-service fixed constant MVA load
	'FX_IL'	Total in-service fixed constant current load
	'FX_YL'	Total in-service fixed constant admittance load
	'FX_TOTAL'	Total in-service fixed load
	'YS'	Total in-service fixed bus shunt
	'YSZERO'	Total nominal in-service zero sequence fixed bus shunt
	'YSZ'	Total nominal in-service zero sequence fixed bus shunt in per unit
	'YSW'	In-service switched shunt
	'YSWZ'	In-service zero sequence switched shunt

	'SHUNTN'	Total in-service negative sequence load (pu nominal)
	'SHUNTZ'	Total in-service zero sequence load (pu nominal)
Character STRING2	String indicating the units to be used (ignored if STRING1 = 'YSZ' or 'YSWZ') (input).	
	'ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'RVAL' returned in MVA
	'O_ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'RVAL' in units determined by the power output option setting (units determined by power output options)
	'NOM'	Nominal load or shunt (at 1.0 pu voltage). 'RVAL' returned in MVA
	'O_NOM'	Nominal load or shunt (at 1.0 pu voltage). 'RVAL' in units determined by the power output option setting
Real RVAL	Magnitude of the complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Bad value of 'STRING1' or 'STRING2'; 'RVAL' unchanged
	IERR = 3	Bus type code 4 or greater; 'RVAL' returned
	IERR = 4	No loads at bus for 'STRING1' = 'MVA', 'IL', 'YL', or 'TOTAL'; 'RVAL' returned set to zero
	IERR = 5	No switched shunt at bus for 'STRING1' = 'YSW'; 'YSWZERO' or 'YSWZ'; 'RVAL' unchanged
	IERR = 6	Sequence data not in case for 'STRING1' = 'YSZERO', 'YSZ', 'YSWZERO', 'YSWZ', 'SHUNTN' or 'SHUNTZ'; 'RVAL' unchanged

10.21. BUSDT2

Use this API to return complex bus parameters. Values may be either nominal or actual. Nominal values return negative values for reactors. Actual values show flow into reactor.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = busdt2(ibus, string1, string2)
```

Fortran command syntax:

```
CALL BUSDT2(IBUS, STRING1, STRING2, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSDT2(IBUS, STRING1, STRING2, P, Q, IERR)
```

Note:

When STRNG1 is one of the following: 'MVA', 'IL', 'YL', 'TOTAL', 'SC_MVA', 'SC_IL', 'SC_YL', 'SC_TOTAL', 'FX_MVA', 'FX_IL', 'FX_YL', 'FX_TOTAL', the values returned are the net load values (i.e., value includes load plus the contribution from any in-service distributed generation on the load feeder at that bus)

Where:

Integer IBUS	Bus number (input).	
Character STRING1	String indicating the bus quantity desired (input).	
	'MVA'	Total in-service constant MVA load
	'IL'	Total in-service constant current load
	'YL'	Total in-service constant admittance load
	'TOTAL'	Total in-service load
	'SC_MVA'	Total in-service scalable constant MVA load
	'SC_IL'	Total in-service scalable constant current load
	'SC_YL'	Total in-service scalable constant admittance load
	'SC_TOTAL'	Total in-service scalable load
	'FX_MVA'	Total in-service fixed constant MVA load
	'FX_IL'	Total in-service fixed constant current load
	'FX_YL'	Total in-service fixed constant admittance load
	'FX_TOTAL'	Total in-service fixed load
	'YS'	Total in-service fixed bus shunt
	'YSZERO'	Total nominal in-service zero sequence fixed bus shunt
	'YSZ'	Total nominal in-service zero sequence fixed bus shunt in per unit
	'YSW'	In-service switched shunt

	'YSWZERO'	Nominal in-service zero sequence switched shunt
	'YSWZ'	Nominal in-service zero sequence switched shunt in per unit
	'SHUNTN'	Total in-service negative sequence load (pu nominal)
	'SHUNTZ'	Total in-service zero sequence load (pu nominal)
Character STRING2	String indicating the units to be used (ignored if STRING1 = 'YSZ' or 'YSWZ') (input).	
	'ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'P' 'Q' returned in MW Mvar
	'O_ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'P' 'Q' in units determined by the power output option setting
	'NOM'	Nominal load (at 1.0 pu voltage). 'P' 'Q' returned in MW Mvar
	'O_NOM'	Nominal load (at 1.0 pu voltage). 'P' 'Q' in units determined by the power output option setting
Real P	Real component of the complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Real Q	Reactive component of the complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Complex CMPVAL	Complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	Bad value of 'STRING1' or 'STRING2'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3	Bus type code 4 or greater; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 4	No loads at bus for 'STRING1' = 'MVA', 'IL', 'YL', or 'TOTAL'; 'P' and 'Q' or 'CMPVAL' returned set to zero
	IERR = 5	No switched shunt at bus for 'STRING1' = 'YSW', 'YSWZERO' or 'YSWZ'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 6	Sequence data not in case for 'STRING1' = 'YSZERO', 'YSZ', 'YSWZERO', 'YSWZ', 'SHUNTN' or 'SHUNTZ'; 'CMPVAL' unchanged

10.22. BUSEXS

Use this API to check for the existence of a specified bus.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = busexs(ibus)
```

Fortran command syntax:

```
CALL BUSEXS( IBUS, IERR)
```

IPLAN command syntax:

```
CALL BUSEXS( IBUS, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	Bus found
	IERR = 1	Bus not found

10.23. BUSINT

Use this API to return integer bus parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = busint(ibus ,string)
```

Fortran command syntax:

```
CALL BUSINX(IBUS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSINT(IBUS, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character STRING	String indicating the bus quantity desired (input).	
	'STATION'	Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number
	'OWNER'	Bus owner number
Integer IVAL	'DUMMY'	Returns 1 (one) if bus is a dummy bus of a multisection line else 0 (zero)
	Value indicated by STRING (output).	
	error code (output).	
	IERR = 0	No error; 'IVAL' returned
Integer IERR	IERR = 1	Bus not found; 'IVAL' unchanged
	IERR = 2	Bad value of 'STRING'; 'IVAL' unchanged

10.24. BUSMSM

Use this API to return complex bus mismatch.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = busmsm(ibus)
```

Fortran command syntax:

```
CALL BUSMSM(IBUS, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSMSM(IBUS, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Real P	Real component (MW) of the bus mismatch	
Real Q	Reactive component (Mvar) of the bus mismatch	
Complex CMPVAL	Complex bus mismatch (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	Bus type code greater than 4; 'P' and 'Q' or 'CMPVAL' returned set to zero

10.25. BUSORDPOS

Use this API to return the ordinal position of the specified bus or bus section in the numerically ordered list of non-star point buses (i.e., star point buses are excluded).

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, iord = busordpos(ibus, inode)
```

Fortran command syntax:

```
CALL BUSORDPOS(IBUS, INODE, IORD, IERR)
```

IPLAN command syntax:

```
CALL BUSORDPOS(IBUS, INODE, IORD, IERR)
```

Where:

Integer IBUS	bus number (input).
Integer INODE	node number. The position in the collating sequence of the bus section to which node INODE is connected is returned. INODE must be specified as 0 if bus IBUS is not in a substation. INODE may be specified as 0 if bus IBUS is represented by a single bus section. If 0 is specified and bus IBUS is represented by multiple bus sections, the collating sequence position of the parent bus section of bus IBUS is returned. (input).
Integer IORD	ordinal position; 1 through the number of non-star point buses in the working case. IORD is unchanged if a positive value of IERR is returned. (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'IORD' returned.
	IERR = 1 invalid bus number.
	IERR = 2 bus IBUS not found.
	IERR = 3 invalid node number.
	IERR = 4 bus IBUS does not belong to a substation.
	IERR = 5 node INODE is not in the substation of bus IBUS.
	IERR = 6 node INODE is not connected to any bus section of bus IBUS.

10.26. BUSSECTDAT

Use this API routine to return real bus section values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rval = bussectdat(ibus, sect, string)
```

Fortran command syntax:

```
CALL BUSSECTDAT(IBUS, SECT, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSSECTDAT(IBUS, SECT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Character STRING	String indicating the bus quantity desired (input).
	'BASE' Bus base voltage, in kV
	'PU' Bus voltage magnitude, in pu
	'KV' Bus voltage magnitude, in kV
	'ANGLE' Bus voltage angle, in radians
	'ANGLED' Bus voltage angle, in degrees
	'NVLMHI' Normal high voltage limit, in pu
	'NVLMLO' Normal low voltage limit, in pu
	'EVLMIHI' Emergency high voltage limit, in pu
	'EVLMILO' Emergency low voltage limit, in pu
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 3 Bus type code 4 or greater; 'RVAL' returned
	IERR = 4 No base voltage and 'STRING' = 'KV'; 'RVAL' unchanged
	IERR = 9 Bus section not found; 'RVAL' unchanged

10.27. BUSSECTDT1

Use this API routine to return complex bus section parameters as MVA. Values may be either nominal or actual.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rval = bussectdt1(ibus, sect, string1, string2)
```

Fortran command syntax:

```
CALL BUSSECTDT1(IBUS, SECT, STRING1, STRING2, RVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSSECTDT1(IBUS, SECT, STRING1, STRING2, RVAL, IERR)
```

Note:

When STRNG1 is one of the following: 'MVA', 'IL', 'YL', 'TOTAL', 'SC_MVA', 'SC_IL', 'SC_YL', 'SC_TOTAL', 'FX_MVA', 'FX_IL', 'FX_YL', 'FX_TOTAL', the values returned are the net load values (i.e., value includes the load plus contribution from any in-service distributed generation on the load feeder at that bus).

Where:

Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Character STRING1	String indicating the bus quantity desired (input).
	'MVA' Net in-service constant MVA load
	'IL' Net in-service constant current load
	'YL' Net in-service constant admittance load
	'TOTAL' Net in-service total load (total of constant MVA constant current and constant admittance portions)
	'LDGEN' Total in-service distributed generation on the load feeder
	'SC_MVA' Net in-service scalable constant MVA load
	'SC_IL' Net in-service scalable constant current load
	'SC_YL' Net in-service scalable constant admittance load
	'SC_TOTAL' Net in-service scalable total load
	'FX_MVA' Net in-service fixed constant MVA load
	'FX_IL' Net in-service fixed constant current load
	'FX_YL' Net in-service fixed constant admittance load
	'FX_TOTAL' Net in-service fixed total load
	'YS' Total in-service fixed bus shunt
	'YSZERO' Total nominal in-service zero sequence fixed bus shunt

	'YSZ'	Total nominal in-service zero sequence fixed bus shunt in per unit
	'YSW'	In-service switched shunt
	'YSWZ'	In-service zero sequence switched shunt
	'SHUNTN'	Total in-service negative sequence load (pu nominal)
	'SHUNTZ'	Total in-service zero sequence load (pu nominal)
Character STRING2	String indicating the units to be used (ignored if STRING1 = 'YSZ' or 'YSWZ') (input).	
	'ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'RVAL' returned in MVA
	'O_ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'RVAL' in units determined by the power option setting
	'NOM'	Nominal load or shunt (at 1.0 pu voltage). 'RVAL' returned in MVA
	'O_NOM'	Nominal load or shunt (at 1.0 pu voltage). 'RVAL' in units determined by the power option setting
Real RVAL	Magnitude of the complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Bad value of 'STRING1' or 'STRING2'; 'RVAL' unchanged
	IERR = 3	Bus type code 4 or greater; 'RVAL' returned
	IERR = 4	No loads at bus for 'STRING1' = 'MVA', 'IL', 'YL', or 'TOTAL'; 'RVAL' returned set to zero
	IERR = 5	No switched shunt at bus for 'STRING1' = 'YSW'; 'YSWZERO' or 'YSWZ'; 'RVAL' unchanged
	IERR = 6	Sequence data not in case for 'STRING1' = 'YSZERO', 'YSZ', 'YSWZERO', 'YSWZ', 'SHUNTN' or 'SHUNTZ'; 'RVAL' unchanged
	IERR = 9	Bus section not found; 'RVAL' unchanged

10.28. BUSSECTDT2

Use this API routine to return complex bus section parameters. Values may be either nominal or actual. Nominal values return negative values for reactors. Actual values show flow into reactor.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, cmpval = bussectdt2(ibus, sect, string1, string2)
```

Fortran command syntax:

```
CALL BUSSECTDT2(IBUS, SECT, STRING1, STRING2, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSSECTDT2(IBUS, SECT, STRING1, STRING2, P, Q, IERR)
```

Note:

When STRNG1 is one of the following: 'MVA', 'IL', 'YL', 'TOTAL', 'SC_MVA', 'SC_IL', 'SC_YL', 'SC_TOTAL', 'FX_MVA', 'FX_IL', 'FX_YL', 'FX_TOTAL', the values returned are the net load values (i.e., value includes the load plus contribution from any in-service distributed generation on the load feeder at that bus).

Where:

Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Character STRING1	String indicating the bus quantity desired (input).
	'MVA' Net in-service constant MVA load
	'IL' Net in-service constant current load
	'YL' Net in-service constant admittance load
	'TOTAL' Net in-service total load (total of constant MVA constant current and constant admittance portions)
	'LDGEN' Total in-service distributed generation on the load feeder
	'SC_MVA' Net in-service scalable constant MVA load
	'SC_IL' Net in-service scalable constant current load
	'SC_YL' Net in-service scalable constant admittance load
	'SC_TOTAL' Net in-service scalable total load
	'FX_MVA' Net in-service fixed constant MVA load
	'FX_IL' Net in-service fixed constant current load
	'FX_YL' Net in-service fixed constant admittance load
	'FX_TOTAL' Net in-service fixed total load
	'YS' Total in-service fixed bus shunt
	'YSZERO' Total nominal in-service zero sequence fixed bus shunt

	'YSZ'	Total nominal in-service zero sequence fixed bus shunt in per unit
	'YSW'	In-service switched shunt
	'YSWZ'	In-service zero sequence switched shunt
	'SHUNTN'	Total in-service negative sequence load (pu nominal)
	'SHUNTZ'	Total in-service zero sequence load (pu nominal)
Character STRING2	String indicating the units to be used (ignored if STRING1 = 'YSZ' or 'YSWZ') (input).	
	'ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'RVAL' returned in MVA
	'O_ACT'	Actual load or shunt (nominal shunt for STRING1 = 'YSZERO' or 'YSWZERO'). 'RVAL' in units determined by the power option setting
	'NOM'	Nominal load or shunt (at 1.0 pu voltage). 'RVAL' returned in MVA
	'O_NOM'	Nominal load or shunt (at 1.0 pu voltage). 'RVAL' in units determined by the power option setting
Real P	Real component of the complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Real Q	Reactive component of the complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Complex CMPVAL	Complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	Bad value of 'STRING1' or 'STRING2'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3	Bus type code 4 or greater; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 4	No loads at bus for 'STRING1' = 'MVA', 'IL', 'YL', or 'TOTAL'; 'P' and 'Q' or 'CMPVAL' returned set to zero
	IERR = 5	No switched shunt at bus for 'STRING1' = 'YSW', 'YSWZERO' or 'YSWZ'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 6	Sequence data not in case for 'STRING1' = 'YSZERO', 'YSZ', 'YSWZERO', 'YSWZ', 'SHUNTN' or 'SHUNTZ'; 'CMPVAL' unchanged
	IERR = 9	Bus section not found; 'CMPVAL' unchanged

10.29. BUSSECTEXS

Use this API routine to check for the existence of a specified bus section.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr = bussectexs(ibus, sect)
```

Fortran command syntax:

```
CALL BUSSECTEXS(IBUS, SECT, IERR)
```

IPLAN command syntax:

```
CALL BUSSECTEXS(IBUS, SECT, IERR)
```

Where:

Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 9 Bus section not found; 'IVAL' unchanged

10.30. BUSSECTINT

Use this API routine to return real bus section values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, ival = bussectint(ibus, sect, string)
```

Fortran command syntax:

```
CALL BUSSECTINT(IBUS, SECT, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL BUSSECTINT(IBUS, SECT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Character STRING	String indicating the bus quantity desired (input).
	'STATION' Bus IBUS substation number (returned as zero if bus IBUS is not in a substation)
	'TYPE' Bus type code
	'AREA' Bus area number
	'ZONE' Bus zone number
	'OWNER' Bus owner number
	'DUMMY' Returns 1 (one) if bus is a dummy bus of a multi-section line else 0 (zero)
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 2 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 9 Bus section not found; 'IVAL' unchanged

10.31. CCTMDLNAM_2DCO

Use this API to return model name of CCT 2-terminal dc line other models.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, model = cctmdlname_2dco(name)
```

Fortran command syntax:

```
CALL CCTMDLNAM_2DCO (NAME, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_2DCO (NAME, MODEL, IERR)
```

Where:

Character*12 NAME	Two-terminal dc line name (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; MODEL name is returned
	IERR = 1 dc line not in case
	IERR = 2 No CCT models in case
	IERR = 3 No 2-terminal dc other model attached to the specified dc line
	IERR = 4 Dynamics data not present in working memo- ry

10.32. CCTMDLNAM_2WTD

Use this API to return model name of the CCT 2-winding transformer device model.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, model = cctmdlname_2wtd(ibus, jbus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_2WTD(IBUS, JBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_2WTD(IBUS, JBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the 2-winding transformer (input).
Integer JBUS	"To" Bus number of the 2-winding transformer (input).
Character*2 ID	2-winding transformer circuit identifier (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
IERR = 0	No error; MODEL name is returned
IERR = 1	2-winding transformer not in case
IERR = 2	No CCT models in case
IERR = 3	No device model attached to the specified 2-winding transformer
IERR = 4	Dynamics data not present in working memory
IERR = 5	Specified branch is not a transformer

10.33. CCTMDLNAM_3WTD

Use this API to return model name of the CCT 3-winding transformer device model.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, model = cctmdlname_3wtd(ibus, jbus, kbus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_3WTD(IBUS, JBUS, KBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_3WTD(IBUS, JBUS, KBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the branch (input).
Integer JBUS	"To" Bus number of the branch (input).
Integer KBUS	"Third" Bus number of the branch (input).
Character*2 ID	3-winding transformer branch circuit identifier (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; MODEL name is returned
	IERR = 1 branch not in case;
	IERR = 2 No CCT models in case
	IERR = 3 No device model attached to the specified 3-winding transformer
	IERR = 4 Dynamics data not present in working memory
	IERR = 5 Specified branch is a transformer

10.34. CCTMDLNAM_BRND

Use this API to return model name of the CCT branch device model.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, model = cctmdlname_brnd(ibus, jbus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_BRND(IBUS, JBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_BRND(IBUS, JBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the branch (input).
Integer JBUS	"To" Bus number of the branch (input).
Character*2 ID	Branch circuit identifier (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
IERR = 0	No error; MODEL name is returned
IERR = 1	branch not in case;
IERR = 2	No CCT models in case
IERR = 3	No branch device model attached to the specified branch
IERR = 4	Dynamics data not present in working memory
IERR = 5	Specified branch is a transformer

10.35. CCTMDLNAM_BRNO

Use this API to return model name of the CCT branch other model.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, model = cctmdlنام_bno(ibus, jbus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_BRNO(IBUS, JBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_BRNO(IBUS, JBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the branch (input).
Integer JBUS	"To" Bus number of the branch (input).
Character*2 ID	Branch circuit identifier (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
IERR = 0	No error; MODEL name is returned
IERR = 1	branch not in case
IERR = 2	No CCT models in case
IERR = 3	No branch other model attached to the specified branch
IERR = 4	Dynamics data not present in working memory
IERR = 5	Specified branch is a transformer

10.36. CCTMDLNAM_BUSO

Use this API to return model name of CCT Bus other models.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, model = cctmdlنام_buso(ibus)
```

Fortran command syntax:

```
CALL CCTMDLNAM_BUSO(IBUS, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_BUSO(IBUS, MODEL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; MODEL name is returned
	IERR = 1 bus not in case
	IERR = 2 No CCT models in case
	IERR = 3 No bus other model attached to the specified bus
	IERR = 4 Dynamics data not present in working memory

10.37. CCTMDLNAM_MCNO

Use this API to return model name of the CCT machine other models.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, model = cctmdlname_mcno(ibus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_MCNO(IBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_MCNO(IBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Machine identifier (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; MODEL name is returned
	IERR = 1 machine not in case
	IERR = 2 No CCT models in case
	IERR = 3 No machine other model attached to the specified machine
	IERR = 4 Dynamics data not present in working memo- ry

10.38. CCTMDLNAM_MCNP

Use this API to return model name of the CCT machine protection models.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, model = cctmdlنام_mcnپ(ibus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_MCNP(IBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_MCNP(IBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Machine identifier (input).
Character*16 MODEL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; MODEL name is returned
	IERR = 1 machine not in case
	IERR = 2 No CCT models in case
	IERR = 3 No machine protection model attached to the specified machine
	IERR = 4 Dynamics data not present in working memo- ry

10.39. CCTMDLNAM_MSCO

Use this API to return model name of the CCT Miscellaneous other model.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, model = cctmdlنام_mscو(mins)
```

Fortran command syntax:

```
CALL CCTMDLNAM_MSCO(MINS, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_MSCO(MINS, MODEL, IERR)
```

Where:

Integer MINS	Model instance number of the model (input).	
Character*16 MODEL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; MODEL name is returned
	IERR = 1	Invalid MINS value
	IERR = 2	No CCT models in case
	IERR = 3	No model attached for the specified MINS
	IERR = 4	Dynamics data not present in working memory

10.40. CCTMDLNAM_SWO_2

Use this API to return model name of the CCT switched shunt other type models.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, model = cctmdl原因_swso_2(ibus, id)
```

Fortran command syntax:

```
CALL CCTMDLNAM_SWO_2(IBUS, ID, MODEL, IERR)
```

IPLAN command syntax:

```
CALL CCTMDLNAM_SWO_2(IBUS, ID, MODEL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character*2 ID	switched shunt identifier (input).	
Character*16 MODEL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; MODEL name is returned
	IERR = 1	bus not in case; MODEL name is returned as blank
	IERR = 2	No CCT models in case
	IERR = 3	No switched shunt other type model attached to the specified switched shunte
	IERR = 4	Dynamics data not present in working memory
	IERR = 5	switched shunt not in case

10.41. CCTMIND_2DCO

Use this API to return starting array indices and status of CCT 2-terminal dc line other models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_2dco(name, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_2DCO (NAME, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_2DCO (NAME, MODEL, STRING, IVAL, IERR)
```

Where:

Character*12 NAME	Two-terminal dc line name (input).
Character*16 MODEL	2-terminal dc other Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect dc line status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 dc line not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to this dc line; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

10.42. CCTMIND_2WTD

Use this API to return starting array indices and status of CCT 2-winding transformer device models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_2wtd(ibus, jbus, id, string)
```

Fortran command syntax:

```
CALL CCTMIND_2WTD(IBUS, JBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_2WTD(IBUS, JBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the 2-winding transformer (input).
Integer JBUS	"To" Bus number of the 2-winding transformer (input).
Character*2 ID	2-winding transformer circuit identifier (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect 2-winding transformer status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 2-winding transformer not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 No device model attached to the specified 2-winding transformer; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

IERR = 7

Specified branch is not a transformer; 'IVAL'
unchanged

10.43. CCTMIND_3WTD

Use this API to return starting array indices and status of CCT 3-winding transformer device models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_3wtd(ibus, jbus, kbus, id, string)
```

Fortran command syntax:

```
CALL CCTMIND_3WTD(IBUS, JBUS, KBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_3WTD(IBUS, JBUS, KBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the 3-winding transformer (input).
Integer JBUS	"To" Bus number of the 3-winding transformer (input).
Integer KBUS	"Third" Bus number of the 3-winding transformer (input).
Character*2 ID	2-winding transformer circuit identifier (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect 3-winding transformer status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 4-winding transformer not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 No device model attached to the specified 3-winding transformer; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned

IERR = 6	Dynamics data not present in working memory; 'IVAL' unchanged
IERR = 7	Specified branch is not a transformer; 'IVAL' unchanged

10.44. CCTMIND_BRND

Use this API to return starting array indices and status of CCT branch device models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_brnd(ibus, jbus, id, string)
```

Fortran command syntax:

```
CALL CCTMIND_BRND(IBUS, JBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_BRND(IBUS, JBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the branch (input).
Integer JBUS	"To" Bus number of the branch (input).
Character*2 ID	Branch circuit identifier (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect branch status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 branch not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 No device model attached to the specified branch; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged
	IERR = 7 Specified branch is a transformer; 'IVAL' unchanged

10.45. CCTMIND_BRNO

Use this API to return starting array indices and status of CCT branch other models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_brno(ibus, jbus, id, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_BRNO(IBUS, JBUS, ID, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_BRNO(IBUS, JBUS, ID, MODEL, STRING, IVAL, IERR)
```

Where:

Integer IBUS	"From" Bus number of the branch (input).
Integer JBUS	"To" Bus number of the branch (input).
Character*2 ID	Branch circuit identifier (input).
Character*16 MODEL	Branch other Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect branch status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 branch not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to the specified branch; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

IERR = 7

Branch is a transformer; 'IVAL' unchanged

10.46. CCTMIND_BUSO

Use this API to return starting array indices and status of CCT Bus other models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_buso(ibus, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_BUSO(IBUS, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_BUSO(IBUS, MODEL, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*16 MODEL	Bus other Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect bus status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 bus not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to this bus; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

10.47. CCTMIND_MCNO

Use this API to return starting array indices and status of CCT machine other models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_mcno(ibus, id, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_MCNO(IBUS, ID, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_MCNO(IBUS, ID, MODEL, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Machine identifier (input).
Character*16 MODEL	Machine other Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect machine status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 machine not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to this machine; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

10.48. CCTMIND_MCNP

Use this API to return starting array indices and status of CCT machine protection models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_mcnp(ibus, id, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_MCNP(IBUS, ID, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_MCNP(IBUS, ID, MODEL, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Machine identifier (input).
Character*16 MODEL	Machine protection Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect machine status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 machine not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to this machine; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

10.49. CCTMIND_MSCO

Use this API to return starting array indices and status of CCT Miscellaneous other models.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_msco(mins, string)
```

Fortran command syntax:

```
CALL CCTMIND_MSCO(MINS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_MSCO(MINS, STRING, IVAL, IERR)
```

Where:

Integer MINS	Model instance number of the model (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' CON Starting CON index
	'STATE' STATE Starting STATE index
	'VAR' VAR Starting VAR index
	'ICON' ICON Starting ICON index
	'NCON' NCON Number of CON values used by the model
	'NSTATE' NSTATE Number of STATE values used by the model
	'NVAR' NVAR Number of VAR values used by the model
	'NICON' NICON Number of ICON values used by the model
	'STATUS' STATUS Bypassed flag: 0 = bypassed; 1 = not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Invalid MINS value; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 No model attached for the specified MINS; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

10.50. CCTMIND_SWSO

This API routine is obsolete. It has been replaced by the API routine [cctmind_swso_2](#).

In versions prior to 35.0, this API would return the starting array indices and status of CCT switched shunt other model types. Starting version 35.0, this API is being retained only for reasons of backward compatibility of python scripts.

Use of this API is not recommended anymore as this will always pick the first switched shunt at a bus.

This API routine was first introduced in release 33.9.0.

Python command syntax:

```
ierr, ival = cctmind_swso(ibus, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_SWSO(IBUS, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_SWSO(IBUS, MODEL, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number at which switched shunt is attached (input).
Character*16 MODEL	Switched shunt other Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect switched shunt status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 bus not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to this bus; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned

IERR = 6

Dynamics data not present in working memory; 'IVAL' unchanged

IERR = 7

No switched shunt at the specified bus; 'IVAL' unchanged

10.51. CCTMIND_SWSO_2

Use this API to return starting array indices and status of CCT Switched Shunt other models.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, ival = cctmind_sws_2(ibus, id, model, string)
```

Fortran command syntax:

```
CALL CCTMIND_SWSO_2(IBUS, ID, MODEL, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL CCTMIND_SWSO_2(IBUS, ID, MODEL, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number at which switched shunt is attached (input).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 MODEL	Switched shunt other Model name (input).
Character STRING	String indicating the model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect switched shunt status
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 bus not in case; 'IVAL' returned as 0
	IERR = 2 No CCT models in case
	IERR = 3 Model name specified in 'MODEL' not attached to this bus; 'IVAL' unchanged
	IERR = 4 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 6 Dynamics data not present in working memory; 'IVAL' unchanged

IERR = 7

No switched shunt at the specified bus; 'IVAL'
unchanged

10.52. CHKTRE

Use this API to check for Type 4 (or greater) buses with in-service branches connected to them. If none are found, it then counts number of ac islands not containing a Type 3 (swing) bus. It may be inappropriate to call this subroutine with generators converted; in this case, there are no Type 3 buses, so there is normally one or more swingless islands.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ival = chktre()
```

Fortran command syntax:

```
CALL CHKTRE(IVAL)
```

IPLAN command syntax:

```
CALL CHKTRE(IVAL)
```

Where:

Integer IVAL	Return code (output).
IVAL = 0	None of the following found.
IVAL = -1	No in-service buses remaining.
IVAL = -2	There are Type 4 buses with in-service branches connected to them.
IVAL > 0	Number of islands without a Type 3 bus.

10.53. CHNVAL

Use this API to return the present value of the simulation variable assigned to a specified output channel.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = chnval(n)
```

Fortran command syntax:

```
CALL CHNVAL(N, RVAL, IERR)
```

IPLAN command syntax:

```
CALL CHNVAL(N, RVAL, IERR)
```

Where:

Integer N	Channel number (input).
Real RVAL	Channel value (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Invalid channel index; 'RVAL' unchanged
	IERR = 2 Invalid channel address; 'RVAL' unchanged
	IERR = 9 Dynamics data not present in working memory; 'RVAL' unchanged

10.54. DC2AUXMIND

Use this API to return the starting array indices and status of auxiliary signal model associated with 2-terminal dc line for the specified signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dc2auxmind(name, isgndx, string)
```

Fortran command syntax:

```
CALL DC2AUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2AUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

Where:

Character*12 NAME	Two-terminal dc line name (input).
Integer ISGNDX	Auxiliary signal index (input).
Character STRING	String indicating the 2-terminal dc line auxiliary signal model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. For a model to be called during simulations the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 dc line not in network but auxiliary signal model in model tables; 'IVAL' returned
	IERR = 2 dc line not in network and auxiliary signal model not in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables for the given auxiliary signal index; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Model does not use any of this data type; 'IVAL' = 0 returned

IERR = 9

Dynamics data not present in working memory; 'IVAL' unchanged

10.55. DC2AUXMNAM

Use this API to return the auxiliary signal model name associated with a 2-terminal dc line for the specified auxiliary signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = dc2auxmnam(name, isgndx)
```

Fortran command syntax:

```
CALL DC2AUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2AUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

Where:

Character NAME	Two-terminal dc line name (input).	
Integer ISGNDX	Auxiliary signal index (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	dc line not in network but auxiliary signal model in model tables; 'CVAL' returned
	IERR = 2	dc line not in network and auxiliary signal model not in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables for the given auxiliary signal index; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.56. DC2DAT

This API routine is obsolete. It has been replaced by the API routine [dc2dat_2](#).

Use this API to return real two-terminal dc line quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = dc2dat(n, ibus, string)
```

Fortran command syntax:

```
CALL DC2DAT(N, IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2DAT(N, IBUS, STRING, RVAL, IERR)
```

Where:

Integer N	Two-terminal dc line number (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the dc line quantity desired (input).
	'DCCUR' dc line current in amps (Line Quantity)
	'RDC' dc line resistance in ohms (Line Quantity)
	'SETVAL' Current (amps) or power (MW) demand (Line Quantity)
	'VSCHD' Scheduled compounded dc voltage in kV (Line Quantity)
	'VCMOD' Mode switch dc voltage in kV (Line Quantity)
	'RCOMP' Compounding resistance in ohms (Line Quantity)
	'DELT' Margin in pu of desired dc power or current (Line Quantity)
	'DCVMIN' Minimum compounded dc voltage in kV (Line Quantity)
	'PAC' Apparent active power flow into the dc line in MW (Converter Quantity)
	'O_PAC' Same as 'PAC' in units determined by the power output option setting (Converter Quantity)
	'QAC' Apparent reactive power flow into the dc line in Mvar (Converter Quantity)
	'O_QAC' Same as 'QAC' in units determined by the power output option setting (Converter Quantity)
	'MVA' Apparent ac flow into the dc line in MVA (Converter Quantity)

	'O_MVA'	Same as 'MVA' in units determined by the power output option setting (Converter Quantity)
	'ACAMPS'	ac current flow into the dc line in amps (Converter Quantity)
	'PUCUR'	ac current flow into the dc line in pu (Converter Quantity)
	'KVDC'	dc voltage in kV (Converter Quantity)
	'ANGLE'	Converter angle in degrees (Converter Quantity)
	'ANGMIN'	Minimum steady-state converter angle in degrees (Converter Quantity)
	'ANGMAX'	Nominal maximum converter angle in degrees (Converter Quantity)
	'RC'	Commutating transformer resistance per bridge in ohms (Converter Quantity)
	'XC'	Commutating transformer reactance per bridge in ohms (Converter Quantity)
	'EBASE'	Primary base ac voltage in kV (Converter Quantity)
	'TR'	Transformer ratio in pu (Converter Quantity)
	'TAP'	Tap setting in pu (Converter Quantity)
	'TPMX'	Maximum tap setting in pu (Converter Quantity)
	'TPMN'	Minimum tap setting in pu (Converter Quantity)
	'STP'	Tap step in pu (Converter Quantity)
	'XCAP'	Commutating capacitor reactance magnitude per bridge in ohms (Converter Quantity)
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	dc line not found; 'RVAL' unchanged
	IERR = 2	Bus not a converter bus of dc line 'N'; 'RVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4	dc line blocked; 'RVAL' of 0.0 returned
	IERR = 5	No base kV at bus; 'RVAL' returned as the per unit current

10.57. DC2DAT_2

This API is the second release of the API that returns real two-terminal dc line quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, rval = dc2dat_2(name, ibus, string)
```

Fortran command syntax:

```
CALL DC2DAT_2(NAME, IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2DAT_2(NAME, IBUS, STRING, RVAL, IERR)
```

Where:

Character NAME	Two-terminal dc line name (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the dc line quantity desired (input).
	'DCCUR' dc line current in amps (Line Quantity)
	'RDC' dc line resistance in ohms (Line Quantity)
	'SETVAL' Current (amps) or power (MW) demand (Line Quantity)
	'VSCHD' Scheduled compounded dc voltage in kV (Line Quantity)
	'VCMOD' Mode switch dc voltage in kV (Line Quantity)
	'RCOMP' Compounding resistance in ohms (Line Quantity)
	'DELT' Margin in pu of desired dc power or current (Line Quantity)
	'DCVMIN' Minimum compounded dc voltage in kV (Line Quantity)
	'PAC' Apparent active power flow into the dc line in MW (Converter Quantity)
	'O_PAC' Same as 'PAC' in units determined by the power output option setting (Converter Quantity)
	'QAC' Apparent reactive power flow into the dc line in Mvar (Converter Quantity)
	'O_QAC' Same as 'QAC' in units determined by the power output option setting (Converter Quantity)
	'MVA' Apparent ac flow into the dc line in MVA (Converter Quantity)
	'O_MVA' Same as 'MVA' in units determined by the power output option setting (Converter Quantity)

	'ACAMPS'	ac current flow into the dc line in amps (Converter Quantity)
	'PUCUR'	ac current flow into the dc line in pu (Converter Quantity)
	'KVDC'	dc voltage in kV (Converter Quantity)
	'ANGLE'	Converter angle in degrees (Converter Quantity)
	'ANGMIN'	Minimum steady-state converter angle in degrees (Converter Quantity)
	'ANGMAX'	Nominal maximum converter angle in degrees (Converter Quantity)
	'RC'	Commutating transformer resistance per bridge in ohms (Converter Quantity)
	'XC'	Commutating transformer reactance per bridge in ohms (Converter Quantity)
	'EBASE'	Primary base ac voltage in kV (Converter Quantity)
	'TR'	Transformer ratio in pu (Converter Quantity)
	'TAP'	Tap setting in pu (Converter Quantity)
	'TPMX'	Maximum tap setting in pu (Converter Quantity)
	'TPMN'	Minimum tap setting in pu (Converter Quantity)
	'STP'	Tap step in pu (Converter Quantity)
	'XCAP'	Commutating capacitor reactance magnitude per bridge in ohms (Converter Quantity)
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	dc line not found; 'RVAL' unchanged
	IERR = 2	Bus not a converter bus of dc line 'NAME'; 'RVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4	dc line blocked; 'RVAL' of 0.0 returned
	IERR = 5	No base kV at bus; 'RVAL' returned as the per unit current

10.58. DC2INT

This API routine is obsolete. It has been replaced by the API routine [dc2int_2](#).

Use this API to return integer two-terminal dc line quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = dc2int(n, string)
```

Fortran command syntax:

```
CALL DC2INT(N, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2INT(N, STRING, IVAL, IERR)
```

Where:

Integer N	Two-terminal dc line number (input).
Character STRING	String indicating the dc line quantity desired (input).
	'MDC' dc line control mode
	'RECT' Bus number of rectifier end of dc line
	'INV' Bus number of inverter end of dc line
	'METER' Bus number of metered end of dc line
	'NBR' Number of bridges in series rectifier end
	'NBI' Number of bridges in series inverter end
	'ICR' Rectifier firing angle measuring bus
	'ICI' Inverter firing angle measuring bus
	'NDR' Rectifier firing angle measuring node
	'NDI' Inverter firing angle measuring node
	'ANSTTR' Firing angle status rectifier end: (-1) low; (0) regulating; (1) high
	'ANSTTI' Firing angle status inverter end: (-1) low; (0) regulating; (1) high
	'TPSTTR' Tap status rectifier end: (-1) low; (0) regulating; (1) high; (-2) locked
	'TPSTTI' Tap status inverter end: (-1) low; (0) regulating; (1) high; (-2) locked
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 2 dc line not found; 'IVAL' unchanged
	IERR = 3 Invalid value of 'STRING'; 'IVAL' unchanged

10.59. DC2INT_2

This API is the second release of the API that returns integer two-terminal dc line quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dc2int_2(name, string)
```

Fortran command syntax:

```
CALL DC2INT_2(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2INT_2(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	Two-terminal dc line name (input).
Character STRING	String indicating the dc line quantity desired (input).
	'MDC' dc line control mode
	'RECT' Bus number of rectifier end of dc line
	'INV' Bus number of inverter end of dc line
	'METER' Bus number of metered end of dc line
	'NBR' Number of bridges in series rectifier end
	'NBI' Number of bridges in series inverter end
	'ICR' Rectifier firing angle measuring bus
	'ICI' Inverter firing angle measuring bus
	'NDR' Rectifier firing angle measuring node
	'NDI' Inverter firing angle measuring node
	'ANSTTR' Firing angle status rectifier end: (-1) low; (0) regulating; (1) high
	'ANSTTI' Firing angle status inverter end: (-1) low; (0) regulating (1) high
	'TPSTTR' Tap status rectifier end: (-1) low; (0) regulating; (1) high; (-2) locked
	'TPSTTI' Tap status inverter end: (-1) low; (0) regulating; (1) high; (-2) locked
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 2 dc line not found; 'IVAL' unchanged
	IERR = 3 Invalid value of 'STRING'; 'IVAL' unchanged

10.60. DC2MIND

Use this API to return 2-terminal dc line model starting array indices and status.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dc2mind(name, string)
```

Fortran command syntax:

```
CALL DC2MIND(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2MIND(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	Two-terminal dc line name (input).	
Character STRING	String indicating the 2-terminal dc line model quantity desired (input).	
	'CON'	Starting CON index
	'STATE'	Starting STATE index
	'VAR'	Starting VAR index
	'ICON'	Starting ICON index
	'NCON'	Number of CON values used by the model
	'NSTATE'	Number of STATE values used by the model
	'NVAR'	Number of VAR values used by the model
	'NICON'	Number of ICON values used by the model
	'STATUS'	Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect dc line status. For a model to be called during simulations the dc line must be in service the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	dc line not in network but in model tables; 'IVAL' returned
	IERR = 2	dc line not in network or in model tables; 'IVAL' unchanged
	IERR = 4	No model in model tables; 'IVAL' unchanged
	IERR = 5	Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6	Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 9	Dynamics data not present in working memory; 'IVAL' unchanged

10.61. DC2MNAM

Use this API to return 2-terminal dc line model name.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = dc2mnam(name)
```

Fortran command syntax:

```
CALL DC2MNAM(NAME, CVAL, IERR)
```

IPLAN command syntax:

```
CALL DC2MNAM(NAME, CVAL, IERR)
```

Where:

Character NAME	Two-terminal dc line name (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	dc line not in network but in model tables; 'CVAL' returned
	IERR = 2	dc line not in network or in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.62. DCNAUXMIND

Use this API to return the starting array indices and status of auxiliary signal model associated with N-terminal dc line for the specified signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dcnauxmind(name, isgndx, string)
```

Fortran command syntax:

```
CALL DCNAUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNAUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

Where:

Character NAME	N-terminal dc line name (input).
Integer ISGNDX	Auxiliary signal index (input).
Character STRING	String indicating the N-terminal dc line auxiliary signal model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. For a model to be called during simulations the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 dc line not in network but auxiliary signal model in model tables; 'IVAL' returned
	IERR = 2 dc line not in network and auxiliary signal model not in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables for the given auxiliary signal index; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Model does not use any of this data type; 'IVAL' = 0 returned

IERR = 9

Dynamics data not present in working memory; 'IVAL' unchanged

10.63. DCNAUXMNAM

Use this API to return the auxiliary signal model name associated with a N-terminal dc line for the specified auxiliary signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = dcnauxmnam(name, isgndx)
```

Fortran command syntax:

```
CALL DCNAUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNAUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

Where:

Character NAME	N-terminal dc line name (input).	
Integer ISGNDX	Auxiliary signal index (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	dc line not in network but auxiliary signal model in model tables; 'CVAL' returned
	IERR = 2	dc line not in network and auxiliary signal model not in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables for the given auxiliary signal index; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.64. DCNCIN

This API routine is obsolete. It has been replaced by the API routine [dcncin_2](#).

Use this API to return integer multi-terminal dc line converter quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = dcncin(n, ibus, string)
```

Fortran command syntax:

```
CALL DCNCIN(N, IBUS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNCIN(N, IBUS, STRING, IVAL, IERR)
```

Where:

Integer N	Multi-terminal dc line number (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the dc line quantity desired (input). 'ANSTT' Firing angle status: (-1) low; (0) regulating; (1) high 'TPSTT' Tap status: (-1) low; (0) regulating; (1) high; (-2) locked
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output). IERR = 0 No error; 'IVAL' returned IERR = 1 dc line not found; 'IVAL' unchanged IERR = 2 Bus not a converter bus of dc line 'N'; 'IVAL' unchanged IERR = 3 Invalid 'STRING'; 'IVAL' unchanged

10.65. DCNCIN_2

This API is the second release of the API that returns integer multi-terminal dc line converter quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dcncin_2(name, ibus, string)
```

Fortran command syntax:

```
CALL DCNCIN_2(NAME, IBUS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNCIN_2(NAME, IBUS, STRING, IVAL, IERR)
```

Where:

Character NAME	Multi-terminal dc line name (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the dc line quantity desired (input). 'ANSTT' Firing angle status: (-1) low; (0) regulating; (1) high 'TPSTT' Tap status: (-1) low; (0) regulating; (1) high; (-2) locked
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output). IERR = 0 No error; 'IVAL' returned IERR = 1 dc line not found; 'IVAL' unchanged IERR = 2 Bus not a converter bus of dc line 'NAME'; 'IVAL' unchanged IERR = 3 Invalid 'STRING'; 'IVAL' unchanged

10.66. DCNDAT

This API routine is obsolete. It has been replaced by the API routine [dcndat_2](#).

Use this API to return real multi-terminal dc line quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = dcndat(n, ibus, string)
```

Fortran command syntax:

```
CALL DCNDAT(N, IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNDAT(N, IBUS, STRING, RVAL, IERR)
```

Where:

Integer N	Multi-terminal dc line number (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the dc line quantity desired (input).
	'VCMOD' Mode switch dc voltage in kV (Line Quantity)
	'PAC' Active power into dc line at converter bus in MW (Converter Quantity)
	'O_PAC' Same as 'PAC' in units determined by the power output option setting (Converter Quantity)
	'QAC' Reactive power into dc line at converter bus in Mvar (Converter Quantity)
	'O_QAC' Same as 'QAC' in units determined by the power output option setting (Converter Quantity)
	'KVDC' dc voltage at converter bus end (Converter Quantity)
	'DCCUR' dc current (Converter Quantity)
	'SETVAL' Converter setpoint (Converter Quantity)
	'ANGLE' Converter angle (Converter Quantity)
	'TAP' Tap setting (Converter Quantity)
	'ANGMIN' Minimum steady-state ALPHA or GAMMA angle in degrees (Converter Quantity)
	'ANGMAX' Nominal maximum ALPHA or GAMMA angle in degrees (Converter Quantity)
	'RC' Commutating resistance per bridge in ohms (Converter Quantity)
	'XC' Commutating reactance per bridge in ohms (Converter Quantity)

	'MVA'	Apparent ac flow into the dc line in MVA (Converter Quantity)
	'O_MVA'	Same as 'MVA' in units determined by the power output option setting (Converter Quantity)
	'ACAMPS'	ac current flow into the dc line in amps (Converter Quantity)
	'PUCUR'	ac current flow into the dc line in pu (Converter Quantity)
	'EBASE'	Primary base ac voltage in kV (Converter Quantity)
	'TR'	Transformer ratio in pu (Converter Quantity)
	'TPMX'	Maximum tap setting in pu (Converter Quantity)
	'TPMN'	Minimum tap setting in pu (Converter Quantity)
	'STP'	Tap step in pu (Converter Quantity)
	'DELT'	Rectifier margin in pu of desired dc power or current (Converter Quantity)
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	dc line not found; 'RVAL' unchanged
	IERR = 2	Bus not a converter bus of dc line 'N'; 'RVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4	dc line blocked; 'RVAL' of 0.0 returned
	IERR = 5	No base kV at bus; 'RVAL' returned as the per unit current

10.67. DCNDAT_2

This API is the second release of the API that returns real multi-terminal dc line quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, rval = dcndat_2(name, ibus, string)
```

Fortran command syntax:

```
CALL DCNDAT_2(NAME, IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNDAT_2(NAME, IBUS, STRING, RVAL, IERR)
```

Where:

Character NAME	Multi-terminal dc line name (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the dc line quantity desired (input).
	'VCMOD' Mode switch dc voltage in kV (Line Quantity)
	'PAC' Active power into dc line at converter bus in MW (Converter Quantity)
	'O_PAC' Same as 'PAC' in units determined by the power output option setting (Converter Quantity)
	'QAC' Reactive power into dc line at converter bus in Mvar (Converter Quantity)
	'O_QAC' Same as 'QAC' in units determined by the power output option setting (Converter Quantity)
	'KVDC' dc voltage at converter bus end (Converter Quantity)
	'DCCUR' dc current (Converter Quantity)
	'SETVAL' Converter setpoint (Converter Quantity)
	'ANGLE' Converter angle (Converter Quantity)
	'TAP' Tap setting (Converter Quantity)
	'ANGMIN' Minimum steady-state ALPHA or GAMMA angle in degrees (Converter Quantity)
	'ANGMAX' Nominal maximum ALPHA or GAMMA angle in degrees (Converter Quantity)
	'RC' Commutating resistance per bridge in ohms (Converter Quantity)
	'XC' Commutating reactance per bridge in ohms (Converter Quantity)
	'MVA' Apparent ac flow into the dc line in MVA (Converter Quantity)

	'O_MVA'	Same as 'MVA' in units determined by the power output option setting (Converter Quantity)
	'ACAMPS'	ac current flow into the dc line in amps (Converter Quantity)
	'PUCUR'	ac current flow into the dc line in pu (Converter Quantity)
	'EBASE'	Primary base ac voltage in kV (Converter Quantity)
	'TR'	Transformer ratio in pu (Converter Quantity)
	'TPMX'	Maximum tap setting in pu (Converter Quantity)
	'TPMN'	Minimum tap setting in pu (Converter Quantity)
	'STP'	Tap step in pu (Converter Quantity)
	'DELT'	Rectifier margin in pu of desired dc power or current (Converter Quantity)
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	dc line not found; 'RVAL' unchanged
	IERR = 2	Bus not a converter bus of dc line 'NAME'; 'RVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4	dc line blocked; 'RVAL' of 0.0 returned
	IERR = 5	No base kV at bus; 'RVAL' returned as the per unit current

10.68. DCNINT

This API routine is obsolete. It has been replaced by the API routine [dcnint_2](#).

Use this API to return integer multi-terminal dc line quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = dcnint(n, string)
```

Fortran command syntax:

```
CALL DCNINT(N, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNINT(N, STRING, IVAL, IERR)
```

Where:

Integer N	Multi-terminal dc line number (input).
Character STRING	String indicating the dc line quantity desired (input).
	'MDC' Control mode
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 2 dc line not found; 'IVAL' unchanged
	IERR = 3 Invalid value of 'STRING'; 'IVAL' unchanged

10.69. DCNINT_2

This API is the second release of the API that returns integer multi-terminal dc line quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dcnint_2(name, string)
```

Fortran command syntax:

```
CALL DCNINT_2(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNINT_2(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	Multi-terminal dc line name (input).
Character STRING	String indicating the dc line quantity desired (input). 'MDC' Control mode
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output). IERR = 0 No error; 'IVAL' returned IERR = 2 dc line not found; 'IVAL' unchanged IERR = 3 Invalid value of 'STRING'; 'IVAL' unchanged

10.70. DCNMIND

Use this API to return N-terminal dc line model starting array indices and status.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = dcnmind(name, string)
```

Fortran command syntax:

```
CALL DCNMIND(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DCNMIND(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	N-terminal dc line name (input).	
Character STRING	String indicating the N-terminal dc line model quantity desired (input).	
	'CON'	Starting CON index
	'STATE'	Starting STATE index
	'VAR'	Starting VAR index
	'ICON'	Starting ICON index
	'NCON'	Number of CON values used by the model
	'NSTATE'	Number of STATE values used by the model
	'NVAR'	Number of VAR values used by the model
	'NICON'	Number of ICON values used by the model
	'STATUS'	Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect dc line status. For a model to be called during simulations the dc line must be in service the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	dc line not in network but in model tables; 'IVAL' returned
	IERR = 2	dc line not in network or in model tables; 'IVAL' unchanged
	IERR = 4	No model in model tables; 'IVAL' unchanged
	IERR = 5	Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6	Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 9	Dynamics data not present in working memory; 'IVAL' unchanged

10.71. DCMNAM

Use this API to return N-terminal dc line model name.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = dcnmnam(name)
```

Fortran command syntax:

```
CALL DCMNAM(NAME, CVAL, IERR)
```

IPLAN command syntax:

```
CALL DCMNAM(NAME, CVAL, IERR)
```

Where:

Character NAME	N-terminal dc line name (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	dc line not in network but in model tables; 'CVAL' returned
	IERR = 2	dc line not in network or in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.72. DSCVAL

Use this API to return dynamics character array values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = dscval(string, indx)
```

Fortran command syntax:

```
CALL DSCVAL (STRING, INDX, CVAL, IERR)
```

IPLAN command syntax:

```
CALL DSCVAL (STRING, INDX, CVAL, IERR)
```

Where:

Character STRING	String indicating the dynamics quantity desired (input).	
	'ICON'	Character model parameters
Integer INDX	Index to the dynamics character array (input).	
Character*12 CVAL	Character dynamics array value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Invalid value of 'STRING'; 'CVAL' unchanged
	IERR = 2	'INDX' invalid; 'CVAL' unchanged
	IERR = 3	'INDX' points to integer icon; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.73. DSIVAL

Use this API to return dynamics integer array values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = dsival(string, indx)
```

Fortran command syntax:

```
CALL DSIVAL(STRING, INDX, IVAL, IERR)
```

IPLAN command syntax:

```
CALL DSIVAL(STRING, INDX, IVAL, IERR)
```

Where:

Character STRING	String indicating the dynamics quantity desired (input).	
	'ICON'	Integer model parameters
Integer INDX	Index to the dynamics integer array (input).	
Integer IVAL	Integer dynamics array value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 2	'INDX' invalid; 'IVAL' unchanged
	IERR = 3	'INDX' points to character icon; 'IVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'IVAL' unchanged

10.74. DSRVAL

Use this API to return dynamics real values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = dsrval(string, indx)
```

Fortran command syntax:

```
CALL DSRVAL(STRING, INDX, RVAL, IERR)
```

IPLAN command syntax:

```
CALL DSRVAL(STRING, INDX, RVAL, IERR)
```

Where:

Character STRING	String indicating the dynamics quantity desired (input).	
	'TIME'	Simulation time
	'DELT'	Simulation time step
	'STATE'	State variable values
	'CON'	Real model parameters
	'VAR'	Real model variable values
Integer INDX	Index to dynamics array Ignored for 'TIME' and 'DELT' (input).	
Real RVAL	Real dynamics quantity or array value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 2	'INDX' invalid; 'RVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'RVAL' unchanged

10.75. FCDAUXMIND

Use this API to return the starting array indices and status of auxiliary signal model associated with FACTS device for the specified signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = fcdauxmind(name, isgndx, string)
```

Fortran command syntax:

```
CALL FCDAUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDAUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

Where:

Character NAME	FACTS device name (input).
Integer ISGNDX	Auxiliary signal index (input).
Character STRING	String indicating the FACTS device auxiliary signal model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. For a model to be called during simulations the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 FACTS device not in network but auxiliary signal model in model tables; 'IVAL' returned
	IERR = 2 FACTS device not in network and auxiliary signal model not in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables for the given auxiliary signal index; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged

IERR = 6

Model does not use any of this data type;
'IVAL' = 0 returned

IERR = 9

Dynamics data not present in working memo-
ry; 'IVAL' unchanged

10.76. FCDAUXMNAM

Use this API to return the auxiliary signal model name associated with a FACTS device for the specified auxiliary signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = fcdauxmnam(name, isgndx)
```

Fortran command syntax:

```
CALL FCDAUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDAUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

Where:

Character NAME	FACTS device name (input).	
Integer ISGNDX	Auxiliary signal index (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	FACTS device not in network but auxiliary signal model in model tables; 'CVAL' returned
	IERR = 2	FACTS device not in network and auxiliary signal model not in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables for the given auxiliary signal index; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.77. FCDDAT

This API routine is obsolete. It has been replaced by the API routine [fcddat_2](#).

Use this API to return FACTS device real quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = fcddat(n, string)
```

Fortran command syntax:

```
CALL FCDDAT(N, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDDAT(N, STRING, RVAL, IERR)
```

Where:

Integer N	FACTS device number (input).	
Character STRING	String indicating the FACTS device quantity desired (input).	
	'PDES'	Desired active power flow at terminal end bus in MW
	'O_PDES'	Same as 'PDES' in units determined by the power output option setting
	'QDES'	Desired reactive power flow at terminal end bus in Mvar
	'O_QDES'	Same as 'QDES' in units determined by the power output option setting
	'VSET'	Voltage setpoint at sending end bus
	'SHMX'	Maximum shunt current at sending end bus in MVA at unity voltage
	'O_SHMX'	Same as 'SHMX' in units determined by the power output option setting
	'TRMX'	Maximum bridge real power transfer in MW
	'O_TRMX'	Same as 'TRMX' in units determined by the power output option setting
	'VTMN'	Minimum voltage at terminal end bus in pu
	'VTMX'	Maximum voltage at terminal end bus in pu
	'VSMX'	Maximum series voltage in pu
	'IMX'	Maximum series current in MVA at unity voltage
	'O_IMX'	Same as 'IMX' in units determined by the power output option setting
	'LINX'	Reactance of the dummy series element in pu
	'PSEND'	Active power into series element at sending end bus in MW

'O_PSEND'	Same as 'PSEND' in units determined by the power output option setting
'QSEND'	Reactive power into series element at sending end bus in Mvar
'O_QSEND'	Same as 'QSEND' in units determined by the power output option setting
'PTERM'	Active power into series element at terminal end bus in MW
'O_PTERM'	Same as 'PTERM' in units determined by the power output option setting
'QTERM'	Reactive power into series element at terminal end bus in Mvar
'O_QTERM'	Same as 'QTERM' in units determined by the power output option setting
'PBRDG'	Active bridge power exchange in MW
'O_PBRDG'	Same as 'PBRDG' in units determined by the power output option setting
'QSHNT'	Reactive power into shunt element in Mvar
'O_QSHNT'	Same as 'QSHNT' in units determined by the power output option setting
'VSERES'	Series voltage magnitude
'MVASND'	Flow into series element at sending bus end in MVA
'O_MVASND'	Same as 'MVASND' in units determined by the power output option setting
'MVATRM'	Flow into series element at terminal bus end in MVA
'O_MVATRM'	Same as 'MVATRM' in units determined by the power output option setting
'MVASHN'	Flow into shunt element in MVA
'O_MVASHN'	Same as 'MVASHN' in units determined by the power output option setting
'IPUSND'	Current flow into series element at sending bus end in pu
'IPUTRM'	Current flow into series element at terminal bus end in pu
'IPUSHN'	Current flow into shunt element in pu
'AMPSND'	Current flow into series element at sending bus end in amps
'AMPTRM'	Current flow into series element at terminal bus end in amps
'AMPSHN'	Current flow into shunt element in amps
'PCTSND'	Percent series current loading at sending bus end
'PCTTRM'	Percent series current loading at terminal bus end

	'PCTSHN'	Percent shunt current loading
	'PCTPBR'	Percent bridge real power loading
	'RMPCT'	Percent of contributed vars
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 2	FACTS device 'N' not found; 'RVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4	No base kV at bus; 'RVAL' returned = per unit current
	IERR = 5	For quantities which are solution results, the FACTS device is blocked or out-of-service; "V" of 0.0 returned.

10.78. FCDDAT_2

This API is the second release of the API that returns FACTS device real quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, rval = fcddat_2(name, string)
```

Fortran command syntax:

```
CALL FCDDAT_2(NAME, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDDAT_2(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	FACTS device name (input).	
Character STRING	String indicating the FACTS device quantity desired (input).	
	'PDES'	Desired active power flow at terminal end bus in MW
	'O_PDES'	Same as 'PDES' in units determined by the power output option setting
	'QDES'	Desired reactive power flow at terminal end bus in Mvar
	'O_QDES'	Same as 'QDES' in units determined by the power output option setting
	'VSET'	Voltage setpoint at sending end bus
	'SHMX'	Maximum shunt current at sending end bus in MVA at unity voltage
	'O_SHMX'	Same as 'SHMX' in units determined by the power output option setting
	'TRMX'	Maximum bridge real power transfer in MW
	'O_TRMX'	Same as 'TRMX' in units determined by the power output option setting
	'VTMN'	Minimum voltage at terminal end bus in pu
	'VTMX'	Maximum voltage at terminal end bus in pu
	'VSMX'	Maximum series voltage in pu
	'IMX'	Maximum series current in MVA at unity voltage
	'O_IMX'	Same as 'IMX' in units determined by the power output option setting
	'LINX'	Reactance of the dummy series element in pu
	'PSEND'	Active power into series element at sending end bus in MW
	'O_PSEND'	Same as 'PSEND' in units determined by the power output option setting

'QSEND'	Reactive power into series element at sending end bus in Mvar
'O_QSEND'	Same as 'QSEND' in units determined by the power output option setting
'PTERM'	Active power into series element at terminal end bus in MW
'O_PTERM'	Same as 'PTERM' in units determined by the power output option setting
'QTERM'	Reactive power into series element at terminal end bus in Mvar
'O_QTERM'	Same as 'QTERM' in units determined by the power output option setting
'PBRDG'	Active bridge power exchange in MW
'O_PBRDG'	Same as 'PBRDG' in units determined by the power output option setting
'QSHNT'	Reactive power into shunt element in Mvar
'O_QSHNT'	Same as 'QSHNT' in units determined by the power output option setting
'VSERES'	Series voltage magnitude
'MVASND'	Flow into series element at sending bus end in MVA
'O_MVASND'	Same as 'MVASND' in units determined by the power output option setting
'MVATRM'	Flow into series element at terminal bus end in MVA
'O_MVATRM'	Same as 'MVATRM' in units determined by the power output option setting
'MVASHN'	Flow into shunt element in MVA
'O_MVASHN'	Same as 'MVASHN' in units determined by the power output option setting
'IPUSND'	Current flow into series element at sending bus end in pu
'IPUTRM'	Current flow into series element at terminal bus end in pu
'IPUSHN'	Current flow into shunt element in pu
'AMPSND'	Current flow into series element at sending bus end in amps
'AMPTRM'	Current flow into series element at terminal bus end in amps
'AMPSHN'	Current flow into shunt element in amps
'PCTSND'	Percent series current loading at sending bus end
'PCTTRM'	Percent series current loading at terminal bus end
'PCTSHN'	Percent shunt current loading
'PCTPBR'	Percent bridge real power loading

	'RMPCT'	Percent of contributed vars
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 2	FACTS device 'NAME' not found; 'RVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 4	No base kV at bus; 'RVAL' returned = per unit current
	IERR = 5	For quantities which are solution results, the FACTS is blocked or out-of-service; "V" of 0.0 returned.

10.79. FCDINT

This API routine is obsolete. It has been replaced by the API routine [fcdint_2](#).

Use this API to return FACTS device integer quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = fcdint(n, string)
```

Fortran command syntax:

```
CALL FCDINT(N, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDINT(N, STRING, IVAL, IERR)
```

Where:

Integer N	FACTS device number (input).	
Character STRING	String indicating the FACTS device quantity desired (input).	
	'SEND'	Sending end bus number
	'TERM'	Terminal end bus number
	'REMOTE'	Bus number of remote bus or zero for local control
	'OWNER'	Owner number
	'MODE'	Control mode (negative for blocked during solution)
	'STATVT'	Terminal end voltage condition code returns: 0 Terminal end voltage not constrained. 1 Holding terminal end voltage high limit. -1 Holding terminal end voltage low limit
	'STATVS'	Series voltage limit code returns. 0 Series voltage not constrained. 1 Holding series voltage limit
	'STATBR'	Bridge active power transfer limit code returns. 0 Bridge real power transfer not constrained. 1 Holding bridge real power transfer limit
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 2	FACTS device 'N' not found; 'IVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'IVAL' unchanged

10.80. FCDINT_2

This API is the second release of the API that returns FACTS device integer quantities.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = fcdint_2(name, string)
```

Fortran command syntax:

```
CALL FCDINT_2(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDINT_2(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	FACTS device name (input).
Character STRING	String indicating the FACTS device quantity desired (input).
	'SEND' Sending end bus number
	'TERM' Terminal end bus number
	'REMOTE' Bus number of regulated bus
	'IREG' Bus number of regulated bus
	'NREG' Node number of regulated node
	'OWNER' Owner number
	'MODE' Control mode (negative for blocked during solution)
	'STATVT' Terminal end voltage condition code returns: 0 Terminal end voltage not constrained. 1 Holding terminal end voltage high limit. -1 Holding terminal end voltage low limit
	'STATVS' Series voltage limit code returns: 0 Series voltage not constrained. 1 Holding series voltage limit
	'STATBR' Bridge active power transfer limit code returns: 0 Bridge real power transfer not constrained. 1 Holding bridge real power transfer limit
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 2 FACTS device 'NAME' not found; 'IVAL' unchanged
	IERR = 3 Invalid value of 'STRING'; 'IVAL' unchanged

10.81. FCDMIND

Use this API to return FACTS device model starting array indices and status.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = fcdmind(name, string)
```

Fortran command syntax:

```
CALL FCDMIND(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDMIND(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	FACTS device name (input).
Character STRING	String indicating the FACTS device model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect status of FACTS device. For a model to be called during simulations the FACTS device must be in service the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 FACTS device not in network but in model tables; 'IVAL' returned
	IERR = 2 FACTS device not in network or in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 9 Dynamics data not present in working memory; 'IVAL' unchanged

10.82. FCDMNAM

Use this API to return FACTS device model name.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = fcdmnam(name)
```

Fortran command syntax:

```
CALL FCDMNAM(NAME, CVAL, IERR)
```

IPLAN command syntax:

```
CALL FCDMNAM(NAME, CVAL, IERR)
```

Where:

Character NAME	FACTS device name (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	FACTS device not in network but in model tables; 'CVAL' returned
	IERR = 2	FACTS device not in network or in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables; 'CVAL' unchanged

10.83. FXSDT1

Use this API to return the magnitude of a specified fixed bus shunt.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, rval = fxsd1(ibus, id ,string)
```

Fortran command syntax:

```
CALL FXSDT1(IBUS, ID, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL FXSDT1(IBUS, ID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Shunt identifier (input).
Character STRING	String indicating the units to be used (input).
	'ACT' Actual shunt. 'RVAL' returned in MVA
	'O_ACT' Actual shunt. 'RVAL' in units determined by the power output option setting
	'NOM' Nominal shunt (at 1.0 pu voltage). 'RVAL' returned in MVA
	'O_NOM' Nominal shunt (at 1.0 pu voltage). 'RVAL' in units determined by the power output option setting
	'PQZERO' Nominal zero sequence shunt (at 1.0 pu voltage). 'RVAL' returned in per unit
	'PQZ' Nominal zero sequence shunt (at 1.0 pu voltage). 'RVAL' returned in MVA
	'O_PQZ' Nominal zero sequence shunt (at 1.0 pu voltage). 'RVAL' returned in units determined by the power output option setting
Real RVAL	Magnitude of the complex shunt in the units indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Shunt not found; 'RVAL' unchanged
	IERR = 3 Bus type code is not 1, 2 or 3; 'RVAL' returned
	IERR = 4 Shunt out-of-service; 'RVAL' returned
	IERR = 5 Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 6 Sequence data not in case for 'STRING1' = 'PQZERO', 'PQZ' or 'O_PQZ'; 'RVAL' unchanged

10.84. FXSDT2

Use this API to return complex fixed bus shunt.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cmpval = fxsdt2(ibus, id ,string)
```

Fortran command syntax:

```
CALL FXSDT2(IBUS, ID, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL FXSDT2(IBUS, ID, STRING, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Shunt identifier (input).
Character STRING	String indicating the units to be used (input).
	'ACT' Actual shunt. 'CMPVAL' returned in MW Mvar
	'O_ACT' Actual shunt. 'CMPVAL' in units determined by the power output option setting
	'NOM' Nominal shunt (at 1.0 pu voltage). 'CMPVAL' returned in MW Mvar
	'O_NOM' Nominal shunt (at 1.0 pu voltage). 'CMPVAL' in units determined by the power output option setting
	'PQZERO' Nominal zero sequence shunt (at 1.0 pu voltage). 'CMPVAL' returned in per unit
	'PQZ' Nominal zero sequence shunt (at 1.0 pu voltage). 'CMPVAL' returned in MW Mvar
	'O_PQZ' Nominal zero sequence shunt (at 1.0 pu voltage). 'CMPVAL' returned in units determined by the power output option setting
Real P	Active power component of the complex shunt in the units indicated by STRING (output).
Real Q	Reactive power component of the complex shunt in the units indicated by STRING (output).
Complex CMPVAL	Complex shunt in the units indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Shunt not found; 'P' and 'Q' or 'CMPVAL' unchanged

IERR = 3	Bus type code is not 1, 2 or 3; 'P' and 'Q' or 'CMPVAL' returned
IERR = 4	Shunt out-of-service; 'P' and 'Q' or 'CMPVAL' returned
IERR = 5	Invalid value of 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 6	Sequence data not in case for 'STRING1' = 'PQZERO', 'PQZ' or 'O_PQZ'; 'P' and 'Q' or 'CMPVAL' unchanged

10.85. FXSINT

Use this API to return integer quantities of the specified fixed bus shunt.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = fxsint(ibus, id, string)
```

Fortran command syntax:

```
CALL FXSINT(IBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL FXSINT(IBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character ID	Shunt identifier (input).	
Character STRING	String indicating the shunt quantity desired (input).	
	'STATION'	Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'SECTION'	Bus IBUS bus section number (returned as 0 if bus IBUS is not in a substation).
	'NODE'	Number of the node to which the fixed shunt is connected (returned as 0 if bus IBUS is not in a substation)
	'STATUS'	Shunt status; 1 (one) for in-service 0 (zero) for out-of-service
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Bus not found; 'IVAL' unchanged
	IERR = 2	Shunt not found; 'IVAL' unchanged
	IERR = 3	Bus type code is not 1, 2 or 3; 'IVAL' returned
	IERR = 4	Shunt out-of-service; 'IVAL' returned
	IERR = 5	Invalid value of 'STRING'; 'IVAL' unchanged

10.86. GENCNV

Use this API to return a flag indicating whether generators are converted.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
icode = gencnv()
```

Fortran command syntax:

```
CALL GENCNV(ICODE)
```

IPLAN command syntax:

```
CALL GENCNV(ICODE)
```

Where:

Integer ICODE	0 if generators are converted, otherwise 1 Stand-alone simulator returns a 1 (output).
---------------	--

10.87. GENDAT

Use this API to return plant total power output.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = gendat(ibus)
```

Fortran command syntax:

```
CALL GENDAT(IBUS, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL GENDAT(IBUS, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Real P	Real component of the complex generation (output).	
Real Q	Reactive component of the complex generation (output).	
Complex CMPVAL	Complex generation (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	Bus type code is not 2 or 3; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 3	No machines at bus; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4	No online machines; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.88. GENDT1

Returns total plant power output in MVA.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = gendtt1(ibus)
```

Fortran command syntax:

```
CALL GENDT1(IBUS, RVAL, IERR)
```

IPLAN command syntax:

```
CALL GENDT1(IBUS, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Real RVAL	Magnitude of total plant generation (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Bus type code is not 2 or 3; 'RVAL' returned
	IERR = 3	No machines at bus; 'RVAL' unchanged
	IERR = 4	No online machines; 'RVAL' of 0.0 returned

10.89. GENSECTDAT

Use this API routine to return a bus section's plant total power output.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, cmpval = gensectdat(ibus, sect)
```

Fortran command syntax:

```
CALL GENSECTDAT(IBUS, SECT, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL GENSECTDAT(IBUS, SECT, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer SECT	Bus section number (input).	
Real P	Real component of the complex generation (output).	
Real Q	Reactive component of the complex generation (output).	
Complex CMPVAL	Complex generation (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	Bus type code is not 2 or 3; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 3	No machines at bus; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4	No online machines; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned
	IERR = 9	Bus section not found; 'CMPVAL' unchanged

10.90. GENSECTDT1

Use this API routine to return a bus section's total plant power output in MVA.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rval = gensectdt1(ibus, sect)
```

Fortran command syntax:

```
CALL GENSECTDT1(IBUS, SECT, RVAL, IERR)
```

IPLAN command syntax:

```
CALL GENSECTDT1(IBUS, SECT, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Real RVAL	Magnitude of total plant generation (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Bus type code is not 2 or 3; 'RVAL' returned
	IERR = 3 No machines at bus; 'RVAL' unchanged
	IERR = 4 No online machines; 'RVAL' of 0.0 returned
	IERR = 9 Bus section not found; 'RVAL' unchanged

10.91. GETHOMEPATH

Use this API to retrieve a user's HOMEPATH directory.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
sfile = gethomepath()
```

Fortran command syntax:

```
CALL GETHOMPTH(SFILE)
```

IPLAN command syntax:

```
CALL GETHOMEPATH(SFILE)
```

Where:

Character*260 SFILE	user's HOMEPATH directory (output).
---------------------	-------------------------------------

10.92. GET_MSTATE

Use this API to return the MSTATE value. MSTATE is meaningful in MODEs one through four and indicates the type of simulation being run by activities STRT/RUN, MSTR/MRUN, ESTR/ERUN, GSTR/GRUN or ASTR.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
n = get_mstate()
```

Fortran command syntax:

```
CALL GET_MSTATE(N)
```

IPLAN command syntax:

```
CALL GET_MSTATE(N)
```

Where:

Integer N	MSTATE value (output).
N = -1	No dynamics data is present.
N = 0	Standard state-space dynamic simulation via activities STRT and RUN, or activity ASTR.
N = 1	Excitation system response ratio test via activities ESTR and ERUN. Models other than generator and excitation system models are not called.
N = 2	Excitation system open circuit step response test via activities ESTR and ERUN. Models other than generator and excitation system models are not called.
N = 3	Governor response test via activities GSTR and GRUN. Models other than generator and turbine governor models are not called.
N = 4	Extended term dynamic simulation via activities MSTR and MRUN.
N = 5	Dynamics data is present but no initialization activity has been successfully executed.

10.93. GNECHR

Use this API routine to return character quantities of a specified GNE device.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, cval = gnechr(name, string)
```

Fortran command syntax:

```
CALL GNECHR(NAME, STRING, CVAL, IERR)
```

IPLAN command syntax:

```
CALL GNECHR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	GNE device name (input).	
Character STRING	String indicating the GNE device quantity desired (input).	
	'MODEL'	Name of the BOSL model used by this GNE device
	'CHARn'	nth two-character identifier required by this model; n must be between 1 and the number of character identifiers required by the model to calculate its inputs
Character*16 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	GNE device not found; 'CVAL' unchanged
	IERR = 2	Invalid value of 'STRING'; 'CVAL' unchanged
	IERR = 3	For 'STRING' value 'CHARn', n is not valid for this model; 'CVAL' unchanged

10.94. GNEDAT

Use this API routine to return real quantities of a specified GNE device.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, rval = gnedat(name, string)
```

Fortran command syntax:

```
CALL GNEDAT(NAME, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL GNEDAT(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	GNE device name (input).	
Character STRING	String indicating the GNE device quantity desired (input).	
	'REALn'	nth real data item required by this model; n must be between 1 and the number of real data items used by the model
	'Pn'	active power in MW flowing into the GNE device at terminal n; n must be between 1 and the number of terminals used by the model
	'Qn'	reactive power in MVAR flowing into the GNE device at terminal n; n must be between 1 and the number of terminals used by the model
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	GNE device not found; 'RVAL' unchanged
	IERR = 2	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 3	For 'STRING' value 'REALn', n is not valid for this model; 'RVAL' unchanged

10.95. GNEINT

Use this API routine to return integer quantities of a specified GNE device.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, ival = gneint(name, string)
```

Fortran command syntax:

```
CALL GNEINT(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL GNEINT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	GNE device name (input).	
Character STRING	String indicating the GNE device quantity desired (input).	
	'NTERM'	Number of terminals used by this model (1 or 2)
	'BUS1'	Number of the first (or only) bus to which this model is connected
	'BUS2'	Number of the second bus to which this model is connected; 0 is returned for a 1 terminal model
	'STATUS'	Device status
	'OWNER'	Owner to which the device is assigned
	'NMETER'	Number of the non-metered end bus; used for GNE devices with more than one terminal
	'NREAL'	Number of floating point data items required by this model
	'NINTG'	Number of buses required by the model to calculate its inputs
	'NCHAR'	Number of number of two-character identifiers required by the model to calculate its inputs
	'INTGn'	nth bus number required by this model; n must be between 1 and the number of buses required by the model to calculate its inputs
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	GNE device not found; 'IVAL' unchanged
	IERR = 2	Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 3	For 'STRING' value 'INTGn', n is not valid for this model; 'IVAL' unchanged

10.96. INDDT1

Use this API routine to return real induction machine quantities.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, rval = inddt1(ibus, id, string)
```

Fortran command syntax:

```
CALL INDDT1(IBUS, ID, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL INDDT1(IBUS, ID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Induction machine identifier (input).
Character STRING	String indicating the induction machine quantity desired (input).
	'MBase' Machine power base
	'RATEKV' Machine rated voltage
	'PSET' Power setpoint (positive for a motor)
	'RA' Armature resistance
	'XA' Armature leakage reactance
	'R1' First cage resistance
	'X1' First cage reactance
	'R2' Second cage resistance
	'X2' Second cage reactance
	'X3' Third reactance
	'E1' Main saturation parameter
	'SE1' Main saturation parameter
	'E2' Main saturation parameter
	'SE2' Main saturation parameter
	'IA1' Leakage saturation parameter
	'IA2' Leakage saturation parameter
	'XAMULT' Leakage saturation parameter
	'TRQA' Load torque variation constant
	'TRQB' Load torque variation constant
	'TRQD' Load torque variation constant
	'TRQE' Load torque variation constant
	'H' Machine inertia constant
	'IRATIO' Ratio of locked rotor current to rated current
	'ROVERX' Ratio of Rpos to Xpos

	'RZERO'	Machine zero sequence fault analysis resistance
	'XZERO'	Machine zero sequence fault analysis reactance
	'RGRND'	Machine zero sequence grounding resistance
	'XGRND'	Machine zero sequence grounding reactance
	'P'	Active power flowing from the bus to the machine in MW
	'O_P'	Same as 'P' in units determined by the power output option setting
	'Q'	Reactive power flowing from the bus to the machine in Mvar
	'O_Q'	Same as 'Q' in units determined by the power output option setting
	'MVA'	Complex power flowing from the bus to the machine in MVA
	'O_MVA'	Same as 'MVA' in units determined by the power output option setting
	'SLIP'	Machine slip
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Induction machine not found; 'RVAL' unchanged
	IERR = 3	Bus type code is not 2 or 3; 'RVAL' returned
	IERR = 4	Induction machine is out-of-service; 'RVAL' returned
	IERR = 5	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 6	Sequence data not in case (when STRING = 'IRATIO', 'ROVERX', 'RZERO', 'XZERO', 'RGRND' or 'XGRND')

10.97. INDDT2

Use this API routine to return complex induction machine quantities.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, cmpval = inddt2(ibus, id, string)
```

Fortran command syntax:

```
CALL INDDT2(IBUS, ID, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL INDDT2(IBUS, ID, STRING, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Induction machine identifier (input).
Character STRING	String indicating the induction machine quantity desired (input).
	'ZA' Armature impedance ($R_a + j X_a$)
	'Z1' First cage impedance ($R_1 + j X_1$)
	'Z2' Second cage impedance ($R_2 + j X_2$)
	'ZZERO' Machine zero sequence fault analysis impedance
	'ZGRND' Machine zero sequence grounding impedance
	'PQ' Actual power flowing from the bus to the machine in MW Mvar
	'O_PQ' Same as 'PQ' in units determined by the power output option setting
Real P	Real component of the complex value indicated by STRING
Real Q	Reactive component of the complex value indicated by STRING
Complex CMPVAL	Complex value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Induction machine not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Bus type code is not 2 or 3; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 4 Induction machine is out-of-service; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 5 Invalid value of 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged

IERR = 6

Sequence data not in case (when STRING =
'ZZERO' or ZGRND')

10.98. INDINT

Use this API routine to return integer induction machine quantities.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, ival = indint(ibus, id, string)
```

Fortran command syntax:

```
CALL INDINT(IBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL INDINT(IBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character ID	Induction machine identifier (input).	
Character STRING	String indicating the induction machine quantity desired (input).	
	'STATUS'	Machine status; 1 (one) for in-service 0 (zero) for out-of-service
	'SCODE'	Machine standard type; 1 for NEMA 2 for IEC
	'DCODE'	Machine design code; 0 for custom 1 through 5 for NEMA designs A through E
	'AREA'	Area number of its area
	'ZONE'	Zone number of its zone
	'OWNER'	Owner number of its owner
	'TCODE'	Type of mechanical torque variation; 1 for a simple power law 2 for the WECC model)
	'BCODE'	Base power code; 1 for mechanical power (MW) output of the machine 2 for apparent electrical power (MVA) drawn by the machine
	'PCODE'	Scheduled power code; 1 for mechanical power (MW) output of the machine 2 for electrical active power (MW) drawn by the machine
	'CZG'	Grounding impedance data input/output (I/O) code (1 for per unit 2 for ohms)
	'CGR'	Grounding code (0 for an ungrounded machine 1 for a grounded machine)
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Bus not found; 'IVAL' unchanged

IERR = 2	Induction machine not found; 'IVAL' unchanged
IERR = 3	Bus type code is not 2 or 3; 'IVAL' returned
IERR = 4	Induction machine is out-of-service, 'IVAL' returned
IERR = 5	Invalid value of 'STRING'; 'IVAL' unchanged
IERR = 6	Sequence data not in case (when STRING = 'CZG' or 'CGR')

10.99. INI2DC

Initializes the two-terminal dc line fetching routine 'NXT2DC' for retrieving two-terminal dc lines in dc line name alphabetical order.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr = ini2dc()
```

Fortran command syntax:

```
CALL INI2DC(IERR)
```

IPLAN command syntax:

```
CALL INI2DC(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error, 'NXT2DC' is properly initialized
	IERR = 1	No two-terminal dc lines in case; 'NXT2DC' may not be used

10.100. INIBRN

Initializes the branch fetching routine 'NXTBRN' or 'NXTBRN3' for returning branches connected to IBUS. For multisection lines, 'NXTBRN' or 'NXTBRN3' returns the adjacent dummy bus as the to bus.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inibrn(ibus, single)
```

Fortran command syntax:

```
CALL INIBRN(IBUS, SINGLE, IERR)
```

IPLAN command syntax:

```
CALL INIBRN(IBUS, SINGLE, IERR)
```

Where:

Integer IBUS	From bus number (input).	
Integer SINGLE	If 1, 'NXTBRN' or 'NXTBRN3' will return only branches for which the from bus ('IBUS') number (or bus name) is lower than the to bus (or buses); if 2, then all branches connected to 'IBUS' are returned by 'NXTBRN' or 'NXTBRN3' (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NXTBRN/NXTBRN3' is properly initialized
	IERR = 1	Bus not found; 'NXTBRN/NXTBRN3' may not be used
	IERR = 2	Invalid 'SINGLE' value; 'NXTBRN/NXTBRN3' may not be used

10.101. INIBRN_2

Initializes the branch fetching routine 'NXTBRN_2' or 'NXTBRN3_2' for returning branches connected to bus sections described by IBUS and INODE. For multisection lines, 'NXTBRN_2' or 'NXTBRN3_2' returns the adjacent dummy bus as the to bus.

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr, isect = inibrn_2(ibus, inode, single)
```

Fortran command syntax:

```
CALL INIBRN_2(IBUS, INODE, SINGLE, ISECT, IERR)
```

IPLAN command syntax:

```
CALL INIBRN_2(IBUS, INODE, SINGLE, ISECT, IERR)
```

Where:

Integer IBUS	bus number (input).
Integer INODE	bus section node number (input).
Integer SINGLE	if 1, 'NXTBRN_2' or 'NXTBRN3_2' will return only branches for which the from bus ('IBUS') number (or bus name) is lower than the to bus (or buses); if 2, then all branches connected to 'IBUS' are returned by 'NXTBRN_2' or 'NXTBRN3_2' (input).
Integer ISECT	bus section number (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'NXTBRN_2/NXTBRN3_2' is properly initialized
	IERR = 1 invalid bus number; 'NXTBRN_2/NXTBRN3_3' may not be used
	IERR = 2 IBUS not found; 'NXTBRN_2/NXTBRN3_3' may not be used
	IERR = 3 invalid node number; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 4 IBUS is not in a substation; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 5 INODE is not in the substation; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 6 INODE is not associated with IBUS; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 7 invalid 'SINGLE' value; 'NXTBRN_2/NXTBRN3_2' may not be used

10.102. INIBRX

Initializes the branch fetching routine, 'NXTBRN' or 'NXTBRN3' for returning branches connected to IBUS. For multisection lines, 'NXTBRN' or 'NXTBRN3' returns the other endpoint bus as the to bus.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inibrx(ibus, single)
```

Fortran command syntax:

```
CALL INIBRX(IBUS, SINGLE, IERR)
```

IPLAN command syntax:

```
CALL INIBRX(IBUS, SINGLE, IERR)
```

Where:

Integer IBUS	From bus (input).	
Integer SINGLE	If 1, 'NXTBRN' or 'NXTBRN3' will return only branches for which the from bus ('IBUS') number (or bus name) is lower than the to bus (or buses); if 2, then all branches connected to 'IBUS' are returned by 'NXTBRN' or 'NXTBRN3' (input).	
Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTBRN/NXTBRN3' properly initialized
	IERR = 1	Bus not found; 'NXTBRN/NXTBRN3' may not be used
	IERR = 2	Invalid 'SINGLE' value; 'NXTBRN/NXTBRN3' may not be used
	IERR = 3	'IBUS' is a multi-section line dummy bus; 'NXTBRN/NXTBRN3' may not be used

10.103. INIBRX_2

Initializes the branch fetching routine, 'NXTBRN_2' or 'NXTBRN3_2' for returning branches connected to IBUS. For multisection lines, 'NXTBRN_2' or 'NXTBRN3_2' returns the other endpoint bus as the to bus.

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr, isect = inibrx_2(ibus, inode, single)
```

Fortran command syntax:

```
CALL INIBRX_2(IBUS, INODE, SINGLE, ISECT, IERR)
```

IPLAN command syntax:

```
CALL INIBRX_2(IBUS, INODE, SINGLE, ISECT, IERR)
```

Where:

Integer IBUS	bus number (input).
Integer INODE	bus section node number (input).
Integer SINGLE	if 1, 'NXTBRN_2' or 'NXTBRN3_2' will return only branches for which the from bus ('IBUS') number (or bus name) is lower than the to bus (or buses); if 2, then all branches connected to 'IBUS' are returned by 'NXTBRN_2' or 'NXTBRN3_2' (input).
Integer ISECT	bus section number (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'NXTBRN_2/NXTBRN3_2' is properly initialized
	IERR = 1 invalid bus number; 'NXTBRN_2/NXTBRN3_3' may not be used
	IERR = 2 IBUS not found; 'NXTBRN_2/NXTBRN3_3' may not be used
	IERR = 3 invalid node number; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 4 IBUS is not in a substation; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 5 INODE is not in the substation; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 6 INODE is not associated with IBUS; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 7 invalid 'SINGLE' value; 'NXTBRN_2/NXTBRN3_2' may not be used
	IERR = 8 IBUS is a multi-section line dummy bus; 'NXTBRN_2/NXTBRN3_2' may not be used

10.104. INIBUS

Initializes the bus fetching routine 'NXTBUS' for retrieving buses in ascending numerical order. Dummy buses for multisection lines are included. Hidden star point buses of three-winding transformers are excluded.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inibus(ibus)
```

Fortran command syntax:

```
CALL INIBUS(IBUS, IERR)
```

IPLAN command syntax:

```
CALL INIBUS(IBUS, IERR)
```

Where:

Integer IBUS	starting bus number, 0 for first bus in ordered list (input).	
Integer IERR	error code (output).	
	IERR = 0	no error; 'NXTBUS' is properly initialized
	IERR = 1	bus not found; 'NXTBUS' may not be used

10.105. INIBUS_2

Initializes the bus fetching routine 'NXTBUS_2' for retrieving buses in ascending numerical order. Hidden star point buses of three-winding transformers are excluded.

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr = inibus_2(ibus,msl,topo)
```

Fortran command syntax:

```
CALL INIBUS_2(IBUS, MSL, TOPO, IERR)
```

IPLAN command syntax:

```
CALL INIBUS_2(IBUS, MSL, TOPO, IERR)
```

Where:

Integer IBUS	starting bus number, 0 for first bus in ordered list (input).
Integer MSL	multi-section line interior bus code (input). MSL = 0 exclude MSL = 1 include
Integer TOPO	topological bus code (input). TOPO = 0 exclude (i.e., for a bus with multiple sections, only one bus section is included) TOPO = 1 include (i.e., for a bus with multiple sections, all bus sections are included)
Integer IERR	error code (output). IERR = 0 no error; 'NXTBUS_2' is properly initialized IERR = 1 bus not found; 'NXTBUS_2' may not be used IERR = 2 invalid MSL value; 'NXTBUS_2' may not be used IERR = 3 invalid TOPO value; 'NXTBUS_2' may not be used

10.106. INIBUX

Initializes the bus fetching routine 'NXTBUS' for retrieving buses in ascending numerical order. Dummy buses of multisection lines are excluded. Hidden star point buses of three-winding transformers are excluded.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inibux(ibus)
```

Fortran command syntax:

```
CALL INIBUX(IBUS, IERR)
```

IPLAN command syntax:

```
CALL INIBUX(IBUS, IERR)
```

Where:

Integer IBUS	Starting bus number, 0 for first bus in ordered list (input).	
Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTBUS' properly initialized
	IERR = 1	Bus not found; 'NXTBUS' may not be used

10.107. INIFAX

Initializes the FACTS device fetching routine 'NXTFAX' for retrieving FACTS devices in FACTS device name alphabetical order.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr = inifax()
```

Fortran command syntax:

```
CALL INIFAX(IERR)
```

IPLAN command syntax:

```
CALL INIFAX(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTFAX' is properly initialized
	IERR = 1	No FACTS devices in case; 'NXTFAX' may not be used

10.108. INIFXS

Initializes the fixed bus shunt fetching routine 'NXTFXS' for returning fixed shunts attached to bus IBUS.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr = inifxs(ibus)
```

Fortran command syntax:

```
CALL INIFXS(IBUS, IERR)
```

IPLAN command syntax:

```
CALL INIFXS(IBUS, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NXTFXS' is properly initialized
	IERR = 1	Bus not found; 'NXTFXS' may not be used
	IERR = 2	Bus has no fixed shunts; 'NXTFXS' may not be used

10.109. INIIND

Initializes induction machine fetching routine 'NXTIND' for returning induction machines attached to IBUS.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr = iniind(ibus)
```

Fortran command syntax:

```
CALL INIIND(IBUS, IERR)
```

IPLAN command syntax:

```
CALL INIIND(IBUS, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NXTIND' is properly initialized
	IERR = 1	Bus not found; 'NXTIND' may not be used
	IERR = 2	Bus has no induction machines connected to it; 'NXTIND' may not be used

10.110. INILOD

Initializes load fetching routine 'NXTLOD' for returning loads attached to IBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inilod(ibus)
```

Fortran command syntax:

```
CALL INILOD(IBUS, IERR)
```

IPLAN command syntax:

```
CALL INILOD(IBUS, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NXTLOD' is properly initialized
	IERR = 1	Bus not found; 'NXTLOD' may not be used
	IERR = 2	Bus has no load entries; 'NXTLOD' may not be used

10.111. INIMAC

Initializes machine fetching routine 'NXTMAC' for returning machines attached to IBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inimac(ibus)
```

Fortran command syntax:

```
CALL INIMAC( IBUS, IERR)
```

IPLAN command syntax:

```
CALL INIMAC( IBUS, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NXTMAC' is properly initialized
	IERR = 1	Bus not found; 'NXTMAC' may not be used
	IERR = 2	Bus not a generator bus; 'NXTMAC' may not be used

10.112. INIMDC

Initializes the multi-terminal dc line fetching routine 'NXTMDC' for retrieving multi-terminal dc lines in dc line name alphabetical order.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr = inimdc()
```

Fortran command syntax:

```
CALL INIMDC(IERR)
```

IPLAN command syntax:

```
CALL INIMDC(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTMDC' is properly initialized
	IERR = 1	No multi-terminal dc lines in case; 'NXTMDC' may not be used

10.113. INIMSL

Initializes the multi-section line member fetching routine 'NXTMSL' for retrieving lines that are sections of the specified multi-section line from IBUS to JBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = inimsl(ibus, jbus, ickt)
```

Fortran command syntax:

```
CALL INIMSL(IBUS, JBUS, ICKT, IERR)
```

IPLAN command syntax:

```
CALL INIMSL(IBUS, JBUS, ICKT, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*2 ICKT	Multi-section line identifier (must begin with &) (input).
Integer IERR	error code (output).
	IERR = 0 No error; NXTMSL properly initialized
	IERR = 1 Bus not found; NXTMSL may not be used
	IERR = 2 & not the first character of 'ICKT'; NXTMSL may not be used
	IERR = 3 Multi-section line not found; NXTMSL may not be used

10.114. ININAM

Initializes the bus fetching routine 'NXTBUS' for retrieving buses in ascending alphabetical order. Dummy buses for multisection lines are included. Hidden star point buses of three winding transformers are excluded.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = ininam(string)
```

Fortran command syntax:

```
CALL ININAM(STRING, IERR)
```

IPLAN command syntax:

```
CALL ININAM(STRING, IERR)
```

Where:

Character STRING	Extended bus name, blank for first bus in ordered list (input).	
Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTBUS' is properly initialized
	IERR = 1	Bus not found; 'NXTBUS' may not be used

10.115. ININAM_2

Initializes the bus fetching routine 'NXTBUS_2' for retrieving buses in ascending alphabetical order. Hidden star point buses of three winding transformers are excluded.

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr = ininam_2(string, msl, topo)
```

Fortran command syntax:

```
CALL ININAM_2(String, MSL, TOPO, IERR)
```

IPLAN command syntax:

```
CALL ININAM_2(String, MSL, TOPO, IERR)
```

Where:

Character STRING	extended bus name, blank for first bus in ordered list (input).
Integer MSL	multi-section line interior bus code (input). MSL = 0 exclude MSL = 1 include
Integer TOPO	topological bus code (input). TOPO = 0 exclude (i.e., for a bus with multiple sections, only one bus section is included) TOPO = 1 include (i.e., for a bus with multiple sections, all bus sections are included)
Integer IERR	error code (output). IERR = 0 no error; 'NXTBUS_2' is properly initialized IERR = 1 bus not found; 'NXTBUS_2' may not be used IERR = 2 invalid MSL value; 'NXTBUS_2' may not be used IERR = 3 invalid TOPO value; 'NXTBUS_2' may not be used

10.116. ININAX

Initializes the bus fetching routine 'NXTBUS' for retrieving buses in ascending alphabetical order. Dummy buses of multisection lines are excluded. Hidden star point buses of three winding transformers are excluded.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = ininax(string)
```

Fortran command syntax:

```
CALL ININAX(STRING, IERR)
```

IPLAN command syntax:

```
CALL ININAX(STRING, IERR)
```

Where:

Character STRING	Extended bus name, blank for first bus in ordered list (input).	
Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTBUS' properly initialized
	IERR = 1	Bus not found; 'NXTBUS' may not be used

10.117. INISTABUSSECT

Use this API routine to initialize the bus section fetching routine 'NXTSTABUSSECT' for retrieving the bus sections in a substation.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr = inistabussect(ista)
```

Fortran command syntax:

```
CALL INISTABUSSECT(ISTA, IERR)
```

IPLAN command syntax:

```
CALL INISTABUSSECT(ISTA, IERR)
```

Note:

Initialize the bus section fetching routine 'NXTSTABUSSECT'.

Where:

Integer ISTA	substation number (input).	
Integer IERR	error code (output).	
	IERR = 0	no error; 'NXTSTABUSSECT' is properly initialized
	IERR = 1	substation not found; 'NXTSTABUSSECT' may not be used

10.118. INISTANODE

Use this API routine to initialize the node fetching routine 'NXTSTANODE' for retrieving the nodes in a substation.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr = inistanode(ista)
```

Fortran command syntax:

```
CALL INISTANODE(ISTA, IERR)
```

IPLAN command syntax:

```
CALL INISTANODE(ISTA, IERR)
```

Note:

Initialize the node fetching routine 'NXTSTANODE'.

Where:

Integer ISTA	substation number (input).
Integer IERR	error code (output).
	IERR = 0 no error; 'NXTSTANODE' is properly initialized
	IERR = 1 substation not found; 'NXTSTANODE' may not be used

10.119. INISTASWDEV

Use this API routine to initialize the switching device fetching routine 'NXTSTASWDEV' for retrieving the switching devices in a substation.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr = inistaswdev(ista)
```

Fortran command syntax:

```
CALL INISTASWDEV(ISTA, IERR)
```

IPLAN command syntax:

```
CALL INISTASWDEV(ISTA, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Integer IERR	error code (output).	
	IERR = 0	no error; 'NXTSTASWDEV' is properly initial- ized
	IERR = 1	substation not found; 'NXTSTASWDEV' may not be used

10.120. INISWS

Initializes the switched shunt fetching routine 'NXTSWS' for returning switched shunts attached to bus IBUS.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr = inisws(ibus)
```

Fortran command syntax:

```
CALL INISWS(IBUS, IERR)
```

IPLAN command syntax:

```
CALL INISWS(IBUS, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NXTSWS' is properly initialized
	IERR = 1	Bus not found; 'NXTSWS' may not be used
	IERR = 2	Bus has no switched shunts; 'NXTSWS' may not be used

10.121. INITIE

Initializes the tie branch fetching routine 'NXTTIE' or 'NXTTIE3' for returning tie branches from area IAR. For multisection lines connected to a from area bus, the adjacent dummy bus is treated as the to bus. Dummy buses for multisection lines are included.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = initie(iar)
```

Fortran command syntax:

```
CALL INITIE(IAR, IERR)
```

IPLAN command syntax:

```
CALL INITIE(IAR, IERR)
```

Where:

Integer IAR	From area number (input).
Integer IERR	error code (output).
IERR = 0	No error, 'NXTTIE' or 'NXTTIE3' is properly initialized
IERR = 1	Area number ≤ 0 or $>$ largest allowable area number; 'NXTTIE' or 'NXTTIE3' may not be used
IERR = 2	No buses in area 'IAR'; 'NXTTIE' or 'NXTTIE3' may not be used

10.122. INITIX

Initializes the tie branch fetching routine 'NXTTIE' or 'NXTTIE3' for returning tie branches from area IAR. For multisection lines connected to a from area bus, the other endpoint bus is treated as the to bus. Dummy buses of multisection lines are excluded.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = initix(iar)
```

Fortran command syntax:

```
CALL INITIX(IAR, IERR)
```

IPLAN command syntax:

```
CALL INITIX(IAR, IERR)
```

Where:

Integer IAR	From area number (input).
Integer IERR	error code (output).
	IERR = 0 No error, 'NXTTIE' or 'NXTTIE3' is properly initialized
	IERR = 1 Area number <= 0 or > largest allowable area number; 'NXTTIE' or 'NXTTIE3' may not be used
	IERR = 2 No buses in area 'IAR'; 'NXTTIE' or 'NXTTIE3' may not be used

10.123. INIVSC

Initializes the VSC dc line fetching routine 'NXTVSC' for retrieving VSC dc lines in dc line name alphabetical order.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr = inivsc()
```

Fortran command syntax:

```
CALL INIVSC(IERR)
```

IPLAN command syntax:

```
CALL INIVSC(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error, 'NXTVSC' is properly initialized
	IERR = 1	No VSC dc lines in case; 'NXTVSC' may not be used

10.124. ISLAND

Trips in-service branches connected to Type 4 (or greater) buses, and disconnects islands not containing a swing bus.

Note: Calling ISLAND with generators converted will disconnect all buses.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = island()
```

Fortran command syntax:

```
CALL ISLAND(IERR)
```

IPLAN command syntax:

```
CALL ISLAND(IERR)
```

Note:

Calling ISLAND with generators converted will disconnect all buses.

Where:

Integer IERR	error code (output).
IERR = 0	No errors.
IERR = -1	No in-service buses remaining.
IERR > 0	Number of islands tripped.

10.125. ITERAT

Use this API to return the number of iterations used in the last solution attempt.

This API routine was first introduced in release 30.1.0.

Python command syntax:

```
ival = iterat()
```

Fortran command syntax:

```
CALL ITERAT(IVAL)
```

IPLAN command syntax:

```
CALL ITERAT(IVAL)
```

Where:

Integer IVAL	Number of iterations used in the last solution attempt (output).
--------------	--

10.126. LMODIND

Returns load-related model starting array indices and status.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = lmodind(ibus, id ,string1, string2)
```

Fortran command syntax:

```
CALL LMODIND(IBUS, ID, STRING1, STRING2, IVAL, IERR)
```

IPLAN command syntax:

```
CALL LMODIND(IBUS, ID, STRING1, STRING2, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Load identifier (input).
Character STRING1	String indicating the type of load model desired (input). 'CHARAC' Load characteristic model 'RELAY' Load relay model
Character STRING2	String indicating the load model quantity desired (input). 'CON' Starting CON index 'STATE' Starting STATE index 'VAR' Starting VAR index 'ICON' Starting ICON index 'RESICON' Starting reserved ICON index 'NCON' Number of CON values used by the model 'NSTATE' Number of STATE values used by the model 'NVAR' Number of VAR values used by the model 'NICON' Number of ICON values used by the model 'NRESICON' Number of reserved ICON values used by the model 'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect load status. For a model to be called during simulations the load must be in-service bus type code must be 1 or 2 and the model's bypassed flag must be not bypassed
Integer IVAL	Load model array index or status (output).
Integer IERR	error code (output). IERR = 0 No error; 'IVAL' returned IERR = 1 Load not in network but in model tables; 'IVAL' returned

IERR = 2	Load not in network or in model tables; 'IVAL' unchanged
IERR = 3	Invalid value of 'STRING1'; 'IVAL' unchanged
IERR = 4	No model of type 'STRING1' for this load; 'IVAL' unchanged
IERR = 5	Invalid value of 'STRING2'; 'IVAL' unchanged
IERR = 6	Model does not use any of this data type; 'IVAL' = 0 returned
IERR = 9	Dynamics data not present in working memory; 'IVAL' unchanged

10.127. LMODNAM

Returns load-related model name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = lmodnam(ibus, id ,string)
```

Fortran command syntax:

```
CALL LMODNAM(IBUS, ID, STRING, CVAL, IERR)
```

IPLAN command syntax:

```
CALL LMODNAM(IBUS, ID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Load identifier (input).
Character STRING	String indicating the type of load model desired (input). 'CHARAC' Load characteristic model 'RELAY' Load relay model
Character*16 CVAL	Model name (output).
Integer IERR	error code (output). IERR = 0 No error; 'CVAL' returned IERR = 1 Load not in network but in model tables; 'CVAL' returned IERR = 2 Load not in network or in model tables; 'CVAL' unchanged IERR = 3 Invalid value of 'STRING'; 'CVAL' unchanged IERR = 4 No model of type 'STRING' for this load; 'CVAL' unchanged IERR = 9 Dynamics data not present in working memory; 'CVAL' unchanged

10.128. LODCNV

This obsolete API always returns a 0.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
icode = lodcnv()
```

Fortran command syntax:

```
CALL LODCNV(ICODE)
```

IPLAN command syntax:

```
CALL LODCNV(ICODE)
```

Where:

Integer ICODE	Returns a 0 (output).
---------------	-----------------------

10.129. LODDT1

Returns load quantities in MVA.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = loddt1(ibus, id ,string1, string2)
```

Fortran command syntax:

```
CALL LODDT1(IBUS, ID, STRING1, STRING2, RVAL, IERR)
```

IPLAN command syntax:

```
CALL LODDT1(IBUS, ID, STRING1, STRING2, RVAL, IERR)
```

Note:

When STRNG1 is one of the following: 'MVA', 'IL', 'YL', 'TOTAL', the values returned are the net load values (i.e., value includes load plus contribution from any in-service distributed generation on the load feeder at that bus)

Where:

Integer IBUS	bus number (input).
Character ID	load identifier (input).
Character STRING1	string indicating the load characteristic desired (input). 'MVA' constant MVA load 'IL' constant current load 'YL' constant admittance load 'TOTAL' total load 'YNEG' exceptional nominal negative sequence load 'YZERO' exceptional nominal zero sequence load
Character STRING2	string indicating the units to be used (input). 'ACT' actual load (nominal load for STRING1 = 'YNEG' or 'YZERO'). 'P' 'Q' returned in MW Mvar 'O_ACT' actual load (nominal load for STRING1 = 'YNEG' or 'YZERO'). 'P' 'Q' in units determined by the power output option setting 'NOM' nominal load (at 1.0 pu voltage). 'RVAL' returned in MVA 'O_NOM' nominal load (at 1.0 pu voltage). 'RVAL' in units determined by the power output option setting
Real RVAL	magnitude of the complex value indicated by STRING1 in the units indicated by STRING2 (output).
Integer IERR	error code (output).

IERR = 0	no error; 'RVAL' returned
IERR = 1	Bbus not found; 'RVAL' unchanged
IERR = 2	Load not found; 'RVAL' unchanged
IERR = 3	Bbus type code is not 1, 2 or 3; 'RVAL' returned
IERR = 4	Lload out-of-service; 'RVAL' returned
IERR = 5	Invalid value of 'STRING1' or 'STRING2'; 'RVAL' unchanged
IERR = 6	Sequence data not in case for 'STRING1' = 'YNEG' or 'YZERO'; 'RVAL' unchanged

10.130. LODDT2

Use this API to return complex load quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = loddt2(ibus, id ,string1, string2)
```

Fortran command syntax:

```
CALL LODDT2(IBUS, ID, STRING1, STRING2, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL LODDT2(IBUS, ID, STRING1, STRING2, P, Q, IERR)
```

Note:

When STRNG1 is one of the following: 'MVA', 'IL', 'YL', 'TOTAL', the values returned are the net load values (i.e., value includes load plus the contribution from any in-service distributed generation on the load feeder at that bus)

Where:

Integer IBUS	bus number (input).
Character ID	load identifier (input).
Character STRING1	string indicating the load characteristic desired (input). 'MVA' constant MVA load 'IL' constant current load 'YL' constant admittance load 'TOTAL' total load 'YNEG' exceptional nominal negative sequence load 'YZERO' exceptional nominal zero sequence load
Character STRING2	String indicating the units to be used (input). 'ACT' actual load (nominal load for STRING1 = 'YNEG' or 'YZERO'). 'P' 'Q' returned in MW Mvar 'O_ACT' actual load (nominal load for STRING1 = 'YNEG' or 'YZERO'). 'P' 'Q' in units determined by the power output option setting 'NOM' nominal load (at 1.0 pu voltage). 'P' 'Q' returned in MW Mvar 'O_NOM' nominal load (at 1.0 pu voltage). 'P' 'Q' in units determined by the power output option setting
Real P	real component of complex value indicated by STRING1 in the units indicated by STRING2
Real Q	reactive component of complex value indicated by STRING1 in the units indicated by STRING2

Complex CMPVAL	complex value indicated by STRING1 in the units indicated by STRING2 (output).	
Integer IERR	error code (output).	
	IERR = 0	no error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	load not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3	bus type code is not 1, 2 or 3; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 4	load out-of-service; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 5	invalid value of 'STRING1' or 'STRING2'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 6	sequence data not in case for 'STRING1' = 'YNEG' or 'YZERO'; 'CMPVAL' unchanged

10.131. LODIND

Use this API to return the load array index.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = lodind(ibus, id)
```

Fortran command syntax:

```
CALL LODIND(IBUS, ID, IVAL, IERR)
```

IPLAN command syntax:

```
CALL LODIND(IBUS, ID, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character*2 ID	Load identifier (input).	
Integer IVAL	Load array index (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Bus not found; 'IVAL' unchanged
	IERR = 2	Load not found; 'IVAL' unchanged

10.132. LODINT

Use this API to return integer load quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = lodint(ibus, id, string)
```

Fortran command syntax:

```
CALL LODINT(IBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL LODINT(IBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Load identifier (input).
Character STRING	String indicating the load quantity desired (input).
	'STATION' Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'SECTION' Bus IBUS bus section number (returned as 0 if bus IBUS is not in a substation)
	'NODE' Node number (0 if bus IBUS is not in a substation)
	'STATUS' Load status; 1 (one) for in-service else 0 (zero)
	'AREA' Load area number
	'ZONE' Load zone number
	'OWNER' Load owner number
	'SCALE' Scalable load flag
	'CGR' Load grounding code (0 for ungrounded 1 for grounded)
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 2 Load not found; 'IVAL' unchanged
	IERR = 3 Bus type code is not 1, 2 or 3; 'IVAL' returned
	IERR = 4 Load out-of-service; 'IVAL' returned
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Sequence data not in case for 'STRING1' = 'CGR'; 'IVAL' unchanged

10.133. LODTYPE

Use this API to return the load type character string.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, string = lodtype(ibus, id)
```

Fortran command syntax:

```
CALL LODTYPE(IBUS, ID, STRING, IERR)
```

IPLAN command syntax:

```
CALL LODTYPE(IBUS, ID, STRING, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Load identifier (input; no default allowed).
Character*12 STRING	String indicating the load type (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'STRING' returned
	IERR = 1 Bus not found; 'STRING' unchanged
	IERR = 2 Load not found; 'STRING' unchanged
	IERR = 3 Bus type code is not 1, 2 or 3; 'STRING' re- turned
	IERR = 4 Load out-of-service; 'STRING' returned

10.134. MACCHR

Use this API to return character machine quantities.

This API routine was first introduced in release 35.2.0.

Python command syntax:

```
ierr, cval = macchr(ibus, id, string)
```

Fortran command syntax:

```
CALL MACCHR(IBUS, ID, STRING, CVAL, IERR)
```

IPLAN command syntax:

```
CALL MACCHR(IBUS, ID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING	String indicating the machine quantity desired (input).
	'POSTBL' Non-conventional source positive sequence table (12 characters).
	'NEGTBL' Non-conventional source negative sequence table (12 characters).
character*12 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Bus not found; 'CVAL' unchanged
	IERR = 2 Machine not found; 'CVAL' unchanged
	IERR = 3 Bus type code is not 2 or 3; 'CVAL' returned
	IERR = 4 Machine off-line, 'CVAL' returned
	IERR = 5 Invalid value of 'STRING'; 'CVAL' unchanged
	IERR = 6 Sequence data not in case; 'CVAL' unchanged
	IERR = 7 No non-conventional source data for this machine; 'CVAL' unchanged

10.135. MACDAT

Use this API to return real machine quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = macdat(ibus, id, string)
```

Fortran command syntax:

```
CALL MACDAT(IBUS, ID, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL MACDAT(IBUS, ID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING	String indicating the machine quantity desired (input).
	'QMAX' Maximum generator reactive output in Mvar
	'O_QMAX' Same as 'QMAX' in units determined by the power output option setting
	'QMIN' Minimum generator reactive output in Mvar
	'O_QMIN' Same as 'QMIN' in units determined by the power output option setting
	'PMAX' Maximum generator active output in MW
	'O_PMAX' Same as 'PMAX' in units determined by the power output option setting
	'PMIN' Minimum generator real active in MW
	'O_PMIN' Same as 'PMIN' in units determined by the power output option setting
	'MBASE' Total MVA base
	'MVA' Machine loading in MVA
	'O_MVA' Same as 'MVA' in units determined by the power output option setting
	'P' Machine loading in MW
	'O_P' Same as 'P' in units determined by the power output option setting
	'Q' Machine loading in Mvar
	'O_Q' Same as 'Q' in units determined by the power output option setting
	'PERCENT' MVA loading of the machines as a percentage of machine base
	'GENTAP' Step-up transformer off-nominal turns ratio
	'VSCHED' Regulated voltage setpoint

	'WPF'	'WPF' Power factor used in setting reactive power limits for this wind machine when WMOD is 2 or 3
	'FRACT1'	Fraction of total ownership assigned to the first owner
	'FRACT2'	Fraction of total ownership assigned to the second owner
	'FRACT3'	Fraction of total ownership assigned to the third owner
	'FRACT4'	Fraction of total ownership assigned to the fourth owner
	'RMPCT'	Percentage of total MVAR required to regulate remote bus voltage
	'RPOS'	Positive sequence fault analysis machine resistance
	'XSUBTR'	Positive sequence fault analysis machine sub-transient reactance
	'XTRANS'	Positive sequence fault analysis machine transient reactance
	'XSYNCH'	Positive sequence fault analysis machine synchronous reactance
	'IFMAX'	Non-conventional source per unit maximum total fault current magnitude
	'DBVMIN'	Non-conventional source per unit dead-band minimum voltage
	'DBVMAX'	Non-conventional source per unit dead-band maximum voltage
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Machine not found; 'RVAL' unchanged
	IERR = 3	Bus type code is not 2 or 3; 'RVAL' returned
	IERR = 4	Machine off-line; 'RVAL' returned
	IERR = 5	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 6	For STRING = 'FRACTn', n > number of owners; 'RVAL' unchanged
	IERR = 7	For STRING = 'WPF', this machine is not a wind machine; 'RVAL' of 1.0 returned
	IERR = 8	Sequence data not in case for STRING = 'RPOS', 'XSUBTR', 'XTRANS', 'XSYNCH', 'IFMAX', 'DBVMIN' or 'DBVMAX'; 'RVAL' unchanged
	IERR = 9	No non-conventional source data for this machine for STRING = 'IFMAX', 'DBVMIN' or 'DBVMAX'; 'RVAL' unchanged

10.136. MACDT2

Use this API to return complex machine quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = macdt2(ibus, id, string)
```

Fortran command syntax:

```
CALL MACDT2(IBUS, ID, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL MACDT2(IBUS, ID, STRING, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING	String indicating the machine quantity desired (input).
	'PQ' Actual generator power output in MW/Mvar
	'O_PQ' Same as 'PQ' in units determined by the power output option setting
	'ZSORCE' Machine impedance
	'XTRAN' Step-up transformer impedance
	'ZPOS' Positive sequence fault analysis machine impedance ($R_{pos} + j X$)
	'ZNEG' Negative sequence machine impedance
	'ZZERO' Zero sequence machine impedance
	'ZGRND' Zero sequence grounding impedance in per unit or ohms according to the machine's grounding impedance data input/output code
	'ZGRNDPU' Zero sequence grounding impedance in per unit
Real P	Real component of the complex value indicated by STRING (output).
Real Q	Reactive component of the complex value indicated by STRING (output).
Complex CMPVAL	Complex value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Machine not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Bus type code is not 2 or 3; 'P' and 'Q' or 'CMPVAL' returned

IERR = 4	Machine off-line; 'P' and 'Q' or 'CMPVAL' returned
IERR = 5	Invalid value of 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 6	Sequence data not in case for STRING = 'ZPOS', 'ZNEG', or 'ZZERO', 'ZGRND', or 'ZGRNDPU'; 'P' and 'Q' or 'CMPVAL' unchanged

10.137. MACIND

Use this API to return the machine array index.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = macind(ibus, id)
```

Fortran command syntax:

```
CALL MACIND(IBUS, ID, IVAL, IERR)
```

IPLAN command syntax:

```
CALL MACIND(IBUS, ID, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character*2 ID	Machine identifier (input).	
Integer IVAL	Machine array index (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Bus not found; 'IVAL' unchanged
	IERR = 2	Machine not found; 'IVAL' unchanged

10.138. MACINT

Use this API to return integer machine quantities.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = macint(ibus, id, string)
```

Fortran command syntax:

```
CALL MACINT(IBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL MACINT(IBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING	String indicating the machine quantity desired (input).
	'STATION' Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'SECTION' Bus IBUS bus section number (returned as 0 if bus IBUS is not in a substation)
	'NODE' Number of the node to which the machine is connected (returned as 0 if bus IBUS is not in a substation)
	'STATUS' Machine status; 1 (one) for in-service else 0 (zero)
	'IREG' Bus number of regulated bus
	'NREG' Node number of regulated node
	'BASFLG' Baseloaded flag value
	'OWNERS' Number of owners
	'WMOD' Wind machine reactive power limits mode; 0 if this machine is not a wind machine
	'OWN1' Owner number of the first owner
	'OWN2' Owner number of the second owner
	'OWN3' Owner number of the third owner
	'OWN4' Owner number of the fourth owner
	'PERCENT' MVA loading of the machine as a percentage of machine base
	'CZG' Grounding impedance data input/output code
	'NCSTYP' Non-conventional source characteristic type
Integer IVAL	Value indicated by STRING (output).
integer IERR	error code (output).

IERR = 0	No error; 'IVAL' returned
IERR = 1	Bus not found; 'IVAL' unchanged
IERR = 2	Machine not found; 'IVAL' unchanged
IERR = 3	Bus type code is not 2 or 3; 'IVAL' returned
IERR = 4	Machine off-line, 'IVAL' returned
IERR = 5	Invalid value of 'STRING'; 'IVAL' unchanged
IERR = 6	For STRING = 'OWNn', n> number of owners; 'IVAL' unchanged
IERR = 7	Sequence data not in case for STRING = 'CZG' or 'NCSTYP'; 'IVAL' unchanged

10.139. MACSTT

Use this API to return the machine status value.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = macstt(ibus, id)
```

Fortran command syntax:

```
CALL MACSTT(IBUS, ID, IVAL, IERR)
```

IPLAN command syntax:

```
CALL MACSTT(IBUS, ID, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Machine identifier (input).
Integer IVAL	Machine status value; 0 for out of service, 1 for in service (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 2 Machine not found; 'IVAL' unchanged

10.140. MAXMSM

Use this API to return the complex bus mismatch at the bus with the largest MVA mismatch.

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, ibus, cmpval = maxmsm()
```

Fortran command syntax:

```
CALL MAXMSM(IBUS, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL MAXMSM(IBUS, P, Q, IERR)
```

Where:

Integer IBUS	Bus number of the bus with the largest MVA mismatch (input).	
Real P	Real component (MW) of the bus mismatch (output).	
Real Q	Reactive component (Mvar) of the bus mismatch (output).	
Complex CMPVAL	Complex bus mismatch (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IBUS', and 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	No in-service buses found; 'IBUS' of 0, and 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.141. MDLIND

Use this API to return plant-related model starting array indices and status.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = mdlind(ibus, id, string1, string2)
```

Fortran command syntax:

```
CALL MDLIND(IBUS, ID, STRING1, STRING2, IVAL, IERR)
```

IPLAN command syntax:

```
CALL MDLIND(IBUS, ID, STRING1, STRING2, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING1	String indicating the type of plant-related model (input). 'GEN' Generator model 'COMP' Compensator model 'STAB' Stabilizer model 'EXC' Excitation system model 'GOV' Turbine governor model 'TLC' Turbine Load Controller model 'MINXL' Minimum excitation limiter model 'MAXXL' Maximum excitation limiter model
Character STRING2	String indicating the plant-related model quantity desired (input). 'CON' Starting CON index 'STATE' Starting STATE index 'VAR' Starting VAR index 'ICON' Starting ICON index 'NCON' Number of CON values used by the model 'NSTATE' Number of STATE values used by the model 'NVAR' Number of VAR values used by the model 'NICON' Number of ICON values used by the model 'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect machine status. For a model to be called during simulations the machine must be in service the type code of the bus must be 2 and the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING Integer (output).
Integer IERR	error code (output).

IERR = 0	No error; 'IVAL' returned
IERR = 1	Machine not in network but in model tables; 'IVAL' returned
IERR = 2	Machine not in network or in model tables; 'IVAL' unchanged
IERR = 3	Invalid value of 'STRING1', 'IVAL' unchanged
IERR = 4	No model of type 'STRING1' for this machine; 'IVAL' unchanged
IERR = 5	Invalid value of 'STRING2'; 'IVAL' unchanged
IERR = 6	Model does not use any of this data type; 'IVAL' = 0 returned
IERR = 9	Dynamics data not present in working memo- ry; 'IVAL' unchanged

10.142. MDLLIBCNT

Use this API to return the number of libraries in the list to be searched for dynamics library models.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
nstr = mdllicnt()
```

Fortran command syntax:

```
CALL GETMODELLIBRARYCOUNT(NSTR)
```

IPLAN command syntax:

```
CALL MDLLIBCNT(NSTR)
```

Where:

Integer NSTR	number of libraries in the list (output).
--------------	---

10.143. MDLNAM

Use this API to return plant-related model name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = mdlnam(ibus, id, string)
```

Fortran command syntax:

```
CALL MDLNAM(IBUS, ID, STRING, CVAL, IERR)
```

IPLAN command syntax:

```
CALL MDLNAM(IBUS, ID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING	String indicating the type of plant-related model (input).
	'GEN' Generator model
	'COMP' Compensator model
	'STAB' Stabilizer model
	'EXC' Excitation system model
	'GOV' Turbine governor model
	'TLC' Turbine Load Controller model
	'MINXL' Minimum excitation limiter model
	'MAXXL' Maximum excitation limiter model
Character*16 CVAL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Machine not in network but in model tables; 'CVAL' returned
	IERR = 2 Machine not in network or in model tables; 'CVAL' unchanged
	IERR = 3 Invalid value of 'STRING', 'CVAL' unchanged
	IERR = 4 No model of type 'STRING' for this machine; 'CVAL' unchanged
	IERR = 9 Dynamics data not present in working memory; 'CVAL' unchanged

10.144. MDLPGMCNT

Use this API to returns the number of model programs loaded from dynamics model libraries.

This API routine was first introduced in release 33.3.0.

Python command syntax:

```
nsiz = mdlpgmcnt()
```

Fortran command syntax:

```
CALL GETMODELPROGRAMCOUNT(NSIZ)
```

IPLAN command syntax:

```
CALL MDLPGMCNT(NSIZ)
```

Where:

Integer NSIZ	number of programs loaded (output).
--------------	-------------------------------------

10.145. NATONO

Use this API to return the bus number for a specified 18-character extended bus name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ibus = natono(string)
```

Fortran command syntax:

```
CALL NATONO(STRING, IBUS, IERR)
```

IPLAN command syntax:

```
CALL NATONO(STRING, IBUS, IERR)
```

Where:

Character STRING	Extended bus name (input).	
Integer IBUS	Bus number (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IBUS' returned
	IERR = 1	Bus not found; 'IBUS' unchanged

10.146. NOTONA

Use this API to return the bus 18-character extended bus name for a specified bus number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = notona(ibus)
```

Fortran command syntax:

```
CALL NOTONA(IBUS, CVAL, IERR)
```

IPLAN command syntax:

```
CALL NOTONA(IBUS, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character*18 CVAL	Extended bus name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Bus not found; 'CVAL' unchanged
	IERR = 2	'CVAL' not long enough to contain entire extended bus name; 'CVAL' unchanged

10.147. NOTONASECT

Use this API to return the bus 18-character extended bus name for a specified bus section.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, busname = notona(ibus, isect)
```

Fortran command syntax:

```
CALL NOTONASECT( IBUS, ISECT, BUSNAME, IERR)
```

IPLAN command syntax:

```
CALL NOTONASECT( IBUS, ISECT, BUSNAME, IERR)
```

Where:

Integer IBUS	bus number (input).	
Integer ISECT	section number; ISECT is returned as 0 if bus IBUS is not represented by multiple bus sections (output).	
Character*18 BUSNAME	bus name (output).	
Integer IERR	error code (output).	
	IERR = 0	no error; 'STRING' returned
	IERR = 1	bus not found; 'STRING' unchanged
	IERR = 2	'STRING' smaller than CHARACTER*16; 'STRING' unchanged

10.148. NXT2DC

Returns the next two-terminal dc line in dc line name alphabetical order. The routine INI2DC must be called first.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, string = nxt2dc()
```

Fortran command syntax:

```
CALL NXT2DC(STRING, IERR)
```

IPLAN command syntax:

```
CALL NXT2DC(STRING, IERR)
```

Where:

Character*12 STRING	Two-terminal dc line name (output).
Integer IERR	error code (output).
IERR = 0	No error; 'STRING' returned
IERR = 1	No more two-terminal dc lines; 'STRING' unchanged
IERR = 2	'INI2DC' was not called; 'STRING' unchanged
IERR = 3	'STRING' not long enough to contain entire dc line name; 'STRING' returned but contains a truncated dc line name

10.149. NXTBRN

Returns the next branch connected to a bus, excluding three-winding transformers. Each time 'NXTBRN' is called it returns the next branch in either numeric or alphabetic ascending order, depending on the PSSE bus output option setting. 'INIBRN' or 'INIBRX' must first be called to establish the from bus number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, jbus, ickt = nxtbrn(ibus)
```

Fortran command syntax:

```
CALL NXTBRN(IBUS, JBUS, ICKT, IERR)
```

IPLAN command syntax:

```
CALL NXTBRN(IBUS, JBUS, ICKT, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (output).
Character*2 ICKT	Circuit identifier (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'JBUS' and 'ICKT' returned
	IERR = 1 No more branches from 'IBUS'; 'JBUS' is re-

10.150. NXTBRN3

Returns the next branch connected to a bus, including three-winding transformers. Each time 'NXTBRN3' is called it returns the next branch in either numeric or alphabetic ascending order, depending on the PSSE bus output option setting. 'INIBRN' or 'INIBRX' must first be called to establish the from bus number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, jbus, kbus, ickt = nxtbrn3(ibus)
```

Fortran command syntax:

```
CALL NXTBRN3(IBUS, JBUS, KBUS, ICKT, IERR)
```

IPLAN command syntax:

```
CALL NXTBRN3(IBUS, JBUS, KBUS, ICKT, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (output).
Integer KBUS	Third bus number (output).
Character*2 ICKT	Circuit identifier (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'JBUS' and 'ICKT' returned
	IERR = 1 No more branches from 'IBUS'; 'JBUS', 'KBUS'
	are returned set to 0, and 'ICKT' returned set
	to spaces
	IERR = 2 'INIBRN' or 'INIBRX' was not called for bus
	'IBUS'; 'JBUS', 'KBUS', and 'ICKT' are un-
	changed

10.151. NXTBRN3_2

Returns the next branch connected to a bus section, including three-winding transformers. Each time 'NXTBRN3_2' is called it returns the next branch in either numeric or alphabetic ascending order, depending on the PSSE bus output option setting. 'INIBRN' or 'INIBRX_2' must first be called to establish the from bus number.

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr, jbus, jsect, kbus, ksect, ckt = nxtbrn3_2(ibus, inode)
```

Fortran command syntax:

```
CALL NXTBRN3_2(IBUS, INODE, JBUS, JSECT, KBUS, KSECT, CKT, IERR)
```

IPLAN command syntax:

```
CALL NXTBRN3_2(IBUS, INODE, JBUS, JSECT, KBUS, KSECT, CKT, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer INODE	from bus node number (input).
Integer JBUS	to bus number (output).
Integer JSECT	to bus section number (output).
Integer KBUS	third bus number (output).
Integer KSECT	third bus section number (output).
Character*2 CKT	circuit identifier (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'JBUS', 'JSECT', 'KBUS', 'KSECT' and 'CKT' returned
	IERR = 1 no more branches from 'IBUS' and 'INODE'; 'JBUS', 'KBUS', 'JSECT', 'KSECT' are returned set to 0, and 'CKT' returned set to spaces
	IERR = 2 'INIBRN_2' or 'INIBRX_2' was not called for node 'INODE' of bus 'IBUS'; 'JBUS', 'JSECT', 'KBUS', 'KSECT' and 'CKT' are unchanged

10.152. NXTBRN_2

Returns the next branch connected to a bus, excluding three-winding transformers. Each time 'NXTBRN_2' is called it returns the next branch in either numeric or alphabetic ascending order, depending on the PSSE bus output option setting. 'INIBRN_2' or 'INIBRX_2' must first be called to establish the from bus number.

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr, jbus, jsect, ckt = nxtbrn_2(ibus, inode)
```

Fortran command syntax:

```
CALL NXTBRN_2(IBUS, INODE, JBUS, JSECT, CKT, IERR)
```

IPLAN command syntax:

```
CALL NXTBRN_2(IBUS, INODE, JBUS, JSECT, CKT, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer INODE	bus section node number (input).
Integer JBUS	to bus number (output).
Integer JSECT	to bus section number (output).
Character*2 CKT	circuit identifier (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'JBUS', 'JSECT', and 'CKT' returned
	IERR = 1 no more branches from 'IBUS' and 'INODE';
	'JBUS', 'JSECT' is returned set to 0, and 'CKT'
	returned set to spaces
	IERR = 2 'INIBRN_2' or 'INIBRX_2' was not called for
	node 'INODE' of bus 'IBUS'; 'JBUS', and 'CKT'
	are unchanged

10.153. NXTBUS

Returns the next bus in ordered sequence. One of the routines INIBUS, INIBUX, ININAM or ININAX must be called first. The sequence can also be affected by STAREA, STZONE, and STBSKV (more than one may be used; conditions are applied in an 'AND' fashion).

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ibus, cval = nxtbus()
```

Fortran command syntax:

```
CALL NXTBUS(IBUS, CVAL, IERR)
```

IPLAN command syntax:

```
CALL NXTBUS(IBUS, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (output).
Character*18 CVAL	Extended bus name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IBUS' and 'CVAL' returned
	IERR = 1 No more buses; 'IBUS' and 'CVAL' unchanged
	IERR = 2 'INIBUS', 'INIBUX', 'ININAM' or 'ININAX' was not called; 'IBUS' and 'CVAL' unchanged
	IERR = 3 'STRING' not long enough to contain entire extended bus name; 'IBUS' and 'CVAL' returned but 'CVAL' does not contain any part of the base voltage portion of extended bus name

10.154. NXTBUS_2

Returns the next bus in ordered sequence. One of the routines INIBUS_2 or ININAM_2 must be called first. The sequence can also be affected by STAREA, STZONE, and STBSKV (more than one may be used; conditions are applied in an 'AND' fashion).

This API routine was first introduced in release 34.2.0.

Python command syntax:

```
ierr, ibus, isect, cval = nxtbus_2()
```

Fortran command syntax:

```
CALL NXTBUS_2(IBUS, ISECT, CVAL, IERR)
```

IPLAN command syntax:

```
CALL NXTBUS_2(IBUS, ISECT, CVAL, IERR)
```

Where:

Integer IBUS	bus number (output).
Integer ISECT	bus section number (returned as 0 for a bus represented by a single bus section) (output).
Character*18 CVAL	extended bus name (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'IBUS', 'ISECT' and 'CVAL' returned
	IERR = 1 no more buses; 'IBUS', 'ISECT' and 'CVAL' unchanged
	IERR = 2 'INIBUS_2' or 'ININAM_2' was not called; 'IBUS', 'ISECT' and 'CVAL' unchanged
	IERR = 3 'CVAL' not long enough to contain entire extended bus name; 'IBUS', 'ISECT' and 'CVAL' returned but 'CVAL' does not contain any part of the base voltage portion of extended bus name

10.155. NXTFAX

Returns the next FACTS device in FACTS device name alphabetical order. The routine INIFAX must be called first.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, string = nxtfax()
```

Fortran command syntax:

```
CALL NXTFAX(STRING, IERR)
```

IPLAN command syntax:

```
CALL NXTFAX(STRING, IERR)
```

Where:

Character*12 STRING	FACTS device name (output).
Integer IERR	error code (output).
IERR = 0	No error; 'STRING' returned
IERR = 1	No more FACTS devices; 'STRING' unchanged
IERR = 2	'INIFAX' was not called; 'STRING' unchanged
IERR = 3	'STRING' not long enough to contain entire FACTS device name; 'STRING' returned but contains a truncated FACTS device name

10.156. NXTFXS

Use this API to return the identifier of the next fixed shunt connected to a bus. Each time 'NXTFXS' is called it returns the next shunt identifier in ascending order. 'INIFXS' must first be called to establish the shunt bus number.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, id = nxtrfs(ibus)
```

Fortran command syntax:

```
CALL NXTFXS(IBUS, ID, IERR)
```

IPLAN command syntax:

```
CALL NXTFXS(IBUS, ID, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Shunt identifier (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'ID' returned
	IERR = 1 No more fixed shunts at 'IBUS'; 'ID' unchanged
	IERR = 2 'INIFXS' was not called for bus 'IBUS'; 'ID' unchanged

10.157. NXTIND

Use this API routine to return the identifier of the next induction machine connected to a bus. Each time 'NXTIND' is called it returns the next induction machine identifier in ascending order. 'INIIND' must first be called to establish the induction machine bus number.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, id = nxtind(ibus)
```

Fortran command syntax:

```
CALL NXTIND(IBUS, ID, IERR)
```

IPLAN command syntax:

```
CALL NXTIND(IBUS, ID, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character*2 ID	Induction machine identifier (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'ID' returned
	IERR = 1	No more induction machines at 'IBUS'; 'ID' unchanged
	IERR = 2	'INIIND' was not called for bus 'IBUS'; 'ID' unchanged

10.158. NXTLOD

Use this API to return the identifier of the next load connected to a bus. Each time 'NXTLOD' is called it returns the next load identifier in ascending order. 'INILOD' must first be called to establish the load bus number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, id = nxtlod(ibus)
```

Fortran command syntax:

```
CALL NXTLOD(IBUS, ID, IERR)
```

IPLAN command syntax:

```
CALL NXTLOD(IBUS, ID, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Load identifier (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'ID' returned
	IERR = 1 No more loads at 'IBUS'; 'ID' unchanged
	IERR = 2 'INILOD' was not called for bus 'IBUS'; 'ID' unchanged

10.159. NXTMAC

Use this API to return the identifier of the next machine connected to a bus. Each time 'NXTMAC' is called it returns the next machine identifier in ascending order. 'INIMAC' must first be called to establish the plant bus number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, id = nxtmac(ibus)
```

Fortran command syntax:

```
CALL NXTMAC(IBUS, ID, IERR)
```

IPLAN command syntax:

```
CALL NXTMAC(IBUS, ID, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	Machine identifier (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'ID' returned
	IERR = 1 No more machines at 'IBUS'; 'ID' unchanged
	IERR = 2 'INIMAC' was not called for bus 'IBUS'; 'ID' unchanged

10.160. NXTMDC

Returns the next multi-terminal dc line in dc line name alphabetical order. The routine INIMDC must be called first.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, string = nxtdmc()
```

Fortran command syntax:

```
CALL NXTMDC(STRING, IERR)
```

IPLAN command syntax:

```
CALL NXTMDC(STRING, IERR)
```

Where:

Character*12 STRING	Multi-terminal dc line name (output).
Integer IERR	error code (output).
IERR = 0	No error; 'STRING' returned
IERR = 1	No more multi-terminal dc lines; 'STRING' unchanged
IERR = 2	'INIMDC' was not called; 'STRING' unchanged
IERR = 3	'STRING' not long enough to contain entire dc line name; 'STRING' returned but contains a truncated dc line name

10.161. NXTMSL

Use this API to return the next multi-section line member branch.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ibus, jbus, ickt = nxtmsl()
```

Fortran command syntax:

```
CALL NXTMSL( IBUS, JBUS, ICKT, IERR)
```

IPLAN command syntax:

```
CALL NXTMSL( IBUS, JBUS, ICKT, IERR)
```

Where:

Integer IBUS	From bus number (output).
Integer JBUS	To bus number (output).
Character*2 ICKT	Multi-section line identifier (output).
Integer IERR	error code (output).
IERR = 0	No error; 'IBUS', 'JBUS', and 'ICKT' returned
IERR = 1	No more branches in multi-section line; 'IBUS', 'JBUS', and 'ICKT' unchanged
IERR = 2	& not the first character of 'ICKT'; NXTMSL may not be used
IERR = 3	INIMSL was not called; 'IBUS', 'JBUS', and 'ICKT' unchanged

10.162. NXTSTABUSSECT

Use this API routine to retrieve the next bus section in the specified substation. The routine IniStaBusSect must be called first with the same substation number.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, ibus, sect = nxtstabussect(ista)
```

Fortran command syntax:

```
CALL NXTSTABUSSECT(ISTA, IBUS, SECT, IERR)
```

IPLAN command syntax:

```
CALL NXTSTABUSSECT(ISTA, IBUS, SECT, IERR)
```

Where:

Integer ISTA	Substation number (input).
Integer IBUS	Bus number (input).
Integer SECT	Bus section number (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IBUS' and 'SECT' are returned
	IERR = 1 No more bus sections in this substation; 'IBUS' and 'SECT' are returned as zero
	IERR = 2 'IniStaBusSect' was not called for this substation; 'IBUS' and 'SECT' unchanged

10.163. NXTSTANODE

Use this API routine to retrieve the next node in the specified substation. The routine IniStaNode must be called first with the same substation number.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, node = nxtstanode(ista)
```

Fortran command syntax:

```
CALL NXTSTANODE(ISTA, NODE, IERR)
```

IPLAN command syntax:

```
CALL NXTSTANODE(ISTA, NODE, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Integer NODE	Node number (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NODE' is returned
	IERR = 1	No more nodes in this substation; 'NODE' is returned as zero
	IERR = 2	'IniStaNode' was not called for this substation; 'NODE' unchanged

10.164. NXTSTASWDEV

Use this API routine to retrieve the next switching device in the specified substation. The routine IniStaSwDev must be called first with the same substation number.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, inode, jnode, id = nxtstaswdev(ista)
```

Fortran command syntax:

```
CALL NXTSTASWDEV(ISTA, INODE, JNODE, ID, IERR)
```

IPLAN command syntax:

```
CALL NXTSTASWDEV(ISTA, INODE, JNODE, ID, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Integer INODE	"From" node number (output).	
Integer JNODE	"To" node number (output).	
Character*2 ID	Switching device identifier (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'INODE', 'JNODE' and 'ID' are returned
	IERR = 1	No more switching devices in this substation; 'INODE' and 'JNODE' are returned as zero, and 'ID' is returned as blanks
	IERR = 2	'IniStaSwDev' was not called for this substation; 'INODE', 'JNODE' and 'ID' unchanged

10.165. NXTSWS

Use this API to return the identifier of the next switched shunt connected to a bus. Each time 'NXTSWS' is called it returns the next shunt identifier in ascending order. 'INISWS' must first be called to establish the shunt bus number.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, id = nextsws(ibus)
```

Fortran command syntax:

```
CALL NXTSWS(IBUS, ID, IERR)
```

IPLAN command syntax:

```
CALL NXTSWS(IBUS, ID, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character*2 ID	Shunt identifier (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'ID' returned
	IERR = 1	No more switched shunts at 'IBUS'; 'ID' unchanged
	IERR = 2	'INISWS' was not called for bus 'IBUS'; 'ID' unchanged

10.166. NXTTIE

Use this API to return the next tie branch from an area, excluding three-winding transformers. IBUS will be in the area IAR specified in the call to 'INITIE' or 'INITIX', which must be called first; JBUS will be in the other area.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ibus, jbus, ickt = nxttie()
```

Fortran command syntax:

```
CALL NXTTIE(IBUS, JBUS, ICKT, IERR)
```

IPLAN command syntax:

```
CALL NXTTIE(IBUS, JBUS, ICKT, IERR)
```

Where:

Integer IBUS	From bus number (output).
Integer JBUS	To bus number (output).
Character*2 ICKT	Circuit identifier (output).
Integer IERR	error code (output).
	IERR = 0 No error, 'IBUS', 'JBUS', and 'ICKT' returned
	IERR = 1 No more tie branches from area 'IAR'; 'IBUS', 'JBUS' returned set to 0, and 'ICKT' set to spaces
	IERR = 2 'INITIE' or 'INITIX' was not called; 'IBUS', 'JBUS' and 'ICKT' unchanged

10.167. NXTTIE3

Use this API to return the next tie branch from an area, including three-winding transformers. IBUS will be in the area IAR specified in the call to 'INITIE' or 'INITIX', which must be called first; JBUS will be in the other area.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ibus, jbus, kbus, ickt = nxttie3()
```

Fortran command syntax:

```
CALL NXTTIE3(IBUS, JBUS, KBUS, ICKT, IERR)
```

IPLAN command syntax:

```
CALL NXTTIE3(IBUS, JBUS, KBUS, ICKT, IERR)
```

Where:

Integer IBUS	From bus number (output).
Integer JBUS	To bus number (output).
Integer KBUS	Third bus number (output).
Character*2 ICKT	Circuit identifier (output).
Integer IERR	error code (output).
IERR = 0	No error, 'IBUS', 'JBUS', 'KBUS', and 'ICKT' returned
IERR = 1	No more tie branches from area 'IAR'; 'IBUS', 'JBUS', 'KBUS' returned set to 0, 'ICKT' returned set to spaces
IERR = 2	'INITIE' or 'INITIX' was not called; 'IBUS', 'JBUS', 'KBUS', and 'ICKT' unchanged

10.168. NXTVSC

Returns the next VSC dc line in dc line name alphabetical order. The routine INIVSC must be called first.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, string = nextvsc()
```

Fortran command syntax:

```
CALL NXTVSC(STRING, IERR)
```

IPLAN command syntax:

```
CALL NXTVSC(STRING, IERR)
```

Where:

Character*12 STRING

VSC dc line name (output).

Integer IERR

error code (output).

IERR = 0

No error; 'STRING' returned

IERR = 1

No more VSC dc lines; 'STRING' unchanged

IERR = 2

'INIVSC' was not called; 'STRING' unchanged

IERR = 3

'STRING' not long enough to contain entire dc line name; 'STRING' returned but contains a truncated dc line name

10.169. OKSTRT

Routine which may be called after activity STRT or MSTR to indicate the presence of INITIAL CONDITIONS SUSPECT errors (for activity STRT) or at least one MODEL NOT AVAILABLE IN MSTR/MRUN message (for MSTR).

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = okstrt()
```

Fortran command syntax:

```
CALL OKSTRT(IERR)
```

IPLAN command syntax:

```
CALL OKSTRT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Simulation initialization errors were detected
	IERR = 9	Dynamics data not present in working memory

10.170. OPENUN

Connects an IPLAN unit number to the Fortran unit used by activity OPEN and returns that IPLAN unit number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
n = openun( )
```

Fortran command syntax:

```
CALL OPENUN(N)
```

IPLAN command syntax:

```
CALL OPENUN(N)
```

Where:

Integer N	IPLAN unit number; zero if no unit is currently open by activity OPEN (output).
-----------	---

10.171. ORDBUS

This API routine returns the bus number corresponding to the specified position in the ordered list (numeric or alphabetic) of non-hidden buses (i.e., star point buses and topological buses are excluded). Dummy buses of multi-section lines are included; hidden star point buses of three-winding transformers are not included; topological buses of buses represented by multiple bus sections are not included.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ibus = ordbus(iord)
```

Fortran command syntax:

```
CALL ORDBUS(IORD, IBUS, IERR)
```

IPLAN command syntax:

```
CALL ORDBUS(IORD, IBUS, IERR)
```

Where:

Integer IORD	Ordinal position; 1 through the number of non-hidden buses in the working case (input).	
Integer IBUS	Bus number (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IBUS' returned
	IERR = 1	'IORD' outside of range 1 through the number of non-hidden buses in the working case; 'IBUS' unchanged

10.172. ORDBUSSECT

This API routine returns the bus number and section number corresponding to the specified position in the ordered list (numeric or alphabetic) of non-star point buses (i.e., star point buses are excluded). Dummy buses of multi-section lines are included; hidden star point buses of three-winding transformers are not included; topological buses of buses represented by multiple bus sections are included.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, ibus, isect = ordbussect(iord)
```

Fortran command syntax:

```
CALL ORDBUSSECT(IORD, IBUS, ISECT, IERR)
```

IPLAN command syntax:

```
CALL ORDBUSSECT(IORD, IBUS, ISECT, IERR)
```

Where:

Integer IORD	Ordinal position; 1 through the number of non-star point buses in the working case (input).	
Integer IBUS	Bus number (output).	
Integer ISECT	Section number; ISECT is returned as 0 if bus IBUS is not represented by multiple bus sections (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IBUS' and 'ISECT' returned
	IERR = 1	'IORD' outside of range 1 through the number of non-start point buses in the working case; 'IBUS' and 'ISECT' unchanged

10.173. OWNDAT

Returns the data associated with an owner ('LOAD' gets loads at buses of owner 'IAR', 'LOADLD' gets loads assigned to owner 'IAR').

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = owndat(iar, string)
```

Fortran command syntax:

```
CALL OWNDAT(IAR, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL OWNDAT(IAR, STRING, P, Q, IERR)
```

Where:

Integer IAR	Owner number (input).	
Character STRING	String indicating the owner total desired (input).	
	'LOAD'	Total owner load by bus owner assignment (net of load plus in-service distributed generation on load feeder)
	'LOADLD'	Total owner load by load owner assignment
	'LDGN'	Total distributed generation on load feeder by bus owner assignment
	'LDGNLD'	Total distributed generation on load feeder by load owner assignment
	'GEN'	Total owner generation
	'LOSS'	Total owner losses; $I^2 * (R + jX)$ for ac branches
	'XFRMAG'	Magnetizing admittance powers for transformers with winding 1 bus in the owner
	'INDMAC'	Total owner induction machine powers by bus owner assignment
	'INDMACMC'	Total owner induction machine powers by machine owner assignment
	'INDGEN'	Total owner induction generator powers by bus owner assignment
	'INDGENMC'	Total owner induction generator powers by machine owner assignment
	'INDMOT'	Total owner induction motor powers by bus owner assignment
	'INDMOTMC'	Total owner induction motor powers by machine owner assignment
Real P	Real component of complex power (output).	

Real Q	Reactive component of complex power (output).	
Complex CMPVAL	Complex power (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	No in-service buses with in-service loads
	IERR = 2	No in-service buses with in-service loads (for 'LOAD'), no in-service loads (for 'LOADLD'), no type 2 or type 3 buses (for 'GEN'), no in-service machines (for 'GENMC'), no in-service branches (for 'LOSS'), no in-service buses with in-service induction machines of the appropriate type (for 'INDMAC', 'INDGEN' and 'INDMOT'), or no inservice induction machines of the appropriate type (for 'INDMACMC', 'INDGENMC' and 'INDMOTMC') in owner; 'P' and 'Q' or 'CMPVAL' unchanged.
	IERR = 3	Owner not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4	Bad 'STRING' value; 'P' and 'Q' or 'CMPVAL' unchanged

10.174. OWNNAM

Returns the owner name for a specified owner number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = ownnam(iar)
```

Fortran command syntax:

```
CALL OWNNAM(IAR, CVAL, IERR)
```

IPLAN command syntax:

```
CALL OWNNAM(IAR, CVAL, IERR)
```

Where:

Integer IAR	Owner number (input).
Character*12 CVAL	Owner name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Owner number <= 0 or > largest allowable owner number; 'CVAL' unchanged
	IERR = 2 Owner not found; 'CVAL' unchanged

10.175. OWNNUM

Returns the owner number for a specified owner name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, iar = ownnum(string)
```

Fortran command syntax:

```
CALL OWNNUM(IAR, STRING, IERR)
```

IPLAN command syntax:

```
CALL OWNNUM(IAR, STRING, IERR)
```

Where:

Integer IAR	Owner number (output).
Character*12 STRING	Owner name (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IAR' returned
	IERR = 1 Owner with name 'STRING' not found; 'IAR' unchanged
	IERR > 1 Multiple owners with the name 'STRING' found; 'IAR' returned as the lowest numbered of these

10.176. OWNUSE

Use this API to indicate whether an owner is in use.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ival = ownuse(iar)
```

Fortran command syntax:

```
CALL OWNUSE(IAR, IVAL)
```

IPLAN command syntax:

```
CALL OWNUSE(IAR, IVAL)
```

Where:

Integer IAR	Owner number (input).
Integer IVAL	Owner status (output).
	IVAL = -1 Owner number ≤ 0 or $>$ largest allowable owner number.
	IVAL = 0 If no equipment is assigned to owner IAR.
	IVAL = 1 If any equipment is assigned to owner IAR.

10.177. PRMDAT

Use this API routine to return real-valued solution parameters.

This API routine was first introduced in release 32.2.0.

Python command syntax:

```
ierr, rval = prmdat(string)
```

Fortran command syntax:

```
CALL PRMDAT(STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL PRMDAT(STRING, RVAL, IERR)
```

Where:

Character STRING	String indicating the solution parameter desired (input).	
	'ACCP'	Gauss-Seidel real component acceleration factor
	'ACQ'	Gauss-Seidel imaginary component acceleration factor
	'ACCM'	special MSLV acceleration factor
	'TOL'	Gauss-Seidel convergence tolerance
	'ACCN'	Newton-Raphson acceleration factor
	'TOLN'	Newton_Raphson mismatch convergence tolerance
	'ACCTY'	TYSL acceleration factor
	'TOLTY'	TYSL convergence tolerance
	'BLOWUP'	blown-up voltage change threshold
	'PQBRK'	constant power load characteristic breakpoint
	'THRSHZ'	zero impedance line threshold
	'ADJTHR'	automatic adjustment threshold tolerance
	'ACCTAP'	tap movement deceleration factor
	'TAPLIM'	maximum tap change per adjustment cycle
	'DVLIM'	largest $\text{abs}(\Delta V) / \text{abs}(V)$ for Newton-Raphson solutions
	'NDVFCT'	non-divergent required improvement factor
	'VCTOLQ'	Newton-Raphson controlled bus reactive power mismatch convergence tolerance
	'VCTOLV'	Newton-Raphson controlled bus voltage error convergence tolerance
	'SWVBND'	percent of voltage controlling band mode switched shunts to be adjusted
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	

IERR = 0	No error; 'RVAL' returned
IERR = 1	Invalid value of 'STRING'; 'RVAL' unchanged

10.178. PRMINT

Use this API routine to return integer-valued solution parameters.

This API routine was first introduced in release 32.2.0.

Python command syntax:

```
ierr, ival = prmint(string)
```

Fortran command syntax:

```
CALL PRMINT(STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL PRMINT(STRING, IVAL, IERR)
```

Where:

Character STRING	String indicating the solution parameter desired (input).	
	'ITMX'	Gauss-Seidel maximum number of iterations
	'ITMXN'	Newton-Raphson maximum number of iterations
	'ITMXTY'	TYSL maximum number of iterations
	'MXT PSS'	maximum number of tap and/or switched shunt adjustment cycles that change data between iterations
	'MXSWIM'	maximum number of induction machine state switchings during a power flow solution
	'PFCODE'	last solution type performed
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Invalid value of 'STRING'; 'IVAL' unchanged

10.179. RATCHR

Use this API to get rating set parameters.

This API routine was first introduced in release 34.0.0.

Python command syntax:

```
ierr, strout = ratchr(ratset, strin)
```

Fortran command syntax:

```
CALL RATCHR(RATSET, STRIN, STROUT, IERR)
```

IPLAN command syntax:

```
CALL RATCHR(RATSET, STRIN, STROUT, IERR)
```

Where:

Integer RATSET	rating set number (1 through 12) (input).	
Character STRIN	(input).	
	'NAME'	column heading (6 characters).
	'DESC'	description (32 characters).
Character*32 STROUT	character string (output).	
Integer IERR	error code (output).	
	IERR = 0	no error; 'STROUT' returned
	IERR = 1	invalid rating set number; 'STROUT' unchanged
	IERR = 2	bad value of 'STRIN'; 'STROUT' unchanged

10.180. RMODIND

Returns the branch relay model starting array indices and status.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = rmodind(ibus, jbus, ckt, slot, string)
```

Fortran command syntax:

```
CALL RMODIND(IBUS, JBUS, CKT, SLOT, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL RMODIND(IBUS, JBUS, CKT, SLOT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Character CKT	circuit identifier (input).
Integer SLOT	relay slot (1 or 2) (input).
Character STRING	string indicating the relay model quantity desired (input).
	'CON' starting CON index
	'STATE' starting STATE index
	'VAR' starting VAR index
	'ICON' starting ICON index
	'NCON' number of CON values used by the model
	'NSTATE' number of STATE values used by the model
	'NVAR' number of VAR values used by the model
	'NICON' number of ICON values used by the model
	'STATUS' bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect branch status. For a model to be called during simulations the branch must be in-service and the model's bypassed flag must be not bypassed
Integer IVAL	branch model index or status (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'IVAL' returned
	IERR = 1 branch not in network but in model tables; 'IVAL' returned
	IERR = 2 branch not in network or in model tables; 'IVAL' unchanged
	IERR = 3 invalid value of 'SLOT'; 'IVAL' unchanged
	IERR = 4 no SLOT 'SLOT' model for this branch; 'IVAL' unchanged

IERR = 5	invalid value of 'STRING'; 'IVAL' unchanged
IERR = 6	model does not use any of this data type; 'IVAL' = 0 returned
IERR = 9	dynamics data not present in working memo- ry; 'IVAL' unchanged

10.181. RMODNAM

Returns the branch relay model name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = rmodnam(ibus, jbus, ickt, slot)
```

Fortran command syntax:

```
CALL RMODNAM(IBUS, JBUS, ICKT, SLOT, CVAL, IERR)
```

IPLAN command syntax:

```
CALL RMODNAM(IBUS, JBUS, ICKT, SLOT, CVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character*16 ICKT	Circuit identifier (input).
Integer SLOT	Relay slot (1 or 2) (input).
Character*16 CVAL	Model name (output).
Integer IERR	error code (output).
IERR = 0	No error; 'CVAL' returned
IERR = 1	Branch not in network but in model tables; 'CVAL' returned
IERR = 2	Branch not in network or in model tables; 'CVAL' unchanged
IERR = 3	Invalid value of 'SLOT'; 'CVAL' unchanged
IERR = 4	No SLOT 'SLOT' model for this branch; 'CVAL' unchanged
IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.182. SBSGTBKV

Use this API to get previously defined bus subsystem voltage limits. It returns BASEKV array used in the definition of BSYS.

This API routine was first introduced in release 34.5.0.

Python command syntax:

```
bskvmn, bskvmx = sbsgtbkv(sidarg)
```

Fortran command syntax:

```
CALL SBSGTBKV(SIDARG, BSKVMN, BSKVMX)
```

Where:

Integer SIDARG	Previously defined valid bus subsystem ID (input; no default allowed).
Real BSKVMN	Minimum basekV limit (output).
Real BSKVMX	Maximum basekV limit (output).

10.183. SC3WND

Returns the three-winding transformer short circuit currents arriving at IBUS following activity SCMU.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr, cmpval = sc3wnd(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL SC3WND(IBUS, JBUS, KBUS, ICKT, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL SC3WND(IBUS, JBUS, KBUS, ICKT, STRING, P, Q, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (string (input)).
Character STRING	String indicating the short circuit current desired (input).
	'IPOS' Positive sequence
	'INEG' Negative sequence
	'IZERO' Zero sequence
	'IA' A-phase
	'IB' B-phase
	'IC' C-phase
Real P	Real component of the complex current indicated by STRING (output).
Real Q	Reactive component of the complex current indicated by STRING (output).
Complex CMPVAL	Complex current indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 'SCINIT' not successfully called; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Branch value not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4 Invalid 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 5 Branch out of service; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.184. SCBRN2

Returns the branch short circuit currents arriving at IBUS following activity SCMU.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = scbrn2(ibus, jbus, ickt, string)
```

Fortran command syntax:

```
CALL SCBRN2(IBUS, JBUS, ICKT, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL SCBRN2(IBUS, JBUS, ICKT, STRING, P, Q, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the short circuit current desired (input).
	'IPOS' Positive sequence
	'INEG' Negative sequence
	'IZERO' Zero sequence
	'IA' A-phase
	'IB' B-phase
	'IC' C-phase
Real P	Real component of the complex current indicated by STRING (output).
Real Q	Reactive component of the complex current indicated by STRING (output).
Complex CMPVAL	Complex current indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 'SCINIT' not successfully called; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Branch not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4 Bad value of 'STRING1'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 5 Branch out of service; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.185. SCBUS2

Returns complex bus voltages and currents following activity SCMU.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = scbus2(ibus, string)
```

Fortran command syntax:

```
CALL SCBUS2(IBUS, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL SCBUS2(IBUS, STRING, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character STRING	String indicating the quantity desired (input).	
	'VPOS'	Positive sequence voltage
	'VNEG'	Negative sequence voltage
	'VZERO'	Zero sequence voltage
	'VA'	A-phase voltage
	'VB'	B-phase voltage
	'VC'	C-phase voltage
	'SHUNTP'	Positive sequence shunt current
	'SHUNTN'	Negative sequence shunt current
	'SHUNTZ'	Zero sequence shunt current
	'SHUNTA'	A-phase shunt current
	'SHUNTB'	B-phase shunt current
	'SHUNTC'	C-phase shunt current
	'FAULTP'	Positive sequence fault current
	'FAULTN'	Negative sequence fault current
	'FAULTZ'	Zero sequence fault current
	'FAULTA'	A-phase fault current
	'FAULTB'	B-phase fault current
	'FAULTC'	C-phase fault current
Real P	Real component of the complex value indicated by STRING (output).	
Real Q	Reactive component of the complex value indicated by STRING (output).	
Complex CMPVAL	Complex value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	'SCINIT' not successfully called; 'P' and 'Q' or 'CMPVAL' unchanged

IERR = 2	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 3	Bad value of 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 4	Bus disconnected; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned
IERR = 5	Bus not faulted; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.186. SCDONE

Use this API to restore the working case after 'SCINIT'.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = scdone()
```

Fortran command syntax:

```
CALL SCDONE(IERR)
```

IPLAN command syntax:

```
CALL SCDONE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	'SCINIT' not successfully called

10.187. SCINIT

Use this API to initialize the short-circuit data retrieval APIs. It must be called when PSSE is at the power flow activity level and must follow each execution of activity SCMU. Can be followed by SCBUS2, SCBRN2, SC3WND and SCMAC2 calls. SCDONE must be called after executing these and before any other calls or PSSE activities can be executed.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = scinit()
```

Fortran command syntax:

```
CALL SCINIT(IERR)
```

IPLAN command syntax:

```
CALL SCINIT(IERR)
```

Where:

Integer IERR

error code (output).

IERR = 0

No error

IERR = 1

Sequence data not in case

IERR = 2

Unable to access SCMU results; one of the following occurred: -No SCMU results file is open. -SCMU results are not compatible with the working case. -Error reading the SCMU results file

10.188. SCMAC2

Use this API to return the machine short circuit currents following activity SCMU.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = scmac2(ibus, ickt, string)
```

Fortran command syntax:

```
CALL SCMAC2(IBUS, ICKT, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL SCMAC2(IBUS, ICKT, STRING, P, Q, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ICKT	Machine identifier (input).
Character STRING	String indicating the short circuit current desired (input).
	'IPOS' Positive sequence
	'INEG' Negative sequence
	'IZERO' Zero sequence
	'IA' A-phase
	'IB' B-phase
	'IC' C-phase
Real P	Real component of the complex current (output).
Real Q	Reactive component of the complex current (output).
Complex CMPVAL	Complex current (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 'SCINIT' not successfully called; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Machine not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4 Bad value of 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 5 Machine out of service; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.189. SELCTR

Use this API to return the activity selector indicator.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ival = selctr()
```

Fortran command syntax:

```
CALL SELCTR(IVAL)
```

IPLAN command syntax:

```
CALL SELCTR(IVAL)
```

Where:

Integer IVAL	Activity indicator (output).
IVAL = 0	Not at 'ACTIVITY'.
IVAL = 1	At power flow activity selector.
IVAL = 2	At dynamics activity selector.

10.190. SETHOMEPATH

Use this API to set a user's HOMEPATH directory.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
sethomepath(sfile)
```

Fortran command syntax:

```
CALL SETHOMPTH(SFILE)
```

IPLAN command syntax:

```
CALL SETHOMEPATH(SFILE)
```

Where:

Character*260 SFILE	user's HOMEPATH directory (input).
---------------------	------------------------------------

10.191. SFILES

Use this API to return the current Saved Case and Snapshot filenames.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
savfilnam, snpfilnam = sfiles()
```

Fortran command syntax:

```
CALL SFILES(SAVFILNAM, SNPFILNAM)
```

IPLAN command syntax:

```
CALL SFILES(SAVFILNAM, SNPFILNAM)
```

Where:

Character*260 SAVFILNAM	Current Saved Case File (output).
Character*260 SNPFILNAM	Current Snapshot File (output).

10.192. SLMODIND

Use this API to return the subsystem load-related model starting array indices and status.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = slmodind(ctype, ibus, id, string1, string2)
```

Fortran command syntax:

```
CALL SLMODIND(CTYPE, ID, IBUS, STRING1, STRING2, IVAL, IERR)
```

IPLAN command syntax:

```
CALL SLMODIND(CTYPE, ID, IBUS, STRING1, STRING2, IVAL, IERR)
```

Where:

Character CTYPE	Subsystem type (input).
	'BUS' Subsystem specified by buses
	'AREA' Subsystem specified by areas
	'ZONE' Subsystem specified by zones
	'OWNER' Subsystem specified by owners
	'ALL' Subsystem of all loads
Integer IBUS	Number of bus, area, zone, or owner, depending on CTYPE. Not used if CTYPE='ALL' (input).
Character ID	Load identifier (input).
Character STRING1	String indicating the type of load model desired (input).
	'CHARAC' Load characteristic model
	'RELAY' Load relay model
Character STRING2	String indicating the load model quantity desired (input).
	'CON' Starting CON index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect load status. For a model to be called during simulations the load must be in-service the bus type code must be 1 or 2 and the model's bypassed flag must be not bypassed
Integer IVAL	Load model index or status (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Invalid value of 'CTYPE'; 'IVAL' unchanged
	IERR = 2 Invalid value of 'STRING1'; 'IVAL' unchanged

IERR = 3	No model of type 'STRING1' for this load; 'IVAL' unchanged
IERR = 4	Invalid value of 'STRING2'; 'IVAL' unchanged
IERR = 5	Model does not use any of this data type; 'IVAL' = 0 returned
IERR = 9	Dynamics data not present in working memo- ry; 'IVAL' unchanged

10.193. SLMODNAM

Use this API to return the subsystem load-related model name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = slmodnam(ctype, ibus, id, string)
```

Fortran command syntax:

```
CALL SLMODNAM(CTYPE, IBUS, ID, STRING, CVAL, IERR)
```

IPLAN command syntax:

```
CALL SLMODNAM(CTYPE, IBUS, ID, STRING, CVAL, IERR)
```

Where:

Character CTYPE	Subsystem type (input).	
	'BUS'	Subsystem specified by buses
	'AREA'	Subsystem specified by areas
	'ZONE'	Subsystem specified by zones
	'OWNER'	Subsystem specified by owners
	'ALL'	Subsystem of all loads
Integer IBUS	Number of bus, area, zone, or owner, depending on CTYPE. Not used if CTYPE='ALL' (input).	
Character ID	Load identifier (input).	
Character STRING	String indicating the type of load model desired (input).	
	'CHARAC'	Load characteristic model
	'RELAY'	Load relay model
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Invalid value of 'CTYPE'; 'CVAL' returned
	IERR = 2	Invalid value of 'STRING'; 'CVAL' unchanged
	IERR = 3	No model of type 'STRING' for this load; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.194. SOLSTR

Use this API to return a string indicating the result of the last solution attempt.

This API routine was first introduced in release 30.1.0.

Python command syntax:

```
desc = solstr()
```

Fortran command syntax:

```
CALL SOLSTR(DESC)
```

IPLAN command syntax:

```
CALL SOLSTR(DESC)
```

Where:

Character*48 DESC	string containing the results of the last solution attempt (output).
-------------------	--

10.195. SOLVED

Use this API to check whether the last solution attempt reached tolerance. This is not a test for whether the working case is a solved case.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ival = solved()
```

Fortran command syntax:

```
CALL SOLVED(IVAL)
```

IPLAN command syntax:

```
CALL SOLVED(IVAL)
```

Where:

Integer IVAL

Solution convergence indicator (output).

IVAL = 0	Met convergence tolerance.
IVAL = 1	Iteration limit exceeded.
IVAL = 2	Blown up (only when non-divergent option disabled).
IVAL = 3	Terminated by non-divergent option.
IVAL = 4	Terminated by console interrupt.
IVAL = 5	Singular Jacobian matrix or voltage of 0.0 detected.
IVAL = 6	Inertial power flow dispatch error (INLF).
IVAL = 7	OPF solution met convergence tolerance (NOPF).
IVAL = 9	Solution not attempted.
IVAL = 10	RSOL converged with Phase shift locked.
IVAL = 11	RSOL converged with TOLN increased.
IVAL = 12	RSOL converged with Y load conversion due to low voltage.

10.196. SOLVED_CA

Use this API to check whether the last corrective action solution attempt reached tolerance.

This API routine was first introduced in release 33.3.0.

Python command syntax:

```
ival = solved_ca()
```

Fortran command syntax:

```
CALL SOLVED_CA(IVAL)
```

IPLAN command syntax:

```
CALL SOLVED_CA(IVAL)
```

Where:

Integer IVAL	Corrective action solution convergence indicator (output).
IVAL = 0	Removed all limit violations successfully
IVAL = 1	Exceeded iteration limit (Number of AC load flows)
IVAL = 2	Terminated with constraint violations
IVAL = 3	Terminated because of insufficient controls
IVAL = 4	Terminated because linear programming model cannot be setup
IVAL = 5	Terminated because Linear Programming solution diverged
IVAL = 6	Terminated because AC load flow exceeded iteration limit
IVAL = 7	Terminated because AC load flow blown up (only when non-divergent option disabled)
IVAL = 8	Terminated because AC load flow terminated by non-divergent option
IVAL = 9	Terminated because AC load flow terminated by console interrupt
IVAL = 10	Terminated because AC load flow terminated by singular jacobian matrix (FNSL) or voltage= 0.0 (FDNS)
IVAL = 13	Terminated because AC load flow converged with stalled and/or tripped induction machines
IVAL = 14	Solution not attempted

10.197. STADAT

Use this API routine to return real substation values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rval = stadat(ista,string)
```

Fortran command syntax:

```
CALL STADAT(ISTA, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL STADAT(ISTA, STRING, RVAL, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Character STRING	String indicating the quantity desired (input).	
	'LATI'	Substation latitude in degrees
	'LONG'	Substation longitude in degrees
	'SRG'	Substation grounding dc resistance in ohms
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Substation not found; 'RVAL' unchanged
	IERR = 2	Invalid value of 'STRING'; 'RVAL' unchanged

10.198. STAINT

Use this API routine to return integer substation values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, ival = staint(ista, string)
```

Fortran command syntax:

```
CALL STAINT(ISTA, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL STAINT(ISTA, STRING, IVAL, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Character STRING	String indicating the quantity desired (input).	
	'NODES'	Number of nodes in the substation
	'PARENTS'	Number of parent buses in the substation
	'SECTIONS'	Number of bus sections in the substation
	'SWDEVS'	Number of switching devices in the substation
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Substation not found; 'IVAL' unchanged
	IERR = 2	Invalid value of 'STRING'; 'IVAL' unchanged

10.199. STANAME

Use this API routine to return a substation's name.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, string = staname(ista)
```

Fortran command syntax:

```
CALL STANAME(ISTA, STRING, IERR)
```

IPLAN command syntax:

```
CALL STANAME(ISTA, STRING, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Character*40 STRING	Substation name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'STRING' returned
	IERR = 1	Substation not found; 'STRING' unchanged

10.200. STANODEINT

Use this API routine to return integer substation values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, ival = stanodeint(ista, node, string)
```

Fortran command syntax:

```
CALL STANODEINT(ISTA, NODE, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL STANODEINT(ISTA, NODE, STRING, IVAL, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Integer NODE	Node number (input).	
Character STRING	String indicating the quantity desired (input).	
	'BUS'	Bus number of the bus section to which the node is connected
	'SECTION'	Section number of the bus section to which the node is connected
	'STATUS'	Node status
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Substation not found; 'IVAL' unchanged
	IERR = 2	Node not found; 'IVAL' unchanged
	IERR = 3	Invalid value of 'STRING'; 'IVAL' unchanged

10.201. STANODENAME

Use this API routine to return the name of a substation node.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, string = stanodename(ista, node)
```

Fortran command syntax:

```
CALL STANODENAME(ISTA, NODE, STRING, IERR)
```

IPLAN command syntax:

```
CALL STANODENAME(ISTA, NODE, STRING, IERR)
```

Where:

Integer ISTA	Substation number (input).	
Integer NODE	Node number (input).	
Character*40 STRING	Node name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'STRING' returned
	IERR = 1	Substation not found; 'STRING' unchanged
	IERR = 2	Node not found; 'STRING' unchanged

10.202. STAREA

Use this API to restrict 'NXTBUS' to a single area. It must be called after INIBUS / INIBUX / ININAM / ININAX.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = starea(iar)
```

Fortran command syntax:

```
CALL STAREA(IAR, IERR)
```

IPLAN command syntax:

```
CALL STAREA(IAR, IERR)
```

Where:

Integer IAR	Area number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid area number

10.203. STASWDEV DAT

Use this API routine to return real substation switching device values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rval = staswdevdat(ista, inode, jnode, id, string)
```

Fortran command syntax:

```
CALL STASWDEV DAT(ISTA, INODE, JNODE, ID, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL STASWDEV DAT(ISTA, INODE, JNODE, ID, STRING, RVAL, IERR)
```

Where:

Integer ISTA	substation number (input).
Integer INODE	"from" node number (input).
Integer JNODE	"to" node number (input).
Character*2 ID	switching device identifier (input).
Character STRING	string indicating the quantity desired (input).
	'X' switching device reactance
	'RATE1' switching device first rating
	'RATE2' switching device second rating
	'RATE3' switching device third rating
	'AMPS' switching device current in amps
	'PUCUR' switching device current in pu
	'P' MW flow at the INODE end
	'O_P' same as P
	'Q' MVAR flow at the INODE end
	'O_Q' same as Q
	'MVA' switching device MVA loading
	'O_MVA' same as MVA
	'PCTRT1' percent current loading of RATE1
	'PCTRT2' percent current loading of RATE2
	'PCTRT3' percent current loading of RATE3
	'PCTMV1' percent MVA loading of RATE1
	'PCTMV2' percent MVA loading of RATE2
	'PCTMV3' percent MVA loading of RATE3
Real RVAL	value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'RVAL' returned
	IERR = 1 substation not found; 'RVAL' unchanged

IERR = 2	node not found; 'RVAL' unchanged
IERR = 3	switching device not found; 'RVAL' unchanged
IERR = 4	invalid value of 'STRING'; 'RVAL' unchanged

10.204. STASWDEVINT

Use this API routine to return integer substation switching device values.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, ival = staswdevint(ista, inode, jnode, id, string)
```

Fortran command syntax:

```
CALL STASWDEVINT(ISTA, INODE, JNODE, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL STASWDEVINT(ISTA, INODE, JNODE, ID, STRING, IVAL, IERR)
```

Where:

Integer ISTA	substation number (input).
Integer INODE	"from" node number (input).
Integer JNODE	"to" node number (input).
Character*2 ID	switching device identifier (input).
Character STRING	string indicating the quantity desired (input).
	'TYPE' switching device type (1 through 3)
	'STATUS' switching device status
	'NSTATUS' switching device normal status
Integer IVAL	value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'IVAL' returned
	IERR = 1 substation not found; 'IVAL' unchanged
	IERR = 2 node not found; 'IVAL' unchanged
	IERR = 3 switching device not found; 'IVAL' unchanged
	IERR = 4 invalid value of 'STRING'; 'IVAL' unchanged

10.205. STASWDEVNAME

Use this API routine to return the name of a substation switching device.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, string = staswdevname(ista, inode, jnode, id)
```

Fortran command syntax:

```
CALL STASWDEVNAME(ISTA, INODE, JNODE, ID, STRING, IERR)
```

IPLAN command syntax:

```
CALL STASWDEVNAME(ISTA, INODE, JNODE, ID, STRING, IERR)
```

Where:

Integer ISTA	substation number (input).
Integer INODE	"from" node number (input).
Integer JNODE	"to" node number (input).
Character*2 ID	switching device identifier (input).
Character*40 STRING	switching device name (output).
Integer IERR	error code (output).
	IERR = 0 no error; 'STRING' returned
	IERR = 1 substation not found; 'STRING' unchanged
	IERR = 2 node not found; 'STRING' unchanged
	IERR = 3 switching device not found; 'STRING' un-
	changed

10.206. STBSKV

Use this API to restrict 'NXTBUS' to a single base voltage level. It must be called after INIBUS / INIBUX / ININAM / ININAX.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = stbskv(bskv)
```

Fortran command syntax:

```
CALL STBSKV(BSKV, IERR)
```

IPLAN command syntax:

```
CALL STBSKV(BSKV, IERR)
```

Where:

Real BSKV	Base kV level (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Negative base voltage

10.207. STZONE

Use this API to restrict 'NXTBUS' to a single zone. It must be called after INIBUS / INIBUX / ININAM / ININAX.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr = stzone(iar)
```

Fortran command syntax:

```
CALL STZONE(IAR, IERR)
```

IPLAN command syntax:

```
CALL STZONE(IAR, IERR)
```

Where:

Integer IAR	Zone number (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Invalid zone number

10.208. SWSBLK

This API routine is obsolete. It has been replaced by the API routine [SWSBLK_2](#).

Use this API to return the switched shunt '1' number of steps and step size for block IBLK.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival, v = swsblk(ibus, iblk)
```

Fortran command syntax:

```
CALL SWSBLK(IBUS, IBLK, IVAL, V, IERR)
```

IPLAN command syntax:

```
CALL SWSBLK(IBUS, IBLK, IVAL, V, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Integer IBLK	Switched shunt block number (input).	
Integer IVAL	Number of steps in block 'IBLK' (output).	
Real V	Admittance in Mvar per step in block 'IBLK' (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' and 'V' returned
	IERR > 0	SWSBLK_2 error code

10.209. SWSBLK_2

Use this API to return data for a specified block of a specified switched shunt.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, istat, nstep, rval = swsblk_2(ibus, id, iblk, string)
```

Fortran command syntax:

```
CALL SWSBLK_2(IBUS, ID, IBLK, STRING, ISTAT, NSTEP, RVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSBLK_2(IBUS, ID, IBLK, STRING, ISTAT, NSTEP, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
character*2 ID	Switched shunt identifier (input).
Integer IBLK	Switched shunt block number (1 through 8) (input).
Character STRING	String indicating the switched shunt quantity desired (input).
	'BSTEP' Admittance in Mvar per step in block "IBLK"
	'PU_ZSTEP' Zero sequence admittance in pu per step in block "IBLK"
	'MVAR_ZSTEP' Zero sequence admittance in Mvar per step in block "IBLK"
Integer ISTAT	Status of block "IBLK" (output).
Integer NSTEP	Number of steps in block "IBLK" (output).
Real RVAL	Admittance value indicated by STRING, per step in block "IBLK" (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'ISTAT', 'NSTEP' and 'RVAL' returned
	IERR = 1 Bus not found; 'ISTAT', 'NSTEP' and 'RVAL' unchanged
	IERR = 2 Switched shunt not found; 'ISTAT', 'NSTEP' and 'RVAL' unchanged
	IERR = 3 Bad value of 'IBLK'; 'ISTAT', 'NSTEP' and 'RVAL' unchanged
	IERR = 4 Bus type code greater than or equal to 4; 'ISTAT', 'NSTEP' and 'RVAL' returned
	IERR = 5 Status is 0; 'ISTAT', 'NSTEP' and 'RVAL' returned
	IERR = 6 Invalid 'STRING'; 'ISTAT', 'NSTEP' and 'RVAL' unchanged
	IERR = 7 Sequence data not in case when STRING is 'PU_ZSTEP' or 'MVAR_ZSTEP'; 'ISTAT', 'NSTEP' and 'RVAL' returned

10.210. SWSBLZ

This API routine is obsolete. It has been replaced by the API routine [SWSBLK_2](#).

Use this API to return the switched shunt '1' number of steps and zero sequence step size in per unit for block IBLK.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival, v = swsblz(ibus, iblk)
```

Fortran command syntax:

```
CALL SWSBLZ(IBUS, IBLK, IVAL, V, IERR)
```

IPLAN command syntax:

```
CALL SWSBLZ(IBUS, IBLK, IVAL, V, IERR)
```

Where:

Integer IBUS	Bus number (input).
Integer IBLK	Switched shunt block number (input).
Integer IVAL	Number of steps in block 'IBLK' (output).
Real V	Admittance in pu per step in block 'IBLK' (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' and 'V' returned
	IERR > 0 SWSBLK_2 error code

10.211. SWSBLZ2

This API routine is obsolete. It has been replaced by the API routine [SWSBLK_2](#).

Use this API to return the switched shunt '1' number of steps and zero sequence step size in Mvar for block IBLK.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, ival, v = swsblz2(ibus, iblk)
```

Fortran command syntax:

```
CALL SWSBLZ2(IBUS, IBLK, IVAL, V, IERR)
```

IPLAN command syntax:

```
CALL SWSBLZ2(IBUS, IBLK, IVAL, V, IERR)
```

Where:

Integer IBUS	Bus number (input).
Integer IBLK	Switched shunt block number (input).
Integer IVAL	Number of steps in block 'IBLK' (output).
Real V	Admittance in Mvar per step in block 'IBLK' (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' and 'V' returned
	IERR > 0 SWSBLK_2 error code

10.212. SWSDAT

This API routine is obsolete. It has been replaced by the API routine [SWSDAT_2](#).

Use this API to return the switched shunt '1' scheduled voltage band.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, vhi, vlo = swsdat(ibus)
```

Fortran command syntax:

```
CALL SWSDAT( IBUS, VHI, VLO, IERR)
```

IPLAN command syntax:

```
CALL SWSDAT( IBUS, VHI, VLO, IERR)
```

Where:

Integer IBUS	Bus number (input).
Real VHI	Desired voltage upper limit (output).
Real VLO	Desired voltage lower limit (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'VHI' and 'VLO' returned
	IERR > 0 SWSDAT_2 error code

10.213. SWSDAT_2

Use this API to return switched shunt real data.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, rval = swsdat_2(ibus, id, string)
```

Fortran command syntax:

```
CALL SWSDAT_2(IBUS, ID, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSDAT_2(IBUS, ID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
character*2 ID	Switched shunt identifier (input).
Character STRING	String indicating the switched shunt quantity desired (input).
	'VSWHI' Controlled quantity upper limit
	'VSWLO' Controlled quantity lower limit
	'RMPCT' Percentage of total Mvar required to regulate controlled bus voltage
	'BINIT' Present admittance switched on in Mvar at unity voltage
	'O_BINIT' Same as 'BINIT' units determined by power output option
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Switched shunt not found; 'RVAL' unchanged
	IERR = 3 Invalid 'STRING'; 'RVAL' unchanged
	IERR = 4 Bus type code greater than or equal to 4; 'RVAL' returned
	IERR = 5 Status is 0; 'RVAL' returned

10.214. SWSDT1

This API routine is obsolete. It has been replaced by the API routine [SWSDAT_2](#).

Use this API to return switched shunt '1' real data.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr, rval = swsdt1(ibus, string)
```

Fortran command syntax:

```
CALL SWSDT1(IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSDT1(IBUS, STRING, RVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character STRING	String indicating the switched shunt quantity desired (input).	
	'VSWHI'	Controlled quantity upper limit
	'VSWLO'	Controlled quantity lower limit
	'RMPCT'	Percentage of total Mvar required to regulate controlled bus voltage
	'BINIT'	Present admittance switched on in Mvar at unity voltage
Integer IERR	'O_BINIT'	Same as 'BINIT' units determined by power output option
	Value indicated by STRING (output).	
	error code (output).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	IERR = 0	No error; 'RVAL' returned
	IERR > 0	SWSDAT_2 error code

10.215. SWSINT

This API routine is obsolete. It has been replaced by the API routine [SWSINT_2](#).

Use this API to return switched shunt '1' integer parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = swsint(ibus, string)
```

Fortran command syntax:

```
CALL SWSINT(IBUS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSINT(IBUS, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character STRING	String indicating the switched shunt quantity desired (input).	
	'STATION'	Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'SECTION'	Bus IBUS bus section number (returned as 0 if bus IBUS is not in a substation)
	'NODE'	Number of the node to which the switched shunt is connected (returned as 0 if bus IBUS is not in a substation)
	'MODE'	Control mode
	'STATUS'	Status flag
	'ADJM'	Adjustment method
	'REMOTE'	Bus number of regulated bus; zero for none
	'IREG'	Bus number of regulated bus; zero for none
	'NREG'	Node number of regulated node
Integer IVAL	'BLOCKS'	Number of blocks
	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR > 0	SWSINT_2 error code

10.216. SWSINT_2

Use this API to return switched shunt integer parameters.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, ival = swsint_2(ibus, id, string)
```

Fortran command syntax:

```
CALL SWSINT_2(IBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSINT_2(IBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
character*2 ID	Switched shunt identifier (input).
Character STRING	String indicating the switched shunt quantity desired (input).
	'STATION' Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'SECTION' Bus IBUS bus section number (returned as 0 if bus IBUS is not represented by multiple bus sections)
	'NODE' Number of the node to which the switched shunt is connected (returned as 0 if bus IBUS is not represented by multiple bus sections)
	'MODE' Control mode
	'STATUS' Status flag
	'ADJM' Adjustment method
	'REMOTE' Bus number of regulated bus; zero for none
	'IREG' Bus number of regulated bus; zero for none
	'NREG' Node number of regulated node
	'BLOCKS' Number of blocks
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 2 Switched shunt not found; 'IVAL' unchanged
	IERR = 3 Bad value of 'STRING'; 'IVAL' unchanged
	IERR = 4 Bus type code greater than or equal to 4; 'IVAL' returned
	IERR = 5 Status is 0; 'IVAL' returned

10.217. SWSMIND

This API routine is obsolete. It has been replaced by the API routine [swsmind_2](#).

In versions prior to 35.0, this API would return switched shunt model starting array indices and status. Starting version 35.0, this API is being retained only for reasons of backward compatibility of python scripts.

Use of this API is not recommended anymore as this will always pick the first switched shunt at a bus.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = swsmind(ibus, string)
```

Fortran command syntax:

```
CALL SWSMIND(IBUS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSMIND(IBUS, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).	
Character STRING	String indicating the switched shunt model quantity desired (input).	
	'CON'	Starting CON index
	'STATE'	Starting STATE index
	'VAR'	Starting VAR index
	'ICON'	Starting ICON index
	'NCON'	Number of CON values used by the model
	'NSTATE'	Number of STATE values used by the model
	'NVAR'	Number of VAR values used by the model
	'NICON'	Number of ICON values used by the model
	'STATUS'	Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect switched shunt status. For a model to be called during simulations the switched shunt must be in service the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Switched shunt not in network but in model tables; 'IVAL' returned
	IERR = 2	Switched shunt not in network or in model tables; 'IVAL' unchanged
	IERR = 4	No model in model tables; 'IVAL' unchanged

IERR = 5	Invalid value of 'STRING'; 'IVAL' unchanged
IERR = 6	Model does not use any of this data type; 'IVAL' = 0 returned
IERR = 7	Bus not found; 'IVAL' unchanged
IERR = 9	Dynamics data not present in working memo- ry; 'IVAL' unchanged

10.218. SWSMIND_2

Use this API to return switched shunt model starting array indices and status.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, ival = swsmind_2(ibus, id, string)
```

Fortran command syntax:

```
CALL SWSMIND_2(IBUS, ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSMIND_2(IBUS, ID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	switched shunt identifier (input; blank by default).
Character STRING	String indicating the switched shunt model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect switched shunt status. For a model to be called during simulations the switched shunt must be in service the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Switched shunt not in network but in model tables; 'IVAL' returned
	IERR = 2 Switched shunt not in network or in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 7 Bus not found; 'IVAL' unchanged

IERR = 9

Dynamics data not present in working memory; 'IVAL' unchanged

10.219. SWSMNAM

This API routine is obsolete. It has been replaced by the API routine [swsmnam_2](#).

In versions prior to 35.0, this API would return switched shunt model name.

Starting version 35.0, this API is being retained only for reasons of backward compatibility of python scripts.

Use of this API is not recommended anymore as this will always pick the first switched shunt at a bus.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = swsmnam(ibus)
```

Fortran command syntax:

```
CALL SWSMNAM(IBUS, CVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSMNAM(IBUS, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*16 CVAL	Model name (output).
Integer IERR	error code (output).
IERR = 0	No error; 'CVAL' returned
IERR = 1	Switched shunt not in network but in model tables; 'CVAL' returned
IERR = 2	Switched shunt not in network or in model tables; 'CVAL' unchanged
IERR = 4	No model in model tables; 'CVAL' unchanged
IERR = 7	Bus not found; 'CVAL' unchanged
IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.220. SWSMNAM_2

Use this API to return switched shunt model name.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, cval = swsmnam_2(ibus,id)
```

Fortran command syntax:

```
CALL SWSMNAM_2(IBUS, ID, CVAL, IERR)
```

IPLAN command syntax:

```
CALL SWSMNAM_2(IBUS, ID, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character*2 ID	switched shunt identifier (input; blank by default).
Character*16 CVAL	Model name (output).
Integer IERR	error code (output).
IERR = 0	No error; 'CVAL' returned
IERR = 1	Switched shunt not in network but in model tables; 'CVAL' returned
IERR = 2	Switched shunt not in network or in model tables; 'CVAL' unchanged
IERR = 4	No model in model tables; 'CVAL' unchanged
IERR = 7	Bus not found; 'CVAL' unchanged
IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.221. SYSMSM

Use this API to return the total system MVA mismatch.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
mva = sysmsm( )
```

Fortran command syntax:

```
CALL SYSMSM(MVA)
```

IPLAN command syntax:

```
CALL SYSMSM(MVA)
```

Where:

Real MVA

Total system MVA mismatch (output).

10.222. SYSMVA

Use this API to return the system base MVA.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
mvabas = sysmva()
```

Fortran command syntax:

```
CALL SYSMVA(MVABAS)
```

IPLAN command syntax:

```
CALL SYSMVA(MVABAS)
```

Where:

Real MVABAS	System base MVA (output).
-------------	---------------------------

10.223. SYSTOT

Use this API to return complex system-wide values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = systot(string)
```

Fortran command syntax:

```
CALL SYSTOT(STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL SYSTOT(STRING, P, Q, IERR)
```

Where:

Character STRING	String indicating the system total desired (input).	
	'LOAD'	Total system load
	'GEN'	Total system generation
	'LOSS'	Total system losses; $I^2 * (R + jX)$ for ac branches
	'XFRMAG'	Total power consumed by transformer magnetizing admittances
	'INDMAC'	Total system induction machine powers
	'INDGEN'	Total system induction generator powers
	'INDMOT'	Total system induction motor powers
	'FACTSH'	Total of FACTS device shunt elements
	'BSSHNT'	Total of bus fixed and switched shunt elements
	'LNSHNT'	Total of line shunts and transformer magnetizing shunt elements
	'ALSHNT'	Total of FACTS device fixed switched line and transformer magnetizing shunt elements
Real P	Real component of the complex power (output).	
Real Q	Reactive component of the complex power (output).	
Complex CMPVAL	Complex power (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Bad 'STRING' value; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	No in-service buses in case; 'P' and 'Q' or 'CMPVAL' unchanged

10.224. TITLDT

Use this API to return the two line case title.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
line1, line2 = titldt()
```

Fortran command syntax:

```
CALL TITLDT(LINE1, LINE2)
```

IPLAN command syntax:

```
CALL TITLDT(LINE1, LINE2)
```

Where:

Character*60 LINE1	First 60-character line (output).
Character*60 LINE2	Second 60-character line (output).

10.225. TOTBUS

Use this API to return the total number of buses in the working case. Dummy buses of multisection lines and star point buses of three-winding transformers are included.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
n = totbus()
```

Fortran command syntax:

```
CALL TOTBUS(N)
```

IPLAN command syntax:

```
CALL TOTBUS(N)
```

Where:

Integer N	Number of buses in the working case. If the working case is empty, then the number of buses returned is zero (output).
-----------	--

10.226. TR3DAT

Use this API to return three-winding transformer real values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = tr3dat(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL TR3DAT(IBUS, JBUS, KBUS, ICT, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL TR3DAT(IBUS, JBUS, KBUS, ICT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICT	Circuit identifier (input).
Character STRING	String indicating the three-winding transformer quantity desired (input).
	'FRACT1' Fraction of total ownership assigned to the first owner
	'FRACT2' Fraction of total ownership assigned to the second owner
	'FRACT3' Fraction of total ownership assigned to the third owner
	'FRACT4' Fraction of total ownership assigned to the fourth owner
	'VMSTAR' Star bus voltage magnitude
	'ANSTAR' Star bus voltage angle in degrees
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Bus not found; 'RVAL' unchanged
	IERR = 2 Three-winding transformer not found; 'RVAL' unchanged
	IERR = 3 Invalid 'STRING'; 'RVAL' unchanged
	IERR = 4 Error fetching transformer data; 'RVAL' unchanged
	IERR = 6 With STRING = FRACTn, n > number of owners; 'RVAL' unchanged

10.227. TR3DT2

Use this API to return three-winding transformer complex values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = tr3dt2(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL TR3DT2(IBUS, JBUS, KBUS, ICKT, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL TR3DT2(IBUS, JBUS, KBUS, ICKT, STRING, P, Q, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the three-winding transformer quantity desired (input).
	'RX1-2' Measured impedance in per unit between the winding 1 and 2 buses
	'RX2-3' Measured impedance in per unit between the winding 2 and 3 buses
	'RX3-1' Measured impedance in per unit between the winding 3 and 1 buses
	'YMAGNT' Magnetizing admittance in pu
	'ZG1', 'ZGRND' Zero-sequence winding 1 grounding impedance
	'Z01' Zero-sequence winding 1 or winding 1 bus to winding 2 bus leakage impedance
	'ZG2' Zero-sequence winding 2 grounding impedance
	'Z02' Zero-sequence winding 2 or winding 2 bus to winding 3 bus leakage impedance
	'ZG3' Zero-sequence winding 3 grounding impedance
	'Z03' Zero-sequence winding 3 or winding 3 bus to winding 1 bus leakage impedance
	'ZNUTRL' Zero-sequence common neutral grounding impedance
Real P	Real component of complex value indicated by STRING (output).
Real Q	Reactive component of complex value indicated by STRING (output).

Complex CMPVAL

Integer IERR

Complex value indicated by STRING (output).

error code (output).

IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
IERR = 1	Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 2	Three-winding transformer not found; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 3	Invalid 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 4	Error fetching transformer data; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 5	Sequence data not in case for 'STRING' = 'ZGRND', 'ZG1', 'Z01', 'ZG2', 'Z02', 'ZG3', 'Z03', or 'ZNUTRL'; 'P' and 'Q' or 'CMPVAL' unchanged

10.228. TR3INT

Use this API to return three-winding transformer integer values.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = tr3int(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL TR3INT(IBUS, JBUS, KBUS, ICKT, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL TR3INT(IBUS, JBUS, KBUS, ICKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the three-winding transformer quantity desired (input).
	'STATUS' Three-winding transformer status
	'NMETER' Non-metered bus number
	'OWNERS' Number of owners
	'OWN1' Owner number of first owner
	'OWN2' Owner number of second owner
	'OWN3' Owner number of third owner
	'OWN4' Owner number of fourth owner
	'CW' Winding data I/O code
	'CZ' Impedance data I/O code
	'CM' Magnetizing admittance data I/O code
	'CZO' Leakage impedance data I/O code
	'CZG' Grounding impedance data I/O code
	'CNXCOD' Winding connection code
	'ZADCOD' Impedance adjustment method code
	'STATION_I' Bus IBUS substation number (returned as 0 if bus IBUS is not in a substation)
	'STATION_J' Bus JBUS substation number (returned as 0 if bus JBUS is not in a substation)
	'STATION_K' Bus KBUS substation number (returned as 0 if bus KBUS is not in a substation)
	'SECTION_I' Bus IBUS bus section number (returned as 0 if bus IBUS is not in a substation)

	'SECTION_J'	Bus JBUS bus section number (returned as 0 if bus JBUS is not in a substation)
	'SECTION_K'	Bus KBUS bus section number (returned as 0 if bus KBUS is not in a substation)
	'NODE_I'	Number of the node to which the winding is connected at the bus IBUS end (returned as 0 if bus IBUS is not in a substation)
	'NODE_J'	Number of the node to which the winding is connected at the bus JBUS end (returned as 0 if bus JBUS is not in a substation)
	'NODE_K'	Number of the node to which the winding is connected at the bus KBUS end (returned as 0 if bus KBUS is not in a substation)
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Bus not found; 'IVAL' unchanged
	IERR = 2	Three-winding transformer not found; 'IVAL' unchanged
	IERR = 3	Invalid 'STRING'; 'IVAL' unchanged
	IERR = 4	Error fetching transformer data; 'IVAL' unchanged
	IERR = 5	Sequence data not in case for 'STRING' = 'CZ0', 'CZG' or 'CNXCOD'; 'IVAL' unchanged
	IERR = 6	With 'STRING' = OWNn, n > number of owners; 'IVAL' unchanged

10.229. TR3NAM

Use this API to return three-winding transformer name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = tr3nam(ibus, jbus, kbus, ickt)
```

Fortran command syntax:

```
CALL TR3NAM(IBUS, JBUS, KBUS, ICKT, CVAL, IERR)
```

IPLAN command syntax:

```
CALL TR3NAM(IBUS, JBUS, KBUS, ICKT, CVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (input).
Character*40 CVAL	Transformer name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Bus not found; 'CVAL' unchanged
	IERR = 2 Three-winding transformer not found; 'CVAL' unchanged
	IERR = 4 Error fetching transformer data; 'CVAL' unchanged

10.230. TRNDAT

This API routine is obsolete. It has been replaced by the API routine [XFRDAT](#).

Return transformer Ratio and Angle.

This API routine was first introduced in release 30.3.3.

Python command syntax:

```
ierr, ratio, angle = trndat(ibus, jbus, ckt)
```

Fortran command syntax:

```
CALL TRNDAT(IBUS, JBUS, CKT, RATIO, ANGLE, IERR)
```

IPLAN command syntax:

```
CALL TRNDAT(IBUS, JBUS, CKT, RATIO, ANGLE, IERR)
```

Where:

Integer IBUS	from bus number (input).
Integer JBUS	to bus number (input).
Character*2 CKT	circuit identifier (input).
Real RATIO	tap position (output).
Real ANGLE	phase shift angle, in degrees (output).
Integer IERR	error code (output).
IERR = 0	no error; 'RATIO' and 'ANGLE' returned
IERR = 1	bus not found; 'RATIO' and 'ANGLE' unchanged
IERR = 2	branch not found; 'RATIO' and 'ANGLE' unchanged
IERR = 3	branch not a transformer; 'RATIO' and 'ANGLE' unchanged

10.231. TRXDAT

Use this API to return the inter-area transfer MW.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr, rval = trxdat(iar, jar, id)
```

Fortran command syntax:

```
CALL TRXDAT(IAR, JAR, ID, RVAL, IERR)
```

IPLAN command syntax:

CALL TRXDAT(IAR, JAR, ID, RVAL, IERR)

Where:

Integer IAR	From area number (input).
Integer JAR	To area number (input).
Character*1 ID	Inter-area transfer identifier (input).
Real RVAL	Value (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Area number <= 0 or > largest allowable area number; 'RVAL' unchanged
	IERR = 2 Interarea transfer not found; 'RVAL' unchanged

10.232. VOLTAGEDROOPDATA

Use this API to return voltage droop control real parameters.

This API routine was first introduced in release 35.3.0.

Python command syntax:

```
ierr, rval = voltagedroopdata(name, string)
```

Fortran command syntax:

```
CALL VOLTAGEDROOPDATA(NAME, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL VOLTAGEDROOPDATA(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	voltage droop control name (input).	
Character STRING	String indicating the voltage droop control quantity desired (input).	
	'STATUS'	voltage droop control status
	'REGBUS'	regulated bus of voltage droop control
Real RVAL	Parameter value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	voltage droop control 'NAME' not found; 'RVAL' unchanged
	IERR = 2	Invalid 'STRING'; 'RVAL' unchanged

10.233. VOLTAGEDROOPINT

Use this API to return voltage droop control integer parameters.

This API routine was first introduced in release 35.3.0.

Python command syntax:

```
ierr, ival = voltagedroopint(name, string)
```

Fortran command syntax:

```
CALL VOLTAGEDROOPINT(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL VOLTAGEDROOPINT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	voltage droop control name (input).	
Character STRING	String indicating the voltage droop control quantity desired (input).	
	'STATUS'	voltage droop control status
	'REGBUS'	regulated bus of voltage droop control
	'ACTSTATUS'	actual voltage droop control status
Integer IVAL	'ACTREGBUS'	actual regulated bus of voltage droop control
	Parameter value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	voltage droop control 'NAME' not found; 'IVAL' unchanged
	IERR = 2	Invalid 'STRING'; 'IVAL' unchanged

10.234. VSCAUXMIND

Use this API to return the starting array indices and status of auxiliary signal model associated with VSC dc line for the specified signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = vscauxmind(name, isgndx, string)
```

Fortran command syntax:

```
CALL VSCAUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCAUXMIND(NAME, ISGNDX, STRING, IVAL, IERR)
```

Where:

Character NAME	VSC dc line name (input).
Integer ISGNDX	Auxiliary signal index (input).
Character STRING	String indicating the VSC dc line auxiliary signal model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. For a model to be called during simulations the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 dc line not in network but auxiliary signal model in model tables; 'IVAL' returned
	IERR = 2 dc line not in network and auxiliary signal model not in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables for the given auxiliary signal index; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Model does not use any of this data type; 'IVAL' = 0 returned

IERR = 9

Dynamics data not present in working memory; 'IVAL' unchanged

10.235. VSCAUXMNAM

Use this API to return the auxiliary signal model name associated with a VSC dc line for the specified auxiliary signal index.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = vscauxmnam(name, isgndx)
```

Fortran command syntax:

```
CALL VSCAUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCAUXMNAM(NAME, ISGNDX, CVAL, IERR)
```

Where:

Character NAME	VSC dc line name (input).
Integer ISGNDX	Auxiliary signal index (input).
Character*16 CVAL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 dc line not in network but auxiliary signal model in model tables; 'CVAL' returned
	IERR = 2 dc line not in network and auxiliary signal model not in model tables; 'CVAL' unchanged
	IERR = 4 No model in model tables for the given auxil- iary signal index; 'CVAL' unchanged
	IERR = 9 Dynamics data not present in working memo- ry; 'CVAL' unchanged

10.236. VSCCDT

Use this API to return VSC dc line real parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = vsccdt(id, ibus, string)
```

Fortran command syntax:

```
CALL VSCCDT(ID, IBUS, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCCDT(ID, IBUS, STRING, RVAL, IERR)
```

Where:

Character ID	VSC dc line name (input).	
Integer IBUS	Converter bus number (input).	
Character STRING	String indicating the VSC dc line quantity desired (input).	
	'PAC'	Real power into dc line at converter bus in MW
	'O_PAC'	Same as 'PAC' in units determined by the power output option setting
	'QAC'	Reactive power into dc line at converter bus in MV
	'O_QAC'	Same as 'QAC' in units determined by the power output option setting
	'MVA'	Apparent ac flow into the dc line in MVA
	'O_MVA'	Same as 'MVA' in units determined by the power output option setting
	'PCTMVA'	ac loading percent of limit
	'ACAMPS'	ac current in amps
	'PUCUR'	ac current in pu
	'KVDC'	Voltage at controlling converter in kV
	'DCCUR'	dc current in amps
	'DCSET'	dc setpoint in pu
	'ACSET'	ac setpoint in pu
	'RDC'	dc line resistance in ohms
Real RVAL	Parameter value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	VSC dc line 'ID' not found; 'RVAL' unchanged
	IERR = 2	Invalid 'STRNG'; 'RVAL' unchanged
	IERR = 3	Bus 'IBUS' not a converter of this dc line; 'RVAL' unchanged

IERR = 4

dc line blocked; 'RVAL' returned as 0.0

IERR = 5

No base kV at bus; 'RVAL' returned as the per
unit current

10.237. VSCCIN

Use this API to return VSC dc line converter integer parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = vsccin(id, ibus, string)
```

Fortran command syntax:

```
CALL VSCCIN(ID, IBUS, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCCIN(ID, IBUS, STRING, IVAL, IERR)
```

Where:

Character ID	VSC dc line name (input).
Integer IBUS	Converter bus number (input).
Character STRING	String indicating the VSC dc line quantity desired (input). 'DCTYPE' Converter dc control code 'ACMODE' Converter ac control mode 'VSREG' Regulated bus 'NREG' Regulated node
Integer IVAL	Parameter value (output).
Integer IERR	error code (output). IERR = 0 No error; 'IVAL' returned IERR = 1 VSC dc line 'ID' not found; 'IVAL' unchanged IERR = 2 Invalid 'STRING'; 'IVAL' unchanged IERR = 3 Bus 'IBUS' not a converter of this dc line; 'IVAL' unchanged

10.238. VSCINT

Use this API to return VSC dc line integer parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = vscint(id, string)
```

Fortran command syntax:

```
CALL VSCINT(ID, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCINT(ID, STRING, IVAL, IERR)
```

Where:

Character ID	VSC dc line name (input).	
Character STRING	String indicating the VSC dc line quantity desired (input).	
	'CONV1'	Converter 1 bus number
	'CONV2'	Converter 2 bus number
	'MDC'	Control mode
Integer IVAL	Parameter value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	VSC dc line 'ID' not found; 'IVAL' unchanged
	IERR = 2	Invalid 'STRING'; 'IVAL' unchanged

10.239. VSCMIND

Use this API to return VSC dc line model starting array indices and status.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = vscmind(name, string)
```

Fortran command syntax:

```
CALL VSCMIND(NAME, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCMIND(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	VSC dc line name (input).
Character STRING	String indicating the VSC dc line model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect dc line status. For a model to be called during simulations the dc line must be in service the model's bypassed flag must be not bypassed
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 dc line not in network but in model tables; 'IVAL' returned
	IERR = 2 dc line not in network or in model tables; 'IVAL' unchanged
	IERR = 4 No model in model tables; 'IVAL' unchanged
	IERR = 5 Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 6 Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 9 Dynamics data not present in working memory; 'IVAL' unchanged

10.240. VSCMNAM

Use this API to return VSC dc line model name.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = vscmnam(name)
```

Fortran command syntax:

```
CALL VSCMNAM(NAME, CVAL, IERR)
```

IPLAN command syntax:

```
CALL VSCMNAM(NAME, CVAL, IERR)
```

Where:

Character NAME	VSC dc line name (input).	
Character*16 CVAL	Model name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	dc line not in network but in model tables; 'CVAL' returned
	IERR = 2	dc line not in network or in model tables; 'CVAL' unchanged
	IERR = 4	No model in model tables; 'CVAL' unchanged
	IERR = 9	Dynamics data not present in working memory; 'CVAL' unchanged

10.241. WINDMIND

Use this API to return wind model starting array indices and status.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, ival = windmind(ibus, id, string1, string2)
```

Fortran command syntax:

```
CALL WINDMIND(IBUS, ID, STRING1, STRING2, IVAL, IERR)
```

IPLAN command syntax:

```
CALL WINDMIND(IBUS, ID, STRING1, STRING2, IVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING1	String indicating the type of wind model (input).
	'WGEN' Renewable Generator model
	'WELEC' Renewable Electrical model
	'WMECH' Renewable Mechanical model
	'WPICH' Renewable Pitch model
	'WAERO' Renewable Aerodynamic model
	'WGUST' Renewable Gust model
	'WAUX' Renewable Auxiliary Signal model
	'WTRQ' Renewable Torque Control model
	'WWGO' Renewable Weak Grid model
	'WPAUX' Renewable Paux Control model
Character STRING2	String indicating the plant-related model quantity desired (input).
	'CON' Starting CON index
	'STATE' Starting STATE index
	'VAR' Starting VAR index
	'ICON' Starting ICON index
	'NCON' Number of CON values used by the model
	'NSTATE' Number of STATE values used by the model
	'NVAR' Number of VAR values used by the model
	'NICON' Number of ICON values used by the model
	'STATUS' Bypassed flag: 0 = bypassed; 1 = not bypassed. Does not reflect machine status. For a model to be called during simulations the machine must be in service the type code of the bus must be 2 and the model's bypassed flag must be not bypassed

Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Machine not in network but in model tables; 'IVAL' returned
	IERR = 2	Machine not in network or in model tables; 'IVAL' unchanged
	IERR = 3	Invalid value of 'STRING1', 'IVAL' unchanged
	IERR = 4	No model of type 'STRING1' for this machine; 'IVAL' unchanged
	IERR = 5	Invalid value of 'STRING2'; 'IVAL' unchanged
	IERR = 6	Model does not use any of this data type; 'IVAL' = 0 returned
	IERR = 9	Dynamics data not present in working memory; 'IVAL' unchanged

10.242. WINDMNAM

Use this API to return wind model name.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, cval = windmnam(ibus, id, string)
```

Fortran command syntax:

```
CALL WINDMNAM(IBUS, ID, STRING, CVAL, IERR)
```

IPLAN command syntax:

```
CALL WINDMNAM(IBUS, ID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	Bus number (input).
Character ID	Machine identifier (input).
Character STRING	String indicating the type of plant-related model (input).
	'WGEN' Renewable Generator model
	'WELEC' Renewable Electrical model
	'WMECH' Renewable Mechanical model
	'WPICH' Renewable Pitch model
	'WAERO' Renewable Aerodynamic model
	'WGUST' Renewable Gust Model
	'WAUX' Renewable Plant Control model
	'WTRQ' Renewable Torque Control model
	'WWGO' Renewable Weak Grid model
	'WPAUX' Renewable Paux Control model
Character*16 CVAL	Model name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Machine not in network but in model tables; 'CVAL' returned
	IERR = 2 Machine not in network or in model tables; 'CVAL' unchanged
	IERR = 3 Invalid value of 'STRING', 'CVAL' unchanged
	IERR = 4 No model of type 'STRING' for this machine; 'CVAL' unchanged
	IERR = 9 Dynamics data not present in working memory; 'CVAL' unchanged

10.243. WNDDAT

Use this API to return three-winding transformer real values for winding connected to bus IBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = wnddat(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL WNDDAT(IBUS, JBUS, KBUS, ICKT, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL WNDDAT(IBUS, JBUS, KBUS, ICKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the transformer winding quantity desired (input).
'RATEA'	Rating set A
'RATEB'	Rating set B
'RATEC'	Rating set C
'RATE'	Default rating set
'RATIO'	Winding tap ratio
'ANGLE'	Winding phase angle shift in degrees
'SBASE'	Winding MVA base
'NOMV'	Nominal winding voltage
'RMAX'	Ratio or angle high limit
'RMIN'	Ratio or angle low limit
'VMAX'	Controlled quantity high limit
'VMIN'	Controlled quantity low limit
'STEP'	Derived tap step
'CNXANG'	Winding connection angle in degrees
'MVA'	Winding MVA flow
'O_MVA'	Same as 'MVA' in units determined by the power output option setting
'AMPS'	Winding current in amps
'PUCUR'	Winding current in pu
'PCTRTA'	Percent current loading of RATEA
'PCTRTB'	Percent current loading of RATEB
'PCTRTC'	Percent current loading of RATEC
'PCTMVA'	Percent MVA loading of RATEA

	'PCTMVB'	Percent MVA loading of RATEB
	'PCTMVC'	Percent MVA loading of RATEC
	'PCTCPA'	Percent current or MVA loading (according to the transformer percent loading units program option setting) of RATEA
	'PCTCPB'	Percent current or MVA loading (according to the transformer percent loading units program option setting) of RATEB
	'PCTCPC'	Percent current or MVA loading (according to the transformer percent loading units program option setting) of RATEC
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Three-winding transformer not found; 'RVAL' unchanged
	IERR = 3	Invalid 'STRING'; 'RVAL' unchanged
	IERR = 4	Error fetching transformer data; 'RVAL' unchanged
	IERR = 7	Branch out of service; 'RVAL' returned set to zero
	IERR = 8	No base kV at IBUS; 'RVAL' returned = per unit current
	IERR = 9	Rating is zero; 'RVAL' returned set to zero

10.244. WNDDT2

Use this API to return three-winding transformer complex values for winding connected to bus IBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = wnddt2(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL WNDDT2(IBUS, JBUS, KBUS, ICKT, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL WNDDT2(IBUS, JBUS, KBUS, ICKT, STRING, P, Q, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the transformer winding quantity desired (input).
	'RX' Winding impedance in per unit
	'RXZ' Zero-sequence winding impedance
	'COMPRX' Compensating impedance
	'FLOW' Complex flow in MW/Mvar
	'O_FLOW' Same as 'FLOW' units determined by power output option
Real P	Real component of complex value indicated by STRING (output).
Real Q	Reactive component of complex value indicated by STRING (output).
Complex CMPVAL	Complex value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1 Bus not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2 Three-winding transformer not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3 Invalid 'STRING'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4 Error fetching transformer data; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 5 Sequence data not in case for 'STRING' = 'RXZ'; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 7 Branch out of service; 'P' and 'Q' of 0.0 or 'CMPVAL' of (0.0,0.0) returned

10.245. WNDINT

Use this API to return three-winding transformer integer values for winding connected to bus IBUS.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = wndint(ibus, jbus, kbus, ickt, string)
```

Fortran command syntax:

```
CALL WNDINT(IBUS, JBUS, KBUS, ICKT, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL WNDINT(IBUS, JBUS, KBUS, ICKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Integer KBUS	Third bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the transformer winding quantity desired (input).
	'STATUS' Status
	'CNXCOD' Winding connection code
	'WNDNUM' Winding number
	'ICONT' Controlled bus number
	'NCONT' Controlled node number
	'TABLE' Transformer impedance correction table number (0 if none)
	'CNTRL' Adjustment flag
	'CNTRL2' Transformer adjustment code
	'NTPOSN' Number of tap positions
	'TPSTT' Transformer winding ratio limit code: (-1) low; (0) regulating; (1) high; (-2) locked
	'ANSTT' Transformer winding angle limit code: (-1) low; (0) regulating; (1) high; (-2) locked
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Bus not found; 'IVAL' unchanged
	IERR = 2 Three-winding transformer not found; 'IVAL' unchanged
	IERR = 3 Invalid 'STRING'; 'IVAL' unchanged
	IERR = 4 Error fetching transformer data; 'IVAL' unchanged

IERR = 5

Sequence data not in case for 'STRING' =
'CNXCOD'; 'IVAL' unchanged

10.246. XFRDAT

Use this API to return two-winding transformer real parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, rval = xfrdat(ibus, jbus, ickt, string)
```

Fortran command syntax:

```
CALL XFRDAT(IBUS, JBUS, ICKT, STRING, RVAL, IERR)
```

IPLAN command syntax:

```
CALL XFRDAT(IBUS, JBUS, ICKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the transformer quantity desired (input).
	'RATIO' Winding one off-nominal turns ratio
	'RATIO2' Winding two off-nominal turns ratio
	'ANGLE' Winding one-phase shift angle in degrees
	'RMAX' Winding one ratio or angle upper limit
	'RMIN' Winding one ratio or angle lower limit
	'VMAX' Controlled quantity upper limit
	'VMIN' Controlled quantity lower limit
	'STEP' Winding one ratio or angle step width
	'CR' Real component of load drop compensation impedance
	'CX' Reactive component of load drop compensation impedance
	'CNXANG' Winding connection angle in degrees
	'SBASE1' Winding one base MVA
	'NOMV1' Winding one nominal voltage in kV
	'NOMV2' Winding two nominal voltage in kV
	'GMAGNT' Conductance component of transformer magnetizing admittance in pu
	'BMAGNT' Susceptance component of transformer magnetizing admittance in pu
	'RG1', 'RGRND' Grounding resistance at the winding 1 bus
	'XG1', 'XGRND' Grounding reactance at the winding 1 bus
	'R01' Zero sequence leakage resistance connected to the winding 1 bus

	'X01'	Zero sequence leakage reactance connected to the winding 1 bus
	"RG2', 'RGRND2"	Grounding resistance at the winding 2 bus
	"XG2', 'XGRND2"	Grounding reactance at the winding 1 bus
	'R02'	Zero sequence leakage resistance connected to the winding 2 bus
	'X02'	Zero sequence leakage reactance connected to the winding 2 bus
	'RNUTRL'	Common neutral grounding resistance
	'XNUTRL'	Common neutral grounding reactance
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Bus not found; 'RVAL' unchanged
	IERR = 2	Branch not found; 'RVAL' unchanged
	IERR = 3	Branch not a transformer; 'RVAL' unchanged
	IERR = 4	Invalid value of 'STRING'; 'RVAL' unchanged
	IERR = 5	Sequence data not in case for STRING = 'RGRND', 'XGRND', 'RGRND2', 'XGRND2', 'RG1', 'XG1', 'R01', 'X01', 'RG2', 'XG2', 'R02', 'X02', 'RNUTRL' or 'XNUTRL'; 'RVAL' unchanged

10.247. XFRINT

Use this API to return two-winding transformer integer parameters.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, ival = xfrint(ibus, jbus, ickt, string)
```

Fortran command syntax:

```
CALL XFRINT(IBUS, JBUS, ICKT, STRING, IVAL, IERR)
```

IPLAN command syntax:

```
CALL XFRINT(IBUS, JBUS, ICKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character ICKT	Circuit identifier (input).
Character STRING	String indicating the transformer quantity desired (input).
	'ICONT' Controlled bus number
	'NCONT' Controlled node number
	'SIDCOD' Controlled bus side code (negative if on the winding 1 side)
	'TAPPED' Tapped side bus number
	'GCIBUS' Bus IBUS old grounding code (derived from CNXCOD)
	'GCJBUS' Bus JBUS old grounding code (derived from CNXCOD)
	'TABLE' Transformer impedance correction table number (0 if none)
	'CNTRL' Adjustment enable flag
	'CNTRL2' Transformer adjustment code
	'NTPOSN' Number of tap positions
	'CNXCOD' Connection code
	'CW' Winding data I/O code
	'CZ' Impedance data I/O code
	'CM' Magnetizing admittance I/O code
	'CZO' Leakage impedance data I/O code
	'CZG' Grounding impedance data I/O code
	'TPSTT' Transformer winding one ratio limit code: (-1) low; (0) regulating; (1) high; (-2) locked; (-3) controlling dc line
	'ANSTT' Transformer winding one angle limit code: (-1) low; (0) regulating; (1) high; (-2) locked

Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Bus not found; 'IVAL' unchanged
	IERR = 2	Branch not found; 'IVAL' unchanged
	IERR = 3	Branch not a transformer; 'IVAL' unchanged
	IERR = 4	Invalid value of 'STRING'; 'IVAL' unchanged
	IERR = 5	Sequence data not in case for STRING = 'CNX-COD', 'CZ0', 'CZG', 'GCIBUS' or 'GCJBUS'; IVAL unchanged
	IERR = 6	Connection code is 6 or greater for STRING = 'GCIBUS' or 'GCJBUS'; IVAL unchanged

10.248. XFRNAM

Use this API to return two-winding transformer name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, string = xfrnam(ibus, jbus, ickt)
```

Fortran command syntax:

```
CALL XFRNAM(IBUS, JBUS, ICKT, STRING, IERR)
```

IPLAN command syntax:

```
CALL XFRNAM(IBUS, JBUS, ICKT, STRING, IERR)
```

Where:

Integer IBUS	From bus number (input).
Integer JBUS	To bus number (input).
Character ICKT	Circuit identifier (input).
Character*40 STRING	Transformer name (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'STRING' returned
	IERR = 1 Bus not found; 'STRING' unchanged
	IERR = 2 Transformer not found; 'STRING' unchanged
	IERR = 3 Branch not a transformer; 'STRING' unchanged

10.249. ZNDAT

Use this API to return zone totals.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = zndat(iar, string)
```

Fortran command syntax:

```
CALL ZNDAT(IAR, STRING, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL ZNDAT(IAR, STRING, P, Q, IERR)
```

Where:

Integer IAR	Zone number (input).	
Character STRING	String indicating the zone total desired (input).	
	'LOAD'	Total zone load by bus zone assignment (net of load plus in-service distributed generation on load feeder)
	'LOADLD'	Total zone load by load zone assignment
	'LDGN'	Total distributed generation on load feeder by bus zone assignment
	'LDGNLD'	Total distributed generation on load feeder by load zone assignment
	'GEN'	Total zone generation
	'LOSS'	Total zone losses; $I^2 * (R + jX)$ for ac branches with non-metered end in the zone
	'XFRMAG'	Magnetizing admittance powers for transformers with winding 1 bus in the zone
	'LNSHNT'	Powers flowing into line shunts of non-transformer branches with non-metered end in the zone
	'CHARGE'	Powers flowing from line charging of non-transformer branches with non-metered end in the zone
	'INT'	Net zone interchange
	'INDMAC'	Total zone induction machine powers by bus zone assignment
	'INDMACMC'	Total zone induction machine powers by machine zone assignment
	'INDGEN'	Total zone induction generator powers by bus zone assignment
	'INDGENMC'	Total zone induction generator powers by machine zone assignment

	'INDMOT'	Total zone induction motor powers by bus zone assignment
	'INDMOTMC'	Total zone induction motor powers by machine zone assignment
Real P	Real component of the desired complex power (output).	
Real Q	Reactive component of the desired complex power (output).	
Complex CMPVAL	Desired complex power (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
	IERR = 1	Zone number < 0 or > largest allowable zone number; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 2	No in-service buses with in-service loads (for 'LOAD'), no in-service loads (for 'LOADLD'), no type 2 or type 3 buses (for 'GEN'), no branches (for 'LOSS'), or no ties (for 'INT') in zone; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 3	Zone not found; 'P' and 'Q' or 'CMPVAL' unchanged
	IERR = 4	Bad 'STRING' value; 'P' and 'Q' or 'CMPVAL' unchanged

10.250. ZNIT0J

Use this API to return the interchange between two zones.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cmpval = znit0j(iar, jar)
```

Fortran command syntax:

```
CALL ZNIT0J(IAR, JAR, CMPVAL, IERR)
```

IPLAN command syntax:

```
CALL ZNIT0J(IAR, JAR, P, Q, IERR)
```

Where:

Integer IAR	From zone number (input).
Integer JAR	To zone number (input).
Real P	Real component of the complex interchange
Real Q	Reactive component of the complex interchange
Complex CMPVAL	Complex interchange (output).
Integer IERR	error code (output).
IERR = 0	No error; 'P' and 'Q' or 'CMPVAL' returned
IERR = 1	Zone number <= 0 or > largest allowable zone number; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 2	No in-service branches between zones; 'P' and 'Q' or 'CMPVAL' unchanged
IERR = 3	Zone not found; 'P' and 'Q' or 'CMPVAL' unchanged

10.251. ZONNAM

Use this API to return the zone name.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, cval = zonnam(iar)
```

Fortran command syntax:

```
CALL ZONNAM(IAR, CVAL, IERR)
```

IPLAN command syntax:

```
CALL ZONNAM(IAR, CVAL, IERR)
```

Where:

Integer IAR	Zone number (input).
Character*12 CVAL	Zone name (output).
Integer IERR	error code (output).
	IERR = 0 No error, 'CVAL' is returned
	IERR = 1 Zone number <= 0 or > largest allowable zone number; 'CVAL' is unchanged
	IERR = 2 Zone not found; 'CVAL' is unchanged

10.252. ZONNUM

Use this API to return the zone number.

This API routine was first introduced in release 28.0.0.

Python command syntax:

```
ierr, iar = zonnum(string)
```

Fortran command syntax:

```
CALL ZONNUM(IAR, STRING, IERR)
```

IPLAN command syntax:

```
CALL ZONNUM(IAR, STRING, IERR)
```

Where:

Integer IAR	Zone number (integer (output)).	
Character STRING	Zone name (string (input)).	
Integer IERR	error code (output).	
	IERR = 0	No error, 'IAR' is returned
	IERR = 1	Zone with name 'STRING' not found, 'IAR' is unchanged
	IERR > 1	Multiple zones with the name 'STRING' found, 'IAR' returned as lowest number of these

10.253. ZONUSE

Use this API to indicate whether a zone is in use.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ival = zonuse(iar)
```

Fortran command syntax:

```
CALL ZONUSE(IAR, IVAL)
```

IPLAN command syntax:

```
CALL ZONUSE(IAR, IVAL)
```

Where:

Integer IAR	Zone number (input).	
Integer IVAL	Zone status (output).	
	IVAL = -1	Zone number <= 0 or > largest allowable zone number.
	IVAL = 0	If no equipment is assigned to zone IAR.
	IVAL = 1	If any equipment is assigned to zone IAR.

Chapter 11

Extension Data Access

This chapter defines API routines that are used to retrieve and set extension data for a single element (e.g., bus, branch, area, etc.) in the PSS®E engine.

These routines do not record themselves when called with recording enabled.

11.1. GET_EXT_ACLINE_CHAR

Use this API to get ac line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_acline_char(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_ACLINE_CHAR(IBUS, JBUS, CKT, STRING, CVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.2. GET_EXT_ACLINE_INT

Use this API to get ac line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_acline_int(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_ACLINE_INT(IBUS, JBUS, CKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.3. GET_EXT_ACLINE_LOGICAL

Use this API to get ac line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_acline_logical(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_ACLINE_LOGICAL(IBUS, JBUS, CKT, STRING, LVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.4. GET_EXT_ACLINE_REAL

Use this API to get ac line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_acline_real(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_ACLINE_REAL(IBUS, JBUS, CKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.5. GET_EXT_AREA_CHAR

Use this API to get area character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_area_char(iarea, string)
```

Fortran command syntax:

```
CALL GET_EXT_AREA_CHAR(IAREA, STRING, CVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).	
Character STRING	String indicating the extension AREA field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.6. GET_EXT_AREA_INT

Use this API to get area integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_area_int(iarea, string)
```

Fortran command syntax:

```
CALL GET_EXT_AREA_INT(IAREA, STRING, IVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).
Character STRING	String indicating the extension AREA field desired (input).
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Element not found; 'IVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4 Unknown error with data access; 'IVAL' not returned
	IERR = 10 API Prereqs not met; 'IVAL' not returned

11.7. GET_EXT_AREA_LOGICAL

Use this API to get area logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_area_logical(iarea, string)
```

Fortran command syntax:

```
CALL GET_EXT_AREA_LOGICAL(IAREA, STRING, LVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).
Character STRING	String indicating the extension AREA field desired (input).
Logical LVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' returned
	IERR = 1 Element not found; 'LVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4 Unknown error with data access; 'LVAL' not returned
	IERR = 10 API Prereqs not met; 'LVAL' not returned

11.8. GET_EXT_AREA_REAL

Use this API to get area real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_area_real(iarea, string)
```

Fortran command syntax:

```
CALL GET_EXT_AREA_REAL(IAREA, STRING, RVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).
Character STRING	String indicating the extension AREA field desired (input).
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Element not found; 'RVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4 Unknown error with data access; 'RVAL' not returned
	IERR = 10 API Prereqs not met; 'RVAL' not returned

11.9. GET_EXT_BUS_CHAR

Use this API to get bus character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_bus_char(ibus, string)
```

Fortran command syntax:

```
CALL GET_EXT_BUS_CHAR(IBUS, STRING, CVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).
Character STRING	String indicating the extension BUS field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.10. GET_EXT_BUS_INT

Use this API to get bus integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_bus_int(ibus, string)
```

Fortran command syntax:

```
CALL GET_EXT_BUS_INT(IBUS, STRING, IVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).	
Character STRING	String indicating the extension BUS field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.11. GET_EXT_BUS_LOGICAL

Use this API to get bus logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_bus_logical(ibus, string)
```

Fortran command syntax:

```
CALL GET_EXT_BUS_LOGICAL(IBUS, STRING, LVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).
Character STRING	String indicating the extension BUS field desired (input).
Logical LVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' returned
	IERR = 1 Element not found; 'LVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4 Unknown error with data access; 'LVAL' not returned
	IERR = 10 API Prereqs not met; 'LVAL' not returned

11.12. GET_EXT_BUS_REAL

Use this API to get bus real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_bus_real(ibus, string)
```

Fortran command syntax:

```
CALL GET_EXT_BUS_REAL(IBUS, STRING, RVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).	
Character STRING	String indicating the extension BUS field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.13. GET_EXT_CHAR

Use this API to get character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_char(tblname, string, irow)
```

Fortran command syntax:

```
CALL GET_EXT_CHAR(TBLNAME, STRING, IROW, CVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Character CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'IVAL' not set

11.14. GET_EXT_FACTS_CHAR

Use this API to get facts device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_facts_char(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_FACTS_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.15. GET_EXT_FACTS_INT

Use this API to get facts device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_facts_int(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_FACTS_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.16. GET_EXT_FACTS_LOGICAL

Use this API to get facts device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_facts_logical(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_FACTS_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.17. GET_EXT_FACTS_REAL

Use this API to get facts device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_facts_real(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_FACTS_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.18. GET_EXT_FIXSHUNT_CHAR

Use this API to get fixed shunt character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_fixshunt_char(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_FIXSHUNT_CHAR(IBUS, SHNTID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.19. GET_EXT_FIXSHUNT_INT

Use this API to get fixed shunt integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_fixshunt_int(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_FIXSHUNT_INT(IBUS, SHNTID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.20. GET_EXT_FIXSHUNT_LOGICAL

Use this API to get fixed shunt logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_fixshunt_logical(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_FIXSHUNT_LOGICAL(IBUS, SHNTID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.21. GET_EXT_FIXSHUNT_REAL

Use this API to get fixed shunt real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_fixshunt_real(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_FIXSHUNT_REAL(IBUS, SHNTID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.23. GET_EXT_GENERATOR_INT

Use this API to get generator integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_generator_int(ibus, machid, string)
```

Fortran command syntax:

```
CALL GET_EXT_GENERATOR_INT(IBUS, MACHID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).	
Character MACHID	GENERATOR machid (input).	
Character STRING	String indicating the extension GENERATOR field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.24. GET_EXT_GENERATOR_LOGICAL

Use this API to get generator logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_generator_logical(ibus, machid, string)
```

Fortran command syntax:

```
CALL GET_EXT_GENERATOR_LOGICAL(IBUS, MACHID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).	
Character MACHID	GENERATOR machid (input).	
Character STRING	String indicating the extension GENERATOR field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.25. GET_EXT_GENERATOR_REAL

Use this API to get generator real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_generator_real(ibus, machid, string)
```

Fortran command syntax:

```
CALL GET_EXT_GENERATOR_REAL(IBUS, MACHID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).	
Character MACHID	GENERATOR machid (input).	
Character STRING	String indicating the extension GENERATOR field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.26. GET_EXT_GNE_CHAR

Use this API to get general network element device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_gne_char(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_GNE_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.27. GET_EXT_GNE_INT

Use this API to get general network element device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_gne_int(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_GNE_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.28. GET_EXT_GNE_LOGICAL

Use this API to get general network element device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_gne_logical(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_GNE_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.29. GET_EXT_GNE_REAL

Use this API to get general network element device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_gne_real(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_GNE_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.30. GET_EXT_IATRANS_CHAR

Use this API to get inter-area transfer character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_iatrans_char(arfrom, arto, trid, string)
```

Fortran command syntax:

```
CALL GET_EXT_IATRANS_CHAR(ARFROM, ARTO, TRID, STRING, CVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).
Integer ARTO	IATRANS arto (input).
Character TRID	IATRANS trid (input).
Character STRING	String indicating the extension IATRANS field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.31. GET_EXT_IATRANS_INT

Use this API to get inter-area transfer integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_iatrans_int(arfrom, arto, trid, string)
```

Fortran command syntax:

```
CALL GET_EXT_IATRANS_INT(ARFROM, ARTO, TRID, STRING, IVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).	
Integer ARTO	IATRANS arto (input).	
Character TRID	IATRANS trid (input).	
Character STRING	String indicating the extension IATRANS field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.32. GET_EXT_IATRANS_LOGICAL

Use this API to get inter-area transfer logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_iatrans_logical(arfrom, arto, trid, string)
```

Fortran command syntax:

```
CALL GET_EXT_IATRANS_LOGICAL(ARFROM, ARTO, TRID, STRING, LVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).
Integer ARTO	IATRANS arto (input).
Character TRID	IATRANS trid (input).
Character STRING	String indicating the extension IATRANS field desired (input).
Logical LVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' returned
	IERR = 1 Element not found; 'LVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4 Unknown error with data access; 'LVAL' not returned
	IERR = 10 API Prereqs not met; 'LVAL' not returned

11.33. GET_EXT_IATRANS_REAL

Use this API to get inter-area transfer real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_iatrans_real(arfrom, arto, trid, string)
```

Fortran command syntax:

```
CALL GET_EXT_IATRANS_REAL(ARFROM, ARTO, TRID, STRING, RVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).
Integer ARTO	IATRANS arto (input).
Character TRID	IATRANS trid (input).
Character STRING	String indicating the extension IATRANS field desired (input).
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Element not found; 'RVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4 Unknown error with data access; 'RVAL' not returned
	IERR = 10 API Prereqs not met; 'RVAL' not returned

11.34. GET_EXT_INDMACH_CHAR

Use this API to get induction machine character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_indmach_char(ibus, imid, string)
```

Fortran command syntax:

```
CALL GET_EXT_INDMACH_CHAR(IBUS, IMID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.35. GET_EXT_INDMACH_INT

Use this API to get induction machine integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_indmach_int(ibus, imid, string)
```

Fortran command syntax:

```
CALL GET_EXT_INDMACH_INT(IBUS, IMID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.36. GET_EXT_INDMACH_LOGICAL

Use this API to get induction machine logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_indmach_logical(ibus, imid, string)
```

Fortran command syntax:

```
CALL GET_EXT_INDMACH_LOGICAL(IBUS, IMID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.37. GET_EXT_INDMACH_REAL

Use this API to get induction machine real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_indmach_real(ibus, imid, string)
```

Fortran command syntax:

```
CALL GET_EXT_INDMACH_REAL(IBUS, IMID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.38. GET_EXT_INT

Use this API to get integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_int(tblname, string, irow)
```

Fortran command syntax:

```
CALL GET_EXT_INT(TBLNAME, STRING, IROW, IVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'IVAL' not set

11.39. GET_EXT_LOAD_CHAR

Use this API to get load character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_load_char(ibus, loadid, string)
```

Fortran command syntax:

```
CALL GET_EXT_LOAD_CHAR(IBUS, LOADID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	LOAD ibus (input).
Character LOADID	LOAD loadid (input).
Character STRING	String indicating the extension LOAD field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.42. GET_EXT_LOAD_REAL

Use this API to get load real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_load_real(ibus, loadid, string)
```

Fortran command syntax:

```
CALL GET_EXT_LOAD_REAL(IBUS, LOADID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	LOAD ibus (input).	
Character LOADID	LOAD loadid (input).	
Character STRING	String indicating the extension LOAD field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.43. GET_EXT_LOGICAL

Use this API to get logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_logical(tblname, string, irow)
```

Fortran command syntax:

```
CALL GET_EXT_LOGICAL(TBLNAME, STRING, IROW, LVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'LVAL' not set

11.44. GET_EXT_MSLINE_CHAR

Use this API to get multi-section line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_msline_char(ibus, jbus, mslid, string)
```

Fortran command syntax:

```
CALL GET_EXT_MSLINE_CHAR(IBUS, JBUS, MSLID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.45. GET_EXT_MSLINE_INT

Use this API to get multi-section line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_msline_int(ibus, jbus, mslid, string)
```

Fortran command syntax:

```
CALL GET_EXT_MSLINE_INT(IBUS, JBUS, MSLID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Element not found; 'IVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4 Unknown error with data access; 'IVAL' not returned
	IERR = 10 API Prereqs not met; 'IVAL' not returned

11.47. GET_EXT_MSLINE_REAL

Use this API to get multi-section line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_msline_real(ibus, jbus, mslid, string)
```

Fortran command syntax:

```
CALL GET_EXT_MSLINE_REAL(IBUS, JBUS, MSLID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Element not found; 'RVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4 Unknown error with data access; 'RVAL' not returned
	IERR = 10 API Prereqs not met; 'RVAL' not returned

11.48. GET_EXT_NTERMDC_CHAR

Use this API to get multi-terminal dc line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_ntermdc_char(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_NTERMDC_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.49. GET_EXT_NTERMDC_INT

Use this API to get multi-terminal dc line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_ntermdc_int(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_NTERMDC_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.50. GET_EXT_NTERMDC_LOGICAL

Use this API to get multi-terminal dc line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_ntermdc_logical(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_NTERMDC_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.51. GET_EXT_NTERMDC_REAL

Use this API to get multi-terminal dc line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_ntermdc_real(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_NTERMDC_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.52. GET_EXT_OWNER_CHAR

Use this API to get owner character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_owner_char(iowner, string)
```

Fortran command syntax:

```
CALL GET_EXT_OWNER_CHAR(IOWNER, STRING, CVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).
Character STRING	String indicating the extension OWNER field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.53. GET_EXT_OWNER_INT

Use this API to get owner integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_owner_int(iowner, string)
```

Fortran command syntax:

```
CALL GET_EXT_OWNER_INT(IOWNER, STRING, IVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).
Character STRING	String indicating the extension OWNER field desired (input).
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Element not found; 'IVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4 Unknown error with data access; 'IVAL' not returned
	IERR = 10 API Prereqs not met; 'IVAL' not returned

11.54. GET_EXT_OWNER_LOGICAL

Use this API to get owner logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_owner_logical(iowner, string)
```

Fortran command syntax:

```
CALL GET_EXT_OWNER_LOGICAL(IOWNER, STRING, LVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).	
Character STRING	String indicating the extension OWNER field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.55. GET_EXT_OWNER_REAL

Use this API to get owner real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_owner_real(iowner, string)
```

Fortran command syntax:

```
CALL GET_EXT_OWNER_REAL(IOWNER, STRING, RVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).	
Character STRING	String indicating the extension OWNER field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.56. GET_EXT_RATING_CHAR

Use this API to get rating character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_rating_char(irate, string)
```

Fortran command syntax:

```
CALL GET_EXT_RATING_CHAR(IRATE, STRING, CVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.57. GET_EXT_RATING_INT

Use this API to get rating integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_rating_int(irate, string)
```

Fortran command syntax:

```
CALL GET_EXT_RATING_INT(IRATE, STRING, IVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.58. GET_EXT_RATING_LOGICAL

Use this API to get rating logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_rating_logical(irate, string)
```

Fortran command syntax:

```
CALL GET_EXT_RATING_LOGICAL(IRATE, STRING, LVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.59. GET_EXT_RATING_REAL

Use this API to get rating real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_rating_real(irate, string)
```

Fortran command syntax:

```
CALL GET_EXT_RATING_REAL(IRATE, STRING, RVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.60. GET_EXT_REAL

Use this API to get real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_real(tblname, string, irow)
```

Fortran command syntax:

```
CALL GET_EXT_REAL(TBLNAME, STRING, IROW, RVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'RVAL' not set

11.61. GET_EXT_ROWCOUNT

Use this API to get extension data table row count.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, nrows = get_ext_rowcount(tblname)
```

Fortran command syntax:

```
CALL GET_EXT_ROWCOUNT(TBLNAME, NROWS, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Integer NROWS	Number of rows in table indicated by TBLNAME (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NROWS' set
	IERR = 1	Table not found; 'NROWS' not set
	IERR = 4	Unknown error with data access; 'NROWS' not set

11.62. GET_EXT_SUBNODE_CHAR

Use this API to get substation node character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_subnode_char(isub, inode, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBNODE_CHAR(ISUB, INODE, STRING, CVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).	
Integer INODE	SUBNODE inode (input).	
Character STRING	String indicating the extension SUBNODE field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.63. GET_EXT_SUBNODE_INT

Use this API to get substation node integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_subnode_int(isub, inode, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBNODE_INT(ISUB, INODE, STRING, IVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).	
Integer INODE	SUBNODE inode (input).	
Character STRING	String indicating the extension SUBNODE field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.65. GET_EXT_SUBNODE_REAL

Use this API to get substation node real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_subnode_real(isub, inode, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBNODE_REAL(ISUB, INODE, STRING, RVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).	
Integer INODE	SUBNODE inode (input).	
Character STRING	String indicating the extension SUBNODE field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.66. GET_EXT_SUBSWD_CHAR

Use this API to get substation switching device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_subswd_char(isub, inode, jnode, swdid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBSWD_CHAR(ISUB, INODE, JNODE, SWDID, STRING, CVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.67. GET_EXT_SUBSWD_INT

Use this API to get substation switching device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_subswd_int(isub, inode, jnode, swdid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBSWD_INT(ISUB, INODE, JNODE, SWDID, STRING, IVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Element not found; 'IVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4 Unknown error with data access; 'IVAL' not returned
	IERR = 10 API Prereqs not met; 'IVAL' not returned

11.68. GET_EXT_SUBSWD_LOGICAL

Use this API to get substation switching device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_subswd_logical(isub, inode, jnode, swdid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBSWD_LOGICAL(ISUB, INODE, JNODE, SWDID, STRING, LVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Logical LVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' returned
	IERR = 1 Element not found; 'LVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4 Unknown error with data access; 'LVAL' not returned
	IERR = 10 API Prereqs not met; 'LVAL' not returned

11.69. GET_EXT_SUBSWD_REAL

Use this API to get substation switching device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_subswd_real(isub, inode, jnode, swdid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUBSWD_REAL(ISUB, INODE, JNODE, SWDID, STRING, RVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).	
Integer INODE	SUBSWD inode (input).	
Integer JNODE	SUBSWD jnode (input).	
Character SWDID	SUBSWD swdid (input).	
Character STRING	String indicating the extension SUBSWD field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.70. GET_EXT_SUB_CHAR

Use this API to get substation character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_sub_char(isub, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUB_CHAR(ISUB, STRING, CVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.71. GET_EXT_SUB_INT

Use this API to get substation integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_sub_int(isub, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUB_INT(ISUB, STRING, IVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.72. GET_EXT_SUB_LOGICAL

Use this API to get substation logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_sub_logical(isub, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUB_LOGICAL(ISUB, STRING, LVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.73. GET_EXT_SUB_REAL

Use this API to get substation real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_sub_real(isub, string)
```

Fortran command syntax:

```
CALL GET_EXT_SUB_REAL(ISUB, STRING, RVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.74. GET_EXT_SWSHUNT_CHAR

Use this API to get switched shunt character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_swshunt_char(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SWSHUNT_CHAR(IBUS, SHNTID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).	
Character SHNTID	SWSHUNT shntid (input).	
Character STRING	String indicating the extension SWSHUNT field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.75. GET_EXT_SWSHUNT_INT

Use this API to get switched shunt integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_swshunt_int(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SWSHUNT_INT(IBUS, SHNTID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).	
Character SHNTID	SWSHUNT shntid (input).	
Character STRING	String indicating the extension SWSHUNT field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.77. GET_EXT_SWSHUNT_REAL

Use this API to get switched shunt real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_swshunt_real(ibus, shntid, string)
```

Fortran command syntax:

```
CALL GET_EXT_SWSHUNT_REAL(IBUS, SHNTID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).	
Character SHNTID	SWSHUNT shntid (input).	
Character STRING	String indicating the extension SWSHUNT field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.78. GET_EXT_SYSSWD_CHAR

Use this API to get system switching device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_sysswd_char(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_SYSSWD_CHAR(IBUS, JBUS, CKT, STRING, CVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.79. GET_EXT_SYSSWD_INT

Use this API to get system switching device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_sysswd_int(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_SYSSWD_INT(IBUS, JBUS, CKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.80. GET_EXT_SYSSWD_LOGICAL

Use this API to get system switching device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_sysswd_logical(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_SYSSWD_LOGICAL(IBUS, JBUS, CKT, STRING, LVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.81. GET_EXT_SYSSWD_REAL

Use this API to get system switching device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_sysswd_real(ibus, jbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_SYSSWD_REAL(IBUS, JBUS, CKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.82. GET_EXT_TRANSFORMER_CHAR

Use this API to get transformer character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_transformer_char(ibus, jbus, kbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_TRANSFORMER_CHAR(IBUS, JBUS, KBUS, CKT, STRING, CVAL, IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.83. GET_EXT_TRANSFORMER_INT

Use this API to get transformer integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_transformer_int(ibus, jbus, kbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_TRANSFORMER_INT(IBUS, JBUS, KBUS, CKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
IERR = 0	No error; 'IVAL' returned
IERR = 1	Element not found; 'IVAL' not returned
IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
IERR = 4	Unknown error with data access; 'IVAL' not returned
IERR = 10	API Prereqs not met; 'IVAL' not returned

11.84. GET_EXT_TRANSFORMER_LOGICAL

Use this API to get transformer logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_transformer_logical(ibus, jbus, kbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_TRANSFORMER_LOGICAL(IBUS, JBUS, KBUS, CKT, STRING, LVAL,  
IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Logical LVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
IERR = 0	No error; 'LVAL' returned
IERR = 1	Element not found; 'LVAL' not returned
IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
IERR = 4	Unknown error with data access; 'LVAL' not returned
IERR = 10	API Prereqs not met; 'LVAL' not returned

11.85. GET_EXT_TRANSFORMER_REAL

Use this API to get transformer real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_transformer_real(ibus, jbus, kbus, ckt, string)
```

Fortran command syntax:

```
CALL GET_EXT_TRANSFORMER_REAL(IBUS, JBUS, KBUS, CKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
IERR = 0	No error; 'RVAL' returned
IERR = 1	Element not found; 'RVAL' not returned
IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
IERR = 4	Unknown error with data access; 'RVAL' not returned
IERR = 10	API Prereqs not met; 'RVAL' not returned

11.86. GET_EXT_TWOTERMDC_CHAR

Use this API to get two-terminal dc line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_twotermdc_char(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_TWOTERMDC_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.87. GET_EXT_TWOTERMDC_INT

Use this API to get two-terminal dc line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_twotermdc_int(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_TWOTERMDC_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.88. GET_EXT_TWOTERMDC_LOGICAL

Use this API to get two-terminal dc line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_twotermdc_logical(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_TWOTERMDC_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.89. GET_EXT_TWOTERMDC_REAL

Use this API to get two-terminal dc line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_twotermdc_real(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_TWOTERMDC_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.90. GET_EXT_VSCDC_CHAR

Use this API to get voltage source converter dc line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_vscdc_char(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_VSCDC_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Character*100 CVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' returned
	IERR = 1	Element not found; 'CVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4	Unknown error with data access; 'CVAL' not returned
	IERR = 10	API Prereqs not met; 'CVAL' not returned

11.91. GET_EXT_VSCDC_INT

Use this API to get voltage source converter dc line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_vscdc_int(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_VSCDC_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Integer IVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' returned
	IERR = 1	Element not found; 'IVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4	Unknown error with data access; 'IVAL' not returned
	IERR = 10	API Prereqs not met; 'IVAL' not returned

11.92. GET_EXT_VSCDC_LOGICAL

Use this API to get voltage source converter dc line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_vscdc_logical(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_VSCDC_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Logical LVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' returned
	IERR = 1	Element not found; 'LVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4	Unknown error with data access; 'LVAL' not returned
	IERR = 10	API Prereqs not met; 'LVAL' not returned

11.93. GET_EXT_VSCDC_REAL

Use this API to get voltage source converter dc line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_vscdc_real(name, string)
```

Fortran command syntax:

```
CALL GET_EXT_VSCDC_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Real RVAL	Value indicated by STRING (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' returned
	IERR = 1	Element not found; 'RVAL' not returned
	IERR = 2	Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4	Unknown error with data access; 'RVAL' not returned
	IERR = 10	API Prereqs not met; 'RVAL' not returned

11.94. GET_EXT_ZONE_CHAR

Use this API to get zone character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, cval = get_ext_zone_char(izone, string)
```

Fortran command syntax:

```
CALL GET_EXT_ZONE_CHAR(IZONE, STRING, CVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Character*100 CVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' returned
	IERR = 1 Element not found; 'CVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'CVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not returned
	IERR = 4 Unknown error with data access; 'CVAL' not returned
	IERR = 10 API Prereqs not met; 'CVAL' not returned

11.95. GET_EXT_ZONE_INT

Use this API to get zone integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ival = get_ext_zone_int(izone, string)
```

Fortran command syntax:

```
CALL GET_EXT_ZONE_INT(IZONE, STRING, IVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Integer IVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' returned
	IERR = 1 Element not found; 'IVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'IVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not returned
	IERR = 4 Unknown error with data access; 'IVAL' not returned
	IERR = 10 API Prereqs not met; 'IVAL' not returned

11.96. GET_EXT_ZONE_LOGICAL

Use this API to get zone logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, lval = get_ext_zone_logical(izone, string)
```

Fortran command syntax:

```
CALL GET_EXT_ZONE_LOGICAL(IZONE, STRING, LVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Logical LVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' returned
	IERR = 1 Element not found; 'LVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'LVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not returned
	IERR = 4 Unknown error with data access; 'LVAL' not returned
	IERR = 10 API Prereqs not met; 'LVAL' not returned

11.97. GET_EXT_ZONE_REAL

Use this API to get zone real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, rval = get_ext_zone_real(izone, string)
```

Fortran command syntax:

```
CALL GET_EXT_ZONE_REAL(IZONE, STRING, RVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Real RVAL	Value indicated by STRING (output).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' returned
	IERR = 1 Element not found; 'RVAL' not returned
	IERR = 2 Bad value of 'STRING'; 'RVAL' not returned
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not returned
	IERR = 4 Unknown error with data access; 'RVAL' not returned
	IERR = 10 API Prereqs not met; 'RVAL' not returned

11.98. SET_EXT_ACLINE_CHAR

Use this API to set ac line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_acline_char(ibus, jbus, ckt, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_ACLINE_CHAR(IBUS, JBUS, CKT, STRING, CVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.99. SET_EXT_ACLINE_INT

Use this API to set ac line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_acline_int(ibus, jbus, ckt, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_ACLINE_INT(IBUS, JBUS, CKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.100. SET_EXT_ACLINE_LOGICAL

Use this API to set ac line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_acline_logical(ibus, jbus, ckt, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_ACLINE_LOGICAL(IBUS, JBUS, CKT, STRING, LVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
		set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.101. SET_EXT_ACLINE_REAL

Use this API to set ac line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_acline_real(ibus, jbus, ckt, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_ACLINE_REAL(IBUS, JBUS, CKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	ACLINE ibus (input).	
Integer JBUS	ACLINE jbus (input).	
Character CKT	ACLINE ckt (input).	
Character STRING	String indicating the extension ACLINE field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.102. SET_EXT_AREA_CHAR

Use this API to set area character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_area_char(iarea, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_AREA_CHAR(IAREA, STRING, CVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).
Character STRING	String indicating the extension AREA field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.103. SET_EXT_AREA_INT

Use this API to set area integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_area_int(iarea, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_AREA_INT(IAREA, STRING, IVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).
Character STRING	String indicating the extension AREA field desired (input).
Integer IVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
IERR = 0	No error; 'IVAL' set
IERR = 1	Element not found; 'IVAL' not set
IERR = 2	Bad value of 'STRING'; 'IVAL' not set
IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
IERR = 4	Unknown error with data access; 'IVAL' not set
IERR = 10	API Prereqs not met; 'IVAL' not set

11.104. SET_EXT_AREA_LOGICAL

Use this API to set area logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_area_logical(iarea, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_AREA_LOGICAL(IAREA, STRING, LVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).	
Character STRING	String indicating the extension AREA field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.105. SET_EXT_AREA_REAL

Use this API to set area real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_area_real(iarea, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_AREA_REAL(IAREA, STRING, RVAL, IERR)
```

Where:

Integer IAREA	AREA iarea (input).
Character STRING	String indicating the extension AREA field desired (input).
Real RVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' set
	IERR = 1 Element not found; 'RVAL' not set
	IERR = 2 Bad value of 'STRING'; 'RVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4 Unknown error with data access; 'RVAL' not set
	IERR = 10 API Prereqs not met; 'RVAL' not set

11.106. SET_EXT_BUS_CHAR

Use this API to set bus character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_bus_char(ibus, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_BUS_CHAR(IBUS, STRING, CVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).
Character STRING	String indicating the extension BUS field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.107. SET_EXT_BUS_INT

Use this API to set bus integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_bus_int(ibus, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_BUS_INT(IBUS, STRING, IVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).	
Character STRING	String indicating the extension BUS field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.108. SET_EXT_BUS_LOGICAL

Use this API to set bus logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_bus_logical(ibus, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_BUS_LOGICAL(IBUS, STRING, LVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).	
Character STRING	String indicating the extension BUS field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.109. SET_EXT_BUS_REAL

Use this API to set bus real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_bus_real(ibus, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_BUS_REAL(IBUS, STRING, RVAL, IERR)
```

Where:

Integer IBUS	BUS ibus (input).	
Character STRING	String indicating the extension BUS field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.110. SET_EXT_CHAR

Use this API to set character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_char(tblname, string, irow, cval)
```

Fortran command syntax:

```
CALL SET_EXT_CHAR(TBLNAME, STRING, IROW, CVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Character CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'CVAL' not set

11.111. SET_EXT_FACTS_CHAR

Use this API to set facts device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_facts_char(name, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_FACTS_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.112. SET_EXT_FACTS_INT

Use this API to set facts device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_facts_int(name, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_FACTS_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.113. SET_EXT_FACTS_LOGICAL

Use this API to set facts device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_facts_logical(name, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_FACTS_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.114. SET_EXT_FACTS_REAL

Use this API to set facts device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_facts_real(name, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_FACTS_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	FACTS name (input).	
Character STRING	String indicating the extension FACTS field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.115. SET_EXT_FIXSHUNT_CHAR

Use this API to set fixed shunt character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_fixshunt_char(ibus, shntid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_FIXSHUNT_CHAR(IBUS, SHNTID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
		set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.116. SET_EXT_FIXSHUNT_INT

Use this API to set fixed shunt integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_fixshunt_int(ibus, shntid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_FIXSHUNT_INT(IBUS, SHNTID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.117. SET_EXT_FIXSHUNT_LOGICAL

Use this API to set fixed shunt logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_fixshunt_logical(ibus, shntid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_FIXSHUNT_LOGICAL(IBUS, SHNTID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.118. SET_EXT_FIXSHUNT_REAL

Use this API to set fixed shunt real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_fixshunt_real(ibus, shntid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_FIXSHUNT_REAL(IBUS, SHNTID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	FIXSHUNT ibus (input).	
Character SHNTID	FIXSHUNT shntid (input).	
Character STRING	String indicating the extension FIXSHUNT field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.119. SET_EXT_GENERATOR_CHAR

Use this API to set generator character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_generator_char(ibus, machid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_GENERATOR_CHAR(IBUS, MACHID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).
Character MACHID	GENERATOR machid (input).
Character STRING	String indicating the extension GENERATOR field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.120. SET_EXT_GENERATOR_INT

Use this API to set generator integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_generator_int(ibus, machid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_GENERATOR_INT(IBUS, MACHID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).	
Character MACHID	GENERATOR machid (input).	
Character STRING	String indicating the extension GENERATOR field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.121. SET_EXT_GENERATOR_LOGICAL

Use this API to set generator logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_generator_logical(ibus, machid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_GENERATOR_LOGICAL(IBUS, MACHID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).	
Character MACHID	GENERATOR machid (input).	
Character STRING	String indicating the extension GENERATOR field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.122. SET_EXT_GENERATOR_REAL

Use this API to set generator real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_generator_real(ibus, machid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_GENERATOR_REAL(IBUS, MACHID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	GENERATOR ibus (input).	
Character MACHID	GENERATOR machid (input).	
Character STRING	String indicating the extension GENERATOR field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.123. SET_EXT_GNE_CHAR

Use this API to set general network element device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_gne_char(name, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_GNE_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	GNE name (input).
Character STRING	String indicating the extension GNE field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.124. SET_EXT_GNE_INT

Use this API to set general network element device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_gne_int(name, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_GNE_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.125. SET_EXT_GNE_LOGICAL

Use this API to set general network element device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_gne_logical(name, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_GNE_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.126. SET_EXT_GNE_REAL

Use this API to set general network element device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_gne_real(name, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_GNE_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	GNE name (input).	
Character STRING	String indicating the extension GNE field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.127. SET_EXT_IATRANS_CHAR

Use this API to set inter-area transfer character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_iatrans_char(arfrom, arto, trid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_IATRANS_CHAR(ARFROM, ARTO, TRID, STRING, CVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).
Integer ARTO	IATRANS arto (input).
Character TRID	IATRANS trid (input).
Character STRING	String indicating the extension IATRANS field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.128. SET_EXT_IATRANS_INT

Use this API to set inter-area transfer integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_iatrans_int(arfrom, arto, trid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_IATRANS_INT(ARFROM, ARTO, TRID, STRING, IVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).
Integer ARTO	IATRANS arto (input).
Character TRID	IATRANS trid (input).
Character STRING	String indicating the extension IATRANS field desired (input).
Integer IVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' set
	IERR = 1 Element not found; 'IVAL' not set
	IERR = 2 Bad value of 'STRING'; 'IVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4 Unknown error with data access; 'IVAL' not set
	IERR = 10 API Prereqs not met; 'IVAL' not set

11.129. SET_EXT_IATRANS_LOGICAL

Use this API to set inter-area transfer logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_iatrans_logical(arfrom, arto, trid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_IATRANS_LOGICAL(ARFROM, ARTO, TRID, STRING, LVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).	
Integer ARTO	IATRANS arto (input).	
Character TRID	IATRANS trid (input).	
Character STRING	String indicating the extension IATRANS field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.130. SET_EXT_IATRANS_REAL

Use this API to set inter-area transfer real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_iatrans_real(arfrom, arto, trid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_IATRANS_REAL(ARFROM, ARTO, TRID, STRING, RVAL, IERR)
```

Where:

Integer ARFROM	IATRANS arfrom (input).	
Integer ARTO	IATRANS arto (input).	
Character TRID	IATRANS trid (input).	
Character STRING	String indicating the extension IATRANS field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.131. SET_EXT_INDMACH_CHAR

Use this API to set induction machine character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_indmach_char(ibus, imid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_INDMACH_CHAR(IBUS, IMID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
		set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.132. SET_EXT_INDMACH_INT

Use this API to set induction machine integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_indmach_int(ibus, imid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_INDMACH_INT(IBUS, IMID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).
Character IMID	INDMACH imid (input).
Character STRING	String indicating the extension INDMACH field desired (input).
Integer IVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' set
	IERR = 1 Element not found; 'IVAL' not set
	IERR = 2 Bad value of 'STRING'; 'IVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4 Unknown error with data access; 'IVAL' not set
	IERR = 10 API Prereqs not met; 'IVAL' not set

11.133. SET_EXT_INDMACH_LOGICAL

Use this API to set induction machine logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_indmach_logical(ibus, imid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_INDMACH_LOGICAL(IBUS, IMID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.134. SET_EXT_INDMACH_REAL

Use this API to set induction machine real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_indmach_real(ibus, imid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_INDMACH_REAL(IBUS, IMID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	INDMACH ibus (input).	
Character IMID	INDMACH imid (input).	
Character STRING	String indicating the extension INDMACH field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.135. SET_EXT_INT

Use this API to set integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_int(tblname, string, irow, ival)
```

Fortran command syntax:

```
CALL SET_EXT_INT(TBLNAME, STRING, IROW, IVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'IVAL' not set

11.136. SET_EXT_LOAD_CHAR

Use this API to set load character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_load_char(ibus, loadid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_LOAD_CHAR(IBUS, LOADID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	LOAD ibus (input).	
Character LOADID	LOAD loadid (input).	
Character STRING	String indicating the extension LOAD field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
		set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.137. SET_EXT_LOAD_INT

Use this API to set load integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_load_int(ibus, loadid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_LOAD_INT(IBUS, LOADID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	LOAD ibus (input).	
Character LOADID	LOAD loadid (input).	
Character STRING	String indicating the extension LOAD field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.138. SET_EXT_LOAD_LOGICAL

Use this API to set load logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_load_logical(ibus, loadid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_LOAD_LOGICAL(IBUS, LOADID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	LOAD ibus (input).	
Character LOADID	LOAD loadid (input).	
Character STRING	String indicating the extension LOAD field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
		set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.139. SET_EXT_LOAD_REAL

Use this API to set load real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_load_real(ibus, loadid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_LOAD_REAL(IBUS, LOADID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	LOAD ibus (input).	
Character LOADID	LOAD loadid (input).	
Character STRING	String indicating the extension LOAD field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
		set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.140. SET_EXT_LOGICAL

Use this API to set logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_logical(tblname, string, irow, lval)
```

Fortran command syntax:

```
CALL SET_EXT_LOGICAL(TBLNAME, STRING, IROW, LVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'LVAL' not set

11.141. SET_EXT_MSLINE_CHAR

Use this API to set multi-section line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_msline_char(ibus, jbus, mslid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_MSLINE_CHAR(IBUS, JBUS, MSLID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.142. SET_EXT_MSLINE_INT

Use this API to set multi-section line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_msline_int(ibus, jbus, mslid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_MSLINE_INT(IBUS, JBUS, MSLID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Integer IVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' set
	IERR = 1 Element not found; 'IVAL' not set
	IERR = 2 Bad value of 'STRING'; 'IVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4 Unknown error with data access; 'IVAL' not set
	IERR = 10 API Prereqs not met; 'IVAL' not set

11.143. SET_EXT_MSLINE_LOGICAL

Use this API to set multi-section line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_msline_logical(ibus, jbus, mslid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_MSLINE_LOGICAL(IBUS, JBUS, MSLID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Logical LVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' set
	IERR = 1 Element not found; 'LVAL' not set
	IERR = 2 Bad value of 'STRING'; 'LVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4 Unknown error with data access; 'LVAL' not set
	IERR = 10 API Prereqs not met; 'LVAL' not set

11.144. SET_EXT_MSLINE_REAL

Use this API to set multi-section line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_msline_real(ibus, jbus, mslid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_MSLINE_REAL(IBUS, JBUS, MSLID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	MSLINE ibus (input).
Integer JBUS	MSLINE jbus (input).
Character MSLID	MSLINE mslid (input).
Character STRING	String indicating the extension MSLINE field desired (input).
Real RVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' set
	IERR = 1 Element not found; 'RVAL' not set
	IERR = 2 Bad value of 'STRING'; 'RVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4 Unknown error with data access; 'RVAL' not set
	IERR = 10 API Prereqs not met; 'RVAL' not set

11.145. SET_EXT_NTERMDC_CHAR

Use this API to set multi-terminal dc line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_ntermdc_char(name, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_NTERMDC_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.146. SET_EXT_NTERMDC_INT

Use this API to set multi-terminal dc line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_ntermdc_int(name, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_NTERMDC_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.147. SET_EXT_NTERMDC_LOGICAL

Use this API to set multi-terminal dc line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_ntermdc_logical(name, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_NTERMDC_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.148. SET_EXT_NTERMDC_REAL

Use this API to set multi-terminal dc line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_ntermdc_real(name, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_NTERMDC_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	NTERMDC name (input).	
Character STRING	String indicating the extension NTERMDC field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.149. SET_EXT_OWNER_CHAR

Use this API to set owner character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_owner_char(iowner, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_OWNER_CHAR(IOWNER, STRING, CVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).	
Character STRING	String indicating the extension OWNER field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.150. SET_EXT_OWNER_INT

Use this API to set owner integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_owner_int(iowner, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_OWNER_INT(IOWNER, STRING, IVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).	
Character STRING	String indicating the extension OWNER field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.151. SET_EXT_OWNER_LOGICAL

Use this API to set owner logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_owner_logical(iowner, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_OWNER_LOGICAL(IOWNER, STRING, LVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).	
Character STRING	String indicating the extension OWNER field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.152. SET_EXT_OWNER_REAL

Use this API to set owner real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_owner_real(iowner, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_OWNER_REAL(IOWNER, STRING, RVAL, IERR)
```

Where:

Integer IOWNER	OWNER iowner (input).	
Character STRING	String indicating the extension OWNER field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.153. SET_EXT_RATING_CHAR

Use this API to set rating character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_rating_char(irate, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_RATING_CHAR(IRATE, STRING, CVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.154. SET_EXT_RATING_INT

Use this API to set rating integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_rating_int(irate, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_RATING_INT(IRATE, STRING, IVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.155. SET_EXT_RATING_LOGICAL

Use this API to set rating logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_rating_logical(irate, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_RATING_LOGICAL(IRATE, STRING, LVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.156. SET_EXT_RATING_REAL

Use this API to set rating real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_rating_real(irate, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_RATING_REAL(IRATE, STRING, RVAL, IERR)
```

Where:

Integer IRATE	RATING irate (input).	
Character STRING	String indicating the extension RATING field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.157. SET_EXT_REAL

Use this API to set real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_real(tblname, string, irow, rval)
```

Fortran command syntax:

```
CALL SET_EXT_REAL(TBLNAME, STRING, IROW, RVAL, IERR)
```

Where:

Character TBLNAME	Extension table name (input).	
Character STRING	String indicating the extension field desired (input).	
Integer IROW	Row index of desired data item (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 5	Data table row index 'IROW' out-of-bounds; 'RVAL' not set

11.158. SET_EXT_SUBNODE_CHAR

Use this API to set substation node character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subnode_char(isub, inode, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_SUBNODE_CHAR(ISUB, INODE, STRING, CVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).	
Integer INODE	SUBNODE inode (input).	
Character STRING	String indicating the extension SUBNODE field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
		set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.159. SET_EXT_SUBNODE_INT

Use this API to set substation node integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subnode_int(isub, inode, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_SUBNODE_INT(ISUB, INODE, STRING, IVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).	
Integer INODE	SUBNODE inode (input).	
Character STRING	String indicating the extension SUBNODE field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.160. SET_EXT_SUBNODE_LOGICAL

Use this API to set substation node logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subnode_logical(isub, inode, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_SUBNODE_LOGICAL(ISUB, INODE, STRING, LVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).
Integer INODE	SUBNODE inode (input).
Character STRING	String indicating the extension SUBNODE field desired (input).
Logical LVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' set
	IERR = 1 Element not found; 'LVAL' not set
	IERR = 2 Bad value of 'STRING'; 'LVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4 Unknown error with data access; 'LVAL' not set
	IERR = 10 API Prereqs not met; 'LVAL' not set

11.161. SET_EXT_SUBNODE_REAL

Use this API to set substation node real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subnode_real(isub, inode, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_SUBNODE_REAL(ISUB, INODE, STRING, RVAL, IERR)
```

Where:

Integer ISUB	SUBNODE isub (input).	
Integer INODE	SUBNODE inode (input).	
Character STRING	String indicating the extension SUBNODE field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
		set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.162. SET_EXT_SUBSWD_CHAR

Use this API to set substation switching device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subswd_char(isub, inode, jnode, swdid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_SUBSWD_CHAR(ISUB, INODE, JNODE, SWDID, STRING, CVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.163. SET_EXT_SUBSWD_INT

Use this API to set substation switching device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subswd_int(isub, inode, jnode, swdid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_SUBSWD_INT(ISUB, INODE, JNODE, SWDID, STRING, IVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Integer IVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'IVAL' set
	IERR = 1 Element not found; 'IVAL' not set
	IERR = 2 Bad value of 'STRING'; 'IVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4 Unknown error with data access; 'IVAL' not set
	IERR = 10 API Prereqs not met; 'IVAL' not set

11.164. SET_EXT_SUBSWD_LOGICAL

Use this API to set substation switching device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subswd_logical(isub, inode, jnode, swdid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_SUBSWD_LOGICAL(ISUB, INODE, JNODE, SWDID, STRING, LVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Logical LVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' set
	IERR = 1 Element not found; 'LVAL' not set
	IERR = 2 Bad value of 'STRING'; 'LVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4 Unknown error with data access; 'LVAL' not set
	IERR = 10 API Prereqs not met; 'LVAL' not set

11.165. SET_EXT_SUBSWD_REAL

Use this API to set substation switching device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_subswd_real(isub, inode, jnode, swdid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_SUBSWD_REAL(ISUB, INODE, JNODE, SWDID, STRING, RVAL, IERR)
```

Where:

Integer ISUB	SUBSWD isub (input).
Integer INODE	SUBSWD inode (input).
Integer JNODE	SUBSWD jnode (input).
Character SWDID	SUBSWD swdid (input).
Character STRING	String indicating the extension SUBSWD field desired (input).
Real RVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' set
	IERR = 1 Element not found; 'RVAL' not set
	IERR = 2 Bad value of 'STRING'; 'RVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4 Unknown error with data access; 'RVAL' not set
	IERR = 10 API Prereqs not met; 'RVAL' not set

11.166. SET_EXT_SUB_CHAR

Use this API to set substation character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sub_char(isub, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_SUB_CHAR(ISUB, STRING, CVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.167. SET_EXT_SUB_INT

Use this API to set substation integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sub_int(isub, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_SUB_INT(ISUB, STRING, IVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.168. SET_EXT_SUB_LOGICAL

Use this API to set substation logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sub_logical(isub, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_SUB_LOGICAL(ISUB, STRING, LVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.169. SET_EXT_SUB_REAL

Use this API to set substation real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sub_real(isub, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_SUB_REAL(ISUB, STRING, RVAL, IERR)
```

Where:

Integer ISUB	SUB isub (input).	
Character STRING	String indicating the extension SUB field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.170. SET_EXT_SWSHUNT_CHAR

Use this API to set switched shunt character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_swshunt_char(ibus, shntid, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_SWSHUNT_CHAR(IBUS, SHNTID, STRING, CVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).	
Character SHNTID	SWSHUNT shntid (input).	
Character STRING	String indicating the extension SWSHUNT field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.171. SET_EXT_SWSHUNT_INT

Use this API to set switched shunt integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_swshunt_int(ibus, shntid, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_SWSHUNT_INT(IBUS, SHNTID, STRING, IVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).	
Character SHNTID	SWSHUNT shntid (input).	
Character STRING	String indicating the extension SWSHUNT field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.172. SET_EXT_SWSHUNT_LOGICAL

Use this API to set switched shunt logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_swshunt_logical(ibus, shntid, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_SWSHUNT_LOGICAL(IBUS, SHNTID, STRING, LVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).
Character SHNTID	SWSHUNT shntid (input).
Character STRING	String indicating the extension SWSHUNT field desired (input).
Logical LVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' set
	IERR = 1 Element not found; 'LVAL' not set
	IERR = 2 Bad value of 'STRING'; 'LVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4 Unknown error with data access; 'LVAL' not set
	IERR = 10 API Prereqs not met; 'LVAL' not set

11.173. SET_EXT_SWSHUNT_REAL

Use this API to set switched shunt real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_swshunt_real(ibus, shntid, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_SWSHUNT_REAL(IBUS, SHNTID, STRING, RVAL, IERR)
```

Where:

Integer IBUS	SWSHUNT ibus (input).	
Character SHNTID	SWSHUNT shntid (input).	
Character STRING	String indicating the extension SWSHUNT field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.174. SET_EXT_SYSSWD_CHAR

Use this API to set system switching device character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sysswd_char(ibus, jbus, ckt, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_SYSSWD_CHAR(IBUS, JBUS, CKT, STRING, CVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.175. SET_EXT_SYSSWD_INT

Use this API to set system switching device integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sysswd_int(ibus, jbus, ckt, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_SYSSWD_INT(IBUS, JBUS, CKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.176. SET_EXT_SYSSWD_LOGICAL

Use this API to set system switching device logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sysswd_logical(ibus, jbus, ckt, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_SYSSWD_LOGICAL(IBUS, JBUS, CKT, STRING, LVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.177. SET_EXT_SYSSWD_REAL

Use this API to set system switching device real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_sysswd_real(ibus, jbus, ckt, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_SYSSWD_REAL(IBUS, JBUS, CKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	SYSSWD ibus (input).	
Integer JBUS	SYSSWD jbus (input).	
Character CKT	SYSSWD ckt (input).	
Character STRING	String indicating the extension SYSSWD field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
		set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.178. SET_EXT_TRANSFORMER_CHAR

Use this API to set transformer character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_transformer_char(ibus, jbus, kbus, ckt, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_TRANSFORMER_CHAR(IBUS, JBUS, KBUS, CKT, STRING, CVAL, IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.179. SET_EXT_TRANSFORMER_INT

Use this API to set transformer integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_transformer_int(ibus, jbus, kbus, ckt, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_TRANSFORMER_INT(IBUS, JBUS, KBUS, CKT, STRING, IVAL, IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Integer IVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
IERR = 0	No error; 'IVAL' set
IERR = 1	Element not found; 'IVAL' not set
IERR = 2	Bad value of 'STRING'; 'IVAL' not set
IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
IERR = 4	Unknown error with data access; 'IVAL' not set
IERR = 10	API Prereqs not met; 'IVAL' not set

11.180. SET_EXT_TRANSFORMER_LOGICAL

Use this API to set transformer logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_transformer_logical(ibus, jbus, kbus, ckt, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_TRANSFORMER_LOGICAL(IBUS, JBUS, KBUS, CKT, STRING, LVAL,  
IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Logical LVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
IERR = 0	No error; 'LVAL' set
IERR = 1	Element not found; 'LVAL' not set
IERR = 2	Bad value of 'STRING'; 'LVAL' not set
IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
IERR = 4	Unknown error with data access; 'LVAL' not set
IERR = 10	API Prereqs not met; 'LVAL' not set

11.181. SET_EXT_TRANSFORMER_REAL

Use this API to set transformer real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_transformer_real(ibus, jbus, kbus, ckt, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_TRANSFORMER_REAL(IBUS, JBUS, KBUS, CKT, STRING, RVAL, IERR)
```

Where:

Integer IBUS	TRANSFORMER ibus (input).
Integer JBUS	TRANSFORMER jbus (input).
Integer KBUS	TRANSFORMER kbus (input).
Character CKT	TRANSFORMER ckt (input).
Character STRING	String indicating the extension TRANSFORMER field desired (input).
Real RVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
IERR = 0	No error; 'RVAL' set
IERR = 1	Element not found; 'RVAL' not set
IERR = 2	Bad value of 'STRING'; 'RVAL' not set
IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
IERR = 4	Unknown error with data access; 'RVAL' not set
IERR = 10	API Prereqs not met; 'RVAL' not set

11.182. SET_EXT_TWOTERMDC_CHAR

Use this API to set two-terminal dc line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_twotermdc_char(name, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_TWOTERMDC_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.183. SET_EXT_TWOTERMDC_INT

Use this API to set two-terminal dc line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_twotermdc_int(name, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_TWOTERMDC_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.184. SET_EXT_TWOTERMDC_LOGICAL

Use this API to set two-terminal dc line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_twotermdc_logical(name, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_TWOTERMDC_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.185. SET_EXT_TWOTERMDC_REAL

Use this API to set two-terminal dc line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_twotermdc_real(name, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_TWOTERMDC_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	TWOTERMDC name (input).	
Character STRING	String indicating the extension TWOTERMDC field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.186. SET_EXT_VSCDC_CHAR

Use this API to set voltage source converter dc line character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_vscdc_char(name, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_VSCDC_CHAR(NAME, STRING, CVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Character*100 CVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'CVAL' set
	IERR = 1	Element not found; 'CVAL' not set
	IERR = 2	Bad value of 'STRING'; 'CVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4	Unknown error with data access; 'CVAL' not set
	IERR = 10	API Prereqs not met; 'CVAL' not set

11.187. SET_EXT_VSCDC_INT

Use this API to set voltage source converter dc line integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_vscdc_int(name, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_VSCDC_INT(NAME, STRING, IVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.188. SET_EXT_VSCDC_LOGICAL

Use this API to set voltage source converter dc line logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_vscdc_logical(name, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_VSCDC_LOGICAL(NAME, STRING, LVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Logical LVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'LVAL' set
	IERR = 1	Element not found; 'LVAL' not set
	IERR = 2	Bad value of 'STRING'; 'LVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4	Unknown error with data access; 'LVAL' not set
	IERR = 10	API Prereqs not met; 'LVAL' not set

11.189. SET_EXT_VSCDC_REAL

Use this API to set voltage source converter dc line real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_vscdc_real(name, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_VSCDC_REAL(NAME, STRING, RVAL, IERR)
```

Where:

Character NAME	VSCDC name (input).	
Character STRING	String indicating the extension VSCDC field desired (input).	
Real RVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'RVAL' set
	IERR = 1	Element not found; 'RVAL' not set
	IERR = 2	Bad value of 'STRING'; 'RVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4	Unknown error with data access; 'RVAL' not set
	IERR = 10	API Prereqs not met; 'RVAL' not set

11.190. SET_EXT_ZONE_CHAR

Use this API to set zone character extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_zone_char(izone, string, cval)
```

Fortran command syntax:

```
CALL SET_EXT_ZONE_CHAR(IZONE, STRING, CVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Character*100 CVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'CVAL' set
	IERR = 1 Element not found; 'CVAL' not set
	IERR = 2 Bad value of 'STRING'; 'CVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'CVAL' not set
	IERR = 4 Unknown error with data access; 'CVAL' not set
	IERR = 10 API Prereqs not met; 'CVAL' not set

11.191. SET_EXT_ZONE_INT

Use this API to set zone integer extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_zone_int(izone, string, ival)
```

Fortran command syntax:

```
CALL SET_EXT_ZONE_INT(IZONE, STRING, IVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).	
Character STRING	String indicating the extension ZONE field desired (input).	
Integer IVAL	Value indicated by STRING (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'IVAL' set
	IERR = 1	Element not found; 'IVAL' not set
	IERR = 2	Bad value of 'STRING'; 'IVAL' not set
	IERR = 3	Bad data type for field 'STRING'; 'IVAL' not set
	IERR = 4	Unknown error with data access; 'IVAL' not set
	IERR = 10	API Prereqs not met; 'IVAL' not set

11.192. SET_EXT_ZONE_LOGICAL

Use this API to set zone logical extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_zone_logical(izone, string, lval)
```

Fortran command syntax:

```
CALL SET_EXT_ZONE_LOGICAL(IZONE, STRING, LVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Logical LVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'LVAL' set
	IERR = 1 Element not found; 'LVAL' not set
	IERR = 2 Bad value of 'STRING'; 'LVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'LVAL' not set
	IERR = 4 Unknown error with data access; 'LVAL' not set
	IERR = 10 API Prereqs not met; 'LVAL' not set

11.193. SET_EXT_ZONE_REAL

Use this API to set zone real extension data.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr = set_ext_zone_real(izone, string, rval)
```

Fortran command syntax:

```
CALL SET_EXT_ZONE_REAL(IZONE, STRING, RVAL, IERR)
```

Where:

Integer IZONE	ZONE ize (input).
Character STRING	String indicating the extension ZONE field desired (input).
Real RVAL	Value indicated by STRING (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'RVAL' set
	IERR = 1 Element not found; 'RVAL' not set
	IERR = 2 Bad value of 'STRING'; 'RVAL' not set
	IERR = 3 Bad data type for field 'STRING'; 'RVAL' not set
	IERR = 4 Unknown error with data access; 'RVAL' not set
	IERR = 10 API Prereqs not met; 'RVAL' not set

Chapter 12

Subsystem Data Retrieval

The subsystem data retrieval APIs are used to retrieve data from the PSS®E engine for elements (e.g., buses, branches, etc.) in a subsystem. One or more input data items to each API allow the user to restrict the elements for which data is returned to a subset of subsystem elements (e.g., to omit out-of-service elements).

These APIs are grouped into families with each family containing up to six APIs:

- An API that returns the number of array entries required to hold one set of subsystem data items returned by the data retrieval APIs in the family (e.g., GET_BUS_COUNT returns the number of buses in subsystem SID that meet the editing criterion indicated by FLAG).
- A data retrieval API that returns an array of one or more sets of integer data values.
- A data retrieval API that returns an array of one or more sets of real data values.
- A data retrieval API that returns an array of one or more sets of complex data values.
- A data retrieval API that returns an array of one or more sets of character data values.
- An API that returns information on the data types corresponding to specified STRING values, each of which may be specified to one or more of the data retrieval APIs in the family. STRING values that are valid input values for both the real and complex data retrieval APIs of a family are indicated as being of type complex.

Each of the data retrieval APIs returns an array of one or more columns containing subsystem data items. Input arguments specify the name of the array to be used, the number data items to be retrieved (which is also the minimum number of columns required in the array), and the number of elements in each column (which must be at least as large as the number returned by the first API listed above). Array elements beyond those required to accommodate the requested data items are left unchanged by the data retrieval APIs.

These routines do not record themselves when called with recording enabled.

12.1. Character Data

Prior to calling any of the subsystem data retrieval APIs, space for the array that is to receive the set(s) of data items that are to be returned must be allocated. For character data items, the number of characters required for each array entry for the data corresponding to any of the STRING arguments of the character data retrieval APIs (i.e., the a*Char APIs) may be obtained from the GET_CHAR_LENGTH API.

12.1.1. GET_CHAR_LENGTH

Use this API to return the number of characters required to accommodate the data corresponding to the specified STRING entries, which can be for any of the a*Char data retrieval functions.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, nchars = get_char_length(string)
```

Fortran command syntax:

```
CALL GET_CHAR_LENGTH(NSTR, STRING, NCHARS, IERR)
```

Where:

Integer NSTR	number of elements in STRING and NCHARS (1 < NSTR < 50); no default allowed	
Character STRING (NSTR)	NSTR valid strings for the a*Char data retrieval functions to be used (input; no default allowed).	
Integer NCHARS (NSTR)	NSTR entries containing the number of characters of each element of the array associated with the corresponding STRING value (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1-50	Position of an element in the array STRING that contains a value that is not recognized by any of the a*Char API routines
	IERR = 99	Invalid NSTR value

12.2. Bus Data

The bus data family of subsystem data retrieval APIs returns arrays of data for buses in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem buses, or to restrict the array entries to data for in-service buses.

Data for subsystem buses is returned from all APIs in the bus data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced.

12.2.1. ABUSCHAR

Use this API to return an array of character values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = abuschar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_BUS_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default). FLAG = 1 for only in-service buses. FLAG = 2 for all buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus quantities desired (input; no default allowed). 'NAME' Bus name (12 characters). 'EXNAME' Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).

Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.2.2. ABUSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the bus data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, buses = abuscount(sid, flag)
```

Fortran command syntax:

```
CALL GET_BUS_COUNT(SID, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service buses.
	FLAG = 2	for all buses.
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid FLAG value; BUSES returned as 0

12.2.3. ABUSCPLX

Use this API to return an array of complex values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = abuscplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_BUS_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service buses.
	FLAG = 2	for all buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage, in pu, rectangular coordinates
	'SHUNTACT'	Actual total in-service fixed bus shunt, in MW and Mvar
	'O_SHUNTACT'	Actual total in-service fixed bus shunt, in units determined by the power output option setting
	'SHUNTNOM'	Nominal total in-service fixed bus shunt, in MW and Mvar at 1.0 pu voltage
	'O_SHUNTNOM'	Nominal total in-service fixed bus shunt, in units determined by the power output option setting at 1.0 pu voltage
	'SHUNTN'	Total in-service negative sequence load (pu nominal)
	'SHUNTZ'	Total in-service zero sequence load (pu nominal)
	'MISMATCH'	Bus mismatch, in MW and Mvar (0.0 if bus type code > 3)

	'O_MISMATCH'	Bus mismatch, in units determined by the power output option setting (0.0 if bus type code > 3)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'SHUNTN' or 'SHUNTZ')

12.2.4. ABUSINT

Use this API to return an array of integer values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = abusint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_BUS_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default). FLAG = 1 for only in-service buses. FLAG = 2 for all buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus quantities desired (input; no default allowed). 'NUMBER' Bus number 'TYPE' Bus type code 'AREA' Bus area number 'ZONE' Bus zone number 'OWNER' Bus owner number 'SECTION' Bus section number, 0 if bus is not in a substation 'STATION' Bus substation number, 0 if bus is not in a substation 'DUMMY' Returns 1 if the bus is a dummy bus of a multisection line, or 0 if it is not
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the

Integer IERR	GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.2.5. ABUSREAL

Use this API to return an array of real values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = abusreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_BUS_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service buses.
	FLAG = 2	for all buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage, in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'NVLMIH'	Normal high voltage limit, in pu
	'NVLMLLO'	Normal low voltage limit, in pu
	'EVLMIH'	Emergency high voltage limit, in pu
	'EVLMLLO'	Emergency low voltage limit, in pu
	'MISMATCH'	Bus mismatch, in MVA (0.0 if bus type code > 3)
	'O_MISMATCH'	Bus mismatch, in units determined by the power output option setting (0.0 if bus type code > 3)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	

Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.2.6. ABUSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the bus data family (aBusInt, aBusReal, aBusCplx and aBusChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = abustypes(string)
```

Fortran command syntax:

```
CALL GET_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.3. Plant Bus Data

The plant bus data family of subsystem data retrieval APIs returns arrays of data for buses in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem buses, or to restrict the array entries to data for a subset of buses according to their bus, plant, and/or machine configuration and statuses

Data for subsystem buses is returned from all APIs in the plant bus data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced.

12.3.1. AGENBUSCHAR

Use this API to return an array of character values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = agenbuschar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_PLANT_BUS_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service plant buses (type code 2 or 3) with at least one in-service machine.
	FLAG = 2	for only in-service plant buses (type code 2 or 3), including those with no in-service machines.
	FLAG = 3	for all in-service buses, including those that are not plant buses.
	FLAG = 4	for all plant buses, including those with no in-service machines.
	FLAG = 5	for all buses, including those that are not plant buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or plant quantities desired (input; no default allowed).	

	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
	'IREGNAME'	Bus name of regulated bus (12 characters).
	'IREGEXNAME'	Extended bus name of regulated bus (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.3.2. AGENBUSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the plant bus data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, buses = agenbuscount(sid, flag)
```

Fortran command syntax:

```
CALL GET_PLANT_BUS_COUNT(SID, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service plant buses (type code 2 or 3) with at least one in-service machine.
	FLAG = 2	for only in-service plant buses (type code 2 or 3), including those with no in-service machines.
	FLAG = 3	for all in-service buses, including those that are not plant buses.
	FLAG = 4	for all plant buses, including those with no in-service machines.
	FLAG = 5	for all buses, including those that are not plant buses.
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid FLAG value; BUSES returned as 0

12.3.3. AGENBUSCPLX

Use this API to return an array of complex values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = agenbuscplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_PLANT_BUS_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service plant buses (type code 2 or 3) with at least one in-service machine.
	FLAG = 2	for only in-service plant buses (type code 2 or 3), including those with no in-service machines.
	FLAG = 3	for all in-service buses, including those that are not plant buses.
	FLAG = 4	for all plant buses, including those with no in-service machines.
	FLAG = 5	for all buses, including those that are not plant buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or plant quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage, in pu, rectangular coordinates
	'PQGEN'	Power output of in-service machines at this plant (returns MW and Mvar)
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (returns MW and Mvar)
	'O_PQGEN'	Power output of in-service machines at this plant (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)

Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.3.4. AGENBUSINT

Use this API to return an array of integer values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = agenbusint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_PLANT_BUS_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service plant buses (type code 2 or 3) with at least one in-service machine.
	FLAG = 2	for only in-service plant buses (type code 2 or 3), including those with no in-service machines.
	FLAG = 3	for all in-service buses, including those that are not plant buses.
	FLAG = 4	for all plant buses, including those with no in-service machines.
	FLAG = 5	for all buses, including those that are not plant buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or plant quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'STATION'	Substation number (0 if bus is not in a substation)
	'SECTION'	Bus section number (0 if bus is not represented by multiple bus sections)
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number
	'OWNER'	Bus owner number

	'DUMMY'	Returns 1 if the bus is a dummy bus of a multisection line or 0 if it is not
	'STATUS'	Inferred plant status. Returns 1 if the bus type code is 2 or 3 and at least one in-service machine is present or 0 otherwise
	'IREG'	Bus number of the regulated bus
	'NREG'	Node number of the regulated node
Integer DIM	number of elements in each column of the array IARRAY. DIM must be at least as large as the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.3.5. AGENBUSREAL

Use this API to return an array of real values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = agenbusreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_PLANT_BUS_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service plant buses (type code 2 or 3) with at least one in-service machine.
	FLAG = 2	for only in-service plant buses (type code 2 or 3), including those with no in-service machines.
	FLAG = 3	for all in-service buses, including those that are not plant buses.
	FLAG = 4	for all plant buses, including those with no in-service machines.
	FLAG = 5	for all buses, including those that are not plant buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or plant quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'PERCENT'	MVA loading as a percentage of total plant MVA base, MBASE
	'IREGBASE'	Regulated bus base voltage, in kV
	'IREGPU'	Actual regulated bus voltage magnitude, in pu

'IREGKV'	Actual regulated bus voltage magnitude, in kV (in pu if base voltage is 0.0)
'VSPU'	Regulated bus scheduled voltage magnitude, in pu
'VSKV'	Regulated bus scheduled voltage magnitude, in kV (in pu if base voltage is 0.0)
'RMPCT'	Percent of total Mvar to be contributed by this plant
'PGEN'	Active power output of in-service machines at this plant, in MW
'QGEN'	Reactive power output of in-service machines at this plant, in Mvar
'MVA'	$\text{abs}(\text{PGEN} + j\text{QGEN})$ of in-service machines at this plant, in MVA
'PMAX'	Active power upper limit of in-service machines at this plant, in MW
'PMIN'	Active power lower limit of in-service machines at this plant, in MW
'QMAX'	Reactive power upper limit of in-service machines at this plant, in Mvar
'QMIN'	Reactive power lower limit of in-service machines at this plant, in Mvar
'MISMATCH'	Bus mismatch, in MVA (0.0 if bus type code > 3)
'O_PGEN'	Active power output of in-service machines at this plant (units determined by power output options)
'O_QGEN'	Reactive power output of in-service machines at this plant (units determined by power output options)
'O_MVA'	$\text{abs}(\text{PGEN} + j\text{QGEN})$ of in-service machines at this plant (units determined by power output options)
'O_PMAX'	Active power upper limit of in-service machines at this plant (units determined by power output options)
'O_PMIN'	Active power lower limit of in-service machines at this plant (units determined by power output options)
'O_QMAX'	Reactive power upper limit of in-service machines at this plant (units determined by power output options)
'O_QMIN'	Reactive power lower limit of in-service machines at this plant (units determined by power output options)
'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)

Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_PLANT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.3.6. AGENBUSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the plant bus data family (aGenBusInt, aGenBusReal, aGenBusCplx and aGenBusChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = agenbustypes(string)
```

Fortran command syntax:

```
CALL GET_PLANT_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the plant bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the plant bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the plant bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the plant bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.4. Machine Data

The machine data family of subsystem data retrieval APIs returns arrays of data for machines in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem machines, or to restrict the array entries to data for a subset of machines according to their bus, plant, and/or machine configuration and statuses.

Data for subsystem machines is returned from all APIs in the machine data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced; multiple machines at the same bus are in ascending machine identifier order.

12.4.1. AMACHCHAR

Use this API to return an array of character values for subsystem machines.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = amachchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_MACHINE_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem machines to include (input; 1 by default).	
	FLAG = 1	for only in-service machines at in-service plants (type code 2 or 3).
	FLAG = 2	for all machines at in-service plants (type code 2 or 3).
	FLAG = 3	for only in-service machines, including those at Type 1 and 4 buses.
	FLAG = 4	for all machines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or machine quantities desired (input; no default allowed).	
	'ID'	Machine identifier (2 characters).
	'NAME'	Bus name (12 characters).

	'EXNAME'	Extended bus name (18 characters).
	'POSTBL'	Non-conventional source positive sequence table (12 characters).
	'NEGTL'	Non-conventional source negative sequence table (12 characters).
	'DROOPNAME'	Voltage droop control name (40 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of CARRAY that are set by this API. MACHS is identical to the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.4.2. AMACHCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the machine data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, machs = amachcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_MACHINE_COUNT(SID, FLAG, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem machines to include (input; 1 by default).	
	FLAG = 1	for only in-service machines at in-service plants (type code 2 or 3).
	FLAG = 2	for all machines at in-service plants (type code 2 or 3).
	FLAG = 3	for only in-service machines, including those at type 1 and 4 buses.
	FLAG = 4	for all machines.
Integer MACHS	number of machines in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, MACHS returned
	IERR = 1	Working case is empty; MACHS returned as 0
	IERR = 2	Invalid SID value; MACHS returned as 0
	IERR = 3	Invalid FLAG value; MACHS returned as 0

12.4.3. AMACHCPLX

Use this API to return an array of complex values for subsystem machines.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = amachcplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_MACHINE_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem machines to include (input; 1 by default).	
	FLAG = 1	for only in-service machines at in-service plants (type code 2 or 3).
	FLAG = 2	for all machines at in-service plants (type code 2 or 3).
	FLAG = 3	for only in-service machines, including those at Type 1 and 4 buses.
	FLAG = 4	for all machines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or machine quantities desired (input; no default allowed).	
	'ZSORCE'	Machine impedance ($Z_R + j Z_X$)
	'XTRAN'	Step-up transformer impedance ($R_T + j X_T$)
	'ZPOS'	" Positive sequence fault analysis machine impedance ($R_{pos} + j X_{pos}$)"
	'ZNEG'	Negative sequence machine impedance ($Z_{RNEG} + j Z_{XNEG}$)
	'ZZERO'	Zero sequence machine impedance ($R_{ZERO} + j X_{ZERO}$)
	'ZGRND'	Grounding impedance. If the grounding impedance data I/O code is 2 and the bus base voltage is positive the impedance is returned in ohms; otherwise it is return in per unit.
	'ZGRNDPU'	Grounding impedance in per unit
	'PQGEN'	Power output (MW and Mvar)

	'O_PQGEN'	Power output (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of XARRAY that are set by this API. MACHS is identical to the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'ZPOS', 'ZNEG', 'ZZERO', 'ZGRND' or 'ZGRND-PU')

12.4.4. AMACHINT

Use this API to return an array of integer values for subsystem machines.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = amachint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_MACHINE_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem machines to include (input; 1 by default).	
	FLAG = 1	for only in-service machines at in-service plants (type code 2 or 3).
	FLAG = 2	for all machines at in-service plants (type code 2 or 3).
	FLAG = 3	for only in-service machines, including those at Type 1 and 4 buses.
	FLAG = 4	for all machines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or machine quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'STATION'	Bus substation number (returned as 0 if the bus is not in a substation)
	'SECTION'	Bus section number (returned as 0 if the bus is not in a substation)
	'NODE'	Number of the node to which the machine is connected (returned as 0 if the bus is not in a substation)
	'BASFLG'	Baseloaded flag value
	'STATUS'	Machine status
	'WMOD'	Wind machine reactive power limits mode; 0 if the machine is not a wind machine
	'OWNERS'	Number of owners
	'OWN1'	First owner

	'OWN2'	Second owner
	'OWN3'	Third owner
	'OWN4'	Fourth owner
	'CZG'	Grounding impedance data input/output (I/O) code (1 for per unit 2 for ohms)
	'NCSTYP'	Non-conventional source characteristic type
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of IARRAY that are set by this API. MACHS is identical to the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'CZG')

12.4.5. AMACHREAL

Use this API to return an array of real values for subsystem machines.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = amachreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_MACHINE_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem machines to include (input; 1 by default).	
	FLAG = 1	for only in-service machines at in-service plants (type code 2 or 3).
	FLAG = 2	for all machines at in-service plants (type code 2 or 3).
	FLAG = 3	for only in-service machines, including those at Type 1 and 4 buses.
	FLAG = 4	for all machines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or machine quantities desired (input; no default allowed).	
	'FRACT1'	First owner fraction
	'FRACT2'	Second owner fraction
	'FRACT3'	Third owner fraction
	'FRACT4'	Fourth owner fraction
	'PERCENT'	MVA loading as a percentage of machine MVA base, MBASE
	'MBASE'	Machine MVA base
	'GENTAP'	Step-up transformer tap ratio
	'WPF'	Power factor used in setting reactive power limits for the wind machine when its WMOD is 2 or 3; 1.0 if the machine is not a wind machine
	'RPOS'	Positive sequence fault analysis machine resistance

	'XSUBTR'	Positive sequence fault analysis machine sub-transient reactance
	'XTRANS'	Positive sequence fault analysis machine transient reactance
	'XSYNCH'	Positive sequence fault analysis machine synchronous reactance
	'PGEN'	Active power output, in MW
	'QGEN'	Reactive power output, in Mvar
	'MVA'	$\text{abs}(\text{PGEN} + j\text{QGEN})$, in MVA
	'PMAX'	Active power upper limit, in MW
	'PMIN'	Active power lower limit, in MW
	'QMAX'	Reactive power upper limit, in Mvar
	'QMIN'	Reactive power lower limit, in Mvar
	'O_PGEN'	Active power output (units determined by power output options)
	'O_QGEN'	Reactive power output (units determined by power output options)
	'O_MVA'	$\text{abs}(\text{PGEN} + j\text{QGEN})$ (units determined by power output options)
	'O_PMAX'	Active power upper limit (units determined by power output options)
	'O_PMIN'	Active power lower limit (units determined by power output options)
	'O_QMAX'	Reactive power upper limit (units determined by power output options)
	'O_QMIN'	Reactive power lower limit (units determined by power output options)
	'IFMAX'	Non-conventional source per unit maximum total fault current magnitude
	'DBVMIN'	Non-conventional source per unit dead-band minimum voltage
	'DBVMAX'	Non-conventional source per unit dead-band maximum voltage
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of RARRAY that are set by this API. MACHS is identical to the value of MACHS returned by the GET_MACHINE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty

IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of RARRAY, is not large enough
IERR = 6	Invalid STRING value
IERR = 7	Sequence data not in case (when STRING = 'RPOS', 'XSUBTR', 'XTRANS', or 'XSYNCH')

12.4.6. AMACHTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the machine data family (aMachInt, aMachReal, aMachCplx and aMachChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = amachtypes(string)
```

Fortran command syntax:

```
CALL GET_MACHINE_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the machine data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the machine data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the machine data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the machine data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.5. Load Bus Data

The load bus data family of subsystem data retrieval APIs returns arrays of data for buses in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem buses, or to restrict the array entries to data for a subset of buses according to their bus and/or load configuration and statuses.

Data for subsystem buses is returned from all APIs in the load bus data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced.

12.5.1. ALODBUSCHAR

Use this API to return an array of character values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = alodbuschar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_BUS_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service load buses (type code 1, 2 or 3) with at least one in-service load.
	FLAG = 2	for only in-service load buses (type code 1, 2 or 3), including those with only out-of-service loads.
	FLAG = 3	for all in-service buses, including those that are not load buses.
	FLAG = 4	for all load buses, including those with only out-of-service loads.
	FLAG = 5	for all buses, including those that are not load buses.
	FLAG = 10	for only in-service load buses (type code 1, 2 or 3) with at least one in-service scalable load.

	FLAG = 11	for only in-service load buses (type code 1, 2 or 3) with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 12	for all load buses with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 20	for only in-service load buses (type code 1, 2 or 3) with at least one in-service fixed load.
	FLAG = 21	for only in-service load buses (type code 1, 2 or 3) with at least one fixed load, including those with all such loads out-of-service.
	FLAG = 22	for all load buses with at least one fixed load, including those with all such loads out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired (input; no default allowed).	
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.5.2. ALODBUSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the load bus data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, buses = alodbuscount(sid, flag)
```

Fortran command syntax:

```
CALL GET_LOAD_BUS_COUNT(SID, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service load buses (type code 1, 2 or 3) with at least one in-service load.
	FLAG = 2	for only in-service load buses (type code 1, 2 or 3), including those with only out-of-service loads.
	FLAG = 3	for all in-service buses, including those that are not load buses.
	FLAG = 4	for all load buses, including those with only out-of-service loads.
	FLAG = 5	for all buses, including those that are not load buses.
	FLAG = 10	for only in-service load buses (type code 1, 2 or 3) with at least one in-service scalable load.
	FLAG = 11	for only in-service load buses (type code 1, 2 or 3) with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 12	for all load buses with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 20	for only in-service load buses (type code 1, 2 or 3) with at least one in-service fixed load.
	FLAG = 21	for only in-service load buses (type code 1, 2 or 3) with at least one fixed load, including those with all such loads out-of-service.

	FLAG = 22	for all load buses with at least one fixed load, including those with all such loads out-of-service.
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid FLAG value; BUSES returned as 0

12.5.3. ALODBUSCPLX

Use this API to return an array of complex values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = alodbuscplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_BUS_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service load buses (type code 1, 2 or 3) with at least one in-service load.
	FLAG = 2	for only in-service load buses (type code 1, 2 or 3), including those with only out-of-service loads.
	FLAG = 3	for all in-service buses, including those that are not load buses.
	FLAG = 4	for all load buses, including those with only out-of-service loads.
	FLAG = 5	for all buses, including those that are not load buses.
	FLAG = 10	for only in-service load buses (type code 1, 2 or 3) with at least one in-service scalable load.
	FLAG = 11	for only in-service load buses (type code 1, 2 or 3) with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 12	for all load buses with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 20	for only in-service load buses (type code 1, 2 or 3) with at least one in-service fixed load.
	FLAG = 21	for only in-service load buses (type code 1, 2 or 3) with at least one fixed load, including those with all such loads out-of-service.

	FLAG = 22	for all load buses with at least one fixed load, including those with all such loads out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage in pu rectangular coordinates
	'MVAACT'	Actual in-service constant MVA load
	'MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage
	'ILACT'	Actual in-service constant current load
	'ILNOM'	Nominal in-service constant current load at 1.0 pu voltage
	'YLACT'	Actual total in-service constant admittance load
	'YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage
	'TOTALACT'	Actual in-service load
	'TOTALNOM'	Nominal in-service load at 1.0 pu voltage
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3)
	'O_MVAACT'	Actual in-service constant MVA load (units determined by power output options)
	'O_MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage (units determined by power output options)
	'O_ILACT'	Actual in-service constant current load (units determined by power output options)
	'O_ILNOM'	Nominal in-service constant current load at 1.0 pu voltage (units determined by power output options)
	'O_YLACT'	Actual total in-service constant admittance load (units determined by power output options)
	'O_YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage (units determined by power output options)
	'O_TOTALACT'	Actual in-service load (units determined by power output options)
	'O_TOTALNOM'	Nominal in-service load at 1.0 pu voltage (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the	

	GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.5.4. ALODBUSINT

Use this API to return an array of integer values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = alodbusint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_BUS_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service load buses (type code 1, 2 or 3) with at least one in-service load.
	FLAG = 2	for only in-service load buses (type code 1, 2 or 3), including those with only out-of-service loads.
	FLAG = 3	for all in-service buses, including those that are not load buses.
	FLAG = 4	for all load buses, including those with only out-of-service loads.
	FLAG = 5	for all buses, including those that are not load buses.
	FLAG = 10	for only in-service load buses (type code 1, 2 or 3) with at least one in-service scalable load.
	FLAG = 11	for only in-service load buses (type code 1, 2 or 3) with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 12	for all load buses with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 20	for only in-service load buses (type code 1, 2 or 3) with at least one in-service fixed load.
	FLAG = 21	for only in-service load buses (type code 1, 2 or 3) with at least one fixed load, including those with all such loads out-of-service.

	FLAG = 22	for all load buses with at least one fixed load, including those with all such loads out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'STATION'	Substation number (0 if bus is not in a substation)
	'SECTION'	Bus section number (0 if bus is not represented by multiple bus sections)
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number
	'OWNER'	Bus owner number
	'DUMMY'	Returns 1 if the bus is a dummy bus of a multisection line, or 0 if it is not
	'STATUS'	Inferred load status. Returns 1 if the bus type code is 1, 2 or 3 and at least one in-service load is present or 0 otherwise
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.5.5. ALODBUSREAL

Use this API to return an array of real values for subsystem buses.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = alodbusreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_BUS_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service load buses (type code 1, 2 or 3) with at least one in-service load.
	FLAG = 2	for only in-service load buses (type code 1, 2 or 3), including those with only out-of-service loads.
	FLAG = 3	for all in-service buses, including those that are not load buses.
	FLAG = 4	for all load buses, including those with only out-of-service loads.
	FLAG = 5	for all buses, including those that are not load buses.
	FLAG = 10	for only in-service load buses (type code 1, 2 or 3) with at least one in-service scalable load.
	FLAG = 11	for only in-service load buses (type code 1, 2 or 3) with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 12	for all load buses with at least one scalable load, including those with all such loads out-of-service.
	FLAG = 20	for only in-service load buses (type code 1, 2 or 3) with at least one in-service fixed load.
	FLAG = 21	for only in-service load buses (type code 1, 2 or 3) with at least one fixed load, including those with all such loads out-of-service.

	FLAG = 22	for all load buses with at least one fixed load, including those with all such loads out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage, in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'MVAACT'	Actual in-service constant MVA load
	'MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage
	'ILACT'	Actual in-service constant current load
	'ILNOM'	Nominal in-service constant current load at 1.0 pu voltage
	'YLACT'	Actual total in-service constant admittance load
	'YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage
	'TOTALACT'	Actual in-service load
	'TOTALNOM'	Nominal in-service load at 1.0 pu voltage
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3)
	'O_MVAACT'	Actual in-service constant MVA load (units determined by power output options)
	'O_MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage (units determined by power output options)
	'O_ILACT'	Actual in-service constant current load (units determined by power output options)
	'O_ILNOM'	Nominal in-service constant current load at 1.0 pu voltage (units determined by power output options)
	'O_YLACT'	Actual total in-service constant admittance load (units determined by power output options)
	'O_YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage (units determined by power output options)
	'O_TOTALACT'	Actual in-service load (units determined by power output options)
	'O_TOTALNOM'	Nominal in-service load at 1.0 pu voltage (units determined by power output options)

	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_LOAD_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Real RARRAY (NSTR*DIM)	(output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.5.6. ALODBUSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the load bus data family (aLodBusInt, aLodBusReal, aLodBusCplx and aLodBusChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = alodbustypes(string)
```

Fortran command syntax:

```
CALL GET_LOAD_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the load bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the load bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the load bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the load bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.6. Load Data

The load data family of subsystem data retrieval APIs returns arrays of data for loads in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem loads, or to restrict the array entries to data for a subset of loads according to their bus and/or load configuration and statuses.

Data for subsystem loads is returned from all APIs in the load data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced; multiple loads at the same bus are in ascending load identifier order.

12.6.1. ALOADCHAR

Use this API to return an array of character values for subsystem loads.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = aloadchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, LOADS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem loads to include (input; 1 by default).	
	FLAG = 1	for only in-service loads at in-service buses (type code < 4).
	FLAG = 2	for all loads at in-service buses (type code < 4).
	FLAG = 3	for only in-service loads, including those at type 4 buses.
	FLAG = 4	for all loads.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired (input; no default allowed).	
	'ID'	Load identifier (2 characters).
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).

	'LODTYPE'	Load type description (12 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer LOADS	number of elements in each column of CARRAY that are set by this API. LOADS is identical to the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.6.2. ALOADCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the load data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, loads = aloadcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_LOAD_COUNT(SID, FLAG, LOADS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem loads to include (input; 1 by default).	
	FLAG = 1	for only in-service loads at in-service buses (type code < 4).
	FLAG = 2	for all loads at in-service buses (type code < 4).
	FLAG = 3	for only in-service loads, including those at type 4 buses.
	FLAG = 4	for all loads.
Integer LOADS	number of loads in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, LOADS returned
	IERR = 1	Working case is empty; LOADS returned as 0
	IERR = 2	Invalid SID value; LOADS returned as 0
	IERR = 3	Invalid FLAG value; LOADS returned as 0

12.6.3. ALOADCPLX

Use this API to return an array of complex values for subsystem loads.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = aloadcplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, LOADS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem loads to include (input; 1 by default). FLAG = 1 for only in-service loads at in-service buses (type code < 4). FLAG = 2 for all loads at in-service buses (type code < 4). FLAG = 3 for only in-service loads, including those at type 4 buses. FLAG = 4 for all loads.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired. NOTE: In the description below, the "net" values is the load value minus any in-service distributed generation on that load feeder. (input; no default allowed). 'MVA ACT' Actual in-service constant MVA load (in MW and Mvar) 'MVA NOM' Nominal in-service constant MVA load at 1.0 pu voltage (in MW and Mvar) 'I ACT' Actual in-service constant current load (in MW and Mvar) 'I NOM' Nominal in-service constant current load at 1.0 pu voltage (in MW and Mvar) 'Y ACT' Actual total in-service constant admittance load (in MW and Mvar) 'Y NOM' Nominal total in-service constant admittance load at 1.0 pu voltage (in MW and Mvar) 'TOTAL ACT' Actual in-service load (in MW and Mvar)

	'TOTALNOM'	Nominal in-service load at 1.0 pu voltage (in MW and Mvar)
	'LDGNACT'	Actual in-service distributed generation
	'LDGNNOM'	Nominal in-service distributed generation
	'YNEG'	Nominal exceptional negative sequence load (at 1.0 pu voltage)
	'YZERO'	Nominal exceptional zero sequence load (at 1.0 pu voltage)
	'O_MVAACT'	Actual in-service constant MVA load (units determined by power output options)
	'O_MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage (units determined by power output options)
	'O_ILACT'	Actual in-service constant current load (units determined by power output options)
	'O_ILNOM'	Nominal in-service constant current load at 1.0 pu voltage (units determined by power output options)
	'O_YLACT'	Actual total in-service constant admittance load (units determined by power output options)
	'O_YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage (units determined by power output options)
	'O_TOTALACT'	Actual in-service load (units determined by power output options)
	'O_TOTALNOM'	Nominal in-service load at 1.0 pu voltage (units determined by power output options)
	'O_LDGNACT'	Actual in-service distributed generation
	'O_LDGNNOM'	Nominal in-service distributed generation
	'O_YNEG'	Nominal exceptional negative sequence load (at 1.0 pu voltage)
	'O_YZERO'	Nominal exceptional zero sequence load (at 1.0 pu voltage)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer LOADS	number of elements in each column of XARRAY that are set by this API. LOADS is identical to the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error

IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of XARRAY, is not large enough
IERR = 6	Invalid STRING value

12.6.4. ALOADINT

Use this API to return an array of integer values for subsystem loads.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = aloadint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, LOADS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem loads to include (input; 1 by default). FLAG = 1 for only in-service loads at in-service buses (type code < 4). FLAG = 2 for all loads at in-service buses (type code < 4). FLAG = 3 for only in-service loads, including those at type 4 buses. FLAG = 4 for all loads.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired (input; no default allowed). 'NUMBER' Bus number 'STATION' Substation number (0 if bus is not in a substation) 'SECTION' Bus section number (0 if bus is not represented by multiple bus sections) 'NODE' Node number (0 if bus is not in a substation) 'AREA' Load area number 'ZONE' Load zone number 'OWNER' Load owner number 'STATUS' Load status 'SCALE' Scalable load flag 'INTRPT' Interruptible load flag (1 for interruptible, 0 for non-interruptible)

	'CGR'	Grounding code (0 for an ungrounded load, 1 for a grounded load)
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer LOADS	number of elements in each column of IARRAY that are set by this API. LOADS is identical to the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'CGR')

12.6.5. ALOADREAL

Use this API to return an array of real values for subsystem loads.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = aloadreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_LOAD_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, LOADS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem loads to include (input; 1 by default).	
	FLAG = 1	for only in-service loads at in-service buses (type code < 4).
	FLAG = 2	for all loads at in-service buses (type code < 4).
	FLAG = 3	for only in-service loads, including those at type 4 buses.
	FLAG = 4	for all loads.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or load quantities desired. NOTE: In the description below, the "net" values is the load value minus any in-service distributed generation on that load feeder. (input; no default allowed).	
	'MVAACT'	Actual in-service constant MVA load, in MVA
	'MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage, in MVA
	'ILACT'	Actual in-service constant current load, in MVA
	'ILNOM'	Nominal in-service constant current load at 1.0 pu voltage, in MVA
	'YLACT'	Actual total in-service constant admittance load, in MVA
	'YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage, in MVA
	'TOTALACT'	Actual in-service load, in MVA

	'TOTALNOM'	Nominal in-service load at 1.0 pu voltage, in MVA
	'YNEG'	Nominal negative sequence total load at 1.0 pu voltage, in MVA
	'YZERO'	Nominal zero sequence total load at 1.0 pu voltage, in MVA
	'O_MVAACT'	Actual in-service constant MVA load (units determined by power output options)
	'O_MVANOM'	Nominal in-service constant MVA load at 1.0 pu voltage (units determined by power output options)
	'O_ILACT'	Actual in-service constant current load (units determined by power output options)
	'O_ILNOM'	Nominal in-service constant current load at 1.0 pu voltage (units determined by power output options)
	'O_YLACT'	Actual total in-service constant admittance load (units determined by power output options)
	'O_YLNOM'	Nominal total in-service constant admittance load at 1.0 pu voltage (units determined by power output options)
	'O_TOTALACT'	Actual in-service load (units determined by power output options)
	'O_TOTALNOM'	Nominal in-service load at 1.0 pu voltage (units determined by power output options)
	'O_YNEG'	Nominal negative sequence total load at 1.0 pu voltage (units determined by power output options)
	'O_YZERO'	Nominal zero sequence total load at 1.0 pu voltage (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer LOADS	number of elements in each column of RARRAY that are set by this API. LOADS is identical to the value of LOADS returned by the GET_LOAD_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value

IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of RARRAY, is not large enough
IERR = 6	Invalid STRING value
IERR = 7	Sequence data not in case (when STRING = 'YNEG', 'O_YNEG', 'YZERO' or 'O_YZERO')

12.6.6. ALOADTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the load data family (aLoadInt, aLoadReal, aLoadCplx and aLoadChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = aloadtypes(string)
```

Fortran command syntax:

```
CALL GET_LOAD_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the load data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the load data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the load data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the load data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.7. Fixed Shunt Bus Data

The fixed shunt bus data family of subsystem data retrieval APIs returns arrays of data for buses in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem buses, or to restrict the array entries to data for a subset of buses according to their bus and/or fixed shunt configuration and statuses.

Data for subsystem buses is returned from all APIs in the fixed shunt bus data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced.

12.7.1. AFXSHNTBUSCHAR

Use this API to return an array of character values for subsystem buses.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, carray = afxshntbuschar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_BUS_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunt buses (type code 1, 2 or 3) with at least one in-service fixed shunt.
	FLAG = 2	for only in-service fixed shunt buses (type code 1, 2 or 3), including those with only out-of-service fixed shunts.
	FLAG = 3	for all in-service buses, including those that are not fixed shunt buses.
	FLAG = 4	for all fixed shunt buses, including those with only out-of-service fixed shunts.
	FLAG = 5	for all buses, including those that are not fixed shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	

Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed).	
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.7.2. AFXSHNTBUSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the fixed shunt bus data family.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, buses = afxshntbuscount(sid, flag)
```

Fortran command syntax:

```
CALL GET_SHUNT_BUS_COUNT(SID, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunt buses (type code 1, 2 or 3) with at least one in-service fixed shunt.
	FLAG = 2	for only in-service fixed shunt buses (type code 1, 2 or 3), including those with only out-of-service fixed shunts.
	FLAG = 3	for all in-service buses, including those that are not fixed shunt buses.
	FLAG = 4	for all fixed shunt buses, including those with only out-of-service fixed shunts.
	FLAG = 5	for all buses, including those that are not fixed shunt buses.
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid FLAG value; BUSES returned as 0

12.7.3. AFXSHNTBUSCPLX

Use this API to return an array of complex values for subsystem buses.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, xarray = afxshntbuscplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_BUS_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunt buses (type code 1, 2 or 3) with at least one in-service fixed shunt.
	FLAG = 2	for only in-service fixed shunt buses (type code 1, 2 or 3), including those with only out-of-service fixed shunts.
	FLAG = 3	for all in-service buses, including those that are not fixed shunt buses.
	FLAG = 4	for all fixed shunt buses, including those with only out-of-service fixed shunts.
	FLAG = 5	for all buses, including those that are not fixed shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage, in pu, rectangular coordinates
	'PU_GBZERO'	Zero sequence total nominal in-service fixed bus shunt, in pu
	'SHUNTACT'	Total actual in-service fixed bus shunt (in MW and Mvar)
	'SHUNTNOM'	Total nominal in-service fixed bus shunt at 1.0 pu voltage (in MW and Mvar)
	'GBZERO'	Zero sequence total nominal in-service fixed bus shunt (in MW and Mvar)

	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (in MW and Mvar)
	'O_SHUNTACT'	Total actual in-service fixed bus shunt (units determined by power output options)
	'O_SHUNTNOM'	Total nominal in-service fixed bus shunt at 1.0 pu voltage (units determined by power output options)
	'O_GBZERO'	Zero sequence total nominal in-service fixed bus shunt (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case; when STRING = 'PU_GBZERO', 'GBZERO' and 'O_GBZERO'

12.7.4. AFXSHNTBUSINT

Use this API to return an array of integer values for subsystem buses.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, iarray = afxshntbusint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_BUS_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunt buses (type code 1, 2 or 3) with at least one in-service fixed shunt.
	FLAG = 2	for only in-service fixed shunt buses (type code 1, 2 or 3), including those with only out-of-service fixed shunts.
	FLAG = 3	for all in-service buses, including those that are not fixed shunt buses.
	FLAG = 4	for all fixed shunt buses, including those with only out-of-service fixed shunts.
	FLAG = 5	for all buses, including those that are not fixed shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'STATION'	Substation number (0 if bus is not in a substation)
	'SECTION'	Bus section number (0 if bus is not represented by multiple bus sections)
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number
	'OWNER'	Bus owner number

	'DUMMY'	Returns 1 if the bus is a dummy bus of a multisection line or 0 if it is not
	'STATUS'	Inferred shunt status. Returns 1 if the bus type code is 1 2 or 3 and at least one in-service fixed shunt is present or 0 otherwise
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.7.5. AFXSHNTBUSREAL

Use this API to return an array of real values for subsystem buses.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, rarray = afxshntbusreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_BUS_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunt buses (type code 1, 2 or 3) with at least one in-service fixed shunt.
	FLAG = 2	for only in-service fixed shunt buses (type code 1, 2 or 3), including those with only out-of-service fixed shunts.
	FLAG = 3	for all in-service buses, including those that are not fixed shunt buses.
	FLAG = 4	for all fixed shunt buses, including those with only out-of-service fixed shunts.
	FLAG = 5	for all buses, including those that are not fixed shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage, in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'PU_GBZERO'	Zero sequence total nominal in-service fixed bus shunt, in pu
	'SHUNTACT'	Total actual in-service fixed bus shunt, in MVA

	'SHUNTNOM'	Total nominal in-service fixed bus shunt at 1.0 pu voltage, in MVA
	'GBZERO'	Zero sequence total nominal in-service fixed bus shunt, in MVA
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3), in MVA
	'O_SHUNTACT'	Total actual in-service fixed bus shunt (units determined by power output options)
	'O_SHUNTNOM'	Total nominal in-service fixed bus shunt at 1.0 pu voltage (units determined by power output options)
	'O_GBZERO'	Zero sequence total nominal in-service fixed bus shunt (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case; when STRING = 'PU_GBZERO', 'GBZERO' and 'O_GBZERO'

12.7.6. AFXSHNTBUSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the fixed shunt bus data family (aFxShntBusInt, aFxShntBusReal, aFxShntBusCplx and aFxShntBusChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = afxshntbustypes(string)
```

Fortran command syntax:

```
CALL GET_SHUNT_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the fixed shunt bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the fixed shunt bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the fixed shunt bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the fixed shunt bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.8. Fixed Shunt Data

The fixed shunt data family of subsystem data retrieval APIs returns arrays of data for fixed bus shunts in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem fixed bus shunts, or to restrict the array entries to data for a subset of fixed bus shunts according to their bus and/or fixed shunt configuration and statuses.

Data for subsystem fixed bus shunts is returned from all APIs in the fixed shunt data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced; multiple fixed shunts at the same bus are in ascending shunt identifier order.

12.8.1. AFXSHUNTCHAR

Use this API to return an array of character values for subsystem fixed shunts.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, carray = afxshuntchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, SHUNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem fixed bus shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunts at in-service buses (type code < 4).
	FLAG = 2	for all fixed shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service fixed shunts, including those at type 4 buses.
	FLAG = 4	for all fixed bus shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed).	
	'ID'	Shunt identifier (2 characters).
	'NAME'	Bus name (12 characters).

	'EXNAME'	Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY DIM must be as least as large as the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SHUNTS	number of elements in each column of CARRAY that are set by this API. SHUNTS is identical to the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.8.2. AFXSHUNTCount

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the fixed shunt data family.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, shunts = afxshuntcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_SHUNT_COUNT(SID, FLAG, SHUNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem fixed bus shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunts at in-service buses (type code < 4).
	FLAG = 2	for all fixed shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service fixed shunts, including those at type 4 buses.
	FLAG = 4	for all fixed bus shunts.
Integer SHUNTS	number of fixed bus shunts in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, SHUNTS returned
	IERR = 1	Working case is empty; SHUNTS returned as 0
	IERR = 2	Invalid SID value; SHUNTS returned as 0
	IERR = 3	Invalid FLAG value; SHUNTS returned as 0

12.8.3. AFXSHUNTCPLX

Use this API to return an array of complex values for subsystem fixed shunts.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, xarray = afxshuntcplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, SHUNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem fixed bus shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service fixed shunts at in-service buses (type code < 4).
	FLAG = 2	for all fixed shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service fixed shunts, including those at type 4 buses.
	FLAG = 4	for all fixed bus shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed).	
	'PU_GBZERO'	Zero sequence nominal fixed bus shunt, in per unit
	'SHUNTACT'	Actual in-service fixed bus shunt (in MW and Mvar)
	'SHUNTNOM'	Nominal fixed bus shunt at 1.0 pu voltage (in MW and Mvar)
	'GBZERO'	Zero sequence nominal fixed bus shunt (in MW and Mvar)
	'O_SHUNTACT'	Actual in-service fixed bus shunt (units determined by power output options)
	'O_SHUNTNOM'	Nominal fixed bus shunt at 1.0 pu voltage (units determined by power output options)
	'O_GBZERO'	Zero sequence nominal fixed bus shunt (units determined by power output options)

Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SHUNTS	number of elements in each column of XARRAY that are set by this API. SHUNTS is identical to the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case; when STRING = 'PU_GBZERO', 'GBZERO' and 'O_GBZERO'

12.8.4. AFXSHUNTINT

Use this API to return an array of integer values for subsystem fixed shunts.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, iarray = afxshuntint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, SHUNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem fixed bus shunts to include (input; 1 by default). FLAG = 1 for only in-service fixed shunts at in-service buses (type code < 4). FLAG = 2 for all fixed shunts at in-service buses (type code < 4). FLAG = 3 for only in-service fixed shunts, including those at type 4 buses. FLAG = 4 for all fixed bus shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed). 'NUMBER' Bus number 'STATION' Substation number (0 if bus is not in a substation) 'SECTION' Bus section number (0 if bus is not represented by multiple bus sections) 'NODE' Node number (0 if bus is not in a substation) 'STATUS' Shunt status
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).

Integer SHUNTS	number of elements in each column of IARRAY that are set by this API. SHUNTS is identical to the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.8.5. AFXSHUNTREAL

Use this API to return an array of real values for subsystem fixed shunts.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
ierr, rarray = afxshuntreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SHUNT_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, SHUNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem fixed bus shunts to include (input; 1 by default). FLAG = 1 for only in-service fixed shunts at in-service buses (type code < 4). FLAG = 2 for all fixed shunts at in-service buses (type code < 4). FLAG = 3 for only in-service fixed shunts, including those at type 4 buses. FLAG = 4 for all fixed bus shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or fixed shunt quantities desired (input; no default allowed). 'PU_GBZERO' Zero sequence nominal fixed bus shunt, in pu 'SHUNTACT' Actual in-service fixed bus shunt, in MVA 'SHUNTNOM' Nominal fixed bus shunt at 1.0 pu voltage, in MVA 'GBZERO' Zero sequence nominal fixed bus shunt, in MVA 'O_SHUNTACT' Actual in-service fixed bus shunt (units determined by power output options) 'O_SHUNTNOM' Nominal fixed bus shunt at 1.0 pu voltage (units determined by power output options) 'O_GBZERO' Zero sequence nominal fixed bus shunt (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of SHUNTS returned by the

	GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SHUNTS	number of elements in each column of RARRAY that are set by this API. SHUNTS is identical to the value of SHUNTS returned by the GET_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case; when STRING = 'PU_GBZERO', 'GBZERO' and 'O_GBZERO'

12.8.6. AFXSHUNTTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the fixed shunt data family (aFxShuntInt, aFxShuntReal, aFxShuntCplx and aFxShuntChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = afxshunttypes(string)
```

Fortran command syntax:

```
CALL GET_SHUNT_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the fixed shunt data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the fixed shunt data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the fixed shunt data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the fixed shunt data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.9. Switched Shunt Bus Data

The switched shunt bus data family of subsystem data retrieval APIs returns arrays of data for buses in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem buses, or to restrict the array entries to data for a subset of buses according to their bus and/or switched shunt configuration and statuses.

Data for subsystem buses is returned from all APIs in the switched shunt bus data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced.

12.9.1. ASWSHUNTBUSCHAR

Use this API to return an array of character values for subsystem buses.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, carray = aswshtbuschar(sid, flag, string)
```

Fortran command syntax:

```
CALL  
GET_SWITCHED_SHUNT_BUS_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunt buses (type code 1, 2 or 3) with at least one in-service switched shunt.
	FLAG = 2	for only in-service switched shunt buses (type code 1, 2 or 3), including those with only out-of-service switched shunts.
	FLAG = 3	for all in-service buses, including those that are not switched shunt buses.
	FLAG = 4	for all switched shunt buses, including those with only out-of-service switched shunts.
	FLAG = 5	for all buses, including those that are not switched shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	

Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.9.2. ASWSHUNTBUSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the switched shunt bus data family.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, buses = aswshtbuscount(sid, flag)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_BUS_COUNT(SID, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunt buses (type code 1, 2 or 3) with at least one in-service switched shunt.
	FLAG = 2	for only in-service switched shunt buses (type code 1, 2 or 3), including those with only out-of-service switched shunts.
	FLAG = 3	for all in-service buses, including those that are not switched shunt buses.
	FLAG = 4	for all switched shunt buses, including those with only out-of-service switched shunts.
	FLAG = 5	for all buses, including those that are not switched shunt buses.
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid FLAG value; BUSES returned as 0

12.9.3. ASWSHUNTBUSCPLX

Use this API to return an array of complex values for subsystem buses.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, xarray = aswshtbuscplx(sid, flag, string)
```

Fortran command syntax:

```
CALL  
GET_SWITCHED_SHUNT_BUS_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunt buses (type code 1, 2 or 3) with at least one in-service switched shunt.
	FLAG = 2	for only in-service switched shunt buses (type code 1, 2 or 3), including those with only out-of-service switched shunts.
	FLAG = 3	for all in-service buses, including those that are not switched shunt buses.
	FLAG = 4	for all switched shunt buses, including those with only out-of-service switched shunts.
	FLAG = 5	for all buses, including those that are not switched shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage, in pu, rectangular coordinates
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (in MW and Mvar)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output option setting)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the	

	GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.9.4. ASWSHUNTBUSINT

Use this API to return an array of integer values for subsystem buses.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, iarray = aswshtbusint(sid, flag, string)
```

Fortran command syntax:

```
CALL  
GET_SWITCHED_SHUNT_BUS_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunt buses (type code 1, 2 or 3) with at least one in-service switched shunt.
	FLAG = 2	for only in-service switched shunt buses (type code 1, 2 or 3), including those with only out-of-service switched shunts.
	FLAG = 3	for all in-service buses, including those that are not switched shunt buses.
	FLAG = 4	for all switched shunt buses, including those with only out-of-service switched shunts.
	FLAG = 5	for all buses, including those that are not switched shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'STATION'	Substation number (0 if bus is not in a substation)
	'SECTION'	Bus section number (0 if bus is not represented by multiple bus sections)
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number

	'OWNER'	Bus owner number
	'DUMMY'	Returns 1 if the bus is a dummy bus of a multisection line or 0 if it is not
	'STATUS'	Inferred shunt status. Returns 1 if the bus type code is 1 2 or 3 and at least one in-service switched shunt is present or 0 otherwise
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.9.5. ASWSHUNTBUSREAL

Use this API to return an array of real values for subsystem buses.

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, rarray = afswhtbusreal(sid, flag, string)
```

Fortran command syntax:

```
CALL  
GET_SWITCHED_SHUNT_BUS_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunt buses (type code 1, 2 or 3) with at least one in-service switched shunt.
	FLAG = 2	for only in-service switched shunt buses (type code 1, 2 or 3), including those with only out-of-service switched shunts.
	FLAG = 3	for all in-service buses, including those that are not switched shunt buses.
	FLAG = 4	for all switched shunt buses, including those with only out-of-service switched shunts.
	FLAG = 5	for all buses, including those that are not switched shunt buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage, in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'PU_BSWZERO'	Zero sequence total nominal in-service switched bus shunt, in pu

	'BSWACT'	Total actual in-service switched bus shunt, in MVAR
	'BSWNOM'	Total nominal in-service switched bus shunt at 1.0 pu voltage, in MVAR
	'BSWZERO'	Zero sequence total nominal in-service switched bus shunt, in MVAR
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3), in MVA
	'O_BSWACT'	Total actual in-service switched bus shunt (units determined by power output option setting)
	'O_BSWNOM'	Total nominal in-service switched bus shunt at 1.0 pu voltage (units determined by power output option setting)
	'O_BSWZERO'	Zero sequence total nominal in-service switched bus shunt (units determined by power output option setting)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output option setting)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_SWITCHED_SHUNT_BUS_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case; when STRING = 'PU_BSWZERO', BSWBZERO' and 'O_BSWZERO'

12.9.6. ASWSHUNTBUSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the switched shunt bus data family (aSwShntBusInt, aSwShntBusReal, aSwShntBusCplx and aSwShntBusChar).

This API routine was first introduced in release 35.0.0.

Python command syntax:

```
ierr, types = aswshntbustypes(string)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the switched shunt bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the switched shunt bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the switched shunt bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the switched shunt bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.10. Switched Shunt Data

The switched shunt data family of subsystem data retrieval APIs returns arrays of data for switched shunts in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for all subsystem switched shunts, or to restrict the array entries to data for switched shunts at in-service buses.

Data for subsystem switched shunts is returned from all APIs in the switched shunt data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API is referenced.

12.10.1. ASWSHCHAR

Use this API to return an array of character values for subsystem switched shunts.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = aswshchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, SHNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).
SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem switched shunts to include (input; 1 by default).
FLAG = 1	for only in-service switched shunts at in-service buses (type code < 4).
FLAG = 2	for all switched shunts at in-service buses (type code < 4).
FLAG = 3	for only in-service switched shunts, including those at type 4 buses.
FLAG = 4	for all switched shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).
	'VSCNAME' VSC dc line name; non-blank name is returned only for those switched shunts for which the control mode, MODSW, is 4 (12 characters).

	'FACTSNAME'	FACTS device name; non-blank name is returned only for those switched shunts for which the control mode, MODSW, is 6 (12 characters).
	'DEVICENAME'	VSC dc line name or FACTS device name; non-blank name is returned only for those switched shunts for which the control mode, MODSW, is 4 or 6 (12 characters).
	'ID'	Switched shunt identifier (2 characters).
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
	'IREGNAME'	Bus name of regulated bus (12 characters).
	'IREGEXNAME'	Extended bus name of regulated bus (18 characters).
Integer DIM		number of elements in each column of the array CARRAY. DIM must be as least as large as the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Character CARRAY (NSTR*DIM)		Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer SHNTS		number of elements in each column of CARRAY that are set by this API. SHNTS is identical to the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).
Integer IERR		error code (output).
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.10.2. ASWSHCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the switched shunt data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, shnts = aswshcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_COUNT(SID, FLAG, SHNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem switched shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunts at in-service buses (type code < 4).
	FLAG = 2	for all switched shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service switched shunts, including those at type 4 buses.
	FLAG = 4	for all switched shunts.
Integer SHNTS	number of switched shunts in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, SHNTS returned
	IERR = 1	Working case is empty; SHNTS returned as 0
	IERR = 2	Invalid SID value; SHNTS returned as 0
	IERR = 3	Invalid FLAG value; SHNTS returned as 0

12.10.3. ASWSHCPLX

Use this API to return an array of complex values for subsystem switched shunts.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = aswshcplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY,  
    SHNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem switched shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunts at in-service buses (type code < 4).
	FLAG = 2	for all switched shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service switched shunts, including those at type 4 buses.
	FLAG = 4	for all switched shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage in pu rectangular coordinates
	'YSWACT'	Present shunt switched on
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3)
	'O_YSWACT'	Present shunt switched on (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	

Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SHNTS	number of elements in each column of XARRAY that are set by this API. SHNTS is identical to the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.10.4. ASWSHINT

Use this API to return an array of integer values for subsystem switched shunts.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = aswshint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY,  
    SHNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem switched shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunts at in-service buses (type code < 4).
	FLAG = 2	for all switched shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service switched shunts, including those at type 4 buses.
	FLAG = 4	for all switched shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'STATION'	Substation number (0 if bus is not in a substation)
	'SECTION'	Bus section number (0 if bus is not represented by multiple bus sections)
	'NODE'	Node number (0 if bus is not in a substation)
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number
	'OWNER'	Bus owner number
	'DUMMY'	Returns 1 if the bus is a dummy bus of a multisection line or 0 if it is not
	'MODE'	Switched shunt control mode

	'STATUS'	Switched shunt status flag
	'ADJMETHOD'	Switched shunt adjustment method
	'IREG'	Bus number of the regulated bus
	'NREG'	Node number of the regulated node
	'BLOCKS'	Number of blocks
	'STATUSBLOCK1'	Status of block 1
	'STATUSBLOCK2'	Status of block 2
	'STATUSBLOCK3'	Status of block 3
	'STATUSBLOCK4'	Status of block 4
	'STATUSBLOCK5'	Status of block 5
	'STATUSBLOCK6'	Status of block 6
	'STATUSBLOCK7'	Status of block 7
	'STATUSBLOCK8'	Status of block 8
	'STEPSBLOCK1'	Number of steps in block 1
	'STEPSBLOCK2'	Number of steps in block 2
	'STEPSBLOCK3'	Number of steps in block 3
	'STEPSBLOCK4'	Number of steps in block 4
	'STEPSBLOCK5'	Number of steps in block 5
	'STEPSBLOCK6'	Number of steps in block 6
	'STEPSBLOCK7'	Number of steps in block 7
	'STEPSBLOCK8'	Number of steps in block 8
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SHNTS	number of elements in each column of IARRAY that are set by this API. SHNTS is identical to the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.10.5. ASWSHREAL

Use this API to return an array of real values for subsystem switched shunts.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = aswshreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, SHNTS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem switched shunts to include (input; 1 by default).	
	FLAG = 1	for only in-service switched shunts at in-service buses (type code < 4).
	FLAG = 2	for all switched shunts at in-service buses (type code < 4).
	FLAG = 3	for only in-service switched shunts, including those at type 4 buses.
	FLAG = 4	for all switched shunts.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or switched shunt quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'VSWHI'	Controlled quantity upper limit
	'VSWLO'	Controlled quantity lower limit
	'RMPCT'	Percent of total Mvar to be contributed by this switched shunt
	'PU_BSWZERO'	Present zero sequence susceptance switched on, in pu
	'PUBZERBLOCK1'	Zero sequence pu step size in block 1
	'PUBZERBLOCK2'	Zero sequence pu step size in block 2

'PUBZERBLOCK3'	Zero sequence pu step size in block 3
'PUBZERBLOCK4'	Zero sequence pu step size in block 4
'PUBZERBLOCK5'	Zero sequence pu step size in block 5
'PUBZERBLOCK6'	Zero sequence pu step size in block 6
'PUBZERBLOCK7'	Zero sequence pu step size in block 7
'PUBZERBLOCK8'	Zero sequence pu step size in block 8
'BSWNOM'	Present susceptance switched on (susceptance)
'BSWMAX'	Admittance with all reactors off, all capacitors on
'BSWMIN'	Admittance with all reactors on, all capacitors off
'BSWACT'	Present susceptance switched on (Mvar)
'BSWZERO'	Present zero sequence susceptance switched on
'BSTPBLOCK1'	Step size in block 1
'BSTPBLOCK2'	Step size in block 2
'BSTPBLOCK3'	Step size in block 3
'BSTPBLOCK4'	Step size in block 4
'BSTPBLOCK5'	Step size in block 5
'BSTPBLOCK6'	Step size in block 6
'BSTPBLOCK7'	Step size in block 7
'BSTPBLOCK8'	Step size in block 8
'BZERBLOCK1'	Zero sequence step size in block 1
'BZERBLOCK2'	Zero sequence step size in block 2
'BZERBLOCK3'	Zero sequence step size in block 3
'BZERBLOCK4'	Zero sequence step size in block 4
'BZERBLOCK5'	Zero sequence step size in block 5
'BZERBLOCK6'	Zero sequence step size in block 6
'BZERBLOCK7'	Zero sequence step size in block 7
'BZERBLOCK8'	Zero sequence step size in block 8
'MISMATCH'	Bus mismatch (0.0 if bus type code > 3)
'O_BSWNOM'	Present susceptance switched on (units determined by power output options)
'O_BSWMAX'	Admittance with all reactors off all capacitors on (units determined by power output options)
'O_BSWMIN'	Admittance with all reactors on all capacitors off (units determined by power output options)
'O_BSWACT'	Present susceptance switched on (units determined by power output options)
'O_BSWZERO'	Present zero sequence susceptance switched on (units determined by power output options)

	'O_BSTPBLOCK1'	Step size in block 1 (units determined by power output options)
	'O_BSTPBLOCK2'	Step size in block 2 (units determined by power output options)
	'O_BSTPBLOCK3'	Step size in block 3 (units determined by power output options)
	'O_BSTPBLOCK4'	Step size in block 4 (units determined by power output options)
	'O_BSTPBLOCK5'	Step size in block 5 (units determined by power output options)
	'O_BSTPBLOCK6'	Step size in block 6 (units determined by power output options)
	'O_BSTPBLOCK7'	Step size in block 7 (units determined by power output options)
	'O_BSTPBLOCK8'	Step size in block 8 (units determined by power output options)
	'O_BZERBLOCK1'	Zero sequence step size in block 1 (units determined by power output options)
	'O_BZERBLOCK2'	Zero sequence step size in block 2 (units determined by power output options)
	'O_BZERBLOCK3'	Zero sequence step size in block 3 (units determined by power output options)
	'O_BZERBLOCK4'	Zero sequence step size in block 4 (units determined by power output options)
	'O_BZERBLOCK5'	Zero sequence step size in block 5 (units determined by power output options)
	'O_BZERBLOCK6'	Zero sequence step size in block 6 (units determined by power output options)
	'O_BZERBLOCK7'	Zero sequence step size in block 7 (units determined by power output options)
	'O_BZERBLOCK8'	Zero sequence step size in block 8 (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SHNTS	number of elements in each column of RARRAY that are set by this API. SHNTS is identical to the value of SHNTS returned by the GET_SWITCHED_SHUNT_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error

IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of RARRAY, is not large enough
IERR = 6	Invalid STRING value
IERR = 7	Sequence data not in case (when STRING = 'BSWZERO', 'PU_BSWZERO', 'O_BSWZERO', 'BZERBLOCKn', 'PUB- ZERBLOCKn', 'O_BZERBLOCKn')

12.10.6. ASWSHTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the switched shunt data family (aSwshInt, aSwshReal, aSwshCplx and aSwshChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = aswshtypes(string)
```

Fortran command syntax:

```
CALL GET_SWITCHED_SHUNT_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the switched shunt data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table><tr><td>'I'</td><td>Integer.</td></tr><tr><td>'R'</td><td>Real.</td></tr><tr><td>'X'</td><td>Complex.</td></tr><tr><td>'C'</td><td>Character.</td></tr><tr><td>'?'</td><td>Invalid STRING value.</td></tr></table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table><tr><td>IERR = 0</td><td>No error</td></tr><tr><td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the switched shunt data family (1 < n < NSTR)</td></tr><tr><td>IERR = 99</td><td>Invalid NSTR value</td></tr></table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the switched shunt data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the switched shunt data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.11. Branch Flow Data

The branch flow data family of subsystem data retrieval APIs returns arrays of loading data for ac branches in a specified subsystem. These APIs return loading data for non-transformer branches, two-winding transformers, and three-winding transformers.

One of the input items to each API allows the user to elect either to retrieve data for all subsystem branches, for subsystem tie branches, or for both subsystem and tie branches. Another input item allows the user to elect either to retrieve data for all such branches, or to restrict the array entries to data for in-service branches.

Data for subsystem branches is returned from all APIs in the branch flow data family in the same order. Unless otherwise restricted for tie branches, each branch appears in both directions (in all three directions for three-winding transformers) in the arrays returned by the APIs of the branch flow data family. Branches are ordered in ascending numerical or alphabetical order by from bus, according to the bus output option setting in effect at the time the API is referenced. For each from bus, branches are ordered in ascending order by to bus. Parallel branches are ordered in ascending circuit identifier order.

12.11.1. AFLOWCHAR

Use this API to return an array of character values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = aflowchar(sid, owner, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_FLOW_CHAR(SID, OWNER, TIES, FLAG, NSTR, STRING, DIM,  
    CARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem branches only.
	TIES = 2	for the subsystem bus end of tie branches only.
	TIES = 3	for the non-subsystem bus end of tie branches only.

	TIES = 4	for each end of tie branches only.
	TIES = 5	for each end of interior subsystem branches and the subsystem bus end of tie branches.
	TIES = 6	for each end of interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).	
	FLAG = 1	for only in-service branches.
	FLAG = 2	for all branches.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).	
	'ID'	Circuit identifier (2 characters).
	'FROMNAME'	From bus name (12 characters).
	'FROMEXNAME'	From bus extended bus name (18 characters).
	'TONAME'	To bus name (three-winding transformer name for a three-winding transformer winding) (12 characters).
	'TOEXNAME'	To bus extended bus name (three-winding transformer name and winding number for a three-winding transformer winding) (18 characters).
	'NMETERNAME'	Non-metered bus name (12 characters).
	'NMETEREXNAME'	Non-metered bus extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid NSTR value

IERR = 7	DIM, and hence the size of CARRAY, is not large enough
IERR = 8	Invalid STRING value

12.11.2. AFLOWCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the branch flow data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, brnchs = aflowcount(sid, owner, ties, flag)
```

Fortran command syntax:

```
CALL GET_BRANCH_FLOW_COUNT(SID, OWNER, TIES, FLAG, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem branches only. TIES = 2 for the subsystem bus end of tie branches only. TIES = 3 for the non-subsystem bus end of tie branches only. TIES = 4 for each end of tie branches only. TIES = 5 for each end of interior subsystem branches and the subsystem bus end of tie branches. TIES = 6 for each end of interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for only in-service branches. FLAG = 2 for all branches.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID and OWNER that meet the editing criteria indicated by TIES and FLAG (output).
Integer IERR	error code (output).

IERR = 0	No error, BRNCHS returned
IERR = 1	Working case is empty; BRNCHS returned as 0
IERR = 2	Invalid SID value; BRNCHS returned as 0
IERR = 3	Invalid OWNER value; BRNCHS returned as 0
IERR = 4	Invalid TIES value; BRNCHS returned as 0
IERR = 5	Invalid FLAG value; BRNCHS returned as 0

12.11.3. AFLOWCPLX

Use this API to return an array of complex values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = aflowcplx(sid, owner, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_FLOW_COMPLEX(SID, OWNER, TIES, FLAG, NSTR, STRING, DIM,  
XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem branches only.
	TIES = 2	for the subsystem bus end of tie branches only.
	TIES = 3	for the non-subsystem bus end of tie branches only.
	TIES = 4	for each end of tie branches only.
	TIES = 5	for each end of interior subsystem branches and the subsystem bus end of tie branches.
	TIES = 6	for each end of interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).	
	FLAG = 1	for only in-service branches.
	FLAG = 2	for all branches.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).	

	'PQ'	P + j Q flow at from bus end (in MW and Mvar)
	'PQLOSS'	Losses (in MW and Mvar)
	'O_PQ'	P + j Q flow at from bus end (units determined by power output options)
	'O_PQLOSS'	Losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of XARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.11.4. AFLOWINT

Use this API to return an array of integer values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = aflowint(sid, owner, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_FLOW_INTEGER(SID, OWNER, TIES, FLAG, NSTR, STRING, DIM,  
IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).
	SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).
	OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).
	TIES = 1 for each end of interior subsystem branches only.
	TIES = 2 for the subsystem bus end of tie branches only.
	TIES = 3 for the non-subsystem bus end of tie branches only.
	TIES = 4 for each end of tie branches only.
	TIES = 5 for each end of interior subsystem branches and the subsystem bus end of tie branches.
	TIES = 6 for each end of interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).
	FLAG = 1 for only in-service branches. FLAG = 2 for all branches.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).

	'FROMNUMBER'	From bus number
	'TONUMBER'	To bus number (>10000000 for a three-winding transformer winding)
	'FROMSTATION'	From bus substation number (0 if bus is not in a substation)
	'TOSTATION'	To bus substation number (0 if bus is not in a substation)
	'FROMSECTION'	From bus section number (0 if bus is not represented by multiple bus sections)
	'TOSECTION'	To bus section number (0 if bus is not represented by multiple bus sections)
	'FROMNODE'	From bus node number (0 if bus is not in a substation)
	'TONODE'	To bus node number (0 if bus is not in a substation)
	'STATUS'	Branch status
	'NMETERNUMBER'	Non-metered end bus number
	'OWNERS'	Number of owners
	'OWN1'	First owner
	'OWN2'	Second owner
	'OWN3'	Third owner
	'OWN4'	Fourth owner
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of IARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.11.5. AFLOWREAL

Use this API to return an array of real values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = aflowreal(sid, owner, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_FLOW_REAL(SID, OWNER, TIES, FLAG, NSTR, STRING, DIM,  
    RARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem branches only.
	TIES = 2	for the subsystem bus end of tie branches only.
	TIES = 3	for the non-subsystem bus end of tie branches only.
	TIES = 4	for each end of tie branches only.
	TIES = 5	for each end of interior subsystem branches and the subsystem bus end of tie branches.
	TIES = 6	for each end of interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).	
	FLAG = 1	for only in-service branches.
	FLAG = 2	for all branches.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).	

'AMPS'	Branch current, in amps (0.0 if bus base voltage is 0.0)
'PUCUR'	Branch current, in pu
'PCTRATE'	Percent from bus current of default rating set
'PCTRATEA'	Percent from bus current of rating set A
'PCTRATEB'	Percent from bus current of rating set B
'PCTRATEC'	Percent from bus current of rating set C
'PCTMVARATE'	Percent from bus MVA of default rating set
'PCTMVARATEA'	Percent from bus MVA of rating set A
'PCTMVARATEB'	Percent from bus MVA of rating set B
'PCTMVARATEC'	Percent from bus MVA of rating set C
'PCTCORPRATE'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'PCTCORPRATEA'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set A
'PCTCORPRATEB'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set B
'PCTCORPRATEC'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set C
'FRACT1'	First owner fraction
'FRACT2'	Second owner fraction
'FRACT3'	Third owner fraction
'FRACT4'	Fourth owner fraction
'RATE'	Rating from default rating set
'RATEA'	Rating from rating set A
'RATEB'	Rating from rating set B
'RATEC'	Rating from rating set C
'P'	Active power flow, in MW
'Q'	Reactive power flow, in Mvar
'MVA'	$\text{abs}(P+jQ)$, in MVA
'PLOSS'	Active power losses, in MW
'QLOSS'	Reactive power losses, in Mvar
'O_P'	Active power flow (units determined by power output options)
'O_Q'	Reactive power flow (units determined by power output options)
'O_MVA'	$\text{abs}(P+jQ)$ (units determined by power output options)
'O_PLOSS'	Active power losses (units determined by power output options)

	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_FLOW_COUNT API when it is called with the same values specified for SID, OWNER, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of RARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.11.6. AFLOWTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the branch flow data family (aFlowInt, aFlowReal, aFlowCplx and aFlowChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = aflowtypes(string)
```

Fortran command syntax:

```
CALL GET_BRANCH_FLOW_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the branch flow data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch flow data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch flow data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch flow data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.12. Branch Data

The branch data family of subsystem data retrieval APIs returns arrays of data for two-terminal ac branches in a specified subsystem. These APIs return data for non-transformer branches and/or two-winding transformers.

One of the input items to each API allows the user to elect either to retrieve data for all subsystem branches, for subsystem tie branches, or for both subsystem and tie branches. Another input item allows the user to elect to retrieve data for only non-transformer branches, only two-winding transformers, or both non-transformer branches and two-winding transformers, and either to retrieve data for all such branches, or to restrict the array entries to data for in-service branches.

Data for subsystem branches is returned from all APIs in the branch data family in the same order. One of the input items to each API allows the user to elect that either single entry arrays (each branch appears once) or double entry arrays (each branch appears in both directions) are to be returned. Branches are ordered in ascending numerical or alphabetical order by from bus, according to the bus output option setting in effect at the time the API is referenced. For each from bus, branches are ordered in ascending order by to bus. Parallel branches are ordered in ascending circuit identifier order.

12.12.1. ABRNCHAR

Use this API to return an array of character values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = abrnchar(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_CHAR(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
CARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem branches only.
	TIES = 2	for subsystem tie branches only.
	TIES = 3	for both interior subsystem branches and tie branches.

Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).
FLAG = 1	for only in-service non-transformer branches.
FLAG = 2	for all non-transformer branches.
FLAG = 3	for only in-service non-transformer branches and two-winding transformers.
FLAG = 4	for all non-transformer branches and two-winding transformers.
FLAG = 5	for only in-service two-winding transformers.
FLAG = 6	for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default).
ENTRY = 1	for single entry (each branch once).
ENTRY = 2	for double entry (each branch in both directions).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).
'ID'	Circuit identifier (2 characters).
'FROMNAME'	From bus name (12 characters).
'FROMEXNAME'	From bus extended bus name (18 characters).
'TONAME'	To bus name (three-winding transformer name for a three-winding transformer winding) (12 characters).
'TOEXNAME'	To bus extended bus name (three-winding transformer name and winding number for a three-winding transformer winding) (18 characters).
'METERNAME'	Metered bus name (12 characters).
'METEREXNAME'	Metered bus extended bus name (18 characters).
'NMETERNAME'	Non-metered bus name (12 characters).
'NMETEREXNAME'	Non-metered bus extended bus name (18 characters).
'BRANCHNAME'	Branch name (40 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the

GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).

Integer IERR

error code (output).

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid OWNER value
IERR = 4	Invalid TIES value
IERR = 5	Invalid FLAG value
IERR = 6	Invalid ENTRY value
IERR = 7	Invalid NSTR value
IERR = 8	DIM, and hence the size of CARRAY, is not large enough
IERR = 9	Invalid STRING value

12.12.2. ABRNCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the branch data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, brnchs = abrncount(sid, owner, ties, flag, entry)
```

Fortran command syntax:

```
CALL GET_BRANCH_COUNT(SID, OWNER, TIES, FLAG, ENTRY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem branches only.
	TIES = 2	for subsystem tie branches only.
	TIES = 3	for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).	
	FLAG = 1	for only in-service non-transformer branches.
	FLAG = 2	for all non-transformer branches.
	FLAG = 3	for only in-service non-transformer branches and two-winding transformers.
	FLAG = 4	for all non-transformer branches and two-winding transformers.
	FLAG = 5	for only in-service two-winding transformers.
	FLAG = 6	for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for single entry (each branch once).
	ENTRY = 2	for double entry (each branch in both directions).

Integer BRNCHS	number of array entries required for the subsystem indicated by SID and OWNER that meet the editing criteria indicated by TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BRNCHS returned
	IERR = 1	Working case is empty; BRNCHS returned as 0
	IERR = 2	Invalid SID value; BRNCHS returned as 0
	IERR = 3	Invalid OWNER value; BRNCHS returned as 0
	IERR = 4	Invalid TIES value; BRNCHS returned as 0
	IERR = 5	Invalid FLAG value; BRNCHS returned as 0
	IERR = 6	Invalid ENTRY value; BRNCHS returned as 0

12.12.3. ABRNCPLX

Use this API to return an array of complex values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = abrnclpx(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_COMPLEX(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem branches only.
	TIES = 2	for subsystem tie branches only.
	TIES = 3	for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).	
	FLAG = 1	for only in-service non-transformer branches.
	FLAG = 2	for all non-transformer branches.
	FLAG = 3	for only in-service non-transformer branches and two-winding transformers.
	FLAG = 4	for all non-transformer branches and two-winding transformers.
	FLAG = 5	for only in-service two-winding transformers.
Integer ENTRY	FLAG = 6	for all two-winding transformers.
	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for single entry (each branch once).
	ENTRY = 2	for double entry (each branch in both directions).

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).																						
Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed). <table> <tr> <td>'RX'</td><td>Branch impedance, in pu</td></tr> <tr> <td>'FROMSHNT'</td><td>Line shunt at from bus end, in pu</td></tr> <tr> <td>'TOSHNT'</td><td>Line shunt at to bus end, in pu</td></tr> <tr> <td>'RXZERO'</td><td>Zero sequence branch impedance, in pu</td></tr> <tr> <td>'FROMSHNTZERO'</td><td>Zero sequence line shunt at from bus end, in pu</td></tr> <tr> <td>'TOSHNTZERO'</td><td>Zero sequence line shunt at to bus end, in pu</td></tr> <tr> <td>'PQ'</td><td>P + j Q flow at from bus end (MW and Mvar)</td></tr> <tr> <td>'PQLOSS'</td><td>Losses (MW and Mvar)</td></tr> <tr> <td>'O_PQ'</td><td>P + j Q flow at from bus end (units determined by power output options)</td></tr> <tr> <td>'O_PQLOSS'</td><td>Losses (units determined by power output options)</td></tr> </table>	'RX'	Branch impedance, in pu	'FROMSHNT'	Line shunt at from bus end, in pu	'TOSHNT'	Line shunt at to bus end, in pu	'RXZERO'	Zero sequence branch impedance, in pu	'FROMSHNTZERO'	Zero sequence line shunt at from bus end, in pu	'TOSHNTZERO'	Zero sequence line shunt at to bus end, in pu	'PQ'	P + j Q flow at from bus end (MW and Mvar)	'PQLOSS'	Losses (MW and Mvar)	'O_PQ'	P + j Q flow at from bus end (units determined by power output options)	'O_PQLOSS'	Losses (units determined by power output options)		
'RX'	Branch impedance, in pu																						
'FROMSHNT'	Line shunt at from bus end, in pu																						
'TOSHNT'	Line shunt at to bus end, in pu																						
'RXZERO'	Zero sequence branch impedance, in pu																						
'FROMSHNTZERO'	Zero sequence line shunt at from bus end, in pu																						
'TOSHNTZERO'	Zero sequence line shunt at to bus end, in pu																						
'PQ'	P + j Q flow at from bus end (MW and Mvar)																						
'PQLOSS'	Losses (MW and Mvar)																						
'O_PQ'	P + j Q flow at from bus end (units determined by power output options)																						
'O_PQLOSS'	Losses (units determined by power output options)																						
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).																						
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).																						
Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).																						
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = 1</td><td>Working case is empty</td></tr> <tr> <td>IERR = 2</td><td>Invalid SID value</td></tr> <tr> <td>IERR = 3</td><td>Invalid OWNER value</td></tr> <tr> <td>IERR = 4</td><td>Invalid TIES value</td></tr> <tr> <td>IERR = 5</td><td>Invalid FLAG value</td></tr> <tr> <td>IERR = 6</td><td>Invalid ENTRY value</td></tr> <tr> <td>IERR = 7</td><td>Invalid NSTR value</td></tr> <tr> <td>IERR = 8</td><td>DIM, and hence the size of XARRAY, is not large enough</td></tr> <tr> <td>IERR = 9</td><td>Invalid STRING value</td></tr> <tr> <td>IERR = 10</td><td>Sequence data not in case (when STRING = 'RXZERO', 'FROMSHNTZERO' or 'TOSHNTZERO')</td></tr> </table>	IERR = 0	No error	IERR = 1	Working case is empty	IERR = 2	Invalid SID value	IERR = 3	Invalid OWNER value	IERR = 4	Invalid TIES value	IERR = 5	Invalid FLAG value	IERR = 6	Invalid ENTRY value	IERR = 7	Invalid NSTR value	IERR = 8	DIM, and hence the size of XARRAY, is not large enough	IERR = 9	Invalid STRING value	IERR = 10	Sequence data not in case (when STRING = 'RXZERO', 'FROMSHNTZERO' or 'TOSHNTZERO')
IERR = 0	No error																						
IERR = 1	Working case is empty																						
IERR = 2	Invalid SID value																						
IERR = 3	Invalid OWNER value																						
IERR = 4	Invalid TIES value																						
IERR = 5	Invalid FLAG value																						
IERR = 6	Invalid ENTRY value																						
IERR = 7	Invalid NSTR value																						
IERR = 8	DIM, and hence the size of XARRAY, is not large enough																						
IERR = 9	Invalid STRING value																						
IERR = 10	Sequence data not in case (when STRING = 'RXZERO', 'FROMSHNTZERO' or 'TOSHNTZERO')																						

12.12.4. ABRNINT

Use this API to return an array of integer values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = abrnint(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_INTEGER(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem branches only. TIES = 2 for subsystem tie branches only. TIES = 3 for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for only in-service non-transformer branches. FLAG = 2 for all non-transformer branches. FLAG = 3 for only in-service non-transformer branches and two-winding transformers. FLAG = 4 for all non-transformer branches and two-winding transformers. FLAG = 5 for only in-service two-winding transformers. FLAG = 6 for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for single entry (each branch once). ENTRY = 2 for double entry (each branch in both directions).
Integer NSTR	the number of elements in STRING (1 < NSTR < 50) (input; no default allowed).

Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).	
	'FROMNUMBER'	From bus number
	'TONUMBER'	To bus number
	'FROMSTATION'	From bus substation number (0 if bus is not in a substation)
	'TOSTATION'	To bus substation number (0 if bus is not in a substation)
	'FROMSECTION'	From bus section number (0 if bus is not represented by multiple bus sections)
	'TOSECTION'	To bus section number (0 if bus is not represented by multiple bus sections)
	'FROMNODE'	From bus node number (0 if bus is not in a substation)
	'TONODE'	To bus node number (0 if bus is not in a substation)
	'STATUS'	Branch status
	'METERNUMBER'	Metered end bus number
	'NMETERNUMBER'	Non-metered end bus number
	'OWNERS'	Number of owners
	'OWN1'	First owner
	'OWN2'	Second owner
	'OWN3'	Third owner
	'OWN4'	Fourth owner
	'TYPE'	System switching device type (0 if branch is not a system switching device)
	'MOVTYPE'	MOV protection mode
Integer DIM	the number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	the number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY. (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value

IERR = 6	Invalid ENTRY value
IERR = 7	Invalid NSTR value
IERR = 8	DIM, and hence the size of IARRAY, is not large enough
IERR = 9	Invalid STRING value

12.12.5. ABRNREAL

Use this API to return an array of real values for subsystem branches.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = abrnreal(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_BRANCH_REAL(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
RARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem branches only. TIES = 2 for subsystem tie branches only. TIES = 3 for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for only in-service non-transformer branches. FLAG = 2 for all non-transformer branches. FLAG = 3 for only in-service non-transformer branches and two-winding transformers. FLAG = 4 for all non-transformer branches and two-winding transformers. FLAG = 5 for only in-service two-winding transformers. FLAG = 6 for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for single entry (each branch once). ENTRY = 2 for double entry (each branch in both directions).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).

Character STRING (NSTR)	NSTR of the following strings indicating the branch quantities desired (input; no default allowed).
'AMPS'	Branch current, in amps (0.0 if bus base voltage is 0.0)
'PUCUR'	Branch current, in pu
'PCTRATE'	Percent from bus current of default rating set
'PCTRATEA'	Percent from bus current of rating set A
'PCTRATEB'	Percent from bus current of rating set B
'PCTRATEC'	Percent from bus current of rating set C
'PCTRATE1'	Percent from bus current of rating set 1
'PCTRATE2'	Percent from bus current of rating set 2
'PCTRATE3'	Percent from bus current of rating set 3
'PCTRATE4'	Percent from bus current of rating set 4
'PCTRATE5'	Percent from bus current of rating set 5
'PCTRATE6'	Percent from bus current of rating set 6
'PCTRATE7'	Percent from bus current of rating set 7
'PCTRATE8'	Percent from bus current of rating set 8
'PCTRATE9'	Percent from bus current of rating set 9
'PCTRATE10'	Percent from bus current of rating set 10
'PCTRATE11'	Percent from bus current of rating set 11
'PCTRATE12'	Percent from bus current of rating set 12
'PCTMVARATE'	Percent from bus MVA of default rating set
'PCTMVARATEA'	Percent from bus MVA of rating set A
'PCTMVARATEB'	Percent from bus MVA of rating set B
'PCTMVARATEC'	Percent from bus MVA of rating set C
'PCTMVARATE1'	Percent from bus MVA of rating set 1
'PCTMVARATE2'	Percent from bus MVA of rating set 2
'PCTMVARATE3'	Percent from bus MVA of rating set 3
'PCTMVARATE4'	Percent from bus MVA of rating set 4
'PCTMVARATE5'	Percent from bus MVA of rating set 5
'PCTMVARATE6'	Percent from bus MVA of rating set 6
'PCTMVARATE7'	Percent from bus MVA of rating set 7
'PCTMVARATE8'	Percent from bus MVA of rating set 8
'PCTMVARATE9'	Percent from bus MVA of rating set 9
'PCTMVARATE10'	Percent from bus MVA of rating set 10
'PCTMVARATE11'	Percent from bus MVA of rating set 11
'PCTMVARATE12'	Percent from bus MVA of rating set 12
'PCTCORPRATE'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'PCTCORPRATEA'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set A

'PCTCORPRATEB'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set B
'PCTCORPRATEC'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set C
'PCTCRPRATE'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'PCTCRPRATE1'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 1
'PCTCRPRATE2'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 2
'PCTCRPRATE3'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 3
'PCTCRPRATE4'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 4
'PCTCRPRATE5'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 5
'PCTCRPRATE6'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 6
'PCTCRPRATE7'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 7
'PCTCRPRATE8'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 8
'PCTCRPRATE9'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 9
'PCTCRPRATE10'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 10
'PCTCRPRATE11'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 11
'PCTCRPRATE12'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 12
'MAXPCTRATE'	Larger of percent from/to bus current of default rating set

'MAXPCTRATEA'	Larger of percent from/to bus current of rating set A
'MAXPCTRATEB'	Larger of percent from/to bus current of rating set B
'MAXPCTRATEC'	Larger of percent from/to bus current of rating set C
'MAXPCTRATE1'	Larger of percent from/to bus current of rating set 1
'MAXPCTRATE2'	Larger of percent from/to bus current of rating set 2
'MAXPCTRATE3'	Larger of percent from/to bus current of rating set 3
'MAXPCTRATE4'	Larger of percent from/to bus current of rating set 4
'MAXPCTRATE5'	Larger of percent from/to bus current of rating set 5
'MAXPCTRATE6'	Larger of percent from/to bus current of rating set 6
'MAXPCTRATE7'	Larger of percent from/to bus current of rating set 7
'MAXPCTRATE8'	Larger of percent from/to bus current of rating set 8
'MAXPCTRATE9'	Larger of percent from/to bus current of rating set 9
'MAXPCTRATE10'	Larger of percent from/to bus current of rating set 10
'MAXPCTRATE11'	Larger of percent from/to bus current of rating set 11
'MAXPCTRATE12'	Larger of percent from/to bus current of rating set 12
'MXPCTMVARAT'	Larger of percent from/to bus MVA of default rating set
'MXPCTMVARATA'	Larger of percent from/to bus MVA of rating set A
'MXPCTMVARATB'	Larger of percent from/to bus MVA of rating set B
'MXPCTMVARATC'	Larger of percent from/to bus MVA of rating set C
'MXPCTPRATE'	Larger of percent from/to bus MVA of rating set C
'MXPCTPRATE1'	Larger of percent from/to bus MVA of rating set 1
'MXPCTPRATE2'	Larger of percent from/to bus MVA of rating set 2
'MXPCTPRATE3'	Larger of percent from/to bus MVA of rating set 3

'MXPCTPRATE4'	Larger of percent from/to bus MVA of rating set 4
'MXPCTPRATE5'	Larger of percent from/to bus MVA of rating set 5
'MXPCTPRATE6'	Larger of percent from/to bus MVA of rating set 6
'MXPCTPRATE7'	Larger of percent from/to bus MVA of rating set 7
'MXPCTPRATE8'	Larger of percent from/to bus MVA of rating set 8
'MXPCTPRATE9'	Larger of percent from/to bus MVA of rating set 9
'MXPCTPRATE10'	Larger of percent from/to bus MVA of rating set 10
'MXPCTPRATE11'	Larger of percent from/to bus MVA of rating set 11
'MXPCTPRATE12'	Larger of percent from/to bus MVA of rating set 12
'MXPCTCRPRAT'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'MXPCTCRPRATA'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set A
'MXPCTCRPRATB'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set B
'MXPCTCRPRATC'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set C
'MXPCTCRPRA'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'MXPCTCRPRA1'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 1
'MXPCTCRPRA2'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 2
'MXPCTCRPRA3'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent

	loading units program option setting) of rating set 3
'MXPCTCRPRA4'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 4
'MXPCTCRPRA5'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 5
'MXPCTCRPRA6'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 6
'MXPCTCRPRA7'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 7
'MXPCTCRPRA8'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 8
'MXPCTCRPRA9'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 9
'MXPCTCRPRA10'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 10
'MXPCTCRPRA11'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 11
'MXPCTCRPRA12'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 12
'FRACT1'	First owner fraction
'FRACT2'	Second owner fraction
'FRACT3'	Third owner fraction
'FRACT4'	Fourth owner fraction
'RATE'	Rating from default rating set
'RATEA'	Rating from rating set A
'RATEB'	Rating from rating set B
'RATEC'	Rating from rating set C
'RATE1'	Rating from rating set 1

	'RATE2'	Rating from rating set 2
	'RATE3'	Rating from rating set 3
	'RATE4'	Rating from rating set 4
	'RATE5'	Rating from rating set 5
	'RATE6'	Rating from rating set 6
	'RATE7'	Rating from rating set 7
	'RATE8'	Rating from rating set 8
	'RATE9'	Rating from rating set 9
	'RATE10'	Rating from rating set 10
	'RATE11'	Rating from rating set 11
	'RATE12'	Rating from rating set 12
	'LENGTH'	Line length
	'CHARGING'	Total charging capacitance, in pu
	'CHARGINGZERO'	Zero sequence total charging capacitance, in pu
	'MOVIRATED'	MOV Rated Current for series capacitor branch, in kA
	'P'	Active power flow at from bus end, in MW
	'Q'	Reactive power flow at from bus end, in Mvar
	'MVA'	$\text{abs}(P+jQ)$ at from bus end, in MVA
	'MAXMVA'	$\text{abs}(P+jQ)$ at from bus or to bus end whichever is larger, in MVA
	'PLOSS'	Active power losses, in MW
	'QLOSS'	Reactive power losses, in Mvar
	'O_P'	Active power flow at from bus end (units determined by power output options)
	'O_Q'	Reactive power flow at from bus end (units determined by power output options)
	'O_MVA'	$\text{abs}(P+jQ)$ at from bus end (units determined by power output options)
	'O_MAXMVA'	$\text{abs}(P+jQ)$ at from bus or to bus end whichever is larger (units determined by power output options)
	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	

Integer BRNCHS number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_BRANCH_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).

Integer IERR error code (output).

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid OWNER value
IERR = 4	Invalid TIES value
IERR = 5	Invalid FLAG value
IERR = 6	Invalid ENTRY value
IERR = 7	Invalid NSTR value
IERR = 8	DIM, and hence the size of RARRAY, is not large enough
IERR = 9	Invalid STRING value
IERR = 10	Sequence data not in case (when STRING = 'CHARGINGZERO')

12.12.6. ABRNTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the branch data family (aBrnInt, aBrnReal, aBrnCplx and aBrnChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = abrntypes(string)
```

Fortran command syntax:

```
CALL GET_BRANCH_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING ($1 < \text{NSTR} < 50$) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the branch data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch data family ($1 < n < \text{NSTR}$)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch data family ($1 < n < \text{NSTR}$)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch data family ($1 < n < \text{NSTR}$)										
IERR = 99	Invalid NSTR value										

12.13. Two-Winding Transformer Data

The two-winding transformer data family of subsystem data retrieval APIs returns arrays of data for two-winding transformers in a specified subsystem.

One of the input items to each API allows the user to elect either to retrieve data for all subsystem two-winding transformers, for subsystem tie two-winding transformers, or for both subsystem and tie two-winding transformers. Another input item allows the user to elect either to retrieve data for all such transformers, or to restrict the array entries to data for in-service transformers.

Data for subsystem two-winding transformers is returned from all APIs in the two-winding transformer data family in the same order. One of the input items to each API allows the user to elect that either single entry arrays (each transformer appears once) or double entry arrays (each transformer appears in both directions) are to be returned. Transformers are ordered in ascending numerical or alphabetical order by from bus, according to the bus output option setting in effect at the time the API is referenced. For each from bus, transformers are ordered in ascending order by to bus. Parallel transformers are ordered in ascending circuit identifier order.

12.13.1. ATRNCHAR

Use this API to return an array of character values for subsystem two-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = atrnchar(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_2WINDING_CHAR(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
CARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use transformer ownership.
Integer TIES	a flag indicating which subsystem two-winding transformers to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem two-winding transformers only.
	TIES = 2	for subsystem tie two-winding transformers only.

	TIES = 3	for both interior subsystem and tie two-winding transformers.
Integer FLAG	a flag indicating which subsystem two-winding transformers to include (input; 1 by default).	
	FLAG = 1	for only in-service two-winding transformers.
	FLAG = 2	for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for single entry (each branch once).
	ENTRY = 2	for double entry (each branch in both directions).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).	
	'ID'	Circuit identifier (2 characters).
	'FROMNAME'	From bus name (12 characters).
	'FROMEXNAME'	From bus extended bus name (18 characters).
	'TONAME'	To bus name (three-winding transformer name for a three-winding transformer winding) (12 characters).
	'TOEXNAME'	To bus extended bus name (three-winding transformer name and winding number for a three-winding transformer winding) (18 characters).
	'METERNAME'	Metered bus name (12 characters).
	'METEREXNAME'	Metered bus extended bus name (18 characters).
	'NMETERNAME'	Non-metered bus name (12 characters).
	'NMETEREXNAME'	Non-metered bus extended bus name (18 characters).
	'ICONTNAME'	Controlled bus name (12 characters).
	'ICONTEXNAME'	Controlled bus extended bus name (18 characters).
	'WIND1NAME'	Winding 1 bus name (12 characters).
	'WIND1EXNAME'	Winding 1 bus extended bus name (18 characters).
	'WIND2NAME'	Winding 2 bus name (12 characters).
	'WIND2EXNAME'	Winding 2 bus extended bus name (18 characters).
	'XFRNAME'	Transformer name (40 characters).
	'VECTORGROUP'	Vector group name (12 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values	

	specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of CARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.13.2. ATRNCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the two-winding transformer data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, brnchs = atrncount(sid, owner, ties, flag, entry)
```

Fortran command syntax:

```
CALL GET_2WINDING_COUNT(SID, OWNER, TIES, FLAG, ENTRY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem two-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-winding transformers only. TIES = 2 for subsystem tie two-winding transformers only. TIES = 3 for both interior subsystem and tie two-winding transformers.
Integer FLAG	a flag indicating which subsystem two-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service two-winding transformers. FLAG = 2 for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for single entry (each branch once). ENTRY = 2 for double entry (each branch in both directions).
Integer BRNCHS	number of array entries required for the subsystem indicated by SID and OWNER that meet the editing criteria indicated by TIES, FLAG and ENTRY (output).
Integer IERR	error code (output). IERR = 0 No error, BRNCHS returned

IERR = 1	Working case is empty; BRNCHS returned as 0
IERR = 2	Invalid SID value; BRNCHS returned as 0
IERR = 3	Invalid OWNER value; BRNCHS returned as 0
IERR = 4	Invalid TIES value; BRNCHS returned as 0
IERR = 5	Invalid FLAG value; BRNCHS returned as 0
IERR = 6	Invalid ENTRY value; BRNCHS returned as 0

12.13.3. ATRNCPLX

Use this API to return an array of complex values for subsystem two-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = atrncplx(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_2WINDING_COMPLEX(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem two-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-winding transformers only. TIES = 2 for subsystem tie two-winding transformers only. TIES = 3 for both interior subsystem and tie two-winding transformers.
Integer FLAG	a flag indicating which subsystem two-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service two-winding transformers. FLAG = 2 for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for single entry (each branch once). ENTRY = 2 for double entry (each branch in both directions).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed). 'RXACT' Actual transformer impedance in pu

	'RXACTCZ'	Actual transformer impedance in units governed by CZ
	'RXNOM'	Nominal transformer impedance in pu
	'RXNOMCZ'	Nominal transformer impedance in units governed by CZ
	'YMAG'	Magnetizing admittance in pu
	'YMAGCM'	Magnetizing admittance in units governed by CM
	'COMPRX'	Load drop compensation impedance in pu
	'RXZERO'	Zero sequence branch impedance in pu
	'ZG1'	ZGRND' Zero sequence winding 1 grounding impedance in pu
	'ZG1CZG'	Zero sequence winding 1 grounding impedance in units governed by CZG
	'ZG2'	'ZGRND2' Zero sequence winding 2 grounding impedance in pu
	'ZG2CZG'	Zero sequence winding 2 grounding impedance in units governed by CZG
	'Z01'	Zero sequence leakage impedance connected to the winding 1 bus in pu
	'Z01CZ0'	Zero sequence leakage impedance connected to the winding 1 bus in units governed by CZ0
	'Z02'	Zero sequence leakage impedance connected to the winding 2 bus in pu
	'Z02CZ0'	Zero sequence leakage impedance connected to the winding 2 bus in units governed by CZ0
	'ZNUTRL'	Zero sequence common neutral grounding impedance in pu
	'ZNUTRLCZG'	Zero sequence common neutral grounding impedance in units governed by CZG
	'PQ'	P + j Q flow at from bus end
	'PQLOSS'	Losses (MW and Mvar)
	'O_PQ'	P + j Q flow at from bus end (units determined by power output options)
	'O_PQLOSS'	Losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	

Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of XARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case (when STRING = 'RXZERO', 'ZGRND', 'ZGRND2', 'ZG1', 'ZG1CZG', 'ZG2', 'ZG2CZG', 'Z01', 'Z01CZ0', 'Z02', 'Z02CZ0', 'ZNUTRL', or 'ZNUTRLCZG')

12.13.4. ATRNINT

Use this API to return an array of integer values for subsystem two-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = atrnint(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_2WINDING_INTEGER(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING,  
    DIM, IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem two-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-winding transformers only. TIES = 2 for subsystem tie two-winding transformers only. TIES = 3 for both interior subsystem and tie two-winding transformers.
Integer FLAG	a flag indicating which subsystem two-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service two-winding transformers. FLAG = 2 for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for single entry (each branch once). ENTRY = 2 for double entry (each branch in both directions).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed). 'FROMNUMBER' From bus number 'TONUMBER' To bus number

'FROMSTATION'	From bus substation number (0 if bus is not in a substation)
'TOSTATION'	To bus substation number (0 if bus is not in a substation)
'FROMSECTION'	From bus section number (0 if bus is not represented by multiple bus sections)
'TOSECTION'	To bus section number (0 if bus is not represented by multiple bus sections)
'FROMNODE'	From bus node number (0 if bus is not in a substation)
'TONODE'	To bus node number (0 if bus is not in a substation)
'STATUS'	Transformer status
'METERNUMBER'	Metered end bus number
'NMETERNUMBER'	Non-metered end bus number
'OWNERS'	Number of owners
'OWN1'	First owner
'OWN2'	Second owner
'OWN3'	Third owner
'OWN4'	Fourth owner
'ICONTNUMBER'	Controlled bus number
'NCONT'	Controlled node number
'WIND1NUMBER'	Winding 1 bus number
'WIND2NUMBER'	Winding 2 bus number
'WIND1STATION'	Winding 1 bus substation number (0 if bus is not in a substation)
'WIND2STATION'	Winding 2 bus substation number (0 if bus is not in a substation)
'WIND1SECTION'	Winding 1 bus section number (0 if bus is not represented by multiple bus sections)
'WIND2SECTION'	Winding 2 bus section number (0 if bus is not represented by multiple bus sections)
'WIND1NODE'	Winding 1 bus node number (0 if bus is not in a substation)
'WIND2NODE'	Winding 2 bus node number (0 if bus is not in a substation)
'TABLE'	Transformer impedance adjustment table number
'CODE'	Transformer control mode for automatic adjustments
'NTPOSN'	Number of tap positions
'CW'	Winding data I/O code
'CZ'	Impedance data I/O code
'CM'	Magnetizing admittance I/O code
'CZO'	Leakage impedance data I/O code

	'CZG'	Grounding impedance data I/O code
	'CNXCOD'	Connection code
	'TPSTT'	Winding 1 ratio limit code: -1 for low, 0 for regulating, 1 for high, -2 for locked, -3 for controlling a dc line
	'ANSTT'	Winding 1 angle limit code: -1 for low, 0 for regulating, 1 for high, -2 for locked
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of IARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case (when STRING = 'CZO', 'CZG' or 'CNXCOD')

12.13.5. ATRNREAL

Use this API to return an array of real values for subsystem two-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = atrnreal(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_2WINDING_REAL(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
RARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem two-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-winding transformers only. TIES = 2 for subsystem tie two-winding transformers only. TIES = 3 for both interior subsystem and tie two-winding transformers.
Integer FLAG	a flag indicating which subsystem two-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service two-winding transformers. FLAG = 2 for all two-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for single entry (each branch once). ENTRY = 2 for double entry (each branch in both directions).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed). 'AMPS' Branch current in amps (0.0 if bus base voltage is 0.0)

'PUCUR'	Branch current in pu
'PCTRATE'	Percent from bus current of default rating set
'PCTRATEA'	Percent from bus current of rating set A
'PCTRATEB'	Percent from bus current of rating set B
'PCTRATEC'	Percent from bus current of rating set C
'PCTRATE1'	Percent from bus current of rating set 1
'PCTRATE2'	Percent from bus current of rating set 2
'PCTRATE3'	Percent from bus current of rating set 3
'PCTRATE4'	Percent from bus current of rating set 4
'PCTRATE5'	Percent from bus current of rating set 5
'PCTRATE6'	Percent from bus current of rating set 6
'PCTRATE7'	Percent from bus current of rating set 7
'PCTRATE8'	Percent from bus current of rating set 8
'PCTRATE9'	Percent from bus current of rating set 9
'PCTRATE10'	Percent from bus current of rating set 10
'PCTRATE11'	Percent from bus current of rating set 11
'PCTRATE12'	Percent from bus current of rating set 12
'PCTMVARATE'	Percent from bus MVA of default rating set
'PCTMVARATEA'	Percent from bus MVA of rating set A
'PCTMVARATEB'	Percent from bus MVA of rating set B
'PCTMVARATEC'	Percent from bus MVA of rating set C
'PCTMVARATE1'	Percent from bus MVA of rating set 1
'PCTMVARATE2'	Percent from bus MVA of rating set 2
'PCTMVARATE3'	Percent from bus MVA of rating set 3
'PCTMVARATE4'	Percent from bus MVA of rating set 4
'PCTMVARATE5'	Percent from bus MVA of rating set 5
'PCTMVARATE6'	Percent from bus MVA of rating set 6
'PCTMVARATE7'	Percent from bus MVA of rating set 7
'PCTMVARATE8'	Percent from bus MVA of rating set 8
'PCTMVARATE9'	Percent from bus MVA of rating set 9
'PCTMVARATE10'	Percent from bus MVA of rating set 10
'PCTMVARATE11'	Percent from bus MVA of rating set 11
'PCTMVARATE12'	Percent from bus MVA of rating set 12
'PCTCORPRATE'	Percent from bus current or MVA loading (according to the transformer percent loading units program option setting) of default rating set
'PCTCORPRATEA'	Percent from bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set A
'PCTCORPRATEB'	Percent from bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set B

'PCTCORPRATEC'	Percent from bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set C
'PCTCRPRATE'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'PCTCRPRATE1'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 1
'PCTCRPRATE2'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 2
'PCTCRPRATE3'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 3
'PCTCRPRATE4'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 4
'PCTCRPRATE5'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 5
'PCTCRPRATE6'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 6
'PCTCRPRATE7'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 7
'PCTCRPRATE8'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 8
'PCTCRPRATE9'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 9
'PCTCRPRATE10'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 10
'PCTCRPRATE11'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 11
'PCTCRPRATE12'	Percent from bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 12
'MAXPCTRATE'	Larger of percent from/to bus current of default rating set
'MAXPCTRATEA'	Larger of percent from/to bus current of rating set A

'MAXPCTRATEB'	Larger of percent from/to bus current of rating set B
'MAXPCTRATEC'	Larger of percent from/to bus current of rating set C
'MAXPCTRATE1'	Larger of percent from/to bus current of rating set 1
'MAXPCTRATE2'	Larger of percent from/to bus current of rating set 2
'MAXPCTRATE3'	Larger of percent from/to bus current of rating set 3
'MAXPCTRATE4'	Larger of percent from/to bus current of rating set 4
'MAXPCTRATE5'	Larger of percent from/to bus current of rating set 5
'MAXPCTRATE6'	Larger of percent from/to bus current of rating set 6
'MAXPCTRATE7'	Larger of percent from/to bus current of rating set 7
'MAXPCTRATE8'	Larger of percent from/to bus current of rating set 8
'MAXPCTRATE9'	Larger of percent from/to bus current of rating set 9
'MAXPCTRATE10'	Larger of percent from/to bus current of rating set 10
'MAXPCTRATE11'	Larger of percent from/to bus current of rating set 11
'MAXPCTRATE12'	Larger of percent from/to bus current of rating set 12
'MXPCTMVARAT'	Larger of percent from/to bus MVA of default rating set
'MXPCTMVARATA'	Larger of percent from/to bus MVA of rating set A
'MXPCTMVARATB'	Larger of percent from/to bus MVA of rating set B
'MXPCTMVARATC'	Larger of percent from/to bus MVA of rating set C
'MXPCTCRPRAT'	Larger of percent from/to bus current or MVA loading (according to the transformer percent loading units program option setting) of default rating set
'MXPCTCRPRATA'	Larger of percent from/to bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set A
'MXPCTCRPRATB'	Larger of percent from/to bus current or MVA loading (according to the transformer percent

	loading units program option setting) of rating set B
'MXPCTCRPRATC'	Larger of percent from/to bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set C
'MXPCTPRATE'	Larger of percent from/to bus MVA of default rating set
'MXPCTPRATE1'	Larger of percent from/to bus MVA of rating set 1
'MXPCTPRATE2'	Larger of percent from/to bus MVA of rating set 2
'MXPCTPRATE3'	Larger of percent from/to bus MVA of rating set 3
'MXPCTPRATE4'	Larger of percent from/to bus MVA of rating set 4
'MXPCTPRATE5'	Larger of percent from/to bus MVA of rating set 5
'MXPCTPRATE6'	Larger of percent from/to bus MVA of rating set 6
'MXPCTPRATE7'	Larger of percent from/to bus MVA of rating set 7
'MXPCTPRATE8'	Larger of percent from/to bus MVA of rating set 8
'MXPCTPRATE9'	Larger of percent from/to bus MVA of rating set 9
'MXPCTPRATE10'	Larger of percent from/to bus MVA of rating set 10
'MXPCTPRATE11'	Larger of percent from/to bus MVA of rating set 11
'MXPCTPRATE12'	Larger of percent from/to bus MVA of rating set 12
'MXPCTCRPRA'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'MXPCTCRPRA1'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 1
'MXPCTCRPRA2'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 2
'MXPCTCRPRA3'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent

	loading units program option setting) of rating set 3
'MXPCTCRPRA4'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 4
'MXPCTCRPRA5'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 5
'MXPCTCRPRA6'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 6
'MXPCTCRPRA7'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 7
'MXPCTCRPRA8'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 8
'MXPCTCRPRA9'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 9
'MXPCTCRPRA10'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 10
'MXPCTCRPRA11'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 11
'MXPCTCRPRA12'	Larger of percent from/to bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 12
'FRACT1'	First owner fraction
'FRACT2'	Second owner fraction
'FRACT3'	Third owner fraction
'FRACT4'	Fourth owner fraction
'RATE'	Rating from default rating set
'RATEA'	Rating from rating set A
'RATEB'	Rating from rating set B
'RATEC'	Rating from rating set C
'RATE1'	Rating from rating set 1

'RATE2'	Rating from rating set 2
'RATE3'	Rating from rating set 3
'RATE4'	Rating from rating set 4
'RATE5'	Rating from rating set 5
'RATE6'	Rating from rating set 6
'RATE7'	Rating from rating set 7
'RATE8'	Rating from rating set 8
'RATE9'	Rating from rating set 9
'RATE10'	Rating from rating set 10
'RATE11'	Rating from rating set 11
'RATE12'	Rating from rating set 12
'RATIO'	Winding 1 tap ratio in pu
'RATIOCW'	Winding 1 tap ratio in units governed by CW
'RATIO2'	Winding 2 tap ratio in pu
'RATIO2CW'	Winding 2 tap ratio in units governed by CW
'ANGLE'	Winding 1 phase shift angle in degrees
'RMAX'	Winding 1 ratio or angle upper limit (in pu if ratio)
'RMAXCW'	Winding 1 ratio or angle upper limit (in units governed by CW if ratio)
'RMIN'	Winding 1 ratio or angle lower limit (in pu if ratio)
'RMINCW'	Winding 1 ratio or angle lower limit (in units governed by CW if ratio)
'VMAX'	Controlled quantity upper limit (in pu if voltage)
'VMAXKV'	Controlled quantity upper limit (in units governed by CW if voltage)
'VMIN'	Controlled quantity lower limit (in pu if voltage)
'VMINKV'	Controlled quantity lower limit (in units governed by CW if voltage)
'STEP'	Winding 1 ratio or angle step width (in pu if ratio)
'STEPCW'	Winding 1 ratio or angle step width (in units governed by CW if ratio)
'NOMV1'	Winding 1 nominal voltage in kv (0.0 for bus base voltage)
'NOMV2'	Winding 2 nominal voltage in kv (0.0 for bus base voltage)
'SBASE1'	Winding 1 base MVA
'P'	Active power flow at from bus end, in MW
'Q'	Reactive power flow at from bus end, in Mvar
'MVA'	$\text{abs}(P+jQ)$ at from bus end, in MVA

	'MAXMVA'	abs(P+jQ) at from bus or to bus end, whichever is larger, in MVA
	'PLOSS'	Active power losses, in MW
	'QLOSS'	Reactive power losses, in Mvar
	'O_P'	Active power flow at from bus end (units determined by power output options)
	'O_Q'	Reactive power flow at from bus end (units determined by power output options)
	'O_MVA'	abs(P+jQ) at from bus end (units determined by power output options)
	'O_MAXMVA'	abs(P+jQ) at from bus or to bus end whichever is larger (units determined by power output options)
	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_2WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of RARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.13.6. ATRNTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the two-winding transformer data family (aTrnInt, aTrnReal, aTrnCplx and aTrnChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = atrntypes(string)
```

Fortran command syntax:

```
CALL GET_2WINDING_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the two-winding transformer data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-winding transformer data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-winding transformer data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-winding transformer data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.14. Three-Winding Transformer Data

The three-winding transformer data family of subsystem data retrieval APIs returns arrays of data for three-winding transformers in a specified subsystem.

One of the input items to each API allows the user to elect either to retrieve data for all subsystem three-winding transformers, for subsystem tie three-winding transformers, or for both subsystem and tie three-winding transformers. Another input item allows the user to elect either to retrieve data for all such transformers, or to restrict the array entries to data for in-service transformers.

Data for subsystem three-winding transformers is returned from all APIs in the three-winding transformer data family in the same order. One of the input items to each API allows the user to elect that transformers be ordered either by transformer name, or in ascending numerical or alphabetical order by winding 1 bus, according to the bus output option setting in effect at the time the API is referenced. For each winding 1 bus, transformers are ordered in ascending order by winding 2 bus, then winding 3 bus, then in ascending circuit identifier order.

12.14.1. ATR3CHAR

Use this API to return an array of character values for subsystem three-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = atr3char(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_CHAR(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
CARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem three-winding transformers only.
	TIES = 2	for subsystem tie three-winding transformers only.

	TIES = 3	for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default).	
	FLAG = 1	for only in-service three-winding transformers.
	FLAG = 2	for all three-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for winding 1 bus order.
	ENTRY = 2	for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).	
	'ID'	Circuit identifier (2 characters).
	'WIND1NAME'	Winding 1 bus name (12 characters).
	'WIND1EXNAME'	Winding 1 bus extended bus name (18 characters).
	'WIND2NAME'	Winding 2 bus name (12 characters).
	'WIND2EXNAME'	Winding 2 bus extended bus name (18 characters).
	'WIND3NAME'	Winding 3 bus name (12 characters).
	'WIND3EXNAME'	Winding 3 bus extended bus name (18 characters).
	'NMETERNAME'	Non-metered bus name (12 characters).
	'NMETEREXNAME'	Non-metered bus extended bus name (18 characters).
	'XFRNAME'	Transformer name (40 characters).
	'VECTORGROUP'	Vector group name (12 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value

IERR = 4	Invalid TIES value
IERR = 5	Invalid FLAG value
IERR = 6	Invalid ENTRY value
IERR = 7	Invalid NSTR value
IERR = 8	DIM, and hence the size of CARRAY, is not large enough
IERR = 9	Invalid STRING value

12.14.2. ATR3COUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the three-winding transformer data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, brnchs = atr3count(sid, owner, ties, flag, entry)
```

Fortran command syntax:

```
CALL GET_3WINDING_COUNT(SID, OWNER, TIES, FLAG, ENTRY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem three-winding transformers only. TIES = 2 for subsystem tie three-winding transformers only. TIES = 3 for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service three-winding transformers. FLAG = 2 for all three-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for winding 1 bus order. ENTRY = 2 for transformer name order.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID and OWNER that meet the editing criteria indicated by TIES, FLAG and ENTRY (output).
Integer IERR	error code (output). IERR = 0 No error, BRNCHS returned

IERR = 1	Working case is empty; BRNCHS returned as 0
IERR = 2	Invalid SID value; BRNCHS returned as 0
IERR = 3	Invalid OWNER value; BRNCHS returned as 0
IERR = 4	Invalid TIES value; BRNCHS returned as 0
IERR = 5	Invalid FLAG value; BRNCHS returned as 0
IERR = 6	Invalid ENTRY value; BRNCHS returned as 0

12.14.3. ATR3CPLX

Use this API to return an array of complex values for subsystem three-winding transformers.

This API routine was first introduced in release 30.3.2.

Python command syntax:

```
ierr, xarray = atr3cplx(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_COMPLEX(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).
	SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).
	OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default).
	TIES = 1 for interior subsystem three-winding transformers only.
	TIES = 2 for subsystem tie three-winding transformers only.
Integer FLAG	TIES = 3 for both interior subsystem and tie three-winding transformers.
	a flag indicating which subsystem three-winding transformers to include (input; 1 by default).
	FLAG = 1 for only in-service three-winding transformers. FLAG = 2 for all three-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default).
	ENTRY = 1 for winding 1 bus order. ENTRY = 2 for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).
	'RX1-2ACT' Actual measured impedance between the winding 1 and winding 2 buses in pu

'RX1-2ACTCZ'	Actual measured impedance between the winding 1 and winding 2 buses in units governed by CZ
'RX1-2NOM'	Nominal measured impedance between the winding 1 and winding 2 buses in pu
'RX1-2NOMCZ'	Nominal measured impedance between the winding 1 and winding 2 buses in units governed by CZ
'RX2-3ACT'	Actual measured impedance between the winding 2 and winding 3 buses in pu
'RX2-3ACTCZ'	Actual measured impedance between the winding 2 and winding 3 buses in units governed by CZ
'RX2-3NOM'	Nominal measured impedance between the winding 2 and winding 3 buses in pu
'RX2-3NOMCZ'	Nominal measured impedance between the winding 2 and winding 3 buses in units governed by CZ
'RX3-1ACT'	Actual measured impedance between the winding 3 and winding 1 buses in pu
'RX3-1ACTCZ'	Actual measured impedance between the winding 3 and winding 1 buses in units governed by CZ
'RX3-1NOM'	Nominal measured impedance between the winding 3 and winding 1 buses in pu
'RX3-1NOMCZ'	Nominal measured impedance between the winding 3 and winding 1 buses in units governed by CZ
'YMAG'	Magnetizing admittance in pu
'YMAGCM'	Magnetizing admittance in units governed by CM
'ZG1'	'ZGRND' Zero sequence winding 1 grounding impedance in pu
'ZG1CZG'	Zero sequence winding 1 grounding impedance in units governed by CZG
'ZG2'	'ZGRND2' Zero sequence winding 2 grounding impedance in pu
'ZG2CZG'	Zero sequence winding 2 grounding impedance in units governed by CZG
'ZG3'	'ZGRND3' Zero sequence winding 3 grounding impedance in pu
'ZG3CZG'	Zero sequence winding 3 grounding impedance in units governed by CZG
'Z01'	Zero sequence winding 1 or bus 1 to bus 2 leakage impedance in pu
'Z01CZ0'	Zero sequence winding 1 or bus 1 to bus 2 leakage impedance in units governed by CZ0

	'Z02'	Zero sequence winding 2 or bus 2 to bus 3 leakage impedance in pu
	'Z02CZ0'	Zero sequence winding 2 or bus 2 to bus 3 leakage impedance in units governed by CZ0
	'Z03'	Zero sequence winding 3 or bus 3 to bus 1 leakage impedance in pu
	'Z03CZ0'	Zero sequence winding 3 or bus 3 to bus 1 leakage impedance in units governed by CZ0
	'ZNUTRL'	Zero sequence common neutral grounding impedance in pu
	'ZNUTRLCZG'	Zero sequence common neutral grounding impedance in units governed by CZG
	'PQLOSS'	Losses (in MW and Mvar)
	'O_PQLOSS'	Losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of XARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case (when STRING = 'ZGRND', 'ZG1', 'ZG1CZG', 'ZG2', 'ZG2CZG', 'ZG3', 'ZG3CZG', 'Z01', 'Z01CZ0', 'Z02', 'Z02CZ0', 'Z03', 'Z03CZ0', 'ZNUTRL', or 'ZNUTRLCZG')

12.14.4. ATR3INT

Use this API to return an array of integer values for subsystem three-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = atr3int(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_INTEGER(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING,  
    DIM, IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem three-winding transformers only. TIES = 2 for subsystem tie three-winding transformers only. TIES = 3 for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service three-winding transformers. FLAG = 2 for all three-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for winding 1 bus order. ENTRY = 2 for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed). 'WIND1NUMBER' Winding 1 bus number 'WIND2NUMBER' Winding 2 bus number

	'WIND3NUMBER'	Winding 3 bus number
	'WIND1STATION'	Winding 1 bus substation number (0 if bus is not in a substation)
	'WIND2STATION'	Winding 2 bus substation number (0 if bus is not in a substation)
	'WIND3STATION'	Winding 3 bus substation number (0 if bus is not in a substation)
	'WIND1SECTION'	Winding 1 bus section number (0 if bus is not represented by multiple bus sections)
	'WIND2SECTION'	Winding 2 bus section number (0 if bus is not represented by multiple bus sections)
	'WIND3SECTION'	Winding 3 bus section number (0 if bus is not represented by multiple bus sections)
	'WIND1NODE'	Winding 1 bus node number (0 if bus is not in a substation)
	'WIND2NODE'	Winding 2 bus node number (0 if bus is not in a substation)
	'WIND3NODE'	Winding 3 bus node number (0 if bus is not in a substation)
	'STATUS'	Transformer status
	'NMETERNUMBER'	Non-metered end bus number
	'OWNERS'	Number of owners
	'OWN1'	First owner
	'OWN2'	Second owner
	'OWN3'	Third owner
	'OWN4'	Fourth owner
	'ZADCOD'	Impedance adjustment method code
	'CW'	Winding data I/O code
	'CZ'	Impedance data I/O code
	'CM'	Magnetizing admittance I/O code
	'CZO'	Leakage impedance data I/O code
	'CZG'	Grounding impedance data I/O code
	'CNXCOD'	Connection code
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid OWNER value
IERR = 4	Invalid TIES value
IERR = 5	Invalid FLAG value
IERR = 6	Invalid ENTRY value
IERR = 7	Invalid NSTR value
IERR = 8	DIM, and hence the size of IARRAY, is not large enough
IERR = 9	Invalid STRING value
IERR = 10	Sequence data not in case (when STRING = 'CZO', 'CZG' or 'CNXCOD')

12.14.5. ATR3REAL

Use this API to return an array of real values for subsystem three-winding transformers.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = atr3real(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_REAL(SID, OWNER, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
RARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem three-winding transformers only. TIES = 2 for subsystem tie three-winding transformers only. TIES = 3 for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service three-winding transformers. FLAG = 2 for all three-winding transformers.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for winding 1 bus order. ENTRY = 2 for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed). 'FRACT1' First owner fraction

	'FRACT2'	Second owner fraction
	'FRACT3'	Third owner fraction
	'FRACT4'	Fourth owner fraction
	'VMSTAR'	Actual bus voltage magnitude at the star point bus, in pu
	'ANSTAR'	Bus voltage phase angle at the star point bus, in degrees
	'PLOSS'	Active power losses, in MW
	'QLOSS'	Reactive power losses, in Mvar
	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of RARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.14.6. ATR3TYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the three-winding transformer data family (aTr3Int, aTr3Real, aTr3Cplx and aTr3Char).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = atr3types(string)
```

Fortran command syntax:

```
CALL GET_3WINDING_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the three-winding transformer data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the three-winding transformer data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the three-winding transformer data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the three-winding transformer data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.15. Three-Winding Transformer Winding Data

The three-winding transformer winding data family of subsystem data retrieval APIs returns arrays of winding data for three-winding transformers in a specified subsystem.

One of the input items to each API allows the user to elect either to retrieve data for all subsystem three-winding transformers, for subsystem tie three-winding transformers, or for both subsystem and tie three-winding transformers. Another input item allows the user to elect either to retrieve data for all such transformers, to restrict the array entries to data for all windings of in-service transformers, or to restrict the array entries to data for in-service windings of in-service transformers.

Data for subsystem three-winding transformers is returned from all APIs in the three-winding transformer winding data family in the same order. One of the input items to each API allows the user to elect that transformers be ordered either by transformer name with all windings of each transformer grouped together, or in ascending numerical or alphabetical order by winding bus, according to the bus output option setting in effect at the time the API is referenced.

12.15.1. AWNDCHAR

Use this API to return an array of character values for subsystem three-winding transformer windings.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, carray = awndchar(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_WINDINGS_CHAR(SID, OWNER, TIES, FLAG, ENTRY, NSTR,  
    STRING, DIM, CARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem three-winding transformers only.
	TIES = 2	for subsystem tie three-winding transformers only.
	TIES = 3	for both interior subsystem and tie three-winding transformers.

Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default).
	FLAG = 1 for only in-service windings of in-service three-winding transformers.
	FLAG = 2 for all windings of in-service three-winding transformers.
	FLAG = 3 for all three-winding transformer windings.
Integer ENTRY	a flag indicating organization (input; 1 by default).
	ENTRY = 1 for winding bus order.
	ENTRY = 2 for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).
	'ID' Circuit identifier (2 characters).
	'WNCBUSNAME' Name of the bus connected to this winding (12 characters).
	'WNCBUSEXNAME' Extended bus name of the bus connected to this winding (18 characters).
	'OTHER1NAME' Name of another bus connected to this winding (12 characters).
	'OTHER1EXNAME' Extended bus name of another bus connected to this winding (18 characters).
	'OTHER2NAME' Name of another bus connected to this winding (12 characters).
	'OTHER2EXNAME' Extended bus name of another bus connected to this winding (18 characters).
	'WIND1NAME' Winding 1 bus name (12 characters).
	'WIND1EXNAME' Winding 1 bus extended bus name (18 characters).
	'WIND2NAME' Winding 2 bus name (12 characters).
	'WIND2EXNAME' Winding 2 bus extended bus name (18 characters).
	'WIND3NAME' Winding 3 bus name (12 characters).
	'WIND3EXNAME' Winding 3 bus extended bus name (18 characters).
	'NMETERNAME' Non-metered bus name (12 characters).
	'NMETEREXNAME' Non-metered bus extended bus name (18 characters).
	'XFRNAME' Transformer name (40 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).

Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of CARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.15.2. AWNDCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the three-winding transformer winding data family.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, brnchs = awndcount(sid, owner, ties, flag, entry)
```

Fortran command syntax:

```
CALL GET_3WINDING_WINDINGS_COUNT(SID, OWNER, TIES, FLAG, ENTRY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem three-winding transformers only. TIES = 2 for subsystem tie three-winding transformers only. TIES = 3 for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service windings of in-service three-winding transformers. FLAG = 2 for all windings of in-service three-winding transformers. FLAG = 3 for all three-winding transformer windings.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for winding 1 bus order. ENTRY = 2 for transformer name order.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID and OWNER that meet the editing criteria indicated by TIES, FLAG and ENTRY (output).

Integer IERR

error code (output).

IERR = 0	No error, BRNCHS returned
IERR = 1	Working case is empty; BRNCHS returned as 0
IERR = 2	Invalid SID value; BRNCHS returned as 0
IERR = 3	Invalid OWNER value; BRNCHS returned as 0
IERR = 4	Invalid TIES value; BRNCHS returned as 0
IERR = 5	Invalid FLAG value; BRNCHS returned as 0
IERR = 6	Invalid ENTRY value; BRNCHS returned as 0

12.15.3. AWNDCPLX

Use this API to return an array of complex values for subsystem three-winding transformer windings.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, xarray = awndcplx(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_WINDINGS_COMPLEX(SID, OWNER, TIES, FLAG, ENTRY, NSTR,  
  STRING, DIM, XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem three-winding transformers only. TIES = 2 for subsystem tie three-winding transformers only. TIES = 3 for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service windings of in-service three-winding transformers. FLAG = 2 for all windings of in-service three-winding transformers. FLAG = 3 for all three-winding transformer windings.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for winding bus order. ENTRY = 2 for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).

	'RXACT'	Actual transformer impedance, in pu
	'RXNOM'	Nominal transformer impedance, in pu
	'COMPRX'	Load drop compensation impedance, in pu
	'RXZERO'	Zero sequence winding leakage impedance, in pu
	'ZGRND'	Zero sequence winding grounding impedance, in pu
	'PQ'	P + j Q flow at winding bus end, in MW and Mvar
	'PQLOSS'	Losses, in MW and Mvar
	'O_PQ'	P + j Q flow at winding bus end (units determined by power output options)
	'O_PQLOSS'	Losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of XARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case (when STRING = 'RXZERO' or 'ZGRND')

12.15.4. AWNDINT

Use this API to return an array of integer values for subsystem three-winding transformer windings.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, iarray = awndint(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_WINDINGS_INTEGER(SID, OWNER, TIES, FLAG, ENTRY, NSTR,  
  STRING, DIM, IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem three-winding transformers only. TIES = 2 for subsystem tie three-winding transformers only. TIES = 3 for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default). FLAG = 1 for only in-service windings of in-service three-winding transformers. FLAG = 2 for all windings of in-service three-winding transformers. FLAG = 3 for all three-winding transformer windings.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for winding 1 bus order. ENTRY = 2 for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).

'WNBUSNUMBER'	Number of the bus connected to this winding
'OTHER1NUMBER'	Number of another bus connected to this transformer
'OTHER2NUMBER'	Number of another bus connected to this transformer
'WNDNUM'	Winding number
'WIND1NUMBER'	Winding 1 bus number
'WIND2NUMBER'	Winding 2 bus number
'WIND3NUMBER'	Winding 3 bus number
'WIND1STATION'	Winding 1 bus substation number (0 if bus is not in a substation)
'WIND2STATION'	Winding 2 bus substation number (0 if bus is not in a substation)
'WIND3STATION'	Winding 3 bus substation number (0 if bus is not in a substation)
'WIND1SECTION'	Winding 1 bus section number (0 if bus is not represented by multiple bus sections)
'WIND2SECTION'	Winding 2 bus section number (0 if bus is not represented by multiple bus sections)
'WIND3SECTION'	Winding 3 bus section number (0 if bus is not represented by multiple bus sections)
'WIND1NODE'	Winding 1 bus node number (0 if bus is not in a substation)
'WIND2NODE'	Winding 2 bus node number (0 if bus is not in a substation)
'WIND3NODE'	Winding 3 bus node number (0 if bus is not in a substation)
'NMETERNUMBER'	Non-metered end bus number
'STATUS'	Winding status
'OWNERS'	Number of owners
'OWN1'	First owner
'OWN2'	Second owner
'OWN3'	Third owner
'OWN4'	Fourth owner
'ICONTNUMBER'	Controlled bus number
'NCONT'	Controlled node number
'TABLE'	Transformer impedance adjustment table number
'CODE'	Transformer control mode for automatic adjustments
'NTPOSN'	Number of tap positions
'CW'	Winding data I/O code
'CZ'	Impedance data I/O code
'CM'	Magnetizing admittance I/O code
'CZO'	Leakage impedance data I/O code

	'CZG'	Grounding impedance data I/O code
	'CNXCOD'	Connection code
	'TPSTT'	Winding 1 ratio limit code: -1 for low, 0 for regulating, 1 for high, -2 for locked
	'ANSTT'	Winding 1 angle limit code: -1 for low, 0 for regulating, 1 for high, -2 for locked
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of IARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case (when STRING = 'CZO', 'CZG' or 'CNXCOD')

12.15.5. AWNDREAL

Use this API to return an array of real values for subsystem three-winding transformer windings.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
ierr, rarray = awndreal(sid, owner, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_3WINDING_WINDINGS_REAL(SID, OWNER, TIES, FLAG, ENTRY, NSTR,  
    STRING, DIM, RARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use transformer ownership.
Integer TIES	a flag indicating which subsystem three-winding transformers to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem three-winding transformers only.
	TIES = 2	for subsystem tie three-winding transformers only.
	TIES = 3	for both interior subsystem and tie three-winding transformers.
Integer FLAG	a flag indicating which subsystem three-winding transformers to include (input; 1 by default).	
	FLAG = 1	for only in-service windings of in-service three-winding transformers.
	FLAG = 2	for all windings of in-service three-winding transformers.
	FLAG = 3	for all three-winding transformer windings.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for winding 1 bus order.
	ENTRY = 2	for transformer name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the transformer quantities desired (input; no default allowed).	

'AMPS'	Branch current in amps (0.0 if bus base voltage is 0.0)
'PUCUR'	Branch current in pu
'PCTRATE'	Percent winding bus current of default rating set
'PCTRATEA'	Percent winding bus current of rating set A
'PCTRATEB'	Percent winding bus current of rating set B
'PCTRATEC'	Percent winding bus current of rating set C
'PCTRATE1'	Percent winding bus current of rating set 1
'PCTRATE2'	Percent winding bus current of rating set 2
'PCTRATE3'	Percent winding bus current of rating set 3
'PCTRATE4'	Percent winding bus current of rating set 4
'PCTRATE5'	Percent winding bus current of rating set 5
'PCTRATE6'	Percent winding bus current of rating set 6
'PCTRATE7'	Percent winding bus current of rating set 7
'PCTRATE8'	Percent winding bus current of rating set 8
'PCTRATE9'	Percent winding bus current of rating set 9
'PCTRATE10'	Percent winding bus current of rating set 10
'PCTRATE11'	Percent winding bus current of rating set 11
'PCTRATE12'	Percent winding bus current of rating set 12
'PCTMVARATE'	Percent winding bus MVA of default rating set
'PCTMVARATEA'	Percent winding bus MVA of rating set A
'PCTMVARATEB'	Percent winding bus MVA of rating set B
'PCTMVARATEC'	Percent winding bus MVA of rating set C
'PCTMVARATE1'	Percent winding bus MVA of rating set 1
'PCTMVARATE2'	Percent winding bus MVA of rating set 2
'PCTMVARATE3'	Percent winding bus MVA of rating set 3
'PCTMVARATE4'	Percent winding bus MVA of rating set 4
'PCTMVARATE5'	Percent winding bus MVA of rating set 5
'PCTMVARATE6'	Percent winding bus MVA of rating set 6
'PCTMVARATE7'	Percent winding bus MVA of rating set 7
'PCTMVARATE8'	Percent winding bus MVA of rating set 8
'PCTMVARATE9'	Percent winding bus MVA of rating set 9
'PCTMVARATE10'	Percent winding bus MVA of rating set 10
'PCTMVARATE11'	Percent winding bus MVA of rating set 11
'PCTMVARATE12'	Percent winding bus MVA of rating set 12
'PCTCRPRATE'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'PCTCRPRATE1'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 1

'PCTCRPRATE2'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 2
'PCTCRPRATE3'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 3
'PCTCRPRATE4'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 4
'PCTCRPRATE5'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 5
'PCTCRPRATE6'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 6
'PCTCRPRATE7'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 7
'PCTCRPRATE8'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 8
'PCTCRPRATE9'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 9
'PCTCRPRATE10'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 10
'PCTCRPRATE11'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 11
'PCTCRPRATE12'	Percent winding bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 12
'PCTCORPRATE'	Percent winding bus current or MVA loading (according to the transformer percent loading units program option setting) of default rating set
'PCTCORPRATEA'	Percent winding bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set A
'PCTCORPRATEB'	Percent winding bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set B
'PCTCORPRATEC'	Percent winding bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set C
'MAXPCTRATE'	Larger of percent winding/star point bus current of default rating set

'MAXPCTRATEA'	Larger of percent winding/star point bus current of rating set A
'MAXPCTRATEB'	Larger of percent winding/star point bus current of rating set B
'MAXPCTRATEC'	Larger of percent winding/star point bus current of rating set C
'MAXPCTRATE1'	Larger of percent winding/star point bus current of rating set 1
'MAXPCTRATE2'	Larger of percent winding/star point bus current of rating set 2
'MAXPCTRATE3'	Larger of percent winding/star point bus current of rating set 3
'MAXPCTRATE4'	Larger of percent winding/star point bus current of rating set 4
'MAXPCTRATE5'	Larger of percent winding/star point bus current of rating set 5
'MAXPCTRATE6'	Larger of percent winding/star point bus current of rating set 6
'MAXPCTRATE7'	Larger of percent winding/star point bus current of rating set 7
'MAXPCTRATE8'	Larger of percent winding/star point bus current of rating set 8
'MAXPCTRATE9'	Larger of percent winding/star point bus current of rating set 9
'MAXPCTRATE10'	Larger of percent winding/star point bus current of rating set 10
'MAXPCTRATE11'	Larger of percent winding/star point bus current of rating set 11
'MAXPCTRATE12'	Larger of percent winding/star point bus current of rating set 12
'MXPCTMVARAT'	Larger of percent winding/star point bus MVA of default rating set
'MXPCTMVARATA'	Larger of percent winding/star point bus MVA of rating set A
'MXPCTMVARATB'	Larger of percent winding/star point bus MVA of rating set B
'MXPCTMVARATC'	Larger of percent winding/star point bus MVA of rating set C
'MXPCTPRATE'	Larger of percent winding/star point bus MVA of default rating set
'MXPCTPRATE1'	Larger of percent winding/star point bus MVA of rating set 1
'MXPCTPRATE2'	Larger of percent winding/star point bus MVA of rating set 2
'MXPCTPRATE3'	Larger of percent winding/star point bus MVA of rating set 3

'MXPCTPRATE4'	Larger of percent winding/star point bus MVA of rating set 4
'MXPCTPRATE5'	Larger of percent winding/star point bus MVA of rating set 5
'MXPCTPRATE6'	Larger of percent winding/star point bus MVA of rating set 6
'MXPCTPRATE7'	Larger of percent winding/star point bus MVA of rating set 7
'MXPCTPRATE8'	Larger of percent winding/star point bus MVA of rating set 8
'MXPCTPRATE9'	Larger of percent winding/star point bus MVA of rating set 9
'MXPCTPRATE10'	Larger of percent winding/star point bus MVA of rating set 10
'MXPCTPRATE11'	Larger of percent winding/star point bus MVA of rating set 11
'MXPCTPRATE12'	Larger of percent winding/star point bus MVA of rating set 12
'MXPCTCRPRAT'	Larger of percent winding/star point bus current or MVA loading (according to the transformer percent loading units program option setting) of default rating set
'MXPCTCRPRATA'	Larger of percent winding/star point bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set A
'MXPCTCRPRATB'	Larger of percent winding/star point bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set B
'MXPCTCRPRATC'	Larger of percent winding/star point bus current or MVA loading (according to the transformer percent loading units program option setting) of rating set C
'MXPCTCRPRA'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of default rating set
'MXPCTCRPRA1'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 1
'MXPCTCRPRA2'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 2
'MXPCTCRPRA3'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 3

	appropriate percent loading units program option setting) of rating set 3
'MXPCTCRPRA4'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 4
'MXPCTCRPRA5'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 5
'MXPCTCRPRA6'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 6
'MXPCTCRPRA7'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 7
'MXPCTCRPRA8'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 8
'MXPCTCRPRA9'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 9
'MXPCTCRPRA10'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 10
'MXPCTCRPRA11'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 11
'MXPCTCRPRA12'	Larger of percent winding/star point bus current or MVA loading (according to the appropriate percent loading units program option setting) of rating set 12
'FRACT1'	First owner fraction
'FRACT2'	Second owner fraction
'FRACT3'	Third owner fraction
'FRACT4'	Fourth owner fraction
'RATE'	Rating from default rating set
'RATEA'	Rating from rating set A
'RATEB'	Rating from rating set B
'RATEC'	Rating from rating set C
'RATE1'	Rating from rating set 1

'RATE2'	Rating from rating set 2
'RATE3'	Rating from rating set 3
'RATE4'	Rating from rating set 4
'RATE5'	Rating from rating set 5
'RATE6'	Rating from rating set 6
'RATE7'	Rating from rating set 7
'RATE8'	Rating from rating set 8
'RATE9'	Rating from rating set 9
'RATE10'	Rating from rating set 10
'RATE11'	Rating from rating set 11
'RATE12'	Rating from rating set 12
'RATIO'	Winding tap ratio in pu
'RATIOCW'	Winding tap ratio in units governed by CW
'ANGLE'	Winding phase shift angle in degrees
'RMAX'	Winding ratio or angle upper limit (in pu if ratio)
'RMAXCW'	Winding ratio or angle upper limit (in units governed by CW if ratio)
'RMIN'	Winding ratio or angle lower limit (in pu if ratio)
'RMINCW'	Winding ratio or angle lower limit (in units governed by CW if ratio)
'VMAX'	Controlled quantity upper limit (in pu if voltage)
'VMAXKV'	Controlled quantity upper limit (in units governed by CW if voltage)
'VMIN'	Controlled quantity lower limit (in pu if voltage)
'VMINKV'	Controlled quantity lower limit (in units governed by CW if voltage)
'STEP'	Winding ratio or angle step width (in pu if ratio)
'STEPCW'	Winding ratio or angle step width (in units governed by CW if ratio)
'NOMV'	Winding nominal voltage in kv (0.0 for bus base voltage)
'SBASE'	Winding base MVA
'P'	Active power flow at winding bus end, in MW
'Q'	Reactive power flow at winding bus end, in Mvar
'MVA'	$\text{abs}(P+jQ)$ at winding bus end, in MVA
'MAXMVA'	$\text{abs}(P+jQ)$ at winding bus or star point bus end whichever is larger, in MVA
'PLOSS'	Active power losses, in MW
'QLOSS'	Reactive power losses, in Mvar

	'O_P'	Active power flow at winding bus end (units determined by power output options)
	'O_Q'	Reactive power flow at winding bus end (units determined by power output options)
	'O_MVA'	$\text{abs}(P+jQ)$ at winding bus end (units determined by power output options)
	'O_MAXMVA'	$\text{abs}(P+jQ)$ at winding bus or star point bus end whichever is larger (units determined by power output options)
	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_3WINDING_WINDINGS_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and ENTRY (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of RARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.15.6. AWNDTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the three-winding transformer winding data family (aWndInt, aWndReal, aWndCplx and aWndChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = awndtypes(string)
```

Fortran command syntax:

```
CALL GET_3WINDING_WINDINGS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the three-winding transformer winding data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the three-winding transformer winding data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the three-winding transformer winding data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the three-winding transformer winding data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.16. Two-Terminal dc Line Data

The two-terminal dc line data family of subsystem data retrieval APIs returns arrays of data for two-terminal dc lines in a specified subsystem.

One of the input items to each API allows the user to elect to retrieve data either for all subsystem two-terminal dc lines, for subsystem two-terminal dc lines that are tie branches, or for both subsystem and tie two-terminal dc lines. Another input item allows the user to elect to retrieve data for all such two-terminal dc lines, or to restrict the array entries to data for in-service two-terminal dc lines.

Data for subsystem two-terminal dc lines is returned from all APIs in the two-terminal dc line data family in dc line name alphabetical order.

12.16.1. A2TRMDCCHAR

Use this API to return an array of character values for subsystem two-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = a2trmdcchar(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_LINE_CHAR(SID, TIES, FLAG, NSTR, STRING, DIM, CARRAY,  
    BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem two-terminal dc lines only.
	TIES = 2	for subsystem tie two-terminal dc lines only.
	TIES = 3	for both interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service two-terminal dc lines.
	FLAG = 2	for all two-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	

Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line quantities desired (input; no default allowed).	
	'DCNAME'	dc line name (12 characters).
	'FROMNAME'	Rectifier bus name (12 characters).
	'FROMEXNAME'	Rectifier bus extended bus name (18 characters).
	'TONAME'	Inverter bus name (12 characters).
	'TOEXNAME'	Inverter bus extended bus name (18 characters).
	'METERNAME'	Metered bus name (12 characters).
	'METEREXNAME'	Metered bus extended bus name (18 characters).
	'NMETERNAME'	Non-metered bus name (12 characters).
	'NMETEREXNAME'	Non-metered bus extended bus name (18 characters).
	'IFRNAME'	Rectifier firing angle measuring bus name (12 characters).
	'IFREXNAME'	Rectifier firing angle measuring bus extended bus name (18 characters).
	'IFINAME'	Inverter firing angle measuring bus name (12 characters).
	'IFIEXNAME'	Inverter firing angle measuring bus extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of CARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.16.2. A2TRMDCCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the two-terminal dc line data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, brnchs = a2trmdccount(sid, ties, flag)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_LINE_COUNT(SID, TIES, FLAG, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem two-terminal dc lines only.
	TIES = 2	for subsystem tie two-terminal dc lines only.
	TIES = 3	for both interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service two-terminal dc lines.
	FLAG = 2	for all two-terminal dc lines.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BRNCHS returned
	IERR = 1	Working case is empty; BRNCHS returned as 0
	IERR = 2	Invalid SID value; BRNCHS returned as 0
	IERR = 3	Invalid TIES value; BRNCHS returned as 0
	IERR = 4	Invalid FLAG value; BRNCHS returned as 0

12.16.3. A2TRMDCCPLX

Use this API to return an array of complex values for subsystem two-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = a2trmdccplx(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_LINE_COMPLEX(SID, TIES, FLAG, NSTR, STRING, DIM,  
XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-terminal dc lines only. TIES = 2 for subsystem tie two-terminal dc lines only. TIES = 3 for both interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service two-terminal dc lines. FLAG = 2 for all two-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line quantities desired (input; no default allowed). 'PQAC_R' Apparent ac power flow into the dc line at the rectifier (in MW and Mvar) 'PQAC_I' Apparent ac power flow into the dc line at the inverter (in MW and Mvar) 'PQLOSS' ac power losses (in MW and Mvar) 'O_PQAC_R' Apparent ac power flow into the dc line at the rectifier (units determined by power output options) 'O_PQAC_I' Apparent ac power flow into the dc line at the inverter (units determined by power output options)

	'O_PQLOSS'	ac power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of XARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.16.4. A2TRMDCINT

Use this API to return an array of integer values for subsystem two-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = a2trmdcint(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_LINE_INTEGER(SID, TIES, FLAG, NSTR, STRING, DIM,  
IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-terminal dc lines only. TIES = 2 for subsystem tie two-terminal dc lines only. TIES = 3 for both interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service two-terminal dc lines. FLAG = 2 for all two-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line quantities desired (input; no default allowed). 'FROMNUMBER' Rectifier bus number 'TONUMBER' Inverter bus number 'METERNUMBER' Metered end bus number 'NMETERNUMBER' Non-metered end bus number 'IFRNUMBER' Rectifier firing angle measuring bus number 'IFINUMBER' Inverter extinction angle measuring bus number 'NDR' Rectifier firing angle measuring node number 'NDI' Inverter extinction angle measuring node number

	'MDC'	Control mode
	'NBR'	Rectifier number of bridges in series
	'NBI'	Inverter number of bridges in series
	'ANSTT_R'	Rectifier angle limit code: -1 (at or below low limit), 0 (in range), or 1 (at or above high limit)
	'ANSTT_I'	Inverter angle limit code: -1 (at or below low limit), 0 (in range), or 1 (at or above high limit)
	'TPSTT_R'	Rectifier tap ratio limit code: -1 (at or below low limit), 0 (in range), 1 (at or above high limit) or -2 (locked)
	'TPSTT_I'	Inverter tap ratio limit code: -1 (at or below low limit), 0 (in range), 1 (at or above high limit) or -2 (locked)
	'CCCITMX'	Iteration limit for capacitor commutated converter solution
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of IARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.16.5. A2TRMDCREAL

Use this API to return an array of real values for subsystem two-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = a2trmdcreal(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_LINE_REAL(SID, TIES, FLAG, NSTR, STRING, DIM, RARRAY,  
    BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem two-terminal dc lines only. TIES = 2 for subsystem tie two-terminal dc lines only. TIES = 3 for both interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service two-terminal dc lines. FLAG = 2 for all two-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line quantities desired (input; no default allowed). 'DCCUR' dc line current in amps 'RDC' dc line resistance in ohms 'SETVAL' Desired current (in amps) or power (in MW) demand 'VSCHD' Scheduled compounded dc voltage in kV 'VCMOD' Mode switch dc voltage in kV 'RCOMP' Compounding resistance in ohms 'DELT' Margin in pu of desired dc power or current 'DCVMIN' Minimum compounded dc voltage in kV 'ACAMPS_R' ac current in amps at the rectifier 'ACAMPS_I' ac current in amps at the inverter

'PUCUR_R'	ac current in pu at the rectifier
'PUCUR_I'	ac current in pu at the inverter
'KVDC_R'	Rectifier dc voltage in kV
'KVDC_I'	Inverter dc voltage in kV
'ANGLE_R'	Rectifier converter angle in degrees
'ANGLE_I'	Inverter converter angle in degrees
'ANGMIN_R'	Rectifier minimum steady-state converter angle in degrees
'ANGMIN_I'	Inverter minimum steady-state converter angle in degrees
'ANGMAX_R'	Rectifier nominal maximum converter angle in degrees
'ANGMAX_I'	Inverter nominal maximum converter angle in degrees
'RC_R'	Rectifier commutating transformer resistance per bridge in ohms
'RC_I'	Inverter commutating transformer resistance per bridge in ohms
'XC_R'	Rectifier commutating transformer reactance per bridge in ohms
'XC_I'	Inverter commutating transformer reactance per bridge in ohms
'EBASE_R'	Rectifier primary base ac voltage in kV
'EBASE_I'	Inverter primary base ac voltage in kV
'TR_R'	Rectifier transformer ratio in pu
'TR_I'	Inverter transformer ratio in pu
'TAP_R'	Rectifier tap setting in pu
'TAP_I'	Inverter tap setting in pu
'TPMX_R'	Rectifier maximum tap setting in pu
'TPMX_I'	Inverter maximum tap setting in pu
'TPMN_R'	Rectifier minimum tap setting in pu
'TPMN_I'	Inverter minimum tap setting in pu
'STP_R'	Rectifier tap step in pu
'STP_I'	Inverter tap step in pu
'XCAP_R'	Rectifier commutating capacitor reactance magnitude per bridge in pu
'XCAP_I'	Inverter commutating capacitor reactance magnitude per bridge in pu
'CCCACC'	Acceleration factor for capacitor commutated converter solution
'PAC_R'	Apparent active power flow into the dc line at the rectifier in MW
'PAC_I'	Apparent active power flow into the dc line at the inverter in MW

	'QAC_R'	Apparent reactive power flow into the dc line at the rectifier in Mvar
	'QAC_I'	Apparent reactive power flow into the dc line at the inverter in Mvar
	'MVA_R'	Apparent ac power flow into the dc line at the rectifier in MVA
	'MVA_I'	Apparent ac power flow into the dc line at the inverter in MVA
	'PLOSS'	Active power losses in MW
	'QLOSS'	Reactive power losses in Mvar
	'O_PAC_R'	Apparent active power flow into the dc line at the rectifier (units determined by power output options)
	'O_PAC_I'	Apparent active power flow into the dc line at the inverter (units determined by power output options)
	'O_QAC_R'	Apparent reactive power flow into the dc line at the rectifier (units determined by power output options)
	'O_QAC_I'	Apparent reactive power flow into the dc line at the inverter (units determined by power output options)
	'O_MVA_R'	Apparent ac power flow into the dc line at the rectifier (units determined by power output options)
	'O_MVA_I'	Apparent ac power flow into the dc line at the inverter (units determined by power output options)
	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_TWO_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty

IERR = 2	Invalid SID value
IERR = 3	Invalid TIES value
IERR = 4	Invalid FLAG value
IERR = 5	Invalid NSTR value
IERR = 6	DIM, and hence the size of RARRAY, is not large enough
IERR = 7	Invalid STRING value

12.16.6. A2TRMDCTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the two-terminal dc line data family (a2TrmDcInt, a2TrmDcReal, a2TrmDcCplx and a2TrmDcChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = a2trmdctypes(string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_LINE_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the two-terminal dc line data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.17. Two-Terminal dc Line Converter Data

The two-terminal dc line converter data family of subsystem data retrieval APIs returns arrays of data for two-terminal dc line converters in a specified subsystem.

One of the input items to each API allows the user to elect to retrieve data either for all subsystem two-terminal dc line converters, for subsystem two-terminal dc line converters of two-terminal dc lines that are tie branches, or for both subsystem and tie two-terminal dc line converters. Another input item allows the user to elect to retrieve data for all such two-terminal dc line converters, or to restrict the array entries to data for in-service two-terminal dc lines.

Data for subsystem converter buses is returned from all APIs in the two-terminal dc line converter data family in the same order. One of the input items to each API allows the user to elect that converter buses be ordered either in dc line name order with all converter buses of each two-terminal dc line grouped together, or in numerical or alphabetical order by converter bus, according to the bus output option setting in effect at the time the API is referenced.

12.17.1. A2TRMDCCONVCHAR

Use this API to return an array of character values for subsystem two-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = a2trmdcconvchar(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_CONV_CHAR(SID, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
    CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem two-terminal dc lines only.
	TIES = 2	for the subsystem bus end of tie two-terminal dc lines only.
	TIES = 3	for the non-subsystem bus end of tie two-terminal dc lines only.
	TIES = 4	for each end of tie two-terminal dc lines only.
	TIES = 5	for each end of interior subsystem two-terminal dc lines and the subsystem bus end of tie two-terminal dc lines.

	TIES = 6	for each end of interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service two-terminal dc lines.
	FLAG = 2	for all two-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for converter bus order.
	ENTRY = 2	for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line converter quantities desired (input; no default allowed).	
	'DCNAME'	dc line name (12 characters).
	'FROMNAME'	From bus name (12 characters).
	'FROMEXNAME'	From bus extended bus name (18 characters).
	'TONAME'	To bus name (12 characters).
	'TOEXNAME'	To bus extended bus name (18 characters).
	'METERNAME'	Metered bus name (12 characters).
	'METEREXNAME'	Metered bus extended bus name (18 characters).
	'NMETERNAME'	Non-metered bus name (12 characters).
	'NMETEREXNAME'	Non-metered bus extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value

IERR = 7

DIM, and hence the size of CARRAY, is not
large enough

IERR = 8

Invalid STRING value

12.17.2. A2TRMDCCONVCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the two-terminal dc line converter data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, buses = a2trmdccconvcount(sid, ties, flag)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_CONV_COUNT(SID, TIES, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem two-terminal dc lines only.
	TIES = 2	for the subsystem bus end of tie two-terminal dc lines only.
	TIES = 3	for the non-subsystem bus end of tie two-terminal dc lines only.
	TIES = 4	for each end of tie two-terminal dc lines only.
	TIES = 5	for each end of interior subsystem two-terminal dc lines and the subsystem bus end of tie two-terminal dc lines.
	TIES = 6	for each end of interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service two-terminal dc lines.
	FLAG = 2	for all two-terminal dc lines.
Integer BUSES	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid TIES value; BUSES returned as 0

IERR = 4

Invalid FLAG value; BUSES returned as 0

12.17.3. A2TRMDCCONVCPLX

Use this API to return an array of complex values for subsystem two-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = a2trmdcconvcplx(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_CONV_COMPLEX(SID, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem two-terminal dc lines only. TIES = 2 for the subsystem bus end of tie two-terminal dc lines only. TIES = 3 for the non-subsystem bus end of tie two-terminal dc lines only. TIES = 4 for each end of tie two-terminal dc lines only. TIES = 5 for each end of interior subsystem two-terminal dc lines and the subsystem bus end of tie two-terminal dc lines. TIES = 6 for each end of interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc line converters to include (input; 1 by default). FLAG = 1 for only in-service two-terminal dc lines. FLAG = 2 for all two-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for converter bus order. ENTRY = 2 for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line converter quantities desired (input; no default allowed).

	'PQAC'	Apparent ac power flow into the dc line at the from bus (in MW and Mvar)
	'PQLOSS'	ac power losses (in MW and Mvar)
	'O_PQAC'	Apparent ac power flow into the dc line at the from bus (units determined by power output options)
	'O_PQLOSS'	ac power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of XARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.17.4. A2TRMDCCONVINT

Use this API to return an array of integer values for subsystem two-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = a2trmdcconvint(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_CONV_INTEGER(SID, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem two-terminal dc lines only. TIES = 2 for the subsystem bus end of tie two-terminal dc lines only. TIES = 3 for the non-subsystem bus end of tie two-terminal dc lines only. TIES = 4 for each end of tie two-terminal dc lines only. TIES = 5 for each end of interior subsystem two-terminal dc lines and the subsystem bus end of tie two-terminal dc lines. TIES = 6 for each end of interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc line converters to include (input; 1 by default). FLAG = 1 for only in-service two-terminal dc lines. FLAG = 2 for all two-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for converter bus order. ENTRY = 2 for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line converter quantities desired (input; no default allowed).

	'FROMNUMBER'	From bus number
	'TONUMBER'	To bus number
	'METERNUMBER'	Metered end bus number
	'NMETERNUMBER'	Non-metered end bus number
	'CONVERTERTYP'	1 if from bus is the rectifier 2 if the inverter
	'MDC'	Control mode
	'ANSTT'	From bus converter angle limit code: -1 (at or below low limit), 0 (in range), or 1 (at or above high limit)
	'TPSTT'	From bus converter tap ratio limit code: -1 (at or below low limit), 0 (in range), 1 (at or above high limit) or -2 (locked)
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of IARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.17.5. A2TRMDCCONVREAL

Use this API to return an array of real values for subsystem two-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = a2trmdcconvreal(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_CONV_REAL(SID, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
  RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of two-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem two-terminal dc lines only.
	TIES = 2	for the subsystem bus end of tie two-terminal dc lines only.
	TIES = 3	for the non-subsystem bus end of tie two-terminal dc lines only.
	TIES = 4	for each end of tie two-terminal dc lines only.
	TIES = 5	for each end of interior subsystem two-terminal dc lines and the subsystem bus end of tie two-terminal dc lines.
	TIES = 6	for each end of interior subsystem two-terminal dc lines and tie two-terminal dc lines.
Integer FLAG	a flag indicating which subsystem two-terminal dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service two-terminal dc lines.
	FLAG = 2	for all two-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for converter bus order.
	ENTRY = 2	for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the two-terminal dc line converter quantities desired (input; no default allowed).	
	'DCCUR'	dc line current in amps

	'ACAMPS'	ac current in amps at the from bus
	'PUCUR'	ac current in pu at the from bus
	'KVDC'	From bus dc voltage in kV
	'ANGLE'	From bus converter angle in degrees
	'TAP'	From bus tap setting in pu
	'PAC'	Apparent active power flow into the dc line at the from bus
	'QAC'	Apparent reactive power flow into the dc line at the from bus
	'MVA'	Apparent ac power flow into the dc line at the from bus
	'PLOSS'	Active power losses
	'QLOSS'	Reactive power losses
	'O_PAC'	Apparent active power flow into the dc line at the from bus (units determined by power output options)
	'O_QAC'	Apparent reactive power flow into the dc line at the from bus (units determined by power output options)
	'O_MVA'	Apparent ac power flow into the dc line at the from bus (units determined by power output options)
	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_TWO_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value

IERR = 7	DIM, and hence the size of RARRAY, is not large enough
IERR = 8	Invalid STRING value

12.17.6. A2TRMDCCONVTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the two-terminal dc line converter data family (a2TrmDcConvInt, a2TrmDcConvReal, a2TrmDcConvCplx and a2TrmDcConvChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = a2trmdcconvtypes(string)
```

Fortran command syntax:

```
CALL GET_TWO_TERM_DC_CONV_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the two-terminal dc line converter data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line converter data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line converter data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line converter data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.18. Multi-Terminal dc Line Data

The multi-terminal dc line data family of subsystem data retrieval APIs returns arrays of data for multi-terminal dc lines in a specified subsystem.

One of the input items to each API allows the user to elect to retrieve data for either all subsystem multi-terminal dc lines, for subsystem multi-terminal dc lines that are tie branches, or for both subsystem and tie multi-terminal dc lines. Another input item allows the user to elect to retrieve data for all such multi-terminal dc lines, or to restrict the array entries to data for in-service multi-terminal dc lines.

Data for subsystem multi-terminal dc lines is returned from all APIs in the multi-terminal dc line data family in dc line name alphabetical order.

12.18.1. AMULTITRMDCCCHAR

Use this API to return an array of character values for subsystem multi-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = amultitrmdccchar(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_LINE_CHAR(SID, TIES, FLAG, NSTR, STRING, DIM,  
CARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem multi-terminal dc lines only.
	TIES = 2	for subsystem tie multi-terminal dc lines only.
	TIES = 3	for both interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service multi-terminal dc lines.
	FLAG = 2	for all multi-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	

Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line quantities desired (input; no default allowed).	
	'DCNAME'	dc line name (12 characters).
	'VCNPOSNAME'	Positive pole voltage controlling converter bus name (12 characters).
	'VCNPOSEXNAME'	Positive pole voltage controlling converter bus extended bus name (18 characters).
	'VCNNEGNAME'	Negative pole voltage controlling converter bus name (12 characters).
	'VCNNEGEXNAME'	Negative pole voltage controlling converter bus extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of CARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.18.2. AMULTITRMDCCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the multi-terminal dc line data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, brnchs = amultitrmdccount(sid, ties, flag)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_LINE_COUNT(SID, TIES, FLAG, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem multi-terminal dc lines only. TIES = 2 for subsystem tie multi-terminal dc lines only. TIES = 3 for both interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error, BRNCHS returned IERR = 1 Working case is empty; BRNCHS returned as 0 IERR = 2 Invalid SID value; BRNCHS returned as 0 IERR = 3 Invalid TIES value; BRNCHS returned as 0 IERR = 4 Invalid FLAG value; BRNCHS returned as 0

12.18.3. AMULTITRMDCCPLX

Use this API to return an array of complex values for subsystem multi-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = amultitrmdccplx(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_LINE_COMPLEX(SID, TIES, FLAG, NSTR, STRING, DIM,  
XARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem multi-terminal dc lines only. TIES = 2 for subsystem tie multi-terminal dc lines only. TIES = 3 for both interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line quantities desired (input; no default allowed). 'PQLOSS' ac power losses (in MW and Mvar) 'O_PQLOSS' ac power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).

Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of XARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.18.4. AMULTITRMDCINT

Use this API to return an array of integer values for subsystem multi-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = amultitrmdcint(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_LINE_INTEGER(SID, TIES, FLAG, NSTR, STRING, DIM,  
IARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem multi-terminal dc lines only. TIES = 2 for subsystem tie multi-terminal dc lines only. TIES = 3 for both interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line quantities desired (input; no default allowed). 'CONVERTERS' Number of converters 'DCBUSES' Number of dc buses 'DCLINKS' Number of dc links 'VCNPOSNUMBER' Positive pole voltage controlling converter bus number 'VCNNEGNUMBER' Negative pole voltage controlling converter bus number 'MDC' Control mode
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the

	same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of IARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.18.5. AMULTITRMDCREAL

Use this API to return an array of real values for subsystem multi-terminal dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = amultitrmdcreal(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_LINE_REAL(SID, TIES, FLAG, NSTR, STRING, DIM,  
  RARRAY, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem multi-terminal dc lines only. TIES = 2 for subsystem tie multi-terminal dc lines only. TIES = 3 for both interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc lines to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line quantities desired (input; no default allowed). 'VCMOD' Mode switch dc voltage, in kV 'PLOSS' Active power losses, in MW 'QLOSS' Reactive power losses, in Mvar 'O_PLOSS' Active power losses (units determined by power output options) 'O_QLOSS' Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the

	same values specified for SID, TIES and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_MULTI_TERM_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of RARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.18.6. AMULTITRMDCTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the multi-terminal dc line data family (aMultiTrmDcInt, aMultiTrmDcReal, aMultiTrmDcCplx and aMultiTrmDcChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = amultitrmdctypes(string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_LINE_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the multi-terminal dc line data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the multi-terminal dc line data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the multi-terminal dc line data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the multi-terminal dc line data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.19. Multi-Terminal dc Line Converter Data

The multi-terminal dc line converter data family of subsystem data retrieval APIs returns arrays of data for multi-terminal dc line converters in a specified subsystem.

One of the input items to each API allows the user to elect to retrieve data either for all subsystem multi-terminal dc line converters, for subsystem multi-terminal dc line converters of multi-terminal dc lines that are tie branches, or for both subsystem and tie multi-terminal dc line converters. Another input item allows the user to elect to retrieve data for all such multi-terminal dc line converters, or to restrict the array entries to data for in-service multi-terminal dc lines.

Data for subsystem converter buses is returned from all APIs in the multi-terminal dc line converter data family in the same order. One of the input items to each API allows the user to elect that converter buses be ordered either in dc line name order with all converter buses of each multi-terminal dc line grouped together, or in numerical or alphabetical order by converter bus, according to the bus output option setting in effect at the time the API is referenced.

12.19.1. AMULTITRMDCCONVCHAR

Use this API to return an array of character values for subsystem multi-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = amultitrmdccconvchar(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_CONV_CHAR(SID, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem multi-terminal dc lines only.
	TIES = 2	for the subsystem bus ends of tie multi-terminal dc lines only.
	TIES = 3	for the non-subsystem bus ends of tie multi-terminal dc lines only.
	TIES = 4	for each end of tie multi-terminal dc lines only.

	TIES = 5	for each end of interior subsystem multi-terminal dc lines and the subsystem bus ends of tie multi-terminal dc lines.
	TIES = 6	for each end of interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service multi-terminal dc lines.
	FLAG = 2	for all multi-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for converter bus order.
	ENTRY = 2	for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line converter quantities desired (input; no default allowed).	
	'DCNAME'	dc line name (12 characters).
	'NAME'	Converter bus name (12 characters).
	'EXNAME'	Converter bus extended bus name (18 characters).
	'DCBUSNAME'	Name of the dc bus connected to this converter bus (12 characters).
	'DCBUS2NAME'	Name of the optional second dc bus connected to this converter bus (12 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of CARRAY, is not large enough

IERR = 8

Invalid STRING value

12.19.2. AMULTITRMDCCONVCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the multi-terminal dc line converter data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, buses = amultitrmdccconvcount(sid, ties, flag)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_CONV_COUNT(SID, TIES, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem multi-terminal dc lines only. TIES = 2 for the subsystem bus ends of tie multi-terminal dc lines only. TIES = 3 for the non-subsystem bus ends of tie multi-terminal dc lines only. TIES = 4 for each end of tie multi-terminal dc lines only. TIES = 5 for each end of interior subsystem multi-terminal dc lines and the subsystem bus ends of tie multi-terminal dc lines. TIES = 6 for each end of interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc line converters to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer BUSES	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error, BUSES returned IERR = 1 Working case is empty; BUSES returned as 0 IERR = 2 Invalid SID value; BUSES returned as 0 IERR = 3 Invalid TIES value; BUSES returned as 0

IERR = 4

Invalid FLAG value; BUSES returned as 0

12.19.3. AMULTITRMDCCONVCPLX

Use this API to return an array of complex values for subsystem multi-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = amultitrmdccconvcplx(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_CONV_COMPLEX(SID, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem multi-terminal dc lines only. TIES = 2 for the subsystem bus ends of tie multi-terminal dc lines only. TIES = 3 for the non-subsystem bus ends of tie multi-terminal dc lines only. TIES = 4 for each end of tie multi-terminal dc lines only. TIES = 5 for each end of interior subsystem multi-terminal dc lines and the subsystem bus ends of tie multi-terminal dc lines. TIES = 6 for each end of interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc line converters to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for converter bus order. ENTRY = 2 for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line converter quantities desired (input; no default allowed).

	'PQAC'	Apparent ac power flow into the dc line at the from bus (in MW and Mvar)
	'PQLOSS'	Total dc line ac power losses (in MW and Mvar)
	'O_PQAC'	Apparent ac power flow into the dc line at the from bus (units determined by power output options)
	'O_PQLOSS'	Total dc line ac power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of XARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.19.4. AMULTITRMDCCONVINT

Use this API to return an array of integer values for subsystem multi-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = amultitrmdcconvint(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_CONV_INTEGER(SID, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem multi-terminal dc lines only. TIES = 2 for the subsystem bus ends of tie multi-terminal dc lines only. TIES = 3 for the non-subsystem bus ends of tie multi-terminal dc lines only. TIES = 4 for each end of tie multi-terminal dc lines only. TIES = 5 for each end of interior subsystem multi-terminal dc lines and the subsystem bus ends of tie multi-terminal dc lines. TIES = 6 for each end of interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc line converters to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for converter bus order. ENTRY = 2 for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line converter quantities desired (input; no default allowed).

	'NUMBER'	Converter bus number
	'CONVERTERTYP'	1 for a voltage controlling converter, 3 for a rectifier, 4 for an inverter
	'POLE'	1 for a positive pole converter, -1 for a negative pole converter
	'DCBUSNUMBER'	Number of the dc bus connected to this converter bus
	'DCBUS2NUMBER'	Number of the optional second dc bus connected to this converter bus
	'NBRIDGES'	Number of bridges in series
	'ANSTT'	Converter angle limit code: -1 (at or below low limit), 0 (in range), or 1 (at or above high limit)
	'TPSTT'	Converter tap ratio limit code: -1 (at or below low limit), 0 (in range), 1 (at or above high limit), or -2 (locked)
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of IARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.19.5. AMULTITRMDCCONVREAL

Use this API to return an array of real values for subsystem multi-terminal dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = amultitrmdcconvreal(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_CONV_REAL(SID, TIES, FLAG, ENTRY, NSTR, STRING,  
DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of multi-terminal dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem multi-terminal dc lines only. TIES = 2 for the subsystem bus ends of tie multi-terminal dc lines only. TIES = 3 for the non-subsystem bus ends of tie multi-terminal dc lines only. TIES = 4 for each end of tie multi-terminal dc lines only. TIES = 5 for each end of interior subsystem multi-terminal dc lines and the subsystem bus ends of tie multi-terminal dc lines. TIES = 6 for each end of interior subsystem multi-terminal dc lines and tie multi-terminal dc lines.
Integer FLAG	a flag indicating which subsystem multi-terminal dc line converters to include (input; 1 by default). FLAG = 1 for only in-service multi-terminal dc lines. FLAG = 2 for all multi-terminal dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for converter bus order. ENTRY = 2 for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the multi-terminal dc line converter quantities desired (input; no default allowed).

'DCCUR'	Converter dc current in amps
'SETVAL'	Voltage (kV) current (amps) or power (MW) setpoint
'ACAMPS'	ac current in amps at the converter bus
'PUCUR'	ac current in pu at the converter bus
'KVDC'	Converter bus dc voltage in kV
'ANGLE'	Converter angle in degrees
'ANGMIN'	Minimum steady-state converter angle in degrees
'ANGMAX'	Nominal maximum converter angle in degrees
'TAP'	Converter bus tap setting in pu
'TPMX'	Maximum tap setting in pu
'TPMN'	Minimum tap setting in pu
'STP'	Tap step in pu
'TR'	Transformer ratio in pu
'RC'	Commutating transformer resistance per bridge in ohms
'XC'	Commutating transformer reactance per bridge in ohms
'EBASE'	Primary base ac voltage in kV
'DELT'	Rectifier margin in pu of desired dc power or current
'DCPF'	Converter participation factor
'PAC'	Apparent active power flow into the dc line at the converter bus in MW
'QAC'	Apparent reactive power flow into the dc line at the converter bus in Mvar
'MVA'	Apparent ac power flow into the dc line at the converter bus in MVA
'PLOSS'	Total dc line active power losses in MW
'QLOSS'	Total dc line reactive power losses in Mvar
'O_PAC'	Apparent active power flow into the dc line at the converter bus (units determined by power output options)
'O_QAC'	Apparent reactive power flow into the dc line at the converter bus (units determined by power output options)
'O_MVA'	Apparent ac power flow into the dc line at the converter bus (units determined by power output options)
'O_PLOSS'	Total dc line active power losses (units determined by power output options)
'O_QLOSS'	Total dc line reactive power losses (units determined by power output options)

Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_MULTI_TERM_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of RARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.19.6. AMULTITRMDCCONVTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the two-terminal dc line converter data family (aMultiTrmDcConvInt, aMultiTrmDcConvReal, aMultiTrmDcConvCplx and aMultiTrmDcConvChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = amultitrmdcconvtypes(string)
```

Fortran command syntax:

```
CALL GET_MULTI_TERM_DC_CONV_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the two-terminal dc line converter data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line converter data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line converter data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the two-terminal dc line converter data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.20. VSC dc Line Data

The VSC dc line data family of subsystem data retrieval APIs returns arrays of data for VSC dc lines in a specified subsystem.

VSC dc lines, for subsystem VSC dc lines that are tie branches, or for both subsystem and tie VSC dc lines. Another input item allows the user to elect to retrieve data for all such VSC dc lines, to restrict the array entries to data for in-service VSC dc lines with one or both converters in-service, or to restrict the array entries to data for in-service VSC dc lines with both converters in-service.

Data for subsystem VSC dc lines is returned from all APIs in the VSC dc line data family in dc line name alphabetical order.

12.20.1. AVSCDCCHAR

Use this API to return an array of character values for subsystem VSC dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = avscdcchar(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_LINE_CHAR(SID, TIES, FLAG, NSTR, STRING, DIM, CARRAY,  
    BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem VSC dc lines only.
	TIES = 2	for subsystem tie VSC dc lines only.
	TIES = 3	for both interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service VSC dc lines with one or both converters in-service.
	FLAG = 2	for only in-service VSC dc lines with both converters in-service.
	FLAG = 3	for all VSC dc lines.

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).																
Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line quantities desired (input; no default allowed). <table> <tr> <td>'VSCNAME'</td><td>dc line name (12 characters).</td></tr> <tr> <td>'FROMNAME'</td><td>Converter 1 bus name (12 characters).</td></tr> <tr> <td>'FROMEXNAME'</td><td>Converter 1 bus extended bus name (18 characters).</td></tr> <tr> <td>'TONAME'</td><td>Converter 2 bus name (12 characters).</td></tr> <tr> <td>'TOEXNAME'</td><td>Converter 2 bus extended bus name (18 characters).</td></tr> </table>	'VSCNAME'	dc line name (12 characters).	'FROMNAME'	Converter 1 bus name (12 characters).	'FROMEXNAME'	Converter 1 bus extended bus name (18 characters).	'TONAME'	Converter 2 bus name (12 characters).	'TOEXNAME'	Converter 2 bus extended bus name (18 characters).						
'VSCNAME'	dc line name (12 characters).																
'FROMNAME'	Converter 1 bus name (12 characters).																
'FROMEXNAME'	Converter 1 bus extended bus name (18 characters).																
'TONAME'	Converter 2 bus name (12 characters).																
'TOEXNAME'	Converter 2 bus extended bus name (18 characters).																
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).																
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).																
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).																
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = 1</td><td>Working case is empty</td></tr> <tr> <td>IERR = 2</td><td>Invalid SID value</td></tr> <tr> <td>IERR = 3</td><td>Invalid TIES value</td></tr> <tr> <td>IERR = 4</td><td>Invalid FLAG value</td></tr> <tr> <td>IERR = 5</td><td>Invalid NSTR value</td></tr> <tr> <td>IERR = 6</td><td>DIM, and hence the size of CARRAY, is not large enough</td></tr> <tr> <td>IERR = 7</td><td>Invalid STRING value</td></tr> </table>	IERR = 0	No error	IERR = 1	Working case is empty	IERR = 2	Invalid SID value	IERR = 3	Invalid TIES value	IERR = 4	Invalid FLAG value	IERR = 5	Invalid NSTR value	IERR = 6	DIM, and hence the size of CARRAY, is not large enough	IERR = 7	Invalid STRING value
IERR = 0	No error																
IERR = 1	Working case is empty																
IERR = 2	Invalid SID value																
IERR = 3	Invalid TIES value																
IERR = 4	Invalid FLAG value																
IERR = 5	Invalid NSTR value																
IERR = 6	DIM, and hence the size of CARRAY, is not large enough																
IERR = 7	Invalid STRING value																

12.20.2. AVSCDCCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the VSC dc line data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, brnchs = avscdccount(sid, ties, flag)
```

Fortran command syntax:

```
CALL GET_VSC_DC_LINE_COUNT(SID, TIES, FLAG, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem VSC dc lines only.
	TIES = 2	for subsystem tie VSC dc lines only.
	TIES = 3	for both interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service VSC dc lines with one or both converters in-service.
	FLAG = 2	for only in-service VSC dc lines with both converters in-service.
	FLAG = 3	for all VSC dc lines.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BRNCHS returned
	IERR = 1	Working case is empty; BRNCHS returned as 0
	IERR = 2	Invalid SID value; BRNCHS returned as 0
	IERR = 3	Invalid TIES value; BRNCHS returned as 0
	IERR = 4	Invalid FLAG value; BRNCHS returned as 0

12.20.3. AVSCDCCPLX

Use this API to return an array of complex values for subsystem VSC dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = avscdccplx(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_LINE_COMPLEX(SID, TIES, FLAG, NSTR, STRING, DIM, XARRAY,  
    BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem VSC dc lines only.
	TIES = 2	for subsystem tie VSC dc lines only.
	TIES = 3	for both interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service VSC dc lines with one or both converters in-service.
	FLAG = 2	for only in-service VSC dc lines with both converters in-service.
	FLAG = 3	for all VSC dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line quantities desired (input; no default allowed).	
	'PQLOSS'	ac power losses (in MW and Mvar)
	'O_PQLOSS'	ac power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	

Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of XARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.20.4. AVSCDCINT

Use this API to return an array of integer values for subsystem VSC dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = avscdcint(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_LINE_INTEGER(SID, TIES, FLAG, NSTR, STRING, DIM, IARRAY,  
    BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem VSC dc lines only.
	TIES = 2	for subsystem tie VSC dc lines only.
	TIES = 3	for both interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc lines to include (input; 1 by default).	
	FLAG = 1	for only in-service VSC dc lines with one or both converters in-service.
	FLAG = 2	for only in-service VSC dc lines with both converters in-service.
	FLAG = 3	for all VSC dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line quantities desired (input; no default allowed).	
	'FROMNUMBER'	Converter 1 bus number
	'TONUMBER'	Converter 2 bus number
	'MDC'	Control mode
	'OWNERS'	Number of owners
	'OWN1'	First owner
	'OWN2'	Second owner
	'OWN3'	Third owner
	'OWN4'	Fourth owner

Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of IARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.20.5. AVSCDCREAL

Use this API to return an array of real values for subsystem VSC dc lines.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = avscdcreal(sid, ties, flag, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_LINE_REAL(SID, TIES, FLAG, NSTR, STRING, DIM, RARRAY,  
    BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem VSC dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem VSC dc lines only. TIES = 2 for subsystem tie VSC dc lines only. TIES = 3 for both interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc lines to include (input; 1 by default). FLAG = 1 for only in-service VSC dc lines with one or both converters in-service. FLAG = 2 for only in-service VSC dc lines with both converters in-service. FLAG = 3 for all VSC dc lines.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line quantities desired (input; no default allowed). 'DCCUR' dc line current in amps 'RDC' dc line resistance in ohms 'FRACT1' First owner fraction 'FRACT2' Second owner fraction 'FRACT3' Third owner fraction 'FRACT4' Fourth owner fraction 'PLOSS' Active power losses, in MW 'QLOSS' Reactive power losses, in Mvar

	'O_PLOSS'	Active power losses (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_VSC_DC_LINE_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid NSTR value
	IERR = 6	DIM, and hence the size of RARRAY, is not large enough
	IERR = 7	Invalid STRING value

12.20.6. AVSCDCTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the VSC dc line data family (aVscDcInt, aVscDcReal, aVscDcCplx and aVscDcChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = avscdctypes(string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_LINE_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the VSC dc line data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the VSC dc line data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the VSC dc line data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the VSC dc line data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.21. VSC dc Line Converter Data

The VSC dc line converter data family of subsystem data retrieval APIs returns arrays of data for VSC dc line converters in a specified subsystem.

One of the input items to each API allows the user to elect to retrieve data either for all subsystem VSC dc line converters, for subsystem VSC dc line converters of VSC dc lines that are tie branches, or for both subsystem and tie VSC dc line converters. Another input item allows the user to elect to retrieve data for all such VSC dc line converters, to restrict the array entries to data for all converters of in-service VSC dc lines, or to restrict the array entries to data for in-service converters of in-service VSC dc lines.

Data for subsystem converter buses is returned from all APIs in the VSC dc line converter data family in the same order. One of the input items to each API allows the user to elect that converter buses be ordered either in dc line name order with all converter buses of each VSC dc line grouped together, or in numerical or alphabetical order by converter bus, according to the bus output option setting in effect at the time the API is referenced.

12.21.1. AVSCDCCONVCHAR

Use this API to return an array of character values for subsystem VSC dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = avscdcconvchar(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_CONV_CHAR(SID, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
    CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem VSC dc lines only.
	TIES = 2	for the subsystem bus end of tie VSC dc lines only.
	TIES = 3	for the non-subsystem bus end of tie VSC dc lines only.
	TIES = 4	for each end of tie VSC dc lines only.
	TIES = 5	for each end of interior subsystem VSC dc lines and the subsystem bus end of tie VSC dc lines.

	TIES = 6	for each end of interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service converters of in-service VSC dc lines.
	FLAG = 2	for all converters of in-service VSC dc lines.
	FLAG = 3	for all converters of all VSC dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for converter bus order.
	ENTRY = 2	for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line converter quantities desired (input; no default allowed).	
	'VSCNAME'	dc line name (12 characters).
	'FROMNAME'	From bus name (12 characters).
	'FROMEXNAME'	From bus extended bus name (18 characters).
	'TONAME'	To bus name (12 characters).
	'TOEXNAME'	To bus extended bus name (18 characters).
	'IREGNAME'	Bus name of the remote voltage controlled bus (12 characters).
	'IREGEXNAME'	Extended bus name of the remote voltage controlled bus (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of CARRAY, is not large enough

IERR = 8

Invalid STRING value

12.21.2. AVSCDCCONVCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the VSC dc line converter data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, buses = avscdcconvcount(sid, ties, flag)
```

Fortran command syntax:

```
CALL GET_VSC_DC_CONV_COUNT(SID, TIES, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of VSC dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem VSC dc lines only. TIES = 2 for the subsystem bus end of tie VSC dc lines only. TIES = 3 for the non-subsystem bus end of tie VSC dc lines only. TIES = 4 for each end of tie VSC dc lines only. TIES = 5 for each end of interior subsystem VSC dc lines and the subsystem bus end of tie VSC dc lines. TIES = 6 for each end of interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc line converters to include (input; 1 by default). FLAG = 1 for only in-service converters of in-service VSC dc lines. FLAG = 2 for all converters of in-service VSC dc lines. FLAG = 3 for all converters of all VSC dc lines.
Integer BUSES	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error, BUSES returned IERR = 1 Working case is empty; BUSES returned as 0 IERR = 2 Invalid SID value; BUSES returned as 0

IERR = 3

Invalid TIES value; BUSES returned as 0

IERR = 4

Invalid FLAG value; BUSES returned as 0

12.21.3. AVSCDCCONVCPLX

Use this API to return an array of complex values for subsystem VSC dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = avscdcconvcplx(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_CONV_COMPLEX(SID, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem VSC dc lines only.
	TIES = 2	for the subsystem bus end of tie VSC dc lines only.
	TIES = 3	for the non-subsystem bus end of tie VSC dc lines only.
	TIES = 4	for each end of tie VSC dc lines only.
	TIES = 5	for each end of interior subsystem VSC dc lines and the subsystem bus end of tie VSC dc lines.
	TIES = 6	for each end of interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service converters of in-service VSC dc lines.
	FLAG = 2	for all converters of in-service VSC dc lines.
	FLAG = 3	for all converters of all VSC dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for converter bus order.
	ENTRY = 2	for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	

Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line converter quantities desired (input; no default allowed).	
	'PQAC'	Apparent ac power flow into the dc line at the from bus (in MW and Mvar)
	'PQLOSS'	ac power losses (in MW and Mvar)
	'O_PQAC'	Apparent ac power flow into the dc line at the from bus (units determined by power output options)
	'O_PQLOSS'	ac power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of XARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.21.4. AVSCDCCONVINT

Use this API to return an array of integer values for subsystem VSC dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = avscdcconvint(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_CONV_INTEGER(SID, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of VSC dc lines to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem VSC dc lines only.
	TIES = 2	for the subsystem bus end of tie VSC dc lines only.
	TIES = 3	for the non-subsystem bus end of tie VSC dc lines only.
	TIES = 4	for each end of tie VSC dc lines only.
	TIES = 5	for each end of interior subsystem VSC dc lines and the subsystem bus end of tie VSC dc lines.
	TIES = 6	for each end of interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc line converters to include (input; 1 by default).	
	FLAG = 1	for only in-service converters of in-service VSC dc lines.
	FLAG = 2	for all converters of in-service VSC dc lines.
	FLAG = 3	for all converters of all VSC dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for converter bus order.
	ENTRY = 2	for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	

Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line converter quantities desired (input; no default allowed).	
	'FROMNUMBER'	From bus number
	'TONUMBER'	To bus number
	'IREG'	Bus number of the voltage controlled bus
	'CONVERTER'	1 if the from bus is converter 1, 2 if converter 2
	'DCTYPE'	Converter dc control code
	'ACMODE'	Converter ac control mode
	'NREG'	Node number of the voltage controlled node
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of IARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.21.5. AVSCDCCONVREAL

Use this API to return an array of real values for subsystem VSC dc line converters.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = avscdcconvreal(sid, ties, flag, entry, string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_CONV_REAL(SID, TIES, FLAG, ENTRY, NSTR, STRING, DIM,  
    RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem converter buses of VSC dc lines to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem VSC dc lines only. TIES = 2 for the subsystem bus end of tie VSC dc lines only. TIES = 3 for the non-subsystem bus end of tie VSC dc lines only. TIES = 4 for each end of tie VSC dc lines only. TIES = 5 for each end of interior subsystem VSC dc lines and the subsystem bus end of tie VSC dc lines. TIES = 6 for each end of interior subsystem VSC dc lines and tie VSC dc lines.
Integer FLAG	a flag indicating which subsystem VSC dc line converters to include (input; 1 by default). FLAG = 1 for only in-service converters of in-service VSC dc lines. FLAG = 2 for all converters of in-service VSC dc lines. FLAG = 3 for all converters of all VSC dc lines.
Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for converter bus order. ENTRY = 2 for dc line name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).

Character STRING (NSTR)	NSTR of the following strings indicating the VSC dc line converter quantities desired (input; no default allowed).
'ACAMPS'	ac current in amps at the from bus
'PUCUR'	ac current in pu at the from bus.
'PCTMVA'	MVA as a percent of MVA rating (more restrictive of SMAX and IMAX) at the from bus
'KVDC'	From bus dc voltage in kV
'DCSET'	dc setpoint (kV or MW) at the from bus
'ACSET'	ac setpoint (power factor or pu voltage) at the from bus
'ALOSS'	From bus A loss coefficient in kW
'BLOSS'	From bus B loss coefficient in kW/amp
'MINLOSS'	From bus minimum converter losses in kW
'SMAX'	From bus converter MVA rating
'IMAX'	From bus converter current rating in amps
'PWF'	From bus power weighting factor fraction
'RMPCT'	Percent of total Mvar to be contributed by this converter
'PAC'	Apparent active power flow into the dc line at the from bus, in MW
'QAC'	Apparent reactive power flow into the dc line at the from bus, in Mvar
'MVA'	Apparent ac power flow into the dc line at the from bus, in MVA
'PLOSS'	Total active power losses, in MW
'QLOSS'	Total reactive power losses, in Mvar
'MAXQ'	Reactive power upper limit, in Mvar
'MINQ'	Reactive power lower limit, in Mvar
'O_PAC'	Apparent active power flow into the dc line at the from bus (units determined by power output options)
'O_QAC'	Apparent reactive power flow into the dc line at the from bus (units determined by power output options)
'O_MVA'	Apparent ac power flow into the dc line at the from bus (units determined by power output options)
'O_PLOSS'	Total active power losses (units determined by power output options)
'O_QLOSS'	Total reactive power losses (units determined by power output options)
'O_MAXQ'	Reactive power upper limit (units determined by power output options)
'O_MINQ'	Reactive power lower limit (units determined by power output options)

Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. DIM must be as least as large as the value of BUSES returned by the GET_VSC_DC_CONV_COUNT API when it is called with the same values specified for SID, TIES and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid ENTRY value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of RARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.21.6. AVSCDCCONVTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the VSC dc line converter data family (aVscDcConvInt, aVscDcConvReal, aVscDcConvCplx and aVscDcConvChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = avscdcconvtypes(string)
```

Fortran command syntax:

```
CALL GET_VSC_DC_CONV_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the VSC dc line converter data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the VSC dc line converter data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the VSC dc line converter data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the VSC dc line converter data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.22. FACTS Device Data

The FACTS device data family of subsystem data retrieval APIs returns arrays of data for FACTS devices in a specified subsystem.

FACTS devices with a series element may be subsystem tie branches. One of the input items to each API allows the user to elect to retrieve data either for all subsystem FACTS devices, for subsystem FACTS devices that are tie branches, or for both subsystem and tie FACTS devices. Another input item allows the user to elect to retrieve data only for FACTS devices without a series element, only for FACTS devices with a series element, or all types of FACTS devices.

Another input item allows the user to elect to retrieve data for all such FACTS devices, or to restrict the array entries to data for in-service FACTS devices.

Data for subsystem FACTS devices is returned from all APIs in the FACTS device data family in ascending FACTS device name alphabetical order.

12.22.1. AFACTSCHAR

Use this API to return an array of character values for subsystem FACTS devices.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = afactschar(sid, ties, flag, fcttyp, string)
```

Fortran command syntax:

```
CALL GET_FACTS_CHAR(SID, TIES, FLAG, FCTTYP, NSTR, STRING, DIM, CARRAY,  
  BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem FACTS devices only.
	TIES = 2	for subsystem tie FACTS devices only.
	TIES = 3	for both interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default).	
	FLAG = 1	for only in-service FACTS devices.
	FLAG = 2	for both in-service and out-of-service FACTS devices.

Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default).	
	FCTTYP = 1	for only FACTS devices without a series element.
	FCTTYP = 2	for only FACTS devices with a series element.
	FCTTYP = 3	for both types of FACTS devices.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed).	
	'FACTSNAME'	FACTS device name (12 characters).
	'FROMNAME'	Sending end bus name (12 characters).
	'FROMEXNAME'	Sending end bus extended bus name (18 characters).
	'TONAME'	Terminal end bus name (12 characters).
	'TOEXNAME'	Terminal end bus extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of CARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid FCTTYP value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of CARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.22.2. AFACTSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the FACTS device data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, brnchs = afactscount(sid, ties, flag, fcttyp)
```

Fortran command syntax:

```
CALL GET_FACTS_COUNT(SID, TIES, FLAG, FCTTYP, BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem FACTS devices only. TIES = 2 for subsystem tie FACTS devices only. TIES = 3 for both interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default). FLAG = 1 for only in-service FACTS devices. FLAG = 2 for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default). FCTTYP = 1 for only FACTS devices without a series element. FCTTYP = 2 for only FACTS devices with a series element. FCTTYP = 3 for both types of FACTS devices.
Integer BRNCHS	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES, FLAG and FCTTYP (output).
Integer IERR	error code (output). IERR = 0 No error, BRNCHS returned IERR = 1 Working case is empty; BRNCHS returned as 0 IERR = 2 Invalid SID value; BRNCHS returned as 0 IERR = 3 Invalid TIES value; BRNCHS returned as 0

IERR = 4	Invalid FLAG value; BRNCHS returned as 0
IERR = 5	Invalid FCTTYP value; BRNCHS returned as 0

12.22.3. AFACTSCPLX

Use this API to return an array of complex values for subsystem FACTS devices.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = afactscplx(sid, ties, flag, fcttyp, string)
```

Fortran command syntax:

```
CALL GET_FACTS_COMPLEX(SID, TIES, FLAG, FCTTYP, NSTR, STRING, DIM, XARRAY,  
  BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem FACTS devices only. TIES = 2 for subsystem tie FACTS devices only. TIES = 3 for both interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default). FLAG = 1 for only in-service FACTS devices. FLAG = 2 for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default). FCTTYP = 1 for only FACTS devices without a series element. FCTTYP = 2 for only FACTS devices with a series element. FCTTYP = 3 for both types of FACTS devices.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed). 'PQDES' Desired complex power flow at the terminal bus end (MW and Mvar) 'PQSEND' Complex power flow into the series element at the sending end bus (MW and Mvar)

	'PQTERM'	Complex power flow into the series element at the terminal end bus (MW and Mvar)
	'PQSHNT'	Complex bridge (active) and shunt (reactive) power flow into the shunt element (MW and Mvar)
	'PQLOSS'	Losses (MW and Mvar)
	'O_PQDES'	Desired complex power flow at the terminal bus end (units determined by power output options)
	'O_PQSEND'	Complex power flow into the series element at the sending end bus (units determined by power output options)
	'O_PQTERM'	Complex power flow into the series element at the terminal end bus (units determined by power output options)
	'O_PQSHNT'	Complex bridge (active) and shunt (reactive) power flow into the shunt element (units determined by power output options)
	'O_PQLOSS'	Losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of XARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid FCTTYP value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of RARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.22.4. AFACTSINT

Use this API to return an array of integer values for subsystem FACTS devices.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = afactsint(sid, ties, flag, fcttyp, string)
```

Fortran command syntax:

```
CALL GET_FACTS_INTEGER(SID, TIES, FLAG, FCTTYP, NSTR, STRING, DIM, IARRAY,  
  BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem FACTS devices only. TIES = 2 for subsystem tie FACTS devices only. TIES = 3 for both interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default). FLAG = 1 for only in-service FACTS devices. FLAG = 2 for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default). FCTTYP = 1 for only FACTS devices without a series element. FCTTYP = 2 for only FACTS devices with a series element. FCTTYP = 3 for both types of FACTS devices.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed). 'SENDNUMBER' Sending end bus number 'TERMNUMBER' Terminal end bus number 'MODE' Control mode (negative if blocked during solution)

	'OWNER'	Owner number
	'IREG'	Regulated bus number
	'NREG'	Regulated node number
	'VSREF'	Series voltage reference code
	'STATVT'	Terminal end voltage condition code: -1 (holding low limit), 0 (in range), or 1 (holding high limit)
	'STATVS'	Series voltage limit code: 0 (in range), or 1 (holding high limit)
	'STATBR'	Bridge active power transfer limit code: 0 (in range), or 1 (holding high limit)
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer BRNCHS	number of elements in each column of IARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid FCTTYP value
	IERR = 6	Invalid NSTR value
	IERR = 7	DIM, and hence the size of IARRAY, is not large enough
	IERR = 8	Invalid STRING value

12.22.5. AFACTSREAL

Use this API to return an array of real values for subsystem FACTS devices.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = afactsreal(sid, ties, flag, fcttyp, string)
```

Fortran command syntax:

```
CALL GET_FACTS_REAL(SID, TIES, FLAG, FCTTYP, NSTR, STRING, DIM, RARRAY,  
  BRNCHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem FACTS devices only. TIES = 2 for subsystem tie FACTS devices only. TIES = 3 for both interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default). FLAG = 1 for only in-service FACTS devices. FLAG = 2 for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default). FCTTYP = 1 for only FACTS devices without a series element. FCTTYP = 2 for only FACTS devices with a series element. FCTTYP = 3 for both types of FACTS devices.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed). 'VSET' Voltage setpoint at the sending end bus in pu 'VTMN' Minimum voltage at the terminal end bus in pu 'VTMX' Maximum voltage at the terminal end bus in pu

'VSMX'	Maximum series voltage magnitude in pu
'LINX'	Reactance of the dummy series element
'RMPCT'	Percentage of the total MVAR required to regulate the controlled bus voltage that are contributed by this device
'VSERES'	Series voltage magnitude in pu
'IPUSND'	Current flow into series element at sending end bus in pu. 'IPUTRM' Current flow into series element at terminal end bus in pu
'IPUSHN'	Current flow into shunt element in pu
'AMPSND'	Current flow into series element at sending end bus in amps
'AMPTRM'	Current flow into series element at terminal end bus in amps
'AMPSHN'	Current flow into shunt element in amps
'PCTSND'	Percent series current loading at sending bus end
'PCTTRM'	Percent series current loading at terminal bus end
'PCTSHN'	Percent shunt current loading
'PCTPBR'	Percent bridge active power loading
'PDES'	Desired active power flow at the terminal bus end, in MW
'QDES'	Desired reactive power flow at the terminal bus end, in Mvar
'SHMX'	Maximum shunt current at the sending end bus at 1.0 pu voltage, in MVA
'TRMX'	Maximum bridge active power transfer, in MVA
'IMX'	Maximum series current at 1.0 pu voltage, in MVA
'PSEND'	Active power flow into the series element at the sending end bus, in MW
'QSEND'	Reactive power flow into the series element at the sending end bus, in Mvar
'PTERM'	Active power flow into the series element at the terminal end bus, in MW
'QTERM'	Reactive power flow into the series element at the terminal end bus, in Mvar
'PBRDG'	Bridge active power exchange, in MW
'QSHNT'	Reactive power flow into the shunt element, in Mvar
'MVASND'	Power flow into the series element at the sending end bus, in MVA
'MVATRM'	Power flow into the series element at the terminal end bus, in MVA

	'MVASHN'	Power flow into the shunt element, in MVA
	'QLOSS'	Reactive power losses, in Mvar
	'O_PDES'	Desired active power flow at the terminal bus end (units determined by power output options)
	'O_QDES'	Desired reactive power flow at the terminal bus end (units determined by power output options)
	'O_SHMX'	Maximum shunt current at the sending end bus at 1.0 pu voltage (units determined by power output options)
	'O_TRMX'	Maximum bridge active power transfer (units determined by power output options)
	'O_IMX'	Maximum series current at 1.0 pu voltage (units determined by power output options)
	'O_PSEND'	Active power flow into the series element at the sending end bus (units determined by power output options)
	'O_QSEND'	Reactive power flow into the series element at the sending end bus (units determined by power output options)
	'O_PTERM'	Active power flow into the series element at the terminal end bus (units determined by power output options)
	'O_QTERM'	Reactive power flow into the series element at the terminal end bus (units determined by power output options)
	'O_PBRDG'	Bridge active power exchange (units determined by power output options)
	'O_QSHNT'	Reactive power flow into the shunt element (units determined by power output options)
	'O_MVASND'	Power flow into the series element at the sending end bus (units determined by power output options)
	'O_MVATRM'	Power flow into the series element at the terminal end bus (units determined by power output options)
	'O_MVASHN'	Power flow into the shunt element (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM		number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).
Real RARRAY (NSTR*DIM)		Is an array of at least NSTR columns, each of which contains DIM elements (output).

Integer BRNCHS number of elements in each column of RARRAY that are set by this API. BRNCHS is identical to the value of BRNCHS returned by the GET_FACTS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).

Integer IERR error code (output).

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid TIES value
IERR = 4	Invalid FLAG value
IERR = 5	Invalid FCTTYP value
IERR = 6	Invalid NSTR value
IERR = 7	DIM, and hence the size of RARRAY, is not large enough
IERR = 8	Invalid STRING value

12.22.6. AFACTSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the FACTS device data family (aFactsInt, aFactsReal, aFactsCplx and aFactsChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = afactstypes(string)
```

Fortran command syntax:

```
CALL GET_FACTS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the FACTS device data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the FACTS device data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the FACTS device data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the FACTS device data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.23. FACTS Device Bus Data

The FACTS device bus data family of subsystem data retrieval APIs returns arrays of data for buses that are in a specified subsystem and to which FACTS devices are connected.

One of the input items to each API allows the user to elect to retrieve data either for all subsystem FACTS device buses, for subsystem buses connected to FACTS devices with a series element that is a tie branch, or for both subsystem and tie FACTS device buses. Another input item allows the user to elect to retrieve data either for FACTS devices without a series element, for FACTS devices with a series element, or for both types of FACTS devices.

Another input item allows the user to elect to retrieve data for all such FACTS device buses, or to restrict the array entries to data for buses connected to in-service FACTS devices.

Data for subsystem buses is returned from all APIs in the FACTS device bus data family in the same order. One of the input items to each API allows the user to elect that FACTS device buses be ordered either in FACTS device name order with all buses of each FACTS device grouped together, or in numerical or alphabetical order by FACTS device bus, according to the bus output option setting in effect at the time the API is referenced.

12.23.1. AFACTSBUSCHAR

Use this API to return an array of character values for subsystem FACTS device buses.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = afactsbuschar(sid, ties, flag, fcttyp, entry, string)
```

Fortran command syntax:

```
CALL GET_FACTS_BUS_CHAR(SID, TIES, FLAG, FCTTYP, ENTRY, NSTR, STRING, DIM,  
CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem buses connected to FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem FACTS devices only. TIES = 2 for the subsystem bus end of tie FACTS devices only. TIES = 3 for the non-subsystem bus end of tie FACTS devices only. TIES = 4 for each end of tie FACTS devices only.

	TIES = 5	for each end of interior subsystem FACTS devices and the subsystem bus end of tie FACTS devices.
	TIES = 6	for each end of interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default).	
	FLAG = 1	for only in-service FACTS devices.
	FLAG = 2	for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default).	
	FCTTYP = 1	for only FACTS devices without a series element.
	FCTTYP = 2	for only FACTS devices with a series element.
	FCTTYP = 3	for both types of FACTS devices.
Integer ENTRY	a flag indicating organization (input; 1 by default).	
	ENTRY = 1	for bus order.
	ENTRY = 2	for FACTS device name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed).	
	'FACTSNAME'	FACTS device name (12 characters).
	'FROMNAME'	Bus name of this FACTS bus (12 characters).
	'FROMEXNAME'	Extended bus name of this FACTS bus (18 characters).
	'TONAME'	Bus name of the other end FACTS bus (12 characters).
	'TOEXNAME'	Extended bus name of the other end FACTS bus (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value

IERR = 3	Invalid TIES value
IERR = 4	Invalid FLAG value
IERR = 5	Invalid FCTTYP value
IERR = 6	Invalid ENTRY value
IERR = 7	Invalid NSTR value
IERR = 8	DIM, and hence the size of CARRAY, is not large enough
IERR = 9	Invalid STRING value

12.23.2. AFACTSBUSCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the FACTS device bus data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, buses = afactsbuscount(sid, ties, flag, fcttyp)
```

Fortran command syntax:

```
CALL GET_FACTS_BUS_COUNT(SID, TIES, FLAG, FCTTYP, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem buses connected to FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem FACTS devices only.
	TIES = 2	for the subsystem bus end of tie FACTS devices only.
	TIES = 3	for the non-subsystem bus end of tie FACTS devices only.
	TIES = 4	for each end of tie FACTS devices only.
	TIES = 5	for each end of interior subsystem FACTS devices and the subsystem bus end of tie FACTS devices.
	TIES = 6	for each end of interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default).	
	FLAG = 1	for only in-service FACTS devices.
	FLAG = 2	for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default).	
	FCTTYP = 1	for only FACTS devices without a series element.
	FCTTYP = 2	for only FACTS devices with a series element.
	FCTTYP = 3	for both types of FACTS devices.

Integer BUSES	number of array entries required for the subsystem indicated by SID that meet the editing criteria indicated by TIES, FLAG and FCTTYP (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, BUSES returned
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid TIES value; BUSES returned as 0
	IERR = 4	Invalid FLAG value; BUSES returned as 0
	IERR = 5	Invalid FCTTYP value; BUSES returned as 0

12.23.3. AFACTSBUSCPLX

Use this API to return an array of complex values for subsystem FACTS device buses.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = afactsbuscplx(sid, ties, flag, fcttyp, entry, string)
```

Fortran command syntax:

```
CALL GET_FACTS_BUS_COMPLEX(SID, TIES, FLAG, FCTTYP, ENTRY, NSTR, STRING,  
DIM, XARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem buses connected to FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem FACTS devices only.
	TIES = 2	for the subsystem bus end of tie FACTS devices only.
	TIES = 3	for the non-subsystem bus end of tie FACTS devices only.
	TIES = 4	for each end of tie FACTS devices only.
	TIES = 5	for each end of interior subsystem FACTS devices and the subsystem bus end of tie FACTS devices.
	TIES = 6	for each end of interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default).	
	FLAG = 1	for only in-service FACTS devices.
	FLAG = 2	for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default).	
	FCTTYP = 1	for only FACTS devices without a series element.
	FCTTYP = 2	for only FACTS devices with a series element.
	FCTTYP = 3	for both types of FACTS devices.

Integer ENTRY	a flag indicating organization (input; 1 by default). ENTRY = 1 for bus order. ENTRY = 2 for FACTS device name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed). 'PQFROM' Complex power flow into the series element at the from bus end (MW and Mvar) 'PQSHNT' Complex bridge (active) and shunt (reactive) power flow into the shunt element (0.0 if the from bus is the terminal end bus) (MW and Mvar) 'PQLOSS' Losses (MW and Mvar) 'O_PQFROM' Complex power flow into the series element at the from bus end (units determined by power output options) 'O_PQSHNT' Complex bridge (active) and shunt (reactive) power flow into the shunt element (0.0 if the from bus is the terminal end bus) (units determined by power output options) 'O_PQLOSS' Losses (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).
Integer BUSES	number of elements in each column of XARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid SID value IERR = 3 Invalid TIES value IERR = 4 Invalid FLAG value IERR = 5 Invalid FCTTYP value IERR = 6 Invalid ENTRY value IERR = 7 Invalid NSTR value IERR = 8 DIM, and hence the size of RARRAY, is not large enough IERR = 9 Invalid STRING value

12.23.4. AFACTSBUSINT

Use this API to return an array of integer values for subsystem FACTS device buses.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = afactsbusint(sid, ties, flag, fcttyp, entry, string)
```

Fortran command syntax:

```
CALL GET_FACTS_BUS_INTEGER(SID, TIES, FLAG, FCTTYP, ENTRY, NSTR, STRING,  
DIM, IARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem buses connected to FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for each end of interior subsystem FACTS devices only. TIES = 2 for the subsystem bus end of tie FACTS devices only. TIES = 3 for the non-subsystem bus end of tie FACTS devices only. TIES = 4 for each end of tie FACTS devices only. TIES = 5 for each end of interior subsystem FACTS devices and the subsystem bus end of tie FACTS devices. TIES = 6 for each end of interior subsystem FACTS devices and tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default). FLAG = 1 for only in-service FACTS devices. FLAG = 2 for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default). FCTTYP = 1 for only FACTS devices without a series element. FCTTYP = 2 for only FACTS devices with a series element. FCTTYP = 3 for both types of FACTS devices.
Integer ENTRY	a flag indicating organization (input; 1 by default).

	ENTRY = 1	for bus order.
	ENTRY = 2	for FACTS device name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed).	
	'FROMNUMBER'	Bus number of this FACTS bus
	'TONUMBER'	Bus number of the other end FACTS bus
	'FACTSEND'	FACTS device end code of this FACTS bus: 1 (sending end bus) or 2 (terminal end bus)
	'MODE'	Control mode (negative if blocked during solution)
	'OWNER'	Owner number
	'IREG'	Regulated bus number
	'NREG'	Regulated node number
	'VSREF'	Series voltage reference code
	'STATVT'	Terminal end voltage condition code: -1 (holding low limit), 0 (in range), or 1 (holding high limit)
	'STATVS'	Series voltage limit code: 0 (in range), or 1 (holding high limit)
	'STATBR'	Bridge active power transfer limit code: 0 (in range), or 1 (holding high limit)
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid FCTTYP value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of IARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.23.5. AFACTSBUSREAL

Use this API to return an array of real values for subsystem FACTS device buses.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = afactsbusreal(sid, ties, flag, fcttyp, entry, string)
```

Fortran command syntax:

```
CALL GET_FACTS_BUS_REAL(SID, TIES, FLAG, FCTTYP, ENTRY, NSTR, STRING, DIM,  
  RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer TIES	a flag indicating which subsystem buses connected to FACTS devices with a series element to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for each end of interior subsystem FACTS devices only.
	TIES = 2	for the subsystem bus end of tie FACTS devices only.
	TIES = 3	for the non-subsystem bus end of tie FACTS devices only.
	TIES = 4	for each end of tie FACTS devices only.
	TIES = 5	for each end of interior subsystem FACTS devices and the subsystem bus end of tie FACTS devices.
Integer FLAG	a flag indicating which subsystem FACTS devices to include (input; 1 by default).	
	FLAG = 1	for only in-service FACTS devices.
	FLAG = 2	for both in-service and out-of-service FACTS devices.
Integer FCTTYP	a flag indicating which types of FACTS devices to include (input; 1 by default).	
	FCTTYP = 1	for only FACTS devices without a series element.
	FCTTYP = 2	for only FACTS devices with a series element.
	FCTTYP = 3	for both types of FACTS devices.
Integer ENTRY	a flag indicating organization (input; 1 by default).	

	ENTRY = 1	for bus order.
	ENTRY = 2	for FACTS device name order.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the FACTS device quantities desired (input; no default allowed).	
	'VSERES'	Series voltage magnitude in pu
	'IPUFROM'	Current flow into series element at the from bus end in pu
	'IPUSHN'	Current flow into shunt element in pu (0.0 if the from bus is the terminal end bus)
	'AMPSFROM'	Current flow into series element at the from bus end in amps
	'AMPSHN'	Current flow into shunt element in amps (0.0 if the from bus is the terminal end bus)
	'PCTFROM'	Percent series current loading at the from bus end
	'PCTSHN'	Percent shunt current loading (0.0 if the from bus is the terminal end bus)
	'PCTPBR'	Percent bridge active power loading (0.0 if the from bus is the terminal end bus)
	'PFROM'	Active power flow into the series element at the from bus end, in MW
	'QFROM'	Reactive power flow into the series element at the from bus end, in Mvar
	'PBRDG'	Bridge active power exchange (0.0 if the from bus is the terminal end bus), in MW
	'QSHNT'	Reactive power flow into the shunt element (0.0 if the from bus is the terminal end bus), in Mvar
	'MVAFROM'	Power flow into the series element at the from bus end, in MVA
	'MVASHN'	Power flow into the shunt element (0.0 if the from bus is the terminal end bus), in MVA
	'QLOSS'	Reactive power losses, in Mvar
	'O_PFROM'	Active power flow into the series element at the from bus end (units determined by power output options)
	'O_QFROM'	Reactive power flow into the series element at the from bus end (units determined by power output options)
	'O_PBRDG'	Bridge active power exchange (0.0 if the from bus is the terminal end bus) (units determined by power output options)

	'O_QSHNT'	Reactive power flow into the shunt element (0.0 if the from bus is the terminal end bus) (units determined by power output options)
	'O_MVAFROM'	Power flow into the series element at the from bus end (units determined by power output options)
	'O_MVASHN'	Power flow into the shunt element (0.0 if the from bus is the terminal end bus) (units determined by power output options)
	'O_QLOSS'	Reactive power losses (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API. BUSES is identical to the value of BUSES returned by the GET_FACTS_BUS_COUNT API when it is called with the same values specified for SID, TIES, FLAG and FCTTYP (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid TIES value
	IERR = 4	Invalid FLAG value
	IERR = 5	Invalid FCTTYP value
	IERR = 6	Invalid ENTRY value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of RARRAY, is not large enough
	IERR = 9	Invalid STRING value

12.23.6. AFACTSBUSTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the FACTS device bus data family (aFactsBusInt, aFactsBusReal, aFactsBusCplx and aFactsBusChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = afactsbustypes(string)
```

Fortran command syntax:

```
CALL GET_FACTS_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the FACTS device bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the FACTS device bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the FACTS device bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the FACTS device bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.24. Area Data

The area data family of subsystem data retrieval APIs returns arrays of data for areas in a specified area subsystem. One of the input items to each API allows the user to elect either to retrieve data for areas with any ac buses, loads, induction machines, or dc buses assigned to them, or to restrict the array entries to data for areas with at least one ac bus assigned to them.

Data for subsystem areas is returned from all APIs in the area data family in the same order: ascending area number order.

12.24.1. AAREACHAR

Use this API to return an array of character values for subsystem areas.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = aareachar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_AREA_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, AREAS, IERR)
```

Where:

Integer SID	Defines the area subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all areas in the working case.
	SID >= 0	valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem areas to include (input; 1 by default).	
	FLAG = 1	for only subsystem areas with at least one ac bus assigned to them.
	FLAG = 2	for subsystem areas with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the area quantities desired (input; no default allowed).	
	'AREANAME'	Area name (12 characters).
	'NAME'	Bus name of the area swing bus (12 characters).
	'EXNAME'	Extended bus name of the area swing bus (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of AREAS returned by the	

	GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer AREAS	number of elements in each column of CARRAY that are set by this API. AREAS is identical to the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.24.2. AAREACOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the area data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, areas = aareacount(sid, flag)
```

Fortran command syntax:

```
CALL GET_AREA_COUNT(SID, FLAG, AREAS, IERR)
```

Where:

Integer SID	Defines the area subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all areas in the working case.
	SID >= 0	valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem areas to include (input; 1 by default).	
	FLAG = 1	for only subsystem areas with at least one ac bus assigned to them.
	FLAG = 2	for subsystem areas with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer AREAS	number of areas in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, AREAS returned
	IERR = 1	Working case is empty; AREAS returned as 0
	IERR = 2	Invalid SID value; AREAS returned as 0
	IERR = 3	Invalid FLAG value; AREAS returned as 0

12.24.3. AAREACPLX

Use this API to return an array of complex values for subsystem areas.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = aareacplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_AREA_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, AREAS, IERR)
```

Where:

Integer SID	Defines the area subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all areas in the working case.
	SID >= 0	valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem areas to include (input; 1 by default).	
	FLAG = 1	for only subsystem areas with at least one ac bus assigned to them.
	FLAG = 2	for subsystem areas with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the area quantities desired (input; no default allowed).	
	'PQLOAD'	Total complex load on buses in the area (in MW and Mvar)
	'PQLOADLD'	Total complex load of loads in the area (in MW and Mvar)
	'PQGEN'	Total complex generation on buses in the area (in MW and Mvar)
	'PQLOSS'	Total complex losses assigned to the area (in MW and Mvar)
	'PQXFRMAG'	Total complex power to transformer magnetizing admittance for winding 1 buses in the area (in MW and Mvar)
	'PQINT'	Total complex net interchange from the area (in MW and Mvar)
	'O_PQLOAD'	Total complex load on buses in the area (units determined by power output option)
	'O_PQLOADLD'	Total complex load of loads in the area (units determined by power output option)

	'O_PQGEN'	Total complex generation on buses in the area (units determined by power output option)
	'O_PQLOSS'	Total complex losses assigned to the area (units determined by power output option)
	'O_PQXFRMAG'	Total complex power to transformer magnetizing admittance for winding 1 buses in the area (units determined by power output option)
	'O_PQINT'	Total complex net interchange from the area (units determined by power output option)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer AREAS	number of elements in each column of XARRAY that are set by this API. AREAS is identical to the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.24.4. AAREINT

Use this API to return an array of integer values for subsystem areas.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = aareint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_AREA_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, AREAS, IERR)
```

Where:

Integer SID	Defines the area subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all areas in the working case. SID >= 0 valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem areas to include (input; 1 by default). FLAG = 1 for only subsystem areas with at least one ac bus assigned to them. FLAG = 2 for subsystem areas with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the area quantities desired (input; no default allowed). 'NUMBER' Area number 'SWING' Number of the area swing bus used for area interchange control purposes 'SWINGSTATION' Area swing bus substation number (0 if bus is not in a substation) 'SWINGSECTION' Area swing bus section number (0 if bus is not represented by multiple bus sections) 'BUSES' Number of ac buses assigned to the area 'LOADS' Number of loads assigned to the area 'INDMACS' Number of induction machines assigned to the area 'DCBUSES' Number of dc buses assigned to the area
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).

Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer AREAS	number of elements in each column of IARRAY that are set by this API. AREAS is identical to the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.24.5. AAREAREAL

Use this API to return an array of real values for subsystem areas.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = aareareal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_AREA_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, AREAS, IERR)
```

Where:

Integer SID	Defines the area subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all areas in the working case.
	SID >= 0	valid area subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem areas to include (input; 1 by default).	
	FLAG = 1	for only subsystem areas with at least one ac bus assigned to them.
	FLAG = 2	for subsystem areas with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the area quantities desired (input; no default allowed).	
	'PDES'	Desired net active power interchange leaving the area, in MW
	'PTOL'	Interchange tolerance bandwidth, in MW
	'PLOAD'	Total active power load on buses in the area, in MW
	'QLOAD'	Total reactive power load on buses in the area, in Mvar
	'PLOADLD'	Total active power load of loads in the area, in MW
	'QLOADLD'	Total reactive power load of loads in the area, in Mvar
	'PGEN'	Total active power generation on buses in the area, in MW
	'QGEN'	Total reactive power generation on buses in the area, in Mvar
	'PLOSS'	Total active power losses assigned to the area, in MW

'QLOSS'	Total reactive power losses assigned to the area, in Mvar
'PXFRMAG'	Total active power to transformer magnetizing admittance for winding 1 buses in the area, in MW
'QXFRMAG'	Total reactive power to transformer magnetizing admittance for winding 1 buses in the area, in MVar
'PINT'	Total active power net interchange from the area, in MW
'QINT'	Total reactive power net interchange from the area, in Mvar
'O_PDES'	Desired net active power interchange leaving the area (units determined by power output option)
'O_PTOL'	Interchange tolerance bandwidth (units determined by power output option)
'O_PLOAD'	Total active power load on buses in the area (units determined by power output option)
'O_QLOAD'	Total reactive power load on buses in the area (units determined by power output option)
'O_PLOADLD'	Total active power load of loads in the area (units determined by power output option)
'O_QLOADLD'	Total reactive power load of loads in the area (units determined by power output option)
'O_PGEN'	Total active power generation on buses in the area (units determined by power output option)
'O_QGEN'	Total reactive power generation on buses in the area (units determined by power output option)
'O_PLOSS'	Total active power losses assigned to the area (units determined by power output option)
'O_QLOSS'	Total reactive power losses assigned to the area (units determined by power output option)
'O_PXFRMAG'	Total active power to transformer magnetizing admittance for winding 1 buses in the area (units determined by power output option)
'O_QXFRMAG'	Total reactive power to transformer magnetizing admittance for winding 1 buses in the area (units determined by power output option)
'O_PINT'	Total active power net interchange from the area (units determined by power output option)

	'O_QINT'	Total reactive power net interchange from the area (units determined by power output option)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer AREAS	number of elements in each column of RARRAY that are set by this API. AREAS is identical to the value of AREAS returned by the GET_AREA_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.24.6. AAREATYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the area data family (aAreaInt, aAreaReal, aAreaCplx and aAreaChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = aareatypes(string)
```

Fortran command syntax:

```
CALL GET_AREA_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the area data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the area data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the area data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the area data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.25. Owner Data

The owner data family of subsystem data retrieval APIs returns arrays of data for owners in a specified owner subsystem. One of the input items to each API allows the user to elect either to retrieve data for owners with any ac buses, loads, machines, induction machines, branches, FACTS devices, VSC dc lines, or dc buses assigned to them, or to restrict the array entries to data for owners with at least one ac bus assigned to them.

Data for subsystem owners is returned from all APIs in the owner data family in the same order: ascending owner number order.

12.25.1. AOWNERCHAR

Use this API to return an array of character values for subsystem owners.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = aownerchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_OWNER_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, OWNERS, IERR)
```

Where:

Integer SID	Defines the owner subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all owners in the working case.
	SID >= 0	valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem owners to include (input; 1 by default).	
	FLAG = 1	for only subsystem owners with at least one ac bus assigned to them.
	FLAG = 2	for subsystem owners with any equipment (ac buses, loads, machines, ac branches, FACTS devices, VSC dc lines and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the owner quantities desired (input; no default allowed).	
	'OWNERNAME'	Owner name (12 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	

Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer OWNERS	number of elements in each column of CARRAY that are set by this API. OWNERS is identical to the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.25.2. AOWNERCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the owner data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, owners = aownercount(sid, flag)
```

Fortran command syntax:

```
CALL GET_OWNER_COUNT(SID, FLAG, OWNERS, IERR)
```

Where:

Integer SID	Defines the owner subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all owners in the working case.
	SID >= 0	valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem owners to include (input; 1 by default).	
	FLAG = 1	for only subsystem owners with at least one ac bus assigned to them.
	FLAG = 2	for subsystem owners with any equipment (ac buses, loads, machines, ac branches, FACTS devices, VSC dc lines and/or dc buses) assigned to them.
Integer OWNERS	number of owners in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, OWNERS returned
	IERR = 1	Working case is empty; OWNERS returned as 0
	IERR = 2	Invalid SID value; OWNERS returned as 0
	IERR = 3	Invalid FLAG value; OWNERS returned as 0

12.25.3. AOWNERCPLX

Use this API to return an array of complex values for subsystem owners.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = aownercplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_OWNER_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, OWNERS, IERR)
```

Where:

Integer SID	Defines the owner subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all owners in the working case.
	SID >= 0	valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem owners to include (input; 1 by default).	
	FLAG = 1	for only subsystem owners with at least one ac bus assigned to them.
	FLAG = 2	for subsystem owners with any equipment (ac buses, loads, machines, ac branches, FACTS devices, VSC dc lines and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the owner quantities desired (input; no default allowed).	
	'PQLOAD'	Total complex load on the owner's buses (in MW and Mvar)
	'PQLOADLD'	Total complex load of the owner's loads (in MW and Mvar)
	'PQGEN'	Total complex generation on the owner's buses (in MW and Mvar)
	'PQGENMC'	Total complex generation on the owner's machines (in MW and Mvar)
	'PQLOSS'	Total complex losses assigned to the owner (in MW and Mvar)
	'PQXFRMAG'	Total complex power to transformer magnetizing admittance assigned to the owner (in MW and Mvar)
	'O_PQLOAD'	Total complex load on the owner's buses (units determined by power output option)

	'O_PQLOADLD'	Total complex load of the owner's loads (units determined by power output option)
	'O_PQGEN'	Total complex generation on the owner's buses (units determined by power output option)
	'O_PQGENMC'	Total complex generation on the owner's machines (units determined by power output option)
	'O_PQLOSS'	Total complex losses assigned to the owner (units determined by power output option)
	'O_PQXFRMAG'	Total complex power to transformer magnetizing admittance assigned to the owner (units determined by power output option)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer OWNERS	number of elements in each column of XARRAY that are set by this API. OWNERS is identical to the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.25.4. AOWNERINT

Use this API to return an array of integer values for subsystem owners.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = aownerint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_OWNER_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, OWNERS, IERR)
```

Where:

Integer SID	Defines the owner subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all owners in the working case.
	SID >= 0	valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem owners to include (input; 1 by default).	
	FLAG = 1	for only subsystem owners with at least one ac bus assigned to them.
	FLAG = 2	for subsystem owners with any equipment (ac buses, loads, machines, ac branches, FACTS devices, VSC dc lines and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the owner quantities desired (input; no default allowed).	
	'NUMBER'	Owner number
	'BUSES'	Number of ac buses assigned to the owner
	'LOADS'	Number of loads assigned to the owner
	'MACHINES'	Number of machine ownership specifications for the owner
	'INDMACS'	Number of induction machines assigned to the owner
	'BRANCHES'	Number of branch ownership specifications for the owner
	'FACTS'	Number of FACTS devices assigned to the owner
	'VSCDCLINES'	Number of VSC dc line ownership specifications for the owner
	'DCBUSES'	Number of dc buses assigned to the owner

Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer OWNERS	number of elements in each column of IARRAY that are set by this API. OWNERS is identical to the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.25.5. AOWNERREAL

Use this API to return an array of real values for subsystem owners.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = aownerreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_OWNER_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, OWNERS, IERR)
```

Where:

Integer SID	Defines the owner subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all owners in the working case.
	SID >= 0	valid owner subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem owners to include (input; 1 by default).	
	FLAG = 1	for only subsystem owners with at least one ac bus assigned to them.
	FLAG = 2	for subsystem owners with any equipment (ac buses, loads, machines, ac branches, FACTS devices, VSC dc lines and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the owner quantities desired (input; no default allowed).	
	'PLOAD'	Total active power load on the owner's buses, in MW
	'QLOAD'	Total reactive power load on the owner's buses, in Mvar
	'PLOADLD'	Total active power load of the owner's loads, in MW
	'QLOADLD'	Total reactive power load of the owner's loads, in Mvar
	'PGEN'	Total active power generation on the owner's buses, in Mw
	'QGEN'	Total reactive power generation on the owner's buses, in Mvar
	'PGENMC'	Total active power generation on the owner's machines, in MW
	'QGENMC'	Total reactive power generation on the owner's machines, in Mvar

	'PLOSS'	Total active power losses assigned to the owner, in MW
	'QLOSS'	Total reactive power losses assigned to the owner, in Mvar
	'PXFRMAG'	Total active power to transformer magnetizing admittance assigned to the owner, in MW
	'QXFRMAG'	Total reactive power to transformer magnetizing admittance assigned to the owner, in MVar
	'O_PLOAD'	Total active power load on the owner's buses (units determined by power output option)
	'O_QLOAD'	Total reactive power load on the owner's buses (units determined by power output option)
	'O_PLOADLD'	Total active power load of the owner's loads (units determined by power output option)
	'O_QLOADLD'	Total reactive power load of the owner's loads (units determined by power output option)
	'O_PGEN'	Total active power generation on the owner's buses (units determined by power output option)
	'O_QGEN'	Total reactive power generation on the owner's buses (units determined by power output option)
	'O_PGENMC'	Total active power generation on the owner's machines (units determined by power output option)
	'O_QGENMC'	Total reactive power generation on the owner's machines (units determined by power output option)
	'O_PLOSS'	Total active power losses assigned to the owner (units determined by power output option)
	'O_QLOSS'	Total reactive power losses assigned to the owner (units determined by power output option)
	'O_PXFRMAG'	Total active power to transformer magnetizing admittance assigned to the owner (units determined by power output option)
	'O_QXFRMAG'	Total reactive power to transformer magnetizing admittance assigned to the owner (units determined by power output option)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	

Integer OWNERS	number of elements in each column of RARRAY that are set by this API. OWNERS is identical to the value of OWNERS returned by the GET_OWNER_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.25.6. AOWNERTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the owner data family (aOwnerInt, aOwnerReal, aOwnerCplx and aOwnerChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = aownertypes(string)
```

Fortran command syntax:

```
CALL GET_OWNER_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the owner data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the owner data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the owner data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the owner data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.26. Zone Data

The zone data family of subsystem data retrieval APIs returns arrays of data for zones in a specified zone subsystem. One of the input items to each API allows the user to elect either to retrieve data for zones with any ac buses, loads, induction machines, or dc buses assigned to them, or to restrict the array entries to data for zones with at least one ac bus assigned to them.

Data for subsystem zones is returned from all APIs in the zone data family in the same order: ascending zone number order.

12.26.1. AZONECHAR

Use this API to return an array of character values for subsystem zones.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, carray = azonechar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_ZONE_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, ZONES, IERR)
```

Where:

Integer SID	Defines the zone subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all zones in the working case. SID >= 0 valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem zones to include (input; 1 by default). FLAG = 1 for only subsystem zones with at least one ac bus assigned to them. FLAG = 2 for subsystem zones with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the zone quantities desired (input; no default allowed). 'ZONENAME' Zone name (12 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).

Integer ZONES	number of elements in each column of CARRAY that are set by this API. ZONES is identical to the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.26.2. AZONECOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the zone data family.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, zones = azonecount(sid, flag)
```

Fortran command syntax:

```
CALL GET_ZONE_COUNT(SID, FLAG, ZONES, IERR)
```

Where:

Integer SID	Defines the zone subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all zones in the working case.
	SID >= 0	valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem zones to include (input; 1 by default).	
	FLAG = 1	for only subsystem zones with at least one ac bus assigned to them.
	FLAG = 2	for subsystem zones with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer ZONES	number of zones in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, ZONES returned
	IERR = 1	Working case is empty; ZONES returned as 0
	IERR = 2	Invalid SID value; ZONES returned as 0
	IERR = 3	Invalid FLAG value; ZONES returned as 0

12.26.3. AZONECPLX

Use this API to return an array of complex values for subsystem zones.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, xarray = azonecplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_ZONE_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, ZONES, IERR)
```

Where:

Integer SID	Defines the zone subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all zones in the working case.
	SID >= 0	valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem zones to include (input; 1 by default).	
	FLAG = 1	for only subsystem zones with at least one ac bus assigned to them.
	FLAG = 2	for subsystem zones with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the zone quantities desired (input; no default allowed).	
	'PQLOAD'	Total complex load on buses in the zone (in MW and Mvar)
	'PQLOADLD'	Total complex load of loads in the zone (in MW and Mvar)
	'PQGEN'	Total complex generation on buses in the zone (in MW and Mvar)
	'PQLOSS'	Total complex losses assigned to the zone (in MW and Mvar)
	'PQXFRMAG'	Total complex power to transformer magnetizing admittance for winding 1 buses in the zone (in MW and Mvar)
	'PQINT'	Total complex net interchange from the zone (in MW and Mvar)
	'O_PQLOAD'	Total complex load on buses in the zone (units determined by power output option)
	'O_PQLOADLD'	Total complex load of loads in the zone (units determined by power output option)

	'O_PQGEN'	Total complex generation on buses in the zone (units determined by power output option)
	'O_PQLOSS'	Total complex losses assigned to the zone (units determined by power output option)
	'O_PQXFRMAG'	Total complex power to transformer magnetizing admittance for winding 1 buses in the zone (units determined by power output option)
	'O_PQINT'	Total complex net interchange from the zone (units determined by power output option)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer ZONES	number of elements in each column of XARRAY that are set by this API. ZONES is identical to the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.26.4. AZONEINT

Use this API to return an array of integer values for subsystem zones.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, iarray = azoneint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_ZONE_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, ZONES, IERR)
```

Where:

Integer SID	Defines the zone subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all zones in the working case. SID >= 0 valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem zones to include (input; 1 by default). FLAG = 1 for only subsystem zones with at least one ac bus assigned to them. FLAG = 2 for subsystem zones with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the zone quantities desired (input; no default allowed). 'NUMBER' Zone number 'BUSES' Number of ac buses assigned to the zone 'LOADS' Number of loads assigned to the zone 'INDMACS' Number of induction machines assigned to the zone 'DCBUSES' Number of dc buses assigned to the zone
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer ZONES	number of elements in each column of IARRAY that are set by this API. ZONES is identical to the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (output).

Integer IERR

error code (output).

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of IARRAY, is not large enough
IERR = 6	Invalid STRING value

12.26.5. AZONEREAL

Use this API to return an array of real values for subsystem zones.

This API routine was first introduced in release 30.3.0.

Python command syntax:

```
ierr, rarray = azonereal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_ZONE_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, ZONES, IERR)
```

Where:

Integer SID	Defines the zone subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all zones in the working case.
	SID >= 0	valid zone subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem zones to include (input; 1 by default).	
	FLAG = 1	for only subsystem zones with at least one ac bus assigned to them.
	FLAG = 2	for subsystem zones with any equipment (ac buses, loads, and/or dc buses) assigned to them.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the zone quantities desired (input; no default allowed).	
	'PLOAD'	Total active power load on buses in the zone, in MW
	'QLOAD'	Total reactive power load on buses in the zone, in Mvar
	'PLOADLD'	Total active power load of loads in the zone, in MW
	'QLOADLD'	Total reactive power load of loads in the zone, in Mvar
	'PGEN'	Total active power generation on buses in the zone, in MW
	'QGEN'	Total reactive power generation on buses in the zone, in Mvar
	'PLOSS'	Total active power losses assigned to the zone, in MW
	'QLOSS'	Total reactive power losses assigned to the zone, in Mvar

'PXFRMAG'	Total active power to transformer magnetizing admittance for winding 1 buses in the zone, in MW
'QXFRMAG'	Total reactive power to transformer magnetizing admittance for winding 1 buses in the zone, in MVar
'PINT'	Total active power net interchange from the zone, in MW
'QINT'	Total reactive power net interchange from the zone, in Mvar
'O_PLOAD'	Total active power load on buses in the zone (units determined by power output option)
'O_QLOAD'	Total reactive power load on buses in the zone (units determined by power output option)
'O_PLOADLD'	Total active power load of loads in the zone (units determined by power output option)
'O_QLOADLD'	Total reactive power load of loads in the zone (units determined by power output option)
'O_PGEN'	Total active power generation on buses in the zone (units determined by power output option)
'O_QGEN'	Total reactive power generation on buses in the zone (units determined by power output option)
'O_PLOSS'	Total active power losses assigned to the zone (units determined by power output option)
'O_QLOSS'	Total reactive power losses assigned to the zone (units determined by power output option)
'O_PXFRMAG'	Total active power to transformer magnetizing admittance for winding 1 buses in the zone (units determined by power output option)
'O_QXFRMAG'	Total reactive power to transformer magnetizing admittance for winding 1 buses in the zone (units determined by power output option)
'O_PINT'	Total active power net interchange from the zone (units determined by power output option)
'O_QINT'	Total reactive power net interchange from the zone (units determined by power output option)

Integer DIM

number of elements in each column of the array RARRAY. DIM must be as least as large as the value of ZONES returned by the

	GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer ZONES	number of elements in each column of RARRAY that are set by this API. ZONES is identical to the value of ZONES returned by the GET_ZONE_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.26.6. AZONETYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the zone data family (aZoneInt, aZoneReal, aZoneCplx and aZoneChar).

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
ierr, types = azonetypes(string)
```

Fortran command syntax:

```
CALL GET_ZONE_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the zone data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the zone data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the zone data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the zone data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.27. Induction Machine Bus Data

The induction machine bus data family of subsystem data retrieval API routines returns arrays of data for buses in a specified subsystem. One of the input items to each API routine allows the user to elect either to retrieve data for all subsystem buses, or to restrict the array entries to data for a subset of buses according to their bus and/or induction machine configuration and statuses.

Data for subsystem buses is returned from all API routines in the induction machine bus data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API routine is referenced.

12.27.1. AINDMACBUSCHAR

Use this API routine to return an array of character values for subsystem buses.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, carray = aindmacbuschar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_BUS_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction machine.
	FLAG = 2	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 3	for all in-service subsystem buses (type code 1, 2 or 3), including those that have no induction machines at the bus.
	FLAG = 4	for all subsystem buses with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 5	for all subsystem buses, including those that have no induction machines at the bus.

	FLAG = 10	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction generator.
	FLAG = 11	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction generator, even if all induction generators at the bus are out-of-service.
	FLAG = 12	for all subsystem buses with at least one induction generator, even if all induction generators at the bus are out-of-service.
	FLAG = 20	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction motor.
	FLAG = 21	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction motor, even if all induction motors at the bus are out-of-service.
	FLAG = 22	for all subsystem buses with at least one induction motor, even if all induction motors at the bus are out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of CARRAY that are set by this API routine. BUSES is identical to the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (output).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.27.2. AINDMACBUSCOUNT

Use this API routine to obtain the number of array entries required to accommodate the data to be returned by the remaining members of the induction machine bus data family.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, buses = aindmacbuscount(sid, flag)
```

Fortran command syntax:

```
CALL GET_IND_MAC_BUS_COUNT(SID, FLAG, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction machine.
	FLAG = 2	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 3	for all in-service subsystem buses (type code 1, 2 or 3), including those that have no induction machines at the bus.
	FLAG = 4	for all subsystem buses with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 5	for all subsystem buses, including those that have no induction machines at the bus.
	FLAG = 10	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction generator.
	FLAG = 11	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction generator, even if all induction generators at the bus are out-of-service.
	FLAG = 12	for all subsystem buses with at least one induction generator, even if all induction generators at the bus are out-of-service.

	FLAG = 20	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction motor.
	FLAG = 21	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction motor, even if all induction motors at the bus are out-of-service.
	FLAG = 22	for all subsystem buses with at least one induction motor, even if all induction motors at the bus are out-of-service.
Integer BUSES	number of buses in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty; BUSES returned as 0
	IERR = 2	Invalid SID value; BUSES returned as 0
	IERR = 3	Invalid FLAG value; BUSES returned as 0

12.27.3. AINDMACBUSCPLX

Use this API routine to return an array of complex values for subsystem buses.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, xarray = aindmacbuscplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_BUS_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, BUSES,  
IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction machine.
	FLAG = 2	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 3	for all in-service subsystem buses (type code 1, 2 or 3), including those that have no induction machines at the bus.
	FLAG = 4	for all subsystem buses with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 5	for all subsystem buses, including those that have no induction machines at the bus.
	FLAG = 10	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction generator.
	FLAG = 11	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction generator, even if all induction generators at the bus are out-of-service.
	FLAG = 12	for all subsystem buses with at least one induction generator, even if all induction generators at the bus are out-of-service.

	FLAG = 20	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction motor.
	FLAG = 21	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction motor, even if all induction motors at the bus are out-of-service.
	FLAG = 22	for all subsystem buses with at least one induction motor, even if all induction motors at the bus are out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'VOLTAGE'	Actual bus voltage, in pu, rectangular coordinates
	'TOTAL'	Flow from the bus to the in-service induction machines at the bus (in MW and Mvar)
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (in MW and Mvar)
	'O_TOTAL'	Flow from the bus to the in-service induction machines at the bus (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of XARRAY that are set by this API routine. BUSES is identical to the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (output).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.27.4. AINDMACBUSINT

Use this API routine to return an array of integer values for subsystem buses.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, iarray = aindmacbusint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_BUS_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, BUSES,  
IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction machine.
	FLAG = 2	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 3	for all in-service subsystem buses (type code 1, 2 or 3), including those that have no induction machines at the bus.
	FLAG = 4	for all subsystem buses with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 5	for all subsystem buses, including those that have no induction machines at the bus.
	FLAG = 10	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction generator.
	FLAG = 11	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction generator, even if all induction generators at the bus are out-of-service.
	FLAG = 12	for all subsystem buses with at least one induction generator, even if all induction generators at the bus are out-of-service.

	FLAG = 20	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction motor.
	FLAG = 21	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction motor, even if all induction motors at the bus are out-of-service.
	FLAG = 22	for all subsystem buses with at least one induction motor, even if all induction motors at the bus are out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'TYPE'	Bus type code
	'AREA'	Bus area number
	'ZONE'	Bus zone number
	'OWNER'	Bus owner number
	'DUMMY'	Returns 1 if the bus is a dummy bus of a multisection line, or 0 if it is not
	'STATUS'	Inferred induction machine status. Returns 1 if the bus type code is 1, 2 or 3, and at least one in-service induction machine is present or 0 otherwise
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of IARRAY that are set by this API routine. BUSES is identical to the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (output).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.27.5. AINDMACBUSREAL

Use this API routine to return an array of real values for subsystem buses.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, rarray = aindmacbusreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_BUS_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, BUSES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem buses to include (input; 1 by default).	
	FLAG = 1	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction machine.
	FLAG = 2	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 3	for all in-service subsystem buses (type code 1, 2 or 3), including those that have no induction machines at the bus.
	FLAG = 4	for all subsystem buses with at least one induction machine, even if all induction machines at the bus are out-of-service.
	FLAG = 5	for all subsystem buses, including those that have no induction machines at the bus.
	FLAG = 10	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction generator.
	FLAG = 11	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction generator, even if all induction generators at the bus are out-of-service.
	FLAG = 12	for all subsystem buses with at least one induction generator, even if all induction generators at the bus are out-of-service.

	FLAG = 20	for all in-service subsystem buses (type code 1, 2 or 3) with at least one in-service induction motor.
	FLAG = 21	for all in-service subsystem buses (type code 1, 2 or 3) with at least one induction motor, even if all induction motors at the bus are out-of-service.
	FLAG = 22	for all subsystem buses with at least one induction motor, even if all induction motors at the bus are out-of-service.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'BASE'	Bus base voltage, in kV
	'PU'	Actual bus voltage magnitude, in pu
	'KV'	Actual bus voltage magnitude, in kV (in pu if base voltage is 0.0)
	'ANGLE'	Bus voltage phase angle, in radians
	'ANGLED'	Bus voltage phase angle, in degrees
	'TOTAL'	Flow from the bus to the in-service induction machines at the bus, in MVA
	'MISMATCH'	Bus mismatch (0.0 if bus type code > 3), in MVA
	'O_TOTAL'	Flow from the bus to the in-service induction machines at the bus (units determined by power output options)
	'O_MISMATCH'	Bus mismatch (0.0 if bus type code > 3) (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer BUSES	number of elements in each column of RARRAY that are set by this API routine. BUSES is identical to the value of BUSES returned by the alndMacBusCount API routine when it is called with the same values specified for SID and FLAG (output).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value

IERR = 5

DIM, and hence the size of RARRAY, is not
large enough

IERR = 6

Invalid STRING value

12.27.6. AINDMACBUSTYPES

Use this API routine to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the induction machine bus data family (alndMacBusInt, alndMacBusReal, alndMacBusCplx and alndMacBusChar).

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, types = aindmacbustypes(string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_BUS_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the induction machine bus data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the induction machine bus data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the induction machine bus data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the induction machine bus data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.28. Induction Machine Data

The induction machine data family of subsystem data retrieval API routines returns arrays of data for induction machines in a specified subsystem. One of the input items to each API routine allows the user to elect either to retrieve data for all subsystem induction machines, or to restrict the array entries to data for a subset of induction machines according to their bus and/or induction machine configuration and statuses.

Data for subsystem induction machines is returned from all API routines in the induction machine data family in the same order: ascending bus number order or alphabetic extended bus name order, according to the bus output option setting in effect at the time the API routine is referenced; multiple induction machines at the same bus are in ascending induction machine identifier order.

12.28.1. AINDMACCHAR

Use this API routine to return an array of character values for subsystem induction machines.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, carray = aindmacchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem induction machines to include (input; 1 by default).	
	FLAG = 1	for all in-service induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 2	for all induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 3	for all in-service induction machines at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 4	for all induction machines at all subsystem buses.
	FLAG = 11	for all in-service induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 12	all induction generators at in-service subsystem buses (type code 1, 2 or 3).

	FLAG = 13	for all in-service induction generators at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 14	for all induction generators at all subsystem buses.
	FLAG = 21	for all in-service induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 22	all induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 23	for all in-service induction motors at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 24	for all induction motors at all subsystem buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'ID'	Induction machine identifier (2 characters).
	'NAME'	Bus name (12 characters).
	'EXNAME'	Extended bus name (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of MACHS returned by the alndMacCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of CARRAY that are set by this API routine. MACHS is identical to the value of MACHS returned by the alndMacCount API routine when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.28.2. AINDMACCOUNT

Use this API routine to obtain the number of array entries required to accommodate the data to be returned by the remaining members of the induction machine data family.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, machs = aindmacount(sid, flag)
```

Fortran command syntax:

```
CALL GET_IND_MAC_COUNT(SID, FLAG, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem induction machines to include (input; 1 by default).	
	FLAG = 1	for all in-service induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 2	for all induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 3	for all in-service induction machines at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 4	for all induction machines at all subsystem buses.
	FLAG = 11	for all in-service induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 12	all induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 13	for all in-service induction generators at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 14	for all induction generators at all subsystem buses.
	FLAG = 21	for all in-service induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 22	all induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 23	for all in-service induction motors at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).

	FLAG = 24	for all induction motors at all subsystem buses.
Integer MACHS	number of induction machines in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty; MACHS returned as 0
	IERR = 2	Invalid SID value; MACHS returned as 0
	IERR = 3	Invalid FLAG value; MACHS returned as 0

12.28.3. AINDMACCPLX

Use this API routine to return an array of complex values for subsystem induction machines.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, xarray = aindmaccplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem induction machines to include (input; 1 by default).	
	FLAG = 1	for all in-service induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 2	for all induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 3	for all in-service induction machines at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 4	for all induction machines at all subsystem buses.
	FLAG = 11	for all in-service induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 12	all induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 13	for all in-service induction generators at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 14	for all induction generators at all subsystem buses.
	FLAG = 21	for all in-service induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 22	all induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 23	for all in-service induction motors at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).

	FLAG = 24	for all induction motors at all subsystem buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'ZA'	(RA + j XA)
	'Z1'	(R1 + j X1)
	'Z2'	(R2 + j X2)
	'ZZERO'	Machine zero sequence fault analysis impedance
	'ZGROUND'	Machine zero sequence grounding impedance
	'PQ'	Complex power flow from the bus to the machine (in MW and Mvar)
	'O_PQ'	Complex power flow from the bus to the machine (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of MACHS returned by the aIndMacCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of XARRAY that are set by this API routine. MACHS is identical to the value of MACHS returned by the aIndMacCount API routine when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of XARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'ZZERO' or 'ZGROUND')

12.28.4. AINDMACINT

Use this API routine to return an array of integer values for subsystem induction machines.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, iarray = aindmacint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem induction machines to include (input; 1 by default).	
	FLAG = 1	for all in-service induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 2	for all induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 3	for all in-service induction machines at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 4	for all induction machines at all subsystem buses.
	FLAG = 11	for all in-service induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 12	all induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 13	for all in-service induction generators at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 14	for all induction generators at all subsystem buses.
	FLAG = 21	for all in-service induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 22	all induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 23	for all in-service induction motors at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).

	FLAG = 24	for all induction motors at all subsystem buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'NUMBER'	Bus number
	'AREA'	Machine area assignment
	'ZONE'	Machine zone assignment
	'OWNER'	Machine owner assignment
	'STATUS'	Machine status
	'STANDARDCODE'	Machine standard code (1 for NEMA, 2 for IEC)
	'DESIGNCODE'	Machine design code (0 through 5)
	'PSETCODE'	Power setpoint code (1 for mechanical, 2 for electrical)
	'BASECODE'	Machine base power code (1 for mechanical, 2 for electrical)
	'TRQVARCODE'	Mechanical torque variation code (1 for simple power law, 2 for WECC model)
	'CZG'	Grounding impedance data input/output (I/O) code (1 for per unit, 2 for ohms)
	'CGR'	Grounding code (0 for an ungrounded machine, 1 for a grounded machine)
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of MACHS returned by the aIndMacCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of IARRAY that are set by this API routine. MACHS is identical to the value of MACHS returned by the aIndMacCount API routine when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of IARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'CZG' or 'CGR')

12.28.5. AINDMACREAL

Use this API routine to return an array of real values for subsystem induction machines.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, rarray = aindmacreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_REAL (SID, FLAG, NSTR, STRING, DIM, RARRAY, MACHS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API routine to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer FLAG	a flag indicating which subsystem induction machines to include (input; 1 by default).	
	FLAG = 1	for all in-service induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 2	for all induction machines at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 3	for all in-service induction machines at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 4	for all induction machines at all subsystem buses.
	FLAG = 11	for all in-service induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 12	all induction generators at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 13	for all in-service induction generators at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).
	FLAG = 14	for all induction generators at all subsystem buses.
	FLAG = 21	for all in-service induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 22	all induction motors at in-service subsystem buses (type code 1, 2 or 3).
	FLAG = 23	for all in-service induction motors at subsystem buses, even if the bus to which it is connected is out-of-service (type code 4).

	FLAG = 24	for all induction motors at all subsystem buses.
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).	
Character STRING (NSTR)	NSTR of the following strings indicating the bus and/or induction machine quantities desired (input; no default allowed).	
	'MBASE'	Machine base power
	'RATEKV'	Machine rated voltage
	'PSETPOINT'	Power setpoint (positive for a motor)
	'RA'	Armature resistance
	'XA'	Armature leakage reactance
	'XM'	Magnetizing reactance
	'R1'	First cage resistance
	'X1'	First cage reactance
	'R2'	Second cage resistance
	'X2'	Second cage reactance
	'X3'	Third reactance
	'E1'	First saturation voltage
	'SE1'	SE(E1)
	'E2'	Second saturation voltage
	'SE2'	SE(E2)
	'IA1'	Starting stator current for applying stator leakage reactance saturation
	'IA2'	Stator current at which the stator leakage reactance is fully saturated
	'XAMULT'	Xa multiplier at full leakage reactance saturation
	'TRQA'	Load torque variation constant A for WECC model
	'TRQB'	Load torque variation constant B for WECC model
	'TRQD'	Load torque variation constant D for both models
	'TRQE'	Load torque variation constant E for WECC model
	'SLIP'	Slip
	'H'	Machine inertia
	'ILKDOVERIRAT'	Ratio of locked rotor current to rated current
	'ROVERX'	Ratio of Rpos to Xpos
	'RZERO'	Machine zero sequence fault analysis resistance
	'XZERO'	Machine zero sequence fault analysis reactance
	'RGROUND'	Machine zero sequence grounding resistance
	'XGROUND'	Machine zero sequence grounding reactance

	'P'	Active power flow from the bus to the machine, in MW
	'Q'	Reactive power flow from the bus to the machine, in Mvar
	'MVA'	MVA flow from the bus to the machine, in MVA
	'O_P'	Active power flow from the bus to the machine (units determined by power output options)
	'O_Q'	Reactive power flow from the bus to the machine (units determined by power output options)
	'O_MVA'	MVA flow from the bus to the machine (units determined by power output options)
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of MACHS returned by the alndMacCount API routine when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MACHS	number of elements in each column of RARRAY that are set by this API routine. MACHS is identical to the value of MACHS returned by the alndMacCount API routine when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value
	IERR = 7	Sequence data not in case (when STRING = 'ILKDOVERIRAT', 'ROVERX', 'RZERO', 'XZERO', 'XZERO', 'RGROUND' or 'XGROUND')

12.28.6. AINDMACTYPES

Use this API routine to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the induction machine data family (aIndMacInt, aIndMacReal, aIndMacCplx and aIndMacChar).

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, types = aindmactypes(string)
```

Fortran command syntax:

```
CALL GET_IND_MAC_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the induction machine data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the induction machine data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the induction machine data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the induction machine data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.29. Substation Data

The substation data family of subsystem data retrieval APIs returns arrays of data for substations in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for substations with a least one subsystem bus, or to restrict the array entries to data for substations with all of their buses in the subsystem.

Data for subsystem substations is returned from all APIs in the substation data family in ascending substation number order.

12.29.1. ASTATIONCHAR

Use this API to return an array of character values for subsystem substations.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, carray = astationchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SUBSTATION_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, STATIONS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (1 by default) (input).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed) (input).
Character STRING (NSTR)	NSTR of the following strings indicating the substation quantities desired (input; no default allowed). 'STATIONNAME' Substation name (40 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of BUSES returned by the GET_BUS_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer STATIONS	number of elements in each column of CARRAY that are set by this API. STATIONS is identical to the value of STATIONS returned by the GET_SUBSTATION_COUNT API when it is called with the same values specified for SID and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid SID value IERR = 3 Invalid FLAG value

IERR = 4

Invalid NSTR value

IERR = 5

DIM, and hence the size of CARRAY, is not
large enough

IERR = 6

Invalid STRING value

12.29.2. ASTATIONCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the substation data family.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, stations = astationcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_SUBSTATION_COUNT(SID, FLAG, STATIONS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer STATIONS	number of substations in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).
Integer IERR	error code (output).
	IERR = 0 No error, STATIONS returned
	IERR = 1 Working case is empty; STATIONS returned as 0
	IERR = 2 Invalid SID value; STATIONS returned as 0
	IERR = 3 Invalid FLAG value; STATIONS returned as 0

12.29.3. ASTATIONINT

Use this API to return an array of integer values for subsystem substations.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, iarray = astationint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SUBSTATION_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, STATIONS,  
IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed) (input).
Character STRING (NSTR)	NSTR of the following strings indicating the substation quantities desired (input; no default allowed). 'NUMBER' Substation number 'NODES' Number of nodes in the substation 'PARENTS' Number of parent buses in the substation 'SECTIONS' Number of bus sections in the substation 'SWDEVS' Number of substation switching devices in the substation
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of STATIONS returned by the GET_SUBSTATION_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer STATIONS	number of elements in each column of IARRAY that are set by this API. STATIONS is identical to the value of STATIONS returned by the GET_SUBSTATION_COUNT API when it is called with the same values specified for SID and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid SID value IERR = 3 Invalid FLAG value IERR = 4 Invalid NSTR value IERR = 5 DIM, and hence the size of IARRAY, is not large enough

IERR = 6

Invalid STRING value

12.29.4. ASTATIONREAL

Use this API to return an array of real values for subsystem substations.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rarray = astationreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_SUBSTATION_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, STATIONS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the substation quantities desired (input; no default allowed). 'LATITUDE' Substation latitude 'LONGITUDE' Substation longitude 'RGROUNDING' Substation grounding dc resistance
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of STATIONS returned by the GET_SUBSTATION_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer STATIONS	number of elements in each column of RARRAY that are set by this API. STATIONS is identical to the value of STATIONS returned by the GET_SUBSTATION_COUNT API when it is called with the same values specified for SID and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid SID value IERR = 3 Invalid FLAG value IERR = 4 Invalid NSTR value IERR = 5 DIM, and hence the size of RARRAY, is not large enough IERR = 6 Invalid STRING value

12.29.5. ASTATIONTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the substation data family (aStationInt, aStationReal and aStationChar).

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, types = astationtypes(string)
```

Fortran command syntax:

```
CALL GET_SUBSTATION_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING ($1 < \text{NSTR} < 50$) (no default allowed) (input).
Character STRING (NSTR)	NSTR of the following strings indicating the substation quantities desired (input; no default allowed).
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output).
	'I' Integer.
	'R' Real.
	'X' Complex.
	'C' Character.
	'?' Invalid STRING value.
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = n Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation data family ($1 < n < \text{NSTR}$)
	IERR = 99 Invalid NSTR value

12.30. Substation Node Data

The substation node data family of subsystem data retrieval APIs returns arrays of data for substation nodes in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for substations with a least one subsystem bus, or to restrict the array entries to data for substations with all of their buses in the subsystem.

Data for subsystem substation nodes is returned from all APIs in the substation node data family in ascending substation number order, and in ascending node number order for each substation.

12.30.1. ANODECHAR

Use this API to return an array of character values for subsystem substation nodes.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, carray = anodechar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_NODE_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, NODES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input).
Integer FLAG	flag indicating which subsystem substations to include (1 by default) (input).
Integer NSTR	number of elements in STRING ($1 < NSTR < 50$) (no default allowed) (input).
Character STRING (NSTR)	NSTR of the following strings indicating the substation quantities desired (input; no default allowed). 'STATIONNAME' Substation name (40 characters). 'NODENAME' Node name (40 characters). 'BUSNAME' Name of the bus to which the node is connected (12 characters). 'BUSEXNAME' Extended bus name of the bus to which the node is connected (18 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of NODES returned by the GET_NODE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements
Integer NODES	number of elements in each column of CARRAY that are set by this API. NODES is identical to the value of NODES returned by the GET_NODES_COUNT API when it is called with the same values specified for SID and FLAG (output).

Integer IERR

error code (output).

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of CARRAY, is not large enough
IERR = 6	Invalid STRING value

12.30.2. ANODECOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the substation node data family.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, nodes = anodecount(sid, flag)
```

Fortran command syntax:

```
CALL GET_NODE_COUNT(SID, FLAG, NODES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).	
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).	
Integer NODES	number of substation nodes in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, NODES returned
	IERR = 1	Working case is empty; NODES returned as 0
	IERR = 2	Invalid SID value; NODES returned as 0
	IERR = 3	Invalid FLAG value; NODES returned as 0

12.30.3. ANODEINT

Use this API to return an array of integer values for subsystem substation nodes.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, iarray = anodeint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_NODE_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, NODES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).												
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).												
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).												
Character STRING (NSTR)	NSTR of the following strings indicating the substation node quantities desired (input; no default allowed). <table> <tr> <td>'STATION'</td><td>Substation number</td></tr> <tr> <td>'NODE'</td><td>Node number</td></tr> <tr> <td>'BUS'</td><td>Number of the bus to which the node is connected</td></tr> <tr> <td>'SECTION'</td><td>Section number of the bus to which the node is connected</td></tr> <tr> <td>'STATUS'</td><td>Node status</td></tr> <tr> <td>'TERMINALS'</td><td>Number of terminals connected to the node</td></tr> </table>	'STATION'	Substation number	'NODE'	Node number	'BUS'	Number of the bus to which the node is connected	'SECTION'	Section number of the bus to which the node is connected	'STATUS'	Node status	'TERMINALS'	Number of terminals connected to the node
'STATION'	Substation number												
'NODE'	Node number												
'BUS'	Number of the bus to which the node is connected												
'SECTION'	Section number of the bus to which the node is connected												
'STATUS'	Node status												
'TERMINALS'	Number of terminals connected to the node												
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of NODES returned by the GET_NODE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).												
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).												
Integer NODES	number of elements in each column of IARRAY that are set by this API. NODES is identical to the value of NODES returned by the GET_NODE_COUNT API when it is called with the same values specified for SID and FLAG (output).												
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = 1</td><td>Working case is empty</td></tr> <tr> <td>IERR = 2</td><td>Invalid SID value</td></tr> <tr> <td>IERR = 3</td><td>Invalid FLAG value</td></tr> <tr> <td>IERR = 4</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = 1	Working case is empty	IERR = 2	Invalid SID value	IERR = 3	Invalid FLAG value	IERR = 4	Invalid NSTR value		
IERR = 0	No error												
IERR = 1	Working case is empty												
IERR = 2	Invalid SID value												
IERR = 3	Invalid FLAG value												
IERR = 4	Invalid NSTR value												

IERR = 5

DIM, and hence the size of IARRAY, is not
large enough

IERR = 6

Invalid STRING value

12.30.4. ANODEREAL

Use this API to return an array of real values for subsystem substation nodes.

This API routine was first introduced in release 34.4.0.

Python command syntax:

```
ierr, rarray = anodereal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_NODE_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, NODES, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the substation node quantities desired (input; no default allowed). 'PU' Node voltage magnitude in per unit 'KV' Node voltage magnitude in kV 'ANGLE' Node voltage angle in radians 'ANGLED' Node voltage angle in degrees
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of NODES returned by the GET_NODE_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer NODES	number of elements in each column of IARRAY that are set by this API. NODES is identical to the value of NODES returned by the GET_NODE_COUNT API when it is called with the same values specified for SID and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid SID value IERR = 3 Invalid FLAG value IERR = 4 Invalid NSTR value IERR = 5 DIM, and hence the size of RARRAY, is not large enough IERR = 6 Invalid STRING value

12.30.5. ANODETYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the substation node data family (aNodeInt and aNodeChar).

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, types = anodetypes(string)
```

Fortran command syntax:

```
CALL GET_NODE_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed); no default allowed										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the substation node data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.31. Substation Switching Device Data

The substation switching device data family of subsystem data retrieval APIs returns arrays of data for substation switching devices in a specified subsystem. One of the input items to each API allows the user to select either to retrieve data for substations with a least one subsystem bus, or to restrict the array entries to data for substations with all of their buses in the subsystem.

Data for subsystem substation switching devices is returned from all APIs in the substation switching device data family in ascending substation number order. For the nodes connected by each switching device, the node with the smaller node number is returned as the "from" node, and the node with the larger node number is returned as the "to" node. Station switching devices for a substation are returned in ascending "from" node number order, and in ascending "to" node number order for each "from" node.

12.31.1. ASTASWDEVCHAR

Use this API to return an array of character values for subsystem substation switching devices.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, carray = astaswdevchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_STASWDEV_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, SWDEVS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).														
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).														
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed) (input).														
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired (input; no default allowed). <table border="0"> <tr> <td>'STATIONNAME'</td><td>Substation name (40 characters).</td></tr> <tr> <td>'FROMNODENAME'</td><td>From node name (40 characters).</td></tr> <tr> <td>'TONODENAME'</td><td>To node name (40 characters).</td></tr> <tr> <td>'ID'</td><td>Switching device identifier (2 characters).</td></tr> <tr> <td>'SWITCHDEVNAME'</td><td>Switching device name (40 characters).</td></tr> <tr> <td>'BUSNAME'</td><td>Name of the bus to which the nodes are connected (12 characters).</td></tr> <tr> <td>'BUSEXNAME'</td><td>Extended bus name of the bus to which the nodes are connected (18 characters).</td></tr> </table>	'STATIONNAME'	Substation name (40 characters).	'FROMNODENAME'	From node name (40 characters).	'TONODENAME'	To node name (40 characters).	'ID'	Switching device identifier (2 characters).	'SWITCHDEVNAME'	Switching device name (40 characters).	'BUSNAME'	Name of the bus to which the nodes are connected (12 characters).	'BUSEXNAME'	Extended bus name of the bus to which the nodes are connected (18 characters).
'STATIONNAME'	Substation name (40 characters).														
'FROMNODENAME'	From node name (40 characters).														
'TONODENAME'	To node name (40 characters).														
'ID'	Switching device identifier (2 characters).														
'SWITCHDEVNAME'	Switching device name (40 characters).														
'BUSNAME'	Name of the bus to which the nodes are connected (12 characters).														
'BUSEXNAME'	Extended bus name of the bus to which the nodes are connected (18 characters).														
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).														

Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SWDEVS	number of elements in each column of CARRAY that are set by this API. SWDEVS is identical to the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.31.2. ASTASWDEVCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the substation switching device data family.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, swdevs = astaswdevcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_STASWDEV_COUNT(SID, FLAG, SWDEVS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer SWDEVS	number of substation switching devices in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).
Integer IERR	error code (output).
	IERR = 0 No error, SWDEVS returned
	IERR = 1 Working case is empty; SWDEVS returned as 0
	IERR = 2 Invalid SID value; SWDEVS returned as 0
	IERR = 3 Invalid FLAG value; SWDEVS returned as 0

12.31.3. ASTASWDEVCPX

Use this API to return an array of complex values for subsystem substation switching devices.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, xarray = astaswdevcplx(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_STASWDEV_COMPLEX(SID, FLAG, NSTR, STRING, DIM, XARRAY, SWDEVS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed) (input).
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired For the following, values are returned in MW and Mvar For the following, values are returned in units determined by the power option setting (input; no default allowed). 'PQ' abs(P+jQ) at the from node end (in MW and Mvar) 'O_PQ' abs(P+jQ) at the from node end (units determined by power output options)
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).
Complex XARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer SWDEVS	number of elements in each column of XARRAY that are set by this API. SWDEVS is identical to the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid SID value IERR = 3 Invalid FLAG value IERR = 4 Invalid NSTR value IERR = 5 DIM, and hence the size of XARRAY, is not large enough IERR = 6 Invalid STRING value

12.31.4. ASTASWDEVINT

Use this API to return an array of integer values for subsystem substation switching devices.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, iarray = astaswdevint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_STASWDEV_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, SWDEVS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).																		
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).																		
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).																		
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired (input; no default allowed). <table> <tr> <td>'STATION'</td><td>Substation number</td></tr> <tr> <td>'FROMNODE'</td><td>From node number</td></tr> <tr> <td>'TONODE'</td><td>To node number</td></tr> <tr> <td>'BUS'</td><td>Number of the bus to which the nodes are connected</td></tr> <tr> <td>'FROMSECTION'</td><td>Section number of the bus to which the from node is connected</td></tr> <tr> <td>'TOSECTION'</td><td>Section number of the bus to which the to node is connected</td></tr> <tr> <td>'TYPE'</td><td>Switching device type (1 through 3)</td></tr> <tr> <td>'STATUS'</td><td>Switching device status</td></tr> <tr> <td>'NSTATUS'</td><td>Switching device normal status</td></tr> </table>	'STATION'	Substation number	'FROMNODE'	From node number	'TONODE'	To node number	'BUS'	Number of the bus to which the nodes are connected	'FROMSECTION'	Section number of the bus to which the from node is connected	'TOSECTION'	Section number of the bus to which the to node is connected	'TYPE'	Switching device type (1 through 3)	'STATUS'	Switching device status	'NSTATUS'	Switching device normal status
'STATION'	Substation number																		
'FROMNODE'	From node number																		
'TONODE'	To node number																		
'BUS'	Number of the bus to which the nodes are connected																		
'FROMSECTION'	Section number of the bus to which the from node is connected																		
'TOSECTION'	Section number of the bus to which the to node is connected																		
'TYPE'	Switching device type (1 through 3)																		
'STATUS'	Switching device status																		
'NSTATUS'	Switching device normal status																		
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).																		
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).																		
Integer SWDEVS	number of elements in each column of IARRAY that are set by this API. SWDEVS is identical to the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (output).																		
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = 1</td><td>Working case is empty</td></tr> </table>	IERR = 0	No error	IERR = 1	Working case is empty														
IERR = 0	No error																		
IERR = 1	Working case is empty																		

IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of IARRAY, is not large enough
IERR = 6	Invalid STRING value

12.31.5. ASTASWDEVREAL

Use this API to return an array of real values for subsystem substation switching devices.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, rarray = astaswdevreal(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_STASWDEV_REAL(SID, FLAG, NSTR, STRING, DIM, RARRAY, SWDEVS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	flag indicating which subsystem substations to include (input; 1 by default).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed) (input).
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired For the following, values are returned in MW, Mvar, or MVA For the following, values are returned in units determined by the power option setting (input; no default allowed).
'X'	Switching device reactance
'RATE1'	Rating from rating set 1
'RATE2'	Rating from rating set 2
'RATE3'	Rating from rating set 3
'AMPS'	Branch current loading in amps
'PUCUR'	Branch current loading in per unit
'PCTRATE1'	Percent current loading of rating set 1
'PCTRATE2'	Percent current loading of rating set 2
'PCTRATE3'	Percent current loading of rating set 3
'PCTMVARATE1'	Percent MVA loading of rating set 1
'PCTMVARATE2'	Percent MVA loading of rating set 2
'PCTMVARATE3'	Percent MVA loading of rating set 3
'P'	Active power flow at the from node end, in MW
'Q'	Reactive power flow at the from node end, in Mvar
'MVA'	abs(P+jQ) at the from node end, in MVA
'O_P'	Active power flow at the from node end (units determined by power output options)
'O_Q'	Reactive power flow at the from node end (units determined by power output options)
'O_MVA'	abs(P+jQ) at the from node end (units determined by power output options)

Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer SWDEVS	number of elements in each column of RARRAY that are set by this API. SWDEVS is identical to the value of SWDEVS returned by the GET_StaSwDev_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of RARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.31.6. ASTASWDEVTYPEPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the substation switching device data family (aStaSwDevInt, aStaSwDevReal, aStaSwDevCplx and aStaSwDevChar).

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, types = astaswdevtypes(string)
```

Fortran command syntax:

```
CALL GET_STASWDEV_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (no default allowed) (input).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the substation node data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table><tr><td>'I'</td><td>Integer.</td></tr><tr><td>'R'</td><td>Real.</td></tr><tr><td>'X'</td><td>Complex.</td></tr><tr><td>'C'</td><td>Character.</td></tr><tr><td>'?'</td><td>Invalid STRING value.</td></tr></table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table><tr><td>IERR = 0</td><td>No error</td></tr><tr><td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation switching device data family (1 < n < NSTR)</td></tr><tr><td>IERR = 99</td><td>Invalid NSTR value</td></tr></table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation switching device data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation switching device data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

12.32. Substation Terminal Data

The substation terminal data family of subsystem data retrieval APIs returns arrays of data for substation terminals in a specified subsystem. One of the input items to each API allows the user to elect either to retrieve data for substations with a least one subsystem bus, or to restrict the array entries to data for substations with all of their buses in the subsystem.

Data for subsystem substation terminals is returned from all APIs in the substation terminal data family in ascending substation number order, and in ascending bus number order for each substation.

12.32.1. ATERMINALCHAR

Use this API to return an array of integer values for subsystem substation terminals.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, carray = aterminalchar(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_TERMINAL_CHAR(SID, FLAG, NSTR, STRING, DIM, CARRAY, TERMINALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired (input; no default allowed).
	'STATIONNAME' Substation name (40 characters).
	'NODENAME' Name of the node to which the terminal is connected (40 characters).
	'BUSNAME' Name of the bus to which the terminal's node is connected (12 characters).
	'BUSEXNAME' Extended bus name of the bus to which the terminal's node is connected (18 characters).
	'OTHER1NAME' Name of another bus connected to this device; returned as blanks except for two-terminal branches and three-winding transformers (12 characters).
	'OTHER1EXNAME' Extended bus name of another bus connected to this device; returned as blanks except for two-terminal branches and three-winding transformers (18 characters).
	'OTHER2NAME' Name of another bus connected to this device; returned as blanks except for three-winding transformers (12 characters).

	'OTHER2EXNAME'	Extended bus name of another bus connected to this device; returned as blanks except for three-winding transformers (18 characters).
	'ID'	Machine, load, fixed shunt, or circuit identifier (2 characters).
	'TERMINALTYPE'	Flag indicating the type of terminal L for Load M for Machine F for Fixed Shunt S for Switched Shunt 2 for AC Line or Two-Winding Transformer 3 for Three-Winding Transformer (1 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of TERMINALS returned by the GET_TERMINAL_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).	
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).	
Integer TERMINALS	number of elements in each column of CARRAY that are set by this API. TERMINALS is identical to the value of TERMINALS returned by the GET_TERMINAL_COUNT API when it is called with the same values specified for SID and FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid FLAG value
	IERR = 4	Invalid NSTR value
	IERR = 5	DIM, and hence the size of CARRAY, is not large enough
	IERR = 6	Invalid STRING value

12.32.2. ATERMINALCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the substation terminal data family.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, terminals = aterminalcount(sid, flag)
```

Fortran command syntax:

```
CALL GET_TERMINAL_COUNT(SID, FLAG, TERMINALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).	
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).	
Integer TERMINALS	number of substation terminals in the subsystem indicated by SID that meet the editing criteria indicated by FLAG (output).	
Integer IERR	error code (output).	
	IERR = 0	No error, TERMINALS returned
	IERR = 1	Working case is empty; TERMINALS returned as 0
	IERR = 2	Invalid SID value; TERMINALS returned as 0
	IERR = 3	Invalid FLAG value; TERMINALS returned as 0

12.32.3. ATERMINALINT

Use this API to return an array of integer values for subsystem substation terminals.

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, iarray = aterterminalint(sid, flag, string)
```

Fortran command syntax:

```
CALL GET_TERMINAL_INTEGER(SID, FLAG, NSTR, STRING, DIM, IARRAY, TERMINALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input; -1).																
Integer FLAG	a flag indicating which subsystem substations to include (input; 1 by default).																
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).																
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired (input; no default allowed). <table border="0"> <tr> <td>'STATION'</td><td>Substation number</td></tr> <tr> <td>'NODE'</td><td>Number of the node to which the terminal is connected</td></tr> <tr> <td>'BUS'</td><td>Number of the bus to which the terminal's node is connected</td></tr> <tr> <td>'SECTION'</td><td>Section number of the bus to which the terminal's node is connected</td></tr> <tr> <td>'OTHER1BUS'</td><td>Number of another bus connected to this device; returned as 0 except for two-terminal branches and three-winding transformers</td></tr> <tr> <td>'OTHER1SECTION'</td><td>Section number of another bus connected to this device; returned as 0 except for two-terminal branches and three-winding transformers</td></tr> <tr> <td>'OTHER2BUS'</td><td>Number of another bus connected to this device; returned as 0 except for three-winding transformers</td></tr> <tr> <td>'OTHER2SECTION'</td><td>Section number of another bus connected to this device; returned as 0 except for three-winding transformers</td></tr> </table>	'STATION'	Substation number	'NODE'	Number of the node to which the terminal is connected	'BUS'	Number of the bus to which the terminal's node is connected	'SECTION'	Section number of the bus to which the terminal's node is connected	'OTHER1BUS'	Number of another bus connected to this device; returned as 0 except for two-terminal branches and three-winding transformers	'OTHER1SECTION'	Section number of another bus connected to this device; returned as 0 except for two-terminal branches and three-winding transformers	'OTHER2BUS'	Number of another bus connected to this device; returned as 0 except for three-winding transformers	'OTHER2SECTION'	Section number of another bus connected to this device; returned as 0 except for three-winding transformers
'STATION'	Substation number																
'NODE'	Number of the node to which the terminal is connected																
'BUS'	Number of the bus to which the terminal's node is connected																
'SECTION'	Section number of the bus to which the terminal's node is connected																
'OTHER1BUS'	Number of another bus connected to this device; returned as 0 except for two-terminal branches and three-winding transformers																
'OTHER1SECTION'	Section number of another bus connected to this device; returned as 0 except for two-terminal branches and three-winding transformers																
'OTHER2BUS'	Number of another bus connected to this device; returned as 0 except for three-winding transformers																
'OTHER2SECTION'	Section number of another bus connected to this device; returned as 0 except for three-winding transformers																
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of TERMINALS returned by the GET_TERMINAL_COUNT API when it is called with the same values specified for SID and FLAG (input; no default allowed).																
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).																

Integer TERMINALS

number of elements in each column of IARRAY that are set by this API. TERMINALS is identical to the value of TERMINALS returned by the GET_TERMINAL_COUNT API when it is called with the same values specified for SID and FLAG (output).

Integer IERR

error code (output).

IERR = 0	No error
IERR = 1	Working case is empty
IERR = 2	Invalid SID value
IERR = 3	Invalid FLAG value
IERR = 4	Invalid NSTR value
IERR = 5	DIM, and hence the size of IARRAY, is not large enough
IERR = 6	Invalid STRING value

12.32.4. ATERMINALTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the substation terminal data family (aTerminalInt and aTerminalChar).

This API routine was first introduced in release 34.1.0.

Python command syntax:

```
ierr, types = aterminaltypes(string)
```

Fortran command syntax:

```
CALL GET_TERMINAL_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the substation switching device quantities desired (input; no default allowed).
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output).
	'I' Integer.
	'R' Real.
	'X' Complex.
	'C' Character.
	'?' Invalid STRING value.
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = n Position of the first element STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the substation terminal data family (1 < n < NSTR)
	IERR = 99 Invalid NSTR value

12.33. Zero Sequence Mutuals Data

12.33.1. AZMUTCHAR

Use this API to return an array of character values for subsystem zero sequence mutual branches.

This API routine was first introduced in release 33.12.0 and 34.0.2.

Python command syntax:

```
ierr, carray = azmutchar(sid, owner, ties, flag, brns, string)
```

Fortran command syntax:

```
CALL  
GET_ZMUT_CHAR(SID, OWNER, TIES, FLAG, BRNS, NSTR, STRING, DIM, CARRAY, MUTUALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1).	
	SID < 0	to instruct the API to assume a subsystem containing all buses in the working case.
	SID >= 0	valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default).	
	OWNER = 1	to use bus ownership.
	OWNER = 2	to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	TIES = 1	for interior subsystem branches only.
	TIES = 2	for subsystem tie branches only.
	TIES = 3	for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default).	
	FLAG = 1	for both mutually coupled branches must be in-service
	FLAG = 2	for all mutually coupled branches
Integer BRNS	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default).	
	BRNS = 1	for at least one mutually coupled branch in subsystem
	BRNS = 2	for both mutually coupled branches in subsystem

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the branch zero sequence mutual quantities desired (input; no default allowed).
	'BR1_FROMNAME' Bus name of Branch1 From Bus (12 characters).
	'BR1_FROMEXNAME' Extended Bus name of Branch1 From Bus (18 characters).
	'BR1_TONAME' Bus name of Branch1 To Bus (12 characters).
	'BR1_TOEXNAME' Extended Bus name of Branch1 To Bus (18 characters).
	'BR1_ID' Branch1 Circuit identifier (2 characters).
	'BR2_FROMNAME' Bus name of Branch2 From Bus (12 characters).
	'BR2_FROMEXNAME' Extended Bus name of Branch2 From Bus (18 characters).
	'BR2_TONAME' Bus name of Branch2 To Bus (12 characters).
	'BR2_TOEXNAME' Extended Bus name of Branch2 To Bus (18 characters).
	'BR2_ID' Branch2 Circuit identifier (2 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (input; no default allowed).
Character CARRAY (NSTR*DIM)	array of at least NSTR columns, each of which contains DIM elements (output).
Integer MUTUALS	number of elements in each column of RARRAY that are set by this API. MUTUALS is identical to the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Working case is empty
	IERR = 2 Invalid SID value
	IERR = 3 Invalid OWNER value
	IERR = 4 Invalid TIES value
	IERR = 5 Invalid FLAG value
	IERR = 6 Invalid BRNS value
	IERR = 7 Invalid NSTR value
	IERR = 8 DIM, and hence the size of CARRAY, is not large enough
	IERR = 9 Invalid STRING value
	IERR = 10 Sequence data not in case

12.33.2. AZMUTCOUNT

Use this API to return the number of array entries required to accommodate the data to be returned by the remaining members of the branch zero sequence mutual data family.

This API routine was first introduced in release 33.12.0 and 34.0.2.

Python command syntax:

```
ierr, mutuals = azmutcount(sid, owner, ties, flag, brns)
```

Fortran command syntax:

```
CALL GET_ZMUT_COUNT(SID, OWNER, TIES, FLAG, BRNS, MUTUALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem branches only. TIES = 2 for subsystem tie branches only. TIES = 3 for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for both mutually coupled branches must be in-service FLAG = 2 for all mutually coupled branches
Integer BRNS	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). BRNS = 1 for at least one mutually coupled branch in subsystem BRNS = 2 for both mutually coupled branches in subsystem
Integer MUTUALS	number of array entries required for the subsystem indicated by SID and OWNER that meet the editing criteria indicated by TIES, FLAG and BRNS. (output).
Integer IERR	error code (output).

IERR = 0	No error, MUTUALS returned
IERR = 1	Working case is empty; MUTUALS returned as 0
IERR = 2	Invalid SID value; MUTUALS returned as 0
IERR = 3	Invalid OWNER value; MUTUALS returned as 0
IERR = 4	Invalid TIES value; MUTUALS returned as 0
IERR = 5	Invalid FLAG value; MUTUALS returned as 0
IERR = 6	Invalid BRNS value; MUTUALS returned as 0
IERR = 10	Sequence data not in case

12.33.3. AZMUTCPLX

Use this API to return an array of complex values for subsystem zero sequence mutual branches.

This API routine was first introduced in release 33.12.0 and 34.0.2.

Python command syntax:

```
ierr, xarray = azmutcplx(sid, owner, ties, flag, brns, string)
```

Fortran command syntax:

```
CALL  
GET_ZMUT_COMPLEX(SID, OWNER, TIES, FLAG, BRNS, NSTR, STRING, DIM, XARRAY, MUTUALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem branches only. TIES = 2 for subsystem tie branches only. TIES = 3 for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for both mutually coupled branches must be in-service FLAG = 2 for all mutually coupled branches
Integer BRNS	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). BRNS = 1 for at least one mutually coupled branch in subsystem BRNS = 2 for both mutually coupled branches in subsystem
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the branch zero sequence mutual quantities desired (input; no default allowed).

	'ZM'	PU Mutual coupling impedance
Integer DIM	number of elements in each column of the array XARRAY. DIM must be as least as large as the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (input; no default allowed).	
Complex XARRAY (NSTR*DIM)	array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MUTUALS	number of elements in each column of RARRAY that are set by this API. MUTUALS is identical to the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid BRNS value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of XARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case

12.33.4. AZMUTINT

Use this API to return an array of integer values for subsystem zero sequence mutual branches.

This API routine was first introduced in release 33.12.0 and 34.0.2.

Python command syntax:

```
ierr, iarray = azmutint(sid, owner, ties, flag, brns, string)
```

Fortran command syntax:

```
CALL  
GET_ZMUT_INTEGER(SID, OWNER, TIES, FLAG, BRNS, NSTR, STRING, DIM, IARRAY, MUTUALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem branches only. TIES = 2 for subsystem tie branches only. TIES = 3 for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for both mutually coupled branches must be in-service FLAG = 2 for all mutually coupled branches
Integer BRNS	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). BRNS = 1 for at least one mutually coupled branch in subsystem BRNS = 2 for both mutually coupled branches in subsystem
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the branch zero sequence mutual quantities desired (input; no default allowed).

	'BR1_FROMNUMBER'	Bus number of Branch1 From Bus
	'BR1_TONUMBER'	Bus number of Branch1 To Bus
	'BR2_FROMNUMBER'	Bus number of Branch2 From Bus
	'BR2_TONUMBER'	Bus number of Branch2 To Bus
	'BR1_FROMSECTION'	Section number of Branch1 From Bus
	'BR1_TOSECTION'	Section number of Branch1 To Bus
	'BR2_FROMSECTION'	Section number of Branch2 From Bus
	'BR2_TOSECTION'	Section number of Branch2 To Bus
Integer DIM	number of elements in each column of the array IARRAY. DIM must be as least as large as the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (input; no default allowed).	
Integer IARRAY (NSTR*DIM)	array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MUTUALS	number of elements in each column of RARRAY that are set by this API. MUTUALS is identical to the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid BRNS value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of IARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case

12.33.5. AZMUTREAL

Use this API to return an array of real values for subsystem zero sequence mutual branches.

This API routine was first introduced in release 33.12.0 and 34.0.2.

Python command syntax:

```
ierr, rarray = azmutreal(sid, owner, ties, flag, brns, string)
```

Fortran command syntax:

```
CALL  
GET_ZMUT_REAL (SID, OWNER, TIES, FLAG, BRNS, NSTR, STRING, DIM, RARRAY, MUTUALS, IERR)
```

Where:

Integer SID	Defines the bus subsystem to be used (input-1). SID < 0 to instruct the API to assume a subsystem containing all buses in the working case. SID >= 0 valid bus subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined.
Integer OWNER	a flag indicating owner usage if ownership is a subsystem selection criterion (ignored if SID is negative) (input; 1 by default). OWNER = 1 to use bus ownership. OWNER = 2 to use branch ownership.
Integer TIES	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). TIES = 1 for interior subsystem branches only. TIES = 2 for subsystem tie branches only. TIES = 3 for both interior subsystem branches and tie branches.
Integer FLAG	a flag indicating which subsystem branches to include (input; 1 by default). FLAG = 1 for both mutually coupled branches must be in-service FLAG = 2 for all mutually coupled branches
Integer BRNS	a flag indicating which subsystem branches to include (ignored if SID is negative) (input; 1 by default). BRNS = 1 for at least one mutually coupled branch in subsystem BRNS = 2 for both mutually coupled branches in subsystem
Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the branch zero sequence mutual quantities desired (input; no default allowed).

	'BR1_LOC_START'	Branch1 mutual coupling start location
	'BR1_LOC_END'	Branch1 mutual coupling end location
	'BR2_LOC_START'	Branch2 mutual coupling start location
	'BR2_LOC_END'	Branch2 mutual coupling end location
Integer DIM	number of elements in each column of the array RARRAY. DIM must be as least as large as the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (input; no default allowed).	
Real RARRAY (NSTR*DIM)	array of at least NSTR columns, each of which contains DIM elements (output).	
Integer MUTUALS	number of elements in each column of RARRAY that are set by this API. MUTUALS is identical to the value of MUTUALS returned by the GET_ZMUT_COUNT API when it is called with the same values specified for SID, OWNER, TIES, FLAG and BRNS. (output).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Working case is empty
	IERR = 2	Invalid SID value
	IERR = 3	Invalid OWNER value
	IERR = 4	Invalid TIES value
	IERR = 5	Invalid FLAG value
	IERR = 6	Invalid BRNS value
	IERR = 7	Invalid NSTR value
	IERR = 8	DIM, and hence the size of RARRAY, is not large enough
	IERR = 9	Invalid STRING value
	IERR = 10	Sequence data not in case

12.33.6. AZMUTTYPES

Use this API to return an array of character values indicating the data types corresponding to a set of specified STRING values that are valid input values to any of the data retrieval routines of the branch zero sequence mutual data family (aZmutInt, aZmutReal, aZmutCplx and aZmutChar).

This API routine was first introduced in release 33.12.0 and 34.0.2.

Python command syntax:

```
ierr, types = azmuttypes(string)
```

Fortran command syntax:

```
CALL GET_ZMUT_TYPES(NSTR, STRING, TYPES, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).										
Character STRING (NSTR)	NSTR strings that are valid STRING values for any of the data retrieval routines of the branch data family (input; no default allowed).										
Character*1 TYPES (NSTR)	each of which contains one of the following characters indicating the data type of the data associated with the corresponding element of STRING (output). <table> <tr> <td>'I'</td><td>Integer.</td></tr> <tr> <td>'R'</td><td>Real.</td></tr> <tr> <td>'X'</td><td>Complex.</td></tr> <tr> <td>'C'</td><td>Character.</td></tr> <tr> <td>'?'</td><td>Invalid STRING value.</td></tr> </table>	'I'	Integer.	'R'	Real.	'X'	Complex.	'C'	Character.	'?'	Invalid STRING value.
'I'	Integer.										
'R'	Real.										
'X'	Complex.										
'C'	Character.										
'?'	Invalid STRING value.										
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = n</td><td>Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch data family (1 < n < NSTR)</td></tr> <tr> <td>IERR = 99</td><td>Invalid NSTR value</td></tr> </table>	IERR = 0	No error	IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch data family (1 < n < NSTR)	IERR = 99	Invalid NSTR value				
IERR = 0	No error										
IERR = n	Position of the first element in STRING that contains a value that is not a valid STRING value for any of the data retrieval routines in the branch data family (1 < n < NSTR)										
IERR = 99	Invalid NSTR value										

Chapter 13

Graphical Analysis Output

This chapter defines API routines that interact with displays and files associated with the graphical analysis capabilities of the PSS®E GUI. They will elicit no action if a GUI is not present when invoked.

13.1. POLY_PRINT

Use this API to print the results of activity POLY from a .pol results file.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_POLY_PRINT  NPLOT  PLOTARRAY(1)..PLOTARRAY(NPLOT)  BOUNDVAL  PRTPARAMS  
RESFILE
```

Python command syntax:

```
poly_print(npplot, plotarray, boundval, prtparams, resfile)
```

Fortran command syntax:

```
CALL POLY_PRINT(NPLOT, PLOTARRAY, BOUNDVAL, PRTPARAMS, RESFILE)
```

Where:

Integer NPLOT	number of plots (input).
Integer PLOTARRAY (NPLOT)	an array of the numbers of plots, selected for printing. The base case is marked by 0, then there are all the contingencies, beginning from 1, and the last number means all the cases together. The array consists of the set of these numbers. The size of the array is equal to NPLOT (input).
Real BOUNDVAL	boundary value for the plot area. It is equal to maximum opposing system delta interchange used for calculations (input).
Integer PRTPARAMS	print (or not) the set of parameters used for calculations (input). PRTPARAMS = 0 no printing of parameters. PRTPARAMS = 1 the set of parameters will be printed.
Character*260 RESFILE	name of the existing POLY results file (.pol) file (input).

13.2. PV_PRINT

Use this API to print the results of PV analysis from the .pv results file

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_PV_PRINT RESFILE RESTYPE NCONTING CONTINGARRAY(1)..
CONTINGARRAY(NCONTING) NOUTPUTS OUTPUTSARRAY(1)..
OUTPUTSARRAY(NOUTPUTS) INTERFACE ENFORCESCALE USELINESTYLES
NUMBERLINES PRTPARAMS
```

Python command syntax:

```
pv_print(resfile, restype, nconting, contingarray, noutputs, outputsarray,
interface, enforcescale, uselinestyles, numberlines, prtparams)
```

Fortran command syntax:

```
CALL PV_PRINT(RESFILE, RESTYPE, NCONTING, CONTINGARRAY, NOUTPUTS,
OUTPUTSARRAY, INTERFACE, ENFORCESCALE, USELINESTYLES, NUMBERLINES,
PRTPARAMS)
```

Where:

Character*260 RESFILE	name of the existing .pv file (input).
Integer RESTYPE	type of the results (input). RESTYPE = 0 bus voltage RESTYPE = 1 generator MW RESTYPE = 2 branch MVA flow RESTYPE = 3 interface MW flow RESTYPE = 4 bus voltage against interface flow
Integer NCONTING	number of specified contingencies (input).
Integer CONTINGARRAY (NCONTING)	an array of the numbers of specified contingencies. The base case is marked by 0. The size of the array is equal to NCONTING (input).
Integer NOUTPUTS	number of specified outputs (input).
Integer OUTPUTSARRAY (NOUTPUTS)	an array of the numbers of specified outputs. The count starts from 0. The size of the array is equal to NOUTPUTS (input).
Integer INTERFACE	number of specified interface. Valid only in case of bus voltage against interface flow (RESTYPE = 4) (input).
Integer ENFORCESCALE	allows to print the results with the different scales (input). ENFORCESCALE = 0 the scales will be not changed according with the results; this allows to print the results from different files in the same scales. ENFORCESCALE = 1 the maximum and minimum values for the used scales will be taken from the file of results, and the printing will be done according with these values.

Integer USELINESTYLES	use (or not) different line styles for plotting (input). USELINESTYLES = 0 all the lines will be solid USELINESTYLES = 1 five different (standard) styles of lines will be used: Solid, Dash-Dash, Dot-Dot, Dash-Dot, Dash-Dot-Dot.
Integer NUMBERLINES	put the numbers (or not) on the graphs (input). NUMBERLINES = 0 no numbering of the graphs. NUMBERLINES = 1 each graph will have its number for better recognition
Integer PRTPARAMS	print (or not) the set of parameters used for calculations (input). PRTPARAMS = 0 no printing of parameters PRTPARAMS = 1 the set of parameters will be printed

13.3. QV_PRINT

Use this API to print the results of QV analysis from a .qv resultsfile.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_QV_PRINT RESFILE NCONTING CONTINGARRAY(1).. CONTINGARRAY(NCONTING)
ENFORCESCALE USELINESTYLES NUMBERLINES PRTPARAMS
```

Python command syntax:

```
qv_print(resfile, nconting, contingarray, enforcescale, uselinestyles,
numberlines, prtparams)
```

Fortran command syntax:

```
CALL QV_PRINT(RESFILE, NCONTING, CONTINGARRAY, ENFORCESCALE,
USELINESTYLES, NUMBERLINES, PRTPARAMS)
```

Where:

Character*260 RESFILE	name of the existing .qv file (input).
Integer NCONTING	number of specified contingencies (input).
Integer CONTINGARRAY (NCONTING)	array of the numbers of specified contingencies. The base case is marked by 0. The size of the array is equal to NCONTING (input).
Integer ENFORCESCALE	allows to print the results with the different scales (input). ENFORCESCALE = 0 the scales will be not changed according with the results; this allows to print the results from different files in the same scales ENFORCESCALE = 1 the maximum and minimum values for the used scales will be taken from the file of results, and the printing will be done according with these values
Integer USELINESTYLES	use (or not) different line styles for plotting (input). USELINESTYLES = 0 all the lines will be solid USELINESTYLES = 1 five different (standard) styles of lines will be used: Solid, Dash-Dash, Dot-Dot, Dash-Dot, Dash-Dot-Dot
Integer NUMBERLINES	put the numbers (or not) on the graphs (input). NUMBERLINES = 0 no numbering of the graphs NUMBERLINES = 1 each graph will have its number for better recognition
Integer PRTPARAMS	print (or not) the set of parameters used for calculations (input). PRTPARAMS = 0 no printing of parameters PRTPARAMS = 1 the set of parameters will be printed

13.4. SETFULLVIEWGRAPHAREA

Use this API to specify the parameters of the scales used for plotting the results of PV and QV analysis.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETFULLVIEWGRAPHAREA AREA VAXISSHOW VAXISSTYLE VAXISCLR(1)..
VAXISCLR(3) VGRIDSHOW VGRIDSTYLE VGRIDCLR(1).. VGRIDCLR(3)
HAXISSHOW HAXISSTYLE HAXISCLR(1).. HAXISCLR(3) HGRIDSHOW HGRIDSTYLE
HGRIDCLR(1).. HGRIDCLR(3) BORDERSHOW BORDERSTYLE BORDERCLR(1)..
BORDERCLR(3) SETAREACLr AREACLr(1).. AREACLr(3)
```

Python command syntax:

```
setfullviewgrapharea(area, vaxisshow, vaxisstyle, vaxisclr, vgridshow,
vgridstyle, vgridclr, haxisshow, haxisstyle, haxisclr, hgridshow,
hgridstyle, hgridclr, bordershow, borderstyle, borderclr, setareaclr,
areaclr)
```

Fortran command syntax:

```
CALL SETFULLVIEWGRAPHAREA(AREA, VAXISSHOW, VAXISSTYLE, VAXISCLR,
VGRIDSHOW, VGRIDSTYLE, VGRIDCLR, HAXISSHOW, HAXISSTYLE, HAXISCLR,
HGRIDSHOW, HGRIDSTYLE, HGRIDCLR, BORDERSHOW, BORDERSTYLE, BORDERCLR,
SETAREACLr, AREACLr)
```

Where:

Integer AREA	number of the plotting area (input). AREA = 0 QV analysis, area for Q(V) plot AREA = 1 QV analysis, area for mismatch plot AREA = 2 PV analysis, area for bus voltage AREA = 3 PV analysis, area for generator MW AREA = 4 PV analysis, area for branch MVA flow AREA = 5 PV analysis, area for interface MW flow AREA = 6 PV analysis, area for bus voltage against inter- face flow.
Integer VAXISSHOW	show (or not) the vertical axis (input).
Integer VAXISSTYLE	style of the vertical axis. Valid only if VAXISSHOW=1 (input). VAXISSTYLE = 0 solid line VAXISSTYLE = 1 dash - dash - dash line VAXISSTYLE = 2 dot - dot - dot line VAXISSTYLE = 3 dash - dot line VAXISSTYLE = 4 dash - dot - dot line
Integer VAXISCLR (3)	array of 3 elements specifying color of the vertical axis. Valid only if VAXISSHOW=1(input). VAXISCLR(1) Red component; the value between 0 and 255

	VAXISCLR(2)	Green component; the value between 0 and 255
	VAXISCLR(3)	Blue component; the value between 0 and 255
Integer VGRIDSHOW	show (or not) the vertical grid (input).	
Integer VGRIDSTYLE	style of the vertical grid. Valid only if VGRIDSHOW =1 (input).	
	VGRIDSTYLE = 0	solid line
	VGRIDSTYLE = 1	dash - dash - dash line
	VGRIDSTYLE = 2	dot - dot - dot line
	VGRIDSTYLE = 3	dash - dot line
	VGRIDSTYLE = 4	dash - dot - dot line
Integer VGRIDCLR (3)	array of 3 elements specifying color of the vertical grid. Valid only if VGRIDSHOW =1(input).	
	VGRIDCLR(1)	Red component; the value between 0 and 255
	VGRIDCLR(2)	Green component; the value between 0 and 255
	VGRIDCLR(3)	Blue component; the value between 0 and 255
Integer HAXISSHOW	show (or not) the horizontal axis (input).	
Integer HAXISSTYLE	style of the horizontal axis. Valid only if HAXISSHOW=1 (input).	
	HAXISSTYLE = 0	solid line
	HAXISSTYLE = 1	dash - dash - dash line
	HAXISSTYLE = 2	dot - dot - dot line
	HAXISSTYLE = 3	dash - dot line
	HAXISSTYLE = 4	dash - dot - dot line
Integer HAXISCLR (3)	array of 3 elements specifying color of the horizontal axis. Valid only if HAXISSHOW=1(input).	
	HAXISCLR(1)	Red component; the value between 0 and 255
	HAXISCLR(2)	Green component; the value between 0 and 255
	HAXISCLR(3)	Blue component; the value between 0 and 255
Integer HGRIDSHOW	show (or not) the horizontal grid (input).	
Integer HGRIDSTYLE	style of the horizontal grid. Valid only if HGRIDSHOW =1 (input).	
	HGRIDSTYLE = 0	solid line
	HGRIDSTYLE = 1	dash - dash - dash line
	HGRIDSTYLE = 2	dot - dot - dot line
	HGRIDSTYLE = 3	dash - dot line
	HGRIDSTYLE = 4	dash - dot - dot line
Integer HGRIDCLR (3)	array of 3 elements specifying color of the horizontal grid. Valid only if HGRIDSHOW =1(input).	

	HGRIDCLR(1)	Red component; the value between 0 and 255
	HGRIDCLR(2)	Green component; the value between 0 and 255
	HGRIDCLR(3)	Blue component; the value between 0 and 255
Integer BORDERSHOW	show (or not) the border around the plot (input).	
Integer BORDERSTYLE	style of the border. Valid only if BORDERSHOW =1 (input).	
	BORDERSTYLE = 0	solid line
	BORDERSTYLE = 1	dash - dash - dash line
	BORDERSTYLE = 2	dot - dot - dot line
	BORDERSTYLE = 3	dash - dot line
	BORDERSTYLE = 4	dash - dot - dot line
Integer BORDERCLR (3)	array of 3 elements specifying color of the border. Valid only if BORDERSHOW =1(input).	
	BORDERCLR(1)	Red component; the value between 0 and 255
	BORDERCLR(2)	Green component; the value between 0 and 255
	BORDERCLR(3)	Blue component; the value between 0 and 255
Integer SETAREACL	set (or not) the back color of the plotting area (input).	
Integer AREACL (3)	array of 3 elements specifying color of the plotting area. Valid only if SETAREACL =1(input).	
	AREACL(1)	Red component; the value between 0 and 255
	AREACL(2)	Green component; the value between 0 and 255
	AREACL(3)	Blue component; the value between 0 and 255

13.5. SETFULLVIEWSCALE

Use this API to specify the parameters of the scales used for plotting the results of PV and QV analysis.

This API routine was first introduced in release 30.0.0.

Batch command syntax:

```
BAT_SETFULLVIEWSCALE SCALE LTVAL RBVAL ADJUST(1) ADJUST(2) AXISPLACE
  AXISVALUE GRIDCALCTYPE GRIDSTEP GRIDMINLINES SHOWNUM (1).. SHOWNUM(3)
  LTPOS INPOS RBPOS LTPLACES INPLACES RBPLACES
```

Python command syntax:

```
setfullviewscale(scale, ltval, rbval, adjust, axisplace, axisvalue,
  gridcalctype, gridstep, gridminlines, shownum, ltpos, inpos, rbpos,
  ltplaces, inplaces, rbplaces)
```

Fortran command syntax:

```
CALL SETFULLVIEWSCALE(SCALE, LTVAL, RBVAL, ADJUST, AXISPLACE, AXISVALUE,
  GRIDCALCTYPE, GRIDSTEP, GRIDMINLINES, SHOWNUM, LTPOS, INPOS, RBPOS,
  LTPLACES, INPLACES, RBPLACES)
```

Where:

Integer SCALE	number of the scale (input).
SCALE = 0	QV analysis, horizontal scale for Q(V) plot
SCALE = 1	QV analysis, vertical scale for Q(V) plot
SCALE = 2	QV analysis, vertical scale for mismatch plot
SCALE = 3	PV analysis, horizontal scale for incremental transfer
SCALE = 4	PV analysis, horizontal scale for interface MW flow (bus voltage against interface flow)
SCALE = 5	PV analysis, vertical scale for bus voltage
SCALE = 6	PV analysis, vertical scale for generator MW
SCALE = 7	PV analysis, vertical scale for branch MVA flow
SCALE = 8	PV analysis, vertical scale for interface MW flow
SCALE = 9	PV analysis, vertical scale for bus voltage (bus voltage against interface flow)
Real LTVAL	left value (for horizontal scale) or top value (for vertical scale) (input).
Real RBVAL	right value (for horizontal scale) or bottom value (for vertical scale) (input).
Integer ADJUST (2)	array of 2 elements specifying (input).
ADJUST(1)	to adjust (or not) the left (top) value of the scale

	ADJUST(2)	to adjust (or not) the right (bottom) value of the scale
Integer AXISPLACE	place of the axis (input). AXISPLACE = 0 on the left (top) border AXISPLACE = 1 the axis place is set in AXISVALUE AXISPLACE = 2 on the right (bottom) border AXISPLACE = 3 undefined, the exact value will be calculated	
Real AXISVALUE	place of the axis. Valid only in case AXISPLACE = 1 (input).	
Integer GRIDCALCTYPE	way the grid is calculated (input). GRIDCALCTYPE = 0 grid step is set in GRIDSTEP GRIDCALCTYPE = 1 grid is defined by minimum grid lines set in GRIDMINLINES	
Real GRIDSTEP	step of the grid. Valid only in case GRIDCALCTYPE = 0 (input).	
Integer GRIDMINLINES	Minimum number of the grid lines. Valid only in case GRIDCALCTYPE = 1 (input).	
Integer SHOWNUM (3)	array of 3 elements specifying (input). SHOWNUM(1) to show (or not) the left (top) value of the scale SHOWNUM(2) to show (or not) all the intermediate values for the grid SHOWNUM(3) to show (or not) the right (bottom) value of the scale	
Integer LTPOS	place of the left (top) value relative to the left (top) border (input). LTPOS = 0 to the left of the border (above the border) LTPOS = 1 centered to the border LTPOS = 2 to the right of the border (below the border)	
Integer INPOS	place of the intermediate values relative to the intermediate grid lines (input). INPOS = 0 to the left of the line (above the line) INPOS = 1 centered to the line INPOS = 2 to the right of the line (below the line)	
Integer RBPOS	place of the right (bottom) value relative to the right (bottom) border (input). RBPOS = 0 to the left of the border (above the border) RBPOS = 1 centered to the border RBPOS = 2 to the right of the border (below the border)	
Integer LTPLACES	number of digits to the right of the decimal point for the left (top) value (input).	
Integer INPLACES	number of digits to the right of the decimal point for intermediate values (input).	
Integer RBPLACES	number of digits to the right of the decimal point for the right (bottom) value (input).	

Chapter 14

Scenarios

14.1. CLOSESCENARIOFILE

This API routine is obsolete. It has been replaced by the API routine [SCENARIOCLOSE](#) .

Use this API to close the currently open Scenario. If a file in the active group has was specified to "Load Last", this file will be opened prior to the closing of the Scenario.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CLOSESCENARIOFILE
```

Python command syntax:

```
closescenariofile()
```

Fortran command syntax:

```
CALL CLOSESCENARIOFILE()
```

14.2. NEWSCENARIOFILE

This API routine is obsolete. It has been replaced by the API routine [SCENARIONEW](#) .

Use this API to create a new Scenario. At least one group must be added to the Scenario through SCENARIOGROUPADD before files may be added to it. If adding files through file tracking is also desired, a group must become the active group which can be done by calling SCENARIOGROUPOPEN.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_NEWSCENARIOFILE  SFILE
```

Python command syntax:

```
newscenariofile(sfile)
```

Fortran command syntax:

```
CALL NEWSCENARIOFILE(SFILE)
```

Where:

Character*260 SFILE	full file path of the new scenario file (input; blank by default. The name of the Scenario will be determined by the file name portion of the full file path. When the default is used no name is given to the Scenario and a full file name will be required upon saving. The root path of the Scenario will be determined by the path portion of the full file path. When the default is used the root path will default to the current working directory).
---------------------	---

14.3. OPENSENARIOFILE

This API routine is obsolete. It has been replaced by the API routine [SCENARIOOPEN](#) .

Use this API to open a previously created Scenario.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPENSENARIOFILE SFILE
```

Python command syntax:

```
openscenariofile(sfile)
```

Fortran command syntax:

```
CALL OPENSENARIOFILE(SFILE)
```

Where:

Character*260 SFILE	full file path of the scenario file to open (input; no default allowed).
---------------------	--

14.4. SAVESCENARIOFILE

This API routine is obsolete. It has been replaced by the API routine [SCENARIOSAVE](#) .

Use this API to save the currently open Scenario.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SAVESCENARIOFILE  SFILE
```

Python command syntax:

```
savescenariofile(sfile)
```

Fortran command syntax:

```
CALL SAVESCENARIOFILE (SFILE)
```

Where:

Character*260 SFILE	full file path to save the scenario file to (input; unchanged by default. When the default is used the Scenario will be saved to the last file-name given in a SCENARIONEW, SCENARIOOPEN, or SCENARIOSAVE operation, if a call to SCENARIONEW with default arguments was the previous call, the Scenario will not be saved due to no previous file-name being available).
---------------------	---

14.5. SCENARIOCLOSE

Use this API to close the currently open Scenario. If a file in the active group has been specified to "Load Last", this file will be opened prior to the closing of the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOCLOSE
```

Python command syntax:

```
ierr = scenarioclose()
```

Fortran command syntax:

```
CALL SCENARIOCLOSE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory

14.6. SCENARIOCOPYFILE

Use this API to copy a file from one group to another group.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOCOPYFILE SRCGROUP SFILE DSTGROUP
```

Python command syntax:

```
ierr = scenariocopyfile(srcgroup, sfile, dstgroup)
```

Fortran command syntax:

```
CALL SCENARIOCOPYFILE(SRCGROUP, SFILE, DSTGROUP, IERR)
```

Where:

Character*72 SRCGROUP	name of the group containing the file to be copied (input; no default allowed).	
Character*260 SFILE	name of the file to be copied (input; no default allowed).	
Character*72 DSTGROUP	name of the group the file will be copied to (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid file name
	IERR = 3	specified group not found
	IERR = 4	specified file not found

14.7. SCENARIOFILEADD

Use this API to add a file to the specified group.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOFILEADD SGROUP SFILE STYPE LOAD SARGS
```

Python command syntax:

```
ierr = scenariofileadd(sgroup, sfile, stype, load, sargs)
```

Fortran command syntax:

```
CALL SCENARIOFILEADD(SGROUP, SFILE, STYPE, LOAD, SARGS, IERR)
```

Where:

Character*72 SGROUP	name of the group to add a file to (input; no default allowed).	
Character*260 SFILE	name of the file to add (input; no default allowed).	
Character*8 STYPE	file type identifier for the specified file (input; blank by default).	
Integer LOAD	file's position in the load order of its group. A load order of 0 specifies that the file is not loaded (input; 0 by default).	
Character*260 SARGS	argument string to be used for the file when automatically opening the file (input; blank by default).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid file name
	IERR = 3	specified group not found

14.8. SCENARIOFILECOUNT

Use this API to retrieve the number of files in a specified group in the Scenario.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, nfiles = scenariofilecount(sgroup)
```

Fortran command syntax:

```
CALL SCENARIOFILECOUNT(SGROUP, NFILES, IERR)
```

Where:

Character*72 SGROUP	group to retrieve the file count of input (input; ignored).
Integer NFILES	number of the files in the specified group (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found

14.9. SCENARIOFILEGETATTRS

Use this API to retrieve the attributes of the specified file.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, stype, load, sargs = scenariofilegetattrs(sgroup, sfile)
```

Fortran command syntax:

```
CALL SCENARIOFILEGETATTRS(SGROUP, SFILE, STYPE, LOAD, SARGS, IERR)
```

Where:

Character*72 SGROUP	group that contains the specified file (input; no default allowed).	
Character*260 SFILE	name of the file whose attributes are to be retrieved (input; no default allowed).	
Character*8 STYPE	file type identifier for the specified file (output).	
Integer LOAD	Denotes the file's position in the load order of its group. A load order of 0 specifies that the file is not loaded (output).	
Character*260 SARGS	argument string to be used for the file when automatically opening the file (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 3	specified group not found
	IERR = 4	specified file not found

14.10. SCENARIOFILEGETCOMMENTS

Use this API to retrieve the comments for the specified file.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, comments = scenariofilegetcomments(sgroup, sfile)
```

Fortran command syntax:

```
CALL SCENARIOFILEGETCOMMENTS(SGROUP, SFILE, COMMENTS, IERR)
```

Where:

Character*72 SGROUP	group that contains the specified file (input; no default allowed).
Character*260 SFILE	name of the file whose attributes are to be retrieved (input; no default allowed).
Character COMMENTS	the comment string for the specified file. Use SCENARIOFILELENGTH-COMMENTS to get required buffer size, if needed. (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found
	IERR = 4 specified file not found

14.11. SCENARIOFILELENGTHCOMMENTS

Use this API to determine the buffer size needed to hold the comments for the specified file.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, length = scenariofilelengthcomments(sgroup, sfile)
```

Fortran command syntax:

```
CALL SCENARIOFILELENGTHCOMMENTS(SGROUP, SFILE, LENGTH, IERR)
```

Where:

Character*72 SGROUP	group that contains the specified file (input; no default allowed).
Character*260 SFILE	name of the file whose comment length is to be returned (input; no default allowed).
Integer LENGTH	length of the Scenario comment string (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found
	IERR = 4 specified file not found

14.12. SCENARIOFILELIST

Use this API to retrieve the list of files in the specified group.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, sfiles = scenariofilelist(sgroup)
```

Fortran command syntax:

```
CALL SCENARIOFILELIST(SGROUP, NFILES, SFILES, IERR)
```

Where:

Character*72 SGROUP	group to retrieve the file list of (input; no default allowed).
Integer NFILES	max number of files to list (input; no default allowed).
Character*260 SFILES (NFILES)	list of files in the specified group (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found

14.13. SCENARIOFILEREMOVE

Use this API to remove a file from the specified group.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOFILEREMOVE SGROUP SFILE
```

Python command syntax:

```
ierr = scenariofileremove(sgroup, sfile)
```

Fortran command syntax:

```
CALL SCENARIOFILEREMOVE(SGROUP, SFILE, IERR)
```

Where:

Character*72 SGROUP	name of the group to remove a file from (input; no default allowed).	
Character*260 SFILE	name of the file to be removed (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid file name
	IERR = 3	specified group not found
	IERR = 4	specified file not found

14.14. SCENARIOFILERENAME

Use this API to rename one of the files in the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOFILERENAME SGROUP SFILE SNEWNAME
```

Python command syntax:

```
ierr = scenariofilerename(sgroup, sfile, snewname)
```

Fortran command syntax:

```
CALL SCENARIOFILERENAME(SGROUP, SFILE, SNEWNAME, IERR)
```

Where:

Character*72 SGROUP	group that contains the specified file (input; no default allowed).
Character*260 SFILE	name of the file whose name is to be changed (input; no default allowed).
Character*260 SNEWNAME	new name to be given to the specified file (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 2 invalid file name
	IERR = 3 specified group not found
	IERR = 4 specified file not found

14.15. SCENARIOFILESETATTRS

Use this API to modify the attributes of the specified file.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOFILESETATTRS SGROUP SFILE STYPE LOAD SARGS
```

Python command syntax:

```
ierr = scenariofilesetattrs(sgroup, sfile, stype, load, sargs)
```

Fortran command syntax:

```
CALL SCENARIOFILESETATTRS(SGROUP, SFILE, STYPE, LOAD, SARGS, IERR)
```

Where:

Character*72 SGROUP	group that contains the specified file (input; no default allowed).
Character*260 SFILE	name of the file whose attributes are to be modified (input; no default allowed).
Character*8 STYPE	new file type identifier for the specified file (input; ignored).
Integer LOAD	file's new position in the load order of its group. A load order of 0 specifies that the file is not loaded (input; ignored).
Character*260 SARGS	argument string to be used for the file when automatically opening the file (input; ignored).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found
	IERR = 4 specified file not found

14.16. SCENARIOFILESETCOMMENTS

Use this API to define or modify the comments for the specified file.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOFILESETCOMMENTS SGROUP SFILE NCOMMENTBLOCKS COMMENTS APPEND
```

Python command syntax:

```
ierr = scenariofilesetcomments(sgroup, sfile, ncommentblocks, comments,
                                append)
```

Fortran command syntax:

```
CALL SCENARIOFILESETCOMMENTS(SGROUP, SFILE, NCOMMENTBLOCKS, COMMENTS,
                                APPEND, IERR)
```

Where:

Character*72 SGROUP	group that contains the specified file (input; no default allowed).
Character*260 SFILE	name of the file whose attributes are to be modified (input; no default allowed).
Integer NCOMMENTBLOCKS	number of 72 character strings that make up the comment. In python, this number can be set to 1 and the full comment string given as the first comment block (input; 0 by default).
Character*72 COMMENTS (NCOMMENTBLOCKS)	comment string to be defined for or added to the comments for the specified file (input; unchanged).
Logical APPEND	flag for appending comments. If TRUE, COMMENTS is appended to the current comments. If FALSE, the current comments are overwritten by COMMENTS (input; FALSE).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found
	IERR = 4 specified file not found

14.17. SCENARIOGETATTRS

Use this API to retrieve the attributes of the Scenario.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, rootpath, startupgroup, creationdate, createdby, changedate,  
changedby, name, version, versionpsse = scenariogetattrs()
```

Fortran command syntax:

```
CALL SCENARIOGETATTRS(ROOTPATH, STARTUPGROUP, CREATIONDATE, CREATEDBY,  
CHANGEDATE, CHANGEDBY, NAME, VERSION, VERSIONPSSE, IERR)
```

Where:

Character*260 ROOTPATH	root path of the Scenario (output).
Character*72 STARTUPGROUP	name of the startup group (output).
Character*23 CREATIONDATE	date of creation (output).
Character*256 CREATEDBY	username of the creator (output).
Character*23 CHANGEDATE	last date of modification (output).
Character*256 CHANGEDBY	username of the last modifier (output).
Character*260 NAME	name of the Scenario (output).
Character*14 VERSION	version of Scenario the file was saved under (output).
Character*14 VERSIONPSSE	version of PSSE the file was saved under (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory

14.18. SCENARIOGETCOMMENTS

Use this API to retrieve the Scenario comments.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, comments = scenariogetcomments()
```

Fortran command syntax:

```
CALL SCENARIOGETCOMMENTS(COMMENTS, IERR)
```

Where:

Character COMMENTS	the comment string for the Scenario. Use SCENARIOLENGTHCOMMENTS to get required buffer size, if needed. (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory

14.19. SCENARIOGETOPT

Use this API to retrieve the Scenario options. Note: Scenario settings are not attached to the Scenario file. They are user preferences that are saved on the user's machine.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, trackopt, uziprootopt, uziplcllopt, uziplclopt, uziprmtpopt,
    uziprmtopt = scenariogetopt()
```

Fortran command syntax:

```
CALL SCENARIOGETOPT(TRACKOPT, UZIPROOTOPT, UZIPLCLLOPT, UZIPLCLOPT,
    UZIPRMTOPT, UZIPRMTOPT, IERR)
```

Where:

Integer TRACKOPT	setting for file tracking (output). TRACKOPT = 0 tracking is turned off. TRACKOPT = 1 the user will be prompted as soon as possible when a new file is being tracked TRACKOPT = 2 the user will be prompted about tracked files when the current active group is being closed TRACKOPT = 3 tracked files will be added to the current ac- tive group immediately.
Integer UZIPROOTOPT	setting for conflict resolution for root files (output). UZIPROOTOPT = 0 skip the file. UZIPROOTOPT = 1 prompt the user for action. UZIPROOTOPT = 2 overwrite the file on disk.
Integer UZIPLCLLOPT	setting for placement of local files (output). UZIPLCLLOPT = 0 do not unzip. UZIPLCLLOPT = 1 unzip to the root path. UZIPLCLLOPT = 2 unzip to the same path the file was at before the file was zipped. UZIPLCLLOPT = 3 unzip to the same path the file was at before, relative to the root path.
Integer UZIPLCLOPT	setting for conflict resolution for local files (output). UZIPLCLOPT = 0 skip the file. UZIPLCLOPT = 1 prompt the user for action. UZIPLCLOPT = 2 overwrite the file on disk.
Integer UZIPRMTOPT	setting for placement of remote files Note: Cannot choose to unzip remote files by relative path (output). UZIPRMTOPT = 0 do not unzip. UZIPRMTOPT = 1 unzip to the root path. UZIPRMTOPT = 2 unzip to the same path the file was at before the file was zipped.

Integer UZIPRMTOPT	setting for conflict resolution for remote files (output).	
	UZIPRMTOPT = 0	skip the file.
	UZIPRMTOPT = 1	prompt the user for action.
Integer IERR	UZIPRMTOPT = 2	overwrite the file on disk.
	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred

14.20. SCENARIOGROUPADD

Use this API to add a group to the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOGROUPADD SGROUP
```

Python command syntax:

```
ierr = scenariogroupadd(sgroup)
```

Fortran command syntax:

```
CALL SCENARIOGROUPADD(SGROUP, IERR)
```

Where:

Character*72 SGROUP	name of the new group to add to the Scenario (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid group name

14.21. SCENARIOGROUPCOUNT

Use this API to retrieve the number of groups in the Scenario.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, ngroups = scenariogroupcount()
```

Fortran command syntax:

```
CALL SCENARIOGROUPCOUNT(NGROUPS, IERR)
```

Where:

Integer NGROUPS	number of the group in the Scenario (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory

14.22. SCENARIOGROUPGETCOMMENTS

Use this API to retrieve the comments for the specified group.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, comments = scenariogroupgetcomments(sgroup)
```

Fortran command syntax:

```
CALL SCENARIOGROUPGETCOMMENTS(SGROUP, COMMENTS, IERR)
```

Where:

Character*72 SGROUP	name of the group whose comments are to be returned (input; no default allowed).	
Character COMMENTS	the comment string for the specified group. Use SCENARIOGROUPLENGTHCOMMENTS to get required buffer size, if needed. (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 3	specified group not found

14.23. SCENARIOGROUPLengthComments

Use this API to determine the buffer size needed to hold the comments for the specified group.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, length = scenariogrouplengthcomments(sgroup)
```

Fortran command syntax:

```
CALL SCENARIOGROUPLengthComments(SGROUP, LENGTH, IERR)
```

Where:

Character*72 SGROUP	name of the group whose comment length is to be returned (input; no default allowed).	
Integer LENGTH	length of the comment string for the specified group (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 3	specified group not found

14.24. SCENARIOGROUPLIST

Use this API to retrieve the list of groups in the Scenario.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, sgroups = scenariogrouplist()
```

Fortran command syntax:

```
CALL SCENARIOGROUPLIST(NGROUPS, SGROUPS, IERR)
```

Where:

Integer NGROUPS	max number of groups to list (input; no default allowed).	
Character*72 SGROUPS (NGROUPS)	list of groups in the Scenario (output; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory

14.25. SCENARIOGROUPOPEN

Use this API to add a group to the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOGROUPOPEN SGROUP
```

Python command syntax:

```
ierr = scenariogroupopen(sgroup)
```

Fortran command syntax:

```
CALL SCENARIOGROUPOPEN(SGROUP, IERR)
```

Where:

Character*72 SGROUP	name of the group to open (input; ignored by default. When default is used the startup group will be opened if one is defined in the Scenario. If the name of a group in the Scenario is given, that group will be opened. If the string is blank or does not match any of the group names in the Scenario no group is opened).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 3	specified group not found

14.26. SCENARIOGROUPREMOVE

Use this API to remove a group from the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOGROUPREMOVE SGROUP
```

Python command syntax:

```
ierr = scenariogroupermove (sgroup)
```

Fortran command syntax:

```
CALL SCENARIOGROUPREMOVE (SGROUP, IERR)
```

Where:

Character*72 SGROUP	name of the group to be removed from the Scenario (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 3	specified group not found

14.27. SCENARIOGROUPRENAME

Use this API to rename one of the groups in the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOGROUPRENAME  SGROUP SNEWNAME
```

Python command syntax:

```
ierr = scenariogrouprename(sgroup, snewname)
```

Fortran command syntax:

```
CALL SCENARIOGROUPRENAME(SGROUP, SNEWNAME, IERR)
```

Where:

Character*72 SGROUP	name of the group to be renamed (input; no default allowed).	
Character*72 SNEWNAME	new name to be given to the specified group (input; no default allowed).	
Integer IERR	error code (output).	
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid group name
	IERR = 3	specified group not found

14.28. SCENARIOGROUPSETCOMMENTS

Use this API to define or modify the comments for the specified group.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOGROUPSETCOMMENTS SGROUP NCOMMENTBLOCKS COMMENTS APPEND
```

Python command syntax:

```
ierr = scenariogroupsetcomments(sgroup, ncommentblocks, comments, append)
```

Fortran command syntax:

```
CALL SCENARIOGROUPSETCOMMENTS(SGROUP, NCOMMENTBLOCKS, COMMENTS, APPEND,  
IERR)
```

Where:

Character*72 SGROUP	name of the group whose comments are to be modified (input; no default allowed).	
Integer NCOMMENTBLOCKS	number of 72 character strings that make up the comment. In python, this number can be set to 1 and the full comment string given as the first comment block (input; 0 by default).	
Character*72 COMMENTS (NCOMMENTBLOCKS)	comment string to be defined for or added to the comments for the specified group (input; unchanged).	
Logical APPEND	flag for appending comments. If TRUE, COMMENTS is appended to the current comments. If FALSE, the current comments are overwritten by COMMENTS (input; FALSE).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 3	specified group not found

14.29. SCENARIOISDIRTY

Use this API to determine if there are any unsaved changes in the current Scenario.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
isdirty = scenarioisdirty()
```

Fortran command syntax:

```
CALL SCENARIOISDIRTY(ISDIRTY)
```

Where:

Logical ISDIRTY	TRUE when the Scenario in memory currently contains unsaved changes (output).
-----------------	---

14.30. SCENARIOISVALID

Use this API to determine if there is a valid Scenario in memory.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
isvalid = scenarioisvalid()
```

Fortran command syntax:

```
CALL SCENARIOISVALID(ISVALID)
```

Where:

Logical ISVALID	TRUE when a valid Scenario is in memory, currently returns FALSE when in Zip Mode (output).
-----------------	---

14.31. SCENARIOLENGTHCOMMENTS

Use this API to determine the buffer size needed to hold the current Scenario comments.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, length = scenariolengthcomments()
```

Fortran command syntax:

```
CALL SCENARIOLENGTHCOMMENTS(LENGTH, IERR)
```

Where:

Integer LENGTH	length of the Scenario comment string (output).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory

14.32. SCENARIOMODELGROUP

Use this API to create a new group that is identical to another group.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOMODELGROUP  SGROUP SNEWNAME
```

Python command syntax:

```
ierr = scenariomodelgroup(sgroup, snewname)
```

Fortran command syntax:

```
CALL SCENARIOMODELGROUP(SGROUP, SNEWNAME, IERR)
```

Where:

Character*72 SGROUP	name of the group to be copied (input; no default allowed).	
Character*72 SNEWNAME	name of the new group (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid file name
	IERR = 3	specified group not found

14.33. SCENARIOMOVEFILE

Use this API to move a file from one group to another group.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOMOVEFILE SRCGROUP SFILE DSTGROUP
```

Python command syntax:

```
ierr = scenariomovefile(srcgroup, sfile, dstgroup)
```

Fortran command syntax:

```
CALL SCENARIOMOVEFILE(SRCGROUP, SFILE, DSTGROUP, IERR)
```

Where:

Character*72 SRCGROUP	name of the group containing the file to be moved (input; no default allowed).	
Character*260 SFILE	name of the file to be moved (input; no default allowed).	
Character*72 DSTGROUP	name of the group the file will be moved to (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	invalid file name
	IERR = 3	specified group not found
	IERR = 4	specified file not found

14.34. SCENARIONEW

Use this API to create a new Scenario. At least one group must be added to the Scenario through SCENARIOGROUPADD before files may be added to it. If adding files through file tracking is also desired, a group must become the active group which can be done by calling SCENARIOGROUPOPEN.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIONEW SFILE
```

Python command syntax:

```
ierr = scenariow(sfile)
```

Fortran command syntax:

```
CALL SCENARIONEW(SFILE, IERR)
```

Where:

Character*260 SFILE	full file path of the new scenario file (input; blank by default. The name of the Scenario will be determined by the file name portion of the full file path. When the default is used no name is given to the Scenario and a full file name will be required upon saving. The root path of the Scenario will be determined by the path portion of the full file path. When the default is used the root path will default to the current working directory).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred

14.35. SCENARIOOPEN

Use this API to open a previously created Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOOPEN SFILE SGROUP
```

Python command syntax:

```
ierr = scenarioopen(sfile, sgroup)
```

Fortran command syntax:

```
CALL SCENARIOOPEN(SFILE, SGROUP, IERR)
```

Where:

Character*260 SFILE	full file path of the scenario file to open (input; no default allowed).
Character*72 SGROUP	name of the group to open when the scenario is loaded. When the default is used the startup group will be opened if one is defined in the Scenario. If the name of a group in the Scenario is given, that group will be opened. If the string is blank or does not match any of the group names in the Scenario, no group is opened. (input; blank by default).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 2 file path is invalid

14.36. SCENARIOSAVE

Use this API to save the currently open Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOSAVE SFILE
```

Python command syntax:

```
ierr = scenariosave(sfile)
```

Fortran command syntax:

```
CALL SCENARIOSAVE(SFILE, IERR)
```

Where:

Character*260 SFILE	full file path to save the scenario file to (input; unchanged by default. When the default is used the Scenario will be saved to the last file-name given in a SCENARIONEW, SCENARIOOPEN, or SCENARIOSAVE operation, if a call to SCENARIONEW with default arguments was the previous call, the Scenario will not be saved due to no previous file-name being available).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory
	IERR = 2	file path is invalid

14.37. SCENARIOSETATTRS

Use this API to modify the root path and startup group attributes of the Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOSETATTRS ROOTPATH STARTUPGROUP
```

Python command syntax:

```
ierr = scenariosetattrs(rootpath, startupgroup)
```

Fortran command syntax:

```
CALL SCENARIOSETATTRS(ROOTPATH, STARTUPGROUP, IERR)
```

Where:

Character*260 ROOTPATH	directory to be used as the root path of the Scenario (input; unchanged).
Character*72 STARTUPGROUP	name of the group to be designated as the startup group (input; unchanged).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred
	IERR = 1 no Scenario in memory
	IERR = 3 specified group not found

14.38. SCENARIOSETCOMMENTS

Use this API to define or modify the Scenario comments.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOSETCOMMENTS NCOMMENTBLOCKS COMMENTS APPEND
```

Python command syntax:

```
ierr = scenariosetcomments(ncommentblocks, comments, append)
```

Fortran command syntax:

```
CALL SCENARIOSETCOMMENTS(NCOMMENTBLOCKS, COMMENTS, APPEND, IERR)
```

Where:

Integer NCOMMENTBLOCKS	number of 72 character strings that make up the comment. In python, this number can be set to 1 and the full comment string given as the first comment block (input; 0 by default).
Character*72 COMMENTS (NCOMMENTBLOCKS)	comment string to be defined for or added to the comments for the Scenario (input; unchanged).
Logical APPEND	flag for appending comments. If TRUE, COMMENTS is appended to the current Scenario comments. If FALSE, the current Scenario comments are overwritten by COMMENTS (input; FALSE).
Integer IERR	error code (output). IERR = 0 no error occurred IERR > 0 fatal error occurred IERR = 1 no Scenario in memory

14.39. SCENARIOSETOPT

Use this API to modify the Scenario options. Note: Scenario settings are not attached to the Scenario file. They are user preferences that are saved on the user's machine.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOSETOPT TRACKOPT UZIPROOTOPT UZIPLCLPCOPT UZIPLCLOPT
  UZIPRMTPCOPT UZIPRMTOPT
```

Python command syntax:

```
ierr = scenariosetopt(trackopt, uziprootopt, uziplclpcopt, uziplclopt,
  uziprmtpcopt, uziprmtopt)
```

Fortran command syntax:

```
CALL SCENARIOSETOPT(TRACKOPT, UZIPROOTOPT, UZIPLCLPCOPT, UZIPLCLOPT,
  UZIPRMTPCOPT, UZIPRMTOPT, IERR)
```

Where:

Integer TRACKOPT	setting for file tracking (input; unchanged).	
	TRACKOPT = 0	The user will not be prompted about tracked files. If there are files that are currently being tracked the user will be prompted as soon as possible for those files.
	TRACKOPT = 1	The user will be prompted as soon as possible when a new file is being tracked
	TRACKOPT = 2	The user will be prompted about tracked files when the current active group is being closed
Integer UZIPROOTOPT	TRACKOPT = 3	Tracked files will be added to the current active group immediately. If there are files that are currently being tracked the user will be prompted as soon as possible for those files.
	setting for conflict resolution for root files (input; unchanged).	
	UZIPROOTOPT = 0	Skip the file.
	UZIPROOTOPT = 1	Prompt the user for action.
Integer UZIPLCLPCOPT	UZIPROOTOPT = 2	Overwrite the file on disk.
	setting for placement of local files (input; unchanged).	
	UZIPLCLPCOPT = 0	Do not unzip.
	UZIPLCLPCOPT = 1	Unzip to the root path.
Integer UZIPLCLOPT	UZIPLCLPCOPT = 2	Unzip to the same path the file was at before the file was zipped.
	UZIPLCLPCOPT = 3	Unzip to the same path the file was at before, relative to the root path.
	setting for conflict resolution for local files (input; unchanged).	
Integer UZIPLCLOPT	UZIPLCLOPT = 0	Skip the file.

Integer UZIPRMTPCOPT	UZIPLCLOPT = 1	Prompt the user for action.
	UZIPLCLOPT = 2	Overwrite the file on disk.
	setting for placement of remote files (input; unchanged by default). Note: Cannot choose to unzip remote files by relative path).	
	UZIPRMTPCOPT = 0	Do not unzip.
	UZIPRMTPCOPT = 1	Unzip to the root path.
Integer UZIPRMTOPT	UZIPRMTPCOPT = 2	Unzip to the same path the file was at before the file was zipped.
	setting for conflict resolution for remote files (input; unchanged).	
	UZIPRMTOPT = 0	Skip the file.
	UZIPRMTOPT = 1	Prompt the user for action.
	UZIPRMTOPT = 2	Overwrite the file on disk.
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred

14.40. SCENARIOTRACKFILEADD

Use this API to add the files currently being tracked.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOTRACKFILEADD  SGROUP NFILES INDEXES DISCARD
```

Python command syntax:

```
ierr = scenariotrackfileadd(sgroup, nfiles, indexes, discard)
```

Fortran command syntax:

```
CALL SCENARIOTRACKFILEADD(SGROUP, NFILES, INDEXES, DISCARD, IERR)
```

Where:

Character*72 SGROUP	group to add tracked file to (input; current active group).	
Integer NFILES	number of files currently being tracked to add (input; no default allowed).	
Integer INDEXES (NFILES)	indexes of the files to add based on the list from SCENARIOTRACK-FILEADD (input; no default allowed).	
Logical DISCARD	a flag to specify whether or not to discard the files being tracked that were not added (input; FALSE).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred

14.41. SCENARIOTRACKFILELIST

Use this API to retrieve the list of files being tracked.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, sfiles, stypes = scenariotrackfilelist()
```

Fortran command syntax:

```
CALL SCENARIOTRACKFILELIST(NFILES, SFILES, STYPES, IERR)
```

Where:

Integer NFILES	max number of files currently being tracked to return (input; no default allowed).
Character*260 SFILES (NFILES)	list of files currently being tracked (output).
Character*8 STYPES (NFILES)	list of file type identifiers for each file being tracked (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred

14.42. SCENARIOTRACKFILENUM

Use this API to retrieve the current number of files being tracked.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, nfiles = scenariotrackfilenum()
```

Fortran command syntax:

```
CALL SCENARIOTRACKFILENUM(NFILES, IERR)
```

Where:

Integer NFILES	number of files currently being tracked (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR > 0 fatal error occurred

14.43. SCENARIOUNZIP

Use this API to unzip a zipped Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOUNZIP SFILE
```

Python command syntax:

```
ierr = scenariounzip(sfile)
```

Fortran command syntax:

```
CALL SCENARIOUNZIP(SFILE, IERR)
```

Where:

Character*260 SFILE	full file path of the scenario archive to unzip (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no conflicts occurred
	IERR > 0	conflicts occurred

14.44. SCENARIOUNZIPPROBLEMS

Use this API to retrieve the problems that occurred during the last unzip attempt.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
ierr, indexes, problems, paths, types = scenariounzipproblems()
```

Fortran command syntax:

```
CALL SCENARIOUNZIPPROBLEMS(ERRCNT, INDEXES, PROBLEMS, PATHS, TYPES, IERR)
```

Where:

Integer ERRCNT	return value from either SCENARIOUNZIP or SCENARIOUNZIPSO- LUTIONS (input; no default allowed).
Integer INDEXES (ERRCNT)	internal problem index which will be used in SCENARIOUNZIPSO- LUTIONS (output).
Integer PROBLEMS (ERRCNT)	problems that were encountered (output). PROBLEMS = 0 file already exists. PROBLEMS = 1 path does not exist. PROBLEMS = 2 a file with the specified name does not exist in the archive. PROBLEMS = 3 a directory with the specified file name al- ready exists.
Character*260 PATHS (ERRCNT)	full file paths of all files that had problems being extracted (output).
Integer TYPES (ERRCNT)	file types associated with each file (output).
Integer IERR	error code (output). IERR = 0 no conflicts occurred IERR > 0 conflicts occurred

14.45. SCENARIOUNZIPSOLUTIONS

Use this API to submit potential solutions to the problems that occurred during the last unzip attempt.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOUNZIPSOLUTIONS  NSOLUTIONS INDEXES SOLUTIONS PATHS
```

Python command syntax:

```
ierr = scenariounzipsolutions(nsolutions, indexes, solutions, paths)
```

Fortran command syntax:

```
CALL SCENARIOUNZIPSOLUTIONS(NSOLUTIONS, INDEXES, SOLUTIONS, PATHS, IERR)
```

Where:

Integer NSOLUTIONS	number of solutions being submitted (input; no default allowed).
Integer INDEXES (NSOLUTIONS)	internal problem indexes which were obtained from SCENARIOUNZIP-PROBLEMS (input; no default allowed).
Integer SOLUTIONS (NSOLUTIONS)	solutions to attempt Note: These solutions do not apply to all problems. For example if the file is missing from the archive only a solution of 0 will solve the problem (input; no default allowed). SOLUTIONS = 0 skip the file. SOLUTIONS = 1 retry to unzip, possibly with a different file name. SOLUTIONS = 2 to overwrite the current item on disk.
Character*260 PATHS (NSOLUTIONS)	used to attempt to unzip a file to a new path or under a new name All name changes will be reflected in the Scenario. If no name is specified for a particular problem the name will not change (input).
Integer IERR	error code (output). IERR = 0 no conflicts occurred IERR > 0 conflicts occurred

14.46. SCENARIOZIP

Use this API to zip up the current Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOZIP SFILE
```

Python command syntax:

```
ierr = scenariozip(sfile)
```

Fortran command syntax:

```
CALL SCENARIOZIP(SFILE, IERR)
```

Where:

Character*260 SFILE	full file path of the file to zip the scenario to (input; unchanged by default). When the default is used the name of the zip will be the same name as the Scenario but with the ZIP extension instead of the PSSXML extension. If a different name is given the Scenario's name and the Scenario PSSXML file name will be changed to reflect the new name).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred
	IERR = 1	no Scenario in memory

14.47. SCENARIOZIPACTIVE

Use this API to determine if the Scenario is currently in Zip Mode.

This API routine was first introduced in release 33.0.0.

Python command syntax:

```
active = scenariozipactive()
```

Fortran command syntax:

```
CALL SCENARIOZIPACTIVE(ACTIVE)
```

Where:

Logical ACTIVE	TRUE when the Scenario is in Zip Mode (output).
----------------	---

14.48. SCENARIOZIPOPEN

Use this API to open a zipped Scenario.

This API routine was first introduced in release 33.0.0.

Batch command syntax:

```
BAT_SCENARIOZIPOPEN  SFILE SGROUP
```

Python command syntax:

```
ierr = scenariozipopen(sfile, sgroup)
```

Fortran command syntax:

```
CALL SCENARIOZIPOPEN(SFILE, SGROUP, IERR)
```

Where:

Character*260 SFILE	full file path of the scenario file to open (input; no default allowed).	
Character*72 SGROUP	Reserved for future use (input; ignored).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR > 0	fatal error occurred

14.49. SCENARIOZIPSAVE

This API routine was first introduced in release 33.2.0.

Batch command syntax:

```
BAT_SCENARIOZIPSAVE SFILE
```

Python command syntax:

```
ierr = scenariozipsave(sfile)
```

Fortran command syntax:

```
CALL SCENARIOZIPSAVE(SFILE, IERR)
```

Where:

Character*260 SFILE	full file path of the scenario file to save to (input; no default allowed).
Integer IERR	error code (output).

Chapter 15

Event Studies

15.1. CLOSEEVENTSTUDYFILE

Use this API to close an open Event Study file.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_CLOSEEVENTSTUDYFILE
```

Python command syntax:

```
closeeventstudyfile()
```

Fortran command syntax:

```
CALL CLOSEEVENTSTUDYFILE
```

15.2. OPENEVENTSTUDYFILE

Use this API to open a new or existing event study file in the GUI.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_OPENEVENTSTUDYFILE SFILE
```

Python command syntax:

```
openeventstudyfile(sfile)
```

Fortran command syntax:

```
CALL OPENEVENTSTUDYFILE(SFILE)
```

Where:

Character*260 SFILE name of the new or existing event study file (input).

15.3. RUNDYNAMICEVENTSTUDY

Use this API to run a dynamic study using the active event study in the open event study file.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_RUNDYNAMICEVENTSTUDY
```

Python command syntax:

```
rundynamiceventstudy()
```

Fortran command syntax:

```
CALL RUNDYNAMICEVENTSTUDY
```

15.4. RUNPOWERFLOWEVENTSTUDY

Use this API to run a power flow study using the active event study in the open event study file.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_RUNPOWERFLOWEVENTSTUDY
```

Python command syntax:

```
runpowerfloweventstudy()
```

Fortran command syntax:

```
CALL RUNPOWERFLOWEVENTSTUDY
```

15.5. SAVEEVENTSTUDYFILE

Use this API to save existing event studies in an event study file.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SAVEEVENTSTUDYFILE SFILE
```

Python command syntax:

```
saveeventstudyfile(sfile)
```

Fortran command syntax:

```
CALL SAVEEVENTSTUDYFILE(SFILE)
```

Where:

Character*260 SFILE	name of the destination event study file (input).
---------------------	---

15.6. SETACTIVEEVENTSTUDY

Use this API to select an Event Study in an Event file as the active Event Study for running dynamic or power flow event studies.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_SETACTIVEEVENTSTUDY SFILE
```

Python command syntax:

```
setactiveeventstudy(sfile)
```

Fortran command syntax:

```
CALL SETACTIVEEVENTSTUDY(SFILE)
```

Where:

Character*260 SFILE	name of an event study in the open event study file (input).
---------------------	--

Chapter 16

Measurement Interface

This chapter describes the API routines used in PSS®E Measurement Interface feature.

16.1. HDAIMPORTDATA

Use this API to import historical data from an OPC HDA database.

This API routine was first introduced in release 33.9.0.

Batch command syntax:

```
BAT_HDAIMPORTDATA  HOST SERVER MAPFILE TIMEFROM(1)..TIMEFROM(6)
                    TIMETO(1)..TIMETO(6) AGGREGATE SID ATTRIBUTECOUNT
                    ATTRIBUTES(1)..ATTRIBUTES(ATTRIBUTECOUNT)
```

Python command syntax:

```
ierr = hdaimportdata(host, server, mapfile, timefrom, timeto, aggregate,
                    sid, attributecount, attributes)
```

Fortran command syntax:

```
CALL HDAIMPORTDATA(HOST, SERVER, MAPFILE, TIMEFROM, TIMETO, AGGREGATE,
                    SID, ATTRIBUTECOUNT, ATTRIBUTES, IERR)
```

Where:

Character*260 HOST	name of the address of the machine hosting the server (input).
Character*260 SERVER	name of the OPC HDA compliant server (input).
Character*260 MAPFILE	name of the excel file mapping network items to HDA tags (input).
Integer TIMEFROM	time from which to start gathering data. The order is Year, Month, Day, Hour, Minute, Second. If all zeros specified, then asnapshot will be taken from the time specified by TIMETO and AGGREGATE will be ignored. (input).
Integer TIMETO	time to gather data to. The order is Year, Month, Day, Hour, Minute, Second (input).
Integer AGGREGATE	ID of the aggregate to use when gathering data. Use the help function in the python module psspihist to retrieve aggregate IDs from a server. (input).
Integer SID	subsystem to gather data for and apply data to (input).
Integer ATTRIBUTECOUNT	number of attributes to gather data for (input).
Character*61 ATTRIBUTES	list of attributes to gather. There are specified by network element type followed by result type, e.g. LOAD-PL. (input).
Integer IERR	error code (output).

Chapter 17

Multiple Element Data

This chapter defines API routines that are used to retrieve data that are neither single elements nor based on subsystems.

These routines do not record themselves when called with recording enabled.

17.1. AVOLTAGEDROOPCHAR

Use this API to return an array of character values for the voltage droop controls.

This API routine was first introduced in release 35.3.0.

Python command syntax:

```
ierr, carray = avoltagedroopchar(string)
```

Fortran command syntax:

```
CALL GET_VD_CHAR(NSTR, STRING, DIM, CARRAY, VDS, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the voltage droop quantities desired (input; no default allowed). 'DROOPNAME' voltage droop name (40 characters).
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of VDS returned by the GET_VD_COUNT API when it is called (input; no default allowed).
Character CARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer VDS	number of elements in each column of CARRAY that are set by this API. VDS is identical to the value of VDS returned by the GET_VD_COUNT API when it is called (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid NSTR value IERR = 3 Invalid STRING value

17.2. AVOLTAGEDROOPCOUNT

Use this API to return the number of voltage droop controls.

This API routine was first introduced in release 35.3.0.

Python command syntax:

```
ierr, vdroops = avoltagedroopcount()
```

Fortran command syntax:

```
CALL GET_VD_COUNT(VDROOPS, IERR)
```

Where:

Integer VDROOPS	number of voltage droop controls (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Working case is empty

17.3. AVOLTAGEDROOPINT

Use this API to return an array of real values for the voltage droop controls.

This API routine was first introduced in release 35.3.0.

Python command syntax:

```
ierr, iarray = avoltagedroopint(string)
```

Fortran command syntax:

```
CALL GET_VD_INT(NSTR, STRING, DIM, IARRAY, VDS, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).
Character STRING (NSTR)	NSTR of the following strings indicating the voltage droop quantities desired (input; no default allowed). 'STATUS' defined voltage droop control status 'ACTSTATUS' actual voltage droop control status 'REGBUS' defined regulated bus of voltage droop control 'ACTREGBUS' actual regulated bus of voltage droop control
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of VDS returned by the GET_VD_COUNT API when it is called (input; no default allowed).
Integer IARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).
Integer VDS	number of elements in each column of CARRAY that are set by this API. VDS is identical to the value of VDS returned by the GET_VD_COUNT API when it is called (output).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Working case is empty IERR = 2 Invalid NSTR value IERR = 3 Invalid STRING value

17.4. AVOLTAGEDROOPREAL

Use this API to return an array of real values for the voltage droop controls.

This API routine was first introduced in release 35.3.0.

Python command syntax:

```
ierr, rarray = avoltagedroopreal(string)
```

Fortran command syntax:

```
CALL GET_VD_REAL(NSTR, STRING, DIM, RARRAY, VDS, IERR)
```

Where:

Integer NSTR	number of elements in STRING (1 < NSTR < 50) (input; no default allowed).																						
Character STRING (NSTR)	NSTR of the following strings indicating the voltage droop quantities desired (input; no default allowed). <table border="0"> <tr> <td>'QMAX'</td><td>QMAX of voltage droop control</td></tr> <tr> <td>'QDB'</td><td>QDB of voltage droop control</td></tr> <tr> <td>'QMIN'</td><td>QMIN of voltage droop control</td></tr> <tr> <td>'VLOW'</td><td>VLOW of voltage droop control</td></tr> <tr> <td>'VDBLOW'</td><td>VDBLOW of voltage droop control</td></tr> <tr> <td>'VDBHIGH'</td><td>VDBHIGH of voltage droop control</td></tr> <tr> <td>'VHIGH'</td><td>VHIGH of voltage droop control</td></tr> <tr> <td>'VOLTAGE'</td><td>voltage at the regulated bus of voltage droop control</td></tr> <tr> <td>'QINJ'</td><td>Q injection to the regulated bus of voltage droop control, Q is positive if the Q enters into the bus</td></tr> <tr> <td>'QMAX'</td><td>desired Q injection to the regulated bus of voltage droop control, Q is positive if the Q enters into the bus</td></tr> <tr> <td>'QGEN'</td><td>total Q outputs of the generators in the voltage droop control</td></tr> </table>	'QMAX'	QMAX of voltage droop control	'QDB'	QDB of voltage droop control	'QMIN'	QMIN of voltage droop control	'VLOW'	VLOW of voltage droop control	'VDBLOW'	VDBLOW of voltage droop control	'VDBHIGH'	VDBHIGH of voltage droop control	'VHIGH'	VHIGH of voltage droop control	'VOLTAGE'	voltage at the regulated bus of voltage droop control	'QINJ'	Q injection to the regulated bus of voltage droop control, Q is positive if the Q enters into the bus	'QMAX'	desired Q injection to the regulated bus of voltage droop control, Q is positive if the Q enters into the bus	'QGEN'	total Q outputs of the generators in the voltage droop control
'QMAX'	QMAX of voltage droop control																						
'QDB'	QDB of voltage droop control																						
'QMIN'	QMIN of voltage droop control																						
'VLOW'	VLOW of voltage droop control																						
'VDBLOW'	VDBLOW of voltage droop control																						
'VDBHIGH'	VDBHIGH of voltage droop control																						
'VHIGH'	VHIGH of voltage droop control																						
'VOLTAGE'	voltage at the regulated bus of voltage droop control																						
'QINJ'	Q injection to the regulated bus of voltage droop control, Q is positive if the Q enters into the bus																						
'QMAX'	desired Q injection to the regulated bus of voltage droop control, Q is positive if the Q enters into the bus																						
'QGEN'	total Q outputs of the generators in the voltage droop control																						
Integer DIM	number of elements in each column of the array CARRAY. DIM must be as least as large as the value of VDS returned by the GET_VD_COUNT API when it is called (input; no default allowed).																						
Real RARRAY (NSTR*DIM)	Is an array of at least NSTR columns, each of which contains DIM elements (output).																						
Integer VDS	number of elements in each column of CARRAY that are set by this API. VDS is identical to the value of VDS returned by the GET_VD_COUNT API when it is called (output).																						
Integer IERR	error code (output). <table border="0"> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = 1</td><td>Working case is empty</td></tr> </table>	IERR = 0	No error	IERR = 1	Working case is empty																		
IERR = 0	No error																						
IERR = 1	Working case is empty																						

IERR = 2	Invalid NSTR value
IERR = 3	Invalid STRING value

17.5. GETMODELLIBRARIES

Return the list of libraries that are searched for dynamically (i.e. run-time) loaded dynamics model programs.

In particular this will be the list of libraries searched for user-written dynamics model programs.

This API routine was first introduced in release 31.0.0.

Python command syntax:

```
names = getmodellibraries()
```

Fortran command syntax:

```
CALL GETMODELLIBRARIES(NSTR, NAMES, NRET)
```

Where:

Integer NSTR	declared size of NAMES (input).
Character*260 NAMES (NSTR)	names of all libraries in the search list (output).
Integer NRET	number of libraries returned (output).

17.6. GETMODELPROGRAMS

Return the list dynamically (i.e. run-time) loaded dynamics model programs currently in use. In particular this will include all user-written dynamics model programs.

This API routine was first introduced in release 33.3.0.

Python command syntax:

```
progs, libs, args = getmodelprograms()
```

Fortran command syntax:

```
CALL GETMODELPROGRAMS(NSIZ, PROGS, LIBS, ARGS, PCNT)
```

Where:

Integer NSIZ	declared size of PROGS and LIBS (input).
Character*260 PROGS (NSIZ)	(output).
Character*260 LIBS (NSIZ)	names of the libraries each program has been loaded from; the array index of program can be used to identify the corresponding library in this array. (output).
Integer ARGS (NSIZ)	number of arguments for each program; the array index of program can be used to identify the corresponding entry in this array. (output).
Integer PCNT	number of programs returned (input).

17.7. LAST_PF

Return last attempted network solution data.

This API routine was first introduced in release 34.0.0.

Python command syntax:

```
method,opts = last_pf()
```

Fortran command syntax:

```
CALL LAST_PF(METHOD,OPTS)
```

Where:

Integer METHOD	last solution api routine used (output).
METHOD = 0	for Unknown
METHOD = 1	for SOLV - standard Gauss-Seidel
METHOD = 2	for MSLV - modified Gauss-Seidel
METHOD = 3	for FNSL - full Newton-Raphson
METHOD = 4	for NSOL - simple decoupled Newton-Raphson
METHOD = 5	for FDNS - fixed slope decoupled Newton-Raphson
Integer OPTS (8)	array of 8 elements specifying solution parameters; values vary by solution type. For options not used by a particular solution type, a very large value is returned.(output).
OPTS(1)	Tap adjustment flag
OPTS(2)	Area interchange adjustment flag
OPTS(3)	Phase shift adjustment flag
OPTS(4)	Dc tap adjustment flag
OPTS(5)	Switched shunt adjustment flag
OPTS(6)	Flat start flag
OPTS(7)	Var limit flag
OPTS(8)	Non-divergent solution flag

17.8. RXPATH

Use this API to return buses from starting bus to ending bus with shortest electricity distance in terms of one of two options, impedance and number of buses. The total values do not include line charging, off-nominal turns ratio, phase shifter angle etc.

This API routine was first introduced in release 34.8.0 and 35.1.0.

Python command syntax:

```
ierr, iarray, rxvalue = rxpath(iopt, ifrom, itobus, tdim)
```

Fortran command syntax:

```
CALL FINDSHORTESTDISTANCEBETWEENTWOBUS(IOPT, IFROM, ITOBUS, TDIM, IARRAY,  
RXVALUE, IERR)
```

Where:

Integer IOPT	the option to calculate the electricity distance (input; 0 by default).
	IOPT = 0 impedance.
	IOPT = 1 number of buses.
Integer IFROM	starting bus (input; 1 by default).
Integer ITOBUS	ending bus (input; 1 by default).
Integer TDIM	number of buses along the path (input; 1 by default).
Integer IARRAY (TDIM)	the list of buses from starting bus to ending bus (output).
real RXVALUE	total value defined by IOPT from starting bus to ending bus (output).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Working case is empty
	IERR = 2 Invalid starting bus number
	IERR = 3 Invalid ending bus number
	IERR = 4 TDIM is zero
	IERR = 5 Number of buses along the path is greater than TDIM

17.9. TREEDAT

Use this API to return Swing Bus and Island Data of Working Case Network.

This API routine was first introduced in release 33.5.1.

Python command syntax:

```
treeobj = treedat(sizeislands)
```

Fortran command syntax:

```
CALL TREEDAT(NBUS, SIZEISLANDS, NSWINGBUS, NISLANDS, NB_ISLANDS,
  NP_ISLANDS, BUSNUMXX, BUSNAMEXX, BUSKVXX, BUSAREAXX, GENPQXX, LOADXX,
  SHUNTXX, IERR)
```

Where:

Integer NBUS	number of buses in the case (input; no default allowed).
Integer SIZEISLANDS	number of (possible) islands (input; 20 by default).
Integer NSWINGBUS	number of swing buses in the case (output).
Integer NISLANDS	number of actual islands (output).
Integer NB_ISLANDS (SIZEISLANDS)	number of buses in each island (output).
Integer NP_ISLANDS (SIZEISLANDS)	number of plant buses in each island (output).
Integer BUSNUMXX (NBUS)	bus number array, composed from swing + islanded buses, (1:n_swbus) -- swing buses, (n_swbus+1,n_swbus+nb_islands(1)) -- buses in island 1 and so on (output).
Character*12 BUSNAMEXX (NBUS)	bus name array, composed same way as BUSNUMXX (output).
Real BUSKVXX (NBUS)	bus base kV array, composed same way as BUSNUMXX (output).
Integer BUSAREAXX (NBUS)	bus area array, composed same way as BUSNUMXX (output).
Real GENPQXX (SIZEISLANDS*4)	pgen, qgen, qt, qb values for each island (output).
Complex LOADXX (SIZEISLANDS*3)	(PQ, IL, YL) loads for each island (output).
Complex SHUNTXX (SIZEISLANDS)	shunts for each island (output).
Integer TREEOBJ	Returned dictionary object. (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 Warning: All islands data is not fetched. Re-run the activity with argument sizeislands value greater than provided value
	IERR = 2 Error: Working case is empty
	IERR = 3 Error: No sizeislands input value provided
	IERR = 4 Error: Invalid sizeislands input value, must be greater than 0

The returned object 'robj' contains the following attributes:

robj['ierr'] --> Error Code

= 0, No error

= 1, All islands data is not fetched. Re-run the activity
with higher argument sizeislands value.

= 2, Working case is empty.

= 3, No sizeislands input value provided.

= 4, Invalid sizeislands input value, must be greater than 0.

Following values are not returned for robj['ierr']=2,3,4.

robj['nswingbus']: Number of Swing Buses

robj['nislands']: Number of Islands

robj['island_nbus']: [] of size nislands, Number of buses in each island

robj['island_nplants']: [] of size nislands, Number of plant buses in each island

robj['swing_busnum']: [] of size nswingbus, Swing Bus Numbers

robj['swing_busname']: [] of size nswingbus, Swing Bus Names

robj['swing_buskv']: [] of size nswingbus, Swing Bus Base kV

robj['swing_busarea']: [] of size nswingbus, Swing Bus Area

robj['island_busnum']: [] of size nislands, each item is [] of Island Bus Numbers

robj['island_busname']: [] of size nislands, each item is [] of Island Bus Names

robj['island_buskv']: [] of size nislands, each item is [] of Island Bus Base kV

robj['island_busarea']: [] of size nislands, each item is [] of Island Bus Area

robj['island_plants']: [] of size nislands, each item is [] of Island Plant Bus Numbers

robj['island_pgen']: [] of size nislands, Total Pgen of each Island (MVA)

robj['island_qgen']: [] of size nislands, Total Qgen of each Island (MVAR)

robj['island_qt']: [] of size nislands, Total QT of each Island (maximum Q limit) (MVAR)

robj['island_qb']: [] of size nislands, Total QB of each Island (minimum Q limit) (MVAR)

robj['island_load_pq']: [] of size nislands, Total Constant MVA (PL+jQL) loads of each Island (MVA)

robj['island_load_il']: [] of size nislands, Total Constant Current (IP+jIQ) loads of each Island (MVA)

robj['island_load_yl']: [] of size nislands, Total Constant admittance (YP+jYQ) loads of each Island (MVA)

robj['island_shunt']: [] of size nislands, Total Bus Shunts (G+jB) of each Island (MVA)

Chapter 18

Using the Vendor Neutral Contingency and RAS Auxiliary File

This chapter defines API routines that work with the auxiliary contingency/RAS file, a vendor neutral format for providing these specifications.

18.1. ACCC_RAS

This API routine is obsolete. It has been replaced by the API routine [accc_ras_2](#).

Use this API to run AC contingency calculation function with RAS model.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_ACCC_RAS ACCFILE
```

Python command syntax:

```
ierr = accc_ras(accfile)
```

Fortran command syntax:

```
CALL ACCC_RAS(ACCFILE, IERR)
```

Where:

Character*260 ACCFILE	Is the name of the Contingency Solution Output file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error occurred
	IERR = 1	invalid tolerance value from RAS file
	IERR = 2	invalid solution option value from RAS file
	IERR = 3	generators are converted
	IERR = 4	buses in island(s) without a swing bus; use activity TREE
	IERR = 5	largest mismatch exceeds mismatch tolerance
	IERR = 7	too many islands in base case
	IERR = 9	no AC Contingency Solution Output File specified
	IERR = 10	in-service induction machines are in the "stalled" or "tripped" state
	IERR = 11	buses with bus type code and series element status inconsistencies
	IERR = 16	Contingency and Remedial Actions definitions not in memory
	IERR = 17	Contingency and Remedial Actions definitions have not been validated
	IERR = 51	error opening Contingency Solution Output File
	IERR = 56	prerequisite requirements for API are not met.

18.2. ACCC_RAS_2

Use this API to run AC contingency calculation function with RAS model.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACCC_RAS_2 ACCFILE XMLFILE OPTION
```

Python command syntax:

```
ierr = accc_ras_2(accfile,xmlfile,option)
```

Fortran command syntax:

```
CALL ACCC_RAS_2(ACCFILE, XMLFILE, OPTION, IERR)
```

Where:

Character*260 ACCFILE	Is the name of the Contingency Solution Output file (input; no default allowed).
Character*260 XMLFILE	Is the name of the Apply Tracing Output file (input; no default allowed).
Integer OPTION	apply tracing option (input; 0 by default). OPTION = 0 Do not create Apply Tracing file. OPTION = 1 Create Apply Tracing file. OPTION = 2 If Apply Tracing file fails to open, write output to current progress device.
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 1 invalid tolerance value from RAS file IERR = 2 invalid solution option value from RAS file IERR = 3 generators are converted IERR = 4 buses in island(s) without a swing bus; use activity TREE IERR = 5 largest mismatch exceeds mismatch tolerance IERR = 7 too many islands in base case IERR = 9 no AC Contingency Solution Output File specified IERR = 10 in-service induction machines are in the "stalled" or "tripped" state IERR = 11 buses with bus type code and series element status inconsistencies IERR = 16 Contingency and Remedial Actions definitions not in memory IERR = 17 Contingency and Remedial Actions definitions have not been validated

IERR = 51	error opening Contingency Solution Output File
IERR = 56	prerequisite requirements for API are not met.

18.3. ADD2WINDINGCONTINGENCYELEMENT

Add 2 Winding Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADD2WINDINGCONTINGENCYELEMENT CTGNAME IBUS JBUS CKT ACTION ACTVALUE
ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = add2windingcontingencyelement(ctgname, ibus, jbus, ckt, action,
actvalue, actmodif, critname, critstat, persistent, comment, time,
timedelay)
```

Fortran command syntax:

```
CALL ADD2WINDINGCONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, JBUS_I, CKT,
ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, IERR)

CALL ADD2WINDINGCONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, JBUS_C, CKT,
ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, IERR)

CALL ADD2WINDINGCONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, JBUS_C, CKT,
ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, IERR)

CALL ADD2WINDINGCONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, JBUS_I, CKT,
ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 JBUS	A union type describing the network element's JBUS value. JBUS_I refers to Integer, JBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 CKT	A string describing the network element's circuit id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).

character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.4. ADD2WINDINGREMEDIALACTIONELEMENT

Add 2 Winding Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADD2WINDINGREMEDIALACTIONELEMENT RACTNAME IBUS JBUS CKT ACTION
ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = add2windingremedialactionelement(ractname, ibus, jbus, ckt, action,
actvalue, actmodif, critname, critstat, persistent, comment, time,
timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADD2WINDINGREMEDIALACTIONELEMENT_NV (RACTNAME, IBUS_I, JBUS_I, CKT,
ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADD2WINDINGREMEDIALACTIONELEMENT_AR (RACTNAME, IBUS_C, JBUS_C, CKT,
ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADD2WINDINGREMEDIALACTIONELEMENT_AV (RACTNAME, IBUS_C, JBUS_C, CKT,
ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADD2WINDINGREMEDIALACTIONELEMENT_NR (RACTNAME, IBUS_I, JBUS_I, CKT,
ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 JBUS	A union type describing the network element's JBUS value. JBUS_I refers to Integer, JBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 CKT	A string describing the network element's circuit id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).

character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise,

	the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.5. ADD3WINDINGCONTINGENCYELEMENT

Add 3 Winding Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADD3WINDINGCONTINGENCYELEMENT CTGNAME IBUS JBUS KBUS CKT ACTION
  ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = add3windingcontingencyelement(ctgname, ibus, jbus, kbus, ckt,
  action, actvalue, actmodif, critname, critstat, persistent, comment,
  time, timedelay)
```

Fortran command syntax:

```
CALL ADD3WINDINGCONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, JBUS_I, KBUS_I,
  CKT, ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT,
  COMMENT, TIME, TIMEDELAY, IERR)

CALL ADD3WINDINGCONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, JBUS_C, KBUS_C,
  CKT, ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT,
  COMMENT, TIME, TIMEDELAY, IERR)

CALL ADD3WINDINGCONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, JBUS_C, KBUS_C,
  CKT, ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT,
  COMMENT, TIME, TIMEDELAY, IERR)

CALL ADD3WINDINGCONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, JBUS_I, KBUS_I,
  CKT, ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT,
  COMMENT, TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 JBUS	A union type describing the network element's JBUS value. JBUS_I refers to Integer, JBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 KBUS	A union type describing the network element's KBUS value. KBUS_I refers to Integer, KBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 CKT	A string describing the network element's circuit id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).

character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred

IERR = 4

Prerequisite requirements for API are not met

18.6. ADD3WINDINGREMEDIALACTIONELEMENT

Add 3 Winding Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADD3WINDINGREMEDIALACTIONELEMENT RACTNAME IBUS JBUS KBUS CKT ACTION
ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = add3windingremedialactionelement(ractname, ibus, jbus, kbus, ckt,
action, actvalue, actmodif, critname, critstat, persistent, comment,
time, timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADD3WINDINGREMEDIALACTIONELEMENT_NV (RACTNAME, IBUS_I, JBUS_I,
KBUS_I, CKT, ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT,
PERSISTENT, COMMENT, TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT,
ARMINGSTAT, IERR)
```

```
CALL ADD3WINDINGREMEDIALACTIONELEMENT_AR (RACTNAME, IBUS_C, JBUS_C,
KBUS_C, CKT, ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT,
PERSISTENT, COMMENT, TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT,
ARMINGSTAT, IERR)
```

```
CALL ADD3WINDINGREMEDIALACTIONELEMENT_AV (RACTNAME, IBUS_C, JBUS_C,
KBUS_C, CKT, ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT,
PERSISTENT, COMMENT, TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT,
ARMINGSTAT, IERR)
```

```
CALL ADD3WINDINGREMEDIALACTIONELEMENT_NR (RACTNAME, IBUS_I, JBUS_I,
KBUS_I, CKT, ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT,
PERSISTENT, COMMENT, TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT,
ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 JBUS	A union type describing the network element's JBUS value. JBUS_I refers to Integer, JBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 KBUS	A union type describing the network element's KBUS value. KBUS_I refers to Integer, KBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).

character*160 CKT	A string describing the network element's circuit id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as

	a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.7. ADDACLINECONTINGENCYELEMENT

Add Acline Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDACLINECONTINGENCYELEMENT CTGNAME IBUS JBUS CKT ACTION ACTVALUE
  ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addaclinecontingencyelement(ctgname, ibus, jbus, ckt, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay)
```

Fortran command syntax:

```
CALL ADDACLINECONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, JBUS_I, CKT, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDACLINECONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, JBUS_C, CKT, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDACLINECONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, JBUS_C, CKT, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDACLINECONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, JBUS_I, CKT, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 JBUS	A union type describing the network element's JBUS value. JBUS_I refers to Integer, JBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 CKT	A string describing the network element's circuit id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).

character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.8. ADDACLINEREMEDIALACTIONELEMENT

Add Acline Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDACLINEREMEDIALACTIONELEMENT RACTNAME IBUS JBUS CKT ACTION
  ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
  INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addaclineremedialactionelement(ractname, ibus, jbus, ckt, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDACLINEREMEDIALACTIONELEMENT_NV (RACTNAME, IBUS_I, JBUS_I, CKT,
  ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDACLINEREMEDIALACTIONELEMENT_AR (RACTNAME, IBUS_C, JBUS_C, CKT,
  ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDACLINEREMEDIALACTIONELEMENT_AV (RACTNAME, IBUS_C, JBUS_C, CKT,
  ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDACLINEREMEDIALACTIONELEMENT_NR (RACTNAME, IBUS_I, JBUS_I, CKT,
  ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
Integer or Character*18 JBUS	A union type describing the network element's JBUS value. JBUS_I refers to Integer, JBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 CKT	A string describing the network element's circuit id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).

character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise,

	the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.9. ADDBUSCONTINGENCYELEMENT

Add Bus Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDBUSCONTINGENCYELEMENT CTGNAME IBUS ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addbuscontingencyelement(ctgname, ibus, action, actvalue, actmodif,
critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDBUSCONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)

CALL ADDBUSCONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)

CALL ADDBUSCONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)

CALL ADDBUSCONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check).

	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.10. ADDBUSREMEDIALACTIONELEMENT

Add Bus Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDBUSREMEDIALACTIONELEMENT RACTNAME IBUS ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY INCLUSIONFILTER
ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addbusremedialactionelement(ractname, ibus, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay,
inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDBUSREMEDIALACTIONELEMENT_NV (RACTNAME, IBUS_I, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDBUSREMEDIALACTIONELEMENT_AR (RACTNAME, IBUS_C, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDBUSREMEDIALACTIONELEMENT_AV (RACTNAME, IBUS_C, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDBUSREMEDIALACTIONELEMENT_NR (RACTNAME, IBUS_I, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).

character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case.

	For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.11. ADDCONTINGENCY

Add Contingency to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDCONTINGENCY CTGNAME CATEGORY SKIP MEMO
```

Python command syntax:

```
ierr = addcontingency(ctgname, category, skip, memo)
```

Fortran command syntax:

```
CALL ADDCONTINGENCY(CTGNAME, CATEGORY, SKIP, MEMO, IERR)
```

Where:

character*160 CTGNAME	Unique name of the Contingency. (input; no default allowed).
character*160 CATEGORY	A comma delimited list of strings representing the contingency categories assigned to this contingency. (input; blank by default).
character*512 MEMO	A comment field. (input; blank by default).
character*3 SKIP	Set to "YES" and a contingency processor will ignore this contingency. (input; NO). " YES (3 characters). " NO (2 characters).
Integer IERR	error code (output). IERR = 0 no error occurred IERR = 4 prerequisite requirements for API are not met

18.12. ADDCONTINGENCYELEMENT

Add Generic Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDCONTINGENCYELEMENT CTGNAME ELMTTYPE ELMTKEY ACTION ACTVALUE
  ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addcontingencyelement(ctgname, elmttype, elmtkey, action, actvalue,
  actmodif, critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDCONTINGENCYELEMENT_V (CTGNAME, ELMTTYPE, ELMTKEY, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDCONTINGENCYELEMENT_R (CTGNAME, ELMTTYPE, ELMTKEY, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
character*160 ELMTTYPE	Type of the Contingency Element (input; no default allowed).
character*160 ELMTKEY	Object field of the Contingency Element. For Python, enter parameters as module name, funcname and path respectively. (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters).

	"	Check (5 characters).
	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.13. ADDDCCONVCONTINGENCYELEMENT

Add Dconv Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDDCCONVCONTINGENCYELEMENT CTGNAME DCNAME RECT ACTION ACTVALUE
  ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = adddcconvcontingencyelement(ctgname, dcname, rect, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay)
```

Fortran command syntax:

```
CALL ADDDCCONVCONTINGENCYELEMENT_V (CTGNAME, DCNAME, RECT, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)
```

```
CALL ADDDCCONVCONTINGENCYELEMENT_R (CTGNAME, DCNAME, RECT, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
character*160 DCNAME	A string describing the network element's dc name. (Key) (input; no default allowed).
character*160 RECT	A string describing the network element's rect. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters).

	"	Never (5 characters).
	"	Check (5 characters).
	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).	
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.14. ADDDCCONVREMEDIALACTIONELEMENT

Add Dconv Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDDCCONVREMEDIALACTIONELEMENT RACTNAME DCNAME RECT ACTION
ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = adddcconvremedialactionelement(ractname, dcname, rect, action,
actvalue, actmodif, critname, critstat, persistent, comment, time,
timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDDCCONVREMEDIALACTIONELEMENT_V (RACTNAME, DCNAME, RECT, ACTION,
ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDDCCONVREMEDIALACTIONELEMENT_R (RACTNAME, DCNAME, RECT, ACTION,
ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
character*160 DCNAME	A string describing the network element's dc name. (Key) (input; no default allowed).
character*160 RECT	A string describing the network element's rect. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters).

	"	Never (5 characters).
	"	Check (5 characters).
	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).	
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	

Integer IERR	"		Always (6 characters).
	"		Never (5 characters).
	"		Check (5 characters).
	error code (output).		
	IERR = 0		No error occurred
	IERR = 4		Prerequisite requirements for API are not met

18.15. ADDDCLINECONTINGENCYELEMENT

Add Dcline Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDDCLINECONTINGENCYELEMENT CTGNAME DCNAME ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = adddclinecontingencyelement(ctgname, dcname, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDDCLINECONTINGENCYELEMENT_V (CTGNAME, DCNAME, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)

CALL ADDDCLINECONTINGENCYELEMENT_R (CTGNAME, DCNAME, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
character*160 DCNAME	A string describing the network element's dc name. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).

character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.16. ADDCLINEREMEDIALACTIONELEMENT

Add Dcline Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDDCLINEREMEDIALACTIONELEMENT RACTNAME DCNAME ACTION ACTVALUE
ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = adddclineremedialactionelement(ractname, dcname, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay,
inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDDCLINEREMEDIALACTIONELEMENT_V (RACTNAME, DCNAME, ACTION,
ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDDCLINEREMEDIALACTIONELEMENT_R (RACTNAME, DCNAME, ACTION,
ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
character*160 DCNAME	A string describing the network element's dc name. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters).

	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGYCHECK and POSTCHECK solution steps. (input; 0.0).	
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).

	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.17. ADDFIXSHUNTCONTINGENCYELEMENT

Add Fix Shunt Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDFIXSHUNTCONTINGENCYELEMENT CTGNAME IBUS SHNTID ACTION ACTVALUE
  ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addfixshuntcontingencyelement(ctgname, ibus, shntid, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay)
```

Fortran command syntax:

```
CALL ADDFIXSHUNTCONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, SHNTID, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDFIXSHUNTCONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, SHNTID, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDFIXSHUNTCONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, SHNTID, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDFIXSHUNTCONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, SHNTID, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 SHNTID	A string describing the network element's shunt id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the

	CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). - IERR = 0 No error occurred - IERR = 4 Prerequisite requirements for API are not met

18.18. ADDFIXSHUNTREMEDIATIONELEMENT

Add Fix Shunt Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDFIXSHUNTREMEDIATIONELEMENT RACTNAME IBUS SHNTID ACTION
  ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
  INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addfixshuntremedialactionelement(ractname, ibus, shntid, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDFIXSHUNTREMEDIATIONELEMENT_NV (RACTNAME, IBUS_I, SHNTID,
  ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDFIXSHUNTREMEDIATIONELEMENT_AR (RACTNAME, IBUS_C, SHNTID,
  ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDFIXSHUNTREMEDIATIONELEMENT_AV (RACTNAME, IBUS_C, SHNTID,
  ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDFIXSHUNTREMEDIATIONELEMENT_NR (RACTNAME, IBUS_I, SHNTID,
  ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 SHNTID	A string describing the network element's shunt id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power

	Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGYCHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The

	specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.19. ADDGENERATORCONTINGENCYELEMENT

Add Generator Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDGENERATORCONTINGENCYELEMENT CTGNAME IBUS MACHID ACTION ACTVALUE
  ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addgeneratorcontingencyelement(ctgname, ibus, machid, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay)
```

Fortran command syntax:

```
CALL ADDGENERATORCONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, MACHID, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDGENERATORCONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, MACHID, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDGENERATORCONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, MACHID, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)

CALL ADDGENERATORCONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, MACHID, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 MACHID	A string describing the network element's mach id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the

	CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.20. ADDGENERATORREMEDIALACTIONELEMENT

Add Generator Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDGENERATORREMEDIALACTIONELEMENT RACTNAME IBUS MACHID ACTION
  ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
  INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addgeneratorremedialactionelement(ractname, ibus, machid, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDGENERATORREMEDIALACTIONELEMENT_NV (RACTNAME, IBUS_I, MACHID,
  ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDGENERATORREMEDIALACTIONELEMENT_AR (RACTNAME, IBUS_C, MACHID,
  ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDGENERATORREMEDIALACTIONELEMENT_AV (RACTNAME, IBUS_C, MACHID,
  ACTION, ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDGENERATORREMEDIALACTIONELEMENT_NR (RACTNAME, IBUS_I, MACHID,
  ACTION, ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT,
  TIME, TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 MACHID	A string describing the network element's mach id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power

	Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The

	specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.21. ADDLOADCONTINGENCYELEMENT

Add Load Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDLOADCONTINGENCYELEMENT CTGNAME IBUS LOADID ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addloadcontingencyelement(ctgname, ibus, loadid, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDLOADCONTINGENCYELEMENT_NV (CTGNAME, IBUS_I, LOADID, ACTION,
ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, IERR)

CALL ADDLOADCONTINGENCYELEMENT_AR (CTGNAME, IBUS_C, LOADID, ACTION,
ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, IERR)

CALL ADDLOADCONTINGENCYELEMENT_AV (CTGNAME, IBUS_C, LOADID, ACTION,
ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, IERR)

CALL ADDLOADCONTINGENCYELEMENT_NR (CTGNAME, IBUS_I, LOADID, ACTION,
ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 LOADID	A string describing the network element's load id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power

	Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.22. ADDLOADREMEDIALACTIONELEMENT

Add Load Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDLOADREMEDIALACTIONELEMENT RACTNAME IBUS LOADID ACTION ACTVALUE
  ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
  INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addloadremedialactionelement(ractname, ibus, loadid, action,
  actvalue, actmodif, critname, critstat, persistent, comment, time,
  timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDLOADREMEDIALACTIONELEMENT_NV (RACTNAME, IBUS_I, LOADID, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDLOADREMEDIALACTIONELEMENT_AR (RACTNAME, IBUS_C, LOADID, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDLOADREMEDIALACTIONELEMENT_AV (RACTNAME, IBUS_C, LOADID, ACTION,
  ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDLOADREMEDIALACTIONELEMENT_NR (RACTNAME, IBUS_I, LOADID, ACTION,
  ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
  TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
Integer or Character*18 IBUS	A union type describing the network element's IBUS value. IBUS_I refers to Integer, IBUS_C refers to Character value in the Fortran syntax. (Key) (input; no default allowed).
character*160 LOADID	A string describing the network element's load id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power

	Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The

	specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).
	"	Check (5 characters).
Integer IERR	error code (output).	
	IERR = 0	No error occurred
	IERR = 4	Prerequisite requirements for API are not met

18.23. ADDPYTHONCONTINGENCYELEMENT

Add Python Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDPYTHONCONTINGENCYELEMENT CTGNAME PATH MODULENAME FUNCNAME CRITNAME
CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addpythoncontingencyelement(ctgname, path, modulename, funcname,
critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDPYTHONCONTINGENCYELEMENT(CTGNAME, PATH, MODULENAME, FUNCNAME,
CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
character*160 PATH	Path of the module (input; blank by default).
character*160 MODULENAME	Module Name of the element (input; no default allowed).
character*160 FUNCNAME	Function Name of the element (input; no default allowed).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until

	a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.24. ADDPYTHONREMEDIALACTIONELEMENT

Add Python Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDPYTHONREMEDIALACTIONELEMENT RACTNAME PATH MODULENAME FUNCNAME
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY INCLUSIONFILTER
ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addpythonremedialactionelement(ractname, path, modulename,
funcname, critname, critstat, persistent, comment, time, timedelay,
inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDPYTHONREMEDIALACTIONELEMENT(RACTNAME, PATH, MODULENAME,
FUNCNAME, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
character*160 PATH	Path of the module (input; blank by default).
character*160 MODULENAME	Module Name of the element (input; no default allowed).
character*160 FUNCNAME	Function Name of the element (input; no default allowed).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLO-

	GYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).
	" YES (3 characters).
	" NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).
	" Always (6 characters).
	" Never (5 characters).
	" Check (5 characters).
Integer IERR	error code (output).
	IERR = 0 No error occurred
	IERR = 4 Prerequisite requirements for API are not met

18.25. ADDREMEDIALACTION

Add Remedial Action to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDREMEDIALACTION RACTNAME SKIP MEMO ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addremedialaction(ractname, skip, memo, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDREMEDIALACTION(RACTNAME, SKIP, MEMO, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Unique name of the remedial action. (input; no default allowed).
character*3 SKIP	Set to "YES" and a remedial action processor will ignore this remedial action. (input; NO).
	" YES (3 characters).
	" NO (2 characters).
character*512 MEMO	A comment field. (input; blank by default).
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).
	" Always (6 characters).
	" Never (5 characters).
	" Check (5 characters).
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 4 prerequisite requirements for API are not met

18.26. ADDREMEDIALACTIONELEMENT

Add Generic Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDREMEDIALACTIONELEMENT RACTNAME ELMTTYPE ELMTKEY ACTION
ACTVALUE ACTMODIF CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
INCLUSIONFILTER ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addremedialactionelement(ractname, elmttype, elmtkey, action,
actvalue, actmodif, critname, critstat, persistent, comment, time,
timedelay, inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDREMEDIALACTIONELEMENT_V (RACTNAME, ELMTTYPE, ELMTKEY, ACTION,
ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDREMEDIALACTIONELEMENT_R (RACTNAME, ELMTTYPE, ELMTKEY, ACTION,
ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
character*160 ELMTTYPE	Type of the Remedial Action Element (input; no default allowed).
character*160 ELMTKEY	Object field of the Remedial Action Element. For Python, enter parameters as modulename, funcname and path respectively. (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters).

	"	Never (5 characters).
	"	Check (5 characters).
	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).	
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	

Integer IERR	"		Always (6 characters).
	"		Never (5 characters).
	"		Check (5 characters).
	error code (output).		
	IERR = 0		No error occurred
	IERR = 4		Prerequisite requirements for API are not met

18.27. ADDSUBCONTINGENCYELEMENT

Add Sub Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDSUBCONTINGENCYELEMENT CTGNAME SUBID ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addsubcontingencyelement(ctgname, subid, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDSUBCONTINGENCYELEMENT_V (CTGNAME, SUBID, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)

CALL ADDSUBCONTINGENCYELEMENT_R (CTGNAME, SUBID, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
character*160 SUBID	A string describing the network element's sub id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).

character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.28. ADDSUBREMEDIATIONELEMENT

Add Sub RemedialAction Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDSUBREMEDIATIONELEMENT RACTNAME SUBID ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY INCLUSIONFILTER
ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addsubremedialactionelement(ractname, subid, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay,
inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDSUBREMEDIATIONELEMENT_V (RACTNAME, SUBID, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDSUBREMEDIATIONELEMENT_R (RACTNAME, SUBID, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY,
INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
character*160 SUBID	A string describing the network element's sub id. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck, PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters).

	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGYCHECK and POSTCHECK solution steps. (input; 0.0).	
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).

Integer IERR	"		Check (5 characters).
	error code (output).		
	IERR = 0		No error occurred
	IERR = 4		Prerequisite requirements for API are not met

18.29. ADDVSCDCCONTINGENCYELEMENT

Add Vscdc Contingency Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDVSCDCCONTINGENCYELEMENT CTGNAME DCNAME ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY
```

Python command syntax:

```
ierr = addvscdccontingencyelement(ctgname, dcname, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay)
```

Fortran command syntax:

```
CALL ADDVSCDCCONTINGENCYELEMENT_V (CTGNAME, DCNAME, ACTION, ACTVALUE_C,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)

CALL ADDVSCDCCONTINGENCYELEMENT_R (CTGNAME, DCNAME, ACTION, ACTVALUE_R,
ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME, TIMEDELAY, IERR)
```

Where:

character*160 CTGNAME	Name of the contingency (or TSContingency) to which this element belongs. (Key) (input; no default allowed).
character*160 DCNAME	A string describing the network element's dc name. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters). " TopologyCheck (13 characters). " PostCheck (9 characters). " SolutionFail (12 characters).

character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO). " YES (3 characters). " NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGY-CHECK and POSTCHECK solution steps. (input; 0.0).
Integer IERR	error code (output). IERR = 0 No error occurred IERR = 4 Prerequisite requirements for API are not met

18.30. ADDVSCDCREMEDIALACTIONELEMENT

Add Vscdc Remedial Action Element to RAS memory model

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_ADDVSCDCREMEDIALACTIONELEMENT RACTNAME DCNAME ACTION ACTVALUE ACTMODIF
CRITNAME CRITSTAT PERSISTENT COMMENT TIME TIMEDELAY INCLUSIONFILTER
ARMINGCRIT ARMINGSTAT
```

Python command syntax:

```
ierr = addvscdcremedialactionelement(ractname, dcname, action, actvalue,
actmodif, critname, critstat, persistent, comment, time, timedelay,
inclusionfilter, armingcrit, armingstat)
```

Fortran command syntax:

```
CALL ADDVSCDCREMEDIALACTIONELEMENT_V (RACTNAME, DCNAME, ACTION,
ACTVALUE_C, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)

CALL ADDVSCDCREMEDIALACTIONELEMENT_R (RACTNAME, DCNAME, ACTION,
ACTVALUE_R, ACTMODIF, CRITNAME, CRITSTAT, PERSISTENT, COMMENT, TIME,
TIMEDELAY, INCLUSIONFILTER, ARMINGCRIT, ARMINGSTAT, IERR)
```

Where:

character*160 RACTNAME	Name of the remedial action to which this element belongs. (Key) (input; no default allowed).
character*160 DCNAME	A string describing the network element's dc name. (Key) (input; no default allowed).
character*5 ACTION	A string describing this action. (Key) (input; no default allowed).
Real or Character*160 ACTVALUE	Value of the Action. ACTVALUE_R refers to Real, ACTVALUE_C refers to Character value in the Fortran syntax (input; blank by default).
character*160 ACTMODIF	Modifier field of the Action (input; blank by default).
character*160 CRITNAME	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies. (input; blank by default).
character*13 CRITSTAT	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. For Transient Stability Elements, the choices are either Always, Never, or CHECK (input; Check). " Always (6 characters). " Never (5 characters). " Check (5 characters).

	"	TopologyCheck (13 characters).
	"	PostCheck (9 characters).
	"	SolutionFail (12 characters).
character*3 PERSISTENT	This field is only defined for the Power Flow Contingency Elements. A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO. (input; NO).	
	"	YES (3 characters).
	"	NO (2 characters).
character*160 COMMENT	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string. (input; blank by default).	
real TIME	Time at which the defined Action takes place specified in a real number in seconds. This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency. (input; 0.0).	
real TIMEDELAY	This field is only defined for the Power Flow Contingency Elements. Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGYCHECK and POSTCHECK solution steps. (input; 0.0).	
character*160 INCLUSIONFILTER	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4. (input; blank by default).	
character*160 ARMINGCRIT	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed. (input; blank by default).	
character*6 ARMINGSTAT	Set to either Always, Never, or Check. Default value used when none specified is Check. Always -> action is considered armed regardless of the ArmingCriteria Never -> action is not armed Check -> action is armed if ArmingCriteria is true or not specified (input; Check).	
	"	Always (6 characters).
	"	Never (5 characters).

Integer IERR	"		Check (5 characters).
	error code (output).		
	IERR = 0		No error occurred
	IERR = 4		Prerequisite requirements for API are not met

18.31. APPEND_RAS

Use this API to read a Contingency Definition and Remedial Actions auxiliary file, adding to definitions in memory, if present.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_APPEND_RAS IFILE
```

Python command syntax:

```
ierr = append_ras(ifile)
```

Fortran command syntax:

```
CALL APPEND_RAS(IFILE, IERR)
```

Where:

character*260 IFILE	Contingency Definition and Remedial Actions auxiliary file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 2	error opening IFILE
	IERR = 3	error closing IFILE
	IERR = 4	prerequisite requirements for API are not met

18.32. READ_RAS

Use this API to read a Contingency Definition and Remedial Actions auxiliary file into memory.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_READ_RAS IFILE
```

Python command syntax:

```
ierr = read_ras(ifile)
```

Fortran command syntax:

```
CALL READ_RAS( IFILE, IERR)
```

Where:

character*260 IFILE	Contingency Definition and Remedial Actions auxiliary file (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 2	error opening IFILE
	IERR = 3	error closing IFILE
	IERR = 4	prerequisite requirements for API are not met

18.33. VALIDATE_RAS

Use this API to validate Contingency and Remedial Actions definitions in memory.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_VALIDATE_RAS
```

Python command syntax:

```
ierr = validate_ras()
```

Fortran command syntax:

```
CALL VALIDATE_RAS( IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	Contingency and Remedial Actions definitions not in memory
	IERR = 4	prerequisite requirements for API are not met

18.34. WRITE_RAS

Use this API to write a Contingency Definition and Remedial Actions auxiliary file from memory.

This API routine was first introduced in release 34.6.0.

Batch command syntax:

```
BAT_WRITE_RAS IFILE OPTION(1)..OPTION(8)
```

Python command syntax:

```
ierr = write_ras(ifile,options)
```

Fortran command syntax:

```
CALL WRITE_RAS(IFILE, OPTIONS, IERR)
```

Where:

character*260 IFILE	Contingency Definition and Remedial Actions auxiliary file (input; no default allowed).
Integer OPTIONS (8)	array of 8 elements specifying (input).
	OPTIONS(1) write records with bad ID fields (alias is IncludeBadId) (0 by default)
	OPTIONS(1) = 0 do not write records with bad ID fields
	OPTIONS(1) = 1 write records with bad ID fields
	OPTIONS(2) write internal contents of fields with bad data (alias is IncludeBadData) (0 by default)
	OPTIONS(2) = 0 do not write fields with bad data
	OPTIONS(2) = 1 write all fields with data input, even if values are invalid
	OPTIONS(3) write all defined fields (alias is includeAllFields) (0 by default)
	OPTIONS(3) = 0 write fields only if at least on record had data for that field
	OPTIONS(3) = 1 write all fields, including fields defined for RAS analysis for which no data was entered on any record
	OPTIONS(3) = 3 label
	OPTIONS(4) (future use) write bus numbers or names (alias is busOutput) (0 by default)
	OPTIONS(4) = 0 bus number
	OPTIONS(4) = 1 bus name
	OPTIONS(4) = 2 bus name and kV
	OPTIONS(4) = 3 label
	OPTIONS(5) future use (0 by default)
	OPTIONS(6) future use (0 by default)
	OPTIONS(7) future use (0 by default)

	OPTIONS(8)	future use (0 by default)
Integer IERR	error code (output).	
	IERR = 0	no error
	IERR = 1	Contingency and Remedial Actions definitions not in memory
	IERR = 2	error opening IFILE
	IERR = 3	error closing IFILE
	IERR = 4	prerequisite requirements for API are not met

Chapter 19

Non-Engineering

This chapter defines API routines that provide functions not associated with PSS®E data, analysis, or graphics capabilities.

Most of these routines do not record themselves when called with recording enabled. Those that have a batch format documented can record themselves.

19.1. ALERT

Use this API to send output to the alert device.

Note: A Fortran program that calls ALERTS must also include a USE statement for KEYPTI.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
alert(string)
```

Fortran command syntax:

```
CALL ALERTS(STRING)
```

```
CALL ALERTS(STRING-ARRAY)
```

Where:

Character*220 STRING	string to be written (input).
Character*220 STRING-ARRAY	array of strings to be written

19.2. BEGINREPORT

Use this API to create a new report tab in the GUI.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
beginreport()
```

Fortran command syntax:

```
CALL RPTBEG()
```

19.3. CLEARALERTOUTPUT

Clear the Alerts/Warnings tab of the output bar in the GUI

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_CLEARALERTOUTPUT
```

Python command syntax:

```
clearalertoutput()
```

Fortran command syntax:

```
CALL CLEARALERTOUTPUT
```

19.4. CLEARPROGRESSOUTPUT

Clear the Progress tab of the output bar in the GUI

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_CLEARPROGRESSOUTPUT
```

Python command syntax:

```
clearprogressoutput()
```

Fortran command syntax:

```
CALL CLEARPROGRESSOUTPUT
```

19.5. FILEIN

Get input from file (Fortran unit number).

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr, string, flags = filein(lunit)
```

Where:

Integer LUNIT	Fortran logical unit number of the file (input).
Character*512 STRING	buffer read from file (output).
Integer ILEN	declared length (input).
Logical FLAGS	the first element of flags is set to true if an end-of-file is encountered; the second element of flags is set to true if the file is closed after the read attempt (output).
Integer IERR	error code (output).
	IERR = 0 no error occurred.

19.6. GETBATDEFAULTS

Retrieve "no input" value for integers and reals.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
idef, rdef = getbatdefaults()
```

Fortran command syntax:

```
CALL GETBATDEFAULTS(IDEF, RDEF)
```

Where:

Integer IDEF	default integer value used in the batch command processor (output).
Real RDEF	default real value used in the batch command processor (output).

19.7. GETDEFAULTCHAR

Retrieve "no input" value for characters (i.e., strings) other than filenames. Specify this value to indicate that "no input" is intended.

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
cdef = getdefaultchar()
```

Fortran command syntax:

```
CALL GETDEFAULTCHAR(CDEF)
```

Where:

Character*1 CDEF	"no character value (output)."
------------------	--------------------------------

19.8. GETDEFAULTINT

Retrieve "no input" value for integers. Specify this value to indicate that "no input" is intended.

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
idef = getdefaultint()
```

Fortran command syntax:

```
CALL GETDEFAULTINT( IDEF )
```

Where:

Integer IDEF	"no integer value (output)."
--------------	------------------------------

19.9. GETDEFAULTREAL

Retrieve "no input" value for reals (floats). Specify this value to indicate that "no input" is intended.

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
rdef = getdefaultreal()
```

Fortran command syntax:

```
CALL GETDEFAULTREAL(RDEF)
```

Where:

Real RDEF	"no real value (output)."
-----------	---------------------------

19.10. GETLOADEDMODULES

Get list of all modules currently loaded.

This API routine was first introduced in release 32.0.1.

Python command syntax:

```
modules = getloadedmodules()
```

Where:

Character MODULES	list of loaded Python modules (output).
-------------------	---

19.11. GETMODFUNCLIST

Get list of external callable methods given a module name. Module is imported in process.

This API routine was first introduced in release 32.0.0.

Python command syntax:

```
c = getmodfunclist(mod)
```

Where:

Character MOD	module name (input).
Character C	list of callable methods (output).

19.12. IOFLUSH

Force all files in PSSE to flush buffers to disk, if possible.

This API routine was first introduced in release 30.2.1.

Python command syntax:

```
ioflush()
```

Fortran command syntax:

```
CALL IOFLSH()
```

19.13. LAUNCH_PROGRAM

This API routine was first introduced in release 34.1.0.

Batch command syntax:

```
BAT_LAUNCH_PROGRAM PROGRAM NUMARGS ARGS(1) .. ARGS(NUMARGS)
```

Python command syntax:

```
ierr = launch_program(program, numargs, args)
```

Fortran command syntax:

```
CALL LAUNCH_PROGRAM(PROGRAM, NUMARGS, ARGS, IERR)
```

Where:

Character*260 PROGRAM	name of program to launch (input; no default allowed).
Integer NUMARGS	number of argument strings to pass to launched program (input).
Character*260 ARGS (NUMARGS)	argument strings to pass to launched program (input).
Integer IERR	error code (output).

19.14. PAGEREPORT

Use this API to place a report separator on the active report tab of the GUI.

This API routine was first introduced in release 30.2.0.

Python command syntax:

```
pagereport ( )
```

Fortran command syntax:

```
CALL RPTPGBK ( )
```

19.15. PROGRESS

Send output to progress device.

Note: A Fortran program that calls PROGRESS must also include a USE statement for KEYPTI.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
progress(string)
```

Fortran command syntax:

```
CALL PROGRESS(STRING)
```

Where:

Character*220 STRING	string to be written (input).
Character*220 STRING-ARRAY	array of strings to be written

19.16. PROMPT

Send output to prompt device. Prompts are stored until the next terminal input request. Up to 36 buffers of up to 220 characters can be stored.

Note: A Fortran program that calls PROMPTS must also include a USE statement for KEYPTI.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
prompt(string)
```

Fortran command syntax:

```
CALL PROMPTS(STRING)
```

```
CALL PROMPTS(STRING-ARRAY)
```

Where:

Character*220 STRING	string to be written (input).
Character*220 STRING-ARRAY	array of strings to be written

19.17. PSSEINIT

Initialize PSSE.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr = psseinit(buses)
```

Fortran command syntax:

```
CALL PSSEINIT(BUSES, IERR)
```

Where:

Integer BUSES	requested bus size; zero for default size level (input).
Integer IERR	error code (output).

19.18. PSSEVERSION

Get PSSE version information.

This API routine was first introduced in release 30.1.0.

Python command syntax:

```
name,major,minor,update,date,stat = psseversion()
```

Fortran command syntax:

```
CALL REVPSSE(NAME, MAJOR, MINOR, UPDATE, DATE, STAT)
```

Where:

Character*32 NAME	product name (output).
Integer MAJOR	major release number (output).
Integer MINOR	minor release number (output).
Integer UPDATE	update release number (output).
Character*30 DATE	release date (output).
Character*132 STAT	any special release information (output).

19.19. REFRESHGUI

Refresh the graphical user interface.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
refreshgui()
```

19.20. REPORT

Send output to report device.

Note: A Fortran program that calls REPORTS must also include a USE statement for KEYPTI.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
report(string)
```

Fortran command syntax:

```
CALL REPORTS(STRING)
```

Where:

Character*220 STRING	string to be written (input).
Character*220 STRING-ARRAY	array of strings to be written

19.21. RUNIPLANFILE

Execute an IPLAN program.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
runiplanfile(iplname)
```

Fortran command syntax:

```
CALL EXECRUN(IPLNAME)
```

Where:

Character*260 IPLNAME	the filename; the filename can be followed by arguments as part of a single string, in which case the filename must be delimited (e.g. enclosed in quotes). The -arg option can be specified this way as well. (input).
-----------------------	---

19.22. RUNRSPNSFILE

Run a response file. Operates by replacing standard input with a file.

Then begin and continue reading from terminal until standard input is no longer redirected using PSSE command line techniques (allowing interaction with IPLAN programs, for example).

Pass any results to Command Line Interface (CLI). The CLI can recognize batch commands and Line Mode commands and direct them to the proper interpreters.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
runrspnsfile(rspname)
```

Where:

Character*260 RSPNAME

the filename; the filename can be followed by arguments as part of a single string, in which case the filename must be delimited (e.g. enclosed in quotes). (input).

19.23. SHOWLOADEDLIBRARIES

Display list of all libraries currently loaded.

This API routine was first introduced in release 34.5.0.

Python command syntax:

```
showloadedlibraries()
```

19.24. SHOWLOADEDMODULES

Display list of all modules currently loaded.

This API routine was first introduced in release 32.0.2.

Python command syntax:

```
showloadedmodules( )
```

19.25. STARTRECORDING

Start recording program operation.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr = startrecording(iopt,string)
```

Fortran command syntax:

```
CALL STARTRECORDING(IOPT, STRING, IERR)
```

Where:

Integer IOPT	type of format to be recorded (input).
	IOPT = 0 record in batch (BAT_*) format.
	IOPT = 1 record in python format.
Character*260 STRING	filename (input).
Integer IERR	error code (output).
	IERR = 0 no error occurred.
	IERR = 2 unable to open file.

19.26. STOPRECORDING

Stop recording program operation.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr = stoprecording()
```

Fortran command syntax:

```
CALL STOPRECORDING(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	no error occurred.
	IERR = 1	error closing file.
	IERR = 2	not recording.

19.27. T_ALERT_OUTPUT

Use this API to specify a "T" alert device, i.e. a destination for a copy of everything sent to the alert device.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_T_ALERT_OUTPUT ISLCT FILARG OPTIONS(1)..OPTIONS(2)
```

Python command syntax:

```
ierr = t_alert_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL TALERTDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
	ISLCT = 1 standard destination. In the PSSE GUI standard output for alerts is a message box and a copy to the Alerts/Warnings tab of the output bar.
	ISLCT = 2 direct output to a file.
	ISLCT = 3 direct output to a printer.
	ISLCT = 4 direct output to progress device.
	ISLCT = 5 direct output to report device.
	ISLCT = 6 no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
	OPTIONS(1) file and printer open options: The OPTIONS(1) values may be summed to select multiple options
	OPTIONS(1) = 0 open with carriage control format and, for files, for overwrite of existing files
	OPTIONS(1) = 1 open with list format
	OPTIONS(1) = 2 open file for append (file output only)
	OPTIONS(1) = 2 set printer orientation to portrait mode (printer output only)
	OPTIONS(1) = 4 open printer in immediate print mode (printer output only)
	OPTIONS(2) number of copies to print (printer only)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met
	IERR = 2 failed to open device

19.28. T_PROGRESS_OUTPUT

Use this API to specify a "T" progress device, i.e. a destination for a copy of everything sent to the progress device.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_T_PROGRESS_OUTPUT ISLCT FILARG OPTIONS(1)..OPTIONS(2)
```

Python command syntax:

```
ierr = t_progress_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL TPROGRESSDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
ISLCT = 1	standard destination. In the PSSE GUI standard output for progress is the Progress tab of the output bar.
ISLCT = 2	direct output to a file.
ISLCT = 3	direct output to a printer.
ISLCT = 4	direct output to progress device.
ISLCT = 5	direct output to report device.
ISLCT = 6	no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
OPTIONS(1)	file and printer open options: The OPTIONS(1) values may be summed to select multiple options
OPTIONS(1) = 0	open with carriage control format and, for files, for overwrite of existing files
OPTIONS(1) = 1	open with list format
OPTIONS(1) = 2	open file for append (file output only)
OPTIONS(1) = 2	set printer orientation to portrait mode (printer output only)
OPTIONS(1) = 4	open printer in immediate print mode (printer output only)
OPTIONS(2)	number of copies to print (printer only)
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	prerequisite requirements for API are not met
IERR = 2	failed to open device

19.29. T_PROMPT_OUTPUT

Use this API to specify a "T" prompt device, i.e. a destination for a copy of everything sent to the prompt device.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_T_PROMPT_OUTPUT ISLCT FILARG OPTIONS(1)..OPTIONS(2)
```

Python command syntax:

```
ierr = t_prompt_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL TPROMPTDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
	ISLCT = 1 standard destination. In the PSSE GUI standard output for prompts is the input window generated by user input requests.
	ISLCT = 2 direct output to a file.
	ISLCT = 3 direct output to a printer.
	ISLCT = 4 direct output to progress device.
	ISLCT = 5 direct output to report device.
	ISLCT = 6 no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
	OPTIONS(1) file and printer open options: The OPTIONS(1) values may be summed to select multiple options
	OPTIONS(1) = 0 open with carriage control format and, for files, for overwrite of existing files
	OPTIONS(1) = 1 open with list format
	OPTIONS(1) = 2 open file for append (file output only)
	OPTIONS(1) = 2 set printer orientation to portrait mode (printer output only)
	OPTIONS(1) = 4 open printer in immediate print mode (printer output only)
	OPTIONS(2) number of copies to print (printer only)
Integer IERR	error code (output).
	IERR = 0 no error occurred
	IERR = 1 prerequisite requirements for API are not met
	IERR = 2 failed to open device

19.30. T_REPORT_OUTPUT

Use this API to specify a "T" report device, i.e. a destination for a copy of everything sent to the report device.

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_T_REPORT_OUTPUT ISLCT FILARG OPTIONS(1)..OPTIONS(2)
```

Python command syntax:

```
ierr = t_report_output(islct, filarg, options)
```

Fortran command syntax:

```
CALL TREPORTDEVICE(ISLCT, FILARG, OPTIONS, IERR)
```

Where:

Integer ISLCT	virtual device selector (input).
ISLCT = 1	standard destination. In the PSSE GUI standard output for reports is the Report tab of the output bar.
ISLCT = 2	direct output to a file.
ISLCT = 3	direct output to a printer.
ISLCT = 4	direct output to progress device.
ISLCT = 5	direct output to report device.
ISLCT = 6	no output.
Character*260 FILARG	printer name or filename; ignored if ISLCT is not 2 or 3 (input).
Integer OPTIONS (2)	array of 2 elements specifying open and printing options; ignored if ISLCT is not 2 or 3(input).
OPTIONS(1)	file and printer open options: The OPTIONS(1) values may be summed to select multiple options
OPTIONS(1) = 0	open with carriage control format and, for files, for overwrite of existing files
OPTIONS(1) = 1	open with list format
OPTIONS(1) = 2	open file for append (file output only)
OPTIONS(1) = 2	set printer orientation to portrait mode (printer output only)
OPTIONS(1) = 4	open printer in immediate print mode (printer output only)
OPTIONS(2)	number of copies to print (printer only)
Integer IERR	error code (output).
IERR = 0	no error occurred
IERR = 1	prerequisite requirements for API are not met
IERR = 2	failed to open device

19.31. USERIN

Get input from interactive device.

This API routine was first introduced in release 30.0.0.

Python command syntax:

```
ierr,string = userin()
```

Where:

Character*512 STRING

buffer input by user (output).

Integer IERR

error code (output).

IERR = 0 no error occurred.

Chapter 20

PSSPLOT Module

This chapter defines API routines that are used to manipulate plots in the interface. They will elicit no action if the GUI is not present when invoked.

Please note that these routines are members of the pssplot Python extension module, not psspy. When recorded for Python, the recording will reference each of these functions within the pssplot namespace.

20.1. ADDFUNCTION

Add a Function Definition

This API routine was first introduced in release 34.4.0.

Batch command syntax:

```
BAT_ADDFUNCTION FUNCNAME FUNCSTR NUMVARS CHANNFILES(1)...CHANNFILES(6)
CHANNINDICES(1)...CHANNINDICES(6)
```

Python command syntax:

```
addfunction(funcname, funcstr, numvars, channfiles, channindices)
```

Fortran command syntax:

```
CALL ADDFUNCTION(FUNCNAME, FUNCSTR, NUMVARS, CHANNFILES, CHANNINDICES)
```

Where:

character*32 FUNCNAME	(input).
character*32 FUNCSTR	(input).
Integer NUMVARS	(input).
character*260 CHANNFILES (6)	(input).
Integer CHANNINDICES (6)	(input).

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_CHANNELFILEEXCELEXPORt SFILENAME
```

Python command syntax:

```
channelfileexcellexport(sfilename)
```

Fortran command syntax:

```
CALL CHANNELFILEEXCELEXPORt(SFILENAME)
```

Where:

Character*260 SFILENAME name of the channel file to be opened (input).

20.3. DELETESELPLLOT

Use this API to delete the selected plot on the active page in the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_DELETESELPLLOT
```

Python command syntax:

```
deleteselplot()
```

Fortran command syntax:

```
CALL DELETESELPLLOT
```

20.4. DRAGDROPLOTDATA

Use this API to load a Channel Output File into the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_DRAGDROPLOTDATA  SFILENAME  SCHANNELNAME
```

Python command syntax:

```
dragdropplotdata(sfilename, schannelname)
```

Fortran command syntax:

```
CALL DRAGDROPLOTDATA(SFILENAME, SCHANNELNAME)
```

Where:

Character*260 SFILENAME Channel File name (input).

Character*260 SCHANNELNAME Channel to be dragged to the plot (input).

20.5. EXPORTPLOT

Use this API to export the selected plot on the active page in the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_EXPORTPLOT SFILENAME NTYPE
```

Python command syntax:

```
exportplot(sfilename, ntype)
```

Fortran command syntax:

```
CALL EXPORTPLOT(SFILENAME, NTYPE)
```

Where:

Character*260 SFILENAME	filename (input).
Integer NTYPE	graphics format for the exported file (input).
	NTYPE = 1 Metafile export
	NTYPE = 2 Bitmap export
	NTYPE = 3 JPEG export
	NTYPE = 4 PDF export

20.6. INSERTPAGE

Use this API to insert a page into the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_INSERTPAGE
```

Python command syntax:

```
insertpage()
```

Fortran command syntax:

```
CALL INSERTPAGE
```

20.7. INSERTPLOT

Use this API to add an empty plot on the active page in the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_INSERTPLOT
```

Python command syntax:

```
insertplot()
```

Fortran command syntax:

```
CALL INSERTPLOT
```

This API routine was first introduced in release 34.0.0.

Batch command syntax:

```
BAT_MULTICHANNEXCELEXPORt SFILENAME, NUMCHANNS,  
    CHANNINDICE(1), . . . , CHANNINDICE(NUMCHANNS)
```

Python command syntax:

```
multichannexcelexport(sfilename, numchanns, channindice)
```

Fortran command syntax:

```
CALL MULTICHANNEXCELEXPORt(SFILENAME, NUMCHANNS, CHANNINDICE)
```

Where:

Character*260 SFILENAME	filename (input).
Integer NUMCHANNS	Number of Channels to Export (input).
Integer CHANNINDICE	Channel Number to Export (input).

20.9. NEWPLOTBOOK

Use this API to create a new plotting book.

This API routine was first introduced in release 32.0.0.

Batch command syntax:

```
BAT_NEWPLOTBOOK
```

Python command syntax:

```
newplotbook()
```

Fortran command syntax:

```
CALL NEWPLOTSHEET
```

20.10. OPENCHANDATAFILE

Use this API to load a Channel Output File into the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_OPENCHANDATAFILE  SFILENAME
```

Python command syntax:

```
openchandatafile(sfilename)
```

Fortran command syntax:

```
CALL OPENCHANDATAFILE(SFILENAME)
```

Where:

Character*260 SFILENAME name of the channel file to be opened (input).

20.11. PLOTPAGEPRINTSETUP

Plot Page Print Settings

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_PLOTPAGEPRINTSETUP ORIENT NUMROWS NUMCOLS VERTSPAC HORSPAC
```

Python command syntax:

```
plotpageprintsetup(orient, numrows, numcols, vertspac, horspac)
```

Fortran command syntax:

```
CALL PLOTPAGEPRINTSETUP(ORIENT, NUMROWS, NUMCOLS, VERTSPAC, HORSPAC)
```

Where:

Integer ORIENT	(input).
Integer NUMROWS	(input).
Integer NUMCOLS	(input).
Integer VERTSPAC	(input).
Integer HORSPAC	(input).

20.12. PRINTACTIVEPAGE

Use this API to print the active page on the default printer.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_PRINTACTIVEPAGE
```

Python command syntax:

```
printactivepage()
```

Fortran command syntax:

```
CALL PRINTACTIVEPAGE
```

20.13. PRINTSEL PLOT

Use this API to print the selected plot on the active page in the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_PRINTSEL PLOT SFILENAME NORIENT NINDEX
```

Python command syntax:

```
printselplot(sfilename, norient, nindex)
```

Fortran command syntax:

```
CALL PRINTSEL PLOT(SFILENAME, NORIENT, NINDEX)
```

Where:

Character*260 SFILENAME	name of the file to print (input).
Integer NORIENT	orientation of the paper (input). NORIENT = 0 Portrait NORIENT = 1 Landscape
Integer NINDEX	index for the printer you wish to use; This index refers to the list of printers defined on your system; default = 1 (input).

20.14. SETSELECTEDPAGE

Use this API to set the active page in the plotting book

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETSELECTEDPAGE    NPAGENUM
```

Python command syntax:

```
setselectedpage(npagenum)
```

Fortran command syntax:

```
CALL SETSELECTEDPAGE(NPAGENUM)
```

Where:

Integer NPAGENUM page number in the plotting book (input).

20.15. SETSELECTEDPLOT

Use this API to set the selected plot on the active page in the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SETSELECTEDPLOT  NPLOTNUM
```

Python command syntax:

```
setselectedplot(npotnum)
```

Fortran command syntax:

```
CALL SETSELECTEDPLOT(NPLOTNUM)
```

Where:

Integer NPLOTNUM plot number on the selected page (input).

20.16. SHOWPLOTEDITOR

Use this API to display the editor for the selected plot in the plotting book.

This API routine was first introduced in release 31.0.0.

Batch command syntax:

```
BAT_SHOWPLOTEDITOR
```

Python command syntax:

```
showploteditor()
```

Fortran command syntax:

```
CALL SHOWPLOTEDITOR
```

20.17. XYPLOT

Use this API to create an X-Y Plot

This API routine was first introduced in release 34.3.0.

Batch command syntax:

```
BAT_XYPLOT  SFILENAME XCHANNELNAME YCHANNELNAME
```

Python command syntax:

```
xypLOT(sfIlename, xchannelname, ychannelname)
```

Fortran command syntax:

```
CALL XYPLOT(SFILENAME, XCHANNELNAME, YCHANNELNAME)
```

Where:

Character*260 SFILENAME	Channel File name (input).
character*260 XCHANNELNAME	(input).
character*260 YCHANNELNAME	(input).

Chapter 21

PSSRDB Module

Note

The PSSRDB Module has been discontinued starting with PSS®E 34.9.1 due to support for Data Visualization and Reporting (DVRM) ending.

The APIs previously provided with the PSSRDB Module are no longer usable and are considered Obsolete.

Chapter 22

MUSTPY Module

This chapter defines API routines that are used for Transfer Analysis and Sensitivities features.

Please note that these routines are members of the mustpy Python extension module, not psspy. When recorded for Python, the recording will reference each of these functions within the mustpy namespace.

22.1. MUST Analysis Functions

These API routines are recordable and perform system analysis functions.

22.1.1. ACCDEFAULTS

Use this function to enter a set of default AC Contingency options for later use in an the AC contingency analysis

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACCDEFAULTS  OPTSI(1)..OPTS(10)  VALUES(1)..VALUES(3)
```

Python command syntax:

```
ierr = accdefaults(options, values)
```

Fortran command syntax:

```
CALL MAPI_ACCDEFAULTS(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (11)	array of 11 elements specifying calculation options(input).
OPTIONS(1)	AC LF method (2 by default)
OPTIONS(1) = 1	AC Newton
OPTIONS(1) = 2	AC Decoupled
OPTIONS(2)	Apply non-divergent LF (0 by default)
OPTIONS(2) = 0	never
OPTIONS(2) = 1	always
OPTIONS(2) = 2	only if regular diverged
OPTIONS(3)	Transformer Tap (0 by default)
OPTIONS(3) = 0	disabled
OPTIONS(3) = 1	enable stepping, No Direct
OPTIONS(4)	Phase Shifter (0 by default)
OPTIONS(4) = 0	disabled
OPTIONS(4) = 1	enabled
OPTIONS(5)	Switchable Shunts (1 by default)
OPTIONS(5) = 0	disabled
OPTIONS(5) = 1	enabled
OPTIONS(6)	Area Interchange (0 by default)
OPTIONS(6) = 0	disabled
OPTIONS(6) = 1	Tie lines only
OPTIONS(6) = 2	Tie lines and loads
OPTIONS(7)	DC Tap (1 by default)
OPTIONS(7) = 0	Locked

	OPTIONS(7) = 1	On
	OPTIONS(8)	Iter. to begin Var limiting (0 by default)
	OPTIONS(8) = 0	Hot Start: apply var limits immediately
	OPTIONS(8) = 99	Automatic:
	OPTIONS(9)	Load Flow Iterations Limit (20 by default)
	OPTIONS(9) > n	Terminate calculation after n iterations
	OPTIONS(10)	Use Flat Start for Load Flow Solution (0 by default)
	OPTIONS(10) = 0	hot
	OPTIONS(10) = 1	flat
	OPTIONS(11)	Iteration to freeze adjustments (15 by default)
	OPTIONS(11) > n	Freeze adjustments after n iterations
Real VALUES (5)	array of 5 elements specifying reporting parameters(input).	
	VALUES(1)	Minimum contingency case flow change cut-off (0.0 by default)
	VALUES(2)	Minimum voltage contingency change cutoff in per-unit (0.0 by default)
	VALUES(3)	Real and Reactive Power Tolerance (0.6 by default)
	VALUES(4)	Reactive Adjustments DeAcceleration Factor (1.0 by default)
	VALUES(5)	Low Voltage break point (pu) for load scaling (0.7 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.2. ACCONTBYCONT

Use this function to generate an AC contingency report by contingency options

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACCONTBYCONT SEL SELOPT1 SELOPT2 RPTTYPE OPTIONS(1)..OPTIONS(6)
NUM(1)..NUM(4)
```

Python command syntax:

```
ierr = acctbycont(sel, selopt1, selopt2, rpttype, options, num)
```

Fortran command syntax:

```
CALL MAPI_ACCONTBYCONT(SEL, SELOPT1, SELOPT2, RPTTYPE, OPTIONS, NUM, IERR)
```

Where:

Integer SEL	Indicate how to filter the contingencies for this report (input; no default allowed).
	'1' Report contingencies by Category
	'2' Report contingencies by Range
	'3' Report contingencies below severity index
	'4' Report contingencies above severity index
Integer SELOPT1	Option used in conjunction with SEL when SEL=(1 or 2) to specify filter criteria (input; no default allowed).
	SELOPT1 = n If SEL = 2 (by Range) then n = lower contingency number in desired range. If SEL = 1 (by Category) then enter one of the following:
	SELOPT1 = 1 Show ALL contingencies
	SELOPT1 = 2 Show contingencies with Violations
	SELOPT1 = 3 Show contingencies without Violations
	SELOPT1 = 4 Show ACTIVE contingencies
	SELOPT1 = 5 Show EXCLUDED contingencies
	SELOPT1 = 6 Show DISABLED contingencies
	SELOPT1 = 7 Show SINGLE BRANCH contingencies
	SELOPT1 = 8 Show COMPLEX contingencies
	SELOPT1 = 9 Show contingencies with Islands
	SELOPT1 = 10 Show IMBALANCED contingencies
	SELOPT1 = 11 Show contingencies with Generation
	SELOPT1 = 12 Show contingencies with Load
	SELOPT1 = 13 Show CONVERGED contingencies
	SELOPT1 = 14 Show NOT CONVERGED contingencies
Integer SELOPT2	Only used if SEL = 2 (by Range) (input).
	SELOPT2 = n Upper contingency number in desired range
Integer RPTTYPE	Type of contingency report (input; no default allowed).

	'1'	Selected Contingencies with Violations
	'2'	Summary List of Selected Contingencies
	'3'	AC Contingency Summary of Selected Contingencies
	'4'	Details for Selected Contingencies
Integer OPTIONS (6)	array of 6 elements specifying report options(input).	
	OPTIONS(1)	Report loading above cutoff (0 by default)
	OPTIONS(1) = 0	No
	OPTIONS(1) = 1	Yes
	OPTIONS(2)	Report Low Voltage (0 by default)
	OPTIONS(2) = 0	No
	OPTIONS(2) = 1	Yes
	OPTIONS(3)	Report High Voltage (0 by default)
	OPTIONS(3) = 0	No
	OPTIONS(3) = 1	Yes
	OPTIONS(4)	Include Contingent Events (0 by default)
	OPTIONS(4) = 0	No
	OPTIONS(4) = 1	Yes
	OPTIONS(5)	Include Islands Report (0 by default)
	OPTIONS(5) = 0	No
	OPTIONS(5) = 1	Yes
	OPTIONS(6)	Include Dispatch Data (0 by default)
	OPTIONS(6) = 0	No
	OPTIONS(6) = 1	Yes
Real NUM (4)	array of 4 elements specifying criteria to be used in conjunction with SEL and OPTIONS (input).	
	NUM(1)	Used with SEL=3 or 4 (by Severity Index) (0 by default)
	NUM(1) = x	x = Severity index for selected contingencies
	NUM(2)	Used with OPTIONS(1) = 1 (Report loading above cutoff) (0 by default)
	NUM(2) = y	y = Cutoff (%) for reporting loading
	NUM(3)	Used with OPTIONS(2) = 1 (Report Low Voltage) (0 by default)
	NUM(3) = vL	vL = Low Voltage Margin (PU)
	NUM(4)	Used with OPTIONS(3) = 1 (Report High Voltage) (0 by default)
	NUM(4) = vH	vH = High Voltage Margin (PU)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.3. ACCONTBYMONEL

Use this function to generate an AC contingency report by monitored elements

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACCONTBYMONEL SEL SELOPT1 SELOPT2 MONELS RPTTYPE NUM(1)..NUM(4)
```

Python command syntax:

```
ierr = acctnbymonel(sel, selopt1, selopt2, monels, rpttype, num)
```

Fortran command syntax:

```
CALL MAPI_ACCONTBYMONEL(SEL, SELOPT1, SELOPT2, MONELS, RPTTYPE, NUM, IERR)
```

Where:

Integer SEL	Indicate how to filter the contingencies for this report (input; no default allowed).
	'1' Report contingencies by Category
	'2' Report contingencies by Range
	'3' Report contingencies below severity index
	'4' Report contingencies above severity index
Integer SELOPT1	Option used in conjunction with SEL when SEL=(1 or 2) to specify filter criteria (input; no default allowed).
	SELOPT1 = n If SEL = 2 (by Range) then n = lower contingency number in desired range. If SEL = 1 (by Category) then enter one of the following:
	SELOPT1 = 1 Show ALL contingencies
	SELOPT1 = 2 Show contingencies with Violations
	SELOPT1 = 3 Show contingencies without Violations
	SELOPT1 = 4 Show ACTIVE contingencies
	SELOPT1 = 5 Show EXCLUDED contingencies
	SELOPT1 = 6 Show DISABLED contingencies
	SELOPT1 = 7 Show SINGLE BRANCH contingencies
	SELOPT1 = 8 Show COMPLEX contingencies
	SELOPT1 = 9 Show contingencies with Islands
	SELOPT1 = 10 Show IMBALANCED contingencies
	SELOPT1 = 11 Show contingencies with Generation
	SELOPT1 = 12 Show contingencies with Load
	SELOPT1 = 13 Show CONVERGED contingencies
	SELOPT1 = 14 Show NOT CONVERGED contingencies
Integer SELOPT2	Only used if SEL = 2 (by Range) (input).
	SELOPT2 = n Upper contingency number in desired range
Integer MONELS	Monitored elements for report (input; no default allowed).

	'1'	Branches
	'2'	Interfaces
	'3'	Flowgates
	'4'	Voltage Buses
Integer RPTTYPE	Type of contingency report (input; no default allowed).	
	'1'	List of Monitored Elements
	'2'	List of Violations above Cutoff
	'3'	Summary of Frequency of Violations
Real NUM (4)	array of 4 elements specifying criteria to be used in conjunction with SEL and RPTTYPE (input).	
	NUM(1)	Used with SEL=3 or 4 (by Severity Index) (0 by default)
	NUM(1) = x	x = Severity index for selected contingencies
	NUM(2)	Used with RPTTYPE = 2 (Violations above cut-off) (100 by default)
	NUM(2) = y	y = Cutoff (%) for reporting loading
	NUM(3)	Used with RPTTYPE = 2 and MONELS = 4 (Voltage Bus Low Voltage Margin) (0 by default)
	NUM(3) = vL	vL = Low Voltage Margin (PU)
	NUM(4)	Used with RPTTYPE = 2 and MONELS = 4 (Voltage Bus High Voltage Margin) (0 by default)
	NUM(4) = vH	vH = High Voltage Margin (PU)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid
	IERR = 3	Not available for flowgates

22.1.4. ACCSOLVE

Use this function to run the AC contingency analysis solution with the specified calculation options

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACCSOLVE OPTSI(1)..OPTS(10) VALUES(1)..VALUES(3)
```

Python command syntax:

```
ierr = accsolve(options, values)
```

Fortran command syntax:

```
CALL MAPI_ACCSOLVE(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (11)	array of 11 elements specifying calculation options(input).
OPTIONS(1)	AC LF method (2 by default)
OPTIONS(1) = 1	AC Newton
OPTIONS(1) = 2	AC Decoupled
OPTIONS(2)	Apply non-divergent LF (0 by default)
OPTIONS(2) = 0	never
OPTIONS(2) = 1	always
OPTIONS(2) = 2	only if regular diverged
OPTIONS(3)	Transformer Tap (0 by default)
OPTIONS(3) = 0	disabled
OPTIONS(3) = 1	enable stepping, No Direct
OPTIONS(4)	Phase Shifter (0 by default)
OPTIONS(4) = 0	disabled
OPTIONS(4) = 1	enabled
OPTIONS(5)	Switchable Shunts (1 by default)
OPTIONS(5) = 0	disabled
OPTIONS(5) = 1	enabled
OPTIONS(6)	Area Interchange (0 by default)
OPTIONS(6) = 0	disabled
OPTIONS(6) = 1	Tie lines only
OPTIONS(6) = 2	Tie lines and loads
OPTIONS(7)	DC Tap (1 by default)
OPTIONS(7) = 0	Locked
OPTIONS(7) = 1	On
OPTIONS(8)	Iter. to begin Var limiting (0 by default)
OPTIONS(8) = 0	Hot Start: apply var limits immediately
OPTIONS(8) = 99	Automatic:
OPTIONS(9)	Load Flow Iterations Limit (20 by default)

	OPTIONS(9) > n	Terminate calculation after n iterations
	OPTIONS(10)	Use Flat Start for Load Flow Solution (0 by default)
	OPTIONS(10) = 0	hot
	OPTIONS(10) = 1	flat
	OPTIONS(11)	Iteration to freeze adjustments (15 by default)
	OPTIONS(11) > n	Freeze adjustments after n iterations
Real VALUES (5)	array of 5 elements specifying reporting parameters(input).	
	VALUES(1)	Minimum contingency case flow change cut-off (0.0 by default)
	VALUES(2)	Minimum voltage contingency change cutoff in percent (0.0 by default)
	VALUES(3)	Real and Reactive Power Tolerance (0.6 by default)
	VALUES(4)	Reactive Adjustments DeAcceleration Factor (1.0 by default)
	VALUES(5)	Low Voltage break point (pu) for load scaling (0.7 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.5. ACLFDC

Use this function to execute an AC load flow solution using the Fast Decoupled Method and the specified calculation options

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACLFDC  OPTSI(1)..OPTS(10) VALUES(1)..VALUES(3)
```

Python command syntax:

```
ierr = aclfdc(options, values)
```

Fortran command syntax:

```
CALL MAPI_ACLFDC(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (10)	array of 10 elements specifying calculation options(input).
OPTIONS(1)	Base Case Load Flow (4 by default)
OPTIONS(1) = 0	DC
OPTIONS(1) = 1	AC Newton
OPTIONS(1) = 2	AC Decoupled
OPTIONS(1) = 3	EMS
OPTIONS(1) = 4	Do Not Solve
OPTIONS(2)	Transformer Tap (0 by default)
OPTIONS(2) = 0	disabled
OPTIONS(2) = 1	enable stepping, No Direct
OPTIONS(3)	Phase Shifter (0 by default)
OPTIONS(3) = 0	disabled
OPTIONS(3) = 1	enabled
OPTIONS(4)	Switchable Shunts (1 by default)
OPTIONS(4) = 0	disabled
OPTIONS(4) = 1	enabled
OPTIONS(5)	Area Interchange (0 by default)
OPTIONS(5) = 0	disabled
OPTIONS(5) = 1	Tie lines only
OPTIONS(5) = 2	Tie lines and loads
OPTIONS(6)	DC Tap (1 by default)
OPTIONS(6) = 0	Locked
OPTIONS(6) = 1	On
OPTIONS(7)	Iter. to begin Var limiting (0 by default)
OPTIONS(7) = 0	Hot Start: apply var limits immediately
OPTIONS(7) = 99	Automatic:
OPTIONS(8)	Load Flow Iterations Limit (20 by default)

	OPTIONS(8) > n	Terminate calculation after n iterations
	OPTIONS(9)	Use Flat Start for Load Flow Solution (0 by default)
	OPTIONS(9) = 0	hot
	OPTIONS(9) = 1	flat
	OPTIONS(10)	Iteration to freeze adjustments (15 by default)
	OPTIONS(10) > n	Freeze adjustments after n iterations
Real VALUES (3)	array of 3 elements specifying reporting parameters(input).	
	VALUES(1)	Real and Reactive Power Tolerance (0.1 by default)
	VALUES(2)	Reactive Adjustments DeAcceleration Factor (1.0 by default)
	VALUES(3)	Low Voltage break point (pu) for load scaling (0.7 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.6. ACLFNS

Use this function to execute an AC load flow solution using the Full Newton Method and the specified calculation options

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ACLFNS  OPTSI(1)..OPTS(10)  VALUES(1)..VALUES(3)
```

Python command syntax:

```
ierr = aclfns(options, values)
```

Fortran command syntax:

```
CALL MAPI_ACLFNS(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (10)	array of 10 elements specifying calculation options(input).
OPTIONS(1)	Base Case Load Flow (4 by default)
OPTIONS(1) = 0	DC
OPTIONS(1) = 1	AC Newton
OPTIONS(1) = 2	AC Decoupled
OPTIONS(1) = 3	EMS
OPTIONS(1) = 4	Do Not Solve
OPTIONS(2)	Transformer Tap (0 by default)
OPTIONS(2) = 0	disabled
OPTIONS(2) = 1	enable stepping, No Direct
OPTIONS(3)	Phase Shifter (0 by default)
OPTIONS(3) = 0	disabled
OPTIONS(3) = 1	enabled
OPTIONS(4)	Switchable Shunts (1 by default)
OPTIONS(4) = 0	disabled
OPTIONS(4) = 1	enabled
OPTIONS(5)	Area Interchange (0 by default)
OPTIONS(5) = 0	disabled
OPTIONS(5) = 1	Tie lines only
OPTIONS(5) = 2	Tie lines and loads
OPTIONS(6)	DC Tap (1 by default)
OPTIONS(6) = 0	Locked
OPTIONS(6) = 1	On
OPTIONS(7)	Iter. to begin Var limiting (0 by default)
OPTIONS(7) = 0	Hot Start: apply var limits immediately
OPTIONS(7) = 99	Automatic:
OPTIONS(8)	Load Flow Iterations Limit (20 by default)

	OPTIONS(8) > n	Terminate calculation after n iterations
	OPTIONS(9)	Use Flat Start for Load Flow Solution (0 by default)
	OPTIONS(9) = 0	hot
	OPTIONS(9) = 1	flat
	OPTIONS(10)	Iteration to freeze adjustments (15 by default)
	OPTIONS(10) > n	Freeze adjustments after n iterations
Real VALUES (3)	array of 3 elements specifying reporting parameters(input).	
	VALUES(1)	Real and Reactive Power Tolerance (0.1 by default)
	VALUES(2)	Reactive Adjustments DeAcceleration Factor (1.0 by default)
	VALUES(3)	Low Voltage break point (pu) for load scaling (0.7 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.7. ACSOLVE_LFD

Use this function to execute an AC load flow solution using the Fast Decoupled Method.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ACSOLVE_LFD DFLAG
```

Python command syntax:

```
ierr = acsolve_lfd(dflag)
```

Fortran command syntax:

```
CALL MAPI_ACSOLVE_LFD(DFLAG, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.8. ACSOLVE_LFN

Use this function to execute an AC load flow solution using the Full Newton Method.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ACSOLVE_LFN DFLAG
```

Python command syntax:

```
ierr = acsolve_lfn(dflag)
```

Fortran command syntax:

```
CALL MAPI_ACSOLVE_LFN(DFLAG, IERR)
```

Where:

Integer DFLAG

This argument is not used and kept only for backward compatibility.
(input).

Integer IERR

error code (output).

IERR = 0

No error

IERR = 1

Prerequisite requirements for function not
met

22.1.9. ACTIVITYACCONT

Use this function to initiate or startup the ACCONT Activities. This function sets up the memory allocations required to perform the analyses listed below. Attempting to execute any of the listed analyses without first invoking this function will not allow the analysis to proceed. You will be prompted to run this function first. Analyses which require this function to be run first. Note that any or all of the listed analyses can be run with a single call to ACTIVITYACCONT. It is not necessary to EXITACTIVITYACCONT as long as you are traversing these listed analyses: Execution (running) of the AC contingency analysis load flow; Reading or Saving the AC contingency analysis file (.acc); AC Constraints analyses by branches, interfaces, flowgates or voltages; AC Contingency analyses by contingencies

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ACTIVITYACCONT
```

Python command syntax:

```
ierr = activityacct()
```

Fortran command syntax:

```
CALL MAPI_PREACCONTANAL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.10. ACTIVITYMUST

Use this function to initiate or startup the PSSE MUST module Activities. This function sets up the memory allocations required to perform the analyses listed below. Attempting to execute any of the listed analyses without first invoking this function will not allow the analysis to proceed. You will be prompted to run this function first.

Analyses which require this function to be run first. Note that any or all of the listed analyses can be run with a single call to ACTIVITYMUST. It is not necessary to EXITACTIVITYMUST as long as you are traversing these listed analyses:

- DC Constraints analyses by branches, interfaces or flowgates
- DC Contingency analyses by contingencies
- DC Transfer analyses
- AC Transfer limit analysis
- Transfer versus transfer sensitivities
- Generator sensitivities on study transfer
- Transaction impact analysis

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ACTIVITYMUST
```

Python command syntax:

```
ierr = activitymust()
```

Fortran command syntax:

```
CALL MAPI_PREMUSTANAL(IERR)
```

Where:

Integer IERR	error code (output).
IERR = 0	No error
IERR = 1	Prerequisite requirements for function not met
IERR = 2	Could not initiate MUST DC Analysis

22.1.11. ACTRANSFERLIMITSTUDY

Use this function to execute an AC Study Transfer.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_ACTRANSFERLIMITSTUDY DFLAG SYS1 SYS2 TRANSFER
```

Python command syntax:

```
ierr = actransferlimitstudy(dflag, sys1, sys2, transfer)
```

Fortran command syntax:

```
CALL MAPI_ACTRANSFERLIMITSTUDY(DFLAG, SYS1, SYS2, TRANSFER, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).	
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem(s) missing
	IERR = 3	No transfer value
	IERR = 4	Subsystem(s) not valid
	IERR = 5	Sending subsystem already selected

22.1.12. ADDTRANSACTION

Use this function to add any transaction for dispatch analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ADDTRANSACTION SUBSFR SUBSIN TRANS
```

Python command syntax:

```
ierr = addtransaction(subsfr, subsin, trans)
```

Fortran command syntax:

```
CALL MAPI_ADDTRAN(SUBSFR, SUBSIN, TRANS, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).	
Real TRANS	Is the MW Transfer Level for this Study Transfer (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	From SubSystem same as TO SubSystem
	IERR = 4	Subsystem label is missing.
	IERR = 5	The MW transfer input is missing.

22.1.13. APPLYSINGLECONT

Use this function to modify the case by applying a single contingency.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_APPLYSINGLECONT CONTNO
```

Python command syntax:

```
ierr = applysinglecont(contno)
```

Fortran command syntax:

```
CALL MAPI_APPSELCONT(CONTNO, IERR)
```

Where:

Integer CONTNO	Is the number of the contingency to be applied. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Selected Contingency out of range
	IERR = 3	The number of the contingency is missing

22.1.14. AREABUBBLE

Use this function to update values for the Area Bubble Diagram.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_AREABUBBLE SYS1, SYS2, TRANSFER
```

Python command syntax:

```
ierr = areabubble(sys1, sys2, transfer)
```

Fortran command syntax:

```
CALL MAPI_UPDAREABUBL(SYS1, SYS2, TRANSFER, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).	
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem(s) missing
	IERR = 3	No transfer value
	IERR = 4	Subsystem(s) not valid
	IERR = 5	Sending subsystem already selected
	IERR = 6	Overlapping systems

22.1.15. AREAIMPACT

Use this function to generate the impact report between Areas, Zones and/or Subsystems

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_AREAIMPACT SYS1 SYS2 TRANSFER OPTIONS(1)..OPTIONS(5)
CUTOFFS(1)..CUTOFFS(3) NUMFROM LISTFROM NUMTO LISTTO
```

Python command syntax:

```
ierr = areaimpact(sys1, sys2, transfer, options, cutoffs, numfrom,
listfrom, numto, listto )
```

Fortran command syntax:

```
CALL MAPI_AZSREPORT(SYS1, SYS2, TRANSFER, OPTIONS, CUTOFFS, NUMFROM,
LISTFROM, NUMTO, LISTTO, IERR)
```

Where:

Character*32 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).																																				
Character*32 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).																																				
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).																																				
Integer OPTIONS (5)	array of 5 elements specifying calculation options(input). <table> <tr> <td>OPTIONS(1)</td><td>Type of Report: (1 by default)</td></tr> <tr> <td>OPTIONS(1) = 1</td><td>Total Participation Factor (TPF)</td></tr> <tr> <td>OPTIONS(1) = 2</td><td>Interface Participation Factor (IPF)</td></tr> <tr> <td>OPTIONS(1) = 3</td><td>Detailed Report for all Tie branches (Ties)</td></tr> <tr> <td>OPTIONS(2)</td><td>Sort Order: (2 by default)</td></tr> <tr> <td>OPTIONS(2) = 1</td><td>by Number</td></tr> <tr> <td>OPTIONS(2) = 2</td><td>by Impact</td></tr> <tr> <td>OPTIONS(2) = 3</td><td>by Name</td></tr> <tr> <td>OPTIONS(3)</td><td>Contingency for impact report (0 by default)</td></tr> <tr> <td>OPTIONS(3) = 0</td><td>Base Case</td></tr> <tr> <td>OPTIONS(3) = x</td><td>x = Contingency number</td></tr> <tr> <td>OPTIONS(4)</td><td>Impacted systems group (1 by default)</td></tr> <tr> <td>OPTIONS(4) = 1</td><td>Areas</td></tr> <tr> <td>OPTIONS(4) = 2</td><td>Zones</td></tr> <tr> <td>OPTIONS(4) = 3</td><td>Subsystems</td></tr> <tr> <td>OPTIONS(5)</td><td>Neighboring systems group (1 by default)</td></tr> <tr> <td>OPTIONS(5) = 1</td><td>Areas</td></tr> <tr> <td>OPTIONS(5) = 2</td><td>Zones</td></tr> </table>	OPTIONS(1)	Type of Report: (1 by default)	OPTIONS(1) = 1	Total Participation Factor (TPF)	OPTIONS(1) = 2	Interface Participation Factor (IPF)	OPTIONS(1) = 3	Detailed Report for all Tie branches (Ties)	OPTIONS(2)	Sort Order: (2 by default)	OPTIONS(2) = 1	by Number	OPTIONS(2) = 2	by Impact	OPTIONS(2) = 3	by Name	OPTIONS(3)	Contingency for impact report (0 by default)	OPTIONS(3) = 0	Base Case	OPTIONS(3) = x	x = Contingency number	OPTIONS(4)	Impacted systems group (1 by default)	OPTIONS(4) = 1	Areas	OPTIONS(4) = 2	Zones	OPTIONS(4) = 3	Subsystems	OPTIONS(5)	Neighboring systems group (1 by default)	OPTIONS(5) = 1	Areas	OPTIONS(5) = 2	Zones
OPTIONS(1)	Type of Report: (1 by default)																																				
OPTIONS(1) = 1	Total Participation Factor (TPF)																																				
OPTIONS(1) = 2	Interface Participation Factor (IPF)																																				
OPTIONS(1) = 3	Detailed Report for all Tie branches (Ties)																																				
OPTIONS(2)	Sort Order: (2 by default)																																				
OPTIONS(2) = 1	by Number																																				
OPTIONS(2) = 2	by Impact																																				
OPTIONS(2) = 3	by Name																																				
OPTIONS(3)	Contingency for impact report (0 by default)																																				
OPTIONS(3) = 0	Base Case																																				
OPTIONS(3) = x	x = Contingency number																																				
OPTIONS(4)	Impacted systems group (1 by default)																																				
OPTIONS(4) = 1	Areas																																				
OPTIONS(4) = 2	Zones																																				
OPTIONS(4) = 3	Subsystems																																				
OPTIONS(5)	Neighboring systems group (1 by default)																																				
OPTIONS(5) = 1	Areas																																				
OPTIONS(5) = 2	Zones																																				

	OPTIONS(5) = 3	Subsystems
Real CUTOFFS (3)	array of 3 elements specifying cutoff values(input).	
	CUTOFFS(1)	TPF Report Cutoff (0.03 by default)
	CUTOFFS(1) = x	x = Cutoff value for TPF Report
	CUTOFFS(2)	IPF Report Cutoff (0.02 by default)
	CUTOFFS(2) = y	y = Cutoff value for IPF Report
	CUTOFFS(3)	Tie Report Cutoff (0.00 by default)
	CUTOFFS(3) = z	z = Cutoff value for Tie Report
Integer NUMFROM	How many impacted systems to consider. (input; no default allowed).	
Character*32 LISTFROM	Is a set of strings forming a list of Impacted Areas, Zones or Subsystems consistent with OPTIONS(4) (input; no default allowed).	
Integer NUMTO	How many neighboring systems to consider. (input; no default allowed).	
Character*32 LISTTO	Is a set of strings forming a list of Neighboring Areas, Zones or Subsystems consistent with OPTIONS(5) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.16. AREASINZONES

Use this function to a report of areas in zones.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_AREASINZONES
```

Python command syntax:

```
ierr = areasinzones()
```

Fortran command syntax:

```
CALL MAPI_AREASINZONES(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.17. AREASLACKS

Use this function to a report of slack buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_AREASLACKS
```

Python command syntax:

```
ierr = areaslacks()
```

Fortran command syntax:

```
CALL MAPI_AREASLACKS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.18. AREASUMMARY

Use this function to generate an area summary report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_AREASUMMARY
```

Python command syntax:

```
ierr = areasummary()
```

Fortran command syntax:

```
CALL MAPI_AREASUMMARY(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.19. BRANCHSENSITIVITY

Use this function to generate the monitored elements sensitivities for specified branches

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_BRANCHSENSITIVITY NUMMONEL LISTML OPTIONS(1)..OPTIONS(4) REFSYS
IMPACTCUTOFF EXPSYS IMPSYS NUMTRANS LISTTRANS
```

Python command syntax:

```
ierr = branchsensitivity(nummonel, listml, options, refsys, impactcutoff,
expsys, impsys, numtrans, listtrans)
```

Fortran command syntax:

```
CALL MAPI_BRSENS(NUMMONEL, LISTML, OPTIONS, REFSYS, IMPACTCUTOFF, EXPSYS,
IMPSYS, NUMTRANS, LISTTRANS, IERR)
```

Where:

Integer NUMMONEL	How many monitored elements to consider. (input; no default allowed).																												
Character*32 LISTML	Is a set of strings forming a list of branches. Each branch consists of a FROM bus followed by a TO bus followed by a Circuit ID. There must be as many sets of FROM TO CktID as indicated by NUMMONEL. (input; no default allowed).																												
Integer OPTIONS (4)	array of 4 elements specifying calculation options(input). <table> <tr> <td>OPTIONS(1)</td><td>Sensitivity Report to: (1 by default)</td></tr> <tr> <td>OPTIONS(1) = 1</td><td>Reference Subsystem</td></tr> <tr> <td>OPTIONS(1) = 2</td><td>Factors for Impact Cutoff</td></tr> <tr> <td>OPTIONS(1) = 3</td><td>Subsystem Participating Buses</td></tr> <tr> <td>OPTIONS(1) = 4</td><td>Transactions</td></tr> <tr> <td>OPTIONS(2)</td><td>Contingency for impact/sensitivity reports (0 by default)</td></tr> <tr> <td>OPTIONS(2) = 0</td><td>Base Case</td></tr> <tr> <td>OPTIONS(2) = x</td><td>x = Contingency number</td></tr> <tr> <td>OPTIONS(3)</td><td>Reference subsystem config for sensitivity analysis (1 by default)</td></tr> <tr> <td>OPTIONS(3) = 1</td><td>Importing</td></tr> <tr> <td>OPTIONS(3) = 2</td><td>Exporting</td></tr> <tr> <td>OPTIONS(4)</td><td>Transactions to consider (1 by default)</td></tr> <tr> <td>OPTIONS(4) = 1</td><td>All possible transactions</td></tr> <tr> <td>OPTIONS(4) = 2</td><td>Only selected transactions</td></tr> </table>	OPTIONS(1)	Sensitivity Report to: (1 by default)	OPTIONS(1) = 1	Reference Subsystem	OPTIONS(1) = 2	Factors for Impact Cutoff	OPTIONS(1) = 3	Subsystem Participating Buses	OPTIONS(1) = 4	Transactions	OPTIONS(2)	Contingency for impact/sensitivity reports (0 by default)	OPTIONS(2) = 0	Base Case	OPTIONS(2) = x	x = Contingency number	OPTIONS(3)	Reference subsystem config for sensitivity analysis (1 by default)	OPTIONS(3) = 1	Importing	OPTIONS(3) = 2	Exporting	OPTIONS(4)	Transactions to consider (1 by default)	OPTIONS(4) = 1	All possible transactions	OPTIONS(4) = 2	Only selected transactions
OPTIONS(1)	Sensitivity Report to: (1 by default)																												
OPTIONS(1) = 1	Reference Subsystem																												
OPTIONS(1) = 2	Factors for Impact Cutoff																												
OPTIONS(1) = 3	Subsystem Participating Buses																												
OPTIONS(1) = 4	Transactions																												
OPTIONS(2)	Contingency for impact/sensitivity reports (0 by default)																												
OPTIONS(2) = 0	Base Case																												
OPTIONS(2) = x	x = Contingency number																												
OPTIONS(3)	Reference subsystem config for sensitivity analysis (1 by default)																												
OPTIONS(3) = 1	Importing																												
OPTIONS(3) = 2	Exporting																												
OPTIONS(4)	Transactions to consider (1 by default)																												
OPTIONS(4) = 1	All possible transactions																												
OPTIONS(4) = 2	Only selected transactions																												
Character*12 REFSYS	Is a string identifying the Reference Subsystem Name - to be used with Report 1 of OPTION(1). Enter -1 for Swing Bus. (input; blank by default).																												

Real IMPACTCUTOFF	Impact CutOff Value - to be used with Report 2 of OPTION(1) (input; 0 by default).	
Character*12 EXPSYS	Is a string identifying the Exporting Subsystem Name - to be used with Report 3 of OPTION(1) (input; blank by default).	
Character*12 IMPSYS	Is a string identifying the Importing Subsystem Name - to be used with Report 3 of OPTION(1) (input; blank by default).	
Integer NUMTRANS	How many transactions in LISTTRANS - to be used with Report 4 of OPTION(1). (input; no default allowed).	
Character*32 LISTTRANS	Is a set of strings forming a list of subsystem names representing transactions with each transaction being made up of a FROM subsystem and a TO subsystem. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.20. CDETAILBRANCHES

Use this function to generate a detailed report by contingencies for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CDETAILBRANCHES
```

Python command syntax:

```
ierr = cdetailbranches()
```

Fortran command syntax:

```
CALL MAPI_CNCDETAILBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.21. CDETAILINTERFACES

Use this function to generate a detailed report by contingencies for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CDETAILINTERFACES
```

Python command syntax:

```
ierr = cdetailinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNCDETAILINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.22. CDETAILVOLTAGEBUSES

Use this function to generate a detailed report by contingencies for the selected voltage buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CDETAILVOLTAGEBUSES
```

Python command syntax:

```
ierr = cdetailvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNCDETAILVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.23. CHANGEPARAMS

Use this function to change any of the option parameters used in the PSSE MUST module.
where:

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CHANGEPARAMS  MENUNM  PARMID  NEWVALUE
```

Python command syntax:

```
ierr = changeparams(menunm, parmid, newvalue)
```

Fortran command syntax:

```
CALL MAPI_CHANGEARM(MENUNM, PARMID, NEWVALUE, IERR)
```

Where:

Character*18 MENUNM	Is a string identifying which menu contains the option parameter you wish to change. Acceptable entries are: (input; no default allowed).
	'MAINOPTIONS' General program setting options
	'LFADJOPTIONS' Load Flow Adjustment options
	'LFGENOPTIONS' Generator Var Limits Checking options
	'LFSOOPTIONS' AC Load Flow Solution options
	'LFADVOPTIONS' Advanced Load Flow Solution options
	'CONSTROPTS' LP/OPF Constraint/Contingency options
	'MUSTOPTIONS' MUST Run time solution options
	'ACVEROPTIONS' AC verification options
	'TRANVIOLOPTS' FCITC Violations report format options
	'ACCONTOPTS' AC Contingency analysis options
	'CONTOPTS' Contingency reporting options
	'TRANIMPOPTS' Transfer impact analysis Options
	'TRGENOPTS' Generation worst dispatch options
	'VOLTAGEOPTS' Voltage violations with respect to specified limits
	'BRANREPOPTS' Branch violations (MW) and impact report analysis options
	'BRANAMPOPTS' Branch violations (MVA) and impact report analysis options
	'FGATEREPOPTS' Flowgate violations and impact report analysis options
	'INTRREPOPTS' Interface violations and impact report analysis options
Integer PARMID (1)	array of 1 elements specifying Is the index of the option parameter you want to change. See below for a full list of menus and indices(input).

PARMID(1)	MAINOPTIONS : General program setting options
PARMID(1) = 1	Console output lines per page
PARMID(1) = 2	File output lines per page. If >= 99999 set to 9999999
PARMID(1) = 3	Bus Input/Output by NAMES or NUMBERS (1- NUMBERS, 2- NAMES)
PARMID(1) = 4	Line shunts in pout (1- no, 2- yes)
PARMID(1) = 5	Separator in ASC file (1- /, 2- \, 3- ;, 4- !)
PARMID(1) = 6	Log File (1- Enabled Log File, 0- Disabled Log File)
PARMID(2)	LFADJOPTIONS: Load Flow Adjustment options
PARMID(2) = 1	Transformer Tap (0- disabled, 1- enabled stepping, No Direct)
PARMID(2) = 2	Phase Shifter (0- disabled, 1- enabled)
PARMID(2) = 3	Switchable Shunts (0- disabled, 1- enabled)
PARMID(2) = 4	Area Interchange (0- disabled, 1- Tie lines only, 2- Tie lines and loads)
PARMID(2) = 5	DC TAP (0- Locked, 1- On)
PARMID(3)	LFGENOPTIONS: Generator Var Limits Checking options
PARMID(3) = 1	Enable Reactive Limit Checking (0- disabled, 1- enabled)
PARMID(3) = 2	Iter. to begin Var limiting (flat start), 99 for automatic
PARMID(3) = 3	Iter. to begin Var limiting (hot start), 99 for automatic
PARMID(4)	LFSOLOPTIONS: AC Load Flow Solution options
PARMID(4) = 1	Load Flow Iterations Limit
PARMID(4) = 2	Real and Reactive Power Tolerance
PARMID(4) = 3	Enable Non-divergent Load Flow (0- disabled, 1- enabled)
PARMID(4) = 4	Use Flat Start for Load Flow Solution (0- hot, 1- flat)
PARMID(4) = 5	Reactive Adjustments DeAcceleration Factor
PARMID(4) = 6	Tap adjustments DeAcceleration Factor
PARMID(4) = 7	Low Voltage break point (pu) for load scaling
PARMID(4) = 8	Iteration to freeze adjustments
PARMID(5)	LFADVOPTIONS: Advanced Load Flow Solution options
PARMID(5) = 1	Maximum voltage magnitude change per iteration
PARMID(5) = 2	Number of first LF iterations to limit voltage change

PARMID(5) = 3	Maximum Tap ratio change per iteration
PARMID(5) = 4	Voltage tolerance (PU) to activate TAP, shunt and DC line adjustments
PARMID(5) = 5	Angle tolerance to activate phase shifters and area interchange adjustments
PARMID(5) = 6	Maximum voltage change in blow up test
PARMID(5) = 7	Maximum angle change in blow up test (except first iteration)
PARMID(5) = 8	Report data warnings
PARMID(6)	CONSTROPTS : LP/OPF Constraint/Contingency options
PARMID(6) = 1	AC MW Mismatch Tolerance
PARMID(6) = 2	Base Case Rating (Select Rating 1-12)
PARMID(6) = 3	Base Case Percent of Rating (branches only)
PARMID(6) = 4	Contingency Case Rating (Select Rating 1-12)
PARMID(6) = 5	Contingency Case Percent of Rating (branches only)
PARMID(6) = 6	Base Case Load Flow (0- DC, 1- AC Newton, 2- AC Decoupled, 3- EMS, 4- Do not solve AC, 5- PSSE Presolved)
PARMID(6) = 7	Convert branch ratings to estimated MW ratings(0- No, 1- Yes)
PARMID(6) = 8	Contingency ID Reporting (1- labels, 2- events, 3- both)
PARMID(6) = 9	Maximum Number of Contingencies to process
PARMID(6) = 10	Line Rating Unit for AC Applications (0- Current expressed as MVA, 1- MVA)
PARMID(7)	MUSTOPTIONS : MUST Run time solution options
PARMID(7) = 1	Phase shifter code (0- fixed, 1- const.flow base case, 2- const.flow in cont)
PARMID(7) = 2	0- ignore base case constraints in FCITC reports, 1- include
PARMID(7) = 3	Max. number of violations to report in FCITC and Gen.Sens. Tables
PARMID(7) = 4	Default minimum distribution factor magnitude cutoff (PTDF&OTDF)
PARMID(7) = 5	Summary table maximum times to report the same element (100- Unlimited)
PARMID(7) = 6	Apply Min.Distr.Factor CutOff for contingency analysis (0- no, 1- yes)
PARMID(7) = 7	Apply minimum distr. factor to FCITC solution reports (0- no, 1- yes)
PARMID(7) = 8	Minimum contingency case (pre&post) flow change

PARMID(7) = 9	Minimum contingency case distribution factor change
PARMID(7) = 10	Minimum distribution factor for transfer sensitivity analysis
PARMID(8)	ACVEROPTIONS: AC verification options
PARMID(8) = 1	AC LF method (1- Newton, 2- Decoupled)
PARMID(8) = 2	Apply non-divergent LF (0- never, 1- always, 2- only if regular diverged)
PARMID(8) = 3	Maximum number violations to verify using AC
PARMID(8) = 4	Tolerance to check study transfer (MW)
PARMID(8) = 5	Report removed violations with FCITC report (0- no, 1- yes)
PARMID(9)	TRANVIOLOPTS: FCITC Violations report format options
PARMID(9) = 1	FCITC format (1- two lines report, 2- wide, 3- TLTG, 4- wide w xfer, 5- DP2Line, 6- DPWide)
PARMID(9) = 2	Report removed violations with FCITC report (0- no, 1- yes, 2- only removed (for 1 4))
PARMID(9) = 3	Report FCITC violations (1- yes, 0- no)
PARMID(9) = 4	Report Export level(1- yes, 0- no)
PARMID(9) = 5	Report Import level(1- yes, 0- no)
PARMID(9) = 6	Report Flowgate/Interfaces flows (0- no, 1- interface, 2- flowgate)
PARMID(10)	ACCONTOPTS : AC Contingency analysis options
PARMID(10) = 1	AC LF method (1- Newton, 2- Decoupled)
PARMID(10) = 2	Apply non-divergent LF (0- never, 1- always, 2- only if regular diverged)
PARMID(10) = 3	Minimum contingency case flow change cut-off
PARMID(10) = 4	Minimum voltage contingency change cutoff in percent
PARMID(11)	CONTOPTS : Contingency reporting options
PARMID(11) = 1	Report details on contingency violations (0- no report, 1- report)
PARMID(11) = 2	Report details on contingency events (0- no report, 1- report)
PARMID(11) = 3	Report islands details (0- no report, 1- report)
PARMID(11) = 4	Report details on dispatch events (0- no report, 1- report)
PARMID(12)	TRANIMPOPTS : Transfer impact analysis Options
PARMID(12) = 1	Sort method for reporting TPF(1- by number, 2- by Impact, 3- by name)
PARMID(12) = 2	TPF (trans. participation factor) report cut off

PARMID(12) = 3	IPF (interface participation factor) report cut off
PARMID(12) = 4	Ties (PTDF/OTDF) report cut off
PARMID(13)	TRGENOPTS : Generation worst dispatch options
PARMID(13) = 1	Specify maximum power transfer (MW) to test
PARMID(13) = 2	Maximum number of worst scenarios to report
PARMID(13) = 3	Worst dispatch subsystem (1- import, 2- export)
PARMID(13) = 4	Show all participating generators in detailed report (0- no, 1- yes)
PARMID(13) = 5	Minimum Factor CutOff for individual generators
PARMID(13) = 6	Minimum Factor CutOff for study transfer
PARMID(14)	VOLTAGEOPTS : Voltage violations with respect to specified limits
PARMID(14) = 1	Low voltage violations tolerance (Vmin-Vtol-Low, use negative to check how close)
PARMID(14) = 2	High voltage violations tolerance (Vmax +VtolHigh, negative - within range)
PARMID(14) = 3	Low voltage cutoff
PARMID(14) = 4	High voltage cutoff
PARMID(15)	BRANREPOPTS : Branch violations (MW) and impact report analysis options
PARMID(15) = 1	Loading Cutoff for reporting violations for the Current case(in %)
PARMID(15) = 2	Loading Cutoff for reporting violations for the Initial case(in %)
PARMID(15) = 3	Check/report initial violations (0- no, 1- yes)
PARMID(15) = 4	Report order (1- bus order, 2- loading, 3- impact)
PARMID(15) = 5	Apply Impact CutOff(0- no, 1- yes)
PARMID(15) = 6	Impact CutOff Value in percent
PARMID(15) = 7	Apply Loading CutOff(0- no, 1- yes)
PARMID(15) = 8	Show Study Transfer Margins(0- no, 1- yes)
PARMID(15) = 9	Subsystem for Study transfer sensitivity analysis (1- importing, 2- exporting)
PARMID(15) = 10	Contingency for impact/sensitivity reports (0- base case, >0- Contin.Index)
PARMID(16)	BRANAMPOPTS : Branch violations (MVA) and impact report analysis options
PARMID(16) = 1	Loading Cutoff for reporting violations for the Current case(in %)

PARMID(16) = 2	Loading Cutoff for reporting violations for the Initial case(in %)
PARMID(16) = 3	Check/report initial violations (0- no, 1- yes)
PARMID(16) = 4	Report order (1- bus order, 2- loading, 3- impact)
PARMID(16) = 5	Apply Impact CutOff(0- no, 1- yes)
PARMID(16) = 6	Impact CutOff Value in percent
PARMID(16) = 7	Apply Loading CutOff(0- no, 1- yes)
PARMID(16) = 8	Show Study Transfer Margins(0- no, 1- yes)
PARMID(16) = 9	Subsystem for Study transfer sensitivity analysis (1- importing, 2- exporting)
PARMID(16) = 10	Contingency for impact/sensitivity reports (0- base case, >0- Contin.Index)
PARMID(17)	FGATEREPOPTS: Flowgate violations and impact report analysis options
PARMID(17) = 1	Loading Cutoff for reporting violations for the Current case(in %)
PARMID(17) = 2	Loading Cutoff for reporting violations for the Initial case(in %)
PARMID(17) = 3	Check/report initial violations (0- no, 1- yes)
PARMID(17) = 4	Report order (1- input order, 2- loading, 3- impact)
PARMID(17) = 5	Apply Impact CutOff(0- no, 1- yes)
PARMID(17) = 6	Impact CutOff Value in percent
PARMID(17) = 7	Apply Loading CutOff(0- no, 1- yes)
PARMID(17) = 8	Show Study Transfer Margins(0- no, 1- yes)
PARMID(17) = 9	Subsystem for Study transfer sensitivity analysis (1- importing, 2- exporting)
PARMID(18)	INTRREPOPTS : Interface violations and impact report analysis options
PARMID(18) = 1	Loading Cutoff for reporting violations for the Current case(in %)
PARMID(18) = 2	Loading Cutoff for reporting violations for the Initial case(in %)
PARMID(18) = 3	Check/report initial violations (0- no, 1- yes)
PARMID(18) = 4	Report order (1- input order, 2- loading, 3- impact)
PARMID(18) = 5	Apply Impact CutOff(0- no, 1- yes)
PARMID(18) = 6	Impact CutOff Value in percent
PARMID(18) = 7	Apply Loading CutOff(0- no, 1- yes)
PARMID(18) = 8	Show Study Transfer Margins(0- no, 1- yes)
PARMID(18) = 9	Subsystem for Study transfer sensitivity analysis (1- importing, 2- exporting)
PARMID(18) = 10	Contingency for impact/sensitivity reports (0- base case, >0- Contin.Index)

Real NEWVALUE	Is the value you want the option to be. A decimal point is not required for parameters which are integer selections. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid Menu Selected - No changes made
	IERR = 3	Invalid Parameter ID - No changes made
	IERR = 4	New value Out of Bounds - No changes made
	IERR = 5	The menu option setting is missing.
	IERR = 6	The option parameter is missing.
	IERR = 7	The option value is missing.

22.1.24. CLEARMULTISTUDY

The Multiple Study Transfer will continually add transfers to an existing report unless the function is cleared.

Use this api to clear the list of Multiple Study Transfers in order to generate new reports.

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_CLEARMULTISTUDY
```

Python command syntax:

```
ierr = clearmultistudy()
```

Fortran command syntax:

```
CALL MAPI_CLEARTSENKNT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.25. CNALLTRANSELBRANCHES

Use this function to display the transactions impact on ALL branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNALLTRANSELBRANCHES
```

Python command syntax:

```
ierr = cnalltranelbranches()
```

Fortran command syntax:

```
CALL MAPI_CNSTALLSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.26. CNALLTRANSELFLOWGATES

Use this function to display the transactions impact on ALL flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNALLTRANSELFLOWGATES
```

Python command syntax:

```
ierr = cnulltranselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNSTALLSELFGE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.27. CNALLTRANSELINTERFACES

Use this function to display the transactions impact on ALL interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNALLTRANSELINTERFACES
```

Python command syntax:

```
ierr = cnalltranelinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNSTALLSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.28. CNALLVIOLATED

Use this function to show all violated constraints for the selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNALLVIOLATED
```

Python command syntax:

```
ierr = cnallviolated()
```

Fortran command syntax:

```
CALL MAPI_CNALLVIOLBYCASE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.29. CNALLVIOLFREQ

Use this function to show the frequency of violations for the selected contingencies

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNALLVIOLFREQ  FRTYPE
```

Python command syntax:

```
ierr = cnallviolfreq(frtype)
```

Fortran command syntax:

```
CALL MAPI_ALLVIOLFREQ(FRTYPE, IERR)
```

Where:

Character*12 FRTYPE

Is a string identifying the frequency type (input).

Integer IERR

error code (output).

IERR = 0

No error

IERR = 1

Prerequisite requirements for function not met

22.1.30. CNBASEVIOLATED

Use this function to report all base case violations.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNBASEVIOLATED
```

Python command syntax:

```
ierr = cnbaseviolated()
```

Fortran command syntax:

```
CALL MAPI_CNBASEVIOLBYCASE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.31. CNCINITSELBRANCHES

Use this function to compare INITIAL contingency flows for selected contingencies for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCINITSELBRANCHES
```

Python command syntax:

```
ierr = cncinitselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNCINITSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.32. CNCINITSELINTERFACES

Use this function to compare INITIAL contingency flows for selected contingencies for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCINITSELINTERFACES
```

Python command syntax:

```
ierr = cncinitselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNCINITSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.33. CNCOMPSELBRANCHES

Use this function to compare INITIAL flows for selected contingencies for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCOMPSELBRANCHES
```

Python command syntax:

```
ierr = cncompsselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNCOMPSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.34. CNCOMPSELINTERFACES

Use this function to compare INITIAL flows for selected contingencies for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCOMPSELINTERFACES
```

Python command syntax:

```
ierr = cncompseinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNCOMPSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.35. CNCOMPSELVOLTAGEBUSES

Use this function to compare INITIAL contingency flows for selected contingencies for the selected voltage buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCOMPSELVOLTAGEBUSES
```

Python command syntax:

```
ierr = cncompselevoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNCOMPSELVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.36. CNCRESULTSSELBRANCHES

Use this function to compare RESULTING contingency flows for selected contingencies for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCRESULTSSELBRANCHES
```

Python command syntax:

```
ierr = cncresultsselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNCRESSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.37. CNCRESULTSSELINTERFACES

Use this function to compare RESULTING contingency flows for selected contingencies for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNCRESULTSSELINTERFACES
```

Python command syntax:

```
ierr = cncresultsselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNCRESSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined

22.1.38. CNDETAILSELFLOWGATES

Use this function to display a detailed report of the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNDETAILSELFLOWGATES
```

Python command syntax:

```
ierr = cndetailselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNDETSELFGE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.39. CNDETAILSELINTERFACES

Use this function to display a detailed report of the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNDETAILSELINTERFACES
```

Python command syntax:

```
ierr = cndetailselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNDETSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.40. CNFACTORSSSELFLOWGATES

Use this function to display the OTDF variation factors for the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNFACTORSSSELFLOWGATES
```

Python command syntax:

```
ierr = cnfactorssselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNFACTSELFG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.41. CNFREQSELBRANCHES

Use this function to generate a violations frequency report for selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNFREQSELBRANCHES
```

Python command syntax:

```
ierr = cnfreqselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNFREQSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.42. CNFREQSELBRANCHES_TBL

Use this function to generate a violations frequency report for selected branches in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNFREQSELBRANCHES_TBL
```

Python command syntax:

```
ierr = cnfreqselbranches_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNFREQSELBRA_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.43. CNFREQSELINTERFACES

Use this function to generate a violations frequency report for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNFREQSELINTERFACES
```

Python command syntax:

```
ierr = cnfreqselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNFREQSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.44. CNFREQSELINTERFACES_TBL

Use this function to generate a violations frequency report for the selected interfaces in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNFREQSELINTERFACES_TBL
```

Python command syntax:

```
ierr = cnfreqselinterfaces_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNFREQSELINT_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.45. CNFREQSELVOLTAGEBUSES

Use this function to generate a violations frequency report for the selected buses with monitored voltages.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNFREQSELVOLTAGEBUSES
```

Python command syntax:

```
ierr = cnfreqselvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNFREQSELVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.46. CNGAPPSELBRANCHES

Use this function to display the GAPP factors for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNGAPPSELBRANCHES
```

Python command syntax:

```
ierr = cngappselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNGAPPSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.47. CNGAPPSELFLOWGATES

Use this function to display the GAPP factors for the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNGAPPSELFLOWGATES
```

Python command syntax:

```
ierr = cngappselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNGAPPSELFG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.48. CNGAPPSELINTERFACES

Use this function to display the GAPP factors for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNGAPPSELINTERFACES
```

Python command syntax:

```
ierr = cngappselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNGAPPSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.49. CNIMPACTSELBRANCHES

Use this function to report on constraints impacted by transfer for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNIMPACTSELBRANCHES
```

Python command syntax:

```
ierr = cnimpactselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNIMPACTSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.50. CNIMPACTSELFLOWGATES

Use this function to report on constraints impacted by transfer for the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNIMPACTSELFLOWGATES
```

Python command syntax:

```
ierr = cnimpactselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNIMPACTSELFG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.51. CNIMPACTSELINTERFACES

Use this function to report on constraints impacted by transfer for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNIMPACTSELINTERFACES
```

Python command syntax:

```
ierr = cnimpactselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNIMPACTSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.52. CNLISTSELBRANCHES

Use this function to generate a list of selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNLISTSELBRANCHES
```

Python command syntax:

```
ierr = cnlistselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.53. CNLISTSELBRANCHES_TBL

Use this function to generate a list of selected branches in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNLISTSELBRANCHES_TBL
```

Python command syntax:

```
ierr = cnlistselbranches_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELBRA_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.54. CNLISTSELFLOWGATES

Use this function to generate a list of selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNLISTSELFLOWGATES
```

Python command syntax:

```
ierr = cnlistselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELFGE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.55. CNLISTSELFLOWGATES_TBL

Use this function to generate a list of selected flowgates in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNLISTSELFLOWGATES_TBL
```

Python command syntax:

```
ierr = cnlistselflowgates_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELFLOWGATES_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.56. CNLISTSELINTERFACES

Use this function to generate a list of selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNLISTSELINTERFACES
```

Python command syntax:

```
ierr = cnlistselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.57. CNLISTSELINTERFACES_TBL

Use this function to generate a list of selected interfaces in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNLISTSELINTERFACES_TBL
```

Python command syntax:

```
ierr = cnlistselinterfaces_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELINT_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.58. CNLISTSELVOLTAGEBUSES

Use this function to generate a list of selected buses with monitored voltages.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNLISTSELVOLTAGEBUSES
```

Python command syntax:

```
ierr = cnlistselvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNLISTSELVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.59. CNOTDFSELBRANCHES

Use this function to display the OTDF variation factors for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNOTDFSELBRANCHES
```

Python command syntax:

```
ierr = cnotdfselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNOTDFSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.60. CNOTDFSELINTERFACES

Use this function to display the OTDF variation factors for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNOTDFSELINTERFACES
```

Python command syntax:

```
ierr = cnotdfselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNOTDFSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.61. CNSELECTBRANCHBYALL

Use this function to select ALL branches for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYALL
```

Python command syntax:

```
ierr = cnselectbranchbyall()
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYALL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.62. CNSELECTBRANCHBYAREAS

Use this function to select branches by areas for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYAREAS VLOW VHIGH NUMMONEL LISTML(1)..LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectbranchbyareas(vlow, vhigh, nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYAREAS(VLOW, VHIGH, NUMMONEL, LISTML, IERR)
```

Where:

Character*12 VLOW	Is the minimum voltage limit for selecting branches (input; no default allowed).
Character*12 VHIGH	Is the maximum voltage limit for selecting branches (input; no default allowed).
Integer NUMMONEL	(input; no default allowed).
Character*12 LISTML	Is a set of strings forming a list of areas. There must be as many areas as indicated by NUMMONEL. (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	No error
IERR = 1	Prerequisite requirements for function not met
IERR = 2	The minimum voltage limit for selecting branches is missing.
IERR = 3	The maximum voltage limit for selecting branches is missing.
IERR = 4	The number of monitored elements is missing.
IERR = 5	One area label is missing.

22.1.63. CNSELECTBRANCHBYBRANCHES

Use this function to select branches for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYBRANCHES  NUMMONEL LISTML(1) .. LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectbranchbybranches(nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYBRANCHES(NUMMONEL, LISTML, IERR)
```

Where:

Integer NUMMONEL	(input; no default allowed).
Character*12 LISTML	Is a set of strings forming a list of branches. Each branch consists of a FROM bus followed by a TO bus followed by a Circuit ID. There must be as many sets of FROM TO CktID as indicated by NUMMONEL. (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 The number of monitored elements is missing.
	IERR = 3 One branch label is missing.

22.1.64. CNSELECTBRANCHBYBUSES

Use this function to select branches by buses for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYBUSES  NUMMONEL LISTML(1) .. LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectbranchbybuses(nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYBUSES(NUMMONEL, LISTML, IERR)
```

Where:

Integer NUMMONEL	(input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of buses. There must be as many buses as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of monitored elements is missing.
	IERR = 3	One of bus labels is missing.

22.1.65. CNSELECTBRANCHBYIMPACT

Use this function to select branches by impact for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYIMPACT
```

Python command syntax:

```
ierr = cnselectbranchbyimpact()
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYIMP(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.66. CNSELECTBRANCHBYTIES

Use this function to select branches by ties for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYTIES LISTML
```

Python command syntax:

```
ierr = cnselectbranchbyties(listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYTIES(LISTML, IERR)
```

Where:

Character*12 LISTML	Is a set of strings forming a list of ties. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The tie line labels are missing.

22.1.67. CNSELECTBRANCHBYVIOL

Use this function to select branches by violation for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYVIOL VIOLMETH
```

Python command syntax:

```
ierr = cnselectbranchbyviol(violmeth)
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYVIOL(VIOLMETH, IERR)
```

Where:

Integer VIOLMETH	Indicates which violation method to use and can be one of the following entries: (input; no default allowed).	
	VIOLMETH = 1:	Violated in the pre-shift case
	VIOLMETH = 2:	Violated/limiting after adjustment
	VIOLMETH = 3:	Violated in the pre-shift case OR after adjustment
	VIOLMETH = 4:	Violated in the pre-shift case AND after adjustment
	VIOLMETH = 5:	Violated/binding after, but not in the pre-shiftcase
	VIOLMETH = 6:	Violated in the pre-shift case, but not after adjustments
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Chosen Violation Method is out of range
	IERR = 3	The violation method number is missing.

22.1.68. CNSELECTBRANCHBYZONES

Use this function to select branches by zones for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTBRANCHBYZONES VLOW VHIGH NUMMONEL LISTML(1)..LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectbranchbyzones(vlow, vhigh, nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELBRABYZONES(VLOW, VHIGH, NUMMONEL, LISTML, IERR)
```

Where:

Character*12 VLOW	Is the minimum voltage limit for selecting branches (input; no default allowed).	
Character*12 VHIGH	Is the maximum voltage limit for selecting branches (input; no default allowed).	
Integer NUMMONEL	(input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of zones. There must be as many zones as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The minimum voltage limit for selecting branches is missing.
	IERR = 3	The maximum voltage limit for selecting branches is missing.
	IERR = 4	The number of monitored elements is missing.
	IERR = 5	One of the zone labels is missing.

22.1.69. CNSELECTFGATEBYALL

Use this function to select ALL flowgates for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTFGATEBYALL
```

Python command syntax:

```
ierr = cnselectfgatebyall()
```

Fortran command syntax:

```
CALL MAPI_CNSELFGBYALL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.70. CNSELECTFGATEBYCONT

Use this function to select Contingent Flowgates Only for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTFGATEBYCONT
```

Python command syntax:

```
ierr = cnselectfgatebycont()
```

Fortran command syntax:

```
CALL MAPI_CNSELFGBYCONT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.71. CNSELECTFGATEBYID

Use this function to select flowgates by flowgate ID for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTFGATEBYID  NUMMONEL LISTML(1) .. LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectfgatebyid(nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELFGBYID(NUMMONEL, LISTML, IERR)
```

Where:

Integer NUMMONEL	Is the number of flowgates to be included in LISTML (input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of flowgate ID's. There must be as many flowgates as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of flowgate IDs is missing.
	IERR = 3	One of the flowgate IDs is missing.

22.1.72. CNSELECTFGATEBYIMPACT

Use this function to select flowgates by impact for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTFGATEBYIMPACT
```

Python command syntax:

```
ierr = cnselectfgatebyimpact()
```

Fortran command syntax:

```
CALL MAPI_CNSELFGBYIMP(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.73. CNSELECTFGATEBYVIOL

Use this function to select flowgates by violation for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTFGATEBYVIOL VIOLMETH
```

Python command syntax:

```
ierr = cnselectfgatebyviol(violmeth)
```

Fortran command syntax:

```
CALL MAPI_CNSELFGBYVIOL(VIOLMETH, IERR)
```

Where:

Integer VIOLMETH	Indicates which violation method to use and can be one of the following entries: (input; no default allowed).	
	VIOLMETH = 1:	Violated in the pre-shift case
	VIOLMETH = 2:	Violated/limiting after adjustment
	VIOLMETH = 3:	Violated in the pre-shift case OR after adjustment
	VIOLMETH = 4:	Violated in the pre-shift case AND after adjustment
	VIOLMETH = 5:	Violated/binding after, but not in the pre-shiftcase
	VIOLMETH = 6:	Violated in the pre-shift case, but not after adjustments
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Chosen Violation Method is out of range
	IERR = 3	The number of violation methods is missing.

22.1.74. CNSELECTINTERBYALL

Use this function to select ALL interfaces for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTINTERBYALL
```

Python command syntax:

```
ierr = cnselectinterbyall()
```

Fortran command syntax:

```
CALL MAPI_CNSELINTBYALL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.75. CNSELECTINTERBYIMPACT

Use this function to select interfaces by impact for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTINTERBYIMPACT
```

Python command syntax:

```
ierr = cnselectinterbyimpact()
```

Fortran command syntax:

```
CALL MAPI_CNSELINTBYIMP(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.76. CNSELECTINTERBYNAME

Use this function to select interfaces by interface name for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTINTERBYNAME  NUMMONEL LISTML(1)..LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectinterbyname(nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELINTBYNAM(NUMMONEL, LISTML, IERR)
```

Where:

Integer NUMMONEL	Is the number of interfaces to be included in LISTML (input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of interface names. There must be as many interfaces as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of monitored interfaces is missing.
	IERR = 3	One of the interface labels is missing.

22.1.77. CNSELECTINTERBYNUMBER

Use this function to select interfaces by interface number for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTINTERBYNUMBER  NUMMONEL LISTML(1)..LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectinterbynumber(nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELINTBYNUM(NUMMONEL, LISTML, IERR)
```

Where:

Integer NUMMONEL	Is the number of interfaces to be included in LISTML (input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of interface numbers. There must be as many interfaces as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of monitored interfaces is missing.
	IERR = 3	One of interface labels is missing.

22.1.78. CNSELECTINTERBYVIOL

Use this function to select interfaces by violation for a constraints analysis.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTINTERBYVIOL VIOLMETH
```

Python command syntax:

```
ierr = cnselectinterbyviol(violmeth)
```

Fortran command syntax:

```
CALL MAPI_CNSELINTBYVIOL(VIOLMETH, IERR)
```

Where:

Integer VIOLMETH	Indicates which violation method to use and can be one of the following entries: (input; no default allowed).	
	VIOLMETH = 1:	Violated in the pre-shift case
	VIOLMETH = 2:	Violated/limiting after adjustment
	VIOLMETH = 3:	Violated in the pre-shift case OR after adjustment
	VIOLMETH = 4:	Violated in the pre-shift case AND after adjustment
	VIOLMETH = 5:	Violated/binding after, but not in the pre-shiftcase
	VIOLMETH = 6:	Violated in the pre-shift case, but not after adjustments
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Chosen Violation Method is out of range
	IERR = 3	The number of violation methods is missing.

22.1.79. CNSELECTVOLTAGEBUSESBYVIOL

Use this function to select buses with monitored voltages by violation.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTVOLTAGEBUSESBYVIOL VIOLMETH
```

Python command syntax:

```
ierr = cnselectvoltagebusesbyviol(violmeth)
```

Fortran command syntax:

```
CALL MAPI_CNSELVOLTBYVIOL(VIOLMETH, IERR)
```

Where:

Integer VIOLMETH	Indicates which violation method to use and can be one of the following entries: (input; no default allowed).
VIOLMETH = 1:	Violated in the pre-shift case
VIOLMETH = 2:	Violated/limiting after adjustment
VIOLMETH = 3:	Violated in the pre-shift case OR after adjustment
VIOLMETH = 4:	Violated in the pre-shift case AND after adjustment
VIOLMETH = 5:	Violated/binding after, but not in the pre-shiftcase
VIOLMETH = 6:	Violated in the pre-shift case, but not after adjustments
Integer IERR	error code (output).
IERR = 0	No error
IERR = 1	Prerequisite requirements for function not met
IERR = 2	Chosen Violation Method is out of range
IERR = 3	The number of violation methods is missing.

22.1.80. CNSELECTVOLTBUSBYALL

Use this function to select ALL buses with monitored voltages.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTVOLTBUSBYALL
```

Python command syntax:

```
ierr = cnselectvoltbusbyall()
```

Fortran command syntax:

```
CALL MAPI_CNSELVOLTBYALL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.81. CNSELECTVOLTBUSBYAREAS

Use this function to select buses with monitored voltages by areas.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTVOLTBUSBYAREAS VLOW VHIGH NUMMONEL
LISTML(1) . . LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectvoltbusbyareas(vlow, vhigh, nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELVOLTBYAREAS(VLOW, VHIGH, NUMMONEL, LISTML, IERR)
```

Where:

Character*12 VLOW	Is the minimum voltage limit for selecting buses (input; no default allowed).
Character*12 VHIGH	Is the maximum voltage limit for selecting buses (input; no default allowed).
Integer NUMMONEL	(input; no default allowed).
Character*12 LISTML	Is a set of strings forming a list of areas. There must be as many areas as indicated by NUMMONEL. (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	No error
IERR = 1	Prerequisite requirements for function not met
IERR = 2	The minimum voltage limit for selecting buses is missing.
IERR = 3	The maximum voltage limit for selecting buses is missing.
IERR = 4	The number of monitored elements is missing.
IERR = 5	One area label is missing.

22.1.82. CNSELECTVOLTBUSBYBUSES

Use this function to select buses with monitored voltages by bus number.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTVOLTBUSBYBUSES  NUMMONEL LISTML(1)..LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectvoltbusbybuses(nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELVOLTBYBUSES(NUMMONEL, LISTML, IERR)
```

Where:

Integer NUMMONEL	(input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of voltage buses. There must be as many voltage buses as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of voltage buses is missing.
	IERR = 3	One bus label is missing.

22.1.83. CNSELECTVOLTBUSBYZONES

Use this function to select buses with monitored voltages by zones.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTVOLTBUSBYZONES VLOW VHIGH NUMMONEL
LISTML(1) . . LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = cnselectvoltbusbyzones(vlow, vhigh, nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_CNSELVOLTBYZONES(VLOW, VHIGH, NUMMONEL, LISTML, IERR)
```

Where:

Character*12 VLOW	Is the minimum voltage limit for selecting buses (input; no default allowed).	
Character*12 VHIGH	Is the maximum voltage limit for selecting buses (input; no default allowed).	
Integer NUMMONEL	(input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of zones. There must be as many zones as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The minimum voltage limit for selecting buses is missing.
	IERR = 3	The maximum voltage limit for selecting buses is missing.
	IERR = 4	The number of monitored elements is missing.
	IERR = 5	One zone label is missing.

22.1.84. CNSELECTVOLTBUSESBYDEVIATION

Use this function to select branches by deviation.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSELECTVOLTBUSESBYDEVIATION VLOW VHIGH
```

Python command syntax:

```
ierr = cnselectvoltbusesbydeviation(vlow, vhigh)
```

Fortran command syntax:

```
CALL MAPI_CNSELVOLTBYDEV(VLOW, VHIGH, IERR)
```

Where:

Real VLOW	Is the minimum voltage limit for selecting buses (input; no default allowed).	
Real VHIGH	Is the maximum voltage limit for selecting buses (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	VLOW outside of acceptable limits
	IERR = 3	VHIGH outside of acceptable limits
	IERR = 4	The minimum voltage limit for selecting buses is missing.
	IERR = 5	The maximum voltage limit for selecting buses is missing.

22.1.85. CNSENSUBSELBRANCHES

Use this function to display the subsystem sensitivities for the first selected branch.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSENSUBSELBRANCHES
```

Python command syntax:

```
ierr = cnsensubselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNSENSSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.86. CNSENSUBSELFLOWGATES

Use this function to display the subsystem sensitivities for the first selected flowgate.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSENSUBSELFLOWGATES
```

Python command syntax:

```
ierr = cnsensubselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNSENSSELFG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.87. CNSENSUBSELINTERFACES

Use this function to display the subsystem sensitivities for the first selected interface.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSENSUBSELINTERFACES
```

Python command syntax:

```
ierr = cnsensubselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNSENSSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.88. CNSTUDYSELBRANCHES

Use this function to generate a sensitivity analysis for study transfer on the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSTUDYSELBRANCHES  SUBSFR SUBSIN
```

Python command syntax:

```
ierr = cnstudyselbranches(subsfr, subsin)
```

Fortran command syntax:

```
CALL MAPI_CNSTUDYSELBRA(SUBSFR, SUBSIN, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying FROM Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying TO Subsystem Name to be used in the study transfer. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	FROM SubSystem same as TO SubSystem
	IERR = 4	The FROM Subsystem Name is missing.
	IERR = 5	The TO Subsystem Name is missing.

22.1.89. CNSTUDYSELFLOWGATES

Use this function to generate a sensitivity analysis for study transfer on the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSTUDYSELFLOWGATES  SUBSFR SUBSIN
```

Python command syntax:

```
ierr = cnstudyselflowgates(subsfr, subsin)
```

Fortran command syntax:

```
CALL MAPI_CNSTUDYSELFPG(SUBSFR, SUBSIN, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying FROM Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying TO Subsystem Name to be used in the study transfer. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	FROM SubSystem same as TO SubSystem
	IERR = 4	The FROM Subsystem Name is missing.
	IERR = 5	The TO Subsystem Name is missing.

22.1.90. CNSTUDYSELINTERFACES

Use this function to generate a sensitivity analysis for study transfer on the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSTUDYSELINTERFACES  SUBSFR SUBSIN
```

Python command syntax:

```
ierr = cnstudyselinterfaces(subsfr, subsin)
```

Fortran command syntax:

```
CALL MAPI_CNSTUDYSELINT(SUBSFR, SUBSIN, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying FROM Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying TO Subsystem Name to be used in the study transfer. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	FROM SubSystem same as TO SubSystem
	IERR = 4	The FROM Subsystem Name is missing.
	IERR = 5	The TO Subsystem Name is missing.

22.1.91. CNSUBSELBRANCHES

Use this function to report on the subsystem branch factors for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSUBSELBRANCHES SUBS
```

Python command syntax:

```
ierr = cnsuselbranches(subs)
```

Fortran command syntax:

```
CALL MAPI_CNSUBSELBRA(SUBS, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the Subsystem Name for which to report the branch factors. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	The Subsystem Name is missing.

22.1.92. CNSUBSELFLOWGATES

Use this function to report on the subsystem branch factors for the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSUBSELFLOWGATES SUBS
```

Python command syntax:

```
ierr = cnsubselflowgates(subs)
```

Fortran command syntax:

```
CALL MAPI_CNSUBSELFGE(SUBS, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the Subsystem Name for which to report the flowgate factors. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	The Subsystem Name is missing.

22.1.93. CNSUBSELINTERFACES

Use this function to report on the subsystem branch factors for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSUBSELINTERFACES SUBS
```

Python command syntax:

```
ierr = cnsubselinterfaces(subs)
```

Fortran command syntax:

```
CALL MAPI_CNSUBSELINT(SUBS, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the Subsystem Name for which to report the interface factors. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	The Subsystem Name is missing.

22.1.94. CNSUMMARYVIOLATIONS

Use this function to report a summary of violations.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNSUMMARYVIOLATIONS
```

Python command syntax:

```
ierr = csummaryviolations()
```

Fortran command syntax:

```
CALL MAPI_CNLPINFOSUM(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.95. CNTRANSACTSELBRANCHES

Use this function to display the transactions impact on the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNTRANSACTSELBRANCHES  NUMTRANS LISTTR(1)..LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = cntransactselbranches(numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_CNTRANSELBRA(NUMTRANS, LISTTR, IERR)
```

Where:

Integer NUMTRANS	Is the number of transactions (input; no default allowed).	
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of transactions is missing.
	IERR = 3	One transaction label is missing.

22.1.96. CNTRANSACTSELFLOWGATES

Use this function to display the transactions impact on the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNTRANSACTSELFLOWGATES  NUMTRANS LISTTR(1)..LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = cntransactselflowgates(numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_CNTRANSELFGE(NUMTRANS, LISTTR, IERR)
```

Where:

Integer NUMTRANS	Is the number of transactions to be included in LISTTR (input; no default allowed).	
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of transactions is missing.
	IERR = 3	One transaction label is missing.

22.1.97. CNTRANSACTSELINTERFACES

Use this function to display the transactions impact on the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNTRANSACTSELINTERFACES  NUMTRANS LISTTR(1)..LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = cntransactselinterfaces(numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_CNTRANSELINT(NUMTRANS, LISTTR, IERR)
```

Where:

Integer NUMTRANS	(input; no default allowed).	
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of transactions is missing.
	IERR = 3	One transaction label is missing.

22.1.98. CNVARSELBRANCHES

Use this function to display the variations report for the selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVARSELBRANCHES
```

Python command syntax:

```
ierr = cnvarselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNVARSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.99. CNVARSELINTERFACES

Use this function to display the variations report for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVARSELINTERFACES
```

Python command syntax:

```
ierr = cnvarselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNVARSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.100. CNVARSELVOLTAGEBUSES

Use this function to display the variations report for the selected voltage buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVARSELVOLTAGEBUSES
```

Python command syntax:

```
ierr = cnvarselvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNVARSELVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.101. CNVIOLSELBRANCHES

Use this function to generate a violations report for selected branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVIOLSELBRANCHES
```

Python command syntax:

```
ierr = cnviolselbranches()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.102. CNVIOLSELBRANCHES_TBL

Use this function to generate a violations report for selected branches in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNVIOLSELBRANCHES_TBL
```

Python command syntax:

```
ierr = cnviolselbranches_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELBRA_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.103. CNVIOLSELFLOWGATES

Use this function to generate a violations report for the selected flowgates.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVIOLSELFLOWGATES
```

Python command syntax:

```
ierr = cnviolselflowgates()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELFVG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.104. CNVIOLSELFLOWGATES_TBL

Use this function to generate a violations report for the selected flowgates in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNVIOLSELFLOWGATES_TBL
```

Python command syntax:

```
ierr = cnviolselflowgates_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELFLOWGATES_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.105. CNVIOLSELINTERFACES

Use this function to generate a violations report for the selected interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVIOLSELINTERFACES
```

Python command syntax:

```
ierr = cnviolselinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.106. CNVIOLSELINTERFACES_TBL

Use this function to generate a violations report for the selected interfaces in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_CNVIOLSELINTERFACES_TBL
```

Python command syntax:

```
ierr = cnviolselinterfaces_tbl()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELINT_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.107. CNVIOLSELVOLTAGEBUSES

Use this function to generate a violations report for the selected buses with monitored voltages.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_CNVIOLSELVOLTAGEBUSES
```

Python command syntax:

```
ierr = cnviolselvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNVIOLSELVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.108. COMPAREFCITC

Use this function to compare two FCITC reports.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_COMPAREFCITC  MNFILE CNFILE
```

Python command syntax:

```
ierr = comparefcitc(mnfile, cnfile)
```

Fortran command syntax:

```
CALL MAPI_COMPAREFCITC(MNFILE, CNFILE, IERR)
```

Where:

Character*260 MNFILE	(input; no default allowed).
Character*260 CNFILE	(input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 File 1 - FCITC file missing, invalid name or no access
	IERR = 3 File 2 - FCITC file missing, invalid name or no access

22.1.109. CONSTRDEFS

Use this function to enter a set of default MUST Options for later use in Transfer Analysis calculations

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_CONSTRDEFS  OPTIONS(1)..OPTIONS(7)  VALUES(1)..VALUES(3)
```

Python command syntax:

```
ierr = constrdefs(options, values)
```

Fortran command syntax:

```
CALL MAPI_CONSTRDEFS(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (7)	array of 7 elements specifying calculation options(input).
OPTIONS(1)	Base Case Rating (Select Rating 1-12) (1 by default)
OPTIONS(1) > n	Rating ID
OPTIONS(2)	Contingency Case Rating (Select Rating 1-12) (2 by default)
OPTIONS(2) > n	Rating ID
OPTIONS(3)	Base Case Load Flow (4 by default)
OPTIONS(3) = 0	DC
OPTIONS(3) = 1	AC Newton
OPTIONS(3) = 2	AC Decoupled
OPTIONS(3) = 3	EMS
OPTIONS(3) = 4	Do not solve AC
OPTIONS(3) = 5	PSS/E Presolved
OPTIONS(4)	Convert branch ratings to estimated MW ratings (0 by default)
OPTIONS(4) = 0	no
OPTIONS(4) = 1	yes
OPTIONS(5)	Contingency ID Reporting (3 by default)
OPTIONS(5) = 1	labels
OPTIONS(5) = 2	events
OPTIONS(5) = 3	both
OPTIONS(6)	Maximum Number of Contingencies to process (900000 by default)
OPTIONS(6) > n	Number of Contingencies
OPTIONS(7)	Line Rating Unit for AC Applications (0 by default)
OPTIONS(7) = 0	Current expressed as MVA
OPTIONS(7) = 1	MVA

Real VALUES (3)	array of 3 elements specifying reporting parameters(input).	
	VALUES(1)	AC MW Mismatch Tolerance (10.0 by default)
	VALUES(2)	Base Case Percent of Rating (branches only) (100.0 by default)
	VALUES(3)	Contingency Case Percent of Rating (branches only) (100.0 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.110. DCCONTBYCONT

Use this function to generate a DC contingency report by contingency options

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_DCCONTBYCONT SEL SELOPT1 SELOPT2 RPTTYPE OPTIONS(1)..OPTIONS(4)
NUM(1)..NUM(2)
```

Python command syntax:

```
ierr = dccontbycont(sel, selopt1, selopt2, rpttype, options, num)
```

Fortran command syntax:

```
CALL MAPI_DCCONTBYCONT(SEL, SELOPT1, SELOPT2, RPTTYPE, OPTIONS, NUM, IERR)
```

Where:

Integer SEL	Indicate how to filter the contingencies for this report (input; no default allowed).
	'1' Report contingencies by Category
	'2' Report contingencies by Range
	'3' Report contingencies below severity index
	'4' Report contingencies above severity index
Integer SELOPT1	Option used in conjunction with SEL when SEL=(1 or 2) to specify filter criteria (input; no default allowed).
	SELOPT1 = n If SEL = 2 (by Range) then n = lower contingency number in desired range. If SEL = 1 (by Category) then enter one of the following:
	SELOPT1 = 1 Show ALL contingencies
	SELOPT1 = 2 Show contingencies with Violations
	SELOPT1 = 3 Show contingencies without Violations
	SELOPT1 = 4 Show ACTIVE contingencies
	SELOPT1 = 5 Show EXCLUDED contingencies
	SELOPT1 = 6 Show DISABLED contingencies
	SELOPT1 = 7 Show SINGLE BRANCH contingencies
	SELOPT1 = 8 Show COMPLEX contingencies
	SELOPT1 = 9 Show contingencies with Islands
	SELOPT1 = 10 Show IMBALANCED contingencies
	SELOPT1 = 11 Show contingencies with Generation
	SELOPT1 = 12 Show contingencies with Load
Integer SELOPT2	Only used if SEL = 2 (by Range) (input).
	SELOPT2 = n Upper contingency number in desired range
Integer RPTTYPE	Type of contingency report (input; no default allowed).
	'1' Selected Contingencies with Violations

	'2'	Summary List of Selected Contingencies
	'3'	Details for Selected Contingencies
Integer OPTIONS (4)	array of 4 elements specifying report options(input).	
	OPTIONS(1)	Report loading above cutoff (0 by default)
	OPTIONS(1) = 0	No
	OPTIONS(1) = 1	Yes
	OPTIONS(2)	Include Contingent Events (0 by default)
	OPTIONS(2) = 0	No
	OPTIONS(2) = 1	Yes
	OPTIONS(3)	Include Islands Report (0 by default)
	OPTIONS(3) = 0	No
	OPTIONS(3) = 1	Yes
	OPTIONS(4)	Include Dispatch Data (0 by default)
	OPTIONS(4) = 0	No
	OPTIONS(4) = 1	Yes
Real NUM (2)	array of 2 elements specifying criteria to be used in conjunction with SEL and OPTIONS (input).	
	NUM(1)	Used with SEL=3 or 4 (by Severity Index) (0 by default)
	NUM(1) = x	x = Severity index for selected contingencies
	NUM(2)	Used with OPTIONS(1) = 1 (Report loading above cutoff) (0 by default)
	NUM(2) = y	y = Cutoff (%) for reporting loading
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.111. DCCONTBYMONEL

Use this function to generate a DC contingency report by monitored elements

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_DCCONTBYMONEL SEL SELOPT1 SELOPT2 MONELS RPTTYPE NUM(1)..NUM(2)
```

Python command syntax:

```
ierr = dccontbymonel(sel, selopt1, selopt2, monels, rpttype, num)
```

Fortran command syntax:

```
CALL MAPI_DCCONTBYMONEL(SEL, SELOPT1, SELOPT2, MONELS, RPTTYPE, NUM, IERR)
```

Where:

Integer SEL	Indicate how to filter the contingencies for this report (input; no default allowed).
	'1' Report contingencies by Category
	'2' Report contingencies by Range
	'3' Report contingencies below severity index
	'4' Report contingencies above severity index
Integer SELOPT1	Option used in conjunction with SEL when SEL=(1 or 2) to specify filter criteria (input; no default allowed).
	SELOPT1 = n If SEL = 2 (by Range) then n = lower contingency number in desired range. If SEL = 1 (by Category) then enter one of the following:
	SELOPT1 = 1 Show ALL contingencies
	SELOPT1 = 2 Show contingencies with Violations
	SELOPT1 = 3 Show contingencies without Violations
	SELOPT1 = 4 Show ACTIVE contingencies
	SELOPT1 = 5 Show EXCLUDED contingencies
	SELOPT1 = 6 Show DISABLED contingencies
	SELOPT1 = 7 Show SINGLE BRANCH contingencies
	SELOPT1 = 8 Show COMPLEX contingencies
	SELOPT1 = 9 Show contingencies with Islands
	SELOPT1 = 10 Show IMBALANCED contingencies
	SELOPT1 = 11 Show contingencies with Generation
	SELOPT1 = 12 Show contingencies with Load
Integer SELOPT2	Only used if SEL = 2 (by Range) (input).
	SELOPT2 = n Upper contingency number in desired range
Integer MONELS	Monitored elements for report (input; no default allowed).
	'1' Branches
	'2' Interfaces

	'3'	Flowgates
Integer RPTTYPE	Type of contingency report (input; no default allowed).	
	'1'	List of Monitored Elements
	'2'	List of Violations above Cutoff
	'3'	Summary of Frequency of Violations
Real NUM (2)	array of 2 elements specifying criteria to be used in conjunction with SEL and RPTTYPE (input).	
	NUM(1)	Used with SEL=3 or 4 (by Severity Index) (0 by default)
	NUM(1) = x	x = Severity index for selected contingencies
	NUM(2)	Used with RPTTYPE = 2 (Violations above cut-off) (0 by default)
	NUM(2) = y	y = Cutoff (%) for reporting loading
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.112. DCSOLVE

Use this function to solve the DC load flow .

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_DCSOLVE
```

Python command syntax:

```
ierr = dcsolve()
```

Fortran command syntax:

```
CALL MAPI_DCSOLVE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Initialization error

22.1.113. DCTransferLimitStudy

Use this function to execute a DC Study Transfer.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_DCTransferLimitStudy DFLAG SYS1 SYS2 TRANSFER
```

Python command syntax:

```
ierr = dctransferlimitstudy(dflag, sys1, sys2, transfer)
```

Fortran command syntax:

```
CALL MAPI_DCTransferLimitStudy(DFLAG, SYS1, SYS2, TRANSFER, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).	
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem(s) missing
	IERR = 3	No transfer value
	IERR = 4	Subsystem(s) not valid
	IERR = 5	Sending subsystem already selected

22.1.114. DETAILSELCONTINGENCIES

Use this function to display details of the selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_DETAILSELCONTINGENCIES
```

Python command syntax:

```
ierr = detailselcontingencies()
```

Fortran command syntax:

```
CALL MAPI_DETSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.115. DETAILSELCONTINGENCISSP

Use this function to display details report on the selected contingencies using the Selected Parameters

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_DETAILSELCONTINGENCISSP CVIOL CEVENTS CISLAND CDISPATCH
```

Python command syntax:

```
ierr = detailselcontingenciessp(cviol, cevents, cisland, cdispatch)
```

Fortran command syntax:

```
CALL MAPI_DETSELCONTSSP(CVIOL, CEVENTS, CISLAND, CDISPATCH, IERR)
```

Where:

Integer CVIOL	Report violation details (0-no report,1 - report) (input; no default allowed).	
Integer CEVENTS	Report details on contingency events (0-no report,1 - report) (input; no default allowed).	
Integer CISLAND	Report islands details (0-no report,1 - report) (input; no default allowed).	
Integer CDISPATCH	Report details on dispatch events (0-no report,1 - report) (input; no default allowed).	
integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Report violation details is missing.
	IERR = 3	Report contingency events details is missing.
	IERR = 4	Report islands details is missing.
	IERR = 5	Report dispatch event details is missing.

22.1.116. DIRECT

Use this function to capture the terminal output to a file. Also use this function to terminate capturing the terminal output. pss must module generally writes all reports to the terminal. This function is used to redirect the reports to the specified file.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_DIRECT DFLAG MARG FILARG
```

Python command syntax:

```
ierr = direct(dflag, marg, filarg)
```

Fortran command syntax:

```
CALL MAPI_DIRECT(DFLAG, MARG, FILARG, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).
Character*1 MARG	Is a one character string denoting the destination of the terminal output. Acceptable entries are: (input; no default allowed). MARG = T send output to terminal (also used to terminate writing to the file) MARG = F send output to the specified file MARG = X append output to the specified file
Character*260 FILARG	Is a string identifying the full pathname of the file to which the terminal output will be written. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Prerequisite requirements for function not met IERR = 2 FILARG missing, invalid file name, or no access IERR = 3 Invalid file specification IERR = 4 MARG invalid specification

22.1.117. EXCLUDESELECTEDCONTS

Use this function to exclude the selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_EXCLUDESELECTEDCONTS
```

Python command syntax:

```
ierr = excludeselectedconts()
```

Fortran command syntax:

```
CALL MAPI_EXCSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.118. EXECUTEACCONT

Use this function to run the AC contingency analysis load flow.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_EXECUTEACCONT
```

Python command syntax:

```
ierr = executeacctcont()
```

Fortran command syntax:

```
CALL MAPI_ACCEXE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Could not complete ACCONT Analysis

22.1.119. EXITACTIVITYACCONT

Use this function to terminate the ACCONT Activities. This function frees up the memory allocations that were required to perform the ACCONT analyses listed below. Analyses for which this function should be run upon completion: Execution (running) of the AC contingency analysis load flow; Reading or Saving the AC contingency analysis file (.acc); AC Constraints analyses by branches, interfaces, flowgates or voltages; AC Contingency analyses by contingencies

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_EXITACTIVITYACCONT
```

Python command syntax:

```
ierr = exitactivityacct()
```

Fortran command syntax:

```
CALL MAPI_POSTACCONTANAL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	ACCONT Analysis has not been initialized

22.1.120. EXITACTIVITYMUST

Use this function to terminate the pss must module Activities. This function frees up the memory allocations that were required to perform the pss must module analyses listed below.

Analyses for which this function should be run upon completion:

- DC Constraints analyses by branches, interfaces or flowgates
- DC Contingency analyses by contingencies
- DC Transfer analyses
- AC Transfer limit analysis
- Transfer versus transfer sensitivities
- Generator sensitivities on study transfer
- Transaction impact analysis

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_EXITACTIVITYMUST EXITC
```

Python command syntax:

```
ierr = exitactivitymust(exitc)
```

Fortran command syntax:

```
CALL MAPI_POSTMUSTANAL(EXITC, IERR)
```

Where:

Integer EXITC	Is Exit Code. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The Exit Code is missing.

22.1.121. FCITC2LINE

Use this function to generate a 2 LINE multiple fcitc report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FCITC2LINE  MAXREP
```

Python command syntax:

```
ierr = fcitc2line(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITC2LIN(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined
	IERR = 3	Maximum Number of Violations to Report is missing.

22.1.122. FCITCAC

Use this function to generate an AC multiple fcitc report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FCITCAC  MAXREP
```

Python command syntax:

```
ierr = fcitcac(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCAC(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Maximum Number of Violations to Report is missing.

22.1.123. FCITCACMULT

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_FCITCACMULT NVIOL NSTUTRA STUTRALIST
```

Python command syntax:

```
ierr = fcitcacmult(nviol,nstutra,stutralist)
```

Fortran command syntax:

```
CALL MAPI_FCITCACMULT(NVIOL, NSTUTRA, STUTRALIST, IERR)
```

Where:

Integer NVIOL	(input; no default allowed).
Integer NSTUTRA	(input; no default allowed).
Character*12 STUTRALIST	(input; no default allowed).
Integer IERR	error code (output).

22.1.124. FCITCACSINGLE

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_FCITCACSINGLE  MAXREP
```

Python command syntax:

```
ierr = fcitcacmultiple(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCACSINGLE(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).
Integer IERR	error code (output).

22.1.125. FCITCBASE

Use this function to generate a BASE multiple fcitc report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FCITCBASE MAXREP
```

Python command syntax:

```
ierr = fcitcbase(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCBASE(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined
	IERR = 3	Maximum Number of Violations to Report is missing.

22.1.126. FCITCBASEMULT

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MAPI_FCITCBASEMULT    MAXREP NSTUTRA STUTRALIST
```

Python command syntax:

```
ierr = fcitcbasemult(maxrep,nstutra,stutralist)
```

Fortran command syntax:

```
CALL MAPI_FCITCBASEMULT(MAXREP, NSTUTRA, STUTRALIST, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).
Integer NSTUTRA	(input; no default allowed).
Character*12 STUTRALIST	(input; no default allowed).
Integer IERR	error code (output).

22.1.127. FCITCBASESINGLE

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_FCITCBASESINGLE    MAXREP
```

Python command syntax:

```
ierr = fcitcbasesingle(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCBASESINGLE(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined
	IERR = 3	Maximum Number of Violations to Report is missing.

22.1.128. FCITCMULT

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_FCITCMULT NVIOL NSTUTRA STUTRALIST
```

Python command syntax:

```
ierr = fcitcmult(nviol,nstutra,stutralist)
```

Fortran command syntax:

```
CALL MAPI_FCITCMULT(NVIOL, NSTUTRA, STUTRALIST, IERR)
```

Where:

Integer NVIOL	(input).
Integer NSTUTRA	(input).
Character*19 STUTRALIST	(input; no default allowed).
Integer IERR	error code (output).

22.1.129. FCITCSINGLE

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_FCITCSINGLE    MAXREP
```

Python command syntax:

```
ierr = fcitcsingle(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCSINGLE(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).
Integer IERR	error code (output).

22.1.130. FCITCSUBS

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_FCITCSUBS SUBSFROM SUBSTO MWLEV
```

Python command syntax:

```
ierr = fcitcsubs(subsfrom, substo,mwlev)
```

Fortran command syntax:

```
CALL MAPI_FCITCSUBS(SUBSFROM, SUBSTO, MWLEV, IERR)
```

Where:

Character*12 SUBSFROM	Is a string identifying the name of the subsystem to list (input; no default allowed).	
Character*12 SUBSTO	Is a string identifying the name of the subsystem to list (input; no default allowed).	
Real MWLEV	The MW transfer level (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem not found
	IERR = 3	The subsystem label is missing.
	IERR = 4	The MW transfer level is missing.

22.1.131. FCITCTLTG

Use this function to generate a TLTG multiple fcitc report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FCITCTLTG  MAXREP
```

Python command syntax:

```
ierr = fcitctlgt(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCTLTG(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined
	IERR = 3	The Maximum Number of Violations to Report is missing.

22.1.132. FCITCWISE

Use this function to generate a WIDE multiple fcitc report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FCITCWISE MAXREP
```

Python command syntax:

```
ierr = fcitcwise(maxrep)
```

Fortran command syntax:

```
CALL MAPI_FCITCWISE(MAXREP, IERR)
```

Where:

Integer MAXREP	Maximum Number of Violations to Report (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined
	IERR = 3	The Maximum Number of Violations to Report is missing.

22.1.133. FLOWGATESENSITIVITY

Use this function to generate the monitored elements sensitivities for specified flowgates

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_FLOWGATESENSITIVITY NUMMONEL LISTML OPTIONS(1)..OPTIONS(4) REFSYS
IMPACTCUTOFF EXPSYS IMPSYS NUMTRANS LISTTRANS
```

Python command syntax:

```
ierr = flowgatesensitivity(nummonel, listml, options, refsys,
    impactcutoff, expsys, impsys, numtrans, listtrans)
```

Fortran command syntax:

```
CALL MAPI_FGSENS(NUMMONEL, LISTML, OPTIONS, REFSYS, IMPACTCUTOFF, EXPSYS,
    IMPSYS, NUMTRANS, LISTTRANS, IERR)
```

Where:

Integer NUMMONEL	How many monitored elements to consider. (input; no default allowed).																												
Character*32 LISTML	Is a set of strings forming a list of flowgate IDs. There must be as many flowgates as indicated by NUMMONEL. (input; no default allowed).																												
Integer OPTIONS (4)	array of 4 elements specifying calculation options(input). <table> <tr> <td>OPTIONS(1)</td><td>Sensitivity Report to: (1 by default)</td></tr> <tr> <td>OPTIONS(1) = 1</td><td>Reference Subsystem</td></tr> <tr> <td>OPTIONS(1) = 2</td><td>Factors for Impact Cutoff</td></tr> <tr> <td>OPTIONS(1) = 3</td><td>Subsystem Participating Buses</td></tr> <tr> <td>OPTIONS(1) = 4</td><td>Transactions</td></tr> <tr> <td>OPTIONS(2)</td><td>Contingency for impact/sensitivity reports (0 by default)</td></tr> <tr> <td>OPTIONS(2) = 0</td><td>Base Case</td></tr> <tr> <td>OPTIONS(2) = x</td><td>x = Contingency number</td></tr> <tr> <td>OPTIONS(3)</td><td>Reference subsystem config for sensitivity analysis (1 by default)</td></tr> <tr> <td>OPTIONS(3) = 1</td><td>Importing</td></tr> <tr> <td>OPTIONS(3) = 2</td><td>Exporting</td></tr> <tr> <td>OPTIONS(4)</td><td>Transactions to consider (1 by default)</td></tr> <tr> <td>OPTIONS(4) = 1</td><td>All possible transactions</td></tr> <tr> <td>OPTIONS(4) = 2</td><td>Only selected transactions</td></tr> </table>	OPTIONS(1)	Sensitivity Report to: (1 by default)	OPTIONS(1) = 1	Reference Subsystem	OPTIONS(1) = 2	Factors for Impact Cutoff	OPTIONS(1) = 3	Subsystem Participating Buses	OPTIONS(1) = 4	Transactions	OPTIONS(2)	Contingency for impact/sensitivity reports (0 by default)	OPTIONS(2) = 0	Base Case	OPTIONS(2) = x	x = Contingency number	OPTIONS(3)	Reference subsystem config for sensitivity analysis (1 by default)	OPTIONS(3) = 1	Importing	OPTIONS(3) = 2	Exporting	OPTIONS(4)	Transactions to consider (1 by default)	OPTIONS(4) = 1	All possible transactions	OPTIONS(4) = 2	Only selected transactions
OPTIONS(1)	Sensitivity Report to: (1 by default)																												
OPTIONS(1) = 1	Reference Subsystem																												
OPTIONS(1) = 2	Factors for Impact Cutoff																												
OPTIONS(1) = 3	Subsystem Participating Buses																												
OPTIONS(1) = 4	Transactions																												
OPTIONS(2)	Contingency for impact/sensitivity reports (0 by default)																												
OPTIONS(2) = 0	Base Case																												
OPTIONS(2) = x	x = Contingency number																												
OPTIONS(3)	Reference subsystem config for sensitivity analysis (1 by default)																												
OPTIONS(3) = 1	Importing																												
OPTIONS(3) = 2	Exporting																												
OPTIONS(4)	Transactions to consider (1 by default)																												
OPTIONS(4) = 1	All possible transactions																												
OPTIONS(4) = 2	Only selected transactions																												
Character*12 REFSYS	Is a string identifying the Reference Subsystem Name - to be used with Report 1 of OPTION(1). Enter -1 for Swing Bus. (input; blank by default).																												

Real IMPACTCUTOFF	Impact CutOff Value - to be used with Report 2 of OPTION(1) (input; 0 by default).	
Character*12 EXPSYS	Is a string identifying the Exporting Subsystem Name - to be used with Report 3 of OPTION(1) (input; blank by default).	
Character*12 IMPSYS	Is a string identifying the Importing Subsystem Name - to be used with Report 3 of OPTION(1) (input; blank by default).	
Integer NUMTRANS	How many transactions in LISTTRANS - to be used with Report 4 of OPTION(1). (input; no default allowed).	
Character*32 LISTTRANS	Is a set of strings forming a list of subsystem names representing transactions with each transaction being made up of a FROM subsystem and a TO subsystem. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.134. FORGETSTUDYTRANSFER

Use this function to remove the current Study Transfer from memory.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_FORGETSTUDYTRANSFER
```

Python command syntax:

```
ierr = forgetstudytransfer()
```

Fortran command syntax:

```
CALL MAPI_FORGETST(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.135. GENDETAILS

Use this function to list the details for a specific subsystem.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_GENDETAILS SUBS MWLEV
```

Python command syntax:

```
ierr = gendetails(subs, mwlev)
```

Fortran command syntax:

```
CALL MAPI_GENDET(SUBS, MWLEV, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the name of the subsystem to list (input; no default allowed).	
Real MWLEV	The MW transfer level (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem not found
	IERR = 3	The subsystem label is missing.
	IERR = 4	The MW transfer level is missing.

22.1.136. GENSENDETAIL

Use this function to generate a detailed report for generator sensitivities on the current study transfer.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_GENSENDETAIL
```

Python command syntax:

```
ierr = gensendetail()
```

Fortran command syntax:

```
CALL MAPI_GENSENDET(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer Not Defined

22.1.137. GENSENSUMMARY

Use this function to generate a summary table for generator sensitivities on the current study transfer.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_GENSENSUMMARY
```

Python command syntax:

```
ierr = gensensummary()
```

Fortran command syntax:

```
CALL MAPI_GENSENSUM(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer Not Defined

22.1.138. ILFDEFAULTS

Use this function to enter a set of default Initial Line Flow options for later use in an AC load flow solution

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_ILFDEFAULTS  OPTSI(1)..OPTS(10) VALUES(1)..VALUES(3)
```

Python command syntax:

```
ierr = ilfdefaults(options, values)
```

Fortran command syntax:

```
CALL MAPI_ILFDEFAULTS(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (10)	array of 10 elements specifying calculation options(input).
OPTIONS(1)	Base Case Load Flow (4 by default)
OPTIONS(1) = 0	DC
OPTIONS(1) = 1	AC Newton
OPTIONS(1) = 2	AC Decoupled
OPTIONS(1) = 3	EMS
OPTIONS(1) = 4	Do Not Solve
OPTIONS(2)	Transformer Tap (0 by default)
OPTIONS(2) = 0	disabled
OPTIONS(2) = 1	enable stepping, No Direct
OPTIONS(3)	Phase Shifter (0 by default)
OPTIONS(3) = 0	disabled
OPTIONS(3) = 1	enabled
OPTIONS(4)	Switchable Shunts (1 by default)
OPTIONS(4) = 0	disabled
OPTIONS(4) = 1	enabled
OPTIONS(5)	Area Interchange (0 by default)
OPTIONS(5) = 0	disabled
OPTIONS(5) = 1	Tie lines only
OPTIONS(5) = 2	Tie lines and loads
OPTIONS(6)	DC Tap (1 by default)
OPTIONS(6) = 0	Locked
OPTIONS(6) = 1	On
OPTIONS(7)	Iter. to begin Var limiting (0 by default)
OPTIONS(7) = 0	Hot Start: apply var limits immediately
OPTIONS(7) = 99	Automatic:
OPTIONS(8)	Load Flow Iterations Limit (20 by default)
OPTIONS(8) > n	Terminate calculation after n iterations

	OPTIONS(9)	Use Flat Start for Load Flow Solution (0 by default)
	OPTIONS(9) = 0	hot
	OPTIONS(9) = 1	flat
	OPTIONS(10)	Iteration to freeze adjustments (15 by default)
	OPTIONS(10) > n	Freeze adjustments after n iterations
Real VALUES (3)	array of 3 elements specifying reporting parameters(input).	
	VALUES(1)	Real and Reactive Power Tolerance (0.1 by default)
	VALUES(2)	Reactive Adjustments DeAcceleration Factor (1.0 by default)
	VALUES(3)	Low Voltage break point (pu) for load scaling (0.7 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.139. IMPACTINTRFACEPARTFACT

Use this function to generate an impact study for the systems interface participation factors (IPF).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_IMPACTINTRFACEPARTFACT  FROBJ TOOBJ NUMFROM LISTFR(1)..LISTFR(NUMFROM)
                             NUMTO LISTTO(1)..LISTTO(NUMTO)
```

Python command syntax:

```
ierr = impactintrfacepartfact(froobj, toobj, numfrom, listfr, numto,
                              listto)
```

Fortran command syntax:

```
CALL MAPI_IMPINTPF(FROBJ, TOOBJ, NUMFROM, LISTFR, NUMTO, LISTTO, IERR)
```

Where:

Character*12 FROBJ	Indicates the impacted system type. Valid entries can be: (input; no default allowed). FROBJ = AREA: Impacted systems listed by area FROBJ = ZONE: Impacted systems listed by zone FROBJ = SYST: Impacted systems listed by subsystem
Character*12 TOOBJ	Indicates the neighboring system type. Valid entries can be: (input; no default allowed). TOOBJ = AREA: Neighboring systems listed by area TOOBJ = ZONE: Neighboring systems listed by zone TOOBJ = SYST: Neighboring systems listed by subsystem
Integer NUMFROM	Is the number of impacted systems to be used in the impact study (input; no default allowed).
Character*12 LISTFR	Is a set of strings forming a list of impacted systems. There must be as many impacted systems as indicated by NUMFROM. (input; no default allowed).
Integer NUMTO	Is the number of neighboring systems to be used in the impact study (input; no default allowed).
Character*12 LISTTO	Is a set of strings forming a list of neighboring systems. There must be as many neighboring systems as indicated by NUMTO. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Prerequisite requirements for function not met IERR = 2 From Category must be AREAS, ZONES or SYSTEMS

IERR = 3	To Category must be AREAS, ZONES or SYSTEMS
IERR = 4	No List of Systems Provided for Selected Category
IERR = 5	No List of Opposing Systems Provided for Selected Category
IERR = 6	The number of impacted systems is missing.
IERR = 7	The number of Opposing systems is missing.

22.1.140. IMPACTSETBASECASE

Use this function to generate an impact study on the base case.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_IMPACTSETBASECASE
```

Python command syntax:

```
ierr = impactsetbasecase()
```

Fortran command syntax:

```
CALL MAPI_IMPSETBASECASE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.141. IMPACTSETCONTINGENCY

Use this function to generate an impact study on the specified contingency.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_IMPACTSETCONTINGENCY CONTNUM
```

Python command syntax:

```
ierr = impactsetcontingency(contnum)
```

Fortran command syntax:

```
CALL MAPI_IMPSETCONTCASE(CONTNUM, IERR)
```

Where:

Integer CONTNUM	Is the number of contingency to be used in the impact study (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Contingency not found
	IERR = 3	The contingency number is missing.

22.1.142. IMPACTTIESPARTFACT

Use this function to generate an impact study providing a detailed report for all tie branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_IMPACTTIESPARTFACT  FROBJ TOOBJ NUMFROM LISTFR(1)..LISTFR(NUMFROM)
                        NUMTO LISTTO(1)..LISTTO(NUMTO)
```

Python command syntax:

```
ierr = impacttiespartfact(frobj, toobj, numfrom, listfr, numto, listto)
```

Fortran command syntax:

```
CALL MAPI_IMPTIEPF(FROBJ, TOOBJ, NUMFROM, LISTFR, NUMTO, LISTTO, IERR)
```

Where:

Character*12 FROBJ	Indicates the impacted system type. Valid entries can be: (input; no default allowed). FROBJ = AREA: Impacted systems listed by area FROBJ = ZONE: Impacted systems listed by zone FROBJ = SYST: Impacted systems listed by subsystem
Character*12 TOOBJ	Indicates the neighboring system type. Valid entries can be: (input; no default allowed). TOOBJ = AREA: Neighboring systems listed by area TOOBJ = ZONE: Neighboring systems listed by zone TOOBJ = SYST: Neighboring systems listed by subsystem
Integer NUMFROM	Is the number of impacted systems to be used in the impact study (input; no default allowed).
Character*12 LISTFR	Is a set of strings forming a list of impacted systems. There must be as many impacted systems as indicated by NUMFROM. (input; no default allowed).
Integer NUMTO	Is the number of neighboring systems to be used in the impact study (input; no default allowed).
Character*12 LISTTO	Is a set of strings forming a list of neighboring systems. There must be as many neighboring systems as indicated by NUMTO. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Prerequisite requirements for function not met IERR = 2 From Category must be AREAS, ZONES or SYSTEMS IERR = 3 To Category must be AREAS, ZONES or SYSTEMS

IERR = 4	No List of Systems Provided for Selected Category
IERR = 5	No List of Opposing Systems Provided for Selected Category
IERR = 6	The number of impacted systems is missing.
IERR = 7	The number of Opposing systems is missing.

22.1.143. IMPACTTOTALPARTFACT

Use this function to generate an impact study for the system totals participation factor (TPF).

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_IMPACTTOTALPARTFACT  FROBJ TOOBJ NUMMONEL LISTOP(1)..LISTOP(NUMMONEL)
```

Python command syntax:

```
ierr = impacttotalpartfact(froobj, toobj, nummonel, listop)
```

Fortran command syntax:

```
CALL MAPI_IMPTOTPF(FROBJ, TOOBJ, NUMMONEL, LISTOP, IERR)
```

Where:

Character*12 FROBJ	Indicates the impacted system type. Valid entries can be: (input; no default allowed). FROBJ = AREA: Impacted systems listed by area FROBJ = ZONE: Impacted systems listed by zone FROBJ = SYST: Impacted systems listed by subsystem
Character*12 TOOBJ	Indicates the neighboring system type. Valid entries can be: (input; no default allowed). TOOBJ = AREA: Neighboring systems listed by area TOOBJ = ZONE: Neighboring systems listed by zone TOOBJ = SYST: Neighboring systems listed by subsystem
Integer NUMMONEL	(input; no default allowed).
Character*12 LISTOP	Is a set of strings forming a list of impacted systems. There must be as many impacted systems as indicated by NUMMONEL. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Prerequisite requirements for function not met IERR = 2 From Category must be AREAS, ZONES or SYSTEMS IERR = 3 To Category must be AREAS, ZONES or SYSTEMS IERR = 4 List of systems not found or not proper for Selected Category IERR = 5 The number of impacted systems is missing

22.1.144. INCLUDESELECTEDCONTS

Use this function to include the selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_INCLUDESELECTEDCONTS
```

Python command syntax:

```
ierr = includeselectedconts()
```

Fortran command syntax:

```
CALL MAPI_INCSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.145. INTERFACESENSITIVITY

Use this function to generate the monitored elements sensitivities for specified interfaces

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_INTERFACESENSITIVITY NUMMONEL LISTML OPTIONS(1)..OPTIONS(4) REFSYS
  IMPACTCUTOFF EXPSYS IMPSYS NUMTRANS LISTTRANS
```

Python command syntax:

```
ierr = interfacesensitivity(nummonel, listml, options, refsys,
  impactcutoff, expsys, impsys, numtrans, listtrans)
```

Fortran command syntax:

```
CALL MAPI_INSENS(NUMMONEL, LISTML, OPTIONS, REFSYS, IMPACTCUTOFF, EXPSYS,
  IMPSYS, NUMTRANS, LISTTRANS, IERR)
```

Where:

Integer NUMMONEL	How many monitored elements to consider. (input; no default allowed).																												
Character*32 LISTML	Is a set of strings forming a list of interface numbers. There must be as many interfaces as indicated by NUMMONEL. (input; no default allowed).																												
Integer OPTIONS (4)	array of 4 elements specifying calculation options(input). <table> <tr> <td>OPTIONS(1)</td><td>Sensitivity Report to: (1 by default)</td></tr> <tr> <td>OPTIONS(1) = 1</td><td>Reference Subsystem</td></tr> <tr> <td>OPTIONS(1) = 2</td><td>Factors for Impact Cutoff</td></tr> <tr> <td>OPTIONS(1) = 3</td><td>Subsystem Participating Buses</td></tr> <tr> <td>OPTIONS(1) = 4</td><td>Transactions</td></tr> <tr> <td>OPTIONS(2)</td><td>Contingency for impact/sensitivity reports (0 by default)</td></tr> <tr> <td>OPTIONS(2) = 0</td><td>Base Case</td></tr> <tr> <td>OPTIONS(2) = x</td><td>x = Contingency number</td></tr> <tr> <td>OPTIONS(3)</td><td>Reference subsystem config for sensitivity analysis (1 by default)</td></tr> <tr> <td>OPTIONS(3) = 1</td><td>Importing</td></tr> <tr> <td>OPTIONS(3) = 2</td><td>Exporting</td></tr> <tr> <td>OPTIONS(4)</td><td>Transactions to consider (1 by default)</td></tr> <tr> <td>OPTIONS(4) = 1</td><td>All possible transactions</td></tr> <tr> <td>OPTIONS(4) = 2</td><td>Only selected transactions</td></tr> </table>	OPTIONS(1)	Sensitivity Report to: (1 by default)	OPTIONS(1) = 1	Reference Subsystem	OPTIONS(1) = 2	Factors for Impact Cutoff	OPTIONS(1) = 3	Subsystem Participating Buses	OPTIONS(1) = 4	Transactions	OPTIONS(2)	Contingency for impact/sensitivity reports (0 by default)	OPTIONS(2) = 0	Base Case	OPTIONS(2) = x	x = Contingency number	OPTIONS(3)	Reference subsystem config for sensitivity analysis (1 by default)	OPTIONS(3) = 1	Importing	OPTIONS(3) = 2	Exporting	OPTIONS(4)	Transactions to consider (1 by default)	OPTIONS(4) = 1	All possible transactions	OPTIONS(4) = 2	Only selected transactions
OPTIONS(1)	Sensitivity Report to: (1 by default)																												
OPTIONS(1) = 1	Reference Subsystem																												
OPTIONS(1) = 2	Factors for Impact Cutoff																												
OPTIONS(1) = 3	Subsystem Participating Buses																												
OPTIONS(1) = 4	Transactions																												
OPTIONS(2)	Contingency for impact/sensitivity reports (0 by default)																												
OPTIONS(2) = 0	Base Case																												
OPTIONS(2) = x	x = Contingency number																												
OPTIONS(3)	Reference subsystem config for sensitivity analysis (1 by default)																												
OPTIONS(3) = 1	Importing																												
OPTIONS(3) = 2	Exporting																												
OPTIONS(4)	Transactions to consider (1 by default)																												
OPTIONS(4) = 1	All possible transactions																												
OPTIONS(4) = 2	Only selected transactions																												
Character*12 REFSYS	Is a string identifying the Reference Subsystem Name - to be used with Report 1 of OPTION(1). Enter -1 for Swing Bus. (input; blank by default).																												

Real IMPACTCUTOFF	Impact CutOff Value - to be used with Report 2 of OPTION(1) (input; 0 by default).	
Character*12 EXPSYS	Is a string identifying the Exporting Subsystem Name - to be used with Report 3 of OPTION(1) (input; blank by default).	
Character*12 IMPSYS	Is a string identifying the Importing Subsystem Name - to be used with Report 3 of OPTION(1) (input; blank by default).	
Integer NUMTRANS	How many transactions in LISTTRANS - to be used with Report 4 of OPTION(1). (input; no default allowed).	
Character*32 LISTTRANS	Is a set of strings forming a list of subsystem names representing transactions with each transaction being made up of a FROM subsystem and a TO subsystem. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.146. LISTACCONTDETAILS

Use this function to provide an AC contingency details report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTACCONTDETAILS
```

Python command syntax:

```
ierr = listaccontdetails()
```

Fortran command syntax:

```
CALL MAPI_ACCONTDET(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.147. LISTACCONTSUMMARY

Use this function to provide an AC contingency summary report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTACCONTSUMMARY
```

Python command syntax:

```
ierr = listaccontsummary()
```

Fortran command syntax:

```
CALL MAPI_ACCCONTSUM(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.148. LISTAREAS

Use this function for a quick list of all areas.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTAREAS
```

Python command syntax:

```
ierr = listareas()
```

Fortran command syntax:

```
CALL MAPI_AREAS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Error in obtaining list

22.1.149. LISTBUSES

Use this function to a report of the list of buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTBUSES
```

Python command syntax:

```
ierr = listbuses()
```

Fortran command syntax:

```
CALL MAPI_BUSES(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.150. LISTEXCLUDES

Use this function to list the constraints or contingencies to be excluded.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTEXCLUDES
```

Python command syntax:

```
ierr = listexcludes()
```

Fortran command syntax:

```
CALL MAPI_LISTEXCLUDE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.151. LISTGENERATORS

Use this function to a report of the list of generators.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTGENERATORS
```

Python command syntax:

```
ierr = listgenerators()
```

Fortran command syntax:

```
CALL MAPI_GENERS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.152. LISTPHASESHIFTERS

Use this function to a report of the list of phase shifters.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTPHASESHIFTERS
```

Python command syntax:

```
ierr = listphaseshifters()
```

Fortran command syntax:

```
CALL MAPI_PHASESHIFT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.153. LISTSELCONTINGENCIES

Use this function to list the selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTSELCONTINGENCIES
```

Python command syntax:

```
ierr = listselcontingencies()
```

Fortran command syntax:

```
CALL MAPI_LISTSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.154. LISTSELCONTINGENCIES_TBL

Use this function to list the selected contingencies in table format.

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_LISTSELCONTINGENCIES_TBL
```

Python command syntax:

```
ierr = listselcontingencies_tbl()
```

Fortran command syntax:

```
CALL MAPI_LISTSELCONTS_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.155. LISTZONES

Use this function for a quick list of all zones.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LISTZONES
```

Python command syntax:

```
ierr = listzones()
```

Fortran command syntax:

```
CALL MAPI_ZONES(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.156. LIST_BFLOW

Use this function for a quick report of base case flows.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_BFLOW
```

Python command syntax:

```
ierr = list_bflow()
```

Fortran command syntax:

```
CALL MAPI_BFLOW(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.157. LIST_BIMPACT

Use this function for a quick report of base case impact on selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_BIMPACT
```

Python command syntax:

```
ierr = list_bimpact()
```

Fortran command syntax:

```
CALL MAPI_BIMPACT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined

22.1.158. LIST_CFLOW

Use this function for a quick report of contingency flows for selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_CFLOW
```

Python command syntax:

```
ierr = list_cflow()
```

Fortran command syntax:

```
CALL MAPI_CFLOW(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.159. LIST_CIMPACT

Use this function for a quick report of study transfer impact on selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_CIMPACT
```

Python command syntax:

```
ierr = list_cimpact()
```

Fortran command syntax:

```
CALL MAPI_CIMPACT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Study Transfer is not defined

22.1.160. LIST_CONTINS

Use this function for a quick list of all defined contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_CONTINS
```

Python command syntax:

```
ierr = list_contins()
```

Fortran command syntax:

```
CALL MAPI_LISTCONTINS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.161. LIST_CONTINS_WISL

Use this function for a quick list of all contingencies with island.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_CONTINS_WISL
```

Python command syntax:

```
ierr = list_contins_wisl()
```

Fortran command syntax:

```
CALL MAPI_LISTCONTINS_WISL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.162. LIST_LODF

Use this function for a quick report of LODF factors.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_LODF
```

Python command syntax:

```
ierr = list_lodf()
```

Fortran command syntax:

```
CALL MAPI_LODF(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.163. LIST_LODF_WISL

Use this function for a quick report of LODF factors with island.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_LODF_WISL
```

Python command syntax:

```
ierr = list_lodf_wisl()
```

Fortran command syntax:

```
CALL MAPI_LODF_WISL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.164. LIST_MONELS

Use this function for a quick list of all monitored elements.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_MONELS
```

Python command syntax:

```
ierr = list_monels()
```

Fortran command syntax:

```
CALL MAPI_LISTMONELS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.165. LIST_PTDF

Use this function for a quick report of PTDF/TDF reference bus factors on monitored elements.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_PTDF
```

Python command syntax:

```
ierr = list_ptdf()
```

Fortran command syntax:

```
CALL MAPI_PTDF(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.166. LIST_PTDFC

Use this function for a quick report of ALL reference bus factors on contingency branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_PTDFC
```

Python command syntax:

```
ierr = list_ptdfc()
```

Fortran command syntax:

```
CALL MAPI_PTDFC(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.167. LIST_SYSTEMS

Use this function for a quick list of all subsystems.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_LIST_SYSTEMS
```

Python command syntax:

```
ierr = list_systems()
```

Fortran command syntax:

```
CALL MAPI_LISTSYSTEMS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.168. MDETAILBRANCHES

Use this function to generate a detailed report by monitored branches.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MDETAILBRANCHES
```

Python command syntax:

```
ierr = mdetailbranches()
```

Fortran command syntax:

```
CALL MAPI_CNMDetailBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	No branches selected

22.1.169. MDETAILINTERFACES

Use this function to generate a detailed report by monitored interfaces.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MDETAILINTERFACES
```

Python command syntax:

```
ierr = mdetailinterfaces()
```

Fortran command syntax:

```
CALL MAPI_CNMDetailINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.170. MDETAILVOLTAGEBUSES

Use this function to generate a detailed report by monitored voltage buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MDETAILVOLTAGEBUSES
```

Python command syntax:

```
ierr = mdetailvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_CNMDetailVOLT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.171. MODIFYDISPATCH

Use this function to modify the dispatch study transaction.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MODIFYDISPATCH TRPOW
```

Python command syntax:

```
ierr = modifydispatch(trpow)
```

Fortran command syntax:

```
CALL MAPI_TRANDISP(TRPOW, IERR)
```

Where:

Real TRPOW	(input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Study Transfer is not defined
	IERR = 3 Transfer Level out of range (0 - 999,999)
	IERR = 4 The transfer level is missing.

22.1.172. MONELIMPACT

Use this function to generate a monitored elements impact analysis report

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_MONELIMPACT SYS1 SYS2 TRANSFER MONELS OPTIONS(1)..OPTIONS(6)
LOADCUTOFF IMPACTCUTOFF
```

Python command syntax:

```
ierr = monelimpact(sys1, sys2, transfer, monels, options, loadcutoff,
impactcutoff)
```

Fortran command syntax:

```
CALL MAPI_MONELIMPACT(SYS1, SYS2, TRANSFER, MONELS, OPTIONS, LOADCUTOFF,
IMPACTCUTOFF, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).
Integer MONELS	Monitored elements for report (input; no default allowed). '1' Branches '2' Interfaces '3' Flowgates
Integer OPTIONS (6)	array of 6 elements specifying calculation options(input). OPTIONS(1) OTDF Sensitivity: (0 by default) OPTIONS(1) = 0 no OPTIONS(1) = 1 yes OPTIONS(2) Report order: (1 by default) OPTIONS(2) = 1 bus order OPTIONS(2) = 2 by loading OPTIONS(2) = 3 by impact reponse OPTIONS(3) Apply Loading CutOff: (0 by default) OPTIONS(3) = 0 no OPTIONS(3) = 1 yes OPTIONS(4) Apply Impact CutOff: (0 by default) OPTIONS(4) = 0 no OPTIONS(4) = 1 yes OPTIONS(5) Report Transfer Limits (0 by default)

	OPTIONS(5) = 0	no
	OPTIONS(5) = 1	yes
	OPTIONS(6)	Contingency for impact/sensitivity reports (0 by default)
	OPTIONS(6) = 0	Base Case
	OPTIONS(6) = x	x = Contingency number
Real LOADCUTOFF	Loading Cutoff for reporting violations; Ignored if OPTION(3) = 0 (input; no default allowed).	
Real IMPACTCUTOFF	Impact CutOff Value; Ignored if OPTION(4) = 0 (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Entry is missing or invalid

22.1.173. MONSENSALLSUBBRANCHES

Use this function to report on the subsystem branch factors for the selected branches.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSALLSUBBRA SUBS
```

Python command syntax:

```
ierr = monsensallsubbranches(subs)
```

Fortran command syntax:

```
CALL MAPI_MONSENSALLSUBBRA(SUBS, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the Subsystem Name for which to report the branch factors. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	The Subsystem Name is missing.

22.1.174. MONSENSALLSUBFLOWGATES

Use this function to report on the subsystem branch factors for the selected flowgates.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSALLSUBFG SUBS
```

Python command syntax:

```
ierr = monsensallsubflowgates(subs)
```

Fortran command syntax:

```
CALL MAPI_MONSENSALLSUBFG(SUBS, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the Subsystem Name for which to report the flowgate factors. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	The Subsystem Name is missing.

22.1.175. MONSENSALLSUBINTERFACES

Use this function to report on the subsystem branch factors for the selected interfaces.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSALLSUBINTER SUBS
```

Python command syntax:

```
ierr = monsensallsubinterfaces(subs)
```

Fortran command syntax:

```
CALL MAPI_MONSENSALLSUBINT(SUBS, IERR)
```

Where:

Character*12 SUBS	Is a string identifying the Subsystem Name for which to report the interface factors. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	The Subsystem Name is missing.

22.1.176. MONSENSALLTRANBRANCHES

Use this function to display the transactions impact on ALL branches.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSALLTRANBRANCHES
```

Python command syntax:

```
ierr = monsensalltranbranches()
```

Fortran command syntax:

```
CALL MAPI_MONSENSALLTRANBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.177. MONSENSALLTRANFLOWGATES

Use this function to display the transactions impact on ALL flowgates.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSALLTRANFLOWGATES
```

Python command syntax:

```
ierr = monsensalltranflowgates()
```

Fortran command syntax:

```
CALL MAPI_MONSENSALLTRANFG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.178. MONSENSALLTRANINTERFACES

Use this function to display the transactions impact on ALL interfaces.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSALLTRANINTERFACES
```

Python command syntax:

```
ierr = monsensalltraninterfaces()
```

Fortran command syntax:

```
CALL MAPI_MONSENSALLTRANINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.179. MONSENSSINGLESUBBRANCHES

Use this function to display the subsystem sensitivities for the first selected branch.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSSINGLESUBBRA
```

Python command syntax:

```
ierr = monsenssinglesubbranches()
```

Fortran command syntax:

```
CALL MAPI_MONSENSSINGLESUBBRA(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.180. MONSENSSINGLESUBFLOWGATES

Use this function to display the subsystem sensitivities for the first selected flowgate.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSSINGLESUBFG
```

Python command syntax:

```
ierr = monsenssinglesubflowgates()
```

Fortran command syntax:

```
CALL MAPI_MONSENSSINGLESUBFG(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.181. MONSENSSINGLESUBINTERFACES

Use this function to display the subsystem sensitivities for the first selected interface.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSSINGLESUBINTER
```

Python command syntax:

```
ierr = monsenssinglesubinterfaces()
```

Fortran command syntax:

```
CALL MAPI_MONSENSSINGLESUBINT(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.182. MONSENSSUBSPARTBRANCHES

Use this function to generate a sensitivity analysis for study transfer on the selected branches.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSSUBSPARTBRANCHES  SUBSFR SUBSIN
```

Python command syntax:

```
ierr = monsenssubpartbranches(subsfr, subsin)
```

Fortran command syntax:

```
CALL MAPI_MONSENSSUBSPARTBRA(SUBSFR, SUBSIN, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying FROM Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying TO Subsystem Name to be used in the study transfer. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	FROM SubSystem same as TO SubSystem
	IERR = 4	The FROM Subsystem Name is missing.
	IERR = 5	The TO Subsystem Name is missing.

22.1.183. MONSENSSUBSPARTFLOWGATES

Use this function to generate a sensitivity analysis for study transfer on the selected flowgates.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSSUBSPARTFLOWGATES  SUBSFR SUBSIN
```

Python command syntax:

```
ierr = monsenssubpartflowgates(subsfr, subsin)
```

Fortran command syntax:

```
CALL MAPI_MONSENSSUBSPARTFG(SUBSFR, SUBSIN, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying FROM Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying TO Subsystem Name to be used in the study transfer. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	FROM SubSystem same as TO SubSystem
	IERR = 4	The FROM Subsystem Name is missing.
	IERR = 5	The TO Subsystem Name is missing.

22.1.184. MONSENSSUBSPARTINTERFACES

Use this function to generate a sensitivity analysis for study transfer on the selected interfaces.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSSUBSPARTINTERFACES  SUBSFR SUBSIN
```

Python command syntax:

```
ierr = monsenssubpartinterfaces(subsfr, subsin)
```

Fortran command syntax:

```
CALL MAPI_MONSENSSUBSPARTINT(SUBSFR, SUBSIN, IERR)
```

Where:

Character*12 SUBSFR	Is a string identifying FROM Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SUBSIN	Is a string identifying TO Subsystem Name to be used in the study transfer. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid SubSystem Selected
	IERR = 3	FROM SubSystem same as TO SubSystem
	IERR = 4	The FROM Subsystem Name is missing.
	IERR = 5	The TO Subsystem Name is missing.

22.1.185. MONSENSTRANBRANCHES

Use this function to display the transactions impact on the selected branches.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSTRANBRANCHES  NUMTRANS LISTTR(1)..LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = monsenstranbranches(numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_MONSENSTRANBRA(NUMTRANS, LISTTR, IERR)
```

Where:

Integer NUMTRANS	Is the number of transactions (input; no default allowed).	
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of transactions is missing.
	IERR = 3	One transaction label is missing.

22.1.186. MONSENSTRANFLOWGATES

Use this function to display the transactions impact on the selected flowgates.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSTRANFLOWGATES  NUMTRANS LISTTR(1)..LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = monsenstranflowgates(numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_MONSENSTRANFG(NUMTRANS, LISTTR, IERR)
```

Where:

Integer NUMTRANS	Is the number of transactions to be included in LISTTR (input; no default allowed).	
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of transactions is missing.
	IERR = 3	One transaction label is missing.

22.1.187. MONSENSTRANINTERFACES

Use this function to display the transactions impact on the selected interfaces.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MONSENSTRANINTERFACES  NUMTRANS LISTTR(1)..LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = monsenstraninterfaces(numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_MONSENSTRANINT(NUMTRANS, LISTTR, IERR)
```

Where:

Integer NUMTRANS	(input; no default allowed).
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 The number of transactions is missing.
	IERR = 3 One transaction label is missing.

22.1.188. MULTACFCITC

Use this function to calculation the effects of a series of AC FCITC Transfers

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MULTACFCITC NUMTRANS LISTTRANS OPTIONS(1)..OPTIONS(5) ACTOLN
```

Python command syntax:

```
ierr = multacfcitc(numtrans, listtrans, options, actoln)
```

Fortran command syntax:

```
CALL MAPI_MULTACFCITC(NUMTRANS, LISTTRANS, OPTIONS, ACTOLN, IERR)
```

Where:

Integer NUMTRANS	(input; no default allowed).																														
Character*32 LISTTRANS	(input; no default allowed).																														
Integer OPTIONS (5)	array of 5 elements specifying calculation options(input). <table> <tr> <td>OPTIONS(1)</td><td>FCITC report format (2 by default)</td></tr> <tr> <td>OPTIONS(1) = 1</td><td>Standard Report</td></tr> <tr> <td>OPTIONS(1) = 2</td><td>Wide Report (Spreadsheet format)</td></tr> <tr> <td>OPTIONS(2)</td><td>Maximum number violations to verify using AC (5 by default)</td></tr> <tr> <td>OPTIONS(2) > n</td><td>Number of DC violations to consider</td></tr> <tr> <td>OPTIONS(3)</td><td>Apply non-divergent LF (0 by default)</td></tr> <tr> <td>OPTIONS(3) = 0</td><td>never</td></tr> <tr> <td>OPTIONS(3) = 1</td><td>always</td></tr> <tr> <td>OPTIONS(3) = 2</td><td>only if regular diverged</td></tr> <tr> <td>OPTIONS(4)</td><td>AC LF method (0 by default)</td></tr> <tr> <td>OPTIONS(4) = 1</td><td>Newton</td></tr> <tr> <td>OPTIONS(4) = 2</td><td>Decoupled</td></tr> <tr> <td>OPTIONS(5)</td><td>Report removed violations with FCITC report (0 by default)</td></tr> <tr> <td>OPTIONS(5) = 0</td><td>no</td></tr> <tr> <td>OPTIONS(5) = 1</td><td>yes</td></tr> </table>	OPTIONS(1)	FCITC report format (2 by default)	OPTIONS(1) = 1	Standard Report	OPTIONS(1) = 2	Wide Report (Spreadsheet format)	OPTIONS(2)	Maximum number violations to verify using AC (5 by default)	OPTIONS(2) > n	Number of DC violations to consider	OPTIONS(3)	Apply non-divergent LF (0 by default)	OPTIONS(3) = 0	never	OPTIONS(3) = 1	always	OPTIONS(3) = 2	only if regular diverged	OPTIONS(4)	AC LF method (0 by default)	OPTIONS(4) = 1	Newton	OPTIONS(4) = 2	Decoupled	OPTIONS(5)	Report removed violations with FCITC report (0 by default)	OPTIONS(5) = 0	no	OPTIONS(5) = 1	yes
OPTIONS(1)	FCITC report format (2 by default)																														
OPTIONS(1) = 1	Standard Report																														
OPTIONS(1) = 2	Wide Report (Spreadsheet format)																														
OPTIONS(2)	Maximum number violations to verify using AC (5 by default)																														
OPTIONS(2) > n	Number of DC violations to consider																														
OPTIONS(3)	Apply non-divergent LF (0 by default)																														
OPTIONS(3) = 0	never																														
OPTIONS(3) = 1	always																														
OPTIONS(3) = 2	only if regular diverged																														
OPTIONS(4)	AC LF method (0 by default)																														
OPTIONS(4) = 1	Newton																														
OPTIONS(4) = 2	Decoupled																														
OPTIONS(5)	Report removed violations with FCITC report (0 by default)																														
OPTIONS(5) = 0	no																														
OPTIONS(5) = 1	yes																														
Real ACTOLN (1)	array of 1 elements specifying Tolerance to check study transfer (MW)(input). <table> <tr> <td>ACTOLN(1)</td><td>AC load flow tolerance level(MW) (10.0 by default)</td></tr> </table>	ACTOLN(1)	AC load flow tolerance level(MW) (10.0 by default)																												
ACTOLN(1)	AC load flow tolerance level(MW) (10.0 by default)																														
Integer IERR	error code (output). <table> <tr> <td>IERR = 0</td><td>No error</td></tr> <tr> <td>IERR = 1</td><td>Prerequisite requirements for function not met</td></tr> </table>	IERR = 0	No error	IERR = 1	Prerequisite requirements for function not met																										
IERR = 0	No error																														
IERR = 1	Prerequisite requirements for function not met																														

IERR = 2

Option is missing or invalid

22.1.189. MULTDCFCITC

Use this function to calculation the effects of a series of Linear FCITC Transfers

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_MULTDCFCITC  NUMTRANS LISTTRANS OPTIONS(1)..OPTIONS(4)
```

Python command syntax:

```
ierr = multdcfcitc(numtrans, listtrans, options)
```

Fortran command syntax:

```
CALL MAPI_MULTDCFCITC(NUMTRANS, LISTTRANS, OPTIONS, IERR)
```

Where:

Integer NUMTRANS	(input; no default allowed).
Character*32 LISTTRANS	(input; no default allowed).
Integer OPTIONS (4)	array of 4 elements specifying calculation options(input).
	OPTIONS(1) FCITC report format (2 by default)
	OPTIONS(1) = 1 2 Line report
	OPTIONS(1) = 2 Wide Report (Spreadsheet format)
	OPTIONS(1) = 3 TLTG Report
	OPTIONS(1) = 4 Wide Report (Old format)
	OPTIONS(2) Maximum violations to display (5 by default)
	OPTIONS(2) > n Number of violations to present on report
	OPTIONS(3) Add separate report for basecase (0 by default)
	OPTIONS(3) = 0 no
	OPTIONS(3) = 1 yes
	OPTIONS(4) Report removed violations with FCITC report (0 by default)
	OPTIONS(4) = 0 no
	OPTIONS(4) = 1 yes
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Option is missing or invalid

22.1.190. MULTIPLEPARALLELTRANSFERS

Use this function to display the impact of a selected set of parallel transfers on one study transfer FCITC.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MULTIPLEPARALLELTRANSFERS SYS1 SYS2 TRANSFER MAXTRANLV TRSTEP NUMTRANS
LISTTR(1) .. LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = multipleparalleltransfers(sys1, sys2, transfer, maxtranlv, trstep,
numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_MULTIPARAL(SYS1, SYS2, TRANSFER, MAXTRANLV, TRSTEP, NUMTRANS,
LISTTR, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).
Real MAXTRANLV	Is the maximum power transfer to be considered in this study (input; no default allowed).
Real TRSTEP	Is the increment of power transfer for each step in this study (input; no default allowed).
Integer NUMTRANS	How many transactions to consider. (input; no default allowed).
Character*32 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Study Transfer not defined
	IERR = 3 Max Power Transfer outside of limits
	IERR = 4 Illegal Transfer Step
	IERR = 5 No Subsystems Selected
	IERR = 6 Specified Subsystem not found
	IERR = 7 The maximum power transfer is missing.
	IERR = 8 The increment of power transfer is missing.

IERR = 9
IERR = 10

The number of subsystems is missing.
One label is missing.

22.1.191. MULTIPLESTUDYTRANSFERS

Use this function to display the impact of one additional transaction on a whole group of study transfers.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MULTIPLESTUDYTRANSFERS SYS1 SYS2 TRANSFER MAXTRANLV TRSTEP NUMTRANS
LISTTR(1) .. LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = multiplestudytransfers(sys1, sys2, transfer, maxtranlv, trstep,
numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_MULTISTUDY(SYS1, SYS2, TRANSFER, MAXTRANLV, TRSTEP, NUMTRANS,
LISTTR, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).
Real MAXTRANLV	Is the maximum power transfer to be considered in this study (input; no default allowed).
Real TRSTEP	Is the increment of power transfer for each step in this study (input; no default allowed).
Integer NUMTRANS	How many transactions to consider. (input; no default allowed).
Character*32 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Study Transfer not defined
	IERR = 3 Max Power Transfer outside of limits
	IERR = 4 Illegal Transfer Step
	IERR = 5 No Subsystems Selected
	IERR = 6 Specified Subsystem not found
	IERR = 7 The maximum power transfer is missing.
	IERR = 8 The increment of power transfer is missing.

IERR = 9
IERR = 10

The number of subsystems is missing.
One label is missing.

22.1.192. MUSTOPTDEFS

Use this function to enter a set of default MUST Options for later use in Transfer Analysis calculations

This API routine was first introduced in release 35.3.0.

Batch command syntax:

```
BAT_MUSTOPTDEFS  OPTIONS(1)..OPTIONS(6)  VALUES(1)..VALUES(4)
```

Python command syntax:

```
ierr = mustoptdefs(options, values)
```

Fortran command syntax:

```
CALL MAPI_MUSTOPTDEFS(OPTIONS, VALUES, IERR)
```

Where:

Integer OPTIONS (6)	array of 6 elements specifying calculation options(input).
OPTIONS(1)	Phase shifter code (0 by default)
OPTIONS(1) = 0	fixed
OPTIONS(1) = 1	const.flow base case
OPTIONS(1) = 2	const.flow in contingency
OPTIONS(2)	ignore base case constraints in FCITC reports (1 by default)
OPTIONS(2) = 0	exclude
OPTIONS(2) = 1	include
OPTIONS(3)	Max. number of violations to report in FCITC and Gen.Sens. Tables (50000 by default)
OPTIONS(3) > n	violations
OPTIONS(4)	Summary table maximum times to report the same element (3 by default)
OPTIONS(4) = n	Limited
OPTIONS(4) = 100	Unlimited
OPTIONS(5)	Apply Min.Distr.Factor CutOff for contingency analysis (0 by default)
OPTIONS(5) = 0	no
OPTIONS(5) = 1	yes
OPTIONS(6)	Apply minimum distr. factor to FCITC solution reports (0 by default)
OPTIONS(6) = 0	no
OPTIONS(6) = 1	yes
Real VALUES (4)	array of 4 elements specifying reporting parameters(input).
VALUES(1)	Default minimum distribution factor magnitude cutoff (PTDF and OTDF) (0.02 by default)

	VALUES(2)	Minimum contingency case (pre and post) flow change (0.0 by default)
	VALUES(3)	Minimum contingency case distribution factor change (0.0 by default)
	VALUES(4)	Minimum distribution factor for transfer sensitivity analysis (0.0 by default)
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer option value is missing
	IERR = 3	Float option value is missing

22.1.193. MUSTSTART

Use this function to startup pss must module from within the Python environment. This function will allocate memory and initialize the pss must module environment for further commands.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MUSTSTART
```

Python command syntax:

```
ierr = muststart()
```

Fortran command syntax:

```
CALL MAPI_INITMUST(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Failed to start pss must module

22.1.194. MUSTSTOP

Use this function to shutdown pss must module from within the Python environment.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_MUSTSTOP
```

Python command syntax:

```
ierr = muststop()
```

Fortran command syntax:

```
CALL MAPI_SHUTDOWNMUST(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.195. PARALLELDETAILTRANSFER

Use this function to generate a detailed report on FCITC adjustments for the selected transfer.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PARALLELDETAILTRANSFER  MAXPOWTR SYSFROM SYSTO REPTYP
```

Python command syntax:

```
ierr = paralleldetailtransfer(maxpowtr, sysfrom, systo, reptyp)
```

Fortran command syntax:

```
CALL MAPI_TSEDET(MAXPOWTR, SYSFROM, SYSTO, REPTYP, IERR)
```

Where:

Real MAXPOWTR	Is the maximum power transfer to be considered in this study (input; no default allowed).
Character*19 SYSFROM	Is the subsystem from which a power transfer parallel to the current study transfer is to be considered (input; no default allowed).
Character*19 SYSTO	Is the subsystem to which a power transfer parallel to the current study transfer is to be considered (input; no default allowed).
Character*19 REPTYP	Is a set of strings forming a list of subsystems. There must be as many subsystems as indicated by NUMTRANS. (input; no default allowed).
	REPTYP = "SUMMARY" : Provide a summary report
	REPTYP = "DETAIL" : Provide a detailed report
	REPTYP = "BOTH" : Provide both a summary report and a detailed report
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Study Transfer not defined
	IERR = 3 Specified Subsystem not found
	IERR = 4 Specified Report Type not found
	IERR = 5 The maximum power transfer is missing.

22.1.196. PARALLELCITCSUMMARY

Use this function to generate a summary on FCITC adjustments for several Parallel transfers.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PARALLELCITCSUMMARY  MAXPOWTR TRSTEP NUMTRANS
    LISTTR(1) .. LISTTR(NUMTRANS)
```

Python command syntax:

```
ierr = parallelcitcsummary(maxpowtr, trstep, numtrans, listtr)
```

Fortran command syntax:

```
CALL MAPI_TSENSUM(MAXPOWTR, TRSTEP, NUMTRANS, LISTTR, IERR)
```

Where:

Real MAXPOWTR	Is the maximum power transfer to be considered in this study (input; no default allowed).
Real TRSTEP	Is the increment of power transfer for each step in this study (input; no default allowed).
Integer NUMTRANS	(input; no default allowed).
Character*19 LISTTR	Is a set of strings forming a list of transactions. Each transaction consists of a FROM Subsystem Name followed by a TO Subsystem Name. There must be as many sets of FROM and TO subsystem names as indicated by NUMTRANS. (input; no default allowed).
Integer IERR	error code (output).
IERR = 0	No error
IERR = 1	Prerequisite requirements for function not met
IERR = 2	Study Transfer not defined
IERR = 3	Max Power Transfer outside of limits
IERR = 4	Illegal Transfer Step
IERR = 5	No Subsystems Selected
IERR = 6	Specified Subsystem not found
IERR = 7	The maximum power transfer is missing.
IERR = 8	The increment of power transfer is missing.
IERR = 9	The number of subsystems is missing.
IERR = 10	One label is missing.

22.1.197. PRINTRPT

Use this function to display a report as specified below.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PRINTRPT  MARG
```

Python command syntax:

```
ierr = printrpt(marg)
```

Fortran command syntax:

```
CALL MAPI_PRINTRPT(MARG, IERR)
```

Where:

Character*20 MARG	(input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Invalid Menu Selected - No changes made

22.1.198. PSCASE

Use this function to enter a PSSE SAV case file into pss must module.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_PSCASE  DFLAG CSFILE
```

Python command syntax:

```
ierr = pscase(dflag, csfile)
```

Fortran command syntax:

```
CALL MAPI_READSAVCASE(DFLAG, CSFILE, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Character*260 CSFILE	Is a string identifying the full pathname of the PSSE case file (.sav) to be read. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	sav file missing, invalid name or no access
	IERR = 3	No buses found

22.1.199. RDEXCHGFILE

Use this function to enter a file listing the constraints or contingencies to be excluded.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_RDEXCHGFILE DFLAG EXFILE
```

Python command syntax:

```
ierr = rdexchgfile(dflag, exfile)
```

Fortran command syntax:

```
CALL MAPI_READEXCCHGFILE(DFLAG, EXFILE, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Character*260 EXFILE	Is a string identifying the full pathname of the excluded monitored elements file (.exc) to be read. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Exclude file missing, invalid name or no access
	IERR = 3	Error reading exclude/change file
	IERR = 4	Memory allocation error. Out of memory
	IERR = 5	Exclude element(s) not recognized

22.1.200. RDMONCONFILE

Use this function to enter both a monitored elements file and a contingency description file. You must enter a name for both files.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_RDMONCONFILE DFLAG MNFILE CNFILE
```

Python command syntax:

```
ierr = rdmonconfile(dflag, mnfile, cnfile)
```

Fortran command syntax:

```
CALL MAPI_READMONCONFILE(DFLAG, MNFILE, CNFILE, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Character*260 MNFILE	Is a string identifying the full pathname of the monitored elements file (.mon) to be read. (input; no default allowed).	
Character*260 CNFILE	Is a string identifying the full pathname of the contingency description file (.con) to be read. (input; no default allowed).	
Integer IERR	Is the error code (output) (output).	
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Monitor file missing, invalid name or no access
	IERR = 3	Contingency file missing, invalid name or no access
	IERR = 4	Error reading Monitor/Contingency file
	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Monitor file missing, invalid name or no access
	IERR = 3	Contingency file missing, invalid name or no access
	IERR = 4	No buses
	IERR = 5	Setup Error

22.1.201. RDMUSTFILES

Use this function to enter a subsystems definition file, a monitored elements file and a contingency description file. You must enter a name for all three files.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_RDMUSTFILES  SBFILE MNFILE CNFILE
```

Python command syntax:

```
ierr = rdmustfiles(sbfile, mnfile, cnfile)
```

Fortran command syntax:

```
CALL MAPI_READMUSTFILES(SBFILE, MNFILE, CNFILE, IERR)
```

Where:

Character*260 SBFILE	Is a string identifying the full pathname of the subsystems definition file (.sub) to be read. (input; no default allowed).	
Character*260 MNFILE	Is a string identifying the full pathname of the monitored elements file (.mon) to be read. (input; no default allowed).	
Character*260 CNFILE	Is a string identifying the full pathname of the contingency description file (.con) to be read. (input; no default allowed).	
Integer IERR	Is the error code (output) (output).	
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem file missing, invalid name or no access
	IERR = 3	Monitor file missing, invalid name or no access
	IERR = 4	Contingency file missing, invalid name or no access
	IERR = 5	Error reading SubSystem/Monitor/Contingency file
	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem file missing, invalid name or no access
	IERR = 3	Monitor file missing, invalid name or no access
	IERR = 4	Contingency file missing, invalid name or no access
	IERR = 5	Error reading Subsystem/Monitor/Contingency file

IERR = 6

Setup Error

22.1.202. RDSUBFILE

Use this function to enter a subsystem definition file.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_RDSUBFILE  DFLAG SBFILE
```

Python command syntax:

```
ierr = rdsbfile(dflag, sbfile)
```

Fortran command syntax:

```
CALL MAPI_READSUBSYS(DFLAG, SBFILE, IERR)
```

Where:

Integer DFLAG	This argument is not used and kept only for backward compatibility. (input).	
Character*260 SBFILE	Is a string identifying the full pathname of the subsystem definition file (.sub) to be read. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsys file missing, invalid name or no access
	IERR = 3	No subsystems found

22.1.203. READACCONTFIL

Use this function to read an AC contingency analysis results file into the ACCONT activity.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_READACCONTFIL  FNAME
```

Python command syntax:

```
ierr = readaccontfile(fname)
```

Fortran command syntax:

```
CALL MAPI_ACCONTREAD(FNAME, IERR)
```

Where:

Character*260 FNAME	Is a string identifying the full pathname of the AC contingency analysis results file (.acc) to be read. (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The full pathname of the AC contingency analysis results file is missing.

22.1.204. READRAWDATA

Use this function to enter a PSSE RAW case file.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_READRAWDATA  NUMNAM  WRFIL
```

Python command syntax:

```
ierr = readrawdata(numnam, wrfile)
```

Fortran command syntax:

```
CALL MAPI_READRAWDATA(NUMNAM, WRFIL, IERR)
```

Where:

Integer NUMNAM	Set NUMNAM to read BUSES by NUMBER or NAME (input; no default allowed).
	NUMNAM = 0 read BUSES by NUMBER
	NUMNAM = 1 read BUSES by NAME
Character*260 WRFIL	Is a string identifying the full pathname of the RAW case file (.raw) to be read. (input; no default allowed).
Integer IERR	error code (output).
	IERR = 0 No error
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Request to read by Numbers but MUST options set to read by Names
	IERR = 3 Request to read by Names but MUST options set to read by Numbers
	IERR = 4 The option to read BUSES is missing.
	IERR = 5 The full pathname of the RAW case file is missing.

22.1.205. REAREABUS

Use this function to change the area assigned to a bus.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_REAREABUS BUSNO AREANO
```

Python command syntax:

```
ierr = reareabus(busno, areano)
```

Fortran command syntax:

```
CALL MAPI_REAREA(BUSNO, AREANO, IERR)
```

Where:

Integer BUSNO	Number of bus to be reassigned (input; no default allowed).	
Integer AREANO	Area number to which bus is to be reassigned (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Bus not found
	IERR = 3	Area not found

22.1.206. REMOVEEXCLUDES

Use this function to remove all excluded constraints and contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_REMOVEEXCLUDES
```

Python command syntax:

```
ierr = removeexcludes()
```

Fortran command syntax:

```
CALL MAPI_REMOVEEXCLUDE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.207. REZONEBUS

Use this function to change the zone assigned to a bus.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_REZONEBUS  BUSNO ZONENO
```

Python command syntax:

```
ierr = rezonebus(busno, zoneno)
```

Fortran command syntax:

```
CALL MAPI_REZONE(BUSNO, ZONENO, IERR)
```

Where:

Integer BUSNO	Number of bus to be reassigned (input; no default allowed).	
Integer ZONENO	Zone number to which bus is to be reassigned (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Bus not found
	IERR = 3	Zone not found

22.1.208. SAVEACCONTFILE

Use this function to save the AC contingency analysis results to a file from the ACCONT activity.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SAVEACCONTFILE  FNAME
```

Python command syntax:

```
ierr = saveaccountfile(fname)
```

Fortran command syntax:

```
CALL MAPI_ACCONTSAVE(FNAME, IERR)
```

Where:

Character*260 FNAME	Is a string identifying the full pathname of the file (.acc) to which the AC contingency analysis will be saved. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	the full pathname of the AC contingency analysis results file is missing

22.1.209. SAVEFLOWGATES

Use this function to generate a list of flowgates in a format which can be read back into MUST.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SAVEFLOWGATES
```

Python command syntax:

```
ierr = saveflowgates()
```

Fortran command syntax:

```
CALL MAPI_SAVEFGATES(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.210. SAVESELECTEDCONTS

Use this function to display the selected contingencies formatted for inclusion in a contingency definition file.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SAVESELECTEDCONTS
```

Python command syntax:

```
ierr = saveselectedconts()
```

Fortran command syntax:

```
CALL MAPI_SAVSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.211. SAVESUBSYSTEMS

Use this function to generate a list of participating subsystems in a format which can be read back into MUST.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SAVESUBSYSTEMS
```

Python command syntax:

```
ierr = savesubsystems()
```

Fortran command syntax:

```
CALL MAPI_SAVSUBS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.212. SAVEXCHGFILE

Use this function to list all excluded constraints and contingencies in a form suitable for capturing to a file.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SAVEXCHGFILE
```

Python command syntax:

```
ierr = savexchgfile()
```

Fortran command syntax:

```
CALL MAPI_SAVEXCCHGFILE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.213. SCEDANALYSIS

Use this function to determine a generation pattern to minimize generation cost or remove branch over-heating.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SCEDANALYSIS SMODE MERIT SECUR MONIT RELAX RATIN CRATN XPCNT RCONT
  RPREV SCUTF SECMAR GENER LOAD PSHIFT DCLINE TOTAREA FNAME RNAME PNAME
```

Python command syntax:

```
ierr = scedanalysis(smode, merit, secur, monit, relax, ratin, cratn,
  xpcnt, rcont, rprev, scutf, secmar, gener, load, pshift, dcline, totarea,
  fname, rname, pname, ierr)
```

Fortran command syntax:

```
CALL MAPI_SCEDAPI(SMODE, MERIT, SECUR, MONIT, RELAX, RATIN, CRATN, XPCNT,
  RCONT, RPREV, SCUTF, SECMAR, GENER, LOAD, PSHIFT, DCLINE, TOTAREA, FNAME,
  RNAME, PNAME, IERR)
```

Where:

Integer SMODE	Enter 0 for SCED Analysis or 1 for SCBD Analysis (input; no default allowed).
Integer MERIT	Enter 1 (yes) to include Merit Order or 0 (No) to ignore (input; no default allowed).
Integer SECUR	Enter 1 (yes) to include Security Constraints or 0 (No) to ignore (input; no default allowed).
Integer MONIT	Enter desired Security Check: -1 to ignore; 0 for All Branches; 1 for Monitored Branches Only (input; no default allowed).
Integer RELAX	Is the Relaxation input option. (input; no default allowed).
Integer RATIN	Enter Branch Violations Rating for base case (1-12) (input; no default allowed).
Integer CRATN	The option for Run Correct (input; no default allowed).
Integer XPCNT	Is the option for Run Load shedding. (input; no default allowed).
Integer RCONT	Enter Branch Violations Rating for contingency case (1-12) (input; no default allowed).
Integer RPREV	Is the option for Run Preventive case. (input; no default allowed).
Real SCUTF	Is the option for Sensitivity Cutoff. (input; no default allowed).
Real SECMAR	Is the Security Margin percentage(0-25) (input; no default allowed).
Integer GENER	Is the MW Controls for Generation. (input; no default allowed).
Integer LOAD	Is the MW Controls for Load. (input; no default allowed).
Integer PSHIFT	Is the MW Controls for Phase Shifter. (input; no default allowed).
Integer DCLINE	Is the MW Controls for DC Lines. (input; no default allowed).

Integer TOTAREA	Is the option for Total Area Generation Persistence. (input; no default allowed).	
Character*260 FNAME	Is the full pathname of the ECDI File is missing. (input; no default allowed).	
Character*260 RNAME	Is the full pathname of the BASE Result File is missing. (input).	
Character*260 PNAME	Is the full pathname of the Preventive case Result File. (input).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	SCED input option out of range (limited to 0 or 1)
	IERR = 3	Merit order input option out of range (limited to 0 or 1)
	IERR = 4	Constraint option input out of range (limited to 0 or 1)
	IERR = 5	Monitor Branch input option out of range (limited to 0 or 1)
	IERR = 6	Relaxation input option out of range (limited to 0 or 1)
	IERR = 7	Base rating input option out of range (limited to 1 through 12)
	IERR = 8	Run correction input option out of range (limited to 0 or 1)
	IERR = 9	Run load shedding input option out of range (limited to 0 or 1)
	IERR = 10	Contingency rating input option out of range (limited to 1 through 12)
	IERR = 11	Run preventive case input option out of range (limited to 0 or 1)
	IERR = 12	Sensitivity cutoff value out of range (limited to 0.05 through 1.0)
	IERR = 13	ECDI filename is missing
	IERR = 14	Security Marge percentage out of range (limited to 0 through 25)
	IERR = 15	Generation input option out of range (limited to 0 or 1)
	IERR = 16	Load input option out of range (limited to 0 or 1)
	IERR = 17	Phase Shifter input option out of range (limited to 0 or 1)
	IERR = 18	DC Lines input option out of range (limited to 0 or 1)
	IERR = 19	Total Area Generation Persistence input option out of range (limited to 0 or 1)

22.1.214. SELECTACTIVECONTS

Use this function to select only active contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTACTIVECONTS
```

Python command syntax:

```
ierr = selectactiveconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTACTIVE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.215. SELECTALLCONTS

Use this function to select ALL contingencies to report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTALLCONTS
```

Python command syntax:

```
ierr = selectallconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTALL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.216. SELECTCOMPLEXCONTS

Use this function to select only complex (not single branch opening) contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTCOMPLEXCONTS
```

Python command syntax:

```
ierr = selectcomplexconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTCMPLX(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.217. SELECTCONVERGECONTS

Use this function to select only contingencies that did converge.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTCONVERGECONTS
```

Python command syntax:

```
ierr = selectconvergeconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTCONV(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.218. SELECTDISABLEDCONTS

Use this function to select only contingencies disabled due to data errors.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTDISABLEDCONTS
```

Python command syntax:

```
ierr = selectdisabledconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTDISABLE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.219. SELECTEXCLUDEDCONTS

Use this function to select only user excluded contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTEXCLUDEDCONTS
```

Python command syntax:

```
ierr = selectexcludedconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTEXC(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.220. SELECTGENCONTS

Use this function to select only contingencies with generation adjustments.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTGENCONTS
```

Python command syntax:

```
ierr = selectgenconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTGEN(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.221. SELECTHISEVCONTS

Use this function to select only contingencies with higher severity index.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTHISEVCONTS SEVCO
```

Python command syntax:

```
ierr = selecthisevconts(sevco)
```

Fortran command syntax:

```
CALL MAPI_SELCONTHSEV(SEVCO, IERR)
```

Where:

Real SEVCO	Is Severity Index. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Severity index out of range (0 - 200)
	IERR = 3	Severity Index is missing.

22.1.222. SELECTIMBALANCECONTS

Use this function to select only imbalanced contingencies (load+gener+losses) to report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTIMBALANCECONTS
```

Python command syntax:

```
ierr = selectimbalanceconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTIMBAL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.223. SELECTISLANDCONTS

Use this function to select only contingencies causing separations.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTISLANDCONTS
```

Python command syntax:

```
ierr = selectislandconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTISL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.224. SELECTLOADCONTS

Use this function to select only contingencies with load adjustments.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTLOADCONTS
```

Python command syntax:

```
ierr = selectloadconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTLD(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.225. SELECTLOSEVCONTS

Use this function to select only contingencies with lower severity index.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTLOSEVCONTS SEVCO
```

Python command syntax:

```
ierr = selectlosevconts(sevco)
```

Fortran command syntax:

```
CALL MAPI_SELCONTLSEV(SEVCO, IERR)
```

Where:

Real SEVCO	Is severity index. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Severity index out of range (0 - 200)
	IERR = 3	Severity Index is missing.

22.1.226. SELECTNOTCONVERGECONTS

Use this function to select only contingencies that did not converge.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTNOTCONVERGECONTS
```

Python command syntax:

```
ierr = selectnotconvergeconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTNCONV(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.227. SELECTNOVIOLCONTS

Use this function to select only contingencies without violations.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTNOVIOLCONTS
```

Python command syntax:

```
ierr = selectnoviolconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTNOVIOL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.228. SELECTSINGLEBRANCHCONTS

Use this function to select only single branch contingencies opening without islands.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTSINGLEBRANCHCONTS
```

Python command syntax:

```
ierr = selectsinglebranchconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTSINGLE(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.229. SELECTSPECIFICCONTS

Use this function to select only specified contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTSPECIFICCONTS  NUMCONTS  CONTLIST(1)..CONTLIST(NUMCONTS)
```

Python command syntax:

```
ierr = selectspecificconts(numconts, contolist)
```

Fortran command syntax:

```
CALL MAPI_SELCONTSPEC(NUMCONTS, CONTLIST, IERR)
```

Where:

Integer NUMCONTS	Is the number of contingencies to be included in CONTLIST (input; no default allowed).	
Integer CONTLIST	Is a set of integers forming a list of contingency numbers. There must be as many contingencies as indicated by NUMCONTS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of contingencies is missing.
	IERR = 3	One label of contingencies is missing.

22.1.230. SELECTVIOLCONTS

Use this function to select only contingencies with violations.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SELECTVIOLCONTS
```

Python command syntax:

```
ierr = selectviolconts()
```

Fortran command syntax:

```
CALL MAPI_SELCONTVIOL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.231. SETEXCLUDEDBRANCHES

Use this function to exclude branches by from bus, to bus and exclusion option.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETEXCLUDEDBRANCHES  NUMBRA LISTBRA(1) .. LISTBRA(NUMBRA)
```

Python command syntax:

```
ierr = setexcludedbranches(numbra, listbra)
```

Fortran command syntax:

```
CALL MAPI_SETEXCLUDEDBRANCHES(NUMBRA, LISTBRA, IERR)
```

Where:

Integer NUMBRA	(input; no default allowed).	
Character*12 LISTBRA	Is a set of strings forming a list of excluded branches. Each branch consists of a FROM bus followed by a TO bus followed by a Circuit ID and Exclusion Option index. There must be as many sets of FROM TO Exclusion Option as indicated by NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of monitored elements is missing.
	IERR = 3	One branch label is missing.

22.1.232. SETEXCLUDEDCONTINGENCIES

Use this function to exclude contingencies by contingency ID.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETEXCLUDEDCONTS  NUMCONTS  CONTLIST(1)..CONTLIST(NUMCONTS)
```

Python command syntax:

```
ierr = setexcludedcontingencies(numconts, contolist)
```

Fortran command syntax:

```
CALL MAPI_SETEXCLUDEDCONTS(NUMCONTS, CONTLIST, IERR)
```

Where:

Integer NUMCONTS	Is the number of contingencies to be included in CONTLIST (input; no default allowed).	
Integer CONTLIST	Is a set of integers forming a list of contingency numbers. There must be as many contingencies as indicated by NUMCONTS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of contingencies is missing.
	IERR = 3	One of Contingency Id is missing.

22.1.233. SETEXCLUDEDFLOWGATES

Use this function to exclude flowgates by flowgate ID

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETEXCLUDEDFGATES  NUMFGATES LISTFGATES(1)..LISTFGATES(NUMFGATES)
```

Python command syntax:

```
ierr = setexcludedflowgates(numfgates, listfgates)
```

Fortran command syntax:

```
CALL MAPI_SETEXCLUDEDFGATES(NUMFGATES, LISTFGATES, IERR)
```

Where:

Integer NUMFGATES	Is the number of excluded flowgates to be included in LISTFGATES (input; no default allowed).	
Integer*12 LISTFGATES	Is a set of integers forming a list of flowgate ID's. There must be as many flowgates as indicated by NUMFGATES. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of flowgate IDs is missing.
	IERR = 3	One of the flowgate IDs is missing.

22.1.234. SETEXCLUDEDINTERFACES

Use this function to exclude interfaces by interface ID and exclusion option

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETEXCLUDEDINTERS  NUMINTER LISTINTER(1)..LISTINTER(NUMINTER)
```

Python command syntax:

```
ierr = setexcludedinterfaces(numinter, listinter)
```

Fortran command syntax:

```
CALL MAPI_SETEXCLUDEDINTERS(NUMINTER, LISTINTER, IERR)
```

Where:

Integer NUMINTER	Is the number of excluded interfaces to be included in LISTML (input; no default allowed).	
Integer*12 LISTINTER	Is a set of integers forming a list of interface ID's followed by exclusion option index. There must be as many sets of interface ID to Exclusion Option as indicated by NUMINTER. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of interfaces is missing.
	IERR = 3	One of Interface Id is missing.

22.1.235. SETEXCLUDEDVOLTAGEBUSES

Use this function to exclude Voltage Buses by bus ID and exclusion option

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_SETEXCLUDEDBUSES  NUMBUS LISTBUS(1) .. LISTBUS(NUMBUS)
```

Python command syntax:

```
ierr = setexcludedbuses(numbus, listbus)
```

Fortran command syntax:

```
CALL MAPI_SETEXCLUDEDBUSES(NUMBUS, LISTBUS, IERR)
```

Where:

Integer NUMBUS	Is the number of excluded voltage buses to be included in LISTML (input; no default allowed).	
Integer*12 LISTBUS	Is a set of integers forming a list of voltage bus ID's followed by exclusion option index. There must be as many sets of voltage bus ID to Exclusion Option as indicated by NUMBUS. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	The number of voltage bus IDs is missing.
	IERR = 3	One of the voltage bus IDs is missing.

22.1.236. SGLACFCITC

Use this function to calculation the effects of a Single AC FCITC Transfer

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SGLACFCITC SYS1 SYS2 TRANSFER OPTSI(1)..OPTS(5) ACTOLN
```

Python command syntax:

```
ierr = sglacfcitc(sys1, sys2, transfer, options, actoln)
```

Fortran command syntax:

```
CALL MAPI_SGLACFCITC(SYS1, SYS2, TRANSFER, OPTIONS, ACTOLN, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).																														
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).																														
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).																														
Integer OPTIONS (5)	array of 5 elements specifying calculation options(input). <table> <tr> <td>OPTIONS(1)</td><td>FCITC report format (2 by default)</td></tr> <tr> <td>OPTIONS(1) = 1</td><td>Standard Report</td></tr> <tr> <td>OPTIONS(1) = 2</td><td>Wide Report (Spreadsheet format)</td></tr> <tr> <td>OPTIONS(2)</td><td>Maximum number violations to verify using AC (5 by default)</td></tr> <tr> <td>OPTIONS(2) > n</td><td>Number of DC violations to consider</td></tr> <tr> <td>OPTIONS(3)</td><td>Apply non-divergent LF (0 by default)</td></tr> <tr> <td>OPTIONS(3) = 0</td><td>never</td></tr> <tr> <td>OPTIONS(3) = 1</td><td>always</td></tr> <tr> <td>OPTIONS(3) = 2</td><td>only if regular diverged</td></tr> <tr> <td>OPTIONS(4)</td><td>AC LF method (0 by default)</td></tr> <tr> <td>OPTIONS(4) = 1</td><td>Newton</td></tr> <tr> <td>OPTIONS(4) = 2</td><td>Decoupled</td></tr> <tr> <td>OPTIONS(5)</td><td>Report removed violations with FCITC report (0 by default)</td></tr> <tr> <td>OPTIONS(5) = 0</td><td>no</td></tr> <tr> <td>OPTIONS(5) = 1</td><td>yes</td></tr> </table>	OPTIONS(1)	FCITC report format (2 by default)	OPTIONS(1) = 1	Standard Report	OPTIONS(1) = 2	Wide Report (Spreadsheet format)	OPTIONS(2)	Maximum number violations to verify using AC (5 by default)	OPTIONS(2) > n	Number of DC violations to consider	OPTIONS(3)	Apply non-divergent LF (0 by default)	OPTIONS(3) = 0	never	OPTIONS(3) = 1	always	OPTIONS(3) = 2	only if regular diverged	OPTIONS(4)	AC LF method (0 by default)	OPTIONS(4) = 1	Newton	OPTIONS(4) = 2	Decoupled	OPTIONS(5)	Report removed violations with FCITC report (0 by default)	OPTIONS(5) = 0	no	OPTIONS(5) = 1	yes
OPTIONS(1)	FCITC report format (2 by default)																														
OPTIONS(1) = 1	Standard Report																														
OPTIONS(1) = 2	Wide Report (Spreadsheet format)																														
OPTIONS(2)	Maximum number violations to verify using AC (5 by default)																														
OPTIONS(2) > n	Number of DC violations to consider																														
OPTIONS(3)	Apply non-divergent LF (0 by default)																														
OPTIONS(3) = 0	never																														
OPTIONS(3) = 1	always																														
OPTIONS(3) = 2	only if regular diverged																														
OPTIONS(4)	AC LF method (0 by default)																														
OPTIONS(4) = 1	Newton																														
OPTIONS(4) = 2	Decoupled																														
OPTIONS(5)	Report removed violations with FCITC report (0 by default)																														
OPTIONS(5) = 0	no																														
OPTIONS(5) = 1	yes																														
Real ACTOLN (1)	array of 1 elements specifying Tolerance to check study transfer (MW)(input). <table> <tr> <td>ACTOLN(1)</td><td>AC load flow tolerance level(MW) (10.0 by default)</td></tr> </table>	ACTOLN(1)	AC load flow tolerance level(MW) (10.0 by default)																												
ACTOLN(1)	AC load flow tolerance level(MW) (10.0 by default)																														

Integer IERR

error code (output).

IERR = 0

No error

IERR = 1

Prerequisite requirements for function not met

IERR = 2

Option is missing or invalid

22.1.237. SGLDCFCITC

Use this function to calculation the effects of a Single Linear FCITC Transfer

This API routine was first introduced in release 35.2.0.

Batch command syntax:

```
BAT_SGLDCFCITC SYS1 SYS2 TRANSFER OPTSI(1)..OPTS(9) MAXTR, NUMMONEL,
LISTML(1)..LISTML(NUMMONEL)
```

Python command syntax:

```
ierr = sgldcfcitc(sys1, sys2, transfer, options, maxtr, nummonel, listml)
```

Fortran command syntax:

```
CALL MAPI_SGLDCFCITC(SYS1, SYS2, TRANSFER, OPTIONS, MAXTR, NUMMONEL,
LISTML, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).
Integer OPTIONS (8)	array of 8 elements specifying calculation options(input).
	OPTIONS(1) FCITC report format (2 by default)
	OPTIONS(1) = 1 2 Line report
	OPTIONS(1) = 2 Wide Report (Spreadsheet format)
	OPTIONS(1) = 3 TLTG Report
	OPTIONS(1) = 4 Wide Report (Old format)
	OPTIONS(2) Report FCITC violations (0 by default)
	OPTIONS(2) = 0 no
	OPTIONS(2) = 1 yes
	OPTIONS(3) Report Export level (0 by default)
	OPTIONS(3) = 0 no
	OPTIONS(3) = 1 yes
	OPTIONS(4) Report Import level (0 by default)
	OPTIONS(4) = 0 no
	OPTIONS(4) = 1 yes
	OPTIONS(5) Add subsystems adjustments detailed report (0 by default)
	OPTIONS(5) = 0 no
	OPTIONS(5) = 1 yes
	OPTIONS(6) Add separate report for basecase (0 by default)

	OPTIONS(6) = 0	no
	OPTIONS(6) = 1	yes
	OPTIONS(7)	Report removed violations with FCITC report (0 by default)
	OPTIONS(7) = 0	no
	OPTIONS(7) = 1	yes
	OPTIONS(8)	Report Flowgates/Interfaces flows (0 by default)
	OPTIONS(8) = 0	no
	OPTIONS(8) = 1	interfaces
	OPTIONS(8) = 2	flowgates
Real MAXTR (1)	array of 1 elements specifying Subsystems adjustments detailed report(input).	
	MAXTR(1)	Maximum transfer level to consider (MW). Ignored if OPTION(5) = 0 (100.0 by default)
Integer NUMMONEL	Is the number of flowgates/interfaces to be included in LISTML (input; no default allowed).	
Character*12 LISTML	Is a set of strings forming a list of flowgate IDs or interface names. There must be as many flowgates/interfaces as indicated in NUMMONEL. (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Integer Option is missing or invalid
	IERR = 3	Float Value is missing or invalid
	IERR = 4	Flowgate/Interface not found
	IERR = 5	Flowgate/Interface list missing entries

22.1.238. SHOWPARAMS

Use this function to display all of the option parameters currently in use for any given menu in pss must module.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SHOWPARAMS  MENUNM
```

Python command syntax:

```
ierr = showparams(menunm)
```

Fortran command syntax:

```
CALL MAPI_SHOWPARMS(MENUNM, IERR)
```

Where:

Character*20 MENUNM	Is a string identifying which menu you wish to display. Acceptable entries are: (input; no default allowed).
	MENUNM = MAINOP- General program setting options
	TIONS
	MENUNM = LFADJOP- Load Flow Adjustment options
	TIONS
	MENUNM = Generator Var Limits Checking options
	LFGENOPTIONS
	MENUNM = LFSOLOP- AC Load Flow Solution options
	TIONS
	MENUNM = LFAD- Advanced Load Flow Solution options
	VOPTIONS
	MENUNM = LP/OPF Constraint/Contingency options
	CONSTROPTS
	MENUNM = MUSTOP- MUST Run time solution options
	TIONS
	MENUNM = AC verification options
	ACVEROPTIONS
	MENUNM = TRAN- FCITC Violations report format options
	VIOLOPTS
	MENUNM = ACCON- AC Contingency analysis options
	TOPTS
	MENUNM = CONTOP- Contingency reporting options
	TS
	MENUNM = TRANIM- Transfer impact analysis Options
	POPTS
	MENUNM = Generation worst dispatch options
	TRGENOPTS
	MENUNM = VOLTA- Voltage violations with respect to specified
	GEOPTS limits

	MENUNM = BRANRE- POPTS	Branch violations (MW) and impact report analysis options
	MENUNM = BRANAM- POPTS	Branch violations (MVA) and impact report analysis options
	MENUNM = FGATERE- POPTS	Flowgate violations and impact report analy- sis options
	MENUNM = INTRRE- POPTS	Interface violations and impact report analy- sis options
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Invalid Menu Selected - No changes made

22.1.239. SUBSYSTEMS

Use this function to generate a subsystem report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SUBSYSTEMS
```

Python command syntax:

```
ierr = subsystems()
```

Fortran command syntax:

```
CALL MAPI_SYSTEMS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.240. SUMMARYCONTINGENCIES

Use this function to display a summary of the selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SUMMARYCONTINGENCIES
```

Python command syntax:

```
ierr = summarycontingencies()
```

Fortran command syntax:

```
CALL MAPI_SUMSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.241. SWINGBUSES

Use this function to a report of swing buses.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_SWINGBUSES
```

Python command syntax:

```
ierr = swingbuses()
```

Fortran command syntax:

```
CALL MAPI_SWINGBUSES(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Error in obtaining list

22.1.242. VIOLSELCONTINGENCIES

Use this function to report the violations by selected contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_VIOLSELCONTINGENCIES
```

Python command syntax:

```
ierr = violselcontingencies()
```

Fortran command syntax:

```
CALL MAPI_VIOLSELCONTS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.243. VIOLSELCONTINGENCIES_TBL

Use this function to report the violations by selected contingencies in table format.

This API routine was first introduced in release 35.1.0.

Batch command syntax:

```
BAT_VIOLSELCONTINGENCIES_TBL
```

Python command syntax:

```
ierr = violselcontingencies_tbl()
```

Fortran command syntax:

```
CALL MAPI_VIOLSELCONTS_TBL(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.244. WRITEEXCLUDES

Use this function to write all excluded constraints and contingencies.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_WRITEEXCLUDES OUT OFILE
```

Python command syntax:

```
ierr = writeexcludes(out, ofile)
```

Fortran command syntax:

```
CALL MAPI_WRITEEXCLUDES(OUT, OFILE, IERR)
```

Where:

Integer OUT	selection option (input; 1 by default).	
	OUT = 0	direct output to the data file specified by OFILE
	OUT = 1	direct output to the report window
Character*260 OFILE	name of the output file (when OUT is 0) (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	prerequisite requirements for API are not met
	IERR = 2	invalid OUT value
	IERR = 3	error opening OFILE

22.1.245. WRITERAWDATA

Use this function to WRITE a PSSE RAW case file from the current MUST data.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_WRITERAWDATA  NUMNAM WRFILE
```

Python command syntax:

```
ierr = writerawdata(numnam, wrfile)
```

Fortran command syntax:

```
CALL MAPI_WRITERAWDATA(NUMNAM, WRFILE, IERR)
```

Where:

integer NUMNAM	Set NUMNAM to write BUSES by NUMBER or NAME (input; no default allowed). NUMNAM = 0 write BUSES by NUMBER NUMNAM = 1 write BUSES by NAME
Character*260 WRFILE	Is a string identifying the full pathname of the RAW case file (.raw) to be written. (input; no default allowed).
Integer IERR	error code (output). IERR = 0 No error IERR = 1 Prerequisite requirements for function not met IERR = 2 Cannot write RAW file with busnamgen on IERR = 3 The option to to write BUSES by NUMBER or NAME is missing. IERR = 4 The name of the output file is missing

22.1.246. ZONEBUBBLE

Use this function to update values for the Zone Bubble Diagram.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ZONEBUBBLE SYS1, SYS2, TRANSFER
```

Python command syntax:

```
ierr = zonebubble(sys1, sys2, transfer)
```

Fortran command syntax:

```
CALL MAPI_UPDZONEBUBL(SYS1, SYS2, TRANSFER, IERR)
```

Where:

Character*12 SYS1	Is a string identifying From Subsystem Name to be used in the study transfer. (input; no default allowed).	
Character*12 SYS2	Is a string identifying To Subsystem Name to be used in the study transfer. (input; no default allowed).	
Real TRANSFER	Is the MW Transfer Level for this Study Transfer (input; no default allowed).	
Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Subsystem(s) missing
	IERR = 3	No transfer value
	IERR = 4	Subsystem(s) not valid
	IERR = 5	Sending subsystem already selected
	IERR = 6	Overlapping systems

22.1.247. ZONESINAREAS

Use this function to a report of zones in areas.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ZONESINAREAS
```

Python command syntax:

```
ierr = zonesinareas()
```

Fortran command syntax:

```
CALL MAPI_ZONESINAREAS(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.1.248. ZONESUMMARY

Use this function to generate an zone summary report.

This API routine was first introduced in release 35.0.0.

Batch command syntax:

```
BAT_ZONESUMMARY
```

Python command syntax:

```
ierr = zonesummary()
```

Fortran command syntax:

```
CALL MAPI_ZONESUMMARY(IERR)
```

Where:

Integer IERR	error code (output).	
	IERR = 0	No error
	IERR = 1	Prerequisite requirements for function not met

22.2. MUST Data Retrieval

These API routines return data and results of MUST operations.

These routines do not record themselves when called with recording enabled.

22.2.1. GETEXCLUDEDBRANCHES

Use this function to get list of exclude branches.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
frombus, tobus, cktid, excopt = getexcludedbranches()
```

Fortran command syntax:

```
CALL MAPI_GETEXCLUDEDBRANCHES(NUMBRA, FROMBUS, TOBUS, CKTID, EXCOPT,  
    NUMRETBRA)
```

Where:

Integer NUMBRA	declared size of output arrays
Integer FROMBUS (NUMBRA)	Is an array of Excluded Branch From Buses (output).
Integer TOBUS (NUMBRA)	Is an array of Excluded Branch To Buses (output).
Character*2 CKTID (NUMBRA)	Is an array of Excluded Branch To Circuit ID's (output).
Integer EXCOPT (NUMBRA)	Is an array of Excluded Branch To Exclusion Options (output).
Integer NUMRETBRA	number of excluded branches returned (output).

22.2.2. GETEXCLUDEDCONTINGENCIES

Use this function to get list of exclude contingencies.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
contid,numretcont = getexcludedcontingencies()
```

Fortran command syntax:

```
CALL MAPI_GETEXCLUDEDCONTS(NUMCONT, CONTID, NUMRETCONT)
```

Where:

Integer NUMCONT	declared size of NAMES
Integer CONTID (NUMCONT)	Is an array of Excluded Contingency Id's (output).
Integer NUMRETCONT	number of libraries returned (output).

22.2.3. GETEXCLUDEDFLOWGATES

Use this function to get list of exclude flowgates.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
listfgates = getexcludedflowgates()
```

Fortran command syntax:

```
CALL MAPI_GETEXCLUDEDFGATES(NUMFGATE, LISTFGATES, NUMRETFGATE)
```

Where:

Integer NUMFGATE	declared size of LISTFGATES
Integer LISTFGATES (NUMFGATE)	Is an array of Excluded Flowgates Id's (output).
Integer NUMRETFGATE	number of excluded flowgates returned (output).

22.2.4. GETEXCLUDEDINTERFACES

Use this function to get list of exclude interfaces.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
interfaceid, excopt = getexcludedinterfaces()
```

Fortran command syntax:

```
CALL MAPI_GETEXCLUDEDINTERS(NUMINTER, INTERFACEID, EXCOPT, NUMRETINTER)
```

Where:

Integer NUMINTER	declared size of output arrays
Integer INTERFACEID (NUMINTER)	Is an array of Excluded Interface Id's (output).
Integer EXCOPT (NUMINTER)	Is an array of Excluded Interface Exclusion Option Index's (output).
Integer NUMRETINTER	number of libraries returned (output).

22.2.5. GETEXCLUDEDVOLTAGEBUSES

Use this function to get list of exclude voltagebuses.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
busid, excopt = getexcludedvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_GETEXCLUDEDDBUSES(NUMBUS, BUSID, EXCOPT, NUMRETBUS)
```

Where:

Integer NUMBUS	declared size of output arrays
Integer BUSID (NUMBUS)	Is an array of Excluded Voltage Bus Id's (output).
Integer EXCOPT (NUMBUS)	Is an array of Excluded Voltage Bus Exclusion Option Index's (output).
Integer NUMRETBUS	number of libraries returned (output).

22.2.6. GETFINALBALANCE

Use this API to return the value of the final balance flow for the given area or zone.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, finalbalflow = getfinalbalance(azindex)
```

Fortran command syntax:

```
CALL MAPI_GETFINALBAL(AZINDEX, FINALBALFLOW, IERR)
```

Where:

Integer AZINDEX	Area/Zone Number (input).	
Real FINALBALFLOW	Final Balance Flow (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; Final Flow Value returned
	IERR = 1	Final Balance Flow not calculated; Check pre-requisite requirements for function
	IERR = 2	Input Area/Zone Number not found

22.2.7. GETFINALFLOW

Use this API to return the value of the final flow between two given areas or zones.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, finalflow = getfinalflow(azindexfrom, azindexto)
```

Fortran command syntax:

```
CALL MAPI_GETFINALFLOW(AZINDEXFROM, AZINDEXTO, FINALFLOW, IERR)
```

Where:

Integer AZINDEXFROM	From Area/Zone Number (input).
Integer AZINDEXTO	To Area/Zone Number (input).
Real FINALFLOW	Final Flow Between From and To Areas/Zones (output).
Integer IERR	error code (output).
	IERR = 0 No error; Final Flow Value returned
	IERR = 1 Final Flow not calculated; Check prerequisite requirements for function
	IERR = 2 Input Area/Zone Number(s) not found
	IERR = 3 Connection Between Given Input Area/Zone Number(s) not found

22.2.8. GETIDOFCONTINGENCYBYNAME

Use this API to return the contingency id by name .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, id = getidofcontingencybyname(name)
```

Fortran command syntax:

```
CALL MAPI_GETIDOFCONTINGENCYBYNAME(ID, NAME, IERR)
```

Where:

Integer ID	Contingency id (output).	
Character*12 NAME	Contingency name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'ID' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Contingency not found; 'ID' unchanged

22.2.9. GETIDOFFFLOWGATEBYNAME

Use this API to return the flowgate id by name .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, id = getidoffflowgatebyname(name)
```

Fortran command syntax:

```
CALL MAPI_GETIDOFFFLOWGATEBYNAME(ID, NAME, IERR)
```

Where:

Integer ID	Flowgate id (output).
Character*12 NAME	Flowgate name (input).
Integer IERR	error code (output).
	IERR = 0 No error; 'ID' returned
	IERR = 1 Prerequisite requirements for function not met
	IERR = 2 Flowgate not found; 'ID' unchanged

22.2.10. GETIDOFINTERFACEBYNAME

Use this API to return the interface id by name .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, id = getidofinterfacebyname(name)
```

Fortran command syntax:

```
CALL MAPI_GETIDOFINTERFACEBYNAME(ID, NAME, IERR)
```

Where:

Integer ID	Interface id (output).	
Character*12 NAME	Interface name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'ID' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Interface not found; 'ID' unchanged

22.2.11. GETIDOFVOLTAGEBUSBYNAME

Use this API to return the voltage bus id by name .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, id = getidofvoltagebusbyname(name)
```

Fortran command syntax:

```
CALL MAPI_GETIDOFVOLTAGEBUSBYNAME(ID, NAME, IERR)
```

Where:

Integer ID	Voltage bus id (output).	
Character*12 NAME	Voltage bus name (input).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'ID' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Voltage bus not found; 'ID' unchanged

22.2.12. GETINITBALANCE

Use this API to return the value of the initial balance flow for the given area or zone.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, initbalflow = getinitbalance(azindex)
```

Fortran command syntax:

```
CALL MAPI_GETINITBAL(AZINDEX, INITBALFLOW, IERR)
```

Where:

Integer AZINDEX	Area/Zone Number (input).	
Real INITBALFLOW	Initial Balance Flow (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; Initial Flow Value returned
	IERR = 1	Initial Balance Flow not calculated; Check pre-requisite requirements for function
	IERR = 2	Input Area/Zone Number not found

22.2.13. GETINITIALFLOW

Use this API to return the value of the initial flow between two given areas or zones.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, initialflow = getinitialflow(azindexfrom, azindexto)
```

Fortran command syntax:

```
CALL MAPI_GETINITFLOW(AZINDEXFROM, AZINDEXTO, INITIALFLOW, IERR)
```

Where:

Integer AZINDEXFROM	From Area/Zone Number (input).
Integer AZINDEXTO	To Area/Zone Number (input).
Real INITIALFLOW	Initial Flow Between From and To Areas/Zones (output).
Integer IERR	error code (output).
	IERR = 0 No error; Initial Flow Value returned
	IERR = 1 Initial Flow not calculated; Check prerequisite requirements for function
	IERR = 2 Input Area/Zone Number(s) not found
	IERR = 3 Connection Between Given Input Area/Zone Number(s) not found

22.2.14. GETIPFFACTOR

Use this API to return the IPF Factor between two given areas or zones.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, ipff = getipffactor(azindexfrom, azindexto)
```

Fortran command syntax:

```
CALL MAPI_GETIPFFACTOR(AZINDEXFROM, AZINDEXTO, IPFF, IERR)
```

Where:

Integer AZINDEXFROM	From Area/Zone Number (input).
Integer AZINDEXTO	To Area/Zone Number (input).
Real IPFF	IPF Factor Between From and To Areas/Zones (output).
Integer IERR	error code (output).
	IERR = 0 No error; Final Flow Value returned
	IERR = 1 Final Flow not calculated; Check prerequisite requirements for function
	IERR = 2 Input Area/Zone Number(s) not found
	IERR = 3 Connection Between Given Input Area/Zone Number(s) not found

22.2.15. GETNAMEOFCONTINGENCYBYID

Use this API to return the contingency name by id .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, name = getnameofcontingencybyname(id)
```

Fortran command syntax:

```
CALL MAPI_GETNAMEOFCONTINGENCYBYID(ID, NAME, IERR)
```

Where:

Integer ID	Contingency id (input).	
Character*12 NAME	Contingency name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NAME' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Contingency id is out of index; 'NAME' unchanged

22.2.16. GETNAMEOFFLOWGATEBYID

Use this API to return the flowgate name by id .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, name = getnameofflowgatebyname(id)
```

Fortran command syntax:

```
CALL MAPI_GETNAMEOFFLOWGATEBYID(ID, NAME, IERR)
```

Where:

Integer ID	Flowgate id (input).	
Character*12 NAME	Flowgate name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NAME' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Flowgate not found; 'NAME' unchanged

22.2.17. GETNAMEOFINTERFACEBYID

Use this API to return the interface name by id .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, name = getnameofinterfacebyname(id)
```

Fortran command syntax:

```
CALL MAPI_GETNAMEOFINTERFACEBYID(ID, NAME, IERR)
```

Where:

Integer ID	Interface id (input).	
Character*12 NAME	Interface name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NAME' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Interface id is out of index; 'NAME' unchanged

22.2.18. GETNAMEOFVOLTAGEBUSBYID

Use this API to return the voltage bus name by id .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, name = getnameofvoltagebusbyname(id)
```

Fortran command syntax:

```
CALL MAPI_GETNAMEOFVOLTAGEBUSBYID(ID, NAME, IERR)
```

Where:

Integer ID	Voltage Bus id (input).	
Character*12 NAME	Voltage bus name (output).	
Integer IERR	error code (output).	
	IERR = 0	No error; 'NAME' returned
	IERR = 1	Prerequisite requirements for function not met
	IERR = 2	Voltage bus not found; 'NAME' unchanged

22.2.19. GETNUMOFEXCLUDEDBRANCHES

Use this API to return the number of excluded branches.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
numbra = getnumofexcludedbranches()
```

Fortran command syntax:

```
CALL MAPI_GETNUMOFEXCBRA(NUMBRA)
```

Where:

Integer NUMBRA	number of excluded branches (output).
----------------	---------------------------------------

22.2.20. GETNUMOFEXCLUDEDCONTINGENCIES

Use this API to return the number of excluded contingencies.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
numcont = getnumofexcludedcontingencies()
```

Fortran command syntax:

```
CALL MAPI_GETNUMOFEXCCONT(NUMCONT)
```

Where:

Integer NUMCONT	number of Excluded Contingencies (output).
-----------------	--

22.2.21. GETNUMOFEXCLUDEDFLOWGATES

Use this API to return the number of excluded flowgates.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
numfgate = getnumofexcludedflowgates()
```

Fortran command syntax:

```
CALL MAPI_GETNUMOFEXCFGATE(NUMFGATE)
```

Where:

Integer NUMFGATE	number of Excluded Flowgates (output).
------------------	--

22.2.22. GETNUMOFEXCLUDEDINTERFACES

Use this API to return the number of excluded interfaces.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
numinter = getnumofexcludedinterfaces()
```

Fortran command syntax:

```
CALL MAPI_GETNUMOFEXCINTER(NUMINTER)
```

Where:

Integer NUMINTER	number of Excluded Interfaces (output).
------------------	---

22.2.23. GETNUMOFEXCLUDEDVOLTAGEBUSES

Use this API to return the number of excluded ac voltage buses.

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
numbus = getnumofexcludedvoltagebuses()
```

Fortran command syntax:

```
CALL MAPI_GETNUMOFEXCBUS(NUMBUS)
```

Where:

Integer NUMBUS	number of excluded Ac Voltage Buses (output).
----------------	---

22.2.24. GETTPFBALANCE

Use this API to return the value of the TPF factor for the given area or zone .

This API routine was first introduced in release 35.1.0.

Python command syntax:

```
ierr, tpfbalflow = gettpfbalance(azindex)
```

Fortran command syntax:

```
CALL MAPI_GETTPFBAL(AZINDEX, TPFBALFLOW, IERR)
```

Where:

Integer AZINDEX	Area/Zone Number (input).
Real TPFBALFLOW	TPF Factor (output).
Integer IERR	error code (output).
	IERR = 0 No error; TPF Factor returned
	IERR = 1 TPF Factor not calculated; Check prerequisite requirements for function
	IERR = 2 Input Area/Zone Number not found

Chapter 23

PSSARRAYS Module

The pssarrays module provides Python functions to retrieve PSS[®] E solution results in arrays. These arrays can then be used in a Python script for post-processing, to create customized reports for export to a text file or an Excel spreadsheet, etc.

These functions do not record themselves when called while recording is enabled in PSS[®] E.

Please note that these routines are members of the pssarrays Python extension module, not psspy. The syntax on the following pages assumes that the module has been imported by executing:

```
import pssarrays
```

23.1. ACCC_SUMMARY

This function returns AC Contingency monitored element labels, contingency labels etc.

Python syntax:

```
rlst = pssarrays.accc_summary(accfile)
```

where:

string	accfile	Is the name of Contingency Solution Output file (input, no default allowed), maximum string length=260
--------	---------	--

Returned object 'rlst' contains the following attributes:

integer	rlst.ierr	Is the error code =0 no error occurred =4 error opening accfile =5 error reading accfile =6 prerequisite requirements for function not met
integer	rlst.acccsize.nmlne	Is the number of monitored branches
integer	rlst.acccsize.ninter	Is the number of monitored interfaces
integer	rlst.acccsize.ncase	Is the number of contingencies + 1 (for base case)
integer	rlst.acccsize.nmvbus	Is the number of voltage monitored buses
integer	rlst.acccsize.nmvrec	Is the number of voltage monitored records
integer	rlst.acccsize.nmvbusrec	Is the number of voltage monitored bus records
integer	rlst.acccsize.nbus	Is the number of buses in the case
integer	rlst.acccsize.ncntlshed	Is the number of load sheds due to dispatch and contingency
integer	rlst.acccsize.ntrplshed	Is the number of load sheds due to tripping
integer	rlst.acccsize.ncactlshed	Is the number of load sheds due to corrective actions
integer	rlst.acccsize.ncactgdisp	Is the number of generation dispatched due to corrective actions
integer	rlst.acccsize.ncactphsfr	Is the number of phase shifter changed due to corrective actions
integer	rlst.acccsize.nmlmtb	Is the number of voltage limit bus records
integer	rlst.acccsize.nmlmtn	Is the number of voltage limit node records
string	rlst.casetitle.line1	Is the case short title line 1, maximum string length=60
string	rlst.casetitle.line2	Is the case short title line 2, maximum string length=60
string	rlst.file.acc	Is the name of contingency output (.acc) file, maximum string length=260

string	rlst.file.sav	Is the name of saved case (.sav) file, maximum string length=260
string	rlst.file.dfx	Is the name of distribution factor data (.dfx) file, maximum string length=260
string	rlst.file.sub	Is the name of subsystem definition data (.sub) file, maximum string length=260
string	rlst.file.mon	Is the name of monitored element data (.mon) file, maximum string length=260
string	rlst.file.con	Is the name of contingency description data (.con) file, maximum string length=260
string	rlst.file.thr	Is the name of load throwover data (.thr) file, maximum string length=260
string	rlst.file.inl	Is the name of unit inertia and governor data (.inl) file, maximum string length=260
string	rlst.file.trp	Is the name of tripping element data (.trp) file, maximum string length=260
string	rlst.melement	Is a list of length (nmlne+ninter) of monitored branch and interface names, maximum string length=54
float	rlst.rating.a	Is a list of length (nmlne+ninter) of monitored element rating A
float	rlst.rating.b	Is a list of length (nmlne+ninter) of monitored element rating B
float	rlst.rating.c	Is a list of length (nmlne+ninter) of monitored element rating C
string	rlst.mvbuslabel	Is a list of length (nmvbusrec) of monitored voltage bus label, maximum string length=25
string	rlst.mvreclabel	Is a list of length (nmvbusrec) of monitored voltage record label, maximum string length=20
float	rlst.mvrecmax	Is a list of length (nmvbusrec) of monitored voltage bus maximum
float	rlst.mvrecmin	Is a list of length (nmvbusrec) of monitored voltage bus minimum
string	rlst.mvrectype	Is a list of length (nmvbusrec) of monitored voltage record type (RANGE / DEVIATION), maximum string length=9
string	rlst.colabel	Is a list of length (ncase) of contingency labels, maximum string length=12
string	rlst.busname	Is a list of length (nbus) of extended bus names, maximum string length=25
string	rlst.mvlbusreclabel	Is a list of length (nmlmtb) indicating the ordering of emergency monitored voltage limit bus records (mvbasel and mvemergrn)
string	rlst.mvbasel	Is a list of length (nmlmtb) of normal monitored voltage limit bus records in order of [[low_limit], [high_limit]]

string	rlst.mvemern	Is a list of length (nmlmtb) of emergency monitored voltage limit bus records in order of [[low_limit], [high_limit]]
string	rlst.mvlnodreclabel	Is a list of length (nmlmtb) of the ordering of emergency monitored voltage limit node records (mvnbasel and mvnemern)
string	rlst.mvnbasel	Is a list of length (nmlmtb) of monitored voltage limit node records in order of [[low_limit], [high_limit]]
string	rlst.mvnemern	Is a list of length (nmlmtb) of emergency monitored voltage limit node records in order of [[low_limit], [high_limit]]

23.2. ACCC_SOLUTION

This function returns ACCC post-contingency, post-tripping or post-corrective action solution monitored MVA flows, ampere flows and bus voltages for one contingency.

Python syntax:

```
rlst = pssarrays.accc_solution(accfile, colabel, stype, busmsm, sysmsm)
```

where:

string	accfile	Is the name of Contingency Solution Output file (input, no default allowed), maximum string length=260
string	colabel	Is the name of contingency label to get ACCC solution for, only one label allowed (input, no default allowed), maximum string length=12
string	stype	Is the name of solution type to get (input, <i>contingency</i> by default), allowed values: <i>contingency,con, tripping, trp, caction,contingency action,cor</i>
float	busmsm	Is the value of bus mismatch tolerance in MVA (input, 0.5 MVA by default)
float	sysmsm	Is the value of system mismatch tolerance in MVA (input, 5.0 MVA by default)

Returned object 'rlst' contains the following attributes:

integer	rlst.ierr	Is the error code =0 no error occurred =4 error opening accfile =5 error reading accfile =6 prerequisite requirements for function not met
string	rlst.codesc	Is the list of length (up to 16) of contingency events description, maximum string length=152
boolean	rlst.cnvflag	Is the convergence status (True when converged)
string	rlst.cnvcond	Is the convergence condition description, maximum string length=34
integer	rlst.island	Is the number of islands
float	rlst.mvaworst	Is the worst MVA mismatch
float	rlst.mvatotal	Is the total MVA mismatch
float	rlst.volts	Is a list of length (nmvbusrec) of monitored bus voltage in pu
float	rlst.mvaflow	Is a list of length (nmline+ninter) of monitored branch and interface MVA flow
float	rlst.ampflow	Is a list of length (nmline) of monitored branch ampere flow

string	rlst.lshedbus	Is a list of extended bus names of the load shed buses, maximum string length=25, list length: = ncntlshed, for post-contingency solution = ntrplshed, for post-tripping solution
float	rlst.loadshed	= nactlshed, for post-corrective action solution Is a list of loads shed in MW, list length: = ncntlshed, for post-contingency solution = ntrplshed, for post-tripping solution = 2 columns of nactlshed, for post-corrective action solution, 1st column gives initial load in MW, and 2nd column gives load shed in MW.
string	rlst.gdispbu	Is a list of length (nactgdisp) of extended bus names of the generation dispatch buses, maximum string length=25, available for post-corrective action solution only.
float	rlst.gendisp	Is a list of generation dispatches in MW, available for post-corrective action solution only, list length = 2 columns of nactgdisp, 1st column gives initial generation in MW, and 2nd column gives generation dispatch in MW.
string	rlst.phsftr	Is a list of length (nactphsftr) of phase shifter names, maximum string length=54, available for post-corrective action solution only.
float	rlst.phsftrang	Is a list of phase shifter angles in degrees, available for post-corrective action solution only, list length = 2 columns of nactphsftr, 1st column gives initial angle in degrees, and 2nd column gives new angle in degrees.

23.3. ACCC_SUMMARY_REPORT

This function generates text report of lists returned by `accc_summary`.

Python syntax:

```
ierr = pssarrays.accc_summary_report(accfile, rptfile)
```

where:

string	<code>accfile</code>	Is the name of Contingency Solution Output file (input, no default allowed), maximum string length=260
string	<code>rptfile</code>	Is the name of report file (input, PSS [®] E Report by default), maximum string length=260

returns:

integer	<code>rlst.ierr</code>	Is the error code
		=0 no error occurred
		=4 error opening accfile
		=5 error reading accfile
		=6 prerequisite requirements for function not met

23.4. SENSITIVITY_FLOW_TO_MW

This API is used to calculate sensitivity factors of a branch flow to MW power at generator buses and MW power at load buses.

The documentation for this API is available by running the following commands in either PSS®E CLI or any Python Interpreter:

```
import pssarrays  
  
help(pssarrays.sensitivity_flow_to_mw)
```

For error codes details please refer to Section 1.1.262, SENSITIVITY_FLOWS.

23.5. ACCC_SOLUTION_REPORT

This function generates text report of lists returned by `accc_solution`.

Python syntax:

```
ierr = pssarrays.accc_solution_report(accfile, colabels, stype, busmsm,
                                     sysmsm, rating, rptfile)
```

where:

string	accfile	Is the name of Contingency Solution Output file (input, no default allowed), maximum string length=260
string	colabels	Is the list of contingency label names (input, all contingencies in accfile by default), maximum string length=12
string	stype	Is the name of solution type to get (input, <i>contingency</i> by default allowed), allowed values: <i>contingency, con, tripping, trp, caction, contingency action, cor</i>
float	busmsm	Is the value of bus mismatch tolerance in MVA (input, 0.5 MVA by default)
float	sysmsm	Is the value of system mismatch tolerance in MVA (input, 5.0 MVA by default)
string	rating	Is the name of rating ('a' or 'b' or 'c') to use for calculating percentage loading (input, 'a' by default), maximum string length=1
string	rptfile	Is the name of report file (input, PSS [®] E Report by default), maximum string length=260

returns:

integer	rlst.ierr	Is the error code
		=0 no error occurred
		=4 error opening accfile
		=5 error reading accfile
		=6 prerequisite requirements for function not met

23.6. ACCC_VIOLATIONS_REPORT

This function generates text report of monitored flow and bus voltage violations of ACCC post-contingency, post-tripping or post-corrective action solution. For each monitored element flow and bus voltage, only the worst violation and contingency which results that violation are reported. That is each element violations is reported once and that violation is the worst violation.

Python syntax:

```
ierr = pssarrays.accc_violations_report (accfile, stype, busmsm, sysmsm,
rating, flowlimit, rptfile)
```

where:

string	accfile	Is the name of Contingency Solution Output file (input, no default allowed), maximum string length=260
string	stype	Is the name of solution type (input, <i>contingency</i> by default allowed), allowed values: <i>contingency,con, tripping, trp, caction,contingency action,cor</i>
float	busmsm	Is the value of bus mismatch tolerance in MVA (input, 0.5 MVA by default)
float	sysmsm	Is the value of system mismatch tolerance in MVA (input, 5.0 MVA by default)
string	rating	Is the name of rating ('a' or 'b' or 'c') to use for calculating percentage loading (input, 'a' by default), maximum string length=1
float	flowlimit	Is the value of percent of flow rating (input, 100% by default)
string	rptfile	Is the name of report file (input, PSS [®] E Report by default), maximum string length=260

returns:

integer	rlst.ierr	Is the error code
		=0 no error occurred
		=4 error opening accfile
		=5 error reading accfile
		=6 prerequisite requirements for function not met

23.7. ASCC_CURRENTS

This function returns short circuit currents and Thevenin impedance in three-phase ac systems from API. Results are returned for bus faults only. Results for line out and line end faults are not returned.

Python syntax:

```
rlst = pssarrays.ascc_currents (sid, all, flt3ph, fltlg, fltllg, fltll,
                                linout, linend, voltop, genxop, tpunty, dclload, zcorec, lnchrg, shntop,
                                loadop, machpq, volts, relfil, fcdfil, scfile)
```

int	sid	Is a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default).
int	all	Is the <i>all buses</i> or selected subsystem flag (input; 1 by default) = 1 process all buses = 0 process only buses in subsystem SID
int	flt3ph	Is to report three phase faults (0 by default). = 0 omit
int	fltlg	= 1 include Is to report line-to-ground faults (0 by default). = 0 omit
int	fltllg	= 1 include Is to report line-line-to-ground faults (0 by default). = 0 omit
int	fltll	= 1 include Is to report line-to-line faults (0 by default). = 0 omit
int	linout	= 1 include Is to report line-out faults (0 by default). = 0 omit
int	linend	= 1 include Is to report line-end faults (0 by default). = 0 omit
int	voltop	= 1 include Is the bus voltage option (0 by default).

		= 0 use bus voltages from power flow solution = 1 set all bus voltages at specified value and at 0 deg = 2 set faulted bus voltage at specified value and at 0 deg
int	genxop	Is the synchronous machine reactance option, ignored if generators are already "converted" (0 by default). = 0 use subtransient reactance = 1 use transient reactance = 2 use synchronous reactance
int	tpunty	Is the transformer tap ratios and phase angle option (0 by default) = 0 leave tap ratios and phase shift angles unchanged = 1 set tap ratios to 1.0 pu and phase shift angles to 0 deg = 2 set tap ratios to 1.0 pu and phase shift angles unchanged = 3 set tap ratios unchanged and phase shift angles to 0 deg
int	dcload	Is the dc line and FACTS device option (0 by default) = 0 blocked = 1 represent as load
int	zcorec	Is the zero sequence transformer impedance correction option (0 by default) = 0 ignore = 1 apply
int	Inchrg	Is the line charging option (0 by default) = 0 leave unchanged = 1 set to 0.0 in the positive and negative sequences = 2 set to 0.0 in all sequences
int	shntop	Is the line shunts, fixed shunts, switched shunts and transformer magnetizing admittance option (0 by default)

		= 0 leave unchanged
		= 1 set to 0.0 in the positive and negative sequences
		= 2 set to 0.0 in all sequences
int	loadop	Is the load option (0 by default)
		= 0 leave unchanged
		= 1 set to 0.0 in the positive and negative sequences
		= 2 set to 0.0 in all sequences
int	machpq	Is the synchronous and asynchronous machines power output option (0 by default)
		= 0 use real and reactive power outputs from power flow solution
		= 1 set real and reactive power outputs to 0.0
int	volts	Is the user specified bus voltage value in pu (1.0 by default)
		This is used only when voltop = 1 or 2.
str	relfil	Is the Relay Output Data (.rel) file; blank for none (input; blank by default); maximum string length=260
str	fcdfil	Is the name of fault control (.fcd) file; blank for none (input; blank by default); maximum string length=260.
str	scfile	Is the ASCC_3 Results (.sc) file; blank for none (output; blank by default); maximum string length=260.

Returned object 'rlst' contains the following attributes:

Index i is the ith faulted bus.

int	rlst.ierr	Is the error code
		= 0, no error occurred
		= 1, invalid SID value or subsystem SID is not defined
		= 2, invalid ALL value
		= 3, invalid STATUS value
		= 4, line end fault invalid; bus table is full
		= 5, error opening RELFIL
		= 6, error opening FCDFIL

		= 7, prerequisite requirements for function not met
		= 8, no faults specified
		= 9, error opening SCFILE
		= 10, SCFILE error
		= 11, bus SC results not available.
		= 12, branch SC results not available.
		= 13, three winding transformer SC results not available.
		= 14, incorrect SCFILE.
		= 15, SCFILE not allowed.
str	rlst.scunit	Is the units of returned fault currents
		= pu
		= physical (r.m.s. amperes)
str	rlst.scfmt	Is the coordinates of returned fault currents
		= rectangular
		= polar
int	rlst.fltbody	Is a list of faulted bus numbers
complex	rlst.fltbody[i].ia1	Is three phase fault, positive sequence current = I''_k
complex	rlst.fltbody[i].ia2	Is three phase fault, negative sequence current
complex	rlst.fltbody[i].ia0	Is three phase fault, zero sequence current
complex	rlst.fltbody[i].ia	Is three phase fault, Phase A current
complex	rlst.fltbody[i].ib	Is three phase fault, Phase B current
complex	rlst.fltbody[i].ic	Is three phase fault, Phase C current
complex	rlst.fltbody[i].ia1	Is line to ground fault, positive sequence current
complex	rlst.fltbody[i].ia2	Is line to ground fault, negative sequence current
complex	rlst.fltbody[i].ia0	Is line to ground fault, zero sequence current = $I''_k/3$
complex	rlst.fltbody[i].ia	Is line to ground fault, Phase A current
complex	rlst.fltbody[i].ib	Is line to ground fault, Phase B current
complex	rlst.fltbody[i].ic	Is line to ground fault, Phase C current
complex	rlst.fltbody[i].ia1	Is line line to ground fault, positive sequence current
complex	rlst.fltbody[i].ia2	Is line line to ground fault, negative sequence current
complex	rlst.fltbody[i].ia0	Is line line to ground fault, zero sequence current = $I''_k/3$
complex	rlst.fltbody[i].ia	Is line line to ground fault, Phase A current
complex	rlst.fltbody[i].ib	Is line line to ground fault, Phase B current
complex	rlst.fltbody[i].ic	Is line line to ground fault, Phase C current

complex	rlst.fltl[i].ia1	Is line to line fault, positive sequence current
complex	rlst.fltl[i].ia2	Is line to line fault, negative sequence current
complex	rlst.fltl[i].ia0	Is line to line fault, zero sequence current
complex	rlst.fltl[i].ia	Is line to line fault, Phase A current
complex	rlst.fltl[i].ib	Is line to line fault, Phase B current = I''_k
complex	rlst.fltl[i].ic	Is line to line fault, Phase C current = $-I''_k$
complex	rlst.thevz[i].z1	Is Thevenin impedance, positive sequence, in PU or OHM as set by SCUNIT
complex	rlst.thevz[i].z2	Is Thevenin impedance, negative sequence, in PU or OHM as set by SCUNIT
complex	rlst.thevz[i].z0	Is Thevenin impedance, zero sequence, in PU or OHM as set by SCUNIT
complex	rlst.thevzpu[i].z1	Is PU Thevenin impedance, positive sequence
complex	rlst.thevzpu[i].z2	Is PU Thevenin impedance, negative sequence
complex	rlst.thevzpu[i].z0	Is PU Thevenin impedance, zero sequence
complex	rlst.maxflt[i].ia1	Is maximum fault current, positive sequence current
complex	rlst.maxflt[i].ia2	Is maximum fault current, negative sequence current
complex	rlst.maxflt[i].ia0	Is maximum fault current, zero sequence current
complex	rlst.maxflt[i].ia	Is maximum fault current, Phase A current
complex	rlst.maxflt[i].ib	Is maximum fault current, Phase B current
complex	rlst.maxflt[i].ic	Is maximum fault current, Phase C current
str	rlst.maxfltdsc[i]	Is description of fault condition for maximum fault current

Note: Maximum fault current is the largest fault current among analyzed faults at a bus.

23.8. IECS_CURRENTS

This function returns short circuit currents and Thevenin impedance in three-phase ac systems according to IEC 60909 standard (IECS_3 API). Results are returned for bus faults only. Results for line out and line end faults are not returned.

Python syntax:

```
rlst = pssarrays.iecs_currents(sid, all, flt3ph, fltlg, fltllg, fltll,
    fltloc, linout, linend, tpunty, lnchrg, shntop, dclload, zcorec, optnftrc,
    loadop, genxop, brktime, vfactorc, iecfil, fcdfil, scfile)
```

where:

int	sid	Is a valid subsystem identifier. Valid subsystem identifiers range from 0 to 11. Subsystem SID must have been previously defined (input; 0 by default)
int	all	Is the <i>all buses</i> or specified subsystem flag (input; 1 by default). = 1 process all buses.
int	flt3ph	= 0 process only buses in subsystem SID. Is to report three phase faults, (0 by default). = 0 omit
int	fltlg	= 1 include Is to report line-to-ground faults (0 by default). = 0 omit
int	fltllg	= 1 include Is to report line-line-to-ground faults, (0 by default). = 0 omit
int	fltll	= 1 include Is to report line-to-line faults, (0 by default). = 0 omit
int	fltloc	= 1 include Is the location of fault (1 by default) =0 fault at network bus =1 fault at LV bus of Power Station Unit (PSU) =2 fault at auxiliary transformer (connected to PSU) LV bus
int	linout	Is to report line-out faults (0 by default).

		= 0 omit
		= 1 include
int	linend	Is to report line-end faults (0 by default).
		= 0 omit
		= 1 include
int	tpunty	Is the transformer tap ratios and phase angle option (0 by default)
		= 0 leave tap ratios and phase shift angels unchanged
		= 1 set tap ratios to 1.0 pu and phase shift angels to 0 deg
		= 2 set tap ratios to 1.0 pu and phase shift angels unchanged
		= 3 set tap ratios unchanged and phase shift angels to 0 deg
int	Inchrg	Is the line charging option (1 by default).
		= 0 leave unchanged
		= 1 set to 0.0 in the positive and negative sequences
		= 2 set to 0.0 in all sequences
int	shntop	Is the line shunts, fixed shunts, switched shunts and transformer magnetizing admittance option (1 by default).
		= 0 leave unchanged
		= 1 set to 0.0 in the positive and negative sequences
		= 2 set to 0.0 in all sequences
int	dcload	Is the dc line and FACTS device option (0 by default)
		= 0 blocked
		= 1 represent as load
int	zcorec	Is the zero sequence transformer impedance correction option (0 by default)
		= 0 ignore
		= 1 apply
int	optnftrc	Is the option for Voltage Factor C

		= 0, Voltage Factor C for maximum fault currents (default)
		= 1, Voltage Factor C for minimum fault currents
		= 2, Voltage Factor C as specified by 'vfactorc' value
int	loadop	Is the load option (1 by default)
		= 0 leave unchanged
		= 1 set to 0.0 in the positive and negative sequences
		= 2 set to 0.0 in all sequences
int	genxop	Is the synchronous machine reactance option, ignored if generators are already "converted" (0 by default).
		= 0 use subtransient reactance
		= 1 use transient reactance
		= 2 use synchronous reactance
float	brktime	Is the breaker contact parting time in seconds (5/ BaseFrequency by default)
float	vfactorc	Is the user specified Voltage Factor C
		This is used only when optnftrc=3.
str	iecfil	Is the name of IEC data (.iec) file; blank for none (input; blank by default); maximum string length=260
str	fcdfil	Is the name of fault control (.fcd) file; blank for none (input; blank by default); maximum string length=260
str	scfile	Is the IECS_3 Results (.sc) file; blank for none (output; blank by default); maximum string length=260.

Returned object 'rlst' contains the following attributes::

Index i is the ith faulted bus.

int	rlst.ierr	Is the error code
		= 0 no error occurred.
		= 1 invalid sid value or subsystem sid is not defined.
		= 2 invalid all value.
		= 3 invalid STATUS value.
		= 4 invalid brktime value.
		= 5 no faults specified.

		= 6 error opening iecfile.
		= 7 error opening fcdfile.
		= 8 prerequisite requirements for API are not met.
		= 9 error opening SCFILE
		= 10 SCFILE error
		= 11 bus SC results not available.
		= 12 branch SC results not available.
		= 13 three winding transformer SC results not available.
		= 14 incorrect SCFILE.
		= 15 SCFILE not allowed.
str	rlst.scunit	Is the units of returned fault currents
		= pu
		= physical (r.m.s. amperes)
str	rlst.scfmt	Is the coordinates of returned fault currents
		= rectangular
		= polar
int	rlst.flbus	Is a list of faulted bus numbers
complex	rlst.fl3ph[i].ia1	Is three phase fault, positive sequence current = I''_k
complex	rlst.fl3ph[i].ia2	Is three phase fault, negative sequence current
complex	rlst.fl3ph[i].ia0	Is three phase fault, zero sequence current
complex	rlst.fl3ph[i].ia	Is three phase fault, Phase A current
complex	rlst.fl3ph[i].ib	Is three phase fault, Phase B current
complex	rlst.fl3ph[i].ic	Is three phase fault, Phase C current
complex	rlst.fl3ph[i].ipb	Is three phase fault, peak current - Method B, ip(B)
complex	rlst.fl3ph[i].ipc	Is three phase fault, peak current - Method C, ip(C)
complex	rlst.fl3ph[i].idc	Is three phase fault, dc component of asymmetrical breaking current, idc
complex	rlst.fl3ph[i].ibsym	Is three phase fault, symmetrical breaking current (r.m.s.), ib(sym)
complex	rlst.fl3ph[i].ibuns	Is three phase fault, symmetrical breaking current (r.m.s.), ib(uns)
complex	rlst.fl1g[i].ia1	Is line to ground fault, positive sequence current
complex	rlst.fl1g[i].ia2	Is line to ground fault, negative sequence current
complex	rlst.fl1g[i].ia0	Is line to ground fault, zero sequence current = $I''_k/3$
complex	rlst.fl1g[i].ia	Is line to ground fault, Phase A current

complex	rlst.fltlg[i].ib	Is line to ground fault, Phase B current
complex	rlst.fltlg[i].ic	Is line to ground fault, Phase C current
complex	rlst.fltlg[i].ipb	Is line to ground fault, peak current - Method B, ip(B)
complex	rlst.fltlg[i].ipc	Is line to ground fault, peak current - Method C, ip(C)
complex	rlst.fltlg[i].idc	Is line to ground fault dc component of asymmetrical breaking current
complex	rlst.fltlg[i].ibsym	Is line to ground fault, symmetrical breaking current (r.m.s.)
complex	rlst.fltlg[i].ibuns	Is line to ground fault, asymmetrical breaking current (r.m.s.)
complex	rlst.fltlg[i].ia1	Is line line to ground fault, positive sequence current
complex	rlst.fltlg[i].ia2	Is line line to ground fault, negative sequence current
complex	rlst.fltlg[i].ia0	Is line line to ground fault, zero sequence current = $I''_k / 3$
complex	rlst.fltlg[i].ia	Is line line to ground fault, Phase A Current
complex	rlst.fltlg[i].ib	Is line line to ground fault, Phase B Current
complex	rlst.fltlg[i].ic	Is line line to ground fault, Phase C Current
complex	rlst.fltlg[i].ipb	Is line line to ground fault, peak current - Method B, ip(B)
complex	rlst.fltlg[i].ipc	Is line line to ground fault, peak current - Method C, ip(C)
complex	rlst.fltlg[i].idc	Is line line to ground fault dc component of asymmetrical breaking current, idc
complex	rlst.fltlg[i].ibsym	Is line line to ground fault, symmetrical breaking current (r.m.s.), ib(sym)
complex	rlst.fltlg[i].ibuns	Is line line to ground fault, asymmetrical breaking current (r.m.s.), ib(uns)
complex	rlst.fltl[i].ia1	Is line to line fault, positive sequence current
complex	rlst.fltl[i].ia2	Is line to line fault, negative sequence current
complex	rlst.fltl[i].ia0	Is line to line fault, zero sequence current
complex	rlst.fltl[i].ia	Is line to line fault, Phase A current
complex	rlst.fltl[i].ib	Is line to line fault, Phase B current = I''_k
complex	rlst.fltl[i].ic	Is line to line fault, Phase C current = $-I''_k$
complex	rlst.fltl[i].ipb	Is line to line fault, peak current - Method B, ip(B)
complex	rlst.fltl[i].ipc	Is line to line fault, peak current - Method C, ip(C)
complex	rlst.fltl[i].idc	Is line to line fault, dc component of asymmetrical breaking current, idc
complex	rlst.fltl[i].ibsym	Is line to line fault, symmetrical breaking current (r.m.s.), ib(sym)
complex	rlst.fltl[i].ibuns	Is line to line fault, asymmetrical breaking current (r.m.s.), ib(uns)
complex	rlst.thevz[i].z1	Is PU Thevenin impedance, positive sequence

complex	rlst.thevzpu[i].z2	Is PU Thevenin impedance, negative sequence
complex	thevzpu[i].z0	Is PU Thevenin impedance, zero sequence
complex	rlst.maxflt[i].ia1	Is maximum fault current, positive sequence current
complex	rlst.maxflt[i].ia2	Is maximum fault current, negative sequence current
complex	rlst.maxflt[i].ia0	Is maximum fault current, zero sequence current
complex	rlst.maxflt[i].ia	Is maximum fault current, Phase A current
complex	rlst.maxflt[i].ib	Is maximum fault current, Phase B current
complex	rlst.maxflt[i].ic	Is maximum fault current, Phase C current
str	rlst.maxfltdsc[i]	Is description of fault condition for maximum fault current

Note: Maximum fault current is the largest fault current among analyzed faults at a bus.

23.9. OTDF_FACTORS

This function returns the OTDF factors array. The PSS[®] E case must be opened prior to execution of this function. Also the dfxfile provided must correspond to the PSS[®] E case opened.

Python syntax:

```
rlst = pssarrays.otdf_factors(dfxfile)
```

where:

string	dfxfile	Is the name of distribution factor .dfx file (input, no default allowed), maximum string length=260
--------	---------	---

Returned object 'rlst' contains the following attributes:

integer	rlst.ierr	Is the error code =0 no error occurred =1 no Distribution Factor Data File specified =2 generators are converted =3 buses in island(s) without a swing bus; use activity TREE =4 error opening file DFXFILE =5 file DFXFILE is not in the form of a PSS [®] E-25 or later DFAX file; run DFAX =6 file does not contain distribution factors; run DFAX with distribution factor option enabled =7 no monitored branches or interfaces defined =8 prerequisite requirements for API are not met =9 requires opened SAV file, for retrieving OTDF factors
integer	rlst.size.nmline	Is the number of monitored branches
integer	rlst.size.ninter	Is the number of monitored interfaces
integer	rlst.size.ncase	Is the number of contingencies + 1 (for base case)
string	rlst.casetitle.line1	Is the case short title line 1, maximum string length=60
string	rlst.casetitle.line2	Is the case short title line 2, maximum string length=60
string	rlst.file.sav	Is the name of saved case (.sav) file, maximum string length=260
string	rlst.file.dfx	Is the name of distribution factor data (.dfx) file, maximum string length=260

string	rlst.file.sub	Is the name of subsystem definition data (.sub) file, maximum string length=260
string	rlst.file.mon	Is the name of monitored element data (.mon) file, maximum string length=260
string	rlst.file.con	Is the name of contingency description data (.con) file, maximum string length=260
string	rlst.melement	Is a list of length (nmline+ninter) of monitored branch and interface names, maximum string length=54
string	rlst.colabel	Is a list of length (ncase) of contingency labels, maximum string length=12
string	rlst.codesc	Is a list of length (ncase) of contingency description, maximum string length=152
float	rlst.factor	Is a list of list OTDF factors, list of ncase elements with each element is a list of nmline+ninter values

23.10. PV_SUMMARY

This functions returns PV analysis summary.

Python syntax:

```
rlst = pssarrays.pv_summary(pvfile)
```

where:

string	pvfile	PV output filename (.pv), (input, no default allowed), maximum string length=260
--------	--------	--

Returned object 'rlst' contains the following attributes:

int	rlst.ierr	error code: =0 no error =1 file not PV type =4 requires SAV file
int	rlst.pvsize.ncase	number of contingencies + 1 (for base case)
int	rlst.pvsize.nmline	number of monitored branches
int	rlst.pvsize.ninter	number of monitored interfaces
int	rlst.pvsize.nmvbus	number of voltage monitored buses
int	rlst.pvsize.nmvrec	number of voltage monitored records
int	rlst.pvsize.nmgdbus	number of monitored plant (generator) buses
int	rlst.pvsize.nmldbus	number of monitored load buses
int	rlst.pvsize.nmxtrns	maximum number of MW transfer changes
int	rlst.options	PV solution options (same as in API manual)
float	rlst.values	PV solution values (same as in API manual)
string	rlst.brnflowunits.xfrcur	PV solution transformer branch flow units ('mbrnamp' in pv_solution return list)
string	rlst.brnflowunits.nxfrcr	PV solution non-transformer branch flow units ('mbrnamp' in pv_solution return list)
string	rlst.casetitle.line1	short title line 1
string	rlst.casetitle.line2	short title line 2
string	rlst.file.pv	contingency output (.acc) filename
string	rlst.file.sav	saved case (.sav) filename
string	rlst.file.ecd	economic dispatch data (.ecd) filename
string	rlst.file.thr	load throwover data (.thr) filename
string	rlst.file.dfx	distribution factor data (.dfx) filename
string	rlst.file.sub	subsystem definition data (.sub) filename
string	rlst.file.mon	monitored element data (.mon) filename
string	rlst.file.con	contingency description data (.con) filename
string	rlst.srcsink	source and sink subsystem names

string	rlst.mbranch	monitored branch names
float	rlst.mbrnrating.a	rating A
float	rlst.mbrnrating.b	rating B
float	rlst.mbrnrating.c	rating C
string	rlst.minterface	monitored interface names
float	rlst.mitfrating	selected rating of monitored interface
string	rlst.mgenbus	monitored plant (generator) bus label
string	rlst.mloadbus	monitored load bus label
string	rlst.mvbuslabel	monitored voltage bus label
string	rlst.mvreclabel	monitored voltage record label
float	rlst.mvrecmax	monitored voltage bus maximum
float	rlst.mvrecmin	monitored voltage bus minimum
string	rlst.mvrectype	monitored voltage record type (range/deviation)
string	rlst.colabel	contingency labels
string	rlst.codesc	contingency description
float	rlst.maxmw	maximum MW transfer

23.11. PV_SUMMARY_REPORT

This function creates PV analysis summary text report.

Python syntax:

```
ierr = pv_summary_report(pvfile, rptfile)
```

where:

string	pvfile	PV output filename (.pv), (input, no default allowed), maximum string length=260
string	rptfile	Is the name of report file (input, PSS [®] E Report by default), maximum string length=260

Returns:

int	rlst.ierr	error code:
		=0 no error
		=1 file not PV type
		=4 requires SAV file

23.12. PV_SOLUTION

This functions returns PV analysis monitored flows and bus voltages for one contingency.

Python syntax:

```
rlst = pssarrays.pv_solution(pvfile, colabel)
```

where:

string	pvfile	PV output filename (.pv), (input, no default allowed), maximum string length=260
string	colabel	Is the name of contingency label to get PV solution for, only one label allowed (input, no default allowed), maximum string length=12

Returned object 'rlst' contains the following attributes:

int	rlst.ierr	error code: =0 no error =1 file not PV type =4 requires SAV file
int	rlst.island	number of islands
float	rlst.mwtransfer	MW transactions, list of size [ntrns]
boolean	rlst.cnvflag	convergence flag (True when converged), list of size [ntrns]
string	rlst.cnvcond	convergence condition
float	rlst.mvaworst	largest bus MVA mismatch, list of size [ntrns]
float	rlst.mvatotal	total system MVA mismatch, list of size [ntrns]
float	rlst.volts	monitored bus voltage (pu), list of size [nmvbus][ntrns]
float	rlst.mgenmw	monitored plant MW, list of size [nmgnbus][ntrns]
float	rlst.mgenmvar	monitored plant MVAR, list of size [nmgnbus][ntrns]
float	rlst.mloadmw	monitored load MW, list of size [nmldbus][ntrns]
float	rlst.mloadmvar	monitored load MVAR, list of size [nmldbus][ntrns]
float	rlst.mbrnmva	monitored branch MVA flow (MVA), list of size [nm-line][ntrns]
float	rlst.mbrnamp	monitored branch flow, AMPS expressed in MVA or MVA, list of size [nm-line][ntrns]. The brnflowunits variable in pv_summary determine the units. Use this value to calculate branch loadings.
float	rlst.mitfmw	monitored interface MW flow (MW), list of size [ninter][ntrns]

where

ntrns =number of MW transfer changes

nmvbus =number of voltage monitored buses

nmgnbus =number of monitored plant (generator) buses

nmldbz =number of monitored load buses

nmline =number of monitored branches

ninter =number of monitored interfaces

23.13. PV_SOLUTION_REPORT

This function creates PV analysis solution text report.

Python syntax:

```
ierr = pv_solution_report(pvfile, colabels, rptfile)
```

where:

string	pvfile	PV output filename (.pv), (input, no default allowed), maximum string length=260
string	colabels	Is the list of contingency label names (input, all contingencies in accfile by default), maximum string length=12
string	rptfile	Is the name of report file (input, PSS® E Report by default), maximum string length=260

Returns:

int	rlst.ierr	error code: =0 no error =1 file not PV type =4 requires SAV file
-----	-----------	---

23.14. QV_SOLUTION

This functions returns QV analysis monitored flows and bus voltages for one contingency.

Python syntax:

```
rlst = pssarrays.qv_solution(qvfile, colabel)
```

where:

string	qvfile	QV output filename (.qv), (input, no default allowed), maximum string length=260
string	colabel	Is the name of contingency label to get QV solution for, only one label allowed (input, no default allowed), maximum string length=12

Returned object 'rlst' contains the following attributes:

int	rlst.ierr	error code: =0 no error =2 file not QV type =5 requires SAV file
int	rlst.island	number of islands
float	rlst.vsetpoint	voltage setpoints, list of size [nvstp]
boolean	rlst.cnvflag	convergence flag (True when converged), list of size [nvstp]
string	rlst.convcond	convergence condition
float	rlst.mvaworst	largest bus MVA mismatch, list of size [nvstp]
float	rlst.mvatotal	total system MVA mismatch, list of size [nvstp]
float	rlst.volts	monitored bus voltage (pu), list of size [nmvbus][nvstp]
float	rlst.mgenmvar	monitored plant Mvar, list of size [nmgnbus][nvstp]

where

ntrans = number of voltage setpoint changes

nmvbus = number of voltage monitored buses

nmgnbus = number of monitored plant (generator) buses

23.15. QV_SOLUTION_REPORT

This function creates QV analysis solution text report.

Python syntax:

```
ierr = qv_solution_report(qvfile, colabels, rptfile)
```

where:

string	qvfile	QV output filename (.qv), (input, no default allowed), maximum string length=260
string	colabels	Is the list of contingency label names (input, all contingencies in accfile by default), maximum string length=12
string	rptfile	Is the name of report file (input, PSS [®] E Report by default), maximum string length=260

Returned list (accessed by attributes as):

int	rlst.ierr	error code:
		=0 no error
		=2 file not QV type
		=5 requires SAV file

23.16. QV_SUMMARY

This functions returns QV analysis summary.

Python syntax:

```
rlst = pssarrays.qv_summary(qvfile)
```

where:

string	qvfile	QV output filename (.qv), (input, no default allowed), maximum string length=260
--------	--------	--

Returned object 'rlst' contains the following attributes:

int	rlst.ierr	error code: =0 no error =2 file not QV type, =5 requires SAV file
int	rlst.qvbus	QV analysis bus name
int	rlst.qvsize.ncase	number of contingencies + 1 (for base case)
int	rlst.qvsize.nmvbus	number of voltage monitored buses
int	rlst.qvsize.nmvrec	number of voltage monitored records
int	rlst.qvsize.nmgmbus	number of monitored plant (generator) buses
int	rlst.qvsize.nmxvstp	maximum number of voltage setpoint changes
int	rlst.options	QV solution options (same as in API manual)
string	rlst.values	QV solution values (same as in API manual)
string	rlst.casetitle.line1	short title line 1
string	rlst.casetitle.line2	short title line 2
string	rlst.file.qv	contingency output (.acc) filename
string	rlst.file.sav	saved case (.sav) filename
string	rlst.file.thr	load throwover data (.thr) filename
string	rlst.file.dfx	distribution factor data (.dfx) filename
string	rlst.file.sub	subsystem definition data (.sub) filename
string	rlst.file.mon	monitored element data (.mon) filename
string	rlst.file.con	contingency description data (.con) filename
string	rlst.mgenbus	monitored plant (generator) bus label
string	rlst.mvbuslabel	monitored voltage bus label
string	rlst.mvreclabel	monitored voltage record label
float	rlst.mvrecmax	monitored voltage bus maximum
float	rlst.mvrecmin	monitored voltage bus minimum
string	rlst.mvrectype	monitored voltage record type (range/deviation)
string	rlst.colabel	contingency labels
string	rlst.codesc	contingency description

float	rlst.minvstp	minimum voltage setpoint
float	rlst.maxvstp	maximum voltage setpoint
float	rlst.minmvar	minimum MVAR change
float	rlst.maxmvar	maximum MVAR change
float	rlst.maxmsm	maximum MVAR mismatch

23.17. QV_SUMMARY_REPORT

This function creates QV analysis summary text report.

Python syntax:

```
ierr = qv_summary_report(qvfile, rptfile)
```

where:

string	qvfile	QV output filename (.qv), (input, no default allowed), maximum string length=260
string	rptfile	Is the name of report file (input, PSS [®] E Report by default), maximum string length=260

Returned list (accessed by attributes as):

int	rlst.ierr	error code:
		=0 no error
		=2 file not QV type
		=5 requires SAV file

Chapter 24

PSSEXCEL Module

The pssexcel module provides Python functions to export PSS[®] E data or solution results to Excel spreadsheets.

These functions do not record themselves when called while recording is enabled in PSS[®] E.

Please note that these routines are members of the pssexcel Python extension module, not psspy. The syntax on the following pages assumes that the module has been imported by executing:

```
import pssexcel
```

24.1. ACCC

This function exports ACCC analysis results to Excel Spreadsheet.

Python syntax:

```
pssexcel.accc(accfile, string, colabel='',
             stype='contingency', busmsm=0.5, sysmsm=5.0, rating='a', namesplit=True,
             xlsfile='', sheet='', overwritesheet=True, show=True, ratecon='b',
             baseflowvio=True,
             basevoltvio=True, flowlimit=100.0, flowchange=0.0, voltchange=0.0,
             swdrating='a',
             swdratecon='b', baseswdfLOWvio=False, basenodevoltvio=False,
             overloadreport=False)
```

where:

string	accfile	ACCC analysis output filename (.acc), no default allowed
string	string	Name or list of names indicating which results to export, no default allowed. Allowed strings: 's' or 'summary' - ACCC Analysis Summary 'e' or 'events' - Contingency Events Description 'b' or 'branch' - Monitored Branch Flow (MVA) 'i' or 'interface' - Monitored Interface Flow (MW) 'v' or 'voltage' - Monitored Bus Voltage 'l' or 'load' - Loads Shed (MW) 'g' or 'generator' - Generator Dispatch (MW)

		'p' or 'phase shifter'
		Phase Shifter Angle
		'n' or 'node voltage'
		Monitored Node Voltage
		'w' or 'swd flow'
		Monitored SWD Flow (MVA)
		Example: string =
		'v
		'or
		['s', 'v', 'g', 'l', 'b', 'i', 'n', 'w']
string	colabel	Contingency label or list of contingency labels for which the solution is exported, default - all contingencies, not required when exporting only summary
string	stype	Is the name of solution type to get (input, contingency by default), allowed values: contingency, con, tripping, trp, caction, contingency action, cor
float	busmsm	Is the value of bus mismatch tolerance in MVA (input, 0.5 MVA by default)
float	sysmsm	Is the value of system mismatch tolerance in MVA (input, 5.0 MVA by default)
string	rating	s the value of rating to use to calculate base case percentage overload, default 'a', allowed values: 'a', 'b', or 'c'
string	stype	Is the name of solution type to get (input, <i>contingency</i> by default allowed), allowed values: <i>contingency</i> , <i>con</i> , <i>tripping</i> , <i>trp</i> , <i>caction</i> , <i>contingency action</i> , <i>cor</i>
float	busmsm	Is the value of bus mismatch tolerance in MVA (input, 0.5 MVA by default)
float	sysmsm	Is the value of system mismatch tolerance in MVA (input, 5.0 MVA by default)
string	rating	Rating to use to calculate percentage overload. Default 'a', allowed values: 'a', 'b', 'c', ..., 'l'.
boolean	namesplit	Split extended bus names, default True
		= True bus names split into three values: number name and bus voltage (three columns in worksheet)
		= False bus names are kept as single value string (one column in worksheet)
string	xlsfile	Excel workbook name, default Book#.xls

string	sheet	Excel worksheet name, default (blank string), depending on string input, worksheets created are: Summary ACCC Analysis Summary Contingency Events Events Description Branch Flow Monitored Branch Flow (MVA) Interface Flow Monitored Interface Flow (MW) Bus Voltage Monitored Bus Voltage Load Shed Loads Shed (MW) Generator Dispatch Generator Dispatch (MW) Phase Shifter Angle Monitored Node Voltage Monitored SWD flow (MVA) (degrees) All worksheet names are prefixed with sheet name, when provided.
boolean	overwritesheet	Overwrite worksheets flag, default True = True existing worksheets are overwritten

		= False existing worksheets are copied and their names appended with (#) where # is next sequence number.
boolean	show	Show or Hide Excel Spreadsheet flag, default True
		= True open and show Excel Spreadsheet
		= False do not show Excel Spreadsheet (create and save)
string	ratecon	Is the value of rating to use to calculate Contingency Case percentage overload default 'b', allowed values:'a', 'b', 'c', ..., 'l'.
boolean	baseflowvio	Exclude elements with base case loading violations from contingency reports default True, allowed values: True or False
boolean	basevoltvio	Exclude buses with base case voltage range violations from contingency reports default True, allowed values: True or False
float	flowlimit	Percent of flow rating, default=100 for 100% Show monitored elements with flow above flowlimit value.
		flowlimit=0 will export flows for all elements.
float	flowchange	Minimum contingency case flow change in MVA for overload reports
		default 0 MVA, allowed values: Any number
float	voltchange	Minimum contingency case voltage change in pu for voltage range violations
		default 0 pu, allowed values: Any number
string	swdrating	Is the value of rating to use to calculate Base Case SWD percentage overload default 'a', allowed values:'a', 'b', or 'c'.
string	swdratecon	Is the value of rating to use to calculate Contingency Case SWD percentage overload default 'b', allowed values:'a', 'b', or 'c'.
boolean	baseswdfflowvio	Exclude SWD flow results with base case loading violations from contingency reports default True, allowed values: True or False
boolean	basenodevoltvio	Exclude node voltage results with base case voltage range violations from contingency reports default True, allowed values: True or False
boolean	overloadreport	Is the Flag to only report overload power flow and overvoltage bus voltage (True) or report all the results (False). percentage overload default False.

24.2. iec_data_file

This function exports synchronous machines, asynchronous machines and transformer data from PSS[®]E Saved Case required to assemble IEC fault data input file as an Excel[®] spreadsheet. IEC data file (.iec) is used by IECS API. The PSS[®]E Saved case must be opened prior to execution of this function.

It creates three worksheets 'Machines', 'Transformers' and 'IEC Data'.

This file is used as a convenient way to create an .iec file by copy/paste generator and transformer records to form a power station unit, modify the generator, motor and transformer data as required by IECS API. After appropriate modifications, save IEC Data worksheet as comma separated file with extension .iec. This file then can be used as *Fault data input file* to the IECS API.

Python syntax:

```
pssexcel.iec_data_file(xlsfile, sheet, overwritesheet,
                        show)
```

where:

string	xlsfile	Is the name of excel workbook filename (input, default savefile prefix and extension .iec)
string	sheet	Excel worksheet name, default (blank string), worksheets created are: Machines Saved case machines data Transformers Saved case two and three windings transformers data IEC Data Data required by IECS API
boolean	overwritesheet	All worksheet names are prefixed with sheet name, when provided. Overwrite worksheets flag, default True = True existing worksheets are overwritten = False existing worksheets are copied and their names appended with (#), where # is next sequence number.
boolean	show	Show or Hide Excel Spreadsheet flag, default True = True open and show Excel Spreadsheet

= False do not show Excel Spreadsheet (create and save)

24.3. pv

This function exports PV solution results to Excel Spreadsheet.

Python syntax:

```
pssexcel.pv(pvfile, string, colabel, namesplit,
            xlsfile, sheet, overwritesheet, show)
```

where:

string	pvfile	PV analysis output filename (.pv), no default allowed
string	string	Name or list of names indicating which results to export, no default allowed. Allowed strings: 's' or 'summary' - PV Solution Summary 'v' or 'voltage' - Monitored Bus Voltage 'm' or 'mismatch' - Largest and Total Mismatch 'g' or 'generator' - Monitored Plants MW and MVAR 'l' or 'load' - Monitored Loads MW and MVAR 'b' or 'branch' - Monitored Branch Flow (MVA) 'i' or 'interface' - Monitored Interface Flow (MW)

Example:

```
string = 'v' or
string =
['s', 'm', 'v', 'g', 'l', 'b', 'i']
```

string	colabel	Contingency label or list of contingency labels for which the solution is exported, default - all contingencies, not required when exporting only summary
boolean	namesplit	Split extended bus names, default True = True bus names split into three values: number name and bus voltage (three columns in worksheet) = False bus names are kept as single value string (one column in worksheet)
string	xlsfile	Excel workbook name, default Book#.xls
string	sheet	Excel worksheet name, default " (blank string), depending on string input, worksheets created are: Summary PV Solution Summary Bus Voltage Monitored Bus Voltage Mismatch Largest and Total Mismatch Generator Dispatch Monitored Plants MW and MVAR Bus Load Monitored Loads MW and MVAR Branch Flow Monitored Branch Flow (MVA) Interface Flow Monitored Interface Flow (MW)
boolean	overwritesheet	All worksheet names are prefixed with sheet name, when provided. Overwrite worksheets flag, default True = True existing worksheets are overwritten

boolean	show	= False existing worksheets are copied and their names appended with (#) where # is next sequence number. Show or Hide Excel Spreadsheet flag, default True = True open and show Excel Spreadsheet = False do not show Excel Spreadsheet (create and save)
---------	------	--

24.4. qv

This function exports QV solution results to Excel Spreadsheet.

Python syntax:

```
pssexcel.qv(qvfile, string, colabel, namesplit,
            xlsfile, sheet, overwritesheet, show)
```

where:

string	qvfile	QV analysis output filename (.qv), no default allowed
string	string	Name or list of names indicating which results to export, no default allowed. Allowed strings: 's' or 'summary' QV Solution Summary 'v' or 'voltage' Monitored Bus Voltage 'm' or 'mismatch' Largest and Total Mismatch 'g' or 'generator' Monitored Plants MW and MVAR
		Example:
		<pre>string = 'v' or</pre> <pre>string = ['s', 'm', 'v', 'g']</pre>
string	colabel	Contingency label or list of contingency labels for which the solution is exported, default - all contingencies, not required when exporting only summary
boolean	namesplit	Split extended bus names, default True = True bus names split into three values: number name and bus voltage (three columns in worksheet) = False bus names are kept as single value string (one column in worksheet)
string	xlsfile	Excel workbook name, default Book#.xls
string	sheet	Excel worksheet name, default "" (blank string), depending on string input, worksheets created are:

Summary

QV

Solution Summary

Bus Voltage

Monitored
Bus Voltage

Mismatch

Largest
and Total Mismatch

Generator Dispatch

Monitored Plants MVAR

		All worksheet names are prefixed with sheet name, when provided.
boolean	overwritesheet	Overwrite worksheets flag, default True = True existing worksheets are overwritten = False existing worksheets are copied and their names appended with (#) where # is next sequence number.
boolean	show	Show or Hide Excel Spreadsheet flag, default True = True open and show Excel Spreadsheet = False do not show Excel Spreadsheet (create and save)

Chapter 25

EXCELPY Module

The excelpy module provides Python functions to interface with Excel. Use this module to create, populate and format Excel workbooks from Python.

These functions do not record themselves when called while recording is enabled in PSS®E.

Please note that these routines are members of the excelpy Python extension module, not psspy. The syntax on the following pages assumes that the module has been imported by executing:

```
import excelpy
```

Following are the definition of arguments used by various functions defined in this module.

string or int	address	tuple of integers/strings. Allowed address when specifying cell: 'adrstr' or ('adrstr') or (row, 'clnstr') or (row, column) Example: Cell address referencing 2nd row, column A, can be provided as- 'a2' or ('a2') or (2, 'a') or (2,1) range: ('adrstr1', 'adrstr2') or (toprow, 'leftcolumnstr', bottomrow, 'rightcolumnstr') or (toprow, leftcolumn, bottomrow, rightcolumn) or ('adrstr1', (bottomrow, rightcolumn)) or (('adrstr1', (bottomrow, 'rightcolumnstr'))) ((toprow, leftcolumn), 'adrstr2') or ((toprow, 'leftcolumnstr'), 'adrstr2')
---------------	---------	---

		where row, column, toprow, leftcolumn, bottomrow, rightcolumn are integer values, adrstr, adrstr1, adrstr2 are cell address string values, and clnstr, leftcolumnstr, rightcolumnstr are column name string values.
string	alignv	Note: Column and address reference string values are case-insensitive. alignment value for cell, range, rows or columns. Allowed values when specifying horizontal alignment: 'left', 'right', 'h_center' vertical alignment: 'top', 'bottom', 'v_center'
string	borderv	border name. Allowed border names when formatting: cell: 'diagonaldown', 'diagonalup', 'top', 'bottom', 'left', 'right', 'none', 'outline' range: 'diagonaldown', 'diagonalup', 'top', 'bottom', 'left', 'right', 'inside', 'hinside', 'vinside', 'none', 'outline'
string or int	borderColor	string, color name; or integer, color index. Allowed color names: 'black', 'white', 'red', 'green', 'blue', 'yellow', 'magenta', 'cyan', 'brown', 'dgreen', 'dblue', 'orange'

		Allowed ColorIndex: 1 to 56 as per ColorIndex property in Excel Visual Basic Reference.
string	borderStyle	border style name. Allowed names: 'continuous', 'dash', 'dashdot', 'dashdotdot', 'dot', 'double', 'none', 'slantdashdot'
string	borderWeight	border weight name. Allowed names: 'hairline', 'medium', 'thick', 'thin'
string	fontStyle	font style name, specified as style name or tuple of style names. Allowed font style names: 'regular', 'bold', 'italic', 'underline'
		Example: (Italic,Bold) or 'bold'
string or int	fontColor	string, color name; or integer, color index.
		This is same as color in 'borderColor'.
string	numberFormat	number format Example: 0.000 for three decimal places
int	leftCol	left column number
string	newSheet	name of the new worksheet
string	oldSheet	name of the worksheet used as reference for worksheet operations
boolean	overwritesheet	overwrite if worksheet exists, Allowed values: = True existing worksheet will be overwritten. = False existing sheet copied and its name appended with (#), where # is next sequence number.

string	sheetspreadsheet	Used when creating new worksheets or re-naming existing worksheets. name of the excel worksheet. If sheet is not provided, active worksheet used.
int	topRow	top row number
boolean	wrapText	wrap text or not, Allowed values: True or False
string	xlsfile	name of the Excel workbook

Default Workbook Style

The excel workbook is created with following default font style:

Black, Regular, Courier New, size 10, no wrapText,
General number format

How to Use?

Create xls file object as below and apply various methods defined here.

(1) When used to create new Excel files or add worksheets to existing Excel files:

```
testxls = excelpy.workbook()
```

```
testxls = excelpy.workbook(r"c:\working dir\ex1.xls")
```

```
testxls = excelpy.workbook(r"c:\working dir\ex1.xls", "MySheet") or
```

```
testxls = excelpy.workbook(r"c:\working dir\ex1.xls", "MySheet", False) or
```

```
testxls = excelpy.workbook(r"c:\working dir\ex1.xls", "MySheet", False, 'w') or
```

```
testxls = excelpy.workbook(xlsfile=r"c:\working dir\ex1.xls", sheet="MySheet",  
overwritesheet=False, mode='w')
```

(2) When used to read existing Excel files:

```
testxls = excelpy.workbook(r"c:\working dir\ex1.xls", mode='r')
```

Note: When using Excel 2007 and later, create file in either 'xlsx' or 'xls' format.

Excel 2003 and earlier - default save format 'xls'.

Excel 2007 and later - default save format 'xlsx'.

25.1. Methods

The following methods are members of the excelpy class that can be instantiated using the workbook functions defined in [Section 25.2, "Workbook Functions"](#). In all these methods, when sheet=None or not provided, active worksheet is used.

align(address, alignv, sheet=None)

Align Cell or Range.

cell, address = (row,col)

range, address = (topRow,leftCol,bottomRow,rightCol)

align_columns(address, alignv, sheet=None)

Align one or more columns.

One column, address = (row,col)

Multiple columns, address = (topRow,leftCol,topRow,rightCol)

align_rows(address, alignv, sheet=None)

Align one or more rows.

One row, address = (row,col)

Multiple rows, address = (topRow,leftCol,bottomRow,leftCol)

autofit_columns(address, sheet=None)

Autofit column or columns.

One column, address = (row,col)

Multiple columns, address = (topRow,leftCol,topRow,rightCol)

autofit_rows(address, sheet=None)

Autofit row or rows.

One row, address = (row,col)

Multiple rows, address = (topRow,leftCol,bottomRow,leftCol)

border(address, borderv, borderStyle='continuous', borderWeight='hairline', borderColor='black', sheet=None)

Format Cell or Range borders.

cell, address = (row,col)

range, address = (topRow,leftCol,bottomRow,rightCol)

close()

Close active Excel workbook and quit Excel application.

delete_columns(address, howmany=1, sheet=None)

Delete columns to the right of specified row.

row address = (row,col)

Number of columns deleted is provided by integer value 'howmany'.

delete_rows(address, howmany=1, sheet=None)

Delete rows below specified row.

row address = (row,col)

Number of rows deleted is provided by integer value 'howmany'.

fontaddress, fontStyle=None, fontName=None, fontSize=None, fontColor=None, wrapText=False, numberFormat=None, sheet=None)

Set cell or range font properties: style, name, size, color, wrap, number format

Cell, address = (row,col)

Range, address = (topRow,leftCol,bottomRow,rightCol)

font_color(address, color, sheet=None)

Set cell or range font color.

Cell, address = (row,col)

Range, address = (topRow,leftCol,bottomRow,rightCol)

font_sheet(fontStyle=('Regular',), fontName='Courier

New', fontSize=10, fontColor='black', wrapText=False, numberFormat=None, sheet=None)

Set font properties for Excel sheet: style, name, size, color, wrap, number format

freezepanes(address, sheet=None)

Freeze worksheet panes.

address = (row,1) to freeze worksheet rows above 'row'

address = (1, col) to freeze worksheet columns left of 'col'

address = (row,col to freeze worksheet rows above 'row' and columns

left of 'col'

height(address, height, sheet=None)

Set height of one row or multiple rows. Height is provided in points.

One row, address = (row,col)

Multiple rows, address = (topRow,leftCol,bottomRow,rightCol)

hide()

Hide opened Excel workbook.

merge(address, sheet=None)

Merge cells in the range.

page_footer(left=None, center=None, right=None, sheet=None)

Set page left, center, and right footers. Footer input value is a string.

page_format(orientation='portrait', left=1.0, right=1.0, top=1.0, bottom=1.0, header=0.5, footer=0.5, sheet=None)

Set page format: orientation, margins (given in inches).

```
Orientation = 'portrait' or 'p' or 1
              = 'landscape' or 'l' or 2
```

Defaults:

```
orientation = Portrait
```

```
margins: left  = 1.0 inch
```

```
          right = 1.0 inch
```

```
          top   = 1.0 inch
```

```
          bottom = 1.0 inch
```

```
          header = 0.5 inch
```

```
          footer = 0.5 inch
```

page_header(left=None, center=None, right=None, sheet=None)

Set page left, center, and right headers. Header input value is a string.

page_landscape(sheet=None)

Set page orientation to landscape.

page_margin(left=1.0, right=1.0, top=1.0, bottom=1.0, header=0.5, footer=0.5, sheet=None)

Set page margins. The margin value is given in inches.

page_portrait(sheet=None)

Set page orientation to portrait.

save(xlsfile=None)

Save active Excel workbook.

xlsfile = save(xlsfile)

Returns name of the saved Excel file.

set_active_sheet(sheet)

Set 'sheet' as active worksheet.

set_cell(address, value, fontStyle=None, fontName=None, fontSize=None, fontColor=None, wrapText=False, numberFormat=None, sheet=None)

Set value to one cell.

set_range(topRow, leftCol, data, transpose=False, fontStyle=None, fontName=None, fontSize=None, fontColor=None, wrapText=False, numberFormat=None, sheet=None)

Set data to cells in the range.

bottomRow, rightCol = set_range(topRow, leftCol, data,)

Boolean, transpose: Allowed values: True or False

Excel methods write data row by row. If data in Python list of lists, or tuple of tuples or any combination of these, is not stored row by row, transpose that data. This functions works same as matrix transpose.

Returns:

bottomRow: Bottom row number after writing input data to worksheet.

rightCol : Right column number after writing input data to worksheet.

show()

Show opened Excel workbook.

show_alerts(display)

Show or suppresses all POP-UP windows, like File Overwrite Yes/No/Cancel, Merge Overwrite.

Boolean, display: Allowed values: True or False, 1 or 0

= True or 1, show alerts

= False or 0, do not show alerts. Data will be overwritten.

transpose_data(data, transpose=True)

Transpose data.

Excel methods write data row by row. If data in Python list of lists, or tuple of tuples or any combination of these, is not stored row by row, transpose that data. This functions works same as matrix transpose.

nrows, nclns, datat = set_range(data, transpose=True)

data : any type of data to be tranposed

transpose: boolean, allowed values: True or False, True by default

Returns:

nrows - number of rows in transposed data

ncols - number of columns in transposed data

data - transposed data

width(address, width, sheet=None)

Set width of one column or multiple columns. Width is provided in points.

One column, address = (row,col)

Multiple columns, address = (topRow,leftCol,topRow,rightCol)

worksheet_add_after(newSheet=None, oldSheet=None, overwritesheet=True)spreadsheet

Add a newSheet after the oldSheet or active sheet. If newSheet name is not provided, Sheet# worksheet is added. If oldSheet name is not provided, worksheet is added at the end. Sheet# is a next available sheet number in the active workbook.

worksheet_add_before(newSheet=None, oldSheet=None, overwritesheet=True)

Add a newSheet before the oldSheet or active sheet. If newSheet name is not provided, Sheet# worksheet is added. If oldSheet name is not provided, worksheet is added at the end. Sheet# is a next available sheet number in the active workbook.spreadsheet

worksheet_add_begin(sheet=None, overwritesheet=True)

Add a sheet at the beginning. If sheet name is not provided, Sheet# worksheet is added. Sheet# is a next available sheet number in the active workbook.spreadsheet

worksheet_add_end(sheet=None, overwritesheet=True)spreadsheet

Add a sheet at the end. If sheet name is not provided, Sheet# worksheet is added. Sheet# is a next available sheet number in the active workbook.

worksheet_delete(sheet)

Delete a sheet from active workbook.

worksheet_left_columns2repeat(columns, sheet=None)spreadsheet

Repeat 'columns' at the left of each page of the worksheet.

'columns' is specified as tuple or list of column numbers,

e.g., columns = (1,3) to repeat columns 1 to 3 at the left or

columns = 1 to repeat column 1 at the left.

worksheet_rename(newSheet, oldSheet=None, overwritesheet=True)spreadsheet

Rename Excel 'oldSheet' or active sheet with newSheet name.

overwritesheet = True, contents of oldSheet are deleted, so newSheet is blank worksheet

= False, contents of oldSheet are written to newSheet.\

worksheet_size_violation(topRow, leftCol, data=None, transpose=False)

Get worksheet size violations and extents.

Inputs:

data - List or List of Lists values to be written transpose - Logical

Excel methods write data row by row. If data in Python list of lists, or tuple of tuples or any combination of these, is not stored that way, transpose that data. This functions same as matrix transpose.

Returns:

Returned tuple contains:

row_violation = rtple[0], True when top/bottom row exceeds maximum allowable rows

col_violation = rtple[2], True when left/right column exceeds maximum allowable columns

topRow = rtple[3], top row number

leftCol = rtple[4], left column number

bottomRow = rtple[5], bottom row number

rightCol = rtple[6], right column number

wshtmaxrows = rtple[7], = 65536, maximum number of rows allowed in a worksheet

wshtmaxcols = rtple[8], = 256, maximum number of columns allowed in a worksheet

worksheet_top_rows2repeat(rows, sheet=None)spreadsheet

Repeat 'rows' at the top of each page of the worksheet.

'rows' is specified as tuple or list of row numbers,

e.g., rows = (1,3) to repeat rows 1 to 3 at the top or

rows = 1 to repeat row 1 at the top.

wraptext(address, sheet=None)

Wrap Text inside the cell or range.

Cell, address = (row,col)

Range, address = (topRow,leftCol,topRow,rightCol)

25.2. Workbook Functions

Use this function to create an Excel workbook object that will possess the methods defined in [Section 25.1, "Methods"](#).

Python syntax:

```
excelpy.workbook(xlsfile=None, sheet=None,  
overwritesheet=True)
```

Examples:

```
testxls = excelpy.workbook()  
  
testxls = excelpy.workbook("c:\working dir\test1.xls")  
  
testxls = excelpy.workbook("c:\working dir\test1.xls",  
"MySheet")  
  
testxls = excelpy.workbook("c:\working dir\test1.xls",  
"MySheet",  
False)  
  
testxls = excelpy.workbook(xlsfile="c:\working  
dir\test1.xls",  
sheet="MySheet", overwritesheet=False)
```

Chapter 26

GICDATA Module

The gicdata module provides Python functions to create the GIC data file required in GIC analysis.

These functions do not record themselves when called while recording is enabled in PSS[®] E.

Please note that these routines are members of the gicdata Python extension module, not psspy. The syntax on the following pages assumes that the module has been imported by executing:

```
import gicdata
```

GIC (Geomagnetically Induced Current) Analysis requires an additional GIC data file (See Section 7.2, GIC Data File Contents in the *Program Operation Manual*) that contains:

- Substation data
- Bus Substation data and
- Transformer data

Functions in the gicdata module help to create GIC data file applicable to a specific Power Flow Network Case for an entire network or just desired subsystem.

Creating GIC data using the gicdata module is a two step process.

Step 1

Create GIC data file template using functions:

- template_excel(..)
- template_py(..)

This will create structure of GIC data that is required.

Step 2

Edit/Update the GIC data file template created in Step (1) to provide:

- Substation data
- Bus Substation data
- Transformer data

For transformers, vector group information must be provided. If power flow Saved Case has vector group information, GIC data file template will have this information as well. If PSSE Saved Case does not have vector group information, this needs to be provided. The GIC data file then can default values for all other transformer record data items.

Once GIC data file template is updated, create GIC data file using functions:

- excel2gicfile(..)
- py2gicfile(..)

This GIC data file can be used in GIC Analysis.

Argument Definitions:

string savfile- PSSE Saved Case file name

string pyfile- GIC data file formatted in Python structures

This module defines Python structures and saves in this file (Step 1 above).

User only edits/updates values.

string excelfile- GIC data file formatted in Excel worksheets

This module creates this Excel file and worksheets in it (Step 1 above).

User only edits/updates values.

string gicfile- GIC data file name (output) that can be used in GIC Analysis.

The following optional arguments are used to define subsystem, if GIC study is to be performed for a subsystem.

real basekv- List of two real values: minimum voltage and maximum voltage,

For example [minVolt, maxVolt], default = []

integer areas- List of areas, default = []

integer buses- List of buses, default = []

integer owners- List of owners, default = []

integer zones- List of zones, default = []

integer tielevels- Number of intertie levels, default = 0

Functions:

check_gicfile(gicfile0, gicfile="")

Check GIC data file 'gicfile0' and create new GIC data file 'gicfile'.

Input gicfile0 is read and processed to do following:

- Add quotes (if already not there) around character data items likes "SUBNAM"
- Remove tabs and such non-ASCII characters

- Check if same geographical location is provided for different substations and if found remove that substation from 'substation' record groups and replace that substation in 'bus substation' record group.

Output 'gicfile' created only if it is specified.

excel2gicfile(excelfile, gicfile)

Create GIC data file (.gic) from GIC data template in Excel.

py2gicfile(pyfile, gicfile)

Create GIC data file (.gic) from GIC data template in Python structures.

template_excel(savfile, excelfile, basekv=[], areas=[], buses=[], owners=[], zones=[], tielevels=0)

Create GIC data file template in Excel Spreadsheet.

template_py(savfile, pyfile, basekv=[], areas=[], buses=[], owners=[], zones=[], tielevels=0)

Create GIC data file template in Python structures.

Chapter 27

PSSPIHIST Module

This python module, psspihist, is helpful when running PSS[®]E. activities with network data that is updated with grid operating conditions. To use this module, it is required that the network operating data is stored in PI Historian and its access is provided with OPC HDA interface.

These functions do not record themselves when called while recording is enabled in PSS[®]E.

Please note that these routines are members of the psspihist Python extension module, not psspy.

The complete documentation for this API is available by running the following commands in either PSS[®]E CLI or any Python Interpreter:

```
import psspihist
help(psspihist)
```

The following example shows how this Python module can be run from Python script.

1. Create an Excel Template File to provide data mapping tags. Modify as required.

```
import psse34
import psspy
import psspihist
psspy.psseinit()
savfile = r"savnw.sav"
xlfile = "test_template.xlsx"
psspy.case(savfile)
sid = -1
xlfile = psspihist.template_excel(sid, xlfile,
showexcel=False)
```

2. Get data from Historian for specified tags and update PSSE case.

```
import psse34
import psspy
import psspihist
psspy.psseinit()
```

```
savfile = r"savnw.sav"

psspy.case(savfile)

opc_host    = "localhost"

opc_server  = "Matrikon.OPC.MicroHistorian.1"

tagfile = "test_tagdata.xlsx"

time_start = (2016, 03, 05, 17, 30, 32)

time_end   = (2016, 03, 05, 17, 30, 32)

aggregate_type = 1

sid = -1

opc_class   = "Graybox.OPC.HDAWrapper"

opc_client  = "PSSE_OPC_HDA" # this is arbitrary

load = ['pl', 'ql']

mach = ['pg', 'vs']

brn  = ['rate1', 'rate2', 'rate12']

psspihist.run(opc_host, opc_server, tagfile,
time_start, time_end, aggregate_type, sid,

    load=load, mach=mach, brn=brn, opc_class=opc_class,
opc_client=opc_client,

    preview=preview)
```

Chapter 28

PFCONTROL Module

This chapter describes Python functions available in the PSS[®]E Remedial Action Scheme (RAS) and Advanced Contingency module.

These functions allow the user to program advanced RAS scenarios and events not supported by the existing SUB/MON/CON and TRP files to be executed in conjunction with the Power Flow Customization Interface (PCI) embedded in the PSS[®]E engine.

These functions do not record themselves when called while recording is enabled in PSS[®]E.

Please note that these routines are members of the pfcontrol Python extension module, not psspy. The syntax on the following pages assumes that the module has been imported by executing:

```
import pfcontrol
```

28.1. PFDSCNBUS

This API is used to disconnect a bus in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr, typcode = pfdscnbus(iocode, frombus)
```

Python syntax:

```
ierr = pfdscnbus(frombus)
```

where:

Integer IOCODE	Is the action code (input). The values are as follows. 0 by default. IOCODE = 0 disconnect the bus IOCODE = 1 return the type code in typcode
Integer FROMBUS	Is the bus number (input).
Integer TYPCODE	Is the bus type code (output).
Integer IERR	Is the error code (output). IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 7 bus not found. IERR = 21 bus is already disconnected (type code > 3).

28.2. PFCNCTBUS

This API is used to connect a bus in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.10.0 and 34.2.0

Python syntax:

```
ierr = pfcnctbus(frombus, typcode)
```

where:

Integer FROMBUS	Is the bus number (input).
Integer TYPCODE	Is the bus type code (input). The values are as follows. 0 by default. TYPCODE = 1 for an ordinary in-service bus. TYPCODE = 2 for a generator bus.
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 7 bus not found. IERR = 22 bus is already connected (type code < 4). IERR = 23 bus is an interior bus of a multi-section line. IERR = 24 new type code is not 1 or 2.

28.3. PFBRCHINT

This API is used to get/set specific integer quantities on a branch in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pfbrchint(frombus, tobus, id, namval, ival)
```

```
ierr, ival = pfbrchint(frombus, tobus, id, namval)
```

where:

Integer FROMBUS	Is the branch from bus number (input).
Integer TOBUS	Is the branch to bus number (input).
Character ID*2	Is the branch Id (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows.
	STATUS the branch status
Integer IVAL	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 20 branch not found.
	IERR = 25 at least one of the endpoint buses is not energized.
	IERR = 26 multi-section line reporting option setting is disabled.

28.4. PFSUBSWDINT

This API is used to get/set specific integer quantities on a substation switching device in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 34.2.0

Python syntax:

```
ierr = pfsubswdint(statnum, fromnode, tonode, id, namval, ival)
```

```
ierr, ival = pfsubswdint(statnum, fromnode, tonode, id, namval)
```

where:

Integer STATNUM	Is the substation switching device substation number (input).
Integer FROMNODE	Is the substation switching device from node number (input).
Integer TONODE	Is the substation switching device to node number (input).
Character ID*2	Is the substation switching device Id (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows.
	STATUS the substation switching device status
Integer IVAL	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 27 substation STANUM not found.
	IERR = 28 node FRNODE not found in substation STANUM.
	IERR = 29 node TONODE not found in substation STANUM.
	IERR = 30 switching device not found in substation STANUM.
	IERR = 31 at least one of the nodes is out-of-service.
	IERR = 32 attempting to open a stuck breaker.

28.5. PFFXSINT

This API is used to get/set specific integer quantities on a fixed shunt in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pffxsint(frombus, id, namval, ival)
```

```
ierr, ival = pffxsint(frombus, id, namval)
```

where:

Integer FROMBUS	Is the fixed shunt from bus number (input).
Character ID*2	Is the fixed shunt Id (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows. STATUS the fixed shunt status
Integer IVAL	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 6 invalid NAMVAL string. IERR = 7 bus not found. IERR = 8 bus is out-of-service. IERR = 16 fixed shunt not found. IERR = 17 fixed shunt is out-of-service. IERR = 39 fatal error from SHUNT_API.

28.6. PFFXSREAL

This API is used to get/set specific real quantities on a fixed shunt in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pffxsreal(frombus, id, namval, rval)
```

```
ierr, rval = pffxsreal(frombus, id, namval)
```

where:

Integer FROMBUS	Is the fixed shunt from bus number (input).
Character ID*2	Is the fixed shunt Id (input).
Character NAMVAL*8	Is the value to set or return (input). The values are as follows. PNOMINAL the nominal active power in MW QNOMINAL the nominal reactive power in MVAR
Integer RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 6 invalid NAMVAL string. IERR = 7 bus not found. IERR = 8 bus is out-of-service. IERR = 16 fixed shunt not found. IERR = 17 fixed shunt is out-of-service. IERR = 39 fatal error from SHUNT_API.

28.7. PFSWSINT

This API is obsolete. It has been replaced by the API routine PFSWSINT_2.

This API is used to get/set specific integer quantities on a switched shunt in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pfswsint(frombus, namval, ival)

ierr, ival = pfswsint(frombus, namval)
```

where:

Integer FROMBUS	Is the switched shunt from bus number (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows.
	STATUS the switched shunt status
Integer IVAL	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 8 bus is out-of-service.
	IERR = 18 switched shunt not found.
	IERR = 19 switched shunt is out-of-service.
	IERR = 40 fatal error from SWITCHED_SHUNT_API.

28.8. PFSWSREAL

This API is obsolete. It has been replaced by the API routine PFSWSREAL_2.

This API is used to get/set specific real quantities on a switched shunt in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pfswsreal(frombus, namval, rval)

ierr, rval = pfswsreal(frombus, namval)
```

where:

Integer FROMBUS	Is the switched shunt from bus number (input).
Character NAMVAL*5	Is the value to set or return (input). The values are as follows. QINIT the present switched shunt admittance in MVAR VMAX the desired voltage upper limit VMIN the desired voltage lower limit
Real RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 6 invalid NAMVAL string. IERR = 7 bus not found. IERR = 8 bus is out-of-service. IERR = 18 switched shunt not found. IERR = 19 switched shunt is out-of-service. IERR = 40 fatal error from SWITCHED_SHUNT_API.

28.9. PFSWSINT_2

This API is used to get/set specific integer quantities on a switched shunt in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 35.3.0

Python syntax:

```
ierr = pfswsint_2(frombus, id, namval, ival)
```

```
ierr, ival = pfswsint_2(frombus, id, namval)
```

where:

Integer FROMBUS	Is the switched shunt from bus number (input).
Character ID*2	Is the fixed shunt Id (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows.
	STATUS the switched shunt status
Integer IVAL	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 8 bus is out-of-service.
	IERR = 18 switched shunt not found.
	IERR = 19 switched shunt is out-of-service.
	IERR = 40 fatal error from SWITCHED_SHUNT_API.

28.10. PFSWSREAL_2

This API is used to get/set specific real quantities on a switched shunt in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 35.3.0

Python syntax:

```
ierr = pfswsreal_2(frombus, id, namval, rval)
```

```
ierr, rval = pfswsreal_2(frombus, id, namval)
```

where:

Integer FROMBUS	Is the switched shunt from bus number (input).
Character ID*2	Is the fixed shunt Id (input).
Character NAMVAL*5	Is the value to set or return (input). The values are as follows.
	QINIT the present switched shunt admittance in MVAR
	VMAX the desired voltage upper limit
	VMIN the desired voltage lower limit
Real RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 8 bus is out-of-service.
	IERR = 18 switched shunt not found.
	IERR = 19 switched shunt is out-of-service.
	IERR = 40 fatal error from SWITCHED_SHUNT_API.

28.11. PFLODINT

This API is used to get/set specific integer quantities on a load in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax to set an integer quantity:

```
ierr = pflodint(frombus, id, namval, ival)
```

```
ierr, ival = pflodint(frombus, id, namval)
```

where:

Integer FROMBUS	Is the load from bus number (input).
Character ID*2	Is the load Id (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows.
	STATUS the load status
Integer IVAL	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 8 bus is out-of-service.
	IERR = 14 load not found.
	IERR = 15 load is out-of-service.
	IERR = 38 fatal error from LOAD_API_5.

28.12. PFLODREAL

This API is used to get/set specific real quantities on a load in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pflodreal(frombus, id, namval, rval)
```

```
ierr, rval = pflodreal(frombus, id, namval)
```

where:

Integer FROMBUS	Is the load from bus number (input).
Character ID*2	Is the load Id (input).
Character NAMVAL*5	Is the value to set or return (input). The values are as follows. PLOAD the nominal active constant power load in MW QLOAD the nominal reactive constant power load in MVAR
Integer RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 6 invalid NAMVAL string. IERR = 7 bus not found. IERR = 8 bus is out-of-service. IERR = 14 load not found. IERR = 15 load is out-of-service. IERR = 38 fatal error from LOAD_API.

28.13. PFMACINT

This API is used to get/set specific integer quantities on a machine in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pfmacint(frombus, id, namval, ival)
```

```
ierr, ival = pfmacint(frombus, id, namval)
```

where:

Integer FROMBUS	machine from bus number (input).
Character ID*2	Is the machine Id (input).
Character NAMVAL*6	Is the value to set or return (input). The values are as follows.
	STATUS the machine status
	Is the integer value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 8 bus is out-of-service.
	IERR = 9 machine not found.
	IERR = 10 machine is out-of-service.
	IERR = 37 fatal error from MACHINE_API_2.

28.14. PFMACREAL

This API is used to get/set specific real quantities on a machine in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pfmacreal(frombus, id, namval, rval)
```

```
ierr, rval = pfmacreal(frombus, id, namval)
```

where:

Integer FROMBUS	Is the machine from bus number (input).
Character ID*2	Is the machine Id (input).
Character NAMVAL*4	Is the value to set or return (input). The values are as follows. PGEN the active power generation in MW QMAX the reactive power high limit in MVAR QMIN the reactive power low limit in MVAR
Integer RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 1 not called from PCI automation function. IERR = 2 not called from allowable PCI automation function. IERR = 3 cannot change data in post_ca_sol_eval. IERR = 4 working case is empty. IERR = 6 invalid NAMVAL string. IERR = 7 bus not found. IERR = 8 bus is out-of-service. IERR = 9 machine not found. IERR = 10 machine is out-of-service. IERR = 37 fatal error from MACHINE_API.

28.15. PFPLNTREAL

This API is used to get/set specific real quantities on a plant in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.9.0 and 34.2.0

Python syntax:

```
ierr = pfplntreal(frombus, section, namval, rval)
```

```
ierr, rval = pfplntreal(frombus, section, namval)
```

where:

Integer FROMBUS	Is the plant from bus number (input).
Integer SECTION	Is the plant bus section number (input).
	SECTION = 0 If bus FROMBUS is not in a substation or if FROMBYS is not represented by multiple bus sections or if the same change applies to all plants at all bus sections
	SECTION != 0 plant bus section to apply change to
Character NAMVAL*4	Is the value to set or return (input). The values are as follows.
	VSET the desired voltage setpoint
Integer RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 2 not called from allowable PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 7 bus not found.
	IERR = 8 bus is out-of-service.
	IERR = 11 no plant present on this bus section.
	IERR = 12 plant is out-of-service.
	IERR = 13 no in-service plant found on any bus section.
	IERR = 33 invalid node number.

IERR = 34 bus is not part of a substation.

IERR = 35 node is not found in this substation.

IERR = 36 fatal error from PLANT_BUS_SECTION_CHNG.

28.16. PFCNTLVSC

This API is used to get/set specific real quantities on a VSC DC line in a PCI automation function. Its use is only supported in the context of a call from a PCI automation function.

This API routine was first introduced in release 33.6.0

Python syntax:

```
ierr = pfctlvsc(name, cnvbus, namval, rval)
```

```
ierr, rval = pfctlvsc(name, cnvbus, namval)
```

where:

Character NAME*12	Is the VSC DC line name (input).
Integer CNVBUS	Is the VSC DC line converter bus number (input).
Character NAMVAL*5	Is the value to set or return (input). The values are as follows.
	DCSET the converter dc setpoint
	ACSET the converter ac setpoint
	ALOSS the converter loss coefficient
	BLOSS the converter loss coefficient
	QMAX the reactive power upper limit in MVAR
	QMIN the reactive power lower limit in MVAR
	QSET the reactive power setpoint in MVAR
Integer RVAL	Is the real value to set if specified (input) else returned (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1 not called from PCI automation function.
	IERR = 3 cannot change data in post_ca_sol_eval.
	IERR = 4 working case is empty.
	IERR = 6 invalid NAMVAL string.
	IERR = 41 dc line not found.
	IERR = 42 converter bus not found.
	IERR = 43 bus is not a converter bus of this dc line.
	IERR = 44 for getting "QSET", VSQMAX and VSQMIN are not equal.

IERR = 45 for setting "QMAX" or "QMIN", called by Pre_Iteration or Post_Iteration.

IERR = 46 fatal error from VSC_DC_LINE_CONVERTER_API.

Chapter 29

PSSACCSS Module

This chapter describes Python functions available in the PSS[®]E Remedial Action Scheme (RAS) and Advanced Contingency module.

These functions allow the user to read an ACC file directly using Python calls. In some situations these APIs are faster than the APIs in the pssarrays module since they deal with smaller amounts of data.

These functions do not record themselves when called while recording is enabled in PSS[®]E.

Please note that these routines are members of the pssaccss Python extension module, not psspy. The syntax on the following pages assumes that the module has been imported by executing:

```
import pssaccss
```

29.1. ACCC_FILE_INIT

This API is used to initialize an ACCC file for direct access to the contingency data contained within.

Python syntax:

```
ierr = accc_file_init(rfile, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_INITIALIZE(RFILE, ACCCSIZE, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.
	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.
	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.
	ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Integer IERR

Is the error code (output).

IERR = 0 no error occurred.

IERR = 1 error opening RFILE.

IERR = 10 prerequisite requirements for API are not met.

29.2. ACCC_FILE_SIZE

This API is used to get the number of elements contained within an ACCC file so that storage may be allocated for retrieving items (if desired).

Python syntax:

```
ierr, acccsize = accc_file_size(rfile)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_SIZE(RFILE, ACCCSIZE, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Output). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.
	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.
	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Integer IERR

Is the error code (output).

IERR = 0 no error occurred.

IERR = 4 error opening RFILE.

IERR = 5 error reading RFILE.

IERR = 10 prerequisite requirements for API are not met.

29.3. ACCC_FILE_GET_SUM_VOLT

This API is used to return information about monitored voltage records and limits contained in the contingency data file.

Python syntax:

```
ierr, mvrec_labelxx, mvrec_limxx, mvrec_typexx, mvbus_seqxx,
vbaselmxx, vemergnxx, mvrec_ivbxx, mvrnd_labelxx, mvrnd_limxx,
mvrnd_typexx, mvnod_seqxx, vnbaselmxx, vnemergnxx, mvrnd_ivbxx =
accc_file_get_sum_volt(rfile, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_SUMMARY_VOLTAGES(RFILE, ACCCSIZE, MVREC_LABELxx,
MVREC_LIMxx, MVREC_TYPExx, MVBUS_SEQxx, VBASELMxx, VEMERGNxx,
MVREC_IVBxx, MVRND_LABELxx, MVRND_LIMxx, MVRND_TYPExx, MVNOD_SEQxx,
VNBASELMxx, VNEMERGNxx, MVRND_IVBxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.
	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.
	ACCCSIZE (14) = -1 Undecided.
	ACCCSIZE (15) ACCC file type.
	ACCCSIZE (15) = 0 ACCC.
	ACCCSIZE (15) = 1 N-1-1.
	ACCCSIZE (16) Number of Areas.
	ACCCSIZE (17) Number of Zones.
	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Character MVREC_LABELxx*34 (ACCCSIZE(5))	Is an array containing monitored voltage record label for all monitored voltage records in the file (output).
Real MVREC_LIMxx (2*ACCCSIZE(5))	Is an array containing monitored voltage record limits for all monitored voltage records in the file (output).
Character MVREC_TYPExx*9 (ACCCSIZE(5))	Is an array containing monitored voltage record type for all monitored voltage records in the file (output). Either 'DEVIATION', 'RANGE' or 'LIMIT'
Integer MVBUS_SEQxx (ACCCSIZE(7))	Is an array containing monitored bus sequence numbers for all buses in the monitored bus list in the file (output).
Real VBASELMxx (2*ACCCSIZE(7))	Is an array containing monitored bus normal limits for all buses in the monitored bus list in the file (output).

Real VEMERGNxx (2*ACCSIZE(7))	Is an array containing monitored bus emergency limits for all buses in the monitored bus list in the file (output).
Integer MVREC_IVBxx (ACCSIZE(7)* ACCCSIZE(5))	Is an array containing flags to indicate if the bus is monitored in a record, indexed by the bus sequence number and monitor record in the file (output).
Character MVRND_LABELxx*34 (ACCCSIZE(23))	Monitored voltage record label
Real MVRND_LIMxx (ACCSIZE(23))	Monitored voltage record limits
Character MVRND_TYPExx*9 (ACCCSIZE(23))	Monitor voltage record TYPE
Integer MVNOD_SEQxx (ACCSIZE(21))	Contains the number in monitored buses list, indexed by the bus sequence number in the bus table
Real VNBASELMxx (ACCSIZE(21))	The normal voltage limits, indexed by the bus sequence in the bus table
Real VNEMERGNxx (ACCSIZE(21))	The emergency voltage limits, indexed by the bus sequence in the bus table
Integer MVRND_IVBxx (ACCSIZE(21)* ACCCSIZE(23))	Contains a flag to indicate if the bus is monitored in a record, indexed by the bus sequence number and monitor record
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 1-4 error in internal parsing routines.
	IERR = 5 RFILE does not match the one called in ACCC_FILE_SIZE.
	IERR = 6 error in internal ordering of buses.
	IERR = 10 prerequisite requirements for API are not met.

29.4. ACCC_FILE_CLOSE

This API is used to close an open ACCC file.

Python syntax:

```
ierr = accc_file_close()
```

Fortran syntax:

```
CALL ACCC_FILE_CLOSE(IERR)
```

where:

Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = X error closing open ACCC file.
	IERR = 10 prerequisite requirements for API are not met.

29.5. ACCC_FILE_SUMMARY

This API routine is obsolete. It has been replaced by the API routine [accc_file_summary_2](#).

This API is used to get a summary of the data contained within an ACCC file.

Python syntax:

```
shrttitle, filenames, cktlabels, mon_ratexx, mvbus_labelxx, mvrev_labelxx,
mvrec_maxxx, mvrec_minxx, mvrec_typexx, lblcntxx, busnamaccxx, addcntxx,
addtrpxx, addcorxx, mvrec_ivbxx, ratnamxx, ratdescxx, mvnod_labelxx,
mvrnd_labelxx, mvrnd_maxxx, mvrnd_minxx, mvrnd_typexx, nodnameaccxx,
mvrnd_ivbxx, ierr = accc_file_summary(rfile, acccsize)
```

Fortran syntax:

```
CALL GET_ACCC_SUMMARY(RFILE, ACCCSIZE, SHRTTITLE, FILENAMES, CKTLABELS,
MON_RATExx, MVBUS_LABELxx, MVREV_LABELxx, MVREC_MAXxx, MVREC_MINxx,
MVREC_TYPExx, LBLCNTxx, BUSNAMACCxx, ADDCNTxx, ADDTRPxx, ADDCORxx,
MVREC_IVBxx, RATNAMxx, RATDESCxx, MVNOD_LABELxx, MVRND_LABELxx,
MVRND_MAXxx, MVRND_MINxx, MVRND_TYPExx, NODNAMEACCxx, MVRND_IVBxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; No default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.
	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.
	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.
	ACCCSIZE (14) = -1 Undecided.
	ACCCSIZE (15) ACCC file type.
	ACCCSIZE (15) = 0 ACCC.
	ACCCSIZE (15) = 1 N-1-1.
	ACCCSIZE (16) Number of Areas.
	ACCCSIZE (17) Number of Zones.
	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Character SHRTTITLE*60(2)	Is an array of two elements that contain the two short title lines of the case contained within the ACCC file. SHRTTITLE (1) First short title line.
	SHRTTITLE (2) Second short title line.
Character FILENAMES*260(9)	Is an array of nine elements that contain the file names of all files used in the case contained within the ACCC file. FILENAMES (1) ACC file name.
	FILENAMES (2) SAV file name.

	FILENAMES (3) DFX file name.
	FILENAMES (4) SUB file name.
	FILENAMES (5) MON file name.
	FILENAMES (6) CON file name.
	FILENAMES (7) THR file name.
	FILENAMES (8) INL file name.
	FILENAMES (9) TRP file name.
Character CKTLABELS*62 (ACCSIZE(1)* ACCCSIZE(2))	Is an array that contains the labels of all monitored lines contained within the ACCC file. Multi-section line labels are not stored.
Float MON_RATExx ((ACCSIZE(1)+ ACCCSIZE(2))* ACCCSIZE(20))	Is an array that contains the Monintored Line Flow ratings.
Character MVBUS_LABELxx*29 (ACCSIZE(6))	Is an array containing the Monitored Bus labels.
Character MVREV_LABELxx*34 (ACCSIZE(6))	Is an array containing the Monitored Bus record labels.
Real MVREC_MAXxx (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record maximum.
Real MVREC_MINxx (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record minimum.
Character MVREC_TYPExx*9 (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record type (Range, Deviation, Limit).
Charcter LBLCNTxx*152 (ACCSIZE(3))	Is an array containing the Contingency labels.
Character BUSNAMACCxx*29 (ACCSIZE(7))	Is an array containing the extended Bus names.
Long Integer ADDCNTxx (ACCSIZE(3))	Is an array containing ACCC Contingency solution result addresses. Used as input to other APIs.
Long Integer ADDTRPxx (ACCSIZE(3))	Is an array containing ACCC Tripping solution result addresses. Used as input to other APIs.
Long Integer ADDCORxx (ACCSIZE(3))	Is an array containing ACCC Corrective Action solution result addresses. Used as input to other APIs.
Integer MVREC_IVBxx (ACCSIZE(4)* ACCCSIZE(5))	Is an array containing flags used to indicate if the Bus is monitored in a record (indexed by the bus sequence number and monitored bus record).
Character RATNAMxx*6 (ACCSIZE(20))	Is an array containing the Line Flow Rating names.
Character RATDESCxx*32 (ACCSIZE(20))	Is an array containing the Line Flow Rating descriptions.
Character MVNOD_LABELxx*29 (ACCSIZE(24))	Is an array containing the Monitored Node labels.
Character MVRND_LABELxx*34 (ACCSIZE(24))	Is an array containing the Monitored Node record labels.

Real MVRND_MAXxx (ACCCSIZE(24))	Is an array containing the Monitored Node voltage record maximum.
Real MVRND_MINxx (ACCCSIZE(24))	Is an array containing the Monitored Node voltage record minimum.
Character MVRND_TYPExx*9 (ACCCSIZE(24))	Is an array containing the Monitored Node voltage record type (Range, Deviation, Limit).
Character NODNAMEACCxx*29 (ACCCSIZE(21))	Is an array containing the Node names.
Integer MVRND_IVBxx (ACCCSIZE(23))	Is an array containing flags used to indicate if the Node is monitored in a record (indexed by the bus sequence number and monitored node record).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 4 error opening RFILE. IERR = 5 RFILE does not match the one called in ACCC_FILE_SIZE. IERR = 6 error in fetching contingency strings. IERR = 10 prerequisite requirements for API are not met.

29.6. ACCC_FILE_SUMMARY_2

This API routine is obsolete. It has been replaced by the API routine [accc_file_summary_3](#).

This API is used to get a summary of the data contained within an ACCC file.

Python syntax:

```
ierr, shrttitle, filenames, cktlabels, mon_ratexx, mvbus_labelxx,
mvrev_labelxx, mvrec_maxxx, mvrec_minxx, mvrec_typexx, lblcntxx,
busnamaccxx, addcntxx, addtrpxx, addcorxx, mvrec_ivbxx, ratnamxx,
ratdescxx, mvnod_labelxx, mvrnd_labelxx, mvrnd_maxxx, mvrnd_minxx,
mvrnd_typexx, nodnameaccxx, mvrnd_ivbxx, vbasellst, vemergnlst,
vnbasellst, vnemergnlst, mvlbusrec_labelLst, mvlnodrec_labelLst =
accc_file_summary(rfile, acccsize, options)
```

Fortran syntax:

```
CALL GET_ACCC_SUMMARY_2(RFILE, ACCCSIZE, OPTIONS, SHRTTITLE, FILENAMES,
CKTLABELS, MON_RATExx, MVBUS_LABELxx, MVREV_LABELxx, MVREC_MAXxx,
MVREC_MINxx, MVREC_TYPExx, LBLCNTxx, BUSNAMACCxx, ADDCNTxx, ADDTRPxx,
ADDCORxx, MVREC_IVBxx, RATNAMxx, RATDESCxx, MVNOD_LABELxx, MVRND_LABELxx,
MVRND_MAXxx, MVRND_MINxx, MVRND_TYPExx, NODNAMEACCxx, MVRND_IVBxx,
VBASELxx, VEMERGNxx, VNBASELxx, VNEMERGNxx, VBASEL_LABEL, VNBASEL_LABEL,
IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; No default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.
	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.
	ACCCSIZE (14) = -1 Undecided.
	ACCCSIZE (15) ACCC file type.
	ACCCSIZE (15) = 0 ACCC.
	ACCCSIZE (15) = 1 N-1-1.
	ACCCSIZE (16) Number of Areas.
	ACCCSIZE (17) Number of Zones.
	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Integer OPTIONS(2)	Is an array of two elements containing base case voltage limit and contingency case voltage limit. OPTIONS (1) Base case voltage limit (default 1)
Character SHRTTITLE*60(2)	OPTIONS (2) Contingency case voltage limit (default 2) Is an array of two elements that contain the two short title lines of the case contained within the ACCC file.

	SHRTTITLE (1) First short title line.
	SHRTTITLE (2) Second short title line.
Character FILENAMES*260(9)	Is an array of nine elements that contain the file names of all files used in the case contained within the ACCC file.
	FILENAMES (1) ACC file name.
	FILENAMES (2) SAV file name.
	FILENAMES (3) DFX file name.
	FILENAMES (4) SUB file name.
	FILENAMES (5) MON file name.
	FILENAMES (6) CON file name.
	FILENAMES (7) THR file name.
	FILENAMES (8) INL file name.
	FILENAMES (9) TRP file name.
Character CKTLABELS*62 (ACCSIZE(1)* ACCCSIZE(2))	Is an array that contains the labels of all monitored lines contained within the ACCC file. Multi-section line labels are not stored.
Float MON_RATExx ((ACCSIZE(1)+ ACCCSIZE(2))* ACCCSIZE(20))	Is an array that contains the Monitored Line Flow ratings.
Character MVBUS_LABELxx*29 (ACCSIZE(6))	Is an array containing the Monitored Bus labels.
Character MVREV_LABELxx*34 (ACCSIZE(6))	Is an array containing the Monitored Bus record labels.
Real MVREC_MAXxx (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record maximum.
Real MVREC_MINxx (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record minimum.
Character MVREC_TYPExx*9 (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record type (Range, Deviation, Limit).
Character LBLCNTxx*152 (ACCSIZE(3))	Is an array containing the Contingency labels.
Character BUSNAMACCxx*29 (ACCSIZE(7))	Is an array containing the extended Bus names.
Long Integer ADDCNTxx (ACCSIZE(3))	Is an array containing ACCC Contingency solution result addresses. Used as input to other APIs.
Long Integer ADDTRPxx (ACCSIZE(3))	Is an array containing ACCC Tripping solution result addresses. Used as input to other APIs.
Long Integer ADDCORxx (ACCSIZE(3))	Is an array containing ACCC Corrective Action solution result addresses. Used as input to other APIs.

Integer MVREC_IVBxx (ACCSIZE(4)* ACCCSIZE(5))	Is an array containing flags used to indicate if the Bus is monitored in a record (indexed by the bus sequence number and monitored bus record).
Character RATNAMxx*6 (ACCSIZE(20))	Is an array containing the Line Flow Rating names.
Character RATDESCxx*32 (ACCSIZE(20))	Is an array containing the Line Flow Rating descriptions.
Character MVNOD_LABELxx*29 (ACCSIZE(24))	Is an array containing the Monitored Node labels.
Character MVRND_LABELxx*34 (ACCSIZE(24))	Is an array containing the Monitored Node record labels.
Real MVRND_MAXxx (ACCSIZE(24))	Is an array containing the Monitored Node voltage record maximum.
Real MVRND_MINxx (ACCSIZE(24))	Is an array containing the Monitored Node voltage record minimum.
Character MVRND_TYPExx*9 (ACCSIZE(24))	Is an array containing the Monitored Node voltage record type (Range, Deviation, Limit).
Character NODNAMEACCxx*29 (ACCSIZE(21))	Is an array containing the Node names.
Integer MVRND_IVBxx (ACCSIZE(23))	Is an array containing flags used to indicate if the Node is monitored in a record (indexed by the bus sequence number and monitored node record).
Integer VBASELxx (ACCSIZE(25))	Is an array containing the normal Monitored Bus voltage limits.
Integer VEMERGNxx (ACCSIZE(25))	Is an array containing the emergency Monitored Bus voltage limits.
Integer VNBASELxx (ACCSIZE(26))	Is an array containing the normal Monitored Node voltage limits.
Integer VNEMERGNxx (ACCSIZE(26))	Is an array containing the emergency Monitored Node voltage limits.
Character MVLBUSREC_LABELxx*29 (ACCSIZE(26))	Is an array containing the monitored limit bus numbers in order of values returned for VBASELxx and VEMERGNxx
Character MVLNODREC_LABELxx*29 (ACCSIZE(26))	Is an array containing the monitored limit node names in order of values returned for VNBASELxx and VNEMERGNxx
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 4 error opening RFILE. IERR = 5 RFILE does not match the one called in ACCC_FILE_SIZE. IERR = 6 error in fetching contingency strings. IERR = 10 prerequisite requirements for API are not met.

29.7. ACCC_FILE_SUMMARY_3

This API is used to get a summary of the data contained within an ACCC file.

Python syntax:

```
ierr, shrttitle, filenames, cktlabels, mon_ratexx, mvbus_labelxx,
mvrev_labelxx, mvrec_maxxx, mvrec_minxx, mvrec_typexx, lblcntxx,
busnamaccxx, addcntxx, addtrpxx, addcorxx, mvrec_ivbxx, ratnamxx,
ratdescxx, mvnod_labelxx, mvrnd_labelxx, mvrnd_maxxx, mvrnd_minxx,
mvrnd_typexx, nodnameaccxx, mvrnd_ivbxx, vbasellst, vemergnlst,
vnbasellst, vnemergnlst, mvlbusrec_labelLst, mvlnodrec_labelLst,
acswdflow_outxx, swd_rat_num_outxx = accc_file_summary_3(rfile, acccsize,
options)
```

Fortran syntax:

```
CALL GET_ACCC_SUMMARY_3(RFILE, ACCCSIZE, OPTIONS, SHRTTITLE, FILENAMES,
CKTLABELS, MON_RATExx, MVBUS_LABELxx, MVREV_LABELxx, MVREC_MAXxx,
MVREC_MINxx, MVREC_TYPExx, LBLCNTxx, BUSNAMACCxx, ADDCNTxx, ADDTRPxx,
ADDCORxx, MVREC_IVBxx, RATNAMxx, RATDESCxx, MVNOD_LABELxx, MVRND_LABELxx,
MVRND_MAXxx, MVRND_MINxx, MVRND_TYPExx, NODNAMEACCxx, MVRND_IVBxx,
VBASELxx, VEMERGNxx, VNBASELxx, VNEMERGNxx, VBASEL_LABEL, VNBASEL_LABEL,
ACSWDFLOW_OUTxx, SWD_RAT_NUM_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; No default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.
	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.
	ACCCSIZE (14) = -1 Undecided.
	ACCCSIZE (15) ACCC file type.
	ACCCSIZE (15) = 0 ACCC.
	ACCCSIZE (15) = 1 N-1-1.
	ACCCSIZE (16) Number of Areas.
	ACCCSIZE (17) Number of Zones.
	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Integer OPTIONS(2)	Is an array of two elements containing base case voltage limit and contingency case voltage limit. OPTIONS (1) Base case voltage limit (default 1)
Character SHRTTITLE*60(2)	OPTIONS (2) Contingency case voltage limit (default 2) Is an array of two elements that contain the two short title lines of the case contained within the ACCC file.

	SHRTTITLE (1) First short title line.
	SHRTTITLE (2) Second short title line.
Character FILENAMES*260(9)	Is an array of nine elements that contain the file names of all files used in the case contained within the ACCC file.
	FILENAMES (1) ACC file name.
	FILENAMES (2) SAV file name.
	FILENAMES (3) DFX file name.
	FILENAMES (4) SUB file name.
	FILENAMES (5) MON file name.
	FILENAMES (6) CON file name.
	FILENAMES (7) THR file name.
	FILENAMES (8) INL file name.
	FILENAMES (9) TRP file name.
Character CKTLABELS*62 (ACCSIZE(1)* ACCCSIZE(2))	Is an array that contains the labels of all monitored lines contained within the ACCC file. Multi-section line labels are not stored.
Float MON_RATExx ((ACCSIZE(1)+ ACCCSIZE(2))* ACCCSIZE(20))	Is an array that contains the Monitored Line Flow ratings.
Character MVBUS_LABELxx*29 (ACCSIZE(6))	Is an array containing the Monitored Bus labels.
Character MVREV_LABELxx*34 (ACCSIZE(6))	Is an array containing the Monitored Bus record labels.
Real MVREC_MAXxx (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record maximum.
Real MVREC_MINxx (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record minimum.
Character MVREC_TYPExx*9 (ACCSIZE(6))	Is an array containing the Monitored Bus voltage record type (Range, Deviation, Limit).
Character LBLCNTxx*152 (ACCSIZE(3))	Is an array containing the Contingency labels.
Character BUSNAMACCxx*29 (ACCSIZE(7))	Is an array containing the extended Bus names.
Long Integer ADDCNTxx (ACCSIZE(3))	Is an array containing ACCC Contingency solution result addresses. Used as input to other APIs.
Long Integer ADDTRPxx (ACCSIZE(3))	Is an array containing ACCC Tripping solution result addresses. Used as input to other APIs.
Long Integer ADDCORxx (ACCSIZE(3))	Is an array containing ACCC Corrective Action solution result addresses. Used as input to other APIs.

Integer MVREC_IVBxx (ACCSIZE(4)* ACCCSIZE(5))	Is an array containing flags used to indicate if the Bus is monitored in a record (indexed by the bus sequence number and monitored bus record).
Character RATNAMxx*6 (ACCSIZE(20))	Is an array containing the Line Flow Rating names.
Character RATDESCxx*32 (ACCSIZE(20))	Is an array containing the Line Flow Rating descriptions.
Character MVNOD_LABELxx*29 (ACCSIZE(24))	Is an array containing the Monitored Node labels.
Character MVRND_LABELxx*34 (ACCSIZE(24))	Is an array containing the Monitored Node record labels.
Real MVRND_MAXxx (ACCSIZE(24))	Is an array containing the Monitored Node voltage record maximum.
Real MVRND_MINxx (ACCSIZE(24))	Is an array containing the Monitored Node voltage record minimum.
Character MVRND_TYPExx*9 (ACCSIZE(24))	Is an array containing the Monitored Node voltage record type (Range, Deviation, Limit).
Character NODNAMEACCxx*29 (ACCSIZE(21))	Is an array containing the Node names.
Integer MVRND_IVBxx (ACCSIZE(23))	Is an array containing flags used to indicate if the Node is monitored in a record (indexed by the bus sequence number and monitored node record).
Integer VBASELxx (ACCSIZE(25))	Is an array containing the normal Monitored Bus voltage limits.
Integer VEMERGNxx (ACCSIZE(25))	Is an array containing the emergency Monitored Bus voltage limits.
Integer VNBASELxx (ACCSIZE(26))	Is an array containing the normal Monitored Node voltage limits.
Integer VNEMERGNxx (ACCSIZE(26))	Is an array containing the emergency Monitored Node voltage limits.
Character MVLBUSREC_LABELxx*29 (ACCSIZE(26))	Is an array containing the monitored limit bus numbers in order of values returned for VBASELxx and VEMERGNxx
Character MVLNODREC_LABELxx*29 (ACCSIZE(26))	Is an array containing the monitored limit node names in order of values returned for VNBASELxx and VNEMERGNxx
Real ACSWDFLOW_OUTxx (ACCSIZE(27))	Is an array containing all the desired MVA flows for the desired SWD (output).
Real SWD_RAT_NUM_OUTxx (ACCSIZE(28))	Is an array containing all the desired Ampere flows for the desired SWD (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 4 error opening RFILE.
	IERR = 5 RFILE does not match the one called in ACCC_FILE_SIZE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.8. ACCC_FILE_SUM_AREAS

This API is used to return information about areas, owners and zone information contained in the contingency data file.

Python syntax:

```
ierr, bsarea_outxxx, bszone_outxx, bsowne_outxx, bsvolt_outxx,
nuarea_outxx, nuzone_outxx, nuowne_outxx, nuvolt_outxx, naarea_outxx,
nazone_outxx, naowne_outxx = accc_file_sum_areas(rfile, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_SUMMARY_AREAS(RFILE, ACCCSIZE, BSAREA_OUTxxx,
BSZONE_OUTxx, BSOWNE_OUTxx, BSVOLT_OUTxx, NUAREA_OUTxx, NUZONE_OUTxx,
NUOWNE_OUTxx, NUVOLT_OUTxx, NAAREA_OUTxx, NAZONE_OUTxx, NAOWNE_OUTxx,
NUVOLT_OUTxx, NAAREA_OUTxx, NAZONE_OUTxx, NAOWNE_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows.
	ACCCSIZE (1) Number of monitored lines.
	ACCCSIZE (2) Number of interfaces.
	ACCCSIZE (3) Number of Contingencies + Base Case.
	ACCCSIZE (4) Number of voltage buses.
	ACCCSIZE (5) Number of voltage records.
	ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)).
	ACCCSIZE (7) Number of buses in ACCC case.
	ACCCSIZE (8) Acc file version number.
	ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency.
	ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.
	ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.
	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Integer BSAREA_OUTxxx (ACCCSIZE(7))

Is an array containing all the Area numbers for the buses in the file (output).

Integer , BSZONE_OUTxxx (ACCCSIZE(7))

Is an array containing all the Zone numbers for the buses in the file (output).

Integer BSOWNE_OUTxxx (ACCCSIZE(7))

Is an array containing all the Owner numbers for the buses in the file (output).

Real BSVOLT_OUTxxx (ACCCSIZE(7))

Is an array containing all the Voltages for the buses in the file (output).

Integer NUAREA_OUTxxx (ACCCSIZE(16))

Is an array containing all the Area numbers in the file (output).

Integer NUZONE_OUTxxx (ACCCSIZE(17))

Is an array containing all the Zone numbers in the file (output).

Integer NUOWNE_OUTxxx (ACCCSIZE(18))	Is an array containing all the Owner numbers in the file (output).
Real NUOWNE_OUTxxx (ACCCSIZE(19))	Is an array containing all the Voltage levels numbers in the file (output).
Character NAAREA_OUTxxx*12 (ACCCSIZE(16))	Is an array containing all the Area names in the file (output).
Character NAZONE_OUTxxx*12 (ACCCSIZE(17))	Is an array containing all the Zone names in the file (output).
Character NAOWNE_OUTxxx*12 (ACCCSIZE(18))	Is an array containing all the Owner names in the file (output).
Integer IERR	Is the error code (output).
	IERR = -1 No results
	IERR = 0 no error occurred.
	IERR = 5 RFILE does not match the one called in ACCC_FILE_SIZE.
	IERR = 6 error in fetching contingency strings.
	IERR = 10 prerequisite requirements for API are not met.

29.9. ACCC_FILE_CNTG_VOLT

This API is used to return voltages for a specified contingency and contingency type for all monitored buses in the contingency data file.

Python syntax:

```
ierr, mv_vmag_outxx = accc_file_cntg_volt(rfile, getwhat, cntpos,
    acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_CONTINGENCY_VOLTAGE(RFILE, GETWHAT, CNTPOS, ACCCSIZE,
    MV_VMAG_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the voltages to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution voltages GETWHAT = 2 Tripping solution voltages GETWHAT = 3 Corrective action solution voltages
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired voltages (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Real MV_VMAG_OUTxx (ACCCSIZE(4))

Is an array containing all the desired voltages for the desired contingency (output).

Integer IERR

Is the error code (output).

IERR = 0 no error occurred.

IERR = 4 error opening RFILE.

IERR = 5 error reading RFILE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.10. ACCC_FILE_CNTG_FLOW

This API routine is obsolete. It has been replaced by the API routine [accc_file_cntg_flow_2](#).

This API is used to return flows for a specified contingency and contingency type for all monitored lines in the contingency data file.

Python syntax:

```
ierr, acflow_outxx, rat_num_outxx = accc_file_cntg_flow(rfile, getwhat,
    cntpos, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_CONTINGENCY_FLOW(RFILE, GETWHAT, CNTPOS, ACCCSIZE,
    ACFLOW_OUTxx, RAT_NUM_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution flows GETWHAT = 2 Tripping solution flows GETWHAT = 3 Corrective action solution flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Real ACFLOW_OUTxx ((ACCCSIZE(1)+ ACCCSIZE(2))

Is an array containing all the desired MVA flows for the desired contingency (output).

Real RAT_NUM_OUTxx (ACCCSIZE(1))

Is an array containing all the desired Ampere flows for the desired contingency (output).

Integer IERR

Is the error code (output).

IERR = 0 no error occurred.

IERR = 4 error opening RFILE.

IERR = 5 error reading RFILE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.11. ACCC_FILE_CNTG_FLOW_2

This API is used to return flows for a specified contingency and contingency type for all monitored lines in the contingency data file.

Python syntax:

```
ierr, acflow_outxx, rat_num_outxx, acswdflow_outxx, swd_rat_num_outxx =
    accc_file_cntg_flow_2(rfile, getwhat, cntpos, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_CONTINGENCY_FLOW_2(RFILE, GETWHAT, CNTPOS, ACCCSIZE,
    ACFLOW_OUTxx, RAT_NUM_OUTxx, ACSWDFLOW_OUTxx, SWD_RAT_NUM_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution flows GETWHAT = 2 Tripping solution flows GETWHAT = 3 Corrective action solution flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Real ACFLOW_OUTxx ((ACCCSIZE(1)+ ACCCSIZE(2))

Is an array containing all the desired MVA flows for the desired contingency (output).

Real RAT_NUM_OUTxx (ACCCSIZE(1))

Is an array containing all the desired Ampere flows for the desired contingency (output).

Real ACSWDFLOW_OUTxx (ACCCSIZE(27))

Is an array containing all the desired MVA flows for the desired SWD (output).

Real SWD_RAT_NUM_OUTxx (AC- Is an array containing all the desired Ampere flows for the desired
CCSIZE(28)) SWD (output).

Integer IERR Is the error code (output).

IERR = 0 no error occurred.

IERR = 4 error opening RFILE.

IERR = 5 error reading RFILE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.12. ACCC_FILE_CNTG_VOLT_FLOW

This API is used to return voltages and flows for a specified contingency and contingency type for all monitored buses and lines in the contingency data file.

Python syntax:

```
ierr, mv_vmag_outxx, acflow_outxx, rat_num_outxx, mvnod_vmag_outxx =
    accc_file_cntg_volt_flow(rfile, getwhat, cntpos, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_CONTINGENCY_VOLT_FLOW(RFILE, GETWHAT, CNTPOS, ACCCSIZE,
    MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx, MVNOD_VMAG_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution voltages and flows GETWHAT = 2 Tripping solution voltages and flows GETWHAT = 3 Corrective action solution voltages and flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Real MV_VMAG_OUTxx (ACCCSIZE(4))

Is an array containing all the desired voltages for the desired contingency (output).

Real ACFLOW_OUTxx (ACCCSIZE(1) +ACCCSIZE(2))

Is an array containing all the desired MVA flows for the desired contingency (output).

Real RAT_NUM_OUTxx (ACCCSIZE(1))

Is an array containing all the desired Ampere flows for the desired contingency (output).

Real MVNOD_VMAG_OUTxx (AC- Is an array containing all the desired monitored node voltages for
CCSIZE(22)) the desired contingency (output)

Integer IERR Is the error code (output).

IERR = 0 no error occurred.

IERR = 5 error reading RFILE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.13. ACCC_FILE_CNTG_VOLT_FLOW_2

This API is used to return voltages and flows for a specified contingency and contingency type for all monitored buses and lines in the contingency data file.

Python syntax:

```
ierr, mv_vmag_outxx, acflow_outxx, rat_num_outxx, mvnod_vmag_outxx,
acswdflow_outxx, swd_rat_num_outxx = accc_file_cntg_volt_flow_2(rfile,
getwhat, cntpos, acccsize)
```

Fortran syntax:

```
CALL GET_ACCC_CONTINGENCY_FLOW_2(RFILE, GETWHAT, CNTPOS, ACCCSIZE,
MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx, MVNOD_VMAG_OUTxx,
ACSWDFLOW_OUTxx, SWD_RAT_NUM_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution voltages and flows GETWHAT = 2 Tripping solution voltages and flows GETWHAT = 3 Corrective action solution voltages and flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.

ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Real MV_VMAG_OUTxx (ACCSIZE(4))

Is an array containing all the desired voltages for the desired contingency (output).

Real ACFLOW_OUTxx (ACCSIZE(1) +ACCCSIZE(2))

Is an array containing all the desired MVA flows for the desired contingency (output).

Real RAT_NUM_OUTxx (ACCSIZE(1))	Is an array containing all the desired Ampere flows for the desired contingency (output).
Real MVNOD_VMAG_OUTxx (ACCSIZE(22))	Is an array containing all the desired monitored node voltages for the desired contingency (output)
Real ACSWDFLOW_OUTxx (ACCSIZE(27))	Is an array containing all the desired MVA flows for the desired SWD (output).
Real SWD_RAT_NUM_OUTxx (ACCSIZE(28))	Is an array containing all the desired Ampere flows for the desired SWD (output).
Integer IERR	Is the error code (output).

IERR = 0 no error occurred.

IERR = 5 error reading RFILE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.14. ACCC_FILE_CNTG_DSCR

This API is used to return voltages and flows for a specified contingency and contingency type for all monitored buses and lines in the contingency data file.

Python syntax:

```
ierr, num_island, case_worst, case_total, cnv_cond, cnt_desc =
    accc_file_cntg_dscr(rfile, getwhat, cntpos, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_CONTINGENCY_DESCRIPTION(RFILE, GETWHAT, CNTPOS,
    ACCCSIZE, NUM_ISLAND, CASE_WORST, CASE_TOTAL, CNV_COND, CNT_DESC, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution voltages and flows GETWHAT = 2 Tripping solution voltages and flows GETWHAT = 3 Corrective action solution voltages and flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

	ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.
	ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.
	ACCCSIZE (14) Name Out option.
	ACCCSIZE (14) = 0 Number.
	ACCCSIZE (14) = 1 Name.
	ACCCSIZE (14) = -1 Undecided.
	ACCCSIZE (15) ACCC file type.
	ACCCSIZE (15) = 0 ACCC.
	ACCCSIZE (15) = 1 N-1-1.
	ACCCSIZE (16) Number of Areas.
	ACCCSIZE (17) Number of Zones.
	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Integer NUM_ISLAND	Is the number of islanded buses in the desired contingency (Output).
Real CASE_WORST	Is the worst case in the desired contingency (Output).
Real CASE_TOTAL	Is the case total in the desired contingency (Output).
Character CNV_COND*34	Is the convergence solution text for the desired contingency (Output).

Character CNT_DESC*160 (32) Is the description of every contingency in the specified contingency group (Output).

Integer IERR Is the error code (output).

IERR = 0 no error occurred.

IERR = 5 error reading RFILE.

IERR = 6 error in fetching contingency strings.

IERR = 10 prerequisite requirements for API are not met.

29.15. ACCC_FILE_CNTG_LOAD

This API is used to return voltages and flows for a specified contingency and contingency type for all monitored buses and lines in the contingency data file.

Python syntax:

```
ierr, num_loadshed, lshed_bus_outxx, lshed_outxx, num_gendisp,
gdisp_bus_outxx, disp_outxx, num_phsshft, pshft_bus_outxx, pshft_outxx =
accc_file_cntg_load(rfile, getwhat, cntpos, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_CONTINGENCY_LOAD(RFILE, GETWHAT, CNTPOS, ACCCSIZE,
NUM_LOADSHED, LSHED_BUS_OUTxx, LSHED_OUTxx, NUM_GENDISP, GDISP_BUS_OUTxx,
GDISP_OUTxx, NUM_PHSSHFT, PSHT_BUS_OUTxx, PSHT_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution loads GETWHAT = 2 Tripping solution loads GETWHAT = 3 Corrective action solution voltages and flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping.

ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions.

ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions.

ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions.

ACCCSIZE (14) Name Out option.

ACCCSIZE (14) = 0 Number.

ACCCSIZE (14) = 1 Name.

ACCCSIZE (14) = -1 Undecided.

ACCCSIZE (15) ACCC file type.

ACCCSIZE (15) = 0 ACCC.

ACCCSIZE (15) = 1 N-1-1.

ACCCSIZE (16) Number of Areas.

ACCCSIZE (17) Number of Zones.

ACCCSIZE (18) Number of Owners.

ACCCSIZE (19) Number of Voltage levels.

ACCCSIZE (20) Number of Ratings.

ACCCSIZE (21) Number of Nodes in ACCC case.

ACCCSIZE (22) Number of Monitored Nodes.

ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).

ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).

ACCCSIZE (25) Number of Monitored Limit Bus records.

ACCCSIZE (26) Number of Monitored Limit Node records.

ACCCSIZE (27) Number of Monitored SWD flows.

ACCCSIZE (28) Number of Monitored SWD ratings.

Integer NUM_LOADSHED

Real LSHED_BUS_OUTxx (ACCSIZE(11))

Real LSHED_OUTxx (2*ACCSIZE(11))

Is the number of loads shed for the desired contingency (Output).

Is an array containing all the load shedding buses for the desired contingency (Output).

Is an array containing all the load shed at the load shedding buses for the desired contingency (Output).

Integer NUM_GENDISP	Is the number of Generators dispatched for the desired contingency (Output).
Real GDISP_BUS_OUTxx (ACCCSIZE(12))	Is an array containing all the generation dispatching buses for the desired contingency (Output).
Real GDISP_OUTxx (2*ACCCSIZE(12))	Is an array containing all the generation dispatch at the generation dispatching buses for the desired contingency (Output).
Integer NUM_PHSSHFT	Is the number of phase shifters for the desired contingency (Output).
Character PSHFT_BUS_OUTxx*33 (ACCCSIZE(13))	Is an array containing all the phase shifting buses for the desired contingency (Output).
Real PSHFT_OUTxx (2*ACCCSIZE(13))	Is an array containing all the phase shifts for the phase shifting buses for the desired contingency (Output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 5 error reading RFILE.
	IERR = 6 error in fetching contingency strings.
	IERR = 10 prerequisite requirements for API are not met.

29.16. ACCC_FILE_SOLUTION

This API is used to return voltages and flows for a specified contingency and contingency type for all monitored buses and lines in the contingency data file.

Python syntax:

```
ierr, cnt_desc, cnv_flg, cnv_cond, num_island, case_worst, case_total,
mv_vmag_outxx, acflow_outxx, rat_num_outxx, lshed_bus_outxx, lshed_outxx,
mvnod_vmagxx = accc_file_solution(rfile, getwhat, cntpos, bus_msm,
sys_msm, acccsize)
```

or:

```
ierr, cnt_desc, cnv_flg, cnv_cond, num_island, case_worst, case_total,
mv_vmag_outxx, acflow_outxx, rat_num_outxx, lshed_bus_outxx,
lshed_outxx, gdispbuxx, gdispxx, phsftnamexx, phsftangxx, mvnod_vmagxx =
accc_file_solution(rfile, getwhat, cntpos, bus_msm, sys_msm, acccsize)
```

Fortran syntax:

```
CALL ACCC_FILE_GET_1CNTGNCY_SOLUTION(RFILE, GETWHAT, CNTPOS,
BUS_MSM, SYS_MSM, ACCCSIZE, CNT_DESC, CNV_FLG, CNV_COND, NUM_ISLAND,
CASE_WORST, CASE_TOTAL, , MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx,
LSHED_BUS_OUTxx, LSHED_OUTxx, MVNOD_VMAGxx, IERR)
```

or:

```
CALL ACCC_FILE_GET_1TRIPPING_SOLUTION(RFILE, GETWHAT, CNTPOS,
BUS_MSM, SYS_MSM, ACCCSIZE, CNT_DESC, CNV_FLG, CNV_COND, NUM_ISLAND,
CASE_WORST, CASE_TOTAL, , MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx,
LSHED_BUS_OUTxx, LSHED_OUTxx, MVNOD_VMAGxx, IERR)
```

or:

```
CALL ACCC_FILE_GET_CACTION_SOLUTION(RFILE, GETWHAT, CNTPOS, BUS_MSM,
SYS_MSM, ACCCSIZE, CNT_DESC, CNV_FLG, CNV_COND, NUM_ISLAND,
CASE_WORST, CASE_TOTAL, , MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx,
LSHED_BUS_OUTxx, LSHED_OUTxx, GDISPBUSxx, GDISPxx, PHSFTNAMExx,
PHSFTANGxx, MVNOD_VMAGxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution loads GETWHAT = 2 Tripping solution loads GETWHAT = 3 Corrective action solution voltages and flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).

Integer BUS_MSM	Is the bus mismatch value to use when reporting contingencies from the contingency file (Input).
Integer SYS_MSM	Is the system mismatch value to use when reporting contingencies from the contingency file (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions. ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions. ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions. ACCCSIZE (14) Name Out option. ACCCSIZE (14) = 0 Number. ACCCSIZE (14) = 1 Name. ACCCSIZE (14) = -1 Undecided. ACCCSIZE (15) ACCC file type. ACCCSIZE (15) = 0 ACCC. ACCCSIZE (15) = 1 N-1-1. ACCCSIZE (16) Number of Areas. ACCCSIZE (17) Number of Zones.

	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Character CNT_DESC*160 (32)	Is the description of every contingency in the specified contingency group (Output).
Logical CNV_FLAG	Is a logical flag indicating whether the specified contingency converged or not (Output).
Character CNV_COND*34	Is the convergence solution text for the desired contingency (Output).
Integer NUM_ISLAND	Is the number of islanded buses in the desired contingency (Output).
Real CASE_WORST	Is the worst case in the desired contingency (Output).
Real CASE_TOTAL	Is the case total in the desired contingency (Output).
Real MV_VMAG_OUTxx * ACCCSIZE(4)	Is an array containing all the desired voltages for the desired contingency (output).
Real ACFLOW_OUTxx (ACCCSIZE(1)+ ACCCSIZE(2))	Is an array containing all the desired MVA flows for the desired contingency (output).
Real RAT_NUM_OUTxx (ACCCSIZE(1))	Is an array containing all the desired Ampere flows for the desired contingency (output).
Real LSHED_BUS_OUTxx (ACCCSIZE(11))	Is an array containing all the load shedding buses for the desired contingency (Output).
Real LSHED_OUTxx (2*ACCCSIZE(11))	Is an array containing all the load shed at the load shedding buses for the desired contingency (Output).
Real MVNOD_VMAGxx (ACCCSIZE(22))	Is an array containing the Monitored Node voltage results (Output).
Integer GDISPBUS (ACCCSIZE(11))	Is an array containing all the generation dispatch buses for the desired contingency (Output).
Real GDISPxx (ACCCSIZE(11))	Is an array containing all the generation dispatched at the generation dispatch buses for the desired contingency (Output).

Character PHSFTNAMExx*62 (ACCCSIZE(11))	Is an array containing all the Phase shifter names (Output).
Real PHSFTANGxx (ACC- CSIZE(11))	Is an array containing all the Phase shifter angles (Output).
Integer IERR	Is the error code (output). IERR = 0 no error occurred. IERR = 4 error opening RFILE. IERR = 5 error reading RFILE. IERR = 6 error in fetching contingency strings. IERR = 10 prerequisite requirements for API are not met.

29.17. ACCC_FILE_SOLUTION_2

This API is used to return voltages and flows for a specified contingency and contingency type for all monitored buses and lines in the contingency data file.

Python syntax:

```
ierr, cnt_desc, cnv_flg, cnv_cond, num_island, case_worst, case_total,
mv_vmag_outxx, acflow_outxx, rat_num_outxx, lshed_bus_outxx,
lshed_outxx, mvnod_vmagxx, acswdflow_outxx, swd_rat_num_outxx =
accc_file_solution_2(rfile, getwhat, cntpos, bus_msm, sys_msm, acccsize)
```

or:

```
ierr, cnt_desc, cnv_flg, cnv_cond, num_island, case_worst, case_total,
mv_vmag_outxx, acflow_outxx, rat_num_outxx, lshed_bus_outxx,
lshed_outxx, gdispbussxx, gdispxx, phsftnamexx, pfsftangxx, mvnod_vmagxx,
acswdflow_outxx, swd_rat_num_outxx = accc_file_solution_2(rfile, getwhat,
cntpos, bus_msm, sys_msm, acccsize)
```

Fortran syntax:

```
CALL GET_ACCC_1CNTGNCY_SOLUTION_2(RFILE, GETWHAT, CNTPOS, BUS_MSM,
SYS_MSM, ACCCSIZE, CNT_DESC, CNV_FLG, CNV_COND, NUM_ISLAND, CASE_WORST,
CASE_TOTAL, MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx, LSHED_BUS_OUTxx,
LSHED_OUTxx, MVNOD_VMAGxx, ACSWDFLOW_OUTxx, SWD_RAT_NUM_OUTxx, IERR)
```

or:

```
CALL GET_ACCC_1TRIPPING_SOLUTION_2(RFILE, GETWHAT, CNTPOS, BUS_MSM,
SYS_MSM, ACCCSIZE, CNT_DESC, CNV_FLG, CNV_COND, NUM_ISLAND, CASE_WORST,
CASE_TOTAL, MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx, LSHED_BUS_OUTxx,
LSHED_OUTxx, MVNOD_VMAGxx, ACSWDFLOW_OUTxx, SWD_RAT_NUM_OUTxx, IERR)
```

or:

```
CALL GET_ACCC_1CACTION_SOLUTION_2(RFILE, GETWHAT, CNTPOS, BUS_MSM,
SYS_MSM, ACCCSIZE, CNT_DESC, CNV_FLG, CNV_COND, NUM_ISLAND, CASE_WORST,
CASE_TOTAL, MV_VMAG_OUTxx, ACFLOW_OUTxx, RAT_NUM_OUTxx, LSHED_BUS_OUTxx,
LSHED_OUTxx, GDISPBUSxx, GDISPxx, PHSFTNAMExx, PFSFTANGxx, MVNOD_VMAGxx,
ACSWDFLOW_OUTxx, SWD_RAT_NUM_OUTxx, IERR)
```

where:

Character RFILE*260	Is the Contingency Solution Output File (input; no default allowed).
Integer GETWHAT	Is the flows to return for the specified contingency (Input). The values are as follows. GETWHAT = 1 Contingency solution loads GETWHAT = 2 Tripping solution loads GETWHAT = 3 Corrective action solution voltages and flows
Long Integer CNTPOS	Is the contingency position in the Contingency Solution Output file from which to read the desired flows (Input).

Integer BUS_MSM	Is the bus mismatch value to use when reporting contingencies from the contingency file (Input).
Integer SYS_MSM	Is the system mismatch value to use when reporting contingencies from the contingency file (Input).
Integer ACCCSIZE(28)	Is an array containing the number of the various elements in the ACCC file (Input). The values are as follows. ACCCSIZE (1) Number of monitored lines. ACCCSIZE (2) Number of interfaces. ACCCSIZE (3) Number of Contingencies + Base Case. ACCCSIZE (4) Number of voltage buses. ACCCSIZE (5) Number of voltage records. ACCCSIZE (6) number monitored bus records (could be more than ACCCSIZE(4)). ACCCSIZE (7) Number of buses in ACCC case. ACCCSIZE (8) Acc file version number. ACCCSIZE (9) Max # of LOAD SHEDS due to dispatch and contingency. ACCCSIZE (10) Max # of LOAD SHEDS due to tripping. ACCCSIZE (11) Max # of LOAD SHEDS due to corrective actions. ACCCSIZE (12) Max # of GENERATION DISPATCHED due to corrective actions. ACCCSIZE (13) max # of PHASE SHIFTER changed due to corrective actions. ACCCSIZE (14) Name Out option. ACCCSIZE (14) = 0 Number. ACCCSIZE (14) = 1 Name. ACCCSIZE (14) = -1 Undecided. ACCCSIZE (15) ACCC file type. ACCCSIZE (15) = 0 ACCC. ACCCSIZE (15) = 1 N-1-1. ACCCSIZE (16) Number of Areas. ACCCSIZE (17) Number of Zones.

	ACCCSIZE (18) Number of Owners.
	ACCCSIZE (19) Number of Voltage levels.
	ACCCSIZE (20) Number of Ratings.
	ACCCSIZE (21) Number of Nodes in ACCC case.
	ACCCSIZE (22) Number of Monitored Nodes.
	ACCCSIZE (23) Number of Monitored Node records (Range and Deviation).
	ACCCSIZE (24) Number of Monitored Node records (Range, Deviation and Limit) (could be more than ACCCSIZE(22)).
	ACCCSIZE (25) Number of Monitored Limit Bus records.
	ACCCSIZE (26) Number of Monitored Limit Node records.
	ACCCSIZE (27) Number of Monitored SWD flows.
	ACCCSIZE (28) Number of Monitored SWD ratings.
Character CNT_DESC*160 (32)	Is the description of every contingency in the specified contingency group (Output).
Logical CNV_FLAG	Is a logical flag indicating whether the specified contingency converged or not (Output).
Character CNV_COND*34	Is the convergence solution text for the desired contingency (Output).
Integer NUM_ISLAND	Is the number of islanded buses in the desired contingency (Output).
Real CASE_WORST	Is the worst case in the desired contingency (Output).
Real CASE_TOTAL	Is the case total in the desired contingency (Output).
Real MV_VMAG_OUTxx * ACCCSIZE(4)	Is an array containing all the desired voltages for the desired contingency (output).
Real ACFLOW_OUTxx (ACCCSIZE(1)+ ACCCSIZE(2))	Is an array containing all the desired MVA flows for the desired contingency (output).
Real RAT_NUM_OUTxx (ACCCSIZE(1))	Is an array containing all the desired Ampere flows for the desired contingency (output).
Real LSHED_BUS_OUTxx (ACCCSIZE(11))	Is an array containing all the load shedding buses for the desired contingency (Output).
Real LSHED_OUTxx (2*ACCCSIZE(11))	Is an array containing all the load shed at the load shedding buses for the desired contingency (Output).
Real MVNOD_VMAGxx (ACCCSIZE(22))	Is an array containing the Monitored Node voltage results (Output).
Integer GDISPBUS (ACCCSIZE(11))	Is an array containing all the generation dispatch buses for the desired contingency (Output).
Real GDISPxx (ACCCSIZE(11))	Is an array containing all the generation dispatched at the generation dispatch buses for the desired contingency (Output).

Character PHSFTNAMExx*62 (ACCCSIZE(11))	Is an array containing all the Phase shifter names (Output).
Real PHSFTANGxx (ACC- CSIZE(11))	Is an array containing all the Phase shifter angles (Output).
Real ACSWDFLOW_OUTxx (ACC- CSIZE(27))	Is an array containing all the desired MVA flows for the desired SWD (output).
Real SWD_RAT_NUM_OUTxx (AC- CCSIZE(28))	Is an array containing all the desired Ampere flows for the desired SWD (output).
Integer IERR	Is the error code (output).
	IERR = 0 no error occurred.
	IERR = 4 error opening RFILE.
	IERR = 5 error reading RFILE.
	IERR = 6 error in fetching contingency strings.
	IERR = 10 prerequisite requirements for API are not met.

Chapter 30

Other Python Modules

This chapter identifies other Python modules that are delivered as part of the PSS®E API.

30.1. Modules Supplied with a GUI

These modules can be imported or run by themselves. They display a GUI that presents their functionality.

`createusrdllw` – Create a user dll for dynamics simulation. Combines the traditional compile and cload4 processes in a more user-friendly way.

`excelexportw` – Provides tools to export psse results to Excel, e.g., pv, qv, and acc files.

`plot2wordw` – Provides tools to create Word documents from plots.

30.2. Modules that Define Functions

Each of these modules contains help information about the functions that they define. Import the module and run the help function on them for more information.

bsntools – Bus renaming tools. Functions to modify bus names by area. Requires psspy.

caspy – Create an object to directly returns arrays of data from a saved case file. Encapsulates the functionality of the Saved Case Data Extraction routines (USRCAS).

dyntools – Tools for processing channel output files, including export to Excel.

pssgrpg – Provides functions intended to be used to supply values to report labels on 1-line diagrams.

pssppe – Convert csv file to a dictionary of tuples.

pssras – Define a Remedial Action Scheme. Used with the Powerflow Customization Interface.

redirect – Tools for directing PSS®E output to Python, and vice versa.

sliderPy – Provides functions to directly manipulate diagram elements.

wordpy – Provides Python functions to interface with Microsoft Word.

Index

A

A2TRMDCCCHAR, 2830
A2TRMDCCCONVCHAR, 2843
A2TRMDCCCONVCOUNT, 2846
A2TRMDCCCONVCPLX, 2848
A2TRMDCCCONVINT, 2850
A2TRMDCCCONVREAL, 2852
A2TRMDCCCONVTYPES, 2855
A2TRMDCCCOUNT, 2832
A2TRMDCCPLX, 2833
A2TRMDCINT, 2835
A2TRMDCREAL, 2837
A2TRMDCTYPES, 2841
AAREACHAR, 2936
AAREACOUNT, 2938
AAREACPLX, 2939
AAREAIN, 2941
AAREAREAL, 2943
AAREATYPES, 2946
ABRNCHAR, 2754
ABRNCOUNT, 2757
ABRNCPLX, 2759
ABRNINT, 2761
ABRNREAL, 2764
ABRNTYPES, 2772
ABUSCHAR, 2632
ABUSCOUNT, 2634
ABUSCPLX, 2635
ABUSINT, 2637
ABUSREAL, 2639
ABUSTYPES, 2641
ACCC, 2
ACCC_2, 4
ACCC_MULTIPLE_MERGE, 6
ACCC_MULTIPLE_RUN_REPORT, 8
ACCC_MULTIPLE_RUN_REPORT_2, 11
ACCC_PARALLEL, 15
ACCC_PARALLEL_2, 18
ACCC_RAS, 3129
ACCC_RAS_2, 3130
ACCC_SINGLE_RUN_REPORT, 21
ACCC_SINGLE_RUN_REPORT_2, 24
ACCC_SINGLE_RUN_REPORT_3, 27
ACCC_SINGLE_RUN_REPORT_4, 30
ACCC_SINGLE_RUN_REPORT_5, 33
ACCC_TRIP_COR, 37
ACCC_TRIP_COR_2, 41
ACCC_TRIP_COR_3, 45
ACCC_WITH_COR, 50
ACCC_WITH_COR_2, 54
ACCC_WITH_COR_3, 58
ACCC_WITH_DSP, 62
ACCC_WITH_DSP_2, 65
ACCC_WITH_DSP_3, 68
ACCC_WITH_TRIP, 71
ACCC_WITH_TRIP_2, 74
ACCC_WITH_TRIP_PARALLEL, 77
ACCDEFAULTS, 3260
ACCONTBYCONT, 3262
ACCONTBYMONEL, 3264
ACCOR, 80
ACCOR_2, 83
ACCOR_3, 86
ACCSOLVE, 3266
ACLFDC, 3268
ACLFNS, 3270
ACSOLVE_LFD, 3272
ACSOLVE_LFN, 3273
ACTIVITYACCONT, 3274
ACTIVITYMUST, 3275

ACTTRANSFERLIMITSTUDY, 3276
ADD_CCT2DCO_MODEL, 1780
ADD_CCT2WTD_MODEL, 1782
ADD_CCT3WTD_MODEL, 1784
ADD_CCTBRND_MODEL, 1786
ADD_CCTBRNO_MODEL, 1788
ADD_CCTBUSO_MODEL, 1790
ADD_CCTMCNO_MODEL, 1791
ADD_CCTMCNP_MODEL, 1793
ADD_CCTMSCO_MODEL, 1795
ADD_CCTSWSO_MODEL, 1796
ADD_CCTSWSO_MODEL_2, 1798
ADD_DETAILS_TO_OPF_LOG, 1020
ADD_FACTS_DEVICE_MODEL, 1728
ADD_FCTSAUXSIGNAL_MODEL, 1879
ADD_INDMAC_MODEL, 1768
ADD_LOAD_MODEL, 1666
ADD_MTDCAUXSIGNAL_MODEL, 1881
ADD_MTDCLINE_MODEL, 1695
ADD_PLANT_MODEL, 1636
ADD_RELAY_MODEL, 1681
ADD_SWSHUNT_MODEL, 1744
ADD_SWSHUNT_MODEL_2, 1746
ADD_TTDCAUXSIGNAL_MODEL, 1883
ADD_TTDCLINE_MODEL, 1697
ADD_VSDCAUXSIGNAL_MODEL, 1885
ADD_VSDCLINE_MODEL, 1699
ADD_WIND_MODEL, 1653
ADD2WINDINGCONTINGENCYELEMENT, 3132
ADD2WINDINGREMEDIALACTIONELEMENT, 3134
ADD3WINDINGCONTINGENCYELEMENT, 3137
ADD3WINDINGREMEDIALACTIONELEMENT, 3140
ADDACTIONCONTINGENCYELEMENT, 3143
ADDACTIONREMEDIALACTIONELEMENT, 3145
ADDBUSCONTINGENCYELEMENT, 3148
ADDBUSREMEDIALACTIONELEMENT, 3150
ADDDCONTINGENCY, 3153
ADDDCONTINGENCYELEMENT, 3154
ADDDCCONVCONTINGENCYELEMENT, 3156
ADDDCCONVREMEDIALACTIONELEMENT, 3158
ADDDCLINECONTINGENCYELEMENT, 3161
ADDDCLINEREMEDIALACTIONELEMENT, 3163
ADDFIXSHUNTCONTINGENCYELEMENT, 3166
ADDFIXSHUNTREMEDIALACTIONELEMENT, 3168
ADDFUNCTION, 3241
ADDGENERATORCONTINGENCYELEMENT, 3171
ADDGENERATORREMEDIALACTIONELEMENT, 3173
ADDLOADCONTINGENCYELEMENT, 3176
ADDLOADREMEDIALACTIONELEMENT, 3178
ADDMODELLIBRARY, 1496
ADDPYTHONCONTINGENCYELEMENT, 3181
ADDPYTHONREMEDIALACTIONELEMENT, 3183
ADDREMEDIALACTION, 3185
ADDREMEDIALACTIONELEMENT, 3186
ADDSUBCONTINGENCYELEMENT, 3189
ADDSUBREMEDIALACTIONELEMENT, 3191
ADDTRANSACTION, 3277
ADDVSCDCCONTINGENCYELEMENT, 3194
ADDVSCDCREMEDIALACTIONELEMENT, 3196
AFACTSBUSCHAR, 2921
AFACTSBUSCOUNT, 2924
AFACTSBUSCPLX, 2926
AFACTSBUSINT, 2928
AFACTSBUSREAL, 2931
AFACTSBUSTYPES, 2934
AFACTSCHAR, 2907
AFACTSCOUNT, 2909
AFACTSCPLX, 2911
AFACTSINT, 2913
AFACTSREAL, 2915
AFACTSTYPES, 2919
AFLOWCHAR, 2740
AFLOWCOUNT, 2743
AFLOWCPLX, 2745
AFLOWINT, 2747
AFLOWREAL, 2749

AFLOWTYPES, 2752
 AFXSHNTBUSCHAR, 2694
 AFXSHNTBUSCOUNT, 2696
 AFXSHNTBUSCPLX, 2697
 AFXSHNTBUSINT, 2699
 AFXSHNTBUSREAL, 2701
 AFXSHNTBUSTYPES, 2703
 AFXSHUNTCHAR, 2705
 AFXSHUNTCount, 2707
 AFXSHUNTCLX, 2708
 AFXSHUNTINT, 2710
 AFXSHUNTREAL, 2712
 AFXSHUNTYPES, 2714
 AGENBUSCHAR, 2643
 AGENBUSCOUNT, 2645
 AGENBUSCPLX, 2646
 AGENBUSINT, 2648
 AGENBUSREAL, 2650
 AGENBUSTYPES, 2653
 AINDMACBUSCHAR, 2972
 AINDMACBUSCOUNT, 2974
 AINDMACBUSCPLX, 2976
 AINDMACBUSINT, 2978
 AINDMACBUSREAL, 2980
 AINDMACBUSTYPES, 2983
 AINDMACCHAR, 2985
 AINDMACCOUNT, 2987
 AINDMACCPLX, 2989
 AINDMACINT, 2991
 AINDMACREAL, 2994
 AINDMACTYPES, 2997
 ALERT, 3205
 ALERT_OUTPUT, 89
 ALLOW_PSSUSERPF, 91
 ALOADCHAR, 2681
 ALOADCOUNT, 2683
 ALOADCPLX, 2684
 ALOADINT, 2687
 ALOADREAL, 2689
 ALOADTYPES, 2692
 ALODBUSCHAR, 2667
 ALODBUSCOUNT, 2669
 ALODBUSCPLX, 2671
 ALODBUSINT, 2674
 ALODBUSREAL, 2676
 ALODBUSTYPES, 2679
 ALPH, 92
 AMACHCHAR, 2655
 AMACHCOUNT, 2657
 AMACHCPLX, 2658
 AMACHINT, 2660
 AMACHREAL, 2662
 AMACHTYPES, 2665
 AMULTITRMDCCCHAR, 2857
 AMULTITRMDCCCONVCHAR, 2868
 AMULTITRMDCCCONVCount, 2871
 AMULTITRMDCCCONVCPLX, 2873
 AMULTITRMDCCCONVINT, 2875
 AMULTITRMDCCCONVREAL, 2877
 AMULTITRMDCCCONVTYPES, 2880
 AMULTITRMDCCCOUNT, 2859
 AMULTITRMDCCCPLX, 2860
 AMULTITRMDCCINT, 2862
 AMULTITRMDCCREAL, 2864
 AMULTITRMDCCTYPES, 2866
 ANODECHAR, 3007
 ANODECOUNT, 3009
 ANODEINT, 3010
 ANODEREAL, 3012
 ANODETYPES, 3013
 ANSI, 1203
 ANSI_2, 1205
 ANSI_3, 1207
 AOWNERCHAR, 2948
 AOWNERCOUNT, 2950
 AOWNERCPLX, 2951
 AOWNERINT, 2953
 AOWNERREAL, 2955
 AOWNERTYPES, 2958
 APIERRSTR, 2120
 APPEND_ACCC, 93
 APPEND_RAS, 3199
 APPLY_ALTERNATE_STEP_SIZE, 1021
 APPLY_AUTOMATIC_SCALING, 1022
 APPLY_VAR_LIMITS, 95
 APPLYSINGLECONT, 3278
 ARDAT, 2121
 AREA, 96
 AREA_2, 97
 AREA_DATA, 658
 AREA_ZONE, 98
 AREABUBBLE, 3279
 AREAIMPACT, 3280
 AREASINZONES, 3282
 AREASLACKS, 3283
 AREASUMMARY, 3284
 AREDAT, 2123
 AREINT, 2124
 ARENAM, 2125
 ARENUM, 2126
 AREUSE, 2127
 ARITJ, 2128
 ARNM, 99
 ARNM_2, 101
 ASCC, 1210
 ASCC_1A, 1212
 ASCC_2, 1214
 ASCC_3, 1216
 ASCC_SCFIL, 1220
 ASTASWDEVCHAR, 3015
 ASTASWDEVCount, 3017
 ASTASWDEVCLX, 3018
 ASTASWDEVINT, 3020
 ASTASWDEVREAL, 3022
 ASTASWDEVTYPES, 3024
 ASTATIONCHAR, 2999
 ASTATIONCOUNT, 3001
 ASTATIONINT, 3002
 ASTATIONREAL, 3004
 ASTATIONTYPES, 3005
 ASTR, 1497
 ASWSHCHAR, 2727
 ASWSHCount, 2729
 ASWSHCPLX, 2730
 ASWSHINT, 2732
 ASWSHREAL, 2734
 ASWSHTYPES, 2738
 ASWSHNTBUSCHAR, 2716
 ASWSHNTBUSCOUNT, 2718
 ASWSHNTBUSCPLX, 2719
 ASWSHNTBUSINT, 2721
 ASWSHNTBUSREAL, 2723
 ASWSHNTBUSTYPES, 2725
 ASYS, 1966
 ASYSDEF, 1967
 ASYSINIT, 1968
 ATERMINALCHAR, 3026
 ATERMINALCOUNT, 3028
 ATERMINALINT, 3029
 ATERMINALTYPES, 3031
 ATR3CHAR, 2795
 ATR3COUNT, 2798
 ATR3CPLX, 2800
 ATR3INT, 2803
 ATR3REAL, 2806
 ATR3TYPES, 2808
 ATRNCHAR, 2774
 ATRNCount, 2777
 ATRNCPLX, 2779
 ATRNINT, 2782
 ATRNREAL, 2785
 ATRNTYPES, 2793

AULIST, 1500
 AUXMOD_PACK, 1887
 AUXMOD_UNCONNECTED, 1888
 AUXMOD_USER, 1889
 AVOLTAGEDROOPCHAR, 3117
 AVOLTAGEDROOPCOUNT, 3118
 AVOLTAGEDROOPINT, 3119
 AVOLTAGEDROOPREAL, 3120
 AVSCDCCHAR, 2882
 AVSCDCCONVCHAR, 2893
 AVSCDCCONVCOUNT, 2896
 AVSCDCCONVCPLX, 2898
 AVSCDCCONVINT, 2900
 AVSCDCCONVREAL, 2902
 AVSCDCCONVTYPES, 2905
 AVSCDCCOUNT, 2884
 AVSCDCCPLX, 2885
 AVSCDCINT, 2887
 AVSCDCREAL, 2889
 AVSCDCTYPES, 2891
 AWNDCHAR, 2810
 AWNDCOUNT, 2813
 AWNDCPLX, 2815
 AWNDINT, 2817
 AWNDREAL, 2820
 AWNDTYPES, 2828
 AZMUTCHAR, 3033
 AZMUTCOUNT, 3035
 AZMUTCPLX, 3037
 AZMUTINT, 3039
 AZMUTREAL, 3041
 AZMUTTYPES, 3043
 AZONECHAR, 2960
 AZONECOUNT, 2962
 AZONECPLX, 2963
 AZONEINT, 2965
 AZONEREAL, 2967
 AZONETYPES, 2970

B

BAD_ITER_COARSE_LIMIT, 1023
 BAD_ITER_FINE_LIMIT, 1024
 BASE_FREQUENCY, 103
 BEGINREPORT, 3206
 BGEN, 104
 BKDY, 1221
 BRANCH_APP_R_X_CHANNEL, 1611
 BRANCH_CHNG, 660
 BRANCH_CHNG_3, 662
 BRANCH_DATA, 665
 BRANCH_DATA_3, 667
 BRANCH_MVA_CHANNEL, 1613
 BRANCH_P_AND_Q_CHANNEL, 1615
 BRANCH_P_CHANNEL, 1617
 BRANCHSENSITIVITY, 3285
 BRCH, 105
 BRCH_2, 107
 BRNCUR, 2129
 BRNDAT, 2130
 BRNDT2, 2132
 BRNFLO, 2134
 BRNINT, 2135
 BRNMSC, 2137
 BRNMVA, 2139
 BRNNAM, 2140
 BRNSTT, 2141
 BSNM, 109
 BSYS, 1970
 BSYSADD, 1972
 BSYSDEF, 1974
 BSYSDELO, 1975
 BSYSINIT, 1976
 BSYSISDEF, 2142
 BSYSMEM, 1977
 BSYSO, 1978

BSYSRCL, 1979
 BUS_CHNG_3, 670
 BUS_CHNG_4, 672
 BUS_DATA, 674
 BUS_DATA_2, 676
 BUS_DATA_3, 678
 BUS_DATA_4, 680
 BUS_FREQUENCY_CHANNEL, 1628
 BUS_INPUT, 113
 BUS_NUMBER, 682
 BUS_OUTPUT, 114
 BUS_SIZE_LEVEL, 115
 BUSDAT, 2143
 BUSDT1, 2144
 BUSDT2, 2146
 BUSEX5, 2148
 BUSINT, 2149
 BUSMSM, 2150
 BUSN, 112
 BUSORDPOS, 2151
 BUSSECTDAT, 2152
 BUSSECTDT1, 2153
 BUSSECTDT2, 2155
 BUSSECTEX5, 2157
 BUSSECTINT, 2158

C

CA_ITERATIONS, 117
 CASE, 116
 CASE_TITLE_DATA, 683
 CASOLUTION_PARAMETERS, 684
 CASOLUTION_PARAMETERS_2, 685
 CCT2DCO_LIST, 1802
 CCT2DCOMOD_REMOVE, 1800
 CCT2DCOMOD_STATUS, 1801
 CCT2WTD_LIST, 1805
 CCT2WTDMOD_REMOVE, 1803
 CCT2WTDMOD_STATUS, 1804
 CCT3WTD_LIST, 1808
 CCT3WTDMOD_REMOVE, 1806
 CCT3WTDMOD_STATUS, 1807
 CCTBRND_LIST, 1811
 CCTBRNDMOD_REMOVE, 1809
 CCTBRNDMOD_STATUS, 1810
 CCTBRNO_LIST, 1814
 CCTBRNOMOD_REMOVE, 1812
 CCTBRNOMOD_STATUS, 1813
 CCTBUSO_LIST, 1817
 CCTBUSOMOD_REMOVE, 1815
 CCTBUSOMOD_STATUS, 1816
 CCTMCNO_LIST, 1820
 CCTMCNOMOD_REMOVE, 1818
 CCTMCNOMOD_STATUS, 1819
 CCTMCNP_LIST, 1823
 CCTMCNPMOD_REMOVE, 1821
 CCTMCNPMOD_STATUS, 1822
 CCTMDLNAM_2DCO, 2159
 CCTMDLNAM_2WTD, 2160
 CCTMDLNAM_3WTD, 2161
 CCTMDLNAM_BRND, 2162
 CCTMDLNAM_BRNO, 2163
 CCTMDLNAM_BUSO, 2164
 CCTMDLNAM_MCNO, 2165
 CCTMDLNAM_MCNP, 2166
 CCTMDLNAM_MSCO, 2167
 CCTMDLNAM_SWO_2, 2168
 CCTMIND_2DCO, 2169
 CCTMIND_2WTD, 2170
 CCTMIND_3WTD, 2172
 CCTMIND_BRND, 2174
 CCTMIND_BRNO, 2176
 CCTMIND_BUSO, 2178
 CCTMIND_MCNO, 2179
 CCTMIND_MCNP, 2180
 CCTMIND_MSCO, 2181

CCTMIND_SWO, 2182
CCTMIND_SWO_2, 2184
CCTMOD_PACK, 1824
CCTMOD_USER, 1825
CCTMSCO_LIST, 1828
CCTMSCOMOD_REMOVE, 1826
CCTMSCOMOD_STATUS, 1827
CCTSWO_LIST, 1833
CCTSWO_SOMOD_REMOVE, 1829
CCTSWO_SOMOD_REMOVE_2, 1830
CCTSWO_SOMOD_STATUS, 1831
CCTSWO_SOMOD_STATUS_2, 1832
CDETAILBRANCHES, 3287
CDETAILINTERFACES, 3288
CDETAILVOLTAGEBUSES, 3289
CHANGE_CCT2DCOMOD_CHRICN, 1834
CHANGE_CCT2DCOMOD_CON, 1835
CHANGE_CCT2DCOMOD_ICON, 1836
CHANGE_CCT2DCOMOD_VAR, 1837
CHANGE_CCT2WDMOD_CHRICN, 1838
CHANGE_CCT2WDMOD_CON, 1839
CHANGE_CCT2WDMOD_ICON, 1840
CHANGE_CCT2WDMOD_VAR, 1841
CHANGE_CCT3WDMOD_CHRICN, 1842
CHANGE_CCT3WDMOD_CON, 1843
CHANGE_CCT3WDMOD_ICON, 1844
CHANGE_CCT3WDMOD_VAR, 1845
CHANGE_CCTBRNDMOD_CHRICN, 1846
CHANGE_CCTBRNDMOD_CON, 1847
CHANGE_CCTBRNDMOD_ICON, 1848
CHANGE_CCTBRNDMOD_VAR, 1849
CHANGE_CCTBRNOMOD_CHRICN, 1850
CHANGE_CCTBRNOMOD_CON, 1851
CHANGE_CCTBRNOMOD_ICON, 1852
CHANGE_CCTBRNOMOD_VAR, 1853
CHANGE_CCTBUSOMOD_CHRICN, 1854
CHANGE_CCTBUSOMOD_CON, 1855
CHANGE_CCTBUSOMOD_ICON, 1856
CHANGE_CCTBUSOMOD_VAR, 1857
CHANGE_CCTMCNOMOD_CHRICN, 1858
CHANGE_CCTMCNOMOD_CON, 1859
CHANGE_CCTMCNOMOD_ICON, 1860
CHANGE_CCTMCNOMOD_VAR, 1861
CHANGE_CCTMCNPMOD_CHRICN, 1862
CHANGE_CCTMCNPMOD_CON, 1863
CHANGE_CCTMCNPMOD_ICON, 1864
CHANGE_CCTMCNPMOD_VAR, 1865
CHANGE_CCTMSCOMOD_CHRICN, 1866
CHANGE_CCTMSCOMOD_CON, 1867
CHANGE_CCTMSCOMOD_ICON, 1868
CHANGE_CCTMSCOMOD_VAR, 1869
CHANGE_CCTSWO_SOMOD_CHRICN, 1870
CHANGE_CCTSWO_SOMOD_CHRICN_2, 1871
CHANGE_CCTSWO_SOMOD_CON, 1872
CHANGE_CCTSWO_SOMOD_CON_2, 1873
CHANGE_CCTSWO_SOMOD_ICON, 1874
CHANGE_CCTSWO_SOMOD_ICON_2, 1875
CHANGE_CCTSWO_SOMOD_VAR, 1876
CHANGE_CCTSWO_SOMOD_VAR_2, 1877
CHANGE_CHANNEL, 1593
CHANGE_CHANNEL_OUT_FILE, 1501
CHANGE_CHRICN, 1502
CHANGE_CON, 1503
CHANGE_FCTMOD_CHRICN, 1730
CHANGE_FCTMOD_CON, 1731
CHANGE_FCTMOD_DATA, 1732
CHANGE_FCTMOD_ICON, 1734
CHANGE_FCTMOD_VAR, 1735
CHANGE_FCTSAUXMOD_CHRICN, 1890
CHANGE_FCTSAUXMOD_CON, 1892
CHANGE_FCTSAUXMOD_DATA, 1894
CHANGE_FCTSAUXMOD_ICON, 1896
CHANGE_FCTSAUXMOD_VAR, 1898
CHANGE_GREF, 1504
CHANGE_ICON, 1505
CHANGE_IMMOD_CHRICN, 1770
CHANGE_IMMOD_CON, 1771
CHANGE_IMMOD_ICON, 1772
CHANGE_IMMOD_VAR, 1773
CHANGE_LDMOD_CHRICN, 1668
CHANGE_LDMOD_CON, 1669
CHANGE_LDMOD_DATA, 1670
CHANGE_LDMOD_ICON, 1672
CHANGE_LDMOD_VAR, 1673
CHANGE_MTDCAUXMOD_CHRICN, 1900
CHANGE_MTDCAUXMOD_CON, 1902
CHANGE_MTDCAUXMOD_DATA, 1904
CHANGE_MTDCAUXMOD_ICON, 1906
CHANGE_MTDCAUXMOD_VAR, 1908
CHANGE_MTDCLMOD_CHRICN, 1700
CHANGE_MTDCLMOD_CON, 1701
CHANGE_MTDCLMOD_DATA, 1702
CHANGE_MTDCLMOD_ICON, 1704
CHANGE_MTDCLMOD_VAR, 1705
CHANGE_PLMOD_CHRICN, 1638
CHANGE_PLMOD_CON, 1639
CHANGE_PLMOD_DATA, 1640
CHANGE_PLMOD_ICON, 1642
CHANGE_PLMOD_VAR, 1643
CHANGE_RLMOD_CHRICN, 1683
CHANGE_RLMOD_CON, 1684
CHANGE_RLMOD_DATA, 1685
CHANGE_RLMOD_ICON, 1687
CHANGE_RLMOD_VAR, 1688
CHANGE_STATE, 1506
CHANGE_SWO_SOMOD_CHRICN, 1748
CHANGE_SWO_SOMOD_CHRICN_2, 1749
CHANGE_SWO_SOMOD_CON, 1750
CHANGE_SWO_SOMOD_CON_2, 1751
CHANGE_SWO_SOMOD_ICON, 1752
CHANGE_SWO_SOMOD_ICON_2, 1753
CHANGE_SWO_SOMOD_VAR, 1754
CHANGE_SWO_SOMOD_VAR_2, 1755
CHANGE_SWOREF, 1507
CHANGE_SWOREF_2, 1508
CHANGE_TTDCAUXMOD_CHRICN, 1910
CHANGE_TTDCAUXMOD_CON, 1912
CHANGE_TTDCAUXMOD_DATA, 1914
CHANGE_TTDCAUXMOD_ICON, 1916
CHANGE_TTDCAUXMOD_VAR, 1918
CHANGE_TTDCLMOD_CHRICN, 1706
CHANGE_TTDCLMOD_CON, 1707
CHANGE_TTDCLMOD_DATA, 1708
CHANGE_TTDCLMOD_ICON, 1710
CHANGE_TTDCLMOD_VAR, 1711
CHANGE_VAR, 1509
CHANGE_VREF, 1510
CHANGE_VSDCAUXMOD_CHRICN, 1920
CHANGE_VSDCAUXMOD_CON, 1921
CHANGE_VSDCAUXMOD_DATA, 1922
CHANGE_VSDCAUXMOD_ICON, 1924
CHANGE_VSDCAUXMOD_VAR, 1925
CHANGE_VSDCLMOD_CHRICN, 1712
CHANGE_VSDCLMOD_CON, 1713
CHANGE_VSDCLMOD_DATA, 1714
CHANGE_VSDCLMOD_ICON, 1716
CHANGE_VSDCLMOD_VAR, 1717
CHANGE_WNMOD_CHRICN, 1655
CHANGE_WNMOD_CON, 1656
CHANGE_WNMOD_ICON, 1657
CHANGE_WNMOD_VAR, 1658
CHANGEDIAGCONTOUR, 1990
CHANGEPARAMS, 3290
CHANNELFILEEXCELEXPOT, 3242
CHECK_POWERFLOW_DATA, 119
CHECK_SEQUENCE_DATA, 1223
CHECKDIAGFILE, 1992
CHECKVOLTAGELIMITS, 118
CHKCNTDUPLICON, 121
CHKCNTDUPLIDFX, 122
CHKTRE, 2186
CHNVAL, 2187

CHSB, 1594
 CLAMP_NONOPTIMIZED_GENS, 1025
 CLEARALERTOUTPUT, 3207
 CLEARMULTISTUDY, 3297
 CLEARPROGRESSOUTPUT, 3208
 CLOSE_POWERFLOW, 123
 CLOSE_REPORT, 124
 CLOSEDIAGFILE, 1993
 CLOSEEVENTSTUDYFILE, 3108
 CLOSESCENARIOFILE, 3056
 CMPR, 125
 CNALLTRANSELBRANCHES, 3298
 CNALLTRANSELFLOWGATES, 3299
 CNALLTRANSELINTERFACES, 3300
 CNALLVIOLATED, 3301
 CNALLVIOLFREQ, 3302
 CNBASEVIOLATED, 3303
 CNCINITSELBRANCHES, 3304
 CNCINITSELINTERFACES, 3305
 CNCOMPSELBRANCHES, 3306
 CNCOMPSELINTERFACES, 3307
 CNCOMPSELVOLTAGEBUSES, 3308
 CNCRESULTSSSELBRANCHES, 3309
 CNCRESULTSSSELINTERFACES, 3310
 CNDETAILSELFLOWGATES, 3311
 CNDETAILSELINTERFACES, 3312
 CNFACTORSELFLOWGATES, 3313
 CNFREQSELBRANCHES, 3314
 CNFREQSELBRANCHES_TBL, 3315
 CNFREQSELINTERFACES, 3316
 CNFREQSELINTERFACES_TBL, 3317
 CNFREQSELVOLTAGEBUSES, 3318
 CNGAPPSELBRANCHES, 3319
 CNGAPPSELFLOWGATES, 3320
 CNGAPPSELINTERFACES, 3321
 CNIMPACTSELBRANCHES, 3322
 CNIMPACTSELFLOWGATES, 3323
 CNIMPACTSELINTERFACES, 3324
 CNLISTSELBRANCHES, 3325
 CNLISTSELBRANCHES_TBL, 3326
 CNLISTSELFLOWGATES, 3327
 CNLISTSELFLOWGATES_TBL, 3328
 CNLISTSELINTERFACES, 3329
 CNLISTSELINTERFACES_TBL, 3330
 CNLISTSELVOLTAGEBUSES, 3331
 CNOTDFSELBRANCHES, 3332
 CNOTDFSELINTERFACES, 3333
 CNSELECTBRANCHBYALL, 3334
 CNSELECTBRANCHBYAREAS, 3335
 CNSELECTBRANCHBYBRANCHES, 3336
 CNSELECTBRANCHBYBUSES, 3337
 CNSELECTBRANCHBYIMPACT, 3338
 CNSELECTBRANCHBYTIES, 3339
 CNSELECTBRANCHBYVIOL, 3340
 CNSELECTBRANCHBYZONES, 3341
 CNSELECTFGATEBYALL, 3342
 CNSELECTFGATEBYCONT, 3343
 CNSELECTFGATEBYID, 3344
 CNSELECTFGATEBYIMPACT, 3345
 CNSELECTFGATEBYVIOL, 3346
 CNSELECTINTERBYALL, 3347
 CNSELECTINTERBYIMPACT, 3348
 CNSELECTINTERBYNAME, 3349
 CNSELECTINTERBYNUMBER, 3350
 CNSELECTINTERBYVIOL, 3351
 CNSELECTVOLTAGEBUSESBYVIOL, 3352
 CNSELECTVOLTBUSBYALL, 3353
 CNSELECTVOLTBUSBYAREAS, 3354
 CNSELECTVOLTBUSBYBUSES, 3355
 CNSELECTVOLTBUSBYZONES, 3356
 CNSELECTVOLTUSESBYDEVIATION, 3357
 CSENSUBSELBRANCHES, 3358
 CSENSUBSELFLOWGATES, 3359
 CSENSUBSELINTERFACES, 3360
 CNSTUDYSELBRANCHES, 3361
 CNSTUDYSELFLOWGATES, 3362

CNSTUDYSELINTERFACES, 3363
 CNSUBSELBRANCHES, 3364
 CNSUBSELFLOWGATES, 3365
 CNSUBSELINTERFACES, 3366
 CNSUMMARYVIOLATIONS, 3367
 CNTB, 127
 CNTRANSACTSELBRANCHES, 3368
 CNTRANSACTSELFLOWGATES, 3369
 CNTRANSACTSELINTERFACES, 3370
 CNVARSELBRANCHES, 3371
 CNVARSELINTERFACES, 3372
 CNVARSELVOLTAGEBUSES, 3373
 CNVIOLSELBRANCHES, 3374
 CNVIOLSELBRANCHES_TBL, 3375
 CNVIOLSELFLOWGATES, 3376
 CNVIOLSELFLOWGATES_TBL, 3377
 CNVIOLSELINTERFACES, 3378
 CNVIOLSELINTERFACES_TBL, 3379
 CNVIOLSELVOLTAGEBUSES, 3380
 COMPAREFCITC, 3381
 CONG, 129
 CONL, 130
 CONNECTIVITY_CHECK, 132
 CONSTRAIN_INTERFACE_FLOWS, 1026
 CONSTRDEFS, 3382
 CONTROL_AREA_INTERCHANGE, 133
 CONVERT_SECTION_TO_BUS, 949
 CRT_PLOT_CHANNEL, 1597
 CSV_TO_RAWX, 134

D

DC_TAP_ADJUSTMENT, 151
 DC2AUXMIND, 2188
 DC2AUXMNAM, 2190
 DC2DAT, 2191
 DC2DAT_2, 2193
 DC2INT, 2195
 DC2INT_2, 2196
 DC2MIND, 2197
 DC2MNAM, 2199
 DCCC, 135
 DCCC_2, 137
 DCCONTBYCONT, 3384
 DCCONTBYMONEL, 3386
 DCCOR, 139
 DCCOR_2, 141
 DCLF, 144
 DCLF_2, 146
 DCLIST, 1511
 DCLMOD_PACK, 1718
 DCLMOD_UNCONNECTED, 1719
 DCLMOD_USER, 1720
 DCNAUXMIND, 2200
 DCNAUXMNAM, 2202
 DCNCIN, 2203
 DCNCIN_2, 2204
 DCNDAT, 2205
 DCNDAT_2, 2207
 DCNINT, 2209
 DCNINT_2, 2210
 DCNMIND, 2211
 DCNMNAM, 2213
 DCPSCOPF, 148
 DCSOLVE, 3388
 DCTransferLimitStudy, 3389
 DELETE_ALL_PLOT_CHANNELS, 1598
 DELETEDIAGCONTOUR, 1994
 DELETEDSELPLT, 3243
 DELTMPFILES, 152
 DETAILSELCONTINGENCIES, 3390
 DETAILSELCONTINGENCIESSP, 3391
 DFAX, 153
 DFAX_2, 155
 DFAX_CONTINGENCY, 157
 DFTI, 158

DIFF, 161
 DIRECT, 3392
 DIST_3PHASE_BUS_FAULT, 1935
 DIST_3WIND_CLOSE, 1937
 DIST_3WIND_FAULT, 1938
 DIST_3WIND_TRIP, 1940
 DIST_BRANCH_CLOSE, 1941
 DIST_BRANCH_FAULT, 1942
 DIST_BRANCH_TRIP, 1944
 DIST_BUS_FAULT, 1945
 DIST_BUS_FAULT_2, 1946
 DIST_BUS_FAULT_3, 1948
 DIST_BUS_TRIP, 1950
 DIST_CLEAR_FAULT, 1951
 DIST_MACHINE_TRIP, 1953
 DIST_SCMU_FAULT, 1954
 DIST_SCMU_FAULT_2, 1956
 DIST_SCMU_FAULT_3, 1958
 DIST_SPCB_FAULT, 1960
 DIST_SPCB_FAULT_2, 1962
 DLST, 1512
 DMPC, 1599
 DOCU, 1513
 DRAGDROPLOTDATA, 3244
 DROPMODELLIBRARY, 1516
 DROPMODELPROGRAM, 1517
 DSCN, 165
 DSCVAL, 2214
 DSIVAL, 2215
 DSRVAL, 2216
 DUPLICATE_CNTLABEL_CHECK, 166
 DYDA, 1518
 DYNAMICS_SOLUTION_PARAM_2, 1524
 DYNAMICS_SOLUTION_PARAMS, 1522
 DYNAMICSMODE, 1521
 DYNEXPORTCSV, 1526
 DYRE_ADD, 1527
 DYRE_NEW, 1528

E

ECDI, 167
 ECHO, 169
 EEQV, 170
 ENABLEDIAGCONTOUR, 1995
 EQRD, 172
 ERUN, 1529
 ESTR_OPEN_CIRCUIT_TEST, 1530
 ESTR_RESPONSE_RATIO_TEST, 1531
 EXAM, 174
 EXCLUDESELECTEDCONTS, 3393
 EXECUTEACCONT, 3394
 EXITACTIVITYACCONT, 3395
 EXITACTIVITYMUST, 3396
 EXPORTBUSLOCFILE, 1997
 EXPORTBUSLOCFILE_2, 1998
 EXPORTIMAGEFILE, 1999
 EXPORTIMAGEFILE_2, 2000
 EXPORTPLOT, 3245
 EXTR, 687

F

FACT, 175
 FACTS_CHNG_2, 688
 FACTS_CHNG_3, 691
 FACTS_DATA, 694
 FACTS_DATA_2, 697
 FACTS_DATA_3, 700
 FCDAUXMIND, 2217
 FCDAUXMNAM, 2219
 FCDDAT, 2220
 FCDDAT_2, 2223
 FCDINT, 2226
 FCDINT_2, 2227
 FCDMIND, 2228

FCDMNAM, 2229
 FCITC2LINE, 3397
 FCITCAC, 3398
 FCITCACMULT, 3399
 FCITCACSINGLE, 3400
 FCITCBASE, 3401
 FCITCBASEMULT, 3402
 FCITCBASESINGLE, 3403
 FCITCMULT, 3404
 FCITCSINGLE, 3405
 FCITCSUBS, 3406
 FCITCTLTG, 3407
 FCITCWIDE, 3408
 FCLIST, 1533
 FCTMOD_PACK, 1736
 FCTMOD_REMOVE, 1737
 FCTMOD_STATUS, 1738
 FCTMOD_UNCONNECTED, 1739
 FCTMOD_USER, 1740
 FCTSAUXMOD_REMOVE, 1926
 FCTSAUXMOD_STATUS, 1927
 FDNS, 176
 FETCH_ADJVAR_TERM_NODE, 974
 FETCH_INDMACHINE_TERM_NODE, 975
 FETCH_LOAD_TERM_NODE, 976
 FETCH_MACHINE_TERM_NODE, 977
 FETCH_SHUNT_TERM_NODE, 978
 FETCH_SWS_SHUNT_TERM_NODE, 979
 FETCH_SWS_SHUNT_TERM_NODE_2, 980
 FILE_OVERWRITE, 178
 FILEIN, 3209
 FINAL_OPF_BARRIER_COEFF, 1027
 FIND, 179
 FLAT, 1224
 FLAT_2, 1226
 FLAT_START, 180
 FLOWGATESENSITIVITY, 3409
 FNSL, 181
 FORGETSTUDYTRANSFER, 3411
 FXSDT1, 2230
 FXSDT2, 2232
 FXSINT, 2234

G

GCAP, 183
 GCAP_2, 184
 GDIF, 185
 GENCNV, 2235
 GENDAT, 2236
 GENDETAILS, 3412
 GENDSP, 187
 GENDSP_2, 189
 GENDT1, 2237
 GENS, 191
 GENSECTDAT, 2238
 GENSECTDT1, 2239
 GENSENDETAIL, 3413
 GENSENSUMMARY, 3414
 GEOL, 192
 GET_CHAR_LENGTH, 2630
 GET_EXT_ACLINE_CHAR, 2436
 GET_EXT_ACLINE_INT, 2437
 GET_EXT_ACLINE_LOGICAL, 2438
 GET_EXT_ACLINE_REAL, 2439
 GET_EXT_AREA_CHAR, 2440
 GET_EXT_AREA_INT, 2441
 GET_EXT_AREA_LOGICAL, 2442
 GET_EXT_AREA_REAL, 2443
 GET_EXT_BUS_CHAR, 2444
 GET_EXT_BUS_INT, 2445
 GET_EXT_BUS_LOGICAL, 2446
 GET_EXT_BUS_REAL, 2447
 GET_EXT_CHAR, 2448
 GET_EXT_FACTS_CHAR, 2449
 GET_EXT_FACTS_INT, 2450

GET_EXT_FACTS_LOGICAL, 2451
 GET_EXT_FACTS_REAL, 2452
 GET_EXT_FIXSHUNT_CHAR, 2453
 GET_EXT_FIXSHUNT_INT, 2454
 GET_EXT_FIXSHUNT_LOGICAL, 2455
 GET_EXT_FIXSHUNT_REAL, 2456
 GET_EXT_GENERATOR_CHAR, 2457
 GET_EXT_GENERATOR_INT, 2458
 GET_EXT_GENERATOR_LOGICAL, 2459
 GET_EXT_GENERATOR_REAL, 2460
 GET_EXT_GNE_CHAR, 2461
 GET_EXT_GNE_INT, 2462
 GET_EXT_GNE_LOGICAL, 2463
 GET_EXT_GNE_REAL, 2464
 GET_EXT_IATRANS_CHAR, 2465
 GET_EXT_IATRANS_INT, 2466
 GET_EXT_IATRANS_LOGICAL, 2467
 GET_EXT_IATRANS_REAL, 2468
 GET_EXT_INDMACH_CHAR, 2469
 GET_EXT_INDMACH_INT, 2470
 GET_EXT_INDMACH_LOGICAL, 2471
 GET_EXT_INDMACH_REAL, 2472
 GET_EXT_INT, 2473
 GET_EXT_LOAD_CHAR, 2474
 GET_EXT_LOAD_INT, 2475
 GET_EXT_LOAD_LOGICAL, 2476
 GET_EXT_LOAD_REAL, 2477
 GET_EXT_LOGICAL, 2478
 GET_EXT_MSLINE_CHAR, 2479
 GET_EXT_MSLINE_INT, 2480
 GET_EXT_MSLINE_LOGICAL, 2481
 GET_EXT_MSLINE_REAL, 2482
 GET_EXT_NTERMDC_CHAR, 2483
 GET_EXT_NTERMDC_INT, 2484
 GET_EXT_NTERMDC_LOGICAL, 2485
 GET_EXT_NTERMDC_REAL, 2486
 GET_EXT_OWNER_CHAR, 2487
 GET_EXT_OWNER_INT, 2488
 GET_EXT_OWNER_LOGICAL, 2489
 GET_EXT_OWNER_REAL, 2490
 GET_EXT_RATING_CHAR, 2491
 GET_EXT_RATING_INT, 2492
 GET_EXT_RATING_LOGICAL, 2493
 GET_EXT_RATING_REAL, 2494
 GET_EXT_REAL, 2495
 GET_EXT_ROWCOUNT, 2496
 GET_EXT_SUB_CHAR, 2505
 GET_EXT_SUB_INT, 2506
 GET_EXT_SUB_LOGICAL, 2507
 GET_EXT_SUB_REAL, 2508
 GET_EXT_SUBNODE_CHAR, 2497
 GET_EXT_SUBNODE_INT, 2498
 GET_EXT_SUBNODE_LOGICAL, 2499
 GET_EXT_SUBNODE_REAL, 2500
 GET_EXT_SUBSWD_CHAR, 2501
 GET_EXT_SUBSWD_INT, 2502
 GET_EXT_SUBSWD_LOGICAL, 2503
 GET_EXT_SUBSWD_REAL, 2504
 GET_EXT_SWSHUNT_CHAR, 2509
 GET_EXT_SWSHUNT_INT, 2510
 GET_EXT_SWSHUNT_LOGICAL, 2511
 GET_EXT_SWSHUNT_REAL, 2512
 GET_EXT_SYSSWD_CHAR, 2513
 GET_EXT_SYSSWD_INT, 2514
 GET_EXT_SYSSWD_LOGICAL, 2515
 GET_EXT_SYSSWD_REAL, 2516
 GET_EXT_TRANSFORMER_CHAR, 2517
 GET_EXT_TRANSFORMER_INT, 2518
 GET_EXT_TRANSFORMER_LOGICAL, 2519
 GET_EXT_TRANSFORMER_REAL, 2520
 GET_EXT_TWOTERMDC_CHAR, 2521
 GET_EXT_TWOTERMDC_INT, 2522
 GET_EXT_TWOTERMDC_LOGICAL, 2523
 GET_EXT_TWOTERMDC_REAL, 2524
 GET_EXT_VSCDC_CHAR, 2525
 GET_EXT_VSCDC_INT, 2526
 GET_EXT_VSCDC_LOGICAL, 2527
 GET_EXT_VSCDC_REAL, 2528
 GET_EXT_ZONE_CHAR, 2529
 GET_EXT_ZONE_INT, 2530
 GET_EXT_ZONE_LOGICAL, 2531
 GET_EXT_ZONE_REAL, 2532
 GET_MSTATE, 2241
 GETBATDEFAULTS, 3210
 GETCONTINGENCYSAVEDCASE, 193
 GETDEFAULTCHAR, 3211
 GETDEFAULTINT, 3212
 GETDEFAULTREAL, 3213
 GETEXCLUDEDBRANCHES, 3541
 GETEXCLUDEDCONTINGENCIES, 3542
 GETEXCLUDEDFLOWGATES, 3543
 GETEXCLUDEDINTERFACES, 3544
 GETEXCLUDEDVOLTAGEBUSES, 3545
 GETFINALBALANCE, 3546
 GETFINALFLOW, 3547
 GETHOMEPath, 2240
 GETIDOFCONTINGENCYBYNAME, 3548
 GETIDOFFLOWGATEBYNAME, 3549
 GETIDOFINTERFACEBYNAME, 3550
 GETIDOFVOLTAGEBUSBYNAME, 3551
 GETINITBALANCE, 3552
 GETINITIALFLOW, 3553
 GETIPFFACTOR, 3554
 GETLOADEDMODULES, 3214
 GETMODELLIBRARIES, 3122
 GETMODELPROGRAMS, 3123
 GETMODFUNCLIST, 3215
 GETNAMEOFCONTINGENCYBYID, 3555
 GETNAMEOFFLOWGATEBYID, 3556
 GETNAMEOFINTERFACEBYID, 3557
 GETNAMEOFVOLTAGEBUSBYID, 3558
 GETNUMOFEXCLUDEDBRANCHES, 3559
 GETNUMOFEXCLUDEDCONTINGENCIES, 3560
 GETNUMOFEXCLUDEDFLOWGATES, 3561
 GETNUMOFEXCLUDEDINTERFACES, 3562
 GETNUMOFEXCLUDEDVOLTAGEBUSES, 3563
 GETTPFBALANCE, 3564
 GEXMBUS, 2001
 GIC, 1378
 GIC_2, 1381
 GIC_2TDC, 1455
 GIC_2TDC_CHNG, 1456
 GIC_2TDC_PURG, 1457
 GIC_3, 1387
 GIC_4, 1393
 GIC_5, 1400
 GIC_6, 1407
 GIC_7, 1416
 GIC_8, 1425
 GIC_BRANCH_EFIELD_NN, 1436
 GIC_BRN, 1458
 GIC_BRN_CHNG, 1460
 GIC_BRN_PURG, 1462
 GIC_EARTH1D_USR, 1463
 GIC_EARTH1D_USR_CHNG, 1464
 GIC_EARTH1D_USR_PURG, 1438
 GIC_EFIELD_WAVESHAPE, 1439
 GIC_EFIELD_WAVESHAPE_REF, 1440
 GIC_EFIELD_WAVESHAPE_SUPP, 1441
 GIC_FACTS, 1465
 GIC_FACTS_CHNG, 1466
 GIC_FACTS_PURG, 1467
 GIC_FXSH, 1468
 GIC_FXSH_CHNG, 1469
 GIC_FXSH_PURG, 1470
 GIC_LOAD, 1471
 GIC_LOAD_CHNG, 1472
 GIC_LOAD_PURG, 1473
 GIC_MTDC, 1474
 GIC_MTDC_CHNG, 1475
 GIC_MTDC_PURG, 1476
 GIC_MVARLOSS_SCALING_FACTORS, 1442

GIC_NEW, 1443
 GIC_PF, 194
 GIC_PF_OPTIONS, 1444
 GIC_PURG, 1446
 GIC_READ, 1447
 GIC_READ_EFIELD_GRID, 1448
 GIC_SUBSTN, 1477
 GIC_SUBSTN_CHNG, 1478
 GIC_SUBSTN_PURG, 1479
 GIC_SWSH, 1480
 GIC_SWSH_CHNG, 1481
 GIC_SWSH_PURG, 1482
 GIC_THERMAL_IMPACT, 1449
 GIC_THERMAL_IMPACT_1, 1450
 GIC_TRN, 1483
 GIC_TRN_CHNG, 1486
 GIC_TRN_PURG, 1489
 GIC_VSCDC, 1490
 GIC_VSCDC_CHNG, 1491
 GIC_VSCDC_PURG, 1492
 GIC_WRITE, 1451
 GIC_WRITE_STN, 1452
 GMB_ADD_FACTS_DEV_MODEL, 1741
 GMB_ADD_PLANT_MODEL, 1644
 GMB_ADD_SWSHUNT_MODEL, 1756
 GMB_ADD_SWSHUNT_MODEL_2, 1758
 GNE_CHNG, 703
 GNE_DATA, 705
 GNECHR, 2242
 GNEDAT, 2243
 GNEINT, 2244
 GNESTATUS, 196
 GNET, 197
 GROWBUS, 2002
 GROWBUSLEVELS, 2003
 GROWDIAGRAM, 2004
 GROWDIAGRAM_2, 2005
 GROWSTATION, 2007
 GRPG, 2008
 GRUN, 1534
 GSTR, 1535

H

HAR_2TDC, 1324
 HAR_2TDC_CHNG, 1325
 HAR_2TDC_PURG, 1326
 HAR_BRN, 1327
 HAR_BRN_CHNG, 1328
 HAR_BRN_PURG, 1329
 HAR_CURSRC, 1330
 HAR_CURSRC_CHNG, 1331
 HAR_CURSRC_CHNG_NAME, 1332
 HAR_CURSRC_CHNG_ONEPT, 1333
 HAR_CURSRC_NAME, 1334
 HAR_CURSRC_ONEPT, 1335
 HAR_CURSRC_PURG, 1336
 HAR_CURSRC_PURG_ONEPT, 1337
 HAR_FACTS, 1338
 HAR_FACTS_CHNG, 1339
 HAR_FACTS_PURG, 1340
 HAR_IMPCHAR, 1341
 HAR_IMPCHAR_CHNG, 1342
 HAR_IMPCHAR_CHNG_NAME, 1343
 HAR_IMPCHAR_CHNG_ONEPT, 1344
 HAR_IMPCHAR_NAME, 1345
 HAR_IMPCHAR_ONEPT, 1346
 HAR_IMPCHAR_PURG, 1347
 HAR_IMPCHAR_PURG_ONEPT, 1348
 HAR_INDMC, 1349
 HAR_INDMC_CHNG, 1350
 HAR_INDMC_PURG, 1351
 HAR_LOAD, 1352
 HAR_LOAD_CHNG, 1353
 HAR_LOAD_PURG, 1354
 HAR_MACH, 1355

HAR_MACH_CHNG, 1356
 HAR_MACH_PURG, 1357
 HAR_MTDC, 1358
 HAR_MTDC_CHNG, 1359
 HAR_MTDC_PURG, 1360
 HAR_NEW, 1316
 HAR_PURG, 1317
 HAR_READ, 1318
 HAR_READX, 1319
 HAR_TRN, 1361
 HAR_TRN_CHNG, 1362
 HAR_TRN_PURG, 1363
 HAR_VLTsrc, 1364
 HAR_VLTsrc_CHNG, 1365
 HAR_VLTsrc_CHNG_NAME, 1366
 HAR_VLTsrc_CHNG_ONEPT, 1367
 HAR_VLTsrc_NAME, 1368
 HAR_VLTsrc_ONEPT, 1369
 HAR_VLTsrc_PURG, 1370
 HAR_VLTsrc_PURG_ONEPT, 1371
 HAR_VSCDC, 1372
 HAR_VSCDC_CHNG, 1373
 HAR_VSCDC_PURG, 1374
 HAR_WRITE, 1320
 HAR_WRITEX, 1321
 HARMONICS, 1314
 HDAIMPORTDATA, 3115

I
 IECS, 1229
 IECS_2, 1231
 IECS_3, 1234
 IECS_4, 1237
 IECS_SCF, 1241
 ILFDEFAULTS, 3415
 IMMOD_PACK, 1774
 IMMOD_REMOVE, 1775
 IMMOD_STATUS, 1776
 IMMOD_UNCONNECTED, 1777
 IMMOD_USER, 1778
 IMNET, 198
 IMOUTAGE, 199
 IMPACTINTRFACEPARTFACT, 3417
 IMPACTSETBASECASE, 3419
 IMPACTSETCONTINGENCY, 3420
 IMPACTTIESPARTFACT, 3421
 IMPACTTOTALPARTFACT, 3423
 IMPC, 200
 IMPEDANCE_CORRECTION_DATA, 707
 IMPEDANCE_CORRECTION_DATA_3, 708
 IMPLEMENT_TRANSFER, 201
 IMPLEMENT_TRANSFER_2, 204
 IMPORT_ECDI, 1028
 IMPORTDRAWFILE, 2009
 IMPORTIMAGEFILE, 2010
 INCLUDESELECTEDCONTS, 3424
 INCREMENT_GREF, 1536
 INCREMENT_SWSREF, 1537
 INCREMENT_SWSREF_2, 1538
 INCREMENT_VREF, 1539
 INDDT1, 2246
 INDDT2, 2248
 INDINT, 2250
 INDUCTION_MACHINE_CHNG, 709
 INDUCTION_MACHINE_DATA, 712
 INI2DC, 2252
 INIBRN, 2253
 INIBRN_2, 2254
 INIBRX, 2255
 INIBRX_2, 2256
 INIBUS, 2257
 INIBUS_2, 2258
 INIBUX, 2259
 INIFAX, 2260
 INIFXS, 2261

INIIND, 2262
 INILOD, 2263
 INIMAC, 2264
 INIMDC, 2265
 INIMSL, 2266
 ININAM, 2267
 ININAM_2, 2268
 ININAX, 2269
 INISTABUSSECT, 2270
 INISTANODE, 2271
 INISTASWDEV, 2272
 INISWS, 2273
 INITIAL_OPF_BARRIER_COEFF, 1029
 INITIE, 2274
 INITIX, 2275
 INIVSC, 2276
 INLF, 207
 INLF_2, 209
 INSERTPAGE, 3246
 INSERTPLOT, 3247
 INTA, 211
 INTERFACE_FLOW_COST_COEFF, 1030
 INTERFACESENSITIVITY, 3425
 INTZ, 212
 IOFLUSH, 3216
 ISLAND, 2277
 ISOLATE_LEVELS, 213
 ISOLATE2DCLINEBYBREAKER, 950
 ISOLATE3WTBYBREAKER, 951
 ISOLATEBUSBYBREAKER, 952
 ISOLATEFACTSBYBREAKER, 953
 ISOLATEINDMACHINEBYBREAKER, 954
 ISOLATELINEBYBREAKER, 955
 ISOLATELOADBYBREAKER, 956
 ISOLATEMACHINEBYBREAKER, 957
 ISOLATEMSLINEBYBREAKER, 958
 ISOLATEMTDCLINEBYBREAKER, 959
 ISOLATENODEBYBREAKER, 960
 ISOLATESHUNTBYBREAKER, 961
 ISOLATESWDBYBREAKER, 962
 ISOLATESWSHUNTBYBREAKER, 963
 ISOLATESWSHUNTBYBREAKER_2, 964
 ISOLATEVSCDCLINEBYBREAKER, 965
 ITERAT, 2278

J

JOIN, 214

L

LAMP, 215
 LAST_PF, 3124
 LAUNCH_PROGRAM, 3217
 LDLIST, 1540
 LDMOD_PACK, 1674
 LDMOD_REMOVE, 1675
 LDMOD_STATUS, 1676
 LDMOD_STATUS2, 1677
 LDMOD_UNCONNECTED, 1678
 LDMOD_USER, 1679
 LINE_SHUNT_REPORTING, 218
 LINES_PER_PAGE, 216
 LINES_PER_PAGE_ONE_DEVICE, 217
 LIST, 219
 LIST_BFLOW, 3437
 LIST_BIMPACT, 3438
 LIST_CFLOW, 3439
 LIST_CHANNEL_MODELS, 1601
 LIST_CIMPACT, 3440
 LIST_CONTINS, 3441
 LIST_CONTINS_WISL, 3442
 LIST_LODF, 3443
 LIST_LODF_WISL, 3444
 LIST_MONELS, 3445
 LIST_PTDF, 3446

LIST_PTDFC, 3447
 LIST_SYSTEMS, 3448
 LISTACCONTDETAILS, 3427
 LISTACCONTSUMMARY, 3428
 LISTAREAS, 3429
 LISTBUSES, 3430
 LISTCONTINGENCYSAVEDCASES, 221
 LISTEXCLUDES, 3431
 LISTGENERATORS, 3432
 LISTPHASESHIFTERS, 3433
 LISTSELCONTINGENCIES, 3434
 LISTSELCONTINGENCIES_TBL, 3435
 LISTZONES, 3436
 LLRF, 222
 LMODIND, 2279
 LMODNAM, 2281
 LOAD_ARRAY_CHANNEL, 1541
 LOAD_CHNG_4, 715
 LOAD_CHNG_5, 717
 LOAD_CHNG_6, 719
 LOAD_DATA, 721
 LOAD_DATA_3, 723
 LOAD_DATA_4, 725
 LOAD_DATA_5, 727
 LOAD_DATA_6, 729
 LOAD_REDUCTION, 224
 LODCNV, 2282
 LODDT1, 2283
 LODDT2, 2285
 LODIND, 2287
 LODINT, 2288
 LODTYPE, 2289
 LONG_TITLE_DATA, 731
 LOUT, 225
 LSTO, 1031
 LTAP, 226

M

MACCC, 227
 MACCC_2, 232
 MACCC_3, 237
 MACCC_PARALLEL, 242
 MACCC_PARALLEL_2, 247
 MACCC_TRIP_COR, 252
 MACCC_TRIP_COR_2, 258
 MACCC_TRIP_COR_3, 264
 MACCC_TRIP_COR_4, 271
 MACCC_WITH_COR, 277
 MACCC_WITH_COR_2, 282
 MACCC_WITH_COR_3, 288
 MACCC_WITH_COR_4, 294
 MACCC_WITH_TRIP, 300
 MACCC_WITH_TRIP_2, 305
 MACCC_WITH_TRIP_3, 310
 MACCC_WITH_TRIP_PARALLEL, 315
 MACCC_WITH_TRIP_PARALLEL_2, 320
 MACCHR, 2290
 MACDAT, 2291
 MACDT2, 2293
 MACHINE_APP_R_X_CHANNEL, 1604
 MACHINE_ARRAY_CHANNEL, 1606
 MACHINE_CAP_CURVE_CHNG, 732
 MACHINE_CAP_CURVE_DATA, 734
 MACHINE_CHNG_2, 736
 MACHINE_CHNG_3, 738
 MACHINE_CHNG_4, 740
 MACHINE_DATA, 742
 MACHINE_DATA_2, 744
 MACHINE_DATA_3, 746
 MACHINE_DATA_4, 749
 MACHINE_ITERM_CHANNEL, 1608
 MACIND, 2295
 MACINT, 2296
 MACSTT, 2298
 MATRIX_GROWTH_FACTOR, 325

MAXMSM, 2299
 MBID2DC, 752
 MBID3WND, 753
 MBIDATRN, 754
 MBIDBRN, 755
 MBIDFACTS, 756
 MBIDGNE, 757
 MBIDINDMAC, 758
 MBIDLOAD, 759
 MBIDMAC, 760
 MBIDMDC, 761
 MBIDMSL, 762
 MBIDNCS, 1269
 MBIDSHUNT, 763
 MBIDSWSHUNT, 764
 MBIDVD, 765
 MBIDVSC, 766
 MCRE, 326
 MDETAILBRANCHES, 3449
 MDETAILINTERFACES, 3450
 MDETAILVOLTAGEBUSES, 3451
 MDLIND, 2300
 MDLLIBCNT, 2302
 MDLNAM, 2303
 MDLPGMCNT, 2304
 MINIMIZE_ADJ_BUS_SHUNTS, 1033
 MINIMIZE_FUEL_COST, 1034
 MINIMIZE_INTERFACE_FLOWS, 1035
 MINIMIZE_LOAD_ADJUSTMENTS, 1036
 MINIMIZE_P_LOSSES, 1037
 MINIMIZE_P_SLACK, 1038
 MINIMIZE_Q_LOSSES, 1039
 MINIMIZE_Q_SLACK, 1040
 MINIMIZE_REACTIVE_RESERVE, 1041
 MINIMIZE_SERIES_COMP, 1042
 MLST, 1542
 MODIFYDISPATCH, 3452
 MODR, 327
 MONELIMPACT, 3453
 MONSENSALLSUBBRANCHES, 3455
 MONSENSALLSUBFLOWGATES, 3456
 MONSENSALLSUBINTERFACES, 3457
 MONSENSALLTRANBRANCHES, 3458
 MONSENSALLTRANFLOWGATES, 3459
 MONSENSALLTRANINTERFACES, 3460
 MONSENSSINGLESUBBRANCHES, 3461
 MONSENSSINGLESUBFLOWGATES, 3462
 MONSENSSINGLESUBINTERFACES, 3463
 MONSENSSUBSPARTBRANCHES, 3464
 MONSENSSUBSPARTFLOWGATES, 3465
 MONSENSSUBSPARTINTERFACES, 3466
 MONSENSTRANBRANCHES, 3467
 MONSENSTRANFLOWGATES, 3468
 MONSENSTRANINTERFACES, 3469
 MOV_ALPHA, 342
 MOV_ITERATIONS, 343
 MOV_TOLERANCE, 344
 MOVE3WND, 329
 MOVEBRN, 330
 MOVEINDMAC, 331
 MOVEINDMACS, 332
 MOVELOAD, 333
 MOVELOADS, 334
 MOVEMAC, 335
 MOVEPLNT, 336
 MOVESHUNT, 337
 MOVESHUNTS, 338
 MOVESWS, 339
 MOVESWSHUNT, 340
 MOVESWSHUNTS, 341
 MRUN, 1544
 MSLV, 345
 MSTR, 1545
 MSUM, 347
 MTDC, 348
 MTDCAUXMOD_REMOVE, 1928

MTDCAUXMOD_STATUS, 1929
 MTDCLMOD_REMOVE, 1721
 MTDCLMOD_STATUS, 1722
 MULTACFCITC, 3470
 MULTDCFCITC, 3472
 MULTI_SECTION_LINE_DATA, 767
 MULTI_SECTION_LINE_EDIT, 769
 MULTI_TERM_DC_BUS_DATA, 770
 MULTI_TERM_DC_CONV_DATA, 772
 MULTI_TERM_DC_LINE_CHNG, 775
 MULTI_TERM_DC_LINE_DATA, 777
 MULTI_TERM_DC_LINK_DATA, 779
 MULTICHANNEXCELEXPORT, 3248
 MULTIPLEPARALLELTRANSFERS, 3473
 MULTIPLESTUDYTRANSFERS, 3475
 MULTISECTION_REPORTING, 349
 MUSTOPTDEFS, 3477
 MUSTSTART, 3479
 MUSTSTOP, 3480
 MWMI, 350
 MWOMWMSF, 352
 MWOMWOSF, 353

N

N11_ACCC, 354
 N11_ACCC_2, 358
 N11_ACCC_3, 362
 N11_ACCC_PARALLEL, 366
 N11_ACCC_PARALLEL_2, 370
 N11_ACCC_PSCOPF, 374
 N11_ACCC_PSCOPF_2, 381
 N11_ACCC_PSCOPF_3, 388
 NATONO, 2305
 NETG, 394
 NEW_DIMENSION, 398
 NEWCAS, 395
 NEWCASE_2, 396
 NEWDIAGFILE, 2011
 NEWOPF, 1084
 NEWPLOTBOOK, 3249
 NEWSENARIOFILE, 3057
 NEWSEQ, 1242
 NEWTON_TOLERANCE, 397
 NEXTDIAGFILEDATASET, 2012
 NON_DIVERGENT, 399
 NON_TRANS_PERCENT_UNITS, 400
 NOPF, 1043
 NOTONA, 2306
 NOTONASECT, 2307
 NSOL, 401
 NUMBER_THREADS, 403
 NXT2DC, 2308
 NXTBRN, 2309
 NXTBRN_2, 2312
 NXTBRN3, 2310
 NXTBRN3_2, 2311
 NXTBUS, 2313
 NXTBUS_2, 2314
 NXTFAX, 2315
 NXTFXS, 2316
 NXTIND, 2317
 NXTLOD, 2318
 NXTMAC, 2319
 NXTMDC, 2320
 NXTMSL, 2321
 NXTSTABUSSECT, 2322
 NXTSTANODE, 2323
 NXTSTASWDEV, 2324
 NXTSWS, 2325
 NXTTIE, 2326
 NXTTIE3, 2327
 NXTVSC, 2328

O

OKSTRT, 2329
OPEN_BUS_VOLTAGE_LIMITS, 1044
OPENACCFILE, 2013
OPENACCFILE_2, 2014
OPENBUSLOCFILE, 2015
OPENCHANDATAFILE, 3250
OPENDIAGFILE, 2016
OPENEVENTSTUDYFILE, 3109
OPENSENARIOFILE, 3058
OPENUN, 2330
OPF_ADJBRX_INDV, 1085
OPF_ADJBRX_SUBSYS, 1087
OPF_ADJLOAD_TBL, 1090
OPF_ADJVAR_INDV, 1092
OPF_ADJVAR_INDV_2, 1094
OPF_ADJVAR_SUBSYS, 1096
OPF_APDSP_TBL, 1099
OPF_BARRIER_STEP_LENGTH, 1045
OPF_BRFLW_3WT_INDV, 1101
OPF_BRFLW_BRN_INDV, 1103
OPF_BRFLW_SUBSYS, 1105
OPF_BUS_INDV, 1108
OPF_BUS_INDV_2, 1110
OPF_BUS_SUBSYS, 1112
OPF_CHANGE_3WT_FLOW_ID, 1115
OPF_CHANGE_ADJVAR_ID, 1116
OPF_CHANGE_BRN_FLOW_ID, 1117
OPF_CLAMP_DECAY_FACTOR, 1046
OPF_CSTTBL_LIN, 1118
OPF_CSTTBL_POLY, 1119
OPF_CSTTBL_QUAD, 1120
OPF_FINAL_CLAMP_TOL, 1047
OPF_FIX_ALL_GENERATORS, 1049
OPF_FIX_PHASE_SHIFTERS, 1050
OPF_FIX_SWITCHED_SHUNTS, 1051
OPF_FIX_TAP_RATIOS, 1052
OPF_FIXED_VOLTAGE_PENALTY, 1048
OPF_GEN_RCAP_INDV, 1126
OPF_GEN_RCAP_SUBSYS, 1128
OPF_GENDSP_INDV, 1121
OPF_GENDSP_SUBSYS, 1122
OPF_GENRSV_INDV, 1123
OPF_GENRSV_SUBSYS, 1124
OPF_INITIAL_CLAMP_TOL, 1053
OPF_INTERIOR_SHIFT_FACTOR, 1054
OPF_INTFLW_3WT, 1131
OPF_INTFLW_BRN, 1132
OPF_INTFLW_MAIN, 1133
OPF_INTFLW_RESET, 1135
OPF_LAMBDA_TOLERANCE, 1055
OPF_LF_CONTROL_PENALTY, 1056
OPF_LNCEQN_ADJLOAD, 1136
OPF_LNCEQN_ADJVAR, 1137
OPF_LNCEQN_BRFLOW, 1138
OPF_LNCEQN_INTFLOW, 1139
OPF_LNCEQN_MAIN, 1140
OPF_LNCEQN_PGEN, 1141
OPF_LNCEQN_QGEN, 1142
OPF_LNCEQN_RESET, 1143
OPF_LNCEQN_SWSHUNT, 1144
OPF_LNCEQN_SWSHUNT_2, 1145
OPF_LNCEQN_TRAN, 1146
OPF_LNCEQN_VANG, 1147
OPF_LNCEQN_VANG_2, 1148
OPF_LNCEQN_VMAG, 1149
OPF_LNCEQN_VMAG_2, 1150
OPF_LOAD_INDV, 1151
OPF_LOAD_SUBSYS, 1152
OPF_MAX_TAP_RATIO_STEP, 1057
OPF_MIN_TAP_RATIO_STEP, 1058
OPF_PERRSV_GEN, 1153
OPF_PERRSV_MAIN, 1154
OPF_PERRSV_RESET, 1155
OPF_REGULATE_AREA_INT, 1059

OPF_ROUND_SWITCHED_SHUNTS, 1060
OPF_ROUND_TAP_RATIOS, 1061
OPF_SCALE_QGEN_LIMITS, 1062
OPF_STEP_LENGTH_TOLERANCE, 1063
OPF_USE_GENERATOR_VSCHED, 1064
OPTO, 1065
ORDBUS, 2331
ORDBUSSECT, 2332
ORDR, 404
OSYS, 1981
OSYSDEF, 1982
OSYSINIT, 1983
OTDF, 405
OUTPUT_Y_MATRIX, 406
OUTS, 407
OWNDAT, 2333
OWNER_DATA, 781
OWNNM, 408
OWNNM_2, 410
OWNNM_3, 412
OWNNNAM, 2335
OWNNUM, 2336
OWNR, 414
OWNUSE, 2337

P

P_LOSSES_COST_COEFF, 1072
PAGEREPORT, 3218
PARALLELDATAILTRANSFER, 3481
PARALLELFCITCSUMMARY, 3482
PATH, 415
PBUS_ADD_MOD, 782
PBUS_DELETE, 783
PHASE_SHIFT_ADJUSTMENT, 416
PLANT_BUS_SECTION_CHNG, 981
PLANT_CHNG, 784
PLANT_CHNG_3, 785
PLANT_CHNG_4, 786
PLANT_DATA, 788
PLANT_DATA_3, 789
PLANT_DATA_4, 790
PLMOD_CONSISTENCY, 1646
PLMOD_PACK, 1647
PLMOD_REMOVE, 1648
PLMOD_STATUS, 1649
PLMOD_UNCONNECTED, 1650
PLMOD_USER, 1651
PLOTPAGEPRINTSETUP, 3251
POLY, 417
POLY_PRINT, 3046
POUT, 420
POWER_OUTPUT, 421
POWERFLOWMODE, 1546
PP_ACCC, 422
PP_ACCC_MULTI_CASE, 424
PREVDIAGFILEDATASET, 2017
PRINT_OUTAGED_BRANCHES, 427
PRINT_WINDING_BUSES, 428
PRINTACTIVEPAGE, 3252
PRINTDIAGFILE, 2018
PRINTDIAGFILE_2, 2019
PRINTRPT, 3483
PRINTSELPLT, 3253
PRMDAT, 2338
PRMINT, 2340
PRODUCE_OPF_LOG_FILE, 1071
PROGRESS, 3219
PROGRESS_OUTPUT, 429
PROMPT, 3220
PROMPT_OUTPUT, 430
PRTI, 431
PSAS, 1547
PSCASE, 3484
PSCOPF, 432
PSCOPF_2, 438

PSEB, 444
 PSSEHALT, 445
 PSSEHALT_2, 446
 PSSEINIT, 3221
 PSSEVERSION, 3222
 PURG, 792
 PURG_VOLTAGE_DROOP, 822
 PURG2DC, 794
 PURG3WND, 795
 PURGAREA, 796
 PURGATRN, 797
 PURGBRN, 798
 PURGCAPCURVE, 799
 PURGE_ALL_OPF_DATA, 1156
 PURGE_MULTI_TERM_DC_BUS, 800
 PURGE_MULTI_TERM_DC_CONVR, 801
 PURGE_MULTI_TERM_DC_LINK, 803
 PURGE_OPF_ADJBRX_INDV, 1157
 PURGE_OPF_ADJBRX_SUBSYS, 1158
 PURGE_OPF_ADJLOAD_TBL, 1159
 PURGE_OPF_ADJVAR_INDV, 1160
 PURGE_OPF_ADJVAR_INDV_3, 1161
 PURGE_OPF_ADJVAR_SUBSYS, 1162
 PURGE_OPF_APDSP_TBL, 1163
 PURGE_OPF_BRFLW_3WT, 1164
 PURGE_OPF_BRFLW_BRN, 1165
 PURGE_OPF_BRFLW_SUBSYS, 1166
 PURGE_OPF_BUS_INDV, 1167
 PURGE_OPF_BUS_INDV_3, 1168
 PURGE_OPF_BUS_SUBSYS, 1169
 PURGE_OPF_CSTTBL_LIN, 1170
 PURGE_OPF_CSTTBL_POLY, 1171
 PURGE_OPF_CSTTBL_QUAD, 1172
 PURGE_OPF_GEN_RCAP_INDV, 1177
 PURGE_OPF_GEN_RCAP_SUBSYS, 1178
 PURGE_OPF_GENDSP_INDV, 1173
 PURGE_OPF_GENDSP_SUBSYS, 1174
 PURGE_OPF_GENRSV_INDV, 1175
 PURGE_OPF_GENRSV_SUBSYS, 1176
 PURGE_OPF_INTFLW, 1179
 PURGE_OPF_INTFLW_3WT, 1180
 PURGE_OPF_INTFLW_BRN, 1181
 PURGE_OPF_LNCEQN, 1182
 PURGE_OPF_LNCEQN_ADJLOAD, 1183
 PURGE_OPF_LNCEQN_ADJVAR, 1184
 PURGE_OPF_LNCEQN_BRFLOW, 1185
 PURGE_OPF_LNCEQN_INTFLOW, 1186
 PURGE_OPF_LNCEQN_PGEN, 1187
 PURGE_OPF_LNCEQN_QGEN, 1188
 PURGE_OPF_LNCEQN_SWSHUNT, 1189
 PURGE_OPF_LNCEQN_SWSHUNT_2, 1190
 PURGE_OPF_LNCEQN_TRAN, 1191
 PURGE_OPF_LNCEQN_VANG, 1192
 PURGE_OPF_LNCEQN_VANG_2, 1193
 PURGE_OPF_LNCEQN_VMAG, 1194
 PURGE_OPF_LNCEQN_VMAG_2, 1195
 PURGE_OPF_LOAD_INDV, 1196
 PURGE_OPF_LOAD_SUBSYS, 1197
 PURGE_OPF_PERRSV, 1198
 PURGE_OPF_PERRSV_GEN, 1199
 PURGFACTS, 804
 PURGGNE, 805
 PURGINDMAC, 806
 PURGINDMACS, 807
 PURGLOAD, 808
 PURGLOADS, 809
 PURGMAC, 810
 PURGMDC, 811
 PURGMSL, 812
 PURGMUT, 813
 PURGOWNER, 814
 PURGPLNT, 815
 PURGSHUNT, 816
 PURGSHUNTS, 817
 PURGWS, 818
 PURGWSHUNT, 819

PURGVSC, 820
 PURGZONE, 821
 PV_ENGINE, 447
 PV_ENGINE_1A, 452
 PV_ENGINE_2, 457
 PV_ENGINE_3, 463
 PV_ENGINE_4, 469
 PV_ENGINE_5, 475
 PV_ENGINE_6, 481
 PV_PRINT, 3047

Q

Q_LOSSES_COST_COEFF, 1073
 QV_ENGINE, 487
 QV_ENGINE_2, 490
 QV_ENGINE_3, 493
 QV_ENGINE_4, 496
 QV_PRINT, 3049

R

RANK, 500
 RANK_BRN_AND_MAC, 502
 RATCHR, 2341
 RATE, 504
 RATE_2, 506
 RATING_SET, 508
 RATINGSETTEXTDATA, 823
 RAWD, 509
 RAWD_2, 513
 RAWDX, 511
 RAWX_TO_CSV, 515
 RDCH, 516
 RDCHRAWVERSION, 517
 RDEQ, 518
 RDEXCHGFILE, 3485
 RDMONCONFILE, 3486
 RDMUSTFILES, 3487
 RDSUBFILE, 3489
 REACTIVE_RESV_COST_COEFF, 1074
 READ, 520
 READ_RAS, 3200
 READACCONTFI, 3490
 READCAPCURVES, 521
 READDRAWDATA, 3491
 READDRAWVERSION, 522
 READSUB, 523
 READSUBRAWVERSION, 525
 READVDFROMRAWX, 527
 READX, 528
 REAREABUS, 3492
 RECN, 529
 REFRESHDIAGCONTOUR, 2020
 REFRESHDIAGFILE, 2021
 REFRESHGUI, 3223
 REGB, 530
 RELIND, 531
 RELIND_2, 534
 REMM, 537
 REMOVE_UNUSED_CHAN_MODELS, 1602
 REMOVEEXCLUDES, 3493
 RENUMDIAGFILE, 2022
 REPORT, 3224
 REPORT_OUTPUT, 538
 RESQ, 539
 RESQVERSION, 540
 RESTORESTATESFROMISOLATE, 966
 RESULT_TABLE_OUTPUT, 541
 RETI, 542
 RETRY_PSSUSERPF, 543
 REV29_NAMES, 544
 REZONEBUS, 3494
 RLLIST, 1548
 RLMOD_PACK, 1689
 RLMOD_REMOVE, 1690

RLMOD_STATUS, 1691
 RLMOD_UNCONNECTED, 1692
 RLMOD_USER, 1693
 RMODIND, 2342
 RMODNAM, 2344
 RNFI, 545
 ROPF, 1075
 RSOL, 547
 RSTR, 1549
 RUN, 1550
 RUNDYNAMICEVENTSTUDY, 3110
 RUNIPLANFILE, 3225
 RUNLASTSOLUTION, 549
 RUNPOWERFLOWEVENTSTUDY, 3111
 RUNRSPNSFILE, 3226
 RWCM, 550
 RWDY, 1551
 RWMA, 551
 RWMM, 553
 RWOP, 1076
 RWSQ, 554
 RWSQ_2, 556
 RXPATH, 3125

S

SAVE, 558
 SAVEACCONTFILE, 3495
 SAVEDIAGFILE, 2023
 SAVEEVENTSTUDYFILE, 3112
 SAVEFLOWGATES, 3496
 SAVESCENARIOFILE, 3059
 SAVESELECTEDCONTS, 3497
 SAVESUBSYSTEMS, 3498
 SAVEXCHGFILE, 3499
 SBSGTBKV, 2345
 SC3WND, 2346
 SCAL, 559
 SCAL_2, 562
 SCAL_3, 565
 SCAL_4, 568
 SCBRN2, 2348
 SCBUS2, 2349
 SCDONE, 2351
 SCEDANALYSIS, 3500
 SCENARIOCLOSE, 3060
 SCENARIOCOPYFILE, 3061
 SCENARIOFILEADD, 3062
 SCENARIOFILECOUNT, 3063
 SCENARIOFILEGETATTRS, 3064
 SCENARIOFILEGETCOMMENTS, 3065
 SCENARIOFILELENGTHCOMMENTS, 3066
 SCENARIOFILELIST, 3067
 SCENARIOFILEREMOVE, 3068
 SCENARIOFILERENAME, 3069
 SCENARIOFILESETATTRS, 3070
 SCENARIOFILESETCOMMENTS, 3071
 SCENARIOGETATTRS, 3072
 SCENARIOGETCOMMENTS, 3073
 SCENARIOGETOPT, 3074
 SCENARIOGROUPADD, 3076
 SCENARIOGROUPCOUNT, 3077
 SCENARIOGROUPGETCOMMENTS, 3078
 SCENARIOGROUPLENGTHCOMMENTS, 3079
 SCENARIOGROUPLIST, 3080
 SCENARIOGROUPOPEN, 3081
 SCENARIOGROUPREMOVE, 3082
 SCENARIOGROUPRENAME, 3083
 SCENARIOGROUPSETCOMMENTS, 3084
 SCENARIOISDIRTY, 3085
 SCENARIOISVALID, 3086
 SCENARIOLENGTHCOMMENTS, 3087
 SCENARIOMODELGROUP, 3088
 SCENARIOMOVEFILE, 3089
 SCENARIONEW, 3090
 SCENARIOOPEN, 3091
 SCENARIOSAVE, 3092
 SCENARIOSETATTRS, 3093
 SCENARIOSETCOMMENTS, 3094
 SCENARIOSETOPT, 3095
 SCENARIOTRACKFILEADD, 3097
 SCENARIOTRACKFILELIST, 3098
 SCENARIOTRACKFILENUM, 3099
 SCENARIOUNZIP, 3100
 SCENARIOUNZIPPROBLEMS, 3101
 SCENARIOUNZIP SOLUTIONS, 3102
 SCENARIOZIP, 3103
 SCENARIOZIPACTIVE, 3104
 SCENARIOZIPOPEN, 3105
 SCENARIOZIPSAVE, 3106
 SCEQ, 1243
 SCGR, 1245
 SCINIT, 2352
 SCMAC2, 2353
 SCMU, 1247
 SCMU_2, 1254
 SCOP, 1261
 SELCTR, 2354
 SELECTACTIVECONTS, 3502
 SELECTALLCONTS, 3503
 SELECTCOMPLEXCONTS, 3504
 SELECTCONVERGECONTS, 3505
 SELECTDISABLEDCONTS, 3506
 SELECTEXCLUDEDCONTS, 3507
 SELECTGENCONTS, 3508
 SELECTHISEVCONTS, 3509
 SELECTIMBALANCECONTS, 3510
 SELECTISLANDCONTS, 3511
 SELECTLOADCONTS, 3512
 SELECTLOSEVCONTS, 3513
 SELECTNOTCONVERGECONTS, 3514
 SELECTNOVIOLCONTS, 3515
 SELECTSINGLEBRANCHCONTS, 3516
 SELECTSPECIFICCONTS, 3517
 SELECTVIOLCONTS, 3518
 SENSITIVITY_FLOW, 571
 SENSITIVITY_FLOWS, 575
 SENSITIVITY_INTERFACE, 578
 SENSITIVITY_VOLTAGE, 581
 SENSITIVITY_VOLTAGES, 584
 SEQ_3_WIND_GROUNDING_DATA, 1270
 SEQ_3_WIND_WINDING_DATA, 1271
 SEQ_BRANCH_DATA, 1272
 SEQ_BRANCH_DATA_3, 1274
 SEQ_BUS_DATA, 1276
 SEQ_FIXED_SHUNT_DATA, 1277
 SEQ_INDUCTION_MACH_DATA, 1278
 SEQ_INDUCTION_MACH_DATA_2, 1280
 SEQ_LOAD_DATA, 1282
 SEQ_MACHINE_DATA, 1284
 SEQ_MACHINE_DATA_3, 1286
 SEQ_MACHINE_DATA_4, 1288
 SEQ_MACHINE_NCS_DATA, 1290
 SEQ_MACHINE_NCS_DATA_PURG, 1292
 SEQ_MUTUAL_DATA, 1293
 SEQ_NCS_FLT_CNTRB_CHNG, 1295
 SEQ_NCS_FLT_CNTRB_DATA, 1296
 SEQ_NCS_FLT_CNTRB_PURG, 1297
 SEQ_NCS_TABLE_DATA, 1298
 SEQ_NCS_TABLE_PURG, 1299
 SEQ_SWITCHED_SHUNT_DATA, 1300
 SEQ_SWITCHED_SHUNT_DATA_3, 1302
 SEQ_THREE_WINDING_DATA, 1304
 SEQ_THREE_WINDING_DATA_3, 1306
 SEQ_TWO_WINDING_DATA, 1308
 SEQ_TWO_WINDING_DATA_3, 1310
 SEQD, 1263
 SEQD_2, 1264
 SEQUENCE_NETWORK_SETUP, 1265
 SET_CHNFIL_TYPE, 1552
 SET_DISABLE_RUN, 1553
 SET_EXT_ACLINE_CHAR, 2533

SET_EXT_ACLINE_INT, 2534
 SET_EXT_ACLINE_LOGICAL, 2535
 SET_EXT_ACLINE_REAL, 2536
 SET_EXT_AREA_CHAR, 2537
 SET_EXT_AREA_INT, 2538
 SET_EXT_AREA_LOGICAL, 2539
 SET_EXT_AREA_REAL, 2540
 SET_EXT_BUS_CHAR, 2541
 SET_EXT_BUS_INT, 2542
 SET_EXT_BUS_LOGICAL, 2543
 SET_EXT_BUS_REAL, 2544
 SET_EXT_CHAR, 2545
 SET_EXT_FACTS_CHAR, 2546
 SET_EXT_FACTS_INT, 2547
 SET_EXT_FACTS_LOGICAL, 2548
 SET_EXT_FACTS_REAL, 2549
 SET_EXT_FIXSHUNT_CHAR, 2550
 SET_EXT_FIXSHUNT_INT, 2551
 SET_EXT_FIXSHUNT_LOGICAL, 2552
 SET_EXT_FIXSHUNT_REAL, 2553
 SET_EXT_GENERATOR_CHAR, 2554
 SET_EXT_GENERATOR_INT, 2555
 SET_EXT_GENERATOR_LOGICAL, 2556
 SET_EXT_GENERATOR_REAL, 2557
 SET_EXT_GNE_CHAR, 2558
 SET_EXT_GNE_INT, 2559
 SET_EXT_GNE_LOGICAL, 2560
 SET_EXT_GNE_REAL, 2561
 SET_EXT_IATRANS_CHAR, 2562
 SET_EXT_IATRANS_INT, 2563
 SET_EXT_IATRANS_LOGICAL, 2564
 SET_EXT_IATRANS_REAL, 2565
 SET_EXT_INDMACH_CHAR, 2566
 SET_EXT_INDMACH_INT, 2567
 SET_EXT_INDMACH_LOGICAL, 2568
 SET_EXT_INDMACH_REAL, 2569
 SET_EXT_INT, 2570
 SET_EXT_LOAD_CHAR, 2571
 SET_EXT_LOAD_INT, 2572
 SET_EXT_LOAD_LOGICAL, 2573
 SET_EXT_LOAD_REAL, 2574
 SET_EXT_LOGICAL, 2575
 SET_EXT_MSLINE_CHAR, 2576
 SET_EXT_MSLINE_INT, 2577
 SET_EXT_MSLINE_LOGICAL, 2578
 SET_EXT_MSLINE_REAL, 2579
 SET_EXT_NTERMDC_CHAR, 2580
 SET_EXT_NTERMDC_INT, 2581
 SET_EXT_NTERMDC_LOGICAL, 2582
 SET_EXT_NTERMDC_REAL, 2583
 SET_EXT_OWNER_CHAR, 2584
 SET_EXT_OWNER_INT, 2585
 SET_EXT_OWNER_LOGICAL, 2586
 SET_EXT_OWNER_REAL, 2587
 SET_EXT_RATING_CHAR, 2588
 SET_EXT_RATING_INT, 2589
 SET_EXT_RATING_LOGICAL, 2590
 SET_EXT_RATING_REAL, 2591
 SET_EXT_REAL, 2592
 SET_EXT_SUB_CHAR, 2601
 SET_EXT_SUB_INT, 2602
 SET_EXT_SUB_LOGICAL, 2603
 SET_EXT_SUB_REAL, 2604
 SET_EXT_SUBNODE_CHAR, 2593
 SET_EXT_SUBNODE_INT, 2594
 SET_EXT_SUBNODE_LOGICAL, 2595
 SET_EXT_SUBNODE_REAL, 2596
 SET_EXT_SUBSWD_CHAR, 2597
 SET_EXT_SUBSWD_INT, 2598
 SET_EXT_SUBSWD_LOGICAL, 2599
 SET_EXT_SUBSWD_REAL, 2600
 SET_EXT_SWSHUNT_CHAR, 2605
 SET_EXT_SWSHUNT_INT, 2606
 SET_EXT_SWSHUNT_LOGICAL, 2607
 SET_EXT_SWSHUNT_REAL, 2608
 SET_EXT_SYSSWD_CHAR, 2609
 SET_EXT_SYSSWD_INT, 2610
 SET_EXT_SYSSWD_LOGICAL, 2611
 SET_EXT_SYSSWD_REAL, 2612
 SET_EXT_TRANSFORMER_CHAR, 2613
 SET_EXT_TRANSFORMER_INT, 2614
 SET_EXT_TRANSFORMER_LOGICAL, 2615
 SET_EXT_TRANSFORMER_REAL, 2616
 SET_EXT_TWOTERMDC_CHAR, 2617
 SET_EXT_TWOTERMDC_INT, 2618
 SET_EXT_TWOTERMDC_LOGICAL, 2619
 SET_EXT_TWOTERMDC_REAL, 2620
 SET_EXT_VSCDC_CHAR, 2621
 SET_EXT_VSCDC_INT, 2622
 SET_EXT_VSCDC_LOGICAL, 2623
 SET_EXT_VSCDC_REAL, 2624
 SET_EXT_ZONE_CHAR, 2625
 SET_EXT_ZONE_INT, 2626
 SET_EXT_ZONE_LOGICAL, 2627
 SET_EXT_ZONE_REAL, 2628
 SET_FREQ_RELAY_V_THRESH, 1554
 SET_GENANG, 1555
 SET_GENANG_2, 1556
 SET_GENANG_3, 1558
 SET_GENANG_SUBSYS_FLAG, 1560
 SET_GENPWR, 1561
 SET_GENSPDEV, 1562
 SET_GENSPDEV_SUBSYS_FLAG, 1563
 SET_INPUT_DEV, 587
 SET_LOAD_MODEL_THRESH, 1564
 SET_MODEL_DEBUG_OUTPUT_FLAG, 1565
 SET_NETFRQ, 1566
 SET_NEXT_CHANNEL, 1567
 SET_NEXT_ICON, 1568
 SET_NEXT_VAR, 1569
 SET_OPF_REPORT_SUBSYSTEM, 1077
 SET_OSSCAN, 1570
 SET_OSSCAN_2, 1571
 SET_OSSCAN_SUBSYS_FLAG, 1572
 SET_PROGRESS_VERBOSE, 588
 SET_RELANG, 1573
 SET_RELSCN, 1575
 SET_RELSCN_SUBSYS_FLAG, 1576
 SET_VLTSCN, 1577
 SET_VLTSCN_SUBSYS_FLAG, 1578
 SET_VOLT_VIOL_SUBSYS_FLAG, 1582
 SET_VOLTAGE_DIP_CHECK, 1579
 SET_VOLTAGE_REC_CHECK, 1580
 SET_ZSORCE_RECONCILE_FLAG, 1583
 SETACTIVEEVENTSTUDY, 3113
 SETDIAGAUTOFILE, 2024
 SETDIAGFONT, 2025
 SETDIAGPREC, 2026
 SETDIAGPREC_2, 2027
 SETDIAGPROP, 2028
 SETDIAGPROP_2, 2031
 SETDIAGPROP_3, 2034
 SETDIAGPROP_4, 2037
 SETDIAGPROP_5, 2040
 SETDIAGRESACCC, 2043
 SETDIAGRESACCC_2, 2044
 SETDIAGRESACCC_3, 2045
 SETDIAGRESASCC, 2046
 SETDIAGRESASCC_2, 2048
 SETDIAGRESASCC_3, 2050
 SETDIAGRESDATA, 2052
 SETDIAGRESDATA_2, 2055
 SETDIAGRESDATA_3, 2056
 SETDIAGRESDDYN, 2057
 SETDIAGRESDDYN_2, 2058
 SETDIAGRESGDIF, 2059
 SETDIAGRESIEC, 2062
 SETDIAGRESIEC_2, 2064
 SETDIAGRESIEC_3, 2066
 SETDIAGRESMUST, 2068
 SETDIAGRESOPF, 2069
 SETDIAGRESOPF_2, 2070

SETDIAGRESOPF_3, 2071
 SETDIAGRESPFLOWCHECK, 2072
 SETDIAGRESPFLOWCHECK_2, 2076
 SETDIAGRESPFLOWCHECK_3, 2079
 SETDIAGRESPFLOWOPTIONS, 2082
 SETDIAGRESPFLOWOPTIONS_2, 2084
 SETDIAGRESPFLOWOPTIONS_3, 2086
 SETDIAGRESREL, 2088
 SETDIAGRESREL_2, 2090
 SETDIAGRESREL_3, 2092
 SETDIAGRESSCGR, 2094
 SETDIAGRESTYPEACC, 2097
 SETDIAGRESTYPEASCC, 2098
 SETDIAGRESTYPEDATA, 2099
 SETDIAGRESTYPEPDYN, 2100
 SETDIAGRESTYPEGDIF, 2101
 SETDIAGRESTYPEGIC, 2102
 SETDIAGRESTYPEHARM, 2103
 SETDIAGRESTYPEIEC, 2104
 SETDIAGRESTYPEMUST, 2105
 SETDIAGRESTYPEOPF, 2106
 SETDIAGRESTYPEPFLOW, 2107
 SETDIAGRESTYPEREL, 2108
 SETDIAGRESTYPESCGR, 2109
 SETDIAGRESVRCS, 2110
 SETDIAGRESVRCS_2, 2113
 SETDIAGTITLE, 2116
 SETEXCLUDEDBRANCHES, 3519
 SETEXCLUDEDCONTINGENCIES, 3520
 SETEXCLUDEDFLOWGATES, 3521
 SETEXCLUDEDINTERFACES, 3522
 SETEXCLUDEDVOLTAGEBUSES, 3523
 SETFULLVIEWGRAPHAREA, 3050
 SETFULLVIEWSCALE, 3053
 SETHOMEPATH, 2355
 SETSELECTEDPAGE, 3254
 SETSELECTEDPLOT, 3255
 SFILES, 2356
 SGLACFCITC, 3524
 SGLDCFCITC, 3526
 SHNT, 589
 SHORT_CIRCUIT_COORDINATES, 590
 SHORT_CIRCUIT_MODELING, 591
 SHORT_CIRCUIT_UNITS, 592
 SHORT_CIRCUIT_WARNING, 593
 SHORT_CIRCUIT_Z_COORDINATES, 594
 SHORT_CIRCUIT_Z_UNITS, 595
 SHOW, 596
 SHOWLOADEDLIBRARIES, 3227
 SHOWLOADEDMODULES, 3228
 SHOWPARAMS, 3528
 SHOWPLOTEDITOR, 3256
 SHOWTABLE, 597
 SHOWTABLEBYINDEX, 598
 SHUNT_CHNG, 824
 SHUNT_DATA, 825
 SIZE, 599
 SIZE_DS, 1584
 SLMODIND, 2357
 SLMODNAM, 2359
 SNAP, 1585
 SOLSTR, 2360
 SOLUTION_PARAMETERS, 826
 SOLUTION_PARAMETERS_2, 828
 SOLUTION_PARAMETERS_3, 830
 SOLUTION_PARAMETERS_4, 832
 SOLUTION_PARAMETERS_5, 834
 SOLV, 600
 SOLVED, 2361
 SOLVED_CA, 2362
 SPCB, 602
 SPIL, 604
 SPLT, 608
 SQEX, 1266
 SQLI, 609
 SRAIND, 611

STADAT, 2363
 STAINT, 2364
 STANAME, 2365
 STANODEINT, 2366
 STANODENAME, 2367
 STAREA, 2368
 STARTRECORDING, 3229
 STASWDEVDAT, 2369
 STASWDEVINT, 2371
 STASWDEVNAME, 2372
 STATE_CHANNEL, 1629
 STATION_2DC_CONV_TERM_CHNG, 982
 STATION_ADJVAR_TERM_CHNG, 983
 STATION_BRANCH_TERM_CHNG, 984
 STATION_BRANCH_TERM_MOVE, 985
 STATION_BUILD_CONFIG, 967
 STATION_BUS_PURG, 986
 STATION_CHNG, 987
 STATION_DATA, 988
 STATION_FACTS_TERM_CHNG, 989
 STATION_INDMACHINE_TERM_CHNG, 990
 STATION_LIST, 968
 STATION_LOAD_TERM_CHNG, 991
 STATION_MACHINE_TERM_CHNG, 992
 STATION_MTDC_TERM_CHNG, 993
 STATION_NODE_CHNG, 994
 STATION_NODE_DATA, 995
 STATION_NODE_NUMBER, 996
 STATION_NODE_PURG, 997
 STATION_NUMBER, 998
 STATION_POUT, 969
 STATION_POUT_2, 970
 STATION_PURG, 999
 STATION_SHUNT_TERM_CHNG, 1000
 STATION_SWDC_CHNG, 1001
 STATION_SWDC_DATA, 1003
 STATION_SWDC_MBD, 1005
 STATION_SWDC_MOVE, 1006
 STATION_SWDC_PURG, 1007
 STATION_SWS_SHUNT_TERM_CHNG, 1008
 STATION_SWS_SHUNT_TERM_CHNG_2, 1009
 STATION_THREE_WND_TERM_CHNG, 1010
 STATION_THREE_WND_TERM_MOVE, 1011
 STATION_TREE, 971
 STATION_VSCDC_CONV_TERM_CHNG, 1012
 STBSKV, 2373
 STOP, 613
 STOP_2, 614
 STOPRECORDING, 3230
 STRT, 1586
 STRT_2, 1587
 STZONE, 2374
 SUBS, 615
 SUBSYSTEMS, 3530
 SUMMARYCONTINGENCIES, 3531
 SWINGBUSES, 3532
 SWITCHDIAGFILEDATASET, 2117
 SWITCHED_SHUNT_ADJUSTMENT, 616
 SWITCHED_SHUNT_CHNG_3, 837
 SWITCHED_SHUNT_CHNG_4, 840
 SWITCHED_SHUNT_CHNG_5, 843
 SWITCHED_SHUNT_DATA, 846
 SWITCHED_SHUNT_DATA_3, 849
 SWITCHED_SHUNT_DATA_4, 852
 SWITCHED_SHUNT_DATA_5, 855
 SWSBLK, 2375
 SWSBLK_2, 2376
 SWSBLZ, 2378
 SWSBLZ2, 2379
 SWSDAT, 2380
 SWSDAT_2, 2381
 SWSDT1, 2382
 SWSINT, 2383
 SWSINT_2, 2384
 SWSLIST, 1588
 SWSMIND, 2385

SWSMIND_2, 2387
 SWSMNAME, 2389
 SWSMNAME_2, 2390
 SWSMOD_PACK, 1760
 SWSMOD_REMOVE, 1761
 SWSMOD_REMOVE_2, 1762
 SWSMOD_STATUS, 1763
 SWSMOD_STATUS_2, 1764
 SWSMOD_UNCONNECTED, 1765
 SWSMOD_USER, 1766
 SYSMSM, 2391
 SYSMVA, 2392
 SYSTEM_SWDC_HNG, 1013
 SYSTEM_SWDC_DATA, 1015
 SYSTOT, 2393

T

T_ALERT_OUTPUT, 3231
 T_PROGRESS_OUTPUT, 3233
 T_PROMPT_OUTPUT, 3235
 T_REPORT_OUTPUT, 3237
 TAP_ADJUSTMENT, 617
 TEXT, 618
 TFLG, 619
 THREE_WINDING_DATA, 858
 THREE_WND_APP_RX_CHANNEL, 1619
 THREE_WND_IMPED_CHNG_3, 865
 THREE_WND_IMPED_CHNG_4, 868
 THREE_WND_IMPED_DATA_3, 871
 THREE_WND_IMPED_DATA_4, 874
 THREE_WND_IMPEDANCE_DATA, 862
 THREE_WND_MVA_CHANNEL, 1621
 THREE_WND_P_AND_Q_CHANNEL, 1623
 THREE_WND_P_CHANNEL, 1625
 THREE_WND_WINDING_DATA, 877
 THREE_WND_WINDING_DATA_3, 879
 THREE_WND_WINDING_DATA_4, 881
 THREE_WND_WINDING_DATA_5, 884
 TIES, 620
 TIEZ, 621
 TIME, 622
 TITLDT, 2394
 TLST, 623
 TLTG, 624
 TOTBUS, 2395
 TPCH, 628
 TR3DAT, 2396
 TR3DT2, 2397
 TR3INT, 2399
 TR3NAME, 2401
 TRANSACTION_ADD_MOD, 887
 TRANSACTION_DELETE, 888
 TRANSFER_CHNG, 889
 TRANSFER_DATA, 890
 TRANSFORMER_PERCENT_UNITS, 631
 TRANSMISSION_LINE_UNITS, 632
 TREE, 633
 TREEDAT, 3126
 TRIG_VOLT_VIOLATION_CHECK, 1589
 TRNDAT, 2402
 TRXDAT, 2403
 TTDCAUXMOD_REMOVE, 1930
 TTDCAUXMOD_STATUS, 1931
 TTDCLMOD_REMOVE, 1723
 TTDCLMOD_STATUS, 1724
 TWO_TERM_DC_CONVERTER_DATA_3, 896
 TWO_TERM_DC_CONV_DATA, 899
 TWO_TERMINAL_DC_LINE_CHNG, 892
 TWO_TERMINAL_DC_LINE_DATA, 894
 TWO_WINDING_CHNG_4, 902
 TWO_WINDING_CHNG_5, 906
 TWO_WINDING_CHNG_6, 910
 TWO_WINDING_DATA, 915
 TWO_WINDING_DATA_3, 919
 TWO_WINDING_DATA_4, 923

TWO_WINDING_DATA_5, 927
 TWO_WINDING_DATA_6, 931
 TYSL, 634

U

UPDATEBUSLOCdiagFILE, 2118
 USE_DUAL_CRITERIA, 1078
 USE_EMERGENCY_FLOW_LIMITS, 1079
 USE_EMERGENCY_VOLT_LIMITS, 1080
 USER, 635
 USERIN, 3239

V

VALIDATE_RAS, 3201
 VAMM, 636
 VAMO, 637
 VAR_CHANNEL, 1630
 VCHK, 638
 VIOLSELCONTINGENCIES, 3533
 VIOLSELCONTINGENCIES_TBL, 3534
 VOLTAGE_AND_ANGLE_CHANNEL, 1631
 VOLTAGE_CHANNEL, 1633
 VOLTAGE_DROOP_CHNG, 936
 VOLTAGE_DROOP_DATA, 938
 VOLTAGE_INPUT, 639
 VOLTAGE_OUTPUT, 640
 VOLTAGEDROOPDATA, 2404
 VOLTAGEDROOPINT, 2405
 VSC_DC_CONVERTER_DATA, 940
 VSC_DC_CONVERTER_DATA_3, 942
 VSC_DC_LINE_CHNG, 944
 VSC_DC_LINE_DATA, 945
 VSCAUXMIND, 2406
 VSCAUXMNAME, 2408
 VSCCDT, 2409
 VSCCIN, 2411
 VSCINT, 2412
 VSCMIND, 2413
 VSCMNAME, 2414
 VSDCAUXMOD_REMOVE, 1932
 VSDCAUXMOD_STATUS, 1933
 VSDCLMOD_REMOVE, 1725
 VSDCLMOD_STATUS, 1726
 VSMO, 641

W

WINDMIND, 2415
 WINDMNAME, 2417
 WNDDAT, 2418
 WNDDT2, 2420
 WNDINT, 2422
 WNLIST, 1590
 WNMOD_CONSISTENCY, 1659
 WNMOD_PACK, 1660
 WNMOD_REMOVE, 1661
 WNMOD_STATUS, 1662
 WNMOD_UNCONNECTED, 1663
 WNMOD_USER, 1664
 WRITE_OPF_OPTIONS_FILE, 1081
 WRITE_OPTIONS_FILE, 647
 WRITE_RAS, 3202
 WRITECAPCURVES, 642
 WRITEEXCLUDES, 3535
 WRITERAWDATA, 3536
 WRITERAWVERSION, 644
 WRITESEQVERSION, 645
 WRITESEQVERSION_2, 646

X

XEQV, 648
 XFRDAT, 2424

XFRINT, 2426
XFRNAM, 2428
XYPLOT, 3257

Z

ZNDAT, 2429
ZNITOI, 2431
ZONE, 650
ZONE_2, 651
ZONE_AREA, 652
ZONE_DATA, 946
ZONEBUBBLE, 3537
ZONESINAREAS, 3538
ZONESUMMARY, 3539
ZONM, 653
ZONM_2, 655
ZONNAM, 2432
ZONNUM, 2433
ZONUSE, 2434
ZSYS, 1985
ZSYSDEF, 1986
ZSYSINIT, 1987