



4. Deploy the RHV-H Hypervisor on the HCI Compute Nodes: NetApp HCI with RHV

HCI

Dorian Henderson
July 08, 2020

This PDF was generated from https://docs.netapp.com/us-en/hci-solutions/redhat_virtualization_4._deploy_the_rhv-h_hypervisor_on_the_hci_compute_nodes__netapp_hci_with_rhv.html on July 31, 2020. Always check docs.netapp.com for the latest.



Table of Contents

4. Deploy the RHV-H Hypervisor on the HCI Compute Nodes: NetApp HCI with RHV	1
--	---


4. Deploy the RHV-H Hypervisor on the HCI Compute Nodes: NetApp HCI with RHV

This solution employs the recommended self-hosted engine architecture of RHV deployment with the minimum setup (two self-hosted engine nodes). These steps begin after the nodes have been racked and cabled and the IPMI port has been configured on each node for using the console. To deploy the RHV-H hypervisor on HCI compute nodes, complete the following steps:


1. Access the out-of-band management console for the compute nodes in the cluster and log in with the default credentials ADMIN/ADMIN.

A screenshot of a login interface titled "Please Login". It features two input fields: "Username" with the value "ADMIN" and "Password" with the value ".....". Below the password field is a blue rectangular button with the word "login" in white. The entire interface is set against a light gray background.

2. Click the Remote Console Preview image in the center of the screen to download a JNLP file launched by Java Web Start, which launches an interactive console to the system.
3. After the virtual console launches, attach the RHV-H 4.3.9 ISO by navigating to and clicking Virtual Media > Virtual Storage.



- For Logical Drive Type, select ISO File from the drop down. Provide the full path and full name of the RHV-H 4.3.9 ISO file or attach it by clicking the Open Image button. Then click Plug In.



- Reboot the server so that it boots using RHV-H 4.3.9 ISO by navigating and clicking Power Control > Set Power Reset.



- When the node reboots and the initial screen appears, press F11 to enter the boot menu. From the boot menu, navigate to and click ATEN Virtual CDROM YSOJ.



7. On the next screen, navigate to and click Install RHV 4.3. This loads the image, runs the pre-installation scripts, and starts Anaconda, the Red Hat Enterprise Linux system installer.


RHVH 4.3

Install RHVH 4.3
Test this media & install RHVH 4.3


Troubleshooting >

Press Tab for full configuration options on menu items.


8. The installation welcome screen appears. Select the preferred language and click Next.



9. In the next screen, select your time zone under Date & Time. The default is UTC. However, NetApp recommends that you configure NTP servers for your environment on this screen. Then select the keyboard language and click Done.



10. Next, click Installation Destination. In the Installation Destination screen, select the drives on which you want to install RHV-H. Verify that Automatically Configure Partitioning is selected in the Partitioning section. Optionally, you can enable encryption by checking the box next to Encrypt My Data. Click Done to confirm the settings.



11. Click Network & Host Name. Provide the desired host name at the bottom of the screen. Then click

the (+) button at the bottom. Select the Bond from the drop down and click Add.



12. Next, in the bond configuration screen, click Add to add the member interfaces to the bond interface.

Editing Bond connection 1

Connection name: **Bond connection 1**

General **Bond** Proxy IPv4 Settings IPv6 Settings

Interface name: **bond0**

Bonded connections:

	Add
	Edit
	Delete

Mode: **Round-robin**

Link Monitoring: **MII (recommended)**

Monitoring frequency: **1** ms

Link up delay: **0** ms

Link down delay: **0** ms

MTU: **automatic** bytes

Cancel **Save**

13. Select Ethernet from the drop down, indicating that the Ethernet interface is added as a member to the bond interface. Click Create.



Choose a Connection Type

Select the type of connection you wish to create.

If you are creating a VPN, and the VPN connection you wish to create does not appear in the list, you may not have the correct VPN plugin installed.

Ethernet

Cancel

Create...

- From the Device dropdown in the slave 1 configuration screen, select the Ethernet interface. Verify that the MTU is set to 9000. Click Save.

Editing bond0 slave 1

Connection name: **bond0 slave 1**

General **Ethernet** 802.1X Security DCB

Device: en0 (AC:1F:6B:8D:85:28)

Cloned MAC address:

MTU: 9000 - + bytes

Wake on LAN:
 Default Phy Unicast Multicast
 Ignore Broadcast Arp Magic

Wake on LAN password:

Link negotiation: Automatic

Speed: 100 Mb/s

Duplex: Full

Cancel **Save**

15. Repeat steps 12, 13, and 14 to add the other Ethernet port to the bond0 interface.
16. From the Mode dropdown in the bond configuration screen, select 802.3ad for LACP. Verify that the MTU is set to 9000. Then click Save.

Editing Bond connection 1

Connection name: Bond connection 1

General Bond Proxy IPv4 Settings IPv6 Settings

Interface name: bond0

Bonded connections:

- bond0 slave 1
- bond0 slave 2

Add Edit Delete

Mode: 802.3ad

Link Monitoring: MII (recommended)

Monitoring frequency: 1 ms

Link up delay: 0 ms

Link down delay: 0 ms

MTU: 9000 bytes

Cancel Save

17. Create the VLAN interface for the in-band management network. Click the (+) button again, select VLAN from the dropdown and click Create.



18. In the Editing VLAN connection screen, select bond0 in the Parent Interface dropdown, enter the VLAN ID of the in-band management network. Provide the name of the VLAN interface in `bond 0.<vlan_id>` format.

Editing VLAN connection 1

Connection name **VLAN connection 1**

VLAN **General** **Proxy** **IPv4 Settings** **IPv6 Settings**

Parent interface	bond0 (via "Bond connection 1")	▼
VLAN id	1172	- +
VLAN interface name	bond0.1172	
Cloned MAC address		▼
MTU	automatic	- + bytes
Flags	<input checked="" type="checkbox"/> Reorder headers <input type="checkbox"/> GVRP <input type="checkbox"/> Loose binding <input type="checkbox"/> MVRP	

Cancel **Save**

19. In the Editing VLAN connection screen, click the IPv4 Settings sub-tab. In the IPv4 Settings sub-tab, configure the network address, netmask, gateway, and DNS servers corresponding to the in-band management network. Click Save to confirm the settings.

Editing VLAN connection 1

Connection name: **VLAN connection 1**

General VLAN Proxy **IPv4 Settings** IPv6 Settings

Method: **Manual**

Addresses

Address	Netmask	Gateway	
10.63.172.151	24	10.63.172.1	Add

DNS servers: 10.61.184.251, 10.61.184.252

Search domains: cie.netapp.com

DHCP client ID: [empty field]

Require IPv4 addressing for this connection to complete

Routes...

Cancel **Save**

20. Create the VLAN interface for the storage network. Click the (+) button again, select VLAN from the dropdown, and click Create. In the Editing VLAN Connection screen, select bond0 in the Parent Interface dropdown, enter the VLAN ID of the storage network, provide the name of the VLAN interface in the **bond 0.< vlan_id >** format. Adjust the MTU to 9000 to allow jumbo frame support. Click Save.

Editing VLAN connection 2

Connection name: **VLAN connection 2**

General **VLAN** Proxy IPv4 Settings IPv6 Settings

Parent interface: bond0 (via “Bond connection 1”)

VLAN id: 3343 - +

VLAN interface name: bond0.3343

Cloned MAC address:

MTU: 9000 - + bytes

Flags: Reorder headers GVRP Loose binding MVRP

Cancel Save

The screenshot shows a software interface for editing a VLAN connection. At the top, it says "Editing VLAN connection 2". Below that, the "Connection name" is set to "VLAN connection 2". There are five tabs: "General", "VLAN" (which is underlined and has a mouse cursor pointing to it), "Proxy", "IPv4 Settings", and "IPv6 Settings". Under the "VLAN" tab, there are several configuration fields: "Parent interface" (bond0 (via “Bond connection 1”)), "VLAN id" (3343 with increment/decrement buttons), "VLAN interface name" (bond0.3343), "Cloned MAC address" (empty dropdown), "MTU" (9000 with increment/decrement buttons and "bytes" suffix), and "Flags" (checkboxes for "Reorder headers" (checked), "GVRP", "Loose binding", and "MVRP"). At the bottom right are "Cancel" and "Save" buttons.

21. In the Editing VLAN Connection screen, click the IPv4 Settings sub-tab. In the IPv4 Settings sub-tab, configure the network address and the netmask corresponding to the storage network. Click Save to confirm the settings.

Editing VLAN connection 2 (on localhost.localdomain) X

Connection name **VLAN connection 2**

General VLAN Proxy **IPv4 Settings** IPv6 Settings

Method **Manual** ▾

Addresses

Address	Netmask	Gateway	
172.21.87.31	255.255.255.0		Add
			Delete

DNS servers

Search domains

DHCP client ID


Require IPv4 addressing for this connection to complete

Routes...


Cancel **Save**

Address	Netmask	Gateway	
172.21.87.31	255.255.255.0		Add
			Delete

22. Confirm that the network interfaces are up and click Done.



23. After the wizard navigates back to the configuration page, click Begin Installation. The next screen prompts you to configure the root password and optionally to create another user for logging into RHV-H.



24. After the installation completes, unmount the ISO file by navigating to Virtual media > Virtual Storage in the virtual console and click Plug Out. Then click Reboot on the Anaconda GUI to complete the installation process. The node then reboots.



After the node comes up, it displays the login screen.

```
Red Hat Virtualization Host 4.3.9 (el7.8)
Kernel 3.10.0-1127.el7.x86_64 on an x86_64
```

```
rhv-h01 login:
```

- Now that the installation is complete, you must then register RHV-H and enable the required repositories. Open a browser and log in to the Cockpit user interface at <https://<HostFQDN/IP>:9090> using the root credentials provided during the installation.

26. Navigate to localhost > Subscriptions and click Register. Enter your Red Hat Portal username and password, click the check box Connect this System to Red Hat Insights, and click Register. The system automatically subscribes to the Red Hat Virtualization Host entitlement.

Red Hat Insights provide continuous analysis of registered systems to proactively recognize threats to availability, security, performance, and stability across physical, virtual, and cloud environments.

Register system

URL	<input type="text" value="Default"/>
Proxy	<input type="checkbox"/> Use proxy server
Login	<input type="text" value="redhat_user"/>
Password	<input type="password" value="....."/>
Activation Key	<input type="text" value="key_one,key_two"/>
Organization	<input type="text"/>
Insights	<input checked="" type="checkbox"/> Connect this system to Red Hat Insights ↗
<input type="button" value="Cancel"/> <input type="button" value="Register"/>	

27. Navigate to localhost > Terminal to display the CLI. Optionally you can use any SSH client to log in to the RHV-H CLI. Confirm that the required subscription is attached, and then enable the Red Hat Virtualization Host 7 repository to allow further updates and make sure that all other repositories

are disabled.

```
# subscription-manager list
+-----+
   Installed Product Status
+-----+
Product Name: Red Hat Virtualization Host
Product ID: 328
Version: 4.3
Arch: x86_64
Status: Subscribed
# subscription-manager repos --disable=
Repository 'rhel-7-server- rhvh-4-source-rpms' is disabled for this system.
Repository 'rhvh-4-build-beta-for-rhel-8-x86_64-source-rpms' is disabled for this
system.
Repository 'rhel-7-server- rhvh-4-beta-debug-rpms' is disabled for this system.
Repository 'rhvh-4-beta-for-rhel-8-x86_64-debug-rpms' is disabled for this system.
Repository 'jb-eap-textonly-1-for-middleware-rpms' is disabled for this system.
Repository 'rhvh-4-build-beta-for-rhel-8-x86_64-rpms' is disabled for this system.
Repository 'rhvh-4-beta-for-rhel-8-x86_64-source-rpms' is disabled for this system.
Repository 'rhel-7-server- rhvh-4-debug-rpms' is disabled for this system.
Repository 'rhvh-4-build-beta-for-rhel-8-x86_64-debug-rpms' is disabled for this
system.
Repository 'rhel-7-server- rhvh-4-beta-source-rpms' is disabled for this system.
Repository 'rhel-7-server- rhvh-4-rpms' is disabled for this system.
Repository 'jb-coreservices-textonly-1-for-middleware-rpms' is disabled for this
system.
Repository 'rhvh-4-beta-for-rhel-8-x86_64-rpms' is disabled for this system.
Repository 'rhel-7-server- rhvh-4-beta-rpms' is disabled for this system.
# subscription-manager repos --enable=rhel-7-server- rhvh-4-rpms
Repository 'rhel-7-server- rhvh-4-rpms' is enabled for this system.
```

28. From the console, modify the iSCSI initiator ID to match the one you set in the Element access group previously by running the following command.

```
rhv-h01 # echo InitiatorName=iqn.1994-05.com.redhat:rhv-host-node- 01 >
/etc/iscsi/initiatorname.iscsi
```

29. Enable and restart the iscsid service.

```
# systemctl enable iscsid
Created symlink from /etc/systemd/system/multi-user.target.wants/iscsid.service to
/usr/lib/systemd/system/iscsid.service
# systemctl start iscsid
# systemctl status iscsid
● iscsid.service - Open-iSCSI
   Loaded: loaded (/usr/lib/systemd/system/iscsid.service; enabled; vendor preset:
disabled)
   Active: active (running) since Thu 2020-05-14 16:08:52 EDT; 3 days ago
     Docs: man:iscsid(8)
           man:iscsiuio(8)
           man:iscsiadm(8)
 Main PID: 5422 (iscsid)
   Status: "Syncing existing session(s)"
   CGroup: /system.slice/iscsid.service
           └─5422 /sbin/iscsid -f
              └─5423 /sbin/iscsid -f
```

30. Install and prepare the other RHV host by repeating the steps 1 to 29.

Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.