





Adeept




ADEEPT AWR-A ROBOT KIT FOR ARDUINO

www.adeept.com
support@adeept.com







M2 Black Nut  X6 www.adeept.com	M2.5 Silver Nut  X4 www.adeept.com	M3 Black Nut  X20 www.adeept.com	M1.4*6 Self-tapping Silver Screw  X4 www.adeept.com	M2*10 Black Screw  X6 www.adeept.com
M2.5*8 Silver Screw  X4 www.adeept.com	M3*10 Countersunk Head Screw  X2 www.adeept.com	M3*12 Black Screw  X16 www.adeept.com	M3*30 Silver Screw  X8 www.adeept.com	M2.5*6+6 Copper Standoff  X4 www.adeept.com
M3*25 Nylon Standoff  X3 www.adeept.com				

Adeept Smart Hub x 1 	ESP8266 x 1 
18650 Battery Holder Set x 1 	WS2812 RGB LED x 1 




DC motor x 4		Ultrasonic module x 1	
Adept Servo x 1		wheel x4	
3pin wire x 1		USB Cable x 1	
4pin wire x 1			
Tracking Module x 1		5pin wire x 1	



Tools


Cross Screwdriver X1 	Cross Socket Wrench X1 
Large Cross-head Screwdriver X1 	
Ribbon X1 	

Self-prepared Parts

18650 lithium battery X2 




Car Assembly.



Take out the car acrylic plates,
peel off the films.


Take out the plates we will use.




Peel off the protective film on
the two sides of the plates.



Motor Part assembly.




Take out two sets of motors (four motors one set), pay attention not to break the wire connected to the motor, handle gently.




First we take out the materials we need according to the picture on the left:
1x set of motors
1x A01 acrylic plate
4x silver M3*30 screw
4x M3 nut




Pass two silver M3*30 screws from the protruding surface through the fixing hole of the motor. Note: First install the motor welded with four wires.



Use the cross wrench to screw the M3 nut onto the M3*30 screw. Note that the screw can't be too tight. If the M3 nut is tightened too much, it will not be rotated after the motor is energized.





Next pass two M3*30 screws through the other motor.




Note: The M3*30 screw cap is on the protruding face.

Use the cross wrench to fix two M3 nuts to two M3*30 screws. Note that the screw cannot be tightened too much.




On the left is an installation drawings of one assembled set of motor.

Assemble another part according to the above method. Note that the motor needs to be installed on the other side of the acrylic plate. Two sets of motors are symmetrically mounted.




Tracking Module assembly.




Materials needed to assemble the tracking module:
1x A02 acrylic plate
1x 3-CH Tracking Module
2x black M2*10 screws
2x black M2 nut
1x 5Pin wire



Attach the 3-CH Tracking Module to A02 as shown in the figure. Note that the direction of the 5Pin wire interface is to the right. If it is to the left, the car tracking function will not work properly.



Pass two black M2*10 screws through the two holes as shown.



Screw two black M2 nuts onto the M2 screw.




Use the small screwdriver to tighten the screws.

Connect the 5Pin wire to the 3-CH Tracking Module.



Ws2812 RGB LED Assembly.




Materials needed to assemble the WS2812 RGB LED:
1x A03 acrylic plate
1x 3CH WS2812 RGB LED
2x black M2*10 screws
2x black M2 nut
1x 3Pin wire



Attach the WS2812 to the acrylic plate. Pass two black M2*10 screws through the acrylic plate and the WS2812 module, and screw two black M2 nuts into the other end. Use the small screwdriver to tighten the screws.


Front and back after screwing.




Connect the 3Pin wire to the "IN" connector. Note that it is the one with white lines on the 3CH Ws2812 RGB LED. If connected wrong, WS2812 will not work properly.




Car base Assembly.




Materials needed to assemble the car base A04:
1x A04 acrylic plate
2x silver M2.5*8 screws
2x M2.5*6+6 copper standoff




Pass two silver M2.5*8 screws through the two holes on the acrylic plate.




Screw the two M2.5*6+6 copper standoffs onto the M2.5*8 screws as shown in the figure. Pay attention to the position of the copper standoffs. If the copper standoffs are mounted on the other side of the acrylic plate, the subsequent installation of Adeept Smart Hub will fail.




Materials needed to assemble the battery holder:
1x A04 acrylic plate
1x 16850 battery holder
2x silver flat head M3*10 screws
2x black M3 nut




Fix the battery holder on the A04 acrylic plate as shown in the figure. Pay attention to the wiring position of the battery holder. If the battery holder is installed reversely, the wiring will not be able to connect to the power connector of Adeept Smart Hub.



Use the cross wrench to fix the black M3 nut to the silver flat head screw M3 * 10. Note that the screws here should be tightened to prevent them loosening and the battery holder to fall.



Materials needed to assemble the Adeep Smart Hub:
1x Adeep Smart Hub
2x silver M2.5 nut
2x M2.5*6+6 copper standoff






Fix the copper standoff in these two positioning holes.



Pass the M2.6*6+6 copper standoff through the positioning hole as shown in the figure, fix the other end with silver M2.5 nut.


On the right is the effect after assembling.






Materials needed to assemble the base:



- 1x A04 acrylic plate
- 2x silver M2.5 nut
- 2x silver M2.5*8 screws
- 1x Adeept Smart Hub



Pass the M2.5*8 screw through the A04 acrylic plate.



Use the small screws to screw two M2.5 screws to two M2.5*6+6 copper standoffs.




Use the cross wrench to fix two silver M2.5 nuts to the M2.5*6+6 copper standoffs as shown.




Note: If the silver M2.5 nut is not easily screwed onto the M2.5*6+6 copper standoff, push the black 4Pin female header of the P7.

The car base after assembling is as shown.






Motor And Tracking Module Assembly.




Materials needed to assemble the motor and tracking module:
1x A01 acrylic plate
1x black M3*12 screw
1x black M3 nut
1x A02 acrylic plate



Use the small screwdriver to place the black M3 nut into the position as shown.



Place the A02 acrylic plate on the via of the A01 acrylic plate as shown.



Pass the black M3*12 screw through the A01 acrylic plate and tighten the M3*12 screw with the large screwdriver.



On the right is the real product after assembling.






Fix The Base.

Materials needed to fix the base:
1x A01 and A02 acrylic plate
1 x A04 acrylic plate
2x black M3*12 screw
2x black M3 nut




Use the small screwdriver to place the two black M3 nuts into the position as shown. Note: Be careful not to let the M3 nut slip off the A04 acrylic plate.




Fix A04 to this position on the A01 acrylic plate as shown.



Place two black M3*12 screws into the position as shown.




Use the large screwdriver to tighten the M3*12 screws.



On the right is the effect after assembling.



Car Base Assembly.




Materials needed to assemble the car base:

- 1x A01 and A04 base
- 1x A02 acrylic plate
- 1x A05 acrylic plate
- 1x A06 acrylic plate
- 1x A01 acrylic plate


Place the A06 acrylic plate on the A01 acrylic plate as shown.



Place A05 on A01 acrylic plate as shown.





Place A03 acrylic plate on A01 acrylic plate as shown.





The effect diagram when get to this step.









Use the small screwdriver to place the two black M3 nuts in the position as shown.





Fix the A01 acrylic plate to the car base.

Pass two black M3*12 screws through the A01 acrylic plate and tighten the M3*12 screws with the large screwdriver.



On the right is the effect after assembling.

As shown, use the small screwdriver to place the black M3 nut on the screw hole on the A02 acrylic plate.





Pass the black M3*12 screw through the A01 acrylic plate and use the large screwdriver to tighten the M3*12 screw



Ultrasonic Module Assembly.


Materials needed to assemble the ultrasonic module:
1x A07 acrylic plate
4x silver M1.4*6 self-tapping screw
1x ultrasonic module
1x 4Pin wire



Install the ultrasonic module on A07 acrylic plate.



Install four silver M1.4*6 self-tapping screws into the ultrasonic positioning holes and use the small screwdriver to screw the screws vertically into the A07 acrylic plate. Note: if you find that A07 is difficult to screw in, you can try to turn over the A07 acrylic plate and screw it in again.



Connect the 4Pin wire with ultrasonic module.




Materials needed to assemble the servo module:
1x Adeebt AD002 Servo
2x black M2*10 screw
2x black M2 nut
1x A08 acrylic plate



Install the servo on the A08 acrylic plate as shown in the figure, pass two black M2*10 screws through the A08 acrylic plate.






Screw two black M2 nuts onto the two M2*10 screws and tighten the M2*10 screws with the small screwdriver.




Materials needed to assemble the head of the car:
 1x A08 acrylic plate
 1x ultrasonic module
 1x Ad002 servo module
 6x black M3*12 screw
 3x black M3*25 nylon column

Screw three black M3*12 screws through the A08 acrylic plate and screw three black M3*25 nylon columns onto the M3*12 screws as shown.



Pass the wires of the servo and ultrasonic module through the hole of A08 acrylic plate



Mount the ultrasonic module on the A08 acrylic plate.




Cover the A09 acrylic plate on the A08 and the ultrasonic module.



As shown in the figure, pass three black M3*12 screws through the A09 acrylic plate and tighten them with them large screwdriver.




Materials needed to assemble the upper part of the car:
1x A10 acrylic plate
1x servo with rocker and screw
1x ultrasonic car head



Attach the short rocker arm to the servo at any angle and then rotate the rocker arm clockwise until it stops.



Remove the rocker arm and attach it to the servo as shown.



Then rotate 90 degrees counterclockwise, and then rotate counterclockwise about 90 degrees again, until it can not rotate counterclockwise anymore, which indicating that the servo angle calibration is correct.



Finally rotate the rocker arm 90 degrees clockwise as shown. Then gently remove the rocker arm and do not change the servo angle.





Take out the long rocker arm and 2 silver self-tapping screws in the servo package and put 2 silver self-tapping screws into the hole of A10 acrylic as shown.



Attach the rocker arm to the other side of the A10 acrylic plate and screw 2 self-tapping screws into the rocker arm with the small screwdriver.

The effect diagram after screwing in.



Use the silver M2.5*4 small screws provided in the servo package to fix the ultrasonic head to the A10 acrylic plate.




Place the silver M2.5*4 small screw in the hole of the rocker arm of the servo.


Hold the silver screw by hand to prevent it falling down, turn over the A10 acrylic plate, and pass the servo and ultrasonic module wires through the A10 acrylic plate.




Install the servo on A10 acrylic plate at the angle as shown.



Use the small screwdriver to screw the silver M2.5*4 screw into the servo.





On the right is the effect diagram after assembling.




Connect the motor wires to motor A and motor B as shown. Note that the motor on the left is connected to the motor interface, motor B on the left, and the motor on the right is connected to the motor interface, motor A on the right.

Connect the WS2812 wire to the WS2812 interface on the control board as shown.







Connect the wire of the tracking module to the "tracking" interface of the control board as shown.



Connect the wire of the 18650 battery holder to the "Vin" interface of the control board.





Connect the servo wire to the "PWM6|D12" interface on the control board as shown. Note that do not connect the wires reversely.




Connect the wire of the GND pin of the ultrasonic module to the GND interface of the control board.

Connect the VCC pin of the ultrasonic module to the 5V interface on the control board as shown.








Connect the Trig pin of the ultrasonic module to the D10 interface on the control board as shown.




Connect the Echo pin of the ultrasonic module to the D11 interface on the control board as shown.

Connect the ESP8266 to the ESP8266 interface on the control board. Be careful not to connect reversely.





Use the small screwdriver to place 4 black M3 nuts on the A01 acrylic plate.





Install the A10 acrylic plate on the car and use the large screwdriver to screw the four black M3*12 screws into the A10 acrylic plate.

On the right is the effect diagram of screwing in. We can check if the car head is installed correctly, as shown in the figure below, it can be rotated to the following angle.



Install four wheels on the motor respectively.



On the right is the four-wheeled car after assembling.



Arduino and Processing Environment Installation

Let's take the Windows 64-bit system as an example
(the Arduino IDE also supports MAC and Linux).

First open the browser and enter the URL
<https://www.arduino.cc/en/Main/Software>
and you will see the following interface.




Click "JUST DOWNLOAD"




Run the downloaded file.



Click "I Agree"




Click "Next"




Leave the installation path as default,
click "Install".



Then enter the installation process,
please wait.



If the option pops up during the installation process, please select "Install".



When the installation is complete,
click "Close".




After the installation is complete,
you can see the icon
of the Arduino IDE on your computer desktop.




Click to run Arduino, the following interface
will appear.







Next we need to install the driver program of the Adeeps Smart Hub. We provide driver programs for 4 systems, Windows, Android, Linux and Mac in the package. We need to select the corresponding driver installation according to the system. Let's take the Windows system as an example. Firstly connect Adeeps Smart Hub to the computer with a USB cable. Then open the package, find out the CH341SER_Windows.exe application, and run the program.




The following interface appears, click "INSTALL"

wait a few minutes for the driver to be installed, and then open the "Device Manager" of the computer and you will see that the computer has recognized the Adeeps Smart Hub, and Adeeps Smart Hub port number is COM6. It may be recognized differently on different computers for example COM1, COM2, COM3 and so on.






We first install the Adafruit_NeoPixel.ZIP file, open the Arduino IDE, click on "Sketch" -> "Include Library" -> "Add.ZIP Library"




In the pop-up dialog box, find out the Adafruit_NeoPixel file we provided, click "Open"

Library added to your libraries. Check "Include library" menu


The Arduino IDE will prompt for this information after a successful installation.



Connect the USB cable to the computer and switch the "Upload" button on the Adept Smart Hub to "0".




Click "Tools"->"Board:Arduino/Genuino Uno"->"Arduino/Genuino Uno" on Arduino IDE.



Click on "Tools"->"Port:"COM6""->"COM6"






```


25 #define BACKWARD 2
26 #define LEFT 3
27 #define RIGHT 4
28 #define STOP 4
29 char judge = 0;
30 int processingID = 0;
31 String comdata = "";
32 String text1 = "\r\n+n+IPD,0,1:w";//w
33 String phone1 = "\r\n+n+IPD,0,2:w\n";//w
34 String text2 = "\r\n+n+IPD,0,1:a";//a
35 String phone2 = "\r\n+n+IPD,0,2:a\n";//a
36 String text3 = "\r\n+n+IPD,0,1:d";//d
37 String phone3 = "\r\n+n+IPD,0,2:d\n";//d
38 String text4 = "\r\n+n+IPD,0,1:s";//s
39 String phone4 = "\r\n+n+IPD,0,2:s\n";//s
40 String text5 = "\r\n+n+IPD,0,1:5";
41 String phone5 = "\r\n+n+IPD,0,2:5\n";
42 String text6 = "\r\n+n+IPD,0,1:6";
43 String text7 = "\r\n+n+IPD,0,1:7";
44 String text8 = "\r\n+n+IPD,0,1:8";
45 String text9 = "\r\n+n+IPD,0,1:9";
46
47 String text1T = "\r\n+n+IPD,1,1:w";//w
48 String phone1T = "\r\n+n+IPD,1,2:w\n";//w

```

Compiling sketch... 


Arduino/Genuine Uno on COM5

Click the "Upload" button on the Arduino IDE.



After the program is successfully uploaded, switch the "Upload" button on the Adeept Smart Hub to "1". Unplug the USB cable, then install two 18650 batteries, switch on, and wait for the WS2812 indicator light to fully illuminate and then off. After that, you can use the mobile app to control the car. Note: The U4 power chip will generate a lot of heat during the work, the U4 part of the control board may become hot, which is a normal phenomenon.







Download address of Android App:

<https://play.google.com/store/apps/details?id=com.adeept.lenovo001.smartcar>

Or search for "Adeept Remote Control" on Google play.



After installing the app, switch on the car, and remember to switch to 1 on the control board. Wait for the car Wi-Fi to start, connect the mobile phone to the car Wi-Fi. The car Wi-Fi has no password and can be connected directly. After the phone Wi-Fi successfully connects to the Wi-Fi established by the car, open the mobile app "Adeept Remote Control". Enter "192.168.4.1" on "IP Address" on this interface. Enter "333" on "Port" and click "CONNECT" to enter the next interface.



After entering the current interface, you can press the four direction buttons on the left to control the car to turn left and right, go forward and backward.


Note:

When exit the car control interface and enter it again, you may fail to control the car.

Solution: Turn off the car, and then turn on and reconnect the car Wi-Fi.



Commands of the remote control buttons:



Press button 1, the app sends out "forwardStart" .
Release button 1, the app sends out "forwardStop" .

Press button 2, the app sends out "leftStart" .
Release button 2, the app sends out "leftStop" .

Press button 3, the app sends out "backwardStart" .
Release button 3, the app sends out "backwardStop" .

Press button 4, the app sends out "rightStart" .
Release button 4, the app sends out "rightStop" .

Press button 5, the app sends out "upStart" .
Release button 5, the app sends out "upStop" .

Press button 6, the app sends out "lookLeftStart" .
Release button 6, the app sends out "lookLeftStop" .

Press button 7, the app sends out "downStart" .
Release button 7, the app sends out "downStop" .

Press button 8, the app sends out "lookRightStart" .
Release button 8, the app sends out "lookRightStop" .

Press button A, the app sends out "aStart" .
Release button A, the app sends out "aStop" .

Press button B, the app sends out "bStart" .
Release button B, the app sends out "bStop" .

Press button C, the app sends out "cStart" .
Release button C, the app sends out "cStop" .

Press button D, the app sends out "dStart" .
Release button D, the app sends out "dStop" .



Cover
Download
Donate
Exhibition
Reference
Libraries
Tools
Environment
Tutorials
Examples
Books
Handbook
Overview
People
Shop
» Forum
» GitHub
» Issues
» WiFi
» FAQ
» Twitter
» Facebook
» Medium

Welcome to Processing 3
from Processing Foundation

Welcome to Processing 3! Dan explains the new features and changes; the links Dan mentions are on the Vimeo page.

» Download Processing

» Browse Tutorials
» Visit the Reference

Processing is a flexible software sketchbook and a language for learning how to code within the context of the visual arts. Since 2001, Processing has promoted software literacy within the visual arts and visual literacy within technology. There are tens of thousands of students, artists, designers, researchers, and hobbyists who use Processing for learning and prototyping.

- » Free to download and open source
- » Interactive programs with 2D, 3D, PDF, or SVG output
- » OpenGL integration for accelerated 2D and 3D
- » For GNU/Linux, Mac OS X, Windows, Android, and ARM
- » Over 100 libraries extend the core software
- » Well documented, with many books available

» Donate
Please join us as a member of the Processing Foundation. We need your help!

» Exhibition
komorebi by Leslie Nootboom
Particle Flow by NEONANALOG
Objectifier by Björn Karmann

Open your browser and enter the URL
www.processing.org
Click on "Download Processing"

Note: When we use Processing to control the car, we need our computer to have WIFI function. The computer WiFi directly connect to the car WiFi to communicate, which does not pass through the router.

Cover
Download
Donate
Exhibition
Reference
Libraries
Tools
Environment
Tutorials
Examples
Books
Handbook
Overview
People
Shop
» Forum
» GitHub
» Issues
» WiFi
» FAQ
» Twitter
» Facebook
» Medium

Download Processing. Processing is available for Linux, Mac OS X, and Windows. Select your choice to download the software below.

3.4 (26 July 2018)

Windows 64-bit	Linux 64-bit	Mac OS X
Windows 32-bit	Linux 32-bit	Linux ARM (running on Pi)

Read about the changes in 3.0. The list of revisions covers the differences between releases in detail.

Platforms

Stable Releases

- 3.4 (26 July 2018) Win 32 / Win 64 / Linux 32 / Linux 64 / Linux ARMv6hf / Mac OS X
- 3.3.7 (13 March 2018) Win 32 / Win 64 / Linux 32 / Linux 64 / Linux ARMv6hf / Mac OS X
- 2.2.1 (19 May 2014) Win 32 / Win 64 / Linux 32 / Linux 64 / Mac OS X
- 1.5.1 (15 May 2011) Win (standard) / Win (no Java) / Linux x86 / Mac OS X


Earlier releases have been removed because we can only support the current versions of the software. To update old code, read the [changes](#) page. Changes for each release can be found in [revisions.txt](#). If you have problems with the current release, please [file a bug](#) so that we can fix it. Older releases can also be built from the source. Read more about the releases and their numbering. To use [Android Mode](#), Processing 3 or later is required.

The operating system we choose to use here is windows 64-bit, select "Windows 64-bit"




When finish downloading, you will get a compressed file "processing-3.4-windows64.zip".






After extracting this file, you can get the following file, just click to run processing, it can be run directly without installation.



After this interface appears, we need to open the Processing code we provided in the Processing IDE.



In this interface, we need to turn on the computer WiFi function to connect to the car WiFi.




A screenshot of the Processing IDE window titled "AdeptRadarProcessing". The code area contains the following Java code:

```
1 import controlP5.*;
2 import processing.net.*;
3 import java.awt.event.KeyEvent; // imports library for reading key events
4 import java.io.IOException;
5
6 ControlP5 cp5;
7 controlP5.Button b1;
8 controlP5.Button b2;
9 controlP5.Button m1;
10 controlP5.Button m2;
11 controlP5.Button m3;
12 controlP5.Button m4;
13 controlP5.Button m5;
14 controlP5.Button m6;
15 controlP5.Button m7;
16 controlP5.Button m8;
17 controlP5.Button m9;
18 controlP5.Button m10;
19 controlP5.Button k1;
20 controlP5.Button k2;
```

Click the "run" button of the Processing IDE. If an error occurs, it should be that the Processing is missing the corresponding library file. Then follow the prompts to install it online.

Control the button of the car direction.



Control the working mode of the car.

Radar scanning: click the mouse once and the ultrasonic scan stops once.
Tracking function: After the mouse click, the car enters the tracking mode, and it will follow the black line on the white paper.
Obstacle avoidance: After the mouse click, the car enters the obstacle avoidance mode and it will automatically avoid the obstacles ahead





Adeept

www.adeept.com
support@adeept.com