

Yale HSA6200 Siren Based Alarm System Quick Guide

Quick Setup Guide

- 1) SIREN: POWER OFF
- 2) SIREN PROGRAMMING SWITCHES: 1 & 4 TO ON, 3 & 4 TO OFF
- 3) PRESS LEARN BUTTON 3- 4 TIMES THEN TURN POWER ON
- 4) MOVE PROGRAMMING SWITCH 1 BACK TO OFF
- 5) PRESS AND HOLD LEARN BUTTON ON SIREN LED 1 & 3 FLASH
- 6) PRESS RED ARM BUTTON (closed padlock) ON KEYPAD SIREN BEEPS
- 7) PRESS LEARN BUTTON ON SIREN LED 2 FLASHES
- 8) PRESS DISARM BUTTON (open padlock) THEN 0000 SIREN BEEPS
- 9) PRESS PANIC A THEN 0000, PANIC A THEN 2 SIREN BEEPS
- 10) PRESS PANIC A THEN 4 SIREN BEEPS
- 11) PRESS TEST BUTTON ON THE DETECTORS ONE AT A TIME *–SIREN BEEPS EACH TIME*
- 12) PRESS PANIC A THEN 5 SIREN BEEPS
- 13) PRESS DISARM TWICE

Changing the PIN Number

- 1) PRESS PANIC A THEN 0000
- 2) PRESS PANIC B THEN NEW FOUR DIGIT PIN CODE
- 3) PRESS ARM (closed padlock)
- 4) PRESS DISARM (open padlock)TWICE

Using the System

TO ARM: PRESS ARM (closed padlock) FOR 1 SECOND TO DISARM: PRESS DISARM (open padlock) AND ENTER PIN NUMBER

Adding Additional Accessories

- 1) Press Panic A then PIN number, Panic A and 2 siren beeps
- 2) Press Panic A then 4 *siren beeps*
- 3) Press the Test button on the detector to be programmed *siren beeps*
- 4) Press Panic A then 5 siren beeps
- 5) Press DISARM twice Key Pad LED stops flashing

Adding an Additional Key Pad:

- 1) Press Panic A then PIN number, Panic A and 2 siren beeps
- 2) Press Panic A then 4 siren beeps
- 3) Press the ARM button on the Key Fob to learn in *siren beeps*
- 4) Press DISARM twice Key Pad LED stops flashing
- ADDING AN ADDITIONAL KEY PAD:

- 1) Press Panic A then PIN number, Panic A and 2 siren beeps
- 2) Press Panic A then 4 siren beeps
- 3) The new Key Pad press Panic A then 0000, Panic A and 1 siren beeps
- 4) Press DISARM twice on both the Key pads

Changing PIN number on the Key Pad:

1) Press Panic A the PIN (0000 in case of new pad), Then press Panic B + new 4 digit

PIN and press ARM to confirm. (this should be a continuous process)

2) Press DISARM twice to exit the programming mode

Resetting PIN number on the Key Pad Back to 0000:

1) Take the battery out from the Key Pad, Press and Hold 3 and insert the battery back in whilst still holding 3 – the PIN number should be RESET to 0000

SOME QUICK FACTS:

1) Testing the PIN number is working: Press **Panic A** then the **PIN** number – the

green **LED** should **start flashing** continuously (this indicates that the new PIN number has been taken in). After the test **Press DISARM twice** to come out of

the programming mode.

2) **HOME ARM** button not accessible with this system (the same Key Pad is used

as an accessory with the other upgraded system).

- 3) PANIC A + PANIC B sets the alarm off (Panic Alarm)
- 4) **Battery Not Inserted Properly**: If the Key Pad is not responding (no flashing

light when buttons pressed) – make sure that the battery is inserted properlythere

are two steel strips, make sure that the shorter sits below the battery and the longer above.