

Unique code scanning program for steering weels Plant 31 (Russia)



Operator should type in username RUSSIA6 (program is installed only for this user) and password (same RUSSIA6) and press Enter.

Subsys										tem : system : dschirm :	PINTER
Benutzer Kennwort										RUSSIA6	
Menü											
Aktuelle	Bibliot	hel	Κ.								



Operator should choose and type in "1", then press Enter.





Program displays the username (User), assembly line connected to the user (P-Line) and the field requiring input of the customer reference part-number with 5-unique digits from the barcode (Barcode or MABES-Id)

User : RUSSIA6

P-Line: ASSEMBLY7

Barcode or MABES-Id


F3=Exit








- 1. Operator should read out 2d-barcode stacked to assembled steering wheel
- 2. Program should display the code containing customer reference number and 5-digits unique code
- 3. Confirmation with Enter.





To proceed operator should type in Ersteller-ID and press Enter:





Then system will display the counter:



Operator should take another assembled steering wheel of the same model, read in the stacked barcode and press Enter:








3. Input stage – OK and NOK

Click on the images to zoom them





Thank you for your attention!