

KUBOTA U27-4 OPERATOR'S MANUAL (EXCERPT)

Code No. RH418-8193-1 / Issued 2024-08 / KUBOTA Corporation (excerpt for training)

SAFE OPERATION -13

Before starting the engine, make sure the safety lever is in the LOCK position. The engine will not crank while the safety lever is released. This is a designed interlock, not a fault.

Do not attempt to bypass the interlock. If the engine does not crank with the lever locked, inspect the battery terminals and the starter relay before further troubleshooting.

PERIODIC SERVICE

Service intervals are counted in engine service hours shown on the hour meter, not in calendar days. Perform the daily checks before every shift regardless of the hour meter reading.

Every 50 hours: grease all pivot points, check track tension, drain water from the fuel filter separator.

Every 200 hours: replace engine oil and engine oil filter, inspect the fan belt tension, check coolant level and hoses for cracks.

Every 500 hours: replace the hydraulic return filter, replace the fuel filter element, inspect the travel motor for oil leakage.

Every 1000 hours: replace the air cleaner element, replace all filters as a set, adjust the track and inspect idlers and rollers for wear.

In cold weather below -5 degrees Celsius, extend the glow plug preheat time and idle the machine for at least three minutes before operation. Low hydraulic oil temperature slows the control response.

MAINTENANCE RECORD

Record every service in the maintenance logbook with the hour meter reading, the date, the parts replaced and the name of the technician. Keep the record for the life of the machine.