UART DMA / BLE HCI demonstration suite

This repository is a complete desktop simulation and reference implementation of a BLE HCI H4 link carried over UART. It combines real FreeRTOS queues, tasks, notifications, semaphores, circular DMA receive logic, a TX DMA engine, CRC16-CCITT framing, typed HCI wire structures, portable C clients, a Python client, and matching graphical dashboards.

The normal local topology is:

```
TEXT
C client UI or Python client UI
            |
            | serial H4 packets + big-endian CRC16-CCITT
            v
    pseudo-UART slave device
            |
            v
continuous C server engine
            |
            v
FreeRTOS RX DMA -> producer queue -> HCI consumer
FreeRTOS TX queue -> CRC framing -> TX DMA -> client
```

The server creates the pseudo-UART, so start the server before connecting a client. The graphical apps intentionally allow only one user-started transfer direction at a time. When one side is sending a test transfer, every send button on both dashboards remains disabled until the transfer ends. Protocol-generated responses and acknowledgements continue to work.

A printable version of this guide is available as `output/pdf/UART_DMA_BLE_HCI_User_Guide.pdf`.

Contents

1 Repository layout

2 Prerequisites

3 First-time setup

4 Configure and build with CMake

5 Run the graphical server and a client

6 Use the dashboards

7 Run the command-line applications

8 Understand timing, buffers, IRQs, and telemetry

9 Saved settings and Defaults

10 Run tests, benchmarks, and documentation

11 Troubleshooting

12 Wire protocol and implementation notes

13 Port the engine to target hardware

Repository layout

```
TEXT
include/uart_dma/       Public embedded-library headers
src/                    FreeRTOS UART/DMA, ring, CRC, and HCI implementation
apps/common/            Shared C protocol, serial, timing, settings, and UI code
apps/server/            Pseudo-UART and server serial-ingress components
apps/ble_uart_*.c       C command-line and graphical application entry points
python/dashboard_*.py   Python mirrors of the native dashboard components
python/ble_protocol.py  Python H4 framing, CRC, parser, and test protocol
python/serial_ports.py  Cross-platform Python serial-port discovery
python/ble_uart_app.py  Python graphical client controller and layout
demo/                   Embedded round-trip demo and macOS wrapper app
tests/                  Native unit and integration tests
tools/                  Bidirectional benchmark and buffer-effect validation
docs/                   Doxygen configuration and architecture guide
output/pdf/             Generated printable user guide
VERSION                 Shared application version displayed by every UI
```

The public `uart_dma/uart_dma.h` header is the convenience umbrella for the complete embedded stack. A smaller integration may include only the required component headers:

- `uart_crc16.h` for CRC16-CCITT.
- `uart_dma_ring_buffer.h` for the circular DMA receive buffer.
- `ble_hci_parser.h` for incremental H4 parsing.
- `ble_hci_wire.h` for packed, typed wire structures and endian helpers.
- `uart_dma_messages.h` for queue message types.
- `uart_dma_platform.h` for platform register and DMA hooks.

See the runtime dataflow graph and the repository component graph for the relationships between the apps, libraries, FreeRTOS tasks, tests, and documentation targets.

Prerequisites

Required for the native C build

- CMake 3.16 or newer.
- A C11 compiler and platform build tool. Apple Clang plus Ninja or Make works on macOS; GCC or Clang plus Ninja or Make works on Linux; MSVC or MinGW can build the portable client components on Windows.
- Git and network access during the first CMake configure. CMake fetches the pinned FreeRTOS kernel, raylib, raygui, and Space Grotesk sources.
- Doxygen when `UART_DMA_BUILD_DOCS=ON`, which is the default.

Required for the Python client

- Python 3 with Tk support.
- venv support.
- pyserial 3.5 or newer and below version 4, installed from `python/requirements.txt`.

Platform notes

- The continuous pseudo-UART server and graphical server supervisor build on macOS and Linux because they use POSIX pseudo-terminals.

- The portable C graphical client builds on macOS, Linux, and Windows.
- The Python Tk client runs on macOS, Linux, and Windows and can connect either to the local pseudo-UART or to a physical serial adapter.
- A physical UART is not required for local testing. The server prints a local pseudo-UART slave path for the clients.

Typical macOS prerequisites can be installed with:

```
SH
brew install cmake ninja doxygen python
```

On Linux, install the equivalent C compiler, CMake, build tool, Doxygen, Python, Tk, and venv packages using the distribution package manager. The exact package names vary by distribution.

First-time setup

Run all commands in this guide from the repository root.

1. Create the project-local Python environment

The repository intentionally uses `.venv` and excludes it from version control:

```
SH
python3 -m venv .venv
```

Activate it in a POSIX shell:

```
SH
source .venv/bin/activate
```

Or use its interpreter directly without activation:

```
SH
.venv/bin/python -m pip install --upgrade pip
.venv/bin/python -m pip install -r python/requirements.txt
```

On Windows PowerShell, activation is typically:

```
POWERSHELL
.venv\Scripts\Activate.ps1
python -m pip install --upgrade pip
python -m pip install -r python\requirements.txt
```

2. Choose a build directory

The examples use `build`. Any out-of-source directory is valid. Existing IDE users may continue using `cmake-build-debug` or another configured directory.

```
SH
cmake -S . -B build
```

The first configure can take longer because the pinned dependencies are downloaded. Later builds reuse them from the build directory.

Configure and build with CMake

There is no project Makefile. Always configure and build through CMake.

Standard debug/development build

```
SH
cmake -S . -B build -DCMAKE_BUILD_TYPE=Debug
cmake --build build --parallel
```

For a release build:

```
SH
cmake -S . -B build-release -DCMAKE_BUILD_TYPE=Release
cmake --build build-release --parallel
```

Multi-configuration generators such as Visual Studio may require `--config Debug` or `--config Release` during the build.

CMake options

All options default to `ON` unless the platform cannot support the target.

Option	Purpose
`UART_DMA_BUILD_DEMO`	Build the native FreeRTOS UART/DMA round-trip demo.
`UART_DMA_BUILD_SERVER`	Build the continuous POSIX pseudo-UART server.
`UART_DMA_BUILD_CLIENT`	Build the pure-C command-line UART client.
`UART_DMA_BUILD_PORTABLE_UI`	Build the raylib/raygui graphical dashboards.
`UART_DMA_BUILD_APP`	Build the macOS wrapper for the native demo.
`UART_DMA_BUILD_DOCS`	Build Doxygen HTML documentation and fail on warnings.
`BUILD_TESTING`	Build and register the CTest suites.

For example, a small library-only build without the graphical apps or docs is:

```
SH
cmake -S . -B build-library \
  -DUART_DMA_BUILD_DEMO=OFF \
  -DUART_DMA_BUILD_SERVER=OFF \
  -DUART_DMA_BUILD_CLIENT=OFF \
  -DUART_DMA_BUILD_PORTABLE_UI=OFF \
  -DUART_DMA_BUILD_APP=OFF \
  -DUART_DMA_BUILD_DOCS=OFF
cmake --build build-library --parallel
```

Important build outputs

On macOS, the normal build produces:

```
TEXT
build/ble_uart_server
build/ble_uart_client
build/BLE UART Server.app
build/BLE UART Client.app
build/UART DMA Demo.app
build/uart_dma_demo
build/uart_dma_tests
build/docs/html/index.html
```

On Linux, the graphical applications are normally executables named `ble_uart_server_ui` and `ble_uart_client_ui`. On Windows, the portable client is emitted as an `.exe`; the POSIX pseudo-UART server is not built.

Run the graphical server and a client

Recommended local workflow

1. Build the project.
2. Start the graphical server.
3. Click **Start server**.
4. Wait for the **Pseudo-UART** field to display a path such as `/dev/ttys012` or `/dev/pts/5`.
5. Click **Copy port**, or select and copy the path manually.
6. Start either the C graphical client or the Python graphical client.
7. Paste the path into the client's **Port** field.
8. Confirm **Clock = 20 MHz**, **Baud = 4 M**, **Ring = 16 KiB**, and **DMA = 256 B** for the standard baseline.
9. Click **Connect**.
10. Wait for the client status to report that the BLE UART server identity was verified. Do not send before verification completes.

Start the graphical server

macOS:

```
SH
open "build/BLE UART Server.app"
```

Linux:

```
SH
./build/ble_uart_server_ui
```

The graphical server is a supervisor. Clicking **Start server** launches the real `ble_uart_server` engine as a child process, connects nonblocking control and log pipes, and displays the pseudo-UART created by that engine.

Start the portable C graphical client

macOS:

```
SH
open "build/BLE UART Client.app"
```

Linux:

```
SH
./build/ble_uart_client_ui
```

Windows:

```
POWERSHELL
.\build\ble_uart_client_ui.exe
```

Use a Windows device name such as `COM3` when connecting to physical hardware.

Start the Python graphical client

POSIX shell:

```
SH
.venv/bin/python python/ble_uart_app.py
```

Windows PowerShell:

```
POWERSHELL
.venv\Scripts\python.exe python\ble_uart_app.py
```

If no Python window appears, run the command from a terminal so import, Tk, and serial errors remain visible. See Troubleshooting.

Connection verification

The C and Python graphical clients do not trust an opened port immediately. Each client:

1. Opens the selected UART without blocking its UI indefinitely.
2. Enters the **VERIFYING** transport state.
3. Sends a deterministic 128-byte `TEST` probe with a unique identifier.
4. Waits up to 2.5 seconds for a CRC-valid completion event containing the same identifier, a success status, and a size of 128 bytes.
5. Enables the send controls only after that exact acknowledgement arrives.

A wrong, silent, or incompatible port is closed automatically and leaves a visible error in the status field. The Python client performs the operating system open on a background thread so an invalid driver cannot freeze Tk.

Use the dashboards

The C client, Python client, and C server use matching controls and telemetry. The server's settings describe its local receive path. A client's settings describe that client's local receive path. They are deliberately not synchronized between processes.

Top statistic cards

- **RX PACKETS** counts complete packets received by this application.
- **TX PACKETS** or **TX ACTIVITY** counts packets or events sent by this application.
- **RX IRQ CALLS** is the cumulative local receive interrupt count.
- **TRANSPORT** reports `OFFLINE`, `VERIFYING`, `DMA + IDLE`, or `BYTE IRQ`.

The statistic cards are buttons. Click a numeric card to reset that displayed counter to zero. Resetting one app's card does not reset any other app.

Connection and server controls

Client controls:

- **Port** selects or edits the serial device.
- **Baud** selects the requested UART line rate.
- **Connect/Disconnect** opens or closes the selected port.
- **Clock**, **Ring**, and **DMA** configure the local receive simulation.
- **Per-byte IRQ** selects byte-interrupt receive accounting instead of the default DMA/IDLE accounting.
- **Defaults** restores and saves the baseline settings listed below.

Server controls:

- **Start server/Stop server** manages the continuous FreeRTOS engine.
- **Pseudo-UART** displays the client-facing device path.
- **Copy port** copies that path to the native clipboard.
- The remaining timing, buffer, IRQ, and Defaults controls have the same local meaning as on the clients.

Text fields support native clipboard shortcuts: Cmd+C, Cmd+X, and Cmd+V on macOS; Ctrl+C, Ctrl+X, and Ctrl+V on Windows and Linux.

HCI command builder

The **Preset** menu provides:

- HCI Reset.
- Read Local Version.
- Read BD_ADDR.
- LE Read Buffer Size.
- LE Enable Scan.
- LE Disable Scan.

Selecting a preset fills the opcode and parameter fields. You can then edit the four-digit hexadecimal opcode or the hexadecimal parameter bytes before clicking **Send command**.

Parameter input accepts hexadecimal byte pairs separated by spaces, commas, colons, or tabs. For example:

```
TEXT
01 00
```

The **Raw H4 bytes** field accepts a complete H4 packet beginning with its H4 packet indicator. Do not append a CRC manually. **Append CRC + send** calculates and appends the two-byte big-endian CRC trailer.

Test transmissions

- **Send 128-byte packet** sends a small deterministic diagnostic packet. Its bytes may be shown in the log because it is intentionally small.
- **Block size** selects 16 KiB, 64 KiB, 128 KiB, 512 KiB, 1 MiB, 2 MiB, 4 MiB, 8 MiB, or 16 MiB.
- **Send selected block** sends the selected deterministic multi-packet ACL transfer.

- The progress bar updates approximately 30 to 60 times per second without adding every animation update to the retained log.

Large transfers are split into typed H4 ACL packets with deterministic payload bytes and individual CRC trailers. The receiver validates the transfer ID, declared total, offsets, chunk sizes, payload pattern, packet CRCs, and final size. The log records only start, periodic progress, completion, and error messages so formatting cannot become the throughput bottleneck.

At a requested 4 Mbaud, a 2 MiB logical payload should take approximately 4.2 seconds in either direction. The exact wire byte count is larger because each chunk carries H4, ACL, test metadata, and CRC bytes.

Half-duplex send lockout

User-started transmissions are intentionally half-duplex:

1. The originating app disables **Send command**, **Append CRC + send**, **Send 128-byte packet**, and **Send selected block** when a test starts.
2. The receiving app recognizes the transfer START frame and disables the same four buttons.
3. Both apps keep receiving, parsing, updating telemetry, and exchanging protocol-generated acknowledgements.
4. The receiving END frame re-enables the receiver's buttons.
5. Completion of the sender's transfer worker re-enables the sender's buttons.

If a send button is dimmed during traffic, wait for the active transfer to complete. Do not interpret the disabled state as a lost connection.

Logs

Every graphical log:

- Retains the most recent 256 lines.
- Uses colors to distinguish TX, RX, warnings, errors, and test activity.
- Supports mouse-wheel scrolling and a scrollbar.
- Preserves manual scroll position instead of forcing the view back to the newest line.
- Avoids hexadecimal dumps for large test chunks.

Run the command-line applications

Continuous server engine

Start the engine directly when a graphical server supervisor is not needed:

```
SH
./build/ble_uart_server
```

It prints a pseudo-UART path such as `/dev/ttys012`. Keep the process running and connect a client to that path. Stop it with Ctrl+C.

The server reads the following newline-terminated commands from standard input:

Command	Effect
`irq`	Select per-byte RXNE interrupt receive mode.
`dma`	Select circular DMA plus UART IDLE receive mode.

Command	Effect
`mode`	Send the current receive mode to the client.
`stats`	Print cumulative RX IRQ and pipeline statistics.
`buffers`	Print active ring and DMA sizes.
`timing`	Print clock, requested baud, OSR, SBR, actual baud, and error.
`clock HZ`	Change the simulated LPUART source clock.
`baud RATE`	Change the requested line rate.
`ring BYTES`	Change circular ring capacity from 32 through 65536 bytes.
`dma-buffer BYTES`	Change DMA transaction size from 32 through 4096 bytes.
`tx HEX_BYTES`	Queue one H4 packet represented as hexadecimal bytes.
`test BYTES`	Start a deterministic server-to-client test transfer.

Do not resize the ring or DMA transaction while an inbound test transfer is active. The engine rejects that reconfiguration because buffer geometry must remain stable for a complete transmission.

Pure-C terminal client

Start the server, then connect using its printed port:

```sh
./build/ble_uart_client /dev/ttys012 4000000
```

If baud is omitted, the client defaults to 4000000. The interactive commands are:

Command	Effect
`reset`	Send HCI Reset.
`version`	Send Read Local Version.
`address`	Send Read BD_ADDR.
`buffers`	Send LE Read Buffer Size.
`scan-on`	Enable LE scanning.
`scan-off`	Disable LE scanning.
`send OPCODE [PARAM ...]`	Send a custom hexadecimal HCI command.
`raw BYTE [BYTE ...]`	Send raw H4 bytes with an automatically appended CRC.
`mode dma`	Request DMA/IDLE server receive mode.
`mode irq`	Request per-byte server receive mode.
`mode query`	Query the authoritative server receive mode.
`help`	Print the command list.
`quit`	Close the port and exit.

For a one-shot smoke test, append a preset name:

```
SH
./build/ble_uart_client /dev/ttys012 4000000 reset
```

The one-shot client sends the preset, waits up to two seconds for a parsed response, prints its CRC result, and exits with a nonzero status on failure.

Understand timing, buffers, IRQs, and telemetry

Selectable values and defaults

Control	Selectable values	Default
Clock	4, 8, 12, 16, 20, 24, 32, 40, 48 MHz	20 MHz
Baud	115200, 1 M, 2 M, 3 M, 4 M	4 M
Ring	32 B, 64 B, 128 B, 256 B, 1 KiB, 4 KiB, 16 KiB, 64 KiB	16 KiB
DMA	32 B, 64 B, 128 B, 256 B, 512 B, 1 KiB, 4 KiB	256 B
Block	16 KiB, 64 KiB, 128 KiB, 512 KiB, 1, 2, 4, 8, 16 MiB	2 MiB
IRQ mode	DMA + IDLE or Per-byte IRQ	DMA + IDLE

KW47 LPUART model

The server and clients model an NXP KW47-style LPUART baud generator. The divisor search evaluates effective oversampling ratios from 4 through 32 and SBR values from 1 through 8191, selecting the pair with the smallest baud error:

```
TEXT
actual baud = source clock / (OSR * SBR)
```

At a 20 MHz source clock and requested 4 Mbaud, OSR=5 and SBR=1 produce exactly 4 Mbaud. A theoretical 5 Mbaud combination exists at OSR=4 and SBR=1, but the application intentionally exposes only established rates through 4 Mbaud.

The simulation does not reject a packet from a theoretical clock-rate check. It samples the entire 8-N-1 waveform using the selected divisors and continuous phase. Sampled bytes, including corrupted bytes, continue through DMA, H4 framing, and CRC validation. A warning appears only when the actual simulated packet has changed bits or a framing error. Large transfers aggregate these failures into a compact completion warning.

Ring capacity

The circular ring holds bytes delivered before the UART IDLE boundary. The server's producer wakes at IDLE and treats that span as one logical framed packet. Therefore:

- The ring must be large enough for the complete wire frame.
- A ring smaller than the wire frame produces a real simulated overwrite and a ring drop.
- Ring size is not a per-render-frame or per-read throughput budget.
- Decreasing ring size can increase the displayed utilization percentage even when byte rate is unchanged.

DMA transaction size

DMA size controls the maximum bytes completed by one simulated DMA transaction. It does not directly throttle the requested baud. In DMA mode, expected receive interrupts for one wire frame are approximately:

```
TEXT
DMA IRQ calls = ceil(wire frame bytes / selected DMA bytes)
```

For example, a 255-byte wire frame with a 256-byte DMA size needs one DMA completion. The same frame with a 64-byte DMA size needs four completions.

Per-byte IRQ mode

When **Per-byte IRQ** is enabled, every received wire byte invokes the simulated RXNE handler. Consequently, the per-transmission IRQ count should equal the number of transmitted wire bytes. This mode is intentionally much more interrupt-heavy than DMA + IDLE.

IRQ counters

IRQ values are application-local and are never synchronized over HCI:

- The dashboard card is cumulative for that app until clicked or the process exits.
- An ordinary packet log contains the IRQ calls for that packet.
- A chunked test transfer resets its transmission count at START, accumulates across every chunk, and logs one final count at END.
- During client-to-server tests, the server publishes in-flight cumulative and transfer IRQ totals at 256 KiB progress boundaries.

Pipeline graph

The lower dashboard monitor distinguishes current rates from buffer pressure:

- Blue is measured producer throughput.
- Cyan is measured consumer throughput.
- Purple **Q%** is peak completed-packet queue utilization.
- Amber **R%** is peak circular-ring utilization.
- Gray **D%** is peak DMA transaction utilization.
- **Q PEAK** shows packet queue occupancy as a percentage of 16 slots.
- **R PEAK** shows ring occupancy as a percentage of selected ring capacity.
- **LATENCY** is measured enqueue-to-consume time.
- **HEADROOM** is measured time to buffer exhaustion when producer throughput exceeds consumer throughput; otherwise it reads `stable`.
- **DROPS** lists CRC, queue, and ring drops.

All buffer series use percentages of their own configured capacity and clamp at 100 percent. Short ring and DMA peaks remain visible for one half-second sample and clear on the following quiet sample. History retains 120 half-second samples, or approximately one minute.

The server polls detailed pipeline state at 10 Hz and aggregates graph points at 2 Hz. The Python monitor repaints at 20 Hz while using the same half-second sampling units. A wider gray DMA trace is drawn beneath an amber ring trace so equal percentages remain separately visible.

Saved settings and Defaults

The C and Python clients share one client profile. The graphical server uses an independent server profile. Each profile saves:

- Clock.
- Baud.
- Ring capacity.
- DMA transaction size.
- Large-transfer block size.
- Per-byte IRQ mode.

The clients also share the last selected port. Typed, dropdown-selected, and attempted client port names are saved.

Preference locations are:

Platform	Directory
macOS	`~/Library/Application Support/BLE UART/`
Windows	`%APPDATA%\BLE UART\`
Linux	`${XDG_CONFIG_HOME:-~/.config}/ble-uart/`

Files in that directory are:

- `client-port.txt` for the shared last client port.
- `client-settings.txt` for both graphical clients.
- `server-settings.txt` for the graphical server.

Clicking **Defaults** immediately applies and saves:

```
TEXT
Clock:       20 MHz
Baud:        4 Mbaud
Ring:        16 KiB
DMA:         256 B
Block:       2 MiB
Receive:     DMA + IDLE
```

Defaults also resets stale pipeline telemetry so historical percentages from the prior geometry do not remain on the graph.

Run tests, benchmarks, and documentation

Complete native and Python test suite

```
SH
ctest --test-dir build --output-on-failure
```

The registered tests cover the native UART/DMA implementation, round-trip demo, LPUART model, Python framing and preferences, bidirectional timing parity, and buffer-size effects.

Python unit tests only

```
SH
.venv/bin/python -m unittest discover -s python/tests -p 'test_*.py'
```

Bidirectional benchmark

The benchmark launches the real continuous server, sends the same transfer in both directions sequentially, validates CRCs and packetization, and rejects an excessive timing ratio:

```
SH
.venv/bin/python tools/benchmark_bidirectional.py \
  build/ble_uart_server \
  --size 2097152 \
  --baud 4000000 \
  --mode dma \
  --ring 16384 \
  --dma 256 \
  --max-ratio 1.20
```

A healthy 4 Mbaud baseline should report roughly 4.2 seconds per 2 MiB direction and a ratio close to 1.0.

Buffer-effect validation

```
SH
.venv/bin/python tools/test_buffer_effects.py build/ble_uart_server
```

This verifies that selected ring and DMA sizes change overflow behavior and IRQ counts as the simulated hardware model specifies.

Doxygen API documentation

Doxygen is part of the default build:

```
SH
cmake --build build --target docs
```

Open the generated index on macOS:

```
SH
open build/docs/html/index.html
```

On Linux, open `build/docs/html/index.html` in a browser. Documentation warnings are errors. A distribution or cross-compilation build may disable docs with:

```
SH
cmake -S . -B build -DUART_DMA_BUILD_DOCS=OFF
```

Troubleshooting

CMake cannot download a dependency

The first configure needs network access to the pinned upstream repositories. Confirm Git can reach GitHub, then retry the same configure command. Do not delete a working build directory merely to change an application setting.

After dependencies have been populated, an intentionally offline reconfigure can use the existing sources:

```
SH
cmake -S . -B build -DFETCHCONTENT_FULLY_DISCONNECTED=ON
```

Use that only when the build directory already contains all fetched sources.

Doxygen is missing

Install Doxygen or configure with `-DUART_DMA_BUILD_DOCS=OFF`. The default build will stop if Doxygen is unavailable because documentation is a normal target.

The Python app displays no window

Run it from a terminal:

```
SH
.venv/bin/python python/ble_uart_app.py
```

Confirm that:

1. `.venv` exists.
2. `python/requirements.txt` was installed into that environment.
3. `python -c "import tkinter"` succeeds.
4. The current desktop session permits graphical windows.

On Linux, a missing `tkinter` import usually means the distribution's Python Tk package is not installed.

Connecting to an invalid UART appears unsuccessful

That is expected. The clients open asynchronously or nonblocking, send the 128-byte identity probe, and require the exact response. A wrong UART is closed after the open error or 2.5-second verification timeout. Select the path printed by the currently running server.

The pseudo-UART path changed

A new server process can receive a different pseudo-terminal number. Copy the new path after every server restart. The remembered client path is a convenience and can legitimately point to an old device.

Send buttons are disabled

Check the transport and transfer state:

- `VERIFYING` means the connection probe has not completed.
- `OFFLINE` means no verified connection exists.
- A moving progress bar or incoming TEST log means half-duplex lockout is active. Wait for the transfer `END`/completion message.
- If a process was interrupted mid-transfer, disconnect and reconnect to clear its local transfer state.

Server-to-client transfer is slower than expected

1. Confirm both dashboards show 4 Mbaud.
2. Confirm the server timing log shows the expected requested and actual rate.
3. Use Defaults on both apps for a 20 MHz clock, 16 KiB ring, and 256 B DMA.
4. Ensure large chunks are not being hex-dumped; current builds log only compact progress messages.
5. Run `tools/benchmark_bidirectional.py` to separate engine timing from UI or physical-driver behavior.
6. Remember that 16 MiB at 4 Mbaud takes about 33.6 seconds before framing overhead; only 2 MiB is expected near 4.2 seconds.

Ring percentage reaches 100 percent or frames drop

The selected ring is smaller than, or equal to, the incoming IDLE-delimited wire span. Increase the ring size. A 256-byte ring is intentionally easy to saturate with a roughly 255-byte framed packet.

IRQ count does not match expectation

- In byte mode, compare against wire bytes, not logical payload bytes.
- In DMA mode, use `ceil(wire bytes / DMA size)` for each packet.
- The dashboard card is cumulative; the log's completion value is per packet or per complete multi-chunk transmission.
- Counters belong to the receiving app only.

CRC or UART simulation warnings appear

The chosen clock and requested baud produce sampling errors for the actual simulated packet. Increase the source clock, reduce baud, or use Defaults. The simulator still processes the corrupted bytes so the warning reflects a real sampled failure rather than a theoretical threshold.

The log is not following new messages

The log preserves manual scrolling. Scroll to the bottom to resume viewing the newest entries. Old entries are discarded after 256 retained lines.

Wire protocol and implementation notes

Every transmitted frame has this form:

```
TEXT
[H4 packet indicator + typed HCI header + HCI payload] [CRC high] [CRC low]
```

The CRC is CRC16-CCITT and is stored as a typed big-endian `BleHciCrcTrailer_t`. HCI multibyte fields use explicit typed wire structures and endian conversion helpers. Header lengths are derived from `sizeof` their corresponding structures instead of duplicated numeric constants.

Supported H4 packet indicators include Command, ACL, SCO, Event, and ISO. The incremental parser selects the typed header layout, reads its encapsulated payload length, applies packet-specific masks such as ISO's 14-bit length, and waits for the complete CRC-protected frame.

The deterministic large-transfer protocol uses ACL packets containing:

- A TEST signature and protocol version.
- START and END flags.
- A 16-bit transfer identifier.
- Declared total logical size.
- Chunk offset and chunk length.
- A reproducible payload pattern.

This metadata lets the receiver detect missing, duplicated, reordered, or corrupted chunks without storing an entire 16 MiB transfer in memory.

The server uses the actual FreeRTOS kernel fetched by CMake. Its receive path is:

```
TEXT
pseudo-UART read
  -> LPUART sampler
  -> circular DMA writes and completion IRQs
  -> UART IDLE notification
  -> producer task
  -> CRC verification
  -> 16-slot packet queue
  -> consumer task
  -> HCI parser and application callback
```

Its response path is:

```
TEXT
typed HCI message
  -> TX queue
  -> TX engine task
  -> CRC trailer
  -> platform TX DMA hook
  -> pseudo-UART
```

Large server test transfers coalesce host writes while preserving individual H4 frames. The coalescing window spans two visual progress intervals so a 60 Hz client remains continuously supplied without producing one host syscall per packet. Pseudo-UART writes wait for actual descriptor writability rather than adding a fixed delay for every partial write.

Port the engine to target hardware

The desktop server supplies simulated register objects and implements `UartDma_PlatformTransmitDma` by writing to a pseudo-terminal. A target port should keep the protocol, queue, parser, and ring components while replacing the platform boundary.

Recommended steps:

1. Include `uart_dma/uart_dma.h` or the smaller required public headers.
2. Provide real `USART_HW`, `DMA_RX_STREAM`, and `DMA_TX_STREAM` register mappings through the platform header.
3. Configure a circular RX DMA buffer using `UartDma_GetRxBuffer()` and the selected or fixed ring capacity.
4. Update the committed DMA write index on transfer events.
5. Call `DMA_RX_Complete_IRQHandler()` on each completed DMA transaction.
6. Call `USART_IRQHandler()` for UART IDLE and, when supported, RXNE byte mode.
7. Implement `UartDma_PlatformTransmitDma()` to start a real nonblocking TX DMA transfer.
8. Call `DMA_TX_Complete_IRQHandler()` only from the actual TX completion ISR so the TX semaphore is released at the correct time.
9. Provide `UartDma_PlatformTimeUs()` from a monotonic target timer when microsecond latency telemetry is desired.
10. Register HCI command and ACL handlers before starting the scheduler.
11. Keep ISR priorities compatible with FreeRTOS `FromISR` API requirements.
12. Validate cache clean/invalidate requirements on cache-enabled MCUs.
13. Test DMA wraparound, IDLE boundaries, queue-full behavior, CRC errors, and the smallest supported ring before connecting a BLE controller.

The desktop pseudo-UART is a development adapter, not an embedded requirement. The reusable libraries do not depend on the graphical dashboards.

Additional documentation

- `apps/README.md` contains implementation-focused notes for the C clients and server.
- `python/README.md` describes the Python module boundaries.
- `docs/architecture.md` contains the runtime and repository graphs.
- Generated Doxygen output documents every project-owned C, Objective-C, and Python module.