Rider-Pi Command Interface Table

Address	Function	Read and Write	Initial Value	Remark
0x01	Battery level	read	0xff	The range is 0-100, linearly corresponding to the minimum value - maximum value of power
0x02	Working status	read	0x01	0x00 Falling state | 0x01 Normal state
0x03	Performance Mode	Write	0x00	0x00 Normal control mode | 0x01 Loop action
0x04	Calibration mode	Write	0x00	0x01 Enter calibration mode 0x00 Exit calibration mode Complete calibration
0x05	*Update the firmware*	*Write*	*0x00*	*0x01 Enter update mode, the lower computer will send a command with the content of 0x55 as a reply, and the upper computer will start transmitting hex after a delay of 1s*
0x06	*Setting the origin*	*Write*	*0x00*	*0x01 setting, set the current direction to 0 degrees, and reset the odometer to zero*
0x07	Firmware version	read		Returns a 10-byte string, for example "R-1.2.3" L stands for lite, M stands for mini, and R stands for rider
0x09	*gait*			*0x00 Normal gait*
0x0A	Static steering ring switch	Write	0x00	0x00 Off | 0x01 On Maintain the direction, and it will return to the original direction after turning it manually
0x13	Bluetooth Name	Write		The name can be up to 20 bytes long and can only be a combination of English and numbers. The Bluetooth name after naming is XGORider_xxxx
0x30	Moving speed	Read and Write	0x80	The range is 0x00-0xff, linearly corresponding to the reverse maximum value - the forward maximum value
0x32	Clockwise and counterclockwise rotation speed	Read and Write	0x80	Face the z-axis and point clockwise to the direction of the maximum value
0x35	Body height	Read and Write	0x80	
0x39	Rotate the body around the x-axis at a certain period	Read and Write	0x00	0x00 stops, 0x01-0xff linearly corresponds to the minimum-maximum rotation speed. This function cannot work at the same time as directly setting roll.
0x3E	Action Instructions	Write	0x00	For details, see the action instruction table. 255 is to restore the default posture. 1-N is each action.
0x82	Translational motion along the Z axis at a certain period	Read and Write	0x00	0x00 stops, 0x01-0xff corresponds to the minimum-maximum rotation speed, and the movement amplitude is half of the position limit
0x61	ROLL balance mode	Read and Write	0x00	0x00 Off 0x01 Self-stabilizing mode
0x62	ROLL angle	read		float
0x63	PITCH angle	read		float
0x64	YAW Angle	read		float
0x66	ROLL angle	read		int16
0x67	PITCH angle	read		int16
0x68	YAW Angle	read		int16
0x69	Color of LED No. 1	Write		Three bytes, the value range is 0-255, [0,0,0] represents off, [255,255,255] represents the brightest white light
0x6A	Color of LED No. 2	Write		Same as above
0x6B	Color of LED No. 3	Write		Same as above
0x6C	Color of LED No. 4	Write		Same as above