

Linux

Serial Port

<https://community.ruggedboard.com>

tty: prints the file name of the terminal connected to standard input

Redirect out to other terminal using **/dev/pts/....**

```
natarajan@natarajan:~$ tty
```

```
/dev/pts/0
```

```
natarajan@natarajan:~$ echo "Hello"
```

```
Hello
```

```
natarajan@natarajan:~$ echo "Hello" >
```

```
/dev/pts/1
```

```
natarajan@natarajan:~$ echo "Hello" >
```

```
/dev/pts/2
```

minicom is a serial communication program that connects to devices through a GNU/Linux PC's serial ports. If run by calling its name without any additional arguments, it uses whatever settings have been saved for its defaults in `/etc/minicom/minirc.dfl`.

```
sudo apt-get install minicom  
man minicom
```

NAME

`minicom` - friendly serial communication program

SYNOPSIS

`minicom` [options] [configuration]

DESCRIPTION

`minicom` is a communication program which somewhat resembles the share-ware program TELIX but is free with source code and runs under most Unices. Features include dialing directory with auto-redial, support for UUCP-style lock files on serial devices, a separate script language interpreter, capture to file, multiple users with individual configurations, and more.

sudo minicom -s

```
+-----[configuration]-----+
| Filenames and paths          |
| File transfer protocols      |
| Serial port setup            |
| Modem and dialing            |
| Screen and keyboard          |
| Save setup as dfl             |
| Save setup as..              |
| Exit                          |
| Exit from Minicom            |
+-----+
```

```
+-----[configuration]-----+
| Filenames and paths          |
| File transfer protocols      |
| Serial port setup            |
| Modem and dialing            |
| Screen and keyboard          |
| Save setup as dfl             |
| Save setup as..              |
| Exit                          |
| Exit from Minicom            |
+-----+
```

```
+-----+
| A -   Serial Device       : /dev/ttyUSB0 |
| B - Lockfile Location    : /var/lock     |
| C -   Callin Program     :               |
| D -   Callout Program    :               |
| E -   Bps/Par/Bits       : 115200 8N1    |
| F - Hardware Flow Control : No           |
| G - Software Flow Control : No           |
|                                     |
|   Change which setting? █             |
+-----+
| Screen and keyboard |
| Save setup as dfl   |
| Save setup as..     |
| Exit                |
| Exit from Minicom   |
+-----+
```

```
+-----[configuration]-----+
| Filenames and paths          |
| File transfer protocols      |
| Serial port setup            |
| Modem and dialing            |
| Screen and keyboard          |
| Save setup as dfl             |
| Save setup as..              |
| Exit                          |
| Exit from Minicom            |
+-----+
```

Linux-SerialPort

```

+-----+
|                                     |
|                                     |
+-----[configuration] Configuration saved
| File names and paths               |
| File transfer protocol             |
+-----+-----+
| Serial port setup                 |
| Modem and dialing                 |
| Screen and keyboard               |
| Save setup as dfl                 |
| Save setup as..                   |
| Exit                             |
| Exit from Minicon                 |
+-----+

```

```
+-----[configuration]-----+
| Filenames and paths          |
| File transfer protocols      |
| Serial port setup            |
| Modem and dialing            |
| Screen and keyboard          |
| Save setup as dfl             |
| Save setup as..              |
| Exit                         |
| Exit from Minicom            |
+-----+-----+-----+-----+
```



```
Welcome to minicom 2.7

OPTIONS: I18n
Compiled on Nov 15 2018, 20:18:47.
Port /dev/ttyUSB0, 16:57:52

Press CTRL-A Z for help on special keys

Poky (Yocto Project Reference Distro) 2.5.2 rugged-board-a5d2x /dev/ttyS0

rugged-board-a5d2x login: root
-sh: command: not found
root@rugged-board-a5d2x:~# ls /data/test/
gpio_blinky.py
root@rugged-board-a5d2x:~# █
```

Practicals



Developer
Wiki





Attribution 4.0 International (CC BY 4.0)

This is a human-readable summary of (and not a substitute for) the [license](#). [Disclaimer.](#)

You are free to:

Share — copy and redistribute the material in any medium or format

Adapt — remix, transform, and build upon the material for any purpose, even commercially.

The licensor cannot revoke these freedoms as long as you follow the license terms.

