
POWER SUPPLY



POWER FLOW MORE DETAIL IN CORE64 USER GUIDE

PRIMARY SWITCHED POWER SOURCES: ON (BAT) : From battery on LED Array Board OFF (USB) : From USB port on Pico

ALTERNATE/OPTIONAL SWITCHED POWER SOURCES: OFF (USB) : From battery on Logic Board

OFF (USB) : From USB port of LiPo Charger on LED Array Board

* Requires closing USB Charge Enable solder jumper
on the back of the LED Array Board. *

TWO POWER INPUT SOURCES SELECTED BY SPDT SWITCH.

Power Switch ON (BAT), USB cable is NOT connected:
P-FET (gate is low) conducts 5V0 (or less if the battery is less than about 5.2V) so that PICO_SYS is powered.
PICO_VBUS is not energized because of built-in Zener diode on the Pico.

Power Switch OFF (USB), USB cable is NOT connected: System is off and does not receive power from the battery.

Power Switch ON (BAT), USB cable IS connected:

If USB voltage is greater than 5V0, the Pico will operate with VSYS at the USB voltage. The rest of the system will operate from whatever the 5V0 rail voltage is.

If USB voltage is less than 5V0, the Pico will operate with VSYS at 5V0 along with the rest of the system. The Pico diode prevents current flow from 5V0 back out through USB.

Power Switch OFF (USB), USB cable IS connected:
The USB voltage will be greater than 5V0 (because there is a voltage drop through the 5V0 regulator). The
P-FET will be off, the Pico will run at the USB voltage, the rest of the system will run at slightly less
than the USB voltage.

CORE MATRIX SENSE


SENSE SIGNAL DIFFERENTIAL AMPLIFIERS

SYSTEM GROUNDS

2x GND PAD 3.2 mm (.125 in) thru-hole for M3 or #4 screw GND PAD GNDD -BATT GND HIGH POWER SYSTEM GROUND

LOGIC GROUND

CORE MATRIX POWER



LED ARRAY DRIVE **VOLTAGE LEVEL SHIFT**

