Preventive Maintenance Schedule

Meridian-3 robots need preventive maintenance to stay within warranty. Tasks are tracked per robot in the fleet console.

Weekly

Wipe the lidar window and both depth cameras with a dry microfibre cloth. Check caster wheels for wrapped shrink-wrap or strapping.

Every 500 operating hours

Inspect drive-wheel treads; replace when tread depth is below 3 mm. Torque-check the payload deck bolts to 12 Nm.

Every 2,000 operating hours

Replace the drive-wheel treads regardless of wear and run the brake self-test from the service menu. Recalibrate the IMU on a level floor.

Annually

Battery health check by a certified technician. Packs below 80% of rated capacity inside the warranty period are replaced free of charge.