

- Basic Input/Output System. Es un Firmware en ROM (o PROM)
- Dos partes fundamentales:
 - ▶ Setup: Para configurar las opciones. Al arrancar se pulsa una tecla para entrar, normalmente Supr
 - ▶ POST: Revisa que funcionen los componentes principales para poder arrancar

LA BIOS



CHIP

CMOS Setup Utility - Copyright (C) 1984-2011 Award Software

- ▶ MB Intelligent Tweaker(M.I.T.)
- ▶ Standard CMOS Features
- ▶ Advanced BIOS Features
- ▶ Integrated Peripherals
- ▶ Power Management Setup
- ▶ PC Health Status

- Load Fail-Safe Defaults
- Load Optimized Defaults
- Set Supervisor Password
- Set User Password
- Save & Exit Setup
- Exit Without Saving

Esc : Quit ↑↓↔ : Select Item F11 : Save CMOS to BIOS
F8 : Q-Flash F10 : Save & Exit Setup F12 : Load CMOS from BIOS

Change CPU's Clock & Voltage

SETUP