Mobile Phone Support Knowledge Base

Troubleshooting, how-to, security, policies and FAQs for AI customer support (RAG)

Version 1.0 | Applies to Android and iPhone (iOS) smartphones unless stated otherwise
Doc ID prefix: MS- (Mobile Support). Companion to the laptop knowledge bases (LS-).
Items in [SQUARE BRACKETS] are placeholders. Replace them with your company's real details before indexing.

How to use this document

Each entry is self-contained with a unique Doc ID and can be used as one retrieval chunk. Menu names differ between phone brands and software versions, so the assistant should ask for the phone brand, model and software version before giving menu paths, and walk the customer through one or two steps at a time. Where Android and iPhone differ, both are given. Policies for warranty, repair, returns and orders are in this document under the MS-POL entries and apply to mobile phones only.

Table of contents

#	Section	Doc IDs
1	Power and Battery	MS-PWR-001 to 004
2	Performance and Storage	MS-PRF-001 to 005
3	Display and Touch	MS-DSP-001 to 005
4	Network, SIM, Wi-Fi and Bluetooth	MS-NET-001 to 007
5	Audio and Camera	MS-AUD-001 to 003
6	Physical Damage and Hardware	MS-HW-001 to 003
7	Software and Accounts	MS-OS-001 to 006
8	Setup and How-To	MS-SET-001 to 008
9	Security and Privacy	MS-SEC-001 to 004
10	Accessories	MS-ACC-001 to 003
11	Choosing a Phone (Pre-Sales)	MS-BUY-001 to 002
12	Warranty, Repair, Returns and Orders	MS-POL-001 to 004
13	Frequently Asked Questions	MS-FAQ-001 to 010
14	Glossary	MS-REF-001
15	Escalation and Assistant Rules	MS-ESC-001, MS-GUIDE-001

1. Power and Battery

MS-PWR-001: Phone will not turn on

Category: Power | Device type: Mobile phone | Doc ID: MS-PWR-001

Symptoms:

- Black screen, no vibration or logo when pressing power
- Stuck on brand logo

Common causes:

- Fully drained battery
- Faulty cable, adapter or port
- Software crash
- Water or impact damage

Troubleshooting steps:

1. Charge with the original charger and cable for at least 30 minutes, using a wall socket.
2. Check the charging port for lint or debris; clean gently with a wooden or plastic toothpick (not metal).
3. Force restart. Most Android: hold Power + Volume Down for 10 to 20 seconds. iPhone 8 or later: press Volume Up, then Volume Down, then hold the Side button until the Apple logo appears.
4. Try a different charger and cable.
5. If it shows the charging icon but will not start, leave it charging for another hour and retry.
6. If it vibrates or lights up but the screen stays black, see MS-DSP-001.

Escalate to human support if:

there is no response after 1 hour of charging with a known-good charger, or the phone was dropped or exposed to liquid.

MS-PWR-002: Phone not charging or charging very slowly

Category: Power | Device type: Mobile phone | Doc ID: MS-PWR-002

Symptoms:

- Charging icon does not appear
- Percentage does not rise
- 'Slow charging' message

Common causes:

- Dirty or damaged port
- Faulty cable or charger
- Low-wattage charger
- Heavy usage while charging
- Battery wear

Troubleshooting steps:

1. Try a different cable and adapter; use the original or a certified fast charger.
2. Plug directly into a wall socket, not a computer USB port.
3. Clean the charging port gently as in MS-PWR-001.
4. Restart the phone and charge while it is idle.
5. Check that the cable is firmly inserted; a loose connection suggests a worn port.
6. Avoid charging under pillows or in hot places; heat slows charging.
7. Update the phone software.

Escalate to human support if:

the port is loose, the phone only charges at a certain cable angle, or it does not charge with multiple known-good chargers.

MS-PWR-003: Battery draining fast

Category: Power | Device type: Mobile phone | Doc ID: MS-PWR-003

Symptoms:

- Battery drops quickly even when idle
- Phone is hot while idle
- Battery lasts only a few hours

Common causes:

- Background apps
- High screen brightness or refresh rate
- Weak signal causing the modem to work harder
- Aging battery (usually after 500 to 800 charge cycles)
- Recent software update still optimising

Troubleshooting steps:

1. Open Settings > Battery and check which apps use the most power.
2. Lower brightness; use auto-brightness and a shorter screen timeout.
3. Turn on battery saver or low power mode.
4. Restrict background activity for apps you rarely use.
5. Turn off location, Bluetooth and Wi-Fi when not needed.
6. Update apps and the operating system.
7. iPhone: check Settings > Battery > Battery Health & Charging; if maximum capacity is below about 80 percent, replacement is recommended. Android: use the manufacturer's battery health or diagnostics feature.

Escalate to human support if:

battery health is poor, the battery is under warranty, or the phone shuts off suddenly with charge remaining.

MS-PWR-004: Swollen or overheating battery (SAFETY)

Category: Power / Safety | Device type: Mobile phone | Doc ID: MS-PWR-004

Symptoms:

- Screen lifting from the body
- Back panel bulging
- Burning or chemical smell
- Phone too hot to hold

Common causes:

- Aging, damaged or defective lithium-ion battery
- Using non-certified chargers

Troubleshooting steps:

1. Stop using the phone and unplug the charger.
2. Turn it off if you can do so safely.
3. Do not press, puncture or try to open the phone.
4. Place it on a non-flammable surface away from anything flammable and do not charge it.
5. Do not carry it in a pocket or bag.
6. Take it to an authorised service centre for battery replacement.

Escalate to human support if:

always. This is a safety issue; escalate immediately to a human agent and authorised service.

---

2. Performance and Storage

MS-PRF-001: Phone is slow or lagging

Category: Performance | Device type: Mobile phone | Doc ID: MS-PRF-001

Symptoms:

- Apps open slowly
- Typing or scrolling lags
- Phone hangs

Common causes:

- Storage almost full
- Too many background apps
- Old software
- Overheating
- Heavy or poorly optimised apps

Troubleshooting steps:

1. Restart the phone.
2. Free up storage (see MS-PRF-004); keep at least 10 to 15 percent free.
3. Close unused apps and clear app cache for heavy apps.
4. Update the OS and apps.
5. Uninstall apps you no longer use.
6. Turn off animations slightly (Android: Developer options > animation scale 0.5x) only if the customer is comfortable.
7. If the problem started after an app install, uninstall that app or boot in safe mode (Android) to check.

Escalate to human support if:

the phone stays slow after a software update and a backup-and-reset test.

MS-PRF-002: Phone overheating

Category: Performance / Heat | Device type: Mobile phone | Doc ID: MS-PRF-002

Symptoms:

- Phone becomes very hot while using, charging or gaming
- Warning about temperature

Common causes:

- Heavy gaming or video recording
- Charging while using
- Direct sunlight
- Thick case trapping heat
- Bad app or network search for signal

Troubleshooting steps:

1. Stop using heavy apps and let the phone cool in a shaded place; do not put it in a fridge.
2. Remove the case.
3. Unplug the charger and avoid using the phone while charging.
4. Close background apps and lower brightness.
5. Update the OS and apps.
6. Check Settings > Battery for apps with unusual usage.

Escalate to human support if:

overheating happens during light use, or the phone is hot with a swollen battery (see MS-PWR-004).

MS-PRF-003: Phone freezing, restarting or stuck in boot loop

Category: Performance | Device type: Mobile phone | Doc ID: MS-PRF-003

Symptoms:

- Random restarts
- Stuck on the logo
- Screen frozen

Common causes:

- Corrupted software or failed update
- Low storage
- Faulty app
- Hardware fault

Troubleshooting steps:

1. Force restart (see MS-PWR-001).
2. Charge to at least 50 percent.
3. Android: boot into Safe Mode to disable third-party apps; if the problem stops, uninstall recent apps.
4. Android: use Recovery mode and clear cache partition if the model offers it.
5. iPhone: connect to a computer and use the update option in Finder or iTunes; avoid Restore unless data is backed up.
6. If data is not backed up, do not factory reset without informing the customer of data loss.

Escalate to human support if:

boot loop continues; a service centre may need to re-flash the software.

MS-PRF-004: Storage full

Category: Performance / Storage | Device type: Mobile phone | Doc ID: MS-PRF-004

Symptoms:

- 'Storage full' message
- Cannot take photos or install apps

Common causes:

- Photos, videos and downloads
- App data and cache
- Offline media
- WhatsApp media

Troubleshooting steps:

1. Open Settings > Storage to see what uses space.
2. Back up photos and videos to cloud or computer, then delete originals.
3. Clear cache of large apps and delete unused downloads.
4. Delete old chat media (for example in WhatsApp > Settings > Storage and data).
5. Uninstall unused apps; use 'Offload unused apps' on iPhone.
6. Consider a memory card if the phone supports it, or cloud storage.

Escalate to human support if:

not applicable.

MS-PRF-005: Apps crashing or not opening

Category: Performance / Apps | Device type: Mobile phone | Doc ID: MS-PRF-005

Symptoms:

- App closes by itself
- App stuck on loading

Common causes:

- Outdated app or OS
- Insufficient storage or RAM
- Corrupt app data
- Server issue

Troubleshooting steps:

1. Update the app from Play Store or App Store.
2. Restart the phone.
3. Clear the app's cache (Android: Settings > Apps > app > Storage).
4. Uninstall and reinstall the app.
5. Check internet connection and whether the service is down.
6. Update the OS.

Escalate to human support if:

many apps crash at once, or only a specific bank or government app fails because of device restrictions.

---

3. Display and Touch

MS-DSP-001: Black or blank screen

Category: Display | Device type: Mobile phone | Doc ID: MS-DSP-001

Symptoms:

- Screen is black but phone vibrates or rings
- Screen does not wake

Common causes:

- Software freeze
- Drained battery
- Display damage
- Loose display connector

Troubleshooting steps:

1. Press the power button and increase brightness if possible.
2. Force restart (see MS-PWR-001).
3. Charge for 30 minutes and retry.
4. Call the phone from another number to check if it rings.
5. Connect to a computer and check if it is recognised.
6. Do not attempt to open the phone.

Escalate to human support if:

the phone shows signs of life but the display stays black after force restart, or there is physical damage.

MS-DSP-002: Touch not responding or ghost touch

Category: Display / Touch | Device type: Mobile phone | Doc ID: MS-DSP-002

Symptoms:

- Screen does not respond or taps randomly
- Part of the screen is dead

Common causes:

- Screen protector or case interfering
- Wet or dirty screen
- Software glitch
- Damaged digitizer

Troubleshooting steps:

1. Clean and dry the screen; remove gloves.
2. Remove the screen protector and test.
3. Restart the phone.
4. Boot in Safe Mode (Android) to rule out an app.
5. Update the OS.
6. Disconnect any charger of unknown quality; ghost touch can happen with poor chargers.

Escalate to human support if:

touch issues continue after a restart and without a protector.

MS-DSP-003: Cracked or broken screen

Category: Display / Damage | Device type: Mobile phone | Doc ID: MS-DSP-003

Symptoms:

- Screen cracked or shattered
- Touch works partially

Common causes:

- Drop or impact

Troubleshooting steps:

1. Stop using the phone if glass is loose; cover cracks with clear tape to avoid cuts.
2. Back up data immediately if the touch still works.
3. Check warranty terms: physical and liquid damage is usually not covered (see MS-POL-001).
4. Offer authorised service for paid screen replacement; share an estimate process per MS-POL-002.
5. Use only authorised repairs to protect warranty and water resistance.

Escalate to human support if:

the customer wants a repair quote or has accidental damage protection; escalate to service.

MS-DSP-004: Flickering screen, lines or colour issues

Category: Display | Device type: Mobile phone | Doc ID: MS-DSP-004

Symptoms:

- Flicker, green or pink lines, discolouration

Common causes:

- Software bug
- Display hardware fault
- Pressure or impact damage
- PWM dimming at low brightness

Troubleshooting steps:

1. Restart the phone and update the OS.
2. Increase brightness and turn off adaptive brightness; check if flicker stops.
3. Check refresh rate setting; switch between standard and high.
4. Take a screenshot; if lines are visible in the screenshot, it is a software issue, otherwise hardware.
5. Boot in Safe Mode (Android).

Escalate to human support if:

lines or colour issues remain in all cases; display replacement may be needed.

MS-DSP-005: Auto-rotate or auto-brightness not working

Category: Display / Settings | Device type: Mobile phone | Doc ID: MS-DSP-005

Symptoms:

- Screen does not rotate
- Brightness does not adjust

Common causes:

- Setting disabled
- Sensor glitch
- Screen protector covering sensor

Troubleshooting steps:

1. Enable Auto-rotate from the quick settings panel and check the app supports rotation.
2. Turn on Adaptive or Auto brightness in Display settings.
3. Remove any film covering the sensor area near the top.
4. Restart the phone and update the OS.
5. Use a sensor test app or built-in diagnostics (dial the manufacturer's test code if available).

Escalate to human support if:

the sensors still fail after a restart and update.

---

4. Network, SIM, Wi-Fi and Bluetooth

MS-NET-001: No mobile signal or 'No service'

Category: Network | Device type: Mobile phone | Doc ID: MS-NET-001

Symptoms:

- No bars, 'No service' or 'Emergency calls only'
- Cannot make or receive calls

Common causes:

- Network outage in the area
- SIM not seated properly
- Airplane mode
- Wrong network mode or APN
- Unpaid or inactive SIM

Troubleshooting steps:

1. Toggle Airplane mode on for 10 seconds, then off.
2. Restart the phone.
3. Check whether other phones with the same operator also have no signal.
4. Remove and reinsert the SIM with the phone off; clean the SIM contacts with a dry cloth.
5. Set network mode to automatic and choose the operator manually in Settings > Mobile network.
6. Test the SIM in another phone.
7. Contact your operator to confirm the SIM is active and not blocked.

Escalate to human support if:

the SIM works in another phone but not in this one, which suggests a hardware or modem problem.

MS-NET-002: Mobile data not working

Category: Network | Device type: Mobile phone | Doc ID: MS-NET-002

Symptoms:

- Data is on but no internet
- Internet works only on Wi-Fi

Common causes:

- Data limit reached
- Incorrect APN
- Roaming off
- Network congestion

Troubleshooting steps:

1. Check that mobile data is on and that the correct SIM is chosen for data (dual SIM phones).
2. Check the remaining data balance with your operator.
3. Toggle Airplane mode and restart.
4. Reset APN settings to default (Settings > Mobile network > Access Point Names).
5. Turn on data roaming if you are travelling.
6. Reset network settings only if the previous steps fail; this removes saved Wi-Fi and Bluetooth pairings.

Escalate to human support if:

mobile data does not work with an active plan and confirmed network coverage.

MS-NET-003: Wi-Fi not connecting or keeps disconnecting

Category: Network | Device type: Mobile phone | Doc ID: MS-NET-003

Symptoms:

- Cannot join Wi-Fi
- Connected without internet
- Frequent drops

Common causes:

- Router problem
- Wrong password
- Wi-Fi saving mode or IP conflict
- Weak signal

Troubleshooting steps:

1. Check if other devices can use the same Wi-Fi.
2. Toggle Wi-Fi off and on; restart the router.
3. Forget the network and reconnect with the correct password.
4. Move closer to the router; use 5 GHz if available.
5. Turn off VPN or private DNS temporarily.
6. Update the phone and reset network settings as a last step.

Escalate to human support if:

Wi-Fi works on other devices but never on this phone after a network reset.

MS-NET-004: Bluetooth not pairing or disconnecting

Category: Network | Device type: Mobile phone | Doc ID: MS-NET-004

Symptoms:

- Device not found
- Pairing fails
- Audio cuts out

Common causes:

- Device not in pairing mode
- Old pairing data
- Interference
- Software bug

Troubleshooting steps:

1. Turn Bluetooth off and on.
2. Remove the paired device from the list and pair it again.
3. Put the accessory in pairing mode and keep it within 1 metre.
4. Make sure the accessory is not connected to another phone.
5. Restart both devices.
6. Update the phone's software and the accessory's firmware.

Escalate to human support if:

Bluetooth will not turn on or the accessory works on other phones only.

MS-NET-005: Mobile hotspot not working

Category: Network | Device type: Mobile phone | Doc ID: MS-NET-005

Symptoms:

- Others cannot connect to hotspot
- No internet via hotspot

Common causes:

- Plan does not allow tethering
- Battery saver enabled
- Weak mobile data

Troubleshooting steps:

1. Check that mobile data works on the phone itself.
2. Turn hotspot on in Settings > Network > Hotspot and tethering (iPhone: Personal Hotspot).
3. Disable battery saver and Wi-Fi power saving.
4. Set the hotspot band to 2.4 GHz for better compatibility.
5. Check the password entered on the other device.
6. Confirm with your operator that hotspot is supported on your plan.

Escalate to human support if:

the hotspot is on but data still does not reach connected devices.

MS-NET-006: SIM card not detected or 'Invalid SIM'

Category: Network / SIM | Device type: Mobile phone | Doc ID: MS-NET-006

Symptoms:

- 'No SIM card' or 'Invalid SIM'
- SIM disappears randomly

Common causes:

- Misaligned or damaged SIM
- Dirty contacts
- Damaged SIM tray
- Operator lock

Troubleshooting steps:

1. Turn off the phone and use the SIM tool to remove the tray.
2. Check that the SIM is correct size and clean; reinsert and push the tray fully.
3. Test the SIM in another phone and another SIM in this phone.
4. Restart the phone.
5. If the SIM is old or damaged, ask the operator for a replacement SIM.

Escalate to human support if:

a different working SIM is also not detected; the SIM reader may be faulty.

MS-NET-007: Calls dropping, not connecting or cannot hear

Category: Network / Calls | Device type: Mobile phone | Doc ID: MS-NET-007

Symptoms:

- Calls disconnect
- One-way audio
- Cannot receive incoming calls

Common causes:

- Weak signal
- VoLTE or VoWiFi setting
- Call forwarding or DND enabled
- Blocked number
- Network issue

Troubleshooting steps:

1. Check signal strength and move to an open area.
2. Make sure Do Not Disturb and call forwarding are off.
3. Turn VoLTE or Wi-Fi calling on or off in Mobile network settings and test again.
4. Check that the caller is not on a block list.
5. Restart the phone and toggle Airplane mode.
6. Test with another SIM.

Escalate to human support if:

the issue follows the phone to multiple locations and SIMs.

---

5. Audio and Camera

MS-AUD-001: No sound, low volume or crackling speaker

Category: Audio | Device type: Mobile phone | Doc ID: MS-AUD-001

Symptoms:

- No ringtone or media sound
- Speaker crackles
- Cannot hear during calls

Common causes:

- Silent mode or DND
- Dust in speaker
- Bluetooth connected
- Software issue
- Water damage

Troubleshooting steps:

1. Check volume, silent mode and Do Not Disturb.
2. Disconnect Bluetooth devices.
3. Clean speaker grills gently with a soft dry brush.
4. Restart the phone.
5. Test with headphones; if sound works there, the speaker may be faulty.
6. Update the OS.

Escalate to human support if:

sound is missing in speaker and headphones, or after water exposure.

MS-AUD-002: Microphone not working

Category: Audio | Device type: Mobile phone | Doc ID: MS-AUD-002

Symptoms:

- People cannot hear you on calls
- Voice notes are silent

Common causes:

- App permission off
- Blocked mic hole
- Case blocking
- Noise cancellation bug

Troubleshooting steps:

1. Check app microphone permission in Settings > Privacy or Permissions.
2. Remove the case and clean the mic hole at the bottom.
3. Test with the voice recorder and with a wired or Bluetooth headset.
4. Restart the phone.
5. Check for OS updates.

Escalate to human support if:

the mic fails in all apps and with a headset.

MS-AUD-003: Camera blurry, black screen or app not opening

Category: Camera | Device type: Mobile phone | Doc ID: MS-AUD-003

Symptoms:

- Camera app crashes
- Photos blurry
- Black viewfinder

Common causes:

- Dirty lens
- Camera app glitch
- Low storage
- Overheating
- Hardware fault

Troubleshooting steps:

1. Clean the lens with a soft microfibre cloth; remove protective films.
2. Close and reopen the camera app and restart the phone.
3. Clear the camera app cache (Android) and free up storage.
4. Make sure no other app is using the camera.
5. Update the OS and camera app.
6. Test front and rear cameras separately.

Escalate to human support if:

camera is black or shaky in all apps; this suggests a hardware fault.

---

6. Physical Damage and Hardware

MS-HW-001: Water or liquid damage

Category: Hardware / Damage | Device type: Mobile phone | Doc ID: MS-HW-001

Symptoms:

- Phone was dropped in water
- Liquid spilled on the phone
- Moisture warning in the charging port

Common causes:

- Liquid ingress; water resistance reduces over time and does not cover hot, soapy or salt water

Troubleshooting steps:

1. Switch the phone off immediately and do not charge it.
2. Remove the case and SIM tray.
3. Wipe the outside with a soft cloth and let it dry in a well-ventilated place for at least 24 hours.
4. Do not use rice, hair dryers, ovens or compressed air.
5. Do not turn the phone on until completely dry.
6. Take it to authorised service even if it works, as corrosion can appear later.

Escalate to human support if:

always escalate; liquid damage is typically not covered under standard warranty (see MS-POL-001).

MS-HW-002: Buttons not working or stuck

Category: Hardware | Device type: Mobile phone | Doc ID: MS-HW-002

Symptoms:

- Power or volume buttons do not respond
- Button feels stuck

Common causes:

- Case pressing buttons
- Dirt
- Worn or damaged button
- Software issue

Troubleshooting steps:

1. Remove the case.
2. Clean around buttons gently with a dry soft brush.
3. Use on-screen alternatives (screenshot, accessibility menu, power menu) as temporary help.
4. Restart the phone.
5. Check for software updates.

Escalate to human support if:

buttons remain unresponsive; hardware repair is needed.

MS-HW-003: Fingerprint or face unlock not working

Category: Hardware / Security | Device type: Mobile phone | Doc ID: MS-HW-003

Symptoms:

- Fingerprint not recognised
- Face unlock fails

Common causes:

- Wet or dirty finger or sensor
- Screen protector
- Software bug
- Changed appearance or lighting

Troubleshooting steps:

1. Clean the sensor and your finger.
2. Remove or replace the screen protector with one compatible with the fingerprint sensor.
3. Delete and re-register fingerprints; for face unlock, re-scan in good lighting.
4. Restart the phone and update the OS.
5. Use PIN or password as a fallback.

Escalate to human support if:

the sensor is not recognised at all in settings.

---

7. Software and Accounts

MS-OS-001: Software update stuck or failing

Category: Software | Device type: Mobile phone | Doc ID: MS-OS-001

Symptoms:

- Update does not download
- Stuck during installation
- Update error message

Common causes:

- Low storage
- Weak internet
- Low battery
- Server load

Troubleshooting steps:

1. Charge to at least 50 percent and keep the phone plugged in.
2. Free up at least 5 GB of storage.
3. Connect to stable Wi-Fi.
4. Restart the phone and retry.
5. Wait: large updates can take 30 to 60 minutes.
6. iPhone: update using a computer via Finder or iTunes if the over-the-air update fails.

Escalate to human support if:

the phone is stuck on the update screen for over 1 hour.

MS-OS-002: Forgot PIN, pattern or password

Category: Software / Security | Device type: Mobile phone | Doc ID: MS-OS-002

Symptoms:

- Phone is locked
- Too many attempts

Common causes:

- Forgotten screen lock

Troubleshooting steps:

1. Wait for the timeout and try again carefully.
2. Android: use 'Forgot pattern' or Find My Device with your Google account to reset if available.
3. iPhone: use Erase iPhone on the lock screen if it appears, or erase via a computer in recovery mode.
4. Warn the customer that resetting erases local data; cloud backups can restore it.
5. Never ask for the PIN or password; do not suggest bypass tools or unauthorised unlocking.
6. For company-managed phones, contact the company IT department.

Escalate to human support if:

the customer cannot prove ownership or the phone has an account lock (see MS-OS-004).

MS-OS-003: Factory reset

Category: Software | Device type: Mobile phone | Doc ID: MS-OS-003

Symptoms:

- How do I reset my phone?
- Phone must be sold or repaired

Common causes:

- Factory reset erases all data. Back up first.
- Remove Google or Apple account before selling or sending for repair.

Troubleshooting steps:

1. Back up photos, contacts, chats and files.
2. Sign out of Google or Apple ID and turn off Find My Device or Find My iPhone.
3. Android: Settings > System > Reset options > Erase all data. iPhone: Settings > General > Transfer or Reset iPhone > Erase All Content and Settings.
4. Confirm with your PIN or password.
5. Wait for the phone to restart and show the welcome screen.
6. Do not reset a phone that you think is stolen; follow MS-SEC-002.

Escalate to human support if:

the reset fails or the phone asks for an account that the customer does not remember (see MS-OS-004).

MS-OS-004: Google or Apple account lock (FRP or Activation Lock)

Category: Software / Accounts | Device type: Mobile phone | Doc ID: MS-OS-004

Symptoms:

- Phone asks for the previous account after reset
- Cannot activate phone

Common causes:

- Factory Reset Protection (Android) and Activation Lock (iPhone) are security features that stop others from using a lost or stolen phone.

Troubleshooting steps:

1. Ask the customer to sign in with the Google or Apple account previously used on the phone.
2. Use account recovery on the official website to reset the account password.
3. Wait 24 to 72 hours after a password reset because some phones limit logins temporarily on Android.
4. For second-hand phones, contact the previous owner to remove the account.
5. Proof of purchase may be requested for official unlock; the assistant must not suggest bypass methods.

Escalate to human support if:

the customer cannot recover the account; escalate with proof of purchase details.

MS-OS-005: Cannot install or update apps

Category: Software / Apps | Device type: Mobile phone | Doc ID: MS-OS-005

Symptoms:

- Play Store or App Store errors
- Download pending

Common causes:

- Low storage
- Date and time wrong
- Account issue
- Network problem

Troubleshooting steps:

1. Check storage and internet connection.
2. Set date and time to automatic.
3. Clear cache of Play Store and Play Services (Android) or sign out and in to the App Store (iPhone).
4. Restart the phone.
5. Check the account's payment profile or country settings if the app is not available.
6. Update the OS.

Escalate to human support if:

errors continue after all steps.

MS-OS-006: Notifications not coming

Category: Software / Apps | Device type: Mobile phone | Doc ID: MS-OS-006

Symptoms:

- No alerts from apps
- Delayed notifications

Common causes:

- Do Not Disturb
- Battery optimisation
- Notifications turned off
- Background data restricted

Troubleshooting steps:

1. Check Settings > Notifications for the app and ensure it is allowed.
2. Turn off Do Not Disturb and Focus modes.
3. Android: set the app's battery usage to Unrestricted or Not optimised.
4. Allow background data for the app.
5. Make sure the phone has internet access and the app is updated.
6. Reinstall the app if needed.

Escalate to human support if:

not applicable.

---

8. Setup and How-To

MS-SET-001: First-time setup of an Android phone

Category: Setup | Device type: Mobile phone | Doc ID: MS-SET-001

Customer usually asks:

- How do I set up my new phone?

Key points:

- Keep the phone charged above 30 percent.
- Have Wi-Fi and Google account details ready.

Steps:

1. Insert the SIM and press the power button.
2. Choose language and region and connect to Wi-Fi.
3. Sign in with your Google account or create a new one.
4. Choose to copy apps and data from the old phone if offered.
5. Set screen lock and fingerprint or face unlock.
6. Install updates after setup and enable backup in Settings > Google > Backup.

Escalate to human support if:

setup stalls or the phone asks for an account lock (see MS-OS-004).

MS-SET-002: First-time setup of an iPhone

Category: Setup | Device type: Mobile phone | Doc ID: MS-SET-002

Customer usually asks:

- How do I set up my new iPhone?

Key points:

- Apple ID is needed for App Store, iCloud and Find My.
- Quick Start lets you move data from another iPhone.

Steps:

1. Turn on the iPhone and follow the on-screen language and region prompts.
2. Place it next to the old iPhone for Quick Start, or choose to set up manually.
3. Connect to Wi-Fi and sign in with your Apple ID.
4. Restore from iCloud or computer backup, or choose to set up as new.
5. Set up Face ID or Touch ID and a passcode.
6. Install updates in Settings > General > Software Update.

Escalate to human support if:

activation errors continue; Apple handles Apple ID issues.

MS-SET-003: Transfer data from an old phone to a new phone

Category: Setup / Data | Device type: Mobile phone | Doc ID: MS-SET-003

Customer usually asks:

- How do I move my contacts, photos and chats?

Key points:

- Back up before transferring.
- Transfers between Android and iPhone are possible with official apps.

Steps:

1. Android to Android: use Google's setup transfer or the brand's phone clone app during first setup.
2. iPhone to iPhone: use Quick Start or iCloud backup.
3. Android to iPhone: use the 'Move to iOS' app during iPhone setup.
4. iPhone to Android: use the manufacturer's switch app or Google's transfer tool.
5. WhatsApp: use the in-app Chat Transfer or Chat backup option on both phones.
6. Keep the old phone until you confirm everything has moved.

Escalate to human support if:

WhatsApp or banking apps fail to transfer; guide to the app's official help.

MS-SET-004: Back up your phone

Category: Setup / Data | Device type: Mobile phone | Doc ID: MS-SET-004

Customer usually asks:

- How do I back up my data?

Key points:

- Backups protect against loss, theft and damage.

Steps:

1. Android: Settings > Google > Backup, turn on Backup by Google One; use Google Photos for photos.
2. iPhone: Settings > [your name] > iCloud > iCloud Backup > Back Up Now.
3. Or connect to a computer and copy photos and files.
4. Back up WhatsApp separately in its own settings.
5. Check the backup date after finishing.

Escalate to human support if:

not applicable.

MS-SET-005: Screenshot and screen recording

Category: How-To | Device type: Mobile phone | Doc ID: MS-SET-005

Customer usually asks:

- How do I take a screenshot?

Key points:

- Methods differ by brand.

Steps:

1. Most Android: press Power + Volume Down together; some phones also support three-finger swipe or the quick-settings tile.
2. iPhone with Face ID: press Side button + Volume Up. iPhone with Home button: press Home + Side button.
3. Screen recording: add the Screen Recorder or Screen Recording tile from the control centre or quick settings.

Escalate to human support if:

not applicable.

MS-SET-006: Set up an eSIM

Category: Setup / SIM | Device type: Mobile phone | Doc ID: MS-SET-006

Customer usually asks:

- How do I activate eSIM?

Key points:

- The phone must support eSIM and be network-unlocked.
- The operator provides a QR code or app activation.

Steps:

1. Connect to Wi-Fi.
2. Android: Settings > Network > SIMs > Add eSIM. iPhone: Settings > Mobile Service > Add eSIM.
3. Scan the QR code from your operator or follow the operator app instructions.
4. Label the line and choose which line to use for calls, texts and data.
5. Restart if the network does not appear.

Escalate to human support if:

activation fails; the operator controls eSIM provisioning.

MS-SET-007: Turn on Find My Phone

Category: Setup / Security | Device type: Mobile phone | Doc ID: MS-SET-007

Customer usually asks:

- How do I locate a lost phone?

Key points:

- Must be turned on before the phone is lost.

Steps:

1. Android: Settings > Google > Find My Device; ensure it is enabled and Location is on.
2. iPhone: Settings > [your name] > Find My > Find My iPhone, enable Find My network and Send Last Location.
3. Test it by signing in on another device or on the Find My Device or iCloud website.

Escalate to human support if:

not applicable.

MS-SET-008: Use dual SIM

Category: Setup / SIM | Device type: Mobile phone | Doc ID: MS-SET-008

Customer usually asks:

- How do I choose which SIM to use?

Key points:

- Phones may support two physical SIMs, or one physical SIM and an eSIM.

Steps:

1. Open SIM or Mobile network settings.
2. Choose the SIM for calls, messages and mobile data.
3. Rename the SIMs for easy identification.
4. Enable Wi-Fi calling and VoLTE separately for each SIM if needed.

Escalate to human support if:

not applicable.

---

9. Security and Privacy

MS-SEC-001: Suspected malware or unwanted apps

Category: Security | Device type: Mobile phone | Doc ID: MS-SEC-001

Symptoms:

- Pop-up ads
- Unknown apps
- Battery drain and high data use
- Browser redirects

Common causes:

- Apps from unknown sources
- Malicious links
- Fake apps

Troubleshooting steps:

1. Install apps only from Play Store or App Store.
2. Check Settings > Apps for unknown apps and uninstall them.
3. Android: check Device admin apps and disable unknown ones; run Play Protect scan.
4. Remove unknown browser notifications permissions.
5. Update the OS and apps.
6. Change passwords of important accounts from a different, clean device.
7. Back up and factory reset only if the problem persists.

Escalate to human support if:

money was stolen or banking apps were affected.

MS-SEC-002: Lost or stolen phone

Category: Security | Device type: Mobile phone | Doc ID: MS-SEC-002

Symptoms:

- My phone is lost or stolen

Common causes:

- Theft or misplacement

Troubleshooting steps:

1. Call your number or use Find My Device or Find My to locate, lock or erase the phone.
2. Report the SIM loss to the operator to block the SIM and request a duplicate.
3. Change passwords of Google, Apple, banking, email and social accounts.
4. Find the IMEI number on the phone box or invoice, or in the device list of your Google or Apple account.
5. File a police report and keep the copy.
6. In India, report the lost phone on the Sanchar Saathi portal (CEIR) to block it using the IMEI.
7. Contact your bank to block UPI and cards if needed.

Escalate to human support if:

always escalate to a human agent.

MS-SEC-003: Scam calls, OTP fraud and phishing

Category: Security | Device type: Mobile phone | Doc ID: MS-SEC-003

Symptoms:

- I got a call asking for OTP
- Suspicious SMS or link
- Money debited unexpectedly

Common causes:

- Impersonation of banks, couriers, KYC updates or customer care

Troubleshooting steps:

1. Never share OTP, PIN, CVV or card details with anyone; real companies do not ask for them.
2. Do not click links in unexpected SMS or WhatsApp messages.
3. Do not install screen-sharing or remote apps for strangers.
4. If money was lost, call your bank immediately and report on the national cyber crime helpline 1930 or the cybercrime.gov.in portal (India).
5. Block and report the number in the phone app.
6. Enable spam protection in the phone app.

Escalate to human support if:

the customer reports financial loss; escalate and advise contacting the bank and cyber crime helpline immediately.

MS-SEC-004: Secure your accounts and phone

Category: Security | Device type: Mobile phone | Doc ID: MS-SEC-004

Symptoms:

- How can I keep my phone safe?

Common causes:

- Good habits prevent most security problems.

Troubleshooting steps:

1. Use a strong screen lock (6-digit PIN or longer, fingerprint or face).
2. Turn on two-step verification for Google, Apple, email and banking.
3. Keep automatic updates on.
4. Review app permissions and remove unneeded ones.
5. Avoid public Wi-Fi for banking, or use a trusted VPN.
6. Keep Find My Device or Find My turned on.

Escalate to human support if:

not applicable.

---

10. Accessories

MS-ACC-001: Choosing a charger and cable

Category: Accessories | Device type: Mobile phone | Doc ID: MS-ACC-001

Symptoms:

- Which charger should I buy?
- Can I use any fast charger?

Common causes:

- Use a charger that supports your phone's charging standard (USB Power Delivery, PPS or a brand-specific fast charge).
- A higher-wattage charger is safe if certified, because the phone draws only what it supports.
- Cable quality matters for speed.

Troubleshooting steps:

1. Check your phone's maximum charging wattage in the specification sheet.
2. Buy a certified charger with equal or higher wattage.
3. Use a cable rated for that wattage; cheap cables can slow charging or heat up.
4. Avoid unbranded chargers and cables.

Escalate to human support if:

a non-original charger damaged the phone.

MS-ACC-002: Cases and screen protectors

Category: Accessories | Device type: Mobile phone | Doc ID: MS-ACC-002

Symptoms:

- Do I need a case or screen guard?

Common causes:

- Cases protect from drops; tempered glass protects the screen from scratches.
- Fit matters: wrong cases can cover cameras and sensors.

Troubleshooting steps:

1. Choose a case made for your exact model with raised edges around the screen and camera.
2. Choose tempered glass compatible with your fingerprint sensor type (ultrasonic or optical).
3. Ask for professional application or use the alignment tray; clean the screen first.
4. Replace cracked protectors to avoid cuts and touch issues.

Escalate to human support if:

not applicable.

MS-ACC-003: Wireless charging and power banks

Category: Accessories | Device type: Mobile phone | Doc ID: MS-ACC-003

Symptoms:

- Does my phone support wireless charging?
- Which power bank should I buy?

Common causes:

- Wireless charging is slower and warmer than wired charging.
- Power banks must offer enough output wattage and a suitable capacity (mAh).

Troubleshooting steps:

1. Check the phone specs for Qi or MagSafe support.
2. Remove thick cases or metal plates before wireless charging.
3. For power banks, choose a trusted brand with PD output equal to or above the phone's fast charging wattage.
4. Typical phone battery is 4000 to 5500 mAh; a 10000 mAh power bank gives about 1.5 to 2 full charges after conversion losses.
5. Do not leave phones charging under pillows.

Escalate to human support if:

not applicable.

---

11. Choosing a Phone (Pre-Sales)

MS-BUY-001: Which phone should I buy?

Category: Buying advice | Device type: Mobile phone | Doc ID: MS-BUY-001

Symptoms:

- Which phone is best for me?

Common causes:

- Ask about budget, preferred operating system, camera needs, gaming use and battery life before recommending.
- Confirm current prices and stock on [PRODUCT CATALOG URL].

Troubleshooting steps:

1. Everyday use and calls: mid-range Android or an older iPhone with 4 to 6 GB RAM and 128 GB storage.
2. Camera focused: look at sensor quality, stabilisation and software updates rather than megapixels only.
3. Gaming: a powerful processor, 8 GB RAM or more, high-refresh display and good cooling.
4. Battery life: 5000 mAh or more with efficient processor and fast charging.
5. Long-term use: choose a brand that promises many years of software and security updates.
6. Check 5G band support for your operator.

Escalate to human support if:

the customer asks for price, stock, offers or EMI details; share the catalog link or transfer to sales.

MS-BUY-002: Understanding phone specifications

Category: Buying advice | Device type: Mobile phone | Doc ID: MS-BUY-002

Symptoms:

- What does RAM, storage, refresh rate and IP rating mean?

Common causes:

- Specs affect performance, battery life and price.

Troubleshooting steps:

1. RAM: memory for running apps; 6 to 8 GB is comfortable for most people.
2. Storage: space for apps and media; 128 GB is a good starting point.
3. Processor (chipset): affects speed and efficiency.
4. Display: AMOLED offers better contrast; refresh rate of 90 or 120 Hz makes scrolling smoother.
5. Battery (mAh) and charging speed (W): higher mAh lasts longer; higher W charges faster.
6. IP rating (for example IP68): dust and water resistance under test conditions, not a guarantee against all liquids.
7. Software updates: check the number of years of OS and security updates promised.

Escalate to human support if:

not applicable.

---

12. Warranty, Repair, Returns and Orders

Replace all placeholders with your company's actual policy before indexing.

MS-POL-001: Warranty coverage

Category: Policy | Device type: Mobile phone | Doc ID: MS-POL-001

- Standard warranty: [12 months] on the phone and [6 months] on accessories in the box, from the date of purchase.
- Covered: manufacturing defects in display, battery (if capacity falls under [x percent] within warranty), motherboard, cameras, speakers, microphones and buttons under normal use.
- Not covered: physical damage, cracked screens, liquid damage, unauthorised repairs, software modifications or rooting, lost or stolen devices, cosmetic wear.
- Proof of purchase and IMEI number are required.
- Accidental damage or extended warranty plans: [details].

MS-POL-002: Repair request process

Category: Policy | Device type: Mobile phone | Doc ID: MS-POL-002

- Collect customer name, order number, phone model, IMEI (dial *#06# or check the box), and issue description.
- Create a service ticket at [SUPPORT PORTAL URL] or call [PHONE NUMBER].
- Remove screen lock and Find My Device or Find My iPhone before submitting the phone for repair if requested; back up data first because repairs may erase it.
- Typical repair time: [5 to 10 business days]. Service centre locations: [details].
- Support hours: [e.g., Mon to Sat, 9 AM to 6 PM IST]. Email: [SUPPORT EMAIL].

MS-POL-003: Returns and refunds

Category: Policy | Device type: Mobile phone | Doc ID: MS-POL-003

- Return window: [7 / 10 days] for unused or defective phones in original condition.
- Dead-on-arrival or wrongly delivered phones: report within [48 hours] with unboxing video and photos.
- Phone must include the box, charger, cable, SIM tool and all accessories, invoice and IMEI must match.
- Refund goes to the original payment method within [5 to 7 business days] after inspection.
- Phones with account locks, physical damage or missing accessories may not be accepted.

MS-POL-004: Orders, delivery and tracking

Category: Policy | Device type: Mobile phone | Doc ID: MS-POL-004

- Tracking details are sent by email or SMS after dispatch; track at [ORDER TRACKING URL].
- Typical delivery time: [3 to 7 business days].
- Cancellation is available before dispatch from the Orders page; after dispatch, refuse delivery or request a return per MS-POL-003.
- Invoice and GST bill: download from [ACCOUNT URL] or contact support.
- Always check the sealed box and record an unboxing video for damage or missing item claims.

13. Frequently Asked Questions

MS-FAQ-001: How do I find my phone's IMEI number?

Dial *#06# on the phone to display the IMEI. It is also on the box, the invoice, the SIM tray or in Settings > About phone.

MS-FAQ-002: Should I charge my phone overnight?

Modern phones stop charging at 100 percent and manage heat, so it is generally safe. Use a certified charger and avoid covering the phone. Many phones also offer an optimised or limited charging option.

MS-FAQ-003: Is it okay to use the phone while charging?

Light use is fine. Heavy use such as gaming or video recording while charging generates heat and can shorten battery life.

MS-FAQ-004: How long will my battery last?

Most phone batteries keep good capacity for around two to three years of daily use. Battery wear is normal and is not a defect.

MS-FAQ-005: Can I use a charger from another brand?

Yes, if it is certified and supports the right charging standard. Use quality cables and avoid cheap, unbranded chargers.

MS-FAQ-006: What should I do before giving my phone for repair?

Back up your data, sign out of your Google or Apple account, turn off Find My Device, remove the SIM and memory card and note the IMEI.

MS-FAQ-007: Will a factory reset remove viruses?

In most cases yes. Back up your data first and avoid restoring suspicious apps.

MS-FAQ-008: How do I free up space quickly?

Back up photos to the cloud, clear app cache, delete old chat media and uninstall unused apps.

MS-FAQ-009: Can I get water damage repaired under warranty?

Normally no. Water resistance is not permanent and liquid damage is usually excluded from warranty. See MS-POL-001.

MS-FAQ-010: Is public charging safe?

Public USB ports can be risky. Use your own charger and a wall socket, or a power bank, and choose 'charge only' if prompted for data access.

14. Glossary

MS-REF-001: Mobile phone terms explained

Category: Reference | Doc ID: MS-REF-001

Term	Meaning
IMEI	Unique 15-digit number that identifies a phone; used for blocking and repairs.
APN	Access Point Name: settings that let the phone use mobile data.
eSIM	A digital SIM built into the phone instead of a physical card.
VoLTE	Voice over LTE: HD voice calls over 4G or 5G.
VoWiFi	Wi-Fi calling: calls over Wi-Fi when mobile signal is weak.
FRP	Factory Reset Protection on Android: requires the previous Google account after a reset.
Activation Lock	Apple's feature that requires the previous Apple ID after an erase.
Safe Mode	Android mode that runs without third-party apps for troubleshooting.
Cache	Temporary files an app stores to load faster.
Tethering	Sharing the phone's mobile data with another device (hotspot).
mAh	Battery capacity unit; larger means a bigger battery.
PD / PPS	Power Delivery and Programmable Power Supply: fast charging standards over USB-C.
IP rating	Standard that measures dust and water resistance.

15. Escalation and Assistant Rules

MS-ESC-001: When to hand over to a human agent

Category: Assistant policy | Doc ID: MS-ESC-001

- Any safety risk: swollen battery, burning smell, smoke, extreme heat, liquid damage while powered on. Tell the customer to switch off and stop charging if it is safe to do so.
- Lost or stolen phones and suspected fraud, including OTP scams and unauthorised transactions.
- Account locks (FRP, Activation Lock) where the customer cannot recover their account.
- Warranty disputes, refunds, payment issues, legal questions and repair quotes.
- Data recovery requests, or devices that do not respond after force restart and charging.
- The customer is frustrated, has already tried the steps, or asks for a human.
- The question is not covered in this knowledge base: do not guess; say so and offer escalation.

MS-GUIDE-001: Assistant response guidelines

Category: Assistant policy | Doc ID: MS-GUIDE-001

- Ask for brand, model, Android or iOS version and what changed recently before giving menu paths.
- Give one or two steps at a time and confirm the result before continuing.
- Warn before any step that can erase data (factory reset, restore, recovery mode) and recommend a backup first.
- Never ask for or store PINs, passwords, OTPs, card numbers or Apple ID or Google passwords.
- Never suggest bypassing account locks, rooting, jailbreaking or unlocking tools.
- Do not promise prices, stock, delivery dates, refunds or warranty acceptance beyond what MS-POL entries state.
- Do not advise opening the phone or replacing the battery at home; recommend authorised service.
- Use laptop knowledge base entries (LS-) only when the customer's device is a laptop, and MS- entries only for phones.