Setting "SaveGoals=yes" means the expression in each goal is written to the dataset.

freq	Gamma_in_Goal		
	optIter=0	optIter=4	
2.000 GHz	0.456	5.061E-5	

Setting "SaveSolns=yes" means results are written to the dataset.

optlter	OPTIM.TLin1.E	OPTIM.TLin2.E
0 4	45.000 72.506	45.000 44.745

Setting "SaveOptimVars=yes" means values for TLin1.E and TLin2.E are written to the dataset for each iteration.

OPTSOLNVALS.TLin1.E	OPTSOLNVALS.TLin2.E
72.506	44.745

m1 freq=2.000 GHz S(1,1)=5.061E-5 / -109.574 optlter=4 impedance = Z0 * (1.000 - j9.538E-5)

