

Chapter 1: Refrigerator Overview

This manual covers the operation, maintenance, and troubleshooting of your kitchen refrigerator, model KF-2200. The refrigerator uses a dual-compressor system to independently cool the fresh food and freezer compartments.

The recommended temperature setting for the fresh food compartment is between 37F and 40F (3C to 4C). The freezer compartment should be set to 0F (-18C) for optimal food preservation.

Allow at least 2 inches of clearance behind the unit and 1 inch on each side to ensure proper airflow around the condenser coils.

Chapter 2: Refrigerator Troubleshooting

If the refrigerator is not cooling properly, first check that the condenser coils are free of dust and debris. Clean the coils every 6 months using a vacuum attachment.

If the unit is making unusual noises, check that it is level on the floor. Use the adjustable feet at the base to level the unit side to side and front to back.

If frost builds up excessively in the freezer, check the door seal (gasket) for gaps or tears. A damaged gasket allows warm, humid air to enter and should be replaced.

Chapter 3: Oven Overview

Your kitchen oven, model KO-1500, is a dual-fuel range with a gas cooktop and an electric convection oven. The convection fan circulates hot air for even baking.

Before first use, run the oven empty at 400F for one hour to burn off any manufacturing residue. Ensure the kitchen is well ventilated during this process.

The self-cleaning cycle heats the oven interior to approximately 900F to burn off food residue into ash, which can then be wiped away once the cycle completes and the oven has cooled.

Chapter 4: Oven Troubleshooting

If the oven does not heat, check that the igniter (for gas models) is glowing orange when the oven is turned on. A weak or non-glowing igniter usually needs replacement.

If the oven temperature seems inaccurate, use an oven thermometer to verify actual temperature versus the display, and recalibrate using the offset setting in the control menu if the difference exceeds 25F.

Error code F3 indicates an oven temperature sensor fault. Disconnect power for 5 minutes and reconnect; if the error persists, the sensor requires replacement.

Chapter 5: Dishwasher Overview

Your dishwasher, model KD-800, uses a three-stage filtration system and a sanitizing rinse cycle that raises water temperature to 155F to kill bacteria.

Always scrape large food particles from dishes before loading, but pre-rinsing is not necessary. Load sharp items pointing downward in the utensil basket.

Use only detergent formulated for dishwashers; regular dish soap will cause excessive foaming and can damage the pump.

Chapter 6: Dishwasher Troubleshooting

If dishes come out with a cloudy film, this is often caused by hard water mineral deposits. Run a cycle with a dishwasher-safe descaling agent and consider a rinse aid dispenser refill.

If the dishwasher will not drain, check the drain hose for kinks and clean the filter at the bottom of the tub, which can become clogged with food debris.

If the dishwasher is unusually loud, inspect the spray arms for looseness and verify no utensils have fallen and are obstructing the arm rotation.