

# Chapter 1: Washing Machine Overview

This manual covers the LW-500 front-load washing machine. The unit supports load sizes up to 18 lbs and includes cycles for normal, delicates, heavy duty, and sanitize with an internal water heater reaching 150F.

Always use high-efficiency (HE) detergent in a front-load washer. Standard detergent produces excess suds that can cause drainage errors and residue buildup.

Leave the door and detergent drawer open between cycles to allow the drum to dry and prevent mold or mildew odor from developing.

## Chapter 2: Washing Machine Troubleshooting

Error code E1 indicates a water supply issue. Check that both the hot and cold water supply valves behind the unit are fully open and that the inlet hoses are not kinked.

If the washer vibrates excessively during the spin cycle, verify that the shipping bolts were removed during installation and that the unit is level using the adjustable front feet.

If clothes come out with detergent residue, reduce the amount of detergent used and ensure you are not overloading the drum beyond the rated capacity.

## Chapter 3: Washing Machine Maintenance

Clean the rubber door gasket monthly with a damp cloth to remove trapped lint and moisture, which are the most common causes of musty odors in front-load washers.

Run the manufacturer-recommended tub-clean cycle once a month using a washing machine cleaner tablet to remove detergent and mineral buildup from internal components.

Check and clean the drain pump filter, located behind the small panel at the bottom front of the unit, every 3 months to prevent drainage problems.

## Chapter 4: Dryer Overview

This manual covers the LD-500 electric dryer, a companion unit to the LW-500 washer. The dryer has a rated capacity of 18 lbs and includes moisture-sensing auto-dry cycles.

The dryer must be vented to the outside using rigid or semi-rigid metal duct; flexible plastic or foil duct is not recommended due to increased fire risk from lint accumulation.

Clean the lint filter before every load. A clogged lint filter is the leading cause of reduced drying performance and increased drying times.

## Chapter 5: Dryer Troubleshooting

If the dryer runs but does not heat, the most common causes are a blown thermal fuse, a clogged exhaust vent restricting airflow, or a failed heating element.

Start by cleaning the lint trap and inspecting the exhaust vent for lint buildup or blockage along its full length, including the outside vent hood.

If the vent is clear, the thermal fuse should be tested for continuity with a multimeter; a blown fuse must be replaced before the dryer will heat again, and usually indicates the vent was restricted at some point.

## **Chapter 6: Dryer Maintenance and Safety**

Have the full exhaust duct professionally cleaned once a year, especially for long duct runs, to reduce lint accumulation and fire risk.

Never operate the dryer without the lint filter in place, and never dry items that have been in contact with flammable substances such as cooking oil or cleaning solvents.

If the dryer shuts off mid-cycle repeatedly, this may indicate the thermal fuse is tripping due to restricted airflow rather than a fuse defect alone; inspect the full vent path before replacing parts.